

**SAFETY ALERT** FOR YOUR SAFETY, READ ALL INSTRUCTIONS BEFORE INSTALLATION AND OPERATION.**NOTICE:** Products are not to be used nor are warranted in aerospace, nuclear, medical patient connect, or lifesafety applications. This manual is subject to change without prior notice.**Safety Instructions** **WARNING – Avoid Possible Injury or Death****WARNING:** Never work on the power supply when power is applied. Electric shock and arc risks can cause death, severe personal injury or substantial property damage. Power source must be off and properly secured before any installation, maintenance or modification work is completed. Keep away from fire and water. Before installing unit, thoroughly read these instructions.

1. As a reminder, these products are not to be installed in nuclear or medical (patient connect) applications. Units are only to be installed by professionals. Only professionally trained personnel may open the power supply. If you have any questions concerning the installation or operation of this equipment, please call the number located at the front of this document.
2. The units meet the safety requirements of UL508, UL60950-1, IEC/EN60950. They are approved in accordance with EN60950, UL508, (TUV) EN55022, EN55024, CE MARKING and meet the requirements EMC and the Low Voltage Directive.
3. These units must always be installed with any national, county or city regulations that apply. Connections to mains supply must be in compliance with national and city regulations. Power supply and main cables must be sufficiently fused in accordance with local codes. Follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary, and it is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes. Equipment damage or serious injury to personnel can result by not following all applicable standards and codes. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.
4. Sufficient temperature and cooling and space clearances must be ensured as indicated: Operation requires no external cooling but requires minimum clearances on top, bottom, and sides of units. Refer to installation Cooling and Airflow Requirements below
5. Avoid potential danger of contact with case by ensuring all strands of stranded wire use (if applicable) are fastened in the terminal blocks.
6. **SAFETY ALERT** Hazardous voltages and components storing a substantial amount of energy are present in this unit during normal operating conditions. Improper handling may result in electric shock or serious burns.
7. **WARNING** Do not open the power supply until at least 5 minutes after it has been disconnected from the mains on all poles.
8. Do not introduce any objects into the power supply. The **output voltage adjustment** potentiometer may only be actuated using an insulated screwdriver.


**Installation Instructions** **WARNING – Avoid Personal Injury or Product Damage.**

1. **Read and follow all instructions before installation** as indicated in this manual. This publication is based on information that was available at the time it was printed. We reserve the right to make changes to the products and/or publications at any time without notice and without obligation.
2. DIN Rail Connection; as per local electrical codes and recommended wire sizes.
3. DIN Rail mounted per VDE0160 Please see diagram as noted below.
4. This power supply is designed for professional indoor systems. During operation the power supply must not be accessible. Install and put into service by qualified personnel only.
5. **Do not operate without Protective Earth (PE) connection!** To comply with EMC and safety standards (CE mark, approvals) the power supply must be operated only if PE terminal is connected to the non-fused earth conductor.
6. **Do not cover any ventilation holes.** The correct mounting position for optimal cooling performance must be observed. All free space requirements and power de-rating as specified at the beginning of this manual must be observed.
7. **WARNING** The internal fire safety fuse is not accessible. This fuse is not to be replaced by the user. For continued protection against risk of fire, NO REPLACEMENT OF FUSE IS ALLOWED REGARDLESS. If this internal fuse has blown, the power supply has a serious internal defect, and for safety reasons, must be discarded, or if under warranty, returned.
8. **Please ensure that the power supply will be recycled properly at the end of its life.** Some components of this power supply may be suitable for recycling, including some that require special disposal.




Cooling and Airflow

1. Airflow must be upward as shown in figure.
2. Always maintain operation conditions within output power and temperature ratings.
3. All units are rated for convectional cooling but require that there is at least 25mm both above and below unit for proper airflow.
4. Do not block vent holes because by doing so it may overheat and damage the unit.




Names and Descriptions

1. **+** Positive output (50W unit has two terminals)
2. **-** Negative output (50W unit has two terminals)
3. **DC OK** Indicator
4. **ADJ** DC output voltage adjustment
5. **⊕** Safety Ground
6. **N** AC mains (Neutral)
7. **L** AC mains (Line)
8. Din Rail rear mounting clip.



Installation Procedure.

1. Do not connect wiring until after unit is firmly in place.
2. Locate mounting bracket clip on back of unit. A sliding spring release clip is built into the lower channel.
3. First slip the top mounting lip of the clip over the top edge of Din Rail as shown in the figure. (The bottom of the unit should be tilted out about 10°)
4. From the front side, insert a screwdriver and pull the release lever all the way downward and hold it.
5. Apply a downward pressure keeping the top lip firmly seated into the top of the Din Rail.
6. Finally, swing the bottom of the unit downward and slide the release clip upward to ensure a firm fit with the Din rail.



Un-Install and Removal Procedure.

1. Turn off all AC power and disconnect from its source. Disconnect all wiring connections from Power supply.
2. With a screwdriver, pull down the release clip and disengage the bottom channel of the unit from the bottom edge of the Din Rail. Insert pressure downward on the unit and tilt the bottom outward.
3. Rotate upward and lift the unit detaching it from the top edge of the Din Rail.

