

TWR-K40X256

Low-power MCU with
USB and segment LCD



Get to Know the TWR-K40X256



Figure 1: Front Side of TWR-K40X256 Module Not Including TWRPI.



TWR-K40X256

The TWR-K40X256 microcontroller module is part of the Freescale Tower System, a modular development platform that enables rapid prototyping and tool re-use through reconfigurable hardware. Take your design to the next level and begin constructing your Tower System today by visiting freescale.com/tower for additional Tower System microcontroller modules and compatible peripherals.



Figure 2: Front Side of TWR-K40X256 Module with TWRPI-SLCD Attached.




Figure 3: Back Side of TWR-K40X256 Module.

Step-by-Step Installation Instructions

In this Quick Start Guide, you will learn how to set up the TWR-K40X256 module and run the default demonstration.

**STEP
1**

Install the Software and Tools

Install the P&E Micro Kinetis Tower Toolkit to install the OSJTAG and USB-to-Serial drivers. These can be found on the DVD under Software.

**STEP
2**

Configure the Hardware

Install the included battery into the VBAT (RTC) battery holder. Then plug in the included Segment LCD Tower Plug-In (TWRPI-SLCD) into the Touch/SLCD TWRPI socket. Finally, connect one end of the USB cable to the PC and the other end to the Power/OSJTAG mini-B connector on the TWR-K40X256 module. Allow the PC to automatically configure the USB drivers if needed.

**STEP
3**

Tilt the Board

Tilt the board side to side to see the LEDs on E1–E4 light up as it is tilted.

**STEP
4**

Navigate the Segment LCD

The Segment LCD will come up displaying the seconds elapsed since boot-up. Press **SW4** to toggle between viewing the seconds, hours and minutes, potentiometer percent, and temperature.



Explore Further by Conducting Lab 1: TWR-K40X256 Quick Start Demo

Explore all the features and capabilities of the pre-programmed demo by reviewing the lab document located at freescale.com/TWR-K40X256.



Learn More About the Kinetis K40 Microcontrollers

Find more MQX and bare-metal labs and software for the Kinetis K40 microcontrollers at freescale.com/TWR-K40X256.

Jumper Options

The following is a list of all the jumper options. The **default** installed jumper settings are shown in **bold**.

Jumper	Option	Setting	Description
J11	MCU Power Connection	ON	Connect on-board 3.3V supply to MCU
		OFF	Isolate MCU from power (connect an ammeter to measure current)
J12	VBAT Power Selection	1-2	Connect VBAT to on-board 3.3V supply
		2-3	Connect VBAT to the higher voltage between on-board 3.3V supply or coin-cell supply
J13	OSJTAG Bootloader Selection	ON	OSJTAG bootloader mode (OSJTAG firmware reprogramming)
		OFF	Debugger mode
J15	JTAG Board Power Connection	ON	Connect on-board 5V supply to JTAG port (supports powering board from JTAG pod supporting 5V supply output)
		OFF	Disconnect on-board 5V supply to JTAG port

Jumper	Option	Setting	Description
J6	IR Transmitter Connection	ON	Connect PTD7/CMT_IRO to IR Transmitter (D507)
		OFF	Disconnect PTD7/CMT_IRO from IR Transmitter (D507)
J3	VREGIN Power Connection	ON	Connect USB0_VBUS from Elevator to VREGIN
		OFF	Disconnect USB0_VBUS from Elevator to VREGIN
J5	FlexBus Address Latch Selection	1-2	FlexBus address latch disabled
		2-3	FlexBus address latch enabled

TOWER SYSTEM

To learn more about the **TWR-K40X256** and other Freescale Kinetis microcontroller products, please visit freescale.com/TWR-K40X256, freescale.com/Kinetis and freescale.com/Tower.

Freescale, the Freescale logo and CodeWarrior are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Flexis, Kinetis and Processor Expert are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © 2010 Freescale Semiconductor, Inc.

Doc Number: TWRK40QSG / REV 1
Agile Number: 926-78534 / REV B

