



1 Introduction

The purpose of this user manual is to teach how to use the M24LR64-R tool kit with the *M24LRxx_Application_Software*. It describes the *M24LRxx_Application_Software* interface and its menus, and shows how to send commands to M24LR64-R tags.

Contents

1	Introduction	1
2	Tool kit descriptions	7
2.1	Development kit	7
2.2	M24LR64-R demonstration kit	9
2.3	Starter kit	10
3	How to control the RF and I²C channels from your screen	12
3.1	Starting <i>M24LRxx_Application_Software</i>	12
3.1.1	Choosing your tool kit	12
3.1.2	Main menu	13
3.1.3	Image Transfer Application menu	15
3.1.4	Demo STM32-PRIMER2 menu	15
3.1.5	Tools menu	16
3.1.6	Help menu	16
3.2	RF channel commands	16
3.2.1	Inventory command	17
3.2.2	Get System Info command	18
3.2.3	Viewing RF requests and answers	18
3.2.4	Selecting the RF mode	19
3.2.5	Managing the M24LR64-R states	20
3.2.6	Read command	20
3.2.7	Write command	23
3.2.8	Write AFI command	24
3.2.9	Write DSFID command	25
3.2.10	Lock AFI command	25
3.2.11	Lock DSFID command	25
3.2.12	RF password management	26
3.3	I ² C channel	28
3.3.1	I ² C READ commands	29
3.3.2	I ² C WRITE commands	32
3.3.3	I ² C PASSWORD commands	36
4	Data transfer management (picture demo)	38

4.1	Check communication	38
4.1.1	Check communication by RF	39
4.1.2	Check communication by I2C	39
4.2	Writing a picture to your M24LR64-R	40
4.3	Read/display the M24LR64-R's contents	42
5	Demo application for use with DEMOKIT-M24LR-A	44
5.1	Checking the RF communication	44
5.2	Uploading a picture to your DEMOKIT-M24LR-A by RF	45
5.3	Downloading a picture from your DEMOKIT-M24LR-A by RF	45
5.4	Check communication status	46
5.5	Using your STM32-PRIMER2 to read the contents of the reference antenna by I2C	47
6	Revision history	48

List of figures

Figure 1.	RF reader (ISO 15693, RF 13.56 MHz)	7
Figure 2.	External antenna	7
Figure 3.	Serial EEPROM USB reader	8
Figure 4.	I ² C bus cable	8
Figure 5.	ANT1-M24LR-A reference antenna	8
Figure 6.	ANT2-M24LR-A reference antenna	8
Figure 7.	M24LR64-R in SO8 package	9
Figure 8.	RF reader	9
Figure 9.	PRIM2-M24LR-A reference antenna	9
Figure 10.	STM32-PRIMER2	10
Figure 11.	I ² C & RF reader	10
Figure 12.	ANT1-M24LR-A reference antenna	11
Figure 13.	ANT2-M24LR-A reference antenna	11
Figure 14.	M24LR64-R in SO8 package	11
Figure 15.	Application's opening page	12
Figure 16.	Connection check by the software	13
Figure 17.	Main menu window	14
Figure 18.	show Reader application	14
Figure 19.	show Image Transfer application	15
Figure 20.	Demo STM32-PRIMER2 menu	15
Figure 21.	Tools menu	16
Figure 22.	Help menu	16
Figure 23.	RF user interface	17
Figure 24.	Inventory button	17
Figure 25.	Three tags detected	18
Figure 26.	Specific UID selected	18
Figure 27.	Get System Info button	18
Figure 28.	RF TAG REQUEST/ANSWER report	18
Figure 29.	RF request and RF answer	19
Figure 30.	Selecting the Non-addressed mode	19
Figure 31.	Selecting the Addressed mode	19
Figure 32.	Selecting the Select mode	20
Figure 33.	Device state management interface	20
Figure 34.	Initiating a read operation	20
Figure 35.	Result of the read operation - Sector 00h	21
Figure 36.	Result of the read operation - Sector 3Fh	22
Figure 37.	Sector 0 block 0	22
Figure 38.	Sector 0 blocks 1 to 5	22
Figure 39.	Initiating a write operation	23
Figure 40.	Fill with 55	23
Figure 41.	Get Multiple Block Security Status button	23
Figure 42.	Security status byte for sector 07	24
Figure 43.	Security status bytes for sectors 07 and 08	24
Figure 44.	Write AFI command	24
Figure 45.	Write DSFID command	25
Figure 46.	Lock AFI command	25
Figure 47.	Warning before locking the AFI field	25
Figure 48.	Lock DSFID command	25

Figure 49.	Warning before locking the DSFID field	26
Figure 50.	Warning displayed on the user interface	26
Figure 51.	Present-sector Password command	27
Figure 52.	Present-sector Password command successful	27
Figure 53.	Present-sector Password command error	27
Figure 54.	Write-sector Password command	27
Figure 55.	Warning before changing the password	27
Figure 56.	Write-sector Password command successful	28
Figure 57.	Write-sector Password command error	28
Figure 58.	Lock-sector Password command	28
Figure 59.	Lock-sector Password command successful	28
Figure 60.	Lock-sector Password command error	28
Figure 61.	Button to switch between the RF and I2C interfaces	28
Figure 62.	I2C User Interface window	29
Figure 63.	Reading the memory array	29
Figure 64.	Result of a Read operation to the memory array	30
Figure 65.	Reading the sector security status	30
Figure 66.	Result of the read sector security status operation	31
Figure 67.	Reading the I2C_Write_Lock bit area	31
Figure 68.	Result of the I2C_Write_Lock bit area read operation	31
Figure 69.	Reading the system parameter sector	32
Figure 70.	Result of the read system parameter sector operation	32
Figure 71.	Writing to the memory array	32
Figure 72.	Write cycle successful	33
Figure 73.	Write cycle failed (no write cycle detected)	33
Figure 74.	Result of the Write operation (003C)	33
Figure 75.	Page Size field	33
Figure 76.	Writing A1 to the memory array	34
Figure 77.	Writing to the sector security status area	34
Figure 78.	Result of the write to sector security status area operation	35
Figure 79.	Writing to the I2C_Write_Lock bit area	35
Figure 80.	Result of the write to I2C_Write_Lock bit area operation	35
Figure 81.	Issuing an I2C Present Password command	36
Figure 82.	Issuing an I2C Write Password command	36
Figure 83.	Warning	37
Figure 84.	Write Password cycle successful	37
Figure 85.	Write Password cycle failed (no cycle detected)	37
Figure 86.	Show Image Transfer Application window	38
Figure 87.	Check communication tool	38
Figure 88.	RF communication between the tag and the reader is OK	39
Figure 89.	No RF communication between the tag and the reader	39
Figure 90.	I2C communication between the tag and the reader is OK	39
Figure 91.	Failed upload by I2C	39
Figure 92.	WRITE PICTURE TO M24LR64	40
Figure 93.	Picture to be uploaded	40
Figure 94.	Selecting I2C to upload the picture	40
Figure 95.	Uploading the picture by I2C	41
Figure 96.	Selecting RF to upload the picture	41
Figure 97.	Uploading the picture by RF	41
Figure 98.	I2C upload process successful	41
Figure 99.	I2C upload process failed	41
Figure 100.	RF upload process successful	41

Figure 101. RF upload process failed	42
Figure 102. READ M24LR64 CONTENT interface	42
Figure 103. Selecting I2C to download the picture	42
Figure 104. Downloading the picture by I2C	42
Figure 105. Selecting RF to download the picture	43
Figure 106. Downloading the picture by RF.	43
Figure 107. Progress bar	43
Figure 108. The ST logo is displayed	43
Figure 109. Error message	43
Figure 110. Demo STM32-PRIMER2 application window	44
Figure 111. Check RF communication button	44
Figure 112. RF communication ongoing between reader and reference antenna.	44
Figure 113. No RF communication between reader and reference antenna.	44
Figure 114. Upload frame	45
Figure 115. Click to download Picture button	45
Figure 116. HELLO WORLD picture downloaded	46
Figure 117. ST logo downloaded.	46
Figure 118. Upload/download process going smoothly	46
Figure 119. Upload/download process with errors.	46

2 Tool kit descriptions

2.1 Development kit

Ordering information: **DEVKIT-M24LR-A**

The development kit contains:

- a middle-range RF reader (ISO 15693, RF 13.56 MHz) interfaced via the USB bus and an external power supply to have a greater read range. [Figure 1](#) shows the RF reader.
- an external antenna, shown in [Figure 2](#).
- a serial EEPROM USB reader, shown in [Figure 3](#): it is an I²C bus reader (interfaced via the USB bus).
- an I²C bus cable to connect the serial EEPROM USB reader to the I²C bus of the reference antenna. [Figure 4](#) shows the cable to use.
- M24LR64-R reference antennas:
 - ANT1-M24LR-A shown in [Figure 5](#):
RF antenna size: 75 mm × 45 mm (2.9 in × 1.77 in)
 - ANT2-M24LR-A shown in [Figure 6](#):
RF antenna size: 20 mm × 40 mm (0.79 in × 1.57 in)
- M24LR64-R samples in SO8 package (see [Figure 7](#))

Figure 1. RF reader (ISO 15693, RF 13.56 MHz)



Figure 2. External antenna



Figure 3. Serial EEPROM USB reader



Figure 4. I²C bus cable




Figure 5. ANT1-M24LR-A reference antenna




Figure 6. ANT2-M24LR-A reference antenna





Figure 7. M24LR64-R in SO8 package



2.2 M24LR64-R demonstration kit

Ordering information: DEMOKIT-M24LR-A

The demonstration kit contains:

- a middle-range RF reader (ISO 15693, RF 13.56 MHz) interfaced via the USB bus, shown in [Figure 8](#)
- an M24LR64-R's reference antenna: PRIM2-M24LR-A shown in [Figure 9](#)
RF antenna size: 20 mm × 40 mm (0.79 in x 1.57 in)
- Optional: STM32-PRIMER2 (to be ordered separately) shown in [Figure 10](#)

Figure 8. RF reader



Figure 9. PRIM2-M24LR-A reference antenna




Figure 10. STM32-PRIMER2

1. Not included in the kit, to be ordered separately.

2.3 Starter kit

Ordering information: STARTKIT-M24LR-A

The starter kit contains:

- a short-range RF reader (ISO 15693, RF 13.56 MHz), interfaced via the USB bus (including the external I²C bus cable + connector) illustrated in [Figure 11](#)
- M24LR64-R's reference antennas:
 - ANT1-M24LR-A shown in [Figure 12](#): RF antenna size: 75 mm × 45 mm (2.9 in × 1.77 in)
 - ANT2-M24LR-A shown in [Figure 13](#): RF antenna size: 20 mm × 40 mm (0.79 in × 1.57 in)
- M24LR64-R samples in SO8 package (see [Figure 7](#))

Figure 11. I²C & RF reader

Figure 12. ANT1-M24LR-A reference antenna




Figure 13. ANT2-M24LR-A reference antenna





Figure 14. M24LR64-R in SO8 package



3 How to control the RF and I²C channels from your screen

3.1 Starting *M24LRxx_Application_Software*

Before starting, you must have:

- previously installed all the drivers. For how to install the required drivers, please refer to UM0863: "M24LR64-R tool driver install guide"
- connected the reader's USB cable

3.1.1 Choosing your tool kit

On the PC desktop, double click on the *M24LRxx_Application_Software* icon. On launching the software, you will be prompted to select the kit you wish to use as shown in [Figure 15](#).

Figure 15. Application's opening page




Select your kit from the list below and press the OK button:

- STARTER KIT
- DEMO KIT (USB based)
- DEMO KIT (based on the RS232 port - old version)
- DEVELOPMENT KIT

If you select DEMO KIT (USB based), you can also play with the SERIAL EEPROM USB reader by checking the box to add the Serial EEPROM USB reader.

Once the kit has been selected, the software checks that the selected readers are well connected. A progress bar appears during the check as shown in [Figure 16](#).

Figure 16. Connection check by the software




If a problem occurs, a window appears to indicate what the problem is:

- If the development kit is used, the problem could be:
 - medium-range RF reader not plugged in the USB port
 - medium-range RF reader driver not installed
 - I²C bus reader not plugged in the USB port
 - I²C bus reader driver not installed
- If the demo kit is used, the problem could be:
 - medium-range RF reader not plugged in the USB port
 - medium-range RF reader driver not installed
- If the starter kit is used, the problem could be:
 - Short-range RF reader not plugged in the USB port
 - Short-range RF reader driver not installed

3.1.2 Main menu

If all the drivers have been installed correctly, and the selected readers have been plugged, the window shown in [Figure 17](#) appears.


The connection status of the readers as well as the version of the software are displayed at the bottom of the window.

Figure 17. Main menu window

You can use the menu at the top of the window to select several applications:

Reader Application menu

Select **show Reader application** (*Figure 18*) to manage all the I²C and RF functions of the M24LR64-R.


Figure 18. show Reader application

3.1.3 Image Transfer Application menu

Figure 19 shows the Image Transfer Application menu.

Select **show Image Transfer application** to upload or download a picture to or from the M24LR64-R by RF or I²C.

Figure 19. show Image Transfer application



3.1.4 Demo STM32-PRIMER2 menu


Figure 20 shows the Demo STM32-PRIMER2 menu.

Select **show Demo STM32-PRIMER2** to upload or download a picture to or from the M24LR64-R by RF.

Pictures are formatted to be usable by the "Dual EE" firmware of your STM32-PRIMER2 demo.

Refer to UM0850 for details on how to use Dual EE.

Figure 20. Demo STM32-PRIMER2 menu




3.1.5 Tools menu

Figure 21 shows the Tools menu.

Select **stop animation** to stop the animation in the reader application interface.

Figure 21. Tools menu




3.1.6 Help menu

Figure 22 shows the Help menu:

- **Open *.bin file with BinEdit** gives you access to a freeware for reading binary files (*.bin format).
- **Change background color** allows you to change the color of the main window.
- **About** provides information about the software.

Figure 22. Help menu




3.2 RF channel commands

Select **show Reader Application** in the main menu. The *RF user interface* opens. It is shown in *Figure 23*. With this interface you can send any command to the M24LR64-R tag present in the RF reader field.

The **Show I2C Commands** button is used to switch from the RF user interface to the I²C user interface.

Figure 23. RF user interface



3.2.1 Inventory command

The **Inventory** button launches an Inventory command and thus detects the tags present in the RF field. The command is associated with an anticollision algorithm to detect each tag individually (see [Figure 25](#)).

The **Loop** option is used to loop on inventory commands. It is selected (or deselected) by checking (or unchecking) the box next to **Loop**.

Figure 24. Inventory button






Figure 25. Three tags detected



You can select a tag in the list of detected UIDs by clicking on the desired UID in the list as shown in [Figure 26](#). The selected UID will then be used in all RF requests sent in Addressed mode.


Figure 26. Specific UID selected



3.2.2 Get System Info command


The **Get System Info** button launches a Get System Info command, thus filling the **System info** fields.

Figure 27. Get System Info button



3.2.3 Viewing RF requests and answers

Figure 28. RF TAG REQUEST/ANSWER report




The **RF TAG REQUEST report** button shows the RF request sent by the RF reader to the tag.

The **RF TAG ANSWER report** button shows the RF answer from the tag, detected by the RF reader.

Figure 29 shows an example of a reader's RF request and the corresponding answer from the tag.

Figure 29. RF request and RF answer



The RF read request is at address 0000. The RF answer is the read data: FF D8 FF E0.

3.2.4 Selecting the RF mode

The RF ISO 15693 protocol allows the user to communicate in RF in three different modes: the Non-addressed mode, the Addressed mode and the Select mode. For further details, please refer to the M24LR64-R datasheet.


The Non-addressed, Addressed or Select mode can be selected by clicking on the desired mode as shown in *Figure 30*, *Figure 31* or *Figure 32*.

Non-addressed mode

Selecting the Non-addressed mode clears the bits 5 and 6 in the Request_flags of the RF request (bit 5 = 0, bit 6 = 0).

The request is executed by any M24LR64-R device (please refer to the M24LR64-R datasheet for details).

Figure 30. Selecting the Non-addressed mode



Addressed mode

Selecting the Addressed mode clears bit 5 and sets bit 6 in the Request_flags of the RF request (bit 5 = 0, bit 6 = 1).

The request is addressed. The UID field is present (please refer to the M24LR64-R datasheet for details).

After an Inventory command (see *Section 3.2.1: Inventory command*), you will be able to click on an UID to select a specific tag. The desired UID will be sent with the request if the Addressed mode is chosen.

If no specific UID tag is selected, the device sends "00 00 00 00 00 00 00 00" instead of the UID value.

Figure 31. Selecting the Addressed mode




Select mode

Selecting the Select mode sets bit 5 and clears bit 6 in the Request_flags of the RF request (bit 5 = 1 and bit 6 = 0).

The request is executed only by the M24LR64-R device in the Select State (please refer to the M24LR64-R datasheet for details).

To select a tag, refer to the [SELECT](#) paragraph below, and to the M24LR64-R datasheet (Select paragraph).

Figure 32. Selecting the Select mode




3.2.5 Managing the M24LR64-R states

The M24LR64-R can be in different states: Power-off, Ready, Quiet and Selected (refer to the M24LR64-R datasheet for details).

The interface shown in [Figure 33](#) is used to send three types of RF request to place the M24LR64-R in one out of three specific states: Selected, Quiet and Ready.

Figure 33. Device state management interface



SELECT

The **SELECT** button is used to send a Select RF request with the UID of a specific tag ([Section 3.2.1: Inventory command](#)) (refer to the M24LR64-R datasheet for details).

If no tag was selected after the Inventory request, the device sends "00 00 00 00 00 00 00 00" instead of the UID value.

STAY QUIET


The **STAY QUIET** button is used to send a Stay Quiet RF request (refer to the M24LR64-R datasheet for details).

RESET TO READY

The **RESET TO READY** button is used to send a Reset to Ready RF request (refer to the M24LR64-R datasheet for details).

3.2.6 Read command

Figure 34. Initiating a read operation



By pressing the Read button, you launch RF requests to read the contents of the M24LR64-R EEPROM from the block address specified in the **from** field to the block address specified in the **to** field.

The result of the read operation is displayed in the **MEMORY seen by RF** area (see [Figure 35](#) to [Figure 38](#)).

From **0000** to **07FF** reads all M24LR64-R EEPROM contents. [Figure 35](#) and [Figure 36](#) only show the results for sector 0 and sector 3F, respectively.

Figure 35. Result of the read operation - Sector 00h

MEMORY seen by RF			
sector	block	datas	sss
	0000	FF D8 FF E0	
	0001	00 10 4A 46	
	0002	49 46 00 01	
	0003	01 01 00 60	
	0004	00 60 00 00	
	0005	FF E1 00 72	
	0006	45 78 69 66	
	0007	00 00 49 49	
	0008	2A 00 08 00	
	0009	00 00 01 00	
	000A	69 87 04 00	
	000B	01 00 00 00	
	000C	1A 00 00 00	
	000D	00 00 00 00	
	000E	01 00 86 92	
	000F	02 00 3D 00	
00	0010	00 00 2C 00	XX
	0011	00 00 00 00	
	0012	00 00 43 52	
	0013	45 41 54 4F	
	0014	52 3A 20 67	
	0015	64 2D 6A 70	
	0016	65 67 20 76	
	0017	31 2E 30 20	
	0018	28 75 73 69	
	0019	6E 67 20 49	
	001A	4A 47 20 4A	
	001B	50 45 47 20	
	001C	76 36 32 29	
	001D	2C 20 64 65	
	001E	66 61 75 6C	
	001F	74 20 71 75	

Figure 36. Result of the read operation - Sector 3Fh

MEMORY seen by RF			
sector	block	data	sss
	07E0	FF FF FF FF	
	07E1	FF FF FF FF	
	07E2	FF FF FF FF	
	07E3	FF FF FF FF	
	07E4	FF FF FF FF	
	07E5	FF FF FF FF	
	07E6	FF FF FF FF	
	07E7	FF FF FF FF	
	07E8	FF FF FF FF	
	07E9	FF FF FF FF	
	07EA	FF FF FF FF	
	07EB	FF FF FF FF	
	07EC	FF FF FF FF	
	07ED	FF FF FF FF	
	07EE	FF FF FF FF	
	07EF	FF FF FF FF	
3F	07F0	FF FF FF FF	XX
	07F1	FF FF FF FF	
	07F2	FF FF FF FF	
	07F3	FF FF FF FF	
	07F4	FF FF FF FF	
	07F5	FF FF FF FF	
	07F6	FF FF FF FF	
	07F7	FF FF FF FF	
	07F8	FF FF FF FF	
	07F9	FF FF FF FF	
	07FA	FF FF FF FF	
	07FB	FF FF FF FF	
	07FC	FF FF FF FF	
	07FD	FF FF FF FF	
	07FE	FF FF FF FF	
	07FF	FF FF FF FF	

Use the arrows on the keyboard to change the sector or block to be read.

From 0000 to 0000 reads block 0 in sector 0 as shown in Figure 37.

Figure 37. Sector 0 block 0

MEMORY seen by RF			
sector	block	data	sss
00	0000	FF D8 FF E0	XX

From 0001 to 0005 reads the blocks 1, 2, 3, 4, 5 in sector 0 as shown in Figure 38.

Figure 38. Sector 0 blocks 1 to 5

MEMORY seen by RF			
sector	block	data	sss
	0001	00 10 4A 46	
	0002	49 46 00 01	
00	0003	01 01 00 60	XX
	0004	00 60 00 00	
	0005	FF E1 00 72	

How to read the memory area with the RF Interface:

- The first column (**sector**) indicates the sector read.
- The second column (**block**) indicates the address of the block read.
- The third column (**data**) shows the contents of the M24LR64-R at the specified addresses.
- The fourth column (**sss**) gives the sector security status.

Example: in [Figure 38](#) above, the data **49 46 00 01** means:


- 49 (49h Hex) is the first piece of data read in block number 0002 (sector 0)
- 46 (46h Hex) is the second piece of data read in block number 0002 (sector 0)
- 00 (00h Hex) is the third piece of data read in block number 0002 (sector 0)
- 01 (01h Hex) is the fourth piece of data read in block number 0002 (sector 0)

3.2.7 Write command

The **Write** button launches RF requests to write data to the M24LR64-R EEPROM from the block address specified in the **from** field to the block address entered in the **to** field.


In [Figure 39](#), the Write command fills the blocks 0000h to 001Fh with “A1 34 09 67”.

Figure 39. Initiating a write operation



You can choose to write the same byte four times by changing the value in the **Fill with** field. In the example below, the byte 55 is to be written four times.


Figure 40. Fill with 55



Get Multiple Block Security Status command

The **Get Multiple Block Security Status** button launches RF requests to read the security statuses of the blocks that correspond to the address range specified in the **from** and **to** fields.

Figure 41. Get Multiple Block Security Status button



Addresses are managed in the same way as for read operations. In [Figure 42](#) the security status byte is shown for the blocks with addresses ranging between 0x00E0 and 0x00FF (sector 07).

Figure 42. Security status byte for sector 07

MEMORY seen by RF			
sector	block	data	sss
07	00E0		
	00E1		
	00E2		
	00E3		
	00E4		
	00E5		
	00E6		
	00E7		
	00E8		
	00E9		
	00EA		
	00EB		
	00EC		
	00ED		
	00EE		
	00EF		
00F0			
00F1			
00F2			
00F3			
00F4			
00F5			
00F6			
00F7			
00F8			
00F9			
00FA			
00FB			
00FC			
00FD			
00FE			
00FF			

00 sss value = 00
(security status for sector 07)

ai17631

Figure 43 shows the security status bytes for the blocks located at addresses 00FAh to 0109h (sector 07 & sector 08).

Figure 43. Security status bytes for sectors 07 and 08

MEMORY seen by RF			
sector	block	data	sss
07	00FA		
	00FB		
	00FC		
	00FD		
	00FE		
	00FF		
	0100		
08	0101		
	0102		
	0103		
	0104		
	0105		
	0106		
	0107		
	0108		
	0109		

00 Sector security status SSS value = 00 for sector 07


00 Sector security status SSS value = 00 for sector 08

ai17632

3.2.8 Write AFI command

The **Write AFI** button launches a Write AFI command. The data in the dedicated field next to the **Write AFI** button are written to the AFI register.


Figure 44. Write AFI command



3.2.9 Write DSFID command

The **Write DSFID** button launches a Write DSFID command. The data in the dedicated field next to the **Write DSFID** button are written to the DSFID register.

Figure 45. Write DSFID command



3.2.10 Lock AFI command

The **Lock AFI** button launches a Lock AFI command. The execution of this command locks the AFI field *permanently*.


Figure 46. Lock AFI command



Caution: Once the AFI field has been locked, it cannot be unlocked.

For this reason, a warning (shown in [Figure 47](#)) is displayed before locking the AFI. To abort the Lock AFI command, click on **Cancel**. To confirm the command, click on **OK**.

Figure 47. Warning before locking the AFI field



3.2.11 Lock DSFID command


The **Lock DSFID** button launches a Lock DSFID command. When executed, this command locks the DSFID field permanently.

Figure 48. Lock DSFID command



Caution: Once the DSFID field has been locked, it cannot be unlocked.

This is the reason why a warning (shown in [Figure 49](#)) is displayed before locking the DSFID field. To abort the Lock DSFID command, click on **Cancel**. To confirm the command, click on **OK**.

Figure 49. Warning before locking the DSFID field

3.2.12 RF password management

The user interface displays a warning concerning password changes: you should be very careful when you change a password because there is no way of retrieving forgotten RF passwords. You have to remember the new passwords you enter. The sectors locked by a password can only be unlocked if you can provide the correct password. [Figure 50](#) shows the displayed warning.

By default, the RF and I²C passwords are '00 00 00 00'.

Figure 50. Warning displayed on the user interface

Present-sector Password command

The **Present password** button issues a Present-sector Password command with the data filled in the **password data** field and the selected password number.

Figure 51. Present-sector Password command

The result of the Present-sector Password command appears in the RF answer field.

[Figure 52](#) shows a successful command, and [Figure 53](#) shows an example where an error occurred.

Figure 52. Present-sector Password command successful
Figure 53. Present-sector Password command error

Write-sector Password command


The **Write Password** button issues a Write-sector Password command with the data filled in the **password data** field and the selected password number.

Figure 54. Write-sector Password command

When you press the **Write password** button, a warning pops up to prevent any unwanted password change. To abort the Write-sector Password command, click on **Cancel**. To confirm the command, click on **OK**.


Figure 55. Warning before changing the password

Figure 56. Write-sector Password command successful



Write Password HS

Figure 57. Write-sector Password command error



Lock-sector Password command

The **Lock sector** button issues a Lock-sector Password command with the data configured in the **select sector number**, **select password number** and **select lock config** fields.

Figure 58. Lock-sector Password command

Lock sector

select sector number

select password number

select lock config

	pwd presented	pwd not presented
<input checked="" type="radio"/> 00	Read Write	Read No Write
<input type="radio"/> 01	Read Write	Read Write
<input type="radio"/> 10	Read Write	No Read No Write
<input type="radio"/> 11	Read No Write	No Read No Write

Figure 59. Lock-sector Password command successful





Figure 60. Lock-sector Password command error



3.3 I²C channel


You can use the *I2C User Interface window*, illustrated in [Figure 62](#), to exchange data between a tag connected to the I2C reader and the M24LR64-R.

With the **Show RF interface** button ([Figure 61](#)) you can switch from the RF user interface to the I2C user interface.

Figure 61. Button to switch between the RF and I2C interfaces



Figure 62. I2C User Interface window



3.3.1 I2C READ commands

The **Read** button issues read commands to the M24LR64-R connected to the I2C reader. To do so, select the I2C READ area, and then press on the **Read** button.

Read command to the memory array

To read the memory array, select **Memory** from the list and specify the address range to be read. Then click on the **Read** button. Addresses are managed in the same way as for RF commands (see [Section 3.2.6: Read command](#)).

[Figure 63](#) shows an example where the user chooses to issue a Read Memory operation from address 0010h to address 003Fh.

Figure 63. Reading the memory array




Figure 64. Result of a Read operation to the memory array

MEMORY seen by I2C		
sector	memory	data
	0010	00 60 00 00
	0014	FF E1 00 72
	0018	45 78 69 66
	001C	00 00 49 49
	0020	2A 00 08 00
	0024	00 00 01 00
00	0028	69 87 04 00
	002C	01 00 00 00
	0030	1A 00 00 00
	0034	00 00 00 00
	0038	01 00 86 92
	003C	02 00 3D 00

ai17658

Figure 64 illustrates the result of the Read operation to the memory array. The first column shows which sector is read. The second column indicates the address of the first byte in the page. Then the third column gives the data.

Let us take the example corresponding to the data < 69 87 04 00 >

- 69 (69h Hex) is data for address 0028h (sector 0)
- 87 (87h Hex) is data for address 0029h (sector 0)
- 04 (04h Hex) is data for address 002Ah (sector 0)
- 00 (00h Hex) is data for address 002Bh (sector 0)

Reading the sector security status

To read all the sector security status bytes (RF block security), select **Sector Security Status (system)** then press the **Read** button.

Figure 65 shows how to launch an operation to read the sector security status.

Figure 65. Reading the sector security status




Figure 66. Result of the read sector security status operation

MEMORY seen by I2C	
system	SSS
0000	00 00 00 00
0004	00 00 00 00
0008	00 00 00 00
000C	00 00 00 00
0010	00 00 00 00
0014	00 00 00 00
0018	00 00 00 00
001C	00 00 00 00
0020	00 00 00 00
0024	00 00 00 00
0028	00 00 00 00
002C	00 00 00 00
0030	00 00 00 00
0034	00 00 00 00
0038	00 00 00 00
003C	00 00 00 00

Reading the I2C_Write_Lock bit area

To read the I2C_Write_Lock bit area (I2C sector security), select **I2C write lock bits (system)** and press the **Read** button.

Figure 67 shows how to launch an operation to read the I2C_Write_Lock bit area.

Figure 67. Reading the I2C_Write_Lock bit area

I2C READ	
<input type="radio"/>	Memory
<input type="radio"/>	Sector Security Status (system)
<input checked="" type="radio"/>	I2C write Lock bits (system)
<input type="radio"/>	System Parameter Sector (system)
Read	

Figure 68. Result of the I2C_Write_Lock bit area read operation

MEMORY seen by I2C	
system	I2C write lock bits
0800	00 00 00 00
0804	00 00 00 00

Reading the system parameter sector

To read the data in the system parameter sector, select **System Parameter Sector (system)** and press the **Read** button.

Figure 69 shows how to launch an operation to read the system parameter sector.

Figure 69. Reading the system parameter sector




Figure 70. Result of the read system parameter sector operation

MEMORY seen by I2C

system	sector parameters
0900	FF FF FF FF
0904	FF FF FF FF
0908	FF FF FF FF
090C	FF FF FF FF
0910	FF FE 00 00
0914	12 34 56 78
0918	9A BC 02 E0
091C	2C FF 07 03

Please, refers to the M24LR64-R dataheet for the system parameters.

3.3.2 I2C WRITE commands

The **Write** button is used to issue write commands to the M24LR64-R connected to the I2C reader. The button is located in the I2C WRITE area of the I2C User Interface window (see [Figure 62](#)).


To issue a command, select the I2C WRITE area and press the **Read** button.

Write command to the memory array

To write to the memory array, select **Memory** and choose the address range to be written. Then press the **Write** button. Addresses are managed is the same way as for RF commands (see [Section 3.2.6: Read command](#)).

[Figure 71](#) shows how to launch a write operation to the memory array.

Figure 71. Writing to the memory array



In this example, a write operation is issued to write the data < 12 34 56 78 > to EEPROM memory addresses 0000 to 003F by I2C communication.

Note that in the I2C answer, you are notified of whether the write cycle succeeded or failed (see [Figure 72](#) and [Figure 73](#)).

Figure 72. Write cycle successful





Figure 73. Write cycle failed (no write cycle detected)




[Figure 74](#) shows the result of the write operation.

Figure 74. Result of the Write operation (003C)

MEMORY seen by I2C		
sector	memory	datas
00	0000	12 34 56 78
	0004	12 34 56 78
	0008	12 34 56 78
	000C	12 34 56 78
	0010	12 34 56 78
	0014	12 34 56 78
	0018	12 34 56 78
	001C	12 34 56 78
	0020	12 34 56 78
	0024	12 34 56 78
	0028	12 34 56 78
	002C	12 34 56 78
	0030	12 34 56 78
	0034	12 34 56 78
	0038	12 34 56 78
	003C	12 34 56 78

You can write 1, 2, 3 or 4 bytes by playing with the **Page Size** field.

Figure 75. Page Size field



[Figure 76](#) shows how to write "A1" to EEPROM memory address 0005.

Figure 76. Writing A1 to the memory array

The screenshot shows the 'I2C WRITE' dialog box. The 'Memory' radio button is selected. The 'Address' fields are set to '0005' for both 'from' and 'to'. The 'Page Size' is set to '1'. The 'Write Memory (memory area)' section contains the text 'A1' in a text box, a 'Fill with' color selector, and a 'Write' button.

Writing to the sector security status area

To write to the sector security status area, select **Sector Security Status (system)** and type the address range to be written, then press the **Write** button. Addresses are managed in the same way as for RF commands (see [Section 3.2.6: Read command](#)).

Please note that the I2C password has to be presented successfully prior to writing to the Sector Security Status area.

[Figure 77](#) shows how to write to the sector security status area.

Figure 77. Writing to the sector security status area

The screenshot shows the 'I2C WRITE' dialog box. The 'Sector Security Status (system)' radio button is selected. The 'Address' fields are set to '0000' for 'from' and '0003' for 'to'. The 'Page Size' is set to '4'. The 'Write SSS (System area)' section contains the hexadecimal value 'AE F3 21 00' in a text box, a 'Fill with' color selector, and a 'Write' button.

[Figure 78](#) shows the result of the operation.

Figure 78. Result of the write to sector security status area operation

MEMORY seen by I2C	
system	SSS
0000	AE F3 21 00
0004	00 00 00 00
0008	00 00 00 00
000C	00 00 00 00
0010	00 00 00 00
0014	00 00 00 00
0018	00 00 00 00
001C	00 00 00 00
0020	00 00 00 00
0024	00 00 00 00
0028	00 00 00 00
002C	00 00 00 00
0030	00 00 00 00
0034	00 00 00 00
0038	00 00 00 00
003C	00 00 00 00

Writing to the I2C_Write_Lock bit area

To write to the I2C_Write_Lock bit area, select **I2C write lock bits (system)** and fill the address range to be written, then press the **Write** button. Addresses are managed in the same way as for RF commands (see [Section 3.2.6: Read command](#)).

Please note that the I2C password has to be presented successfully prior to writing to the I2C_Write_Lock bit area

[Figure 79](#) shows how to launch a write operation to the I2C_Write_Lock bit area.

Figure 79. Writing to the I2C_Write_Lock bit area

I2C WRITE			
<input type="radio"/>	Memory		
<input type="radio"/>	Sector Security Status (system)		
<input checked="" type="radio"/>	I2C write Lock bits (system)		
<input type="radio"/>	System Parameter Sector (system)		
Address	Address		
from	0800	to	0800
		Page Size	1
Write I2C Lock Bits (System area)			
12	Fill with		Write

[Figure 80](#) shows the result of the operation.

Figure 80. Result of the write to I2C_Write_Lock bit area operation

MEMORY seen by I2C	
system	I2C write lock bits
0800	12 00 00 00
0804	00 00 00 00

3.3.3 I²C PASSWORD commands

In the I²C PASSWORD area of the I²C User Interface window (see [Figure 62](#)), select **Present Password** to be able to send an I²C Present Password command. The button at the bottom right-hand side of the I²C PASSWORD area will indicate **Present**.


In the same area, select **Write Password** to be able to send an I²C Write Password command. The button at the bottom right-hand side of the I²C PASSWORD area will indicate **Write**.

I²C Present Password command

To issue an I²C Present Password command, select **Present Password** and type the I²C password into the **Present Password** field.

[Figure 81](#) shows how to launch an I²C Present Password command.

Figure 81. Issuing an I²C Present Password command




In this example, an I²C Present Password command is sent with the I²C password <AE 45 80 63 >.

I²C Write Password command

To issue an I²C Write Password command, select **Write Password** and type the I²C password into the **Write Password** field.

[Figure 82](#) shows how to launch an I²C Write Password command.

Figure 82. Issuing an I²C Write Password command





In this example, an I²C Write Password command is sent with the I²C password <54 13 4B C8 >.

A warning (see [Figure 83](#)) was added to prevent unwanted password changes.

Figure 83. Warning


Note that in the I2C answer, you are notified of whether the write cycle succeeded or failed (see [Figure 84](#) and [Figure 85](#)).

Figure 84. Write Password cycle successful**Figure 85. Write Password cycle failed (no cycle detected)**

4 Data transfer management (picture demo)

Select **show Image Transfer Application** from the main menu of the *M24LRxx_Application_Software* application.

Figure 86. Show Image Transfer Application window



The show Demo application allows you to play with the M24LR64-R device with both interfaces: I2C and RF.

With this demo you can load a picture by RF or I2C (.jpeg file of 2 Kbytes) into the M24LR64-R device. You can also download and display the contents of the memory by I2C or RF. If JPG-like contents were previously loaded into the EEPROM, you will be able to visualize them.

4.1 Check communication

This tool help you test the I2C or RF communications between the M24LR64-R device and the reader.

Figure 87. Check communication tool



If you want to use the RF interface to check communications, click on the **check RF communication** button. If you want to use the I2C bus, click on the **check I2C communication** button.

4.1.1 Check communication by RF

After clicking on **check RF communication**, the button changes to **running** as shown in [Figure 88](#).

If the circle next to the **running** button is green, the communication by RF between the M24LR64-R and the reader is OK.

Figure 88. RF communication between the tag and the reader is OK



If the circle next to the **running** button is red, the communication by RF between the M24LR64-R and the reader is NOT OK

Figure 89. No RF communication between the tag and the reader



4.1.2 Check communication by I2C

After clicking on **check I2C communication**, the button changes to **running** as shown in [Figure 90](#).

If the circle next to the **running** button is green, the communication by I2C between the M24LR64-R and the reader is OK.

Figure 90. I2C communication between the tag and the reader is OK



If the circle next to the **running** button is red, the upload by I2C failed.

Figure 91. Failed upload by I2C



4.2 Writing a picture to your M24LR64-R

In the show Demo application window, go to the WRITE PICTURE TO M24LR64 area (see [Figure 92](#)), and choose the picture you would like to upload into the memory. Click on the picture to select it.

Figure 92. WRITE PICTURE TO M24LR64



In [Figure 93](#), the ST logo was chosen as an example.


Figure 93. Picture to be uploaded



After selecting the picture, you need to choose which of the I2C or RF interface you will use to upload it to the memory of the M24LR64-R device.

To upload it by I2C, click on **I2C** as shown below.


Figure 94. Selecting I2C to upload the picture




You then have to click on the **Upload by I2C** button as shown in [Figure 95](#).

Figure 95. Uploading the picture by I2C

To upload the picture by RF, click on **RF** as shown below.

Figure 96. Selecting RF to upload the picture

You then have to click on the **Upload by RF** button to launch the upload process (see [Figure 97](#)).

Figure 97. Uploading the picture by RF

You can use the CHECK COMMUNICATION area to verify whether the data are written successfully or not.

If the I2C bus was used, click on **check I2C communication**. The color of the circle will tell you if the upload process was successful (green circle like in [Figure 98](#)) or failed (red circle like in [Figure 99](#)).

Figure 98. I2C upload process successful**Figure 99. I2C upload process failed**


If the RF interface was used, click on **check RF communication**. The color of the circle will tell you if the upload process was successful (green circle like in [Figure 100](#)) or failed (red circle like in [Figure 101](#)).

Figure 100. RF upload process successful

Figure 101. RF upload process failed

4.3 Read/display the M24LR64-R's contents

In the show Demo application window, the READ M24LR64 CONTENT area allows you to display the contents of the memory on your computer screen if the picture was uploaded.


Figure 102. READ M24LR64 CONTENT interface

You first have to select which of the I2C or RF interface you will use to download the picture from the memory of the M24LR64-R.


To download it by I2C, click on **I2C** as shown below.

Figure 103. Selecting I2C to download the picture


You then have to click on the **Upload by I2C** button to launch the upload process (see [Figure 104](#)).

Figure 104. Downloading the picture by I2C


To download the picture by RF, click on **RF** as shown below.

Figure 105. Selecting RF to download the picture


You then have to click on the **Upload by RF** button to launch the upload process (see [Figure 106](#)).

Figure 106. Downloading the picture by RF

The application reads the contents of the EEPROM. A progress bar (shown in [Figure 107](#)) indicates that the process is running.

Figure 107. Progress bar

If the download process is successful, the picture is displayed on the screen like in [Figure 108](#). Otherwise, an error message appears (see [Figure 109](#)).

Figure 108. The ST logo is displayed**Figure 109. Error message**

You can use the CHECK COMMUNICATION area to verify whether the data were read successfully or not.


If you used the I2C bus to download the picture, click on **check I2C communication**. The color of the circle will tell you if the upload process was successful (green circle) or failed (red circle).

If you used the RF interface to download the picture, click on **check RF communication**. The color of the circle will tell you if the upload process was successful (green circle) or failed (red circle).

5 Demo application for use with DEMOKIT-M24LR-A

The demo application window, shown in [Figure 110](#), is intended for use with the DEMOKIT-M24LR-A kit. All the pictures are in the bitmap format to be compliant with the STM32-PRIMER2 firmware and LCD screen driver.

Figure 110. Demo STM32-PRIMER2 application window



5.1 Checking the RF communication

To check the RF communication between the reader and the reference antenna, press the **check RF communication** button (see [Figure 111](#)). The button changes to **running**. If the RF communication between the reader and the reference antenna is good, the circle is green like in [Figure 112](#). If there is no RF communication between the reader and the reference antenna, the circle appears red like in [Figure 113](#).

Figure 111. Check RF communication button



Figure 112. RF communication ongoing between reader and reference antenna




Figure 113. No RF communication between reader and reference antenna



5.2 Uploading a picture to your DEMOKIT-M24LR-A by RF

Use the frame shown below to upload a picture by RF.

Figure 114. Upload frame



Click on a picture to upload the picture in bmp format to the M24LR64-R by RF.

You can use the three additional icons on the right-hand side (HELLO WORLD, HALLO WELT...) to decrease the upload time (3 seconds versus 20 seconds).

5.3 Downloading a picture from your DEMOKIT-M24LR-A by RF

Press the **click to download Picture** button shown below to download a picture by RF. Once downloaded, the picture appears next to the button as shown in [Figure 116](#) and [Figure 117](#).

Figure 115. Click to download Picture button



Figure 116. HELLO WORLD picture downloaded



Figure 117. ST logo downloaded



5.4 Check communication status

You can use the CHECK COMMUNICATION area to verify whether the data were written or read successfully or not.

The green circle (*Figure 118*) indicates that the RF upload/download process is going smoothly.

The red circle (*Figure 119*) indicates that errors are occurring during the RF upload/download process.

Figure 118. Upload/download process going smoothly



Figure 119. Upload/download process with errors



5.5 Using your STM32-PRIMER2 to read the contents of the reference antenna by I2C

If the picture was uploaded by RF as described above, you will be able to display it on the LCD screen of your STM32-PRIMER2.

Please refer to the UM0850 user guide to configure your STM32-PRIMER2 and use the embedded software.

Enjoy your M24LR64-R kit!

6 Revision history

Table 1. Document revision history

Date	Revision	Changes
28-Jan-2010	1	Initial release.

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED ST REPRESENTATIVE, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2010 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com

