



1 Introduction

This user manual gives the procedures to install the different software drivers required to use your development, demonstration and starter kits.

It also gives a description of the development, demonstration and starter kits, and explains how to connect the RF and I²C readers to your computer.

Contents

1	Introduction	1
2	Installing the setup.exe	5
3	Installing the drivers specific to the development kit and demonstration kit	10
3.1	Step1: Installing the drivers for the medium-range RF reader	10
3.2	Step2: Installing the drivers for the I ² C serial bus reader (serial EEPROM USB reader)	21
3.3	Trouble shooting	29
3.3.1	RF reader driver	29
4	Tool kit descriptions	31
4.1	M24LR64-R's development kit	31
4.1.1	Ordering information	31
4.1.2	Development kit package	31
4.2	M24LR64-R's demonstration kit	33
4.2.1	Ordering information	33
4.2.2	Demonstration kit package	33
4.3	M24LR64-R's starter kit	35
4.3.1	Ordering information	35
4.3.2	Starter kit package	35
4.3.3	Connecting the readers and cables to your computer	37
4.3.4	Web support and references	38
5	Revision history	39

List of figures

Figure 1.	Setup - M24LRxx Application Software window	5
Figure 2.	License Agreement window	6
Figure 3.	Installation path.	6
Figure 4.	Creating the program shortcuts	7
Figure 5.	Location of the application icon	7
Figure 6.	Installing the user interface.	8
Figure 7.	Software README	8
Figure 8.	Software installation completion	9
Figure 9.	Messages that pop up when the RF reader is connected to the computer	10
Figure 10.	Welcome to the Found New Hardware Wizard window	11
Figure 11.	“Install from a list or specific location (Advanced)”	11
Figure 12.	Search and installation options.	12
Figure 13.	Hardware type	12
Figure 14.	Selecting the device driver	13
Figure 15.	Install from disk.	13
Figure 16.	Locate file	14
Figure 17.	Select the <i>obidusb.inf</i> file and Open	14
Figure 18.	Click “OK” to return to initial window	15
Figure 19.	The driver has been selected	15
Figure 20.	Driver installation process.	16
Figure 21.	Installation complete	16
Figure 22.	Start > Settings > Control Panel	17
Figure 23.	System Properties window	18
Figure 24.	Hardware tab	19
Figure 25.	Device Manager window.	20
Figure 26.	Popup message	21
Figure 27.	Welcome to the Found New Hardware Wizard window	21
Figure 28.	“Install from a list or specific location (Advanced)”	22
Figure 29.	Search and installation options.	22
Figure 30.	Selecting the device driver to install	23
Figure 31.	Browsing your computer	23
Figure 32.	File location.	24
Figure 33.	Instal from disk	24
Figure 34.	EEPROM USB drivers to be installed.	25
Figure 35.	Software installation	26
Figure 36.	Installation complete	27
Figure 37.	Device Manager window.	28
Figure 38.	Example where OBID is not correctly installed.	29
Figure 39.	Update Driver.....	30
Figure 40.	RF reader	31
Figure 41.	External antenna.	31
Figure 42.	I ² C bus reader (serial EEPROM USB reader).	32
Figure 43.	I ² C bus cable.	32
Figure 44.	ANT1-M24LR-A reference antenna	32
Figure 45.	ANT2-M24LR-A reference antenna	33
Figure 46.	M24LR64-R in SO8 package	33
Figure 47.	RF reader	34
Figure 48.	PRIM2-M24LR-A reference antenna	34

Figure 49.	STM32-PRIMER2	34
Figure 50.	Connecting your reference antenna to your STM32-PRIMER2	35
Figure 51.	I ² C & RF reader	35
Figure 52.	ANT1-M24LR-A reference antenna	36
Figure 53.	ANT2-M24LR-A reference antenna	36
Figure 54.	M24LR64-R in SO8 package	36
Figure 55.	External connector pinout of the serial I ² C bus reader	37
Figure 56.	External connector pinout of the M24LR64-R tag.	37
Figure 57.	Connecting the RF and I ² C bus readers	38

2 Installing the *setup.exe*


The *setup.exe* file is used to install all the drivers required by the *M24LRxx_Application_Software* on your computer.

This *setup.exe* file has to be installed for the development, demonstration and starter kits.

Caution: Please do NOT connect the USB cable(s) to your computer now.


- Double click on the *setup.exe* file. The window shown in *Figure 1* appears. Click on "Next >" to continue.

Figure 1. Setup - M24LRxx Application Software window




- Read the License Agreement and click on “I accept the agreement” if you agree (see [Figure 2](#)).

Figure 2. License Agreement window




- Browse your computer to select the path where you want to install this software (see [Figure 3](#)). Then click on Next.

Figure 3. Installation path




- A new window opens to create the application shortcuts. By default, select “Next”, otherwise, browse your computer (see [Figure 4](#)).

Figure 4. Creating the program shortcuts




- Define the type of icon you want then click “Next” (see [Figure 5](#)).

Figure 5. Location of the application icon




- Install the user Interface software of the M24LR64-R tools (see [Figure 6](#)).

Figure 6. Installing the user interface




- The README information of the software is then displayed as shown in [Figure 7](#). Please read it carefully.

Figure 7. Software README



- The first step of the installation process is over!

Figure 8. Software installation completion



What is the status now?

- The *M24LRxx_Application_Software* is now installed on your computer
- You still have to install the drivers as described in [Section 3: Installing the drivers specific to the development kit and demonstration kit](#).

3 Installing the drivers specific to the development kit and demonstration kit


This section describes how to install the drivers allowing your computer to interface the RF reader and the I²C serial bus reader through the USB ports.

Note: The starter kit does not need any specific installation driver.

3.1 Step1: Installing the drivers for the medium-range RF reader

You should first power up the RF reader and connect its USB cable to your computer. The RF reader is then detected, and the popup messages shown in [Figure 9](#) appear.

Figure 9. Messages that pop up when the RF reader is connected to the computer



The “Found New Hardware Wizard” then starts up and you should follow the procedure described below:


1. The “Welcome to the Found New Hardware Wizard” window opens (see [Figure 10](#)). Select “Yes, this time only”, and click on “Next >”.

Figure 10. Welcome to the Found New Hardware Wizard window




2. In the next window (see [Figure 11](#)), select “Install from a list or specific location (Advanced)”, and click on “Next >”.

Figure 11. “Install from a list or specific location (Advanced)”




3. As shown in [Figure 12](#), select “Don’t search. I will choose the driver to install.”, and click on “Next >”.

Figure 12. Search and installation options




4. Then, like in [Figure 13](#), select “Show All Devices”, and click on “Next >”.

Figure 13. Hardware type




5. In the next window (see [Figure 14](#)), click on “Have Disk...”.

Figure 14. Selecting the device driver




6. Then, click on “Browse...” to locate the file (see [Figure 15](#) and [Figure 16](#)).

Figure 15. Install from disk



7. Select the *ObidUsb.inf* file in the install directory. The default path is:
C:/Program File/M24LRxx_Application_Software/Driver/OBID USB driver/

Figure 16. Locate file

Click on "Open" (see [Figure 17](#)) and then on "OK" (see [Figure 18](#))



Figure 17. Select the *obidusb.inf* file and Open

Figure 18. Click “OK” to return to initial window

8. The window now displays the OBID drivers that have been selected (see [Figure 19](#)). Click on “Next >” to install the driver (see [Figure 20](#)).


Figure 19. The driver has been selected

Figure 20. Driver installation process

9. When the installation is complete, click on “Finish” (see [Figure 21](#)).

Figure 21. Installation complete


The drivers allowing your computer to interface the RF reader are now installed. The following step is described in [Section 3.2: Step2: Installing the drivers for the I²C serial bus reader \(serial EEPROM USB reader\)](#).

Advanced information

You can verify that the medium-range RF reader drivers are correctly installed. OBID USB Devices should be detected when the medium-range RF reader is plugged into your computer's USB port.


To check that the drivers are correctly installed, go to Start/Settings/Control Panel as shown in [Figure 22](#).

Figure 22. Start > Settings > Control Panel




In the Control Panel folder, double click on System. This causes the System Properties window to open (see [Figure 23](#)).

Figure 23. System Properties window




Then click on the Hardware tab and then on Device Manager as shown in [Figure 24](#).

Figure 24. Hardware tab



The Device Manager window opens (see [Figure 25](#)). “OBID USB Devices” should be present.

Figure 25. Device Manager window




3.2 Step2: Installing the drivers for the I²C serial bus reader (serial EEPROM USB reader)

Note that if you do not have to use the serial EEPROM USB reader, you do not need to install these drivers.

To install the drivers: first, connect the USB cable between the I²C serial bus reader and your computer. The I²C bus reader is then detected and the following popup message appears (see [Figure 26](#)).

Figure 26. Popup message



The “Found New Hardware Wizard” then starts up and you should follow the procedure described below:


10. The “Welcome to the Found New Hardware Wizard” window opens (see [Figure 27](#)). Select “Yes, this time only”, and click on “Next >”.

Figure 27. Welcome to the Found New Hardware Wizard window




11. In the next window (see [Figure 28](#)), select “Install from a list or specific location (Advanced)”, and click on “Next >”.

Figure 28. “Install from a list or specific location (Advanced)”




12. As shown in [Figure 29](#), select “Don’t search. I will choose the driver to install.”, and click on “Next >”.

Figure 29. Search and installation options




13. In the next window (see [Figure 30](#)), uncheck the box in front of “Show compatible hardware” and click on “Have Disk...”.

Figure 30. Selecting the device driver to install



14. Then, click on “Browse...” to locate the file (see [Figure 15](#) and [Figure 16](#)).

Figure 31. Browsing your computer



15. Browse your computer for the `Serial_EEPROM_USB_Reader_driver.inf` file. The default path is:

C:/Program File/M24LRxx_Application_Software/driver/Serial EEPROM USB Reader Driver/

Select the *Serial_EEPROM_USB_Reader_driver.inf* file and then click on “Open” (see [Figure 32](#)) and “OK” (see [Figure 33](#))

Figure 32. File location






Figure 33. Instal from disk



16. The window now displays the EEPROM USB drivers that have been selected (see [Figure 34](#)). Click on “Next >” to install the driver (see [Figure 35](#)).

Figure 34. EEPROM USB drivers to be installed



17. During the installation, a new windows appears to inform you that the driver was not certified by Microsoft®. Click on “Continue Anyway”. When the installation is complete, click on “Finish” (see [Figure 36](#)).

Figure 35. Software installation






Figure 36. Installation complete

The drivers allowing your computer to interface the I²C bus reader are now installed.

Advanced information

You can check that the I²C bus reader drivers are installed by going to Start/Settings/Control Panel/System. Click on the Hardware tab and then on Device Manager. In the Device Manager the I²C bus reader should be shown as a USB peripheral (defined as *Serial EEPROM USB Reader*, as shown in [Figure 36](#)).

Figure 37. Device Manager window




3.3 Troubleshooting

3.3.1 RF reader driver

You can check that the drivers for the RF and I²C bus readers are correctly installed by viewing the “Device Manager” window.


In the example shown in [Figure 38](#), you can see that the OBID is not correctly installed.

Figure 38. Example where OBID is not correctly installed



Right-click on “OBID RCI” and select “Update Driver...” as shown in [Figure 39](#).

Figure 39. Update Driver...



You can now try to reinstall the reader drivers, as explained in [Section 3.1: Step1: Installing the drivers for the medium-range RF reader](#) for the RF reader, and in [Section 3.2: Step2: Installing the drivers for the I²C serial bus reader \(serial EEPROM USB reader\)](#) for the I²C reader).

4 Tool kit descriptions

4.1 M24LR64-R's development kit

4.1.1 Ordering information

The part number of the development kit is: **DEVKIT-M24LR-A**.

4.1.2 Development kit package

The development kit contains:

- a middle-range RF reader (ISO 15693, RF 13.56 MHz) interfaced via the USB bus and an external power supply to have a greater read range.

Figure 40. RF reader



- an external antenna shown in [Figure 41](#).


Figure 41. External antenna



- Serial EEPROM USB reader: I²C bus reader (interfaced via the USB bus). [Figure 42](#) shows the reader.

Figure 42. I²C bus reader (serial EEPROM USB reader)

- An I²C bus cable to connect the serial EEPROM USB reader and the I²C bus of the reference antenna. [Figure 43](#) shows the cable to use.

Figure 43. I²C bus cable

- M24LR64-R's reference antennas:
 - ANT1-M24LR-A: RF antenna size: 75 mm × 45 mm (2.9 in × 1.77 in) shown in [Figure 44](#).
 - ANT2-M24LR-A: RF antenna size: 20 mm × 40 mm (0.79 in × 1.57 in) shown in [Figure 45](#).




Figure 44. ANT1-M24LR-A reference antenna

Figure 45. ANT2-M24LR-A reference antenna

- M24LR64-R samples in SO8 package (see [Figure 46](#)).

Figure 46. M24LR64-R in SO8 package

4.2 M24LR64-R's demonstration kit

4.2.1 Ordering information

The part number of the demonstration kit is: **DEMOKIT-M24LR-A**.

4.2.2 Demonstration kit package

The demonstration kit contains:

- a middle-range RF reader (ISO 15693, RF 13.56 MHz) interfaced via the USB bus, shown in [Figure 47](#).
- an M24LR64-R's reference antenna: PRIM2-M24LR-A, RF antenna size: 20 mm x 40 mm (0.79 in x 1.57 in) shown in [Figure 48](#).
- Optional: STM32-PRIMER2 (to be ordered separately) shown in [Figure 49](#).

Figure 47. RF reader



Figure 48. PRIM2-M24LR-A reference antenna




Figure 49. STM32-PRIMER2



1. Not included in the kit, to be ordered separately.

Figure 50. Connecting your reference antenna to your STM32-PRIMER2

4.3 M24LR64-R's starter kit

4.3.1 Ordering information

The part number of the starter kit is: STARTKIT-M24LR-A

4.3.2 Starter kit package

The starter kit contains:

- a reader with an integrated solution for I²C communication (connector) and RF communication (ISO 15693, RF 13.56 MHz) interfaced with a USB bus as shown in [Figure 51](#).

Figure 51. I²C & RF reader

- M24LR64-R's reference antennas:
 - ANT1-M24LR-A: RF antenna size: 75 mm × 45 mm (2.9 in × 1.77 in) shown in [Figure 44](#).
 - ANT2-M24LR-A: RF antenna size: 20 mm × 40 mm (0.79 in × 1.57 in) shown in [Figure 45](#).

Figure 52. ANT1-M24LR-A reference antenna






Figure 53. ANT2-M24LR-A reference antenna



- M24LR64-R samples in SO8 package (see [Figure 46](#)).

Figure 54. M24LR64-R in SO8 package



4.3.3 Connecting the readers and cables to your computer

Once the installation of the software drivers is complete (see previous sections [Installing the setup.exe](#) and [Installing the setup.exe](#)), you have to physically connect the readers.

Connecting the RF reader

- first, connect the external antenna to the RF reader
- then, connect the power supply of the RF reader
- you can now connect the RF reader to the USB port of your computer

The RF reader is ready to be used. Keep your tag on the external antenna to communicate through the application software.

Connecting the I²C bus reader

- First, connect the I²C bus reader to the USB port of your computer
- then connect the I²C cable from the I²C bus reader to an M24LR64-R tag

Figure 55. External connector pinout of the serial I²C bus reader




Figure 56. External connector pinout of the M24LR64-R tag





Figure 57. Connecting the RF and I²C bus readers

4.3.4 Web support and references

ST products (M24LR64-R datasheet, application notes, etc.)
Serial EEPROM USB reader
Software

For further information and copies of the available technical documentation, please contact your nearest ST sales office.

FEIG ELECTRONICS RF readers

<http://www.obid.eu/>

<http://www.feig.de/>

eStar RF & I²C reader

<http://www.estarcorp.net/en/index.asp>

STM32-PRIMER2

<http://www.raisonance.com/>

<http://www.stm32circle.com/>

You can now enjoy your kit!

5 Revision history

Table 1. Document revision history

Date	Revision	Changes
30-Nov-2009	1	Initial release.

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED ST REPRESENTATIVE, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2009 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com