

Couplings



- · Bellow type couplings are recommended as an inexpensive type of coupling
- · They are also suitable to compensate larger angular displacements
- · Spring washer type couplings for high speed applications
- · Easy to mount, two parts

Description and applications

Manufacturing and installation tolerances as well as the effects of temperature cause alignment errors between shafts in drive engineering which can sometimes lead to extreme overload on the bearings.

This may result in increased wear of the bearings and may lead to premature failure of the encoder. By using couplings, these

Areas of application:

Metal bellows-type couplings (.1101 and 1201) are recommended as an inexpensive type of coupling. They are also suitable for compensating larger angle displacements.

Installation instructions:

- 1. Check shaft for displacement; See technical data for details
- 2. Align and adjust coupling on shafts.

alignment errors can be compensated, thereby reducing the load on the bearings to a minimum.


A distinction should be made between three different kinds of alignment error: radial, angular and axial displacement. Whilst with torsion-free but bendable shaft

couplings, axial shaft displacements

Spring washer-type couplings (.1300 and .1401) are used mainly in those cases where high speeds and smaller angular displacements are involved. For applications where

produce only static forces in the coupling, radial and angular displacements produce alternating stresses, restoring forces and moments which may have an impact on adjoining components (shaft bearings). Depending on the type of coupling, particular attention should be paid to radial shaft displacement which should be kept to a minimum.

electrical insulation between rotary encoder and drive is required, the electrically insulating spring whasher-type coupling should be used.



- 3. Tighten locking screws carefully. Avoid overtightening.
- 4. During installation protect the coupling from damage and from overbending.

1/2006

Technical data

Туре		8.0000.1101.XXXX	8.0000.1201.XXXX	8.0000.1301.XXXX	8.0000.1401.XXXX	8.0000.1501.XXXX
Max. speed	min ⁻¹	12000	12000	12000	12000	12000
Max. torque	Ncm	150	50	80	60	200
Max. radial displacement	mm	± 0.2	± 0.2	± 0.4	± 0.3	± 0.2
Max. angular displacement	Grad	± 1.5	± 1.5	± 3	± 2.5	± 1.5
Max. axial displacement	mm	± 0.7	± 0.5	± 0.4	± 0.4	± 0.6
Torsion spring parameter	Ncm/Grad	700	210	150	55	1300
Moment of inertia	gcm ²	5.5	1.2	19	35	18
Weight approx.	g	14	6	16	30	24
Material: Flange		Al	Al	Al cu Mg Pb	diecast Zinc	Al
Bellow or spring washer/casing		stainless steel	stainless steel	Cu Sn 6 Vern.	PA 6,6 20% gf	stainless stee
Diameter d/d1 from to	mm	312	39	38	416	316
Max. tightening torque						
of locking screws	Ncm	150	70	80	80	180
Standard bore	mm	12/12	8/6	6/6	12/12	15/12
diameter		12/10 10/10	6/6 6/4	6/4	12/10 10/10	14/12 14/10
		6/6	4/4		10/10	06/14
		0/0	10/8		6/6	00/14
			10/0		3/8"/10	
					3/8"/6	
					1/4"/10	
MO					1/4"/6	1/200

Downloaded from Elcodis.com electronic components distributor


Accessories



Couplings


Bellows-type coupling

Order code 8.0000.1501.XXXX




Spring washer coupling

Order code 8.0000.1300.XXXX




Bellows-type coupling

Order code 8.0000.1101.XXXX




Spring washer coupling

Order code 8.0000.1401.XXXX



Bellows-type coupling

Order code 8.0000.1201.XXXX



Order code:

Type of coupling

- Bellows-type ø 19 mm
- 2 Bellows-type ø 15 mm
- 3 Spring washer type
- Spring washer type*
- Bellows-type ø 25 mm
 - * electronically isolated

8.0000.1X0X.XXXX Bore diameter d₂ see table

Bore diameter d₁

e.g.: $d_1 = 10 \text{ mm}$ and $d_2 = 12 \text{ mm}$

=> XXXX.XXXX.101²⁾

for the bore diameter $d_1 = 3/8"$ Code = A1

 $d_1 = 1/4"$ Code = A2

Example: Coupling type 1401:

 $d_1 = 3/8"$ and $d_1 = 10$ mm:

Order-Code = 1401.A110