

MB3A

BiSS to PC-LPT ADAPTER



Release A1, Page 1/2

ORDERING INFORMATION

Type	Order Designation	Description / Options
BiSS to PC-LPT Adapter	MB3A	Protocol converter for connecting BiSS/SSI sensors to the LPT port on a PC
		Scope of delivery: ready-to-use adapter; LPT device driver (Win 98/ME, 2000/XP) and BiSS master PC software for downloading


DESCRIPTION

The BiSS to PC-LPT Adapter enables BiSS or SSI sensors to be connected to a PC easily and at low cost.

The parallel printer port is used as hardware link, whereas by software an SPI compatible data communication is emulated, granting a speedy measurement data transmission and the configuration of the adapter. Regarding the sensor side BiSS/SSI communication is carried out via differential RS422 lines, optionally via single ended signals when removing a jumper.

Technical Data

- ◆ Synchronously triggered measurement data collection from up to 3 BiSS sensors or one SSI encoder
- ◆ BiSS data rates up to 10 Mbit/sec., SSI up to 4 Mbit/sec.
- ◆ Protocol compatible with BiSS Master iC-MB3
- ◆ Connection to the PC parallel printer port
- ◆ Operates from a single 5 V voltage supplied via the sensor connection or solder terminals



Size approx. 50 mm x 70 mm

BiSS Plug Pin Configuration J2 (9-pole SUB-D)

Pin	Name	Function
1	VB	not wired
2	MA +	Clock output P
3	MA -	Clock output N
4	VDD	+5 V Adapter supply voltage* (supply current ca. 90 mA)
5	MO -	+5 V High-level signal (Optional: master data output N)
6	GND	Ground (0V)
7	SL +	Data input P
8	SL -	Data input N
9	MO +	0 V Low-level signal (Optional: master data output P)

*) This operating voltage is supplied by iC-Haus demo boards.

MB3A

BiSS to PC-LPT ADAPTER



Release A1, Page 2/2

PC Plug Pin Configuration J1 (25-pole SUB-D)

Pin	LPT Name	Signal	Function
1	nStrobe	ALE	Address latch enable Input
2	Data0	n/a	
...	
9	Data7	n/a	
10	nAck	n/a	
11	Busy	DB1-SO	SPI data output
12	PaperOut	EOT	End-of-transmission output
13	Select	NER	Error message (active low)
14	LineFeed	DB0-SI	SPI data input
15	nError	n/a	
16	nInitialize	NCS	Chip select input
17	nSelect	n/a	
18	GND	GND	Ground
...	
25	GND	GND	Ground

Wiring circuit




Fig. 1: MB3A schematic diagram. Jumper JP3_2 can be removed to enable single-ended SL line communication. (U3 is not assembled).

This specification is for a newly developed product. iC-Haus therefore reserves the right to change or update, without notice, any information contained herein, design and specification; and to discontinue or limit production or distribution of any product versions. Please contact iC-Haus to ascertain the current data. Copying - even as an excerpt - is only permitted with iC-Haus approval in writing and precise reference to source. iC-Haus does not warrant the accuracy, completeness or timeliness of the specification on this site and does not assume liability for any errors or omissions in the materials. The data specified is intended solely for the purpose of product description. No representations or warranties, either express or implied, of merchantability, fitness for a particular purpose or of any other nature are made hereunder with respect to information/specification or the products to which information refers and no guarantee with respect to compliance to the intended use is given. In particular, this also applies to the stated possible applications or areas of applications of the product. iC-Haus conveys no patent, copyright, mask work right or other trade mark right to this product. iC-Haus assumes no liability for any patent and/or other trade mark rights of a third party resulting from processing or handling of the product and/or any other use of the product.