Xircom® Products
Support for Xircom Products in Windows* XP

Windows* XP support for a given Xircom® product falls into one of three categories, depending on the product in question. These categories are defined as follows:

- **Xircom Drivers for Windows XP**
  Products for which Windows XP specific drivers have been developed and are available from the Intel web site. *Drivers for XP will not be developed for most Xircom products.* Xircom products for which XP drivers have been developed are noted in the table below.

- **Microsoft Drivers Included With Windows XP**
  Products for which drivers have been incorporated by Microsoft, and included as part of the Windows XP operating system. In most cases the products should install and function without any difficulty using these built-in drivers. *These drivers have not been tested by Intel.* If Xircom drivers are available for your product, then only those drivers are supported with your product.

- **Products For Which No Drivers or Support Is Available**

Note: Windows* 2000 Drivers May Work in XP
In cases where specific Windows XP drivers are not available for a given product, it may be possible to use the NDIS5 drivers that are intended for use with Windows 2000. Such drivers may operate successfully in Windows XP. However, these drivers have not been tested in Windows XP, the results are not guaranteed, and this configuration is not supported.

Technical Support (see table below)

- **Xircom Driver fully supported**
  Products for which we have released Windows XP drivers will receive full technical support.

- **No XP Support**
  No phone, fax, email, or web support is offered for these products.

Product	Xircom Drivers for Windows XP	Microsoft Drivers Included with Windows XP	Technical Support
Xircom® 10/100 Network PC Card Adapter *(XE2000)*	no	no	no XP Support
Xircom® 10/100 Network+Modem 56 PC Card Adapter *(XEM5600)*	no	no	no XP Support
Xircom® CardBus Ethernet 10/100 Adapter *(CBE-10/100BTX)*	yes (xbe314-2.exe)	yes	Xircom Driver fully supported
Xircom® CardBus Ethernet 10/100+Modem 56 GlobalACCESS Adapter *(CBEM56G-100)*	yes (xbem_314-2.exe)	yes	Xircom Driver fully supported
Xircom® CardBus Ethernet II 10/100 Adapter *(CBE2-100)*	yes (xbe314-2.exe)	yes	Xircom Driver fully supported
Xircom® CardBus ISDN Connection Kit *(CBICK)*	no	no	no XP Support
Xircom® Cellular Analog Connection Kit** *(CCK2-MOT-1)*	no	no	no XP Support
Xircom® Cellular Analog Connection Kit** *(CCK-33ATT)*	no	no	no XP Support
Xircom® Cellular Analog Connection Kit** *(CCK-33MOT)*	no	no	no XP Support
Xircom® StarTAC Cellular Analog Connection Kit** *(CCK-33MOT)*	no	no	no XP Support
Xircom® Cellular Analog Connection Kit** *(CCK-56MOT)*	no	no	no XP Support
Xircom® Elite Cellular Analog Connection Kit** *(CCK-56MOT)*	no	no	no XP Support
Xircom® StarTAC Cellular Analog Connection Kit** *(CCK-56MOT)*	no	no	no XP Support
Xircom® CreditCard Ethernet Adapter *(CE/A)*	no	no	no XP Support
Xircom® CreditCard Ethernet Adapter *(CE10)*	no	no	no XP Support
Xircom® CreditCard 56K Modem Adapter *(CM-56)*	no	yes	no XP Support
Xircom® CreditCard 56K Modem Adapter *(CM56T)*	no	yes	no XP Support
Xircom® CompactCard 56K GlobalACCESS Modem Adapter *(CFM56G)*	no	no	no XP Support
Xircom® CompactCard Ethernet 10 Adapter *(CFE-10)*	no	no	no XP Support
Xircom® CompactCard GSM Adapter *(CFGSM)*	no	no	no XP Support
Xircom® CreditCard 28.8K Modem Adapter *(CM-28)*	no	no	no XP Support
Xircom® CreditCard 33.6K GlobalACCESS Modem Adapter *(CM-33I, CM-33G)*	no	no	no XP Support
Xircom® CreditCard 33.6K Modem Adapter *(CM33)*	no	no	no XP Support
Xircom® CreditCard 33.6K Upgradeable Modem Adapter *(CM-33U)*	no	no	no XP Support
Xircom® CreditCard 56K GlobalACCESS Modem Adapter *(CM56G)*	no	yes	no XP Support
Xircom® CreditCard Bluetooth Adapter *(CBT)*	yes (bluetooth_v1.10.exe)	yes	Xircom Driver fully supported
Xircom® CreditCard Ethernet 10 Adapter *(CE3-10)*	no	yes	no XP Support
Xircom® CreditCard Ethernet 10/100 Adapter *(CE3B-100BTX)*	no	yes	no XP Support
Xircom® CreditCard Ethernet 10/100+Modem 56 Adapter *(CEM56-100)*	no	yes	no XP Support
Xircom® CreditCard Ethernet II Adapter *(CE2, PS-CE2-10)*	no	yes	no XP Support
Xircom® CreditCard Ethernet+Modem 28.8 Adapter *(CEM28, CEM-28)*	no	yes	no XP Support
Xircom® CreditCard Ethernet+Modem 33.6 Adapter *(CEM33)*	no	yes	no XP Support
Xircom® CreditCard Ethernet+Modem 33.6 GlobalACCESS Adapter *(CEM33I)*	no	yes	no XP Support
Xircom® CreditCard Ethernet+Modem Adapter *(CEM-10)*	no	no	no XP Support
Xircom® CreditCard Ethernet+Modem II Adapter *(CEM2)*	no	no	no XP Support
Xircom® CreditCard GSM Adapter *(CGSM)*	no	yes	no XP Support
Xircom® CreditCard ISDN Adapter *(CI-Euro)*	no	yes	no XP Support
Xircom® CreditCard ISDN Connection Kit *(CICK)*	no	no	no XP Support
Xircom® CreditCard NetWave Adapter *(CNW)*	no	no	no XP Support
Xircom® CreditCard Token Ring Adapter *(CT-16CTP)*	no	no	no XP Support
Xircom® CreditCard Token Ring II Adapter *(CT2-16CTP, PS-CT2-16)*	no	no	no XP Support
Xircom® CreditCard Token Ring+Modem 33.6 Adapter *(CTM-33CTP)*	no	no	no XP Support
Xircom® CreditCard Wireless Ethernet Adapter *(CWE-1120)*	---->	click here	<-----
Xircom® CreditCard Wireless Ethernet Adapter *(CWE-1130)*	---->	click here	<-----
Xircom® External Ethernet Adapter *(EE10BU)*	no	no	no XP Support
Xircom® External Token Ring Adapter *(ET)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-56ERI-1)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-56ERI-2)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-56ERI-3)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-56ERI-4)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-ERI-2)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-ERI-3)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-ERI-4)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(SMCK2-NOK-1)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-NOK-3)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-SIE-3)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK2-SIE-4)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK-56NOK-1)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK-56NOK-2)*	no	no	no XP Support
Xircom®GSM Connection Kit** *(GSMCK-56NOK-3)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK-56SIE-1)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK-56SIE-2)*	no	no	no XP Support
Xircom® GSM Connection Kit *(GSMCK-56SIE-3)*	no	no	no XP Support
Xircom® GSM Connection Kit** *(GSMCK-56SIE-4)*	no	no	no XP Support
Xircom® MiniPCI Ethernet 10/100+Modem 56 GlobalACCESS Adapter *(MPCI3A56G-100P)*	no	no	no XP Support
Xircom® MultiPort 4 Port Modem Adapter *(MPM-4)*	no	no	no XP Support
Xircom® MultiPort 8 Port Modem Adapter *(MPM-8)*	no	no	no XP Support
Xircom® NetStation 4 Port Switch *(NSE4100)*	no	no	no XP Support
Xircom® NetStation 8 Port Switch *(NSE8100)*	no	no	no XP Support
Xircom® NetWave Wireless Access Point *(NWAP)*	no	no	no XP Support
Xircom® Parallel Port Multiplexor *(PPX)*	no	no	no XP Support
Xircom® Parallel Port Multiplexor II *(PPX-02)*	no	no	no XP Support
Xircom® Parallel Port Multiplexor III *(PPX-03)*	no	no	no XP Support
Xircom® PDC Connection Kit *(PDCCK)***	no	no	no XP Support
Xircom® PDC Connection Kit 2 *(PDCCK2)***	no	no	no XP Support
Xircom® Pocket 3270 Adapter *(P3270)*	no	no	no XP Support
Xircom® Pocket Arcnet Adapter *(PA0286-8K)*	no	no	no XP Support
Xircom® Pocket Arcnet II Adapter *(PA-2)*	no	no	no XP Support
Xircom® Pocket Ethernet Adapter *(PE10Bx)*	no	no	no XP Support
Xircom® Pocket Ethernet II Adapter *(PE2)*	no	no	no XP Support
Xircom® Pocket Ethernet III Adapter *(PE3-10Bx)*	no	no	no XP Support
Xircom® Pocket Ethernet Print Server *(PEPS)*	no	no	no XP Support
Xircom® Pocket Ethernet Print Server II *(PEPS2)*	no	no	no XP Support
Xircom® Pocket Ethernet+Modem Adapter *(PEM-10BT)*	no	no	no XP Support
Xircom® Pocket EtherTalk Adapter *(PET)*	no	no	no XP Support
Xircom® Pocket Token Ring Adapter *(PT0483-128K)*	no	no	no XP Support
Xircom® Pocket Token Ring II Adapter *(PT2)*	no	no	no XP Support
Xircom® Pocket Token Ring III Adapter *(PT3-16CTP)*	no	no	no XP Support
Xircom® Pocket Token Ring Print Server *(PTPS)*	no	no	no XP Support
Xircom® Pocket Token Ring Print Server II *(PTPS2)*	no	no	no XP Support
Xircom® PortGear 2 Port PCI to USB Expansion Card *(PCI-2U, PGPCI2)*	no	no	no XP Support
Xircom® PortGear 4 Port Multifunction USB Hub *(HUB-2U1S1P, PGMHUB4)*	no	no	no XP Support
Xircom® PortGear 4 Port PCI to USB Expansion Card *(PCI-4U, PGPCI4)*	no	no	no XP Support
Xircom® PortGear 4 Port USB Hub *(MAC-HUB-4U, PGHUB4, HUB-4U)*	no	no	no XP Support
Xircom® PortGear 6 Port Multifunction USB Hub *(HUB-2U4S, PGMHUB6)*	no	no	no XP Support
Xircom® PortGear 7 Port Multifunction USB Hub *(HUB-4U2S1P, PGMHUB7)*	no	no	no XP Support
Xircom® PortGear 7 Port USB Hub *(MAC-HUB-7U, PGHUB7, HUB-7U)*	no	no	no XP Support
Xircom® PortGear Ethernet Adapter + 3 Port USB Hub *(HUB-3U1E, PGFHUB01)*	no	no	no XP Support
Xircom® PortGear Mac Dock Multifunction USB Hub *(MAC-USB-DOCK, PGMFHUB)*	no	no	no XP Support
Xircom® PortGear USB To 25 pin Serial Converter *(U1-S25, PGSDB25)*	no	no	no XP Support
Xircom® PortGear USB To 9 pin Serial Converter *(U1-S9, PGSDB9)*	no	no	no XP Support
Xircom® PortGear USB To Ethernet Adapter *(U1-E45, PGENET10)*	no	no	no XP Support
Xircom® PortGear USB to Mac DIN8-Serial Converter *(U1-D8, PGMSD8)*	no	no	no XP Support
Xircom® PortGear USB To Parallel Printer Converter *(U1-P36, PGPC36)*	no	no	no XP Support
Xircom® PortGear USB To SCSI Converter *(U1-SCSI, PGSCSI)*	no	no	no XP Support
Xircom® PortGear USBnet (USB to USB) Network Adapter *(U1-U1, PGUNET)*	no	no	no XP Support
Xircom® PortStation 4 Port USB Hub Module *(STUH4)*	no	no	no XP Support
Xircom® PortStation 56K GlobalACCESS Modem Adapter Module *(STM56G)*	no	no	no XP Support
Xircom® PortStation 56K Modem Adapter Module *(STM56V)*	no	no	no XP Support
Xircom® PortStation 7 Port USB Hub Module *(STUH7)*	no	no	no XP Support
Xircom® PortStation Parallel Module *(STDB25)*	no	no	no XP Support
Xircom® PortStation Dual 9-pin Serial Module *(STDB92)*	no	no	no XP Support
Xircom® PortStation Dual PS2 Module *(STPS22)*	no	no	no XP Support
Xircom® PortStation End Cap *(STTERM)*	no	no	no XP Support
Xircom® PortStation Ethernet 10 Module *(STE10)*	no	no	no XP Support
Xircom® PortStation Parallel Module *(STDB25)*	no	no	no XP Support
Xircom® RealPort 56K GlobalACCESS Modem Adapter *(RM56G)*	no	yes	no XP Support
Xircom® RealPort Cardbus 56K GlobalACCESS Modem Adapter *(RBM56G)*	no	yes	no XP Support
Xircom® RealPort CardBus Ethernet 10/100 Adapter *(RBE-100)*	yes (xbe314-2.exe)	yes	Xircom Driver fully supported
Xircom® RealPort CardBus Ethernet 10/100+Modem 56 GlobalACCESS Adapter *(RBEM56G-100)*	yes (xbem_314-2.exe)	yes	Xircom Driver fully supported
Xircom® RealPort Cellular Analog Connection Kit** *(RCCK-MOT-1)*	no	no	no XP Support
Xircom® RealPort Ethernet 10 Adapter *(RE-10)*	no	no	no XP Support
Xircom® RealPort Ethernet 10/100 Adapter *(RE-100)*	no	yes	no XP Support
Xircom® RealPort Ethernet 10/100+Modem 56 GlobalACCESS Adapter *(REM56G-100)*	no	yes	no XP Support
Xircom® RealPort Ethernet 10+Modem 56 GlobalACCESS Adapter *(REM56G-10)*	no	yes	no XP Support
Xircom® RealPort ISDN Connection Kit *(RICK)*	no	no	no XP Support
Xircom® RealPort PDC Connection Kit** *(RPDCCK)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-ERI-2)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-ERI-3)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-ERI-4)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-NOK-1)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-NOK-3)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-SIE-3)*	no	no	no XP Support
Xircom® RealPort GSM Connection Kit** *(RGSMCK-SIE-4)*	no	no	no XP Support
Xircom® RealPort2 56K GlobalACCESS Modem Adapter *(R2M56GA)*	no	yes	no XP Support
Xircom® RealPort2 Bluetooth Adapter *(R2BT)*	yes (bluetooth_v1.10.exe)	no	Xircom Driver fully supported
Xircom® RealPort2 CardBus Ethernet 10/100 Adapter *(R2BE-100)*	yes (xbe314-2.exe)	yes	Xircom Driver fully supported
Xircom® RealPort2 CardBus Ethernet 10/100+Modem 56 GlobalACCESS Adapter *(R2BEM56G)*	yes (xbem_314-2.exe)	yes	Xircom Driver fully supported
Xircom® RealPort2 Ethernet 10/100 Adapter *(R2E-100BTX)*	no	yes	no XP Support
Xircom® RealPort2 ISDN Adapter *(R2I)*	no	no	no XP Support
Xircom® RealPort2 WinGlobal CardBus 56K Modem Adapter *(R2BM56WG)*	no	yes	no XP Support
Xircom® RealPort2 Win-GlobalACCESS CardBus 56K Modem Adapter *(R2BM56WGA)*	no	yes	no XP Support
Xircom® RealPort2 WinSwift CardBus 56K Modem Adapter *(R2BM56W)*	no	yes	no XP Support
Xircom® RealPort2 Wireless Data Adapter *(R2WD)*	no	no	no XP Support
Xircom® REX 5000	no	no	no XP Support
Xircom® REX 5001	no	no	no XP Support
Xircom® REX 5500	no	no	no XP Support
Xircom® REX 6000	no	no	no XP Support
Xircom® REX-3	no	no	no XP Support
Xircom® REX-PRO5	no	no	no XP Support
Xircom® RealPort 56K Modem Adapter *(RM56V1)*	no	yes	no XP Support
Xircom® RealPort 56K Modem Adapter *(RM56V2)*	no	yes	no XP Support
Xircom® RealPort 56K Modem Adapter *(RM56V3)*	no	yes	no XP Support
Xircom® SpringPort 56K GlobalACCESS Modem Adapter Module *(SM56GA)*	no	no	no XP Support
Xircom® SpringPort Wireless Data Module *(SWD)*	no	no	no XP Support
Xircom® SpringPort Wireless Ethernet Adapter Module *(SWE1130)*	no	no	no XP Support
Xircom® WinGlobal CardBus 56K Modem Adapter *(CBM56WG)*	no	yes	no XP Support
Xircom® WinSwift CardBus 56K Modem Adapter *(CBM56W)*	no	yes	no XP Support
Xircom® Wireless Ethernet Access Point *(APWE1120)*	---->	click here	<-----
Xircom® Wireless LAN Module for Palm Handhelds *(PWE1130)*	no	no	no XP Support
Xircom® 56K PC Card Modem Adapter *(XM5600)*	no	no	no XP Support
Xircom® 56K PC Card Modem Adapter *(XM5620)*	no	no	no XP Support

Troubleshooting Tips

There are a few common situations in which difficulty with these products under Windows XP may be encountered. Please check into these issues prior to contacting Intel Technical Support:

- Lack of proper system BIOS support for Windows XP. Check with your computer manufacturer for information on possible system BIOS upgrades or other modifications that may be required in order for Windows XP to run properly on your computer.
- Lack of support for ACPI power management. Check with your computer manufacturer for information about patches or changes that may be required to fully support ACPI.
- Lack of available resources (especially free interrupts) to support additional hardware. Some computers may be configured so that all available resources are already in use. In such cases disabling certain embedded devices in the system BIOS (such as Infra-red ports or other serial devices) may free up resources for use by other devices.

**This connection kit uses no drivers. It should work as long as the Xircom card it attaches to will work in Windows XP.

©2005 Intel Corporation

Downloaded from Elcodis.com electronic components distributor