




APPLICATION SPECIFICATION




LANGUAGE

ENGLISH




3. FLARE BRAID AND INSERT CABLE INTO CONNECTOR TO DIMENSION SHOWN.



4. SLIP CRIMP TUBE OVER BRAID UNTIL BOTTOMS ON CONNECTOR BODY.

CRIMP USING .128 HEX. DIE



5. SLIP SHRINK TUBE OVER CONNECTOR UNTIL IT BOTTOMS BEHIND THE FLANGE AS SHOWN. APPLY HEAT.

REVISE ON PC ONLY		TITLE CABLE ASSEMBLY INSTRUCTIONS FOR SMA JACK CA-SMA			
3	Assembly Instructions 89675-1640 per ECN URF-xxxx				
REV	DESCRIPTION	THIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX INC. AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION			
DESIGN CONTROL URF	STATUS	WRITTEN BY: TEF	CHECKED BY: SSS	APPROVED BY: GMH	DATE: YR/MO/DAY 12/20/01
DOCUMENT NO. ES-89675-164				FILE NAME: ES-89675-164	SHT NO. 2 of 2