

INDASH by PANAVISE®

I-75103-600

Page 1 of 1

MOUNTING LOCATION:

Right side of climate control CR

TOOLS REQUIRED:

Hook tool
3/32 Drill bit and drill
Phillips screwdriver

HARDWARE INCLUDED:

(2)#8x3.4" Tek Screw [2B]

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75103-600

MFG: BMW

MODELS & YEARS: X5 2000-2006

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With hook tool pull off wood grain panel on passenger side over glove box and below air bag, by gently prying at either corner. There are (3) clips that need to be released. Set panel aside.

STEP #2: Align InDash Mount with far left clip slot on dash located to the right of the radio housing. InDash mount will rest on the dash with notch lined up below and on the right side of slot.

STEP #3: Drill (2) holes and install InDash Mount with screws provided. Replace wood grain panel. Install phone holder.



Mounting Location Less Screws

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH MOUNT.



Finished Install Picture



01-10-06

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com © 2002 PanaVise Products, Inc.