AUTOMOTIVE HIGH-SIDE CURRENT MONITOR

DESCRIPTION

The ZXCT1008 is a high side current sense monitor. Using this device eliminates the need to disrupt the ground plane when sensing a load current.

It takes a high side voltage developed across a current shunt resistor and translates it into a proportional output current.

A user defined output resistor scales the output current into a ground-referenced voltage.

The wide input voltage range of 20V down to as low as 2.5V make it suitable for a range of applications. The ability to withstand high voltage transients and reverse polarity connection, makes this part very suitable for automotive and other transient rich environments.

FEATURES

- Low cost, accurate high-side current sensing
- -40 to +125°C temperature range
- Up to 500mV sense voltage
- 2.5V 20V supply range
- 4µA quiescent current
- 1% typical accuracy
- SOT23

ORDERING INFORMATION

DEVICE	REEL SIZE	TAPE WIDTH	QUANTITY PER REEL
ZXCT1008FTA	7″	8mm	3,000 units

DEVICE MARKING


ISSUE 3 - FEBRUARY 2007

• 108

APPLICATIONS

- Automotive current measurement
- DC motor and solenoid control
- Over current monitor
- Power management

APPLICATION CIRCUIT





1

ABSOLUTE MAXIMUM RATINGS

Voltage on any pin Continuous output current Continuous sense voltage Operating temperature Storage temperature Package power dissipation (TA = $25^{\circ}C$)

-0.6V to 20V (relative to lout) 10mA $V_{in} + 0.5V > V_{sense}^{\dagger} > V_{in} - 5V$ -40 to 125°C -55 to 150°C 450mW Derate to zero at 150°C

Operation above the absolute maximum rating may cause device failure. Operation at the absolute maximum ratings, for extented periods, may reduce device reliability.


SYMBOL	PARAMETER	CONDITIONS	LIMITS			UNIT
			Min	Тур	Max	
V _{in}	V _{CC} range		2.5		20	V
l _{out} ¹	Output current	V _{sense} =0V	1	4	15	μA
		V _{sense} =10mV	90	104	120	μA
		V _{sense} =100mV	0.975	1.0	1.025	mA
		V _{sense} =200mV	1.95	2.0	2.05	mA
		V _{sense} =500mV	4.8	5.0	5.2	mA
V _{sense} †	Sense voltage		0		500	mV
I _{sense} -	V _{sense} -				100	nA
	input current					
Acc	Accuracy	$R_{sense} = 0.1\Omega$				
		V _{sense} =200mV	-2.5		2.5	%
Gm	Transconductance,			10000		μA/V
	I _{out} / V _{sense}					
BW	Bandwidth	RF P _{in} = -20dBm‡				
		$V_{sense} = 10 mV dc$		300		kHz
		$V_{sense} = 100 mV dc$		2		MHz

2

$\label{eq:expectation} \begin{array}{l} \textbf{ELECTRICAL CHARACTERISTICS} \\ \textbf{Test Conditions TA} = 25^\circ\text{C}, \ \textbf{Vin} = 5\text{V}, \ \textbf{R}_{out} = 100\Omega. \end{array}$

 1 Includes input offset voltage contribution $^tVsense=Vin-Vload$ \ddagger -20dBm=63mVp-p into 50 Ω






3


TYPICAL CHARACTERISTICS

ISSUE 3 - FEBRUARY 2007

SEMICONDUCTORS



SCHEMATIC DIAGRAM




PIN DESCRIPTION

Pin Name	Pin Function		
V _{sense} +	Supply voltage		
V _{sense} -	Connection to load/battery		
I _{out} Output current, proportional to V _{in} -V _l			

4

CONNECTION DIAGRAM






POWER DISSIPATION

The maximum allowable power dissipation of the device for normal operation (Pmax), is a function of the package junction to ambient thermal resistance (0ja), maximum junction temperature (Tjmax), and ambient temperature (Tamb), according to the expression:

 $P_{max} = (Tj_{max} - T_{amb}) / \theta_{ja}$

The device power dissipation, $\ensuremath{\mathsf{PD}}$ is given by the expression:

PD=lout.(Vin-Vout) Watts



APPLICATIONS INFORMATION

The following lines describe how to scale a load current to an output voltage.

E.g.

A 1A current is to be represented by a 100mV output voltage:

1) Choose the value of R_{sense} to give 50mV > V_{sense} > 500mV at full load.

For example V_{sense} = 100mV at 1.0A. R_{sense} = 0.1/1.0 => 0.1 Ω

2) Choose R_{out} to give V_{out} = 100mV, when V_{sense} = 100mV.

Rearranging ¹ for R_{out} gives: R_{out} = V_{out} /(V_{sense} x 0.01)

 $R_{out} = 0.1 / (0.1 \times 0.01) = 100 \Omega$



Where R_{load} represents any load including DC motors, a charging battery or further circuitry that requires monitoring, Rsense can be selected on specific requirements of accuracy, size and power rating.

An additional resistor, Rlim can be added in series with Rout (figure 1.0), to limit the current from lout. Any circuit connected to Vout will be protected from input voltage transients. This can be of particular use in automotive applications where load dump and other common transients need to be considered. The zener Z1 provides additional protection for local dump, reverse battery and high voltage transient incidents.

Assuming the worst case condition of V_{out} = 0V; providing a low impedance to a transient, the minimum value of R_{lim} is given by:-

$$\mathsf{R}_{\mathsf{lim}}(\mathsf{min}) = \frac{\mathsf{V}_{\mathsf{pk}} - \mathsf{V}_{\mathsf{max}}}{\mathsf{I}_{\mathsf{pk}}}$$

 $\begin{array}{l} V_{pk} &= \mbox{Peak transient voltage to be withstood} \\ V_{max} &= \mbox{Maximum working Voltage} = 20 V \\ I_{pk} &= \mbox{Peak output current} = 40 m A \end{array}$

The maximum value of Rlim is set by Vin(min), $V_{out}(\text{max})$ and the dropout voltage (see transfer characteristic on page 3) of the ZXCT1009 :-

$$R_{lim}(max) = \frac{R_{out}[V_{in}(min) - (V_{dp} + V_{out}(max))]}{V_{out}(max)}$$

Vin(min) = Minimum Supply Operating Voltage Vdp = Dropout Voltage

Vout (max) = Maximum Operating Output Voltage

TYPICAL AUTOMOTIVE CIRCUIT APPLICATION




Figure 1.0

6

 $Z\bar{X}CT1009$ with additional current limiting Resistor R_{lim} and zener Z1




APPLICATIONS INFORMATION


PCB trace shunt resistor for low cost solution.

The figure below shows output characteristics of the device when using a PCB resistive trace for a low cost solution in replacement for a conventional shunt resistor. The graph shows the linear rise in voltage across the resistor due to the PTC of the material and demonstrates how this rise in resistance value over temperature compensates for the NTC of the device.

The figure opposite shows a PCB layout suggestion. The resistor section is 25mm x 0.25mm giving approximately 150m Ω using 1oz copper. The data for the normalised graph was obtained using a 1A load current and a 100 Ω output resistor. An electronic version of the PCB layout is available at www.zetex.com/isense








Layout shows area of shunt resistor compared to SOT23 package. Not actual size

ZXCT1008






ISSUE 3 - FEBRUARY 2007

7



PACKAGE OUTLINE



Controlling dimensions are in millimeters. Approximate conversions are given in inches

PACKAGE DIMENSIONS

	Millimeters		Inches			Millimeters		Inches	
DIM	Min.	Max. N	Min.	Max.	DIM	Min.	Max.	Max.	Max.
Α	_	1.12	—	0.044	e1	1.90	NOM	0.075	NOM
A1	0.01	0.10	0.0004	0.004	E	2.10	2.64	0.083	0.104
b	0.30	0.50	0.012	0.020	E1	1.20	1.40	0.047	0.055
С	0.085	0.120	0.003	0.008	L	0.25	0.62	0.018	0.024
D	2.80	3.04	0.0110	0.120	L1	0.45	0.62	0.018	0.024
е	0.95	NOM	0.0375	NOM	—	_	_	—	_

© Zetex Semiconductors plc 2007

Europe	Americas	Asia Pacific	Corporate Headquarters
Zetex GmbH Kustermann-Park Balanstraße 59 D-81541 München Germany	Zetex Inc 700 Veterans Memorial Hwy Hauppauge, NY 11788 USA	Zetex (Asia) Ltd 3701-04 Metroplaza Tower 1 Hing Fong Road, Kwai Fong Hong Kong	Zetex Semiconductors plc Lansdowne Road, Chadderton Oldham, OL9 9TY United Kingdom
Telefon: (49) 89 45 49 49 0 Fax: (49) 89 45 49 49 49 europe.sales@zetex.com	Telephone: (1) 631 360 2222 Fax: (1) 631 360 8222 <u>usa.sales@zetex.com</u>	Telephone: (852) 26100 611 Fax: (852) 24250 494 <u>asia.sales@zetex.com</u>	Telephone (44) 161 622 4444 Fax: (44) 161 622 4446 <u>hq@zetex.com</u>

These offices are supported by agents and distributors in major countries world-wide.

This publication is issued to provide outline information only which (unless agreed by the Company in writing) may not be used, applied or reproduced for any purpose or form part of any order or contract or be regarded as a representation relating to the products or services concerned. The Company reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service.

8

For the latest product information, log on to www.zetex.com

