



### Silicon Low Leakage Diode

- Low-leakage applications
- Medium speed switching times



### **BAS116**



Type	Package	Configuration	Marking
BAS116	SOT23	single	JVs

**Maximum Ratings at  $T_A = 25^\circ\text{C}$ , unless otherwise specified**

Parameter	Symbol	Value	Unit
Diode reverse voltage	$V_R$	80	V
Peak reverse voltage	$V_{RM}$	85	
Forward current	$I_F$	250	mA
Surge forward current	$I_{FS}$	4.5	A
Total power dissipation	$P_{tot}$	370	mW
$T_S \leq 54^\circ\text{C}$			
Storage temperature	$T_{stg}$	-65 ... 150	°C

### Thermal Resistance


Parameter	Symbol	Value	Unit
Junction - soldering point <sup>1)</sup>	$R_{thJS}$	$\leq 260$	K/W
BAS116			

<sup>1</sup>For calculation of  $R_{thJA}$  please refer to Application Note Thermal Resistance

**Electrical Characteristics** at  $T_A = 25^\circ\text{C}$ , unless otherwise specified

Parameter	Symbol	Values			Unit
		min.	typ.	max.	
<b>DC Characteristics</b>					
Breakdown voltage $I_{(\text{BR})} = 100 \mu\text{A}$	$V_{(\text{BR})}$	85	-	-	V
Reverse current $V_R = 75 \text{ V}$ $V_R = 75 \text{ V}, T_A = 150^\circ\text{C}$	$I_R$	-	-	5 80	nA
Forward voltage $I_F = 1 \text{ mA}$ $I_F = 10 \text{ mA}$ $I_F = 50 \text{ mA}$ $I_F = 150 \text{ mA}$	$V_F$	-	-	900 1000 1100 1250	mV
<b>AC Characteristics</b>					
Diode capacitance $V_R = 0 \text{ V}, f = 1 \text{ MHz}$	$C_T$	-	2	-	pF
Reverse recovery time $I_F = 10 \text{ mA}, I_R = 10 \text{ mA}$ , measured at $I_R = 1 \text{ mA}$ , $R_L = 100 \Omega$	$t_{rr}$	-	0.5	3	μs


Test circuit for reverse recovery time


Puls generator:  $t_p = 10 \mu\text{s}$ ,  $D = 0.05$ ,  
 $t_r = 0.6 \text{ ns}$ ,  $R_i = 50 \Omega$ 

Oscillograph:  $R = 50 \Omega$ ,  $t_r = 0.35 \text{ ns}$ ,  $C \leq 1 \text{ pF}$


**Reverse current  $I_R = f(T_A)$**

$V_R$  = Parameter




**Forward Voltage  $V_F = f(T_A)$**

$I_F$  = Parameter




**Forward current  $I_F = f(V_F)$**

$T_A = 25^\circ\text{C}$



**Peak forward current  $I_{FM} = f(t_p)$**

$T_A = 25^\circ\text{C}$



**Forward current**  $I_F = f(T_S)$

BAS116

