



Home
Embedded Software

Development Tools
J-Link ARM

Adapters
5V adapter
 JTAG 14 pin adapter
DFPUs
Flash breakpoints

Flash download
Flash SDK
GDB Server
IDE integration
Interface description

J-Flash ARM
J-Link software
J-Mem
JTAG Isolator
Model comparison

Non-commercial-use
Performance comparison
RDI
SDK

J-Link ARM Pro

J-Link ARM Lite
J-Link Coldfire
J-Trace ARM
J-Trace for Cortex-M3

Production Tools

Evaluate our software!
Downloads

Distributors
Customers

Partners
Sales

Forum
About us

Head office Germany

Phone: +49-2103-2876-0
Fax: +49-2103-2876-288
E-mail: info@segger.com
www.segger.com

US office

Phone: +1-978-874-0299
Fax: +1-978-874-0599
E-mail: info@segger-us.com
www.segger-us.com



Development Tools J-Link ARM Adapters JTAG 14 pin adapter

JTAG 14 pin adapter

An adapter is available to use J-Link ARM with targets using this 14 pin 0.1" mating JTAG connector.

Pin	Signal	Pin no. on 20 pin JTAG
1	VTrref	1
2	GND	GND
3	nTRST	3
4	GND	GND
5	TDI	5
6	GND	GND
7	TMS	7
8	GND	GND
9	TCK	9
10	GND	GND
11	TDO	13
12	RESET	15
13	VTrref	1
14	GND	GND



Mapping between the JTAG 14 pin adapter and 20 pin JTAG interface
[Pricing](#)

[Imprint](#) [Disclaimer](#) [Sitemap](#)

[back to top](#)

© 2009, www.segger.com, All rights reserved.