

## DEVICE LIST 3/1/2011 14:54:46

Illustration of the list:

93LC46(08bit)@SOIC8 [(SA602A)]  
 93LC46(08bit): Part number  
 SOIC8: Package in QFP44  
 SA602A: Adapter purchase number

HR6P62P4SH@SOP20 [(SA404+B003)]  
 HR6P62P4SH: Part number  
 SOP20: Package in FBGA48  
 SA404: Adapter purchase number (Top board with socket)  
 B003: Adapter purchase number (Bottom board, exchangable for different parts)

87C196CA@PLCC68(universal adapter) [PEP+S414T]  
 87C196CA: Part number  
 PLCC68: Package in PLCC68  
 universal adapter: this adapter is valid for all parts in this package  
 PEP: The PEP (Pin-driver Expansion Pack necessary to work with the adapter S414T)  
 S414T: Adapter purchase number (Universal for all parts in this package)

S71PL127J80B@FBGA64(special adapter) [(SA642A-B079A-Y096AF001)]  
 S71PL127J80B: Part number  
 FBGA64: Package in FBGA64  
 special adapter: this adapter is valid for this chip  
 SA642A-B079A-Y096AF001: Adapter purchase number

Total Manufacturers 211

Total Devices 48519

<a href="#">ABOV</a>	<a href="#">ACT</a>	<a href="#">ACTRANS</a>	<a href="#">ADI</a>
<a href="#">ADVANCE GROUP</a>	<a href="#">AEROFLEX</a>	<a href="#">ALI(Acer)</a>	
<a href="#">ALL 24 SERIES(ISP)</a>		<a href="#">ALLIANCE</a>	<a href="#">ALTERA</a>
<a href="#">AMD</a>	<a href="#">AMI SEMICONDUCTOR</a>		<a href="#">AMIC</a>
<a href="#">ANACHIP</a>	<a href="#">ANALOG</a>	<a href="#">AOYU</a>	<a href="#">APLUS FLASH</a>
<a href="#">ARTSCHIP</a>	<a href="#">ASAHI KASEI(AKM)</a>	<a href="#">ASD</a>	<a href="#">ASI</a>
<a href="#">ASP</a>	<a href="#">ASTIGP-MICROCHIP</a>	<a href="#">ATC</a>	<a href="#">ATMEL</a>
<a href="#">ATMEL W&amp;M</a>	<a href="#">ATMEL-CUSTOMER</a>	<a href="#">AUSTIN</a>	<a href="#">BELLING-SYSTRON</a>
<a href="#">BENCHMARKO</a>	<a href="#">BMT</a>	<a href="#">BOSEN</a>	<a href="#">BRIGHT</a>
<a href="#">CATALYST</a>	<a href="#">CELESTICA</a>	<a href="#">CERAMATE</a>	<a href="#">CFeon</a>
<a href="#">CHINA CORE</a>	<a href="#">CHINGIS</a>	<a href="#">CHIPCON</a>	<a href="#">CHIPSWINNER</a>
<a href="#">CORERIVER</a>	<a href="#">CWI</a>	<a href="#">CYGNAL</a>	<a href="#">CYPRESS</a>
<a href="#">DALLAS</a>	<a href="#">DENSE-PAC</a>	<a href="#">DEUTRON</a>	<a href="#">EFST</a>
<a href="#">ELECTRONIC ARRAYS</a>		<a href="#">ELPIDA</a>	<a href="#">EM</a>
<a href="#">EMTC</a>	<a href="#">EON</a>	<a href="#">EPSON</a>	<a href="#">ESMT</a>
<a href="#">EVERSTAR</a>	<a href="#">EXCELSEMI</a>	<a href="#">EXEL</a>	<a href="#">FAIRCHILD</a>
<a href="#">FIDELIX</a>	<a href="#">FORCE TECHNOLOGIES</a>		<a href="#">FORWARD</a>
<a href="#">FREESCALE</a>	<a href="#">Fremont Micro Devices</a>		<a href="#">FUJITSU</a>
<a href="#">GENCORE</a>	<a href="#">GENERAL(GI)</a>	<a href="#">GENERIC</a>	<a href="#">GIGADEVICE</a>
<a href="#">GOAL</a>	<a href="#">GOULD</a>	<a href="#">GREENWICH</a>	<a href="#">HAIER</a>
<a href="#">HARRIS</a>	<a href="#">HITACHI</a>	<a href="#">HOLTEK</a>	<a href="#">HONGKONG</a>
<a href="#">HYNIX</a>	<a href="#">HYNIX(HYUNDAI)</a>	<a href="#">HYNIX-CUSTOMER</a>	<a href="#">HYUNDAI</a>
<a href="#">ICE</a>	<a href="#">ICMIC</a>	<a href="#">ICSI</a>	<a href="#">ICT</a>
<a href="#">IDT</a>	<a href="#">IGS</a>	<a href="#">IMT</a>	<a href="#">INFINEON</a>
<a href="#">INTEL</a>	<a href="#">INTEL-CUSTOMER</a>	<a href="#">INTELSIL</a>	<a href="#">ISSI</a>
<a href="#">ITHINKO</a>	<a href="#">K-LINE</a>	<a href="#">LATTICE</a>	<a href="#">Lg Semicon</a>
<a href="#">LINKSMART</a>	<a href="#">MACRONIX</a>	<a href="#">MAGNACHIP</a>	<a href="#">MAXIM</a>
<a href="#">MAXWELL</a>	<a href="#">MEGAWIN</a>	<a href="#">MEMOCOM</a>	<a href="#">MICON</a>
<a href="#">MICROCHIP</a>	<a href="#">MICRON</a>	<a href="#">MICRONAS</a>	<a href="#">MICRON-CUSTOMER</a>
<a href="#">MITSUBISHI</a>	<a href="#">MMI</a>	<a href="#">MOSEL-VITELIC</a>	<a href="#">MOSTEK</a>
<a href="#">MOTOROLA</a>	<a href="#">MYSON</a>	<a href="#">MYSON-CUSTOMER</a>	<a href="#">NANTRONICS</a>
<a href="#">NEC</a>	<a href="#">NEXFLASH</a>	<a href="#">NJRC</a>	<a href="#">NOVATEK</a>
<a href="#">NSC</a>	<a href="#">NTE</a>	<a href="#">NUMONYX</a>	<a href="#">NUVOTON</a>
<a href="#">NXP</a>	<a href="#">OKI</a>	<a href="#">ON Semiconductor</a>	<a href="#">PARALLAX</a>
<a href="#">PFLASH(MSTAR)</a>	<a href="#">PHILIPS</a>	<a href="#">PJ</a>	<a href="#">PMC</a>
<a href="#">POLYSTAK</a>	<a href="#">PSS</a>	<a href="#">PTC</a>	<a href="#">QIXIN</a>
<a href="#">Quick Pulse</a>	<a href="#">RAMTRON</a>	<a href="#">RATO</a>	<a href="#">RAYDIUM</a>
<a href="#">RENESAS</a>	<a href="#">RICOH</a>	<a href="#">ROCKWELL</a>	<a href="#">ROHM</a>
<a href="#">SAIFUN</a>	<a href="#">SAMSUNG</a>	<a href="#">SAMSUNG-CUSTOMER</a>	<a href="#">SANYO</a>
<a href="#">SCENIX</a>	<a href="#">SEEQ</a>	<a href="#">SEIKO</a>	<a href="#">SGS-THOMSON</a>
<a href="#">SHARP</a>	<a href="#">SHARP-CUSTOMER</a>	<a href="#">SIEMENS</a>	<a href="#">SIGNETICS</a>

<a href="#">Silicon Laboratories</a>	<a href="#">SILICON7</a>	<a href="#">SIMTEK</a>
<a href="#">SIRE</a>	<a href="#">SONIX</a>	<a href="#">SONY</a>
<a href="#">SPACE ELECTRONICS[SEI]</a>	<a href="#">SPANSION</a>	
<a href="#">SPANSION-CUSTOMER</a>	<a href="#">SSSC</a>	<a href="#">SST</a>
<a href="#">ST</a>	<a href="#">ST-CUSTOMER</a>	<a href="#">SUMMIT</a>
<a href="#">SUNPLUS</a>	<a href="#">SYNERTEK</a>	<a href="#">SYNTEK</a>
<a href="#">TDICOMS</a>	<a href="#">TEKMOS</a>	<a href="#">TEMIC</a>
<a href="#">Terra Semiconductor</a>	<a href="#">TEST</a>	<a href="#">TEST-LOGIC</a>
<a href="#">TI</a>	<a href="#">TOPRO</a>	<a href="#">TOSHIBA</a>
<a href="#">TOSHIBA-CUSTOMER</a>	<a href="#">UBICOM</a>	<a href="#">UMC</a>
<a href="#">UTRON</a>	<a href="#">VERSACHIPS</a>	<a href="#">VLSI</a>
<a href="#">WELTREND</a>	<a href="#">WHITE ELECTRONIC DESIGNS</a>	<a href="#">WINBOND</a>
<a href="#">WISTRON</a>	<a href="#">WSI</a>	<a href="#">XICOR</a>
<a href="#">XILINX</a>	<a href="#">XILINX-CUSTOMER</a>	<a href="#">YSS</a>
<a href="#">ZHIXIN</a>	<a href="#">ZLOG</a>	

## ABOV

### MICROCONTROLLER

MC80F0104	MC80F0104@SOP16 [(SA404+B003)]
MC80F0104@TSSOP16 [(SA026)]	MC80F0204
MC80F0204@SOP20 [(SA404+B003)]	MC80F0208@MQFP44 [(SA675-B005)]
MC80F0208@SDIP42 [(SA028)]	MC80F0216@MQFP44 [(SA675-B005)]
MC80F0216@SDIP42 [(SA028)]	MC80F0224@MQFP44 [(SA675-B005)]
MC80F0224@SDIP42 [(SA028)]	MC80F0304
MC80F0304@SOP28 [(SA404+B003)]	MC80F0308
MC80F0308@SOP28 [(SA404+B003)]	MC80F0316
MC80F0316@SOP28 [(SA404+B003)]	
MC80F0424K@SDIP64(*) [(SA752+B290)]	
MC80F0424L@LQFP64(*) [(SA732+B291)]	
MC80F0424LG@LQFP64 [(PEP+S616)]	
MC80F0424Q@MQFP64(*) [(SA758+B289)]	
MC80F0432K@SDIP64(*) [(SA752+B290)]	
MC80F0432L@LQFP64(*) [(SA732+B291)]	
MC80F0432LG@LQFP64 [(PEP+S616)]	
MC80F0432Q@MQFP64(*) [(SA758+B289)]	
MC80F0448K@SDIP64(*) [(SA752+B292)]	
MC80F0448L@LQFP64(*) [(SA732+B291)]	
MC80F0448LG@LQFP64 [(PEP+S616)]	
MC80F0448Q@MQFP64(*) [(SA758+B289)]	
MC80F0504	MC80F0504@SOP16 [(SA715)]
MC80F0504@SSOP16 [(SA626A)]	
MC80F0504[153mil]@SOP16 [(SA602)]	
MC80F0604	MC80F0604@SOP20 [(SA715)]
MC80F0604@SSOP20 [(SA626A)]	MC80F0704
MC80F0704@QFN28 [(SA697)]	MC80F0704@SOP28 [(SA715)]
MC80F0708	MC80F0708@QFN28 [(SA697)]
MC80F0708@SOP28 [(SA715)]	MC80F0804@SDIP32 [(SA653)]
MC80F0804@SOP32 [(SA715)]	MC80F0808@SDIP32 [(SA653)]
MC80F0808@SOP32 [(SA715)]	MC80F7108@TQFP44 [(SA675-B005)]
MC80F7308@SDIP42 [(SA028)]	MC80F7408@TQFP44 [(SA675-B005)]

## ACT

### E(E) PROM/FRAM/NVRAM

93LC46(08bit)	93LC46(08bit)@SOIC8 [(SA602A)]
93LC46(16bit)	93LC46(16bit)@SOIC8 [(SA602A)]
93LC56(08bit)	93LC56(08bit)@SOIC8 [(SA602A)]
93LC56(16bit)	93LC56(16bit)@SOIC8 [(SA602A)]
93LC66(08bit)	93LC66(08bit)@SOIC8 [(SA602A)]
93LC66(16bit)	93LC66(16bit)@SOIC8 [(SA602A)]
93LC86(08bit)	93LC86(08bit)@SOIC8 [(SA602A)]
93LC86(16bit)	93LC86(16bit)@SOIC8 [(SA602A)]

## ACTRANS

**E (E) PROM/FRAM/NVRAM**

AC25010@SOIC8 [(SA602A)]	AC25512@SOIC8 [(SA602A)]
AC25LC010@SOIC8 [(SA602A)]	AC25LC512@SOIC8 [(SA602A)]
AC39LV010@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV010@PLCC32 [(SA015A1T)]	AC39LV010@VSOP32 [(SA620)]
AC39LV020@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV020@PLCC32 [(SA015A1T)]	AC39LV020@VSOP32 [(SA620)]
AC39LV040@PLCC32 [(SA015A1T)]	AC39LV040@VSOP32 [(SA620)]
AC39LV080@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV080@TSOP40 [(SA409T)]	AC39LV088@TSOP48 [(SA247-B005)]
AC39LV512@PLCC32 [(SA015A1T)]	AC39LV512@VSOP32 [(SA620)]
AC39VF800@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39VF800@TSOP48 [(SA247-B005)]	

**ADI****MICROCONTROLLER**

ADE7166F16@LQFP64 [(PEP+S616)]	
ADE7166F16@LQFP64(*) [(SA732+B237)]	
ADE7169F16@LQFP64 [(PEP+S616)]	
ADE7169F16@LQFP64(*) [(SA732+B237)]	
ADE7566F16@LQFP64 [(PEP+S616)]	
ADE7566F16@LQFP64(*) [(SA732+B237)]	
ADE7569F16@LQFP64 [(PEP+S616)]	
ADE7569F16@LQFP64(*) [(SA732+B237)]	
ADM1026@LQFP48 [(SA248+B005)]	ADM1060@TSSOP28 [(SA643-B005)]
ADM1062@LFCSP40 [(SA750+B006)]	ADM1062@LQFP48 [(SA248+B005)]
ADM1066@LFCSP40 [(SA750+B006)]	ADM1066@LQFP48 [(SA248+B005)]
ADUC814@SSOP28 [(SA643+B005)]	
ADuC831BCP@LFCSP56 [(SA706+B296)]	
ADuC831BS@MQFP52 [(SA662+B042)]	
ADuC832BCP@LFCSP56 [(SA706+B296)]	
ADuC832BS@MQFP52 [(SA662+B042)]	
ADuC834BCP@LFCSP56 [(SA706+B296)]	
ADuC834BS@MQFP52 [(SA662+B042)]	
ADuC836BCP@LFCSP56 [(SA706+B296)]	
ADuC836BS@MQFP52 [(SA662+B042)]	
ADuC841BCP62@LFCSP56 [(SA706+B296)]	
ADuC841BS62@MQFP52 [(SA662+B042)]	
ADuC842BCP62@LFCSP56 [(SA706+B296)]	
ADuC842BS62@MQFP52 [(SA662+B042)]	
ADuC843BCP62@LFCSP56 [(SA706+B296)]	
ADuC843BS62@MQFP52 [(SA662+B042)]	
ADuC845BCP62@LFCSP56 [(SA706+B297)]	
ADuC845BS62@MQFP52 [(SA662+B042)]	
ADuC847BCP62@LFCSP56 [(SA706+B297)]	
ADuC847BS62@MQFP52 [(SA662+B042)]	
ADuC848BCP62@LFCSP56 [(SA706+B297)]	
ADuC848BS62@MQFP52 [(SA662+B042)]	

**ADVANCE GROUP****E (E) PROM/FRAM/NVRAM**

AF24BC01	AF24BC01@SOIC8 [(SA602A)]
AF24BC01@TSOP8 [(SA026)]	AF24BC02
AF24BC02@SOIC8 [(SA602A)]	AF24BC02@TSOP8 [(SA026)]
AF24BC04	AF24BC04@SOIC8 [(SA602A)]
AF24BC04@TSOP8 [(SA026)]	AF24BC08
AF24BC08@SOIC8 [(SA602A)]	AF24BC08@TSOP8 [(SA026)]
AF24BC16	AF24BC16@SOIC8 [(SA602A)]
AF24BC16@TSOP8 [(SA026)]	AF24C128
AF24C128@SOIC8 [(SA602A)]	AF24C128@TSOP8 [(SA026)]
AF24C256	AF24C256@SOIC8 [(SA602A)]
AF24C256@TSOP8 [(SA026)]	AF24C32
AF24C32@SOIC8 [(SA602A)]	AF24C32@TSOP8 [(SA026)]
AF24C64	AF24C64@SOIC8 [(SA602A)]
AF24C64@TSOP8 [(SA026)]	AF93C46(08bit)
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8 [(SA026)]
AF93C46(16bit)	AF93C46(16bit)@SOIC8 [(SA602A)]
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56(08bit)
AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8 [(SA026)]

AF93C56(16bit)	AF93C56(16bit)@SOIC8 [(SA602A)]
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66(08bit)
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8 [(SA026)]
AF93C66(16bit)	AF93C66(16bit)@SOIC8 [(SA602A)]
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86(08bit)
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8 [(SA026)]
AF93C86(16bit)	AF93C86(16bit)@SOIC8 [(SA602A)]
AF93C86(16bit)@TSOP8 [(SA026)]	

#### MICROCONTROLLER

A1000A2	A1000A2@PLCC44 [(SA244)]
A1000A2@PQFP44 [(SA245A)]	A1000A3
A1000A3@PLCC44 [(SA244)]	A1000A3@PQFP44 [(SA245A)]
AG1001@SDIP42 [(SA028)]	AG88F516
AG88F516@LQFP44 [(SA245A)]	AG88F516@PLCC44 [(SA244)]
AG88F516@PQFP64 [(PEP+S616)]	AG88F92@PQFP64 [(PEP+S616)]
AG88F92@PQFP80 [(PEP+S640B)]	AG89F516
AG89F516@PLCC44 [(SA244)]	AG89F516@PQFP44 [(SA245A)]
AG89F54	AG89F54@PLCC44 [(SA244)]
AG89F54@PQFP44 [(SA245A)]	AG89P51
AG89P51@PLCC44 [(SA244)]	AG89P51@PQFP44 [(SA675)]
AG89P516	AG89P516@PLCC44 [(SA244)]
AG89P516@PQFP44 [(SA675)]	AG89P51A
AG89P51A@PLCC44 [(SA244)]	AG89P51A@PQFP44 [(SA675)]
AG89P52	AG89P52@PLCC44 [(SA244)]
AG89P52@PQFP44 [(SA675)]	

## AEROFLEX

#### E(E) PROM/FRAM/NVRAM

ACT-F128K32@PGA66(SAD) [(PEP+S667+B6601)]
ACT-F512K32@PGA66(*) [(PEP+S667+B6601)]

## ALI(Acer)

#### E(E) PROM/FRAM/NVRAM

M8720	M8720@PLCC32 [(SA015A1T)]
-------	---------------------------

#### MICROCONTROLLER

M6759	M6759@PLCC44 [(SA244)]
M6759@TQFP44 [(SA245A)]	

## ALL 24 SERIES(ISP)

#### E(E) PROM/FRAM/NVRAM

24C01(ISP) [ISP-HEADER01]	24C02(ISP) [ISP-HEADER01]
24C04(ISP) [ISP-HEADER01]	24C08(ISP) [ISP-HEADER01]
24C128(ISP) [ISP-HEADER01]	24C16(ISP) [ISP-HEADER01]
24C256(ISP) [ISP-HEADER01]	24C32(ISP) [ISP-HEADER01]
24C64(ISP) [ISP-HEADER01]	

## ALLIANCE

#### E(E) PROM/FRAM/NVRAM

AS29F200@PSOP44 [(SA638-B006)]	AS29F200@TSOP48 [(SA247-B005)]
AS29F200B@PSOP44 [(SA638-B006)]	AS29F200B@TSOP48 [(SA247-B005)]
AS29F200T@PSOP44 [(SA638-B006)]	AS29F200T@TSOP48 [(SA247-B005)]

**ALTERA****E(E) PROM/FRAM/NVRAM**

```

EPC1(LC)@PLCC20 [(SA001A)]          EPC1(LI)@PLCC20 [(SA001A)]
EPC1(PC)                             EPC1(PI)
EPC1064(LC)@PLCC20 [ordering number is marked above]
EPC1064(LI)@PLCC20 [ordering number is marked above]
EPC1064(PC)                           EPC1064(PI)
EPC1213(LC)@PLCC20 [ordering number is marked above]
EPC1213(LI)@PLCC20 [ordering number is marked above]
EPC1213(PC)                           EPC1213(PI)
EPC1441(LC)@PLCC20 [(SA001A)]       EPC1441(LI)@PLCC20 [(SA001A)]
EPC1441(PC)                           EPC1441(PI)
EPC1441(TC)@TQFP32 [(SA663)]       EPC1441(TI)@TQFP32 [(SA663)]
EPC16QC100@PQFP100(*) [(TA017-B006)]
EPC16QI100@PQFP100(*) [(TA017-B006)]
EPC16UC88@BGA88 [(SA642A-B146A-Y096F001Y)]
EPC16UC88AA@BGA88 [(SA642A-B146A-Y096F001Y)]
EPC16UC88AB@BGA88 [(SA642A-B146A-Y096F001Y)]
EPC16UC88N@BGA88 [(SA642A-B146A-Y096F001Y)]
EPC16UI88AA@BGA88 [(SA642A-B146A-Y096F001Y)]
EPC2(LC)@PLCC20 [(SA001A)]         EPC2(LI)@PLCC20 [(SA001A)]
EPC2(TC)@TQFP32 [(SA663)]         EPC2(TI)@TQFP32 [(SA663)]
EPC4QC100@PQFP100(*) [(TA017-B006)]
EPC4QC100N@PQFP100(*) [(TA017-B006)]
EPC4QI100@PQFP100(*) [(TA017-B006)]
EPC8QC100@PQFP100(*) [(TA017-B006)]
EPC8QC100DM@PQFP100(*) [(TA017-B006)]
EPC8QI100@PQFP100(*) [(TA017-B006)]
EPCS16SI16@SOIC16 [(SA404)]        EPCS16SI8N@SOIC8 [(SA602A)]
EPCS1SI8@SOIC8 [(SA602A)]         EPCS4SI8@SOIC8 [(SA602A)]
EPCS64SI16@SOIC16 [(SA404)]

```

**PLD**

```

EP1800@PLCC68 [(PEP+S414T)]        EP1810@PLCC68 [(PEP+S414T)]
EP1810T@PLCC68 [(PEP+S414T)]      EP1830@PLCC68 [(PEP+S414T)]
EP310                               EP310@PLCC20 [(SA001A)]
EP320                               EP320@PLCC20 [(SA001A)]
EP330                               EP330@PLCC20 [(SA001A)]
EP600                               EP600@PLCC28 [(SA008A)]
EP600@SOIC24 [(SA404)]            EP600I
EP600I@PLCC28 [(SA008A)]          EP600I@SOIC24 [(SA404)]
EP610                               EP610@PLCC28 [(SA008A)]
EP610@SOIC24 [(SA404)]            EP610A
EP610A@PLCC28 [(SA008A)]          EP610A@SOIC24 [(SA404)]
EP610I                              EP610I@PLCC28 [(SA008A)]
EP610I@SOIC24 [(SA404)]          EP610T
EP610T@PLCC28 [(SA008A)]          EP610T@SOIC24 [(SA404)]
EP630                               EP630@PLCC28 [(SA008A)]
EP630@SOIC24 [(SA404)]            EP900
EP900@PLCC44 [(SA244)]            EP900I
EP900I@PLC44 [(SA244)]            EP910
EP910@PLCC44 [(SA244)]            EP910A
EP910A@PLCC44 [(SA244)]           EP910I
EP910I@PLCC44 [(SA244)]           EP910T
EP910T@PLCC44 [(SA244)]
EPM1270@FBGA256(*) [(SA800-B209)]
EPM1270@FBGA256(ISP) [ISP-HEADER01]
EPM1270@TQFP144(*) [(SA681-B14405)]
EPM1270@TQFP144(ISP) [ISP-HEADER01]
EPM1270ES@FBGA256(ISP) [ISP-HEADER01]
EPM1270ES@TQFP144(ISP) [ISP-HEADER01]
EPM1270G@FBGA256(*) [(SA800-B209)]
EPM1270G@FBGA256(ISP) [ISP-HEADER01]
EPM1270G@TQFP144(*) [(SA681-B14405)]
EPM1270G@TQFP144(ISP) [ISP-HEADER01]
EPM2210@FBGA256(*) [(SA800-B209)]
EPM2210@FBGA256(ISP) [ISP-HEADER01]
EPM2210@FBGA324(ISP) [ISP-HEADER01]
EPM2210G@FBGA256(*) [(SA800-B209)]
EPM2210G@FBGA256(ISP) [ISP-HEADER01]
EPM2210G@FBGA324(ISP) [ISP-HEADER01]
EPM240@FBGA100(*) [(SA800B-B293-W100F001Y)]
EPM240@TQFP100 [(PEP+S604)]        EPM240@TQFP100(*) [(TA053-B006)]
EPM240@TQFP100(ISP) [ISP-HEADER01]
EPM240G@FBGA100(*) [(SA800B-B293-W100F001Y)]

```

```

EPM240G@TQFP100 [(PEP+S604)]
EPM240G@TQFP100(*) [(TA053-B006)]
EPM240G@TQFP100(ISP) [ISP-HEADER01]
EPM3032A@PLCC44 [(SA244)]
EPM3032A@PLCC44(ISP) [ISP-HEADER01]
EPM3032A@TQFP44 [(SA245A)]
EPM3032A@TQFP44(ISP) [ISP-HEADER01]
EPM3064A@PLCC44 [(SA244)] EPM3064A@TQFP100 [(PEP+S604)]
EPM3064A@TQFP100(*) [(TA062+B006)]
EPM3064A@TQFP44 [(SA245A)]
EPM3128A@FBGA256(ISP) [ISP-HEADER01]
EPM3128A@TQFP100 [(PEP-S604)]
EPM3128A@TQFP100(*) [(TA062-B006)]
EPM3128A@TQFP100(ISP) [ISP-HEADER01]
EPM3128A@TQFP144(*) [(SA681-B14409)]
EPM3128A@TQFP144(ISP) [ISP-HEADER01]
EPM3256A@PQFP208(*) [(TA078-B084)]
EPM3256A@PQFP208(ISP) [ISP-HEADER01]
EPM3256A@TQFP144(ISP) [ISP-HEADER01]
EPM3512A@FBGA256(ISP) [ISP-HEADER01]
EPM3512A@PQFP208(ISP) [ISP-HEADER01]
EPM5032A EPM5032A@PLCC28 [(SA008A)]
EPM5064A@PLCC44 [(SA244)] EPM5128A@PGA68 [(SA650+B6811)]
EPM5128A@PLCC68 [(PEP+S414T)] EPM5130A@PLCC84 [(PEP+S416T)]
EPM5130A@PQFP100 [(PEP+S427)] EPM570@FBGA256(*) [(SA800-B209)]
EPM570@FBGA256(ISP) [ISP-HEADER01]
EPM570@TQFP100 [(PEP+S604)] EPM570@TQFP100(*) [(TA053-B006)]
EPM570@TQFP100(ISP) [ISP-HEADER01]
EPM570@TQFP144(*) [(SA681-B14405)]
EPM570@TQFP144(ISP) [ISP-HEADER01]
EPM570G@FBGA256(*) [(SA800-B209)]
EPM570G@FBGA256(ISP) [ISP-HEADER01]
EPM570G@TQFP100 [(PEP+S604)]
EPM570G@TQFP100(*) [(TA053-B006)]
EPM570G@TQFP100(ISP) [ISP-HEADER01]
EPM570G@TQFP144(*) [(SA681-B14405)]
EPM570G@TQFP144(ISP) [ISP-HEADER01]
EPM7032@PLCC44 [(SA244)] EPM7032@TQFP44 [(SA245A)]
EPM7032AE@JLCC44 (7032 mode) [(SA244)]
EPM7032AE@PLCC44 (7032 mode) [(SA244)]
EPM7032AE@PLCC44 (7032AE mode) [(SA244)]
EPM7032AE@PLCC44 (7032S mode) [(SA244)]
EPM7032AE@PQFP44 (7032 mode) [(SA245A)]
EPM7032AE@TQFP44 (7032 mode) [(SA245A)]
EPM7032AE@TQFP44 (7032AE mode) [(SA245A)]
EPM7032AE@TQFP44 (7032S mode) [(SA245A)]
EPM7032B@FBGA49(7032AEmode)(ISP) [ISP-HEADER01]
EPM7032B@FBGA49(7032B mode)(ISP) [ISP-HEADER01]
EPM7032B@FBGA49(7032S mode)(ISP) [ISP-HEADER01]
EPM7032B@PLCC44 (7032AE mode) [(SA244)]
EPM7032B@PLCC44 (7032B mode) [(SA244)]
EPM7032B@PLCC44 (7032S mode) [(SA244)]
EPM7032B@TQFP44 (7032AE mode) [(SA245A)]
EPM7032B@TQFP44 (7032B mode) [(SA245A)]
EPM7032B@TQFP44 (7032S mode) [(SA245A)]
EPM7032B@TQFP48 (7032AE mode) [(SA248)]
EPM7032B@TQFP48 (7032B mode) [(SA248)]
EPM7032B@TQFP48 (7032S mode) [(SA248)]
EPM7032S@PLCC44 (7032 mode) [(SA244)]
EPM7032S@PLCC44 (7032S mode) [(SA244)]
EPM7032S@TQFP44 (7032 mode) [(SA245A)]
EPM7032S@TQFP44 (7032S mode) [(SA245A)]
EPM7032V@PLCC44 [(SA244)] EPM7032V@TQFP44 [(SA245A)]
EPM7064@PLCC44 [(SA244)] EPM7064@PLCC68 [(PEP+S414T)]
EPM7064@PLCC84 [(PEP+S416T)] EPM7064@PQFP100 [(PEP+S427)]
EPM7064@TQFP44 [(SA245A)]
EPM7064AE@FBGA100 (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@FBGA100 (7064AE mode) [(SA800B+B325A+W100F001Y)]
EPM7064AE@FBGA100 (7064AE)(ISP) [ISP-HEADER01]
EPM7064AE@FBGA100 (7064S mode) [(SA800B+B325A+W100F001Y)]
EPM7064AE@PLCC44 (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@PLCC44 (7064AE mode) [(SA244)]
EPM7064AE@PLCC44 (7064AE)(ISP) [ISP-HEADER01]
EPM7064AE@PLCC44 (7064S mode) [(SA244)]
EPM7064AE@PLCC84 (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@PLCC84 (7064AE mode) [(PEP+S416T)]
EPM7064AE@PLCC84 (7064AE)(ISP) [ISP-HEADER01]
EPM7064AE@PLCC84 (7064S mode) [(PEP+S416T)]
EPM7064AE@TQFP100 (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@TQFP100 (7064AE mode) [(PEP+S604)]
EPM7064AE@TQFP100 (7064AE)(ISP) [ISP-HEADER01]

```

```

EPM7064AE@TQFP100 (7064S mode) [(PEP+S604)]
EPM7064AE@TQFP44 (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@TQFP44 (7064AE mode) [(SA245A)]
EPM7064AE@TQFP44 (7064AE)(ISP) [ISP-HEADER01]
EPM7064AE@TQFP44 (7064S mode) [(SA245A)]
EPM7064B@FBGA100 (7064B)(ISP) [ISP-HEADER01]
EPM7064B@FBGA100 (7064S)(ISP) [ISP-HEADER01]
EPM7064B@FBGA100 (7064AE)(ISP) [ISP-HEADER01]
EPM7064B@FBGA49 (7064B)(ISP) [ISP-HEADER01]
EPM7064B@FBGA49 (7064S)(ISP) [ISP-HEADER01]
EPM7064B@FBGA49 (7064AE)(ISP) [ISP-HEADER01]
EPM7064B@PLCC44 (7064AE mode) [(SA244)]
EPM7064B@PLCC44 (7064B mode) [(SA244)]
EPM7064B@PLCC44 (7064S mode) [(SA244)]
EPM7064B@TQFP100 (7064B)(ISP) [ISP-HEADER01]
EPM7064B@TQFP100 (7064S)(ISP) [ISP-HEADER01]
EPM7064B@TQFP100 (7064AE mode) [(PEP+S604)]
EPM7064B@TQFP100 (7064AE)(ISP) [ISP-HEADER01]
EPM7064B@TQFP100 (7064B mode) [(PEP+S604)]
EPM7064B@TQFP100 (7064S mode) [(PEP+S604)]
EPM7064B@TQFP44 (7064AE mode) [(SA245A)]
EPM7064B@TQFP44 (7064B mode) [(SA245A)]
EPM7064B@TQFP44 (7064S mode) [(SA245A)]
EPM7064B@TQFP48 (7064AE mode) [(SA248)]
EPM7064B@TQFP48 (7064B mode) [(SA248)]
EPM7064B@TQFP48 (7064S mode) [(SA248)]
EPM7064S@PLCC44 (7064 mode) [(SA244)]
EPM7064S@PLCC44 (7064S mode) [(SA244)]
EPM7064S@PLCC68 (7064 mode) [(PEP+S414T)]
EPM7064S@PLCC68 (7064S mode) [(PEP+S414T)]
EPM7064S@PLCC84 (7064 mode) [(PEP+S416T)]
EPM7064S@PLCC84 (7064S mode) [(PEP+S416T)]
EPM7064S@PQFP100 (7064 mode) [(PEP+S427)]
EPM7064S@PQFP100 (7064S mode) [(PEP+S427)]
EPM7064S@TQFP100 (7064 mode) [(PEP+S604)]
EPM7064S@TQFP100 (7064S mode) [(PEP+S604)]
EPM7064S@TQFP44 (7064 mode) [(SA245A)]
EPM7064S@TQFP44 (7064S mode) [(SA245A)]
EPM7096@PLCC68 [(PEP+S414T)] EPM7096@PLCC84 [(PEP+S416T)]
EPM7096@PQFP100 [(PEP+S427)]
EPM7128A@PLCC84 (7128E mode) [(PEP+S416T)]
EPM7128A@PLCC84 (7128S mode) [(PEP+S416T)]
EPM7128A@PQFP100 (7128E mode) [(PEP+S427)]
EPM7128A@PQFP100 (7128S mode) [(PEP+S427)]
EPM7128A@PQFP160(*) (7128S mode)
EPM7128A@TQFP100 (7128S mode) [(PEP+S604)]
EPM7128A@TQFP100(*) (7128S mode) [(SA773+B343)]
EPM7128AE@FBGA100 (7128AE mode) [(SA800B+B325A+W100F001Y)]
EPM7128AE@PLCC44 (7128AE mode) [(SA244)]
EPM7128AE@PLCC84 (7128AE mode) [(PEP+S416T)]
EPM7128AE@TQFP100 (7128AE mode) [(PEP+S604)]
EPM7128AE@TQFP44 (7128AE mode) [(SA245A)]
EPM7128B@TQFP100 (7128A mode) [(PEP+S604)]
EPM7128B@TQFP100 (7128AE mode) [(PEP+S604)]
EPM7128B@TQFP100 (7128B mode) [(PEP+S604)]
EPM7128B@TQFP100 (7128S mode) [(PEP+S604)]
EPM7128E@PLCC84 [(PEP+S416T)] EPM7128E@PQFP100 [(PEP+S427)]
EPM7128E@PQFP160(*)
EPM7128S@PLCC84 (7128E mode) [(PEP+S416T)]
EPM7128S@PQFP100 (7128E mode) [(PEP+S427)]
EPM7128S@PQFP100 (7128S mode) [(PEP+S427)]
EPM7128S@PQFP160(*)
EPM7128S@TQFP100 (7128S mode) [(PEP+S604)]
EPM7128S@TQFP100(*) (7128S mode) [(SA773+B343)]
EPM7128SLC84@PLCC84 (7128S mode) [(PEP+S416T)]
EPM7128SLI84@PLCC84 (7128S mode) [(PEP+S416T)]
EPM7160E@PQFP100 [(PEP+S427)] EPM7160E@PQFP160(*)
EPM7160ELC84@PLCC84 [(PEP+S416T)]
EPM7160ELI84@PLCC84 [(PEP+S416T)]

```

## AMD

### E(E) PROM/FRAM/NVRAM

```

1736 1736@SOIC8 [(SA602A)]
1765 1765@SOIC8 [(SA602A)]
AM25FL005D@SOIC8 [(SA602A)] AM25FL005D@USON8 [(SA683)]
AM25FL010D@SOIC8 [(SA602A)] AM25FL010D@USON8 [(SA683)]

```

AM25FL016A@SOIC16 [(SA404)]  
 AM25FL016A@SOIC16(ISP) [ISP-HEADER01]  
 AM25FL016A@WSON8 [(SA684)]  
 AM25FL016A@WSON8(ISP) [ISP-HEADER01]  
 AM25FL020D@SOIC8 [(SA602A)] AM25FL020D@USON8 [(SA683)]  
 AM25FL032A@SOIC16 [(SA404)]  
 AM25FL032A@SOIC16(ISP) [ISP-HEADER01]  
 AM25FL032A@WSON8 [(SA684)]  
 AM25FL032A@WSON8(ISP) [ISP-HEADER01]  
 AM25FL040D@SOIC8 [(SA602A)] AM25FL040D@USON8 [(SA683)]  
 AM25FL080D@SOIC8 [(SA602A)] AM25FL080D@USON8 [(SA683)]  
 AM27128  
 AM27128(DC)@PLCC32 [(SA015A1T)] AM27128@PLCC32 [(SA015A1T)]  
 AM27128A  
 AM27128A(F)@PLCC32 [(SA015A1T)] AM27128A(F)  
 AM27128A(PC)@PLCC32 [(SA015A1T)] AM27128A(PC)  
 AM27128A@PLCC32 [(SA015A1T)] AM27128A@PLCC32 [(SA015A1T)]  
 AM2716  
 AM27256  
 AM27256@PLCC32 [(SA015A1T)] AM27256@PLCC32 [(SA015A1T)]  
 AM27256AP  
 AM27256AP@PLCC32 [(SA015A1T)] AM27256AP@PLCC32 [(SA015A1T)]  
 AM27256F  
 AM27256F@PLCC32 [(SA015A1T)] AM27256F@PLCC32 [(SA015A1T)]  
 AM27256PC  
 AM27256PC@PLCC32 [(SA015A1T)] AM27256PC@PLCC32 [(SA015A1T)]  
 AM2732  
 AM2732A  
 AM27512  
 AM27512@PLCC32 [(SA015A1T)] AM27512@PLCC32 [(SA015A1T)]  
 AM27512DC  
 AM27512DC@PLCC32 [(SA015A1T)] AM27512DC@PLCC32 [(SA015A1T)]  
 AM27512F  
 AM27512F@PLCC32 [(SA015A1T)] AM27512F@PLCC32 [(SA015A1T)]  
 AM27512PC  
 AM27512PC@PLCC32 [(SA015A1T)] AM27512PC@PLCC32 [(SA015A1T)]  
 AM27513  
 AM2764  
 AM2764@PLCC32 [(SA015A1T)] AM2764@PLCC32 [(SA015A1T)]  
 AM2764A  
 AM2764A(DC)@PLCC32 [(SA015A1T)] AM2764A(DC)  
 AM2764A(DCB)  
 AM2764A(DIB)  
 AM2764A(F)@PLCC32 [(SA015A1T)] AM2764A(F)@PLCC32 [(SA015A1T)]  
 AM2764A(LC)  
 AM2764A(LCB)  
 AM2764A(LE)  
 AM2764A(PC)  
 AM2764A@PLCC32 [(SA015A1T)] AM2764A@PLCC32 [(SA015A1T)]  
 AM27C010  
 AM27C010@PLCC32 [(SA015A1T)] AM27C010@PLCC32 [(SA015A1T)]  
 AM27C010@TSOP32 [(SA410T)] AM27C010@TSOP32 [(SA410T)]  
 AM27C020@PLCC32 [(SA015A1T)] AM27C020@PLCC32 [(SA015A1T)]  
 AM27C020@TSOP32 [(SA410T)] AM27C020@TSOP32 [(SA410T)]  
 AM27C040  
 AM27C040@PLCC32 [(SA015A1T)] AM27C040@PLCC32 [(SA015A1T)]  
 AM27C040@TSOP32 [(SA410T)] AM27C040@TSOP32 [(SA410T)]  
 AM27C080@PLCC32 [(SA015A1T)] AM27C080@PLCC32 [(SA015A1T)]  
 AM27C080@TSOP32 [(SA410T)] AM27C080@TSOP32 [(SA410T)]  
 AM27C100  
 AM27C100@PLCC32 [(SA015A1T)] AM27C100@PLCC32 [(SA015A1T)]  
 AM27C100@TSOP32 [(SA410T)] AM27C100@TSOP32 [(SA410T)]  
 AM27C1024  
 AM27C1024@PLCC44 [(SA244)] AM27C1024@PLCC44 [(SA244)]  
 AM27C128  
 AM27C128@PLCC32 [(SA015A1T)] AM27C128@PLCC32 [(SA015A1T)]  
 AM27C2048  
 AM27C2048@PLCC44 [(SA244)] AM27C2048@PLCC44 [(SA244)]  
 AM27C2048@TSOP40 [(SA409T)] AM27C2048@TSOP40 [(SA409T)]  
 AM27C256  
 AM27C256(F)@PLCC32 [(SA015A1T)] AM27C256(F)@PLCC32 [(SA015A1T)]  
 AM27C256(PC)@PLCC32 [(SA015A1T)] AM27C256(PC)@PLCC32 [(SA015A1T)]  
 AM27C256@PLCC32 [(SA015A1T)] AM27C256@PLCC32 [(SA015A1T)]  
 AM27C400  
 AM27C400@PLCC44 [(SA244)] AM27C400@PLCC44 [(SA244)]  
 AM27C4096  
 AM27C4096@PLCC44 [(SA244)] AM27C4096@PLCC44 [(SA244)]  
 AM27C512  
 AM27C512(P)@PLCC32 [(SA015A1T)] AM27C512(P)@PLCC32 [(SA015A1T)]  
 AM27C512@PLCC32 [(SA015A1T)] AM27C512@PLCC32 [(SA015A1T)]  
 AM27C64  
 AM27C64@PLCC32 [(SA015A1T)] AM27C64@PLCC32 [(SA015A1T)]  
 AM27H010  
 AM27H010@PLCC32 [(SA015A1T)] AM27H010@PLCC32 [(SA015A1T)]  
 AM27H010@TSOP32 [(SA410T)] AM27H010@TSOP32 [(SA410T)]  
 AM27H256  
 AM27H256@PLCC32 [(SA015A1T)] AM27H256@PLCC32 [(SA015A1T)]  
 AM27HB010  
 AM27HB010@PLCC32 [(SA015A1T)] AM27HB010@PLCC32 [(SA015A1T)]  
 AM27HB010@TSOP32 [(SA410T)] AM27HB010@TSOP32 [(SA410T)]  
 AM27LV010  
 AM27LV010@PLCC32 [(SA015A1T)] AM27LV010@PLCC32 [(SA015A1T)]  
 AM27LV010B  
 AM27LV010B@TSOP32 [(SA410T)] AM27LV010B@TSOP32 [(SA410T)]  
 AM27LV010B@PLCC32 [(SA015A1T)] AM27LV010B@PLCC32 [(SA015A1T)]  
 AM27LV020  
 AM27LV020@TSOP32 [(SA410T)] AM27LV020@TSOP32 [(SA410T)]  
 AM27LV020B  
 AM27LV020B@PLCC32 [(SA015A1T)] AM27LV020B@PLCC32 [(SA015A1T)]  
 AM27LV020B@TSOP32 [(SA410T)] AM27LV020B@TSOP32 [(SA410T)]  
 AM2817A  
 AM2817A@PLCC32 [(SA015A1T)] AM2817A@PLCC32 [(SA015A1T)]  
 AM2817A@SOIC28 [(SA404)] AM2817A@SOIC28 [(SA404)]  
 AM2864A  
 AM2864A(E)@PLCC32 [(SA015A1T)] AM2864A(E)@PLCC32 [(SA015A1T)]  
 AM2864A@PLCC32 [(SA015A1T)] AM2864A@PLCC32 [(SA015A1T)]  
 AM2864B  
 AM2864B(E)@PLCC32 [(SA015A1T)] AM2864B(E)@PLCC32 [(SA015A1T)]  
 AM2864B@PLCC32 [(SA015A1T)] AM2864B@PLCC32 [(SA015A1T)]  
 AM28F001  
 AM28F001@PLCC32 [(SA015A1T)] AM28F001@PLCC32 [(SA015A1T)]  
 AM28F001@TSOP32 [(SA410T)] AM28F001@TSOP32 [(SA410T)]  
 AM28F010  
 AM28F010@PLCC32 [(SA015A1T)] AM28F010@PLCC32 [(SA015A1T)]  
 AM28F010@TSOP32 [(SA410T)] AM28F010@TSOP32 [(SA410T)]  
 AM28F010A  
 AM28F010A@PLCC32 [(SA015A1T)] AM28F010A@PLCC32 [(SA015A1T)]  
 AM28F010A@TSOP32 [(SA410T)] AM28F010A@TSOP32 [(SA410T)]  
 AM28F020  
 AM28F020@PLCC32 [(SA015A1T)] AM28F020@PLCC32 [(SA015A1T)]  
 AM28F020@TSOP32 [(SA410T)] AM28F020@TSOP32 [(SA410T)]  
 AM28F020A  
 AM28F020A@PLCC32 [(SA015A1T)] AM28F020A@PLCC32 [(SA015A1T)]  
 AM28F020A@TSOP32 [(SA410T)] AM28F020A@TSOP32 [(SA410T)]  
 AM28F256  
 AM28F256@PLCC32 [(SA015A1T)] AM28F256@PLCC32 [(SA015A1T)]  
 AM28F256@TSOP32 [(SA410T)] AM28F256@TSOP32 [(SA410T)]  
 AM28F256A  
 AM28F256A@PLCC32 [(SA015A1T)] AM28F256A@PLCC32 [(SA015A1T)]



```

AM28F256A@TSOP32 [(SA410T)]          AM28F512
AM28F512(F)                          AM28F512(F)@PLCC32 [(SA015A1T)]
AM28F512(F)@TSOP32 [(SA410T)]        AM28F512@PLCC32 [(SA015A1T)]
AM28F512@TSOP32 [(SA410T)]           AM28F512A
AM28F512A(F)                          AM28F512A(F)@PLCC32 [(SA015A1T)]
AM28F512A(F)@TSOP32 [(SA410T)]       AM28F512A@PLCC32 [(SA015A1T)]
AM28F512A@TSOP32 [(SA410T)]
AM29BL162CB@SSOP56 [(SA629A-B022)]
AM29BL802CB@SSOP56 [(SA629A-B022)]
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DB@FBGA63 [(SA642L-B026A-W048F001Y)]
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DB@TSOP48 [(SA247-B005)]
AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DT@TSOP48 [(SA247-B005)]
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@TSOP48 [(SA247-B005)]
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CT@TSOP48 [(SA247-B005)]
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DB@TSOP48 [(SA247-B005)]
AM29DL162DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DT@TSOP48 [(SA247-B005)]
AM29DL162DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@TSOP48 [(SA247-B005)]
AM29DL163CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CT@TSOP48 [(SA247-B005)]
AM29DL163DB@FBGA48 [(SA642HH-B026A-T048F001Y)]
AM29DL163DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL163DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL163DB@TSOP48 [(SA247-B005)]
AM29DL163DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163DT@FBGA48 [(SA642HH-B026A-T048F001Y)]
AM29DL163DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL163DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL163DT@TSOP48 [(SA247-B005)]
AM29DL163DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CB@TSOP48 [(SA247-B005)]
AM29DL164CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CT@TSOP48 [(SA247-B005)]
AM29DL164DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL164DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL164DB@TSOP48 [(SA247-B005)]
AM29DL164DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL164DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL164DT@TSOP48 [(SA247-B005)]
AM29DL164DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GB@FBGA63 [(SA642L-B026A-W080F001Y)]
AM29DL320GB@FBGA64 [(SA655D-B044A-W064F001Y)]
AM29DL320GB@TSOP48 [(SA247-B005)]
AM29DL320GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GT@FBGA63 [(SA642L-B026A-W080F001Y)]
AM29DL320GT@FBGA64 [(SA655D-B044A-W064F001Y)]
AM29DL320GT@TSOP48 [(SA247-B005)]
AM29DL321CB@TSOP48 [(SA247-B005)]
AM29DL321CT@TSOP48 [(SA247-B005)]
AM29DL322CB@FBGA63 [(SA642L-B026A-W048F001Y)]
AM29DL322CB@TSOP48 [(SA247-B005)]
AM29DL322CT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322CT@TSOP48 [(SA247-B005)]
AM29DL322DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322DB@TSOP48 [(SA247-B005)]
AM29DL322DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322DT@TSOP48 [(SA247-B005)]
AM29DL322GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL322GB@FBGA63 [(SA642L-B026A-W080F001Y)]

```

```

AM29DL322GB@FBGA64 [ (SA655D-B044A-W064F001Y) ]
AM29DL322GB@TSOP48 [ (SA247-B005) ]
AM29DL322GT@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL322GT@FBGA63 [ (SA642L-B026A-W080F001Y) ]
AM29DL322GT@FBGA64 [ (SA655D-B044A-W064F001Y) ]
AM29DL322GT@TSOP48 [ (SA247-B005) ]
AM29DL323CB@FBGA63 [ (SA642E-B026A-T056N001) ]
AM29DL323CB@TSOP48 [ (SA247-B005) ]
AM29DL323CT@FBGA63 [ (SA642E-B026A-T056N001) ]
AM29DL323CT@TSOP48 [ (SA247-B005) ]
AM29DL323DB@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL323DB@FBGA63 [ (SA642E-B026A-T056N001) ]
AM29DL323DB@TSOP48 [ (SA247-B005) ]
AM29DL323DT@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL323DT@FBGA63 [ (SA642E-B026A-T056N001) ]
AM29DL323DT@TSOP48 [ (SA247-B005) ]
AM29DL323GB@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL323GB@FBGA63 [ (SA642L-B026A-W080F001Y) ]
AM29DL323GB@FBGA64 [ (SA655D-B044A-W064F001Y) ]
AM29DL323GB@TSOP48 [ (SA247-B005) ]
AM29DL323GT@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL323GT@FBGA63 [ (SA642L-B026A-W080F001Y) ]
AM29DL323GT@FBGA64 [ (SA655D-B044A-W064F001Y) ]
AM29DL323GT@TSOP48 [ (SA247-B005) ]
AM29DL324CB@TSOP48 [ (SA247-B005) ]
AM29DL324CT@TSOP48 [ (SA247-B005) ]
AM29DL324DB@FBGA63 [ (SA642E-B026A-T056N001) ]
AM29DL324DB@TSOP48 [ (SA247-B005) ]
AM29DL324DT@FBGA63 [ (SA642E-B026A-T056N001) ]
AM29DL324DT@TSOP48 [ (SA247-B005) ]
AM29DL324GB@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL324GB@FBGA63 [ (SA642L-B026A-W080F001Y) ]
AM29DL324GB@FBGA64 [ (SA655D-B044A-W064F001Y) ]
AM29DL324GB@TSOP48 [ (SA247-B005) ]
AM29DL324GT@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DL324GT@FBGA63 [ (SA642L-B026A-W080F001Y) ]
AM29DL324GT@FBGA64 [ (SA655D-B044A-W064F001Y) ]
AM29DL324GT@TSOP48 [ (SA247-B005) ]
AM29DL400BB@PSOP44 [ (SA638-B006) ]
AM29DL400BB@TSOP48 [ (SA247-B005) ]
AM29DL400BT@PLCC44 [ (SA638-B006) ]
AM29DL400BT@TSOP48 [ (SA247-B005) ]
AM29DL640D@FBGA63 [ (SA642C-B026A-Y056F001) ]
AM29DL640D@TSOP48 [ (SA247-B005) ]
AM29DL640G@FBGA63 [ (SA642C-B026A-Y056F001) ]
AM29DL640G@FBGA64 [ (SA655A-B044A-T064N001) ]
AM29DL640G@TSOP48 [ (SA247-B005) ]
AM29DL642G@FBGA63 [ (SA642C-B026A-Y056F001) ]
AM29DL800B@PSOP44 [ (SA638-B006) ]
AM29DL800B@TSOP48 [ (SA247-B005) ]
AM29DL800BB@FBGA48 [ (SA642N-B026A-W048F001Y) ]
AM29DL800BB@PSOP44 [ (SA638) ]
AM29DL800BB@TSOP48 [ (SA247-B005) ]
AM29DL800BT@FBGA48 [ (SA642N-B026A-W048F001Y) ]
AM29DL800BT@PSOP44 [ (SA638) ]
AM29DL800BT@TSOP48 [ (SA247-B005) ]
AM29DL800T@PSOP44 [ (SA638-B006) ]
AM29DL800T@TSOP48 [ (SA247-B005) ]
AM29DS163CB@TSOP48 [ (SA247-B005) ]
AM29DS163CT@TSOP48 [ (SA247-B005) ]
AM29DS163DB@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DS163DB@TSOP48 [ (SA247-B005) ]
AM29DS163DT@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DS163DT@TSOP48 [ (SA247-B005) ]
AM29DS323DB@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DS323DB@TSOP48 [ (SA247-B005) ]
AM29DS323DT@FBGA48 [ (SA642B-B026A-Y072F001) ]
AM29DS323DT@TSOP48 [ (SA247-B005) ]
AM29F002B
AM29F002B@TSOP32 [ (SA410T) ]
AM29F002BB@PLCC32 [ (SA015A1T) ]
AM29F002BB@TSOP32 [ (SA410T) ]
AM29F002BT
AM29F002BT@PLCC32 [ (SA015A1T) ]
AM29F002BT@TSOP32 [ (SA410T) ]
AM29F002NB@PLCC32 [ (SA015A1T) ]
AM29F002NB@TSOP32 [ (SA410T) ]
AM29F002NBB
AM29F002NBB@PLCC32 [ (SA015A1T) ]
AM29F002NBB@TSOP32 [ (SA410T) ]
AM29F002NBT@PLCC32 [ (SA015A1T) ]
AM29F002NBT@TSOP32 [ (SA410T) ]
AM29F002NT
AM29F002NT@PLCC32 [ (SA015A1T) ]
AM29F002NT@TSOP32 [ (SA410T) ]
AM29F002T@PLCC32 [ (SA015A1T) ]
AM29F002T@TSOP32 [ (SA410T) ]
AM29F004BB@PLCC32 [ (SA015A1T) ]
AM29F004BB@TSOP32 [ (SA410T) ]
AM29F004BT@PLCC32 [ (SA015A1T) ]
AM29F004BT@TSOP32 [ (SA410T) ]
AM29F010
AM29F010@PLCC32 [ (SA015A1T) ]

```

AM29F010@TSOP32 [(SA410T)]	AM29F010A
AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32 [(SA410T)]
AM29F010B	AM29F010B@PLCC32 [(SA015A1T)]
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44 [(SA638)]
AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-B005)]
AM29F016B(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40 [(SA409T)]
AM29F016B@TSOP48 [(SA247-B005)]	
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40 [(SA409T)]
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-B005)]
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-B005)]
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40 [(SA409T)]
AM29F040	AM29F040@PLCC32 [(SA015A1T)]
AM29F040@TSOP32 [(SA410T)]	AM29F040A
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32 [(SA410T)]
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32 [(SA410T)]
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40 [(SA409T)]
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40 [(SA409T)]
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-B005)]
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-B005)]
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-B005)]
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-B005)]
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-B005)]
AM29F200AB@PSOP44 [(SA638-B006)]	AM29F200AB@TSOP48 [(SA247-B005)]
AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-B005)]
AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-B005)]
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-B005)]
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-B005)]
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-B005)]
AM29F400AT@PSOP44 [(SA638-B006)]	AM29F400AT@TSOP48 [(SA247-B005)]
AM29F400BB@PSOP44 [(SA638-B006)]	AM29F400BB@TSOP48 [(SA247-B005)]
AM29F400BBE@PSOP44 [(SA638-B006)]	
AM29F400BBE@TSOP48 [(SA247-B005)]	
AM29F400BBF@PSOP44 [(SA638-B006)]	
AM29F400BBF@TSOP48 [(SA247-B005)]	
AM29F400BBS@PSOP44 [(SA638-B006)]	
AM29F400BBS@TSOP48 [(SA247-B005)]	
AM29F400BE@PSOP44 [(SA638-B006)]	AM29F400BE@TSOP48 [(SA247-B005)]
AM29F400BF@PSOP44 [(SA638-B006)]	AM29F400BF@TSOP48 [(SA247-B005)]
AM29F400BS@PSOP44 [(SA638-B006)]	AM29F400BS@TSOP48 [(SA247-B005)]
AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-B005)]
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	
AM29F400BTF@PSOP44 [(SA638-B006)]	
AM29F400BTF@TSOP48 [(SA247-B005)]	
AM29F400BTS@PSOP44 [(SA638-B006)]	
AM29F400BTS@TSOP48 [(SA247-B005)]	
AM29F800B@PSOP44 [(SA638-B006)]	AM29F800B@TSOP48 [(SA247-B005)]
AM29F800BB@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29F800BB@PSOP44 [(SA638-B006)]	AM29F800BB@TSOP48 [(SA247-B005)]
AM29F800BBF@PSOP44 [(SA638-B006)]	
AM29F800BBF@TSOP48 [(SA247-B005)]	
AM29F800BF@PSOP44 [(SA638-B006)]	AM29F800BF@TSOP48 [(SA247-B005)]
AM29F800BT@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29F800BT@PSOP44 [(SA638-B006)]	AM29F800BT@TSOP48 [(SA247-B005)]
AM29F800BTF@PSOP44 [(SA638-B006)]	
AM29F800BTF@TSOP48 [(SA247-B005)]	
AM29F800T@PSOP44 [(SA638-B006)]	AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@PSOP44 [(SA638-B006)]	AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@PSOP44 [(SA638-B006)]	AM29F800TF@TSOP48 [(SA247-B005)]
AM29LL800B@TSOP48 [(SA247-B005)]	
AM29LL800BB@TSOP48 [(SA247-B005)]	
AM29LL800BT@TSOP48 [(SA247-B005)]	
AM29LL800T@TSOP48 [(SA247-B005)]	
AM29LV001BB@TSOP32 [(SA410T)]	AM29LV001BB@PLCC32 [(SA015A1T)]
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV001BT@PLCC32 [(SA015A1T)]
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV002@TSOP40 [(SA409T)]
AM29LV002B@TSOP40 [(SA409T)]	AM29LV002BB@TSOP40 [(SA409T)]
AM29LV002BT@TSOP40 [(SA409T)]	AM29LV004B@PSOP44 [(SA638)]
AM29LV004B@TSOP40 [(SA409T)]	AM29LV004BB@TSOP40 [(SA409T)]
AM29LV004BT@TSOP40 [(SA409T)]	AM29LV004T@PSOP44 [(SA638)]
AM29LV004T@TSOP40 [(SA409T)]	AM29LV008B@PSOP44 [(SA638)]
AM29LV008B@TSOP40 [(SA409T)]	AM29LV008BB@TSOP40 [(SA409T)]
AM29LV008BT@TSOP40 [(SA409T)]	AM29LV008T@PSOP44 [(SA638)]
AM29LV008T@TSOP40 [(SA409T)]	AM29LV010B@PLCC32 [(SA015A1T)]
AM29LV010B@TSOP32 [(SA410T)]	AM29LV017B@TSOP40 [(SA409T)]

AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29LV017D@TSOP40 [(SA409T)] AM29LV020B@PLCC32 [(SA015A1T)]  
 AM29LV020B@TSOP32 [(SA410T)]  
 AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]  
 AM29LV033C@TSOP40 [(SA409T)]  
 AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29LV033MU@TSOP40 [(SA409T)] AM29LV040B@PLCC32 [(SA015A1T)]  
 AM29LV040B@TSOP32 [(SA410T)] AM29LV040E@PLCC32 [(SA015A1T)]  
 AM29LV040E@TSOP32 [(SA410T)] AM29LV040J@PLCC32 [(SA015A1T)]  
 AM29LV040J@TSOP32 [(SA410T)]  
 AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]  
 AM29LV065D@TSOP48 [(SA247-B005)]  
 AM29LV065MU@FBGA63 [(SA642C-B026A-Y056F001)]  
 AM29LV065MU@TSOP48 [(SA247-B005)]  
 AM29LV080@TSOP40 [(SA409T)] AM29LV081@TSOP40 [(SA409T)]  
 AM29LV081B@TSOP40 [(SA409T)] AM29LV116BB@TSOP40 [(SA409T)]  
 AM29LV116BT@TSOP40 [(SA409T)] AM29LV116DB@TSOP40 [(SA409T)]  
 AM29LV116DT@TSOP40 [(SA409T)]  
 AM29LV128MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
 AM29LV128MH@TSOP56 [(SA628-B067)]  
 AM29LV128ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
 AM29LV128ML@TSOP56 [(SA628-B067)]  
 AM29LV160BB@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160BB@PSOP44 [(SA638)]  
 AM29LV160BB@TSOP48 [(SA247-B005)]  
 AM29LV160BT@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160BT@PSOP44 [(SA638)]  
 AM29LV160BT@TSOP48 [(SA247-B005)]  
 AM29LV160DB(REVERSE)@TSOP48 [(SA247-B005)]  
 AM29LV160DB@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160DB@PSOP44 [(SA638)]  
 AM29LV160DB@TSOP48 [(SA247-B005)]  
 AM29LV160DT(REVERSE)@TSOP48 [(SA247-B005)]  
 AM29LV160DT@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160DT@PSOP44 [(SA638)]  
 AM29LV160DT@TSOP48 [(SA247-B005)]  
 AM29LV160MB@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29LV160MB@FBGA64 [(SA655A-B044A-T064N001)]  
 AM29LV160MB@PSOP44 [(SA638)]  
 AM29LV160MB@TSOP48 [(SA247-B005)]  
 AM29LV160MT@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29LV160MT@FBGA64 [(SA655A-B044A-T064N001)]  
 AM29LV160MT@PSOP44 [(SA638)]  
 AM29LV160MT@TSOP48 [(SA247-B005)]  
 AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]  
 AM29LV200BB@PSOP44 [(SA638-B006)]  
 AM29LV200BB@TSOP48 [(SA247-B005)]  
 AM29LV200BE@PSOP44 [(SA638-B006)]  
 AM29LV200BE@TSOP48 [(SA247-B005)]  
 AM29LV200BF@PSOP44 [(SA638-B006)]  
 AM29LV200BF@TSOP48 [(SA247-B005)]  
 AM29LV200BS@PSOP44 [(SA638-B006)]  
 AM29LV200BS@TSOP48 [(SA247-B005)]  
 AM29LV200BT@PSOP44 [(SA638-B006)]  
 AM29LV200BT@TSOP48 [(SA247-B005)]  
 AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]  
 AM29LV200TE@PSOP44 [(SA638-B006)]  
 AM29LV200TE@TSOP48 [(SA247-B005)]  
 AM29LV200TF@PSOP44 [(SA638-B006)]  
 AM29LV200TF@TSOP48 [(SA247-B005)]  
 AM29LV200TS@PSOP44 [(SA638-B006)]  
 AM29LV200TS@TSOP48 [(SA247-B005)]  
 AM29LV256MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
 AM29LV256MH@TSOP56 [(SA628-B067)]  
 AM29LV256ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
 AM29LV256ML@TSOP56 [(SA628-B067)]  
 AM29LV320DB@FBGA48 [(SA642E-B026A-T072F001)]  
 AM29LV320DB@TSOP48 [(SA247-B005)]  
 AM29LV320DT@FBGA48 [(SA642E-B026A-T072F001)]  
 AM29LV320DT@TSOP48 [(SA247-B005)]  
 AM29LV320FB@TSOP48 [(SA247-B005)]  
 AM29LV320FT@TSOP48 [(SA247-B005)]  
 AM29LV320MB@FBGA48 [(SA642HH-B026A-T048F001Y)]  
 AM29LV320MB@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV320MB@TSOP48 [(SA247-B005)]  
 AM29LV320MH@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV320MH@TSOP56 [(SA628-B067)]  
 AM29LV320ML@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV320ML@TSOP56 [(SA628-B067)]  
 AM29LV320MT@FBGA48 [(SA642HH-B026A-T048F001Y)]  
 AM29LV320MT@FBGA64 [(SA655D-B044A-W064F001Y)]

AM29LV320MT@TSOP48 [(SA247-B005)]  
 AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]  
 AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AM29LV400BB@PSOP44 [(SA638-B006)]  
 AM29LV400BB@TSOP48 [(SA247-B005)]  
 AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AM29LV400BT@PSOP44 [(SA638-B006)]  
 AM29LV400BT@TSOP48 [(SA247-B005)]  
 AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]  
 AM29LV640DH@SSOP56 [(SA629A-B020)]  
 AM29LV640DL@SSOP56 [(SA629A-B020)]  
 AM29LV640DU@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV640DU@FBGA64 [(SA655D-B044A-W064F001)]  
 AM29LV640GU@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV640GU@FBGA64 [(SA655D-B044A-W064F001)]  
 AM29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV640MB@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV640MB@TSOP48 [(SA247-B005)]  
 AM29LV640MH@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV640MH@TSOP56 [(SA628-B067)]  
 AM29LV640ML@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV640ML@TSOP56 [(SA628-B067)]  
 AM29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV640MT@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV640MT@TSOP48 [(SA247-B005)]  
 AM29LV640MU@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV640MU@FBGA64 [(SA655D-B044A-W064F001Y)]  
 AM29LV641DH@TSOP48 [(SA247-B005)]  
 AM29LV641DHR@TSOP48 [(SA247-B005)]  
 AM29LV641DL@TSOP48 [(SA247-B005)]  
 AM29LV641DLR@TSOP48 [(SA247-B005)]  
 AM29LV641GH@TSOP48 [(SA247-B005)]  
 AM29LV641GHR@TSOP48 [(SA247-B005)]  
 AM29LV641GL@TSOP48 [(SA247-B005)]  
 AM29LV641GLR@TSOP48 [(SA247-B005)]  
 AM29LV641MH@TSOP48 [(SA247-B005)]  
 AM29LV641ML@TSOP48 [(SA247-B005)]  
 AM29LV642G@FBGA64 [(SA655A-B038A-T064N001)]  
 AM29LV652D@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]  
 AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800BB@PSOP44 [(SA638-B006)]  
 AM29LV800BB@TSOP48 [(SA247-B005)]  
 AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800BT@PSOP44 [(SA638-B006)]  
 AM29LV800BT@TSOP48 [(SA247-B005)]  
 AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29LV800DB@PSOP44 [(SA638)]  
 AM29LV800DB@TSOP48 [(SA247-B005)]  
 AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29LV800DT@PSOP44 [(SA638)]  
 AM29LV800DT@TSOP48 [(SA247-B005)]  
 AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]  
 AM29N163DT@FBGA47 [(SA733A-B206A-M056F001N)]  
 AM29N323DT@FBGA47 [(SA733A-B206A-M056F001N)]  
 AM29N643GT@FBGA44 [(SA733A-B206A-M056F001Y)]  
 AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]  
 AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]  
 AM29PL160CB@PSOP44 [(SA638-B006)]  
 AM29PL160CB@TSOP48 [(SA247-B005)]  
 AM29PL160CT@PSOP44 [(SA638-B006)]  
 AM29PL160CT@TSOP48 [(SA247-B005)]  
 AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29SL160CB@TSOP48 [(SA247-B005)]  
 AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29SL160CT@TSOP48 [(SA247-B005)]  
 AM29SL400CB@TSOP48 [(SA247-B005)]  
 AM29SL400CT@TSOP48 [(SA247-B005)]  
 AM29SL800BB@TSOP48 [(SA247-B005)]  
 AM29SL800BT@TSOP48 [(SA247-B005)]  
 AM29SL800CB@TSOP48 [(SA247-B005)]  
 AM29SL800CT@TSOP48 [(SA247-B005)]  
 AM29SL800DB@TSOP48 [(SA247-B005)]  
 AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]  
 AM29SL800DT@TSOP48 [(SA247-B005)]

AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DTV@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]  
 AM9716 AM9732  
 AM9732A AM9764  
 AM9764@PLCC32 [(SA015A1T)]  
 BS128HD8V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
 BS128HD9V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
 BS128HE8V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
 BS128HE9V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
 BS128HF8V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
 BS128HF9V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
 BS640HD8V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
 BS640HD9V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
 BS640HE8V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
 BS640HE9V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
 BS640HF8V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
 BS640HF9V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
 DS42514(AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]  
 DS42515(AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]  
 DS42516(AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42546(AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]  
 DS42553(AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42585(AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42587(AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42629(AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]  
 DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
 DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
 DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
 DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
 DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
 DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
 DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
 DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
 DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
 M410000000(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000001(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000002(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000003(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000004(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000005(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000006(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000007(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000008(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M410000009(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000A(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000B(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000C(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000D(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000E(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000F(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
 M41000000G(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000000H(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000001W(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000001X(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000001Y(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000001Z(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000020(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000021(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000022(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000023(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000024(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000025(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000026(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M410000027(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002L(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002M(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002N(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002O(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002P(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002Q(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002R(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002S(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002T(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002U(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002V(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000002W(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000003D(AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
 M41000003E(AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]

M41000003F (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003G (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000095 (AM41LV3204MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000096 (AM41LV3204MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000009B (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009C (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009D (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000000 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000001 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000004 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000005 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000006 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000007 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000I (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000J (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000K (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000L (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000M (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000N (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000O (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000P (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000Q (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000R (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000S (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000T (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000U (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000V (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000W (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000X (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001A (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001B (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001C (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001D (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001E (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001F (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001G (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001H (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001I (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001J (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001K (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001L (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001M (AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001N (AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001O (AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001P (AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000022 (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000023 (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000024 (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000025 (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000026 (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000027 (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000028 (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000029 (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002A (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002B (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002C (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002D (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002U (AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002V (AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002Y (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000002Z (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000030 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000031 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000032 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000033 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000034 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000035 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Y (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Z (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000050 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000051 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000052 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000053 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000054 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000055 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000005M (AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005N (AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005W (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005X (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Y (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Z (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]

M420000060 (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000061 (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000070 (AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077 (AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000078 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000079 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000000 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000001 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000008 (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000009 (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000A (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000B (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000S (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000T (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000U (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000V (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001C (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001D (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001E (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001F (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001W (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001X (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Y (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Z (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000000 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000001 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000G (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000H (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000J (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000K (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000L (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000M (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000N (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000O (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000P (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000Q (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000R (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000S (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000T (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000U (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001A (AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001B (AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000001Y (AM49PDL640AG)@FBGA73 [(SA642A-B032A-Y096N001)]  
M49000001Z (AM49PDL640AG)@FBGA73 [(SA642A-B032A-Y096N001)]  
M490000025 (AM49DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000026 (AM49DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000028 (AM49PDL127BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000029 (AM49PDL127BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M49000002I (AM49PDL127AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M49000002J (AM49PDL127AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M49000002T (AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000002U (AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000002V (AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000002X (AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000030 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000031 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M490000032 (AM49DL3208GB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000032 (AM49DL3208GT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000034 (AM49DL3208GT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M490000035 (AM49DL3208GB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000003A (AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003B (AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003C (AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003D (AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003E (AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003F (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003G (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003H (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003I (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003J (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003X (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003Y (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000003Z (AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000004A (AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M49000004B (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]



```

M490000004C (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M490000004D (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M490000004E (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M490000004H (AM49LV128BMH)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004J (AM49LV128BML)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004K (AM49LV128BMH)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004L (AM49LV128BML)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004S (AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004T (AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004U (AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]
M490000004V (AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000000K (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]
M49000000L (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]
M5000000000 (AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]
M5000000001 (AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]
M5000000008 (AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]
M5000000009 (AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]
M500000004J (AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M500000004K (AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M500000004L (AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M500000004M (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
M500000004N (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
M500000004P (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
M5000000000 (AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]
M5500000001 (AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]
PDL127H53V (AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H63V (AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H68V (AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H88V (AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H53V (AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H63V (AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H68V (AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H88V (AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]

```

## BPROM

```

AM27LS19 AM27LS19@PLCC20 [(SA001A)]
AM27LS19@SOIC16 [(SA404)] AM27PS191
AM27PS191@PLCC28 [(SA008A)] AM27PS191@PLCC32 [(SA015A1T)]
AM27PS191@SOIC24 [(SA404)] AM27PS191A
AM27PS191A@PLCC28 [(SA008A)] AM27PS191A@PLCC32 [(SA015A1T)]
AM27PS191A@SOIC24 [(SA404)] AM27PS291
AM27PS291@PLCC28 [(SA008A)] AM27PS291@PLCC32 [(SA015A1T)]
AM27PS291@SOIC24 [(SA404)] AM27PS291A
AM27PS291A@PLCC28 [(SA008A)] AM27PS291A@PLCC32 [(SA015A1T)]
AM27PS291A@SOIC24 [(SA404)] AM27PS41
AM27PS41@PLCC28 [(SA008A)] AM27PS41@SOIC20 [(SA404)]
AM27S13 AM27S13@PLCC20 [(SA001A)]
AM27S13@SOIC16 [(SA404)] AM27S13A
AM27S13A@PLCC20 [(SA001A)] AM27S13A@SOIC16 [(SA404)]
AM27S18 AM27S18@PLCC20 [(SA001A)]
AM27S18@SOIC16 [(SA404)] AM27S180
AM27S180@PLCC28 [(SA008A)] AM27S180@PLCC32 [(SA015A1T)]
AM27S180@SOIC24 [(SA404)] AM27S180A
AM27S180A@PLCC28 [(SA008A)] AM27S180A@PLCC32 [(SA015A1T)]
AM27S180A@SOIC24 [(SA404)] AM27S181
AM27S181@PLCC28 [(SA008A)] AM27S181@PLCC32 [(SA015A1T)]
AM27S181@SOIC24 [(SA404)] AM27S181A
AM27S181A@PLCC28 [(SA008A)] AM27S181A@PLCC32 [(SA015A1T)]
AM27S181A@SOIC24 [(SA404)] AM27S184
AM27S184@PLCC28 [(SA008A)] AM27S184@SOIC18 [(SA404)]
AM27S185 AM27S185@PLCC28 [(SA008A)]
AM27S185@SOIC18 [(SA404)] AM27S185A
AM27S185A@PLCC28 [(SA008A)] AM27S185A@SOIC18 [(SA404)]
AM27S18A AM27S18A@PLCC20 [(SA001A)]
AM27S18A@SOIC16 [(SA404)] AM27S19
AM27S19@PLCC20 [(SA001A)] AM27S19@SOIC16 [(SA404)]
AM27S190 AM27S190@PLCC28 [(SA008A)]
AM27S190@PLCC32 [(SA015A1T)] AM27S190@SOIC24 [(SA404)]
AM27S190A AM27S190A@PLCC28 [(SA008A)]
AM27S190A@PLCC32 [(SA015A1T)] AM27S190A@SOIC24 [(SA404)]
AM27S191 AM27S191@PLCC28 [(SA008A)]
AM27S191@PLCC32 [(SA015A1T)] AM27S191@SOIC24 [(SA404)]
AM27S191A AM27S191A@PLCC28 [(SA008A)]
AM27S191A@PLCC32 [(SA015A1T)] AM27S191A@SOIC24 [(SA404)]
AM27S191SA AM27S191SA@PLCC28 [(SA008A)]
AM27S191SA@PLCC32 [(SA015A1T)] AM27S191SA@SOIC24 [(SA404)]
AM27S19A AM27S19A@PLCC20 [(SA001A)]
AM27S19A@SOIC16 [(SA404)] AM27S19SA

```

AM27S19SA@PLCC20 [(SA001A)]	AM27S19SA@SOIC16 [(SA404)]
AM27S20	AM27S20@PLCC20 [(SA001A)]
AM27S20@SOIC16 [(SA404)]	AM27S21
AM27S21@PLCC20 [(SA001A)]	AM27S21@SOIC16 [(SA404)]
AM27S21A	AM27S21A@PLCC20 [(SA001A)]
AM27S21A@SOIC16 [(SA404)]	AM27S23
AM27S23@PLCC20 [(SA001A)]	AM27S23@SOIC20 [(SA404)]
AM27S23A	AM27S23A@PLCC20 [(SA001A)]
AM27S23A@SOIC20 [(SA404)]	AM27S25
AM27S25@PLCC28 [(SA008A)]	AM27S25@PLCC32 [(SA015A1T)]
AM27S25@SOIC24 [(SA404)]	AM27S25A
AM27S25A@PLCC28 [(SA008A)]	AM27S25A@PLCC32 [(SA015A1T)]
AM27S25A@SOIC24 [(SA404)]	AM27S25SA
AM27S25SA@PLCC28 [(SA008A)]	AM27S25SA@PLCC32 [(SA015A1T)]
AM27S25SA@SOIC24 [(SA404)]	AM27S27
AM27S27@SOIC24 [(SA404)]	AM27S27A
AM27S27A@SOIC24 [(SA404)]	AM27S280
AM27S280@PLCC28 [(SA008A)]	AM27S280@PLCC32 [(SA015A1T)]
AM27S280@SOIC24 [(SA404)]	AM27S281
AM27S281@PLCC28 [(SA008A)]	AM27S281@PLCC32 [(SA015A1T)]
AM27S281@SOIC24 [(SA404)]	AM27S281A
AM27S281A@PLCC28 [(SA008A)]	AM27S281A@PLCC32 [(SA015A1T)]
AM27S281A@SOIC24 [(SA404)]	AM27S29
AM27S29@PLCC20 [(SA001A)]	AM27S29@SOIC20 [(SA404)]
AM27S291	AM27S291@PLCC28 [(SA008A)]
AM27S291@PLCC32 [(SA015A1T)]	AM27S291@SOIC24 [(SA404)]
AM27S291A	AM27S291A@PLCC28 [(SA008A)]
AM27S291A@PLCC32 [(SA015A1T)]	AM27S291A@SOIC24 [(SA404)]
AM27S291SA	AM27S291SA@PLCC28 [(SA008A)]
AM27S291SA@PLCC32 [(SA015A1T)]	AM27S291SA@SOIC24 [(SA404)]
AM27S29A	AM27S29A@PLCC20 [(SA001A)]
AM27S29A@SOIC20 [(SA404)]	AM27S29SA
AM27S29SA@PLCC20 [(SA001A)]	AM27S29SA@SOIC20 [(SA404)]
AM27S31	AM27S31@PLCC28 [(SA008A)]
AM27S31@PLCC32 [(SA015A1T)]	AM27S31@SOIC24 [(SA404)]
AM27S31A	AM27S31A@PLCC28 [(SA008A)]
AM27S31A@PLCC32 [(SA015A1T)]	AM27S31A@SOIC24 [(SA404)]
AM27S33	AM27S33@PLCC20 [(SA001A)]
AM27S33@SOIC18 [(SA404)]	AM27S33A
AM27S33A@PLCC20 [(SA001A)]	AM27S33A@SOIC18 [(SA404)]
AM27S35	AM27S35@PLCC28 [(SA008A)]
AM27S35@PLCC32 [(SA015A1T)]	AM27S35@SOIC24 [(SA404)]
AM27S35A	AM27S35A@PLCC28 [(SA008A)]
AM27S35A@PLCC32 [(SA015A1T)]	AM27S35A@SOIC24 [(SA404)]
AM27S37	AM27S37@PLCC28 [(SA008A)]
AM27S37@PLCC32 [(SA015A1T)]	AM27S37@SOIC24 [(SA404)]
AM27S37A	AM27S37A@PLCC28 [(SA008A)]
AM27S37A@PLCC32 [(SA015A1T)]	AM27S37A@SOIC24 [(SA404)]
AM27S41	AM27S41@PLCC28 [(SA008A)]
AM27S41@SOIC20 [(SA404)]	AM27S41A
AM27S41A@PLCC28 [(SA008A)]	AM27S41A@SOIC20 [(SA404)]
AM27S43	AM27S43@PLCC28 [(SA008A)]
AM27S43@PLCC32 [(SA015A1T)]	AM27S43@SOIC24 [(SA404)]
AM27S43A	AM27S43A@PLCC28 [(SA008A)]
AM27S43A@PLCC32 [(SA015A1T)]	AM27S43A@SOIC24 [(SA404)]
AM27S45	AM27S45@PLCC28 [(SA008A)]
AM27S45@PLCC32 [(SA015A1T)]	AM27S45@SOIC24 [(SA404)]
AM27S45A	AM27S45A@PLCC28 [(SA008A)]
AM27S45A@PLCC32 [(SA015A1T)]	AM27S45A@SOIC24 [(SA404)]
AM27S45SA	AM27S45SA@PLCC28 [(SA008A)]
AM27S45SA@PLCC32 [(SA015A1T)]	AM27S45SA@SOIC24 [(SA404)]
AM27S47	AM27S47@PLCC28 [(SA008A)]
AM27S47@PLCC32 [(SA015A1T)]	AM27S47@SOIC24 [(SA404)]
AM27S47A	AM27S47A@PLCC28 [(SA008A)]
AM27S47A@PLCC32 [(SA015A1T)]	AM27S47A@SOIC24 [(SA404)]
AM27S47SA	AM27S47SA@PLCC28 [(SA008A)]
AM27S47SA@PLCC32 [(SA015A1T)]	AM27S47SA@SOIC24 [(SA404)]
AM27S49	AM27S49@PLCC28 [(SA008A)]
AM27S49@PLCC32 [(SA015A1T)]	AM27S49@SOIC24 [(SA404)]
AM27S49A	AM27S49A@PLCC28 [(SA008A)]
AM27S49A@PLCC32 [(SA015A1T)]	AM27S49A@SOIC24 [(SA404)]
AM27S49SA	AM27S49SA@PLCC28 [(SA008A)]
AM27S49SA@PLCC32 [(SA015A1T)]	AM27S49SA@SOIC24 [(SA404)]

## PLD

AMPAL22V10	AMPAL22V10@PLCC28 [(SA008A)]
AMPAL22V10@SOIC24 [(SA404)]	AMPAL22V10A
AMPAL22V10A@PLCC28 [(SA008A)]	AMPAL22V10A@SOIC24 [(SA404)]

AMPAL23S8	AMPAL23S8@SOIC20 [(SA404)]
M4-128/64@PQFP100 [(PEP+S427)]	M4-128/64@TQFP100 [(PEP+S604)]
M4-128N/64@PLCC84 [(PEP+S416T)]	M4A3-128/64@PQFP100 [(PEP+S427)]
M4A3-128/64@TQFP100 [(PEP+S604)]	
M4A3-128N/64@PLCC84 [(PEP+S416T)]	
M4A3-32/32@PLCC44 [(SA244)]	M4A3-32/32@TQFP44 [(SA245A)]
M4A3-32/32@TQFP48 [(SA248)]	M4A3-64/32@PLCC44 [(SA244)]
M4A3-64/32@TQFP44 [(SA245A)]	M4A3-64/32@TQFP48 [(SA248)]
M4A3-64/64@TQFP100 [(PEP+S604)]	M4A3-96/48@TQFP100 [(PEP+S604)]
M4A5-128/64@PQFP100 [(PEP+S427)]	M4A5-128/64@TQFP100 [(PEP+S604)]
M4A5-128N/64@PLCC84 [(PEP+S416T)]	
M4A5-32/32@PLCC44 [(SA244)]	M4A5-32/32@TQFP44 [(SA245A)]
M4A5-32/32@TQFP48 [(SA248)]	M4A5-64/32@PLCC44 [(SA244)]
M4A5-64/32@TQFP44 [(SA245A)]	M4A5-64/32@TQFP48 [(SA248)]
M4A5-96/48@TQFP100 [(PEP+S604)]	M4LV-128/64@PQFP100 [(PEP+S427)]
M4LV-128/64@TQFP100 [(PEP+S604)]	
M4LV-128N/64@PLCC84 [(PEP+S416T)]	
MACH110@PLCC44 [(SA244)]	MACH111@PLCC44 [(SA244)]
MACH111@TQFP44 [(SA245A)]	MACH120@PLCC68 [(PEP+S414T)]
MACH130@PLCC84 [(PEP+S416T)]	MACH131/1@PLCC84 [(PEP+S416T)]
MACH131@PLCC84 [(PEP+S416T)]	MACH131SP@PQFP100 [(PEP+S427)]
MACH131SP@TQFP100 [(PEP+S604)]	MACH210@PLCC44 [(SA244)]
MACH210@TQFP44 [(SA245A)]	MACH210A@PLCC44 [(SA244)]
MACH210A@TQFP44 [(SA245A)]	MACH210AQ@PLCC44 [(SA244)]
MACH210AQ@TQFP44 [(SA245A)]	MACH211@PLCC44 [(SA244)]
MACH211@TQFP44 [(SA245A)]	MACH211SP@PLCC44 [(SA244)]
MACH211SP@TQFP44 [(SA245A)]	
MACH215@PLCC44 [ordering number is marked above]	
MACH220@PLCC68 [(PEP+S414T)]	MACH221@PLCC68 [(PEP+S414T)]
MACH230@PLCC84 [(PEP+S416T)]	MACH231@PLCC84 [(PEP+S416T)]
MACH231SP@PLCC84 [(PEP+S416T)]	MACH231SP@PQFP100 [(PEP+S427)]
MACH231SP@TQFP100 [(PEP+S604)]	MACH435@PLCC84 [(PEP+S416T)]
MACH436@PLCC84 [(PEP+S416T)]	MACH446@PQFP100 [(PEP+S427)]
MACH446@TQFP100 [(PEP+S604)]	MACHLV210@PLCC44 [(SA244)]
MACHLV436@PLCC84 [(PEP+S416T)]	MACHLV446@PQFP100 [(PEP+S427)]
MACHLV446@TQFP100 [(PEP+S604)]	PAL16L8-4
PAL16L8-4@PLCC20 [(SA001A)]	PAL16L8-4@SOIC20 [(SA404)]
PAL16L8-5	PAL16L8-5@PLCC20 [(SA001A)]
PAL16L8-5@SOIC20 [(SA404)]	PAL16L8-7
PAL16L8-7@PLCC20 [(SA001A)]	PAL16L8-7@SOIC20 [(SA404)]
PAL16L8A	PAL16L8A@PLCC20 [(SA001A)]
PAL16L8-H10	PAL16L8-H10@PLCC20 [(SA001A)]
PAL16L8-H10@SOIC20 [(SA404)]	PAL16R4-4
PAL16R4-4@PLCC20 [(SA001A)]	PAL16R4-4@SOIC20 [(SA404)]
PAL16R4-5	PAL16R4-5@PLCC20 [(SA001A)]
PAL16R4-5@SOIC20 [(SA404)]	PAL16R4-7
PAL16R4-7@PLCC20 [(SA001A)]	PAL16R4-7@SOIC20 [(SA404)]
PAL16R4-H10	PAL16R4-H10@PLCC20 [(SA001A)]
PAL16R4-H10@SOIC20 [(SA404)]	PAL16R6-4
PAL16R6-4@PLCC20 [(SA001A)]	PAL16R6-4@SOIC20 [(SA404)]
PAL16R6-5	PAL16R6-5@PLCC20 [(SA001A)]
PAL16R6-5@SOIC20 [(SA404)]	PAL16R6-7
PAL16R6-7@PLCC20 [(SA001A)]	PAL16R6-7@SOIC20 [(SA404)]
PAL16R6-H10	PAL16R6-H10@PLCC20 [(SA001A)]
PAL16R6-H10@SOIC20 [(SA404)]	PAL16R8-4
PAL16R8-4@PLCC20 [(SA001A)]	PAL16R8-4@SOIC20 [(SA404)]
PAL16R8-5	PAL16R8-5@PLCC20 [(SA001A)]
PAL16R8-5@SOIC20 [(SA404)]	PAL16R8-7
PAL16R8-7@PLCC20 [(SA001A)]	PAL16R8-7@SOIC20 [(SA404)]
PAL16R8-H10	PAL16R8-H10@PLCC20 [(SA001A)]
PAL16R8-H10@SOIC20 [(SA404)]	PAL20L8-10/2
PAL20L8-10/2@PLCC28 [(SA008A)]	PAL20L8-10/2@SOIC24 [(SA404)]
PAL20L8-5	PAL20L8-5@PLCC28 [(SA008A)]
PAL20L8-5@SOIC24 [(SA404)]	PAL20L8-7
PAL20L8-7@PLCC28 [(SA008A)]	PAL20L8-7@SOIC24 [(SA404)]
PAL20R4-10/2	PAL20R4-10/2@PLCC28 [(SA008A)]
PAL20R4-10/2@SOIC24 [(SA404)]	PAL20R4-5
PAL20R4-5@PLCC28 [(SA008A)]	PAL20R4-5@SOIC24 [(SA404)]
PAL20R4-7	PAL20R4-7@PLCC28 [(SA008A)]
PAL20R4-7@SOIC24 [(SA404)]	PAL20R6-10/2
PAL20R6-10/2@PLCC28 [(SA008A)]	PAL20R6-10/2@SOIC24 [(SA404)]
PAL20R6-5	PAL20R6-5@PLCC28 [(SA008A)]
PAL20R6-5@SOIC24 [(SA404)]	PAL20R6-7
PAL20R6-7@PLCC28 [(SA008A)]	PAL20R6-7@SOIC24 [(SA404)]
PAL20R8-10/2	PAL20R8-10/2@PLCC28 [(SA008A)]
PAL20R8-10/2@SOIC24 [(SA404)]	PAL20R8-5
PAL20R8-5@PLCC28 [(SA008A)]	PAL20R8-5@SOIC24 [(SA404)]
PAL20R8-7	PAL20R8-7@PLCC28 [(SA008A)]
PAL20R8-7@SOIC24 [(SA404)]	PAL20RA10
PAL22V10	PAL22V10@PLCC28 [(SA008A)]
PAL22V10@SOIC24 [(SA404)]	PAL22V10A

PAL22V10A@PLCC28 [(SA008A)]	PAL22V10A@SOIC24 [(SA404)]
PAL29M16H	PALC16L8Q
PALC16L8Q@PLCC20 [(SA001A)]	PALC16L8Z
PALC16L8Z@PLCC20 [(SA001A)]	PALC16R4Q
PALC16R4Q@PLCC20 [(SA001A)]	PALC16R4Z
PALC16R4Z@PLCC20 [(SA001A)]	PALC16R6Q
PALC16R6Q@PLCC20 [(SA001A)]	PALC16R6Z
PALC16R6Z@PLCC20 [(SA001A)]	PALC16R8Q
PALC16R8Q@PLCC20 [(SA001A)]	PALC16R8Z
PALC16R8Z@PLCC20 [(SA001A)]	PALCE16V8H
PALCE16V8H@PLCC20 [(SA001A)]	PALCE16V8H@SOIC20 [(SA404)]
PALCE16V8Q	PALCE16V8Q@PLCC20 [(SA001A)]
PALCE16V8Q@SOIC20 [(SA404)]	PALCE16V8Z
PALCE16V8Z@PLCC20 [(SA001A)]	PALCE16V8Z@SOIC20 [(SA404)]
PALCE20RA10	PALCE20RA10@PLCC28 [(SA008A)]
PALCE20RA10@SOIC24 [(SA404)]	PALCE20RA10H
PALCE20RA10H@PLCC28 [(SA008A)]	PALCE20RA10H@SOIC24 [(SA404)]
PALCE20RA10Q	PALCE20RA10Q@PLCC28 [(SA008A)]
PALCE20RA10Q@SOIC24 [(SA404)]	PALCE20V8H
PALCE20V8H@PLCC28 [(SA008A)]	PALCE20V8H@SOIC24 [(SA404)]
PALCE20V8Q	PALCE20V8Q@PLCC28 [(SA008A)]
PALCE20V8Q@SOIC24 [(SA404)]	PALCE22V10H
PALCE22V10H@PLCC28 [(SA008A)]	PALCE22V10H@SOIC24 [(SA404)]
PALCE22V10Q	PALCE22V10Q@PLCC28 [(SA008A)]
PALCE22V10Q@SOIC24 [(SA404)]	PALCE22V10Z
PALCE22V10Z@PLCC28 [(SA008A)]	PALCE22V10Z@SOIC24 [(SA404)]
PALCE26V12H/4	PALCE26V12H/4@PLCC28 [(SA008A)]
PALCE26V12H/4@SOIC28 [(SA404)]	PALCE26V12H-15
PALCE26V12H-15@PLCC28 [(SA008A)]	PALCE26V12H-15@SOIC28 [(SA404)]
PALCE26V12H-20	PALCE26V12H-20@PLCC28 [(SA008A)]
PALCE26V12H-20@SOIC28 [(SA404)]	PALCE26V12H-25
PALCE26V12H-25@PLCC28 [(SA008A)]	PALCE26V12H-25@SOIC28 [(SA404)]
PALCE29M16H	PALCE29M16H@PLCC28 [(SA008A)]
PALCE29M16H@SOIC24 [(SA404)]	PALCE29MA16H
PALCE29MA16H@PLCC28 [(SA008A)]	PALCE29MA16H@SOIC24 [(SA404)]
PALCE610	PALCE610@PLCC28 [(SA008A)]
PALCE610@SOIC24 [(SA404)]	PALCE610H
PALCE610H@PLCC28 [(SA008A)]	PALCE610H@SOIC24 [(SA404)]
PALCE630H	PALCE630H@SOIC24 [(SA404)]
PALCE630H-P28 [(SA008A)]	PALLV16V8
PALLV16V8@PLCC20 [(SA001A)]	PALLV16V8@SOIC20 [(SA404)]
PALLV16V8Z	PALLV16V8Z@PLCC20 [(SA001A)]
PALLV16V8Z@SOIC20 [(SA404)]	

**MICROCONTROLLER**

AM8751H	AM8753H
AM87C51	AM87C51@PLCC44 [(SA244)]
AM87C51@TQFP44 [(SA245A)]	AM87C521
AM87C521@PLCC44 [(SA244)]	AM87C521@TQFP44 [(SA245A)]
AM87C541	AM87C541@PLCC44 [(SA244)]
AM87C541@TQFP44 [(SA245A)]	

**AMI SEMICONDUCTOR****E (E) PROM/FRAM/NVRAM**

N256S0818HDA	N256S0818HDA@SOIC8 [(SA602A)]
N256S0818HDA@TSSOP8 [(SA026)]	N256S0830HDA
N256S0830HDA@SOIC8 [(SA602A)]	N256S0830HDA@TSSOP8 [(SA026)]
N64S0818HDA	N64S0818HDA@SOIC8 [(SA602A)]
N64S0818HDA@TSSOP8 [(SA026)]	N64S0830HDA
N64S0830HDA@SOIC8 [(SA602A)]	N64S0830HDA@TSSOP8 [(SA026)]

**AMIC****E (E) PROM/FRAM/NVRAM**

A25L010	A25L010[150mil]@SOP8 [(SA602A)]
A25L010[209mil]@SOP8 [(SA605A)]	A25L016
A25L016@SOP8 [(SA023A)]	A25L020
A25L020[150mil]@SOP8 [(SA602A)]	A25L020[209mil]@SOP8 [(SA605A)]
A25L032	A25L032@SOP8 [(SA023A)]

A25L040	A25L040@QFN8 [(SA683)]
A25L040@SOP16 [(SA404)]	A25L040@SOP8 [(SA602A)]
A25L05P (Bottom)	A25L05P(Bottom)@QFN8 [(SA683)]
A25L05P (Bottom)[150mil]@SOP8 [(SA602A)]	
A25L05P (Bottom)[209mil]@SOP8 [(SA605A)]	
A25L05P (Top)	A25L05P(Top)@QFN8 [(SA683)]
A25L05P (Top)[150mil]@SOP8 [(SA602A)]	
A25L05P (Top)[209mil]@SOP8 [(SA605A)]	
A25L080	A25L080@QFN8 [(SA683)]
A25L080@SOP16 [(SA404)]	A25L080@SOP8 [(SA023A)]
A25L10P (Bottom)	A25L10P(Bottom)@QFN8 [(SA683)]
A25L10P (Bottom)[150mil]@SOP8 [(SA602A)]	
A25L10P (Bottom)[209mil]@SOP8 [(SA605A)]	
A25L10P (Top)	A25L10P(Top)@QFN8 [(SA683)]
A25L10P (Top)[150mil]@SOP8 [(SA602A)]	
A25L10P (Top)[209mil]@SOP8 [(SA605A)]	
A25L16P (Bottom)@QFN8 [(SA683)]	
A25L16P (Bottom)@QFN8 (ISP) [ISP-HEADER01]	
A25L16P (Bottom)@SOP16 [(SA404)]	
A25L16P (Bottom)@SOP16 (ISP) [ISP-HEADER01]	
A25L16P (Bottom)@SOP8 [(SA023A)]	
A25L16P (Bottom)@SOP8 (ISP) [ISP-HEADER01]	
A25L16P (Top)@QFN8 [(SA683)]	
A25L16P (Top)@QFN8 (ISP) [ISP-HEADER01]	
A25L16P (Top)@SOP16 [(SA404)]	
A25L16P (Top)@SOP16 (ISP) [ISP-HEADER01]	
A25L16P (Top)@SOP8 [(SA023A)]	
A25L16P (Top)@SOP8 (ISP) [ISP-HEADER01]	
A25L20P (Bottom)	A25L20P(Bottom)@QFN8 [(SA683)]
A25L20P (Bottom)[150mil]@SOP8 [(SA602A)]	
A25L20P (Bottom)[209mil]@SOP8 [(SA605A)]	
A25L20P (Top)	A25L20P(Top)@QFN8 [(SA683)]
A25L20P (Top)[150mil]@SOP8 [(SA602A)]	
A25L20P (Top)[209mil]@SOP8 [(SA605A)]	
A25L40P (Bottom Boot)	
A25L40P (Bottom Boot)@QFN8 [(SA683)]	
A25L40P (Bottom Boot)@SOP16 [(SA404)]	
A25L40P (Bottom Boot)@SOP8 [(SA602A)]	
A25L40P (Top Boot)	A25L40P(Top Boot)@QFN8 [(SA683)]
A25L40P (Top Boot)@SOP16 [(SA404)]	
A25L40P (Top Boot)@SOP8 [(SA602A)]	
A25L42P (Bottom Boot)	
A25L42P (Bottom Boot)@QFN8 [(SA683)]	
A25L42P (Bottom Boot)@SOP16 [(SA404)]	
A25L42P (Bottom Boot)@SOP8 [(SA602A)]	
A25L42P (Top Boot)	A25L42P(Top Boot)@QFN8 [(SA683)]
A25L42P (Top Boot)@SOP16 [(SA404)]	
A25L42P (Top Boot)@SOP8 [(SA602A)]	
A25L512	A25L512[150mil]@SOP8 [(SA602A)]
A25L512[209mil]@SOP8 [(SA605A)]	A25L80P
A25L80P@QFN8 [(SA683)]	A25L80P@SOP16 [(SA404)]
A25L80P@SOP8 [(SA023A)]	A25L82P(Bottom Boot)
A25L82P (Bottom Boot)@QFN8 [(SA683)]	
A25L82P (Bottom Boot)@SOP16 [(SA404)]	
A25L82P (Bottom Boot)@SOP8 [(SA023A)]	
A25L82P (Top Boot)	A25L82P(Top Boot)@QFN8 [(SA683)]
A25L82P (Top Boot)@SOP16 [(SA404)]	
A25L82P (Top Boot)@SOP8 [(SA023A)]	
A25LS080	A25LS080@QFN8 [(SA683)]
A25LS080@SOP16 [(SA404)]	A25LS080@SOP8 [(SA023A)]
A27020	A27020@PLCC32 [(SA015A1T)]
A27020@TSOP32 [(SA410T)]	A27020L
A27020L@PLCC32 [(SA015A1T)]	A27020L@TSOP32 [(SA410T)]
A275308	A275308@PLCC32 [(SA015A1T)]
A276308	A276308 (E)
A276308 (E)@PLCC32 [(SA015A1T)]	A276308 (E)@SOIC28 [(SA404)]
A276308@PLCC32 [(SA015A1T)]	A276308@SOIC28 [(SA404)]
A276308A	A276308A (L)
A276308A (L)@PLCC32 [(SA015A1T)]	A276308A (L)@SOIC28 [(SA404)]
A276308A@PLCC32 [(SA015A1T)]	A276308A@SOIC28 [(SA404)]
A277308	A277308@PLCC32 [(SA015A1T)]
A277308A	A277308A@PLCC32 [(SA015A1T)]
A278308	A278308@PLCC32 [(SA015A1T)]
A278308A	A278308A (L)
A278308A (L)@PLCC32 [(SA015A1T)]	A278308A@PLCC32 [(SA015A1T)]
A279308	A279308@PLCC32 [(SA015A1T)]
A290011T	A290011T@PLCC32 [(SA015A1T)]
A290011T@TSOP32 [(SA410T)]	A290011U
A290011U@PLCC32 [(SA015A1T)]	A290011U@TSOP32 [(SA410T)]
A29001T	A29001T@PLCC32 [(SA015A1T)]
A29001T@TSOP32 [(SA410T)]	A29001U

A29001U@PLCC32 [(SA015A1T)]	A29001U@TSOP32 [(SA410T)]
A290021T	A290021T@PLCC32 [(SA015A1T)]
A290021T@TSOP32 [(SA410T)]	A290021U
A290021U@PLCC32 [(SA015A1T)]	A290021U@TSOP32 [(SA410T)]
A29002T	A29002T@PLCC32 [(SA015A1T)]
A29002T@TSOP32 [(SA410T)]	A29002U
A29002U@PLCC32 [(SA015A1T)]	A29002U@TSOP32 [(SA410T)]
A29010	A29010@PLCC32 [(SA015A1T)]
A29010@TSOP32 [(SA410T)]	A29040
A29040@PLCC32 [(SA015A1T)]	A29040@TSOP32 [(SA410T)]
A29040A	A29040A@PLCC32 [(SA015A1T)]
A29040A@TSOP32 [(SA410T)]	A29040B
A29040B@PLCC32 [(SA015A1T)]	A29040B@TSOP32 [(SA410T)]
A29160TG@FBGA48 [(SA642G-B026A-T048F001Y)]	A29160TV@TSOP48 [(SA247-B005)]
A29160TM@PSOP44 [(SA638)]	A29160UG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29160UG@FBGA48 [(SA642G-B026A-T048F001Y)]	A29160UV@TSOP48 [(SA247-B005)]
A29160UM@PSOP44 [(SA638)]	A29400TV@TSOP48 [(SA247-B005)]
A29400TM@PSOP44 [(SA638)]	A29400UV@TSOP48 [(SA247-B005)]
A29400UM@PSOP44 [(SA638)]	A29512@PLCC32 [(SA015A1T)]
A29512	A29512A
A29512@TSOP32 [(SA410T)]	A29512A@TSOP32 [(SA410T)]
A29512A@PLCC32 [(SA015A1T)]	A29800TV@TSOP48 [(SA247-B005)]
A29800TM@PSOP44 [(SA638)]	A29800UV@TSOP48 [(SA247-B005)]
A29800UM@PSOP44 [(SA638)]	
A29DL162TG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL162TV@TSOP48 [(SA247-B005)]	
A29DL162UG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL162UV@TSOP48 [(SA247-B005)]	
A29DL163TG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL163TV@TSOP48 [(SA247-B005)]	
A29DL163UG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL163UV@TSOP48 [(SA247-B005)]	
A29DL164TG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL164TV@TSOP48 [(SA247-B005)]	
A29DL164UG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL164UV@TSOP48 [(SA247-B005)]	
A29DL320FTV@TSOP48 [(SA247-B005)]	
A29DL320FUV@TSOP48 [(SA247-B005)]	
A29DL322TG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL322TV@TSOP48 [(SA247-B005)]	
A29DL322UG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL322UV@TSOP48 [(SA247-B005)]	
A29DL323TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL323TG@FBGA63 [(SA642A-B026A-Y096F001)]	
A29DL323TV(New)@TSOP48 [(SA247-B005)]	
A29DL323TV@TSOP48 [(SA247-B005)]	
A29DL323UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL323UG@FBGA63 [(SA642A-B026A-Y096F001)]	
A29DL323UV(New)@TSOP48 [(SA247-B005)]	
A29DL323UV@TSOP48 [(SA247-B005)]	
A29DL324TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL324TG@FBGA63 [(SA642A-B026A-Y096F001)]	
A29DL324TV(New)@TSOP48 [(SA247-B005)]	
A29DL324TV@TSOP48 [(SA247-B005)]	
A29DL324UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL324UG@FBGA63 [(SA642A-B026A-Y096F001)]	
A29DL324UV(New)@TSOP48 [(SA247-B005)]	
A29DL324UV@TSOP48 [(SA247-B005)]	A29L004ATL@PLCC32 [(SA015A1T)]
A29L004ATV@TSOP32 [(SA410T)]	A29L004ATW@TSOP40 [(SA409T)]
A29L004ATY@VSOP32 [(SA620)]	A29L004AUL@PLCC32 [(SA015A1T)]
A29L004AUV@TSOP32 [(SA410T)]	A29L004AUW@TSOP40 [(SA409T)]
A29L004AUY@VSOP32 [(SA620)]	A29L004T@PLCC32 [(SA015A1T)]
A29L004T@TSOP32 [(SA410T)]	A29L004T@TSOP40 [(SA409T)]
A29L004T@VSOP32 [(SA620)]	A29L004U@PLCC32 [(SA015A1T)]
A29L004U@TSOP32 [(SA410T)]	A29L004U@TSOP40 [(SA409T)]
A29L004U@VSOP32 [(SA620)]	A29L008ATV@TSOP40 [(SA409T)]
A29L008AUV@TSOP40 [(SA409T)]	A29L008T@TSOP40 [(SA409T)]
A29L008U@TSOP40 [(SA409T)]	A29L040
A29L040@PLCC32 [(SA015A1T)]	A29L040@TSOP32 [(SA410T)]
A29L040@VSOP32 [(SA620)]	
A29L160ATG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L160ATM@PSOP44 [(SA638)]	A29L160ATV@TSOP48 [(SA247-B005)]
A29L160AUG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L160AUM@PSOP44 [(SA638)]	A29L160AUV@TSOP48 [(SA247-B005)]
A29L160BTG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L160BTGB@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L160BTM@PSOP44 [(SA638)]	A29L160BTV@TSOP48 [(SA247-B005)]
A29L160BUG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L160BUGB@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L160BUM@PSOP44 [(SA638)]	A29L160BUV@TSOP48 [(SA247-B005)]
A29L160HTG@FBGA48 [(SA642B-B026A-Y072F001)]	

A29L160HTV@TSOP48 [(SA247-B005)]  
A29L160HUG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160HUV@TSOP48 [(SA247-B005)]  
A29L160TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160TM@PSOP44 [(SA638)] A29L160TV@TSOP48 [(SA247-B005)]  
A29L160UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160UM@PSOP44 [(SA638)] A29L160UV@TSOP48 [(SA247-B005)]  
A29L320ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L320ATV@TSOP48 [(SA247-B005)]  
A29L320AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L320AUV@TSOP48 [(SA247-B005)]  
A29L400ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L400ATM@PSOP44 [(SA638)] A29L400ATV@TSOP48 [(SA247-B005)]  
A29L400AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L400AUM@PSOP44 [(SA638)] A29L400AUV@TSOP48 [(SA247-B005)]  
A29L400TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L400TM@PSOP44 [(SA638)] A29L400TV@TSOP48 [(SA247-B005)]  
A29L400UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L400UM@PSOP44 [(SA638)] A29L400UV@TSOP48 [(SA247-B005)]  
A29L800ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L800ATM@PSOP44 [(SA638)] A29L800ATV@TSOP48 [(SA247-B005)]  
A29L800AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L800AUM@PSOP44 [(SA638)] A29L800AUV@TSOP48 [(SA247-B005)]  
A29L800HTG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800HTM@PSOP44 [(SA638)] A29L800HTV@TSOP48 [(SA247-B005)]  
A29L800HUG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800HUM@PSOP44 [(SA638)] A29L800HUV@TSOP48 [(SA247-B005)]  
A29L800TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800TM@PSOP44 [(SA638)] A29L800TV@TSOP48 [(SA247-B005)]  
A29L800UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L800UM@PSOP44 [(SA638)] A29L800UV@TSOP48 [(SA247-B005)]  
A49LF004@PLCC32 [(SA015A1T)] A49LF004@VSOP32 [(SA620)]  
A49LF004M@PLCC32 [(SA015A1T)] A49LF004M@VSOP32 [(SA620)]  
A49LF040ATL@PLCC32 [(SA015A1T)] A49LF040ATX@VSOP32 [(SA620)]  
A49LF040ATY@VSOP32 [(SA620)] A49LF040TL@PLCC32 [(SA015A1T)]  
A49LF040TX@VSOP32 [(SA620)] A50FW040@PLCC32 [(SA015A1T)]  
A50FW040@VSOP32 [(SA620)] A50FW040M@PLCC32 [(SA015A1T)]  
A50FW040M@VSOP32 [(SA620)] A50LPW040@PLCC32 [(SA015A1T)]  
A50LPW040@TSOP32 [(SA410T)] A617308  
A617308@TSOP32 [(SA410T)] A61L5308  
A61L5308@TSOP28 [(SA430T)] A623308(M)  
A623308(R)@TSOP28 [(SA430T)] A623308(V)@TSOP28 [(SA430T)]  
A625308(M) A625308(R)@TSOP28 [(SA430T)]  
A625308(V)@TSOP28 [(SA430T)] A62L256  
A62L256(M) A62L256(R)@TSOP28 [(SA430T)]  
A62L256(V)@TSOP28 [(SA430T)] A62S6308(M)  
A62S6308(X)@TSOP32 [(SA410T)] A62S7308A(M)  
A62S7308A(X)@TSOP32 [(SA410T)] A62S8308A(M)  
A62S8308A(X)@TSOP32 [(SA410T)] A62W5308(M)  
A62W5308(R)@TSOP28 [(SA430T)] A62W5308(V)@TSOP28 [(SA430T)]  
A81L801TG@FBGA69 [(SA642A-B078A-Y096F001Y)]  
A81L801UG@FBGA69 [(SA642A-B078A-Y096F001Y)]  
A82DL1622TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1622UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1624TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1624UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1632TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1632UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1634TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1634UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1642TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1642UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1644TG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL1644UG@FBGA69 [(SA642A-B032A-Y096F001Y)]  
A82DL32216TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32216UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3224TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3224UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3228TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3228UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32316TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32316UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3234TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3234UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3238TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3238UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32416TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL32416UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3244TG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3244UG@FBGA69 [(SA642A-B254A-Y096F001Y)]  
A82DL3248TG@FBGA69 [(SA642A-B254A-Y096F001Y)]

A82DL3248UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]

**ANACHIP****E (E) PROM/FRAM/NVRAM**

27CX010	27CX010@PLCC32 [ (SA015A1T) ]
27CX010@TSOP32 [ (SA410T) ]	27CX161
27CX162	27CX256
27CX321	27CX322
27CX641	27CX642
93C46	93C46@SOIC8 [ (SA602A) ]
93C46A	93C46A@SOIC8 [ (SA602A) ]
93C56A	93C56A@SOIC8 [ (SA602A) ]
93C66A	93C66A@SOIC8 [ (SA602A) ]
93CX46	93CX46@SOIC8 [ (SA602A) ]
93CX56	93CX56@SOIC8 [ (SA602A) ]
93CX66	93CX66@SOIC8 [ (SA602A) ]
AM24LC02	AM24LC02@SOIC8 [ (SA602A) ]
AM24LC02@TSSOP8 [ (SA026) ]	AM24LC04
AM24LC04@SOIC8 [ (SA602A) ]	AM24LC04@TSSOP8 [ (SA026) ]
AM24LC08	AM24LC08@SOIC8 [ (SA602A) ]
AM24LC08@TSSOP8 [ (SA026) ]	AM24LC16
AM24LC16@SOIC8 [ (SA602A) ]	AM24LC16@TSSOP8 [ (SA026) ]
AM24LC21	AM24LC21@SOIC8 [ (SA602A) ]
AM24LC21@TSSOP8 [ (SA026) ]	AM24LC21B
AM24LC21B@SOIC8 [ (SA602A) ]	AM24LC21B@TSSOP8 [ (SA026) ]
AM93LC46 (08bit)	AM93LC46 (08bit)@SOIC8 [ (SA602A) ]
AM93LC46 (08bit)@TSOP8 [ (SA026) ]	AM93LC46 (16bit)
AM93LC46 (16bit)@SOIC8 [ (SA602A) ]	AM93LC46 (16bit)@TSOP8 [ (SA026) ]
AM93LC56 (08bit)	AM93LC56 (08bit)@SOIC8 [ (SA602A) ]
AM93LC56 (08bit)@TSOP8 [ (SA026) ]	AM93LC56 (16bit)
AM93LC56 (16bit)@SOIC8 [ (SA602A) ]	AM93LC56 (16bit)@TSOP8 [ (SA026) ]
AM93LC66 (08bit)	AM93LC66 (08bit)@SOIC8 [ (SA602A) ]
AM93LC66 (08bit)@TSOP8 [ (SA026) ]	AM93LC66 (16bit)
AM93LC66 (16bit)@SOIC8 [ (SA602A) ]	AM93LC66 (16bit)@TSOP8 [ (SA026) ]
AM93LC86 (08bit)	AM93LC86 (08bit)@SOIC8 [ (SA602A) ]
AM93LC86 (08bit)@TSOP8 [ (SA026) ]	AM93LC86 (16bit)
AM93LC86 (16bit)@SOIC8 [ (SA602A) ]	AM93LC86 (16bit)@TSOP8 [ (SA026) ]

**PLD**

PA7024	PA7024 (J)@PLCC28 [ (SA008A) ]
PA7024 (JN)@PLCC28 [ (SA008A) ]	PA7024@SOIC24 [ (SA404) ]
PA7128	PA7128@PLCC28 [ (SA008A) ]
PA7128@SOIC28 [ (SA404) ]	PA7140
PA7140@PLCC44 [ (SA244) ]	PA7140@TQFP44 [ (SA245A) ]
PA7536	PA7536@PLCC28 [ (SA008A) ]
PA7536@SOIC28 [ (SA404) ]	PA7540
PA7540 (J)@PLCC28 [ (SA008A) ]	PA7540 (JN)@PLCC28 [ (SA008A) ]
PA7572	PA7572@PLCC44 [ (SA244) ]
PA7572@TQFP44 [ (SA245A) ]	PEEL16CV8
PEEL16CV8@PLCC20 [ (SA001A) ]	PEEL16CV8@SOIC20 [ (SA404) ]
PEEL16CV8@TSOP20 [ (SA026) ]	PEEL18CV8
PEEL18CV8@PLCC20 [ (SA001A) ]	PEEL18CV8@SOIC20 [ (SA404) ]
PEEL18CV8@TSOP20 [ (SA026) ]	PEEL18CV8Z
PEEL18CV8Z@PLCC20 [ (SA001A) ]	PEEL18CV8Z@SOIC20 [ (SA404) ]
PEEL18CV8Z@TSOP20 [ (SA026) ]	PEEL18LV8Z
PEEL18LV8Z@PLCC20 [ (SA001A) ]	PEEL18LV8Z@SOIC20 [ (SA404) ]
PEEL18LV8Z@TSOP20 [ (SA026) ]	PEEL22CV10A
PEEL22CV10A@PLCC28 [ (SA008A) ]	PEEL22CV10A@SOIC24 [ (SA404) ]
PEEL22CV10A@TSOP24 [ (SA026) ]	PEEL22CV10A+
PEEL22CV10A+@PLCC28 [ (SA008A) ]	PEEL22CV10A+@SOIC24 [ (SA404) ]
PEEL22CV10A+@TSOP24 [ (SA026) ]	PEEL22CV10A++
PEEL22CV10A++@PLCC28 [ (SA008A) ]	PEEL22CV10A++@SOIC24 [ (SA404) ]
PEEL22CV10A++@TSOP24 [ (SA026) ]	PEEL22CV10AZ
PEEL22CV10AZ@PLCC28 [ (SA008A) ]	PEEL22CV10AZ@SOIC24 [ (SA404) ]
PEEL22CV10AZ@TSOP24 [ (SA026) ]	PEEL22CV10AZ+
PEEL22CV10AZ+@PLCC28 [ (SA008A) ]	PEEL22CV10AZ+@SOIC24 [ (SA404) ]
PEEL22CV10AZ+@TSOP24 [ (SA026) ]	PEEL22CV10AZ++
PEEL22CV10AZ++@PLCC28 [ (SA008A) ]	PEEL22CV10AZ++@SOIC24 [ (SA404) ]
PEEL22CV10AZ++@TSOP24 [ (SA026) ]	PEEL22CV8
PEEL22CV8@PLCC24 [ (SA008A) ]	PEEL22CV8@SOIC24 [ (SA404) ]
PEEL22LV10AZ	PEEL22LV10AZ@PLCC28 [ (SA008A) ]
PEEL22LV10AZ@SOIC24 [ (SA404) ]	PEEL22LV10AZ@TSOP24 [ (SA026) ]
PEEL22LV10AZ+	PEEL22LV10AZ+@PLCC28 [ (SA008A) ]



PEEL22LV10AZ+@SOIC24 [(SA404)]  
 PEEL22LV10AZ++  
 PEEL22LV10AZ++@SOIC24 [(SA404)]

PEEL22LV10AZ+@TSOP24 [(SA026)]  
 PEEL22LV10AZ++@PLCC28 [(SA008A)]  
 PEEL22LV10AZ++@TSOP24 [(SA026)]

## ANALOG

### MICROCONTROLLER

ADUC812BS@LFCSP56 [(PEP+S706)]  
 ADUC816BS@LFCSP56 [(PEP+S706)]  
 ADUC824BS@LFCSP56 [(PEP+S706)]

ADUC812BS@MQFP52 [(PEP+S662)]  
 ADUC816BS@MQFP52 [(PEP+S662)]  
 ADUC824BS@MQFP52 [(PEP+S662)]

## AOYU

### PLD

AY666@BGA256(\*) [(TA086+B084)]

## APLUS FLASH

### E(E) PROM/FRAM/NVRAM

AF24BC01  
 AF24BC01@TSSOP8 [(SA026)]  
 AF24BC02@SOIC8 [(SA602A)]  
 AF24BC04  
 AF24BC04@TSSOP8 [(SA026)]  
 AF24BC08@SOIC8 [(SA602A)]  
 AF24BC128  
 AF24BC128@TSOP8 [(SA026)]  
 AF24BC16@SOIC8 [(SA602A)]  
 AF24BC256  
 AF24BC256@TSOP8 [(SA026)]  
 AF24BC32@SOIC8 [(SA602A)]  
 AF24BC64  
 AF24BC64@TSOP8 [(SA026)]  
 AF24C128@SOIC8 [(SA602A)]  
 AF24C256  
 AF24C256@TSOP8 [(SA026)]  
 AF24C32@SOIC8 [(SA602A)]  
 AF24C64  
 AF24C64@TSOP8 [(SA026)]  
 AF25BC08@SOIC8 [(SA602A)]  
 AF25BC128  
 AF25BC128@TSOP8 [(SA026)]  
 AF25BC16@SOIC8 [(SA602A)]  
 AF25BC256  
 AF25BC256@TSOP8 [(SA026)]  
 AF25BC32@SOIC8 [(SA602A)]  
 AF25BC64  
 AF25BC64@TSOP8 [(SA026)]  
 AF93BC46(08bit)@SOIC8 [(SA602A)]  
 AF93BC46(16bit)  
 AF93BC46(16bit)@TSOP8 [(SA026)]  
 AF93BC56(08bit)@SOIC8 [(SA602A)]  
 AF93BC56(16bit)  
 AF93BC56(16bit)@TSOP8 [(SA026)]  
 AF93BC66(08bit)@SOIC8 [(SA602A)]  
 AF93BC66(16bit)  
 AF93BC66(16bit)@TSOP8 [(SA026)]  
 AF93BC86(08bit)@SOIC8 [(SA602A)]  
 AF93BC86(16bit)  
 AF93BC86(16bit)@TSOP8 [(SA026)]  
 AF93C46(08bit)@SOIC8 [(SA602A)]  
 AF93C46(16bit)  
 AF93C46(16bit)@TSOP8 [(SA026)]  
 AF93C56(08bit)@SOIC8 [(SA602A)]  
 AF93C56(16bit)  
 AF93C56(16bit)@TSOP8 [(SA026)]  
 AF93C66(08bit)@SOIC8 [(SA602A)]  
 AF93C66(16bit)

AF24BC01@SOIC8 [(SA602A)]  
 AF24BC02  
 AF24BC02@TSSOP8 [(SA026)]  
 AF24BC04@SOIC8 [(SA602A)]  
 AF24BC08  
 AF24BC08@TSSOP8 [(SA026)]  
 AF24BC128@SOIC8 [(SA602A)]  
 AF24BC16  
 AF24BC16@TSSOP8 [(SA026)]  
 AF24BC256@SOIC8 [(SA602A)]  
 AF24BC32  
 AF24BC32@TSOP8 [(SA026)]  
 AF24BC64@SOIC8 [(SA602A)]  
 AF24C128  
 AF24C128@TSOP8 [(SA026)]  
 AF24C256@SOIC8 [(SA602A)]  
 AF24C32  
 AF24C32@TSOP8 [(SA026)]  
 AF24C64@SOIC8 [(SA602A)]  
 AF25BC08  
 AF25BC08@TSOP8 [(SA026)]  
 AF25BC128@SOIC8 [(SA602A)]  
 AF25BC16  
 AF25BC16@TSOP8 [(SA026)]  
 AF25BC256@SOIC8 [(SA602A)]  
 AF25BC32  
 AF25BC32@TSOP8 [(SA026)]  
 AF25BC64@SOIC8 [(SA602A)]  
 AF93BC46(08bit)  
 AF93BC46(08bit)@TSOP8 [(SA026)]  
 AF93BC46(16bit)@SOIC8 [(SA602A)]  
 AF93BC56(08bit)  
 AF93BC56(08bit)@TSOP8 [(SA026)]  
 AF93BC56(16bit)@SOIC8 [(SA602A)]  
 AF93BC66(08bit)  
 AF93BC66(08bit)@TSOP8 [(SA026)]  
 AF93BC66(16bit)@SOIC8 [(SA602A)]  
 AF93BC86(08bit)  
 AF93BC86(08bit)@TSOP8 [(SA026)]  
 AF93BC86(16bit)@SOIC8 [(SA602A)]  
 AF93C46(08bit)  
 AF93C46(08bit)@TSOP8 [(SA026)]  
 AF93C46(16bit)@SOIC8 [(SA602A)]  
 AF93C56(08bit)  
 AF93C56(08bit)@TSOP8 [(SA026)]  
 AF93C56(16bit)@SOIC8 [(SA602A)]  
 AF93C66(08bit)  
 AF93C66(08bit)@TSOP8 [(SA026)]  
 AF93C66(16bit)@SOIC8 [(SA602A)]

```

AF93C66(16bit)@TSOP8 [(SA026)]      AF93C86(08bit)
AF93C86(08bit)@SOIC8 [(SA602A)]    AF93C86(08bit)@TSOP8 [(SA026)]
AF93C86(16bit)                      AF93C86(16bit)@SOIC8 [(SA602A)]
AF93C86(16bit)@TSOP8 [(SA026)]

```

## ARTSCHIP

### E(E) PROM/FRAM/NVRAM

```

24AA02                                24AA02@MSOP8 [(SA666)]
24AA02@SOIC8 [(SA602A)]             24AA02@SOT5 [(SA717)]
24AA02@TSSOP8 [(SA026)]             24LC01A
24LC01A@SOIC8 [(SA602A)]           24LC01A@SOT5 [(SA717)]
24LC01A@TSSOP8 [(SA026)]           24LC01B
24LC01B@SOIC8 [(SA602A)]           24LC01B@SOT5 [(SA717)]
24LC01B@TSSOP8 [(SA026)]           24LC02A
24LC02A@SOIC8 [(SA602A)]           24LC02A@SOT5 [(SA717)]
24LC02A@TSSOP8 [(SA026)]           24LC02B
24LC02B@MSOP8 [(SA666)]            24LC02B@SOIC8 [(SA602A)]
24LC02B@SOT5 [(SA717)]            24LC02B@TSSOP8 [(SA026)]
24LC04A                                24LC04A@SOIC8 [(SA602A)]
24LC04A@SOT5 [(SA717)]            24LC04A@TSSOP8 [(SA026)]
24LC04B                                24LC04B@MSOP8 [(SA666)]
24LC04B@SOIC8 [(SA602A)]           24LC04B@SOT5 [(SA717)]
24LC04B@TSSOP8 [(SA026)]           24LC08A
24LC08A@SOIC8 [(SA602A)]           24LC08A@SOT5 [(SA717)]
24LC08A@TSSOP8 [(SA026)]           24LC08B
24LC08B@MSOP8 [(SA666)]            24LC08B@SOIC8 [(SA602A)]
24LC08B@SOT5 [(SA717)]            24LC08B@TSSOP8 [(SA026)]
24LC16A                                24LC16A@SOIC8 [(SA602A)]
24LC16A@SOT5 [(SA717)]            24LC16A@TSSOP8 [(SA026)]
24LC256B                                24LC256B@MSOP8 [(SA666)]
24LC256B@SOIC8 [(SA602A)]           24LC256B@TSSOP8 [(SA026)]
24LC32                                24LC32@SOIC14 [(SA026)]
24LC32@SOIC8 [(SA602A)]           24LC32@TSSOP8 [(SA026)]
24LC64                                24LC64@SOIC14 [(SA026)]
24LC64@SOIC8 [(SA602A)]           24LC64@TSSOP8 [(SA026)]

```

## ASAHI KASEI(AKM)

### E(E) PROM/FRAM/NVRAM

```

AK27CX161                            AK27CX162
AK27CX321                            AK27CX322
AK27CX641                            AK27CX642
AK6002A(F)@SOP8 [(SA602A)]          AK6002A(V)@TSSOP8 [(SA026)]
AK6003A(V)@TSSOP8 [(SA026)]          AK6004A(F)@SOP8 [(SA602A)]
AK6004A(M)@SSOP8 [(SA605A)]          AK6008A(F)@SOP8 [(SA602A)]
AK6010A(F)@SOP8 [(SA602A)]          AK6012A(F)@SOP8 [(SA602A)]
AK6416A(M)@SSOP8 [(SA026)]          AK6416C(F)@SOP8 [(SA602A)]
AK6420A(F)@SOP8 [(SA602A)]          AK6420A(M)@SSOP8 [(SA605A)]
AK6420B(H)@MSOP8 [(SA666)]          AK6440A(F)@SOP8 [(SA602A)]
AK6440A(M)@SSOP8 [(SA026)]          AK6440B(H)@MSOP8 [(SA666)]
AK6480A(F)@SOP8 [(SA602A)]          AK6480A(M)@SSOP8 [(SA026)]
AK6480B(H)@MSOP8 [(SA666)]          AK6480C(F)@SOP8 [(SA602A)]
AK6480C(H)@MSOP8 [(SA666)]          AK6480C(L)@SON8
AK6480C(M)@SSOP8 [(SA026)]          AK6481C(H)@MSOP8 [(SA666)]
AK6481C(M)@SSOP8 [(SA026)]          AK6508C(T)@MSOP8 [(SA666)]
AK6508C(U)@USON8                     AK6510C(L)@SONW8
AK6510C(M)@SSOP8 [(SA026)]          AK6512C(L)@SONW8
AK6512C(M)@SSOP8 [(SA026)]          AK6514C(F)@SOP8 [(SA602A)]
AK6514C(N)@QFN20 [(SA692)]          AK6516C(F)@SOP8 [(SA602A)]
AK93C10A(F)@SOP8 [(SA602A)]          AK93C41A(V)@TSSOP8 [(SA026)]
AK93C45                                AK93C45(F)@SOP8 [(SA602A)]
AK93C45A(F)@SOP8 [(SA602A)]          AK93C45A(NF)@SOP8 [(SA602A)]
AK93C45A(V)@TSSOP8 [(SA026)]          AK93C45B(H)@MSOP8 [(SA666)]
AK93C45B(L)@SON8                     AK93C45C(T)@MSOP8 [(SA666)]
AK93C45C(U)@USON8                     AK93C45L
AK93C45L(F)@SOP8 [(SA602A)]          AK93C46
AK93C46(F)@SOP8 [(SA602A)]          AK93C46A(F)@SOP8 [(SA602A)]
AK93C46A(NF)@SOP8 [(SA602A)]          AK93C46A(V)@TSSOP8 [(SA026)]
AK93C46B(H)@MSOP8 [(SA666)]          AK93C46B(L)@SON8
AK93C46C(T)@MSOP8 [(SA666)]          AK93C46C(U)@USON8
AK93C46L                                AK93C46L(F)@SOP8 [(SA602A)]

```

AK93C51A(V)@TSSOP8 [(SA026)]	AK93C55
AK93C55(F)@SOP8 [(SA602A)]	AK93C55A(F)@SOP8 [(SA602A)]
AK93C55A(NF)@SOP8 [(SA602A)]	AK93C55A(V)@TSSOP8 [(SA026)]
AK93C55B(H)@MSOP8 [(SA666)]	AK93C55B(L)@SON8
AK93C55C(T)@MSOP8 [(SA666)]	AK93C55C(U)@USON8
AK93C55L	AK93C55L(F)@SOP8 [(SA602A)]
AK93C56	AK93C56(F)@SOP8 [(SA602A)]
AK93C56A(F)@SOP8 [(SA602A)]	AK93C56A(NF)@SOP8 [(SA602A)]
AK93C56A(V)@TSSOP8 [(SA026)]	AK93C56B(H)@MSOP8 [(SA666)]
AK93C56B(L)@SON8	AK93C56C(T)@MSOP8 [(SA666)]
AK93C56C(U)@USON8	AK93C56L
AK93C56L(F)@SOP8 [(SA602A)]	AK93C61A(V)@TSSOP8 [(SA026)]
AK93C65	AK93C65(F)@SOP8 [(SA602A)]
AK93C65A(F)@SOP8 [(SA602A)]	AK93C65A(NF)@SOP8 [(SA602A)]
AK93C65A(V)@TSSOP8 [(SA026)]	AK93C65B(H)@MSOP8 [(SA666)]
AK93C65B(L)@SON8	AK93C65C(T)@MSOP8 [(SA666)]
AK93C65C(U)@USON8	AK93C65L
AK93C65L(F)@SOP8 [(SA602A)]	AK93C66
AK93C66(F)@SOP8 [(SA602A)]	AK93C66A(F)@SOP8 [(SA602A)]
AK93C66A(NF)@SOP8 [(SA602A)]	AK93C66A(V)@TSSOP8 [(SA026)]
AK93C66B(H)@MSOP8 [(SA666)]	AK93C66B(L)@SON8
AK93C66C(T)@MSOP8 [(SA666)]	AK93C66C(U)@USON8
AK93C66L	AK93C66L(F)@SOP8 [(SA602A)]
AK93C75	AK93C75(F)@SOP8 [(SA602A)]
AK93C75A(F)@SOP8 [(SA602A)]	AK93C75A(NF)@SOP8 [(SA602A)]
AK93C75A(V)@TSSOP8 [(SA026)]	AK93C75B(H)@MSOP8 [(SA666)]
AK93C75L	AK93C75L(F)@SOP8 [(SA602A)]
AK93C85	AK93C85(F)@SOP8 [(SA602A)]
AK93C85L	AK93C85L(F)@SOP8 [(SA602A)]
AK93C95A(F)@SOP8 [(SA602A)]	AK9822(M)@SSOP8 [(SA026)]
AK9824(M)@SSOP8 [(SA026)]	AK9844@SOIC14 [(SA602)]

## ASD

### E(E) PROM/FRAM/NVRAM

AE29F1008	AE29F2008
-----------	-----------

## ASI

### E(E) PROM/FRAM/NVRAM

AS58C1001	AS58C1001@PLCC32 [(SA015A1T)]
AS58C1001@SSOP32 [(SA438T)]	

## ASP

### MICROCONTROLLER

AP827C51	AP827C51@PLCC44 [(SA244)]
AP827C52	AP827C52@PLCC44 [(SA244)]
AP827C54	AP827C54@PLCC44 [(SA244)]
AP827C58	AP827C58@PLCC44 [(SA244)]

## ASTIGP-MICROCHIP

### MICROCONTROLLER

PIC16F616	PIC16F616-Q16
PIC16F616-S14	PIC16F616-T14

## ATC

### E(E) PROM/FRAM/NVRAM

ATC24C02	ATC24C02@SOIC8 [(SA602A)]
ATC24C02@TSSOP8 [(SA026)]	ATC24C04
ATC24C04@SOIC8 [(SA602A)]	ATC24C04@TSSOP8 [(SA026)]
ATC24C08	ATC24C08@SOIC8 [(SA602A)]
ATC24C08@TSSOP8 [(SA026)]	ATC24C16
ATC24C16@SOIC8 [(SA602A)]	ATC24C16@TSSOP8 [(SA026)]
ATC24LC02	ATC24LC02@SOIC8 [(SA602A)]
ATC24LC02@TSSOP8 [(SA026)]	ATC24LC02A
ATC24LC02A@SOIC8 [(SA602A)]	ATC24LC02A@TSSOP8 [(SA026)]
ATC24LC04	ATC24LC04@SOIC8 [(SA602A)]
ATC24LC04@TSSOP8 [(SA026)]	ATC24LC08
ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8 [(SA026)]
ATC24LC16	ATC24LC16@SOIC8 [(SA602A)]
ATC24LC16@TSSOP8 [(SA026)]	ATC93C46(08bit)
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46(16bit)
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit)	ATC93C56(08bit)@SOIC8 [(SA602A)]
ATC93C56(16bit)	ATC93C56(16bit)@SOIC8 [(SA602A)]
ATC93C56R(08bit)@SOIC8 [(SA602A)]	
ATC93C56R(16bit)@SOIC8 [(SA602A)]	
ATC93C66(08bit)	ATC93C66(08bit)@SOIC8 [(SA602A)]
ATC93C66(16bit)	ATC93C66(16bit)@SOIC8 [(SA602A)]
ATC93C66R(08bit)@SOIC8 [(SA602A)]	
ATC93C66R(16bit)@SOIC8 [(SA602A)]	
ATC93LC46(08bit)	
ATC93LC46(08bit)@SOIC8 [(SA602A)]	
ATC93LC46(16bit)	
ATC93LC46(16bit)@SOIC8 [(SA602A)]	
ATC93LC46R(08bit)@SOIC8 [(SA602A)]	
ATC93LC46R(16bit)@SOIC8 [(SA602A)]	
ATC93LC56(08bit)	
ATC93LC56(08bit)@SOIC8 [(SA602A)]	
ATC93LC56(16bit)	
ATC93LC56(16bit)@SOIC8 [(SA602A)]	
ATC93LC56R(08bit)@SOIC8 [(SA602A)]	
ATC93LC56R(16bit)@SOIC8 [(SA602A)]	
ATC93LC66(08bit)	
ATC93LC66(08bit)@SOIC8 [(SA602A)]	
ATC93LC66(16bit)	
ATC93LC66(16bit)@SOIC8 [(SA602A)]	
ATC93LC66R(08bit)@SOIC8 [(SA602A)]	
ATC93LC66R(16bit)@SOIC8 [(SA602A)]	

## ATMEL

### E(E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)]	AT17C002@PLCC44 [(SA244)]
AT17C002@SOIC20 [(SA404)]	AT17C002@TQFP44 [(SA245A)]
AT17C002A@PLCC20 [(SA001A)]	AT17C002A@TQFP32 [(SA663)]
AT17C010	AT17C010@PLCC20 [(SA001A)]
AT17C010A	AT17C010A@PLCC20 [(SA001A)]
AT17C040@PLCC44 [(SA244)]	AT17C040@TQFP44 [(SA245A)]
AT17C128	AT17C128@PLCC20 [(SA001A)]
AT17C128@SOIC20 [(SA404)]	AT17C128@SOIC8 [(SA602A)]
AT17C128A@PLCC20 [(SA001A)]	AT17C256
AT17C256@PLCC20 [(SA001A)]	AT17C256@SOIC20 [(SA404)]
AT17C256@SOIC8 [(SA602A)]	AT17C256A@PLCC20 [(SA001A)]
AT17C512	AT17C512@PLCC20 [(SA001A)]
AT17C512A	AT17C512A@PLCC20 [(SA001A)]
AT17C65	AT17C65@PLCC20 [(SA001A)]
AT17C65@SOIC20 [(SA404)]	AT17C65@SOIC8 [(SA602A)]
AT17C65A@PLCC20 [(SA001A)]	AT17F040@LAP8 [(SA760)]
AT17F040@PLCC20 [(SA001A)]	
AT17F040@PLCC20(Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)]	AT17F040A@PLCC20 [(SA001A)]
AT17F040A@TQFP32 [(SA663)]	AT17F080@LAP8 [(SA760)]
AT17F080@PLCC20 [(SA001A)]	AT17F080@PLCC44 [(SA244)]
AT17F080@TQFP44 [(SA245A)]	AT17F080A@LAP8 [(SA760)]
AT17F080A@PLCC20 [(SA001A)]	AT17F080A@TQFP32 [(SA001A)]
AT17F16@LAP8 [(SA760)]	AT17F16@PLCC20 [(SA001A)]
AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44 [(SA245A)]
AT17F16A@LAP8 [(SA760)]	AT17F16A@PLCC20 [(SA001A)]
AT17F32@PLCC44 [(SA244)]	AT17F32A@PLCC44 [(SA244)]
AT17LV002@PLCC20 [(SA001A)]	AT17LV002@PLCC44 [(SA244)]

AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44 [(SA245A)]
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32 [(SA663)]
AT17LV010	AT17LV010@PLCC20 [(SA001A)]
AT17LV010A	AT17LV010A@PLCC20 [(SA001A)]
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44 [(SA245A)]
AT17LV128	AT17LV128@PLCC20 [(SA001A)]
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8 [(SA602A)]
AT17LV128A@PLCC20 [(SA001A)]	AT17LV256
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20 [(SA404)]
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20 [(SA001A)]
AT17LV512	AT17LV512@PLCC20 [(SA001A)]
AT17LV512A	AT17LV512A@PLCC20 [(SA001A)]
AT17LV65	AT17LV65@PLCC20 [(SA001A)]
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8 [(SA602A)]
AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20 [(SA404)]
AT17N002@TQFP44 [(SA245A)]	AT17N010
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44 [(SA245A)]
AT17N256	AT17N256@SOIC20 [(SA404)]
AT17N256@SOIC8 [(SA602A)]	AT17N512
AT17N512@SOIC20 [(SA404)]	AT24C01
AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8 [(SA602A)]
AT24C01@TSSOP8 [(SA026)]	AT24C01A
AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8 [(SA602A)]
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8 [(SA026)]
AT24C01B	AT24C01B@dBG2
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8 [(SA602A)]
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8 [(SA026)]
AT24C02	AT24C02@SOIC8 [(SA602A)]
AT24C02@TSSOP8 [(SA026)]	AT24C02A
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8 [(SA026)]
AT24C02B	AT24C02B@dBG2
AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8 [(SA602A)]
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8 [(SA026)]
AT24C02C	AT24C02C@SOIC8 [(SA602A)]
AT24C02C@TSSOP8 [(SA026)]	AT24C04
AT24C04@MAP8 [(SA724)]	AT24C04@SOIC8 [(SA602A)]
AT24C04@SOT23-5 [(SA717)]	AT24C04@TSSOP8 [(SA026)]
AT24C04A	AT24C04A@MAP8 [(SA724)]
AT24C04A@SOIC8 [(SA602A)]	AT24C04A@TSSOP8 [(SA026)]
AT24C08	AT24C08@MAP8 [(SA724)]
AT24C08@SOIC8 [(SA602A)]	AT24C08@TSSOP8 [(SA026)]
AT24C08A	AT24C08A@MAP8 [(SA724)]
AT24C08A@SOIC8 [(SA602A)]	AT24C08A@TSSOP8 [(SA026)]
AT24C1024	AT24C1024@LAP8 [(SA724)]
AT24C1024@SAP8 [(SA684)]	AT24C1024@SOIC8 [(SA023A)]
AT24C1024B(1.8V)	AT24C1024B(1.8V)@LAP8 [(SA724)]
AT24C1024B(1.8V)@SAP8 [(SA684)]	AT24C11@SOIC8 [(SA602A)]
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	AT24C128(1.8V)
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	AT24C128(1.8V)@SAP8 [(SA683)]
AT24C1024B(2.5V)	AT24C128(1.8V)@TSSOP8 [(SA026)]
AT24C1024B(2.5V)@SAP8 [(SA684)]	AT24C128(2.7V)@MAP8 [(SA724)]
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	AT24C128(2.7V)@SOIC8 [(SA602A)]
AT24C1024B(2.5V)@TSSOP8 [(SA026)]	AT24C128B
AT24C11	AT24C128B@SAP8 [(SA683)]
AT24C11@TSSOP8 [(SA026)]	AT24C128B@TSSOP8 [(SA026)]
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C16@SOIC8 [(SA602A)]
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C164
AT24C128(2.7V)	AT24C16A
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C16A@SOIC8 [(SA602A)]
AT24C128(2.7V)@TSSOP8 [(SA026)]	AT24C16B
AT24C128B@MAP8 [(SA724)]	AT24C16B@SOIC8 [(SA602A)]
AT24C128B@SOIC8 [(SA602A)]	AT24C21
AT24C16	AT24C256(1.8V)
AT24C16@TSSOP8 [(SA026)]	AT24C256(1.8V)@SAP8 [(SA683)]
AT24C164@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8 [(SA026)]
AT24C16A@MAP8 [(SA724)]	AT24C256(2.7V)@MAP8 [(SA724)]
AT24C16A@TSSOP8 [(SA026)]	AT24C256(2.7V)@SOIC8 [(SA602A)]
AT24C16B@MAP8 [(SA724)]	AT24C256B
AT24C16B@TSSOP8 [(SA026)]	AT24C256B@SAP8 [(SA683)]
AT24C21@SOIC8 [(SA602A)]	AT24C256B@TSSOP8 [(SA026)]
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C32@SOIC8 [(SA602A)]
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C32A
AT24C256(2.7V)	AT24C32A@MAP8 [(SA724)]
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C32A@TSSOP8 [(SA026)]
AT24C256(2.7V)@TSSOP8 [(SA026)]	
AT24C256B@MAP8 [(SA724)]	
AT24C256B@SOIC8 [(SA602A)]	
AT24C32	
AT24C32@TSSOP8 [(SA026)]	
AT24C32A@MAP8 [(SA724)]	
AT24C32A@TSSOP8 [(SA026)]	

AT24C32C@dBG8 [(BBBB)]	AT24C32C@MAP8 [(SA724)]
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8 [(SA602A)]
AT24C32C@TSSOP8 [(SA026)]	AT24C512(1.8V)
AT24C512(1.8V)@LAP8 [(SA684)]	AT24C512(1.8V)@SAP8 [(SA683)]
AT24C512(1.8V)@SOIC8 [(SA602A)]	AT24C512(1.8V)@TSSOP8 [(SA026)]
AT24C512(2.7V)	AT24C512(2.7V)@LAP8 [(SA684)]
AT24C512(2.7V)@SAP8 [(SA683)]	AT24C512(2.7V)@SOIC8 [(SA602A)]
AT24C512(2.7V)@TSSOP8 [(SA026)]	AT24C512B
AT24C512B@LAP8 [(SA684)]	AT24C512B@SAP8 [(SA683)]
AT24C512B@SOIC8 [(SA602A)]	AT24C512B@TSSOP8 [(SA026)]
AT24C64	AT24C64@SOIC8 [(SA602A)]
AT24C64@TSSOP8 [(SA026)]	AT24C64A
AT24C64A@MAP8 [(SA724)]	AT24C64A@SOIC8 [(SA602A)]
AT24C64A@TSSOP8 [(SA026)]	AT24C64B
AT24C64B@SOIC8 [(SA602A)]	AT24C64B@TSSOP8 [(SA026)]
AT24C64C	AT24C64C@dBG8 [(BBBB)]
AT24C64C@MAP8 [(SA724)]	AT24C64C@SAP8 [(SA683)]
AT24C64C@SOIC8 [(SA602A)]	AT24C64C@TSSOP8 [(SA026)]
AT24CS128	AT24CS128@SOIC8 [(SA602A)]
AT24HC02B	AT24HC02B@SOIC8 [(SA602A)]
AT24HC02B@TSSOP8 [(SA026)]	AT24RF08AN@SOIC8 [(SA602A)]
AT24RF08AT@TSSOP14 [(SA026)]	AT24RF08BN@SOIC8 [(SA602A)]
AT24RF08BT@TSSOP14 [(SA026)]	AT24RF08CN@SOIC8 [(SA602A)]
AT24RF08CT@TSSOP14 [(SA026)]	AT25010
AT25010@SOIC8 [(SA602A)]	AT25010A
AT25010A@SOIC8 [(SA602A)]	AT25010A@TSSOP8 [(SA026)]
AT25020	AT25020@SOIC8 [(SA602A)]
AT25020A	AT25020A@SOIC8 [(SA602A)]
AT25020A@TSSOP8 [(SA026)]	AT25040
AT25040(ISP) [ISP-HEADER01]	AT25040@SOIC8 [(SA602A)]
AT25040@SOIC8(ISP) [ISP-HEADER01]	AT25040A(ISP) [ISP-HEADER01]
AT25040A	
AT25040A@SOIC8 [(SA602A)]	
AT25040A@SOIC8(ISP) [ISP-HEADER01]	
AT25080	AT25080@SOIC8 [(SA602A)]
AT25080@TSSOP14 [(SA026)]	AT25080@TSSOP20 [(SA026)]
AT25080A	AT25080A@SOIC8 [(SA602A)]
AT25080A@TSSOP14 [(SA026)]	AT25080B
AT25080B@dBG8 [(BBBB)]	AT25080B@MAP8 [(SA724)]
AT25080B@SOIC8 [(SA602A)]	AT25080B@TSSOP8 [(SA026)]
AT25128	AT25128@SOIC16 [(SA602)]
AT25128@SOIC8 [(SA602A)]	AT25128@TSSOP14 [(SA026)]
AT25128@TSSOP20 [(SA026)]	AT25128A
AT25128A@dBG8 [(BBBB)]	AT25128A@SAP8 [(SA683)]
AT25128A@SOIC8(4.0) [(SA602A)]	AT25128A@SOIC8(5.4) [(SA605A)]
AT25128A@TSSOP14 [(SA026)]	AT25128A@TSSOP8 [(SA026)]
AT25160	AT25160@SOIC8 [(SA602A)]
AT25160@TSSOP14 [(SA026)]	AT25160@TSSOP20 [(SA026)]
AT25160A	AT25160A@SOIC8 [(SA602A)]
AT25160A@TSSOP14 [(SA026)]	AT25160B
AT25160B@dBG8 [(BBBB)]	AT25160B@MAP8 [(SA724)]
AT25160B@SOIC8 [(SA602A)]	AT25160B@TSSOP8 [(SA026)]
AT25256	AT25256@SOIC16 [(SA602)]
AT25256@SOIC8 [(SA602A)]	AT25256@TSSOP14 [(SA026)]
AT25256@TSSOP20 [(SA026)]	AT25256A
AT25256A@dBG8 [(BBBB)]	AT25256A@SAP8 [(SA683)]
AT25256A@SOIC8(4.0) [(SA602A)]	AT25256A@SOIC8(5.4) [(SA605A)]
AT25256A@TSSOP14 [(SA026)]	AT25256A@TSSOP8 [(SA026)]
AT25320	AT25320@SOIC8 [(SA602A)]
AT25320@TSSOP14 [(SA026)]	AT25320@TSSOP20 [(SA026)]
AT25320A	AT25320A@SOIC8 [(SA602A)]
AT25320A@TSSOP14 [(SA026)]	AT25320B
AT25320B@dBG8 [(BBBB)]	AT25320B@MAP8 [(SA724)]
AT25320B@SOIC8 [(SA602A)]	AT25320B@TSSOP8 [(SA026)]
AT25640	AT25640@SOIC8 [(SA602A)]
AT25640@TSSOP14 [(SA026)]	AT25640@TSSOP20 [(SA026)]
AT25640A	AT25640A@SOIC8 [(SA602A)]
AT25640A@TSSOP14 [(SA026)]	AT25640B
AT25640B@dBG8 [(BBBB)]	AT25640B@MAP8 [(SA724)]
AT25640B@SOIC8 [(SA602A)]	AT25640B@TSSOP8 [(SA026)]
AT25DF021@SOIC8 [(SA602A)]	AT25DF021@UDFN8 [(SA683)]
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8(4.0) [(SA602A)]
AT25DF041A@SOIC8(5.4) [(SA605A)]	AT25DF081@SOIC8 [(SA602A)]
AT25DF081@UDFN8 [(SA683)]	AT25DF161@MLF8 [(SA683)]
AT25DF161@SOIC8(4.0) [(SA602A)]	AT25DF161@SOIC8(5.4) [(SA605A)]
AT25DF321@SOIC16 [(SA404)]	AT25DF321@SOIC8 [(SA605A)]
AT25DF641@SOIC16 [(SA404)]	AT25DF641@VDFN8 [(SA683)]
AT25F1024	AT25F1024(W)@SOIC8 [(SA605A)]
AT25F1024(W)@VQFPN8 [(SA684)]	AT25F1024@SOIC8 [(SA602A)]
AT25F1024@VQFPN8 [(SA683)]	AT25F1024A
AT25F1024A(W)@SOIC8 [(SA605A)]	AT25F1024A(W)@VQFPN8 [(SA684)]

AT25F1024A@SOIC8 [(SA602A)]	AT25F1024A@VQFPN8 [(SA683)]
AT25F2048	AT25F2048(W)@SOIC8 [(SA605A)]
AT25F2048(W)@VQFPN8 [(SA684)]	AT25F2048@SOIC8 [(SA602A)]
AT25F2048@VQFPN8 [(SA683)]	AT25F2048A
AT25F2048A(W)@SOIC8 [(SA605A)]	AT25F2048A(W)@VQFPN8 [(SA684)]
AT25F2048A@SOIC8 [(SA602A)]	AT25F2048A@VQFPN8 [(SA683)]
AT25F4096	AT25F4096(W)@SOIC8 [(SA605A)]
AT25F4096(W)@VQFPN8 [(SA684)]	AT25F4096@SOIC8 [(SA602A)]
AT25F4096@VQFPN8 [(SA683)]	AT25F4096A
AT25F4096A(W)@SOIC8 [(SA605A)]	AT25F4096A(W)@VQFPN8 [(SA684)]
AT25F4096A@SOIC8 [(SA602A)]	AT25F4096A@VQFPN8 [(SA683)]
AT25F512	AT25F512(W)@SOIC8 [(SA605A)]
AT25F512(W)@VQFPN8 [(SA684)]	AT25F512@SOIC8 [(SA602A)]
AT25F512@VQFPN8 [(SA683)]	AT25F512A
AT25F512A(W)@SOIC8 [(SA605A)]	AT25F512A(W)@VQFPN8 [(SA684)]
AT25F512A@SOIC8 [(SA602A)]	AT25F512A@VQFPN8 [(SA683)]
AT25F512B@SOIC8 [(SA602A)]	AT25F512B@UDFN8 [(SA724)]
AT25FS010@SAP8 [(SA683)]	AT25FS010@SOIC8 [(SA602A)]
AT25FS040@SAP8 [(SA683)]	AT25FS040@SOIC8 [(SA602A)]
AT25HP256	AT25HP256(W)@VQFPN8 [(SA684)]
AT25HP256@SOIC16 [(SA404)]	AT25HP256@SOIC8 [(SA602A)]
AT25HP256@VQFPN8 [(SA683)]	AT25HP512
AT25HP512(W)@VQFPN8 [(SA684)]	AT25HP512@SOIC16 [(SA404)]
AT25HP512@SOIC8 [(SA602A)]	AT25HP512@VQFPN8 [(SA683)]
AT25P1024@SOIC20 [(SA404)]	AT25P1024@VQFPN8 [(SA684)]
AT26DF041@MLF8 [(SA683)]	AT26DF041@SOIC8(4.0) [(SA602A)]
AT26DF041@SOIC8(5.4) [(SA605A)]	AT26DF081@SOIC8(4.0) [(SA602A)]
AT26DF081@SOIC8(5.4) [(SA605A)]	AT26DF081A@SOIC8(4.0) [(SA602A)]
AT26DF081A@SOIC8(5.4) [(SA605A)]	AT26DF161@MLF8 [(SA683)]
AT26DF161@SOIC8 [(SA605A)]	AT26DF161A@MLF8 [(SA683)]
AT26DF161A@SOIC8 [(SA605A)]	AT26DF321@MLF8(5*6mm) [(SA683)]
AT26DF321@MLF8(6*8mm) [(SA684)]	AT26DF321@SOIC16 [(SA404)]
AT26DF321@SOIC8 [(SA605A)]	AT26F004@MLF8 [(SA683)]
AT26F004@SOIC8(4.0) [(SA602A)]	AT26F004@SOIC8(5.4) [(SA605A)]
AT27011	AT27011@PLCC32 [(SA015A1T)]
AT27256	AT2732A
AT27BV010	AT27BV010@PLCC32 [(SA015A1T)]
AT27BV010@TSOP32 [(SA620)]	AT27BV020
AT27BV020@PLCC32 [(SA015A1T)]	AT27BV020@TSOP32 [(SA620)]
AT27BV040	AT27BV040@PLCC32 [(SA015A1T)]
AT27BV040@TSOP32 [(SA620)]	AT27BV1024@PLCC44 [(SA244)]
AT27BV1024@TSOP40 [(SA623)]	AT27BV256
AT27BV256@PLCC32 [(SA015A1T)]	AT27BV256@TSOP28 [(SA430T)]
AT27BV4096	AT27BV4096@PLCC44 [(SA244)]
AT27BV4096@TSOP40 [(SA623)]	AT27BV512
AT27BV512@PLCC32 [(SA015A1T)]	AT27BV512@SOIC28 [(SA630)]
AT27BV512@TSOP28 [(SA430T)]	AT27BV520@SOIC20 [(SA404)]
AT27BV520@TSOP28 [(SA430T)]	AT27BV520@TSSOP20 [(SA026)]
AT27C010	AT27C010@PLCC32 [(SA015A1T)]
AT27C010@TSOP32 [(SA410T)]	AT27C010L
AT27C010L@PLCC32 [(SA015A1T)]	AT27C010L@TSOP32 [(SA410T)]
AT27C020	AT27C020@PLCC32 [(SA015A1T)]
AT27C020@TSOP32 [(SA410T)]	AT27C040
AT27C040@PLCC32 [(SA015A1T)]	AT27C040@TSOP32 [(SA410T)]
AT27C080	AT27C080@PLCC32 [(SA015A1T)]
AT27C080@TSOP32 [(SA410T)]	AT27C1024
AT27C1024@PLCC44 [(SA244)]	AT27C1024@TSOP40 [(SA623)]
AT27C1024L	AT27C1024L@PLCC44 [(SA244)]
AT27C128	AT27C128@PLCC32 [(SA015A1T)]
AT27C2048	AT27C2048@PLCC44 [(SA244)]
AT27C2048@TSOP40 [(SA623)]	AT27C256
AT27C256@PLCC32 [(SA015A1T)]	AT27C256R
AT27C256R@PLCC32 [(SA015A1T)]	AT27C256R@SOIC28 [(SA630)]
AT27C256R@TSOP28 [(SA430T)]	AT27C4096
AT27C4096@PLCC44 [(SA244)]	AT27C4096@TSOP40 [(SA623)]
AT27C512	AT27C512@PLCC32 [(SA015A1T)]
AT27C512R	AT27C512R@PLCC32 [(SA015A1T)]
AT27C512R@SOIC28 [(SA630)]	AT27C512R@TSOP28 [(SA430T)]
AT27C513	AT27C513@PLCC32 [(SA015A1T)]
AT27C513@SOIC28 [(SA630)]	AT27C513R
AT27C513R@PLCC32 [(SA015A1T)]	AT27C513R@SOIC28 [(SA630)]
AT27C515	AT27C515@PLCC32 [(SA015A1T)]
AT27C516	AT27C516@PLCC44 [(SA244)]
AT27C516@TSOP40 [(SA623)]	AT27C520@SOIC20 [(SA404)]
AT27C520@TSOP28 [(SA430T)]	AT27C520@TSSOP20 [(SA026)]
AT27C64	AT27C800
AT27C800@PLCC44 [(SA244)]	AT27C800@PSOP44 [(SA638)]
AT27HC1024	AT27HC1024@PLCC44 [(SA244)]
AT27HC256	AT27HC256@PLCC32 [(SA015A1T)]
AT27HC256L	AT27HC256L@PLCC32 [(SA015A1T)]
AT27HC256R	AT27HC256R@PLCC32 [(SA015A1T)]

AT27HC256RL	AT27HC256RL@PLCC32 [(SA015A1T)]
AT27HC64	AT27HC64@PLCC32 [(SA015A1T)]
AT27HC641	AT27HC641@PLCC28 [(SA008A)]
AT27HC641R	AT27HC641R@PLCC28 [(SA008A)]
AT27HC642	AT27HC642@PLCC28 [(SA008A)]
AT27HC642R	AT27HC642R@PLCC28 [(SA008A)]
AT27HC64L	AT27HC64L@PLCC32 [(SA015A1T)]
AT27LV010	AT27LV010@PLCC32 [(SA015A1T)]
AT27LV010@TSOP32 [(SA620)]	AT27LV010A
AT27LV010A@PLCC32 [(SA015A1T)]	AT27LV010A@TSOP32 [(SA620)]
AT27LV020A	AT27LV020A@PLCC32 [(SA015A1T)]
AT27LV020A@TSOP32 [(SA620)]	AT27LV040
AT27LV040@PLCC32 [(SA015A1T)]	AT27LV040@TSOP32 [(SA620)]
AT27LV040A	AT27LV040A@PLCC32 [(SA015A1T)]
AT27LV040A@TSOP32 [(SA620)]	AT27LV1024
AT27LV1024@PLCC44 [(SA244)]	AT27LV256A
AT27LV256A@PLCC32 [(SA015A1T)]	AT27LV256A@SOIC28 [(SA630)]
AT27LV256A@TSOP28 [(SA430T)]	AT27LV256R
AT27LV256R@PLCC32 [(SA015A1T)]	AT27LV256R@SOIC28 [(SA630)]
AT27LV256R@TSOP28 [(SA430T)]	AT27LV4096
AT27LV4096@PLCC44 [(SA244)]	AT27LV512A
AT27LV512A@PLCC32 [(SA015A1T)]	AT27LV512A@SOIC28 [(SA630)]
AT27LV512A@TSOP28 [(SA430T)]	AT27LV512R
AT27LV512R@PLCC32 [(SA015A1T)]	AT27LV512R@TSOP28 [(SA430T)]
AT27LV520@SOIC20 [(SA404)]	AT27LV520@TSOP28 [(SA430T)]
AT27LV520@TSSOP20 [(SA026)]	AT27LV800
AT27LV800@PSOP44 [(SA638)]	AT28BV16
AT28BV16@PLCC32 [(SA015A1T)]	AT28BV16@SOIC24 [(SA404)]
AT28BV16@TSOP28 [(SA430T)]	AT28BV256
AT28BV256@PLCC32 [(SA015A1T)]	AT28BV256@SOIC28 [(SA404)]
AT28BV256@TSOP28 [(SA430T)]	AT28BV64
AT28BV64@PLCC32 [(SA015A1T)]	AT28BV64@SOIC28 [(SA404)]
AT28BV64@TSOP28 [(SA430T)]	AT28BV64B
AT28BV64B@PLCC32 [(SA015A1T)]	AT28BV64B@SOIC28 [(SA404)]
AT28BV64B@TSOP28 [(SA430T)]	AT28C010
AT28C010@PLCC32 [(SA015A1T)]	AT28C010@PLCC44 [(SA244)]
AT28C010@TSOP32 [(SA410T)]	AT28C010E
AT28C010E@PLCC32 [(SA015A1T)]	AT28C010E@PLCC44 [(SA244)]
AT28C010E@TSOP32 [(SA410T)]	AT28C04
AT28C04@PLCC32 [(SA015A1T)]	AT28C040
AT28C040@PLCC32 [(SA015A1T)]	AT28C04E
AT28C04E@PLCC32 [(SA015A1T)]	AT28C04F
AT28C04F@PLCC32 [(SA015A1T)]	AT28C16
AT28C16@PLCC32 [(SA015A1T)]	AT28C16@SOIC24 [(SA404)]
AT28C16@TSOP28 [(SA430T)]	AT28C16E
AT28C16E@PLCC32 [(SA015A1T)]	AT28C16F
AT28C16F@PLCC32 [(SA015A1T)]	AT28C17
AT28C17@PLCC32 [(SA015A1T)]	AT28C17@SOIC28 [(SA404)]
AT28C17E	AT28C17E@PLCC32 [(SA015A1T)]
AT28C17F	AT28C17F@PLCC32 [(SA015A1T)]
AT28C256	AT28C256@PLCC32 [(SA015A1T)]
AT28C256@SOIC28 [(SA404)]	AT28C256@TSOP28 [(SA430T)]
AT28C256E	AT28C256E@PLCC32 [(SA015A1T)]
AT28C256E@SOIC28 [(SA404)]	AT28C256E@TSOP28 [(SA430T)]
AT28C256F	AT28C256F@PLCC32 [(SA015A1T)]
AT28C64	AT28C64@PLCC32 [(SA015A1T)]
AT28C64@SOIC28 [(SA404)]	AT28C64@TSOP28 [(SA430T)]
AT28C64B	AT28C64B@PLCC32 [(SA015A1T)]
AT28C64B@SOIC28 [(SA404)]	AT28C64B@TSOP28 [(SA430T)]
AT28C64E	AT28C64E@PLCC32 [(SA015A1T)]
AT28C64E@TSOP28 [(SA430T)]	AT28C64F
AT28C64F@PLCC32 [(SA015A1T)]	AT28C64F@TSOP28 [(SA430T)]
AT28C64X	AT28C64X@PLCC32 [(SA015A1T)]
AT28C64X@SOIC28 [(SA404)]	AT28C64X@TSOP28 [(SA430T)]
AT28HC04	AT28HC16
AT28HC16L	AT28HC191
AT28HC191L	AT28HC256
AT28HC256@PLCC32 [(SA015A1T)]	AT28HC256@TSOP28 [(SA430T)]
AT28HC256E	AT28HC256E@PLCC32 [(SA015A1T)]
AT28HC256F	AT28HC256F@PLCC32 [(SA015A1T)]
AT28HC256L	AT28HC256L@PLCC32 [(SA015A1T)]
AT28HC256LE	AT28HC256LE@PLCC32 [(SA015A1T)]
AT28HC291	AT28HC291@PLCC28 [(SA008A)]
AT28HC291L	AT28HC291L@PLCC28 [(SA008A)]
AT28HC64	AT28HC64@PLCC32 [(SA015A1T)]
AT28HC64@TSOP28 [(SA430T)]	AT28HC64B
AT28HC64B@PLCC32 [(SA015A1T)]	AT28HC64B@SOIC28 [(SA404)]
AT28HC64B@TSOP28 [(SA430T)]	AT28HC64BF
AT28HC64BF@PLCC32 [(SA015A1T)]	AT28HC64BF@SOIC28 [(SA404)]
AT28HC64BF@TSOP28 [(SA430T)]	AT28HC64L
AT28HC64L@PLCC32 [(SA015A1T)]	AT28HC64L@TSOP28 [(SA430T)]



AT28LV010	AT28LV010@PLCC32 [(SA015A1T)]
AT28LV010@TSOP32 [(SA410T)]	AT28LV256
AT28LV256@PLCC32 [(SA015A1T)]	AT28LV256@TSOP28 [(SA430T)]
AT28LV64	AT28LV64@PLCC32 [(SA015A1T)]
AT28LV64B	AT28LV64B@PLCC32 [(SA015A1T)]
AT28LV64B@SOIC28 [(SA404)]	AT28LV64B@TSOP28 [(SA430T)]
AT28MC010	AT28MC010@PLCC32 [(SA015A1T)]
AT28MC010@PLCC44 [(SA244)]	AT28MC010@TSOP32 [(SA410T)]
AT28MC020	AT28MC020@PLCC32 [(SA015A1T)]
AT28MC020@PLCC44 [(SA244)]	AT28MC020@TSOP32 [(SA410T)]
AT28MC040	AT28MC040@PLCC32 [(SA015A1T)]
AT28MC040@PLCC44 [(SA244)]	AT28MC040@TSOP32 [(SA410T)]
AT28PC64	AT28PC64@PLCC32 [(SA015A1T)]
AT28PC64@TSOP28 [(SA430T)]	AT28PC64E
AT28PC64E@PLCC32 [(SA015A1T)]	AT28PC64E@TSOP28 [(SA430T)]
AT29BV010A@PLCC32 [(SA015A1T)]	AT29BV010A@TSOP32 [(SA410T)]
AT29BV020@PLCC32 [(SA015A1T)]	AT29BV020@TSOP32 [(SA410T)]
AT29BV040A@TSOP32 [(SA410T)]	AT29C010
AT29C010@PLCC32 [(SA015A1T)]	AT29C010@TSOP32 [(SA410T)]
AT29C010A	AT29C010A@PLCC32 [(SA015A1T)]
AT29C010A@TSOP32 [(SA410T)]	AT29C020
AT29C020@PLCC32 [(SA015A1T)]	AT29C020@TSOP32 [(SA410T)]
AT29C040	AT29C040@PLCC32 [(SA015A1T)]
AT29C040@TSOP32 [(SA410T)]	AT29C040A
AT29C040A@PLCC32 [(SA015A1T)]	AT29C040A@TSOP32 [(SA410T)]
AT29C1024@PLCC44 [(SA244)]	AT29C1024@TSOP48 [(SA247-B005)]
AT29C256	AT29C256@PLCC32 [(SA015A1T)]
AT29C256@TSOP28 [(SA430T)]	AT29C257
AT29C257@PLCC32 [(SA015A1T)]	AT29C512
AT29C512@PLCC32 [(SA015A1T)]	AT29C512@TSOP32 [(SA410T)]
AT29LV010	AT29LV010@PLCC32 [(SA015A1T)]
AT29LV010@TSOP32 [(SA410T)]	AT29LV010A@PLCC32 [(SA015A1T)]
AT29LV010A@TSOP32 [(SA410T)]	AT29LV020
AT29LV020@PLCC32 [(SA015A1T)]	AT29LV020@TSOP32 [(SA410T)]
AT29LV040@TSOP32 [(SA410T)]	AT29LV040A
AT29LV040A@PLCC32 [(SA015A1T)]	AT29LV040A@TSOP32 [(SA410T)]
AT29LV1024@PLCC44 [(SA244)]	AT29LV1024@TSOP48 [(SA247-B005)]
AT29LV256	AT29LV256@PLCC32 [(SA015A1T)]
AT29LV256@TSOP28 [(SA430T)]	AT29LV512
AT29LV512@PLCC32 [(SA015A1T)]	AT29LV512@TSOP32 [(SA410T)]
AT32C16	AT32C16@PLCC44 [(SA244)]
AT34C02	AT34C02@SOIC8 [(SA602A)]
AT34C02@TSSOP8 [(SA026)]	AT34C02B
AT34C02B@SOIC8 [(SA602A)]	AT34C02B@TSSOP8 [(SA026)]
AT34C02C	AT34C02C@dBG8 [(BBB)]
AT34C02C@MAP8 [(SA724)]	AT34C02C@SOIC8 [(SA602A)]
AT34C02C@TSSOP8 [(SA026)]	
AT45BCM021D(page256)@SOIC8 [(SA605A)]	
AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]	
AT45BCM021D(page264)@SOIC8 [(SA605A)]	
AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]	
AT45D011@PLCC32 [(SA015A1T)]	AT45D011@SOIC8 [(SA605A)]
AT45D011@TSSOP14 [(SA026)]	AT45D021@PLCC32 [(SA015A1T)]
AT45D021@SOIC28 [(SA630)]	AT45D021@TSOP28 [(SA430T)]
AT45D041@PLCC32 [(SA015A1T)]	AT45D041@SOIC28 [(SA630)]
AT45D041@TSOP28 [(SA430T)]	AT45D081@SOIC28 [(SA630)]
AT45D081@TSOP32 [(SA410T)]	AT45D161@PLCC32 [(SA015A1T)]
AT45D161@SOIC28 [(SA630)]	AT45D161@TSOP28 [(SA430T)]
AT45DB011@PLCC32 [(SA015A1T)]	AT45DB011@SOIC8 [(SA605A)]
AT45DB011@TSSOP14 [(SA026)]	AT45DB011B@PLCC32 [(SA015A1T)]
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]	
AT45DB011B@SOIC8 [(SA605A)]	
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]	
AT45DB011B@TSSOP14 [(SA026)]	
AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]	
AT45DB011D(page264)@QFN8 [(SA683)]	
AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]	
AT45DB011D(page264)@SOIC8 [(SA023A)]	
AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]	
AT45DB021@PLCC32 [(SA015A1T)]	AT45DB021@SOIC28 [(SA630)]
AT45DB021@TSOP28 [(SA430T)]	AT45DB021A@PLCC32 [(SA015A1T)]
AT45DB021A@PLCC32(ISP) [ISP-HEADER01]	
AT45DB021A@SOIC28 [(SA630)]	
AT45DB021A@SOIC28(ISP) [ISP-HEADER01]	
AT45DB021A@TSOP28 [(SA430T)]	
AT45DB021A@TSOP28(ISP) [ISP-HEADER01]	
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]	
AT45DB021B@CBGA9(ISP) [ISP-HEADER01]	
AT45DB021B@SOIC28 [(SA630)]	
AT45DB021B@SOIC28(ISP) [ISP-HEADER01]	
AT45DB021B@SOIC8 [(SA023A)]	

```

AT45DB021B@SOIC8 (ISP) [ISP-HEADER01]
AT45DB021B@TSOP28 [(SA430T)]
AT45DB021B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB021D6(page264)@CASON8 [(SA683)]
AT45DB021D6(page264)@CASON8 (ISP) [ISP-HEADER01]
AT45DB021D6(page264)@SOIC8 [(SA023A)]
AT45DB021D6(page264)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28 [(SA630)]
AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32 [(SA015A1T)]
AT45DB041A@PLCC32 (ISP) [ISP-HEADER01]
AT45DB041A@SOIC28 [(SA630)]
AT45DB041A@SOIC28 (ISP) [ISP-HEADER01]
AT45DB041A@TSOP28 [(SA430T)]
AT45DB041A@TSOP28 (ISP) [ISP-HEADER01]
AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8 (ISP) [(SA684)]
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]
AT45DB041B@CBGA14 (ISP) [ISP-HEADER01]
AT45DB041B@SOIC28 [(SA630)]
AT45DB041B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB041B@SOIC8 [(SA605A)]
AT45DB041B@SOIC8 (ISP) [ISP-HEADER01]
AT45DB041B@TSOP28 [(SA430T)]
AT45DB041B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB041D(page256)@QFN8 [(SA683)]
AT45DB041D(page256)@QFN8 (ISP) [ISP-HEADER01]
AT45DB041D(page256)@SOIC8 [(SA605A)]
AT45DB041D(page256)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB041D(page264)@QFN8 [(SA683)]
AT45DB041D(page264)@QFN8 (ISP) [ISP-HEADER01]
AT45DB041D(page264)@SOIC8 [(SA605A)]
AT45DB041D(page264)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32 [(SA410T)]
AT45DB081A@PLCC32 [(SA015A1T)]
AT45DB081A@PLCC32 (ISP) [ISP-HEADER01]
AT45DB081A@SOIC28 [(SA630)]
AT45DB081A@SOIC28 (ISP) [ISP-HEADER01]
AT45DB081A@TSOP28 [(SA430T)]
AT45DB081A@TSOP28 (ISP) [ISP-HEADER01]
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8 (ISP) [(SA684)]
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]
AT45DB081B@CBGA14 (ISP) [ISP-HEADER01]
AT45DB081B@SOIC28 [(SA630)]
AT45DB081B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB081B@SOIC8 [(SA605A)]
AT45DB081B@SOIC8 (ISP) [ISP-HEADER01]
AT45DB081B@TSOP28 [(SA430T)]
AT45DB081B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB081D(page256)@MLF8 [(SA683)]
AT45DB081D(page256)@QFN8 (ISP) [ISP-HEADER01]
AT45DB081D(page256)@SOIC8 [(SA023A)]
AT45DB081D(page256)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB081D(page264)@MLF8 [(SA683)]
AT45DB081D(page264)@QFN8 (ISP) [ISP-HEADER01]
AT45DB081D(page264)@SOIC8 [(SA023A)]
AT45DB081D(page264)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28 [(SA630)]
AT45DB161@TSOP28 [(SA430T)]
AT45DB161B@CASON8 (ISP) [ISP-HEADER01]
AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28 [(SA630)]
AT45DB161B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB161B@TSOP28 [(SA430T)]
AT45DB161B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB161D(page512)@QFN8 [(SA683)]
AT45DB161D(page512)@QFN8 (ISP) [ISP-HEADER01]
AT45DB161D(page512)@SOIC8 [(SA605A)]
AT45DB161D(page512)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB161D(page512)@TSOP28 [(SA430T)]
AT45DB161D(page512)@TSOP28 (ISP) [ISP-HEADER01]
AT45DB161D(page528)@QFN8 [(SA683)]
AT45DB161D(page528)@QFN8 (ISP) [ISP-HEADER01]
AT45DB161D(page528)@SOIC8 [(SA605A)]
AT45DB161D(page528)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB161D(page528)@TSOP28 [(SA430T)]
AT45DB161D(page528)@TSOP28 (ISP) [ISP-HEADER01]
AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28 [(SA630)]
AT45DB321B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB321B@TSOP32 [(SA410T)]
AT45DB321B@TSOP32 (ISP) [ISP-HEADER01]
AT45DB321C@CASON8 [(SA684)]
AT45DB321C@CASON8 (ISP) [ISP-HEADER01]
AT45DB321C@SOIC28 [(SA630)]

```

AT45DB321C@SOIC28 (ISP) [ISP-HEADER01]  
 AT45DB321C@TSOP28 [(SA430T)]  
 AT45DB321C@TSOP28 (ISP) [ISP-HEADER01]  
 AT45DB321D(page512)@QFN8 [(SA683)]  
 AT45DB321D(page512)@QFN8 (ISP) [ISP-HEADER01]  
 AT45DB321D(page512)@SOIC8 [(SA023A)]  
 AT45DB321D(page512)@SOIC8 (ISP) [ISP-HEADER01]  
 AT45DB321D(page512)@TSOP28 [(SA430T)]  
 AT45DB321D(page512)@TSOP28 (ISP) [ISP-HEADER01]  
 AT45DB321D(page528)@QFN8 [(SA683)]  
 AT45DB321D(page528)@QFN8 (ISP) [ISP-HEADER01]  
 AT45DB321D(page528)@SOIC8 [(SA023A)]  
 AT45DB321D(page528)@SOIC8 (ISP) [ISP-HEADER01]  
 AT45DB321D(page528)@TSOP28 [(SA430T)]  
 AT45DB321D(page528)@TSOP28 (ISP) [ISP-HEADER01]  
 AT45DB642@TSOP40 [(SA409T)]  
 AT45DB642@TSOP40 (ISP) [ISP-HEADER01]  
 AT45DB642D(page1024)@CAS0N8 [(SA684)]  
 AT45DB642D(page1024)@CAS0N8 (ISP) [(ISP-HEADER01)]  
 AT45DB642D(page1024)@TSOP28 [(SA430)]  
 AT45DB642D(page1024)@TSOP28 (ISP) [(ISP-HEADER01)]  
 AT45DB642D(page1056)@CAS0N8 [(SA684)]  
 AT45DB642D(page1056)@CAS0N8 (ISP) [(ISP-HEADER01)]  
 AT45DB642D(page1056)@TSOP28 [(SA430)]  
 AT45DB642D(page1056)@TSOP28 (ISP) [(ISP-HEADER01)]  
 AT45DCB002 [(CARD005-B005)] AT45DCB002 (ISP) [ISP-HEADER01]  
 AT45DCB004 [(CARD005-B005)] AT45DCB004 (ISP) [ISP-HEADER01]  
 AT45DCB004C [(CARD005-B005)] AT45DCB004C (ISP) [ISP-HEADER01]  
 AT45DCB008 [(CARD005-B005)] AT45DCB008 (ISP) [ISP-HEADER01]  
 AT45DCB008D4(page1024) [(CARD005-B005)]  
 AT45DCB008D4(page1024) (ISP) [(ISP-HEADER01)]  
 AT45DCB008D6(page1056) [(CARD005-B005)]  
 AT45DCB008D6(page1056) (ISP) [(ISP-HEADER01)]  
 AT49BV001 AT49BV001@PLCC32 [(SA015A1T)]  
 AT49BV001@TSOP32 [(SA410T)] AT49BV001@VSOP32 [(SA620)]  
 AT49BV001A AT49BV001A@PLCC32 [(SA015A1T)]  
 AT49BV001A@TSOP32 [(SA410T)] AT49BV001A@VSOP32 [(SA620)]  
 AT49BV001AN AT49BV001AN@PLCC32 [(SA015A1T)]  
 AT49BV001AN@TSOP32 [(SA410T)] AT49BV001AN@VSOP32 [(SA620)]  
 AT49BV001ANT AT49BV001ANT@PLCC32 [(SA015A1T)]  
 AT49BV001ANT@TSOP32 [(SA410T)] AT49BV001ANT@VSOP32 [(SA620)]  
 AT49BV001AT AT49BV001AT@PLCC32 [(SA015A1T)]  
 AT49BV001AT@TSOP32 [(SA410T)] AT49BV001AT@VSOP32 [(SA620)]  
 AT49BV001N AT49BV001N@PLCC32 [(SA015A1T)]  
 AT49BV001N@TSOP32 [(SA410T)] AT49BV001N@VSOP32 [(SA620)]  
 AT49BV001NT AT49BV001NT@PLCC32 [(SA015A1T)]  
 AT49BV001NT@TSOP32 [(SA410T)] AT49BV001NT@VSOP32 [(SA620)]  
 AT49BV001T AT49BV001T@PLCC32 [(SA015A1T)]  
 AT49BV001T@TSOP32 [(SA410T)] AT49BV001T@VSOP32 [(SA620)]  
 AT49BV002 AT49BV002@PLCC32 [(SA015A1T)]  
 AT49BV002@TSOP32 [(SA410T)] AT49BV002@VSOP32 [(SA620)]  
 AT49BV002A AT49BV002A@PLCC32 [(SA015A1T)]  
 AT49BV002A@TSOP32 [(SA410T)] AT49BV002A@VSOP32 [(SA620)]  
 AT49BV002AN AT49BV002AN@PLCC32 [(SA015A1T)]  
 AT49BV002AN@TSOP32 [(SA410T)] AT49BV002AN@VSOP32 [(SA620)]  
 AT49BV002ANT AT49BV002ANT@PLCC32 [(SA015A1T)]  
 AT49BV002ANT@TSOP32 [(SA410T)] AT49BV002ANT@VSOP32 [(SA620)]  
 AT49BV002AT AT49BV002AT@PLCC32 [(SA015A1T)]  
 AT49BV002AT@TSOP32 [(SA410T)] AT49BV002AT@VSOP32 [(SA620)]  
 AT49BV002N AT49BV002N@PLCC32 [(SA015A1T)]  
 AT49BV002N@TSOP32 [(SA410T)] AT49BV002N@VSOP32 [(SA620)]  
 AT49BV002NT AT49BV002NT@PLCC32 [(SA015A1T)]  
 AT49BV002NT@TSOP32 [(SA410T)] AT49BV002NT@VSOP32 [(SA620)]  
 AT49BV002T AT49BV002T@PLCC32 [(SA015A1T)]  
 AT49BV002T@TSOP32 [(SA410T)] AT49BV002T@VSOP32 [(SA620)]  
 AT49BV008@TSOP40 [(SA409T)] AT49BV008A@TSOP40 [(SA409T)]  
 AT49BV008A@uBGA48 [(SA634)] AT49BV008AT@TSOP40 [(SA409T)]  
 AT49BV008AT@uBGA48 [(SA634)] AT49BV010  
 AT49BV010@PLCC32 [(SA015A1T)] AT49BV010@TSOP32 [(SA410T)]  
 AT49BV020 AT49BV020@PLCC32 [(SA015A1T)]  
 AT49BV020@TSOP32 [(SA410T)] AT49BV040  
 AT49BV040@PLCC32 [(SA015A1T)] AT49BV040@TSOP32 [(SA410T)]  
 AT49BV040A@PLCC32 [(SA015A1T)] AT49BV040A@TSOP32 [(SA410T)]  
 AT49BV040A@VSOP32 [(SA620)]  
 AT49BV040B@PLCC32 [(SA015A1T-B001)]  
 AT49BV040B@TSOP32 [(SA410T-B003)]  
 AT49BV040B@VSOP32 [(SA620-B005)] AT49BV040T  
 AT49BV040T@PLCC32 [(SA015A1T)] AT49BV040T@TSOP32 [(SA410T)]  
 AT49BV080@PSOP44 [(SA638)] AT49BV080@TSOP40 [(SA409T)]  
 AT49BV080T@PSOP44 [(SA638)] AT49BV080T@TSOP40 [(SA409T)]  
 AT49BV1024A@TSOP40 [(SA623)] AT49BV160@TSOP48 [(SA247-B005)]

AT49BV160@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV1604@TSOP48 [(SA247-B005)]  
 AT49BV1604@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV1604A@TSOP48 [(SA247-B005)]  
 AT49BV1604A@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV1604AT@TSOP48 [(SA247-B005)]  
 AT49BV1604AT@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV1604T@TSOP48 [(SA247-B005)]  
 AT49BV1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV160C@TSOP48 [(SA247-B005)]  
 AT49BV160C@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV160CT@TSOP48 [(SA247-B005)]  
 AT49BV160CT@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV160D@TSOP48 [(SA247-B005)]  
 AT49BV160DT@TSOP48 [(SA247-B005)]  
 AT49BV160S@FBGA64 [(SA705A-B147A-W064F001Y)]  
 AT49BV160ST@FBGA64 [(SA705A-B147A-W064F001Y)]  
 AT49BV160T@TSOP48 [(SA247-B005)]  
 AT49BV160T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV161@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV161@TSOP48 [(SA247-B005)]  
 AT49BV1614@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV1614@TSOP48 [(SA247-B005)]  
 AT49BV1614A@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV1614A@TSOP48 [(SA247-B005)]  
 AT49BV1614AT@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV1614AT@TSOP48 [(SA247-B005)]  
 AT49BV1614T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV1614T@TSOP48 [(SA247-B005)]  
 AT49BV1618@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV1618@TSOP48 [(SA247-B005)]  
 AT49BV1618T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV1618T@TSOP48 [(SA247-B005)]  
 AT49BV161T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV161T@TSOP48 [(SA247-B005)]  
 AT49BV162A@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV162A@TSOP48 [(SA247-B005)]  
 AT49BV162AT@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV162AT@TSOP48 [(SA247-B005)]  
 AT49BV163A@CBGA48 [(SA642G-B026A-T048F001Y)]  
 AT49BV163A@TSOP48 [(SA247-B005)]  
 AT49BV163AT@CBGA48 [(SA642G-B026A-T048F001Y)]  
 AT49BV163AT@TSOP48 [(SA247-B005)]  
 AT49BV163D@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AT49BV163D@TSOP48 [(SA247-B005)]  
 AT49BV163DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AT49BV163DT@TSOP48 [(SA247-B005)]  
 AT49BV2048@PSOP44 [(SA638)] AT49BV2048@TSOP48 [(SA247-B005)]  
 AT49BV2048A@PSOP44 [(SA638)]  
 AT49BV2048A@TSOP48 [(SA247-B005)]  
 AT49BV2048B@TSOP48 [(SA247-B005)]  
 AT49BV320@TSOP48 [(SA247-B005)]  
 AT49BV320@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV320C@TSOP48 [(SA247-B005)]  
 AT49BV320C@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV320CT@TSOP48 [(SA247-B005)]  
 AT49BV320CT@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV320D@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 AT49BV320D@TSOP48 [(SA247-B005)]  
 AT49BV320DT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 AT49BV320DT@TSOP48 [(SA247-B005)]  
 AT49BV320S@FBGA64 [(SA705A-B147A-W064F001Y)]  
 AT49BV320ST@FBGA64 [(SA705A-B147A-W064F001Y)]  
 AT49BV320T@TSOP48 [(SA247-B005)]  
 AT49BV320T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49BV321@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV321@TSOP48 [(SA247-B005)]  
 AT49BV3218@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV3218@TSOP48 [(SA247-B005)]  
 AT49BV3218T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV3218T@TSOP48 [(SA247-B005)]  
 AT49BV321T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV321T@TSOP48 [(SA247-B005)]  
 AT49BV322A@FBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV322A@TSOP48 [(SA247-B005)]  
 AT49BV322AT@FBGA48 [(SA642F-B026A-T064F001)]  
 AT49BV322AT@TSOP48 [(SA247-B005)]  
 AT49BV322D@FBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49BV322D@TSOP48 [(SA247-B005)]  
 AT49BV322DT@FBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49BV322DT@TSOP48 [(SA247-B005)]

```

AT49BV4096@PSOP44 [(SA638)] AT49BV4096@TSOP48 [(SA247-B005)]
AT49BV4096A@PSOP44 [(SA638)]
AT49BV4096A@TSOP48 [(SA247-B005)]
AT49BV4096A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV512 AT49BV512@PLCC32 [(SA015A1T)]
AT49BV512@TSOP32 [(SA410T)] AT49BV512@VSOP32 [(SA620)]
AT49BV640D@FBGA48 [(SA634A-B005A-Y048F001Y)]
AT49BV640D@TSOP56 [(SA628-B131)]
AT49BV640DT@FBGA48 [(SA634A-B005A-Y048F001Y)]
AT49BV640DT@TSOP56 [(SA628-B131)]
AT49BV640S@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV640ST@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV6416@TSOP48 [(SA247-B005)]
AT49BV6416T@TSOP48 [(SA247-B005)]
AT49BV642D@TSOP48 [(SA247-B005)]
AT49BV642DT@TSOP48 [(SA247-B005)]
AT49BV8004@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8004@TSOP48 [(SA247-B005)]
AT49BV8004T@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8004T@TSOP48 [(SA247-B005)]
AT49BV8011@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8011@TSOP48 [(SA247-B005)]
AT49BV8011T@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8011T@TSOP48 [(SA247-B005)]
AT49BV802A@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV802A@TSOP48 [(SA247-B005)]
AT49BV802AT@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV802AT@TSOP48 [(SA247-B005)]
AT49BV802D@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV802D@TSOP48 [(SA247)]
AT49BV802DT@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV802DT@TSOP48 [(SA247)] AT49BV8192@PSOP44 [(SA638)]
AT49BV8192@TSOP48 [(SA247-B005)]
AT49BV8192A@TSOP48 [(SA247-B005)]
AT49BV8192A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV8192AT@TSOP48 [(SA247-B005)]
AT49BV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV8192T@PSOP44 [(SA638)]
AT49BV8192T@TSOP48 [(SA247-B005)]
AT49F001 AT49F001@PLCC32 [(SA015A1T)]
AT49F001@TSOP32 [(SA410T)] AT49F001@VSOP32 [(SA620)]
AT49F001A AT49F001A@PLCC32 [(SA015A1T)]
AT49F001A@TSOP32 [(SA410T)] AT49F001A@VSOP32 [(SA620)]
AT49F001AN AT49F001AN@PLCC32 [(SA015A1T)]
AT49F001AN@TSOP32 [(SA410T)] AT49F001AN@VSOP32 [(SA620)]
AT49F001ANT AT49F001ANT@PLCC32 [(SA015A1T)]
AT49F001ANT@TSOP32 [(SA410T)] AT49F001ANT@VSOP32 [(SA620)]
AT49F001AT AT49F001AT@PLCC32 [(SA015A1T)]
AT49F001AT@TSOP32 [(SA410T)] AT49F001AT@VSOP32 [(SA620)]
AT49F001N AT49F001N@PLCC32 [(SA015A1T)]
AT49F001N@TSOP32 [(SA410T)] AT49F001N@VSOP32 [(SA620)]
AT49F001NT AT49F001NT@PLCC32 [(SA015A1T)]
AT49F001NT@TSOP32 [(SA410T)] AT49F001NT@VSOP32 [(SA620)]
AT49F001T AT49F001T@PLCC32 [(SA015A1T)]
AT49F001T@TSOP32 [(SA410T)] AT49F001T@VSOP32 [(SA620)]
AT49F002 AT49F002@PLCC32 [(SA015A1T)]
AT49F002@TSOP32 [(SA410T)] AT49F002@VSOP32 [(SA620)]
AT49F002A AT49F002A@PLCC32 [(SA015A1T)]
AT49F002A@TSOP32 [(SA410T)] AT49F002A@VSOP32 [(SA620)]
AT49F002AN AT49F002AN@PLCC32 [(SA015A1T)]
AT49F002AN@TSOP32 [(SA410T)] AT49F002AN@VSOP32 [(SA620)]
AT49F002ANT AT49F002ANT@PLCC32 [(SA015A1T)]
AT49F002ANT@TSOP32 [(SA410T)] AT49F002ANT@VSOP32 [(SA620)]
AT49F002AT AT49F002AT@PLCC32 [(SA015A1T)]
AT49F002AT@TSOP32 [(SA410T)] AT49F002AT@VSOP32 [(SA620)]
AT49F002N AT49F002N@PLCC32 [(SA015A1T)]
AT49F002N@TSOP32 [(SA410T)] AT49F002N@VSOP32 [(SA620)]
AT49F002NT AT49F002NT@PLCC32 [(SA015A1T)]
AT49F002NT@TSOP32 [(SA410T)] AT49F002NT@VSOP32 [(SA620)]
AT49F002T AT49F002T@PLCC32 [(SA015A1T)]
AT49F002T@TSOP32 [(SA410T)] AT49F002T@VSOP32 [(SA620)]
AT49F008@TSOP40 [(SA409T)] AT49F008A@TSOP40 [(SA409T)]
AT49F008AT@TSOP40 [(SA409T)]
AT49F010@PLCC32 [(SA015A1T)] AT49F010
AT49F020 AT49F010@TSOP32 [(SA410T)]
AT49F020@TSOP32 [(SA410T)] AT49F020@PLCC32 [(SA015A1T)]
AT49F040@PLCC32 [(SA015A1T)] AT49F040
AT49F040A AT49F040@TSOP32 [(SA410T)]
AT49F040A@TSOP32 [(SA410T)] AT49F040A@PLCC32 [(SA015A1T)]
AT49F080@PSOP44 [(SA638)]
AT49F080@TSOP40 [(SA409T)] AT49F080T@PSOP44 [(SA638)]
AT49F080T@TSOP40 [(SA409T)] AT49F1024@TSOP40 [(SA623)]

```

AT49F1024A@TSOP40 [(SA623)] AT49F1025@PLCC44 [(SA244)]  
 AT49F1604@TSOP48 [(SA247-B005)]  
 AT49F1604@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49F1604T@TSOP48 [(SA247-B005)]  
 AT49F1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49F1614@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49F1614@TSOP48 [(SA247-B005)]  
 AT49F1614T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49F1614T@TSOP48 [(SA247-B005)] AT49F2048@PSOP44 [(SA638)]  
 AT49F2048@TSOP48 [(SA247-B005)] AT49F2048A@PSOP44 [(SA638)]  
 AT49F2048A@TSOP48 [(SA247-B005)] AT49F4096@PSOP44 [(SA638)]  
 AT49F4096@TSOP48 [(SA247-B005)]  
 AT49F4096A@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49F4096A@PSOP44 [(SA638)] AT49F4096A@TSOP48 [(SA247-B005)]  
 AT49F4096A@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49F512 AT49F512@PLCC32 [(SA015A1T)]  
 AT49F512@TSOP32 [(SA410T)] AT49F512@VSOP32 [(SA620)]  
 AT49F516@PLCC44 [(SA244)] AT49F516@TSOP40 [(SA623)]  
 AT49F8004@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8004@TSOP48 [(SA247-B005)]  
 AT49F8004T@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8004T@TSOP48 [(SA247-B005)]  
 AT49F8011@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8011@TSOP48 [(SA247-B005)]  
 AT49F8011T@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49F8011T@TSOP48 [(SA247-B005)] AT49F8192@PSOP44 [(SA638)]  
 AT49F8192@TSOP48 [(SA247-B005)] AT49F8192A@PSOP44 [(SA638)]  
 AT49F8192A@TSOP48 [(SA247-B005)] AT49F8192AT@PSOP44 [(SA638)]  
 AT49F8192AT@TSOP48 [(SA247-B005)]  
 AT49F8192T@PSOP44 [(SA638)] AT49F8192T@TSOP48 [(SA247-B005)]  
 AT49HBV010 AT49HBV010@PLCC32 [(SA015A1T)]  
 AT49HF010 AT49HF010  
 AT49HF010@PLCC32 [(SA015A1T)] AT49HF010@TSOP32 [(SA410T)]  
 AT49HLV010 AT49HLV010@PLCC32 [(SA015A1T)]  
 AT49HLV010@TSOP32 [(SA410T)]  
 AT49LH002@TSOP40 [(SA409T)] AT49LH002@PLCC32 [(SA015A1T)]  
 AT49LH004@TSOP40 [(SA409T)] AT49LH004@PLCC32 [(SA015A1T)]  
 AT49LH004@uBGA48 [(SA409T)] AT49LH00B4@PLCC32 [(SA015A1T)]  
 AT49LL020@TSOP40 [(SA409T)] AT49LL020@PLCC32 [(SA015A1T)]  
 AT49LL040@TSOP40 [(SA409T)] AT49LL040@PLCC32 [(SA015A1T)]  
 AT49LL080@TSOP40 [(SA409T)] AT49LL080@PLCC32 [(SA015A1T)]  
 AT49LV001@PLCC32 [(SA015A1T)] AT49LV001  
 AT49LV001@VSOP32 [(SA620)] AT49LV001@TSOP32 [(SA410T)]  
 AT49LV001N@PLCC32 [(SA015A1T)] AT49LV001N  
 AT49LV001N@VSOP32 [(SA620)] AT49LV001N@TSOP32 [(SA410T)]  
 AT49LV001NT@PLCC32 [(SA015A1T)] AT49LV001NT  
 AT49LV001NT@VSOP32 [(SA620)] AT49LV001NT@TSOP32 [(SA410T)]  
 AT49LV001T@PLCC32 [(SA015A1T)] AT49LV001T  
 AT49LV001T@VSOP32 [(SA620)] AT49LV001T@TSOP32 [(SA410T)]  
 AT49LV002@PLCC32 [(SA015A1T)] AT49LV002  
 AT49LV002@VSOP32 [(SA620)] AT49LV002@TSOP32 [(SA410T)]  
 AT49LV002N@PLCC32 [(SA015A1T)] AT49LV002N  
 AT49LV002N@VSOP32 [(SA620)] AT49LV002N@TSOP32 [(SA410T)]  
 AT49LV002NT@PLCC32 [(SA015A1T)] AT49LV002NT  
 AT49LV002NT@VSOP32 [(SA620)] AT49LV002NT@TSOP32 [(SA410T)]  
 AT49LV002T@PLCC32 [(SA015A1T)] AT49LV002T  
 AT49LV002T@VSOP32 [(SA620)] AT49LV002T@TSOP32 [(SA410T)]  
 AT49LV008A@TSOP40 [(SA409T)] AT49LV008@TSOP40 [(SA409T)]  
 AT49LV008A@uBGA48 [(SA634)] AT49LV008A@uBGA48 [(SA634)]  
 AT49LV008AT@TSOP40 [(SA409T)] AT49LV008AT@uBGA48 [(SA634)]  
 AT49LV010 AT49LV010@PLCC32 [(SA015A1T)]  
 AT49LV010@TSOP32 [(SA410T)] AT49LV020  
 AT49LV020@PLCC32 [(SA015A1T)] AT49LV020@TSOP32 [(SA410T)]  
 AT49LV040 AT49LV040@PLCC32 [(SA015A1T)]  
 AT49LV040@TSOP32 [(SA410T)] AT49LV040T  
 AT49LV040T@PLCC32 [(SA015A1T)] AT49LV040T@TSOP32 [(SA410T)]  
 AT49LV080@PSOP44 [(SA638)] AT49LV080@TSOP40 [(SA409T)]  
 AT49LV080T@PSOP44 [(SA638)] AT49LV080T@TSOP40 [(SA409T)]  
 AT49LV1024@TSOP40 [(SA623)] AT49LV1024A@TSOP40 [(SA623)]  
 AT49LV1025@PLCC44 [(SA244)] AT49LV160@TSOP48 [(SA247-B005)]  
 AT49LV160@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV1604@TSOP48 [(SA247-B005)]  
 AT49LV1604@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV1604T@TSOP48 [(SA247-B005)]  
 AT49LV1604T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV161@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV161@TSOP48 [(SA247-B005)]  
 AT49LV1614@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV1614@TSOP48 [(SA247-B005)]  
 AT49LV1614A@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV1614A@TSOP48 [(SA247-B005)]  
 AT49LV1614AT@CBGA48 [(SA642F-B026A-T064F001)]

AT49LV1614AT@TSOP48 [(SA247-B005)]  
 AT49LV1614T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV1614T@TSOP48 [(SA247-B005)]  
 AT49LV161T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV161T@TSOP48 [(SA247-B005)] AT49LV2048@PSOP44 [(SA638)]  
 AT49LV2048@TSOP48 [(SA247-B005)] AT49LV2048A@PSOP44 [(SA638)]  
 AT49LV2048A@TSOP48 [(SA247-B005)]  
 AT49LV2048B@TSOP48 [(SA247-B005)]  
 AT49LV320@TSOP48 [(SA247-B005)]  
 AT49LV320@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV320T@TSOP48 [(SA247-B005)]  
 AT49LV320T@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV321@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV321@TSOP48 [(SA247-B005)]  
 AT49LV3218@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV3218@TSOP48 [(SA247-B005)]  
 AT49LV3218T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV3218T@TSOP48 [(SA247-B005)]  
 AT49LV321T@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV321T@TSOP48 [(SA247-B005)]  
 AT49LV4096A@CBGA48 [(SA642F-B026A-T064F001)]  
 AT49LV4096A@PSOP44 [(SA638)]  
 AT49LV4096A@TSOP48 [(SA247-B005)]  
 AT49LV4096A@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV8011@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49LV8011@TSOP48 [(SA247-B005)]  
 AT49LV8011T@CBGA48 [(SA642B-B026A-Y072F001)]  
 AT49LV8011T@TSOP48 [(SA247-B005)]  
 AT49LV8192@PSOP44 [(SA638)] AT49LV8192@TSOP48 [(SA247-B005)]  
 AT49LV8192A@TSOP48 [(SA247-B005)]  
 AT49LV8192A@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LV8192AT@TSOP48 [(SA247-B005)]  
 AT49LV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]  
 AT49LW040@PLCC32 [(SA015A1T)] AT49LW040@TSOP40 [(SA409T)]  
 AT49LW080@PLCC32 [(SA015A1T)] AT49LW080@TSOP40 [(SA409T)]  
 AT49SV163D@FBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49SV163D@TSOP48 [(SA247-B005)]  
 AT49SV163DT@FBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49SV163DT@TSOP48 [(SA247-B005)]  
 AT49SV322A@CBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49SV322A@TSOP48 [(SA247-B005)]  
 AT49SV322AT@CBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49SV322AT@TSOP48 [(SA247-B005)]  
 AT49SV322D@FBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49SV322D@TSOP48 [(SA247-B005)]  
 AT49SV322DT@FBGA48 [(SA642U-B026A-T064F001Y)]  
 AT49SV322DT@TSOP48 [(SA247-B005)]  
 AT49SV802A@CBGA48 [(SA642G-B026A-T048F001Y)]  
 AT49SV802A@TSOP48 [(SA247-B005)]  
 AT49SV802AT@CBGA48 [(SA642G-B026A-T048F001Y)]  
 AT49SV802AT@TSOP48 [(SA247-B005)]  
 AT52BC1660A@FBGA66 [(SA642R-B023A-T096F001Y)]  
 AT52BC1660AT@FBGA66 [(SA642R-B023A-T096F001Y)]  
 AT52BC1661A@FBGA66 [(SA642R-B023A-T096F001Y)]  
 AT52BC1661AT@FBGA66 [(SA642R-B023A-T096F001Y)]  
 AT52BC3221A@FBGA66 [(SA642R-B023A-T080F001Y)]  
 AT52BC3221AT@FBGA66 [(SA642R-B023A-T080F001Y)]  
 AT52BC3221D@FBGA66 [(SA642R-B023A-T080F001Y)]  
 AT52BC3221DT@FBGA66 [(SA642R-B023A-T080F001Y)]  
 AT52BC6402A@FBGA66 [(SA642B-B023A-Y072F001Y)]  
 AT52BC6402AT@FBGA66 [(SA642B-B023A-Y072F001Y)]  
 AT52BR1662@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1662A@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1662AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1662T@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1664@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1664A@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1664AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1664T@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1672@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1672T@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1674@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR1674T@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3224@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3224A@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3224AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3224T@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3228@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3228A@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3228AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
 AT52BR3228T@CBGA66 [(SA642E-B023A-T072F001Y)]

AT52BR3244@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3244T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3248@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3248T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR6408A@CSP66 [(SA642E-B023A-T072F001Y)]	
AT52BR6408AT@CSP66 [(SA642E-B023A-T072F001Y)]	
AT59C11	AT59C11@SOIC8 [(SA602A)]
AT59C12	AT59C12@SOIC8 [(SA602A)]
AT59C13	AT59C13@SOIC8 [(SA602A)]
AT59C22	AT59C22@SOIC8 [(SA602A)]
AT93C46(08bit)	AT93C46(08bit)@SOIC8 [(SA602A)]
AT93C46(08bit)@TSSOP8 [(SA026)]	AT93C46(16bit)
AT93C46(16bit)@SOIC8 [(SA602A)]	AT93C46(16bit)@TSSOP8 [(SA026)]
AT93C46A	AT93C46A@SOIC8 [(SA602A)]
AT93C46A@TSSOP8 [(SA026)]	AT93C46C
AT93C46C@SOIC8 [(SA602A)]	AT93C46C@TSSOP8 [(SA026)]
AT93C46D(08bit)	AT93C46D(08bit)@dBGA8 [(BBBB)]
AT93C46D(08bit)@MAP8 [(SA724)]	AT93C46D(08bit)@SOIC8 [(SA602A)]
AT93C46D(08bit)@TSSOP8 [(SA026)]	AT93C46D(16bit)
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8 [(SA724)]
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8 [(SA026)]
AT93C46E	AT93C46E@SOIC8 [(SA602A)]
AT93C46E@TSSOP8 [(SA026)]	AT93C56(08bit)
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56(16bit)
AT93C56(16bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)
AT93C56A(08bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)@TSSOP8 [(SA026)]
AT93C56A(16bit)	AT93C56A(16bit)@SOIC8 [(SA602A)]
AT93C56A(16bit)@TSSOP8 [(SA026)]	AT93C57
AT93C57@SOIC8 [(SA602A)]	AT93C66(08bit)
AT93C66(08bit)@SOIC8 [(SA602A)]	AT93C66(16bit)
AT93C66(16bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)
AT93C66A(08bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)@TSSOP8 [(SA026)]
AT93C66A(16bit)	AT93C66A(16bit)@SOIC8 [(SA602A)]
AT93C66A(16bit)@TSSOP8 [(SA026)]	AT93C86(08bit)
AT93C86(08bit)@SOIC8 [(SA602A)]	AT93C86(08bit)@TSSOP8 [(SA026)]
AT93C86(16bit)	AT93C86(16bit)@SOIC8 [(SA602A)]
AT93C86(16bit)@TSSOP8 [(SA026)]	AT93C86A(08bit)
AT93C86A(08bit)@SOIC8 [(SA602A)]	AT93C86A(08bit)@TSSOP8 [(SA026)]
AT93C86A(16bit)	AT93C86A(16bit)@SOIC8 [(SA602A)]
AT93C86A(16bit)@TSSOP8 [(SA026)]	

**DRAM & SRAM**

AT3864L	AT3864L@TSOP28 [(SA643)]
AT38H256	AT38H256@TSOP28 [(SA643)]

**PLD**

AT22LV10	AT22LV10@PLCC28 [(SA008A)]
AT22LV10@SOIC24 [(SA404)]	AT22LV10L
AT22LV10L@PLCC28 [(SA008A)]	AT22LV10L@SOIC24 [(SA404)]
AT22V10	AT22V10@PLCC28 [(SA008A)]
AT22V10@SOIC24 [(SA404)]	AT22V10L
AT22V10L@PLCC28 [(SA008A)]	AT22V10L@SOIC24 [(SA404)]
ATF1500A@PLCC44 [(SA244)]	ATF1500A@TQFP44 [(SA245A)]
ATF1500ABV@PLCC44 [(SA244)]	ATF1500ABV@TQFP44 [(SA245A)]
ATF1500ABVL@PLCC44 [(SA244)]	ATF1500ABVL@TQFP44 [(SA245A)]
ATF1500AL@PLCC44 [(SA244)]	ATF1500AL@TQFP44 [(SA245A)]
ATF1502AS@PLCC44 [(SA244)]	ATF1502AS@PQFP44 [(SA675)]
ATF1502AS@TQFP44 [(SA245A)]	ATF1502ASL@PLCC44 [(SA244)]
ATF1502ASL@PQFP44 [(SA675)]	ATF1502ASL@TQFP44 [(SA245A)]
ATF1502ASV@PLCC44 [(SA244)]	ATF1502ASV@PQFP44 [(SA675)]
ATF1502ASV@TQFP44 [(SA245A)]	ATF1502ASVL@PLCC44 [(SA244)]
ATF1502ASVL@PQFP44 [(SA675)]	ATF1502ASVL@TQFP44 [(SA245A)]
ATF1504AS@PLCC44 [(SA244)]	
ATF1504AS@PLCC44(ISP) [ISP-HEADER01]	
ATF1504AS@PLCC68 [(PEP+S414T)]	
ATF1504AS@PLCC68(ISP) [ISP-HEADER01]	
ATF1504AS@PLCC84 [(PEP+S416T)]	
ATF1504AS@PLCC84(ISP) [ISP-HEADER01]	
ATF1504AS@PQFP100 [(PEP+S427)]	
ATF1504AS@PQFP100(ISP) [ISP-HEADER01]	
ATF1504AS@TQFP100 [(PEP+S604)]	
ATF1504AS@TQFP100(ISP) [ISP-HEADER01]	
ATF1504AS@TQFP44 [(SA245A)]	
ATF1504AS@TQFP44(ISP) [ISP-HEADER01]	
ATF1504ASV(L)@PLCC44 [(SA244)]	
ATF1504ASV(L)@PLCC44(ISP) [ISP-HEADER01]	



```

ATF1504ASV(L)@PLCC68 [(PEP+S414T)]
ATF1504ASV(L)@PLCC68(ISP) [ISP-HEADER01]
ATF1504ASV(L)@PLCC84 [(PEP+S416T)]
ATF1504ASV(L)@PLCC84(ISP) [ISP-HEADER01]
ATF1504ASV(L)@PQFP100 [(PEP+S427)]
ATF1504ASV(L)@PQFP100(ISP) [ISP-HEADER01]
ATF1504ASV(L)@TQFP100 [(PEP+S604)]
ATF1504ASV(L)@TQFP100(ISP) [ISP-HEADER01]
ATF1504ASV(L)@TQFP44 [(SA245A)]
ATF1504ASV(L)@TQFP44(ISP) [ISP-HEADER01]
ATF1508@PLCC68 [(PEP+S414T)]
ATF1508@PLCC68(ISP) [ISP-HEADER01]
ATF1508@PLCC84 [(PEP+S416T)]
ATF1508@PLCC84(ISP) [ISP-HEADER01]
ATF1508@PQFP100 [(PEP+S427)]
ATF1508@PQFP100(ISP) [ISP-HEADER01]
ATF1508@TQFP100 [(PEP+S604)]
ATF1508@TQFP100(ISP) [ISP-HEADER01]
ATF1508AS(L)@PLCC84 [(PEP+S416T)]
ATF1508AS(L)@PLCC84(ISP) [ISP-HEADER01]
ATF1508AS(L)@PQFP100 [(PEP+S427)]
ATF1508AS(L)@PQFP100(ISP) [ISP-HEADER01]
ATF1508AS(L)@TQFP100 [(PEP+S604)]
ATF1508AS(L)@TQFP100(ISP) [ISP-HEADER01]
ATF1508ASV(L)@PLCC84 [(PEP+S416T)]
ATF1508ASV(L)@PLCC84(ISP) [ISP-HEADER01]
ATF1508ASV(L)@PQFP100 [(PEP+S427)]
ATF1508ASV(L)@PQFP100(ISP) [ISP-HEADER01]
ATF1508ASV(L)@TQFP100 [(PEP+S604)]
ATF1508ASV(L)@TQFP100(ISP) [ISP-HEADER01]
ATF16LV8C
ATF16LV8C@SOIC20 [(SA404)]
ATF16LV8CEXT
ATF16LV8CEXT@SOIC20 [(SA404)]
ATF16V8B
ATF16V8B@SOIC20 [(SA404)]
ATF16V8BL
ATF16V8BL@SOIC20 [(SA404)]
ATF16V8BQ
ATF16V8BQ@SOIC20 [(SA404)]
ATF16V8BQL
ATF16V8BQL@SOIC20 [(SA404)]
ATF16V8C
ATF16V8C@SOIC20 [(SA404)]
ATF16V8CEXT
ATF16V8CEXT@SOIC20 [(SA404)]
ATF16V8CZ
ATF16V8CZ@SOIC20 [(SA404)]
ATF20V8B
ATF20V8B@SOIC24 [(SA404)]
ATF20V8BL@PLCC28 [(SA008A)]
ATF20V8BQ
ATF20V8BQ@SOIC24 [(SA404)]
ATF20V8BQL@PLCC28 [(SA008A)]
ATF22LV10C
ATF22LV10C(UES)@PLCC28 [(SA008A)]
ATF22LV10C(UES)@SOIC24 [(SA404)]
ATF22LV10C(UES)@TSSOP24 [(SA643)]
ATF22LV10C@PLCC28 [(SA008A)]
ATF22LV10C@TSSOP24 [(SA643)]
ATF22LV10CEXT@PLCC28 [(SA008A)]
ATF22LV10CEXT@TSSOP24 [(SA643)]
ATF22LV10CQ(UES)
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]
ATF22LV10CQ(UES)@SOIC24 [(SA404)]
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]
ATF22LV10CQ@PLCC28 [(SA008A)]
ATF22LV10CQ@TSSOP24 [(SA643)]
ATF22LV10CQZ(UES)
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]
ATF22LV10CQZ@PLCC28 [(SA008A)]
ATF22LV10CQZ@TSSOP24 [(SA643)]
ATF22LV10CZ(UES)
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]
ATF22LV10CZ(UES)@SOIC24 [(SA404)]
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]
ATF22LV10CZ@PLCC28 [(SA008A)]
ATF22LV10CZ@TSSOP24 [(SA643)]
ATF22V10B(UES)
ATF16LV8C@PLCC20 [(SA001A)]
ATF16LV8C@TSOP20 [(SA026)]
ATF16LV8CEXT@PLCC20 [(SA001A)]
ATF16LV8CEXT@TSOP20 [(SA026)]
ATF16V8B@PLCC20 [(SA001A)]
ATF16V8B@TSOP20 [(SA026)]
ATF16V8BL@PLCC20 [(SA001A)]
ATF16V8BL@TSOP20 [(SA026)]
ATF16V8BQ@PLCC20 [(SA001A)]
ATF16V8BQ@TSOP20 [(SA026)]
ATF16V8BQL@PLCC20 [(SA001A)]
ATF16V8BQL@TSOP20 [(SA026)]
ATF16V8C@PLCC20 [(SA001A)]
ATF16V8C@TSOP20 [(SA026)]
ATF16V8CEXT@PLCC20 [(SA001A)]
ATF16V8CEXT@TSOP20 [(SA026)]
ATF16V8CZ@PLCC20 [(SA001A)]
ATF16V8CZ@TSOP20 [(SA026)]
ATF20V8B@PLCC28 [(SA008A)]
ATF20V8BL@SOIC24 [(SA404)]
ATF20V8BQ@PLCC28 [(SA008A)]
ATF20V8BQL@SOIC24 [(SA404)]
ATF22LV10C(UES)
ATF22LV10C@SOIC24 [(SA404)]
ATF22LV10CEXT
ATF22LV10CEXT@SOIC24 [(SA404)]
ATF22LV10CQ
ATF22LV10CQ@SOIC24 [(SA404)]
ATF22LV10CQZ
ATF22LV10CQZ@SOIC24 [(SA404)]
ATF22LV10CZ
ATF22LV10CZ@SOIC24 [(SA404)]
ATF22V10B
ATF22V10B(UES)@PLCC28 [(SA008A)]

```

```

ATF22V10B(UES)@SOIC24 [(SA404)]      ATF22V10B@PLCC28 [(SA008A)]
ATF22V10B@SOIC24 [(SA404)]          ATF22V10BL
ATF22V10BL(UES)
ATF22V10BL(UES)@PLCC28 [(SA008A)]
ATF22V10BL(UES)@SOIC24 [(SA404)]      ATF22V10BL@PLCC28 [(SA008A)]
ATF22V10BL@SOIC24 [(SA404)]          ATF22V10BQ
ATF22V10BQ(UES)
ATF22V10BQ(UES)@PLCC28 [(SA008A)]
ATF22V10BQ(UES)@SOIC24 [(SA404)]      ATF22V10BQ@PLCC28 [(SA008A)]
ATF22V10BQ@SOIC24 [(SA404)]          ATF22V10BQL
ATF22V10BQL(UES)
ATF22V10BQL(UES)@PLCC28 [(SA008A)]
ATF22V10BQL(UES)@SOIC24 [(SA404)]
ATF22V10BQL@PLCC28 [(SA008A)]        ATF22V10BQL@SOIC24 [(SA404)]
ATF22V10C                               ATF22V10C(UES)
ATF22V10C(UES)@PLCC28 [(SA008A)]      ATF22V10C(UES)@SOIC24 [(SA404)]
ATF22V10C(UES)@TSSOP24 [(SA643)]      ATF22V10C@PLCC28 [(SA008A)]
ATF22V10C@SOIC24 [(SA404)]            ATF22V10C@TSSOP24 [(SA643)]
ATF22V10CEXT                             ATF22V10CEXT@PLCC28 [(SA008A)]
ATF22V10CEXT@SOIC24 [(SA404)]          ATF22V10CEXT@TSSOP24 [(SA643)]
ATF22V10CQ                               ATF22V10CQ(UES)
ATF22V10CQ(UES)@PLCC28 [(SA008A)]
ATF22V10CQ(UES)@SOIC24 [(SA404)]
ATF22V10CQ(UES)@TSSOP24 [(SA643)]
ATF22V10CQ@PLCC28 [(SA008A)]          ATF22V10CQ@SOIC24 [(SA404)]
ATF22V10CQ@TSSOP24 [(SA643)]          ATF22V10CQZ
ATF22V10CQZ(UES)
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]
ATF22V10CQZ(UES)@SOIC24 [(SA404)]
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]
ATF22V10CQZ@PLCC28 [(SA008A)]        ATF22V10CQZ@SOIC24 [(SA404)]
ATF22V10CQZ@TSSOP24 [(SA643)]        ATF22V10CZ
ATF22V10CZ(UES)
ATF22V10CZ(UES)@PLCC28 [(SA008A)]
ATF22V10CZ(UES)@SOIC24 [(SA404)]
ATF22V10CZ(UES)@TSSOP24 [(SA643)]
ATF22V10CZ@PLCC28 [(SA008A)]          ATF22V10CZ@SOIC24 [(SA404)]
ATF22V10CZ@TSSOP24 [(SA643)]          ATF2500C(F2500C)
ATF2500C(F2500C)@PLCC44 [(SA244)]
ATF2500C(F2500C)@TQFP44 [(SA245A)]
ATF2500C(V2500)                          ATF2500C(V2500)@PLCC44 [(SA244)]
ATF2500C(V2500)@TQFP44 [(SA245A)]
ATF2500C(V2500B)
ATF2500C(V2500B)@PLCC44 [(SA244)]
ATF2500C(V2500B)@TQFP44 [(SA245A)]
ATF2500CL(F2500C)
ATF2500CL(F2500C)@PLCC44 [(SA244)]
ATF2500CL(F2500C)@TQFP44 [(SA245A)]
ATF2500CL(V2500)
ATF2500CL(V2500)@PLCC44 [(SA244)]
ATF2500CL(V2500)@TQFP44 [(SA245A)]
ATF2500CL(V2500B)
ATF2500CL(V2500B)@PLCC44 [(SA244)]
ATF2500CL(V2500B)@TQFP44 [(SA245A)]
ATF2500CQ(F2500C)
ATF2500CQ(F2500C)@PLCC44 [(SA244)]
ATF2500CQ(F2500C)@TQFP44 [(SA245A)]
ATF2500CQ(V2500B)
ATF2500CQ(V2500B)@PLCC44 [(SA244)]
ATF2500CQ(V2500B)@TQFP44 [(SA245A)]
ATF2500CQL(F2500C)
ATF2500CQL(F2500C)@PLCC44 [(SA244)]
ATF2500CQL(F2500C)@TQFP44 [(SA245A)]
ATF2500CQL(V2500B)
ATF2500CQL(V2500B)@PLCC44 [(SA244)]
ATF2500CQL(V2500B)@TQFP44 [(SA245A)]
ATF750C                               (ATF750C mode)      ATF750C                               (ATV750 mode)
ATF750C                               (ATV750B mode)
ATF750C@PLCC28                          (ATF750C mode) [(SA008A)]
ATF750C@PLCC28                          (ATV750 mode) [(SA008A)]
ATF750C@PLCC28                          (ATV750B mode) [(SA008A)]
ATF750C@SOIC24                          (ATF750C mode) [(SA404)]
ATF750C@SOIC24                          (ATV750 mode) [(SA404)]
ATF750C@SOIC24                          (ATV750B mode) [(SA404)]
ATF750CEXT                              (ATF750C mode)
ATF750CEXT@PLCC28                      (ATF750C mode) [(SA008A)]
ATF750CEXT@SOIC24                      (ATF750C mode) [(SA404)]
ATF750CL                              (ATV750 mode)      ATF750CL                              (ATV750B mode)
ATF750CL@PLCC28                        (ATV750 mode) [(SA008A)]
ATF750CL@PLCC28                        (ATV750B mode) [(SA008A)]
ATF750CL@SOIC24                        (ATV750 mode) [(SA404)]

```

```

ATF750CL@SOIC24 (ATV750B mode) [(SA404)]
ATF750LVC (ATF750C mode) ATF750LVC (ATV750 mode)
ATF750LVC (ATV750B mode)
ATF750LVC@PLCC28 (ATF750C mode) [(SA008A)]
ATF750LVC@PLCC28 (ATV750 mode) [(SA008A)]
ATF750LVC@PLCC28 (ATV750B mode) [(SA008A)]
ATF750LVC@SOIC24 (ATF750C mode) [(SA404)]
ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]
ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]
ATF750LVCEXT (ATF750C mode)
ATF750LVCEXT@PLCC28 (ATF750C mode) [(SA008A)]
ATF750LVCEXT@SOIC24 (ATF750C mode) [(SA404)]
ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)
ATF750LVCL (ATV750B mode)
ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]
ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]
ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]
ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]
ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]
ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]
ATV22V10 ATF22V10@PLCC28 [(SA008A)]
ATV22V10@SOIC24 [(SA404)] ATF2500
ATV2500@PLCC44 [(SA244)] ATF2500B
ATV2500B@PLCC44 [(SA244)] ATF2500BL
ATV2500BL@PLCC44 [(SA244)] ATF2500BQ
ATV2500BQ@PLCC44 [(SA244)] ATF2500BQL
ATV2500BQL@PLCC44 [(SA244)] ATF2500H
ATV2500H@PLCC44 [(SA244)] ATF2500L
ATV2500L@PLCC44 [(SA244)] ATF750
ATV750@PLCC28 [(SA008A)] ATF750@SOIC24 [(SA404)]
ATV750B ATF750B@PLCC28 [(SA008A)]
ATV750BL ATF750BL
ATV750BL@PLCC28 [(SA008A)] ATF750BL@SOIC24 [(SA404)]
ATV750L ATF750L@PLCC28 [(SA008A)]
ATV750L@SOIC24 [(SA404)]

```

## MICROCONTROLLER

```

AT80F51 AT80F51@PLCC44 [(SA244)]
AT80F51@TQFP44 [(SA245A)] AT80F52
AT80F52@PLCC44 [(SA244)] AT80F52@TQFP44 [(SA245A)]
AT87F51 AT87F51@PLCC44 [(SA244)]
AT87F51@TQFP44 [(SA245A)] AT87F51RC
AT87F51RC@PLCC44 [(SA244)] AT87F51RC@TQFP44 [(SA245A)]
AT87F52 AT87F52@PLCC44 [(SA244)]
AT87F52@TQFP44 [(SA245A)] AT87F55
AT87F55@PLCC44 [(SA244)] AT87F55@TQFP44 [(SA245A)]
AT87F55WD AT87F55WD@PLCC44 [(SA244)]
AT87F55WD@TQFP44 [(SA245A)] AT87LV51
AT87LV51@PLCC44 [(SA244)] AT87LV51@TQFP44 [(SA245A)]
AT87LV52 AT87LV52@PLCC44 [(SA244)]
AT87LV52@TQFP44 [(SA245A)] AT89C1051
AT89C1051@SOIC20 [(SA404)] AT89C1051U
AT89C1051U@SOIC20 [(SA404)] AT89C2051
AT89C2051@SOIC20 [(SA404)] AT89C2051X2
AT89C2051X2@SOIC20 [(SA404)] AT89C4051
AT89C4051@SOIC20 [(SA404)] AT89C51
AT89C51@PLCC44 [(SA244)] AT89C51@TQFP44 [(SA245A)]
AT89C5130A@PLCC52 [(PEP+S415T)] AT89C5130A@QFN32 [(SA701)]
AT89C5130A@SOIC28 [(SA404)] AT89C5130A@VQFP64 [(PEP+S625A)]
AT89C5130AM@PLCC52 [(PEP+S415T)] AT89C5130AM@QFN32 [(SA701)]
AT89C5130AM@SOIC28 [(SA404)] AT89C5130AM@VQFP64 [(PEP+S625A)]
AT89C5131@MLF48 [(SA696)] AT89C5131@PLCC52 [(PEP+S415T)]
AT89C5131@SOIC28 [(SA404)] AT89C5131@VQFP64 [(PEP+S616)]
AT89C5131A@PLCC52 [(PEP+S415T)] AT89C5131A@QFN32 [(SA701)]
AT89C5131A@SOIC28 [(SA404)] AT89C5131A@VQFP64 [(PEP+S616)]
AT89C5131AL@PLCC52 [(PEP+S415T)] AT89C5131AL@QFN32 [(SA701)]
AT89C5131AL@SOIC28 [(SA404)] AT89C5131AL@VQFP64 [(PEP+S616)]
AT89C5131AM@PLCC52 [(PEP+S415T)] AT89C5131AM@QFN32 [(SA701)]
AT89C5131AM@SOIC28 [(SA404)] AT89C5131AM@VQFP64 [(PEP+S616)]
AT89C5132@TQFP80 [(PEP+S704)] AT89C51AC2@PLCC44 [(SA244)]
AT89C51AC2@TQFP44 [(SA245A)] AT89C51AC3@PLCC44 [(SA244)]
AT89C51AC3@PLCC52 [(PEP+S415T)] AT89C51AC3@TQFP44 [(SA245A)]
AT89C51AC3@TQFP64 [(PEP+S616)] AT89C51CC01@PLCC44 [(SA244)]
AT89C51CC01@TQFP44 [(SA245A)] AT89C51CC03A@PLCC44 [(SA244)]
AT89C51CC03A@PLCC52 [(PEP+S415T)] AT89C51CC03A@TQFP44 [(PEP+S616)]
AT89C51CC03A@TQFP64 [(SA245A)]
AT89C51CC03C@PLCC44 [(SA244)]
AT89C51CC03C@PLCC52 [(PEP+S415T)]

```

AT89C51CC03C@TQFP44 [(SA245A)]	AT89C51CC03C@TQFP64 [(PEP+S616)]
AT89C51CC03U@PLCC44 [(SA244)]	
AT89C51CC03U@PLCC52 [(PEP+S415T)]	
AT89C51CC03U@TQFP44 [(SA245A)]	AT89C51CC03U@TQFP64 [(PEP+S616)]
AT89C51ED2	AT89C51ED2@PLCC44 [(SA244)]
AT89C51ED2@PLCC68 [(PEP+S414T)]	
AT89C51ED2@PLCC68(*) [(SA648-B6808)]	
AT89C51ED2@TQFP44 [(SA245A)]	AT89C51ED2@TQFP64 [(PEP+S616)]
AT89C51ED2@TQFP64(*) [(TA054-B006)]	
AT89C51IC2@PLCC44 [(SA244)]	AT89C51IC2@TQFP44 [(SA245A)]
AT89C51ID2	AT89C51ID2@PLCC44 [(SA244)]
AT89C51ID2@PLCC68 [(PEP+S414T)]	
AT89C51ID2@PLCC68(*) [(SA648-B6808)]	
AT89C51ID2@TQFP44 [(SA245A)]	AT89C51ID2@TQFP64 [(PEP+S616)]
AT89C51ID2@TQFP64(*) [(TA054-B006)]	
AT89C51RB2	AT89C51RB2@PLCC44 [(SA244)]
AT89C51RB2@TQFP44 [(SA245A)]	AT89C51RC
AT89C51RC@PLCC44 [(SA244)]	AT89C51RC@TQFP44 [(SA245A)]
AT89C51RC2	AT89C51RC2@PLCC44 [(SA244)]
AT89C51RC2@TQFP44 [(SA245A)]	AT89C51RD2
AT89C51RD2@PLCC44 [(SA244)]	AT89C51RD2@PLCC68 [(PEP+S414T)]
AT89C51RD2@PLCC68(*) [(SA648-B6808)]	
AT89C51RD2@TQFP44 [(SA245A)]	AT89C51RD2@TQFP64 [(PEP+S616)]
AT89C51RD2@TQFP64(*) [(TA054-B006)]	
AT89C51RE2@PLCC44 [(SA244)]	AT89C51RE2@TQFP44 [(SA675)]
AT89C51RE2@VQFP64 [(SA732+B317)]	
AT89C51SND1C@BGA81(*) [(SA664E-B156A-P081F001Y)]	
AT89C51SND1C@PLCC84 [(PEP+S416T)]	
AT89C51SND1C@TQFP80 [(PEP+S704)]	
AT89C51SND2C@BGA100 [(SA664K-B242A-W100F001Y)]	
AT89C52	AT89C52@PLCC44 [(SA244)]
AT89C52@TQFP44 [(SA245A)]	AT89C55
AT89C55@PLCC44 [(SA244)]	AT89C55@TQFP44 [(SA245A)]
AT89C55WD	AT89C55WD@PLCC44 [(SA244)]
AT89C55WD@TQFP44 [(SA245A)]	AT89LP2051
AT89LP2051@SOIC20 [(SA404)]	AT89LP2051@TSSOP20 [(SA026)]
AT89LP2052	AT89LP2052(ISP) [ISP-HEADER01]
AT89LP2052@SOIC20 [(SA404)]	
AT89LP2052@SOIC20(ISP) [ISP-HEADER01]	
AT89LP2052@TSSOP20 [(SA026)]	
AT89LP2052@TSSOP20(ISP) [ISP-HEADER01]	
AT89LP213	AT89LP213(ISP) [ISP-HEADER01]
AT89LP213@TSSOP14 [(SA026)]	
AT89LP213@TSSOP14(ISP) [ISP-HEADER01]	
AT89LP214	AT89LP214(ISP) [ISP-HEADER01]
AT89LP214@TSSOP14 [(SA026)]	
AT89LP214@TSSOP14(ISP) [ISP-HEADER01]	
AT89LP216	AT89LP216(ISP) [ISP-HEADER01]
AT89LP216@TSSOP16 [(SA026)]	
AT89LP216@TSSOP16(ISP) [ISP-HEADER01]	
AT89LP4051	AT89LP4051@SOIC20 [(SA404)]
AT89LP4051@TSSOP20 [(SA026)]	AT89LP4052
AT89LP4052(ISP) [ISP-HEADER01]	AT89LP4052@SOIC20 [(SA404)]
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]	
AT89LP4052@TSSOP20 [(SA026)]	
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]	
AT89LP428	AT89LP428(ISP) [ISP-HEADER01]
AT89LP428@PLCC32 [(SA015A1T)]	
AT89LP428@PLCC32(ISP) [ISP-HEADER01]	
AT89LP428@TQFP32 [(SA636)]	
AT89LP428@TQFP32(ISP) [ISP-HEADER01]	
AT89LP828	AT89LP828(ISP) [ISP-HEADER01]
AT89LP828@PLCC32 [(SA015A1T)]	
AT89LP828@PLCC32(ISP) [ISP-HEADER01]	
AT89LP828@TQFP32 [(SA636)]	
AT89LP828@TQFP32(ISP) [ISP-HEADER01]	
AT89LS51	AT89LS51(ISP) [ISP-HEADER01]
AT89LS51@PLCC44 [(SA244)]	
AT89LS51@PLCC44(ISP) [ISP-HEADER01]	
AT89LS51@TQFP44 [(SA245A)]	
AT89LS51@TQFP44(ISP) [ISP-HEADER01]	
AT89LS52	AT89LS52(ISP) [ISP-HEADER01]
AT89LS52@PLCC44 [(SA244)]	
AT89LS52@PLCC44(ISP) [ISP-HEADER01]	
AT89LS52@TQFP44 [(SA245A)]	
AT89LS52@TQFP44(ISP) [ISP-HEADER01]	
AT89LS53	AT89LS53(ISP) [ISP-HEADER01]
AT89LS53@PLCC44 [(SA244)]	
AT89LS53@PLCC44(ISP) [ISP-HEADER01]	
AT89LS53@TQFP44 [(SA245A)]	
AT89LS53@TQFP44(ISP) [ISP-HEADER01]	

AT89LS8252	AT89LS8252(ISP) [ISP-HEADER01]
AT89LS8252@PLCC44 [(SA244)]	
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]	
AT89LS8252@TQFP44 [(SA245A)]	
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]	
AT89LV51	AT89LV51@PLCC44 [(SA244)]
AT89LV51@TQFP44 [(SA245A)]	AT89LV52
AT89LV52@PLCC44 [(SA244)]	AT89LV52@TQFP44 [(SA245A)]
AT89LV55	AT89LV55@PLCC44 [(SA244)]
AT89LV55@TQFP44 [(SA245A)]	AT89S2051
AT89S2051@SOIC20 [(SA404)]	AT89S4051
AT89S4051@SOIC20 [(SA404)]	AT89S51
AT89S51(ISP) [ISP-HEADER01]	AT89S51@PLCC44 [(SA244)]
AT89S51@PLCC44(ISP) [ISP-HEADER01]	
AT89S51@TQFP44 [(SA245A)]	
AT89S51@TQFP44(ISP) [ISP-HEADER01]	
AT89S52	AT89S52(ISP) [ISP-HEADER01]
AT89S52@PLCC44 [(SA244)]	
AT89S52@PLCC44(ISP) [ISP-HEADER01]	
AT89S52@TQFP44 [(SA245A)]	
AT89S52@TQFP44(ISP) [ISP-HEADER01]	
AT89S53	AT89S53(ISP) [ISP-HEADER01]
AT89S53@PLCC44 [(SA244)]	
AT89S53@PLCC44(ISP) [ISP-HEADER01]	
AT89S53@TQFP44 [(SA245A)]	
AT89S53@TQFP44(ISP) [ISP-HEADER01]	
AT89S54	AT89S54@PLCC44 [(SA244)]
AT89S54@TQFP44 [(SA245A)]	AT89S58
AT89S58@PLCC44 [(SA244)]	AT89S58@TQFP44 [(SA245A)]
AT89S64	AT89S64@PLCC44 [(SA244)]
AT89S64@TQFP44 [(SA245A)]	AT89S8252
AT89S8252(ISP) [ISP-HEADER01]	AT89S8252@PLCC44 [(SA244)]
AT89S8252@PLCC44(ISP) [ISP-HEADER01]	
AT89S8252@TQFP44 [(SA245A)]	
AT89S8252@TQFP44(ISP) [ISP-HEADER01]	
AT89S8253	AT89S8253(ISP) [ISP-HEADER01]
AT89S8253@PLCC44 [(SA244)]	
AT89S8253@PLCC44(ISP) [ISP-HEADER01]	
AT89S8253@TQFP44 [(SA245A)]	
AT89S8253@TQFP44(ISP) [ISP-HEADER01]	
AT90CAN128@QFN64(ISP) [ISP-HEADER01]	
AT90CAN128@TQFP64(ISP) [ISP-HEADER01]	
AT90CAN128-AI@TQFP64 [(S625A)]	AT90CAN128-AU@TQFP64 [(S625A)]
AT90CAN32@QFN64 [(PEP+S702)]	
AT90CAN32@QFN64(ISP) [ISP-HEADER01]	
AT90CAN32@TQFP64 [(PEP+S625A)]	
AT90CAN32@TQFP64(ISP) [ISP-HEADER01]	
AT90CAN64@QFN64(ISP) [ISP-HEADER01]	
AT90CAN64@TQFP64(ISP) [ISP-HEADER01]	
AT90LS2323	AT90LS2323(ISP) [ISP-HEADER01]
AT90LS2323@SOIC8 [(SA605A)]	
AT90LS2323@SOIC8(ISP) [ISP-HEADER01]	
AT90LS2333	AT90LS2333(ISP) [ISP-HEADER01]
AT90LS2333@TQFP32 [(SA663)]	
AT90LS2333@TQFP32(ISP) [ISP-HEADER01]	
AT90LS2343	AT90LS2343(ISP) [ISP-HEADER01]
AT90LS2343@SOIC8 [(SA605A)]	
AT90LS2343@SOIC8(ISP) [ISP-HEADER01]	
AT90LS4433	AT90LS4433(ISP) [ISP-HEADER01]
AT90LS4433@TQFP32 [(SA663)]	
AT90LS4433@TQFP32(ISP) [ISP-HEADER01]	
AT90LS4434	AT90LS4434(ISP) [ISP-HEADER01]
AT90LS4434@PLCC44 [(SA244)]	
AT90LS4434@PLCC44(ISP) [ISP-HEADER01]	
AT90LS4434@TQFP44 [(SA245A)]	
AT90LS4434@TQFP44(ISP) [ISP-HEADER01]	
AT90LS8535	AT90LS8535(ISP) [ISP-HEADER01]
AT90LS8535@PLCC44 [(SA244)]	
AT90LS8535@PLCC44(ISP) [ISP-HEADER01]	
AT90LS8535@TQFP44 [(SA245A)]	
AT90LS8535@TQFP44(ISP) [ISP-HEADER01]	
AT90PWM1@SOIC24 [(SA404)]	AT90PWM2@SOIC24 [(SA404)]
AT90PWM2@SOIC24(ISP) [ISP-HEADER01]	
AT90PWM216@SOIC24 [(SA404)]	AT90PWM2B@SOIC24 [(SA404)]
AT90PWM2B@SOIC24(ISP) [ISP-HEADER01]	
AT90PWM3@QFN32 [(SA701)]	
AT90PWM3@QFN32(ISP) [ISP-HEADER01]	
AT90PWM3@SOIC32 [(SA715)]	
AT90PWM3@SOIC32(ISP) [ISP-HEADER01]	
AT90PWM316@QFN32 [(SA701)]	AT90PWM316@SOIC32 [(SA715)]
AT90PWM3B@QFN32 [(SA701)]	

```

AT90PWM3B@QFN32(ISP) [ISP-HEADER01]
AT90PWM3B@SOIC32 [(SA715)]
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]
AT90S1200 AT90S1200(ISP) [ISP-HEADER01]
AT90S1200@SOIC20 [(SA404)]
AT90S1200@SOIC20(ISP) [ISP-HEADER01]
AT90S1200@SSOP20 [(SA626A)]
AT90S1200@SSOP20(ISP) [ISP-HEADER01]
AT90S1200A AT90S1200A(ISP) [ISP-HEADER01]
AT90S1200A@SOIC20 [(SA404)]
AT90S1200A@SOIC20(ISP) [ISP-HEADER01]
AT90S1200A@SSOP20 [(SA626A)]
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]
AT90S2313 AT90S2313(ISP) [ISP-HEADER01]
AT90S2313@SOIC20 [(SA404)]
AT90S2313@SOIC20(ISP) [ISP-HEADER01]
AT90S2323 AT90S2323(ISP) [ISP-HEADER01]
AT90S2323@SOIC8 [(SA605A)]
AT90S2323@SOIC8(ISP) [ISP-HEADER01]
AT90S2333 AT90S2333(ISP) [ISP-HEADER01]
AT90S2333@TQFP32 [(SA663)]
AT90S2333@TQFP32(ISP) [ISP-HEADER01]
AT90S2343 AT90S2343(ISP) [ISP-HEADER01]
AT90S2343@SOIC8 [(SA605A)]
AT90S2343@SOIC8(ISP) [ISP-HEADER01]
AT90S4414 AT90S4414(ISP) [ISP-HEADER01]
AT90S4414@PLCC44 [(SA244)]
AT90S4414@PLCC44(ISP) [ISP-HEADER01]
AT90S4414@TQFP44 [(SA245A)]
AT90S4414@TQFP44(ISP) [ISP-HEADER01]
AT90S4433 AT90S4433(ISP) [ISP-HEADER01]
AT90S4433@TQFP32 [(SA663)]
AT90S4433@TQFP32(ISP) [ISP-HEADER01]
AT90S4434 AT90S4434(ISP) [ISP-HEADER01]
AT90S4434@PLCC44 [(SA244)]
AT90S4434@PLCC44(ISP) [ISP-HEADER01]
AT90S4434@TQFP44 [(SA245A)]
AT90S4434@TQFP44(ISP) [ISP-HEADER01]
AT90S8515 AT90S8515(ISP) [ISP-HEADER01]
AT90S8515@PLCC44 [(SA244)]
AT90S8515@PLCC44(ISP) [ISP-HEADER01]
AT90S8515@TQFP44 [(SA245A)]
AT90S8515@TQFP44(ISP) [ISP-HEADER01]
AT90S8535 AT90S8535(ISP) [ISP-HEADER01]
AT90S8535@PLCC44 [(SA244)]
AT90S8535@PLCC44(ISP) [ISP-HEADER01]
AT90S8535@TQFP44 [(SA245A)]
AT90S8535@TQFP44(ISP) [ISP-HEADER01]
AT90USB1286@QFN64 [(PEP+S702)]
AT90USB1286@QFN64(ISP) [ISP-HEADER01]
AT90USB1286@TQFP64 [(PEP+S625A)]
AT90USB1286@TQFP64(ISP) [ISP-HEADER01]
AT90USB1287@QFN64 [(PEP+S702)]
AT90USB1287@QFN64(ISP) [ISP-HEADER01]
AT90USB1287@TQFP64 [(PEP+S625A)]
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]
AT90USB162@QFN32 [(SA686)] AT90USB162@VQFP32 [(SA663)]
AT90USB646@QFN64 [(PEP+S702)]
AT90USB646@QFN64(ISP) [ISP-HEADER01]
AT90USB646@TQFP64 [(PEP+S625A)]
AT90USB646@TQFP64(ISP) [ISP-HEADER01]
AT90USB647@QFN64 [(PEP+S702)]
AT90USB647@QFN64(ISP) [ISP-HEADER01]
AT90USB647@TQFP64 [(PEP+S625A)]
AT90USB647@TQFP64(ISP) [ISP-HEADER01]
AT90USB82@QFN32 [(SA686)]
AT91FR40162@FBGA121 [(SA664B-B100A-W121F001)]
AT91FR40162S@FBGA121 [(SA664B-B100A-W121F001Y)]
AT91FR4042@FBGA121 [(SA664B-B100A-W121F001)]
AT91SAM7S128@LQFP64 [(PEP+S616)]
AT91SAM7S128@LQFP64(*) [(TA059-B006)]
AT91SAM7S128@QFN64 [(PEP+S702)]
AT91SAM7S128@QFN64(*) [(SA734-B318)]
AT91SAM7S256@LQFP64 [(PEP+S616)]
AT91SAM7S256@LQFP64(*) [(TA059-B006)]
AT91SAM7S256@QFN64 [(PEP+S702)]
AT91SAM7S256@QFN64(*) [(SA734-B318)]
AT91SAM7S32@LQFP48 [(SA248)] AT91SAM7S321@LQFP64 [(PEP+S616)]
AT91SAM7S321@LQFP64(*) [(TA059-B006)]
AT91SAM7S321@QFN64(*) [(SA734-B318)]
AT91SAM7S512@LQFP64 [(PEP+S616)] AT91SAM7S512@QFN64 [(PEP+S702)]

```

```

AT91SAM7S64(B)@LQFP64(*) [(TA059-B006)]
AT91SAM7S64@LQFP64 [(PEP+S616)]
AT91SAM7S64@LQFP64(*) [(TA059-B006)]
AT91SAM7S64@QFN64(*) [(SA734-B318)]
AT91SAM7S64B@LQFP64 [(PEP+S616)]
AT91SAM7SE512AU@LQFP128(*) [(SA720-B203)]
AT91SAM7X128@LQFP100 [(PEP+S604)]
AT91SAM7X128AU@LQFP100(*) [(SA718+B185)]
AT91SAM7X256@LQFP100 [(PEP+S604)]
AT91SAM7X256AU@LQFP100(*) [(SA718+B185)]
AT91SAM7XC128AU@LQFP100(*) [(SA718+B185)]
AT91SAM7XC256AU@LQFP100(*) [(SA718+B185)]
ATAM862@SSO24 [(SA026)] ATAM893@SSO20 [(SA026)]
ATAM894@SSO24 [(SA026)] ATMEGA103@TQFP64 [(PEP+S625A)]
ATMEGA103L@TQFP64 [(PEP+S625A)] ATMEGA128@QFN64 [(PEP+S702)]
ATMEGA128@QFN64(*) [(SA734+B211)]
ATMEGA128@QFN64(ISP) [ISP-HEADER01]
ATMEGA128@TQFP64 [(PEP+S625A)]
ATMEGA128@TQFP64(*) [(SA768+B211)]
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]
ATMEGA128@TQFP64(JTAG) [ISP-HEADER01]
ATMEGA1280@TQFP100(*) [(TA065+B006)]
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]
ATMEGA1280V@TQFP100(*) [(TA065+B006)]
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA1281@QFN64 [(PEP+S702)] ATMEGA1281@TQFP64 [(PEP+S625A)]
ATMEGA1281@TQFP64(*) [(TA057-B006)]
ATMEGA1284P ATMEGA1284P(ISP) [ISP-HEADER01]
ATMEGA1284P@MLF44 [(SA712)]
ATMEGA1284P@MLF44(ISP) [ISP-HEADER01]
ATMEGA1284P@TQFP44 [(SA245A)]
ATMEGA1284P@TQFP44(ISP) [ISP-HEADER01]
ATMEGA1284PV ATMEGA1284PV(ISP) [ISP-HEADER01]
ATMEGA1284PV@MLF44 [(SA712)]
ATMEGA1284PV@MLF44(ISP) [ISP-HEADER01]
ATMEGA1284PV@TQFP44 [(SA245A)]
ATMEGA1284PV@TQFP44(ISP) [ISP-HEADER01]
ATMEGA128L@QFN64 [(PEP+S702)]
ATMEGA128L@QFN64(*) [(SA734+B211)]
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]
ATMEGA128L@TQFP64 [(PEP+S625A)]
ATMEGA128L@TQFP64(*) [(SA768+B211)]
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA128L@TQFP64(JTAG) [ISP-HEADER01]
ATMEGA16 ATMEGA16(fast)
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44 [(SA245A)]
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16(JTAG) [ISP-HEADER01]
ATMEGA16@MLF44 [(SA712)]
ATMEGA16@MLF44(ISP) [ISP-HEADER01]
ATMEGA16@QFN44(JTAG) [ISP-HEADER01]
ATMEGA16@TQFP44 [(SA245A)]
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]
ATMEGA16@TQFP44(JTAG) [ISP-HEADER01]
ATMEGA161 ATMEGA161@TQFP44 [(SA245A)]
ATMEGA161L ATMEGA161L@TQFP44 [(SA245A)]
ATMEGA162 ATMEGA162(ISP) [ISP-HEADER01]
ATMEGA162@MLF44 [(SA712)]
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]
ATMEGA162@TQFP44 [(SA245A)]
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]
ATMEGA162V ATMEGA162V@MLF44 [(SA712)]
ATMEGA162V@TQFP44 [(SA245A)] ATMEGA163
ATMEGA163@TQFP44 [(SA245A)] ATMEGA163L
ATMEGA163L@TQFP44 [(SA245A)] ATMEGA164P
ATMEGA164P@MLP44 [(SA712)] ATMEGA164P@TQFP44 [(SA245A)]
ATMEGA164PL ATMEGA164PL@MLP44 [(SA712)]
ATMEGA164PL@TQFP44 [(SA245A)] ATMEGA165@QFN64 [(PEP+S702)]
ATMEGA165@QFN64(ISP) [ISP-HEADER01]
ATMEGA165@TQFP64 [(PEP+S625A)]
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]
ATMEGA168 ATMEGA168(ISP) [ISP-HEADER01]
ATMEGA168@MLP32 [(SA686)]
ATMEGA168@MLP32(ISP) [ISP-HEADER01]
ATMEGA168@TQFP32 [(SA663)]
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168P ATMEGA168P(ISP) [ISP-HEADER01]
ATMEGA168P@MLP32 [(SA686)]
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]
ATMEGA168P@TQFP32 [(SA663)]
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168PA ATMEGA168PA@MLP32 [(SA686)]

```

```

ATMEGA168PA@TQFP32 [(SA663)]          ATMEGA168PV
ATMEGA168PV(ISP) [ISP-HEADER01]      ATMEGA168PV@MLP32 [(SA686)]
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]
ATMEGA168PV@TQFP32 [(SA663)]
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168V          ATMEGA168V(ISP) [ISP-HEADER01]
ATMEGA168V@MLP32 [(SA686)]
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]
ATMEGA168V@TQFP32 [(SA663)]
ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA169@MLF64 [(PEP+S702)]
ATMEGA169@MLF64(ISP) [ISP-HEADER01]
ATMEGA169@TQFP64 [(PEP+S625A)]
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]
ATMEGA169P@MLF64 [(PEP+S702)]          ATMEGA169P@TQFP64 [(PEP+S625A)]
ATMEGA169PV@MLF64 [(PEP+S702)]
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]
ATMEGA169PV@TQFP64 [(PEP+S625A)]
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]
ATMEGA169V@MLF64 [(PEP+S702)]          ATMEGA169V@TQFP64 [(PEP+S625A)]
ATMEGA16L          ATMEGA16L(fast)
ATMEGA16L(fast)@MLF44 [(SA712)]
ATMEGA16L(fast)@TQFP44 [(SA245A)]
ATMEGA16L(ISP) [ISP-HEADER01]          ATMEGA16L(JTAG) [ISP-HEADER01]
ATMEGA16L@MLF44 [(SA712)]
ATMEGA16L@MLF44(ISP) [ISP-HEADER01]
ATMEGA16L@QFN44(JTAG) [ISP-HEADER01]
ATMEGA16L@TQFP44 [(SA245A)]
ATMEGA16L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA16L@TQFP44(JTAG) [ISP-HEADER01]
ATMEGA2560@TQFP100(*) [(TA065+B006)]
ATMEGA2560@TQFP100(ISP) [ISP-HEADER01]
ATMEGA2560V@TQFP100(*) [(TA065+B006)]
ATMEGA2560V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA2561@QFN64 [(PEP+S702)]
ATMEGA2561@QFN64(ISP) [ISP-HEADER01]
ATMEGA2561@TQFP64 [(PEP+S625A)]
ATMEGA2561@TQFP64(*) [(TA057-B006)]
ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]
ATMEGA2561V@QFN64 [(PEP+S702)]
ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]
ATMEGA2561V@TQFP64 [(PEP+S625A)]
ATMEGA2561V@TQFP64(*) [(TA057-B006)]
ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]
ATMEGA32          ATMEGA32(fuse)
ATMEGA32(fuse)@MLF44 [(SA712)]          ATMEGA32(fuse)@PLCC44 [(SA244)]
ATMEGA32(fuse)@TQFP44 [(SA245A)]          ATMEGA32(ISP) [ISP-HEADER01]
ATMEGA32(JTAG) [ISP-HEADER01]          ATMEGA32(new)
ATMEGA32(new)(fast)
ATMEGA32(new)(fast)@MLF44 [(SA712)]
ATMEGA32(new)(fast)@PLCC44 [(SA244)]
ATMEGA32(new)(fast)@TQFP44 [(SA245A)]
ATMEGA32(new)@MLF44 [(SA712)]          ATMEGA32(new)@PLCC44 [(SA244)]
ATMEGA32(new)@TQFP44 [(SA245A)]          ATMEGA32@MLF44 [(SA712)]
ATMEGA32@MLF44(ISP) [ISP-HEADER01]
ATMEGA32@PLCC44 [(SA244)]
ATMEGA32@QFN44(JTAG) [ISP-HEADER01]
ATMEGA32@TQFP44 [(SA245A)]
ATMEGA32@TQFP44(ISP) [ISP-HEADER01]
ATMEGA32@TQFP44(JTAG) [ISP-HEADER01]
ATMEGA323          ATMEGA323@TQFP44 [(SA245A)]
ATMEGA323L          ATMEGA323L@TQFP44 [(SA245A)]
ATMEGA324P          ATMEGA324P@MLP44 [(SA712)]
ATMEGA324P@TQFP44 [(SA245A)]          ATMEGA324PL
ATMEGA324PL@MLP44 [(SA712)]          ATMEGA324PL@TQFP44 [(SA245A)]
ATMEGA325@TQFP64 [(PEP+S625A)]
ATMEGA3250@TQFP100(*) [(TA065-B006)]
ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]
ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]
ATMEGA325V@QFN64 [(PEP+S702)]
ATMEGA325V@QFN64(ISP) [ISP-HEADER01]
ATMEGA328P          ATMEGA328P(ISP) [ISP-HEADER01]
ATMEGA328P@MLP32 [(SA686)]
ATMEGA328P@MLP32(ISP) [ISP-HEADER01]
ATMEGA328P@TQFP32 [(SA663)]
ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]
ATMEGA328PV          ATMEGA328PV(ISP) [ISP-HEADER01]
ATMEGA328PV@MLP32 [(SA686)]
ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]
ATMEGA328PV@TQFP32 [(SA663)]
ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]

```



```

ATMEGA329@QFN64 [(PEP+S702)]
ATMEGA329@QFN64(ISP) [ISP-HEADER01]
ATMEGA329@TQFP64 [(PEP+S625A)]
ATMEGA3290@TQFP100(*) [(TA065-B006)]
ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]
ATMEGA3290P@TQFP100(*) [(TA065-B006)]
ATMEGA329P@QFN64 [(PEP+S702)] ATMEGA329P@TQFP64 [(PEP+S625A)]
ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]
ATMEGA329PV@QFN64 [(PEP+S702)] ATMEGA329PV@TQFP64 [(PEP+S625A)]
ATMEGA329V@QFN64 [(PEP+S702)] ATMEGA329V@TQFP64 [(PEP+S625A)]
ATMEGA32L ATMEGA32L(fuse)
ATMEGA32L(fuse)@MLF44 [(SA712)] ATMEGA32L(fuse)@PLCC44 [(SA244)]
ATMEGA32L(fuse)@TQFP44 [(SA245A)]
ATMEGA32L(ISP) [ISP-HEADER01] ATMEGA32L(JTAG) [ISP-HEADER01]
ATMEGA32L(new) ATMEGA32L(new)(fast)
ATMEGA32L(new)(fast)@MLF44 [(SA712)]
ATMEGA32L(new)(fast)@PLCC44 [(SA244)]
ATMEGA32L(new)(fast)@TQFP44 [(SA245A)]
ATMEGA32L(new)@MLF44 [(SA712)] ATMEGA32L(new)@PLCC44 [(SA244)]
ATMEGA32L(new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44 [(SA712)]
ATMEGA32L@MLF44(ISP) [ISP-HEADER01]
ATMEGA32L@PLCC44 [(SA244)]
ATMEGA32L@QFN44(JTAG) [ISP-HEADER01]
ATMEGA32L@TQFP44 [(SA245A)]
ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA32L@TQFP44(JTAG) [ISP-HEADER01]
ATMEGA406@LQFP48 [(SA248)] ATMEGA48
ATMEGA48(ISP) [ISP-HEADER01] ATMEGA48@MLP32 [(SA686)]
ATMEGA48@MLP32(ISP) [ISP-HEADER01]
ATMEGA48@TQFP32 [(SA663)]
ATMEGA48@TQFP32(ISP) [ISP-HEADER01]
ATMEGA48P ATMEGA48P@MLP32 [(SA686)]
ATMEGA48P@TQFP32 [(SA663)] ATMEGA48PA
ATMEGA48PA@MLP32 [(SA686)] ATMEGA48PA@TQFP32 [(SA663)]
ATMEGA48PV ATMEGA48PV@MLP32 [(SA686)]
ATMEGA48PV@TQFP32 [(SA663)] ATMEGA48V
ATMEGA48V(ISP) [ISP-HEADER01] ATMEGA48V@MLP32 [(SA686)]
ATMEGA48V@MLP32(ISP) [ISP-HEADER01]
ATMEGA48V@TQFP32 [(SA663)]
ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA603@TQFP64 [(PEP+S625A)] ATMEGA603L@TQFP64 [(PEP+S625A)]
ATMEGA64@QFN64 [(PEP+S702)]
ATMEGA64@QFN64(ISP) [ISP-HEADER01]
ATMEGA64@QFN64(JTAG) [ISP-HEADER01]
ATMEGA64@TQFP64 [(PEP+S625A)]
ATMEGA64@TQFP64(*) [(SA768+B211)]
ATMEGA64@TQFP64(ISP) [ISP-HEADER01]
ATMEGA64@TQFP64(JTAG) [ISP-HEADER01]
ATMEGA640@TQFP100(*) [(TA065+B006)]
ATMEGA644 ATMEGA644(ISP) [ISP-HEADER01]
ATMEGA644(JTAG) [ISP-HEADER01] ATMEGA644@MLF44 [(SA712)]
ATMEGA644@MLF44(ISP) [ISP-HEADER01]
ATMEGA644@QFN44(JTAG) [ISP-HEADER01]
ATMEGA644@TQFP44 [(SA245A)]
ATMEGA644@TQFP44(ISP) [ISP-HEADER01]
ATMEGA644@TQFP44(JTAG) [ISP-HEADER01]
ATMEGA644P ATMEGA644P(ISP) [ISP-HEADER01]
ATMEGA644P@MLF44 [(SA712)]
ATMEGA644P@MLF44(ISP) [ISP-HEADER01]
ATMEGA644P@TQFP44 [(SA245A)]
ATMEGA644P@TQFP44(ISP) [ISP-HEADER01]
ATMEGA644PV ATMEGA644PV(ISP) [ISP-HEADER01]
ATMEGA644PV@MLF44 [(SA712)]
ATMEGA644PV@MLF44(ISP) [ISP-HEADER01]
ATMEGA644PV@TQFP44 [(SA245A)]
ATMEGA644PV@TQFP44(ISP) [ISP-HEADER01]
ATMEGA644V ATMEGA644V(ISP) [ISP-HEADER01]
ATMEGA644V@MLF44 [(SA712)]
ATMEGA644V@MLF44(ISP) [ISP-HEADER01]
ATMEGA644V@TQFP44 [(SA245A)]
ATMEGA644V@TQFP44(ISP) [ISP-HEADER01]
ATMEGA645@QFN64 [(PEP+S702)]
ATMEGA645@QFN64(ISP) [ISP-HEADER01]
ATMEGA645@TQFP64 [(PEP+S625A)]
ATMEGA645@TQFP64(ISP) [ISP-HEADER01]
ATMEGA6450@TQFP100(*) [(TA065-B006)]
ATMEGA6450@TQFP100(ISP) [ISP-HEADER01]
ATMEGA649@TQFP64 [(PEP+S625A)]
ATMEGA649@TQFP64(ISP) [ISP-HEADER01]
ATMEGA6490@TQFP100(*) [(TA065-B006)]
ATMEGA6490@TQFP100(ISP) [ISP-HEADER01]

```

```

ATMEGA649V@QFN64 [(PEP+S702)]
ATMEGA649V@QFN64(ISP) [ISP-HEADER01]
ATMEGA64L@QFN64 [(PEP+S702)]
ATMEGA64L@QFN64(ISP) [ISP-HEADER01]
ATMEGA64L@QFN64(JTAG) [ISP-HEADER01]
ATMEGA64L@TQFP64 [(PEP+S625A)]
ATMEGA64L@TQFP64(*) [(SA768+B211)]
ATMEGA64L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA64L@TQFP64(JTAG) [ISP-HEADER01]
ATMEGA8 ATMEGA8(fast)
ATMEGA8(fast)@TQFP32 [(SA663)] ATMEGA8(ISP) [ISP-HEADER01]
ATMEGA8@MLF32 [(SA686)]
ATMEGA8@MLF32(ISP) [ISP-HEADER01]
ATMEGA8@TQFP32 [(SA663)]
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]
ATMEGA8515 ATMEGA8515(fast)
ATMEGA8515(fast)@PLCC44 [(SA244)]
ATMEGA8515(fast)@TQFP44 [(SA245A)]
ATMEGA8515(ISP) [ISP-HEADER01] ATMEGA8515@PLCC44 [(SA244)]
ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515@TQFP44 [(SA245A)]
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8515L ATMEGA8515L(fast)
ATMEGA8515L(fast)@PLCC44 [(SA244)]
ATMEGA8515L(fast)@TQFP44 [(SA245A)]
ATMEGA8515L(ISP) [ISP-HEADER01] ATMEGA8515L@PLCC44 [(SA244)]
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515L@TQFP44 [(SA245A)]
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535 ATMEGA8535(fast)
ATMEGA8535(fast)@MLF44 [(SA712)]
ATMEGA8535(fast)@PLCC44 [(SA244)]
ATMEGA8535(fast)@TQFP44 [(SA245A)]
ATMEGA8535(ISP) [ISP-HEADER01] ATMEGA8535@PLCC44 [(SA244)]
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535@TQFP44 [(SA245A)]
ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535L ATMEGA8535L(fast)
ATMEGA8535L(fast)@MLF44 [(SA712)]
ATMEGA8535L(fast)@PLCC44 [(SA244)]
ATMEGA8535L(fast)@TQFP44 [(SA245A)]
ATMEGA8535L(ISP) [ISP-HEADER01] ATMEGA8535L@PLCC44 [(SA244)]
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535L@TQFP44 [(SA245A)]
ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA88 ATMEGA88(ISP) [ISP-HEADER01]
ATMEGA88@MLP32 [(SA686)]
ATMEGA88@MLP32(ISP) [ISP-HEADER01]
ATMEGA88@TQFP32 [(SA663)]
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]
ATMEGA88P ATMEGA88P@MLP32 [(SA686)]
ATMEGA88P@TQFP32 [(SA663)] ATMEGA88PA
ATMEGA88PA@MLP32 [(SA686)] ATMEGA88PA@TQFP32 [(SA663)]
ATMEGA88PV ATMEGA88PV@MLP32 [(SA686)]
ATMEGA88PV@TQFP32 [(SA663)] ATMEGA88V
ATMEGA88V(ISP) [ISP-HEADER01] ATMEGA88V@MLP32 [(SA686)]
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]
ATMEGA88V@TQFP32 [(SA663)]
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA8L ATMEGA8L(fast)
ATMEGA8L(fast)@TQFP32 [(SA663)] ATMEGA8L(ISP) [ISP-HEADER01]
ATMEGA8L@MLF32 [(SA686)]
ATMEGA8L@MLF32(ISP) [ISP-HEADER01]
ATMEGA8L@TQFP32 [(SA663)]
ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]
ATtiny10 ATtiny10(ISP) [ISP-HEADER01]
ATtiny10@SOIC8 [(SA605A)]
ATtiny10@SOIC8(ISP) [ISP-HEADER01]
ATtiny10@SOT23 [(SA717)]
ATtiny10@SOT23(ISP) [ISP-HEADER01]
ATtiny11 ATtiny11(ISP) [ISP-HEADER01]
ATtiny11@SOIC8 [(SA605A)]
ATtiny11@SOIC8(ISP) [ISP-HEADER01]
ATtiny11L ATtiny11L(ISP) [ISP-HEADER01]
ATtiny11L@SOIC8 [(SA605A)]
ATtiny11L@SOIC8(ISP) [ISP-HEADER01]
ATtiny12 ATtiny12(ISP) [ISP-HEADER01]
ATtiny12@SOIC8 [(SA605A)]
ATtiny12@SOIC8(ISP) [ISP-HEADER01]
ATtiny12L ATtiny12L(ISP) [ISP-HEADER01]
ATtiny12L@SOIC8 [(SA605A)]

```

```

Attiny12L@SOIC8(ISP) [ISP-HEADER01]
Attiny12V                               Attiny12V(ISP) [ISP-HEADER01]
Attiny12V@SOIC8 [(SA605A)]
Attiny12V@SOIC8(ISP) [ISP-HEADER01]
Attiny13                               Attiny13(Fuse)
Attiny13(Fuse)@QFN10 [(SA695A)]       Attiny13(Fuse)@QFN20 [(SA692)]
Attiny13(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
Attiny13(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
Attiny13(ISP) [ISP-HEADER01]          Attiny13@QFN10 [(SA695A)]
Attiny13@QFN10(ISP) [ISP-HEADER01]
Attiny13@QFN20 [(SA692)]
Attiny13@QFN20(ISP) [ISP-HEADER01]
Attiny13@SOIC8(3.9*6.2) [(SA602A)]
Attiny13@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
Attiny13@SOIC8(5.5*8.0) [(SA605A)]
Attiny13@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
Attiny13A                               Attiny13A(Fuse)
Attiny13A(Fuse)@QFN10 [(SA695A)]       Attiny13A(Fuse)@QFN20 [(SA692)]
Attiny13A(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
Attiny13A(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
Attiny13A@QFN10 [(SA695A)]            Attiny13A@QFN20 [(SA692)]
Attiny13A@SOIC8(3.9*6.2) [(SA602A)]
Attiny13A@SOIC8(5.5*8.0) [(SA605A)]
Attiny13V                               Attiny13V(Fuse)
Attiny13V(Fuse)@QFN10 [(SA695A)]       Attiny13V(Fuse)@QFN20 [(SA692)]
Attiny13V(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
Attiny13V(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
Attiny13V(ISP) [ISP-HEADER01]         Attiny13V@QFN10 [(SA695A)]
Attiny13V@QFN10(ISP) [ISP-HEADER01]
Attiny13V@QFN20 [(SA692)]
Attiny13V@QFN20(ISP) [ISP-HEADER01]
Attiny13V@SOIC8(3.9*6.2) [(SA602A)]
Attiny13V@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
Attiny13V@SOIC8(5.5*8.0) [(SA605A)]
Attiny13V@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
Attiny15                               Attiny15(ISP) [ISP-HEADER01]
Attiny15@SOIC8 [(SA605A)]
Attiny15@SOIC8(ISP) [ISP-HEADER01]
Attiny15L                               Attiny15L(ISP) [ISP-HEADER01]
Attiny15L@SOIC8 [(SA605A)]
Attiny15L@SOIC8(ISP) [ISP-HEADER01]
Attiny2313                             Attiny2313(ISP) [ISP-HEADER01]
Attiny2313@MLF20 [(SA692)]
Attiny2313@MLF20(ISP) [ISP-HEADER01]
Attiny2313@SOIC20 [(SA404)]
Attiny2313@SOIC20(ISP) [ISP-HEADER01]
Attiny2313V                             Attiny2313V(ISP) [ISP-HEADER01]
Attiny2313V@MLF20 [(SA692)]
Attiny2313V@MLF20(ISP) [ISP-HEADER01]
Attiny2313V@SOIC20 [(SA404)]
Attiny2313V@SOIC20(ISP) [ISP-HEADER01]
Attiny24                               Attiny24(Fuse)
Attiny24(Fuse)@QFN20 [(SA692)]         Attiny24(Fuse)@SOIC14 [(SA602)]
Attiny24(ISP) [ISP-HEADER01]          Attiny24@QFN20 [(SA692)]
Attiny24@QFN20(ISP) [ISP-HEADER01]
Attiny24@SOIC14 [(SA602)]
Attiny24@SOIC14(ISP) [ISP-HEADER01]
Attiny24V                               Attiny24V(Fuse)
Attiny24V(Fuse)@QFN20 [(SA692)]       Attiny24V(Fuse)@SOIC14 [(SA602)]
Attiny24V(ISP) [ISP-HEADER01]         Attiny24V@QFN20 [(SA692)]
Attiny24V@QFN20(ISP) [ISP-HEADER01]
Attiny24V@SOIC14 [(SA602)]
Attiny24V@SOIC14(ISP) [ISP-HEADER01]
Attiny25                               Attiny25(ISP) [ISP-HEADER01]
Attiny25@QFN20 [(SA692)]
Attiny25@QFN20(ISP) [ISP-HEADER01]
Attiny25@SOIC8 [(SA023A)]
Attiny25@SOIC8(ISP) [ISP-HEADER01]
Attiny26                               Attiny26(ISP) [ISP-HEADER01]
Attiny26(new)
Attiny26(new)(ISP) [ISP-HEADER01]
Attiny26(new)@QFN32 [(SA686)]         Attiny26(new)@SOIC20 [(SA404)]
Attiny26(new)@SOIC20(ISP) [ISP-HEADER01]
Attiny26(new)@TSSOP20 [(SA026)]
Attiny26(new)@TSSOP20(ISP) [ISP-HEADER01]
Attiny26@QFN32 [(SA686)]             Attiny26@SOIC20 [(SA404)]
Attiny26@SOIC20(ISP) [ISP-HEADER01]
Attiny26@TSSOP20 [(SA026)]
Attiny26@TSSOP20(ISP) [ISP-HEADER01]
Attiny261                               Attiny261(ISP) [ISP-HEADER01]
Attiny261@MLP32 [(SA686)]

```

```

Attiny261@MLP32(ISP) [ISP-HEADER01]
Attiny261@SOIC20 [(SA404)]
Attiny261@SOIC20(ISP) [ISP-HEADER01]
Attiny261V                                     Attiny261V(ISP) [ISP-HEADER01]
Attiny261V@MLP32 [(SA686)]
Attiny261V@MLP32(ISP) [ISP-HEADER01]
Attiny261V@SOIC20 [(SA404)]
Attiny261V@SOIC20(ISP) [ISP-HEADER01]
Attiny26L                                     Attiny26L(ISP) [ISP-HEADER01]
Attiny26L(new)
Attiny26L(new)(ISP) [ISP-HEADER01]
Attiny26L(new)@QFN32 [(SA686)]       Attiny26L(new)@SOIC20 [(SA404)]
Attiny26L(new)@SOIC20(ISP) [ISP-HEADER01]
Attiny26L(new)@TSSOP20 [(SA026)]
Attiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]
Attiny26L@QFN32 [(SA686)]       Attiny26L@SOIC20 [(SA404)]
Attiny26L@SOIC20(ISP) [ISP-HEADER01]
Attiny26L@TSSOP20 [(SA026)]
Attiny26L@TSSOP20(ISP) [ISP-HEADER01]
Attiny28L                                     Attiny28L@TQFP32 [(SA663)]
Attiny28V                                     Attiny28V@TQFP32 [(SA663)]
Attiny44                                     Attiny44(ISP) [ISP-HEADER01]
Attiny44@QFN20 [(SA692)]
Attiny44@QFN20(ISP) [ISP-HEADER01]
Attiny44@SOIC14 [(SA602)]
Attiny44@SOIC14(ISP) [ISP-HEADER01]
Attiny45
Attiny45(ISP)(12V) [ISP-HEADER01]
Attiny45(ISP)(5V) [ISP-HEADER01]       Attiny45@QFN20 [(SA692)]
Attiny45@QFN20(ISP)(12V) [ISP-HEADER01]
Attiny45@QFN20(ISP)(5V) [ISP-HEADER01]
Attiny45@SOIC8 [(S605)]
Attiny45@SOIC8(ISP)(12V) [ISP-HEADER01]
Attiny45@SOIC8(ISP)(5V) [ISP-HEADER01]
Attiny461                                     Attiny461(ISP) [ISP-HEADER01]
Attiny461@MLP32 [(SA686)]
Attiny461@MLP32(ISP) [ISP-HEADER01]
Attiny461@SOIC20 [(SA404)]
Attiny461@SOIC20(ISP) [ISP-HEADER01]
Attiny461V                                     Attiny461V(ISP) [ISP-HEADER01]
Attiny461V@MLP32 [(SA686)]
Attiny461V@MLP32(ISP) [ISP-HEADER01]
Attiny461V@SOIC20 [(SA404)]
Attiny461V@SOIC20(ISP) [ISP-HEADER01]
Attiny48                                     Attiny48(ISP) [ISP-HEADER01]
Attiny48@MLF32 [(SA686)]
Attiny48@MLF32(ISP) [ISP-HEADER01]
Attiny48@TQFP32 [(SA663)]
Attiny48@TQFP32(ISP) [ISP-HEADER01]
Attiny48V                                     Attiny48V(ISP) [ISP-HEADER01]
Attiny48V@MLF32 [(SA686)]
Attiny48V@MLF32(ISP) [ISP-HEADER01]
Attiny48V@TQFP32 [(SA663)]
Attiny48V@TQFP32(ISP) [ISP-HEADER01]
Attiny84                                     Attiny84(ISP) [ISP-HEADER01]
Attiny84@QFN20 [(SA692)]
Attiny84@QFN20(ISP) [ISP-HEADER01]
Attiny84@SOIC14 [(SA602)]
Attiny84@SOIC14(ISP) [ISP-HEADER01]
Attiny85
Attiny85(ISP)(12V) [ISP-HEADER01]
Attiny85(ISP)(5V) [ISP-HEADER01]       Attiny85@QFN20 [(SA692)]
Attiny85@QFN20(ISP)(12V) [ISP-HEADER01]
Attiny85@QFN20(ISP)(5V) [ISP-HEADER01]
Attiny85@SOIC8 [(S605)]
Attiny85@SOIC8(ISP)(12V) [ISP-HEADER01]
Attiny85@SOIC8(ISP)(5V) [ISP-HEADER01]
Attiny861                                     Attiny861(ISP) [ISP-HEADER01]
Attiny861@MLP32 [(SA686)]
Attiny861@MLP32(ISP) [ISP-HEADER01]
Attiny861@SOIC20 [(SA404)]
Attiny861@SOIC20(ISP) [ISP-HEADER01]
Attiny861V                                     Attiny861V(ISP) [ISP-HEADER01]
Attiny861V@MLP32 [(SA686)]
Attiny861V@MLP32(ISP) [ISP-HEADER01]
Attiny861V@SOIC20 [(SA404)]
Attiny861V@SOIC20(ISP) [ISP-HEADER01]
Attiny88                                     Attiny88(ISP) [ISP-HEADER01]
Attiny88@MLF32 [(SA686)]
Attiny88@MLF32(ISP) [ISP-HEADER01]
Attiny88@TQFP32 [(SA663)]

```

```

ATtiny88@TQFP32(ISP) [ISP-HEADER01]
ATtiny88V
ATtiny88V@MLF32 [(SA686)]
ATtiny88V@MLF32(ISP) [ISP-HEADER01]
ATtiny88V@TQFP32 [(SA663)]
ATtiny88V@TQFP32(ISP) [ISP-HEADER01]
T89C51SND1@TQFP80 [(PEP+S704)]
T89F64@PLCC44 [(SA244)]
ATtiny88V(ISP) [ISP-HEADER01]
T89F64
T89F64@TQFP44 [(SA245A)]
    
```

## ATMEL W&M

### MICROCONTROLLER

```

AT89C5115@PLCC28 [(SA008A)]
AT89C5115@TQFP32 [(SA663)]
AT89C51CC02@SOIC28 [(SA404)]
T89C5115@PLCC28 [(SA008A)]
T89C5115@TQFP32 [(SA663)]
T89C51AC2@TQFP44 [(SA245A)]
T89C51CC01@TQFP44 [(SA245A)]
T89C51CC02@SOIC28 [(SA404)]
T89C51CC02@TQFP32 [(SA663)]
T89C51IB2@TQFP44 [(SA245A)]
T89C51IC2@TQFP44 [(SA245A)]
T89C51RB2@PLCC44 [(SA244)]
T89C51RC2
T89C51RC2@TQFP44 [(SA245A)]
T89C51RD2@PLCC44 [(SA244)]
T89C51RD2@TQFP44 [(SA245A)]
T89F64@PLCC44 [(SA244)]
TS87C51RB2
TS87C51RB2@TQFP44 [(SA245A)]
TS87C51RC2@PLCC44 [(SA244)]
TS87C51RD2
TS87C51RD2@TQFP44 [(SA245A)]
TS87C51U2@PLCC44 [(SA244)]
TS87C52X2
TS87C52X2@TQFP44 [(SA245A)]
TS87C54X2@PLCC44 [(SA244)]
TS87C58X2
TS87C58X2@TQFP44 [(SA245A)]
TSC87251G1
TSC87251G1A
TSC87251G2D
TSC87251G2D@TQFP44 [(SA245A)]
TSC87C51@PLCC44 [(SA244)]
AT89C5115@SOIC28 [(SA404)]
AT89C51CC02@PLCC28 [(SA008A)]
AT89C51CC02@TQFP32 [(SA663)]
T89C5115@SOIC28 [(SA404)]
T89C51AC2@PLCC44 [(SA244)]
T89C51CC01@PLCC44 [(SA244)]
T89C51CC02@PLCC28 [(SA008A)]
T89C51CC02@SOIC28 [(SA404)]
T89C51IB2@PLCC44 [(SA244)]
T89C51IC2@PLCC44 [(SA244)]
T89C51RB2
T89C51RB2@TQFP44 [(SA245A)]
T89C51RC2@PLCC44 [(SA244)]
T89C51RD2
T89C51RD2@PLCC68 [(PEP+S414T)]
T89F64
T89F64@TQFP44 [(SA245A)]
TS87C51RB2@PLCC44 [(SA244)]
TS87C51RC2
TS87C51RC2@TQFP44 [(SA245A)]
TS87C51RD2@PLCC44 [(SA244)]
TS87C51U2
TS87C51U2@TQFP44 [(SA245A)]
TS87C52X2@PLCC44 [(SA244)]
TS87C54X2
TS87C54X2@TQFP44 [(SA245A)]
TS87C58X2@PLCC44 [(SA244)]
TSC87251A1@PLCC44 [(SA244)]
TSC87251G1@PLCC44 [(SA244)]
TSC87251G1A@PLCC44 [(SA244)]
TSC87251G2D@PLCC44 [(SA244)]
TSC87C51
TSC87C51@TQFP44 [(SA245A)]
    
```

## ATMEL-CUSTOMER

### E(E) PROM/FRAM/NVRAM

```

AT24C01
AT24C04
AT24C16
AT24C02
AT24C08
    
```

## AUSTIN

### E(E) PROM/FRAM/NVRAM

```

AS8E512K8
AS8E512K8@SOJ32 [(SA661)]
    
```

## BELLING-SYSTRON

### MICROCONTROLLER

```

CM5001
    
```

## BENCHMARK

### E (E) PROM/FRAM/NVRAM

BQ4010	BQ4010Y
BQ4011	BQ4011Y
BQ4013	BQ4013Y
BQ4014	BQ4014Y
BQ4015	BQ4015Y
BQ4832Y	BQ4842Y

## BMT

### E (E) PROM/FRAM/NVRAM

BM29LV160B@FBGA48	[(SA642Z-B026A-W048F001Y)]
BM29LV160B@TSOP48	[(SA247-B005)]
BM29LV160T@FBGA48	[(SA642Z-B026A-W048F001Y)]
BM29LV160T@TSOP48	[(SA247-B005)]

## BOSEN

### E (E) PROM/FRAM/NVRAM

M28W320FST@FBGA47	[(SA714B-B026A-T048F001Y)]
M28W640FSB@FBGA64	[(SA655E-B090A-T064F001Y)]
PC28F640P30B@EBGA64	[(SA655G-B122A-T064F001Y)]
PC28F640P30T@EBGA64	[(SA655G-B122A-T064F001Y)]
S29GL128PFFIS1@FBGA64	[(SA655F-B099A-W064F001Y)]
S29GL512PFFI02@FBGA64	[(SA655F-B287A-W064F001Y)]
S29GL512PTFI02@TSOP56	[(SA628-B257)]
S71WS256NC0BAWA7@FBGA84	[(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAM@FBGA84	[(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWA7@FBGA84	[(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAM@FBGA84	[(SA642A-B139A-Y096F001Y)]
SST39VF800@TSOP48	[(SA247)]
SST39VF800A@FBGA48	[(SA642G-B026A-T048F001Y)]
SST39VF800A@TSOP48	[(SA247)]
SST39VF800Q@TSOP48	[(SA247)]

## BRIGHT

### E (E) PROM/FRAM/NVRAM

BM29F040	BM29F040@PLCC32 [(SA015A1T)]
BM29F040@TSOP32 [(SA410T)]	BM29F400B@PSOP44 [(SA638-B006)]
BM29F400B@TSOP48 [(SA247-B005)]	BM29F400T@PSOP44 [(SA638-B006)]
BM29F400T@TSOP48 [(SA247-B005)]	

## CATALYST

### E (E) PROM/FRAM/NVRAM

CAT1021(L)	CAT1021(P)
CAT1021(R)@MSOP8 [(SA026)]	CAT1021(S)@SOIC8 [(SA602A)]
CAT1021(U)@TSSOP8 [(SA026)]	CAT1021(V)@SOIC8 [(SA602A)]
CAT1021(Y)@TSSOP8 [(SA026)]	CAT1021(Z)@MSOP8 [(SA026)]
CAT1022(L)	CAT1022(P)
CAT1022(R)@MSOP8 [(SA026)]	CAT1022(S)@SOIC8 [(SA602A)]
CAT1022(U)@TSSOP8 [(SA026)]	CAT1022(V)@SOIC8 [(SA602A)]
CAT1022(Y)@TSSOP8 [(SA026)]	CAT1022(Z)@MSOP8 [(SA026)]
CAT1023(L)	CAT1023(P)
CAT1023(R)@MSOP8 [(SA026)]	CAT1023(S)@SOIC8 [(SA602A)]
CAT1023(U)@TSSOP8 [(SA026)]	CAT1023(V)@SOIC8 [(SA602A)]
CAT1023(Y)@TSSOP8 [(SA026)]	CAT1023(Z)@MSOP8 [(SA026)]
CAT1024(L)	CAT1024(P)
CAT1024(R)@MSOP8 [(SA026)]	CAT1024(S)@SOIC8 [(SA602A)]
CAT1024(U)@TSSOP8 [(SA026)]	CAT1024(V)@SOIC8 [(SA602A)]

CAT1024(Y)@TSSOP8 [(SA026)]	CAT1024(Z)@MSOP8 [(SA026)]
CAT1025(L)	CAT1025(P)
CAT1025(R)@MSOP8 [(SA026)]	CAT1025(S)@SOIC8 [(SA602A)]
CAT1025(U)@TSSOP8 [(SA026)]	CAT1025(V)@SOIC8 [(SA602A)]
CAT1025(Y)@TSSOP8 [(SA026)]	CAT1025(Z)@MSOP8 [(SA026)]
CAT1026(L)	CAT1026(P)
CAT1026(R)@MSOP8 [(SA026)]	CAT1026(S)@SOIC8 [(SA602A)]
CAT1026(U)@TSSOP8 [(SA026)]	CAT1026(V)@SOIC8 [(SA602A)]
CAT1026(Y)@TSSOP8 [(SA026)]	CAT1026(Z)@MSOP8 [(SA026)]
CAT1027(L)	CAT1027(P)
CAT1027(R)@MSOP8 [(SA026)]	CAT1027(S)@SOIC8 [(SA602A)]
CAT1027(U)@TSSOP8 [(SA026)]	CAT1027(V)@SOIC8 [(SA602A)]
CAT1027(Y)@TSSOP8 [(SA026)]	CAT1027(Z)@MSOP8 [(SA026)]
CAT1161(J)@SOIC8 [(SA602A)]	CAT1161(P)
CAT1162(J)@SOIC8 [(SA602A)]	CAT1162(P)
CAT1163(J)@SOIC8 [(SA602A)]	CAT1163(P)
CAT1320	CAT1320@SOIC8 [(SA602A)]
CAT1320@TDFN8	CAT1320@TSSOP8 [(SA026)]
CAT1321	CAT1321@SOIC8 [(SA602A)]
CAT1321@TDFN8	CAT1321@TSSOP8 [(SA026)]
CAT14002@SOIC8 [(SA602A)]	CAT14004@SOIC8 [(SA602A)]
CAT14008@SOIC8 [(SA602A)]	CAT14016@SOIC8 [(SA602A)]
CAT15002@SOIC8 [(SA602A)]	CAT15004@SOIC8 [(SA602A)]
CAT15008@SOIC8 [(SA602A)]	CAT15016@SOIC8 [(SA602A)]
CAT1640	CAT1640@SOIC8 [(SA602A)]
CAT1640@TDFN8	CAT1640@TSSOP8 [(SA026)]
CAT1641	CAT1641@SOIC8 [(SA602A)]
CAT1641@TDFN8	CAT1641@TSSOP8 [(SA026)]
CAT2210	CAT2210@SOIC16 [(SA404)]
CAT2210I	CAT2210I@SOIC16 [(SA404)]
CAT2212	CAT2212@SOIC20 [(SA404)]
CAT2212I	CAT2212I@SOIC20 [(SA404)]
CAT22C10	CAT22C10@SOIC16 [(SA404)]
CAT22C10I	CAT22C10I@SOIC16 [(SA404)]
CAT22C12	CAT22C12@SOIC20 [(SA404)]
CAT22C12I	CAT22C12I@SOIC20 [(SA404)]
CAT24AA01@SOIC8 [(SA602A)]	CAT24AA01@TSOT-23 [(SA717)]
CAT24AA02@SOIC8 [(SA602A)]	CAT24AA02@TSOT-23 [(SA717)]
CAT24AA04@SOIC8 [(SA602A)]	CAT24AA04@TSOT-23 [(SA717)]
CAT24AA08@SOIC8 [(SA602A)]	CAT24AA08@TSOT-23 [(SA717)]
CAT24AA16@SOIC8 [(SA602A)]	CAT24AA16@TSOT-23 [(SA717)]
CAT24AC128	CAT24AC128@SOIC8 [(SA602A)]
CAT24AC128@TSSOP14 [(SA026)]	CAT24AC128@UDFN8 [(SA724)]
CAT24C00	CAT24C00@SOIC8 [(SA602A)]
CAT24C00@TSSOP8 [(SA026)]	CAT24C01
CAT24C01@SOIC14 [(SA602)]	CAT24C01@SOIC8 [(SA602A)]
CAT24C01@TSSOP8 [(SA026)]	CAT24C01B(J)@SOIC8 [(SA602A)]
CAT24C01B(L)	CAT24C01B(P)
CAT24C01B(R)@MSOP8 [(SA026)]	CAT24C01B(U)@TSSOP8 [(SA026)]
CAT24C01B(W)@SOIC8 [(SA602A)]	CAT24C01B(Y)@TSSOP8 [(SA026)]
CAT24C01B(Z)@MSOP8 [(SA026)]	CAT24C02
CAT24C02@SOIC14 [(SA602)]	CAT24C02@SOIC8 [(SA602A)]
CAT24C02@TSSOP8 [(SA026)]	CAT24C021
CAT24C022	CAT24C023
CAT24C03	CAT24C03@SOIC8 [(SA602A)]
CAT24C03@TSSOP8 [(SA026)]	CAT24C04
CAT24C04@SOIC14 [(SA602)]	CAT24C04@SOIC8 [(SA602A)]
CAT24C04@TSSOP8 [(SA026)]	CAT24C041
CAT24C042	CAT24C043
CAT24C05	CAT24C05@SOIC8 [(SA602A)]
CAT24C05@TSSOP8 [(SA026)]	CAT24C08
CAT24C08@SOIC14 [(SA602)]	CAT24C08@SOIC8 [(SA602A)]
CAT24C08@TSSOP8 [(SA026)]	CAT24C081
CAT24C082	CAT24C083
CAT24C08I	CAT24C08I@SOIC8 [(SA602A)]
CAT24C09	CAT24C09@SOIC8 [(SA602A)]
CAT24C09@TSSOP8 [(SA026)]	CAT24C128
CAT24C128@SOIC8 [(SA602A)]	CAT24C128@UDFN8 [(SA724)]
CAT24C16	CAT24C16@SOIC14 [(SA602)]
CAT24C16@SOIC8 [(SA602A)]	CAT24C16@TSSOP8 [(SA026)]
CAT24C161	CAT24C162
CAT24C163	CAT24C164
CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8 [(SA026)]
CAT24C16I	CAT24C16I@SOIC8 [(SA602A)]
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208(L)
CAT24C208(P)	CAT24C208(R)@MSOP8 [(SA666)]
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8 [(SA602A)]
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8 [(SA666)]
CAT24C21	CAT24C21@SOIC8 [(SA602A)]
CAT24C21@TSSOP8 [(SA026)]	CAT24C256
CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8 [(SA683)]

CAT24C256@TSSOP8 [(SA026)]	CAT24C32
CAT24C32@SOIC8 [(SA602A)]	CAT24C44
CAT24C44@SOIC8 [(SA602A)]	CAT24C64
CAT24C64@SOIC8 [(SA602A)]	CAT24F32
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8 [(SA026)]
CAT24F32A	CAT24F32A@SOIC8 [(SA602A)]
CAT24F32A@TSSOP8 [(SA026)]	CAT24FC01
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8 [(SA602A)]
CAT24FC01@TSSOP8 [(SA026)]	CAT24FC02
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8 [(SA602A)]
CAT24FC02@TSSOP8 [(SA026)]	CAT24FC16
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8 [(SA602A)]
CAT24FC16@TSSOP8 [(SA026)]	CAT24FC17
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8 [(SA026)]
CAT24FC256	CAT24FC256@SOIC8 [(SA602A)]
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8 [(SA026)]
CAT24FC32	CAT24FC32@SOIC8 [(SA602A)]
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8 [(SA026)]
CAT24FC64	CAT24FC64@SOIC8 [(SA602A)]
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8 [(SA026)]
CAT24FC65	CAT24FC65@SOIC8 [(SA602A)]
CAT24FC65@TDFN8 [(SA683)]	CAT24FC65@TSSOP8 [(SA026)]
CAT24FC66	CAT24FC66@SOIC8 [(SA602A)]
CAT24FC66@TDFN8 [(SA683)]	CAT24FC66@TSSOP8 [(SA026)]
CAT24LC02	CAT24LC02@SOIC8 [(SA602A)]
CAT24LC02@TSSOP8 [(SA026)]	CAT24WC01
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8 [(SA026)]
CAT24WC02	CAT24WC02@SOIC8 [(SA602A)]
CAT24WC02@TSSOP8 [(SA026)]	CAT24WC03
CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8 [(SA026)]
CAT24WC04	CAT24WC04@SOIC8 [(SA602A)]
CAT24WC04@TSSOP8 [(SA026)]	CAT24WC05
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8 [(SA026)]
CAT24WC08	CAT24WC08@SOIC8 [(SA602A)]
CAT24WC08@TSSOP8 [(SA026)]	CAT24WC09
CAT24WC09@SOIC8 [(SA602A)]	CAT24WC09@TSSOP8 [(SA026)]
CAT24WC128	CAT24WC128@SOIC8 [(SA602A)]
CAT24WC129	CAT24WC129@SOIC8 [(SA602A)]
CAT24WC16	CAT24WC16@SOIC8 [(SA602A)]
CAT24WC16@TSSOP8 [(SA026)]	CAT24WC164
CAT24WC164@SOIC8 [(SA602A)]	CAT24WC164@TSSOP8 [(SA026)]
CAT24WC17	CAT24WC17@SOIC8 [(SA602A)]
CAT24WC17@TSSOP8 [(SA026)]	CAT24WC256
CAT24WC256@SOIC8 [(SA602A)]	CAT24WC256@TDFN8 [(SA683)]
CAT24WC256@TSSOP8 [(SA026)]	CAT24WC257
CAT24WC257@SOIC8 [(SA605A)]	CAT24WC32
CAT24WC32@SOIC8 [(SA602A)]	CAT24WC33
CAT24WC33@SOIC8 [(SA602A)]	CAT24WC64
CAT24WC64@SOIC8 [(SA602A)]	CAT24WC65
CAT24WC65@SOIC8 [(SA602A)]	CAT24WC66
CAT24WC66@SOIC8 [(SA602A)]	CAT25010
CAT25010(S)@SOIC8 [(SA605A)]	CAT25010(U)@TSSOP8 [(SA602A)]
CAT25020	CAT25020(S)@SOIC8 [(SA605A)]
CAT25020(U)@TSSOP8 [(SA602A)]	CAT25040
CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8 [(SA602A)]
CAT25080	CAT25080@SOIC8 [(SA602A)]
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8 [(SA026)]
CAT25080@UDFN8 [(BBBB)]	CAT25128
CAT25128@SOIC8[150 mil] [(SA602A)]	CAT25128@TSSOP8 [(SA026)]
CAT25128@SOIC8[208 mil] [(SA605A)]	CAT25160@SOIC8 [(SA602A)]
CAT25128@TDFN8 [(SA724)]	CAT25160@TSSOP8 [(SA026)]
CAT25160	CAT25256
CAT25160@TDFN8 [(SA724)]	CAT25256@TSSOP8 [(SA026)]
CAT25160@UDFN8 [(BBBB)]	CAT25320@SOIC8 [(SA602A)]
CAT25256@SOIC8[150 mil] [(SA602A)]	CAT25320@TSSOP8 [(SA026)]
CAT25256@SOIC8[208 mil] [(SA605A)]	CAT25640@SOIC8 [(SA602A)]
CAT25256@TDFN8 [(SA602A)]	CAT25640@TSSOP8 [(SA026)]
CAT25320	CAT25C01@SOIC16 [(SA602)]
CAT25320@TDFN8 [(SA724)]	CAT25C01@TSSOP14 [(SA026)]
CAT25640	CAT25C02
CAT25640@TDFN8 [(SA724)]	CAT25C02@SOIC8 [(SA602A)]
CAT25C01	CAT25C02@TSSOP8 [(SA026)]
CAT25C01@SOIC8 [(SA602A)]	CAT25C03@SOIC8 [(SA602A)]
CAT25C01@TSSOP8 [(SA026)]	CAT25C03@TSSOP8 [(SA026)]
CAT25C02@SOIC16 [(SA602)]	CAT25C04@SOIC16 [(SA602)]
CAT25C02@TSSOP14 [(SA026)]	CAT25C04@TSSOP14 [(SA026)]
CAT25C03	CAT25C05
CAT25C03@TSSOP14 [(SA026)]	
CAT25C04	
CAT25C04@SOIC8 [(SA602A)]	
CAT25C04@TSSOP8 [(SA026)]	



CAT25C05@SOIC8 [(SA602A)]	CAT25C05@TSSOP14 [(SA026)]
CAT25C05@TSSOP8 [(SA026)]	CAT25C08
CAT25C08@SOIC16 [(SA602)]	CAT25C08@SOIC8 [(SA602A)]
CAT25C08@TSSOP14 [(SA026)]	CAT25C08@TSSOP8 [(SA026)]
CAT25C09	CAT25C09@SOIC8 [(SA602A)]
CAT25C09@TSSOP14 [(SA026)]	CAT25C09@TSSOP8 [(SA026)]
CAT25C11	CAT25C11@SOIC8 [(SA602A)]
CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8 [(SA026)]
CAT25C128	CAT25C128@SOIC16 [(SA602)]
CAT25C128@SOIC8[150 mil] [(SA602A)]	
CAT25C128@SOIC8[208 mil] [(SA605A)]	
CAT25C128@TSSOP14 [(SA026)]	CAT25C128@TSSOP20 [(SA026)]
CAT25C16	CAT25C16@SOIC16 [(SA602)]
CAT25C16@SOIC8 [(SA602A)]	CAT25C16@TSSOP14 [(SA026)]
CAT25C16@TSSOP8 [(SA026)]	CAT25C17
CAT25C17@SOIC8 [(SA602A)]	CAT25C17@TSSOP14 [(SA026)]
CAT25C17@TSSOP8 [(SA026)]	CAT25C256
CAT25C256@SOIC16 [(SA602)]	
CAT25C256@SOIC8[150 mil] [(SA602A)]	CAT25C256@TSSOP20 [(SA026)]
CAT25C256@SOIC8[208 mil] [(SA605A)]	CAT25C32@SOIC8 [(SA602A)]
CAT25C256@TSSOP14 [(SA026)]	CAT25C32@TSSOP20 [(SA026)]
CAT25C32	CAT25C33@SOIC8 [(SA602A)]
CAT25C32@TSSOP14 [(SA026)]	CAT25C64
CAT25C33	CAT25C64@TSSOP14 [(SA026)]
CAT25C33@TSSOP14 [(SA026)]	CAT25C65
CAT25C64@SOIC8 [(SA602A)]	CAT25C65@TSSOP14 [(SA026)]
CAT25C64@TSSOP20 [(SA026)]	CAT27010@PLCC32 [(SA015A1T)]
CAT25C65@SOIC8 [(SA602A)]	CAT27128A
CAT27010	CAT27512
CAT27010@TSOP32 [(SA410T)]	CAT2764A
CAT27256	CAT27C210
CAT27512@PLCC32 [(SA015A1T)]	CAT27HC256
CAT27C16A	CAT27HC256I
CAT27C210@PLCC44 [(SA244)]	CAT28C16A
CAT27HC256@PLCC32 [(SA015A1T)]	CAT28C16A@SOIC24 [(SA404)]
CAT27HC256I@PLCC32 [(SA015A1T)]	CAT28C16AI@PLCC32 [(SA015A1T)]
CAT28C16A@PLCC32 [(SA015A1T)]	CAT28C17A
CAT28C16AI	CAT28C17AI
CAT28C16AI@SOIC24 [(SA404)]	CAT28C256
CAT28C17A@PLCC32 [(SA015A1T)]	CAT28C256@TSOP28 [(SA430T)]
CAT28C17AI@PLCC32 [(SA015A1T)]	CAT28C256I@PLCC32 [(SA015A1T)]
CAT28C256@PLCC32 [(SA015A1T)]	CAT28C257
CAT28C256I	CAT28C257@TSOP28 [(SA430T)]
CAT28C256I@TSOP28 [(SA430T)]	CAT28C512@PLCC32 [(SA015A1T)]
CAT28C257@PLCC32 [(SA015A1T)]	CAT28C512@TSOP40 [(SA409T)]
CAT28C512	CAT28C64A
CAT28C512@TSOP32 [(SA410T)]	CAT28C64A@SOIC28 [(SA404)]
CAT28C513@PLCC32 [(SA015A1T)]	CAT28C64AI@PLCC32 [(SA015A1T)]
CAT28C64A@PLCC32 [(SA015A1T)]	CAT28C64B
CAT28C64AI	CAT28C64B@TSOP28 [(SA430T)]
CAT28C64AI@SOIC28 [(SA404)]	CAT28C64BI@PLCC32 [(SA015A1T)]
CAT28C64B@PLCC32 [(SA015A1T)]	CAT28C65B
CAT28C64BI	CAT28C65B@TSOP28 [(SA430T)]
CAT28C64BI@TSOP28 [(SA430T)]	CAT28C65BI@PLCC32 [(SA015A1T)]
CAT28C65B@PLCC32 [(SA015A1T)]	CAT28F001N-B@PLCC32 [(SA015A1T)]
CAT28C65BI	CAT28F001P-B
CAT28C65BI@TSOP28 [(SA430T)]	CAT28F001T-B@TSOP32 [(SA410T)]
CAT28F001N-T@PLCC32 [(SA015A1T)]	CAT28F002
CAT28F001P-T	CAT28F010
CAT28F001T-T@TSOP32 [(SA410T)]	CAT28F010@TSOP32 [(SA410T)]
CAT28F002@TSOP40 [(SA409T)]	CAT28F010I@PLCC32 [(SA015A1T)]
CAT28F010@PLCC32 [(SA015A1T)]	CAT28F020
CAT28F010I	
CAT28F010I@TSOP32 [(SA410T)]	CAT28F020@TSOP32 [(SA410T)]
CAT28F020(REVERSE)@TSOP32 [(SA410T)]	CAT28F020I@PLCC32 [(SA015A1T)]
CAT28F020@PLCC32 [(SA015A1T)]	CAT28F102
CAT28F020I	CAT28F102@TSOP40 [(SA409T)]
CAT28F020I@TSOP32 [(SA410T)]	CAT28F512@PLCC32 [(SA015A1T)]
CAT28F102@PLCC44 [(SA244)]	CAT28F512I
CAT28F512	CAT28F512I@TSOP32 [(SA410T)]
CAT28F512@TSOP32 [(SA410T)]	CAT28LV256@PLCC32 [(SA015A1T)]
CAT28F512I@PLCC32 [(SA015A1T)]	CAT28LV64
CAT28LV256	CAT28LV64@TSOP28 [(SA430T)]
CAT28LV256@TSOP28 [(SA430T)]	CAT28LV65@PLCC32 [(SA015A1T)]
CAT28LV64@PLCC32 [(SA015A1T)]	CAT33C101(08bit)
CAT28LV65	CAT33C101(16bit)
CAT28LV65@TSOP28 [(SA430T)]	CAT33C101(16bit)@SOIC8 [(SA602A)]
CAT33C101(08bit)@SOIC8 [(SA602A)]	
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8 [(SA602A)]	
CAT33C101H(08bit)	

CAT33C101H(08bit)@SOIC8 [(SA602A)]	
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8 [(SA602A)]	
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8 [(SA602A)]	
CAT33C101I(16bit)	
CAT33C101I(16bit)@SOIC8 [(SA602A)]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [(SA602A)]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [(SA602A)]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [(SA602A)]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [(SA602A)]	
CAT34AC02	CAT34AC02@SOIC8 [(SA602A)]
CAT34AC02@TSSOP8 [(SA026)]	CAT34C02
CAT34C02@SOIC8 [(SA602A)]	CAT34C02@TDFN8 [(SA694)]
CAT34C02@TSSOP8 [(SA026)]	CAT34FC02
CAT34FC02@SOIC8 [(SA602A)]	CAT34FC02@TDFN8 [(SA694)]
CAT34FC02@TSSOP8 [(SA026)]	CAT34RC02
CAT34RC02@SOIC8 [(SA602A)]	CAT34RC02@TDFN8 [(SA694)]
CAT34RC02@TSSOP8 [(SA026)]	
CAT34TS02@TDFN8 [ordering number is marked above]	
CAT34WC02	CAT34WC02@SOIC8 [(SA602A)]
CAT34WC02@TDFN8 [(SA694)]	CAT34WC02@TSSOP8 [(SA026)]
CAT35C102	CAT35C102H
CAT35C102I	CAT35C104(08bit)
CAT35C104(08bit)@SOIC8 [(SA602A)]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [(SA602A)]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [(SA602A)]	
CAT59C11	CAT59C11@SOIC8 [(SA602A)]
CAT59C11A	CAT59C11A@SOIC8 [(SA602A)]
CAT59C11H	CAT59C11H@SOIC8 [(SA602A)]
CAT59C11I	CAT59C11I@SOIC8 [(SA602A)]
CAT64LC10(J)@SOIC8 [(SA602A)]	CAT64LC10(P)
CAT64LC10(S)@SOIC8 [(SA602A)]	CAT64LC10(U)@TSSOP8 [(SA026)]
CAT64LC10(UR)@TSSOP8 [(SA026)]	CAT64LC20(J)@SOIC8 [(SA602A)]
CAT64LC20(P)	CAT64LC20(S)@SOIC8 [(SA602A)]
CAT64LC20(U)@TSSOP8 [(SA026)]	CAT64LC20(UR)@TSSOP8 [(SA026)]
CAT64LC40(J)@SOIC8 [(SA602A)]	CAT64LC40(P)
CAT64LC40(S)@SOIC8 [(SA602A)]	CAT64LC40(U)@TSSOP8 [(SA026)]
CAT64LC40(UR)@TSSOP8 [(SA026)]	CAT93C46(08bit)
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C46A	CAT93C56(08bit)
CAT93C56(08bit)@SOIC8 [(SA602A)]	CAT93C56(16bit)
CAT93C56(16bit)@SOIC8 [(SA602A)]	CAT93C56A
CAT93C57	CAT93C66(08bit)
CAT93C66(08bit)@SOIC8 [(SA602A)]	CAT93C66(08bit)@TSSOP8 [(SA026)]
CAT93C66(16bit)	CAT93C66(16bit)@SOIC8 [(SA602A)]
CAT93C66(16bit)@TSSOP8 [(SA026)]	CAT93C66A
CAT93C76(08bit)	
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C76(16bit)	
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C86(08bit)	
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C86(16bit)	

CAT93C86 (16bit) (J)@SOIC8 [(SA602A)]  
CAT93C86 (16bit) (K)@SOIC8 [(SA605A)]  
CAT93C86 (16bit) (S)@SOIC8 [(SA602A)]  
CAT93C86 (16bit) (U)@TSSOP8 [(SA026)]  
CAT93H46 (08bit)  
CAT93H46 (08bit) (J)@SOIC8 [(SA602A)]  
CAT93H46 (08bit) (K)@SOIC8 [(SA605A)]  
CAT93H46 (08bit) (S)@SOIC8 [(SA602A)]  
CAT93H46 (08bit) (U)@TSSOP8 [(SA026)]  
CAT93H46 (16bit)  
CAT93H46 (16bit) (J)@SOIC8 [(SA602A)]  
CAT93H46 (16bit) (K)@SOIC8 [(SA605A)]  
CAT93H46 (16bit) (S)@SOIC8 [(SA602A)]  
CAT93H46 (16bit) (U)@TSSOP8 [(SA026)]  
CAT93HC46 (08bit)  
CAT93HC46 (08bit) (J)@SOIC8 [(SA602A)]  
CAT93HC46 (08bit) (K)@SOIC8 [(SA605A)]  
CAT93HC46 (08bit) (S)@SOIC8 [(SA602A)]  
CAT93HC46 (08bit) (U)@TSSOP8 [(SA026)]  
CAT93HC46 (16bit)  
CAT93HC46 (16bit) (J)@SOIC8 [(SA602A)]  
CAT93HC46 (16bit) (K)@SOIC8 [(SA605A)]  
CAT93HC46 (16bit) (S)@SOIC8 [(SA602A)]  
CAT93HC46 (16bit) (U)@TSSOP8 [(SA026)]

#### DRAM & SRAM

CAT71C256 CAT71C256@TSOP28 [(SA643)]  
CAT71C256L CAT71C256L@TSOP28 [(SA643)]

## CELESTICA

#### E(E) PROM/FRAM/NVRAM

SST49LF160C@TSOP40 [(SA409T)]

## CERAMATE

#### E(E) PROM/FRAM/NVRAM

24LC02 24LC02@SOIC8 [(SA602A)]  
24LC02@TSSOP8 [(SA026)] 24LC08  
24LC08@SOIC8 [(SA602A)] 24LC08@TSSOP8 [(SA026)]  
24LC16 24LC16@SOIC8 [(SA602A)]  
24LC16@TSSOP8 [(SA026)] 24LLC02  
24LLC02@SOIC8 [(SA602A)] 24LLC02@TSSOP8 [(SA026)]  
24LLC08 24LLC08@SOIC8 [(SA602A)]  
24LLC08@TSSOP8 [(SA026)] 93LC46  
93LC46@SOIC8 [(SA602A)] 93LC46R  
93LC46R@SOIC8 [(SA602A)] 93LC56  
93LC56@SOIC8 [(SA602A)] 93LC66  
93LC66@SOIC8 [(SA602A)]

## CFeon

#### E(E) PROM/FRAM/NVRAM

EN25Q128@SOP16 [(SA404)] EN25Q128@VDFN8 [(SA684)]  
EN29GL064B@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29GL064B@TSOP48 [(SA247)]  
EN29GL064H@FBGA64 [(SA655F-B099A-W064F001Y)]  
EN29GL064H@TSOP56 [(SA628-B102)]  
EN29GL064L@FBGA64 [(SA655F-B099A-W064F001Y)]  
EN29GL064L@TSOP56 [(SA628-B102)]  
EN29GL064T@FBGA48 [(SA642G-B026A-T048F001Y)]  
EN29GL064T@TSOP48 [(SA247)]  
EN29GL128H@FBGA64 [(SA655F-B099A-W064F001Y)]  
EN29GL128H@TSOP56 [(SA628-B102)]  
EN29GL128L@FBGA64 [(SA655F-B099A-W064F001Y)]  
EN29GL128L@TSOP56 [(SA628-B102)]

```

EN29LV160BB@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV160BB@TSOP48 [(SA247-B005)]
EN29LV160BT@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV160BT@TSOP48 [(SA247-B005)]
EN29LV320BB@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV320BB@TSOP48 [(SA247-B005)]
EN29LV320BT@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV320BT@TSOP48 [(SA247-B005)]
EN29LV800BB@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV800BB@TSOP48 [(SA247-B005)]
EN29LV800BT@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV800BT@TSOP48 [(SA247-B005)]
EN29LV800CB@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV800CB@TSOP48 [(SA247-B005)]
EN29LV800CT@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV800CT@TSOP48 [(SA247-B005)]
EN29PL032@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29PL032@FBGA56 [(SA642P-B079A-W056F001Y)]
EN29PL032@TSOP48 [(SA247-B005)] EN39LV010@PLCC32 [(sa015at)]
EN39LV010@VSOP32 [(SA620)]
EN39LV010@WFBGA34 [(SA716A-B120A-M048F001Y)]
EN71GL128B0@FBGA56 [(SA642P-B079A-W056F001Y)]

```

## CHINA CORE

### MICROCONTROLLER

```

CCM89C51 CCM89C51@PLCC44 [(SA244)]
CCM89C51@TQFP44 [(SA245A)] CCM89C52
CCM89C52@PLCC44 [(SA244)] CCM89C52@TQFP44 [(SA245A)]

```

## CHINGIS

### E(E) PROM/FRAM/NVRAM

```

PM24C64 PM24C64@SOIC8 [(SA602A)]
PM24C64@TSOP8 [(SA026)] PM25LD040(B)@SOIC8 [(SA023A)]
PM25LD040(Q)@WSON8 [(SA683)] PM25LD040(S)@SOIC8 [(SA602A)]
PM25LV010(B)@SOIC8 [(SA023A)] PM25LV010(Q)@WSON8 [(SA683)]
PM25LV010(S)@SOIC8 [(SA602A)] PM25LV010A@SOIC8 [(SA602A)]
PM25LV010A@WSON8 [(SA683)] PM25LV016@SOIC8 [(SA605A)]
PM25LV016@WSON8 [(SA683)] PM25LV016A@SOIC8 [(SA605A)]
PM25LV016A@WSON8 [(SA683)] PM25LV020(B)@SOIC8 [(SA023A)]
PM25LV020(Q)@WSON8 [(SA683)] PM25LV020(S)@SOIC8 [(SA602A)]
PM25LV040(B)@SOIC8 [(SA023A)] PM25LV040(Q)@WSON8 [(SA683)]
PM25LV040(S)@SOIC8 [(SA602A)] PM25LV080@SOIC8 [(SA605A)]
PM25LV080@WSON8 [(SA683)] PM25LV080A@SOIC8 [(SA605A)]
PM25LV080A@WSON8 [(SA683)] PM25LV512(B)@SOIC8 [(SA023A)]
PM25LV512(Q)@WSON8 [(SA683)] PM25LV512(S)@SOIC8 [(SA602A)]
PM25W020(B)@SOIC8 [(SA023A)] PM25W020(Q)@WSON8 [(SA683)]
PM25W020(S)@SOIC8 [(SA602A)] PM29F002B
PM29F002B@PLCC32 [(SA015A1T)] PM29F002T
PM29F002T@PLCC32 [(SA015A1T)] PM29F004B
PM29F004B@PLCC32 [(SA015A1T)] PM29F004T
PM29F004T@PLCC32 [(SA015A1T)] PM29LV002B
PM29LV002B@PLCC32 [(SA015A1T)] PM29LV002B@VSOP32 [(SA620)]
PM29LV002T PM29LV002T@PLCC32 [(SA015A1T)]
PM29LV002T@VSOP32 [(SA620)] PM29LV004B@PLCC32 [(SA015A1T)]
PM29LV004B@VSOP32 [(SA620)] PM29LV004T@PLCC32 [(SA015A1T)]
PM29LV004T@VSOP32 [(SA620)] PM29LV104RB@PLCC32 [(SA015A1T)]
PM29LV104RB@VSOP32 [(SA620)] PM29LV104RT@PLCC32 [(SA015A1T)]
PM29LV104RT@VSOP32 [(SA620)] PM37LV512
PM37LV512@PLCC32 [(SA015A1T)] PM37LV512@VSOP32 [(SA620)]
PM39F010 PM39F010@PLCC32 [(SA015A1T)]
PM39F010@VSOP32 [(SA620)] PM39F020
PM39F020@PLCC32 [(SA015A1T)] PM39F020@VSOP32 [(SA620)]
PM39F040 PM39F040@PLCC32 [(SA015A1T)]
PM39F040@VSOP32 [(SA620)] PM39LV010@PLCC32 [(SA015A1T)]
PM39LV010@VSOP32 [(SA620)] PM39LV010R@PLCC32 [(SA015A1T)]
PM39LV010R@VSOP32 [(SA620)] PM39LV020@PLCC32 [(SA015A1T)]
PM39LV020@VSOP32 [(SA620)] PM39LV040@PLCC32 [(SA015A1T)]
PM39LV040@VSOP32 [(SA620)] PM39LV512@PLCC32 [(SA015A1T)]
PM39LV512@VSOP32 [(SA620)] PM39LV512R@PLCC32 [(SA015A1T)]
PM39LV512R@VSOP32 [(SA620)] PM49FL002T@PLCC32 [(SA015A1T)]

```

PM49FL002T@VSOP32 [(SA620)]  
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]  
PM49FL004T(Low)@VSOP32 [(SA620-B005)]  
PM49FL004T@PLCC32 [(SA015A1T)] PM49FL004T@VSOP32 [(SA620)]  
PM49FL008T@PLCC32 [(SA015A1T)] PM49FL008T@VSOP32 [(SA620)]  
PM49LP002T@PLCC32 [(SA015A1T)] PM49LP002T@VSOP32 [(SA620)]

## CHIPCON

### MICROCONTROLLER

CC1010@TQFP64 [(PEP+S616)]  
CC1010@TQFP64(ISP) [ISP-HEADER01]

## CHIPSWINNER

### E(E) PROM/FRAM/NVRAM

CW24C02 CW24C02@SOIC8 [(SA602A)]  
CW24C04 CW24C04@SOIC8 [(SA602A)]  
CW24C08 CW24C08@SOIC8 [(SA602A)]  
CW24C16 CW24C16@SOIC8 [(SA602A)]  
CW24C32 CW24C32@SOIC8 [(SA602A)]  
CW24C64 CW24C64@SOIC8 [(SA602A)]

### MICROCONTROLLER

CW88CS028@SDIP28 [(SA653)] CW88CS032@SDIP32 [(SA653)]  
CW88CS128@SDIP28 [(SA653)] CW88CS132@SDIP32 [(SA653)]  
CW89F1050 CW89F2050  
CW89F4050@SDIP28 [(SA653)] CW89F4050@SOP28 [(SA404)]  
CW89F52 CW89F52@LQFP44 [(SA675)]  
CW89F54 CW89F54@LQFP44 [(SA675)]

## CORERIVER

### E(E) PROM/FRAM/NVRAM

CR24C02LI CR24C02WI@SOIC8 [(SA602)]  
CR24C08LI CR24C08WI@SOIC8 [(SA602)]  
CR24C16LI CR24C16WI@SOIC8 [(SA602)]  
CR24C256LI CR24C256WI@SOIC8 [(SA602)]  
CR24C32LI CR24C32WI@SOIC8 [(SA602)]  
CR24C64LI CR24C64WI@SOIC8 [(SA602)]

### MICROCONTROLLER

GC87C520A0 GC87C520A0@MQFP44 [(SA675)]  
GC87C520A0@PLCC44 [(SA244)]

## CWI

### E(E) PROM/FRAM/NVRAM

39LV040@VSOP32 [(SA620)]

## CYGNAL

### MICROCONTROLLER

C8051F000@TQFP64 [(PEP+S616)]  
C8051F000@TQFP64(\*) [(SA732+B335)]  
C8051F000@TQFP64(ISP) [(PEP+S616)]

C8051F001@TQFP48 [(SA248)]	C8051F001@TQFP48(ISP) [(SA248)]
C8051F002@TQFP32 [(SA663)]	C8051F002@TQFP32(ISP) [(SA663)]
C8051F005@TQFP64 [(PEP+S616)]	
C8051F005@TQFP64(*) [(SA732+B335)]	
C8051F005@TQFP64(ISP) [(PEP+S616)]	
C8051F006@TQFP48 [(SA248)]	C8051F006@TQFP48(ISP) [(SA248)]
C8051F007@TQFP32 [(SA663)]	C8051F007@TQFP32(ISP) [(SA663)]
C8051F010@TQFP64 [(PEP+S616)]	
C8051F010@TQFP64(*) [(SA732+B335)]	
C8051F010@TQFP64(ISP) [(PEP+S616)]	
C8051F011@TQFP48 [(SA248)]	C8051F011@TQFP48(ISP) [(SA248)]
C8051F012@TQFP32 [(SA663)]	C8051F012@TQFP32(ISP) [(SA663)]
C8051F015@TQFP64 [(PEP+S616)]	
C8051F015@TQFP64(*) [(SA732+B335)]	
C8051F015@TQFP64(ISP) [(PEP+S616)]	
C8051F016@TQFP48 [(SA248)]	C8051F016@TQFP48(ISP) [(SA248)]
C8051F017@TQFP32 [(SA663)]	C8051F017@TQFP32(ISP) [(SA663)]
C8051F018@TQFP64 [(PEP+S616)]	
C8051F018@TQFP64(*) [(SA732+B335)]	
C8051F018@TQFP64(ISP) [(PEP+S616)]	
C8051F019@TQFP48 [(SA248)]	C8051F019@TQFP48(ISP) [(SA248)]
C8051F020@TQFP100 [(PEP+S604)]	
C8051F020@TQFP100(ISP) [ISP-HEADER01]	
C8051F021@TQFP64 [(PEP+S616)]	
C8051F021@TQFP64(*) [(TA050-B005)]	
C8051F021@TQFP64(ISP) [ISP-HEADER01]	
C8051F022@TQFP100 [(PEP+S604)]	
C8051F022@TQFP100(ISP) [ISP-HEADER01]	
C8051F023@TQFP64 [(PEP+S616)]	
C8051F023@TQFP64(*) [(TA050-B005)]	
C8051F023@TQFP64(ISP) [ISP-HEADER01]	
C8051F040@TQFP100 [(PEP+S604)]	
C8051F040@TQFP100(ISP) [ISP-HEADER01]	
C8051F041@TQFP64 [(PEP+S616)]	
C8051F041@TQFP64(*) [(TA050-B005)]	
C8051F041@TQFP64(ISP) [ISP-HEADER01]	
C8051F042@TQFP100 [(PEP+S604)]	
C8051F042@TQFP100(ISP) [ISP-HEADER01]	
C8051F043@TQFP64 [(PEP+S616)]	
C8051F043@TQFP64(*) [(TA050-B005)]	
C8051F043@TQFP64(ISP) [ISP-HEADER01]	
C8051F044@TQFP100 [(PEP+S604)]	
C8051F044@TQFP100(ISP) [ISP-HEADER01]	
C8051F045@TQFP64 [(PEP+S616)]	
C8051F045@TQFP64(*) [(TA050-B005)]	
C8051F045@TQFP64(ISP) [ISP-HEADER01]	
C8051F046@TQFP100 [(PEP+S604)]	
C8051F046@TQFP100(ISP) [ISP-HEADER01]	
C8051F047@TQFP64 [(PEP+S616)]	
C8051F047@TQFP64(*) [(TA050-B005)]	
C8051F047@TQFP64(ISP) [ISP-HEADER01]	
C8051F060@TQFP100 [(PEP+S604)]	C8051F061@TQFP64 [(PEP+S616)]
C8051F062@TQFP100 [(PEP+S604)]	C8051F063@TQFP64 [(PEP+S616)]
C8051F064@TQFP100 [(PEP+S604)]	C8051F065@TQFP64 [(PEP+S616)]
C8051F066@TQFP100 [(PEP+S604)]	C8051F067@TQFP64 [(PEP+S616)]
C8051F120@TQFP100 [(PEP+S604)]	
C8051F120-GQ@TQFP100 [(PEP+S604)]	
C8051F121@TQFP64 [(PEP+S616)]	C8051F121-GQ@TQFP64 [(PEP+S616)]
C8051F122@TQFP100 [(PEP+S604)]	
C8051F122-GQ@TQFP100 [(PEP+S604)]	
C8051F123@TQFP64 [(PEP+S616)]	C8051F123-GQ@TQFP64 [(PEP+S616)]
C8051F124@TQFP100 [(PEP+S604)]	
C8051F124-GQ@TQFP100 [(PEP+S604)]	
C8051F125@TQFP64 [(PEP+S616)]	C8051F125-GQ@TQFP64 [(PEP+S616)]
C8051F126@TQFP100 [(PEP+S604)]	
C8051F126-GQ@TQFP100 [(PEP+S604)]	
C8051F127@TQFP64 [(PEP+S616)]	C8051F127-GQ@TQFP64 [(PEP+S616)]
C8051F130@TQFP100 [(PEP+S604)]	
C8051F130-GQ@TQFP100 [(PEP+S604)]	
C8051F131@TQFP64 [(PEP+S616)]	C8051F131-GQ@TQFP64 [(PEP+S616)]
C8051F132@TQFP100 [(PEP+S604)]	
C8051F132-GQ@TQFP100 [(PEP+S604)]	
C8051F133@TQFP64 [(PEP+S616)]	C8051F133-GQ@TQFP64 [(PEP+S616)]
C8051F206@TQFP48 [(SA248)]	C8051F220@TQFP48 [(SA248)]
C8051F221@TQFP32 [(SA663)]	C8051F226@TQFP48 [(SA248)]
C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32 [(SA663)]
C8051F236@TQFP48 [(SA248)]	C8051F300 [(SA695A)]
C8051F301 [(SA695A)]	C8051F302 [(SA695A)]
C8051F303 [(SA695A)]	C8051F304 [(SA695A)]
C8051F305 [(SA695A)]	C8051F310@TQFP32 [(SA663)]
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-B006)]

C8051F311-GM@QFN28 [(SA697-B006)]  
 C8051F312@TQFP32 [(SA663)] C8051F312-GQ@TQFP32 [(SA663)]  
 C8051F313@QFN28 [(SA697-B006)]  
 C8051F313-GM@QFN28 [(SA697-B006)]  
 C8051F314@TQFP32 [(SA663)] C8051F314-GQ@TQFP32 [(SA663)]  
 C8051F315@QFN28 [(SA697-B006)]  
 C8051F315-GM@QFN28 [(SA697-B006)]  
 C8051F316-GM@QFN24 [(SA710-B006)]  
 C8051F317-GM@QFN24 [(SA710-B006)]  
 C8051F320@TQFP32 [(SA663)] C8051F321@QFN28 [(SA697-B006)]  
 C8051F326@QFN28 [(SA697-B006)]  
 C8051F326-GQ@QFN28 [(SA697-B006)]  
 C8051F327@QFN28 [(SA697-B006)]  
 C8051F327-GQ@QFN28 [(SA697-B006)]  
 C8051F330@MLP20 [(SA692)]  
 C8051F331@MLP20 [(SA692)] C8051F330D  
 C8051F333-GM@MLP20 [(SA692)] C8051F332-GM@MLP20 [(SA692)]  
 C8051F335-GM@MLP20 [(SA692)] C8051F334-GM@MLP20 [(SA692)]  
 C8051F337-GM@QFN20 [(SA692)] C8051F336-GM@QFN20 [(SA692)]  
 C8051F339-GM@QFN24 [(SA710)] C8051F338-GM@QFN24 [(SA710)]  
 C8051F341-GQ@TQFP48 [(SA248)] C8051F340-GQ@TQFP48 [(SA248)]  
 C8051F343-GQ@LQFP32 [(SA663)] C8051F342-GQ@LQFP32 [(SA663)]  
 C8051F345-GQ@TQFP48 [(SA248)] C8051F344-GQ@TQFP48 [(SA248)]  
 C8051F347-GQ@LQFP32 [(SA663)] C8051F346-GQ@LQFP32 [(SA663)]  
 C8051F351-GM@QFN28 [(SA697-B006)] C8051F350-GQ@LQFP32 [(SA663)]  
 C8051F352-GQ@LQFP32 [(SA663)]  
 C8051F353-GM@QFN28 [(SA697-B006)]  
 C8051F360@QFP48 [(SA248)] C8051F361@QFP32 [(SA663)]  
 C8051F362@QFN28 [(SA697)] C8051F363@QFP48 [(SA248)]  
 C8051F364@QFP32 [(SA663)] C8051F365@QFN28 [(SA697)]  
 C8051F366@QFP32 [(SA663)] C8051F367@QFN28 [(SA697)]  
 C8051F368@QFP32 [(SA663)] C8051F369@QFN28 [(SA697)]  
 C8051F410-GQ@LQFP32 [(SA663)] C8051F411-GM@QFN28 [(SA697)]  
 C8051F412-GQ@LQFP32 [(SA663)] C8051F413-GM@QFN28 [(SA697)]  
 C8051F520-IM@QFN10 [(SA695A)] C8051F521-IM@QFN10 [(SA695A)]  
 C8051F523-IM@QFN10 [(SA695A)] C8051F524-IM@QFN10 [(SA695A)]  
 C8051F526-IM@QFN10 [(SA695A)] C8051F527-IM@QFN10 [(SA695A)]  
 C8051F530-IM@QFN20 [(SA692)] C8051F530-IT@TSSOP20 [(SA026)]  
 C8051F531-IM@QFN20 [(SA692)] C8051F531-IT@TSSOP20 [(SA026)]  
 C8051F533-IM@QFN20 [(SA692)] C8051F533-IT@TSSOP20 [(SA026)]  
 C8051F534-IM@QFN20 [(SA692)] C8051F534-IT@TSSOP20 [(SA026)]  
 C8051F536-IM@QFN20 [(SA692)] C8051F536-IT@TSSOP20 [(SA026)]  
 C8051F537-IM@QFN20 [(SA692)] C8051F537-IT@TSSOP20 [(SA026)]  
 C8051F610-GQ@QFP32 [(SA663)]  
 C8051F611-GM@QFN28 [(SA697-B006)]  
 C8051F612-GQ@QFP32 [(SA663)]  
 C8051F613-GM@QFN28 [(SA697-B006)]  
 C8051F614-GQ@QFP32 [(SA663)]  
 C8051F615-GM@QFN28 [(SA697-B006)]  
 C8051F616-GM@QFN24 [(SA710-B006)]  
 C8051F617-GM@QFN24 [(SA710-B006)]  
 C8051T600@QFN11 [(SA695A)] C8051T600@SOIC14 [(SA602)]  
 C8051T601@QFN11 [(SA695A)] C8051T601@SOIC14 [(SA602)]  
 C8051T602@QFN11 [(SA695A)] C8051T602@SOIC14 [(SA602)]  
 C8051T603@QFN11 [(SA695A)] C8051T603@SOIC14 [(SA602)]  
 C8051T604@QFN11 [(SA695A)] C8051T604@SOIC14 [(SA602)]  
 C8051T605@QFN11 [(SA695A)] C8051T605@SOIC14 [(SA602)]  
 SI8250@LQFP32 [(SA663)] SI8250@QFN28 [(SA697)]  
 SI8251@LQFP32 [(SA663)] SI8251@QFN28 [(SA697)]  
 SI8252@LQFP32 [(SA663)] SI8252@QFN28 [(SA697)]

## CYPRESS

### E(E) PROM/FRAM/NVRAM

CY14B256L@SOIC32 [(SA715)]  
 CY27C010@PLCC32 [(SA015A1T)] CY27C010  
 CY27C020  
 CY27C020@TSOP32 [(SA410T)] CY27C020@PLCC32 [(SA015A1T)]  
 CY27C040@PLCC32 [(SA015A1T)] CY27C040  
 CY27C040@TSOP32 [(SA410T)]  
 CY27C128  
 CY27C256  
 CY27C256@TSOP28 [(SA430T)] CY27C128@PLCC32 [(SA015A1T)]  
 CY27C512@PLCC32 [(SA015A1T)] CY27C256@PLCC32 [(SA015A1T)]  
 CY27H010  
 CY27H010@TSOP32 [(SA410T)] CY27C512  
 CY27H256@PLCC32 [(SA015A1T)] CY27C512@TSOP28 [(SA430T)]  
 CY27H512  
 CY27H512@PLCC32 [(SA015A1T)]

CY27H512@TSOP28 [(SA430T)]	CY7C225A
CY7C225A@PLCC28 [(SA008A)]	CY7C243
CY7C243@PLCC28 [(SA008A)]	CY7C244
CY7C244@PLCC28 [(SA008A)]	CY7C245
CY7C245@PLCC28 [(SA008A)]	CY7C245A
CY7C245A@PLCC28 [(SA008A)]	CY7C251
CY7C251@PLCC32 [(SA015A1T)]	CY7C254
CY7C254@PLCC32 [(SA015A1T)]	CY7C256
CY7C256@PLCC32 [(SA015A1T)]	CY7C261
CY7C261@PLCC28 [(SA008A)]	CY7C263
CY7C263@PLCC28 [(SA008A)]	CY7C264
CY7C264@PLCC28 [(SA008A)]	CY7C265
CY7C265@PLCC28 [(SA008A)]	CY7C266
CY7C266@PLCC32 [(SA015A1T)]	CY7C268
CY7C268@PLCC32 [(SA015A1T)]	CY7C271
CY7C271@PLCC32 [(SA015A1T)]	CY7C271A
CY7C271A@PLCC32 [(SA015A1T)]	CY7C274
CY7C274@PLCC32 [(SA015A1T)]	CY7C276(25HC)@PLCC44 [(SA244)]
CY7C276(25JC)@PLCC44 [(SA244)]	CY7C276(30JC)@PLCC44 [(SA244)]
CY7C281	CY7C281@PLCC28 [(SA008A)]
CY7C281A	CY7C281A@PLCC28 [(SA008A)]
CY7C282	CY7C282@PLCC28 [(SA008A)]
CY7C282A	CY7C282A@PLCC28 [(SA008A)]
CY7C285	CY7C285@PLCC32 [(SA015A1T)]
CY7C286	CY7C286@PLCC32 [(SA015A1T)]
CY7C287	CY7C287@PLCC32 [(SA015A1T)]
CY7C291	CY7C291@PLCC28 [(SA008A)]
CY7C291A	CY7C291A@PLCC28 [(SA008A)]
CY7C292	CY7C292@PLCC28 [(SA008A)]
CY7C292A	CY7C292A@PLCC28 [(SA008A)]
CY7C293A	CY7C293A@PLCC28 [(SA008A)]
CY8C9520@SSOP28 [(SA626A)]	CY8C9540@SSOP48 [(SA669)]
CY8C9560@TQFP100 [(PEP+S604)]	

**DRAM & SRAM**

CY62128@SOIC32 [(SA687)]	CY62128@SOJ32 [(SA661)]
CY62128@VSOP32 [(SA620)]	CY62128L@SOIC32 [(SA687)]
CY62128L@SOJ32 [(SA661)]	CY62128L@VSOP32 [(SA620)]
CY62128LL@SOIC32 [(SA687)]	CY62128LL@SOJ32 [(SA661)]
CY62128LL@VSOP32 [(SA620)]	CY7C1011@TSOP44 [(SA645)]
CY7C1020@TSOP44 [(SA645)]	CY7C1021@TSOP44 [(SA645)]
CY7C1049@SOJ36 [(SA027)]	CY7C1049@TSOP44 [(SA645)]
CY7C107	CY7C107@SOJ28 [(SA661)]
CY7C147	CY7C167
CY7C167@PLCC20 [(SA001A)]	CY7C167A
CY7C167A@PLCC20 [(SA001A)]	CY7C185
CY7C185@SOIC28 [(SA404)]	CY7C185@SOJ28 [(SA646)]
CY7C186	CY7C187
CY7C187@SOJ24 [(SA646)]	CY7C187A
CY7C187A@SOJ24 [(SA646)]	CY7C193
CY7C193@SOJ28 [(SA646)]	CY7C199
CY7C199@PLCC28 [(SA008A)]	CY7C199@SOJ28 [(SA646)]
CY7C199@TSOP28 [(SA430T)]	

**PLD**

CY22381@SOIC8 [(SA602A)]	CY22392@TSSOP16 [(SA026)]
CY22393@TSSOP16 [(SA026)]	CY22394@TSSOP16 [(SA026)]
CY22395@TSSOP16 [(SA026)]	
CY2291@SOIC20 [ordering number is marked above]	
CY2292@SOIC16 [ordering number is marked above]	
CY2295@SSOP28 [ordering number is marked above]	
CY37032@PLCC44 [(SA244)]	CY37032@TQFP44 [(SA245A)]
CY37032V@PLCC44 [(SA244)]	CY37032V@TQFP44 [(SA245A)]
CY37064@PLCC44 [(SA244)]	
CY37064@PLCC44(ISP) [ISP-HEADER01]	
CY37064@PLCC84 [(PEP+S416T)]	
CY37064@PLCC84(ISP) [ISP-HEADER01]	
CY37064@TQFP100 [PEP+S604]	
CY37064@TQFP100(ISP) [ISP-HEADER01]	
CY37064@TQFP44 [(SA245A)]	
CY37064@TQFP44(ISP) [ISP-HEADER01]	
CY37064V@PLCC44 [(SA244)]	
CY37064V@PLCC44(ISP) [ISP-HEADER01]	
CY37064V@PLCC84 [(PEP+S416T)]	
CY37064V@PLCC84(ISP) [ISP-HEADER01]	
CY37064V@TQFP100 [PEP+S604]	



CY37064V@TQFP100 (ISP) [ISP-HEADER01]  
 CY37064V@TQFP44 [(SA245A)]  
 CY37064V@TQFP44 (ISP) [ISP-HEADER01]  
 CY37128@PLCC84 [(PEP+S416T)] CY37128@TQFP100 [(PEP+S604)]  
 CY37128@TQFP160 (ISP) [ISP-HEADER01]  
 CY37128V@PLCC84 [(PEP+S416T)] CY37128V@TQFP100 [(PEP+S604)]  
 CY37128V@TQFP160 (ISP) [ISP-HEADER01]  
 CY37192@TQFP160 (ISP) [ISP-HEADER01]  
 CY37192V@TQFP160 (ISP) [ISP-HEADER01]  
 CY37256@BGA256 (ISP) [ISP-HEADER01]  
 CY37256@TQFP160 (ISP) [ISP-HEADER01]  
 CY37256@TQFP208 (ISP) [ISP-HEADER01]  
 CY37256V@BGA256 (ISP) [ISP-HEADER01]  
 CY37256V@TQFP160 (ISP) [ISP-HEADER01]  
 CY37256V@TQFP208 (ISP) [ISP-HEADER01]  
 CY37384@BGA256 (ISP) [ISP-HEADER01]  
 CY37384@TQFP208 (ISP) [ISP-HEADER01]  
 CY37384V@BGA256 (ISP) [ISP-HEADER01]  
 CY37384V@TQFP208 (ISP) [ISP-HEADER01]  
 CY37512@BGA256 (ISP) [ISP-HEADER01]  
 CY37512@BGA352 (ISP) [ISP-HEADER01]  
 CY37512@TQFP208 (ISP) [ISP-HEADER01]  
 CY37512V@BGA256 (ISP) [ISP-HEADER01]  
 CY37512V@BGA352 (ISP) [ISP-HEADER01]  
 CY37512V@TQFP208 (ISP) [ISP-HEADER01]  
 CY7C342B@PGA68 [(SA650+B6811)] CY7C342B@PLCC68 [(PEP+S414T)]  
 CY7C343B@PLCC44 [(SA244)] CY7C344B  
 CY7C344B@PLCC28 [(SA008A)] CY7C346B@PLCC84 [(PEP+S416T)]  
 CY7C346B@PQFP100 [(PEP+S427)] CY7C371@PLCC44 [(SA244)]  
 CY7C371@TQFP44 [(SA245A)] CY7C371I@PLCC44 [(SA244)]  
 CY7C371I@TQFP44 [(SA245A)] CY7C372@PLCC44 [(SA244)]  
 CY7C372@TQFP44 [(SA245A)] CY7C372I@PLCC44 [(SA244)]  
 CY7C372I@TQFP44 [(SA245A)] CY7C373@PLCC84 [(PEP+S416T)]  
 CY7C373@TQFP100 [(PEP+S604)] CY7C373I@PLCC84 [(PEP+S416T)]  
 CY7C373I@TQFP100 [(PEP+S604)] CY7C374@PLCC84 [(PEP+S416T)]  
 CY7C374@TQFP100 [(PEP+S604)] CY7C374I@PLCC84 [(PEP+S416T)]  
 CY7C374I@TQFP100 [(PEP+S604)] CY7C374U@PLCC84 [(PEP+S416T)]  
 CY7C374U@TQFP100 [(PEP+S604)] PALC16L8  
 PALC16L8@PLCC20 [(SA001A)] PALC16L8L  
 PALC16L8L@PLCC20 [(SA001A)] PALC16R4  
 PALC16R4@PLCC20 [(SA001A)] PALC16R4L  
 PALC16R4L@PLCC20 [(SA001A)] PALC16R6  
 PALC16R6@PLCC20 [(SA001A)] PALC16R6L  
 PALC16R6L@PLCC20 [(SA001A)] PALC16R8  
 PALC16R8@PLCC20 [(SA001A)] PALC16R8L  
 PALC16R8L@PLCC20 [(SA001A)] PALC22V10  
 PALC22V10@PLCC28 [(SA008A)] PALC22V10A  
 PALC22V10A@PLCC28 [(SA008A)] PALC22V10B  
 PALC22V10B@PLCC28 [(SA008A)] PALC22V10D  
 PALC22V10D@PLCC28 [(SA008A)] PALC22V10L  
 PALC22V10L@PLCC28 [(SA008A)] PALCE16V8  
 PALCE16V8@PLCC20 [(SA001A)] PALCE20V8  
 PALCE20V8@PLCC28 [(SA008A)] PALCE20V8L  
 PALCE20V8L@PLCC28 [(SA008A)] PALCE22V10  
 PALCE22V10@PLCC28 [(SA008A)]

## MICROCONTROLLER

CG6457AM@SSOP20 [(SA626A)]  
 CG6457AM@SSOP20 (ISP) [ISP-HEADER01]  
 CG6462AM@SOIC8 [(SA602A)]  
 CG6462AM@SOIC8 (ISP) [ISP-HEADER01]  
 CY7C53120E2@SOIC32 [(SA687)] CY7C53120E2@TQFP44 [(SA245A)]  
 CY7C53120E4@SOIC32 [(SA687)] CY7C53120E4@TQFP44 [(SA245A)]  
 CY7C60113@SSOP28 [(SA626A)] CY7C60123  
 CY7C60123@SSOP48 [(SA669)] CY7C60223  
 CY7C60223@QSOP24 [(SA643)] CY7C60223@SOIC24 [(SA404)]  
 CY7C60323@MLF32 [(SA686)]  
 CY7C60323@MLF32 (ISP) [ISP-HEADER01]  
 CY7C60323@SSOP28 [(SA626A)]  
 CY7C60323@SSOP28 (ISP) [ISP-HEADER01]  
 CY7C60333@MLF32 [(SA686)]  
 CY7C60333@MLF32 (ISP) [ISP-HEADER01]  
 CY7C60445@QFN32 [(SA686)]  
 CY7C60445@QFN32 (ISP) [ISP-HEADER01]  
 CY7C60455@QFN48 [(SA696)]  
 CY7C60455@QFN48 (ISP) [ISP-HEADER01]  
 CY7C60456@QFN48 [(SA696)]  
 CY7C60456@QFN48 (ISP) [ISP-HEADER01]

CY7C63000	CY7C63000@SOIC20 [(SA404)]
CY7C63000A	CY7C63000A@SOIC20 [(SA404)]
CY7C63001	CY7C63001@SOIC20 [(SA404)]
CY7C63001A	CY7C63001A@SOIC20 [(SA404)]
CY7C63100	CY7C63100@SOIC24 [(SA404)]
CY7C63100A	CY7C63100A@SOIC24 [(SA404)]
CY7C63101	CY7C63101@SOIC24 [(SA404)]
CY7C63101A	CY7C63101A@SOIC24 [(SA404)]
CY7C63200	CY7C63200@SOIC18 [(SA404)]
CY7C63200A	CY7C63200A@SOIC18 [(SA404)]
CY7C63201	CY7C63201@SOIC18 [(SA404)]
CY7C63201A	CY7C63201A@SOIC18 [(SA404)]
CY7C63221	CY7C63221A
CY7C63231	CY7C63231@SOIC18 [(SA404)]
CY7C63231A	CY7C63231A@SOIC18 [(SA404)]
CY7C63310	CY7C63310@SOIC16 [(SA602)]
CY7C63411(dip40)	CY7C63411(dip48)
CY7C63411@SSOP48 [(SA669)]	CY7C63412(dip40)
CY7C63412(dip48)	CY7C63412@SSOP48 [(SA669)]
CY7C63413(dip40)	CY7C63413(dip48)
CY7C63413@SSOP48 [(SA669)]	CY7C63511(dip48)
CY7C63511@SSOP48 [(SA669)]	CY7C63512(dip48)
CY7C63512@SSOP48 [(SA669)]	CY7C63513(dip48)
CY7C63513@SSOP48 [(SA669)]	CY7C63722
CY7C63722@SOIC18 [(SA404)]	CY7C63722C
CY7C63722C@SOIC18 [(SA404)]	CY7C63723
CY7C63723@SOIC18 [(SA404)]	CY7C63723C
CY7C63723C@SOIC18 [(SA404)]	CY7C63742
CY7C63742@QSOP24 [(SA674)]	CY7C63742@SOIC24 [(SA404)]
CY7C63742C	CY7C63742C@QSOP24 [(SA674)]
CY7C63742C@SOIC24 [(SA404)]	CY7C63743
CY7C63743@QSOP24 [(SA674)]	CY7C63743@SOIC24 [(SA404)]
CY7C63743C	CY7C63743C@QSOP24 [(SA674)]
CY7C63743C@SOIC24 [(SA404)]	CY7C63801
CY7C63801@SOIC16 [(SA602)]	CY7C63803@SOIC16 [(SA602)]
CY7C63813	CY7C63813@SOIC18 [(SA404)]
CY7C63823	CY7C63823@QSOP24 [(SA643)]
CY7C63823@SOIC24 [(SA404)]	CY7C63833@QFN32 [(SA686)]
CY7C63903@SSOP28 [(SA626A)]	CY7C63913
CY7C63923@SSOP48 [(SA669)]	CY7C64011
CY7C64011@SOIC28 [(SA404)]	CY7C64011C
CY7C64011C@SOIC28 [(SA404)]	CY7C64012
CY7C64012@SOIC28 [(SA404)]	CY7C64012C
CY7C64012C@SOIC28 [(SA404)]	CY7C64013
CY7C64013@SOIC28 [(SA404)]	CY7C64013C
CY7C64013C@SOIC28 [(SA404)]	CY7C64111
CY7C64111@SSOP48 [(SA669)]	CY7C64111C
CY7C64111C@SSOP48 [(SA669)]	CY7C64112
CY7C64112@SSOP48 [(SA669)]	CY7C64112C
CY7C64112C@SSOP48 [(SA669)]	CY7C64113
CY7C64113@SSOP48 [(SA669)]	CY7C64113C
CY7C64113C@SSOP48 [(SA669)]	CY7C64215@MLF56 [(PEP+S706)]
CY7C64215@MLF56(*) [(SA706+B268)]	
CY7C64215@MLF56(ISP) [ISP-HEADER01]	
CY7C64215@SSOP28 [(SA626A)]	
CY7C64215@SSOP28(ISP) [ISP-HEADER01]	
CY7C64315@QFN16 [(SA743)]	
CY7C64315@QFN16(ISP) [ISP-HEADER01]	
CY7C64316@QFN16 [(SA743)]	
CY7C64316@QFN16(ISP) [ISP-HEADER01]	
CY7C64345@QFN32 [(SA686)]	
CY7C64345@QFN32(ISP) [ISP-HEADER01]	
CY7C64355@QFN48 [(SA696)]	
CY7C64355@QFN48(ISP) [ISP-HEADER01]	
CY7C64356@QFN48 [(SA696)]	
CY7C64356@QFN48(ISP) [ISP-HEADER01]	
CY7C65013	CY7C65013@SSOP48 [(SA669)]
CY7C65013C	CY7C65013C@SSOP48 [(SA669)]
CY7C65113	CY7C65113@SOIC28 [(SA404)]
CY7C65113C	CY7C65113C@SOIC28 [(SA404)]
CY7C66011	CY7C66011@SSOP48 [(SA669)]
CY7C66011C	CY7C66011C@SSOP48 [(SA669)]
CY7C66012	CY7C66012@SSOP48 [(SA669)]
CY7C66012C	CY7C66012C@SSOP48 [(SA669)]
CY7C66013	CY7C66013@SSOP48 [(SA669)]
CY7C66013C	CY7C66013C@SSOP48 [(SA669)]
CY7C66111@QFN56 [(PEP+S706)]	
CY7C66111@SSOP56(*) [(SA772-B183)]	
CY7C66111@TSOP56(*) [(SA628+B183)]	
CY7C66111C@QFN56 [(PEP+S706)]	
CY7C66111C@SSOP56(*) [(SA772-B183)]	

CY7C66111C@TSOP56 (\*) [(SA628+B183)]  
 CY7C66112@QFN56 [(PEP+S706)]  
 CY7C66112@SSOP56 (\*) [(SA772-B183)]  
 CY7C66112@TSOP56 (\*) [(SA628+B183)]  
 CY7C66112C@QFN56 [(PEP+S706)]  
 CY7C66112C@SSOP56 (\*) [(SA772-B183)]  
 CY7C66112C@TSOP56 (\*) [(SA628+B183)]  
 CY7C66113@QFN56 [(PEP+S706)]  
 CY7C66113@SSOP56 (\*) [(SA772-B183)]  
 CY7C66113@TSOP56 (\*) [(SA628+B183)]  
 CY7C66113C@QFN56 [(PEP+S706)]  
 CY7C66113C@SSOP56 (\*) [(SA772-B183)]  
 CY7C66113C@TSOP56 (\*) [(SA628+B183)]  
 CY8C20000@MLF48 [(SA696)]  
 CY8C20000@MLF48 (ISP) [ISP-HEADER01]  
 CY8C20234@MLF16 [(SA743)]  
 CY8C20234@MLF16 (ISP) [ISP-HEADER01]  
 CY8C20246@QFN16 [(SA743)]  
 CY8C20246@QFN16 (ISP) [ISP-HEADER01]  
 CY8C20266@QFN16 [(SA743)]  
 CY8C20266@QFN16 (ISP) [ISP-HEADER01]  
 CY8C20324@MLF24 [(SA710)]  
 CY8C20324@MLF24 (ISP) [ISP-HEADER01]  
 CY8C20334@MLF24 [(SA710)]  
 CY8C20334@MLF24 (ISP) [ISP-HEADER01]  
 CY8C20346@QFN24 [(SA710)]  
 CY8C20346@QFN24 (ISP) [ISP-HEADER01]  
 CY8C20366@QFN24 [(SA710)]  
 CY8C20366@QFN24 (ISP) [ISP-HEADER01]  
 CY8C20424@MLF32 [(SA686)]  
 CY8C20424@MLF32 (ISP) [ISP-HEADER01]  
 CY8C20434@MLF32 [(SA686)]  
 CY8C20434@MLF32 (ISP) [ISP-HEADER01]  
 CY8C20446@MLF32 [(SA686)]  
 CY8C20446@MLF32 (ISP) [ISP-HEADER01]  
 CY8C20466@MLF32 [(SA686)]  
 CY8C20466@MLF32 (ISP) [ISP-HEADER01]  
 CY8C20546@SSOP48 [(SA669)]  
 CY8C20546@SSOP48 (ISP) [ISP-HEADER01]  
 CY8C20566@SSOP48 [(SA669)]  
 CY8C20566@SSOP48 (ISP) [ISP-HEADER01]  
 CY8C20646@QFN48 [(SA696)]  
 CY8C20646@QFN48 (ISP) [ISP-HEADER01]  
 CY8C20666@QFN48 [(SA696)]  
 CY8C20666@QFN48 (ISP) [ISP-HEADER01]  
 CY8C21123@SOIC8 [(SA602A)]  
 CY8C21123@SOIC8 (ISP) [ISP-HEADER01]  
 CY8C21223@SOIC16 [(SA602)]  
 CY8C21223@SOIC16 (ISP) [ISP-HEADER01]  
 CY8C21234@SOIC16 [(SA602)]  
 CY8C21234@SOIC16 (ISP) [ISP-HEADER01]  
 CY8C21323@MLF24 [(BBBB)]  
 CY8C21323@MLF24 (ISP) [ISP-HEADER01]  
 CY8C21323@SSOP20 [(SA626A)]  
 CY8C21323@SSOP20 (ISP) [ISP-HEADER01]  
 CY8C21334@SSOP20 [(SA626A)]  
 CY8C21334@SSOP20 (ISP) [ISP-HEADER01]  
 CY8C21434@MLF32 [(SA686)]  
 CY8C21434@MLF32 (ISP) [ISP-HEADER01]  
 CY8C21534@SSOP28 [(SA626A)]  
 CY8C21534@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C21634@MLF32 [(SA686)]  
 CY8C21634@MLF32 (ISP) [ISP-HEADER01]  
 CY8C22113  
 CY8C22113 (ISP) [ISP-HEADER01]  
 CY8C22113@SOIC8 [(SA602A)]  
 CY8C22113@SOIC8 (ISP) [ISP-HEADER01]  
 CY8C22213  
 CY8C22213 (ISP) [ISP-HEADER01]  
 CY8C22213@MLF32 [(SA686)]  
 CY8C22213@MLF32 (ISP) [ISP-HEADER01]  
 CY8C22213@SOIC20 [(SA404)]  
 CY8C22213@SOIC20 (ISP) [ISP-HEADER01]  
 CY8C22213@SSOP20 [(SA626A)]  
 CY8C22213@SSOP20 (ISP) [ISP-HEADER01]  
 CY8C24123  
 CY8C24123 (ISP) [ISP-HEADER01]  
 CY8C24123@SOIC8 [(SA602A)]  
 CY8C24123@SOIC8 (ISP) [ISP-HEADER01]  
 CY8C24123A  
 CY8C24123A (ISP) [ISP-HEADER01]  
 CY8C24123A@SOIC8 [(SA602A)]  
 CY8C24123A@SOIC8 (ISP) [ISP-HEADER01]  
 CY8C24223  
 CY8C24223 (ISP) [ISP-HEADER01]  
 CY8C24223@SOIC20 [(SA404)]

CY8C24223@SOIC20 (ISP) [ISP-HEADER01]  
 CY8C24223@SSOP20 [(SA626A)]  
 CY8C24223@SSOP20 (ISP) [ISP-HEADER01]  
 CY8C24223A  
 CY8C24223A@SOIC20 [(SA404)]  
 CY8C24223A@SOIC20 (ISP) [ISP-HEADER01]  
 CY8C24223A@SSOP20 [(SA626A)]  
 CY8C24223A@SSOP20 (ISP) [ISP-HEADER01]  
 CY8C24423  
 CY8C24423@MLF32 [(SA686)]  
 CY8C24423@MLF32 (ISP) [ISP-HEADER01]  
 CY8C24423@SOIC28 [(SA404)]  
 CY8C24423@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24423@SSOP28 [(SA626A)]  
 CY8C24423@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24423A  
 CY8C24423A@MLF32 [(SA686)]  
 CY8C24423A@MLF32 (ISP) [ISP-HEADER01]  
 CY8C24423A@SOIC28 [(SA404)]  
 CY8C24423A@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24423A@SSOP28 [(SA626A)]  
 CY8C24423A@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24533  
 CY8C24533@SOIC28 [(SA404)]  
 CY8C24533@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24533@SSOP28 [(SA626A)]  
 CY8C24533@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24533A  
 CY8C24533A@SOIC28 [(SA404)]  
 CY8C24533A@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24533A@SSOP28 [(SA626A)]  
 CY8C24533A@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24533C  
 CY8C24533C@SOIC28 [(SA404)]  
 CY8C24533C@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24533C@SSOP28 [(SA626A)]  
 CY8C24533C@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24633  
 CY8C24633@SOIC28 [(SA404)]  
 CY8C24633@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24633@SSOP28 [(SA626A)]  
 CY8C24633@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24633A  
 CY8C24633A@SOIC28 [(SA404)]  
 CY8C24633A@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24633A@SSOP28 [(SA626A)]  
 CY8C24633A@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24633C  
 CY8C24633C@SOIC28 [(SA404)]  
 CY8C24633C@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C24633C@SSOP28 [(SA626A)]  
 CY8C24633C@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C24794@MLF56 [(PEP+S706)]  
 CY8C24794@MLF56 (\*) [(SA706+B268)]  
 CY8C24794@MLF56 (ISP) [ISP-HEADER01]  
 CY8C24894@MLF56 [(PEP+S706)]  
 CY8C24894@MLF56 (\*) [(SA706+B268)]  
 CY8C24894@MLF56 (ISP) [ISP-HEADER01]  
 CY8C24994@MLF68 [(PEP+S762)]  
 CY8C24994@MLF68 (ISP) [ISP-HEADER01]  
 CY8C25122  
 CY8C26233  
 CY8C26233@SOIC20 [(SA404)]  
 CY8C26233@SOIC20 (ISP) [ISP-HEADER01]  
 CY8C26233@SSOP20 [(SA626A)]  
 CY8C26233@SSOP20 (ISP) [ISP-HEADER01]  
 CY8C26443  
 CY8C26443@SOIC28 [(SA404)]  
 CY8C26443@SOIC28 (ISP) [ISP-HEADER01]  
 CY8C26443@SSOP28 [(SA626A)]  
 CY8C26443@SSOP28 (ISP) [ISP-HEADER01]  
 CY8C26643  
 CY8C26643@SSOP48 [(SA669)]  
 CY8C26643@SSOP48 (ISP) [ISP-HEADER01]  
 CY8C26643@TQFP44 [(SA245A)]  
 CY8C26643@TQFP44 (ISP) [ISP-HEADER01]  
 CY8C27143  
 CY8C27243  
 CY8C27243@SOIC20 [(SA404)]  
 CY8C27243@SOIC20 (ISP) [ISP-HEADER01]  
 CY8C27243@SSOP20 [(SA626A)]

CY8C24223A (ISP) [ISP-HEADER01]  
 CY8C24423 (ISP) [ISP-HEADER01]  
 CY8C24423A (ISP) [ISP-HEADER01]  
 CY8C24533 (ISP) [ISP-HEADER01]  
 CY8C24533A (ISP) [ISP-HEADER01]  
 CY8C24533C (ISP) [ISP-HEADER01]  
 CY8C24633 (ISP) [ISP-HEADER01]  
 CY8C24633A (ISP) [ISP-HEADER01]  
 CY8C24633C (ISP) [ISP-HEADER01]  
 CY8C25122 (ISP) [ISP-HEADER01]  
 CY8C26233 (ISP) [ISP-HEADER01]  
 CY8C26443 (ISP) [ISP-HEADER01]  
 CY8C26643 (ISP) [ISP-HEADER01]  
 CY8C27143 (ISP) [ISP-HEADER01]  
 CY8C27243 (ISP) [ISP-HEADER01]

```

CY8C27243@SSOP20(ISP) [ISP-HEADER01]
CY8C27443                                     CY8C27443(ISP) [ISP-HEADER01]
CY8C27443@SOIC28 [(SA404)]
CY8C27443@SOIC28(ISP) [ISP-HEADER01]
CY8C27443@SSOP28 [(SA626A)]
CY8C27443@SSOP28(ISP) [ISP-HEADER01]
CY8C27466                                     CY8C27466(ISP) [ISP-HEADER01]
CY8C27466@SSOP28 [(SA626A)]
CY8C27466@SSOP28(ISP) [ISP-HEADER01]
CY8C27543@TQFP44 [(SA245A)]
CY8C27543@TQFP44(ISP) [ISP-HEADER01]
CY8C27566@TQFP44 [(SA245A)]
CY8C27566@TQFP44(ISP) [ISP-HEADER01]
CY8C27643@MLF48 [(SA696)]
CY8C27643@MLF48(ISP) [ISP-HEADER01]
CY8C27643@SSOP48 [(SA669)]
CY8C27643@SSOP48(ISP) [ISP-HEADER01]
CY8C27666@MLF48 [(SA696)]
CY8C27666@MLF48(ISP) [ISP-HEADER01]
CY8C27666@SSOP48 [(SA669)]
CY8C27666@SSOP48(ISP) [ISP-HEADER01]
CY8C27866@TQFP100 [(PEP+S604)]
CY8C27866@TQFP100(*) [(TA052-B006)]
CY8C27866@TQFP100(ISP) [ISP-HEADER01]
CY8C29466                                     CY8C29466(ISP) [ISP-HEADER01]
CY8C29466@SSOP28 [(SA626A)]
CY8C29466@SSOP28(ISP) [ISP-HEADER01]
CY8C29566@TQFP44 [(SA245A)]
CY8C29566@TQFP44(ISP) [ISP-HEADER01]
CY8C29666@MLF48 [(SA696)]
CY8C29666@MLF48(ISP) [ISP-HEADER01]
CY8C29666@SSOP48 [(SA669)]
CY8C29666@SSOP48(ISP) [ISP-HEADER01]
CY8C29866@TQFP100 [(PEP+S604)]
CY8C29866@TQFP100(*) [(TA052-B006)]
CY8C29866@TQFP100(ISP) [ISP-HEADER01]
CY8CTMA110@QFN32 [(SA686)]
CY8CTMG200@QFN16 [(SA743)]
CY8CTMG200@QFN32 [(SA686)]
CY8CTMG200@SSOP48 [(SA686)]
CY8CTMG200A@QFN24 [(SA710)]
CY8CTMG200A@QFN48 [(SA696)]
CY8CTMG201@QFN16 [(SA743)]
CY8CTMG201@QFN32 [(SA686)]
CY8CTMG201@SSOP48 [(SA686)]
CY8CTMG201A@QFN24 [(SA710)]
CY8CTMG201A@QFN48 [(SA696)]
CY8CTST110@QFN32 [(SA686)]
CYRF69213@QFN40 [(SA750)]
CY8CTMG110@QFN32 [(SA686)]
CY8CTMG200@QFN24 [(SA710)]
CY8CTMG200@QFN48 [(SA696)]
CY8CTMG200A@QFN16 [(SA743)]
CY8CTMG200A@QFN32 [(SA686)]
CY8CTMG200A@SSOP48 [(SA686)]
CY8CTMG201@QFN24 [(SA710)]
CY8CTMG201@QFN48 [(SA696)]
CY8CTMG201A@QFN16 [(SA743)]
CY8CTMG201A@QFN32 [(SA686)]
CY8CTMG201A@SSOP48 [(SA686)]
CYRF69103@QFN40 [(SA750)]

```

## DALLAS

### E(E) PROM/FRAM/NVRAM

```

DS1073M-100
DS1073M-66
DS1073Z-100@SOIC8 [(SA602A)]
DS1073Z-66@SOIC8 [(SA602A)]
DS1077LZ-40@SOIC8 [(SA602A)]
DS1077LZ-60@SOIC8 [(SA602A)]
DS1077Z-40@SOIC8 [(SA602A)]
DS1077Z-60@SOIC8 [(SA602A)]
DS1220AB
DS1220Y
DS1225AD
DS1225E
DS1230AB
DS1230Y
DS1235Y
DS1244
DS1245AB
DS1245P
DS1245Y
DS1248W
DS1249AB
DS1249Y
DS1250W
DS1251AB
DS1073M-60
DS1073M-80
DS1073Z-60@SOIC8 [(SA602A)]
DS1073Z-80@SOIC8 [(SA602A)]
DS1077LZ-50@SOIC8 [(SA602A)]
DS1077LZ-66@SOIC8 [(SA602A)]
DS1077Z-50@SOIC8 [(SA602A)]
DS1077Z-66@SOIC8 [(SA602A)]
DS1220AD
DS1225AB
DS1225D
DS1225Y
DS1230W
DS1235AB
DS1243Y
DS1244Y
DS1245EE
DS1245W
DS1248P
DS1248Y
DS1249W
DS1250AB
DS1250Y
DS1251W

```

DS1251Y	DS1256P
DS1256W	DS1256Y
DS1258AB	DS1258W
DS1258Y	DS1265AB
DS1265W	DS1265Y
DS1270AB	DS1270W
DS1270Y	DS1284
DS1284N	DS1284Q@PLCC28 [(SA008A)]
DS1284QN@PLCC28 [(SA008A)]	DS1286
DS1286I	DS1287
DS1287A	DS12887
DS12887A	DS12C887
DS12C887A	DS1330AB
DS1330WP	DS1330Y
DS1345AB	DS1345P
DS1345W	DS1345Y
DS1350AB	DS1350P
DS1350W	DS1350Y
DS1386(32K)	DS1386(8K)
DS14285	DS14287
DS1485	DS1485@SOIC28 [(SA630)]
DS1486	DS1488
DS1501	DS1511
DS1553	DS1553W
DS1554	DS1554W
DS1556	DS1630AB
DS1630Y	DS1642
DS1643	DS1644
DS1644P	DS1644PS [(PEP+S414T)]
DS1645AB	DS1645EE
DS1645Y	DS1646
DS1647	DS1647LPM
DS1650AB	DS1650Y
DS1687-3	DS1687-5
DS17287-3	DS17287-5
DS1742	DS1742W
DS1743	DS1743P
DS1743W	DS1743WP
DS1744	DS1744P
DS1744W	DS1744WP
DS1746	DS1747
DS1747P	DS1747PS [(PEP+S414T)]
DS1747W	DS1747WP
DS1747WPS [(PEP+S414T)]	DS17487-3
DS17487-5	DS17887-3
DS17887-5	DS2406@TO-92
DS2406P@TSOC6	DS2430A@TO-92
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-92
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6 [(SA602A)]
DS2433@PR-35	DS2433S(3.9)@SOIC8 [(SA602A)]
DS2433S(5.5)@SOIC8 [(SA605A)]	DS2502
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8 [(SA602A)]
DS2502UNW	DS2502UNW@SOIC8 [(SA602A)]
DS2502UNW@TSOC6 [(SA602A)]	DS2506
DS2506S@SOIC8 [(SA023A)]	DS4510@uSOP10
DS4520@TSSOP16 [(SA026)]	DS4550@TSSOP20 [(SA026)]

**MICROCONTROLLER**

DS5000[32K]	DS5000[8K]
DS5000T[32K]	DS5000T[8K]
DS87C520	DS87C520@PLCC44 [(SA244)]
DS87C520@TQFP44 [(SA245A)]	DS87C530@PLCC52 [(PEP+S415T)]
DS87C550@PLCC68 [(PEP+S414T)]	DS89C420
DS89C420(rev.A)	DS89C420(rev.A)@PLCC44 [(SA244)]
DS89C420(rev.A)@TQFP44 [(SA245A)]	DS89C420@TQFP44 [(SA245A)]
DS89C420@PLCC44 [(SA244)]	DS89C430@PLCC44 [(SA244)]
DS89C430	DS89C440
DS89C430@TQFP44 [(SA245A)]	DS89C440@TQFP44 [(SA245A)]
DS89C440@PLCC44 [(SA244)]	DS89C450@PLCC44 [(SA244)]
DS89C450	
DS89C450@TQFP44 [(SA245A)]	

**DENSE-PAC****E(E) PROM/FRAM/NVRAM**

DPV27C101	DPV27C101@PLCC32 [(SA015A1T)]
DPV27C256	DPV27C256@PLCC32 [(SA015A1T)]
DPV27C512	DPV27C512@PLCC32 [(SA015A1T)]

## DEUTRON

### E (E) PROM/FRAM/NVRAM

AC25LV010	AC25LV010@SOIC8 [(SA602A)]
AC25LV512	AC25LV512@SOIC8 [(SA602A)]
P439LV010@PLCC32 [(SA015A1T)]	P439LV010@VSOP32 [(SA620)]
P439LV040@PLCC32 [(SA015A1T)]	P439LV040@VSOP32 [(SA620)]
P439LV088@TSOP48 [(SA247-B005)]	P439VF800@TSOP48 [(SA247-B005)]

## EFST

### E (E) PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)]	EM25LV010@VFQFPN8 [(SA684)]
EM25LV512@SOIC8 [(SA602A)]	EM25LV512@VFQFPN8 [(SA684)]
F25L004A@SOIC8 [(SA602A)]	F49B002UA
F49B002UA@PLCC32 [(SA015A1T)]	F49L004BA@PLCC32 [(SA015A1T)]
F49L004BA@TSOP40 [(SA409T)]	F49L004UA@PLCC32 [(SA015A1T)]
F49L004UA@TSOP40 [(SA409T)]	F49L040A@PLCC32 [(SA015A1T)]
F49L040A@VSOP32 [(SA620)]	F49L400BA@TSOP48 [(SA247-B005)]
F49L400UA@TSOP48 [(SA247-B005)]	F49L800BA@TSOP48 [(SA247)]
F49L800UA@TSOP48 [(SA247)]	

## ELECTRONIC ARRAYS

### E (E) PROM/FRAM/NVRAM

EA2716

## ELPIDA

### E (E) PROM/FRAM/NVRAM

EHD0010A1MA@FBGA137 [(SA700C-B327A-Y137F001Y)]
EHD013011MA@FBGA137 [(SA700C-B327A-Y137F001Y)]
EHF0030A17B@FBGA137 [(SA700E-B153A-M137F001Y)]

## EM

### MICROCONTROLLER

EM6503@SOIC24 [(SA404)]	
EM6503@SOIC24 (ISP) [ISP-HEADER01]	
EM6504@SOIC24 [(SA404)]	
EM6504@SOIC24 (ISP) [ISP-HEADER01]	
EM6505@SOIC24 [(SA404)]	
EM6505@SOIC24 (ISP) [ISP-HEADER01]	
EM6517@SOIC28 [(SA404)]	
EM6517@SOIC28 (ISP) [ISP-HEADER01]	
EM6520@TQFP44 [(SA245A)]	
EM6520@TQFP44 (ISP) [ISP-HEADER01]	
EM6521@TQFP52 [(PEP+S673)]	
EM6521@TQFP52 (ISP) [ISP-HEADER01]	
EM6522@TQFP64 [(PEP+S616)]	
EM6522@TQFP64 (ISP) [ISP-HEADER01]	
EM6540@SOIC18 [(SA404)]	
EM6540@SOIC18 (ISP) [ISP-HEADER01]	
EM6580	EM6580 (ISP) [ISP-HEADER01]
EM6580@SOIC14 [(SA602)]	
EM6580@SOIC14 (ISP) [ISP-HEADER01]	

```

EM6580@SOIC8 [(SA602A)]           EM6580@SOIC8(ISP) [ISP-HEADER01]
EM6580@TSSOP14 [(SA026)]
EM6580@TSSOP14(ISP) [ISP-HEADER01]
EM6812_2K                           EM6812_2K(ISP) [ISP-HEADER01]
EM6812_2K@SOIC24 [(SA404)]
EM6812_2K@SOIC24(ISP) [ISP-HEADER01]
EM6812_2K@TSSOP24 [(SA026)]
EM6812_2K@TSSOP24(ISP) [ISP-HEADER01]
EM6812_4K                           EM6812_4K(ISP) [ISP-HEADER01]
EM6812_4K@SOIC24 [(SA404)]
EM6812_4K@SOIC24(ISP) [ISP-HEADER01]
EM6812_4K@TSSOP24 [(SA026)]
EM6812_4K@TSSOP24(ISP) [ISP-HEADER01]
EM6812_8K                           EM6812_8K(ISP) [ISP-HEADER01]
EM6812_8K@SOIC24 [(SA404)]
EM6812_8K@SOIC24(ISP) [ISP-HEADER01]
EM6812_8K@TSSOP24 [(SA026)]
EM6812_8K@TSSOP24(ISP) [ISP-HEADER01]

```

## EMTC

### E(E) PROM/FRAM/NVRAM

```

EM24C02                               EM24C02@SOIC8 [(SA602A)]
EM24C02@TSSOP8 [(SA026)]           EM24C04
EM24C04@SOIC8 [(SA602A)]           EM24C04@TSSOP8 [(SA026)]
EM24C08                               EM24C08@SOIC8 [(SA602A)]
EM24C08@TSSOP8 [(SA026)]           EM24C16
EM24C16@SOIC8 [(SA602A)]           EM24C16@TSSOP8 [(SA026)]
EM25SL512@SOIC8 [(SA602A)]         EM29SF002AB
EM29SF002AB@PLCC32 [(SA015A1T)]    EM29SF002AB@TSOP32 [(SA410T)]
EM29SF002AT                           EM29SF002AT@PLCC32 [(SA015A1T)]
EM29SF002AT@TSOP32 [(SA410T)]      EM29SF002NAB
EM29SF002NAB@PLCC32 [(SA015A1T)]   EM29SF002NAB@TSOP32 [(SA410T)]
EM29SF002NAT                           EM29SF002NAT@PLCC32 [(SA015A1T)]
EM29SF002NAT@TSOP32 [(SA410T)]

```

## EON

### E(E) PROM/FRAM/NVRAM

```

EN25B05(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B05(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B05(Bottom Boot)@VDFN8 [(SA683)]
EN25B05(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B05(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B05(Top Boot)@VDFN8 [(SA683)]
EN25B10(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B10(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B10(Bottom Boot)@VDFN8 [(SA683)]
EN25B10(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B10(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B10(Top Boot)@VDFN8 [(SA683)]
EN25B16(Bottom Boot)@SOP8 [(SA605A)]
EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]
EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]
EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]
EN25B16(Top Boot)@SOP8 [(SA605A)]
EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]
EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]
EN25B16(Top Boot)@VFQFPN8 [(SA684)]
EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B20(Bottom Boot)@VDFN8 [(SA683)]
EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B20(Top Boot)@VDFN8 [(SA683)]
EN25B32(Bottom Boot)@SOIC16 [(SA404)]
EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]
EN25B32(Bottom Boot)@SOP8 [(SA605A)]
EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]
EN25B32(Bottom Boot)@VDFN8 [(SA684)]
EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]
EN25B32(Top Boot)@SOIC16 [(SA404)]

```



```

EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]
EN25B32(Top Boot)@SOP8 [(SA605A)]
EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]
EN25B32(Top Boot)@VDFN8 [(SA684)]
EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]
EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B40(Bottom Boot)@VDFN8 [(SA683)]
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B40(Top Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@SOIC16 [(SA404)]
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Bottom Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@SOIC16 [(SA404)]
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@VDFN8 [(SA683)]
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Bottom Boot)@VDFN8 [(SA683)]
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Top Boot)@VDFN8 [(SA683)]
EN25D16
EN25D16@SOP8 [(SA605A)]
EN25D80
EN25D80@VDFN8 [(SA683)]
EN25F05@SOP8(5.4) [(SA605A)]
EN25F10@SOP8(4.0) [(SA602A)]
EN25F10@VDFN8 [(SA683)]
EN25F16@SOP16 [(SA404)]
EN25F16@VDFN8 [(SA684)]
EN25F20@VDFN8 [(SA683)]
EN25F32@SOIC16 [(SA404)]
EN25F32@VDFN8 [(SA684)]
EN25F40@SOP8(200mil) [(SA605A)]
EN25F80
EN25F80@VDFN8 [(SA683)]
EN25LF05@SOP8(5.4) [(SA605A)]
EN25LF10@SOP8(4.0) [(SA602A)]
EN25LF10@VDFN8 [(SA683)]
EN25LF20@VDFN8 [(SA683)]
EN25LF40@SOP8(200mil) [(SA605A)]
EN25LV010@SOIC8 [(SA602A)]
EN25LV020@SOIC8 [(SA602A)]
EN25LV040@SOIC8 [(SA602A)]
EN25LV080@SOIC8 [(SA602A)]
EN25LV160@SOIC8 [(SA602A)]
EN25LV160@SOIC8(ISP) [ISP-HEADER01]
EN25LV160@VFQFPN8 [(SA683)]
EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]
EN25LV512@SOIC8 [(SA602A)]
EN25P05@SOP8(4.0) [(SA602A)]
EN25P05@VDFN8 [(SA683)]
EN25P10@SOP8(5.4) [(SA605A)]
EN25P16@SOP8 [(SA605A)]
EN25P16@VFQFPN8 [(SA684)]
EN25P16@VFQFPN8(ISP) [ISP-HEADER01]
EN25P20@SOP8(4.0) [(SA602A)]
EN25P20@VDFN8 [(SA683)]
EN25P32@SOIC16(ISP) [(SA404)]
EN25P32@SOP8(ISP) [(SA605A)]
EN25P32@VDFN8(ISP) [(SA684)]
EN25P40@SOP8(5.4) [(SA605A)]
EN25P64@SOIC16 [(SA404)]
EN25P64@SOIC16(ISP) [ISP-HEADER01]
EN25P64@VDFN8 [(SA683)]
EN25P64@VDFN8(ISP) [ISP-HEADER01]
EN25P80@SOP8(4.0) [(SA602A)]
EN25P80@VDFN8 [(SA683)]
EN25Q16@SOP16 [(SA404)]
EN25Q16@VDFN8 [(SA684)]
EN25Q32A@SOP8 [(SA605A)]
EN25Q40@SOP8 [(SA605A)]
EN25Q64@SOP16 [(SA404)]
EN25Q64@VDFN8(5*6mm) [(SA683)]
EN25Q80A@SOP8(4.0) [(SA602A)]
EN25Q80A@VDFN8 [(SA683)]
EN25S10@VDFN8 [(SA724)]
EN25D16@SOP16 [(SA404)]
EN25D16@VDFN8 [(SA684)]
EN25D80@SOP8 [(SA605A)]
EN25F05@SOP8(4.0) [(SA602A)]
EN25F05@VDFN8 [(SA683)]
EN25F10@SOP8(5.4) [(SA605A)]
EN25F16
EN25F16@SOP8 [(SA605A)]
EN25F20@SOP8 [(SA605A)]
EN25F32
EN25F32@SOP8 [(SA605A)]
EN25F40@SOP8(150mil) [(SA602A)]
EN25F40@VDFN8 [(SA683)]
EN25F80@SOP8 [(SA605A)]
EN25LF05@SOP8(4.0) [(SA602A)]
EN25LF05@VDFN8 [(SA683)]
EN25LF10@SOP8(5.4) [(SA605A)]
EN25LF20@SOP8 [(SA605A)]
EN25LF40@SOP8(150mil) [(SA602A)]
EN25LF40@VDFN8 [(SA683)]
EN25LV010@VFQFPN8 [(SA684)]
EN25LV020@VFQFPN8 [(SA684)]
EN25LV040@VFQFPN8 [(SA684)]
EN25LV080@VFQFPN8 [(SA684)]
EN25LV512@VFQFPN8 [(SA684)]
EN25P05@SOP8(5.4) [(SA605A)]
EN25P10@SOP8(4.0) [(SA602A)]
EN25P10@VDFN8 [(SA683)]
EN25P16@SOP8(ISP) [ISP-HEADER01]
EN25P20@SOP8(5.4) [(SA605A)]
EN25P32@SOIC16 [(SA404)]
EN25P32@SOP8 [(SA605A)]
EN25P32@VDFN8 [(SA684)]
EN25P40@SOP8(4.0) [(SA602A)]
EN25P40@VDFN8 [(SA683)]
EN25P80@SOP8(5.4) [(SA605A)]
EN25Q16
EN25Q16@SOP8 [(SA605A)]
EN25Q32A
EN25Q32A@VDFN8 [(SA683)]
EN25Q40@VDFN8 [(SA683)]
EN25Q64@SOP8 [(SA605)]
EN25Q64@VDFN8(6*8mm) [(SA684)]
EN25Q80A@SOP8(5.4) [(SA605A)]
EN25S10@SOP8 [(SA602A)]
EN25S16@SOP8 [(SA605A)]

```

EN25S16@VFQFPN8 [(SA684)]                    EN25S20@SOP8 [(SA605A)]  
 EN25S20@VDFN8 [(SA724)]  
 EN25S32(Bottom Boot)@SOIC16 [(SA404)]  
 EN25S32(Bottom Boot)@SOIC16(ISP) [(SA404)]  
 EN25S32(Bottom Boot)@SOP8 [(SA605A)]  
 EN25S32(Bottom Boot)@SOP8(ISP) [(SA605A)]  
 EN25S32(Bottom Boot)@VDFN8 [(SA684)]  
 EN25S32(Bottom Boot)@VDFN8(ISP) [(SA684)]  
 EN25S32(Top Boot)@SOIC16 [(SA404)]  
 EN25S32(Top Boot)@SOIC16(ISP) [(SA404)]  
 EN25S32(Top Boot)@SOP8 [(SA605A)]  
 EN25S32(Top Boot)@SOP8(ISP) [(SA605A)]  
 EN25S32(Top Boot)@VDFN8 [(SA684)]  
 EN25S32(Top Boot)@VDFN8(ISP) [(SA684)]  
 EN25S40@SOP8 [(SA605A)]                    EN25S40@VDFN8(2\*3mm) [(SA724)]  
 EN25S40@VDFN8(5\*6mm) [(SA683)]           EN25S80@SOP8(150mil) [(SA605A)]  
 EN25S80@SOP8(200mil) [(SA602A)]           EN25S80@VDFN8 [(SA683)]  
 EN25T16@SOP8 [(SA605A)]                    EN25T16@VFQFPN8 [(SA684)]  
 EN25T80                                        EN25T80@SOP8 [(SA605A)]  
 EN25T80@VDFN8 [(SA683)]                    EN27C010  
 EN27C010@PLCC32 [(SA015A1T)]            EN27C512  
 EN27C512@PLCC32 [(SA015A1T)]            EN29F002AB  
 EN29F002AB@PLCC32 [(SA015A1T)]          EN29F002AB@TSOP32 [(SA410T)]  
 EN29F002ANB                                 EN29F002ANB@PLCC32 [(SA015A1T)]  
 EN29F002ANB@TSOP32 [(SA410T)]            EN29F002ANT  
 EN29F002ANT@PLCC32 [(SA015A1T)]        EN29F002ANT@TSOP32 [(SA410T)]  
 EN29F002AT                                  EN29F002AT@PLCC32 [(SA015A1T)]  
 EN29F002AT@TSOP32 [(SA410T)]            EN29F002B  
 EN29F002B@PLCC32 [(SA015A1T)]          EN29F002B@TSOP32 [(SA410T)]  
 EN29F002NB                                  EN29F002NB@PLCC32 [(SA015A1T)]  
 EN29F002NB@TSOP32 [(SA410T)]            EN29F002NT  
 EN29F002NT@PLCC32 [(SA015A1T)]        EN29F002NT@TSOP32 [(SA410T)]  
 EN29F002T                                    EN29F002T@PLCC32 [(SA015A1T)]  
 EN29F002T@TSOP32 [(SA410T)]            EN29F010  
 EN29F010@PLCC32 [(SA015A1T)]            EN29F010@TSOP32 [(SA410T)]  
 EN29F010@VSOP32 [(SA620)]                EN29F040  
 EN29F040@PLCC32 [(SA015A1T)]            EN29F040@TSOP32 [(SA410T)]  
 EN29F040A                                    EN29F040A@PLCC32 [(SA015A1T)]  
 EN29F040A@TSOP32 [(SA410T)]            EN29F080@TSOP40 [(SA409T)]  
 EN29F512                                    EN29F512@PLCC32 [(SA015A1T)]  
 EN29F512@TSOP32 [(SA410T)]            EN29F512@VSOP32 [(SA620)]  
 EN29F800B@TSOP48 [(SA247-B005)]        EN29F800T@TSOP48 [(SA247-B005)]  
 EN29LV010@PLCC32 [(SA015A1T)]            EN29LV010@TSOP32 [(SA410T)]  
 EN29LV010@VSOP32 [(SA620)]                EN29LV040@PLCC32 [(SA015A1T)]  
 EN29LV040@TSOP32 [(SA410T)]            EN29LV040@VSOP32 [(SA620)]  
 EN29LV040A@PLCC32 [(SA015A1T)]        EN29LV040A@TSOP32 [(SA410T)]  
 EN29LV040A@VSOP32 [(SA620)]  
 EN29LV160AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160AB@TSOP48 [(SA247-B005)]  
 EN29LV160AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160AT@TSOP48 [(SA247-B005)]  
 EN29LV160B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160B@TSOP48 [(SA247-B005)]  
 EN29LV160T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160T@TSOP48 [(SA247-B005)]  
 EN29LV320AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV320AB@TSOP48 [(SA247-B005)]  
 EN29LV320AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV320AT@TSOP48 [(SA247-B005)]  
 EN29LV320B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV320B@TSOP48 [(SA247-B005)]  
 EN29LV320T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV320T@TSOP48 [(SA247-B005)]  
 EN29LV400AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400AB@TSOP48 [(SA247-B005)]  
 EN29LV400AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400AT@TSOP48 [(SA247-B005)]  
 EN29LV400B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400B@TSOP48 [(SA247-B005)]  
 EN29LV400T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400T@TSOP48 [(SA247-B005)]        EN29LV512@PLCC32 [(SA015A1T)]  
 EN29LV512@TSOP32 [(SA410T)]            EN29LV512@VSOP32 [(SA620)]  
 EN29LV640B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV640B@TSOP48 [(SA247-B005)]  
 EN29LV640H@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV640H@TSOP48 [(SA247-B005)]  
 EN29LV640L@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV640L@TSOP48 [(SA247-B005)]  
 EN29LV640T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV640T@TSOP48 [(SA247-B005)]  
 EN29LV641H@FBGA63 [(SA642M-B026A-W048F001Y)]

EN29LV641H@TSOP48 [(SA247-B005)]  
 EN29LV641L@FBGA63 [(SA642M-B026A-W048F001Y)]  
 EN29LV641L@TSOP48 [(SA247-B005)]  
 EN29LV800AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV800AB@TSOP48 [(SA247-B005)]  
 EN29LV800AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV800AT@TSOP48 [(SA247-B005)]  
 EN29LV800B@TSOP48 [(SA247-B005)]  
 EN29LV800BB(Low)@TSOP48 [(SA247-B005)]  
 EN29LV800BB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV800BB@TSOP48 [(SA247-B005)]  
 EN29LV800BT(Low)@TSOP48 [(SA247-B005)]  
 EN29LV800BT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV800BT@TSOP48 [(SA247-B005)]  
 EN29LV800CB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV800CB@TSOP48 [(SA247-B005)]  
 EN29LV800CT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV800CT@TSOP48 [(SA247-B005)]  
 EN29LV800T@TSOP48 [(SA247-B005)]  
 EN29PL032@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29PL032@FBGA56 [(SA642P-B079A-W056F001Y)]  
 EN29PL032@TSOP48 [(SA247-B005)]  
 EN29PL064@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29PL064@FBGA56 [(SA642P-B079A-W056F001Y)]  
 EN29PL064@TSOP48 [(SA247-B005)]  
 EN29SL160B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29SL160B@TSOP48 [(SA247-B005)]  
 EN29SL160T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29SL160T@TSOP48 [(SA247-B005)]  
 EN29SL400B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29SL400B@TSOP48 [(SA247-B005)]  
 EN29SL400T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29SL400T@TSOP48 [(SA247-B005)]  
 EN29SL800B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29SL800B@TSOP48 [(SA247-B005)]  
 EN29SL800T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29SL800T@TSOP48 [(SA247-B005)]  
 EN71PL03280(new)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 EN71PL03280@FBGA56 [(SA642P-B079A-W056F001Y)]  
 EN71PL032A0@FBGA56 [(SA642P-B079A-W056F001Y)]  
 EN71PL064A0@FBGA56 [(SA642P-B079A-W056F001Y)]  
 EN71PL064B0@FBGA56 [(SA642P-B079A-W056F001Y)]

## EPSON

### E(E) PROM/FRAM/NVRAM

S1H0H324B2B1@FBGA66 [(SA642E-B023A-T072F001)]  
 S1H0H324B2T1@FBGA66 [(SA642E-B023A-T072F001)]  
 S1H0H326B2B1@FBGA66 [(SA642E-B023A-T072F001)]  
 S1H0H326B2T1@FBGA66 [(SA642E-B023A-T072F001)]  
 S1H0H328B2B2@FBGA66 [(SA642E-B023A-T072F001)]  
 S1H0H328B2T2@FBGA66 [(SA642E-B023A-T072F001)]  
 S1H0J642B2B3@FBGA68 [(SA642E-B023A-T072F001)]  
 S1H0J642B2T3@FBGA68 [(SA642E-B023A-T072F001)]  
 S1H0J646B2B3@FBGA68 [(SA642E-B023A-T072F001)]  
 S1H0J646B2T3@FBGA68 [(SA642E-B023A-T072F001)]  
 S1H0J648B2B2@FBGA68 [(SA642E-B023A-T072F001)]  
 S1H0J648B2T2@FBGA68 [(SA642E-B023A-T072F001)]

## ESMT

### E(E) PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)]  
 EM25LV512@SOIC8 [(SA602A)]  
 F25L004AB  
 F25L004AB@SOIC8(150mil) [(SA602A)]  
 F25L004AB@SOIC8(200mil) [(SA605A)]  
 F25L004AT  
 F25L004AT@SOIC8(150mil) [(SA602A)]  
 F25L004AT@SOIC8(200mil) [(SA605A)]  
 F25L008AB@SOIC8 [(SA605A)]  
 F25L016AB@SOIC8 [(SA605A)]  
 EM25LV010@VFQFPN8 [(SA684)]  
 EM25LV512@VFQFPN8 [(SA684)]  
 F25L008AT@SOIC8 [(SA605A)]  
 F25L016AT@SOIC8 [(SA605A)]

F25L04PA  
 F25L04PA@SOIC8(150mil) [(SA602A)]  
 F25L04PA@SOIC8(200mil) [(SA605A)]  
 F25L04UA@SOIC8 [(SA602A)]  
 F25L08PA(AAI-PROGRAM)@SOIC8 [(SA605A)]  
 F25L08PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]  
 F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]  
 F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]  
 F25L320PA(4K OTP)@SOIC16 [(SA404)]  
 F25L320PA(4K OTP)@SOIC8 [(SA605A)]  
 F25L320PA@SOIC16 [(SA404)] F25L320PA@SOIC8 [(SA605A)]  
 F25L32PA(4K OTP)(new)@SOIC16 [(SA404)]  
 F25L32PA(4K OTP)(new)@SOIC8 [(SA605A)]  
 F25L32PA(4K OTP)@SOIC16 [(SA404)]  
 F25L32PA(4K OTP)@SOIC8 [(SA605A)]  
 F25L32PA(new)@SOIC16 [(SA404)] F25L32PA(new)@SOIC8 [(SA605A)]  
 F25L32PA@SOIC16 [(SA404)] F25L32PA@SOIC8 [(SA605A)]  
 F25L32QA(4K OTP)@SOIC16 [(SA404)]  
 F25L32QA(4K OTP)@SOIC8 [(SA605A)]  
 F25L32QA@SOIC16 [(SA404)] F25L32QA@SOIC8 [(SA605A)]  
 F49B002UA F49B002UA@PLCC32 [(SA015A1T)]  
 F49L004BA@PLCC32 [(SA015A1T)] F49L004BA@TSOP40 [(SA409T)]  
 F49L004UA@PLCC32 [(SA015A1T)] F49L004UA@TSOP40 [(SA409T)]  
 F49L040A@PLCC32 [(SA015A1T)] F49L040A@VSOP32 [(SA620)]  
 F49L160BA@TSOP48 [(SA247)] F49L160UA@TSOP48 [(SA247)]  
 F49L320BA@TSOP48 [(SA247)] F49L320UA@TSOP48 [(SA247)]  
 F49L400BA@TSOP48 [(SA247-B005)] F49L400UA@TSOP48 [(SA247-B005)]  
 F49L800BA@TSOP48 [(SA247)] F49L800UA@TSOP48 [(SA247)]  
 FM91L01604BA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L01604UA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208BA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208BIA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208UA@FBGA56 [(SA642P-B207A-W056F001Y)]  
 FM91L03208UIA@FBGA56 [(SA642P-B207A-W056F001Y)]

## EVERSTAR

### E(E) PROM/FRAM/NVRAM

EV29LV160AB EV29LV160AT  
 EV29LV640MB EV29LV640MT

## EXCELSMI

### E(E) PROM/FRAM/NVRAM

ES25M16 ES25M16@SOP16 [(SA404)]  
 ES25M16@SOP8[150 mil] [(SA602A)] ES25M16@SOP8[208 mil] [(SA605A)]  
 ES25M40 ES25M40@SOP16 [(SA404)]  
 ES25M40@SOP8[150 mil] [(SA602A)] ES25M40@SOP8[208 mil] [(SA605A)]  
 ES25M80 ES25M80@SOP16 [(SA404)]  
 ES25M80@SOP8[150 mil] [(SA602A)] ES25M80@SOP8[208 mil] [(SA605A)]  
 ES25P16@SOP8 [(SA605A)] ES25P40@SOP8 [(SA605A)]  
 ES25P80@SOP8 [(SA605A)]  
 ES29LV160DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV160DB@PSOP44 [(SA638)]  
 ES29LV160DB@TSOP48 [(SA247-B005)]  
 ES29LV160DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV160DT@PSOP44 [(SA638)]  
 ES29LV160DT@TSOP48 [(SA247-B005)]  
 ES29LV160EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV160EB@TSOP48 [(SA247-B005)]  
 ES29LV160ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV160ET@TSOP48 [(SA247-B005)]  
 ES29LV160FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV160FB@TSOP48 [(SA247-B005)]  
 ES29LV160FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV160FT@TSOP48 [(SA247-B005)]  
 ES29LV320DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV320DB@TSOP48 [(SA247-B005)]  
 ES29LV320DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV320DT@TSOP48 [(SA247-B005)]  
 ES29LV320EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV320EB@TSOP48 [(SA247-B005)]

ES29LV320ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV320ET@TSOP48 [(SA247-B005)]  
 ES29LV320FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV320FB@TSOP48 [(SA247-B005)]  
 ES29LV320FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV320FT@TSOP48 [(SA247-B005)]  
 ES29LV400DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400DB@TSOP48 [(SA247-B005)]  
 ES29LV400DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400DT@TSOP48 [(SA247-B005)]  
 ES29LV400EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400EB@TSOP48 [(SA247-B005)]  
 ES29LV400ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV400ET@TSOP48 [(SA247-B005)]  
 ES29LV800DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800DB@PSOP44 [(SA638)]  
 ES29LV800DB@TSOP48 [(SA247-B005)]  
 ES29LV800DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800DT@PSOP44 [(SA638)]  
 ES29LV800DT@TSOP48 [(SA247-B005)]  
 ES29LV800EB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800EB@TSOP48 [(SA247-B005)]  
 ES29LV800ET@FBGA48 [(SA642G-B026A-T048F001Y)]  
 ES29LV800ET@TSOP48 [(SA247-B005)]

## EXEL

### E (E) PROM / FRAM / NVRAM

XL24C01A	XL24C02
XL24C04	XL24C16
XL24C16@SOIC8 [(SA602A)]	XL24C32
XL28C256	XL28C256@PLCC32 [(SA015A1T)]
XL28C256@TSOP28 [(SA430T)]	XL9010
XL9010(F) [(SA602A)]	XL9020
XL9020(F) [(SA602A)]	XL9040
XL9040(F) [(SA602A)]	XL9346
XL9346@SOIC8 [(SA602A)]	XL93CS56
XL93CS56@SOIC8 [(SA602A)]	XL93CS56@TSSOP8 [(SA026)]
XL93CS66	XL93CS66@SOIC8 [(SA602A)]
XL93CS66@TSSOP8 [(SA026)]	XL93LC46
XL93LC46@SOIC8 [(SA602A)]	XL93LC46A
XL93LC46A@SOIC8 [(SA602A)]	XL93LC56
XL93LC56@SOIC8 [(SA602A)]	XL93LC56A
XL93LC56A@SOIC8 [(SA602A)]	XL93LC66A
XL93LC66A@SOIC8 [(SA602A)]	XL9764
XLE28C16A	XLE28C16A@PLCC32 [(SA015A1T)]
XLE28C16B	XLE28C16B@PLCC32 [(SA015A1T)]
XLE28C16B@SOIC24 [(SA404)]	XLM28C16A
XLM28C16A@PLCC32 [(SA015A1T)]	XLM46C15
XLM46P15	XLS2804A
XLS2816A	XLS2816A@PLCC32 [(SA015A1T)]
XLS2817A	XLS28C16A
XLS28C16A@PLCC32 [(SA015A1T)]	XLS28C16B
XLS28C16B@PLCC32 [(SA015A1T)]	XLS28C16B@SOIC24 [(SA404)]
XLS28C64B	XLS28C64B@PLCC32 [(SA015A1T)]
XLS28C64B@SOIC28 [(SA404)]	XLS46C15
XLS46P15	XLS93C46
XLS93C46@SOIC8 [(SA602A)]	XLS93C56
XLS93C56@SOIC8 [(SA602A)]	XLS93C66
XLS93C66@SOIC8 [(SA602A)]	XLS93CS46
XLS93CS46@SOIC8 [(SA602A)]	XLS93CS46@TSSOP8 [(SA026)]
XLS93LC06	XLS93LC06@SOIC8 [(SA602A)]
XLS93LC66	XLS93LC66@SOIC8 [(SA602A)]

### PLD

XLE78C800P-25	XLE78C800P-35
XLE78C800P-45	XLE78C800S-25
XLE78C800S-35	XLE78C800S-45
XLM78C800S-35	XLM78C800S-45
XLS78C800P-25	XLS78C800P-35
XLS78C800P-45	XLS78C800S-25
XLS78C800S-35	XLS78C800S-45

**FAIRCHILD****E (E) PROM/FRAM/NVRAM**

```

FM24C02(M8)@SOIC8 [(SA602A)]
FM24C02(N)
FM24C03(MT8)@TSSOP8 [(SA026)]
FM24C04(M8)@SOIC8 [(SA602A)]
FM24C04(N)
FM24C05(MT8)@TSSOP8 [(SA026)]
FM24C08(M8)@SOIC8 [(SA602A)]
FM24C08(N)
FM24C09(MT8)@TSSOP8 [(SA026)]
FM24C128(MT8)@TSSOP8 [(SA026)]
FM24C128(N)
FM24C16(MT8)@TSSOP8 [(SA026)]
FM24C17(M8)@SOIC8 [(SA602A)]
FM24C17(N)
FM24C256(N)
FM24C32(N)
FM27C010@PLCC32 [(SA015A1T)]
FM27C040
FM27C040@TSOP32 [(SA410T)]
FM27C256@PLCC32 [(SA015A1T)]
FM27C256Q@PLCC32 [(SA015A1T)]
FM27C512@PLCC32 [(SA015A1T)]
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]
FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C06(N)(08bit)
FM93C14(16bit)
FM93C46(MT8)@TSSOP8 [(SA026)]
FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C46A(N)(08bit)
FM93C56(M8)@SOIC8 [(SA602A)]
FM93C56(N)
FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C56A(N)(08bit)
FM93C66(M8)@SOIC8 [(SA602A)]
FM93C66(N)
FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C66A(N)(08bit)
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C76(N)(16bit)
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C76A(N)(08bit)
FM93C86(M8)(16bit)@SOIC8 [(SA602A)]
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C86(N)(16bit)
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C86A(N)(08bit)
FM93CS06(M8)@SOIC8 [(SA602A)]
FM93CS06(N)
FM93CS46(MT8)@TSSOP8 [(SA026)]
FM93CS56(M8)@SOIC8 [(SA602A)]
FM93CS56(N)
FM93CS66(MT8)@TSSOP8 [(SA026)]
FM93S46(M8)@SOIC8 [(SA602A)]
FM93S46(N)
FM93S56(MT8)@TSSOP8 [(SA026)]
FM93S66(M8)@SOIC8 [(SA602A)]
FM93S66(N)
FM24C02(MT8)@TSSOP8 [(SA026)]
FM24C03(M8)@SOIC8 [(SA602A)]
FM24C03(N)
FM24C04(MT8)@TSSOP8 [(SA026)]
FM24C05(M8)@SOIC8 [(SA602A)]
FM24C05(N)
FM24C08(MT8)@TSSOP8 [(SA026)]
FM24C09(M8)@SOIC8 [(SA602A)]
FM24C09(N)
FM24C128(MW8)@SOIC8 [(SA602A)]
FM24C16(M8)@SOIC8 [(SA602A)]
FM24C16(N)
FM24C17(MT8)@TSSOP8 [(SA026)]
FM24C256(M8)@SOIC8 [(SA602A)]
FM24C32(M8)@SOIC8 [(SA602A)]
FM27C010
FM27C010@TSOP32 [(SA410T)]
FM27C040@PLCC32 [(SA015A1T)]
FM27C256
FM27C256Q
FM27C512
FM93C06(N)(16bit)
FM93C46(M8)@SOIC8 [(SA602A)]
FM93C46(N)
FM93C46A(N)(16bit)
FM93C56(MT8)@TSSOP8 [(SA026)]
FM93C56A(N)(16bit)
FM93C66(MT8)@TSSOP8 [(SA026)]
FM93C66A(N)(16bit)
FM93C76A(N)(16bit)
FM93C86A(N)(16bit)
FM93CS06(MT8)@TSSOP8 [(SA026)]
FM93CS46(M8)@SOIC8 [(SA602A)]
FM93CS46(N)
FM93CS56(MT8)@TSSOP8 [(SA026)]
FM93CS66(M8)@SOIC8 [(SA602A)]
FM93CS66(N)
FM93S46(MT8)@TSSOP8 [(SA026)]
FM93S56(M8)@SOIC8 [(SA602A)]
FM93S56(N)
FM93S66(MT8)@TSSOP8 [(SA026)]
MM2716

```

MM2716E	NM24C02(M8)@SOIC8 [(SA602A)]
NM24C02(MT8)@TSSOP8 [(SA026)]	NM24C02(N)
NM24C02L(M8)@SOIC8 [(SA602A)]	NM24C02L(MT8)@TSSOP8 [(SA026)]
NM24C02L(N)	NM24C03(M8)@SOIC8 [(SA602A)]
NM24C03(MT8)@TSSOP8 [(SA026)]	NM24C03(N)
NM24C04(M8)@SOIC8 [(SA602A)]	NM24C04(MT8)@TSSOP8 [(SA026)]
NM24C04(N)	NM24C05(M8)@SOIC8 [(SA602A)]
NM24C05(MT8)@TSSOP8 [(SA026)]	NM24C05(N)
NM24C08(M8)@SOIC8 [(SA602A)]	NM24C08(MT8)@TSSOP8 [(SA026)]
NM24C08(N)	NM24C09(M8)@SOIC8 [(SA602A)]
NM24C09(MT8)@TSSOP8 [(SA026)]	NM24C09(N)
NM24C16(M8)@SOIC8 [(SA602A)]	NM24C16(MT8)@TSSOP8 [(SA026)]
NM24C16(N)	NM24C17(M8)@SOIC8 [(SA602A)]
NM24C17(MT8)@TSSOP8 [(SA026)]	NM24C17(N)
NM24C65(M8)@SOIC8 [(SA602A)]	NM24C65(N)
NM27C010	NM27C010@PLCC32 [(SA015A1T)]
NM27C010@TSOP32 [(SA410T)]	NM27C020
NM27C020@PLCC32 [(SA015A1T)]	NM27C020@TSOP32 [(SA410T)]
NM27C020Q	NM27C020Q@PLCC32 [(SA015A1T)]
NM27C020Q@TSOP32 [(SA410T)]	NM27C040
NM27C040@PLCC32 [(SA015A1T)]	NM27C040@TSOP32 [(SA410T)]
NM27C128	NM27C128@PLCC32 [(SA015A1T)]
NM27C210	NM27C210@PLCC44 [(SA244)]
NM27C240	NM27C240@PLCC44 [(SA244)]
NM27C256	NM27C256@PLCC32 [(SA015A1T)]
NM27C512	NM27C512@PLCC32 [(SA015A1T)]
NM27C64Q	NM27C64Q@PLCC32 [(SA015A1T)]
NM27LC256	NM27LC256@PLCC32 [(SA015A1T)]
NM27LC512	NM27LC512@PLCC32 [(SA015A1T)]
NM27LV010	NM27LV010@PLCC32 [(SA015A1T)]
NM27LV010@TSOP32 [(SA410T)]	NM27LV210
NM27LV210@PLCC44 [(SA244)]	NM27LV512
NM27LV512@PLCC32 [(SA015A1T)]	NM27P040
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32 [(SA410T)]
NM27P210	NM27P210@PLCC44 [(SA244)]
NM27P512	NM27P512@PLCC32 [(SA015A1T)]
NM93C66(M8)(16bit)@SOIC8 [(SA602A)]	NM93CS06(M8)@SOIC8 [(SA602A)]
NM93C66(MT8)(16bit)@TSSOP8 [(SA026)]	NM93CS06(N)
NM93C66(N)(16bit)	NM93CS46(MT8)@TSSOP8 [(SA026)]
NM93CS06(MT8)@TSSOP8 [(SA026)]	NM93CS46(M8)@SOIC8 [(SA602A)]
NM93CS46(M8)@SOIC8 [(SA602A)]	NM93CS46(N)
NM93CS46(N)	NM93CS56(MT8)@TSSOP8 [(SA026)]
NM93CS56(MT8)@TSSOP8 [(SA026)]	NM93CS56(N)
NM93CS56(M8)@SOIC8 [(SA602A)]	NM93CS66(MT8)@TSSOP8 [(SA026)]
NM93CS66(N)	NMC2732
NMC27C010	NMC27C010@PLCC32 [(SA015A1T)]
NMC27C010@TSOP32 [(SA410T)]	NMC27C1024
NMC27C1024@PLCC44 [(SA244)]	NMC27C128B
NMC27C128B@PLCC32 [(SA015A1T)]	NMC27C128BN
NMC27C128BN@PLCC32 [(SA015A1T)]	NMC27C128BQ
NMC27C128BQ@PLCC32 [(SA015A1T)]	NMC27C128CQ
NMC27C16	NMC27C16BQ
NMC27C16BQE	NMC27C16H
NMC27C16HQ	NMC27C16Q
NMC27C256	NMC27C256@PLCC32 [(SA015A1T)]
NMC27C256B	NMC27C256B@PLCC32 [(SA015A1T)]
NMC27C256Q	NMC27C256Q@PLCC32 [(SA015A1T)]
NMC27C32	NMC27C32B
NMC27C32BQ	NMC27C32E
NMC27C32EH	NMC27C32H
NMC27C512	NMC27C512@PLCC32 [(SA015A1T)]
NMC27C512A	NMC27C512A@PLCC32 [(SA015A1T)]
NMC27C512AN	NMC27C512AN@PLCC32 [(SA015A1T)]
NMC27C64	NMC27C64(BN)
NMC27C64(N)	NMC27CP128
NMC87C257Q	NMC87C257Q@PLCC32 [(SA015A1T)]
NMC87C257V	NMC87C257V@PLCC32 [(SA015A1T)]
NMC9346(M8)(16bit)@SOIC8 [(SA602A)]	
NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC9346(N)(16bit)	
NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C46(N)(16bit)	
NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C46A(N)(16bit)	
NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]	

NMC93C66(N)(16bit)	NMC93CS06(M8)@SOIC8 [(SA602A)]
NMC93CS06(MT8)@TSSOP8 [(SA026)]	NMC93CS06(N)
NMC93CS46(M8)@SOIC8 [(SA602A)]	NMC93CS46(MT8)@TSSOP8 [(SA026)]
NMC93CS46(N)	NMC93CS56(M8)@SOIC8 [(SA602A)]
NMC93CS56(MT8)@TSSOP8 [(SA026)]	NMC93CS56(N)
NMC93CS66(M8)@SOIC8 [(SA602A)]	NMC93CS66(MT8)@TSSOP8 [(SA026)]
NMC93CS66(N)	NMC9817

**DRAM & SRAM**

F1600	F1600@SOJ24 [(SA646)]
F1601	F1601@SOJ24 [(SA646)]
F1620	F1621

**MICROCONTROLLER**

ACE1001(M8)@SOIC8 [(SA602A)]	ACE1001(M8X)@SOIC8 [(SA602A)]
ACE1001(MT8)@TSSOP8 [(SA026)]	ACE1001(MT8X)@TSSOP8 [(SA026)]
ACE1001E(M8)@SOIC8 [(SA602A)]	ACE1001E(M8X)@SOIC8 [(SA602A)]
ACE1001E(MT8)@TSSOP8 [(SA026)]	ACE1001E(MT8X)@TSSOP8 [(SA026)]
ACE1001L(M8)@SOIC8 [(SA602A)]	ACE1001L(M8X)@SOIC8 [(SA602A)]
ACE1001L(MT8)@TSSOP8 [(SA026)]	ACE1001L(MT8X)@TSSOP8 [(SA026)]
ACE1101(EMT8)@TSSOP8 [(SA026)]	ACE1101(EMT8X)@TSSOP8 [(SA026)]
ACE1101(EN)	ACE1101(EN14)
ACE1101(LMT8)@TSSOP8 [(SA026)]	ACE1101(LMT8X)@TSSOP8 [(SA026)]
ACE1101(LN)	ACE1101(LN14)
ACE1101(MT8)@TSSOP8 [(SA026)]	ACE1101(MT8X)@TSSOP8 [(SA026)]
ACE1101(N)	ACE1101(N14)
ACE1101(VMT8)@TSSOP8 [(SA026)]	ACE1101(VMT8X)@TSSOP8 [(SA026)]
ACE1101(VN)	ACE1101(VN14)
ACE1101B(EMT8)@TSSOP8 [(SA026)]	ACE1101B(EMT8X)@TSSOP8 [(SA026)]
ACE1101B(EN)	ACE1101B(EN14)
ACE1101B(MT8)@TSSOP8 [(SA026)]	ACE1101B(MT8X)@TSSOP8 [(SA026)]
ACE1101B(N)	ACE1101B(N14)
ACE1101B(VMT8)@TSSOP8 [(SA026)]	ACE1101B(VMT8X)@TSSOP8 [(SA026)]
ACE1101B(VN)	ACE1101B(VN14)
ACE1202(dip14)	ACE1202(dip8)
ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8 [(SA602A)]
ACE12022(dip14)	ACE12022(dip8)
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8 [(SA602A)]
ACE12022B(dip14)	ACE12022B(dip8)
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8 [(SA602A)]
ACE12022BE(dip14)	ACE12022BE(dip8)
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8 [(SA602A)]
ACE12022BV(dip14)	ACE12022BV(dip8)
ACE12022BV(M14)@SOIC14 [(SA602)]	ACE12022BV(M8)@SOIC8 [(SA602A)]
ACE12022E(dip14)	ACE12022E(dip8)
ACE12022E(M14)@SOIC14 [(SA602)]	ACE12022E(M8)@SOIC8 [(SA602A)]
ACE1202B(dip14)	ACE1202B(dip8)
ACE1202B(M14)@SOIC14 [(SA602)]	ACE1202B(M8)@SOIC8 [(SA602A)]
ACE1202BE(dip14)	ACE1202BE(dip8)
ACE1202BE(M14)@SOIC14 [(SA602)]	ACE1202BE(M8)@SOIC8 [(SA602A)]
ACE1202BV(dip14)	ACE1202BV(dip8)
ACE1202BV(M14)@SOIC14 [(SA602)]	ACE1202BV(M8)@SOIC8 [(SA602A)]
ACE1202E(dip14)	ACE1202E(dip8)
ACE1202E(M14)@SOIC14 [(SA602)]	ACE1202E(M8)@SOIC8 [(SA602A)]
ACE1202L(dip14)	ACE1202L(dip8)
ACE1202L(M14)@SOIC14 [(SA602)]	ACE1202L(M8)@SOIC8 [(SA602A)]
ACE1202V(dip8)	ACE1202V(M14)@SOIC14 [(SA602)]
ACE1202V(M8)@SOIC8 [(SA602A)]	ACE1501(EM)@SOIC14 [(SA602)]
ACE1501(EM8)@SOIC8 [(SA602A)]	ACE1501(EM8X)@SOIC8 [(SA602A)]
ACE1501(EMT)@TSOP14 [(SA026)]	ACE1501(EMT8)@TSSOP8 [(SA026)]
ACE1501(EMT8X)@TSSOP8 [(SA026)]	ACE1501(EMTX)@TSOP14 [(SA026)]
ACE1501(EMX)@SOIC14 [(SA602)]	ACE1501(EN)
ACE1501(EN14)	ACE1501(VM)@SOIC14 [(SA602)]
ACE1501(VM8)@SOIC8 [(SA602A)]	ACE1501(VM8X)@SOIC8 [(SA602A)]
ACE1501(VMT)@TSOP14 [(SA026)]	ACE1501(VMT8)@TSSOP8 [(SA026)]
ACE1501(VMT8X)@TSSOP8 [(SA026)]	ACE1501(VMTX)@TSOP14 [(SA026)]
ACE1501(VMX)@SOIC14 [(SA602)]	ACE1501(VN)
ACE1501(VN14)	ACE1502(EM)@SOIC14 [(SA602)]
ACE1502(EM8)@SOIC8 [(SA602A)]	ACE1502(EMT)@TSOP14 [(SA026)]
ACE1502(EMT8)@TSSOP8 [(SA026)]	ACE1502(EN)
ACE1502(EN14)	ACE1502(VM)@SOIC14 [(SA602)]
ACE1502(VM8)@SOIC8 [(SA602A)]	ACE1502(VMT)@TSOP14 [(SA026)]
ACE1502(VMT8)@TSSOP8 [(SA026)]	ACE1502(VN)
ACE1502(VN14)	ACE8000(M8)@SOIC8 [(SA602A)]
ACE8000(M8X)@SOIC8 [(SA602A)]	ACE8000E(M8)@SOIC8 [(SA602A)]
ACE8000E(M8X)@SOIC8 [(SA602A)]	ACE8001(M8)@SOIC8 [(SA602A)]



ACE8001(M8X)@SOIC8 [(SA602A)]	ACE8001(MT8)@TSSOP8 [(SA026)]
ACE8001(MT8X)@TSSOP8 [(SA026)]	ACE8001E(M8)@SOIC8 [(SA602A)]
ACE8001E(M8X)@SOIC8 [(SA602A)]	ACE8001E(MT8)@TSSOP8 [(SA026)]
ACE8001E(MT8X)@TSSOP8 [(SA026)]	FMS7401L(EM8X)@SOIC8 [(SA602A)]
FMS7401L(EMT8X)@TSSOP8 [(SA026)]	FMS7401L(EMTX)@TSSOP14 [(SA026)]
FMS7401L(EMX)@SOIC14 [(SA602)]	FMS7401L(EN)
FMS7401L(EN14)	FMS7401L(VN)
FMS7401L(VN14)	

## FIDELIX

### E(E) PROM/FRAM/NVRAM

FM25Q16	FM25Q16@SOP8 [(SA023A)]
FM25Q16@WSON8 [(SA683)]	FM25Q16A
FM25Q16A@SOP8 [(SA023A)]	FM25Q16A@WSON8 [(SA683)]

## FORCE TECHNOLOGIES

### E(E) PROM/FRAM/NVRAM

FT24C01	FT24C01@SOIC8 [(SA602A)]
FT24C01@TSOP8 [(SA026)]	FT24C01A
FT24C01A@SOIC8 [(SA602A)]	FT24C01A@TSOP8 [(SA026)]
FT24C02	FT24C02@SOP8 [(SA602A)]
FT24C02@TSSOP8 [(SA026)]	FT24C02A
FT24C02A@SOP8 [(SA602A)]	FT24C02A@TSSOP8 [(SA026)]
FT24C04	FT24C04@SOP8 [(SA602A)]
FT24C04@TSSOP8 [(SA026)]	FT24C04A
FT24C04A@SOP8 [(SA602A)]	FT24C04A@TSSOP8 [(SA026)]
FT24C08	FT24C08@SOIC8 [(SA602A)]
FT24C08@TSOP8 [(SA026)]	FT24C08A
FT24C08A@SOIC8 [(SA602A)]	FT24C08A@TSOP8 [(SA026)]
FT24C128	FT24C128@SOIC8 [(SA602A)]
FT24C128@TSOP8 [(SA026)]	FT24C128A
FT24C128A@SOIC8 [(SA602A)]	FT24C128A@TSOP8 [(SA026)]
FT24C16	FT24C16@SOIC8 [(SA602A)]
FT24C16@TSOP8 [(SA026)]	FT24C16A
FT24C16A@SOIC8 [(SA602A)]	FT24C16A@TSOP8 [(SA026)]
FT24C256	FT24C256@SOIC8 [(SA602A)]
FT24C256@TSOP8 [(SA026)]	FT24C256A
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8 [(SA026)]
FT24C32	FT24C32@SOIC8 [(SA602A)]
FT24C32@TSOP8 [(SA026)]	FT24C32A
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8 [(SA026)]
FT24C64	FT24C64@SOIC8 [(SA602A)]
FT24C64@TSOP8 [(SA026)]	FT24C64A
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8 [(SA026)]
FT27C010	FT27C010@PLCC32 [(SA015A1T)]
FT27C010@TSOP32 [(SA410T)]	FT27C020
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32 [(SA410T)]
FT27C040	FT27C040@PLCC32 [(SA015A1T)]
FT27C040@TSOP32 [(SA410T)]	FT27C16
FT27C256	FT27C256@PLCC32 [(SA015A1T)]
FT27C64	FT27C64@PLCC32 [(SA015A1T)]
FT27HC256	FT27HC256@PLCC32 [(SA015A1T)]
FT27HC64	FT27HC64@PLCC32 [(SA015A1T)]
FT28C010	FT28C010@JLCC32 [(SA412A)]
FT28C010@PLCC32 [(SA015A1T)]	FT28C010@PLCC44 [(SA244)]
FT28C010@TSOP32 [(SA410T)]	FT28C010E
FT28C010E@JLCC32 [(SA412A)]	FT28C010E@PLCC32 [(SA015A1T)]
FT28C010E@PLCC44 [(SA244)]	FT28C010E@TSOP32 [(SA410T)]
FT28C020	FT28C020@JLCC32 [(SA412A)]
FT28C020@PLCC32 [(SA015A1T)]	FT28C020@PLCC44 [(SA244)]
FT28C020@TSOP32 [(SA410T)]	FT28C040
FT28C040@JLCC32 [(SA412A)]	FT28C040@PLCC32 [(SA015A1T)]
FT28C040@PLCC44 [(SA244)]	FT28C040@TSOP32 [(SA410T)]
FT28C16	FT28C16@PLCC32 [(SA015A1T)]
FT28C256	FT28C256@JLCC32 [(SA412A)]
FT28C256@PLCC32 [(SA015A1T)]	FT28C256@SOIC28 [(SA404)]
FT28C256@TSOP28 [(SA430T)]	FT28C256B
FT28C256B@JLCC32 [(SA412A)]	FT28C256B@PLCC32 [(SA015A1T)]
FT28C256B@SOIC28 [(SA404)]	FT28C256B@TSOP28 [(SA430T)]
FT28C64	FT28C64@PLCC32 [(SA015A1T)]

FT28C64@SOIC28 [(SA404)]	FT28C64@TSOP28 [(SA430T)]
FT28C64B	FT28C64B@JLCC32 [(SA412A)]
FT28C64B@PLCC32 [(SA015A1T)]	FT28C64B@SOIC28 [(SA404)]
FT28C64B@TSOP28 [(SA430T)]	FT28C64X
FT28C64X@PLCC32 [(SA015A1T)]	FT28C64X@SOIC28 [(SA404)]
FT28C64X@TSOP28 [(SA430T)]	FT28HC64
FT28HC64@PLCC32 [(SA015A1T)]	FT28HC64@TSOP28 [(SA430T)]
FT58C1001	FT58C1001@SSOP32 [(SA438T)]
FT58C1001@VSOP32 [(SA620)]	

## FORWARD

### E(E) PROM/FRAM/NVRAM

24LC01	24LC01@SOIC8 [(SA602A)]
24LC02	24LC02@SOIC8 [(SA602A)]
24LC04	24LC04@SOIC8 [(SA602A)]
24LC08	24LC08@SOIC8 [(SA602A)]
24LC16	24LC16@SOIC8 [(SA602A)]
24LC32	24LC32@SOIC8 [(SA602A)]
24LC64	24LC64@SOIC8 [(SA602A)]

## FREESCALE

### MICROCONTROLLER

68HC711E9MFN2@PLCC52 [(SA647-B5202)]	
68HC711E9MFNE2@PLCC52 [(SA647-B5202)]	
68HC711E9VFN2@PLCC52 [(SA647-B5202)]	
68HC711E9VFNE2@PLCC52 [(SA647-B5202)]	
DSP56F801(FA60)@TQFP48 [(SA248)]	
DSP56F801(FA60E)@TQFP48 [(SA248)]	
DSP56F801(FA80)@TQFP48 [(SA248)]	
DSP56F801(FA80E)@TQFP48 [(SA248)]	
DSP56F802(TA60)@TQFP32 [(SA663)]	
DSP56F802(TA60E)@TQFP32 [(SA663)]	
DSP56F802(TA80)@TQFP32 [(SA663)]	
DSP56F802(TA80E)@TQFP32 [(SA663)]	
DSP56F803(BU80)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F803(BU80E)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F805(FV80)@TQFP144(JTAG) [ISP-HEADER01]	
DSP56F805(FV80E)@TQFP144(JTAG) [ISP-HEADER01]	
DSP56F807(PY80)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F807(PY80E)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F807(VF80)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F807(VF80E)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F826(BU80)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F826(BU80E)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F827(FG80)@TQFP128(JTAG) [ISP-HEADER01]	
DSP56F827(FG80E)@TQFP128(JTAG) [ISP-HEADER01]	
MC56F8011VF80@QFP32 [(SA663+B005)]	
MC56F8013VF80@QFP32 [(SA663+B005)]	
MC56F8014VF80@QFP32 [(SA663+B005)]	
MC56F8023MFAE@QFP32 [(SA663+B005)]	
MC56F8023VF80@QFP32 [(SA663+B005)]	
MC56F8025VLD@QFP44 [(SA245A+B005)]	
MC56F8036MFAE@QFP48 [(SA248+B005)]	
MC56F8036VF80@QFP48 [(SA248+B005)]	
MC56F8037VLH@QFP64 [(PEP+S616)]	
MC56F8122VFA@TQFP48 [(SA248+B005)]	
MC56F8122VF80@TQFP48 [(SA248+B005)]	
MC56F8123VFB@TQFP64 [(PEP+S616)]	
MC56F8123VFBE@TQFP64 [(PEP+S616)]	
MC56F8322MFA60@TQFP48 [(SA248+B005)]	
MC56F8322MFAE@TQFP48 [(SA248+B005)]	
MC56F8322VFA60@TQFP48 [(SA248+B005)]	
MC56F8322VF80@TQFP48 [(SA248+B005)]	
MC56F8323MFB60@TQFP64 [(PEP+S616)]	
MC56F8323MFBE@TQFP64 [(PEP+S616)]	
MC56F8323VFB60@TQFP64 [(PEP+S616)]	
MC56F8323VFBE@TQFP64 [(PEP+S616)]	
MC68705R3	MC68705R5
MC68705U3	MC68705U5
MC68HC11A0	MC68HC11A0@PLCC52 [(PEP+S415T)]

MC68HC11A1 MC68HC11A1@PLCC52 [(PEP+S415T)]  
 MC68HC11A8 MC68HC11A8@PLCC52 [(PEP+S415T)]  
 MC68HC11E1@PLCC52 [(PEP+S415T)]  
 MC68HC11E1@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E1@QFP52 [(PEP+S673)] MC68HC11E20@PLCC52 [(PEP+S415T)]  
 MC68HC11E20@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E20@QFP52 [(PEP+S673)] MC68HC11E9@PLCC52 [(PEP+S415T)]  
 MC68HC11E9@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E9@QFP52 [(PEP+S673)] MC68HC11F1@PLCC68 [(PEP+S414T)]  
 MC68HC11K1@PLCC84 [(PEP+S416T)]  
 MC68HC11K1@TQFP80(\*) [(TA031-B006)]  
 MC68HC11P1@PLCC84(\*) [(SA649-B8405)]  
 MC68HC705B16@PLCC52 [(PEP+S415T)]  
 MC68HC705B16@TQFP64 [(PEP+S625A)]  
 MC68HC705B16@TQFP64(\*) [(SA668+B204)]  
 MC68HC705B16N@PLCC52 [(PEP+S415T)]  
 MC68HC705B16N@TQFP64 [(PEP+S625A)]  
 MC68HC705B16N@TQFP64(\*) [(SA668+B204)]  
 MC68HC705B5@PLCC52 [(PEP+S415T)] MC68HC705C4  
 MC68HC705C4@PLCC44 [(SA244)] MC68HC705C4A  
 MC68HC705C4A@PLCC44 [(SA244)] MC68HC705C8  
 MC68HC705C8@PLCC44 [(SA244)] MC68HC705C8@SDIP42 [SA028]  
 MC68HC705C8@TQFP44 [(SA245A)] MC68HC705C8A  
 MC68HC705C8A@PLCC44 [(SA244)] MC68HC705C8A@SDIP42 [SA028]  
 MC68HC705C8A@TQFP44 [(SA245A)] MC68HC705C9A  
 MC68HC705C9A@PLCC44 [(SA244)] MC68HC705C9A@TQFP44 [(SA245A)]  
 MC68HC705J1A(CDW)@SOIC20 [(SA404)]  
 MC68HC705J1A(CSD)@SSOP20 [(SA626A)]  
 MC68HC705J1A(P) MC68HC705J2(Emulation)  
 MC68HC705J2(Emulation)@SOIC20 [(SA404)]  
 MC68HC705J2(Emulation)@SSOP20 [(SA626A)]  
 MC68HC705J2(Native)  
 MC68HC705J2(Native)@SOIC20 [(SA404)]  
 MC68HC705J2(Native)@SSOP20 [(SA626A)]  
 MC68HC705KJ1 MC68HC705KJ1@SOIC16 [(SA404)]  
 MC68HC705P6(CDW)@SOIC28 [(SA404)]  
 MC68HC705P6(CP)  
 MC68HC705P6A(CDW)@SOIC28 [(SA404)]  
 MC68HC705P6A(CP) MC68HC705P9  
 MC68HC705P9@SOIC28 [(SA404)] MC68HC705SR3  
 MC68HC705SR3@SDIP42 [(SA028)] MC68HC705SR3@TQFP44 [(SA245A)]  
 MC68HC711D3 MC68HC711D3@PLCC44 [(SA244)]  
 MC68HC711D3@TQFP44 [(SA675)]  
 MC68HC711E20@PLCC52 [(PEP+S415T)]  
 MC68HC711E20@TQFP64 [(PEP+S625A)]  
 MC68HC711E9(4.5V)@PLCC52 [(SA647-B5202)]  
 MC68HC711E9@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711E9CFN(4.5V)@PLCC52 [(SA647-B5202)]  
 MC68HC711E9CFN2@PLCC52 [(SA647-B5202)]  
 MC68HC711E9CFN3@PLCC52 [(SA647-B5202)]  
 MC68HC711E9CFNE2@PLCC52 [(SA647-B5202)]  
 MC68HC711E9CFNE3@PLCC52 [(SA647-B5202)]  
 MC68HC711E9-FN@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711K4@PLCC84 [(PEP+S416T)]  
 MC68HC711K4@TQFP80(\*) [(TA031-B006)]  
 MC68HC711KA2@PLCC68 [(PEP+S414T)]  
 MC68HC711KA4@PLCC68 [(PEP+S414T)]  
 MC68HC711KS2@PLCC68 [(PEP+S414T)]  
 MC68HC711L6@TQFP64 [(SA668+B188)]  
 MC68HC711P2@PLCC84(\*) [(SA649-B8405)]  
 MC68HC811E2@PLCC52 [(PEP+S415T)] MC68HC811E2CP2  
 MC68HC811E2MP2 MC68HC811E2P2  
 MC68HC811E2VP2  
 MC68HC812A4CPV@TQFP112(\*) [(SA719+B210)]  
 MC68HC812A4CPVE@TQFP112(\*) [(SA719+B210)]  
 MC68HC812A4MPV@TQFP112(\*) [(SA719+B210)]  
 MC68HC812A4MPVE@TQFP112(\*) [(SA719+B210)]  
 MC68HC908AB32CFU@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AB32MFU@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
 MC68HC908AP16CB@SDIP42 [(SA028)]  
 MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
 MC68HC908AP16CFA@LQFP48 [(SA248)]  
 MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP16CFB@TQFP44 [(SA675)]  
 MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
 MC68HC908AP32CB@SDIP42 [(SA028)]  
 MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
 MC68HC908AP32CFA@LQFP48 [(SA248)]  
 MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP32CFB@TQFP44 [(SA675)]

MC68HC908AP64CB@SDIP42 [(SA028)]  
 MC68HC908AP64CFA@LQFP48 [(SA248)]  
 MC68HC908AP64CFB@TQFP44 [(SA675)]  
 MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
 MC68HC908AP8CB@SDIP42 [(SA028)]  
 MC68HC908AP8CFA(S)@LQFP48 [(SA248)]  
 MC68HC908AP8CFA@LQFP48 [(SA248)]  
 MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP8CFB@TQFP44 [(SA675)]  
 MC68HC908AS32A(CFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS32A(MFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS32A(VFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(CFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AS60(MFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AS60(VFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AS60A(CFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60A(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AS60A(MFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60A(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AS60A(VFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60A(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ32A(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ32A(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ32A(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60A(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60A(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60A(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908BD48IB@SDIP42 [(SA028)]  
 MC68HC908BD48IFB@TQFP44 [(SA675)]  
 MC68HC908EY16CFA@TQFP32 [(SA663)]  
 MC68HC908EY16MFA@TQFP32 [(SA663)]  
 MC68HC908EY16VFA@TQFP32 [(SA663)]  
 MC68HC908EY8CFA@TQFP32 [(SA663)]  
 MC68HC908EY8VFA@TQFP32 [(SA663)]  
 MC68HC908GP32@SDIP42 [(SA028)]  
 MC68HC908GR16CFA@TQFP48 [(SA248)]  
 MC68HC908GR16CFJ@TQFP32 [(SA663)]  
 MC68HC908GR16MFA@TQFP48 [(SA248)]  
 MC68HC908GR16MFJ@TQFP32 [(SA663)]  
 MC68HC908GR16VFA@TQFP48 [(SA248)]  
 MC68HC908GR16VFJ@TQFP32 [(SA663)]  
 MC68HC908GR4CDW@SOIC28 [(SA404)]  
 MC68HC908GR4CP  
 MC68HC908GR4MFA@TQFP32 [(SA663)]  
 MC68HC908GR4VDW@SOIC28 [(SA404)]  
 MC68HC908GR4VP  
 MC68HC908GR8CFA@TQFP32 [(SA663)]  
 MC68HC908GR8MDW@SOIC28 [(SA404)]  
 MC68HC908GR8MP  
 MC68HC908GR8VFA@TQFP32 [(SA663)]  
 MC68HC908GT16@SDIP42 [(SA028)]  
 MC68HC908GT8CB@SDIP42 [(SA028)]  
 MC68HC908GZ16(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ16(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ16(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ16(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ16(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ16(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(VFA)@TQFP48 [(SA248)]

MC68HC908EY8MFA@TQFP32 [(SA663)]  
 MC68HC908GP32  
 MC68HC908GP32@TQFP44 [(SA675)]  
 MC68HC908GR4CFA@TQFP32 [(SA663)]  
 MC68HC908GR4MDW@SOIC28 [(SA404)]  
 MC68HC908GR4MP  
 MC68HC908GR4VFA@TQFP32 [(SA663)]  
 MC68HC908GR8CDW@SOIC28 [(SA404)]  
 MC68HC908GR8CP  
 MC68HC908GR8MFA@TQFP32 [(SA663)]  
 MC68HC908GR8VDW@SOIC28 [(SA404)]  
 MC68HC908GR8VP  
 MC68HC908GT16@TQFP44 [(SA675)]  
 MC68HC908GT8CFB@TQFP44 [(SA675)]

MC68HC908GZ60(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(VFJ)@TQFP32 [(SA663)]  
 MC68HC908JB12(DW)@SOIC28 [(SA404)]  
 MC68HC908JB12(JDW)@SOIC20 [(SA404)]  
 MC68HC908JB16(DW)@SOIC28 [(SA404)]  
 MC68HC908JB16(FA)@QFP32 [(SA663)]  
 MC68HC908JB16(JDW)@SOIC20 [(SA404)]  
 MC68HC908JB8 MC68HC908JB8@SOIC20 [(SA404)]  
 MC68HC908JB8@SOIC28 [(SA404)] MC68HC908JB8@TQFP44 [(SA675)]  
 MC68HC908JK1CDW@SOIC20 [(SA404)] MC68HC908JK1CP  
 MC68HC908JK1ECDW@SOIC20 [(SA404)]  
 MC68HC908JK1ECP  
 MC68HC908JK1EMDW@SOIC20 [(SA404)]  
 MC68HC908JK1EMP MC68HC908JK1MDW@SOIC20 [(SA404)]  
 MC68HC908JK1MP MC68HC908JK3CDW@SOIC20 [(SA404)]  
 MC68HC908JK3CP  
 MC68HC908JK3ECDW@SOIC20 [(SA404)]  
 MC68HC908JK3ECP  
 MC68HC908JK3EMDW@SOIC20 [(SA404)]  
 MC68HC908JK3EMP MC68HC908JK3MDW@SOIC20 [(SA404)]  
 MC68HC908JK3MP MC68HC908JK8  
 MC68HC908JK8@SOIC20 [(SA404)] MC68HC908JL3CDW@SOIC28 [(SA404)]  
 MC68HC908JL3CFA@TQFP48 [(SA248)] MC68HC908JL3CP  
 MC68HC908JL3ECDW@SOIC28 [(SA404)]  
 MC68HC908JL3ECFA@TQFP48 [(SA248)]  
 MC68HC908JL3ECP  
 MC68HC908JL3EMDW@SOIC28 [(SA404)]  
 MC68HC908JL3EMFA@TQFP48 [(SA248)]  
 MC68HC908JL3EMP MC68HC908JL3MDW@SOIC28 [(SA404)]  
 MC68HC908JL3MFA@TQFP48 [(SA248)] MC68HC908JL3MP  
 MC68HC908JL8(dip20) MC68HC908JL8(dip28)  
 MC68HC908JL8@LQFP32 [(SA663)] MC68HC908JL8@SDIP32 [(SA653)]  
 MC68HC908JL8@SOIC20 [(SA404)] MC68HC908JL8@SOIC28 [(SA404)]  
 MC68HC908KX2(CDW)@SOIC16 [(SA404)]  
 MC68HC908KX2(CP)  
 MC68HC908KX2(MDW)@SOIC16 [(SA404)]  
 MC68HC908KX2(MP)  
 MC68HC908KX2(VDW)@SOIC16 [(SA404)]  
 MC68HC908KX2(VP)  
 MC68HC908KX8(CDW)@SOIC16 [(SA404)]  
 MC68HC908KX8(CP)  
 MC68HC908KX8(MDW)@SOIC16 [(SA404)]  
 MC68HC908KX8(MP)  
 MC68HC908KX8(VDW)@SOIC16 [(SA404)]  
 MC68HC908KX8(VP) MC68HC908LB8CDWE(S)@SOIC20  
 MC68HC908LB8CDWE@SOIC20 [(SA404)] MC68HC908LB8CPE(S)  
 MC68HC908LB8CPE  
 MC68HC908LB8MDWE(S)@SOIC20  
 MC68HC908LB8MDWE@SOIC20 [(SA404)]  
 MC68HC908LB8MPE MC68HC908LB8MPE(S)  
 MC68HC908LB8VDWE(S)@SOIC20  
 MC68HC908LB8VDWE@SOIC20 [(SA404)]  
 MC68HC908LB8VPE MC68HC908LB8VPE(S)  
 MC68HC908LD60IFU@QFP64 [(PEP+S625)]  
 MC68HC908LD64IFU@QFP64 [(PEP+S625)]  
 MC68HC908LJ12CFB@TQFP52 [(PEP-S673)]  
 MC68HC908LJ12CFBE@TQFP52 [(PEP-S673)]  
 MC68HC908LJ12CFU@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ12CFU@TQFP64(\*) [(SA757-B331)]  
 MC68HC908LJ12CFUE@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ12CFUE@TQFP64(\*) [(SA757-B331)]  
 MC68HC908LJ12CPB@TQFP64 [(PEP-S616)]  
 MC68HC908LJ12CPBE@TQFP64 [(PEP-S616)]  
 MC68HC908LJ24CFQ@TQFP80 [(PEP-S615B)]  
 MC68HC908LJ24CFQE@TQFP80 [(PEP-S615B)]  
 MC68HC908LJ24CFU@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ24CFU@TQFP64(\*) [(SA757-B331)]  
 MC68HC908LJ24CFUE@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ24CFUE@TQFP64(\*) [(SA757-B331)]  
 MC68HC908LJ24CPB@TQFP64 [(PEP-S616)]  
 MC68HC908LJ24CPBE@TQFP64 [(PEP-S616)]  
 MC68HC908LJ24CPK@TQFP80 [(PEP-S640B)]  
 MC68HC908LJ24CPKE@TQFP80 [(PEP-S640B)]  
 MC68HC908LK24CFQ@TQFP80 [(PEP-S615B)]  
 MC68HC908LK24CFQE@TQFP80 [(PEP-S615B)]  
 MC68HC908LK24CFU@TQFP64 [(PEP-S625A)]

MC68HC908LK24CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LK24CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CPB@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPK@TQFP80 [(PEP-S640B)]  
MC68HC908LK24CPKE@TQFP80 [(PEP-S640B)]  
MC68HC908LV8CPBE@TQFP52 [(PEP+S673)]  
MC68HC908MR16(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(CB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR16(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR16(CFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908MR16(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(VB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR16(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR16(VFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(CB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(CFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(VB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(VFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908QB4(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(CDW)@SOIC16 [(SA404)]  
MC68HC908QB4(CP)  
MC68HC908QB4(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(MDW)@SOIC16 [(SA404)]  
MC68HC908QB4(MP)  
MC68HC908QB4(VDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(VDW)@SOIC16 [(SA404)]  
MC68HC908QB4(VP)  
MC68HC908QB8(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(CDW)@SOIC16 [(SA404)]  
MC68HC908QB8(CP)  
MC68HC908QB8(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(MDW)@SOIC16 [(SA404)]  
MC68HC908QB8(MP)  
MC68HC908QB8(VDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(VDW)@SOIC16 [(SA404)]  
MC68HC908QB8(VP)  
MC68HC908QC16(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDX)@SOIC16 [(SA404)]  
MC68HC908QC16(CDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(CDY)@SOIC20 [(SA404)]  
MC68HC908QC16(CDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(CDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(CDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(MDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDX)@SOIC16 [(SA404)]  
MC68HC908QC16(MDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(MDY)@SOIC20 [(SA404)]  
MC68HC908QC16(MDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(MDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(MDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(VDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDX)@SOIC16 [(SA404)]  
MC68HC908QC16(VDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(VDY)@SOIC20 [(SA404)]  
MC68HC908QC16(VDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(VDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(VDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDS)@TSSOP20 [(SA643)]

MC68HC908QC4 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC4 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC4 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC4 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC4 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC4 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC4 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QF4 (CFJ)@TQFP32 [(SA663)]  
MC68HC908QF4 (FJ)@TQFP32 [(SA663)]  
MC68HC908QL2 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (MDW)@SOIC16 [(SA404)]

MC68HC908QL3 (VDT)@TSSOP16 [(SA643)]  
 MC68HC908QL3 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QL4 (CDT)@TSSOP16 [(SA643)]  
 MC68HC908QL4 (CDW)@SOIC16 [(SA404)]  
 MC68HC908QL4 (MDT)@TSSOP16 [(SA643)]  
 MC68HC908QL4 (MDW)@SOIC16 [(SA404)]  
 MC68HC908QL4 (VDT)@TSSOP16 [(SA643)]  
 MC68HC908QL4 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QT1ACFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT1AMFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT1AVFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT1CDW@SOIC8 [(SA605A)]  
 MC68HC908QT1CFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT1CP MC68HC908QT1MDW@SOIC8 [(SA605A)]  
 MC68HC908QT1MFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT1MP MC68HC908QT1VDW@SOIC8 [(SA605A)]  
 MC68HC908QT1VFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT1VP  
 MC68HC908QT2ACFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT2AMFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT2AVFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT2CDW@SOIC8 [(SA605A)]  
 MC68HC908QT2CFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT2CP MC68HC908QT2MDW@SOIC8 [(SA605A)]  
 MC68HC908QT2MFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT2MP MC68HC908QT2VDW@SOIC8 [(SA605A)]  
 MC68HC908QT2VFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT2VP  
 MC68HC908QT4ACFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT4AMFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT4AVFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT4CDW@SOIC8 [(SA605A)]  
 MC68HC908QT4CFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT4CP MC68HC908QT4MDW@SOIC8 [(SA605A)]  
 MC68HC908QT4MFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT4MP MC68HC908QT4VDW@SOIC8 [(SA605A)]  
 MC68HC908QT4VFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT4VP  
 MC68HC908QY1CDT@TSSOP16 [(SA026)]  
 MC68HC908QY1CDW@SOIC16 [(SA404)] MC68HC908QY1CP  
 MC68HC908QY1MDT@TSSOP16 [(SA026)]  
 MC68HC908QY1MDW@SOIC16 [(SA404)] MC68HC908QY1MP  
 MC68HC908QY1VDT@TSSOP16 [(SA026)]  
 MC68HC908QY1VDW@SOIC16 [(SA404)] MC68HC908QY1VP  
 MC68HC908QY2CDT@TSSOP16 [(SA026)]  
 MC68HC908QY2CDW@SOIC16 [(SA404)] MC68HC908QY2CP  
 MC68HC908QY2MDT@TSSOP16 [(SA026)]  
 MC68HC908QY2MDW@SOIC16 [(SA404)] MC68HC908QY2MP  
 MC68HC908QY2VDT@TSSOP16 [(SA026)]  
 MC68HC908QY2VDW@SOIC16 [(SA404)] MC68HC908QY2VP  
 MC68HC908QY4CDT@TSSOP16 [(SA026)]  
 MC68HC908QY4CDW@SOIC16 [(SA404)] MC68HC908QY4CP  
 MC68HC908QY4MDT@TSSOP16 [(SA026)]  
 MC68HC908QY4MDW@SOIC16 [(SA404)] MC68HC908QY4MP  
 MC68HC908QY4VDT@TSSOP16 [(SA026)]  
 MC68HC908QY4VDW@SOIC16 [(SA404)] MC68HC908QY4VP  
 MC68HC908QY8 (CDT)@TSSOP16 [(SA026)]  
 MC68HC908QY8 (CDW)@SOIC16 [(SA404)]  
 MC68HC908QY8 (CP)  
 MC68HC908QY8 (MDT)@TSSOP16 [(SA026)]  
 MC68HC908QY8 (MDW)@SOIC16 [(SA404)]  
 MC68HC908QY8 (MP)  
 MC68HC908QY8 (VDT)@TSSOP16 [(SA026)]  
 MC68HC908QY8 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QY8 (VP)  
 MC68HC908RF2 (CFA)@TQFP32 [(SA663)]  
 MC68HC908RF2 (MFA)@TQFP32 [(SA663)]  
 MC68HC908SR12 (CB)@SDIP42 [(SA028)]  
 MC68HC908SR12 (CFA)@TQFP48 [(SA248)]  
 MC68HC908SR12 (MB)@SDIP42 [(SA028)]  
 MC68HC908SR12 (MFA)@TQFP48 [(SA248)]  
 MC68HC912B32 (CFU8)@TQFP80 [(TA045-B006)]  
 MC68HC912B32 (MFU8)@TQFP80 [(TA045-B006)]  
 MC68HC912B32 (VFU8)@TQFP80 [(TA045-B006)]  
 MC68HC912BC32 (CFU8)@TQFP80 [(TA045-B006)]  
 MC68HC912BC32 (MFU8)@TQFP80 [(TA045-B006)]  
 MC68HC912BC32 (VFU8)@TQFP80 [(TA045-B006)]  
 MC68HCP11E1@PLCC52 [(PEP+S415T)]  
 MC68HCP11E1@PLCC52 (\*) [(SA647-B5202)]  
 MC68HCP11E1@QFP52 [(PEP+S673)]  
 MC68HRC908JK1CDW@SOIC20 [(SA404)]



MC68HRC908JK1CP	
MC68HRC908JK1ECDW@SOIC20 [(SA404)]	
MC68HRC908JK1ECP	
MC68HRC908JK1EMDW@SOIC20 [(SA404)]	
MC68HRC908JK1EMP	
MC68HRC908JK1MDW@SOIC20 [(SA404)]	
MC68HRC908JK1MP	
MC68HRC908JK3CDW@SOIC20 [(SA404)]	
MC68HRC908JK3CP	
MC68HRC908JK3ECDW@SOIC20 [(SA404)]	
MC68HRC908JK3ECP	
MC68HRC908JK3EMDW@SOIC20 [(SA404)]	
MC68HRC908JK3EMP	
MC68HRC908JK3MDW@SOIC20 [(SA404)]	
MC68HRC908JK3MP	MC68HRC908JK8
MC68HRC908JK8@SOIC20 [(SA404)]	
MC68HRC908JL3CDW@SOIC28 [(SA404)]	
MC68HRC908JL3CFA@TQFP48 [(SA248)]	
MC68HRC908JL3CP	
MC68HRC908JL3ECDW@SOIC28 [(SA404)]	
MC68HRC908JL3ECFA@TQFP48 [(SA248)]	
MC68HRC908JL3ECP	
MC68HRC908JL3EMDW@SOIC28 [(SA404)]	
MC68HRC908JL3EMFA@TQFP48 [(SA248)]	
MC68HRC908JL3EMP	
MC68HRC908JL3MDW@SOIC28 [(SA404)]	
MC68HRC908JL3MFA@TQFP48 [(SA248)]	
MC68HRC908JL3MP	MC68HRC908JL8(dip20)
MC68HRC908JL8(dip28)	MC68HRC908JL8@LQFP32 [(SA663)]
MC68HRC908JL8@SDIP32 [(SA653)]	MC68HRC908JL8@SOIC20 [(SA404)]
MC68HRC908JL8@SOIC28 [(SA404)]	MC68HSC705C8A
MC68HSC705C8A@PLCC44 [(SA244)]	MC68HSC705C8A@SDIP42 [SA028]
MC68HSC705C8A@TQFP44 [(SA245A)]	
MC68S711E9@PLCC52(*) [(SA647-B5202)]	
MC68S711E9-FN@PLCC52(*) [(SA647-B5202)]	
MC908AB32CFUE@TQFP64(*) [(TA011-B006)]	
MC908AB32MFUE@TQFP64(*) [(TA011-B006)]	
MC908AP16CBE@SDIP42 [(SA028)]	MC908AP16CFAE@LQFP48 [(SA248)]
MC908AP16CFBE@TQFP44 [(SA675)]	MC908AP32CBE@SDIP42 [(SA028)]
MC908AP32CFAE@LQFP48 [(SA248)]	MC908AP32CFBE@TQFP44 [(SA675)]
MC908AP64CBE@SDIP42 [(SA028)]	MC908AP64CFAE@LQFP48 [(SA248)]
MC908AP64CFBE@TQFP44 [(SA675)]	MC908AP8CBE@SDIP42 [(SA028)]
MC908AP8CFAE@LQFP48 [(SA248)]	MC908AP8CFBE@TQFP44 [(SA675)]
MC908BD48IBE@SDIP42 [(SA028)]	MC908BD48IFBE@TQFP44 [(SA675)]
MC908EY16ACFJE@TQFP32 [(SA663)]	MC908EY16AKFJE@TQFP32 [(SA663)]
MC908EY16AMFJE@TQFP32 [(SA663)]	MC908EY16AVFJE@TQFP32 [(SA663)]
MC908EY8ACFJE@TQFP32 [(SA663)]	MC908EY8AKFJE@TQFP32 [(SA663)]
MC908EY8AMFJE@TQFP32 [(SA663)]	MC908EY8AVFJE@TQFP32 [(SA663)]
MC908JL16CDWE@SOIC28 [(SA404)]	MC908JL16CFJE@LQFP32 [(SA663)]
MC908JL16CPE	MC908JL16CSPE@SDIP32 [(SA653)]
MC908QT1ACDWE@SOIC8 [(SA605A)]	MC908QT1ACPE
MC908QT1AMDWE@SOIC8 [(SA605A)]	MC908QT1AMPE
MC908QT1AVDWE@SOIC8 [(SA605A)]	MC908QT1AVPE
MC908QT2ACDWE@SOIC8 [(SA605A)]	MC908QT2ACPE
MC908QT2AMDWE@SOIC8 [(SA605A)]	MC908QT2AMPE
MC908QT2AVDWE@SOIC8 [(SA605A)]	MC908QT2AVPE
MC908QT4ACDWE@SOIC8 [(SA605A)]	MC908QT4ACPE
MC908QT4AMDWE@SOIC8 [(SA605A)]	MC908QT4AMPE
MC908QT4AVDWE@SOIC8 [(SA605A)]	MC908QT4AVPE
MC908QY1ACDTE@TSSOP16 [(SA026)]	MC908QY1ACDWE@SOIC16 [(SA404)]
MC908QY1ACPE	MC908QY1AMDTE@TSSOP16 [(SA026)]
MC908QY1AMDWE@SOIC16 [(SA404)]	MC908QY1AMPE
MC908QY1AVDTE@TSSOP16 [(SA026)]	MC908QY1AVDWE@SOIC16 [(SA404)]
MC908QY1AVPE	MC908QY2ACDTE@TSSOP16 [(SA026)]
MC908QY2ACDWE@SOIC16 [(SA404)]	MC908QY2ACPE
MC908QY2AMDTE@TSSOP16 [(SA026)]	MC908QY2AMDWE@SOIC16 [(SA404)]
MC908QY2AMPE	MC908QY2AVDTE@TSSOP16 [(SA026)]
MC908QY2AVDWE@SOIC16 [(SA404)]	MC908QY2AVPE
MC908QY4ACDTE@TSSOP16 [(SA026)]	MC908QY4ACDWE@SOIC16 [(SA404)]
MC908QY4ACPE	MC908QY4AMDTE@TSSOP16 [(SA026)]
MC908QY4AMDWE@SOIC16 [(SA404)]	MC908QY4AMPE
MC908QY4AVDTE@TSSOP16 [(SA026)]	MC908QY4AVDWE@SOIC16 [(SA404)]
MC908QY4AVPE	
MC912D60ACFU8@TQFP80(*) [(TA034-B006)]	
MC912D60ACPV8@TQFP112(*) [(TA035+B084)]	
MC912D60AMFU8@TQFP80(*) [(TA034-B006)]	
MC912D60AMPV8@TQFP112(*) [(TA035+B084)]	
MC912D60AVFU8@TQFP80(*) [(TA034-B006)]	
MC912D60AVPV8@TQFP112(*) [(TA035+B084)]	
MC912D60CCFU8@TQFP80(*) [(TA034-B006)]	
MC912D60CCPV8@TQFP112(*) [(TA035+B084)]	

MC912D60CMFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60CMPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60CVFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60CVPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60PCFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60PCPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60PMFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60PMPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60PVFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60PVPV8@TQFP112(\*) [(TA035+B084)]  
 MC912DG128ACPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128AMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128AVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128CCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128CMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128CVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128PCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128PMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128PVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128ACPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128AMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128AVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128CCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128CMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128CVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128PCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128PMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128PVPV@TQFP112(\*) [(TA035+B084)]  
 MC9RS08KA1CPC [(SA726+B179)]  
 MC9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
 MC9RS08KA2CPC [(SA726+B179)]  
 MC9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
 MC9RS08KA4CPG MC9RS08KA4CPJ  
 MC9RS08KA4CTG@TSSOP16 [(SA026+B349)]  
 MC9RS08KA4CWG@SOIC16 [(SA404+B349)]  
 MC9RS08KA4CWJ@SOIC20 [(SA404+B348)]  
 MC9RS08KA8CPG MC9RS08KA8CPJ  
 MC9RS08KA8CTG@TSSOP16 [(SA026+B349)]  
 MC9RS08KA8CWG@SOIC16 [(SA404+B349)]  
 MC9RS08KA8CWJ@SOIC20 [(SA404+B348)]  
 MC9S08AC16CFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16CFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16CFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16CFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16MFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16MFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16MFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16MFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16VFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16VFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16VFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16VFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32CFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32CFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32CFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32CFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32CFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32CFUE@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32CPU@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32CPUE@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32MFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32MFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32MFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32MFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32MFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32MFUE@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32MPU@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32MPUE@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32VFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32VFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32VFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32VFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32VFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32VFUE@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32VPU@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32VPUE@QFP64(\*) [(SA732-B196)]  
 MC9S08AC48CFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC48CFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC48CFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC48CFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC48CFU@LQFP64(\*) [(SA757-B196)]

MC9S08AC48CFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AC48CPU@QFP64(\*) [(SA732-B196)]  
MC9S08AC48CPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AC48MFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC48MFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC48MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC48MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC48MFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AC48MFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AC48MPU@QFP64(\*) [(SA732-B196)]  
MC9S08AC48MPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AC48VFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC48VFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC48VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC48VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC48VFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AC48VFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AC48VPU@QFP64(\*) [(SA732-B196)]  
MC9S08AC48VPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AC60CFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC60CFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC60CFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC60CFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC60CFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AC60CFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AC60CPU@QFP64(\*) [(SA732-B196)]  
MC9S08AC60CPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AC60MFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC60MFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC60MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC60MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC60MFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AC60MFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AC60MPU@QFP64(\*) [(SA732-B196)]  
MC9S08AC60MPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AC60VFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC60VFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC60VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC60VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC60VFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AC60VFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AC60VPU@QFP64(\*) [(SA732-B196)]  
MC9S08AC60VPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AC8CFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC8CFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC8CFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC8CFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC8MFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC8MFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC8MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC8MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC8VFD@QFN48(\*) [(SA696-B198)]  
MC9S08AC8VFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AC8VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AC8VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16CFD@QFN48(\*) [(SA696-B198)]  
MC9S08AW16CFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AW16CFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16CFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16CFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AW16CFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AW16CPU@QFP64(\*) [(SA732-B196)]  
MC9S08AW16CPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AW16MFD@QFN48(\*) [(SA696-B198)]  
MC9S08AW16MFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AW16MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16MFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16MFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AW16MFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AW16MPU@QFP64(\*) [(SA732-B196)]  
MC9S08AW16MPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AW16VFD@QFN48(\*) [(SA696-B198)]  
MC9S08AW16VFDE@QFN48(\*) [(SA696-B198)]  
MC9S08AW16VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16VFG@LQFP44(\*) [(SA245-B4404)]  
MC9S08AW16VFU@LQFP64(\*) [(SA757-B196)]  
MC9S08AW16VFUE@LQFP64(\*) [(SA757-B196)]  
MC9S08AW16VPU@QFP64(\*) [(SA732-B196)]  
MC9S08AW16VPUE@QFP64(\*) [(SA732-B196)]  
MC9S08AW32CFD@QFN48(\*) [(SA696-B198)]  
MC9S08AW32CFDE@QFN48(\*) [(SA696-B198)]

MC9S08AW32CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32CFGE@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32CFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32MFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32VFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48CFGE@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48CFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48MFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48VFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60CFGE@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60CFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60MFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60VFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08GB32ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB32ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB32CFU@LQFP64 [(TA066-B006)]  
MC9S08GB32CFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60CFU@LQFP64 [(TA066-B006)]  
MC9S08GB60CFUE@LQFP64 [(TA066-B006)]  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFC@MLF32 [(SA686-B231)]

MC9S08GT16ACFCE@MLF32 [(SA686-B231)]  
 MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
 MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
 MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
 MC9S08GT16AMFC@MLF32 [(SA686-B231)]  
 MC9S08GT16AMFCE@MLF32 [(SA686-B231)]  
 MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
 MC9S08GT16CB@SDIP42 [(SA028-B167)]  
 MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
 MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
 MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
 MC9S08GT16CFD@QFN48 [(SA696-B166)]  
 MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
 MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
 MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
 MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
 MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
 MC9S08GT32CB@SDIP42 [(SA028-B167)]  
 MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
 MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
 MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
 MC9S08GT32CFD@QFN48 [(SA696-B166)]  
 MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
 MC9S08GT60ACFB@LQFP44 [(SA675-B168)]  
 MC9S08GT60ACFBE@LQFP44 [(SA675-B168)]  
 MC9S08GT60ACFD@QFN48 [(SA696-B166)]  
 MC9S08GT60ACFDE@QFN48 [(SA696-B166)]  
 MC9S08GT60CB@SDIP42 [(SA028-B167)]  
 MC9S08GT60CBE@SDIP42 [(SA028-B167)]  
 MC9S08GT60CFB@LQFP44 [(SA675-B168)]  
 MC9S08GT60CFBE@LQFP44 [(SA675-B168)]  
 MC9S08GT60CFD@QFN48 [(SA696-B166)]  
 MC9S08GT60CFDE@QFN48 [(SA696-B166)]  
 MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
 MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
 MC9S08GT8ACFC@MLF32 [(SA686-B231)]  
 MC9S08GT8ACFCE@MLF32 [(SA686-B231)]  
 MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
 MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
 MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
 MC9S08GT8AMFC@MLF32 [(SA686-B231)]  
 MC9S08GT8AMFCE@MLF32 [(SA686-B231)]  
 MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
 MC9S08JM16CGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM16CGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM16CLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM16CLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM16MGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM16MGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM16MLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM16MLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM16VGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM16VGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM16VLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM16VLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32CGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM32CGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM32CLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32CLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32CLH@QFP64(\*) [(SA732+B311)]  
 MC9S08JM32CLHE@QFP64(\*) [(SA732+B311)]  
 MC9S08JM32CQH@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM32CQHE@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM32MGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM32MGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM32MLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32MLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32MLH@QFP64(\*) [(SA732+B311)]  
 MC9S08JM32MLHE@QFP64(\*) [(SA732+B311)]  
 MC9S08JM32MQH@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM32MQHE@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM32VGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM32VGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM32VLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32VLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM32VLH@QFP64(\*) [(SA732+B311)]  
 MC9S08JM32VLHE@QFP64(\*) [(SA732+B311)]  
 MC9S08JM32VQH@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM32VQHE@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM60CGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM60CLDE@QFP44(\*) [(SA245A+B4405)]

MC9S08JM60CLHE@QFP64(\*) [(SA732+B311)]  
 MC9S08JM60CQHE@TQFP64(\*) [(SA668+B311)]  
 MC9S08JM8CGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM8CGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM8CLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM8CLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM8MGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM8MGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM8MLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM8MLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM8VGT@QFN48(\*) [(SA696+B310)]  
 MC9S08JM8VGTE@QFN48(\*) [(SA696+B310)]  
 MC9S08JM8VLD@QFP44(\*) [(SA245A+B4405)]  
 MC9S08JM8VLDE@QFP44(\*) [(SA245A+B4405)]  
 MC9S08QA2CDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA2CDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA2CFQ@DFN8 [(SA744+B248)]  
 MC9S08QA2CFQE@DFN8 [(SA744+B248)]  
 MC9S08QA2CPA MC9S08QA2CPAE  
 MC9S08QA2MDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA2MDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA2MFQ@DFN8 [(SA744+B248)]  
 MC9S08QA2MFQE@DFN8 [(SA744+B248)]  
 MC9S08QA2MPA MC9S08QA2MPAE  
 MC9S08QA2VDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA2VDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA2VFQ@DFN8 [(SA744+B248)]  
 MC9S08QA2VFQE@DFN8 [(SA744+B248)]  
 MC9S08QA2VPA MC9S08QA2VPAE  
 MC9S08QA4CDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA4CDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA4CFQ@DFN8 [(SA744+B248)]  
 MC9S08QA4CFQE@DFN8 [(SA744+B248)]  
 MC9S08QA4CPA MC9S08QA4CPAE  
 MC9S08QA4MDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA4MDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA4MFQ@DFN8 [(SA744+B248)]  
 MC9S08QA4MFQE@DFN8 [(SA744+B248)]  
 MC9S08QA4MPA MC9S08QA4MPAE  
 MC9S08QA4VDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA4VDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA4VFQ@DFN8 [(SA744+B248)]  
 MC9S08QA4VFQE@DFN8 [(SA744+B248)]  
 MC9S08QA4VPA MC9S08QA4VPAE  
 MC9S08QD2CPC [(SA726+B179)]  
 MC9S08QD2CSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD2MPC [(SA726+B179)]  
 MC9S08QD2MSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD2VPC [(SA726+B179)]  
 MC9S08QD2VSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD4CPC [(SA726+B179)]  
 MC9S08QD4CSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD4MPC [(SA726+B179)]  
 MC9S08QD4MSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD4VPC [(SA726+B179)]  
 MC9S08QD4VSC@SOIC8 [(SA602A+B179)]  
 MC9S08QG4CDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QG4CDTE@TSSOP16 [(SA026+B182)]  
 MC9S08QG4CFQE@QFN16 [(SA747+B247)]  
 MC9S08QG4CFQE@DFN8 [(SA744+B248)]  
 MC9S08QG4CPAE [(SA726+B179)]  
 MC9S08QG8CDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QG8CDTE@TSSOP16 [(SA026+B182)]  
 MC9S08QG8CFQE@QFN16 [(SA747+B247)]  
 MC9S08QG8CFQE@DFN8 [(SA744+B248)]  
 MC9S08QG8CPBE [(SA726+B182)] MC9S08RC16CFG@LQFP44 [(SA245A)]  
 MC9S08RC16CFJ@LQFP32 [(SA663)] MC9S08RC16FG@LQFP44 [(SA245A)]  
 MC9S08RC16FJ@LQFP32 [(SA663)] MC9S08RC32CFG@LQFP44 [(SA245A)]  
 MC9S08RC32CFJ@LQFP32 [(SA663)] MC9S08RC32FG@LQFP44 [(SA245A)]  
 MC9S08RC32FJ@LQFP32 [(SA663)] MC9S08RC60CFG@LQFP44 [(SA245A)]  
 MC9S08RC60CFJ@LQFP32 [(SA663)] MC9S08RC60FG@LQFP44 [(SA245A)]  
 MC9S08RC60FJ@LQFP32 [(SA663)] MC9S08RC8CFG@LQFP44 [(SA245A)]  
 MC9S08RC8CFJ@LQFP32 [(SA663)] MC9S08RC8FG@LQFP44 [(SA245A)]  
 MC9S08RC8FJ@LQFP32 [(SA663)] MC9S08RD16CDW@SOIC28 [(SA404)]  
 MC9S08RD16CFG@LQFP44 [(SA245A)] MC9S08RD16CFJ@LQFP32 [(SA663)]  
 MC9S08RD16CP MC9S08RD16DW@SOIC28 [(SA404)]  
 MC9S08RD16FG@LQFP44 [(SA245A)] MC9S08RD16FJ@LQFP32 [(SA663)]  
 MC9S08RD16P MC9S08RD32CDW@SOIC28 [(SA404)]  
 MC9S08RD32CFG@LQFP44 [(SA245A)] MC9S08RD32CFJ@LQFP32 [(SA663)]  
 MC9S08RD32CP MC9S08RD32DW@SOIC28 [(SA404)]  
 MC9S08RD32FG@LQFP44 [(SA245A)] MC9S08RD32FJ@LQFP32 [(SA663)]

MC9S08RD32P  
 MC9S08RD60CFG@LQFP44 [(SA245A)]  
 MC9S08RD60CP  
 MC9S08RD60FG@LQFP44 [(SA245A)]  
 MC9S08RD60P  
 MC9S08RD8CFG@LQFP44 [(SA245A)]  
 MC9S08RD8CP  
 MC9S08RD8FG@LQFP44 [(SA245A)]  
 MC9S08RD8P  
 MC9S08RE16CFJ@LQFP32 [(SA663)]  
 MC9S08RE16FJ@LQFP32 [(SA663)]  
 MC9S08RE32CFJ@LQFP32 [(SA663)]  
 MC9S08RE32FJ@LQFP32 [(SA663)]  
 MC9S08RE60CFJ@LQFP32 [(SA663)]  
 MC9S08RE60FJ@LQFP32 [(SA663)]  
 MC9S08RE8CFJ@LQFP32 [(SA663)]  
 MC9S08RE8FJ@LQFP32 [(SA663)]  
 MC9S08RG32CFJ@LQFP32 [(SA663)]  
 MC9S08RG32FJ@LQFP32 [(SA663)]  
 MC9S08RG60CFJ@LQFP32 [(SA663)]  
 MC9S08RG60FJ@LQFP32 [(SA663)]  
 MC9S08SG4CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG4CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG4MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG4MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG4VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG4VTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG8CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG8CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG8MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG8MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG8VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG8VTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH4CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH4CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH4MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH4MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH4VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH4VTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH8CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH8CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH8MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH8MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH8VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH8VTG@TSSOP16 [(SA026+B182)]  
 MC9S12A128BCFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128BMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128BVFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128BVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256BCFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256BMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256BVFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256BVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A64CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64CPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12A64FU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64MPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12A64PV@TQFP112(\*) [(TA037-B006)]  
 MC9S12A64VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64VPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B128CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B128CPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B128MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B128MPV@TQFP112(\*) [(TA037-B006)]

MC9S08RD60CDW@SOIC28 [(SA404)]  
 MC9S08RD60CFJ@LQFP32 [(SA663)]  
 MC9S08RD60DW@SOIC28 [(SA404)]  
 MC9S08RD60FJ@LQFP32 [(SA663)]  
 MC9S08RD8CDW@SOIC28 [(SA404)]  
 MC9S08RD8CFJ@LQFP32 [(SA663)]  
 MC9S08RD8DW@SOIC28 [(SA404)]  
 MC9S08RD8FJ@LQFP32 [(SA663)]  
 MC9S08RE16CFG@LQFP44 [(SA245A)]  
 MC9S08RE16FG@LQFP44 [(SA245A)]  
 MC9S08RE32CFG@LQFP44 [(SA245A)]  
 MC9S08RE32FG@LQFP44 [(SA245A)]  
 MC9S08RE60CFG@LQFP44 [(SA245A)]  
 MC9S08RE60FG@LQFP44 [(SA245A)]  
 MC9S08RE8CFG@LQFP44 [(SA245A)]  
 MC9S08RE8FG@LQFP44 [(SA245A)]  
 MC9S08RG32CFG@LQFP44 [(SA245A)]  
 MC9S08RG32FG@LQFP44 [(SA245A)]  
 MC9S08RG60CFG@LQFP44 [(SA245A)]  
 MC9S08RG60FG@LQFP44 [(SA245A)]

MC9S12B128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12B128VPV@TQFP112(\*) [(TA037-B006)]  
MC9S12B64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12B64CPV@TQFP112(\*) [(TA037-B006)]  
MC9S12B64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12B64MPV@TQFP112(\*) [(TA037-B006)]  
MC9S12B64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12B64VPV@TQFP112(\*) [(TA037-B006)]  
MC9S12C128CFA@TQFP48 [(SA248)]  
MC9S12C128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128CPB@TQFP52 [(PEP+S673)]  
MC9S12C128MFA@TQFP48 [(SA248)]  
MC9S12C128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128MPB@TQFP52 [(PEP+S673)]  
MC9S12C128VFA@TQFP48 [(SA248)]  
MC9S12C128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128VPB@TQFP52 [(PEP+S673)]  
MC9S12C32CFA16@TQFP48 [(SA248)] MC9S12C32CFA25@TQFP48 [(SA248)]  
MC9S12C32CFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CPB16@TQFP52 [(PEP+S673)]  
MC9S12C32CPB25@TQFP52 [(PEP+S673)]  
MC9S12C32MFA16@TQFP48 [(SA248)] MC9S12C32MFA25@TQFP48 [(SA248)]  
MC9S12C32MFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MPB16@TQFP52 [(PEP+S673)]  
MC9S12C32MPB25@TQFP52 [(PEP+S673)]  
MC9S12C32VFA16@TQFP48 [(SA248)] MC9S12C32VFA25@TQFP48 [(SA248)]  
MC9S12C32VFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VPB16@TQFP52 [(PEP+S673)]  
MC9S12C32VPB25@TQFP52 [(PEP+S673)]  
MC9S12C64CFA@TQFP48 [(SA248)]  
MC9S12C64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64CPB@TQFP52 [(PEP+S673)] MC9S12C64MFA@TQFP48 [(SA248)]  
MC9S12C64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64MPB@TQFP52 [(PEP+S673)] MC9S12C64VFA@TQFP48 [(SA248)]  
MC9S12C64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64VPB@TQFP52 [(PEP+S673)] MC9S12C96CFA@TQFP48 [(SA248)]  
MC9S12C96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96CPB@TQFP52 [(PEP+S673)] MC9S12C96MFA@TQFP48 [(SA248)]  
MC9S12C96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96MPB@TQFP52 [(PEP+S673)] MC9S12C96VFA@TQFP48 [(SA248)]  
MC9S12C96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96VPB@TQFP52 [(PEP+S673)]  
MC9S12D64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64CPV@TQFP112(\*) [(TA037-B006)]  
MC9S12D64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64MPV@TQFP112(\*) [(TA037-B006)]  
MC9S12D64PV@TQFP112(\*) [(TA037-B006)]  
MC9S12D64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64VPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DB128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BMPV@TQFP112(\*) [(TA037-B084)]



MC9S12DG256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64CPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DJ64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DJ64PV@TQFP112(\*) [(TA037-B006)]  
MC9S12DJ64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64VPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DP256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CVPV@TQFP112(\*) [(TA037-B084)]

MC9S12DT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12E128CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E32CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12GC128CFA@TQFP48 [(SA248)]  
MC9S12GC128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128CPB@TQFP52 [(PEP+S673)]  
MC9S12GC128MFA@TQFP48 [(SA248)]  
MC9S12GC128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128MPB@TQFP52 [(PEP+S673)]  
MC9S12GC128VFA@TQFP48 [(SA248)]  
MC9S12GC128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128VPB@TQFP52 [(PEP+S673)]  
MC9S12GC16CFA@TQFP48 [(SA248)]  
MC9S12GC16CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16CPB@TQFP52 [(PEP+S673)]  
MC9S12GC16MFA@TQFP48 [(SA248)]  
MC9S12GC16MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16MPB@TQFP52 [(PEP+S673)]  
MC9S12GC16VFA@TQFP48 [(SA248)]  
MC9S12GC16VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16VPB@TQFP52 [(PEP+S673)]  
MC9S12GC32CFA@TQFP48 [(SA248)]  
MC9S12GC32CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32CPB@TQFP52 [(PEP+S673)]  
MC9S12GC32MFA@TQFP48 [(SA248)]  
MC9S12GC32MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32MPB@TQFP52 [(PEP+S673)]  
MC9S12GC32VFA@TQFP48 [(SA248)]  
MC9S12GC32VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32VPB@TQFP52 [(PEP+S673)]  
MC9S12GC64CFA@TQFP48 [(SA248)]  
MC9S12GC64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64CPB@TQFP52 [(PEP+S673)]  
MC9S12GC64MFA@TQFP48 [(SA248)]  
MC9S12GC64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64MPB@TQFP52 [(PEP+S673)]  
MC9S12GC64VFA@TQFP48 [(SA248)]  
MC9S12GC64VFU@TQFP80(\*) [(TA015-B006)]

MC9S12GC64VPB@TQFP52 [(PEP+S673)]  
MC9S12GC96CFA@TQFP48 [(SA248)]  
MC9S12GC96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96CPB@TQFP52 [(PEP+S673)]  
MC9S12GC96MFA@TQFP48 [(SA248)]  
MC9S12GC96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96MPB@TQFP52 [(PEP+S673)]  
MC9S12GC96VFA@TQFP48 [(SA248)]  
MC9S12GC96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96VPB@TQFP52 [(PEP+S673)]  
MC9S12HN64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12KG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12KG256CPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12KG256MPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12KG256VPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KT256CPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KT256MPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KT256VPV@LQFP112(\*) [(TA037-B084)]  
MC9S12NE64CPV@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64CPVE@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64VTU@TQFP80(\*) [(TA085-B006)]  
MC9S12NE64VTUE@TQFP80(\*) [(TA085-B006)]  
MC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
MC9S12XA128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MFU@TQFP80(\*) [(TA015-B006)]

MC9S12XA128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VfV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CFU@TQFP80(\*) [(TA015-B006)]

MC9S12XD256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD64CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CAA@TQFP80(\*) [(TA015-B006)]

```

MC9S12XDT384CAG@LQFP144(*) [(SA681-B14412)]
MC9S12XDT384CAL@TQFP112(*) [(TA037-B084)]
MC9S12XDT384CFV@LQFP144(*) [(SA681-B14412)]
MC9S12XDT384CPU@TQFP80(*) [(TA015-B006)]
MC9S12XDT384CPV@TQFP112(*) [(TA037-B084)]
MC9S12XDT384MAA@TQFP80(*) [(TA015-B006)]
MC9S12XDT384MAG@LQFP144(*) [(SA681-B14412)]
MC9S12XDT384MAL@TQFP112(*) [(TA037-B084)]
MC9S12XDT384MFV@LQFP144(*) [(SA681-B14412)]
MC9S12XDT384MPU@TQFP80(*) [(TA015-B006)]
MC9S12XDT384MPV@TQFP112(*) [(TA037-B084)]
MC9S12XDT384VAA@TQFP80(*) [(TA015-B006)]
MC9S12XDT384VAG@LQFP144(*) [(SA681-B14412)]
MC9S12XDT384VAL@TQFP112(*) [(TA037-B084)]
MC9S12XDT384VAV@LQFP144(*) [(SA681-B14412)]
MC9S12XDT384VPU@TQFP80(*) [(TA015-B006)]
MC9S12XDT384VPV@TQFP112(*) [(TA037-B084)]
MC9S12XDT512CAA@TQFP80(*) [(TA015-B006)]
MC9S12XDT512CAG@LQFP144(*) [(SA681-B14412)]
MC9S12XDT512CAL@TQFP112(*) [(TA037-B084)]
MC9S12XDT512CFU@TQFP80(*) [(TA015-B006)]
MC9S12XDT512CFV@LQFP144(*) [(SA681-B14412)]
MC9S12XDT512CPV@TQFP112(*) [(TA037-B084)]
MC9S12XDT512MAA@TQFP80(*) [(TA015-B006)]
MC9S12XDT512MAG@LQFP144(*) [(SA681-B14412)]
MC9S12XDT512MAL@TQFP112(*) [(TA037-B084)]
MC9S12XDT512MFU@TQFP80(*) [(TA015-B006)]
MC9S12XDT512MFV@LQFP144(*) [(SA681-B14412)]
MC9S12XDT512MPV@TQFP112(*) [(TA037-B084)]
MC9S12XDT512VAA@TQFP80(*) [(TA015-B006)]
MC9S12XDT512VAG@LQFP144(*) [(SA681-B14412)]
MC9S12XDT512VAL@TQFP112(*) [(TA037-B084)]
MC9S12XDT512VFU@TQFP80(*) [(TA015-B006)]
MC9S12XDT512VAV@LQFP144(*) [(SA681-B14412)]
MC9S12XDT512VPV@TQFP112(*) [(TA037-B084)]
MC9S12XHZ256CAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ256CAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ256MAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ256MAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ256VAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ256VAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ384CAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ384CAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ384MAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ384MAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ384VAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ384VAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ512CAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ512CAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ512MAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ512MAL@TQFP112(*) [(SA719-B264)]
MC9S12XHZ512VAG@LQFP144(*) [(SA681-B14414)]
MC9S12XHZ512VAL@TQFP112(*) [(SA719-B264)]
MCHC908JW32FAE@LQFP48 [(SA248+B005)]
MCHC908JW32FC@TQFN48 [(SA696+B006)]
P912XDG128CAA@TQFP80(*) [(TA015-B006)]
P912XDG128CAL@TQFP112(*) [(TA037-B084)]
P912XDG128CFU@TQFP80(*) [(TA015-B006)]
P912XDG128CPV@TQFP112(*) [(TA037-B084)]
P912XDG128MAA@TQFP80(*) [(TA015-B006)]
P912XDG128MAL@TQFP112(*) [(TA037-B084)]
P912XDG128MFU@TQFP80(*) [(TA015-B006)]
P912XDG128MPV@TQFP112(*) [(TA037-B084)]
P912XDG128VAA@TQFP80(*) [(TA015-B006)]
P912XDG128VAL@TQFP112(*) [(TA037-B084)]
P912XDG128VFU@TQFP80(*) [(TA015-B006)]
P912XDG128VPV@TQFP112(*) [(TA037-B084)]
P9RS08KA1CPC [(SA726+B179)]
P9RS08KA1CSC@SOIC8 [(SA602A+B179)]
P9RS08KA2CPC [(SA726+B179)]
P9RS08KA2CSC@SOIC8 [(SA602A+B179)]
PC56F8011VFAE@QFP32 [(SA663+B005)]
PC56F8013VFAE@QFP32 [(SA663+B005)]
PC56F8014VFAE@QFP32 [(SA663+B005)]
PC68HC908GP32 PC68HC908GP32@SDIP42 [(SA028)]
PC68HC908GP32@TQFP44 [(SA675)]
PC9S12UF32PB@QFP64(*) [(SA732+B200)]
PC9S12UF32PBE@QFP64(*) [(SA732+B200)]
PC9S12UF32PU@QFP100(*) [(SA718+B201)]
PC9S12XF128@QFP112(*) [(SA719-B253)]
PC9S12XF128@QFP144(*) [(SA681-B14411)]

```

```

PC9S12XF128@QFP64(*) [(SA732-B252)]
PC9S12XF256@QFP112(*) [(SA719-B253)]
PC9S12XF256@QFP144(*) [(SA681-B14411)]
PC9S12XF256@QFP64(*) [(SA732-B252)]
PC9S12XF384@QFP112(*) [(SA719-B253)]
PC9S12XF384@QFP144(*) [(SA681-B14411)]
PC9S12XF384@QFP64(*) [(SA732-B252)]
PC9S12XF512@QFP112(*) [(SA719-B253)]
PC9S12XF512@QFP144(*) [(SA681-B14411)]
PC9S12XF512@QFP64(*) [(SA732-B252)]
PC9S12XHZ256CAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ256CAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ256MAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ256MAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ256VAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ256VAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ384CAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ384CAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ384MAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ384MAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ384VAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ384VAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ512CAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ512CAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ512MAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ512MAL@TQFP112(*) [(SA719-B264)]
PC9S12XHZ512VAG@LQFP144(*) [(SA681-B14414)]
PC9S12XHZ512VAL@TQFP112(*) [(SA719-B264)]
S9S08AW16ACFT@QFN48(*) [(SA696-B198)]
S9S08AW16ACLS@QFP44(*) [(SA245-B4404)]
S9S08AW16AMFT@QFN48(*) [(SA696-B198)]
S9S08AW16AMLS@QFP44(*) [(SA245-B4404)]
S9S08AW16AVFT@QFN48(*) [(SA696-B198)]
S9S08AW16AVLS@QFP44(*) [(SA245-B4404)]
S9S08AW8ACFT@QFN48(*) [(SA696-B198)]
S9S08AW8ACLS@QFP44(*) [(SA245-B4404)]
S9S08AW8AMFT@QFN48(*) [(SA696-B198)]
S9S08AW8AMLS@QFP44(*) [(SA245-B4404)]
S9S08AW8AVFT@QFN48(*) [(SA696-B198)]
S9S08AW8AVLS@QFP44(*) [(SA245-B4404)]
XC68HC705P6A(CDW)@SOIC28 [(SA404)]
XC68HC711D3 XC68HC711D3@PLCC44 [(SA244)]
XC68HC711D3@TQFP44 [(SA675)]
XC68HC908MR32(CB)@SDIP56 [(PEP+S627)]
XC68HC908MR32(CB)@SDIP56(*) [(SA627+B5604)]
XC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]
XC68HC908MR32(CFU)@TQFP64(*) [(SA757+B331)]
XC68HC908MR32(VB)@SDIP56 [(PEP+S627)]
XC68HC908MR32(VB)@SDIP56(*) [(SA627+B5604)]
XC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]
XC68HC908MR32(VFU)@TQFP64(*) [(SA757+B331)]
XC68HSC705C9A XC68HSC705C9A@PLCC44 [(SA244)]
XC68HSC705C9A@TQFP44 [(SA245A)]

```

## Fremont Micro Devices

### E(E) PROM/FRAM/NVRAM

```

FT24C02 FT24C02@SOP8 [(SA602A)]
FT24C02@TSSOP8 [(SA026)] FT24C02A
FT24C02A@SOP8 [(SA602A)] FT24C02A@TSSOP8 [(SA026)]
FT24C04 FT24C04@SOP8 [(SA602A)]
FT24C04@TSSOP8 [(SA026)] FT24C04A
FT24C04A@SOP8 [(SA602A)] FT24C04A@TSSOP8 [(SA026)]
FT24C08 FT24C08@SOP8 [(SA602A)]
FT24C08@TSSOP8 [(SA026)] FT24C08A
FT24C08A@SOP8 [(SA602A)] FT24C08A@TSSOP8 [(SA026)]
FT24C1024 FT24C1024@SOP8 [(SA023A)]
FT24C1024@TSSOP8 [(SA026)] FT24C1024A
FT24C1024A@SOP8 [(SA023A)] FT24C1024A@TSSOP8 [(SA026)]
FT24C128 FT24C128@SOP8 [(SA602A)]
FT24C128@TSSOP8 [(SA026)] FT24C128A
FT24C128A@SOP8 [(SA602A)] FT24C128A@TSSOP8 [(SA026)]
FT24C16 FT24C16@SOP8 [(SA602A)]
FT24C16@TSSOP8 [(SA026)] FT24C16A
FT24C16A@SOP8 [(SA602A)] FT24C16A@TSSOP8 [(SA026)]
FT24C256 FT24C256@SOP8 [(SA602A)]

```

FT24C256@TSSOP8 [(SA026)]	FT24C256A
FT24C256A@SOP8 [(SA602A)]	FT24C256A@TSSOP8 [(SA026)]
FT24C32	FT24C32@SOP8 [(SA602A)]
FT24C32@TSSOP8 [(SA026)]	FT24C32A
FT24C32A@SOP8 [(SA602A)]	FT24C32A@TSSOP8 [(SA026)]
FT24C512	FT24C512@SOP8 [(SA602A)]
FT24C512@TSSOP8 [(SA026)]	FT24C512A
FT24C512A@SOP8 [(SA602A)]	FT24C512A@TSSOP8 [(SA026)]
FT24C64	FT24C64@SOP8 [(SA602A)]
FT24C64@TSSOP8 [(SA026)]	FT24C64A
FT24C64A@SOP8 [(SA602A)]	FT24C64A@TSSOP8 [(SA026)]
FT34C02	FT34C02@SOP8 [(SA602A)]
FT34C02@TSSOP8 [(SA026)]	FT34C02A
FT34C02A@SOP8 [(SA602A)]	FT34C02A@TSSOP8 [(SA026)]
FT93C46(08bit)	FT93C46(08bit)@SOP8 [(SA602A)]
FT93C46(08bit)@TSSOP8 [(SA026)]	FT93C46(16bit)
FT93C46(16bit)@SOP8 [(SA602A)]	FT93C46(16bit)@TSSOP8 [(SA026)]
FT93C46A(08bit)	FT93C46A(08bit)@SOP8 [(SA602A)]
FT93C46A(08bit)@TSSOP8 [(SA026)]	FT93C46A(16bit)
FT93C46A(16bit)@SOP8 [(SA602A)]	FT93C46A(16bit)@TSSOP8 [(SA026)]
FT93C56(08bit)	FT93C56(08bit)@SOP8 [(SA602A)]
FT93C56(08bit)@TSSOP8 [(SA026)]	FT93C56(16bit)
FT93C56(16bit)@SOP8 [(SA602A)]	FT93C56(16bit)@TSSOP8 [(SA026)]
FT93C56A(08bit)	FT93C56A(08bit)@SOP8 [(SA602A)]
FT93C56A(08bit)@TSSOP8 [(SA026)]	FT93C56A(16bit)
FT93C56A(16bit)@SOP8 [(SA602A)]	FT93C56A(16bit)@TSSOP8 [(SA026)]
FT93C66(08bit)	FT93C66(08bit)@SOP8 [(SA602A)]
FT93C66(08bit)@TSSOP8 [(SA026)]	FT93C66(16bit)
FT93C66(16bit)@SOP8 [(SA602A)]	FT93C66(16bit)@TSSOP8 [(SA026)]
FT93C66A(08bit)	FT93C66A(08bit)@SOP8 [(SA602A)]
FT93C66A(08bit)@TSSOP8 [(SA026)]	FT93C66A(16bit)
FT93C66A(16bit)@SOP8 [(SA602A)]	FT93C66A(16bit)@TSSOP8 [(SA026)]
FT93C86(08bit)	FT93C86(08bit)@SOP8 [(SA602A)]
FT93C86(08bit)@TSSOP8 [(SA026)]	FT93C86(16bit)
FT93C86(16bit)@SOP8 [(SA602A)]	FT93C86(16bit)@TSSOP8 [(SA026)]
FT93C86A(08bit)	FT93C86A(08bit)@SOP8 [(SA602A)]
FT93C86A(08bit)@TSSOP8 [(SA026)]	FT93C86A(16bit)
FT93C86A(16bit)@SOP8 [(SA602A)]	FT93C86A(16bit)@TSSOP8 [(SA026)]

## FUJITSU

### E(E) PROM/FRAM/NVRAM

MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21191DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21191EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21191EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21192DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21192EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21192EM@FBGA56 [(SA642C-B032A-Y056F001)]



```

MB84VD21193DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21193EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21193EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21194DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21194EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21194EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD22180FA@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22180FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22181A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22181EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22181EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22181FM@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD22182A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22182EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22182EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22183A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22183EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22183EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22184EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184FM@FBGA56 [(SA642E-B032A-T072F001)]
MB84VD22190FA@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22190FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22191A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22191EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22191EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22191FM@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD22192A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22192EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22192EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22193A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22193EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22193EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22194EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194FM@FBGA56 [(SA642E-B032A-T072F001)]
MB84VD22280FE@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22282EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22283EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22284EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22290FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22292EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22293EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22294EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22386EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22387EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22388EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]
MB85R256@SOP28 [(SA630)] MB85R256@TSOP28 [(SA430T)]
MB85R256A@SOP28 [(SA630)] MB85R256A@TSOP28 [(SA430T)]
MBM2212 MBM271001
MBM271001@PLCC32 [(SA015A1T)] MBM271001@TSOP32 [(SA410T)]
MBM27128 MBM27128@PLCC32 [(SA015A1T)]
MBM2716 MBM2716H
MBM27256 MBM27256@PLCC32 [(SA015A1T)]
MBM2732 MBM2732A
MBM2764 MBM2764@PLCC32 [(SA015A1T)]
MBM27C1000 MBM27C1000@PLCC32 [(SA015A1T)]
MBM27C1000@TSOP32 [(SA410T)] MBM27C1001
MBM27C1001@PLCC32 [(SA015A1T)] MBM27C1001@TSOP32 [(SA410T)]
MBM27C1024 MBM27C1024@PLCC44 [(SA244)]
MBM27C1028 MBM27C1028@PLCC32 [(SA015A1T)]
MBM27C128 MBM27C128@PLCC32 [(SA015A1T)]
MBM27C128P MBM27C128P@PLCC32 [(SA015A1T)]
MBM27C2000 MBM27C2000@PLCC32 [(SA015A1T)]

```

```

MBM27C2000@TSOP32 [(SA410T)]          MBM27C2001
MBM27C2001@PLCC32 [(SA015A1T)]       MBM27C2001@TSOP32 [(SA410T)]
MBM27C2048                             MBM27C256
MBM27C256@PLCC32 [(SA015A1T)]       MBM27C256A
MBM27C256A@PLCC32 [(SA015A1T)]     MBM27C256AP
MBM27C256AP@PLCC32 [(SA015A1T)]    MBM27C256H
MBM27C256H@PLCC32 [(SA015A1T)]     MBM27C32A
MBM27C4001                             MBM27C4001@PLCC32 [(SA015A1T)]
MBM27C4001@TSOP32 [(SA410T)]       MBM27C4096
MBM27C512                             MBM27C512@PLCC32 [(SA015A1T)]
MBM27C512P                             MBM27C512P@PLCC32 [(SA015A1T)]
MBM27C64                               MBM27C64@PLCC32 [(SA015A1T)]
MBM28C64                               MBM28C65
MBM28F010                             MBM28F010@PLCC32 [(SA015A1T)]
MBM28F010@TSOP32 [(SA410T)]
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161BD@TSOP48 [(SA247-B005)]
MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161TD@TSOP48 [(SA247-B005)]
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BD@TSOP48 [(SA247-B005)]
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BE@TSOP48 [(SA247-B005)]
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162TD@TSOP48 [(SA247-B005)]
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162TE@TSOP48 [(SA247-B005)]
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163BD@TSOP48 [(SA247-B005)]
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163BE@TSOP48 [(SA247-B005)]
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163TD@TSOP48 [(SA247-B005)]
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163TE@TSOP48 [(SA247-B005)]
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164BD@TSOP48 [(SA247-B005)]
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164BE@TSOP48 [(SA247-B005)]
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164TD@TSOP48 [(SA247-B005)]
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164TE@TSOP48 [(SA247-B005)]
MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL320BF@TSOP48 [(SA247-B005)]
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL320TF@TSOP48 [(SA247-B005)]
MBM29DL321BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL321BD@TSOP48 [(SA247-B005)]
MBM29DL321BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL321TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL321TD@TSOP48 [(SA247-B005)]
MBM29DL321TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL322BD@TSOP48 [(SA247-B005)]
MBM29DL322BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322BE@TSOP48 [(SA247-B005)]
MBM29DL322TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL322TD@TSOP48 [(SA247-B005)]
MBM29DL322TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322TE@TSOP48 [(SA247-B005)]
MBM29DL323BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL323BD@TSOP48 [(SA247-B005)]
MBM29DL323BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL323BE@TSOP48 [(SA247-B005)]
MBM29DL323BF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL323BF@TSOP48 [(SA247-B005)]
MBM29DL323TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL323TD@TSOP48 [(SA247-B005)]
MBM29DL323TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL323TE@TSOP48 [(SA247-B005)]
MBM29DL323TF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL323TF@TSOP48 [(SA247-B005)]
MBM29DL324BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL324BD@TSOP48 [(SA247-B005)]
MBM29DL324BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324BE@TSOP48 [(SA247-B005)]
MBM29DL324TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL324TD@TSOP48 [(SA247-B005)]

```

```

MBM29DL324TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324TE@TSOP48 [(SA247-B005)]
MBM29DL32BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32BF@TSOP48 [(SA247-B005)]
MBM29DL32TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32TF@TSOP48 [(SA247-B005)]
MBM29DL34BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34BF@TSOP48 [(SA247-B005)]
MBM29DL34TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34TF@TSOP48 [(SA247-B005)]
MBM29DL400BB@PSOP44 [(SA638-B006)]
MBM29DL400BB@TSOP48 [(SA247-B005)]
MBM29DL400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400BC@PSOP44 [(SA638)]
MBM29DL400BC@TSOP48 [(SA247-B005)]
MBM29DL400BT@PSOP44 [(SA638-B006)]
MBM29DL400BT@TSOP48 [(SA247-B005)]
MBM29DL400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400TC@PSOP44 [(SA638)]
MBM29DL400TC@TSOP48 [(SA247-B005)]
MBM29DL640E@FBGA63 [(SA642C-B026A-Y056F001)]
MBM29DL640E@TSOP48 [(SA247-B005)]
MBM29DL64DF@FBGA48 [(SA642F-B026A-T064F001)]
MBM29DL64DF@TSOP48 [(SA247-B005)]
MBM29DL800B@PSOP44 [(SA638-B006)]
MBM29DL800B@TSOP48 [(SA247-B005)]
MBM29DL800BA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800BA@TSOP48 [(SA247-B005)]
MBM29DL800BB@PSOP44 [(SA638-B006)]
MBM29DL800BB@TSOP48 [(SA247-B005)]
MBM29DL800BT@PSOP44 [(SA638-B006)]
MBM29DL800BT@TSOP48 [(SA247-B005)]
MBM29DL800T@PSOP44 [(SA638-B006)]
MBM29DL800T@TSOP48 [(SA247-B005)]
MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800TA@TSOP48 [(SA247-B005)]
MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163BE@TSOP48 [(SA247-B005)]
MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163TE@TSOP48 [(SA247-B005)]
MBM29F001B MBM29F001B@PLCC32 [(SA015A1T)]
MBM29F001B@TSOP32 [(SA410T)] MBM29F001T
MBM29F001T@PLCC32 [(SA015A1T)] MBM29F001T@TSOP32 [(SA410T)]
MBM29F002B MBM29F002B@PLCC32 [(SA015A1T)]
MBM29F002B@TSOP32 [(SA410T)] MBM29F002NB
MBM29F002NB@PLCC32 [(SA015A1T)] MBM29F002NB@TSOP32 [(SA410T)]
MBM29F002NT MBM29F002NT@PLCC32 [(SA015A1T)]
MBM29F002NT@TSOP32 [(SA410T)] MBM29F002T
MBM29F002T@PLCC32 [(SA015A1T)] MBM29F002T@TSOP32 [(SA410T)]
MBM29F010 MBM29F010@PLCC32 [(SA015A1T)]
MBM29F010@TSOP32 [(SA410T)] MBM29F010A
MBM29F010A@PLCC32 [(SA015A1T)] MBM29F010A@TSOP32 [(SA410T)]
MBM29F016@PSOP44 [(SA638)] MBM29F016@TSOP40 [(SA409T)]
MBM29F016@TSOP48 [(SA247-B005)] MBM29F016A@PSOP44 [(SA638)]
MBM29F016A@TSOP40 [(SA409T)] MBM29F016A@TSOP48 [(SA247-B005)]
MBM29F016B@PSOP44 [(SA638)] MBM29F016B@TSOP40 [(SA409T)]
MBM29F016B@TSOP48 [(SA247-B005)] MBM29F017B@TSOP48 [(SA247-B005)]
MBM29F017D@TSOP40 [(SA409T)] MBM29F017D@TSOP48 [(SA247-B005)]
MBM29F032B@PSOP44 [(SA638)] MBM29F032B@TSOP40 [(SA409T)]
MBM29F033C@TSOP40 [(SA409T)] MBM29F040
MBM29F040@PLCC32 [(SA015A1T)] MBM29F040@TSOP32 [(SA410T)]
MBM29F040B MBM29F040B@PLCC32 [(SA015A1T)]
MBM29F040B@TSOP32 [(SA410T)] MBM29F040C@PLCC32 [(SA015A1T)]
MBM29F040C@TSOP32 [(SA410T)] MBM29F080@PSOP44 [(SA638)]
MBM29F080@TSOP40 [(SA409T)] MBM29F080A@TSOP48 [(SA247-B005)]
MBM29F080B@PSOP44 [(SA638)] MBM29F080B@TSOP40 [(SA409T)]
MBM29F100B@PSOP44 [(SA638-B006)] MBM29F100B@TSOP48 [(SA247-B005)]
MBM29F100T@PSOP44 [(SA638-B006)] MBM29F100T@TSOP48 [(SA247-B005)]
MBM29F160BE@TSOP48 [(SA247-B005)]
MBM29F160TE@TSOP48 [(SA247-B005)]
MBM29F200AB@PSOP44 [(SA638-B006)]
MBM29F200AB@TSOP48 [(SA247-B005)]
MBM29F200AT@PSOP44 [(SA638-B006)]
MBM29F200AT@TSOP48 [(SA247-B005)]
MBM29F200B@PSOP44 [(SA638-B006)] MBM29F200B@TSOP48 [(SA247-B005)]
MBM29F200T@PSOP44 [(SA638-B006)] MBM29F200T@TSOP48 [(SA247-B005)]
MBM29F400AB@PSOP44 [(SA638-B006)]
MBM29F400AB@TSOP48 [(SA247-B005)]
MBM29F400AT@PSOP44 [(SA638-B006)]
MBM29F400AT@TSOP48 [(SA247-B005)]
MBM29F400B@PSOP44 [(SA638-B006)] MBM29F400B@TSOP48 [(SA247-B005)]

```

```

MBM29F400BB@PSOP44 [(SA638-B006)]
MBM29F400BB@TSOP48 [(SA247-B005)]
MBM29F400BT@PSOP44 [(SA638-B006)]
MBM29F400BT@TSOP48 [(SA247-B005)]
MBM29F400T@PSOP44 [(SA638-B006)] MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)] MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BA@PSOP44 [(SA638-B006)]
MBM29F800BA@TSOP48 [(SA247-B005)]
MBM29F800BB@PSOP44 [(SA638-B006)]
MBM29F800BB@TSOP48 [(SA247-B005)]
MBM29F800BT@PSOP44 [(SA638-B006)]
MBM29F800BT@TSOP48 [(SA247-B005)]
MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]
MBM29F800TA@PSOP44 [(SA638-B006)]
MBM29F800TA@TSOP48 [(SA247-B005)]
MBM29LL800B@TSOP48 [(SA247-B005)]
MBM29LL800BB@TSOP48 [(SA247-B005)]
MBM29LL800BT@TSOP48 [(SA247-B005)]
MBM29LL800T@TSOP48 [(SA247-B005)]
MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001BB@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)] MBM29LV001T@TSOP32 [(SA410T)]
MBM29LV001TC@PLCC32 [(SA015A1T)] MBM29LV001TC@TSOP32 [(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)] MBM29LV002T@TSOP40 [(SA409T)]
MBM29LV004B@PSOP44 [(SA638)] MBM29LV004B@TSOP40 [(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)] MBM29LV004BT@TSOP40 [(SA409T)]
MBM29LV004T@PSOP44 [(SA638)] MBM29LV004T@TSOP40 [(SA409T)]
MBM29LV008B@PSOP44 [(SA638)] MBM29LV008B@TSOP40 [(SA409T)]
MBM29LV008BB@TSOP40 [(SA409T)] MBM29LV008BT@TSOP40 [(SA409T)]
MBM29LV008T@PSOP44 [(SA638)] MBM29LV008T@TSOP40 [(SA409T)]
MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40 [(SA409T)]
MBM29LV016B@TSOP40 [(SA409T)]
MBM29LV017@FBGA48 [(SA6420-B026A-T064F001)]
MBM29LV017@TSOP40 [(SA409T)] MBM29LV017B@TSOP40 [(SA409T)]
MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40 [(SA409T)]
MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40 [(SA409T)]
MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40 [(SA409T)]
MBM29LV160B@SON46 [(SA631)] MBM29LV160B@SON46(*)
MBM29LV160BB@PSOP44 [(SA638-B006)]
MBM29LV160BB@TSOP48 [(SA247-B005)]
MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160BE@TSOP48 [(SA247-B005)]
MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160BM@TSOP48 [(SA247-B005)]
MBM29LV160BT@PSOP44 [(SA638-B006)]
MBM29LV160BT@TSOP48 [(SA247-B005)]
MBM29LV160T@SON46 [(SA631)] MBM29LV160T@SON46(*)
MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TE@TSOP48 [(SA247-B005)]
MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TM@TSOP48 [(SA247-B005)]
MBM29LV200B@PSOP44 [(SA638-B006)]
MBM29LV200B@TSOP48 [(SA247-B005)]
MBM29LV200BB@PSOP44 [(SA638-B006)]
MBM29LV200BB@TSOP48 [(SA247-B005)]
MBM29LV200BC@PSOP44 [(SA638)]
MBM29LV200BC@TSOP48 [(SA247-B005)]
MBM29LV200BT@PSOP44 [(SA638-B006)]
MBM29LV200BT@TSOP48 [(SA247-B005)]
MBM29LV200T@PSOP44 [(SA638-B006)]
MBM29LV200T@TSOP48 [(SA247-B005)]
MBM29LV200TC@PSOP44 [(SA638)]
MBM29LV200TC@TSOP48 [(SA247-B005)]
MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320BE@TSOP48 [(SA247-B005)]
MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320TE@TSOP48 [(SA247-B005)]
MBM29LV400B@PSOP44 [(SA638-B006)]
MBM29LV400B@TSOP48 [(SA247-B005)]
MBM29LV400BB@PSOP44 [(SA638-B006)]
MBM29LV400BB@TSOP48 [(SA247-B005)]
MBM29LV400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400BC@PSOP44 [(SA638)]
MBM29LV400BC@TSOP48 [(SA247-B005)]
MBM29LV400BT@PSOP44 [(SA638-B006)]
MBM29LV400BT@TSOP48 [(SA247-B005)]
MBM29LV400T@PSOP44 [(SA638-B006)]
MBM29LV400T@TSOP48 [(SA247-B005)]
MBM29LV400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400TC@PSOP44 [(SA638)]

```

MBM29LV400TC@TSOP48 [(SA247-B005)]  
 MBM29LV650UE@TSOP48 [(SA247-B005)]  
 MBM29LV651UE@TSOP48 [(SA247-B005)]  
 MBM29LV652UE@FGBA63 [(SA642C-B026A-Y056F001)]  
 MBM29LV800B@PSOP44 [(SA638-B006)]  
 MBM29LV800B@SON46 [(SA631)] MBM29LV800B@SON46 (\*)  
 MBM29LV800B@TSOP48 [(SA247-B005)]  
 MBM29LV800BA@FGBA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800BA@PSOP44 [(SA638)]  
 MBM29LV800BA@TSOP48 [(SA247-B005)]  
 MBM29LV800BB@PSOP44 [(SA638-B006)]  
 MBM29LV800BB@TSOP48 [(SA247-B005)]  
 MBM29LV800BE@FGBA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800BE@PSOP44 [(SA638)]  
 MBM29LV800BE@TSOP48 [(SA247-B005)]  
 MBM29LV800BT@PSOP44 [(SA638-B006)]  
 MBM29LV800BT@TSOP48 [(SA247-B005)]  
 MBM29LV800T@PSOP44 [(SA638-B006)]  
 MBM29LV800T@SON46 [(SA631)] MBM29LV800T@SON46 (\*)  
 MBM29LV800T@TSOP48 [(SA247-B005)]  
 MBM29LV800TA@FGBA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800TA@PSOP44 [(SA638)]  
 MBM29LV800TA@TSOP48 [(SA247-B005)]  
 MBM29LV800TE@FGBA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800TE@PSOP44 [(SA638)]  
 MBM29LV800TE@TSOP48 [(SA247-B005)]  
 MBM29PDS323B@FGBA63 [(SA642B-B026A-Y072F001)]  
 MBM29PDS323T@FGBA63 [(SA642B-B026A-Y072F001)]  
 MBM29PL12LM@TSOP56 [(SA628-B102)]  
 MBM29PL160BD@PSOP44 [(SA638)]  
 MBM29PL160BD@TSOP48 [(SA247-B005)]  
 MBM29PL160TD@PSOP44 [(SA638)]  
 MBM29PL160TD@TSOP48 [(SA247-B005)]  
 MBM29PL32BM@FGBA48 [(SA642G-B026A-T048F001)]  
 MBM29PL32BM@TSOP48 [(SA247-B005)]  
 MBM29PL32TM@FGBA48 [(SA642G-B026A-T048F001)]  
 MBM29PL32TM@TSOP48 [(SA247-B005)]  
 MBM29PL64LM@TSOP48 [(SA247-B005)]  
 MBM29PL64LM@TSOP56 [(SA628-B067)]  
 MBM29QM12DH@FGBA88 [(SA642J-B101A-W080F001)]  
 MBM29QM12DH@TSOP56 [(SA628-B097)]  
 MBM29SL160BD@FGBA48 [(SA642B-B026A-Y072F001)]  
 MBM29SL160BD@TSOP48 [(SA247-B005)]  
 MBM29SL160TD@FGBA48 [(SA642B-B026A-Y072F001)]  
 MBM29SL160TD@TSOP48 [(SA247-B005)]  
 MBM29SL800BB@TSOP48 [(SA247-B005)]  
 MBM29SL800BT@TSOP48 [(SA247-B005)]  
 MSP55LV128@PSOP44 [(SA638-B006)]  
 MSP55LV128T@TSOP56 [(SA628-B102)]  
 MSP55LV256@PSOP44 [(SA638)]

**DRAM & SRAM**

MB81C78A MB81C78A@SOIC28 [(SA630)]

**MICROCONTROLLER**

MB89F051@LQFP64 MB89F202@SDIP32 [(SA653)]  
 MB89F202@SSOP34 [(SA689)] MB89F202RA@QFP32 [(SA663)]  
 MB89F202RA@SDIP32 [(SA653)] MB89F202RA@SSOP34 [(SA689)]  
 MB89F482AS@LQFP44 [(SA675)] MB89F482AS@SDIP42 [(SA028)]  
 MB89F482AW@LQFP44 [(SA675)] MB89F482AW@SDIP42 [(SA028)]  
 MB89F482HS@LQFP44 [(SA675)] MB89F482HS@SDIP42 [(SA028)]  
 MB89F482HW@LQFP44 [(SA675)] MB89F482HW@SDIP42 [(SA028)]  
 MB89F497@TQFP80 [(PEP+S704)] MB89F497A@TQFP80 [(PEP+S704)]  
 MB89F499@PQFP100 [(PEP+S427)] MB89F538@SDIP64 [(PEP+S600A)]  
 MB89F538-101PFM@TQFP64 [(PEP+S680)]  
 MB89F538-101PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538-201PFM@TQFP64 [(PEP+S680)]  
 MB89F538-201PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538L-101PFM@TQFP64 [(PEP+S680)]  
 MB89F538L-101PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538L-201PFM@TQFP64 [(PEP+S680)]  
 MB89F538L-201PFM@TQFP64(\*) [(SA739+B255)]  
 MB89P131APFM@TQFP48 [(SA745)] MB89P131PFM@TQFP48 [(SA745)]  
 MB89P133APFM@TQFP48 [(SA745)] MB89P133PFM@TQFP48 [(SA745)]  
 MB89P135APFM@TQFP48 [(SA745)] MB89P135PFM@TQFP48 [(SA745)]  
 MB89P165-101(PF)@QFP80 [(PEP+S611A)]

MB89P165-101(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-101(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-102(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-102(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-102(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-103(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-103(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-103(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-104(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-104(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-104(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-105(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-105(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-105(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-201(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-201(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-201(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-202(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-202(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-202(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-203(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-203(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-203(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P195 MB89P195(F)@SOIC28 [(SA777)]  
 MB89P195AP MB89P195AP(F)@SOIC28 [(SA777)]  
 MB89P195P MB89P195P(F)@SOIC28 [(SA777)]  
 MB89P475-101P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-102P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-201P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-202P-SH@SDIP48 [(SA627-B5604)]  
 MB89P485LPPM-101@TQFP64 [(PEP+S680)]  
 MB89P485LPPM-101@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPPM-102@TQFP64 [(PEP+S680)]  
 MB89P485LPPM-102@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPPM-103@TQFP64 [(PEP+S680)]  
 MB89P485LPPM-103@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPPM-104@TQFP64 [(PEP+S680)]  
 MB89P485LPPM-104@TQFP64(\*) [(TA055-B006)]  
 MB89P485PPM-101@TQFP64 [(PEP+S680)]  
 MB89P485PPM-101@TQFP64(\*) [(TA055-B006)]  
 MB89P485PPM-102@TQFP64 [(PEP+S680)]  
 MB89P485PPM-102@TQFP64(\*) [(TA055-B006)]  
 MB89P485PPM-103@TQFP64 [(PEP+S680)]  
 MB89P485PPM-103@TQFP64(\*) [(TA055-B006)]  
 MB89P485PPM-104@TQFP64 [(PEP+S680)]  
 MB89P485PPM-104@TQFP64(\*) [(TA055-B006)]  
 MB89P538@SDIP64 [(PEP+S600A)]  
 MB89P538-101PFM@TQFP64 [(PEP+S680)]  
 MB89P538-201PFM@TQFP64 [(PEP+S680)]  
 MB89P538L-101PFM@TQFP64 [(PEP+S680)]  
 MB89P538L-201PFM@TQFP64 [(PEP+S680)]  
 MB89P857@SDIP64 [(PEP+S600A)] MB89P935CP  
 MB89P935CP--G-SH@SDIP32 [(SA653)]  
 MB90867A@LQFP100 [(PEP+S604)] MB90867A@QFP100 [(PEP+S427)]  
 MB90867AS@LQFP100 [(PEP+S604)] MB90867AS@QFP100 [(PEP+S427)]  
 MB90F334APFF@LQFP120 [(TA051-B006)]  
 MB90F334APMC@LQFP120 [(TA036-B006)]  
 MB90F342A@LQFP100 [(PEP+S604)] MB90F342A@QFP100 [(PEP+S427)]  
 MB90F342A@QFP100(\*) [(TA075)] MB90F342AS@LQFP100 [(PEP+S604)]  
 MB90F342AS@QFP100 [(PEP+S427)] MB90F342AS@QFP100(\*) [(TA075)]  
 MB90F342CA@LQFP100 [(PEP+S604)] MB90F342CA@QFP100 [(PEP+S427)]  
 MB90F342CA@QFP100(\*) [(TA075)] MB90F342CAS@LQFP100 [(PEP+S604)]  
 MB90F342CAS@QFP100 [(PEP+S427)] MB90F342CAS@QFP100(\*) [(TA075)]  
 MB90F343A@LQFP100 [(PEP+S604)] MB90F343A@QFP100 [(PEP+S427)]  
 MB90F343A@QFP100(\*) [(TA075)] MB90F343AS@LQFP100 [(PEP+S604)]  
 MB90F343AS@QFP100 [(PEP+S427)] MB90F343AS@QFP100(\*) [(TA075)]  
 MB90F343CA@LQFP100 [(PEP+S604)] MB90F343CA@QFP100 [(PEP+S427)]  
 MB90F343CA@QFP100(\*) [(TA075)] MB90F343CAS@LQFP100 [(PEP+S604)]  
 MB90F343CAS@QFP100 [(PEP+S427)] MB90F343CAS@QFP100(\*) [(TA075)]  
 MB90F345A@LQFP100 [(PEP+S604)] MB90F345A@QFP100 [(PEP+S427)]  
 MB90F345A@QFP100(\*) [(TA075)] MB90F345AS@LQFP100 [(PEP+S604)]  
 MB90F345AS@QFP100 [(PEP+S427)] MB90F345AS@QFP100(\*) [(TA075)]  
 MB90F345CA@LQFP100 [(PEP+S604)] MB90F345CA@QFP100 [(PEP+S427)]  
 MB90F345CA@QFP100(\*) [(TA075)] MB90F345CAS@LQFP100 [(PEP+S604)]  
 MB90F345CAS@QFP100 [(PEP+S427)] MB90F345CAS@QFP100(\*) [(TA075)]  
 MB90F346A@LQFP100 [(PEP+S604)] MB90F346A@QFP100 [(PEP+S427)]  
 MB90F346A@QFP100(\*) [(TA075)] MB90F346AS@LQFP100 [(PEP+S604)]  
 MB90F346AS@QFP100 [(PEP+S427)] MB90F346AS@QFP100(\*) [(TA075)]  
 MB90F346CA@LQFP100 [(PEP+S604)] MB90F346CA@QFP100 [(PEP+S427)]  
 MB90F346CA@QFP100(\*) [(TA075)] MB90F346CAS@LQFP100 [(PEP+S604)]  
 MB90F346CAS@QFP100 [(PEP+S427)] MB90F346CAS@QFP100(\*) [(TA075)]

```

MB90F347@LQFP100 [(PEP+S604)] MB90F347@QFP100 [(PEP+S427)]
MB90F347@QFP100(*) [(TA075)] MB90F347A@LQFP100 [(PEP+S604)]
MB90F347A@QFP100 [(PEP+S427)] MB90F347A@QFP100(*) [(TA075)]
MB90F347AS@LQFP100 [(PEP+S604)] MB90F347AS@QFP100 [(PEP+S427)]
MB90F347AS@QFP100(*) [(TA075)] MB90F347C@LQFP100 [(PEP+S604)]
MB90F347C@QFP100 [(PEP+S427)] MB90F347C@QFP100(*) [(TA075)]
MB90F347CA@LQFP100 [(PEP+S604)] MB90F347CA@QFP100 [(PEP+S427)]
MB90F347CA@QFP100(*) [(TA075)] MB90F347CAS@LQFP100 [(PEP+S604)]
MB90F347CAS@QFP100 [(PEP+S427)] MB90F347CAS@QFP100(*) [(TA075)]
MB90F347CS@LQFP100 [(PEP+S604)] MB90F347CS@QFP100 [(PEP+S427)]
MB90F347CS@QFP100(*) [(TA075)] MB90F347S@LQFP100 [(PEP+S604)]
MB90F347S@QFP100 [(PEP+S427)] MB90F347S@QFP100(*) [(TA075)]
MB90F349A@LQFP100 [(PEP+S604)] MB90F349A@QFP100 [(PEP+S427)]
MB90F349A@QFP100(*) [(TA075)] MB90F349AS@LQFP100 [(PEP+S604)]
MB90F349AS@QFP100 [(PEP+S427)] MB90F349AS@QFP100(*) [(TA075)]
MB90F349CA@LQFP100 [(PEP+S604)] MB90F349CA@QFP100 [(PEP+S427)]
MB90F349CA@QFP100(*) [(TA075)] MB90F349CAS@LQFP100 [(PEP+S604)]
MB90F349CAS@QFP100 [(PEP+S427)] MB90F349CAS@QFP100(*) [(TA075)]
MB90F352PFM@LQFP64 [(PEP+S680)]
MB90F352PFM@LQFP64(*) [(SA739+B260)]
MB90F352SPFM@LQFP64 [(PEP+S680)]
MB90F352SPFM@LQFP64(*) [(SA739+B260)]
MB90F372@LQFP144(*) [(SA748+B14410)]
MB90F377@LQFP144(*) [(SA748+B14410)]
MB90F387PMT@LQFP48 [(SA248)] MB90F387SPMT@LQFP48 [(SA248)]
MB90F394H@LQFP120(*) [(TA036-B006)]
MB90F395H@LQFP120(*) [(TA036-B006)]
MB90F423GA@LQFP100 [(PEP+S604)] MB90F423GA@QFP100 [(PEP+S427)]
MB90F423GA@TQFP100(*) [(SA773+BBBB)]
MB90F423GB@LQFP100 [(PEP+S604)] MB90F423GB@QFP100 [(PEP+S427)]
MB90F423GB@TQFP100(*) [(SA773+BBBB)]
MB90F423GC@LQFP100 [(PEP+S604)] MB90F423GC@QFP100 [(PEP+S427)]
MB90F423GC@TQFP100(*) [(SA773+BBBB)]
MB90F428GA@LQFP100 [(PEP+S604)] MB90F428GA@QFP100 [(PEP+S427)]
MB90F428GA@TQFP100(*) [(SA773+BBBB)]
MB90F428GB@LQFP100 [(PEP+S604)] MB90F428GB@QFP100 [(PEP+S427)]
MB90F428GB@TQFP100(*) [(SA773+BBBB)]
MB90F428GC@LQFP100 [(PEP+S604)] MB90F428GC@QFP100 [(PEP+S427)]
MB90F428GC@TQFP100(*) [(SA773+BBBB)]
MB90F438LPF@LQFP100 [(PEP+S427)]
MB90F438LPFV@TQFP100 [(PEP+S604)]
MB90F438LSPF@LQFP100 [(PEP+S427)]
MB90F438LSPFV@TQFP100 [(PEP+S604)]
MB90F439PF@LQFP100 [(PEP+S427)] MB90F439PFV@TQFP100 [(PEP+S604)]
MB90F439SPF@LQFP100 [(PEP+S427)]
MB90F439SPFV@TQFP100 [(PEP+S604)]
MB90F455PMT@LQFP48 [(SA248)]
MB90F456PMT@LQFP48 [(SA248)]
MB90F457PMT@LQFP48 [(SA248)]
MB90F457SPMT@LQFP48 [(SA248)]
MB90F462AP@SDIP64 [(PEP+S600A)]
MB90F462AP@SDIP64(*) [(SA752+B307)]
MB90F462APF@QFP64 [(PEP+S735)] MB90F462APFM@LQFP64 [(PEP+S680)]
MB90F462APFM@LQFP64(*) [(SA739+B245)]
MB90F462P@SDIP64 [(PEP+S600A)]
MB90F462P@SDIP64(*) [(SA752+B307)]
MB90F462PF@QFP64 [(PEP+S735)] MB90F462PFM@LQFP64 [(PEP+S680)]
MB90F462PFM@LQFP64(*) [(SA739+B245)]
MB90F463AP@SDIP64 [(PEP+S600A)]
MB90F463AP@SDIP64(*) [(SA752+B307)]
MB90F463APF@QFP64 [(PEP+S735)] MB90F463APFM@LQFP64 [(PEP+S680)]
MB90F463APFM@LQFP64(*) [(SA739+B245)]
MB90F474HPF@LQFP100 [(PEP+S427)] MB90F474HPFV@QFP100 [(PEP+S604)]
MB90F474LPF@LQFP100 [(PEP+S427)] MB90F474LPFV@QFP100 [(PEP+S604)]
MB90F481PF@LQFP100 [(PEP+S427)] MB90F481PFV@TQFP100 [(PEP+S604)]
MB90F482PF@LQFP100 [(PEP+S427)] MB90F482PFV@TQFP100 [(PEP+S604)]
MB90F488BPF@LQFP100 [(PEP+S427)]
MB90F488BPFV@TQFP100 [(PEP+S604)]
MB90F488BPFV@TQFP100(*) [(SA773-B223A)]
MB90F489BPF@LQFP100 [(PEP+S427)]
MB90F489BPFV@TQFP100 [(PEP+S604)]
MB90F489BPFV@TQFP100(*) [(SA773-B223A)]
MB90F497G@LQFP64 [(PEP+S680)] MB90F497G@LQFP64(*) [(TA070)]
MB90F497G@QFP64 [(PEP+S618)] MB90F497G@QFP64(*) [(TA070)]
MB90F498G@LQFP64 [(PEP+S680)] MB90F498G@LQFP64(*) [(TA070)]
MB90F498G@QFP64 [(PEP+S618)] MB90F498G@QFP64(*) [(TA070)]
MB90F543GPF@LQFP100 [(PEP+S427)]
MB90F543GPFV@TQFP100 [(PEP+S604)]
MB90F543GSPF@LQFP100 [(PEP+S427)]
MB90F543GSPFV@TQFP100 [(PEP+S604)]
MB90F543PF@LQFP100 [(PEP+S427)] MB90F543PFV@TQFP100 [(PEP+S604)]
MB90F546GPF@LQFP100 [(PEP+S427)]

```

```

MB90F546GPFV@TQFP100 [(PEP+S604)]
MB90F546GSPF@LQFP100 [(PEP+S427)]
MB90F546GSPFV@TQFP100 [(PEP+S604)]
MB90F548GPF@LQFP100 [(PEP+S427)]
MB90F548GPFV@TQFP100 [(PEP+S604)]
MB90F548GSPF@LQFP100 [(PEP+S427)]
MB90F548GSPFV@TQFP100 [(PEP+S604)]
MB90F549GPF@LQFP100 [(PEP+S427)]
MB90F549GPFV@TQFP100 [(PEP+S604)]
MB90F549GSPF@LQFP100 [(PEP+S427)]
MB90F549GSPFV@TQFP100 [(PEP+S604)]
MB90F549PF@LQFP100 [(PEP+S427)] MB90F549PFV@TQFP100 [(PEP+S604)]
MB90F553APF@QFP100 [(PEP+S427)]
MB90F553APFV@LQFP100 [(PEP+S604)]
MB90F562@LQFP64 [(PEP+S680)] MB90F562@LQFP64(*) [(TA070)]
MB90F562@QFP64 [(PEP+S618)] MB90F562@QFP64(*) [(TA070)]
MB90F562B@LQFP64 [(PEP+S680)] MB90F562B@LQFP64(*) [(TA070)]
MB90F562B@QFP64 [(PEP+S618)]
MB90F562B@QFP64(*) [(SA758+B322)]
MB90F562B@SDIP64(*) [(SA752+B307)]
MB90F568@LQFP64 [(PEP+S680)] MB90F568@QFP64 [(PEP+S618)]
MB90F568T@LQFP64 [(PEP+S680)] MB90F568T@QFP64 [(PEP+S618)]
MB90F583CAPF@LQFP100 [(PEP+S427)]
MB90F583CAPFV@TQFP100 [(PEP+S604)]
MB90F583CAPFV@TQFP100(*) [(SA773+B223)]
MB90F583CPF@LQFP100 [(PEP+S427)]
MB90F583CPFV@TQFP100 [(PEP+S604)]
MB90F583CPFV@TQFP100(*) [(SA773+B223)]
MB90F591APF@QFP100 [(PEP+S427)] MB90F591GPF@QFP100 [(PEP+S427)]
MB90F591PF@QFP100 [(PEP+S427)] MB90F594APF@QFP100 [(PEP+S427)]
MB90F594GPF@QFP100 [(PEP+S427)] MB90F594PF@QFP100 [(PEP+S427)]
MB90F598GPF@PQFP100 [(PEP+S427)] MB90F598PF@PQFP100 [(PEP+S427)]
MB90F822PF@PQFP80 [(PEP+S611A)]
MB90F822PF@PQFP80(*) [(SA756+B314)]
MB90F822PFM@LQFP80 [(PEP+S704)] MB90F822PFV@LQFP80 [(PEP+S640B)]
MB90F823PF@PQFP80 [(PEP+S611A)]
MB90F823PF@PQFP80(*) [(SA756+B314)]
MB90F823PFM@LQFP80 [(PEP+S704)] MB90F823PFV@LQFP80 [(PEP+S640B)]
MB90F867A@LQFP100 [(PEP+S604)] MB90F867A@QFP100 [(PEP+S427)]
MB90F867AS@LQFP100 [(PEP+S604)] MB90F867AS@QFP100 [(PEP+S427)]
MB90F882@LQFP100 [(PEP+S604)] MB90F884@LQFP100 [(PEP+S604)]
MB90F897PMT@LQFP48 [(SA248)] MB90F897SPMT@LQFP48 [(SA248)]
MB90F927@LQFP100 [(PEP+S604)] MB90F927@QFP100 [(PEP+S427)]
MB90F927@QFP100(*) [(SA753+B270)]
MB90F927S@LQFP100 [(PEP+S604)] MB90F927S@QFP100 [(PEP+S427)]
MB90F927S@QFP100(*) [(SA753+B270)]
MB90F947APF@QFP100(*) [(SA753+B312)]
MB90F947PF@QFP100(*) [(SA753+B312)]
MB90F949APF@QFP100(*) [(SA753+B312)]
MB90F949PF@QFP100(*) [(SA753+B312)]
MB90P663APFM@QFP64 [(PEP+S680)]
MB95F108AHSPFM@LQFP64 [(PEP+S680)]
MB95F108AHSPFM@LQFP64(*) [(SA739+B259)]
MB95F108AHSPFV@LQFP64 [(PEP+S616)]
MB95F108AHSPFV@LQFP64(*) [(SA732+B259)]
MB95F108AHWPFM@LQFP64 [(PEP+S680)]
MB95F108AHWPFM@LQFP64(*) [(SA739+B259)]
MB95F108AHWPFV@LQFP64 [(PEP+S616)]
MB95F108AHWPFV@LQFP64(*) [(SA732+B259)]
MB95F108AJSPFM@LQFP64(*) [(SA739+B259)]
MB95F108AJSPFV@LQFP64(*) [(SA732+B259)]
MB95F108AJWPFM@LQFP64(*) [(SA739+B259)]
MB95F108AJWPFV@LQFP64(*) [(SA732+B259)]
MB95F108AKSPFM@LQFP64 [(PEP+S680)]
MB95F108AKSPFM@LQFP64(*) [(SA739+B259)]
MB95F108AKSPFV@LQFP64 [(PEP+S616)]
MB95F108AKSPFV@LQFP64(*) [(SA732+B259)]
MB95F108AKWPFM@LQFP64 [(PEP+S680)]
MB95F108AKWPFM@LQFP64(*) [(SA739+B259)]
MB95F108AKWPFV@LQFP64 [(PEP+S616)]
MB95F108AKWPFV@LQFP64(*) [(SA732+B259)]
MB95F108AMPFM@LQFP64 [(PEP+S680)]
MB95F108AMPFM@LQFP64(*) [(SA739+B259)]
MB95F108AMPFV@LQFP64 [(PEP+S616)]
MB95F108AMPFV@LQFP64(*) [(SA732+B259)]
MB95F108AMWPFM@LQFP64 [(PEP+S680)]
MB95F108AMWPFM@LQFP64(*) [(SA739+B259)]
MB95F108AMWPFV@LQFP64 [(PEP+S616)]
MB95F108AMWPFV@LQFP64(*) [(SA732+B259)]
MB95F108ANSPFM@LQFP64(*) [(SA739+B259)]
MB95F108ANSPFV@LQFP64(*) [(SA732+B259)]

```



```

MB95F108ANWPFM@LQFP64(*) [(SA739+B259)]
MB95F108ANWPFV@LQFP64(*) [(SA732+B259)]
MB95F108ASPFM@LQFP64 [(PEP+S680)]
MB95F108ASPFM@LQFP64(*) [(SA739+B259)]
MB95F108ASPFV@LQFP64 [(PEP+S616)]
MB95F108ASPFV@LQFP64(*) [(SA732+B259)]
MB95F108ATSPFM@LQFP64 [(PEP+S680)]
MB95F108ATSPFM@LQFP64(*) [(SA739+B259)]
MB95F108ATSPFV@LQFP64 [(PEP+S616)]
MB95F108ATSPFV@LQFP64(*) [(SA732+B259)]
MB95F108ATWPFM@LQFP64 [(PEP+S680)]
MB95F108ATWPFM@LQFP64(*) [(SA739+B259)]
MB95F108ATWPFV@LQFP64 [(PEP+S616)]
MB95F108ATWPFV@LQFP64(*) [(SA732+B259)]
MB95F108AWPFM@LQFP64 [(PEP+S680)]
MB95F108AWPFM@LQFP64(*) [(SA739+B259)]
MB95F108AWPFV@LQFP64 [(PEP+S616)]
MB95F108AWPFV@LQFP64(*) [(SA732+B259)]
MB95F108HSPFM@LQFP64 [(PEP+S680)]
MB95F108HSPFM@LQFP64(*) [(SA739+B259)]
MB95F108HSPFV@LQFP64 [(PEP+S616)]
MB95F108HSPFV@LQFP64(*) [(SA732+B259)]
MB95F108HWPFM@LQFP64 [(PEP+S680)]
MB95F108HWPFM@LQFP64(*) [(SA739+B259)]
MB95F108HWPFV@LQFP64 [(PEP+S616)]
MB95F108HWPFV@LQFP64(*) [(SA732+B259)]
MB95F116NAS@LQFP52(*) [(SA740+B267)]
MB95F118AS@LCC48 [(SA248)] MB95F118AS@LQFP52 [(PEP+S673)]
MB95F118AS@LQFP52(*) [(SA740+B267)]
MB95F118AS@TQFP48 [(SA248)] MB95F118AW@LCC48 [(SA248)]
MB95F118AW@LQFP52 [(PEP+S673)]
MB95F118AW@LQFP52(*) [(SA740+B267)]
MB95F118AW@TQFP48 [(SA248)] MB95F118HS@LQFP52 [(PEP+S673)]
MB95F118HS@LQFP52(*) [(SA740+B267)]
MB95F118HW@LQFP52 [(PEP+S673)]
MB95F118HW@LQFP52(*) [(SA740+B267)]
MB95F118MS@LQFP52 [(PEP+S673)]
MB95F118MS@LQFP52(*) [(SA740+B267)]
MB95F118MW@LQFP52 [(PEP+S673)]
MB95F118MW@LQFP52(*) [(SA740+B267)]
MB95F118NS@LQFP52 [(PEP+S673)]
MB95F118NS@LQFP52(*) [(SA740+B267)]
MB95F118NW@LQFP52 [(PEP+S673)]
MB95F118NW@LQFP52(*) [(SA740+B267)]
MB95F118TS@LQFP52 [(PEP+S673)]
MB95F118TS@LQFP52(*) [(SA740+B267)]
MB95F118TW@LQFP52 [(PEP+S673)]
MB95F118TW@LQFP52(*) [(SA740+B267)]
MB95F128D@LQFP100 [(PEP+S604)]
MB95F128D@LQFP100(*) [(SA773+B324)]
MB95F128D@QFP100 [(PEP+S427)]
MB95F128D@QFP100(*) [(SA753+B261)]
MB95F128E@LQFP100 [(PEP+S604)]
MB95F128E@LQFP100(*) [(SA773+B324)]
MB95F128E@QFP100 [(PEP+S427)]
MB95F128E@QFP100(*) [(SA753+B261)]
MB95F128H@LQFP100 [(PEP+S604)]
MB95F128H@LQFP100(*) [(SA773+B324)]
MB95F128H@QFP100 [(PEP+S427)]
MB95F128H@QFP100(*) [(SA753+B261)]
MB95F128J@LQFP100(*) [(SA773+B324)]
MB95F128J@QFP100(*) [(SA753+B261)]
MB95F128M@LQFP100(*) [(SA773+B324)]
MB95F128M@QFP100(*) [(SA753+B261)]
MB95F128N@LQFP100(*) [(SA773+B324)]
MB95F128N@QFP100(*) [(SA753+B261)]
MB95F128T@LQFP100 [(PEP+S604)]
MB95F128T@LQFP100(*) [(SA773+B324)]
MB95F128T@QFP100 [(PEP+S427)]
MB95F128T@QFP100(*) [(SA753+B261)]
MB95F133HBS@SSOP30 [(SA689)] MB95F133HBW@SSOP30 [(SA689)]
MB95F133HS@SOP28 [(SA630)] MB95F133HW@SOP28 [(SA630)]
MB95F133JBS@SSOP30 [(SA689)] MB95F133JBW@SSOP30 [(SA689)]
MB95F133JS@SOP28 [(SA630)] MB95F133JW@SOP28 [(SA630)]
MB95F133MBS@SSOP30 [(SA689)] MB95F133MBW@SSOP30 [(SA689)]
MB95F133MS@SOP28 [(SA630)] MB95F133MW@SOP28 [(SA630)]
MB95F133NBS@SSOP30 [(SA689)] MB95F133NBW@SSOP30 [(SA689)]
MB95F133NS@SOP28 [(SA630)] MB95F133NW@SOP28 [(SA630)]
MB95F133TBS@SSOP30 [(SA689)] MB95F133TBW@SSOP30 [(SA689)]
MB95F133TS@SOP28 [(SA630)] MB95F133TW@SOP28 [(SA630)]
MB95F134HBS@SSOP30 [(SA689)] MB95F134HBW@SSOP30 [(SA689)]

```

MB95F134HS@SOP28 [(SA630)]	MB95F134HW@SOP28 [(SA630)]
MB95F134JBS@SSOP30 [(SA689)]	MB95F134JBW@SSOP30 [(SA689)]
MB95F134JS@SOP28 [(SA630)]	MB95F134JW@SOP28 [(SA630)]
MB95F134MBS@SSOP30 [(SA689)]	MB95F134MBW@SSOP30 [(SA689)]
MB95F134MS@SOP28 [(SA630)]	MB95F134MW@SOP28 [(SA630)]
MB95F134NBS@SSOP30 [(SA689)]	MB95F134NBW@SSOP30 [(SA689)]
MB95F134NS@SOP28 [(SA630)]	MB95F134NW@SOP28 [(SA630)]
MB95F134TBS@SSOP30 [(SA689)]	MB95F134TBW@SSOP30 [(SA689)]
MB95F134TS@SOP28 [(SA630)]	MB95F134TW@SOP28 [(SA630)]
MB95F136HBS@SSOP30 [(SA689)]	MB95F136HBW@SSOP30 [(SA689)]
MB95F136HS@SOP28 [(SA630)]	MB95F136HW@SOP28 [(SA630)]
MB95F136JBS@SSOP30 [(SA689)]	MB95F136JBW@SSOP30 [(SA689)]
MB95F136JS@SOP28 [(SA630)]	MB95F136JW@SOP28 [(SA630)]
MB95F136KBS@SSOP30 [(SA689)]	MB95F136KBW@SSOP30 [(SA689)]
MB95F136KS@SOP28 [(SA630)]	MB95F136KW@SOP28 [(SA630)]
MB95F136MBS@SSOP30 [(SA689)]	MB95F136MBW@SSOP30 [(SA689)]
MB95F136MS@SOP28 [(SA630)]	MB95F136MW@SOP28 [(SA630)]
MB95F136NBS@SSOP30 [(SA689)]	MB95F136NBW@SSOP30 [(SA689)]
MB95F136NS@SOP28 [(SA630)]	MB95F136NW@SOP28 [(SA630)]
MB95F136TBS@SSOP30 [(SA689)]	MB95F136TBW@SSOP30 [(SA689)]
MB95F136TS@SOP28 [(SA630)]	MB95F136TW@SOP28 [(SA630)]
MB95F156MPMC@LQFP52 [(PEP+S673)]	
MB95F156MPMC@LQFP52(*) [(SA740+B304)]	
MB95F156MPMT@LQFP48 [(SA248)]	
MB95F156MPMT@LQFP48(*) [(SA248+B4803)]	
MB95F156NPMC@LQFP52 [(PEP+S673)]	
MB95F156NPMC@LQFP52(*) [(SA740+B304)]	
MB95F156NPMT@LQFP48 [(SA248)]	
MB95F156NPMT@LQFP48(*) [(SA248+B4803)]	
MB95F168JPMC@LQFP64 [(PEP+S680)]	
MB95F168JPMC@LQFP64(*) [(SA739+B288)]	
MB95F168JPMC1@LQFP64 [(PEP+S616)]	
MB95F168JPMC1@LQFP64(*) [(SA732+B288)]	
MB95F168MPMC@LQFP64 [(PEP+S680)]	
MB95F168MPMC@LQFP64(*) [(SA739+B288)]	
MB95F168MPMC1@LQFP64 [(PEP+S616)]	
MB95F168MPMC1@LQFP64(*) [(SA732+B288)]	
MB95F168NPMC@LQFP64 [(PEP+S680)]	
MB95F168NPMC@LQFP64(*) [(SA739+B288)]	
MB95F168NPMC1@LQFP64 [(PEP+S616)]	
MB95F168NPMC1@LQFP64(*) [(SA732+B288)]	
MB95F176JSPMC@LQFP64 [(PEP+S680)]	
MB95F176JSPMC@LQFP64(*) [(SA739+B305)]	
MB95F176JSPMC1@LQFP64 [(PEP+S616)]	
MB95F176JSPMC1@LQFP64(*) [(SA739+B305)]	
MB95F176JWPMC@LQFP64 [(PEP+S680)]	
MB95F176JWPMC@LQFP64(*) [(SA732+B305)]	
MB95F176JWPMC1@LQFP64 [(PEP+S616)]	
MB95F176JWPMC1@LQFP64(*) [(SA732+B305)]	
MB95F188@QFP80 [(PEP+S640B)]	MB95F188J@QFP80 [(PEP+S640B)]
MBL8742H	MBL8742N
MBL8749H	MBL8749N

## GENCORE

### MICROCONTROLLER

GC87C520A0	GC87C520A0@PLCC44 [(SA244)]
GC87C520A0@TQFP44 [(SA245A)]	GC87C520G0
GC87C520G0@PLCC44 [(SA244)]	GC87C520G0@TQFP44 [(SA245A)]

## GENERAL(GI)

### E(E) PROM/FRAM/NVRAM

27256	27C128
27C128@PLCC32 [(SA015A1T)]	27C256
27C256@PLCC32 [(SA015A1T)]	27C512
27C513	27C64
27C64@PLCC32 [(SA015A1T)]	27HC191
27HC291	27HC64
27HC641	27HC641L
27HC64L	28C04
28C04A	28C04F

28C16	28C16A
28C16F	28C17
28C17F	ER5911
ER5911@SOIC8 [(SA602A)]	GI5911
GI5911@SOIC8 [(SA602A)]	GI59C11
GI59C11@SOIC8 [(SA602A)]	GI59C12
GI59C12@SOIC8 [(SA602A)]	GR27C513

## GENERIC

### E(E) PROM/FRAM/NVRAM

27128 (21V)	27128A (12.5V)
2716 (25V)	27256 (12.5V)
2732 (25V)	2732A (21V)
2732B (12.5V)	27512 (12.5V)
27512 (21V)	2764 (21V)
2764A (12.5V)	27C128 (12.5V)
27C128 (21V)	27C16 (25V)
27C256 (12.5V)	27C32 (25V)
27C512 (12.5V)	27C64 (12.5V)
27C64 (21V)	

## GIGADEVICE

### E(E) PROM/FRAM/NVRAM

GD25D40	GD25D40 (ISP) [ISP-HEADER01]
GD25D40@SOP8 [(SA605A)]	GD25D40@SOP8 (ISP) [ISP-HEADER01]
GD25D80	GD25D80 (ISP) [ISP-HEADER01]
GD25D80@SOP8 [(SA605A)]	GD25D80@SOP8 (ISP) [ISP-HEADER01]
GD25F40	GD25F40 (ISP) [ISP-HEADER01]
GD25F40@SOP8 [(SA605A)]	GD25F40@SOP8 (ISP) [ISP-HEADER01]
GD25F80	GD25F80 (ISP) [ISP-HEADER01]
GD25F80@SOP8 [(SA605A)]	GD25F80@SOP8 (ISP) [ISP-HEADER01]
GD25Q16	GD25Q16@SOP8 [(SA023A)]
GD25Q32	GD25Q32@SOP8 [(SA023A)]
GD25Q80	GD25Q80@SOP8 [(SA023A)]
GD25T80	GD25T80 (ISP) [ISP-HEADER01]
GD25T80@SOP8 [(SA605A)]	GD25T80@SOP8 (ISP) [ISP-HEADER01]

## GOAL

### MICROCONTROLLER

VRS1000	VRS1000@PLCC44 [(SA244)]
VRS1000@TQFP44 [(SA245A)]	VRS1050
VRS1050@PLCC44 [(SA244)]	VRS1050@TQFP44 [(SA675)]
VRS1100	VRS1100@PLCC44 [(SA244)]
VRS1100@TQFP44 [(SA245A)]	VRS540
VRS540@PLCC44 [(SA244)]	VRS540@TQFP44 [(SA245A)]
VRS550	VRS550@PLCC44 [(SA244)]
VRS550@TQFP44 [(SA245A)]	VRS560
VRS560@PLCC44 [(SA244)]	VRS560@TQFP44 [(SA245A)]
VRS570	VRS570@PLCC44 [(SA244)]
VRS570@TQFP44 [(SA245A)]	VRS580
VRS580@PLCC44 [(SA244)]	VRS580@TQFP44 [(SA245A)]
VRS700	VRS700@PLCC44 [(SA244)]
VRS700@TQFP44 [(SA245A)]	VRS900
VRS900@PLCC44 [(SA244)]	VRS900@TQFP44 [(SA245A)]

## GOULD

### PLD

PEEL18CV8	PEEL18CV8@PLCC20 [(SA001A)]
PEEL18CV8@SOIC20 [(SA404)]	PEEL18CV8@TSOP20 [(SA026)]

**GREENWICH****E(E) PROM/FRAM/NVRAM**

GR27128	GR27256
GR27512	GR2764

**HAIER****MICROCONTROLLER**

HCM87CP311SP@SDIP42 [(SA028)]	HR6P58P1D1L
HR6P58P1D1L(INTOSC)	HR6P58P1D2L
HR6P58P1D2L(INTOSC)	HR6P58P1RL@SSOP10 [(SA626A)]
HR6P58P1RL@SSOP10(INTOSC) [(SA626A)]	
HR6P58P1S2L@SOP8 [(SA602A)]	
HR6P58P1S2L@SOP8(INTOSC) [(SA602A)]	
HR6P58P1YL@SOP14 [(SA404)]	
HR6P58P1YL@SOP14(INTOSC) [(SA404)]	
HR6P59P2D2HL	HR6P59P2DHL
HR6P59P2DL	HR6P59P2RHL@SSOP10 [(SA626A)]
HR6P59P2S2HL@SOP8 [(SA605A)]	HR6P59P2SHL@SOP14 [(SA404)]
HR6P59P2SL@SOP14 [(SA602)]	HR6P59P2YHL@SOP8 [(SA602A)]
HR6P60P2D2HL	HR6P60P2DL
HR6P60P2DL-A	HR6P60P2EL
HR6P60P2EL-A	HR6P60P2RHL@SSOP20 [(SA626A)]
HR6P60P2S1HL@SOP20 [(SA404)]	HR6P60P2S2HL@SOP18 [(SA404)]
HR6P60P2SL@SOP20 [(SA404)]	HR6P60P2SL@SSOP20 [(SA626A)]
HR6P60P2SL-A@SOP20 [(SA404)]	HR6P60P2SL-A@SSOP20 [(SA626A)]
HR6P60P2XL@SOP18 [(SA404)]	HR6P60P2XL-A@SOP18 [(SA404)]
HR6P60P2YL@SOP14 [(SA404)]	HR6P60P2YL-A@SOP14 [(SA404)]
HR6P62P4D	HR6P62P4DH
HR6P62P4DHL	HR6P62P4DHL(INTOSC)
HR6P62P4DHL-D	HR6P62P4DHL-D(INTOSC)
HR6P62P4NHL(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4NHL@SSOP20 [(SA626A)]	
HR6P62P4NHL-D(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4NHL-D@SSOP20 [(SA626A)]	
HR6P62P4RHL(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4RHL@SSOP20 [(SA626A)]	
HR6P62P4RHL-D(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4RHL-D@SSOP20 [(SA626A)]	HR6P62P4SH@SOP20 [(SA404+B003)]
HR6P62P4SHL(INTOSC)@SOP20 [(SA404)]	
HR6P62P4SHL@SOP20 [(SA404)]	
HR6P62P4SHL-D(INTOSC)@SOP20 [(SA404)]	
HR6P62P4SHL-D@SOP20 [(SA404)]	
HR6P62P4XHL(INTOSC)@SOP18 [(SA404)]	
HR6P62P4XHL@SOP18 [(SA404)]	
HR6P62P4XHL-D(INTOSC)@SOP18 [(SA404)]	
HR6P62P4XHL-D@SOP18 [(SA404)]	HR6P62P4YHL@SOIC14 [(SA602)]
HR6P62P4YHL-D@SOP14 [(SA602)]	HR6P67P4D
HR6P67P4DL	HR6P67P4DL-B
HR6P67P4SL@SOP14 [(SA404+B003)]	
HR6P67P4SL-B@SOP14 [(SA404+B003)]	
HR6P71F8D	HR6P71F8D(REVERSE)
HR6P71F8S(REVERSE)@SOP20 [(SA404)]	
HR6P71F8S@SOP20 [(SA404)]	HR6P72P4D
HR6P72P4DL	HR6P72P4S@SOP28 [(SA404)]
HR6P72P4SL@SOP28 [(SA404+B003)]	HR6P73P8DB
HR6P73P8DBL	HR6P73P8SB@SOP28 [(SA404)]
HR6P73P8SBL@SOP28 [(SA404-B003)]	HR6P73PGD
HR6P73PGDH	HR6P73PGDHL
HR6P73PGS@SOP28 [(SA404+B003)]	HR6P73PGSH@SOP28 [(SA404)]
HR6P73PGSHL@SOP28 [(SA404-B003)]	HR6P76PGD
HR6P76PGDL	HR6P76PGS@SOP28 [(SA404)]
HR6P76PGSL@SOP28 [(SA404-B003)]	HR6P77PGD
HR6P77PGDL	HR6P77PGL@LQFP44 [(SA245-B005)]
HR6P77PGL@LQFP44 [(SA245-B005)]	HR6P78P4SL@SOP32 [(SA715+B006)]
HR6P90FGD	HR6P90FGS@SOP28 [(SA404)]
HR6P90FHD	HR6P90FHS@SOP28 [(SA404)]
HR6P91FGS@SOP32 [(SA715)]	HR6P91FHS@SOP32 [(SA715)]
HR6P92FGD	HR6P92FGL@LQFP44 [(SA245A)]
HR6P92FHD	HR6P92FHL@LQFP44 [(SA245A)]
HR6P95F8D	HR6P95F8S@SOP28 [(SA404)]
HR6P97FGD	HR6P97FGD(EEPROM)

```

HR6P97FGD (EEPROM) (ISP) [ISP-HEADER01]
HR6P97FGD (ISP) [ISP-HEADER01]
HR6P97FGS (EEPROM)@SOP28 [(SA404)]
HR6P97FGS (EEPROM)@SOP28 (ISP) [ISP-HEADER01]
HR6P97FGS@SOP28 [(SA404)]
HR6P97FGS@SOP28 (ISP) [ISP-HEADER01]
HR6P98FGD HR6P98FGD (EEPROM)
HR6P98FGD (EEPROM) (ISP) [ISP-HEADER01]
HR6P98FGD (ISP) [ISP-HEADER01]
HR6P98FGL (EEPROM)@LQFP44 [(SA245A)]
HR6P98FGL (EEPROM)@LQFP44 (ISP) [ISP-HEADER01]
HR6P98FGL@LQFP44 [(SA245A)]
HR6P98FGL@LQFP44 (ISP) [ISP-HEADER01]
HR7T46P8V@SDIP42 [(SA028)] HR7T46PGV@SDIP42 [(SA028+B005)]
HR7T47P8L@LQFP44 [(SA245A)] HR7T47PGL@LQFP44 [(SA245A+B005)]

```

## HARRIS

### BPROM

7610A 7611A

### DRAM & SRAM

HM6516 HM6516@PLCC32 [(SA015A1T)]  
 HM65162 HM65162@PLCC32 [(SA015A1T)]  
 HM65642 HM65642@TSOP28 [(SA643)]

## HITACHI

### E(E)PROM/FRAM/NVRAM

```

HN27128AG HN27128AP
HN27256G HN27256P
HN27512G HN27512P
HN27C101AG HN27C101AP
HN27C101G HN27C101P
HN27C1024HG HN27C1024HG@PLCC44 [(SA244)]
HN27C256AG HN27C256FP
HN27C256G HN27C256HG
HN27C301AG HN27C301AP
HN27C301G HN27C301P
HN27C4000FP HN27C4000G
HN27C4001 HN27C4001@TSOP32 [(SA410T)]
HN27C4001G HN27C4096A
HN27C4096A@PLCC44 [(SA244)] HN27C4096FP
HN27C4096FP@PLCC44 [(SA244)] HN27C4096G
HN27C4096G@PLCC44 [(SA244)] HN27C512G
HN27C512G@PLCC32 [(SA015A1T)] HN27C64G
HN28F101 HN28F101@PLCC32 [(SA015A1T)]
HN28F101@SOP32 [(SA438T)] HN28F101@TSOP32 [(SA410T)]
HN29A128A0A@CSP95 [(SA642A-B066A-Y096N001)]
HN29A128A0A@TSOP48 [(SA247-B005)]
HN29V128A0A@CSP95 [(SA642A-B066A-Y096N001)]
HN29V128A0A@TSOP48 [(SA247-B005)]
HN29V128A0E@CSP95 [(SA642A-B066A-Y096N001)]
HN29V51211@TSOP48 [(SA247-B005)] HN462716G
HN462732G HN48016
HN48016P HN4827128G
HN4827128P HN482732AG
HN482764G HN482764P
HN58064 (FP)@SOIC28 [(SA404)] HN58064 (P)
HN58C1001 (FP)@SSOP32 [(SA438T)] HN58C1001 (P)
HN58C1001 (T)@VSOP32 [(SA620)] HN58C256A (FP)@SOP28 [(SA630)]
HN58C256A (P) HN58C256A (T)@TSOP28 [(SA643)]
HN58C257A (T)@TSOP32 [(SA620)] HN58C65 (FP)@SOIC28 [(SA404)]
HN58C65 (P) HN58C66
HN58C66@SOP28 [(SA630)] HN58C66@TSOP28 [(SA430T)]
HN58V24256 HN58V24256@SOIC8 [(SA602A)]
HN58V24256@TSSOP14 [(SA026)] HN58V24512
HN58V24512@SOIC8 [(SA602A)] HN58V256A
HN58V256A@TSOP28 [(SA430T)] HN58V65A
HN58V65A@SOIC28 [(SA630)] HN58V65A@TSOP28 [(SA430T)]

```

HN58V66A	HN58V66A@SOIC28 [(SA630)]
HN58V66A@TSOP28 [(SA430T)]	HN58W241000
HN58W241000@SOIC8 [(SA602A)]	HN58X2402
HN58X2402@SOIC8 [(SA602A)]	HN58X2402@TSSOP8 [(SA026)]
HN58X2404	HN58X2404@SOIC8 [(SA602A)]
HN58X2404@TSSOP8 [(SA026)]	HN58X2408
HN58X2408@SOIC8 [(SA602A)]	HN58X2408@TSSOP8 [(SA026)]
HN58X24128	HN58X24128@SOIC8 [(SA602A)]
HN58X2416	HN58X2416@SOIC8 [(SA602A)]
HN58X2416@TSSOP8 [(SA026)]	HN58X24256
HN58X24256@SOIC8 [(SA602A)]	HN58X2432
HN58X2432@SOIC8 [(SA602A)]	HN58X2432@TSSOP8 [(SA026)]
HN58X24512	HN58X24512@SOIC8 [(SA602A)]
HN58X2464	HN58X2464@SOIC8 [(SA602A)]
HN58X2464@TSSOP8 [(SA026)]	HN58X2502@SOIC8 [(SA602A)]
HN58X2502@TSSOP8 [(SA026)]	HN58X2504@SOIC8 [(SA602A)]
HN58X2504@TSSOP8 [(SA026)]	HN58X25128@SOIC8 [(SA602A)]
HN58X25128@TSSOP14 [(SA026)]	HN58X25256@SOIC8 [(SA602A)]
HN58X25256@TSSOP14 [(SA026)]	HN58X2532@SOIC8 [(SA602A)]
HN58X2532@TSSOP8 [(SA026)]	HN58X2564@SOIC8 [(SA602A)]
HN58X2564@TSSOP8 [(SA026)]	HT29VB800@TSOP48 [(SA247-B005)]
HT29VT800@TSOP48 [(SA247-B005)]	HT29WB800@TSOP48 [(SA247-B005)]
HT29WT800@TSOP48 [(SA247-B005)]	
V128128A0E@CSP95 [(SA642A-B105A-Y096N001)]	

**DRAM & SRAM**

HM6116	HM6116@PLCC32 [(SA015A1T)]
HM6116A	HM6116A@PLCC32 [(SA015A1T)]
HM6208	HM6208@SOJ24 [(SA646)]
HM6208H	HM6208H@SOJ24 [(SA646)]
HM62256	HM62256@TSOP28 [(SA643)]
HM62256B	HM62256B@TSOP28 [(SA643)]
HM624256	HM624256@SOJ28 [(SA646)]
HM6264A	HM6264A@TSOP28 [(SA643)]
HM6267	HM6268
HM628128	HM628128@TSOP32 [(SA410T)]
HM628128A	HM628128A@TSOP32 [(SA410T)]
HM62832	HM62832@TSOP28 [(SA643)]
HM62832H	HM62832H@TSOP28 [(SA643)]
HM628512	HM628512@TSOP32 [(SA729)]
HM6287	HM6287HP
HM6288	HM6288@SOJ22 [(SA646)]
HM65256B	HM65256B@TSOP28 [(SA643)]
HM658128	HM658128@TSOP32 [(SA410T)]
HM66204	HM66204@TSOP32 [(SA410T)]
HM6707	HM6707@SOJ24 [(SA646)]
HM6707A	HM6707A@SOJ24 [(SA646)]
HM6708	HM6708@SOJ24 [(SA646)]
HM6708A	HM6708A@SOJ24 [(SA646)]
HM6716	HM6716@PLCC32 [(SA015A1T)]
HM6787	HM6787HP
HM6788	HM6788@SOJ22 [(SA646)]
HM6788H	HM6788H@SOJ22 [(SA646)]
HM6788HA	HM6788HA@SOJ22 [(SA646)]

**MICROCONTROLLER**

HD4074344@SDIP28 [(SA022A)]	HD4074344@SOIC28 [(SA404)]
HD4074394@SDIP28 [(SA022A)]	HD4074394@SOIC28 [(SA404)]
HD63701V0C	HD63701V0P
HD63701X0C@SDIP64 (*) [(SA752+B265)]	
HD63701X0P@SDIP64 (*) [(SA752+B265)]	HD63701Y0C
HD63701Y0	
HD63701Y0C@SDIP64 (*) [(SA752+B265)]	
HD63701Y0P@SDIP64 (*) [(SA752+B265)]	HD637A01V0P
HD637A01V0C	
HD637A01X0C@SDIP64 (*) [(SA752+B265)]	
HD637A01X0P@SDIP64 (*) [(SA752+B265)]	
HD637A01Y0C@SDIP64 (*) [(SA752+B265)]	
HD637A01Y0P@SDIP64 (*) [(SA752+B265)]	HD637B01V0P
HD637B01V0C	
HD637B01X0C@SDIP64 (*) [(SA752+B265)]	
HD637B01X0P@SDIP64 (*) [(SA752+B265)]	
HD637B01Y0C@SDIP64 (*) [(SA752+B265)]	
HD637B01Y0P@SDIP64 (*) [(SA752+B265)]	
HD6472357F@PQFP128 (*) [(SA720+B262)]	
HD6472655F@PQFP128 (*) [(SA720+B175)]	

HD6472655TE@TQFP128(\*) [(SA721+B174)]  
 HD6472655VF@PQFP128(\*) [(SA720+B175)]  
 HD6472655VTE@TQFP128(\*) [(SA721+B174)]  
 HD6473228P@SDIP64(\*) [(SA736-B229)]  
 HD6473238P@SDIP64(\*) [(SA736-B229)]  
 HD6473258P@SDIP64(\*) [(SA736-B229)]  
 HD6473308@PLCC84(\*) [(SA649-B8406)]  
 HD6473644@TQFP64 [(PEP+S621)]  
 HD64738024F(FP-80B)(\*) [(TA006-B006)]  
 HD64738024H(FP-80A)(\*) [(TA008-B006)]  
 HD64738024W(TFP-80C)(\*) [(TA007-B006)]  
 HD6473877H@TQFP100(\*) [(SA718+B202)]  
 HD6475328@PLCC84(\*) [(SA649-B8404)]  
 HD6475348@PLCC84(\*) [(SA649-B8404)]  
 HD6477034F@QFP112(\*) [(SA738+B213)]  
 HD64F2110BFA@QFP100 [(SA718-B299)]  
 HD64F2110BTE@QFP100 [(SA718-B299)]  
 HD64F2110BVFA@QFP100 [(SA718-B299)]  
 HD64F2110BVTE@QFP100 [(SA718-B299)]  
 HD64F2132RFA@QFP80 [(PEP+S615B)] HD64F2132RTF@QFP80 [(PEP+S640B)]  
 HD64F2132RVFA@QFP80 [(PEP+S615B)]  
 HD64F2132RVTF@QFP80 [(PEP+S640B)]  
 HD64F2138AFA@TQFP80 [(PEP+S615B)]  
 HD64F2138ATF@TQFP80 [(PEP+S640B)]  
 HD64F2140BVFA@TQFP100 [(PEP+S604)]  
 HD64F2140BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2140BVTE@TQFP100 [(PEP+S604)]  
 HD64F2140BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2141BVFA@TQFP100 [(PEP+S604)]  
 HD64F2141BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2141BVTE@TQFP100 [(PEP+S604)]  
 HD64F2141BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RFA@TQFP100 [(PEP+S604)]  
 HD64F2142RFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RTE@TQFP100 [(PEP+S604)]  
 HD64F2142RTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RVFA@TQFP100 [(PEP+S604)]  
 HD64F2142RVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RVTE@TQFP100 [(PEP+S604)]  
 HD64F2142RVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144AFA@TQFP100 [(PEP+S604)]  
 HD64F2144AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144ATE@TQFP100 [(PEP+S604)]  
 HD64F2144ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144AVFA@TQFP100 [(PEP+S604)]  
 HD64F2144AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144AVTE@TQFP100 [(PEP+S604)]  
 HD64F2144AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144FA@TQFP100 [(PEP+S604)]  
 HD64F2144FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144TE@TQFP100 [(PEP+S604)]  
 HD64F2144TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144VFA@TQFP100 [(PEP+S604)]  
 HD64F2144VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144VTE@TQFP100 [(PEP+S604)]  
 HD64F2144VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2145BVFA@TQFP100 [(PEP+S604)]  
 HD64F2145BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2145BVTE@TQFP100 [(PEP+S604)]  
 HD64F2145BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147AFA@TQFP100 [(PEP+S604)]  
 HD64F2147AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147ATE@TQFP100 [(PEP+S604)]  
 HD64F2147ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147AVFA@TQFP100 [(PEP+S604)]  
 HD64F2147AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147AVTE@TQFP100 [(PEP+S604)]  
 HD64F2147AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147NFA@TQFP100 [(PEP+S604)]  
 HD64F2147NFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147NTE@TQFP100 [(PEP+S604)]  
 HD64F2147NTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147NVFA@TQFP100 [(PEP+S604)]  
 HD64F2147NVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147NVTE@TQFP100 [(PEP+S604)]  
 HD64F2147NVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2148AFA@TQFP100 [(PEP+S604)]  
 HD64F2148AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2148ATE@TQFP100 [(PEP+S604)]  
 HD64F2148ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2148AVFA@TQFP100 [(PEP+S604)]

HD64F2148AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVTE@TQFP100 [(PEP+S604)]  
HD64F2148AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BFA@TQFP100 [(PEP+S604)]  
HD64F2148BFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BTE@TQFP100 [(PEP+S604)]  
HD64F2148BTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVFA@TQFP100 [(PEP+S604)]  
HD64F2148BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVTE@TQFP100 [(PEP+S604)]  
HD64F2148BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148FA@TQFP100 [(PEP+S604)]  
HD64F2148FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148TE@TQFP100 [(PEP+S604)]  
HD64F2148TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VFA@TQFP100 [(PEP+S604)]  
HD64F2148VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VTE@TQFP100 [(PEP+S604)]  
HD64F2148VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YFA@TQFP100 [(PEP+S604)]  
HD64F2149YFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YTE@TQFP100 [(PEP+S604)]  
HD64F2149YTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2166VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2167VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2168VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2177VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2265FA13@TQFP100 [(PEP+S604)]  
HD64F2265FA20@TQFP100 [(PEP+S604)]  
HD64F2265TE13@TQFP100 [(PEP+S604)]  
HD64F2265TE20@TQFP100 [(PEP+S604)]  
HD64F2265TF13@TQFP100 [(PEP+S604)]  
HD64F2265TF20@TQFP100 [(PEP+S604)]  
HD64F2266FA13@TQFP100 [(PEP+S604)]  
HD64F2266FA20@TQFP100 [(PEP+S604)]  
HD64F2266TE13@TQFP100 [(PEP+S604)]  
HD64F2266TE20@TQFP100 [(PEP+S604)]  
HD64F2266TF13@TQFP100 [(PEP+S604)]  
HD64F2266TF20@TQFP100 [(PEP+S604)]  
HD64F2268FA13@TQFP100 [(PEP+S604)]  
HD64F2268FA20@TQFP100 [(PEP+S604)]  
HD64F2268TE13@TQFP100 [(PEP+S604)]  
HD64F2268TE20@TQFP100 [(PEP+S604)]  
HD64F2268TF13@TQFP100 [(PEP+S604)]  
HD64F2268TF20@TQFP100 [(PEP+S604)]  
HD64F2280@PQFP100(\*) [(TA046-B006)]  
HD64F2282@PQFP100(\*) [(TA046-B006)]  
HD64F2326VF@PQFP128(\*) [(SA720+B281)]  
HD64F2326VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2328BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328VF@PQFP128(\*) [(SA720+B281)]  
HD64F2328VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329EVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329EVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329VF@PQFP128(\*) [(SA720+B281)]  
HD64F2329VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2338VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339EVF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2357F@PQFP128(\*) [(SA720+B193A)]  
HD64F2357TE@QFP120(\*) [(SA721+B194)]  
HD64F2377@TQFP144(\*) [(SA681-B14408)]  
HD64F2377R@TQFP144(\*) [(SA681-B14408)]  
HD64F2398F@PQFP128(\*) [(SA720+B193B)]  
HD64F2398TE@QFP120(\*) [(SA721+B194)]  
HD64F2505FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2506FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2551FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2552FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2556FC20@QFP144(\*) [(SA681+B14403)]  
HD64F2612FA20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F24@TQFP80(\*) [(SA722+B176)]  
HD64F2646RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2648RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2649FC20@QFP144(\*) [(SA681+B14404)]  
HD64F2667VFC33@QFP144(\*) [(SA681+B14402)]  
HD64F3024F@TQFP100(\*) [(TA029-B006)]



HD64F3024FP@PQFP100(\*) [(TA030-B006)]  
 HD64F3024TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3026F@TQFP100(\*) [(TA029-B006)]  
 HD64F3026FP@PQFP100(\*) [(TA030-B006)]  
 HD64F3026TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3048BF@TQFP100(\*) [(TA029-B006)]  
 HD64F3048BTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3048BVF@TQFP100(\*) [(TA029-B006)]  
 HD64F3048BVTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3048F@TQFP100(\*) [(TA067+B006)]  
 HD64F3048TF@TQFP100(\*) [(TA067+B006)]  
 HD64F3048VVF@TQFP100(\*) [(TA067+B006)]  
 HD64F3048VTF@TQFP100(\*) [(TA067+B006)]  
 HD64F3052BF@TQFP100(\*) [(TA029-B006)]  
 HD64F3052BTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3052BVF@TQFP100(\*) [(TA029-B006)]  
 HD64F3052BVTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3052F@TQFP100(\*) [(TA029-B006)]  
 HD64F3052TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3062BF@TQFP100(\*) [(TA029-B006)]  
 HD64F3062BFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3062BTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3062F@TQFP100(\*) [(TA029-B006)]  
 HD64F3062FF@PQFP100(\*) [(TA030-B006)]  
 HD64F3062RF@TQFP100(\*) [(TA029-B006)]  
 HD64F3062RFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3062RTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3062RVF@TQFP100(\*) [(TA029-B006)]  
 HD64F3062RVFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3062RVTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3062TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3064BF@TQFP100(\*) [(TA029-B006)]  
 HD64F3064BFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3064BTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3064F@TQFP100(\*) [(TA029-B006)]  
 HD64F3064FF@PQFP100(\*) [(TA030-B006)]  
 HD64F3064TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3067F@TQFP100(\*) [(TA029-B006)]  
 HD64F3067FP@PQFP100(\*) [(TA030-B006)]  
 HD64F3067RF@TQFP100(\*) [(TA029-B006)]  
 HD64F3067RFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3067RTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3067RVF@TQFP100(\*) [(TA029-B006)]  
 HD64F3067RVFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3067RVTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3067TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3068F@TQFP100(\*) [(TA029-B006)]  
 HD64F3068TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3069F@TQFP100(\*) [(SA718+B271)]  
 HD64F3069RF@TQFP100(\*) [(SA718+B271)]  
 HD64F3069RTE@TQFP100(\*) [(SA718+B271)]  
 HD64F3069TE@TQFP100(\*) [(SA718+B271)]  
 HD64F3334YCP16@PLCC84(\*) [(SA649-B8402)]  
 HD64F3334YF16@TQFP80(\*) [(TA018-B006)]  
 HD64F3334YFLH16@TQFP80(\*) [(TA018-B006)]  
 HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3337YCP16@PLCC84(\*) [(SA649-B8402)]  
 HD64F3337YF16@TQFP80(\*) [(TA018-B006)]  
 HD64F3337YFLH16@TQFP80(\*) [(TA018-B006)]  
 HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3394YCP16@PLCC84(\*) [(SA649-B8402)]  
 HD64F3394YF16@TQFP80(\*) [(TA018-B006)]  
 HD64F3394YFLH16@TQFP80(\*) [(TA018-B006)]  
 HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3397CP17@PLCC84(\*) [(SA649-B8402)]  
 HD64F3397F17@TQFP80(\*) [(TA018-B006)]  
 HD64F3397FLH17@TQFP80(\*) [(TA018-B006)]  
 HD64F3397TF17@TQFP80(\*) [(TA019-B006)]  
 HD64F3397TFLH17@TQFP80(\*) [(TA019-B006)]  
 HD64F3434F@QFP100(\*) [(SA718+B306)]  
 HD64F3434TF@QFP100(\*) [(SA718+B306)]  
 HD64F3437F@QFP100(\*) [(SA718+B306)]  
 HD64F3437TF@QFP100(\*) [(SA718+B306)]  
 HD64F36012FX@TQFP48 [(SA671)] HD64F36012FY@TQFP48 [(SA248)]  
 HD64F36012GFP@TQFP64 [(SA732+B313)]  
 HD64F36012GFX@TQFP48 [(SA671)] HD64F36012GFY@TQFP48 [(SA248)]  
 HD64F36014FX@TQFP48 [(SA671)] HD64F36014FY@TQFP48 [(SA248)]  
 HD64F36014GFP@TQFP64 [(SA732+B313)]

HD64F36014GFX@TQFP48 [(SA671)] HD64F36014GFY@TQFP48 [(SA248)]  
 HD64F36022FX@TQFP48 [(SA671)] HD64F36022FY@TQFP48 [(SA248)]  
 HD64F36022GFP@TQFP64 [(SA732+B313)]  
 HD64F36022GFZ@TQFP48 [(SA671)] HD64F36022GFY@TQFP48 [(SA248)]  
 HD64F36024FX@TQFP48 [(SA671)] HD64F36024FY@TQFP48 [(SA248)]  
 HD64F36024GFP@TQFP64 [(SA732+B313)]  
 HD64F36024GFZ@TQFP48 [(SA671)] HD64F36024GFY@TQFP48 [(SA248)]  
 HD64F36034FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36034GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36034GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36034H@TQFP64(\*) [(TA042-B006)]  
 HD64F36037FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36037GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36037GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36037H@TQFP64(\*) [(TA042-B006)]  
 HD64F36054FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36054GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36054GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36054H@TQFP64(\*) [(TA042-B006)]  
 HD64F36057FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36057GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36057GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36057H@TQFP64(\*) [(TA042-B006)]  
 HD64F36064GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F36064GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36074GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36074GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36074GH@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36074LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36074LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36074LHZW@QFP64(\*) [(SA732-B235)]  
 HD64F36077GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36077GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36077GH@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36077LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36077LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36077LHZW@QFP64(\*) [(SA732-B235)]  
 HD64F36078GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36078GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36078GH@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36078LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36078LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36078LHZW@QFP64(\*) [(SA732-B235)]  
 HD64F36079GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36079GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36079GH@QFP64(\*) [(SA757-B235)]  
 HD64F36079GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36079GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36079GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36079GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36079LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36079LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36079LHZW@QFP64(\*) [(SA732-B235)]

```

HD64F36087FP@LQFP64(*) [(SA732-B235)]
HD64F36087H@QFP64(*) [(SA757-B235)]
HD64F3642AH@QFP64(*) [(SA668+B275)]
HD64F3642AP@SDIP64(*) [(SA736+B274)]
HD64F3642AW@QFP80(*) [(SA731+B276)]
HD64F3643H@QFP64(*) [(SA668+B275)]
HD64F3643P@SDIP64(*) [(SA736+B274)]
HD64F3643W@QFP80(*) [(SA731+B276)]
HD64F3644H@QFP64(*) [(SA668+B275)]
HD64F3644P@SDIP64(*) [(SA736+B274)]
HD64F3644W@QFP80(*) [(SA731+B276)]
HD64F3664BP@SDIP42 [(SA028)] HD64F3664FP@TQFP64 [(PEP+S616)]
HD64F3664FP@TQFP64(*) [(SA732+B224)]
HD64F3664FX@TQFP48 [(SA671)] HD64F3664FY@TQFP48 [(SA248)]
HD64F3664H@TQFP64 [(PEP+S621)] HD64F3684FP@TQFP64 [(PEP+S616)]
HD64F3684FP@TQFP64(*) [(TA043-B006)]
HD64F3684GFP@TQFP64 [(PEP+S616)]
HD64F3684GFP@TQFP64(*) [(TA043-B006)]
HD64F3684GH@TQFP64 [(PEP+S621)]
HD64F3684GH@TQFP64(*) [(TA042-B006)]
HD64F3684H@TQFP64 [(PEP+S621)]
HD64F3684H@TQFP64(*) [(TA042-B006)]
HD64F3687FP@TQFP64 [(PEP+S616)]
HD64F3687FP@TQFP64(*) [(TA043-B006)]
HD64F3687GFP@TQFP64 [(PEP+S616)]
HD64F3687GFP@TQFP64(*) [(TA043-B006)]
HD64F3687GH@TQFP64 [(PEP+S621)]
HD64F3687GH@TQFP64(*) [(TA042-B006)]
HD64F3687H@TQFP64 [(PEP+S621)]
HD64F3687H@TQFP64(*) [(TA042-B006)]
HD64F36902G@LQFP32 [(SA663)] HD64F36902G@SOP32 [(SA682)]
HD64F36912G@LQFP32 [(SA663)] HD64F36912G@SOP32 [(SA682)]
HD64F3694FP@TQFP64 [(PEP+S616)] HD64F3694FX@TQFP48 [(SA671)]
HD64F3694FY@TQFP48 [(SA248)] HD64F3694GFP@TQFP64 [(PEP+S616)]
HD64F3694GFY@TQFP48 [(SA671)] HD64F3694GFY@TQFP48 [(SA248)]
HD64F3694GH@TQFP64 [(PEP+S621)] HD64F3694H@TQFP64 [(PEP+S621)]
HD64F38002FPA@TQFP64 [(PEP+S625A)]
HD64F38002FPE@TQFP64 [(PEP+S616)]
HD64F38004FPA@TQFP64 [(PEP+S625A)]
HD64F38004FPE@TQFP64 [(PEP+S616)]
HD64F38024F(FP-80B)@PQFP80 [(PEP+S611A)]
HD64F38024F(FP-80B)@PQFP80(*) [(TA003-B006)]
HD64F38024H(FP-80A)@TQFP80 [(PEP+S615B)]
HD64F38024H(FP-80A)@TQFP80(*) [(TA005-B006)]
HD64F38024RF(FP-80B)@PQFP80 [(PEP+S611A)]
HD64F38024RF(FP-80B)@PQFP80(*) [(TA003-B006)]
HD64F38024RH(FP-80A)@TQFP80 [(PEP+S615B)]
HD64F38024RH(FP-80A)@TQFP80(*) [(TA005-B006)]
HD64F38024RW(TFP-80C)@TQFP80 [(PEP+S640B)]
HD64F38024RW(TFP-80C)@TQFP80(*) [(TA004-B006)]
HD64F38024W(TFP-80C)@TQFP80 [(PEP+S640B)]
HD64F38024W(TFP-80C)@TQFP80(*) [(TA004-B006)]
HD64F38102FPA@TQFP64 [(PEP+S625A)]
HD64F38102FPE@TQFP64 [(PEP+S616)]
HD64F38104FPA@TQFP64 [(PEP+S625A)]
HD64F38104FPE@TQFP64 [(PEP+S616)]
HD64F38124F(FP-80B)@PQFP80 [(PEP+S611A)]
HD64F38124F(FP-80B)@PQFP80(*) [(TA003-B006)]
HD64F38124H(FP-80A)@TQFP80 [(PEP+S615B)]
HD64F38124H(FP-80A)@TQFP80(*) [(TA005-B006)]
HD64F38124W(TFP-80C)@TQFP80 [(PEP+S640B)]
HD64F38124W(TFP-80C)@TQFP80(*) [(TA004-B006)]
HD64F39802G@SDIP32 [(SA653)]
HD64F7044F@QFP112(*) [(SA755+B278)]
HD64F7046F@QFP80(*) [(TA014+B006)]
HD64F7047@QFP100(*) [(SA718+B172)]
R4F2463VTE34DV@TQFP144(*) [(SA748-B14419)]
R4F2463VTE34V@TQFP144(*) [(SA748-B14419)]

```

## HOLTEK

### E(E) PROM/FRAM/NVRAM

```

HT24C01 HT24C01@SOIC8 [(SA602A)]
HT24C02 HT24C02@SOIC8 [(SA602A)]
HT24C04 HT24C04@SOIC8 [(SA602A)]
HT24C08 HT24C16

```

HT24LC01		HT24LC01@SOIC8 [(SA602A)]
HT24LC01@TSSOP8 [(SA026)]		HT24LC02
HT24LC02@SOIC8 [(SA602A)]		HT24LC02@TSSOP8 [(SA026)]
HT24LC04		HT24LC04@SOIC8 [(SA602A)]
HT24LC08		HT24LC08@SOIC8 [(SA602A)]
HT24LC16		HT24LC16@SOIC8 [(SA602A)]
HT24LC32		HT24LC32@SOIC8 [(SA602A)]
HT24LC64		HT24LC64@SOIC8 [(SA602A)]
HT25LC512@SOIC8 [(SA602A)]		HT27C010
HT27C010@PLCC32 [(SA015A1T)]		HT27C010@TSOP32 [(SA410T)]
HT27C020		HT27C020@PLCC32 [(SA015A1T)]
HT27C020@TSOP32 [(SA410T)]		HT27C040
HT27C040@PLCC32 [(SA015A1T)]		HT27C040@TSOP32 [(SA410T)]
HT27C4096		HT27C4096@PLCC44 [(SA244)]
HT27C512		HT27C512@PLCC32 [(SA015A1T)]
HT27C512@TSOP28 [(SA430T)]		HT27LC010
HT27LC010@PLCC32 [(SA015A1T)]		HT27LC010@TSOP32 [(SA410T)]
HT27LC020		HT27LC020@PLCC32 [(SA015A1T)]
HT27LC020@TSOP32 [(SA410T)]		HT27LC040
HT27LC040@PLCC32 [(SA015A1T)]		HT27LC040@TSOP32 [(SA410T)]
HT27LC4096		HT27LC4096@PLCC44 [(SA244)]
HT27LC512		HT27LC512@PLCC32 [(SA015A1T)]
HT27LC512@TSOP28 [(SA430T)]		HT93C46(16bit)
HT93C46(16bit)@SOP8-A [(SA602A)]		HT93C46(16bit)@SOP8-B [(SA602A)]
HT93C46(16bit)@TSSOP8 [(SA026)]		HT93C56(16bit)
HT93C56(16bit)@SOP8-A [(SA602A)]		HT93C56(16bit)@SOP8-B [(SA602A)]
HT93C56(16bit)@TSSOP8 [(SA026)]		HT93C66(16bit)
HT93C66(16bit)@SOP8-A [(SA602A)]		HT93C66(16bit)@SOP8-B [(SA602A)]
HT93C66(16bit)@TSSOP8 [(SA026)]		HT93LC46A(08bit)
HT93LC46A(08bit)@SOP8-A [(SA602A)]		
HT93LC46A(08bit)@SOP8-B [(SA602A)]		
HT93LC46A(08bit)@TSSOP8 [(SA026)]		
HT93LC46A(16bit)		
HT93LC46A(16bit)@SOP8-A [(SA602A)]		
HT93LC46A(16bit)@SOP8-B [(SA602A)]		
HT93LC46A(16bit)@TSSOP8 [(SA026)]		
HT93LC46B(08bit)		
HT93LC46B(08bit)@SOP8-A [(SA602A)]		
HT93LC46B(08bit)@SOP8-B [(SA602A)]		
HT93LC46B(08bit)@TSSOP8 [(SA026)]		
HT93LC46B(16bit)		
HT93LC46B(16bit)@SOP8-A [(SA602A)]		
HT93LC46B(16bit)@SOP8-B [(SA602A)]		
HT93LC46B(16bit)@TSSOP8 [(SA026)]		
HT93LC56A(08bit)		
HT93LC56A(08bit)@SOP8-A [(SA602A)]		
HT93LC56A(08bit)@SOP8-B [(SA602A)]		
HT93LC56A(08bit)@TSSOP8 [(SA026)]		
HT93LC56A(16bit)		
HT93LC56A(16bit)@SOP8-A [(SA602A)]		
HT93LC56A(16bit)@SOP8-B [(SA602A)]		
HT93LC56A(16bit)@TSSOP8 [(SA026)]		
HT93LC56B(08bit)		
HT93LC56B(08bit)@SOP8-A [(SA602A)]		
HT93LC56B(08bit)@SOP8-B [(SA026)]		
HT93LC56B(08bit)@TSSOP8 [(SA026)]		
HT93LC56B(16bit)		
HT93LC56B(16bit)@SOP8-A [(SA602A)]		
HT93LC56B(16bit)@SOP8-B [(SA602A)]		
HT93LC56B(16bit)@TSSOP8 [(SA026)]		
HT93LC66A(08bit)		
HT93LC66A(08bit)@SOP8-A [(SA602A)]		
HT93LC66A(08bit)@SOP8-B [(SA602A)]		
HT93LC66A(08bit)@TSSOP8 [(SA026)]		
HT93LC66A(16bit)		
HT93LC66A(16bit)@SOP8-A [(SA602A)]		
HT93LC66A(16bit)@SOP8-B [(SA602A)]		
HT93LC66A(16bit)@TSSOP8 [(SA026)]		
HT93LC66B(08bit)		
HT93LC66B(08bit)@SOP8-A [(SA602A)]		
HT93LC66B(08bit)@SOP8-B [(SA026)]		
HT93LC66B(08bit)@TSSOP8 [(SA026)]		
HT93LC66B(16bit)		
HT93LC66B(16bit)@SOP8-A [(SA602A)]		
HT93LC66B(16bit)@SOP8-B [(SA602A)]		
HT93LC66B(16bit)@TSSOP8 [(SA026)]		
HT93LC76(08bit)		
HT93LC76(08bit)@SOP8-A [(SA602A)]		
HT93LC76(08bit)@SOP8-B [(SA602A)]		
HT93LC76(08bit)@TSSOP8 [(SA026)]		HT93LC76(16bit)
HT93LC76(16bit)@SOP8-A [(SA602A)]		

```

HT93LC76(16bit)@SOP8-B [(SA602A)]
HT93LC76(16bit)@TSSOP8 [(SA026)] HT93LC86(08bit)
HT93LC86(08bit)@SOP8-A [(SA602A)]
HT93LC86(08bit)@SOP8-B [(SA602A)]
HT93LC86(08bit)@TSSOP8 [(SA026)] HT93LC86(16bit)
HT93LC86(16bit)@SOP8-A [(SA602A)]
HT93LC86(16bit)@SOP8-B [(SA602A)]
HT93LC86(16bit)@TSSOP8 [(SA026)]

```

## MICROCONTROLLER

```

HT46R22 HT46R22@SOP24 [(SA404)]
HT46R23(dip24) HT46R23(dip28)
HT46R23@SOP24 [(SA404)] HT46R23@SOP28 [(SA404)]
HT46R24 HT46R24@SOP28 [(SA404)]
HT46R24@SSOP48 [(SA669)] HT46R46(dip18)
HT46R46(dip20) HT46R46@SOP18 [(SA404)]
HT46R46@SOP20 [(SA404)] HT46R46E(dip18)
HT46R46E@SOP18 [(SA404)] HT46R46-H
HT46R46-H@SOP18 [(SA404)] HT46R47(dip18)
HT46R47(dip20) HT46R47@SOP18 [(SA404)]
HT46R47@SOP20 [(SA404)] HT46R47@SSOP20 [(SA674)]
HT46R47E(dip18) HT46R47E@SOP18 [(SA404)]
HT46R47-H HT46R47-H@SOP18 [(SA404)]
HT46R48(dip20) HT46R48(dip24)
HT46R48@SOP20 [(SA404)] HT46R48@SOP24 [(SA404)]
HT46R48@SSOP24 [(SA674)] HT46R48E(dip24)
HT46R48E@SOP24 [(SA404)] HT46R48E@SSOP24 [(SA674)]
HT46R51A(dip18) HT46R51A@SOP20 [(SA404)]
HT46R51A@SSOP20 [(SA674)] HT46R52A(dip18)
HT46R52A@SOP20 [(SA404)] HT46R52A@SSOP20 [(SA674)]
HT46R53A(dip28) HT46R53A@SOP28 [(SA404)]
HT46R54A(dip28) HT46R54A@SOP28 [(SA404)]
HT46R62@SSOP56 [(SA669)] HT46R63@PQFP100 [(PEP+S427)]
HT46R63@SSOP56 [(SA669)] HT46R64@PQFP100 [(PEP+S427)]
HT46R64@SSOP56 [(SA669)] HT46R65@PQFP100 [(PEP+S427)]
HT46R65@SSOP56 [(SA669)] HT46R71D@SSOP48 [(SA669)]
HT46RB70 HT46RB70@SOP28 [(SA404)]
HT46RB70@SSOP48 [(SA669)] HT46RU22(dip24)
HT46RU22@SOP24 [(SA404)] HT46RU22@SSOP24 [(SA674)]
HT47R10A@QFP44 [(SA245)] HT48R05A
HT48R05A@SOP16 [(SA026)] HT48R05A@SOP18 [(SA404)]
HT48R06A HT48R06A@SOP16 [(SA026)]
HT48R06A@SOP18 [(SA404)] HT48R07A
HT48R07A@SOP24 [(SA404)] HT48R07A@SSOP24 [(SA674)]
HT48R08A HT48R08A@SOP16 [(SA026)]
HT48R08A@SOP18 [(SA404)] HT48R09A
HT48R09A@SOP24 [(SA404)] HT48R09A@SSOP24 [(SA674)]
HT48R10A HT48R10A@SOP24 [(SA404)]
HT48R30A(dip24) HT48R30A(dip28)
HT48R30A@SOP24 [(SA404)] HT48R30A@SOP28 [(SA404)]
HT48R50A HT48R50A@SOP28 [(SA404)]
HT48R50A@SSOP48 [(SA669)] HT48R52A@QFP44 [(SA245A)]
HT48R70A@PQFP64 [(PEP+S618)] HT48R70A@SSOP48 [(SA669)]
HT48RA0-1 HT48RA0-1@SOP24 [(SA404)]
HT48RA0-2 HT48RA0-2@SOP20 [(SA404)]
HT48RA0-2@SSOP20 [(SA674)] HT48RA0-3
HT48RA0-3@SOP20 [(SA404)] HT48RA1@SOP28 [(SA404)]
HT48RA1@SSOP28 [(SA626A)] HT48RA3(dip28)
HT48RA3@SOP28 [(SA404)] HT48RA3@SSOP28 [(SA626A)]
HT48RA5(dip28) HT48RA5@SOP28 [(SA404)]
HT48RA5@SSOP28 [(SA626A)] HT48RB50
HT48RB50@SOP28 [(SA404)] HT48RB50@SSOP48 [(SA669)]
HT48RB8@SOP28 [(SA404)] HT48RB8@SSOP48 [(SA669)]
HT49R30A@SSOP48 [(SA669)] HT49R50A@SSOP48 [(SA669)]
HT49RV5@SSOP56 [(SA669)] HT49RV7@PQFP100 [(PEP+S427)]
HT82A821R@SOP24 [(SA404)] HT82A821R@SSOP24 [(SA674)]
HT82A822R@SSOP48 [(SA669)] HT82A832R@QFP48 [(SA248)]
HT82A832R@SSOP48 [(SA669)] HT82K68E
HT82K68E@SOP20 [(SA404)] HT82K68E@SOP28 [(SA404)]
HT82K68E@SSOP48 [(SA669)] HT82K94E@SSOP48 [(SA669)]
HT82K95E@SOP20 [(SA404)] HT82K95E@SOP28 [(SA404)]
HT82K95E@SSOP48 [(SA669)] HT82K96E(dip20)
HT82K96E(dip40) HT82K96E@SOP20 [(SA404)]
HT82K96E@SOP28 [(SA404)] HT82K96E@SSOP48 [(SA669)]
HT82M99E(dip18) HT82M99E(dip20)
HT82M99E@SOP18 [(SA404)] HT82M99E@SOP20 [(SA404)]
HT82M9AE@SOP20 [(SA404)] HT82M9AE@SOP24 [(SA404)]
HT82M9AE@SSOP20 [(SA674)] HT82M9AE@SSOP24 [(SA674)]

```

HT82M9BE@SOP24 [(SA404)]	HT82M9BE@SOP28 [(SA404)]
HT82M9BE@SSOP24 [(SA674)]	HT82M9BE@SSOP28 [(SA626A)]
HT95A100@SOP28 [(SA404)]	HT95A10P@SOP28 [(SA404)]
HT95A200@SSOP48 [(SA669)]	HT95A20P@SSOP48 [(SA669)]
HT95A300@SSOP48 [(SA669)]	HT95A30P@SSOP48 [(SA669)]
HT95A400@PQFP64 [(PEP+S618)]	HT95A40P@PQFP64 [(PEP+S618)]
HT95L000@SSOP56 [(SA669)]	HT95L00P@SSOP56 [(SA669)]
HT95L100@PQFP64 [(PEP+S618)]	HT95L10P@PQFP64 [(PEP+S618)]

## HONGKONG

### E(E) PROM/FRAM/NVRAM

HK1215	HK1225
HK1235	HK1245
HK1255	HK1265
HK1275	HK1285
HK1295	HK12A5
HK12B5	OKS1225
OKS1235	OKS1245
OKS1255	OKS1265
OKS1275	OKS1285
OKS1295	OKS12A5
OKS12B5	

## HYNIX

### E(E) PROM/FRAM/NVRAM

H8ACSOEJ0MCP@FBGA137 [(SA700E-B153A-M137F001Y)]	
H8BCS0SI0MAP@FBGA149 [(SA700I-B308-T149F001Y)]	
H8BCS0SJMCP@FBGA137 [(SA700E-B327A-M137F001Y)]	
HY2764	HY27C64A
HY27SF081G2A@FBGA63 [(SA642KK-B026A-W048F001Y)]	
HY27UA081G1M@TSOP48 [(SA247-B005)]	
HY27UF081G2A@FBGA63 [(SA642KK-B026-W048F001Y)]	
HY27UF081G2A@TSOP48 [(SA247-B005)]	
HY27UF081G2M@TSOP48 [(SA247-B005)]	
HY27UF082G2A@TSOP48 [(SA247-B005)]	
HY27UF082G2B@TSOP48 [(SA247-B005)]	
HY27UF082G2M@TSOP48 [(SA247-B005)]	
HY27UF084G2B@TSOP48 [(SA247-B005)]	
HY27UF084G2M@TSOP48 [(SA247-B005)]	
HY27UG082G2M@TSOP48 [(SA247-B005)]	
HY27UG088G5M@TSOP48 [(SA247+B005)]	
HY27US08121A@FBGA63 [(SA642KK-B026-W048F001Y)]	
HY27US08121A@TSOP48 [(SA247-B005)]	
HY27US08121B@TSOP48 [(SA247-B005)]	
HY27US08121M@TSOP48 [(SA247-B005)]	
HY27US081G1M@USOP48 [(SA765-B005)]	
HY27US08281A@TSOP48 [(SA247-B005)]	
HY27US08561A@FBGA63 [(SA642KK-B026A-W048F001Y)]	
HY27US08561A@TSOP48 [(SA247-B005)]	
HY27US08561M@TSOP48 [(SA247-B005)]	
HY27UT084G2M@TSOP48 [(SA247-B005)]	
HY27UT088G2A@TSOP48 [(SA247-B005)]	
HY27UT088G2M@TSOP48 [(SA247-B005)]	
HY27UU088G5M@TSOP48 [(SA247+B005)]	
HY27UV08BG5M@TSOP48 [(SA247-B005)]	
HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL162BT@TSOP48 [(SA247-B005)]	
HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL162TT@TSOP48 [(SA247-B005)]	
HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL163BT@TSOP48 [(SA247-B005)]	
HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL163TT@TSOP48 [(SA247-B005)]	
HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS162BT@TSOP48 [(SA247-B005)]	
HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS162TT@TSOP48 [(SA247-B005)]	
HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS163BT@TSOP48 [(SA247-B005)]	
HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]	

HY29DS163TT@TSOP48 [(SA247-B005)]	
HY29F002T	HY29F002T@PLCC32 [(SA015A1T)]
HY29F002T@TSOP32 [(SA410T)]	HY29F040
HY29F040@PLCC32 [(SA015A1T)]	HY29F040@TSOP32 [(SA410T)]
HY29F040A	HY29F040A@PLCC32 [(SA015A1T)]
HY29F040A@TSOP32 [(SA410T)]	HY29F080@TSOP40 [(SA409T)]
HY29F200B@PSOP44 [(SA638-B006)]	HY29F200B@TSOP48 [(SA247-B005)]
HY29F200T@PSOP44 [(SA638-B006)]	HY29F200T@TSOP48 [(SA247-B005)]
HY29F400ABG@PSOP44 [(SA638)]	
HY29F400ABT@TSOP48 [(SA247-B005)]	
HY29F400ATG@PSOP44 [(SA638)]	
HY29F400ATT@TSOP48 [(SA247-B005)]	
HY29F400BG@PSOP44 [(SA638)]	HY29F400BT@TSOP48 [(SA247-B005)]
HY29F400TG@PSOP44 [(SA638)]	HY29F400TT@TSOP48 [(SA247-B005)]
HY29F800ABG@PSOP44 [(SA638)]	
HY29F800ABT@TSOP48 [(SA247-B005)]	
HY29F800ATG@PSOP44 [(SA638)]	
HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-B005)]
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-B005)]
HY29LV160BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV160BT@TSOP48 [(SA247-B005)]	
HY29LV160TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV160TT@TSOP48 [(SA247-B005)]	
HY29LV320BF@FBGA48 [(SA642E-B026A-T072F001)]	
HY29LV320BF@FBGA63 [(SA642E-B026A-T072F001)]	
HY29LV320BT@TSOP48 [(SA247-B005)]	
HY29LV320TF@FBGA48 [(SA642E-B026A-T072F001)]	
HY29LV320TF@FBGA63 [(SA642E-B026A-T072F001)]	
HY29LV320TT@TSOP48 [(SA247-B005)]	
HY29LV400BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV400BT@TSOP48 [(SA247-B005)]	
HY29LV400TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV400TT@TSOP48 [(SA247-B005)]	
HY29LV800BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV800BG@PSOP44 [(SA638)]	
HY29LV800BT@TSOP48 [(SA247-B005)]	
HY29LV800TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV800TG@PSOP44 [(SA638)]	
HY29LV800TT@TSOP48 [(SA247-B005)]	
HY93C46	HY93C46@SOIC8 [(SA602A)]
HY93C56	HY93C56@SOIC8 [(SA602A)]
HY93C66	HY93C66@SOIC8 [(SA602A)]
HY93C76	HY93C76@SOIC8 [(SA602A)]
HY93C86	HY93C86@SOIC8 [(SA602A)]
HYC0SEF0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYC0SEH0AF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYC0SEH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYC0UEE0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]	
HYC0UEF0AF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYC0UEF0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYC0UEH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYD0SEE0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]	
HYD0SFE0BF1P@BGA149 [(SA700I-B308-T149F001Y)]	
HYD0SFG0MF1P@BGA149 [(SA700I-B308-T149F001Y)]	
HYG0SEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]	
HYG0SGH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYG0SGJ0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYG0UEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]	
HYG0UGH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	
HYH0SSJ0MF3P@FBGA137 [(SA700E-B327A-M137F001Y)]	
HYI0UGG0AF1P@FBGA149 [(SA700I-B295-T149F001Y)]	
HYI0UIJ0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]	

**DRAM & SRAM**

HY62256A	HY62256A@TSOP28 [(SA643)]
HY6264A	HY6264A@TSOP28 [(SA643)]
HY628100A	HY628100A@SOP32 [(SA438T)]
HY628100A@TSOP32 [(SA410T)]	HY628100B
HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32 [(SA410T)]
HY628400	HY628400@SOP32 [(SA438T)]
HY628400@TSOP32 [(SA410T)]	HY628400A
HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32 [(SA410T)]
HY62CT08081E	HY62CT08081E@SOP28 [(SA438T)]
HY62CT08081E@TSOP28 [(SA643)]	HY62KT08081E
HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28 [(SA643)]
HY62U8100B	HY62U8100B@SOP32 [(SA438T)]
HY62U8100B@TSOP32 [(SA410T)]	HY62U8200B

HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32 [(SA410T)]
HY62U8400A	HY62U8400A@SOP32 [(SA438T)]
HY62U8400A@TSOP32 [(SA410T)]	HY62UT08081E
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28 [(SA643)]
HY62V8100B	HY62V8100B@SOP32 [(SA438T)]
HY62V8100B@TSOP32 [(SA410T)]	HY62V8200B
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32 [(SA410T)]
HY62V8400A	HY62V8400A@SOP32 [(SA438T)]
HY62V8400A@TSOP32 [(SA410T)]	HY62VT08081E
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28 [(SA643)]
HY62WT08081E	HY62WT08081E@SOP28 [(SA438T)]
HY62WT08081E@TSOP28 [(SA643)]	

## MICROCONTROLLER

GMS34004TK	GMS34004TM
GMS34004TW	GMS34112TK
GMS34112TK@SOIC20 [(SA404)]	GMS34112TK@SSOP20 [(SA626A)]
GMS34140TK	GMS34140TK@SOIC24 [(SA404)]
GMS77C1000	GMS77C1000@SOIC20 [(SA404)]
GMS77C1001	GMS77C1001@SOIC20 [(SA404)]
GMS81004(dip20)	GMS81004(dip24)
GMS81004(dip28)	GMS81004@PLCC44 [(SA244)]
GMS81004@SOIC20 [(SA404)]	GMS81004@SOIC24 [(SA404)]
GMS81004@SOIC28 [(SA404)]	GMS81008(dip20)
GMS81008(dip24)	GMS81008(dip28)
GMS81008@PLCC44 [(SA244)]	GMS81008@SOIC20 [(SA404)]
GMS81008@SOIC24 [(SA404)]	GMS81008@SOIC28 [(SA404)]
GMS81016(dip20)	GMS81016(dip24)
GMS81016(dip28)	GMS81016@PLCC44 [(SA244)]
GMS81016@SOIC20 [(SA404)]	GMS81016@SOIC24 [(SA404)]
GMS81016@SOIC28 [(SA404)]	GMS81024(dip20)
GMS81024(dip24)	GMS81024(dip28)
GMS81024@PLCC44 [(SA244)]	GMS81024@SOIC20 [(SA404)]
GMS81024@SOIC24 [(SA404)]	GMS81024@SOIC28 [(SA404)]
GMS81032(dip20)	GMS81032(dip24)
GMS81032(dip28)	GMS81032@PLCC44 [(SA244)]
GMS81032@SOIC20 [(SA404)]	GMS81032@SOIC24 [(SA404)]
GMS81032@SOIC28 [(SA404)]	GMS81504AT
GMS81504T	GMS81516
GMS81516@LQFP64 [(PEP+S616)]	GMS81516@MQFP64 [(PEP+S618)]
GMS81516@SDIP64 [(PEP+S600A)]	GMS81516AT
GMS81516AT@LQFP64 [(PEP+S616)]	GMS81516AT@MQFP64 [(PEP+S618)]
GMS81516AT@SDIP64 [(PEP+S600A)]	GMS81516BT
GMS81516BT@LQFP64 [(PEP+S616)]	GMS81516BT@MQFP64 [(PEP+S618)]
GMS81516BT@SDIP64 [(PEP+S600A)]	GMS81524
GMS81524@LQFP64 [(PEP+S616)]	GMS81524@MQFP64 [(PEP+S618)]
GMS81524@SDIP64 [(PEP+S600A)]	GMS81524AT
GMS81524AT@LQFP64 [(PEP+S616)]	GMS81524AT@MQFP64 [(PEP+S618)]
GMS81524AT@SDIP64 [(PEP+S600A)]	GMS81524BT
GMS81524BT@LQFP64 [(PEP+S616)]	GMS81524BT@MQFP64 [(PEP+S618)]
GMS81524BT@SDIP64 [(PEP+S600A)]	GMS81604T
GMS81604T@PLCC44 [(SA244)]	GMS81604T@SDIP42 [(SA028)]
GMS81608T	GMS81608T@PLCC44 [(SA244)]
GMS81608T@SDIP42 [(SA028)]	GMS81C5016(dip28)
GMS81C5016(dip40)	GMS81C5016@PLCC44 [(SA244)]
GMS81C5016@SOIC28 [(SA404)]	GMS81C5016@TQFP44 [(SA245A)]
GMS81C5024(dip28)	GMS81C5024(dip40)
GMS81C5024@PLCC44 [(SA244)]	GMS81C5024@SOIC28 [(SA404)]
GMS81C5024@TQFP44 [(SA245A)]	GMS81C5032(dip28)
GMS81C5032(dip40)	GMS81C5032@PLCC44 [(SA244)]
GMS81C5032@SOIC28 [(SA404)]	GMS81C5032@TQFP44 [(SA245A)]
GMS82516T	GMS82516T@LQFP64 [(PEP+S616)]
GMS82516T@MQFP64 [(PEP+S618)]	GMS82516T@SDIP64 [(PEP+S600A)]
GMS82524T	GMS82524T@LQFP64 [(PEP+S616)]
GMS82524T@MQFP64 [(PEP+S618)]	GMS82524T@SDIP64 [(PEP+S600A)]
GMS84512T@SDIP52 [(PEP+S600A)]	GMS84524T@SDIP52 [(PEP+S600A)]
GMS87C1102	GMS87C1102@SOP16 [(SA404)]
GMS87C1202	GMS87C1202@SOP20 [(SA404)]
GMS87C1404	GMS87C1404@SDIP28 [(SA022A)]
GMS87C1408	GMS87C1408@SDIP28 [(SA022A)]
GMS87C2020@LQFP64 [(PEP+S616)]	GMS87C2020@MQFP64 [(PEP+S618)]
GMS87C2020@SDIP64 [(PEP+S600A)]	GMS87C5032(dip28)
GMS87C5032(dip40)	GMS87C5032@PLCC44 [(SA244)]
GMS87C5032@SOIC28 [(SA404)]	GMS87C5032@TQFP44 [(SA245A)]
GMS87C5108@PQFP80 [(PEP+S611A)]	GMS87C7008@LQFP64 [(PEP+S616)]
GMS87C7008@MQFP64 [(PEP+S618)]	GMS87C7008@SDIP64 [(PEP+S600A)]
GMS87C7016@LQFP64 [(PEP+S616)]	GMS87C7016@MQFP64 [(PEP+S618)]
GMS87C7016@SDIP64 [(PEP+S600A)]	GMS97C1051



GMS97C1051@SOIC20 [(SA404)]	GMS97C2051
GMS97C2051@SOIC20 [(SA404)]	GMS97C51
GMS97C51@PLCC44 [(SA244)]	GMS97C51@TQFP44 [(SA245A)]
GMS97C52	GMS97C52@PLCC44 [(SA244)]
GMS97C52@TQFP44 [(SA245A)]	GMS97C54
GMS97C54@PLCC44 [(SA244)]	GMS97C54@TQFP44 [(SA245A)]
GMS97C56	GMS97C56@PLCC44 [(SA244)]
GMS97C56@TQFP44 [(SA245A)]	GMS97C58
GMS97C58@PLCC44 [(SA244)]	GMS97C58@TQFP44 [(SA245A)]
GMS97L1051	GMS97L1051@SOIC20 [(SA404)]
GMS97L2051	GMS97L2051@SOIC20 [(SA404)]
GMS97L51	GMS97L51@PLCC44 [(SA244)]
GMS97L51@TQFP44 [(SA245A)]	GMS97L52
GMS97L52@PLCC44 [(SA244)]	GMS97L52@TQFP44 [(SA245A)]
GMS97L54	GMS97L54@PLCC44 [(SA244)]
GMS97L54@TQFP44 [(SA245A)]	GMS97L56
GMS97L56@PLCC44 [(SA244)]	GMS97L56@TQFP44 [(SA245A)]
GMS97L58	GMS97L58@PLCC44 [(SA244)]
GMS97L58@TQFP44 [(SA245A)]	GMS99C52
GMS99C52@PLCC44 [(SA244)]	GMS99C52@TQFP44 [(SA245A)]
GMS99C58	GMS99C58@PLCC44 [(SA244)]
GMS99C58@TQFP44 [(SA245A)]	HMS81004E(dip20)
HMS81004E(dip24)	HMS81004E(dip28)
HMS81004E@PLCC44 [(SA244)]	HMS81004E@SOIC20 [(SA404)]
HMS81004E@SOIC24 [(SA404)]	HMS81004E@SOIC28 [(SA404)]
HMS81008E(dip20)	HMS81008E(dip24)
HMS81008E(dip28)	HMS81008E@PLCC44 [(SA244)]
HMS81008E@SOIC20 [(SA404)]	HMS81008E@SOIC24 [(SA404)]
HMS81008E@SOIC28 [(SA404)]	HMS81016E(dip20)
HMS81016E(dip24)	HMS81016E(dip28)
HMS81016E@PLCC44 [(SA244)]	HMS81016E@SOIC20 [(SA404)]
HMS81016E@SOIC24 [(SA404)]	HMS81016E@SOIC28 [(SA404)]
HMS81020ET(dip20)	HMS81020ET(dip24)
HMS81020ET(dip28)	HMS81020ET@SOIC20 [(SA404)]
HMS81020ET@SOIC24 [(SA404)]	HMS81020ET@SOIC28 [(SA404)]
HMS81020TL(dip20)	HMS81020TL(dip24)
HMS81020TL(dip28)	HMS81020TL@SOIC20 [(SA404)]
HMS81020TL@SOIC24 [(SA404)]	HMS81020TL@SOIC28 [(SA404)]
HMS81024E(dip20)	HMS81024E(dip24)
HMS81024E(dip28)	HMS81024E@PLCC44 [(SA244)]
HMS81024E@SOIC20 [(SA404)]	HMS81024E@SOIC24 [(SA404)]
HMS81024E@SOIC28 [(SA404)]	HMS81032(dip20)
HMS81032(dip24)	HMS81032(dip28)
HMS81032@SOIC20 [(SA404)]	HMS81032@SOIC24 [(SA404)]
HMS81032@SOIC28 [(SA404)]	HMS81032ET(dip20)
HMS81032ET(dip24)	HMS81032ET(dip28)
HMS81032ET@SOIC20 [(SA404)]	HMS81032ET@SOIC24 [(SA404)]
HMS81032ET@SOIC28 [(SA404)]	HMS81032T(dip20)
HMS81032T(dip24)	HMS81032T(dip28)
HMS81032T@SOIC20 [(SA404)]	HMS81032T@SOIC24 [(SA404)]
HMS81032T@SOIC28 [(SA404)]	HMS81032TL(dip20)
HMS81032TL(dip24)	HMS81032TL(dip28)
HMS81032TL@SOIC20 [(SA404)]	HMS81032TL@SOIC24 [(SA404)]
HMS81032TL@SOIC28 [(SA404)]	HMS87C1102A
HMS87C1102A@SOP16 [(SA404)]	HMS87C1104A
HMS87C1104A@SOP16 [(SA404)]	HMS87C1202A
HMS87C1202A@SOP20 [(SA404)]	HMS87C1204A
HMS87C1204A@SOP20 [(SA404)]	
HMS87C1302A@SDIP24 [(SA022A-B005)]	
HMS87C1302A@SOP24 [(SA404)]	
HMS87C1304A@SDIP24 [(SA022A-B005)]	
HMS87C1304A@SOP24 [(SA404)]	
HMS87C1404B@SDIP28 [(SA022A)]	HMS87C1404B
HMS87C1408B	HMS87C1404B@SOIC28 [(SA404)]
HMS87C1408B@SOIC28 [(SA404)]	HMS87C1408B@SDIP28 [(SA022A)]
HMS87C1416B@SDIP28 [(SA022A)]	HMS87C1416B
HMS87C1508B	HMS87C1416B@SOIC28 [(SA404)]
HMS87C1608B	HMS87C1516B
HMS87C1708B@SDIP42 [(SA028)]	HMS87C1616B
HMS87C1808B@TQFP44 [(SA245A)]	HMS87C1716B@SDIP42 [(SA028)]
HMS87C5216	HMS87C1816B@TQFP44 [(SA245A)]
HMS87C5216@SOIC28 [(SA404)]	HMS87C5216@PLCC44 [(SA244)]
HMS99C52	HMS87C5216@TQFP44 [(SA245A)]
HMS99C52@TQFP44 [(SA245A)]	HMS99C52@PLCC44 [(SA244)]
HMS99C58@PLCC44 [(SA244)]	HMS99C58
	HMS99C58@TQFP44 [(SA245A)]

**HYNIX(HYUNDAI)**

## PLD

HY18CV8 HY18CV8@PLCC20 [(SA001A)]  
 HY18CV8@SOIC20 [(SA404)] HY18CV8@TSOP20 [(SA026)]

## HYNIX-CUSTOMER

## E(E) PROM/FRAM/NVRAM

H8BCS0SI0MAP(YH)@FBGA149 [(SA700I-B308-T149F001Y)]  
 HY27UF081G2A(DD)@TSOP48 [(SA247-B005)]  
 HY27UF081G2A(DD5)@TSOP48 [(SA247+B005)]  
 HY27UF081G2A(MLT)@TSOP48 [(SA247-B005)]  
 HY27UF081G2A(TZ)@TSOP48 [(SA247-B005)]  
 HY27UF081G2A(ZX)@TSOP48 [(SA247-B005)]  
 HY27UF082G2A(AMLOGIC)@TSOP48 [(SA247-B005)]  
 HY27UF082G2A(MLT)@TSOP48 [(SA247-B005)]  
 HY27UF082G2M(ZX)@TSOP48 [(SA247-B005)]  
 HY27UF084G2M(YH)@TSOP48 [(SA247-B005)]  
 HY27UG088G5M(KD)@TSOP48 [(SA247+B005)]  
 HY27UG088G5M(MLT)@TSOP48 [(SA247-B005)]  
 HY27US08121A(ASUS)@TSOP48 [(SA247-B005)]  
 HY27US08121A(DD)@TSOP48 [(SA247-B005)]  
 HY27US08121A(MLTATL)@TSOP48 [(SA247-B005)]  
 HY27US08121A(XJ)@TSOP48 [(SA247-B005)]  
 HY27US08121B(LG)@TSOP48 [(SA247-B005)]  
 HY27US08281A(WS)@TSOP48 [(SA247-B005)]  
 HY27UT088G2A(64M)@TSOP48 [(SA247-B005)]  
 HY27UT088G2M(OMB)@TSOP48 [(SA247-B005)]

## HYUNDAI

## E(E) PROM/FRAM/NVRAM

HY2764	HY27C64A
HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL162BT@TSOP48 [(SA247-B005)]	
HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL162TT@TSOP48 [(SA247-B005)]	
HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL163BT@TSOP48 [(SA247-B005)]	
HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DL163TT@TSOP48 [(SA247-B005)]	
HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS162BT@TSOP48 [(SA247-B005)]	
HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS162TT@TSOP48 [(SA247-B005)]	
HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS163BT@TSOP48 [(SA247-B005)]	
HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29DS163TT@TSOP48 [(SA247-B005)]	
HY29F002T	HY29F002T@PLCC32 [(SA015A1T)]
HY29F002T@TSOP32 [(SA410T)]	HY29F040
HY29F040@PLCC32 [(SA015A1T)]	HY29F040@TSOP32 [(SA410T)]
HY29F040A	HY29F040A@PLCC32 [(SA015A1T)]
HY29F040A@TSOP32 [(SA410T)]	HY29F080@TSOP40 [(SA409T)]
HY29F200B@PSOP44 [(SA638-B006)]	HY29F200B@TSOP48 [(SA247-B005)]
HY29F200T@PSOP44 [(SA638-B006)]	HY29F200T@TSOP48 [(SA247-B005)]
HY29F400ABG@PSOP44 [(SA638)]	
HY29F400ABT@TSOP48 [(SA247-B005)]	
HY29F400ATG@PSOP44 [(SA638)]	
HY29F400ATT@TSOP48 [(SA247-B005)]	
HY29F400BG@PSOP44 [(SA638)]	HY29F400BT@TSOP48 [(SA247-B005)]
HY29F400TG@PSOP44 [(SA638)]	HY29F400TT@TSOP48 [(SA247-B005)]
HY29F800ABG@PSOP44 [(SA638)]	
HY29F800ABT@TSOP48 [(SA247-B005)]	
HY29F800ATG@PSOP44 [(SA638)]	
HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-B005)]
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-B005)]
HY29LV160BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV160BT@TSOP48 [(SA247-B005)]	
HY29LV160TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV160TT@TSOP48 [(SA247-B005)]	

HY29LV320BF@FBGA48	[ (SA642E-B026A-T072F001) ]		
HY29LV320BF@FBGA63	[ (SA642E-B026A-T072F001) ]		
HY29LV320BT@TSOP48	[ (SA247-B005) ]		
HY29LV320TF@FBGA48	[ (SA642E-B026A-T072F001) ]		
HY29LV320TF@FBGA63	[ (SA642E-B026A-T072F001) ]		
HY29LV320TT@TSOP48	[ (SA247-B005) ]		
HY29LV400BF@FBGA48	[ (SA642F-B026A-T064F001) ]		
HY29LV400BT@TSOP48	[ (SA247-B005) ]		
HY29LV400TF@FBGA48	[ (SA642F-B026A-T064F001) ]		
HY29LV400TT@TSOP48	[ (SA247-B005) ]		
HY29LV800BF@FBGA48	[ (SA642F-B026A-T064F001) ]		
HY29LV800BG@PSOP44	[ (SA638) ]		
HY29LV800BT@TSOP48	[ (SA247-B005) ]		
HY29LV800TF@FBGA48	[ (SA642F-B026A-T064F001) ]		
HY29LV800TG@PSOP44	[ (SA638) ]		
HY29LV800TT@TSOP48	[ (SA247-B005) ]		
HY93C46		HY93C46@SOIC8	[ (SA602A) ]
HY93C56		HY93C56@SOIC8	[ (SA602A) ]
HY93C66		HY93C66@SOIC8	[ (SA602A) ]
HY93C76		HY93C76@SOIC8	[ (SA602A) ]
HY93C86		HY93C86@SOIC8	[ (SA602A) ]

**DRAM & SRAM**

HY62256A		HY62256A@TSOP28	[ (SA643) ]
HY6264A		HY6264A@TSOP28	[ (SA643) ]
HY628100A		HY628100A@SOP32	[ (SA438T) ]
HY628100A@TSOP32	[ (SA410T) ]	HY628100B	
HY628100B@SOP32	[ (SA438T) ]	HY628100B@TSOP32	[ (SA410T) ]
HY628400		HY628400@SOP32	[ (SA438T) ]
HY628400@TSOP32	[ (SA410T) ]	HY628400A	
HY628400A@SOP32	[ (SA438T) ]	HY628400A@TSOP32	[ (SA410T) ]
HY62CT08081E		HY62CT08081E@SOP28	[ (SA438T) ]
HY62CT08081E@TSOP28	[ (SA643) ]	HY62KT08081E	
HY62KT08081E@SOP28	[ (SA438T) ]	HY62KT08081E@TSOP28	[ (SA643) ]
HY62U8100B		HY62U8100B@SOP32	[ (SA438T) ]
HY62U8100B@TSOP32	[ (SA410T) ]	HY62U8200B	
HY62U8200B@SOP32	[ (SA438T) ]	HY62U8200B@TSOP32	[ (SA410T) ]
HY62U8400A		HY62U8400A@SOP32	[ (SA438T) ]
HY62U8400A@TSOP32	[ (SA410T) ]	HY62UT08081E	
HY62UT08081E@SOP28	[ (SA438T) ]	HY62UT08081E@TSOP28	[ (SA643) ]
HY62V8100B		HY62V8100B@SOP32	[ (SA438T) ]
HY62V8100B@TSOP32	[ (SA410T) ]	HY62V8200B	
HY62V8200B@SOP32	[ (SA438T) ]	HY62V8200B@TSOP32	[ (SA410T) ]
HY62V8400A		HY62V8400A@SOP32	[ (SA438T) ]
HY62V8400A@TSOP32	[ (SA410T) ]	HY62VT08081E	
HY62VT08081E@SOP28	[ (SA438T) ]	HY62VT08081E@TSOP28	[ (SA643) ]
HY62WT08081E		HY62WT08081E@SOP28	[ (SA438T) ]
HY62WT08081E@TSOP28	[ (SA643) ]		

**MICROCONTROLLER**

GMS34004TK		GMS34004TM	
GMS34004TW		GMS34112TK	
GMS34112TK@SOIC20	[ (SA404) ]	GMS34112TK@SSOP20	[ (SA626A) ]
GMS34140TK		GMS34140TK@SOIC24	[ (SA404) ]
GMS77C1000		GMS77C1000@SOIC20	[ (SA404) ]
GMS77C1001		GMS77C1001@SOIC20	[ (SA404) ]
GMS81004(dip20)		GMS81004(dip24)	
GMS81004(dip28)		GMS81004@PLCC44	[ (SA244) ]
GMS81004@SOIC20	[ (SA404) ]	GMS81004@SOIC24	[ (SA404) ]
GMS81004@SOIC28	[ (SA404) ]	GMS81008(dip20)	
GMS81008(dip24)		GMS81008(dip28)	
GMS81008@PLCC44	[ (SA244) ]	GMS81008@SOIC20	[ (SA404) ]
GMS81008@SOIC24	[ (SA404) ]	GMS81008@SOIC28	[ (SA404) ]
GMS81016(dip20)		GMS81016(dip24)	
GMS81016(dip28)		GMS81016@PLCC44	[ (SA244) ]
GMS81016@SOIC20	[ (SA404) ]	GMS81016@SOIC24	[ (SA404) ]
GMS81016@SOIC28	[ (SA404) ]	GMS81024(dip20)	
GMS81024(dip24)		GMS81024(dip28)	
GMS81024@PLCC44	[ (SA244) ]	GMS81024@SOIC20	[ (SA404) ]
GMS81024@SOIC24	[ (SA404) ]	GMS81024@SOIC28	[ (SA404) ]
GMS81032(dip20)		GMS81032(dip24)	
GMS81032(dip28)		GMS81032@PLCC44	[ (SA244) ]
GMS81032@SOIC20	[ (SA404) ]	GMS81032@SOIC24	[ (SA404) ]
GMS81032@SOIC28	[ (SA404) ]	GMS81504AT	
GMS81504T		GMS81516	
GMS81516@LQFP64	[ (PEP+S616) ]	GMS81516@MQFP64	[ (PEP+S618) ]

GMS81516@SDIP64 [(PEP+S600A)]	GMS81516AT
GMS81516AT@LQFP64 [(PEP+S616)]	GMS81516AT@MQFP64 [(PEP+S618)]
GMS81516AT@SDIP64 [(PEP+S600A)]	GMS81516BT
GMS81516BT@LQFP64 [(PEP+S616)]	GMS81516BT@MQFP64 [(PEP+S618)]
GMS81516BT@SDIP64 [(PEP+S600A)]	GMS81524
GMS81524@LQFP64 [(PEP+S616)]	GMS81524@MQFP64 [(PEP+S618)]
GMS81524@SDIP64 [(PEP+S600A)]	GMS81524AT
GMS81524AT@LQFP64 [(PEP+S616)]	GMS81524AT@MQFP64 [(PEP+S618)]
GMS81524AT@SDIP64 [(PEP+S600A)]	GMS81524BT
GMS81524BT@LQFP64 [(PEP+S616)]	GMS81524BT@MQFP64 [(PEP+S618)]
GMS81524BT@SDIP64 [(PEP+S600A)]	GMS81604T
GMS81604T@PLCC44 [(SA244)]	GMS81604T@SDIP42 [(SA028)]
GMS81608T	GMS81608T@PLCC44 [(SA244)]
GMS81608T@SDIP42 [(SA028)]	GMS81C5016(dip28)
GMS81C5016(dip40)	GMS81C5016@PLCC44 [(SA244)]
GMS81C5016@SOIC28 [(SA404)]	GMS81C5016@TQFP44 [(SA245A)]
GMS81C5024(dip28)	GMS81C5024(dip40)
GMS81C5024@PLCC44 [(SA244)]	GMS81C5024@SOIC28 [(SA404)]
GMS81C5024@TQFP44 [(SA245A)]	GMS81C5032(dip28)
GMS81C5032(dip40)	GMS81C5032@PLCC44 [(SA244)]
GMS81C5032@SOIC28 [(SA404)]	GMS81C5032@TQFP44 [(SA245A)]
GMS82516T	GMS82516T@LQFP64 [(PEP+S616)]
GMS82516T@MQFP64 [(PEP+S618)]	GMS82516T@SDIP64 [(PEP+S600A)]
GMS82524T	GMS82524T@LQFP64 [(PEP+S616)]
GMS82524T@MQFP64 [(PEP+S618)]	GMS82524T@SDIP64 [(PEP+S600A)]
GMS84512T@SDIP52 [(PEP+S600A)]	GMS84524T@SDIP52 [(PEP+S600A)]
GMS87C1102	GMS87C1102@SOP16 [(SA404)]
GMS87C1202	GMS87C1202@SOP20 [(SA404)]
GMS87C1404	GMS87C1404@SDIP28 [(SA022A)]
GMS87C1408	GMS87C1408@SDIP28 [(SA022A)]
GMS87C2020@LQFP64 [(PEP+S616)]	GMS87C2020@MQFP64 [(PEP+S618)]
GMS87C2020@SDIP64 [(PEP+S600A)]	GMS87C5032(dip28)
GMS87C5032(dip40)	GMS87C5032@PLCC44 [(SA244)]
GMS87C5032@SOIC28 [(SA404)]	GMS87C5032@TQFP44 [(SA245A)]
GMS87C5108@PQFP80 [(PEP+S611A)]	GMS87C7008@LQFP64 [(PEP+S616)]
GMS87C7008@MQFP64 [(PEP+S618)]	GMS87C7008@SDIP64 [(PEP+S600A)]
GMS87C7016@LQFP64 [(PEP+S616)]	GMS87C7016@MQFP64 [(PEP+S618)]
GMS87C7016@SDIP64 [(PEP+S600A)]	GMS97C1051
GMS97C1051@SOIC20 [(SA404)]	GMS97C2051
GMS97C2051@SOIC20 [(SA404)]	GMS97C51
GMS97C51@PLCC44 [(SA244)]	GMS97C51@TQFP44 [(SA245A)]
GMS97C52	GMS97C52@PLCC44 [(SA244)]
GMS97C52@TQFP44 [(SA245A)]	GMS97C54
GMS97C54@PLCC44 [(SA244)]	GMS97C54@TQFP44 [(SA245A)]
GMS97C56	GMS97C56@PLCC44 [(SA244)]
GMS97C56@TQFP44 [(SA245A)]	GMS97C58
GMS97C58@PLCC44 [(SA244)]	GMS97C58@TQFP44 [(SA245A)]
GMS97L1051	GMS97L1051@SOIC20 [(SA404)]
GMS97L2051	GMS97L2051@SOIC20 [(SA404)]
GMS97L51	GMS97L51@PLCC44 [(SA244)]
GMS97L51@TQFP44 [(SA245A)]	GMS97L52
GMS97L52@PLCC44 [(SA244)]	GMS97L52@TQFP44 [(SA245A)]
GMS97L54	GMS97L54@PLCC44 [(SA244)]
GMS97L54@TQFP44 [(SA245A)]	GMS97L56
GMS97L56@PLCC44 [(SA244)]	GMS97L56@TQFP44 [(SA245A)]
GMS97L58	GMS97L58@PLCC44 [(SA244)]
GMS97L58@TQFP44 [(SA245A)]	GMS99C52
GMS99C52@PLCC44 [(SA244)]	GMS99C52@TQFP44 [(SA245A)]
GMS99C58	GMS99C58@PLCC44 [(SA244)]
GMS99C58@TQFP44 [(SA245A)]	HMS81004E(dip20)
HMS81004E(dip24)	HMS81004E(dip28)
HMS81004E@PLCC44 [(SA244)]	HMS81004E@SOIC20 [(SA404)]
HMS81004E@SOIC24 [(SA404)]	HMS81004E@SOIC28 [(SA404)]
HMS81008E(dip20)	HMS81008E(dip24)
HMS81008E(dip28)	HMS81008E@PLCC44 [(SA244)]
HMS81008E@SOIC20 [(SA404)]	HMS81008E@SOIC24 [(SA404)]
HMS81008E@SOIC28 [(SA404)]	HMS81016E(dip20)
HMS81016E(dip24)	HMS81016E(dip28)
HMS81016E@PLCC44 [(SA244)]	HMS81016E@SOIC20 [(SA404)]
HMS81016E@SOIC24 [(SA404)]	HMS81016E@SOIC28 [(SA404)]
HMS81020ET(dip20)	HMS81020ET(dip24)
HMS81020ET(dip28)	HMS81020ET@SOIC20 [(SA404)]
HMS81020ET@SOIC24 [(SA404)]	HMS81020ET@SOIC28 [(SA404)]
HMS81020TL(dip20)	HMS81020TL(dip24)
HMS81020TL(dip28)	HMS81020TL@SOIC20 [(SA404)]
HMS81020TL@SOIC24 [(SA404)]	HMS81020TL@SOIC28 [(SA404)]
HMS81024E(dip20)	HMS81024E(dip24)
HMS81024E(dip28)	HMS81024E@PLCC44 [(SA244)]
HMS81024E@SOIC20 [(SA404)]	HMS81024E@SOIC24 [(SA404)]
HMS81024E@SOIC28 [(SA404)]	HMS81032(dip20)
HMS81032(dip24)	HMS81032(dip28)

HMS81032@SOIC20 [(SA404)]	HMS81032@SOIC24 [(SA404)]
HMS81032@SOIC28 [(SA404)]	HMS81032ET(dip20)
HMS81032ET(dip24)	HMS81032ET(dip28)
HMS81032ET@SOIC20 [(SA404)]	HMS81032ET@SOIC24 [(SA404)]
HMS81032ET@SOIC28 [(SA404)]	HMS81032T(dip20)
HMS81032T(dip24)	HMS81032T(dip28)
HMS81032T@SOIC20 [(SA404)]	HMS81032T@SOIC24 [(SA404)]
HMS81032T@SOIC28 [(SA404)]	HMS81032TL(dip20)
HMS81032TL(dip24)	HMS81032TL(dip28)
HMS81032TL@SOIC20 [(SA404)]	HMS81032TL@SOIC24 [(SA404)]
HMS81032TL@SOIC28 [(SA404)]	HMS87C1102A
HMS87C1102A@SOP16 [(SA404)]	HMS87C1104A
HMS87C1104A@SOP16 [(SA404)]	HMS87C1202A
HMS87C1202A@SOP20 [(SA404)]	HMS87C1204A
HMS87C1204A@SOP20 [(SA404)]	
HMS87C1302A@SDIP24 [(SA022A-B005)]	
HMS87C1302A@SOP24 [(SA404)]	
HMS87C1304A@SDIP24 [(SA022A-B005)]	
HMS87C1304A@SOP24 [(SA404)]	HMS87C1404B
HMS87C1404B@SDIP28 [(SA022A)]	HMS87C1404B@SOIC28 [(SA404)]
HMS87C1408B	HMS87C1408B@SDIP28 [(SA022A)]
HMS87C1408B@SOIC28 [(SA404)]	HMS87C1416B
HMS87C1416B@SDIP28 [(SA022A)]	HMS87C1416B@SOIC28 [(SA404)]
HMS87C1508B	HMS87C1516B
HMS87C1608B	HMS87C1616B
HMS87C1708B@SDIP42 [(SA028)]	HMS87C1716B@SDIP42 [(SA028)]
HMS87C1808B@TQFP44 [(SA245A)]	HMS87C1816B@TQFP44 [(SA245A)]
HMS87C5216	HMS87C5216@PLCC44 [(SA244)]
HMS87C5216@SOIC28 [(SA404)]	HMS87C5216@TQFP44 [(SA245A)]
HMS99C52	HMS99C52@PLCC44 [(SA244)]
HMS99C52@TQFP44 [(SA245A)]	HMS99C58
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44 [(SA245A)]

## ICE

### E(E) PROM/FRAM/NVRAM

ICE25P05	ICE25P05@SOIC8 [(SA602A)]
ICE27C010	ICE27C010@PLCC32 [(SA015A1T)]
ICE27C010@TSOP32 [(SA410T)]	ICE27C020
ICE27C020@PLCC32 [(SA015A1T)]	ICE27C020@TSOP32 [(SA410T)]
ICE27C512	ICE27C512@PLCC32 [(SA015A1T)]
ICE27C512@TSOP28 [(SA430T)]	ICE27LC010
ICE27LC010@PLCC32 [(SA015A1T)]	ICE27LC010@TSOP32 [(SA410T)]
ICE27LC020	ICE27LC020@PLCC32 [(SA015A1T)]
ICE27LC020@TSOP32 [(SA410T)]	ICE27LC512
ICE27LC512@PLCC32 [(SA015A1T)]	ICE27LC512@TSOP28 [(SA430T)]
ICE28LF010	ICE28LF010@PLCC32 [(SA015A1T)]
ICE37C512	ICE37C512@PLCC32 [(SA015A1T)]
ICE37C512@TSOP32 [(SA410T)]	ICE37LC512
ICE37LC512@PLCC32 [(SA015A1T)]	ICE37LC512@TSOP32 [(SA410T)]

## ICMIC

### E(E) PROM/FRAM/NVRAM

X76F101	X76F101@SOIC8 [(SA602A)]
X76F400@SOIC8 [(SA602A)]	X76F400@TSSOP8 [(SA026)]

## ICSI

### E(E) PROM/FRAM/NVRAM

IC71V08F32AS04@FBGA64 [(SA642A-B032A-Y096F001)]
IC71V08F32AS04@FBGA73 [(SA642A-B032A-Y096F001)]
IC71V08F32AS08@FBGA64 [(SA642A-B032A-Y096F001)]
IC71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]
IC71V08F32BS04@FBGA64 [(SA642A-B032A-Y096F001)]
IC71V08F32BS04@FBGA73 [(SA642A-B032A-Y096F001)]
IC71V08F32BS08@FBGA64 [(SA642A-B032A-Y096F001)]
IC71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32CS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32CS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32CS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32DS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32DS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32DS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32ES04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32ES04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32ES08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32FS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32FS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V08F32FS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32AS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32AS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32AS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32BS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32BS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32BS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32CS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32CS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32CS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32DS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32DS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32DS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32ES04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32ES04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32ES08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32FS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32FS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32FS08@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32GS04@FBGA64 [(SA642A-B032A-Y096F001)]  
 IC71V16F32GS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32HS04@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F32HS08@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F64IP16@FBGA73 [(SA642A-B032A-Y096F001)]  
 IC71V16F64IS08@FBGA73 [(SA642A-B032A-Y096F001)]

## MICROCONTROLLER

IC89LV51A	IC89LV51A@PLCC44 [(SA244)]
IC89LV51A@TQFP44 [(SA245A)]	IC89LV52A
IC89LV52A@PLCC44 [(SA244)]	IC89LV52A@TQFP44 [(SA245A)]
IS89C51A	IS89C51A@PLCC44 [(SA244)]
IS89C51A@TQFP44 [(SA245A)]	IS89C52A
IS89C52A@PLCC44 [(SA244)]	IS89C52A@TQFP44 [(SA245A)]
IS89C54	IS89C54@PLCC44 [(SA244)]
IS89C54@TQFP44 [(SA245A)]	IS89C58
IS89C58@PLCC44 [(SA244)]	IS89C58@TQFP44 [(SA245A)]
IS89C64	IS89C64@PLCC44 [(SA244)]
IS89C64@TQFP44 [(SA245A)]	IS89E54
IS89E54@PLCC44 [(SA244)]	IS89E54@TQFP44 [(SA245A)]
IS89E58	IS89E58@PLCC44 [(SA244)]
IS89E58@TQFP44 [(SA245A)]	IS89E64
IS89E64@PLCC44 [(SA244)]	IS89E64@TQFP44 [(SA245A)]

## ICT

### E(E)PROM/FRAM/NVRAM

27CX010	27CX010@PLCC32 [(SA015A1T)]
27CX010@TSOP32 [(SA410T)]	27CX161
27CX162	27CX256
27CX321	27CX322
27CX641	27CX642
93C46	93C46@SOIC8 [(SA602A)]
93C46A	93C46A@SOIC8 [(SA602A)]

93C56A	93C56A@SOIC8 [(SA602A)]
93C66A	93C66A@SOIC8 [(SA602A)]
93CX46	93CX46@SOIC8 [(SA602A)]
93CX56	93CX56@SOIC8 [(SA602A)]
93CX66	93CX66@SOIC8 [(SA602A)]

**PLD**

PA7024	PA7024(J)@PLCC28 [(SA008A)]
PA7024(JN)@PLCC28 [(SA008A)]	PA7024@SOIC24 [(SA404)]
PA7128	PA7128@PLCC28 [(SA008A)]
PA7128@SOIC28 [(SA404)]	PA7140
PA7140@PLCC44 [(SA244)]	PA7140@TQFP44 [(SA245A)]
PA7536	PA7536@PLCC28 [(SA008A)]
PA7536@SOIC28 [(SA404)]	PA7540
PA7540(J)@PLCC28 [(SA008A)]	PA7540(JN)@PLCC28 [(SA008A)]
PA7572	PA7572@PLCC44 [(SA244)]
PA7572@TQFP44 [(SA245A)]	PEEL16CV8
PEEL16CV8@PLCC20 [(SA001A)]	PEEL16CV8@SOIC20 [(SA404)]
PEEL16CV8@TSOP20 [(SA026)]	PEEL18CV8
PEEL18CV8@PLCC20 [(SA001A)]	PEEL18CV8@SOIC20 [(SA404)]
PEEL18CV8@TSOP20 [(SA026)]	PEEL18CV8Z
PEEL18CV8Z@PLCC20 [(SA001A)]	PEEL18CV8Z@SOIC20 [(SA404)]
PEEL18CV8Z@TSOP20 [(SA026)]	PEEL18LV8Z
PEEL18LV8Z@PLCC20 [(SA001A)]	PEEL18LV8Z@SOIC20 [(SA404)]
PEEL18LV8Z@TSOP20 [(SA026)]	PEEL22CV10
PEEL22CV10@PLCC28 [(SA008A)]	PEEL22CV10A
PEEL22CV10A@PLCC28 [(SA008A)]	PEEL22CV10A@SOIC24 [(SA404)]
PEEL22CV10A@TSOP24 [(SA026)]	PEEL22CV10A+
PEEL22CV10A+@PLCC28 [(SA008A)]	PEEL22CV10A+@SOIC24 [(SA404)]
PEEL22CV10A+@TSOP24 [(SA026)]	PEEL22CV10A++
PEEL22CV10A++@PLCC28 [(SA008A)]	PEEL22CV10A++@SOIC24 [(SA404)]
PEEL22CV10A++@TSOP24 [(SA026)]	PEEL22CV10AZ
PEEL22CV10AZ@PLCC28 [(SA008A)]	PEEL22CV10AZ@SOIC24 [(SA404)]
PEEL22CV10AZ@TSOP24 [(SA026)]	PEEL22CV10AZ+
PEEL22CV10AZ+@PLCC28 [(SA008A)]	PEEL22CV10AZ+@SOIC24 [(SA404)]
PEEL22CV10AZ+@TSOP24 [(SA026)]	PEEL22CV10AZ++
PEEL22CV10AZ++@PLCC28 [(SA008A)]	PEEL22CV10AZ++@SOIC24 [(SA404)]
PEEL22CV10AZ++@TSOP24 [(SA026)]	PEEL22CV8
PEEL22CV8@PLCC24 [(SA008A)]	PEEL22CV8@SOIC24 [(SA404)]
PEEL22LV10AZ	PEEL22LV10AZ@PLCC28 [(SA008A)]
PEEL22LV10AZ@SOIC24 [(SA404)]	PEEL22LV10AZ@TSOP24 [(SA026)]
PEEL22LV10AZ+	PEEL22LV10AZ+@PLCC28 [(SA008A)]
PEEL22LV10AZ+@SOIC24 [(SA404)]	PEEL22LV10AZ+@TSOP24 [(SA026)]
PEEL22LV10AZ++	PEEL22LV10AZ++@PLCC28 [(SA008A)]
PEEL22LV10AZ++@SOIC24 [(SA404)]	PEEL22LV10AZ++@TSOP24 [(SA026)]

**IDT****E(E) PROM/FRAM/NVRAM**

ICS280@TSSOP16 [(SA026)]	ICS281@TSSOP16 [(SA026)]
--------------------------	--------------------------

**IGS****E(E) PROM/FRAM/NVRAM**

EV29LV160AB	EV29LV160AT
EV29LV640MB	EV29LV640MT

**IMT****E(E) PROM/FRAM/NVRAM**

IM29F001B	IM29F001B@PLCC32 [(SA015A1T)]
IM29F001B@TSOP32 [(SA410T)]	IM29F001B@VSOP32 [(SA620)]
IM29F001T	IM29F001T@PLCC32 [(SA015A1T)]
IM29F001T@TSOP32 [(SA410T)]	IM29F001T@VSOP32 [(SA620)]
IM29F002B	IM29F002B@PLCC32 [(SA015A1T)]
IM29F002B@TSOP32 [(SA410T)]	IM29F002B@VSOP32 [(SA620)]

IM29F002T	IM29F002T@PLCC32 [(SA015A1T)]
IM29F002T@TSOP32 [(SA410T)]	IM29F002T@VSOP32 [(SA620)]
IM29F004B	IM29F004B@PLCC32 [(SA015A1T)]
IM29F004B@TSOP32 [(SA410T)]	IM29F004B@VSOP32 [(SA620)]
IM29F004T	IM29F004T@PLCC32 [(SA015A1T)]
IM29F004T@TSOP32 [(SA410T)]	IM29F004T@VSOP32 [(SA620)]
IM29LV004B	IM29LV004B@PLCC32 [(SA015A1T)]
IM29LV004B@TSOP32 [(SA410T)]	IM29LV004B@VSOP32 [(SA620)]
IM29LV004T	IM29LV004T@PLCC32 [(SA015A1T)]
IM29LV004T@TSOP32 [(SA410T)]	IM29LV004T@VSOP32 [(SA620)]
IM29LV400B@PSOP44 [(SA638)]	IM29LV400B@TSOP48 [(SA247-B005)]
IM29LV400T@PSOP44 [(SA638)]	IM29LV400T@TSOP48 [(SA247-B005)]

## INFINEON

### MICROCONTROLLER

SAB-C504-2EM@TQFP44 [(SA245A)]	SAB-C505A-4EM@TQFP44 [(SA245A)]
SAB-C505CA-4EM@TQFP44 [(SA245A)]	
SAB-C505L-4EM@PQFP80 [(PEP+S611A)]	
SAB-C508-4EM@TQFP64 [(PEP+S625A)]	
SAB-C508-4EP@SDIP64 [(PEP+S600A)]	
SAB-C515C-8EM@TQFP80 [(PEP+S615B)]	
SAB-C540U-1EN@PLCC44 [(SA244)]	
SAB-C540U-1EP@SDIP52 [(PEP+S600A)]	
SAB-C541U-1EN@PLCC44 [(SA244)]	
SAB-C541U-1EP@SDIP52 [(PEP+S600A)]	
SAB-XC167CI-16F20F@TQFP144 [(SA681-B14401)]	
SAB-XC167CI-16F40F@TQFP144 [(SA681-B14401)]	
SAF-C164CI-8EM@TQFP80 [(PEP+S615B)]	
SAF-C504-2EM@TQFP44 [(SA245A)]	SAF-C505A-4EM@TQFP44 [(SA245A)]
SAF-C505CA-4EM@TQFP44 [(SA245A)]	
SAF-C505L-4EM@PQFP80 [(PEP+S611A)]	
SAF-C508-4EM@TQFP64 [(PEP+S616)]	
SAF-C508-4EP@SDIP64 [(PEP+S600A)]	
SAF-C513AO-2EM@TQFP44 [(SA245A)]	SAF-C513AO-2EN@PLCC44 [(SA244)]
SAF-C513AO-2EP	
SAF-C515C-8EM@TQFP80 [(PEP+S615B)]	
SAF-XC161CJ-16F20F@TQFP144 [(SA681-B14401)]	
SAF-XC161CJ-16F40F@TQFP144 [(SA681-B14401)]	
SAF-XC164CM-4F20F@TQFP64 [(PEP+S616)]	
SAF-XC164CM-4F40F@TQFP64 [(PEP+S616)]	
SAF-XC164CM-8F20F@TQFP64 [(PEP+S616)]	
SAF-XC164CM-8F40F@TQFP64 [(PEP+S616)]	
SAF-XC164CS-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-32F20F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-32F40F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC164D-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164D-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164D-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164D-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC164N-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164N-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164N-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164N-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC164S-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164S-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164S-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164S-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC167CI-16F20F@TQFP144 [(SA681-B14401)]	
SAF-XC167CI-16F40F@TQFP144 [(SA681-B14401)]	
SAF-XC846-1FR@TSSOP38 [(SA693)]	
SAF-XC856CLM-13FFI@QFP64(*) [(SA732+B227)]	
SAF-XC856CLM-16FFI@QFP64(*) [(SA732+B227)]	
SAF-XC856CLM-9FFI@QFP64(*) [(SA732+B227)]	
SAF-XC856LM-13FFI@QFP64(*) [(SA732+B227)]	
SAF-XC856LM-16FFI@QFP64(*) [(SA732+B227)]	
SAF-XC856LM-9FFI@QFP64(*) [(SA732+B227)]	
SAF-XC866-1FR@TSSOP38 [(SA693)]	
SAF-XC866-2FR(A STEP)@TSSOP38 [(SA693)]	
SAF-XC866-2FR(BB STEP)@TSSOP38 [(SA693)]	
SAF-XC866-4FR(A STEP)@TSSOP38 [(SA693)]	
SAF-XC866-4FR(BB STEP)@TSSOP38 [(SA693)]	
SAF-XC866L-2FR(A STEP)@TSSOP38 [(SA693)]	



SAF-XC866L-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAF-XC866L-4FR(A STEP)@TSSOP38 [(SA693)]  
SAF-XC866L-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAF-XC878-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC886-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886C-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886C-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886C-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886C-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC888-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFA(5v)@QFP64(\*) [(SA732+B227)]

SAF-XC888CM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAH-C504-2EM@TQFP44 [(SA245A)] SAH-C505A-4EM@TQFP44 [(SA245A)]  
SAH-C505CA-4EM@TQFP44 [(SA245A)]  
SAK-C164CI-8EM@TQFP80 [(PEP+S615B)]  
SAK-C504-2EM@TQFP44 [(SA245A)] SAK-C505A-4EM@TQFP44 [(SA245A)]  
SAK-C505CA-4EM@TQFP44 [(SA245A)]  
SAK-C505L-4EM@PQFP80 [(PEP+S611A)]  
SAK-C515C-8EM@TQFP80 [(PEP+S615B)]  
SAK-XC161CJ-16F20F@TQFP144 [(SA681-B14401)]  
SAK-XC161CJ-16F40F@TQFP144 [(SA681-B14401)]  
SAK-XC164CM-4F20F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-4F40F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-8F20F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-8F40F@TQFP64 [(PEP+S616)]  
SAK-XC164CS-16F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-16F40F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-32F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-32F40F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-8F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-8F40F@TQFP100 [(PEP+S604)]  
SAK-XC167CI-16F20F@TQFP144 [(SA681-B14401)]  
SAK-XC167CI-16F40F@TQFP144 [(SA681-B14401)]  
SAK-XC846-1FR@TSSOP38 [(SA693)] SAK-XC866-1FR@TSSOP38 [(SA693)]  
SAK-XC866-2FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866-4FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-2FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-4FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC886-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886C-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886C-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886C-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886C-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFA(3.3v)@QFP48 [(SA248)]

SAK-XC886LM-8FFA (5v)@QFP48 [(SA248)]  
 SAK-XC886LM-8FFI (3.3v)@QFP48 [(SA248)]  
 SAK-XC886LM-8FFI (5v)@QFP48 [(SA248)]  
 SAK-XC888-6FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-6FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-6FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-6FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-8FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-8FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-8FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888-8FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-6FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-6FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-6FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-6FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-8FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-8FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-8FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888C-8FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-6FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-6FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-6FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-6FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-8FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-8FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-8FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CLM-8FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-6FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-6FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-6FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-6FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-8FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-8FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-8FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888CM-8FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-6FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-6FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-6FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-6FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-8FFA (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-8FFA (5v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-8FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAK-XC888LM-8FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-13FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-13FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-16FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-16FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-13FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-13FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-16FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-16FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-13FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-13FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-16FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-16FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-13FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-13FFI (5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-16FFI (3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-16FFI (5v)@QFP64(\*) [(SA732+B227)]

## INTEL

### E(E) PROM/FRAM/NVRAM

27010	27010@PLCC32 [(SA015A1T)]
27010@TSOP32 [(SA410T)]	27128
27128A	27128B
2716	27210
27256	2732
2732A	27512
2764	2764A
27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C010A
27C010A@PLCC32 [(SA015A1T)]	27C010A@TSOP32 [(SA410T)]
27C020	27C020@PLCC32 [(SA015A1T)]
27C020@TSOP32 [(SA410T)]	27C040
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32 [(SA410T)]

27C100	27C100@PLCC32 [(SA015A1T)]
27C100@TSOP32 [(SA410T)]	27C128
27C128@PLCC32 [(SA015A1T)]	27C210
27C210@PLCC44 [(SA244)]	27C220
27C220@PLCC44 [(SA244)]	27C240
27C240@PLCC44 [(SA244)]	27C256
27C256@PLCC32 [(SA015A1T)]	27C400
27C400@PLCC44 [(SA244)]	27C512
27C512@PLCC32 [(SA015A1T)]	27C64
27C64@PLCC32 [(SA015A1T)]	27C800
27S512	2816A
2817A	2864A
68C257	68C257@PLCC32 [(SA015A1T)]
87C256	87C257
87C257@PLCC32 [(SA015A1T)]	87C64
D27011	D27513
D27C011	D27C513
D2816	D28F256
D28F256A	D28F512
DA28F016SA@SSOP56 [(SA629A-B013)]	
DA28F016SV@SSOP56 [(SA629A-B013)]	
DA28F320J5(low)@SSOP56 [(SA629-B013)]	
DA28F320J5@SSOP56 [(SA629A-B013)]	
DA28F320J5A(low)@SSOP56 [(SA629-B013)]	
DA28F320J5A@SSOP56 [(SA629A-B013)]	
DA28F640J5@SSOP56 [(SA629A-B013)]	
DA28F640J5A@SSOP56 [(SA629A-B013)]	
DD28F032SA@TSOP56 [(SA628-B011)]	
DT28F016SA@SSOP56 [(SA629A-B013)]	
DT28F016SA@TSOP56 [(SA628-B011)]	
DT28F016SV@SSOP56 [(SA629A-B013)]	
DT28F016SV@TSOP56 [(SA628-B011)]	
DT28F160F3B@SSOP56 [(SA629A-B015)]	
DT28F160F3T@SSOP56 [(SA629A-B015)]	
DT28F160S3@SSOP56 [(SA629A-B013)]	
DT28F160S5@SSOP56 [(SA629A-B013)]	
DT28F320J5@SSOP56 [(SA629A-B013)]	
DT28F320J5A@SSOP56 [(SA629A-B013)]	
DT28F320S3@SSOP56 [(SA629A-B013)]	
DT28F320S5@SSOP56 [(SA629A-B013)]	
DT28F640J5@SSOP56 [(SA629A-B013)]	
DT28F640J5A@SSOP56 [(SA629A-B013)]	
DT28F800F3B@SSOP56 [(SA629A-B015)]	
DT28F800F3T@SSOP56 [(SA629A-B015)]	
E28F001BX-B@TSOP32 [(SA410T)]	E28F001BX-T@TSOP32 [(SA410T)]
E28F002BCT@TSOP40 [(SA409T)]	E28F002BEB@TSOP40 [(SA409T)]
E28F002BET@TSOP40 [(SA409T)]	E28F002BLB@TSOP40 [(SA409T)]
E28F002BLT@TSOP40 [(SA409T)]	E28F002BVB@TSOP40 [(SA409T)]
E28F002BVT@TSOP40 [(SA409T)]	E28F002BXB@TSOP40 [(SA409T)]
E28F002BXT@TSOP40 [(SA409T)]	E28F004B5B@TSOP40 [(SA409T)]
E28F004B5T@TSOP40 [(SA409T)]	E28F004BEB@TSOP40 [(SA409T)]
E28F004BET@TSOP40 [(SA409T)]	E28F004BLB@TSOP40 [(SA409T)]
E28F004BLT@TSOP40 [(SA409T)]	E28F004BVB@TSOP40 [(SA409T)]
E28F004BVT@TSOP40 [(SA409T)]	E28F004BXB@TSOP40 [(SA409T)]
E28F004BXT@TSOP40 [(SA409T)]	E28F004S3@TSOP40 [(SA409T)]
E28F004S5@TSOP40 [(SA409T)]	E28F004SC@TSOP40 [(SA409T)]
E28F008BEB@TSOP40 [(SA409T)]	E28F008BET@TSOP40 [(SA409T)]
E28F008BLB@TSOP40 [(SA409T)]	E28F008BLT@TSOP40 [(SA409T)]
E28F008BVB@TSOP40 [(SA409T)]	E28F008BVT@TSOP40 [(SA409T)]
E28F008BXB@TSOP40 [(SA409T)]	E28F008BXT@TSOP40 [(SA409T)]
E28F008S3@TSOP40 [(SA409T)]	E28F008S5@TSOP40 [(SA409T)]
E28F008SA@TSOP40 [(SA409T)]	E28F008SA-L@TSOP40 [(SA409T)]
E28F008SC@TSOP40 [(SA409T)]	E28F010@TSOP32 [(SA410T)]
E28F016S3@TSOP40 [(SA409T)]	E28F016S5@TSOP40 [(SA409T)]
E28F016SA@TSOP56 [(SA628-B011)]	E28F016SC@TSOP40 [(SA409T)]
E28F016SV@TSOP56 [(SA628-B011)]	E28F020@TSOP32 [(SA410T)]
E28F128J3A@TSOP56 [(SA628-B018)]	E28F200B5B@TSOP48 [(SA247-B005)]
E28F200B5T@TSOP48 [(SA247-B005)]	E28F200BVB@TSOP56 [(SA628-B012)]
E28F200BVT@TSOP56 [(SA628-B012)]	E28F200BXB@TSOP56 [(SA628-B012)]
E28F200BXT@TSOP56 [(SA628-B012)]	E28F200CVB@TSOP48 [(SA247-B005)]
E28F200CVT@TSOP48 [(SA247-B005)]	E28F256@TSOP32 [(SA410T)]
E28F256A@TSOP32 [(SA410T)]	E28F320J3A@TSOP56 [(SA628-B018)]
E28F320J5(low)@TSOP56 [(SA628-B011)]	
E28F320J5@TSOP56 [(SA628-B011)]	
E28F320J5A(low)@TSOP56 [(SA628-B011)]	
E28F320J5A@TSOP56 [(SA628-B011)]	E28F400B5B@TSOP48 [(SA247-B005)]
E28F400B5T@TSOP48 [(SA247-B005)]	E28F400BVB@TSOP56 [(SA628-B012)]
E28F400BVT@TSOP56 [(SA628-B012)]	E28F400BXB@TSOP56 [(SA628-B012)]
E28F400BXT@TSOP56 [(SA628-B012)]	E28F400CVB@TSOP48 [(SA247-B005)]
E28F400CVT@TSOP48 [(SA247-B005)]	E28F512@TSOP32 [(SA410T)]
E28F640J3A@TSOP56 [(SA628-B018)]	E28F800B5B@TSOP48 [(SA247-B005)]

E28F800B5T@TSOP48 [(SA247-B005)] E28F800CEB@TSOP48 [(SA247-B005)]  
 E28F800CET@TSOP48 [(SA247-B005)] E28F800CVB@TSOP48 [(SA247-B005)]  
 E28F800CVT@TSOP48 [(SA247-B005)] E82802AA@TSOP40 [(SA409T)]  
 E82802AB@TSOP40 [(SA409T)] E82802AC@TSOP40 [(SA409T)]  
 F28F010@TSOP32 [(SA410T)]  
 F28F020(REVERSE)@TSOP32 [(SA410T)]  
 F28F020@TSOP32 [(SA410T)] F28F256@TSOP32 [(SA410T)]  
 F28F256A@TSOP32 [(SA410T)] F28F512@TSOP32 [(SA410T)]  
 G28F640J5@uBGA56 [(SA644A-B028A-Y072F001Y)]  
 G28F640J5A@uBGA56 [(SA644A-B028A-Y072F001Y)]  
 GE28F008B3BA@uBGA48 [(SA634)] GE28F008B3TA@uBGA48 [(SA634)]  
 GE28F128K18C@FBGA56 [(SA656D-B085A-T056F001Y)]  
 GE28F128K3C@FBGA56 [(SA656D-B085A-T056F001Y)]  
 GE28F128L18B@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F128L18T@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F128L30B@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F128L30T@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W30BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W30BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W30BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W30BD@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W30TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W30TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
 GE28F128W30TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F128W30TD@VFBGA56 [(SA656E-B085A-W056F001)]  
 GE28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F160B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F160B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F160C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F160C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]  
 GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]  
 GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]  
 GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]  
 GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]  
 GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]  
 GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 GE28F320C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F320C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
 GE28F320W18BC(NO EFP)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 GE28F320W18BE(SLOW)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 GE28F320W18TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 GE28F320W30BC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F320W30TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
 GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]

GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640W18BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
JS28F128J3C@TSOP56 [(SA628-B018)]  
JS28F128J3D@TSOP56 [(SA628-B018)]  
JS28F128P30B@TSOP56 [(SA628-B131)]  
JS28F128P30T@TSOP56 [(SA628-B131)]  
JS28F128P33B@TSOP56 [(SA628-B131)]  
JS28F128P33T@TSOP56 [(SA628-B131)]  
JS28F160B3BD@TSOP48 [(SA247-B005)]  
JS28F160B3TD@TSOP48 [(SA247-B005)]  
JS28F160C3BD@TSOP48 [(SA247-B005)]  
JS28F160C3TD@TSOP48 [(SA247-B005)]  
JS28F256J3C@TSOP56 [(SA628-B018)]  
JS28F256J3D@TSOP56 [(SA628-B018)]  
JS28F256P30B@TSOP56 [(SA628-B131)]  
JS28F256P30T@TSOP56 [(SA628-B131)]  
JS28F256P33B@TSOP56 [(SA628-B131)]  
JS28F256P33T@TSOP56 [(SA628-B131)]  
JS28F320B3BD@TSOP48 [(SA247-B005)]  
JS28F320B3TD@TSOP48 [(SA247-B005)]  
JS28F320C3BD@TSOP48 [(SA247-B005)]  
JS28F320C3TD@TSOP48 [(SA247-B005)]  
JS28F320J3C@TSOP56 [(SA628-B018)]  
JS28F320J3D@TSOP56 [(SA628-B018)]  
JS28F640J3C@TSOP56 [(SA628-B018)]

JS28F640J3D@TSOP56 [(SA628-B018)]  
 JS28F640P30B(Low)@TSOP56 [(SA628-B131)]  
 JS28F640P30B@TSOP56 [(SA628-B131)]  
 JS28F640P30T@TSOP56 [(SA628-B131)]  
 JS28F640P33B@TSOP56 [(SA628-B131)]  
 JS28F640P33T@TSOP56 [(SA628-B131)]  
 JS28F800C3BD@TSOP48 [(SA247-B005)]  
 JS28F800C3TD@TSOP48 [(SA247-B005)]  
 JS48F4400P0TB00@TSOP56 [(SA628-B164)]  
 JS48F4400P0VB00@TSOP56 [(SA628-B164)]  
 JS48F4400P0VT00@TSOP56 [(SA628-B164)]  
 JZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 JZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 JZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 JZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 LZ38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
 LZ38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
 LZ38F4070L0YBP1@FBGA137 [(SA678B-B162A-P137F001Y)]  
 M28F010 M28F010@PLCC32 [(SA015A1T)]  
 M28F010@TSOP32 [(SA410T)] N28F001BN-B@PLCC32 [(SA015A1T)]  
 N28F001BN-T@PLCC32 [(SA015A1T)] N28F001BX-B@PLCC32 [(SA015A1T)]  
 N28F001BX-T@PLCC32 [(SA015A1T)] N28F010@PLCC32 [(SA015A1T)]  
 N28F020@PLCC32 [(SA015A1T)] N28F256@PLCC32 [(SA015A1T)]  
 N28F256A@PLCC32 [(SA015A1T)] N28F512@PLCC32 [(SA015A1T)]  
 N82802AA@PLCC32 [(SA015A1T)] N82802AB@PLCC32 [(SA015A1T)]  
 N82802AC@PLCC32 [(SA015A1T)]  
 NZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 P27011 P27128A  
 P27128A@PLCC32 [(SA015A1T)] P27128B  
 P27128B@PLCC32 [(SA015A1T)] P27256  
 P27256@PLCC32 [(SA015A1T)] P27512  
 P27513 P2764A  
 P2764A@PLCC32 [(SA015A1T)] P27C011  
 P27C128 P27C128@PLCC32 [(SA015A1T)]  
 P27C256 P27C256@PLCC32 [(SA015A1T)]  
 P27C513 P27C64  
 P27C64@PLCC32 [(SA015A1T)] P28F001BX-B  
 P28F001BX-T P28F002BCT@TSOP40 [(SA409T)]  
 P28F010 P28F020  
 P28F256 P28F256A  
 P28F512 P87C64  
 P87C64@PLCC32 [(SA015A1T)] PA28F004S3@PSOP44 [(SA638)]  
 PA28F004S5@PSOP44 [(SA638)] PA28F004SC@PSOP44 [(SA638)]  
 PA28F008S3@PSOP44 [(SA638)] PA28F008S5@PSOP44 [(SA638)]  
 PA28F008SA@PSOP44 [(SA638)] PA28F008SA-L@PSOP44 [(SA638)]  
 PA28F008SC@PSOP44 [(SA638)] PA28F016S3@PSOP44 [(SA638)]  
 PA28F016S5@PSOP44 [(SA638)] PA28F016SC@PSOP44 [(SA638)]  
 PA28F200B5B@PSOP44 [(SA638)] PA28F200B5T@PSOP44 [(SA638)]  
 PA28F200BVB@PSOP44 [(SA638)] PA28F200BVT@PSOP44 [(SA638)]  
 PA28F200BVB@PSOP44 [(SA638)] PA28F200BXT@PSOP44 [(SA638)]  
 PA28F400B5B@PSOP44 [(SA638)] PA28F400B5T@PSOP44 [(SA638)]  
 PA28F400BVB@PSOP44 [(SA638)] PA28F400BVT@PSOP44 [(SA638)]  
 PA28F400BXT@PSOP44 [(SA638)] PA28F400BXT@PSOP44 [(SA638)]  
 PA28F800B5B@PSOP44 [(SA638)] PA28F800B5T@PSOP44 [(SA638)]  
 PA28F800BVB@PSOP44 [(SA638)] PA28F800BVT@PSOP44 [(SA638)]  
 PC28F128J3C@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
 PC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
 PC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
 PC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
 PC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
 PC28F256J3D@FBGA64 [(SA655M-B054A-T064F001Y)]  
 PC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
 PC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
 PC28F320J3C@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F640J3C@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
 PC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 PC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]

PC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
PC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
PC48F3300J0Z00S@FBGA64 [(SA655A-B054A-T064F001Y)]  
PC48F4400P0TB00@FBGA64 [(SA655G-B163A-T064F001Y)]  
PC48F4400P0VB00@FBGA64 [(SA655G-B163A-T064F001Y)]  
PC48F4400P0VT00@FBGA64 [(SA655G-B163A-T064F001Y)]  
PF38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030C0ZBL0@FBGA72 [(SA642R-B041A-T096F001Y)]  
PF38F1030C0ZTL0@FBGA72 [(SA642R-B041A-T096F001Y)]  
PF38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YQC3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0ZTQ0 (SLOW)@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YQC3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2040W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2040W0YQC1@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YQC3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F2040W0YUQ1@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F2040W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F2040W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3040L0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F3040L0YQC0@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3040L0YQC3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3040L0YTYQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0YTYQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0YTYQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF38F3040L0YUQ0@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3040L0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3040L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3040M0Y0CE@FBGA107 [(SA664F-B148A-W108F001N)]  
PF38F3040M0Y1QE@FBGA88 [(SA642R-B303A-T096F001Y)]  
PF38F3040M0Y3QE@FBGA88 [(SA642R-B303A-T096F001Y)]  
PF38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YQC0@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3050L0YQC2@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3050L0YQC3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0YUQ0@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3050L0YUQ2@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3050L0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]  
PF38F3050L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF38F3050L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF38F3050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]





PF48F3000M0Y0QE@FBGA88 [(SA642R-B300A-T096F001Y)]  
 PF48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
 PF48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
 PF48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
 PF48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
 PF48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
 PF48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
 PF48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
 PF48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
 PF48F3300W0YTTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
 PF48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 PF48F4000L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
 PF48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 PF48F4000M0Y0CE@FBGA107 [(SA664F-B148A-W108F001N)]  
 PF48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
 PF48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
 PF48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
 PF48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
 PF48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
 PF48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
 PF48F4400P0TBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F4400P0VBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F4400P0VTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
 PF48F5000M0Y0BE@FBGA105 [(SA664F-B298A-W108F001Y)]  
 PF48F5000M0Y0C0@FBGA107 [(SA664F-B148A-W108F001N)]  
 PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]  
 PH28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 PH28F128W18BC(VF)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 PH28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
 PH28F128W18BD(VF)@VFBGA56 [(SA656E-B085A-W056F001)]  
 PH28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 PH28F128W18TC(VF)@VFBGA56 [(SA656A-B085A-Y056F001)]  
 PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
 PH28F128W18TD(VF)@VFBGA56 [(SA656E-B085A-W056F001)]  
 PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 PH28F160C3BD(VF)@VFBGA48 [(SA634A-B005A-Y048F001)]  
 PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 PH28F160C3TD(VF)@VFBGA48 [(SA634A-B005A-Y048F001)]  
 PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
 PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
 PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 PH28F320C3BD(VF)@VFBGA48 [(SA634A-B005A-Y048F001)]  
 PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
 PH28F320C3TD(VF)@VFBGA48 [(SA634A-B005A-Y048F001)]  
 PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F320W18BE(SLOW)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F320W18BE(VF)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 PH28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
 QB25F016S33B60@SOIC8 [(SA605A)] QB25F016S33T60@SOIC8 [(SA605A)]  
 QB25F160S33B60@SOIC16 [(SA404)] QB25F160S33T60@SOIC16 [(SA404)]  
 QB25F320S33B60@SOIC16 [(SA404)] QB25F320S33T60@SOIC16 [(SA404)]  
 QB25F640S33B60@SOIC16 [(SA404)] QB25F640S33T60@SOIC16 [(SA404)]  
 QH25F016S33B60@SOIC8 [(SA605A)] QH25F016S33T60@SOIC8 [(SA605A)]  
 QH25F160S33B60@SOIC16 [(SA404)] QH25F160S33T60@SOIC16 [(SA404)]  
 QH25F320S33B60@SOIC16 [(SA404)] QH25F320S33T60@SOIC16 [(SA404)]  
 QH25F640S33B60@SOIC16 [(SA404)] QH25F640S33T60@SOIC16 [(SA404)]  
 RC28F128J3A@FBGA64 [(SA655A-B054A-T064F001)]  
 RC28F128J3C@FBGA64 [(SA655A-B054A-T064F001)]  
 RC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
 RC28F128K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
 RC28F128K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
 RC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
 RC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
 RC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
 RC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
 RC28F160C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
 RC28F160C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
 RC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
 RC28F160C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
 RC28F160C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]

RC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F256J3A@FBGA96 [(SA642A-B273-Y096N001N)]  
RC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256J3D@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256K18C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256K3C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F320C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F320J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F320J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F640C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F640C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F640J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F640J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F640K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F800C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC48F3300J0Z00S@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC48F4400P0TB00@FBGA64 [(SA655G-B163A-T064F001Y)]  
RC48F4400P0VB00@FBGA64 [(SA655G-B163A-T064F001Y)]  
RC48F4400P0VT00@FBGA64 [(SA655G-B163A-T064F001Y)]  
RD28F1602C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1602C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3208C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3208C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F6408W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]  
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2010W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]

RD38F2020W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0ZBQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0ZTQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2040W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2220WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWZDQ1@FBGA88 [(SA642A-B113A-Y096F001Y)]
RD38F2240WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F3040L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F3040L0YBQ0@FBGA88 [(SA642R-B180A-T096F001Y)]
RD38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F3040L0YUQ0@FBGA88 [(SA642R-B180A-T096F001Y)]
RD38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YBQ0@FBGA88 [(SA642R-B180A-T096F001Y)]
RD38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YUQ0@FBGA88 [(SA642R-B180A-T096F001Y)]
RD38F3050L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F3050L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F3340LLYDQ1@FBGA88 [(SA642A-B091A-Y096F001)]
RD38F3350LLZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD38F3350W0ZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD38F3350W0ZDQ1@FBGA88 [(SA642R-B137A-T096F001Y)]
RD38F4050L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YBQ0@FBGA88 [(SA642A-B180A-Y096F001Y)]
RD38F4050L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YUQ0@FBGA88 [(SA642A-B180A-Y096F001Y)]

RD38F4050L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4055L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F4070V0YBPD@FBGA137 [(SA678B-B162A-P137F001Y)]  
RD38F4350LLYBQ1@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4350LLYTQ1@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYBQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYBQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYTQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4450LVYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]  
RD38F4455LLYBQ0@FBGA88 [(SA642A-B125A-Y096N001N)]  
RD38F4455LLYBQ1@FBGA88 [(SA642A-B125A-Y096N001N)]  
RD38F4455LLYBQ2@FBGA88 [(SA642A-B125A-Y096N001N)]  
RD38F4455LLYTQ0@FBGA88 [(SA642A-B125A-Y096N001N)]  
RD38F4455LLYTQ1@FBGA88 [(SA642A-B125A-Y096N001N)]  
RD38F4455LLYTQ2@FBGA88 [(SA642A-B125A-Y096N001N)]  
RD38F4460LVYB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
RD38F4460LVYGB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
RD38F4460LVYTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
RD38F4470LLYBH0@FBGA137 [(SA678B-B159A-P137F001Y)]  
RD38F4470LLYFH0@FBGA137 [(SA678B-B159A-P137F001Y)]  
RD38F4470LLYGH0@FBGA137 [(SA678B-B159A-P137F001Y)]  
RD38F4470LLYTH0@FBGA137 [(SA678B-B159A-P137F001Y)]  
RD38F4470VVUBPD@FBGA137 [(SA678B-B162A-P137F001Y)]  
RD38F4470VVUTPD@FBGA137 [(SA678B-B162A-P137F001Y)]  
RD38F4476VVUBPD@FBGA137 [(SA678B-B162A-P137F001Y)]  
RD38F4476VVUTPD@FBGA137 [(SA678B-B162A-P137F001Y)]  
RD48F2000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F2000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F2000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F2000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F2000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F2000W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2000W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2000W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2000W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F2100W0YBQ0@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD48F2100W0YDQE@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD48F2100W0YTQ0@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD48F2200W0YBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0YDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0YTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0ZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0ZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F2200W0ZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD48F3000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
RD48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
RD48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
RD48F4040LVYBQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYBQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYTQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVYTQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZBQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZBQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZTQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
RD48F4040LVZTQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]

```

RD48F4040LVZTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4400P0TBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F4400P0VBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F4400P0VTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
TB28F004S3@PSOP44 [(SA638)]
TB28F004S5@PSOP44 [(SA638)]
TB28F004SC@PSOP44 [(SA638)]
TB28F008S3@PSOP44 [(SA638)]
TB28F008SA@PSOP44 [(SA638)]
TB28F008SA-L@PSOP44 [(SA638)]
TB28F008SC@PSOP44 [(SA638)]
TB28F016S3@PSOP44 [(SA638)]
TB28F016S5@PSOP44 [(SA638)]
TB28F016SC@PSOP44 [(SA638)]
TB28F200B5T@PSOP44 [(SA638)]
TB28F200B5B@PSOP44 [(SA638)]
TB28F200BVT@PSOP44 [(SA638)]
TB28F200BVB@PSOP44 [(SA638)]
TB28F200BXT@PSOP44 [(SA638)]
TB28F200BXB@PSOP44 [(SA638)]
TB28F200BXT@PSOP44 [(SA638)]
TB28F400B5T@PSOP44 [(SA638)]
TB28F400B5B@PSOP44 [(SA638)]
TB28F400BVT@PSOP44 [(SA638)]
TB28F400BVB@PSOP44 [(SA638)]
TB28F400BXT@PSOP44 [(SA638)]
TB28F400BXB@PSOP44 [(SA638)]
TB28F800B5T@PSOP44 [(SA638)]
TB28F800B5B@PSOP44 [(SA638)]
TB28F800BVT@PSOP44 [(SA638)]
TB28F800BVB@PSOP44 [(SA638)]
TE28F002BET@TSOP40 [(SA409T)]
TE28F002BVB@TSOP40 [(SA409T)]
TE28F002BXT@TSOP40 [(SA409T)]
TE28F002BXT@TSOP40 [(SA409T)]
TE28F002BXT@TSOP40 [(SA409T)]
TE28F004BET@TSOP40 [(SA409T)]
TE28F004BVB@TSOP40 [(SA409T)]
TE28F004BXT@TSOP40 [(SA409T)]
TE28F004BXT@TSOP40 [(SA409T)]
TE28F004S5@TSOP40 [(SA409T)]
TE28F004SC@TSOP40 [(SA409T)]
TE28F008B3B@TSOP40 [(SA409T)]
TE28F008B3BA@TSOP40 [(SA409T)]
TE28F008B3T@TSOP40 [(SA409T)]
TE28F008B3TA@TSOP40 [(SA409T)]
TE28F008BEB@TSOP40 [(SA409T)]
TE28F008BET@TSOP40 [(SA409T)]
TE28F008BVB@TSOP40 [(SA409T)]
TE28F008BVT@TSOP40 [(SA409T)]
TE28F008C3BA@TSOP40 [(SA409T)]
TE28F008C3TA@TSOP40 [(SA409T)]
TE28F008S3@TSOP40 [(SA409T)]
TE28F008S5@TSOP40 [(SA409T)]
TE28F008SA@TSOP40 [(SA409T)]
TE28F008SC@TSOP40 [(SA409T)]
TE28F016B3T@TSOP40 [(SA409T)]
TE28F016B3B@TSOP40 [(SA409T)]
TE28F016C3TA@TSOP40 [(SA409T)]
TE28F016C3BA@TSOP40 [(SA409T)]
TE28F016S5@TSOP40 [(SA409T)]
TE28F016SC@TSOP40 [(SA409T)]
TE28F128J3C@TSOP56 [(SA628-B018)]
TE28F128J3D@TSOP56 [(SA628-B018)]
TE28F128P30B@TSOP56 [(SA628-B131)]
TE28F128P30T@TSOP56 [(SA628-B131)]
TE28F128P33B@TSOP56 [(SA628-B131)]
TE28F128P33T@TSOP56 [(SA628-B131)]
TE28F160B3B@TSOP48 [(SA247-B005)]
TE28F160B3BA@TSOP48 [(SA247-B005)]
TE28F160B3BC@TSOP48 [(SA247-B005)]
TE28F160B3BD@TSOP48 [(SA247-B005)]
TE28F160B3T@TSOP48 [(SA247-B005)]
TE28F160B3TA@TSOP48 [(SA247-B005)]
TE28F160B3TC@TSOP48 [(SA247-B005)]
TE28F160B3TD@TSOP48 [(SA247-B005)]
TE28F160C3BA@TSOP48 [(SA247-B005)]
TE28F160C3BC@TSOP48 [(SA247-B005)]
TE28F160C3BD@TSOP48 [(SA247-B005)]
TE28F160C3TA@TSOP48 [(SA247-B005)]
TE28F160C3TC@TSOP48 [(SA247-B005)]
TE28F160C3TD@TSOP48 [(SA247-B005)]
TE28F160F3B@TSOP56 [(SA628-B014)]
TE28F160F3T@TSOP56 [(SA628-B014)]
TE28F160S3@TSOP56 [(SA628-B011)]
TE28F160S5@TSOP56 [(SA628-B011)]
TE28F200B5B@TSOP48 [(SA247-B005)]
TE28F200B5T@TSOP48 [(SA247-B005)]
TE28F200BVB@TSOP56 [(SA628-B012)]
TE28F200BVT@TSOP56 [(SA628-B012)]
TE28F200BXT@TSOP56 [(SA628-B012)]
TE28F200BXT@TSOP56 [(SA628-B012)]
TE28F200CEB@TSOP56 [(SA628-B012)]
TE28F200CET@TSOP56 [(SA628-B012)]
TE28F200CVB@TSOP48 [(SA247-B005)]
TE28F200CVT@TSOP48 [(SA247-B005)]
TE28F256J3C@TSOP56 [(SA628-B018)]
TE28F256J3D@TSOP56 [(SA628-B018)]
TE28F256P30B@TSOP56 [(SA628-B131)]
TE28F256P30T@TSOP56 [(SA628-B131)]
TE28F256P33B@TSOP56 [(SA628-B131)]
TE28F256P33T@TSOP56 [(SA628-B131)]
TE28F320B3B@TSOP48 [(SA247-B005)]
TE28F320B3BA@TSOP48 [(SA247-B005)]
TE28F320B3BC@TSOP48 [(SA247-B005)]
TE28F320B3BD@TSOP48 [(SA247-B005)]
TE28F320B3T@TSOP48 [(SA247-B005)]
TE28F320B3TA@TSOP48 [(SA247-B005)]

```

```

TE28F160S5@TSOP56 [(SA628-B011)]

```

TE28F320B3TC@TSOP48 [(SA247-B005)]  
 TE28F320B3TD@TSOP48 [(SA247-B005)]  
 TE28F320C3BA@TSOP48 [(SA247-B005)]  
 TE28F320C3BC@TSOP48 [(SA247-B005)]  
 TE28F320C3BD@TSOP48 [(SA247-B005)]  
 TE28F320C3TA@TSOP48 [(SA247-B005)]  
 TE28F320C3TC@TSOP48 [(SA247-B005)]  
 TE28F320C3TD@TSOP48 [(SA247-B005)]  
 TE28F320J3C@TSOP56 [(SA628-B018)]  
 TE28F320J3D@TSOP56 [(SA628-B018)]  
 TE28F400B3B@TSOP48 [(SA247-B005)]  
 TE28F400B3T@TSOP48 [(SA247-B005)]  
 TE28F400B5B@TSOP48 [(SA247-B005)]  
 TE28F400B5T@TSOP48 [(SA247-B005)]  
 TE28F400BVB@TSOP56 [(SA628-B012)]  
 TE28F400BVT@TSOP56 [(SA628-B012)]  
 TE28F400BXB@TSOP56 [(SA628-B012)]  
 TE28F400BXT@TSOP56 [(SA628-B012)]  
 TE28F400CEB@TSOP48 [(SA247-B005)]  
 TE28F400CET@TSOP48 [(SA247-B005)]  
 TE28F400CVB@TSOP48 [(SA247-B005)]  
 TE28F400CVT@TSOP48 [(SA247-B005)]  
 TE28F640B3BC@TSOP48 [(SA247-B005)]  
 TE28F640B3TC@TSOP48 [(SA247-B005)]  
 TE28F640C3BC@TSOP48 [(SA247-B005)]  
 TE28F640C3TC@TSOP48 [(SA247-B005)]  
 TE28F640J3C@TSOP56 [(SA628-B018)]  
 TE28F640J3D@TSOP56 [(SA628-B018)]  
 TE28F640P30B@TSOP56 [(SA628-B131)]  
 TE28F640P30T@TSOP56 [(SA628-B131)]  
 TE28F640P33B@TSOP56 [(SA628-B131)]  
 TE28F640P33T@TSOP56 [(SA628-B131)]  
 TE28F800B3B@TSOP48 [(SA247-B005)]  
 TE28F800B3BA@TSOP48 [(SA247-B005)]  
 TE28F800B3T@TSOP48 [(SA247-B005)]  
 TE28F800B3TA@TSOP48 [(SA247-B005)]  
 TE28F800B5B@TSOP48 [(SA247-B005)]  
 TE28F800B5T@TSOP48 [(SA247-B005)]  
 TE28F800C3BA@TSOP48 [(SA247-B005)]  
 TE28F800C3BD@TSOP48 [(SA247-B005)]  
 TE28F800C3TA@TSOP48 [(SA247-B005)]  
 TE28F800C3TD@TSOP48 [(SA247-B005)]  
 TE28F800CEB@TSOP48 [(SA247-B005)]  
 TE28F800CET@TSOP48 [(SA247-B005)]  
 TE28F800CVB@TSOP48 [(SA247-B005)]  
 TE28F800CVT@TSOP48 [(SA247-B005)]  
 TE28F800F3B@TSOP56 [(SA628-B014)]  
 TE28F800F3T@TSOP56 [(SA628-B014)]  
 TE48F4400P0TB00@TSOP56 [(SA628-B164)]  
 TE48F4400P0VB00@TSOP56 [(SA628-B164)]  
 TE48F4400P0VT00@TSOP56 [(SA628-B164)]

## PLD

5C031	5C031@PLCC20 [(SA001A)]
5C032	5C032@PLCC20 [(SA001A)]
5C090	5C090@PLCC44 [(SA244)]
5C180@PLCC68 [(PEP+S414T)]	85C090
85C090-P44 [(SA244)]	85C220
85C220@PLCC20 [(SA001A)]	IPLD910
IPLD910-P44 [(SA244)]	

## MICROCONTROLLER

8741	8741AH
8741AH@PLCC44 [(SA244)]	8741AH@TQFP44 [(SA245A)]
8742	8742AH
8742AH@PLCC44 [(SA244)]	8742AH@TQFP44 [(SA245A)]
8744	8744H
8748	8748 (25V)
8748H	8749
8749H	8751
8751BH	8751BH@PLCC44 [(SA244)]
8751H	8751H-8
8752BH	8752BH@PLCC44 [(SA244)]
8796BH@PLCC68 [(PEP+S414T)]	8796BH@PLCC68(*) [(SA648-B6803)]
8796JF@PLCC68 [(PEP+S414T)]	8796JF@PLCC68(*) [(SA648-B6803)]
8797BH@PGA68 [(PEP+S612)]	8797BH@PGA68(*) [(SA650-B6804)]

8797BH@PLCC68 [(PEP+S414T)]	8797BH@PLCC68(*) [(SA648-B6803)]
8797JF@PGA68 [(PEP+S612)]	8797JF@PGA68(*) [(SA650-B6804)]
8797JF@PLCC68 [(PEP+S414T)]	8797JF@PLCC68(*) [(SA648-B6803)]
8798	87C151SA
87C151SA@PLCC44 [(SA244)]	87C151SB
87C151SB@PLCC44 [(SA244)]	87C194@PLCC52 [(PEP+S415T)]
87C196CA@PLCC68 [(PEP+S414T)]	
87C196CA@PLCC68(*) [(SA648-B6805)]	
87C196JQ@PLCC52 [(PEP+S415T)]	
87C196JQ@PLCC52(*) [(SA647-B5201)]	
87C196JR@PLCC52 [(PEP+S415T)]	
87C196JR@PLCC52(*) [(SA647-B5201)]	
87C196JT@PLCC52 [(PEP+S415T)]	
87C196JT@PLCC52(*) [(SA647-B5201)]	
87C196JV@PLCC52 [(PEP+S415T)]	
87C196JV@PLCC52(*) [(SA647-B5201)]	
87C196KB@PGA68(*) [(S667+B309)]	87C196KB@PLCC68 [(PEP+S414T)]
87C196KB@PLCC68(*) [(SA648-B6801)]	
87C196KC@PGA68(*) [(S667+B309)]	87C196KC@PLCC68 [(PEP+S414T)]
87C196KC@PLCC68(*) [(SA648-B6801)]	
87C196KD@PGA68(*) [(S667+B309)]	87C196KD@PLCC68 [(PEP+S414T)]
87C196KD@PLCC68(*) [(SA648-B6801)]	
87C196KQ@PLCC68 [(PEP+S414T)]	
87C196KQ@PLCC68(*) [(SA648-B6802)]	
87C196KR@PLCC68 [(PEP+S414T)]	
87C196KR@PLCC68(*) [(SA648-B6802)]	
87C196KS@PLCC68 [(PEP+S414T)]	
87C196KS@PLCC68(*) [(SA648-B6802)]	
87C196KT@PLCC68 [(PEP+S414T)]	
87C196KT@PLCC68(*) [(SA648-B6802)]	
87C196LA@PLCC52 [(PEP+S415T)]	
87C196LA@PLCC52(*) [(SA647-B5201)]	
87C196MC@PLCC84 [(PEP+S416T)]	
87C196MC@PLCC84(*) [(SA649-B8401)]	
87C196MC@PQFP80 [(PEP+S611A)]	
87C196MC@PQFP80(*) [(TA026-B006)]	
87C196MC@SDIP64 [(PEP+S600A)]	87C196MC@SDIP64(*) [(SA651)]
87C196MH@PLCC84 [(PEP+S416T)]	
87C196MH@PLCC84(*) [(SA649-B8401)]	
87C196MH@PQFP80 [(PEP+S611A)]	
87C196MH@PQFP80(*) [(TA026-B006)]	
87C196MH@SDIP64 [(PEP+S600A)]	87C196MH@SDIP64(*) [(SA651)]
87C198@PLCC52 [(PEP+S415T)]	
87C251SA@PLCC44 [(SA244)]	87C251SA
87C251SB@PLCC44 [(SA244)]	87C251SB
87C251SP@PLCC44 [(SA244)]	87C251SP
87C251SQ@PLCC44 [(SA244)]	87C251SQ
87C42@PLCC44 [(SA244)]	87C42
87C51	87C42@TQFP44 [(SA245A)]
87C51@TQFP44 [(SA245A)]	87C51@PLCC44 [(SA244)]
87C51FA@PLCC44 [(SA244)]	87C51FA
87C51FB	87C51FA@TQFP44 [(SA245A)]
87C51FB@TQFP44 [(SA245A)]	87C51FB@PLCC44 [(SA244)]
87C51FC@PLCC44 [(SA244)]	87C51FC
87C51GB@PLCC68 [(PEP+S414T)]	87C51FC@TQFP44 [(SA245A)]
87C51RA@PLCC44 [(SA244)]	87C51RA
87C51RB	87C51RA@TQFP44 [(SA245A)]
87C51RB@TQFP44 [(SA245A)]	87C51RB@PLCC44 [(SA244)]
87C51RC@PLCC44 [(SA244)]	87C51RC
87C52	87C51RC@TQFP44 [(SA245A)]
87C52@TQFP44 [(SA245A)]	87C52@PLCC44 [(SA244)]
87C54@PLCC44 [(SA244)]	87C54
87C58	87C54@TQFP44 [(SA245A)]
87C58@TQFP44 [(SA245A)]	87C58@PLCC44 [(SA244)]
87L42@PLCC44 [(SA244)]	87L42
87L51FA@PLCC44 [(SA244)]	87L42@TQFP44 [(SA245A)]
87L51FB@PLCC44 [(SA244)]	87L51FA@TQFP44 [(SA245A)]
87L51FC@PLCC44 [(SA244)]	87L51FB@TQFP44 [(SA245A)]
87L52@PLCC44 [(SA244)]	87L51FC@TQFP44 [(SA245A)]
87L54@PLCC44 [(SA244)]	87L52@TQFP44 [(SA245A)]
87L58@PLCC44 [(SA244)]	87L54@TQFP44 [(SA245A)]
	87L58@TQFP44 [(SA245A)]

## INTEL-CUSTOMER

### E(E) PROM/FRAM/NVRAM

87J01H(YCL)@FBGA129 [(SA678A-B151A-Y129F001Y)]



87J01L(YCL)@FBGA129 [(SA678A-B150A-Y129F001Y)]  
 TE28F800C3TD@TSOP48 [(SA247-B005)]

## INTELSIL

### E(E) PROM/FRAM/NVRAM

HS-6617RH	HS-6617RH@SOIC24 [(SA404)]
HS-6617RH-T	HS-6617RH-T@SOIC24 [(SA404)]
HS-6883RH	HS-6883RH@SOIC24 [(SA404)]
HS-6883RH-T	HS-6883RH-T@SOIC24 [(SA404)]

## ISSI

### E(E) PROM/FRAM/NVRAM

IS24C01	IS24C01@MSOP8 [(SA666)]
IS24C01@SOIC8 [(SA602A)]	IS24C01@TSSOP8 [(SA026)]
IS24C01B	IS24C01B@MSOP8 [(SA666)]
IS24C01B@SOIC8 [(SA602A)]	IS24C01B@TSSOP8 [(SA026)]
IS24C02	IS24C02@MSOP8 [(SA666)]
IS24C02@SOIC8 [(SA602A)]	IS24C02@TSSOP8 [(SA026)]
IS24C02A	IS24C02A@DFN8
IS24C02A@MSOP8 [(SA666)]	IS24C02A@SOIC8 [(SA602A)]
IS24C02A@TSSOP8 [(SA026)]	IS24C02B
IS24C02B@DFN8	IS24C02B@MSOP8 [(SA666)]
IS24C02B@SOIC8 [(SA602A)]	IS24C02B@TSSOP8 [(SA026)]
IS24C02C	IS24C02C@DFN8
IS24C02C@MSOP8 [(SA666)]	IS24C02C@SOIC8 [(SA602A)]
IS24C02C@TSSOP8 [(SA026)]	IS24C04
IS24C04@MSOP8 [(SA666)]	IS24C04@SOIC8 [(SA602A)]
IS24C04@TSSOP8 [(SA026)]	IS24C04A
IS24C04A@DFN8	IS24C04A@MSOP8 [(SA666)]
IS24C04A@SOIC8 [(SA602A)]	IS24C04A@TSSOP8 [(SA026)]
IS24C08	IS24C08@MSOP8 [(SA666)]
IS24C08@SOIC8 [(SA602A)]	IS24C08@TSSOP8 [(SA026)]
IS24C08A	IS24C08A@DFN8
IS24C08A@MSOP8 [(SA666)]	IS24C08A@SOIC8 [(SA602A)]
IS24C08A@TSSOP8 [(SA026)]	IS24C128
IS24C128@SOIC8 [(SA602A)]	IS24C128@TSSOP14 [(SA026)]
IS24C16	IS24C16@MSOP8 [(SA666)]
IS24C16@SOIC8 [(SA602A)]	IS24C16@TSSOP8 [(SA026)]
IS24C16A	IS24C16A@MSOP8 [(SA666)]
IS24C16A@SOIC8 [(SA602A)]	IS24C16A@TSSOP8 [(SA026)]
IS24C256	IS24C256@SOIC8 [(SA602A)]
IS24C256@TSSOP14 [(SA026)]	IS24C256A
IS24C256A@SOIC8 [(SA602A)]	IS24C256A@TSSOP14 [(SA026)]
IS24C32	IS24C32@SOIC8 [(SA602A)]
IS24C32@TSSOP8 [(SA026)]	IS24C32A
IS24C32A@MSOP8 [(SA666)]	IS24C32A@SOIC8 [(SA602A)]
IS24C32A@TSSOP8 [(SA026)]	IS24C32B
IS24C32B@SOIC8 [(SA602A)]	IS24C32B@TSSOP8 [(SA026)]
IS24C32C	IS24C32C@DFN8 [(SA724)]
IS24C32C@MSOP8 [(SA666)]	IS24C32C@SOIC8 [(SA602A)]
IS24C32C@TSSOP8 [(SA026)]	IS24C64
IS24C64@SOIC8 [(SA602A)]	IS24C64@TSSOP8 [(SA026)]
IS24C64A	IS24C64A@MSOP8 [(SA666)]
IS24C64A@SOIC8 [(SA602A)]	IS24C64A@TSSOP8 [(SA026)]
IS24C64B	IS24C64B@SOIC8 [(SA602A)]
IS24C64B@TSSOP8 [(SA026)]	IS24L128
IS24L128@SOIC8(150mil) [(SA602A)]	
IS24L128@SOIC8(200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8(150mil) [(SA602A)]	
IS24L256@SOIC8(200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8 [(SA602A)]
IS25C01@TSSOP8 [(SA026)]	IS25C02
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8 [(SA026)]
IS25C04	IS25C04@SOIC8 [(SA602A)]
IS25C04@TSSOP8 [(SA026)]	IS25C08
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8 [(SA026)]
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8 [(SA026)]
IS25C16	IS25C16@SOIC8 [(SA602A)]
IS25C16@TSSOP8 [(SA026)]	IS25C256@SOIC8 [(SA602A)]

IS25C256@TSSOP8 [(SA026)]	IS25C32A
IS25C32A@SOIC8 [(SA602A)]	IS25C32A@TSSOP8 [(SA026)]
IS25C64A	IS25C64A@SOIC8 [(SA602A)]
IS25C64A@TSSOP8 [(SA026)]	IS27C010
IS27C010@PLCC32 [(SA015A1T)]	IS27C010@TSOP32 [(SA410T)]
IS27C020	IS27C020@PLCC32 [(SA015A1T)]
IS27C020@TSOP32 [(SA410T)]	IS27C256
IS27C256@PLCC32 [(SA015A1T)]	IS27C512
IS27C512@PLCC32 [(SA015A1T)]	IS27C512@TSOP28 [(SA430T)]
IS27HC010	IS27HC010@PLCC32 [(SA015A1T)]
IS27HC010@TSOP32 [(SA410T)]	IS27HC020
IS27HC020@PLCC32 [(SA015A1T)]	IS27HC020@TSOP32 [(SA410T)]
IS27HC256	IS27HC256@PLCC32 [(SA015A1T)]
IS27HC512	IS27HC512@PLCC32 [(SA015A1T)]
IS27HC512@TSOP28 [(SA430T)]	IS27LV010
IS27LV010@PLCC32 [(SA015A1T)]	IS27LV010@TSOP32 [(SA410T)]
IS27LV512	IS27LV512@PLCC32 [(SA015A1T)]
IS27LV512@TSOP28 [(SA430T)]	IS28F010
IS28F010@PLCC32 [(SA015A1T)]	IS28F010@TSOP32 [(SA410T)]
IS28F010A	IS28F010A@PLCC32 [(SA015A1T)]
IS28F010A@TSOP32 [(SA410T)]	IS28F020
IS28F020@PLCC32 [(SA015A1T)]	IS28F020@TSOP32 [(SA410T)]
IS29F010	IS29F010@PLCC32 [(SA015A1T)]
IS29F010@TSOP32 [(SA410T)]	IS34C02
IS34C02@MSOP8 [(SA666)]	IS34C02@SOIC8 [(SA602A)]
IS34C02@TSSOP8 [(SA026)]	IS34C02B@DFN8
IS34C02B@TSSOP8 [(SA026)]	
IS71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V08F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]	
IS71V08F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32B04@FBGA56 [(SA642A-B032A-Y096F001)]	
IS71V16F32B04@FBGA59 [(SA642A-B032A-Y096F001)]	
IS71V16F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71V16F32T04@FBGA56 [(SA642A-B032A-Y096F001)]	
IS71V16F32T04@FBGA59 [(SA642A-B032A-Y096F001)]	
IS71V16F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]	
IS71V16F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF32AS04@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF32BS04@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF32CS04@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF32DS04@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF32ES04@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF32FS04@FBGA73 [(SA642A-B032A-Y096F001)]	
IS71VPCF64GS08@FBGA73 [(SA642C-B032A-Y056F001)]	
IS75V16F64GS16@FBGA65 [(SA642C-B032A-Y056F001)]	
IS75V16F64GS32@FBGA65 [(SA642C-B032A-Y056F001)]	
IS93C46	IS93C46@SOIC8 [(SA602A)]
IS93C46A(08bit)	IS93C46A(08bit)@SOIC8 [(SA602A)]
IS93C46A(08bit)@TSSOP8 [(SA026)]	IS93C46A(16bit)
IS93C46A(16bit)@SOIC8 [(SA602A)]	IS93C46A(16bit)@TSSOP8 [(SA026)]
IS93C46B	IS93C46B@SOIC8 [(SA602A)]
IS93C46B@TSSOP8 [(SA026)]	IS93C46D(08bit)
IS93C46D(08bit)@SOIC8 [(SA602A)]	IS93C46D(08bit)@TSSOP8 [(SA026)]
IS93C46D(16bit)	IS93C46D(16bit)@SOIC8 [(SA602A)]
IS93C46D(16bit)@TSSOP8 [(SA026)]	IS93C56
IS93C56@SOIC8 [(SA602A)]	IS93C56A(08bit)
IS93C56A(08bit)@SOIC8 [(SA602A)]	IS93C56A(08bit)@TSSOP8 [(SA026)]
IS93C56A(16bit)	IS93C56A(16bit)@SOIC8 [(SA602A)]
IS93C56A(16bit)@TSSOP8 [(SA026)]	IS93C66
IS93C66@SOIC8 [(SA602A)]	IS93C66A(08bit)
IS93C66A(08bit)@SOIC8 [(SA602A)]	IS93C66A(08bit)@TSSOP8 [(SA026)]
IS93C66A(16bit)	IS93C66A(16bit)@SOIC8 [(SA602A)]
IS93C66A(16bit)@TSSOP8 [(SA026)]	IS93C76A(08bit)

IS93C76A(08bit)@SOIC8 [(SA602A)]	IS93C76A(08bit)@TSSOP8 [(SA026)]
IS93C76A(16bit)	IS93C76A(16bit)@SOIC8 [(SA602A)]
IS93C76A(16bit)@TSSOP8 [(SA026)]	IS93C86A(08bit)
IS93C86A(08bit)@SOIC8 [(SA602A)]	IS93C86A(08bit)@TSSOP8 [(SA026)]
IS93C86A(16bit)	IS93C86A(16bit)@SOIC8 [(SA602A)]
IS93C86A(16bit)@TSSOP8 [(SA026)]	

**DRAM & SRAM**

IS61C1024	IS61C1024(300m)@SOJ32 [(SA646)]
IS61C1024(400m)@SOJ32 [(SA661)]	IS61C1024@TSOP32 [(SA410T)]
IS61C1024L	IS61C1024L(300m)@SOJ32 [(SA646)]
IS61C1024L(400m)@SOJ32 [(SA661)]	IS61C1024L@TSOP32 [(SA410T)]
IS61C256AH	IS61C256AH@SOJ28 [(SA646)]
IS61C256AH@TSOP28 [(SA430T)]	IS61C512
IS61C512(300m)@SOJ32 [(SA646)]	IS61C512(400m)@SOJ32 [(SA661)]
IS61C512@TSOP32 [(SA410T)]	IS61C64AH
IS61C64AH@SOJ28 [(SA646)]	IS61C64AH@TSOP28 [(SA430T)]
IS61LV256	IS61LV256@SOJ28 [(SA646)]
IS61LV256@TSOP28 [(SA430T)]	IS61M256
IS61M256@SOJ28 [(SA646)]	IS61M256@TSOP28 [(SA430T)]
IS62C1024	IS62C1024(300m)@SOJ32 [(SA646)]
IS62C1024(400m)@SOJ32 [(SA661)]	IS62C1024@TSOP32 [(SA410T)]
IS62C256	IS62C256@SOJ28 [(SA646)]
IS62C256@TSOP28 [(SA430T)]	IS62C512
IS62C512(300m)@SOJ32 [(SA646)]	IS62C512(400m)@SOJ32 [(SA661)]
IS62C512@TSOP32 [(SA410T)]	IS62C64
IS62C64@SOJ28 [(SA646)]	IS62C64@TSOP28 [(SA430T)]
IS62LV256	IS62LV256@SOJ28 [(SA646)]
IS62LV256@TSOP28 [(SA430T)]	

**MICROCONTROLLER**

IS89C51A	IS89C51A@PLCC44 [(SA244)]
IS89C51A@TQFP44 [(SA245A)]	IS89C52A
IS89C52A@PLCC44 [(SA244)]	IS89C52A@TQFP44 [(SA245A)]

**ITHINKO**

**MICROCONTROLLER**

AX5012	AX5012(5.0V)@SOP24 [(SA404)]
AX5012(5.5V)@SOP24 [(SA404)]	AX5012(6.0V)@SOP24 [(SA404)]
AX5012@SOP24 [(SA404)]	AX5012@SOP32

**K-LINE**

**E(E) PROM/FRAM/NVRAM**

K24C32	K24C32@SOIC8 [(SA602A)]
K24C32@TSSOP8 [(SA026)]	K24C64
K24C64@SOIC8 [(SA602A)]	K24C64@TSSOP8 [(SA026)]

**LATTICE**

**PLD**

GAL16LV8	GAL16LV8@PLCC20 [(SA001A)]
GAL16LV8C	GAL16LV8C@PLCC20 [(SA001A)]
GAL16LV8D	GAL16LV8D@PLCC20 [(SA001A)]
GAL16LV8Z	GAL16LV8Z@PLCC20 [(SA001A)]
GAL16LV8ZD	GAL16LV8ZD@PLCC20 [(SA001A)]
GAL16V8	GAL16V8@PLCC20 [(SA001A)]
GAL16V8@SOIC20 [(SA404)]	GAL16V8A
GAL16V8A@PLCC20 [(SA001A)]	GAL16V8A@SOIC20 [(SA404)]
GAL16V8B	GAL16V8B@PLCC20 [(SA001A)]
GAL16V8B@SOIC20 [(SA404)]	GAL16V8C
GAL16V8C@PLCC20 [(SA001A)]	GAL16V8C@SOIC20 [(SA404)]
GAL16V8D	GAL16V8D@PLCC20 [(SA001A)]

GAL16V8D@SOIC20 [(SA404)]	GAL16V8Z
GAL16V8Z@PLCC20 [(SA001A)]	GAL16V8Z@SOIC20 [(SA404)]
GAL18V10	GAL18V10@PLCC20 [(SA001A)]
GAL18V10B	GAL18V10B@PLCC20 [(SA001A)]
GAL20LV8	GAL20LV8@PLCC28 [(SA008A)]
GAL20LV8Z	GAL20LV8Z@PLCC28 [(SA008A)]
GAL20LV8ZD	GAL20LV8ZD@PLCC28 [(SA008A)]
GAL20RA10	GAL20RA10@PLCC28 [(SA008A)]
GAL20RA10B	GAL20RA10B@PLCC28 [(SA008A)]
GAL20V8	GAL20V8@PLCC28 [(SA008A)]
GAL20V8A	GAL20V8A@PLCC28 [(SA008A)]
GAL20V8B	GAL20V8B@PLCC28 [(SA008A)]
GAL20V8C	GAL20V8C@PLCC28 [(SA008A)]
GAL20V8Z	GAL20V8Z@PLCC28 [(SA008A)]
GAL20XV10	GAL20XV10@PLCC28 [(SA008A)]
GAL20XV10B	GAL20XV10B@PLCC28 [(SA008A)]
GAL22LV10C	GAL22LV10C@PLCC28 [(SA008A)]
GAL22LV10C@SOIC24 [(SA404)]	GAL22LV10C@TSOP24 [(SA643)]
GAL22LV10D	GAL22LV10D@PLCC28 [(SA008A)]
GAL22LV10D@SOIC24 [(SA404)]	GAL22LV10D@TSOP24 [(SA643)]
GAL22LV10Z	GAL22LV10Z@PLCC28 [(SA008A)]
GAL22LV10Z@SOIC24 [(SA404)]	GAL22LV10Z@TSOP24 [(SA643)]
GAL22LV10ZD	GAL22LV10ZD@PLCC28 [(SA008A)]
GAL22LV10ZD@SOIC24 [(SA404)]	GAL22LV10ZD@TSOP24 [(SA643)]
GAL22V10	GAL22V10@PLCC28 [(SA008A)]
GAL22V10@SOIC24 [(SA404)]	GAL22V10A
GAL22V10A@PLCC28 [(SA008A)]	GAL22V10A@SOIC24 [(SA404)]
GAL22V10B	GAL22V10B@PLCC28 [(SA008A)]
GAL22V10B@SOIC24 [(SA404)]	GAL22V10BQ
GAL22V10BQ@PLCC28 [(SA008A)]	GAL22V10BQ@SOIC24 [(SA404)]
GAL22V10C	GAL22V10C@PLCC28 [(SA008A)]
GAL22V10C@SOIC24 [(SA404)]	GAL22V10D
GAL22V10D@PLCC28 [(SA008A)]	GAL22V10D@SOIC24 [(SA404)]
GAL26CLV12	GAL26CLV12@PLCC28 [(SA008A)]
GAL26CLV12@SOIC28 [(SA404)]	GAL26CLV12@TSOP28 [(SA643)]
GAL26CLV12B	GAL26CLV12B@PLCC28 [(SA008A)]
GAL26CLV12B@SOIC28 [(SA404)]	GAL26CLV12B@TSOP28 [(SA643)]
GAL26CLV12C	GAL26CLV12C@PLCC28 [(SA008A)]
GAL26CLV12C@SOIC28 [(SA404)]	GAL26CLV12C@TSOP28 [(SA643)]
GAL26CLV12D	GAL26CLV12D@PLCC28 [(SA008A)]
GAL26CLV12D@SOIC28 [(SA404)]	GAL26CLV12D@TSOP28 [(SA643)]
GAL26CLV12Z	GAL26CLV12Z@PLCC28 [(SA008A)]
GAL26CLV12Z@SOIC28 [(SA404)]	GAL26CLV12Z@TSOP28 [(SA643)]
GAL26CLV12ZD	GAL26CLV12ZD@PLCC28 [(SA008A)]
GAL26CLV12ZD@SOIC28 [(SA404)]	GAL26CLV12ZD@TSOP28 [(SA643)]
GAL26CV12	GAL26CV12@PLCC28 [(SA008A)]
GAL26CV12B	GAL26CV12B@PLCC28 [(SA008A)]
GAL26CV12C	GAL26CV12C@PLCC28 [(SA008A)]
GAL26V12C	GAL26V12C@PLCC28 [(SA008A)]
GAL6001B	GAL6001B@PLCC28 [(SA008A)]
GAL6002B	GAL6002B@PLCC28 [(SA008A)]
ispGAL22LV10	ispGAL22LV10(ISP) [ISP-HEADER01]
ispGAL22LV10@PLCC28 [(SA008A)]	
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10@SSOP28 [(SA626A)]	
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10A	
ispGAL22LV10A(ISP) [ISP-HEADER01]	
ispGAL22LV10A@PLCC28 [(SA008A)]	
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10A@SSOP28 [(SA626A)]	
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10B	
ispGAL22LV10B(ISP) [ISP-HEADER01]	
ispGAL22LV10B@PLCC28 [(SA008A)]	
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10B@SSOP28 [(SA626A)]	
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10C	
ispGAL22LV10C(ISP) [ISP-HEADER01]	
ispGAL22LV10C@PLCC28 [(SA008A)]	
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10C@SSOP28 [(SA626A)]	
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10D	
ispGAL22LV10D(ISP) [ISP-HEADER01]	
ispGAL22LV10D@PLCC28 [(SA008A)]	
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10D@SSOP28 [(SA626A)]	
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22V10AB@PLCC28 [(SA008A)]	ispGAL22V10AB@QFN32 [(SA686)]

```

ispGAL22V10AC@PLCC28 [(SA008A)]      ispGAL22V10AC@QFN32 [(SA686)]
ispGAL22V10AV@PLCC28 [(SA008A)]      ispGAL22V10AV@QFN32 [(SA686)]
ispGAL22V10C(UES)@PLCC28 [(SA008A)]
ispGAL22V10C@PLCC28 [(SA008A)]
ispGDX120A@TQFP176(ISP) [ISP-HEADER01]
ispGDX160@MQUAD208(ISP) [ISP-HEADER01]
ispGDX160V@MQUAD208(ISP) [ISP-HEADER01]
ispGDX160VA@PBGA208(ISP) [ISP-HEADER01]
ispGDX160VA@PBGA272(ISP) [ISP-HEADER01]
ispGDX160VA@PQFP208(ISP) [ISP-HEADER01]
ispGDX240VA@PBGA388(ISP) [ISP-HEADER01]
ispGDX80A@TQFP100(ISP) [ISP-HEADER01]
ispGDX80VA@CBGA100(ISP) [ISP-HEADER01]
ispGDX80VA@TQFP100 [(PEP+S604)]      ispLSI1016@PLCC44 [(SA244)]
ispLSI1016@TQFP44 [(SA245A)]         ispLSI1016E@PLCC44 [(SA244)]
ispLSI1016E@TQFP44 [(SA245A)]       ispLSI1016EA@PLCC44 [(SA244)]
ispLSI1016EA@TQFP44 [(SA245A)]      ispLSI1024@PLCC68 [(PEP+S414T)]
ispLSI1024E@PLCC68 [(PEP+S414T)]
ispLSI1024EA@PLCC68 [(PEP+S414T)]
ispLSI1032@PGA84 [(PEP+S667+B8403)]
ispLSI1032@PLCC84 [(PEP+S416T)]      ispLSI1032@TQFP100 [(PEP+S604)]
ispLSI1032E@PLCC84 [(PEP+S416T)]    ispLSI1032E@TQFP100 [(PEP+S604)]
ispLSI1032EA@TQFP100 [(PEP+S604)]
ispLSI1048EA@PQFP128(ISP) [ISP-HEADER01]
ispLSI2032@PLCC44 [(SA244)]         ispLSI2032@TQFP44 [(SA245A)]
ispLSI2032A@PLCC44 [(SA244)]        ispLSI2032A@TQFP44 [(SA245A)]
ispLSI2032A@TQFP48 [(SA248)]        ispLSI2032E@PLCC44 [(SA244)]
ispLSI2032E@TQFP44 [(SA245A)]      ispLSI2032E@TQFP48 [(SA248)]
ispLSI2032V@PLCC44 [(SA244)]        ispLSI2032V@TQFP44 [(SA245A)]
ispLSI2032V@TQFP48 [(SA248)]
ispLSI2032VE@CBGA49(ISP) [ISP-HEADER01]
ispLSI2032VE@PLCC44 [(SA244)]       ispLSI2032VE@TQFP44 [(SA245A)]
ispLSI2064@PLCC84 [(PEP+S416T)]     ispLSI2064@TQFP100 [(PEP+S604)]
ispLSI2064A@PLCC44 [(SA244)]        ispLSI2064A@PLCC84 [(PEP+S416T)]
ispLSI2064A@TQFP100 [(PEP+S604)]    ispLSI2064A@TQFP44 [(SA245A)]
ispLSI2064E@PQFP100 [(PEP+S427)]   ispLSI2064E@TQFP100 [(PEP+S604)]
ispLSI2064V@PLCC44 [(SA244)]        ispLSI2064V@PLCC84 [(PEP+S416T)]
ispLSI2064V@TQFP100 [(PEP+S604)]   ispLSI2064V@TQFP44 [(SA245A)]
ispLSI2064VE@CBGA100(ISP) [ISP-HEADER01]
ispLSI2064VE@PLCC44 [(SA244)]
ispLSI2064VE@PLCC84 [(PEP+S416T)]
ispLSI2064VE@TQFP100 [(PEP+S604)]
ispLSI2064VE@TQFP44 [(SA245A)]
ispLSI2096E@PQFP128(ISP) [ISP-HEADER01]
ispLSI2096E@TQFP128(ISP) [ISP-HEADER01]
ispLSI2096V@PQFP128(ISP) [ISP-HEADER01]
ispLSI2096V@TQFP128(ISP) [ISP-HEADER01]
ispLSI2096VE@PQFP128(ISP) [ISP-HEADER01]
ispLSI2096VE@TQFP128(ISP) [ISP-HEADER01]
ispLSI2128A@PLCC84 [(PEP+S416T)]
ispLSI2128A@PQFP160(ISP) [ISP-HEADER01]
ispLSI2128A@TQFP100 [(PEP+S604)]
ispLSI2128E@TQFP176(ISP) [ISP-HEADER01]
ispLSI2128V@PLCC84 [(PEP+S416T)]
ispLSI2128V@PQFP160(ISP) [ISP-HEADER01]
ispLSI2128V@TQFP100 [(PEP+S604)]
ispLSI2128V@TQFP176(ISP) [ISP-HEADER01]
ispLSI2128VE@CBGA100(ISP) [ISP-HEADER01]
ispLSI2128VE@PBGA208(ISP) [ISP-HEADER01]
ispLSI2128VE@PLCC84 [(PEP+S416T)]
ispLSI2128VE@PQFP160(ISP) [ISP-HEADER01]
ispLSI2128VE@TQFP100 [(PEP+S604)]
ispLSI2128VE@TQFP176(ISP) [ISP-HEADER01]
ispLSI2192VE@PBGA144(ISP) [ISP-HEADER01]
ispLSI2192VE@TQFP128(ISP) [ISP-HEADER01]
ispLSI5128VE@TQFP128(ISP) [ISP-HEADER01]
ispLSI5256A@PBGA272(ISP) [ISP-HEADER01]
ispLSI5256V@PBGA272(ISP) [ISP-HEADER01]
ispLSI5256VE@PBGA256(ISP) [ISP-HEADER01]
ispLSI5256VE@PBGA272(ISP) [ISP-HEADER01]
ispLSI5256VE@TQFP100 [(PEP+S604)]
ispLSI5256VE@TQFP128(ISP) [ISP-HEADER01]
ispLSI5384A@PBGA272(ISP) [ISP-HEADER01]
ispLSI5384V@PBGA272(ISP) [ISP-HEADER01]
ispLSI5384VE@PBGA256(ISP) [ISP-HEADER01]
ispLSI5384VE@PBGA272(ISP) [ISP-HEADER01]
ispLSI5384VE@PQFP208(ISP) [ISP-HEADER01]
ispLSI5512A@PBGA272(ISP) [ISP-HEADER01]
ispLSI5512V@PBGA272(ISP) [ISP-HEADER01]
ispLSI5512VE@PBGA256(ISP) [ISP-HEADER01]
ispLSI5512VE@PBGA272(ISP) [ISP-HEADER01]

```

```

ispLSI5512VE@PBGA388(ISP) [ISP-HEADER01]
ispLSI5512VE@PQFP208(ISP) [ISP-HEADER01]
ispLSI81080V@PBGA272(ISP) [ISP-HEADER01]
ispLSI81080V@PBGA492(ISP) [ISP-HEADER01]
ispLSI8600V@PBGA272(ISP) [ISP-HEADER01]
ispLSI8600V@PBGA492(ISP) [ISP-HEADER01]
ispLSI8840@SBGA352(ISP) [ISP-HEADER01]
ispLSI8840@SBGA432(ISP) [ISP-HEADER01]
ispLSI8840V@PBGA272(ISP) [ISP-HEADER01]
ispLSI8840V@PBGA492(ISP) [ISP-HEADER01]
ispPAL-POWR1208@TQFP44 [(SA245A)]
ispPAL-POWR1208P1@TQFP44 [(SA245A)]
ispPAL-POWR604@TQFP44 [(SA245A)] LC4032B@TQFP44 [(SA245A)]
LC4032B@TQFP44(ISP) [ISP-HEADER01]
LC4032B@TQFP48 [(SA248)]
LC4032B@TQFP48(ISP) [ISP-HEADER01]
LC4032C@TQFP44 [(SA245A)]
LC4032C@TQFP44(ISP) [ISP-HEADER01]
LC4032C@TQFP48 [(SA248)]
LC4032C@TQFP48(ISP) [ISP-HEADER01]
LC4032V@TQFP44 [(SA245A)]
LC4032V@TQFP44(ISP) [ISP-HEADER01]
LC4032V@TQFP48 [(SA248)]
LC4032V@TQFP48(ISP) [ISP-HEADER01]
LC4032ZC@csBGA56 [(SA699+B161)]
LC4032ZC@csBGA56(ISP) [ISP-HEADER01]
LC4032ZC@TQFP48 [(SA248)]
LC4032ZC@TQFP48(ISP) [ISP-HEADER01]
LC4032ZE@TQFP48 [(SA248)]
LC4032ZE@TQFP48(ISP) [ISP-HEADER01]
LC4064B@TQFP100 [(PEP+S604)]
LC4064B@TQFP100(*) [(TA074+B006)]
LC4064B@TQFP100(ISP) [ISP-HEADER01]
LC4064B@TQFP44 [(SA245A)]
LC4064B@TQFP44(ISP) [ISP-HEADER01]
LC4064B@TQFP48 [(SA248)]
LC4064B@TQFP48(ISP) [ISP-HEADER01]
LC4064C@TQFP100 [(PEP+S604)]
LC4064C@TQFP100(*) [(TA074+B006)]
LC4064C@TQFP100(ISP) [ISP-HEADER01]
LC4064C@TQFP44 [(SA245A)]
LC4064C@TQFP44(ISP) [ISP-HEADER01]
LC4064C@TQFP48 [(SA248)]
LC4064C@TQFP48(ISP) [ISP-HEADER01]
LC4064V@TQFP100 [(PEP+S604)]
LC4064V@TQFP100(*) [(TA074+B006)]
LC4064V@TQFP100(ISP) [ISP-HEADER01]
LC4064V@TQFP44 [(SA245A)]
LC4064V@TQFP44(ISP) [ISP-HEADER01]
LC4064V@TQFP48 [(SA248)]
LC4064V@TQFP48(ISP) [ISP-HEADER01]
LC4064ZC@csBGA56 [(SA699+B161)]
LC4064ZC@csBGA56(ISP) [ISP-HEADER01]
LC4064ZC@TQFP100 [(PEP+S604)]
LC4064ZC@TQFP100(*) [(TA074+B006)]
LC4064ZC@TQFP100(ISP) [ISP-HEADER01]
LC4064ZC@TQFP48 [(SA248)]
LC4064ZC@TQFP48(ISP) [ISP-HEADER01]
LC4064ZE@TQFP100 [(PEP+S604)]
LC4064ZE@TQFP100(*) [(TA074+B006)]
LC4064ZE@TQFP100(ISP) [ISP-HEADER01]
LC4064ZE@TQFP48 [(SA248)]
LC4064ZE@TQFP48(ISP) [ISP-HEADER01]
LC4128B@TQFP100 [(PEP+S604)]
LC4128B@TQFP100(*) [(TA074+B006)]
LC4128B@TQFP100(ISP) [ISP-HEADER01]
LC4128B@TQFP128(*) [(SA721+B195)]
LC4128B@TQFP128(ISP) [ISP-HEADER01]
LC4128C@TQFP100 [(PEP+S604)]
LC4128C@TQFP100(*) [(TA074+B006)]
LC4128C@TQFP100(ISP) [ISP-HEADER01]
LC4128C@TQFP128(*) [(SA721+B195)]
LC4128C@TQFP128(ISP) [ISP-HEADER01]
LC4128V@TQFP100 [(PEP+S604)]
LC4128V@TQFP100(*) [(TA074+B006)]
LC4128V@TQFP100(ISP) [ISP-HEADER01]
LC4128V@TQFP128(*) [(SA721+B195)]
LC4128V@TQFP128(ISP) [ISP-HEADER01]
LC4128V@TQFP144(*) [(SA681+B14406)]
LC4128V@TQFP144(ISP) [ISP-HEADER01]
LC4128ZC@csBGA132(ISP) [ISP-HEADER01]

```

LC4128ZC@TQFP100 [(PEP+S604)]  
LC4128ZC@TQFP100(\*) [(TA074+B006)]  
LC4128ZC@TQFP100(ISP) [ISP-HEADER01]  
LC4128ZC@TQFP128(\*) [(SA721+B195)]  
LC4128ZC@TQFP128(ISP) [ISP-HEADER01]  
LC4128ZE@TQFP100 [(PEP+S604)]  
LC4128ZE@TQFP100(\*) [(TA074+B006)]  
LC4128ZE@TQFP100(ISP) [ISP-HEADER01]  
LC4256B(128I/O)@FBGA256A [(SA800+B269)]  
LC4256B(128I/O)@FBGA256A(ISP) [ISP-HEADER01]  
LC4256B(160I/O)@FBGA256B [(SA800+B269)]  
LC4256B(160I/O)@FBGA256B(ISP) [ISP-HEADER01]  
LC4256B@TQFP100 [(PEP+S604)]  
LC4256B@TQFP100(\*) [(TA074+B006)]  
LC4256B@TQFP100(ISP) [ISP-HEADER01]  
LC4256B@TQFP176(ISP) [ISP-HEADER01]  
LC4256C(128I/O)@FBGA256A [(SA800+B269)]  
LC4256C(128I/O)@FBGA256A(ISP) [ISP-HEADER01]  
LC4256C(160I/O)@FBGA256B [(SA800+B269)]  
LC4256C(160I/O)@FBGA256B(ISP) [ISP-HEADER01]  
LC4256C@TQFP100 [(PEP+S604)]  
LC4256C@TQFP100(\*) [(TA074+B006)]  
LC4256C@TQFP100(ISP) [ISP-HEADER01]  
LC4256C@TQFP176(ISP) [ISP-HEADER01]  
LC4256V(128I/O)@FBGA256A [(SA800+B269)]  
LC4256V(128I/O)@FBGA256A(ISP) [ISP-HEADER01]  
LC4256V(160I/O)@FBGA256B [(SA800+B269)]  
LC4256V(160I/O)@FBGA256B(ISP) [ISP-HEADER01]  
LC4256V@TQFP100 [(PEP+S604)]  
LC4256V@TQFP100(\*) [(TA074+B006)]  
LC4256V@TQFP100(ISP) [ISP-HEADER01]  
LC4256V@TQFP144(\*) [(SA681+B14406)]  
LC4256V@TQFP176(ISP) [ISP-HEADER01]  
LC4256ZC@csBGA132(ISP) [ISP-HEADER01]  
LC4256ZC@TQFP100 [(PEP+S604)]  
LC4256ZC@TQFP100(\*) [(TA074+B006)]  
LC4256ZC@TQFP100(ISP) [ISP-HEADER01]  
LC4256ZC@TQFP176(ISP) [ISP-HEADER01]  
LC4256ZE@TQFP100 [(PEP+S604)]  
LC4256ZE@TQFP100(\*) [(TA074+B006)]  
LC4256ZE@TQFP100(ISP) [ISP-HEADER01]  
LC4384B@FBGA256 [(SA800+B269)]  
LC4384B@FBGA256(ISP) [ISP-HEADER01]  
LC4384B@TQFP176(ISP) [ISP-HEADER01]  
LC4384C@FBGA256 [(SA800+B269)]  
LC4384C@FBGA256(ISP) [ISP-HEADER01]  
LC4384C@TQFP176(ISP) [ISP-HEADER01]  
LC4384V@FBGA256 [(SA800+B269)]  
LC4384V@FBGA256(ISP) [ISP-HEADER01]  
LC4384V@TQFP176(ISP) [ISP-HEADER01]  
LC4512B@FBGA256 [(SA800+B269)]  
LC4512B@FBGA256(ISP) [ISP-HEADER01]  
LC4512B@TQFP176(ISP) [ISP-HEADER01]  
LC4512C@FBGA256 [(SA800+B269)]  
LC4512C@FBGA256(ISP) [ISP-HEADER01]  
LC4512C@TQFP176(ISP) [ISP-HEADER01]  
LC4512V@FBGA256 [(SA800+B269)]  
LC4512V@FBGA256(ISP) [ISP-HEADER01]  
LC4512V@TQFP176(ISP) [ISP-HEADER01]  
LC51024MB@fpBGA484(ISP) [ISP-HEADER01]  
LC51024MB@fpBGA672(ISP) [ISP-HEADER01]  
LC51024MC@fpBGA484(ISP) [ISP-HEADER01]  
LC51024MC@fpBGA672(ISP) [ISP-HEADER01]  
LC51024MV@fpBGA484(ISP) [ISP-HEADER01]  
LC51024MV@fpBGA672(ISP) [ISP-HEADER01]  
LC5128B@TQFP128(ISP) [ISP-HEADER01]  
LC5256B@fpBGA256(ISP) [ISP-HEADER01]  
LC5256B@PQFP208(ISP) [ISP-HEADER01]  
LC5256B@TQFP128(ISP) [ISP-HEADER01]  
LC5256MB@fpBGA256(ISP) [ISP-HEADER01]  
LC5256MC@fpBGA256(ISP) [ISP-HEADER01]  
LC5256MV@fpBGA256(ISP) [ISP-HEADER01]  
LC5384B@fpBGA256(ISP) [ISP-HEADER01]  
LC5384B@PQFP208(ISP) [ISP-HEADER01]  
LC5512B@fpBGA256(ISP) [ISP-HEADER01]  
LC5512B@fpBGA484(ISP) [ISP-HEADER01]  
LC5512B@PQFP208(ISP) [ISP-HEADER01]  
LC5512MB@fpBGA256(ISP) [ISP-HEADER01]  
LC5512MB@fpBGA484(ISP) [ISP-HEADER01]  
LC5512MB@PQFP208(ISP) [ISP-HEADER01]  
LC5512MC@fpBGA256(ISP) [ISP-HEADER01]

LC5512MC@fpBGA484 (ISP) [ISP-HEADER01]  
LC5512MC@PQFP208 (ISP) [ISP-HEADER01]  
LC5512MV@fpBGA256 (ISP) [ISP-HEADER01]  
LC5512MV@fpBGA484 (ISP) [ISP-HEADER01]  
LC5512MV@PQFP208 (ISP) [ISP-HEADER01]  
LC5768MB@fpBGA256 (ISP) [ISP-HEADER01]  
LC5768MB@fpBGA484 (ISP) [ISP-HEADER01]  
LC5768MC@fpBGA256 (ISP) [ISP-HEADER01]  
LC5768MC@fpBGA484 (ISP) [ISP-HEADER01]  
LC5768MV@fpBGA256 (ISP) [ISP-HEADER01]  
LC5768MV@fpBGA484 (ISP) [ISP-HEADER01]  
LCMXO1200C3TN100 [(PEP+S604)]  
LCMXO1200C-FT256(\*) [(SA800-B208)]  
LCMXO1200C-FT256 (ISP) [ISP-HEADER01]  
LCMXO1200C-FT324 (ISP) [ISP-HEADER01]  
LCMXO1200C-FTN256(\*) [(SA800-B208)]  
LCMXO1200C-FTN256 (ISP) [ISP-HEADER01]  
LCMXO1200C-FTN324 (ISP) [ISP-HEADER01]  
LCMXO1200C-M100 (ISP) [ISP-HEADER01]  
LCMXO1200C-M132 (ISP) [ISP-HEADER01]  
LCMXO1200C-MN100 (ISP) [ISP-HEADER01]  
LCMXO1200C-MN132 (ISP) [ISP-HEADER01]  
LCMXO1200C-T100 [(PEP+S604)]  
LCMXO1200C-T100(\*) [(SA773+B346)]  
LCMXO1200C-T100 (ISP) [ISP-HEADER01]  
LCMXO1200C-T144(\*) [(SA681+B14417)]  
LCMXO1200C-T144 (ISP) [ISP-HEADER01]  
LCMXO1200C-TN100 [(PEP+S604)]  
LCMXO1200C-TN100(\*) [(SA773+B346)]  
LCMXO1200C-TN100 (ISP) [ISP-HEADER01]  
LCMXO1200C-TN144(\*) [(SA681+B14417)]  
LCMXO1200C-TN144 (ISP) [ISP-HEADER01]  
LCMXO1200E3TN100 [(PEP+S604)]  
LCMXO1200E-FT256(\*) [(SA800-B208)]  
LCMXO1200E-FT256 (ISP) [ISP-HEADER01]  
LCMXO1200E-FT324 (ISP) [ISP-HEADER01]  
LCMXO1200E-FTN256(\*) [(SA800-B208)]  
LCMXO1200E-FTN256 (ISP) [ISP-HEADER01]  
LCMXO1200E-FTN324 (ISP) [ISP-HEADER01]  
LCMXO1200E-M100 (ISP) [ISP-HEADER01]  
LCMXO1200E-M132 (ISP) [ISP-HEADER01]  
LCMXO1200E-MN100 (ISP) [ISP-HEADER01]  
LCMXO1200E-MN132 (ISP) [ISP-HEADER01]  
LCMXO1200E-T100 [(PEP+S604)]  
LCMXO1200E-T100(\*) [(SA773+B346)]  
LCMXO1200E-T100 (ISP) [ISP-HEADER01]  
LCMXO1200E-T144(\*) [(SA681+B14417)]  
LCMXO1200E-T144 (ISP) [ISP-HEADER01]  
LCMXO1200E-TN100 [(PEP+S604)]  
LCMXO1200E-TN100(\*) [(SA773+B346)]  
LCMXO1200E-TN100 (ISP) [ISP-HEADER01]  
LCMXO1200E-TN144(\*) [(SA681+B14417)]  
LCMXO1200E-TN144 (ISP) [ISP-HEADER01]  
LCMXO22800C-FT256(\*) [(SA800-B208)]  
LCMXO22800C-FTN256(\*) [(SA800-B208)]  
LCMXO22800E-FT256(\*) [(SA800-B208)]  
LCMXO22800E-FTN256(\*) [(SA800-B208)]  
LCMXO2280C3TN100 [(PEP+S604)]  
LCMXO2280C-FT256 (ISP) [ISP-HEADER01]  
LCMXO2280C-FT324 (ISP) [ISP-HEADER01]  
LCMXO2280C-FTN256 (ISP) [ISP-HEADER01]  
LCMXO2280C-FTN324 (ISP) [ISP-HEADER01]  
LCMXO2280C-M100 (ISP) [ISP-HEADER01]  
LCMXO2280C-M132 (ISP) [ISP-HEADER01]  
LCMXO2280C-MN100 (ISP) [ISP-HEADER01]  
LCMXO2280C-MN132 (ISP) [ISP-HEADER01]  
LCMXO2280C-T100 [(PEP+S604)]  
LCMXO2280C-T100(\*) [(SA773+B346)]  
LCMXO2280C-T100 (ISP) [ISP-HEADER01]  
LCMXO2280C-T144(\*) [(SA681+B14417)]  
LCMXO2280C-T144 (ISP) [ISP-HEADER01]  
LCMXO2280C-TN100 [(PEP+S604)]  
LCMXO2280C-TN100(\*) [(SA773+B346)]  
LCMXO2280C-TN100 (ISP) [ISP-HEADER01]  
LCMXO2280C-TN144(\*) [(SA681+B14417)]  
LCMXO2280C-TN144 (ISP) [ISP-HEADER01]  
LCMXO2280E3TN100 [(PEP+S604)]  
LCMXO2280E-FT256 (ISP) [ISP-HEADER01]  
LCMXO2280E-FT324 (ISP) [ISP-HEADER01]  
LCMXO2280E-FTN256 (ISP) [ISP-HEADER01]  
LCMXO2280E-FTN324 (ISP) [ISP-HEADER01]



```
LCMXO2280E-M100(ISP) [ISP-HEADER01]
LCMXO2280E-M132(ISP) [ISP-HEADER01]
LCMXO2280E-MN100(ISP) [ISP-HEADER01]
LCMXO2280E-MN132(ISP) [ISP-HEADER01]
LCMXO2280E-T100 [(PEP+S604)]
LCMXO2280E-T100(*) [(SA773+B346)]
LCMXO2280E-T100(ISP) [ISP-HEADER01]
LCMXO2280E-T144(*) [(SA681+B14417)]
LCMXO2280E-T144(ISP) [ISP-HEADER01]
LCMXO2280E-TN100 [(PEP+S604)]
LCMXO2280E-TN100(*) [(SA773+B346)]
LCMXO2280E-TN100(ISP) [ISP-HEADER01]
LCMXO2280E-TN144(*) [(SA681+B14417)]
LCMXO2280E-TN144(ISP) [ISP-HEADER01]
LCMXO256C3TN100 [(PEP+S604)]
LCMXO256C-FT256(ISP) [ISP-HEADER01]
LCMXO256C-FT324(ISP) [ISP-HEADER01]
LCMXO256C-FTN256(ISP) [ISP-HEADER01]
LCMXO256C-FTN324(ISP) [ISP-HEADER01]
LCMXO256C-M100(ISP) [ISP-HEADER01]
LCMXO256C-M132(ISP) [ISP-HEADER01]
LCMXO256C-MN100(ISP) [ISP-HEADER01]
LCMXO256C-MN132(ISP) [ISP-HEADER01]
LCMXO256C-T100 [(PEP+S604)]
LCMXO256C-T100(ISP) [ISP-HEADER01]
LCMXO256C-T144(*) [(SA681+B14417)]
LCMXO256C-T144(ISP) [ISP-HEADER01]
LCMXO256C-TN100 [(PEP+S604)]
LCMXO256C-TN100(ISP) [ISP-HEADER01]
LCMXO256C-TN144(*) [(SA681+B14417)]
LCMXO256C-TN144(ISP) [ISP-HEADER01]
LCMXO256C-TQ100(*) [(SA773+B341)]
LCMXO256E3TN100 [(PEP+S604)]
LCMXO256E-FT256(ISP) [ISP-HEADER01]
LCMXO256E-FT324(ISP) [ISP-HEADER01]
LCMXO256E-FTN256(ISP) [ISP-HEADER01]
LCMXO256E-FTN324(ISP) [ISP-HEADER01]
LCMXO256E-M100(ISP) [ISP-HEADER01]
LCMXO256E-M132(ISP) [ISP-HEADER01]
LCMXO256E-MN100(ISP) [ISP-HEADER01]
LCMXO256E-MN132(ISP) [ISP-HEADER01]
LCMXO256E-T100 [(PEP+S604)]
LCMXO256E-T100(ISP) [ISP-HEADER01]
LCMXO256E-T144(*) [(SA681+B14417)]
LCMXO256E-T144(ISP) [ISP-HEADER01]
LCMXO256E-TN100 [(PEP+S604)]
LCMXO256E-TN100(ISP) [ISP-HEADER01]
LCMXO256E-TN144(*) [(SA681+B14417)]
LCMXO256E-TN144(ISP) [ISP-HEADER01]
LCMXO256E-TQ100(*) [(SA773+B341)]
LCMXO640C3TN100 [(PEP+S604)]
LCMXO640C-FT256(*) [(SA800-B208)]
LCMXO640C-FT256(ISP) [ISP-HEADER01]
LCMXO640C-FT324(ISP) [ISP-HEADER01]
LCMXO640C-FTN256(*) [(SA800-B208)]
LCMXO640C-FTN256(ISP) [ISP-HEADER01]
LCMXO640C-FTN324(ISP) [ISP-HEADER01]
LCMXO640C-M100(ISP) [ISP-HEADER01]
LCMXO640C-M132(ISP) [ISP-HEADER01]
LCMXO640C-MN100(ISP) [ISP-HEADER01]
LCMXO640C-MN132(ISP) [ISP-HEADER01]
LCMXO640C-T100 [(PEP+S604)]
LCMXO640C-T100(ISP) [ISP-HEADER01]
LCMXO640C-T144(*) [(SA681+B14417)]
LCMXO640C-T144(ISP) [ISP-HEADER01]
LCMXO640C-TN100 [(PEP+S604)]
LCMXO640C-TN100(ISP) [ISP-HEADER01]
LCMXO640C-TN144(*) [(SA681+B14417)]
LCMXO640C-TN144(ISP) [ISP-HEADER01]
LCMXO640E3TN100 [(PEP+S604)]
LCMXO640E-FT256(*) [(SA800-B208)]
LCMXO640E-FT256(ISP) [ISP-HEADER01]
LCMXO640E-FT324(ISP) [ISP-HEADER01]
LCMXO640E-FTN256(*) [(SA800-B208)]
LCMXO640E-FTN256(ISP) [ISP-HEADER01]
LCMXO640E-FTN324(ISP) [ISP-HEADER01]
LCMXO640E-M100(ISP) [ISP-HEADER01]
LCMXO640E-M132(ISP) [ISP-HEADER01]
LCMXO640E-MN100(ISP) [ISP-HEADER01]
LCMXO640E-MN132(ISP) [ISP-HEADER01]
LCMXO640E-T100 [(PEP+S604)]
```

LCMXO640E-T100 (ISP) [ISP-HEADER01]  
LCMXO640E-T144 (\*) [(SA681+B14417)]  
LCMXO640E-T144 (ISP) [ISP-HEADER01]  
LCMXO640E-TN100 [(PEP+S604)]  
LCMXO640E-TN100 (ISP) [ISP-HEADER01]  
LCMXO640E-TN144 (\*) [(SA681+B14417)]  
LCMXO640E-TN144 (ISP) [ISP-HEADER01]  
LFXP10C-3F256C [(SA800A+B184)]  
LFXP10C-3F256C (ISP) [ISP-HEADER01]  
LFXP10C-3F256I [(SA800A+B184)]  
LFXP10C-3F256I (ISP) [ISP-HEADER01]  
LFXP10C-3F388C (ISP) [ISP-HEADER01]  
LFXP10C-3F388I (ISP) [ISP-HEADER01]  
LFXP10C-3FN256C [(SA800A+B184)]  
LFXP10C-3FN256C (ISP) [ISP-HEADER01]  
LFXP10C-3FN256I [(SA800A+B184)]  
LFXP10C-3FN256I (ISP) [ISP-HEADER01]  
LFXP10C-3FN388C (ISP) [ISP-HEADER01]  
LFXP10C-3FN388I (ISP) [ISP-HEADER01]  
LFXP10C-4F256C [(SA800A+B184)]  
LFXP10C-4F256C (ISP) [ISP-HEADER01]  
LFXP10C-4F256I [(SA800A+B184)]  
LFXP10C-4F256I (ISP) [ISP-HEADER01]  
LFXP10C-4F388C (ISP) [ISP-HEADER01]  
LFXP10C-4F388I (ISP) [ISP-HEADER01]  
LFXP10C-4FN256C [(SA800A+B184)]  
LFXP10C-4FN256C (ISP) [ISP-HEADER01]  
LFXP10C-4FN256I [(SA800A+B184)]  
LFXP10C-4FN256I (ISP) [ISP-HEADER01]  
LFXP10C-4FN388C (ISP) [ISP-HEADER01]  
LFXP10C-4FN388I (ISP) [ISP-HEADER01]  
LFXP10C-5F256C [(SA800A+B184)]  
LFXP10C-5F256C (ISP) [ISP-HEADER01]  
LFXP10C-5F256I [(SA800A+B184)]  
LFXP10C-5F256I (ISP) [ISP-HEADER01]  
LFXP10C-5F388C (ISP) [ISP-HEADER01]  
LFXP10C-5F388I (ISP) [ISP-HEADER01]  
LFXP10C-5FN256C [(SA800A+B184)]  
LFXP10C-5FN256C (ISP) [ISP-HEADER01]  
LFXP10C-5FN256I [(SA800A+B184)]  
LFXP10C-5FN256I (ISP) [ISP-HEADER01]  
LFXP10C-5FN388C (ISP) [ISP-HEADER01]  
LFXP10C-5FN388I (ISP) [ISP-HEADER01]  
LFXP10E-3F256C [(SA800A+B184)]  
LFXP10E-3F256C (ISP) [ISP-HEADER01]  
LFXP10E-3F256I [(SA800A+B184)]  
LFXP10E-3F256I (ISP) [ISP-HEADER01]  
LFXP10E-3F388C (ISP) [ISP-HEADER01]  
LFXP10E-3F388I (ISP) [ISP-HEADER01]  
LFXP10E-3FN256C [(SA800A+B184)]  
LFXP10E-3FN256C (ISP) [ISP-HEADER01]  
LFXP10E-3FN256I [(SA800A+B184)]  
LFXP10E-3FN256I (ISP) [ISP-HEADER01]  
LFXP10E-3FN388C (ISP) [ISP-HEADER01]  
LFXP10E-3FN388I (ISP) [ISP-HEADER01]  
LFXP10E-4F256C [(SA800A+B184)]  
LFXP10E-4F256C (ISP) [ISP-HEADER01]  
LFXP10E-4F256I [(SA800A+B184)]  
LFXP10E-4F256I (ISP) [ISP-HEADER01]  
LFXP10E-4F388C (ISP) [ISP-HEADER01]  
LFXP10E-4F388I (ISP) [ISP-HEADER01]  
LFXP10E-4FN256C [(SA800A+B184)]  
LFXP10E-4FN256C (ISP) [ISP-HEADER01]  
LFXP10E-4FN256I [(SA800A+B184)]  
LFXP10E-4FN256I (ISP) [ISP-HEADER01]  
LFXP10E-4FN388C (ISP) [ISP-HEADER01]  
LFXP10E-4FN388I (ISP) [ISP-HEADER01]  
LFXP10E-5F256C [(SA800A+B184)]  
LFXP10E-5F256C (ISP) [ISP-HEADER01]  
LFXP10E-5F256I [(SA800A+B184)]  
LFXP10E-5F256I (ISP) [ISP-HEADER01]  
LFXP10E-5F388C (ISP) [ISP-HEADER01]  
LFXP10E-5F388I (ISP) [ISP-HEADER01]  
LFXP10E-5FN256C [(SA800A+B184)]  
LFXP10E-5FN256C (ISP) [ISP-HEADER01]  
LFXP10E-5FN256I [(SA800A+B184)]  
LFXP10E-5FN256I (ISP) [ISP-HEADER01]  
LFXP10E-5FN388C (ISP) [ISP-HEADER01]  
LFXP10E-5FN388I (ISP) [ISP-HEADER01]  
LFXP15C-3F256C [(SA800A+B184)]  
LFXP15C-3F256C (ISP) [ISP-HEADER01]

LFXP15C-3F256I [(SA800A+B184)]  
LFXP15C-3F256I (ISP) [ISP-HEADER01]  
LFXP15C-3F388C (ISP) [ISP-HEADER01]  
LFXP15C-3F388I (ISP) [ISP-HEADER01]  
LFXP15C-3F484C (ISP) [ISP-HEADER01]  
LFXP15C-3F484I (ISP) [ISP-HEADER01]  
LFXP15C-3FN256C [(SA800A+B184)]  
LFXP15C-3FN256C (ISP) [ISP-HEADER01]  
LFXP15C-3FN256I [(SA800A+B184)]  
LFXP15C-3FN256I (ISP) [ISP-HEADER01]  
LFXP15C-3FN388C (ISP) [ISP-HEADER01]  
LFXP15C-3FN388I (ISP) [ISP-HEADER01]  
LFXP15C-3FN484C (ISP) [ISP-HEADER01]  
LFXP15C-3FN484I (ISP) [ISP-HEADER01]  
LFXP15C-4F256C [(SA800A+B184)]  
LFXP15C-4F256C (ISP) [ISP-HEADER01]  
LFXP15C-4F256I [(SA800A+B184)]  
LFXP15C-4F256I (ISP) [ISP-HEADER01]  
LFXP15C-4F388C (ISP) [ISP-HEADER01]  
LFXP15C-4F388I (ISP) [ISP-HEADER01]  
LFXP15C-4F484C (ISP) [ISP-HEADER01]  
LFXP15C-4F484I (ISP) [ISP-HEADER01]  
LFXP15C-4FN256C [(SA800A+B184)]  
LFXP15C-4FN256C (ISP) [ISP-HEADER01]  
LFXP15C-4FN256I [(SA800A+B184)]  
LFXP15C-4FN256I (ISP) [ISP-HEADER01]  
LFXP15C-4FN388C (ISP) [ISP-HEADER01]  
LFXP15C-4FN388I (ISP) [ISP-HEADER01]  
LFXP15C-4FN484C (ISP) [ISP-HEADER01]  
LFXP15C-4FN484I (ISP) [ISP-HEADER01]  
LFXP15C-5F256C [(SA800A+B184)]  
LFXP15C-5F256C (ISP) [ISP-HEADER01]  
LFXP15C-5F256I [(SA800A+B184)]  
LFXP15C-5F256I (ISP) [ISP-HEADER01]  
LFXP15C-5F388C (ISP) [ISP-HEADER01]  
LFXP15C-5F388I (ISP) [ISP-HEADER01]  
LFXP15C-5F484C (ISP) [ISP-HEADER01]  
LFXP15C-5F484I (ISP) [ISP-HEADER01]  
LFXP15C-5FN256C [(SA800A+B184)]  
LFXP15C-5FN256C (ISP) [ISP-HEADER01]  
LFXP15C-5FN256I [(SA800A+B184)]  
LFXP15C-5FN256I (ISP) [ISP-HEADER01]  
LFXP15C-5FN388C (ISP) [ISP-HEADER01]  
LFXP15C-5FN388I (ISP) [ISP-HEADER01]  
LFXP15C-5FN484C (ISP) [ISP-HEADER01]  
LFXP15C-5FN484I (ISP) [ISP-HEADER01]  
LFXP15E-3F256C [(SA800A+B184)]  
LFXP15E-3F256C (ISP) [ISP-HEADER01]  
LFXP15E-3F256I [(SA800A+B184)]  
LFXP15E-3F256I (ISP) [ISP-HEADER01]  
LFXP15E-3F388C (ISP) [ISP-HEADER01]  
LFXP15E-3F388I (ISP) [ISP-HEADER01]  
LFXP15E-3F484C (ISP) [ISP-HEADER01]  
LFXP15E-3F484I (ISP) [ISP-HEADER01]  
LFXP15E-3FN256C [(SA800A+B184)]  
LFXP15E-3FN256C (ISP) [ISP-HEADER01]  
LFXP15E-3FN256I [(SA800A+B184)]  
LFXP15E-3FN256I (ISP) [ISP-HEADER01]  
LFXP15E-3FN388C (ISP) [ISP-HEADER01]  
LFXP15E-3FN388I (ISP) [ISP-HEADER01]  
LFXP15E-3FN484C (ISP) [ISP-HEADER01]  
LFXP15E-3FN484I (ISP) [ISP-HEADER01]  
LFXP15E-4F256C [(SA800A+B184)]  
LFXP15E-4F256C (ISP) [ISP-HEADER01]  
LFXP15E-4F256I [(SA800A+B184)]  
LFXP15E-4F256I (ISP) [ISP-HEADER01]  
LFXP15E-4F388C (ISP) [ISP-HEADER01]  
LFXP15E-4F388I (ISP) [ISP-HEADER01]  
LFXP15E-4F484C (ISP) [ISP-HEADER01]  
LFXP15E-4F484I (ISP) [ISP-HEADER01]  
LFXP15E-4FN256C [(SA800A+B184)]  
LFXP15E-4FN256C (ISP) [ISP-HEADER01]  
LFXP15E-4FN256I [(SA800A+B184)]  
LFXP15E-4FN256I (ISP) [ISP-HEADER01]  
LFXP15E-4FN388C (ISP) [ISP-HEADER01]  
LFXP15E-4FN388I (ISP) [ISP-HEADER01]  
LFXP15E-4FN484C (ISP) [ISP-HEADER01]  
LFXP15E-4FN484I (ISP) [ISP-HEADER01]  
LFXP15E-5F256C [(SA800A+B184)]  
LFXP15E-5F256C (ISP) [ISP-HEADER01]  
LFXP15E-5F256I [(SA800A+B184)]

LFXP15E-5F256I (ISP) [ISP-HEADER01]  
LFXP15E-5F388C (ISP) [ISP-HEADER01]  
LFXP15E-5F388I (ISP) [ISP-HEADER01]  
LFXP15E-5F484C (ISP) [ISP-HEADER01]  
LFXP15E-5F484I (ISP) [ISP-HEADER01]  
LFXP15E-5FN256C [(SA800A+B184)]  
LFXP15E-5FN256C (ISP) [ISP-HEADER01]  
LFXP15E-5FN256I [(SA800A+B184)]  
LFXP15E-5FN256I (ISP) [ISP-HEADER01]  
LFXP15E-5FN388C (ISP) [ISP-HEADER01]  
LFXP15E-5FN388I (ISP) [ISP-HEADER01]  
LFXP15E-5FN484C (ISP) [ISP-HEADER01]  
LFXP15E-5FN484I (ISP) [ISP-HEADER01]  
LFXP20C-3F256C [(SA800A+B184)]  
LFXP20C-3F256C (ISP) [ISP-HEADER01]  
LFXP20C-3F256I [(SA800A+B184)]  
LFXP20C-3F256I (ISP) [ISP-HEADER01]  
LFXP20C-3F388C (ISP) [ISP-HEADER01]  
LFXP20C-3F388I (ISP) [ISP-HEADER01]  
LFXP20C-3F484C (ISP) [ISP-HEADER01]  
LFXP20C-3F484I (ISP) [ISP-HEADER01]  
LFXP20C-3FN256C [(SA800A+B184)]  
LFXP20C-3FN256C (ISP) [ISP-HEADER01]  
LFXP20C-3FN256I [(SA800A+B184)]  
LFXP20C-3FN256I (ISP) [ISP-HEADER01]  
LFXP20C-3FN388C (ISP) [ISP-HEADER01]  
LFXP20C-3FN388I (ISP) [ISP-HEADER01]  
LFXP20C-3FN484C (ISP) [ISP-HEADER01]  
LFXP20C-3FN484I (ISP) [ISP-HEADER01]  
LFXP20C-4F256C [(SA800A+B184)]  
LFXP20C-4F256C (ISP) [ISP-HEADER01]  
LFXP20C-4F256I [(SA800A+B184)]  
LFXP20C-4F256I (ISP) [ISP-HEADER01]  
LFXP20C-4F388C (ISP) [ISP-HEADER01]  
LFXP20C-4F388I (ISP) [ISP-HEADER01]  
LFXP20C-4F484C (ISP) [ISP-HEADER01]  
LFXP20C-4F484I (ISP) [ISP-HEADER01]  
LFXP20C-4FN256C [(SA800A+B184)]  
LFXP20C-4FN256C (ISP) [ISP-HEADER01]  
LFXP20C-4FN256I [(SA800A+B184)]  
LFXP20C-4FN256I (ISP) [ISP-HEADER01]  
LFXP20C-4FN388C (ISP) [ISP-HEADER01]  
LFXP20C-4FN388I (ISP) [ISP-HEADER01]  
LFXP20C-4FN484C (ISP) [ISP-HEADER01]  
LFXP20C-4FN484I (ISP) [ISP-HEADER01]  
LFXP20C-5F256C [(SA800A+B184)]  
LFXP20C-5F256C (ISP) [ISP-HEADER01]  
LFXP20C-5F256I [(SA800A+B184)]  
LFXP20C-5F256I (ISP) [ISP-HEADER01]  
LFXP20C-5F388C (ISP) [ISP-HEADER01]  
LFXP20C-5F388I (ISP) [ISP-HEADER01]  
LFXP20C-5F484C (ISP) [ISP-HEADER01]  
LFXP20C-5F484I (ISP) [ISP-HEADER01]  
LFXP20C-5FN256C [(SA800A+B184)]  
LFXP20C-5FN256C (ISP) [ISP-HEADER01]  
LFXP20C-5FN256I [(SA800A+B184)]  
LFXP20C-5FN256I (ISP) [ISP-HEADER01]  
LFXP20C-5FN388C (ISP) [ISP-HEADER01]  
LFXP20C-5FN388I (ISP) [ISP-HEADER01]  
LFXP20C-5FN484C (ISP) [ISP-HEADER01]  
LFXP20C-5FN484I (ISP) [ISP-HEADER01]  
LFXP20E-3F256C [(SA800A+B184)]  
LFXP20E-3F256C (ISP) [ISP-HEADER01]  
LFXP20E-3F256I [(SA800A+B184)]  
LFXP20E-3F256I (ISP) [ISP-HEADER01]  
LFXP20E-3F388C (ISP) [ISP-HEADER01]  
LFXP20E-3F388I (ISP) [ISP-HEADER01]  
LFXP20E-3F484C (ISP) [ISP-HEADER01]  
LFXP20E-3F484I (ISP) [ISP-HEADER01]  
LFXP20E-3FN256C [(SA800A+B184)]  
LFXP20E-3FN256C (ISP) [ISP-HEADER01]  
LFXP20E-3FN256I [(SA800A+B184)]  
LFXP20E-3FN256I (ISP) [ISP-HEADER01]  
LFXP20E-3FN388C (ISP) [ISP-HEADER01]  
LFXP20E-3FN388I (ISP) [ISP-HEADER01]  
LFXP20E-3FN484C (ISP) [ISP-HEADER01]  
LFXP20E-3FN484I (ISP) [ISP-HEADER01]  
LFXP20E-4F256C [(SA800A+B184)]  
LFXP20E-4F256C (ISP) [ISP-HEADER01]  
LFXP20E-4F256I [(SA800A+B184)]  
LFXP20E-4F256I (ISP) [ISP-HEADER01]

LFXP20E-4F388C( ISP) [ISP-HEADER01]  
LFXP20E-4F388I( ISP) [ISP-HEADER01]  
LFXP20E-4F484C( ISP) [ISP-HEADER01]  
LFXP20E-4F484I( ISP) [ISP-HEADER01]  
LFXP20E-4FN256C [(SA800A+B184)]  
LFXP20E-4FN256C( ISP) [ISP-HEADER01]  
LFXP20E-4FN256I [(SA800A+B184)]  
LFXP20E-4FN256I( ISP) [ISP-HEADER01]  
LFXP20E-4FN388C( ISP) [ISP-HEADER01]  
LFXP20E-4FN388I( ISP) [ISP-HEADER01]  
LFXP20E-4FN484C( ISP) [ISP-HEADER01]  
LFXP20E-4FN484I( ISP) [ISP-HEADER01]  
LFXP20E-5F256C [(SA800A+B184)]  
LFXP20E-5F256C( ISP) [ISP-HEADER01]  
LFXP20E-5F256I [(SA800A+B184)]  
LFXP20E-5F256I( ISP) [ISP-HEADER01]  
LFXP20E-5F388C( ISP) [ISP-HEADER01]  
LFXP20E-5F388I( ISP) [ISP-HEADER01]  
LFXP20E-5F484C( ISP) [ISP-HEADER01]  
LFXP20E-5F484I( ISP) [ISP-HEADER01]  
LFXP20E-5FN256C [(SA800A+B184)]  
LFXP20E-5FN256C( ISP) [ISP-HEADER01]  
LFXP20E-5FN256I [(SA800A+B184)]  
LFXP20E-5FN256I( ISP) [ISP-HEADER01]  
LFXP20E-5FN388C( ISP) [ISP-HEADER01]  
LFXP20E-5FN388I( ISP) [ISP-HEADER01]  
LFXP20E-5FN484C( ISP) [ISP-HEADER01]  
LFXP20E-5FN484I( ISP) [ISP-HEADER01]  
LFXP3C-3Q208C( ISP) [ISP-HEADER01]  
LFXP3C-3Q208I( ISP) [ISP-HEADER01]  
LFXP3C-3QN208C( ISP) [ISP-HEADER01]  
LFXP3C-3QN208I( ISP) [ISP-HEADER01]  
LFXP3C-3T100C( ISP) [ISP-HEADER01]  
LFXP3C-3T100I( ISP) [ISP-HEADER01]  
LFXP3C-3T144C( ISP) [ISP-HEADER01]  
LFXP3C-3T144I( ISP) [ISP-HEADER01]  
LFXP3C-3TN100C( ISP) [ISP-HEADER01]  
LFXP3C-3TN100I( ISP) [ISP-HEADER01]  
LFXP3C-3TN144C( ISP) [ISP-HEADER01]  
LFXP3C-3TN144I( ISP) [ISP-HEADER01]  
LFXP3C-4Q208C( ISP) [ISP-HEADER01]  
LFXP3C-4Q208I( ISP) [ISP-HEADER01]  
LFXP3C-4QN208C( ISP) [ISP-HEADER01]  
LFXP3C-4QN208I( ISP) [ISP-HEADER01]  
LFXP3C-4T100C( ISP) [ISP-HEADER01]  
LFXP3C-4T100I( ISP) [ISP-HEADER01]  
LFXP3C-4T144C( ISP) [ISP-HEADER01]  
LFXP3C-4T144I( ISP) [ISP-HEADER01]  
LFXP3C-4TN100C( ISP) [ISP-HEADER01]  
LFXP3C-4TN100I( ISP) [ISP-HEADER01]  
LFXP3C-4TN144C( ISP) [ISP-HEADER01]  
LFXP3C-4TN144I( ISP) [ISP-HEADER01]  
LFXP3C-5Q208C( ISP) [ISP-HEADER01]  
LFXP3C-5Q208I( ISP) [ISP-HEADER01]  
LFXP3C-5QN208C( ISP) [ISP-HEADER01]  
LFXP3C-5QN208I( ISP) [ISP-HEADER01]  
LFXP3C-5T100C( ISP) [ISP-HEADER01]  
LFXP3C-5T100I( ISP) [ISP-HEADER01]  
LFXP3C-5T144C( ISP) [ISP-HEADER01]  
LFXP3C-5T144I( ISP) [ISP-HEADER01]  
LFXP3C-5TN100C( ISP) [ISP-HEADER01]  
LFXP3C-5TN100I( ISP) [ISP-HEADER01]  
LFXP3C-5TN144C( ISP) [ISP-HEADER01]  
LFXP3C-5TN144I( ISP) [ISP-HEADER01]  
LFXP3E-3Q208C( ISP) [ISP-HEADER01]  
LFXP3E-3Q208I( ISP) [ISP-HEADER01]  
LFXP3E-3QN208C( ISP) [ISP-HEADER01]  
LFXP3E-3QN208I( ISP) [ISP-HEADER01]  
LFXP3E-3T100C( ISP) [ISP-HEADER01]  
LFXP3E-3T100I( ISP) [ISP-HEADER01]  
LFXP3E-3T144C( ISP) [ISP-HEADER01]  
LFXP3E-3T144I( ISP) [ISP-HEADER01]  
LFXP3E-3TN100C( ISP) [ISP-HEADER01]  
LFXP3E-3TN100I( ISP) [ISP-HEADER01]  
LFXP3E-3TN144C( ISP) [ISP-HEADER01]  
LFXP3E-3TN144I( ISP) [ISP-HEADER01]  
LFXP3E-4Q208C( ISP) [ISP-HEADER01]  
LFXP3E-4Q208I( ISP) [ISP-HEADER01]  
LFXP3E-4QN208C( ISP) [ISP-HEADER01]  
LFXP3E-4QN208I( ISP) [ISP-HEADER01]  
LFXP3E-4T100C( ISP) [ISP-HEADER01]

LFXP3E-4T100I (ISP) [ISP-HEADER01]  
 LFXP3E-4T144C (ISP) [ISP-HEADER01]  
 LFXP3E-4T144I (ISP) [ISP-HEADER01]  
 LFXP3E-4TN100C (ISP) [ISP-HEADER01]  
 LFXP3E-4TN100I (ISP) [ISP-HEADER01]  
 LFXP3E-4TN144C (ISP) [ISP-HEADER01]  
 LFXP3E-4TN144I (ISP) [ISP-HEADER01]  
 LFXP3E-5Q208C (ISP) [ISP-HEADER01]  
 LFXP3E-5Q208I (ISP) [ISP-HEADER01]  
 LFXP3E-5QN208C (ISP) [ISP-HEADER01]  
 LFXP3E-5QN208I (ISP) [ISP-HEADER01]  
 LFXP3E-5T100C (ISP) [ISP-HEADER01]  
 LFXP3E-5T100I (ISP) [ISP-HEADER01]  
 LFXP3E-5T144C (ISP) [ISP-HEADER01]  
 LFXP3E-5T144I (ISP) [ISP-HEADER01]  
 LFXP3E-5TN100C (ISP) [ISP-HEADER01]  
 LFXP3E-5TN100I (ISP) [ISP-HEADER01]  
 LFXP3E-5TN144C (ISP) [ISP-HEADER01]  
 LFXP3E-5TN144I (ISP) [ISP-HEADER01]  
 LFXP6C-3F256C [(SA800A+B184)]  
 LFXP6C-3F256C (ISP) [ISP-HEADER01]  
 LFXP6C-3F256I [(SA800A+B184)]  
 LFXP6C-3F256I (ISP) [ISP-HEADER01]  
 LFXP6C-3FN256C [(SA800A+B184)]  
 LFXP6C-3FN256C (ISP) [ISP-HEADER01]  
 LFXP6C-3FN256I [(SA800A+B184)]  
 LFXP6C-3FN256I (ISP) [ISP-HEADER01]  
 LFXP6C-3Q208C (ISP) [ISP-HEADER01]  
 LFXP6C-3Q208I (ISP) [ISP-HEADER01]  
 LFXP6C-3QN208C (ISP) [ISP-HEADER01]  
 LFXP6C-3QN208I (ISP) [ISP-HEADER01]  
 LFXP6C-3T144C (\*) [(SA681+B14407)]  
 LFXP6C-3T144C (ISP) [ISP-HEADER01]  
 LFXP6C-3T144I (\*) [(SA681+B14407)]  
 LFXP6C-3T144I (ISP) [ISP-HEADER01]  
 LFXP6C-3TN144C (\*) [(SA681+B14407)]  
 LFXP6C-3TN144C (ISP) [ISP-HEADER01]  
 LFXP6C-3TN144I (\*) [(SA681+B14407)]  
 LFXP6C-3TN144I (ISP) [ISP-HEADER01]  
 LFXP6C-4F256C [(SA800A+B184)]  
 LFXP6C-4F256C (ISP) [ISP-HEADER01]  
 LFXP6C-4F256I [(SA800A+B184)]  
 LFXP6C-4F256I (ISP) [ISP-HEADER01]  
 LFXP6C-4FN256C [(SA800A+B184)]  
 LFXP6C-4FN256C (ISP) [ISP-HEADER01]  
 LFXP6C-4FN256I [(SA800A+B184)]  
 LFXP6C-4FN256I (ISP) [ISP-HEADER01]  
 LFXP6C-4Q208C (ISP) [ISP-HEADER01]  
 LFXP6C-4Q208I (ISP) [ISP-HEADER01]  
 LFXP6C-4QN208C (ISP) [ISP-HEADER01]  
 LFXP6C-4QN208I (ISP) [ISP-HEADER01]  
 LFXP6C-4T144C (ISP) [ISP-HEADER01]  
 LFXP6C-4T144I (ISP) [ISP-HEADER01]  
 LFXP6C-4TN144C (ISP) [ISP-HEADER01]  
 LFXP6C-4TN144I (ISP) [ISP-HEADER01]  
 LFXP6C-5F256C [(SA800A+B184)]  
 LFXP6C-5F256C (ISP) [ISP-HEADER01]  
 LFXP6C-5F256I [(SA800A+B184)]  
 LFXP6C-5F256I (ISP) [ISP-HEADER01]  
 LFXP6C-5FN256C [(SA800A+B184)]  
 LFXP6C-5FN256C (ISP) [ISP-HEADER01]  
 LFXP6C-5FN256I [(SA800A+B184)]  
 LFXP6C-5FN256I (ISP) [ISP-HEADER01]  
 LFXP6C-5Q208C (ISP) [ISP-HEADER01]  
 LFXP6C-5Q208I (ISP) [ISP-HEADER01]  
 LFXP6C-5QN208C (ISP) [ISP-HEADER01]  
 LFXP6C-5QN208I (ISP) [ISP-HEADER01]  
 LFXP6C-5T144C (ISP) [ISP-HEADER01]  
 LFXP6C-5T144I (ISP) [ISP-HEADER01]  
 LFXP6C-5TN144C (ISP) [ISP-HEADER01]  
 LFXP6C-5TN144I (ISP) [ISP-HEADER01]  
 LFXP6E-3F256C [(SA800A+B184)]  
 LFXP6E-3F256C (ISP) [ISP-HEADER01]  
 LFXP6E-3F256I [(SA800A+B184)]  
 LFXP6E-3F256I (ISP) [ISP-HEADER01]  
 LFXP6E-3FN256C [(SA800A+B184)]  
 LFXP6E-3FN256C (ISP) [ISP-HEADER01]  
 LFXP6E-3FN256I [(SA800A+B184)]  
 LFXP6E-3FN256I (ISP) [ISP-HEADER01]  
 LFXP6E-3Q208C (ISP) [ISP-HEADER01]  
 LFXP6E-3Q208I (ISP) [ISP-HEADER01]

```

LFXP6E-3QN208C( ISP) [ISP-HEADER01]
LFXP6E-3QN208I( ISP) [ISP-HEADER01]
LFXP6E-3T144C( ISP) [ISP-HEADER01]
LFXP6E-3T144I( ISP) [ISP-HEADER01]
LFXP6E-3TN144C( ISP) [ISP-HEADER01]
LFXP6E-3TN144I( ISP) [ISP-HEADER01]
LFXP6E-4F256C [(SA800A+B184)]
LFXP6E-4F256C( ISP) [ISP-HEADER01]
LFXP6E-4F256I [(SA800A+B184)]
LFXP6E-4F256I( ISP) [ISP-HEADER01]
LFXP6E-4FN256C [(SA800A+B184)]
LFXP6E-4FN256C( ISP) [ISP-HEADER01]
LFXP6E-4FN256I [(SA800A+B184)]
LFXP6E-4FN256I( ISP) [ISP-HEADER01]
LFXP6E-4Q208C( ISP) [ISP-HEADER01]
LFXP6E-4Q208I( ISP) [ISP-HEADER01]
LFXP6E-4QN208C( ISP) [ISP-HEADER01]
LFXP6E-4QN208I( ISP) [ISP-HEADER01]
LFXP6E-4T144C( ISP) [ISP-HEADER01]
LFXP6E-4T144I( ISP) [ISP-HEADER01]
LFXP6E-4TN144C( ISP) [ISP-HEADER01]
LFXP6E-4TN144I( ISP) [ISP-HEADER01]
LFXP6E-5F256C [(SA800A+B184)]
LFXP6E-5F256C( ISP) [ISP-HEADER01]
LFXP6E-5F256I [(SA800A+B184)]
LFXP6E-5F256I( ISP) [ISP-HEADER01]
LFXP6E-5FN256C [(SA800A+B184)]
LFXP6E-5FN256C( ISP) [ISP-HEADER01]
LFXP6E-5FN256I [(SA800A+B184)]
LFXP6E-5FN256I( ISP) [ISP-HEADER01]
LFXP6E-5Q208C( ISP) [ISP-HEADER01]
LFXP6E-5Q208I( ISP) [ISP-HEADER01]
LFXP6E-5QN208C( ISP) [ISP-HEADER01]
LFXP6E-5QN208I( ISP) [ISP-HEADER01]
LFXP6E-5T144C( ISP) [ISP-HEADER01]
LFXP6E-5T144I( ISP) [ISP-HEADER01]
LFXP6E-5TN144C( ISP) [ISP-HEADER01]
LFXP6E-5TN144I( ISP) [ISP-HEADER01]
LX128B(EB)@fpBGA208( ISP) [ISP-HEADER01]
LX128B-2R@fpBGA208( ISP) [ISP-HEADER01]
LX128C(EC)@fpBGA208( ISP) [ISP-HEADER01]
LX128C-2R@fpBGA208( ISP) [ISP-HEADER01]
LX128V(EV)@fpBGA208( ISP) [ISP-HEADER01]
LX128V-2R@fpBGA208( ISP) [ISP-HEADER01]
LX256B(EB)@fpBGA484( ISP) [ISP-HEADER01]
LX256B-2R@fpBGA484( ISP) [ISP-HEADER01]
LX256C(EC)@fpBGA484( ISP) [ISP-HEADER01]
LX256C-2R@fpBGA484( ISP) [ISP-HEADER01]
LX256V(EV)@fpBGA484( ISP) [ISP-HEADER01]
LX256V-2R@fpBGA484( ISP) [ISP-HEADER01]
LX64B(EB)@fpBGA100( ISP) [ISP-HEADER01]
LX64B-2R@fpBGA100( ISP) [ISP-HEADER01]
LX64C(EC)@fpBGA100( ISP) [ISP-HEADER01]
LX64C-2R@fpBGA100( ISP) [ISP-HEADER01]
LX64V(EV)@fpBGA100( ISP) [ISP-HEADER01]
LX64V-2R@fpBGA100( ISP) [ISP-HEADER01]
M4-128/64@PQFP100 [(PEP+S427)] M4-128/64@TQFP100 [(PEP+S604)]
M4-128N/64@PLCC84 [(PEP+S416T)] M4A3-128/64@PQFP100 [(PEP+S427)]
M4A3-128/64@TQFP100 [(PEP+S604)]
M4A3-128N/64@PLCC84 [(PEP+S416T)]
M4A3-32/32@PLCC44 [(SA244)] M4A3-32/32@TQFP44 [(SA245A)]
M4A3-32/32@TQFP48 [(SA248)] M4A3-64/32@PLCC44 [(SA244)]
M4A3-64/32@TQFP44 [(SA245A)] M4A3-64/32@TQFP48 [(SA248)]
M4A3-64/64@TQFP100 [(PEP+S604)] M4A3-96/48@TQFP100 [(PEP+S604)]
M4A5-128/64@PQFP100 [(PEP+S427)] M4A5-128/64@TQFP100 [(PEP+S604)]
M4A5-128N/64@PLCC84 [(PEP+S416T)]
M4A5-32/32@PLCC44 [(SA244)] M4A5-32/32@TQFP44 [(SA245A)]
M4A5-32/32@TQFP48 [(SA248)] M4A5-64/32@PLCC44 [(SA244)]
M4A5-64/32@TQFP44 [(SA245A)] M4A5-64/32@TQFP48 [(SA248)]
M4A5-96/48@TQFP100 [(PEP+S604)] M4LV-128/64@PQFP100 [(PEP+S427)]
M4LV-128/64@TQFP100 [(PEP+S604)]
M4LV-128N/64@PLCC84 [(PEP+S416T)]
MACH110@PLCC44 [(SA244)] MACH111@PLCC44 [(SA244)]
MACH111@TQFP44 [(SA245A)] MACH120@PLCC68 [(PEP+S414T)]
MACH130@PLCC84 [(PEP+S416T)] MACH131/1@PLCC84 [(PEP+S416T)]
MACH131@PLCC84 [(PEP+S416T)] MACH131SP@PQFP100 [(PEP+S427)]
MACH131SP@TQFP100 [(PEP+S604)] MACH210@PLCC44 [(SA244)]
MACH210@TQFP44 [(SA245A)] MACH210A@PLCC44 [(SA244)]
MACH210A@TQFP44 [(SA245A)] MACH210AQ@PLCC44 [(SA244)]
MACH210AQ@TQFP44 [(SA245A)] MACH211@PLCC44 [(SA244)]
MACH211@TQFP44 [(SA245A)] MACH211SP@PLCC44 [(SA244)]

```

MACH211SP@TQFP44 [(SA245A)]	MACH220@PLCC68 [(PEP+S414T)]
MACH221@PLCC68 [(PEP+S414T)]	MACH230@PLCC84 [(PEP+S416T)]
MACH231@PLCC84 [(PEP+S416T)]	MACH231SP@PLCC84 [(PEP+S416T)]
MACH231SP@PQFP100 [(PEP+S427)]	MACH231SP@TQFP100 [(PEP+S604)]
MACH435@PLCC84 [(PEP+S416T)]	MACH436@PLCC84 [(PEP+S416T)]
MACH446@PQFP100 [(PEP+S427)]	MACH446@TQFP100 [(PEP+S604)]
MACHLV210@PLCC44 [(SA244)]	MACHLV436@PLCC84 [(PEP+S416T)]
MACHLV446@PQFP100 [(PEP+S427)]	MACHLV446@TQFP100 [(PEP+S604)]
PAL29M16H	PALCE20RA10
PALCE20RA10@PLCC28 [(SA008A)]	PALCE20RA10@SOIC24 [(SA404)]
PALCE20RA10H	PALCE20RA10H@PLCC28 [(SA008A)]
PALCE20RA10H@SOIC24 [(SA404)]	PALCE20RA10Q
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24 [(SA404)]
PALCE22V10H	PALCE22V10H@PLCC28 [(SA008A)]
PALCE22V10H@SOIC24 [(SA404)]	PALCE22V10Q
PALCE22V10Q@PLCC28 [(SA008A)]	PALCE22V10Q@SOIC24 [(SA404)]
PALCE22V10Z	PALCE22V10Z@PLCC28 [(SA008A)]
PALCE22V10Z@SOIC24 [(SA404)]	PALCE26V12H/4
PALCE26V12H/4@PLCC28 [(SA008A)]	PALCE26V12H/4@SOIC28 [(SA404)]
PALCE26V12H-15	PALCE26V12H-15@PLCC28 [(SA008A)]
PALCE26V12H-15@SOIC28 [(SA404)]	PALCE26V12H-20
PALCE26V12H-20@PLCC28 [(SA008A)]	PALCE26V12H-20@SOIC28 [(SA404)]
PALCE26V12H-25	PALCE26V12H-25@PLCC28 [(SA008A)]
PALCE26V12H-25@SOIC28 [(SA404)]	PALCE29M16H
PALCE29M16H@PLCC28 [(SA008A)]	PALCE29M16H@SOIC24 [(SA404)]
PALCE29MA16H	PALCE29MA16H@PLCC28 [(SA008A)]
PALCE29MA16H@SOIC24 [(SA404)]	PALCE610
PALCE610@PLCC28 [(SA008A)]	PALCE610@SOIC24 [(SA404)]
PALCE610H	PALCE610H@PLCC28 [(SA008A)]
PALCE610H@SOIC24 [(SA404)]	PALCE630H
PALCE630H@PLCC28 [(SA008A)]	PALCE630H@SOIC24 [(SA404)]

## LG Semicon

### DRAM & SRAM

GM76C256CL	GM76C256CL@SSOP28 [(SA430T)]
GM76C256CL@TSOP28 [(SA630)]	GM76C256CLL
GM76C256CLL@SSOP28 [(SA430T)]	GM76C256CLL@TSOP28 [(SA630)]
GM76C8128CL	GM76C8128CL@SSOP32 [(SA438T)]
GM76C8128CL@TSOP32 [(SA410T)]	GM76C8128CL@VSOP32 [(SA620)]
GM76C8128CLL	GM76C8128CLL@SSOP32 [(SA438T)]
GM76C8128CLL@TSOP32 [(SA410T)]	GM76C8128CLL@VSOP32 [(SA620)]
GM76C88AL	GM76C88AL@SSOP28 [(SA430T)]
GM76C88AL@TSOP28 [(SA643)]	GM76U256CL
GM76U256CL@SSOP28 [(SA430T)]	GM76U256CL@TSOP28 [(SA643)]
GM76U256CLL	GM76U256CLL@SSOP28 [(SA430T)]
GM76U256CLL@TSOP28 [(SA643)]	GM76U8128CL
GM76U8128CL@SSOP32 [(SA438T)]	GM76U8128CL@TSOP32 [(SA410T)]
GM76U8128CL@VSOP32 [(SA620)]	GM76U8128CLL
GM76U8128CLL@SSOP32 [(SA438T)]	GM76U8128CLL@TSOP32 [(SA410T)]
GM76U8128CLL@VSOP32 [(SA620)]	GM76U8128DL
GM76U8128DL@SSOP32 [(SA438T)]	GM76U8128DL@TSOP32 [(SA410T)]
GM76U8128DL@VSOP32 [(SA620)]	GM76U8128DLL
GM76U8128DLL@SSOP32 [(SA438T)]	GM76U8128DLL@TSOP32 [(SA410T)]
GM76U8128DLL@VSOP32 [(SA620)]	GM76U8512L
GM76U8512L@SSOP32 [(SA438T)]	GM76U8512L@TSOP32 [(SA410T)]
GM76U8512L@VSOP32 [(SA620)]	GM76U8512LL
GM76U8512LL@SSOP32 [(SA438T)]	GM76U8512LL@TSOP32 [(SA410T)]
GM76U8512LL@VSOP32 [(SA620)]	GM76V256CL
GM76V256CL@SSOP28 [(SA430T)]	GM76V256CL@TSOP28 [(SA630)]
GM76V256CLL	GM76V256CLL@SSOP28 [(SA430T)]
GM76V256CLL@TSOP28 [(SA630)]	GM76V8128CL
GM76V8128CL@SSOP32 [(SA438T)]	GM76V8128CL@TSOP32 [(SA410T)]
GM76V8128CL@VSOP32 [(SA620)]	GM76V8128CLL
GM76V8128CLL@SSOP32 [(SA438T)]	GM76V8128CLL@TSOP32 [(SA410T)]
GM76V8128CLL@VSOP32 [(SA620)]	GM76V8128DL
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32 [(SA410T)]
GM76V8128DL@VSOP32 [(SA620)]	GM76V8128DLL
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32 [(SA410T)]
GM76V8128DLL@VSOP32 [(SA620)]	GM76V8512L
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32 [(SA410T)]
GM76V8512L@VSOP32 [(SA620)]	GM76V8512LL
GM76V8512LL@SSOP32 [(SA438T)]	GM76V8512LL@TSOP32 [(SA410T)]
GM76V8512LL@VSOP32 [(SA620)]	GM77C8128A
GM77C8128A@SSOP32 [(SA438T)]	GM77C8128A@TSOP32 [(SA410T)]
GM77C8128A@VSOP32 [(SA620)]	



## MICROCONTROLLER

GMS34004TK	GMS34004TM
GMS34004TW	GMS34112TK
GMS34112TK@SOIC20 [(SA404)]	GMS34112TK@SSOP20 [(SA626A)]
GMS34140TK	GMS34140TK@SOIC24 [(SA404)]
GMS77C1000	GMS77C1000@SOIC20 [(SA404)]
GMS77C1001	GMS77C1001@SOIC20 [(SA404)]
GMS81004(dip20)	GMS81004(dip24)
GMS81004(dip28)	GMS81004@PLCC44 [(SA244)]
GMS81004@SOIC20 [(SA404)]	GMS81004@SOIC24 [(SA404)]
GMS81004@SOIC28 [(SA404)]	GMS81008(dip20)
GMS81008(dip24)	GMS81008(dip28)
GMS81008@PLCC44 [(SA244)]	GMS81008@SOIC20 [(SA404)]
GMS81008@SOIC24 [(SA404)]	GMS81008@SOIC28 [(SA404)]
GMS81016(dip20)	GMS81016(dip24)
GMS81016(dip28)	GMS81016@PLCC44 [(SA244)]
GMS81016@SOIC20 [(SA404)]	GMS81016@SOIC24 [(SA404)]
GMS81016@SOIC28 [(SA404)]	GMS81024(dip20)
GMS81024(dip24)	GMS81024(dip28)
GMS81024@PLCC44 [(SA244)]	GMS81024@SOIC20 [(SA404)]
GMS81024@SOIC24 [(SA404)]	GMS81024@SOIC28 [(SA404)]
GMS81032(dip20)	GMS81032(dip24)
GMS81032(dip28)	GMS81032@PLCC44 [(SA244)]
GMS81032@SOIC20 [(SA404)]	GMS81032@SOIC24 [(SA404)]
GMS81032@SOIC28 [(SA404)]	GMS81504AT
GMS81504T	GMS81516
GMS81516@LQFP64 [(PEP+S616)]	GMS81516@MQFP64 [(PEP+S618)]
GMS81516@SDIP64 [(PEP+S600A)]	GMS81516AT
GMS81516AT@LQFP64 [(PEP+S616)]	GMS81516AT@MQFP64 [(PEP+S618)]
GMS81516AT@SDIP64 [(PEP+S600A)]	GMS81516BT
GMS81516BT@LQFP64 [(PEP+S616)]	GMS81516BT@MQFP64 [(PEP+S618)]
GMS81516BT@SDIP64 [(PEP+S600A)]	GMS81524
GMS81524@LQFP64 [(PEP+S616)]	GMS81524@MQFP64 [(PEP+S618)]
GMS81524@SDIP64 [(PEP+S600A)]	GMS81524AT
GMS81524AT@LQFP64 [(PEP+S616)]	GMS81524AT@MQFP64 [(PEP+S618)]
GMS81524AT@SDIP64 [(PEP+S600A)]	GMS81524BT
GMS81524BT@LQFP64 [(PEP+S616)]	GMS81524BT@MQFP64 [(PEP+S618)]
GMS81524BT@SDIP64 [(PEP+S600A)]	GMS81604T
GMS81604T@PLCC44 [(SA244)]	GMS81604T@SDIP42 [(SA028)]
GMS81608T	GMS81608T@PLCC44 [(SA244)]
GMS81608T@SDIP42 [(SA028)]	GMS81C5016(dip28)
GMS81C5016(dip40)	GMS81C5016@PLCC44 [(SA244)]
GMS81C5016@SOIC28 [(SA404)]	GMS81C5016@TQFP44 [(SA245A)]
GMS81C5024(dip28)	GMS81C5024(dip40)
GMS81C5024@PLCC44 [(SA244)]	GMS81C5024@SOIC28 [(SA404)]
GMS81C5024@TQFP44 [(SA245A)]	GMS81C5032(dip28)
GMS81C5032(dip40)	GMS81C5032@PLCC44 [(SA244)]
GMS81C5032@SOIC28 [(SA404)]	GMS81C5032@TQFP44 [(SA245A)]
GMS82516T	GMS82516T@LQFP64 [(PEP+S616)]
GMS82516T@MQFP64 [(PEP+S618)]	GMS82516T@SDIP64 [(PEP+S600A)]
GMS82524T	GMS82524T@LQFP64 [(PEP+S616)]
GMS82524T@MQFP64 [(PEP+S618)]	GMS82524T@SDIP64 [(PEP+S600A)]
GMS84512T@SDIP52 [(PEP+S600A)]	GMS84524T@SDIP52 [(PEP+S600A)]
GMS87C1102	GMS87C1102@SOP16 [(SA404)]
GMS87C1202	GMS87C1202@SOP20 [(SA404)]
GMS87C1404	GMS87C1404@SDIP28 [(SA022A)]
GMS87C1408	GMS87C1408@SDIP28 [(SA022A)]
GMS87C2020@LQFP64 [(PEP+S616)]	GMS87C2020@MQFP64 [(PEP+S618)]
GMS87C2020@SDIP64 [(PEP+S600A)]	GMS87C5032(dip28)
GMS87C5032(dip40)	GMS87C5032@PLCC44 [(SA244)]
GMS87C5032@SOIC28 [(SA404)]	GMS87C5032@TQFP44 [(SA245A)]
GMS87C5108@PQFP80 [(PEP+S611A)]	GMS87C7008@LQFP64 [(PEP+S616)]
GMS87C7008@MQFP64 [(PEP+S618)]	GMS87C7008@SDIP64 [(PEP+S600A)]
GMS87C7016@LQFP64 [(PEP+S616)]	GMS87C7016@MQFP64 [(PEP+S618)]
GMS87C7016@SDIP64 [(PEP+S600A)]	GMS97C1051
GMS97C1051@SOIC20 [(SA404)]	GMS97C2051
GMS97C2051@SOIC20 [(SA404)]	GMS97C51
GMS97C51@PLCC44 [(SA244)]	GMS97C51@TQFP44 [(SA245A)]
GMS97C52	GMS97C52@PLCC44 [(SA244)]
GMS97C52@TQFP44 [(SA245A)]	GMS97C54
GMS97C54@PLCC44 [(SA244)]	GMS97C54@TQFP44 [(SA245A)]
GMS97C56	GMS97C56@PLCC44 [(SA244)]
GMS97C56@TQFP44 [(SA245A)]	GMS97C58
GMS97C58@PLCC44 [(SA244)]	GMS97C58@TQFP44 [(SA245A)]
GMS97L1051	GMS97L1051@SOIC20 [(SA404)]
GMS97L2051	GMS97L2051@SOIC20 [(SA404)]
GMS97L51	GMS97L51@PLCC44 [(SA244)]

GMS97L51@TQFP44 [(SA245A)]	GMS97L52
GMS97L52@PLCC44 [(SA244)]	GMS97L52@TQFP44 [(SA245A)]
GMS97L54	GMS97L54@PLCC44 [(SA244)]
GMS97L54@TQFP44 [(SA245A)]	GMS97L56
GMS97L56@PLCC44 [(SA244)]	GMS97L56@TQFP44 [(SA245A)]
GMS97L58	GMS97L58@PLCC44 [(SA244)]
GMS97L58@TQFP44 [(SA245A)]	GMS99C52
GMS99C52@PLCC44 [(SA244)]	GMS99C52@TQFP44 [(SA245A)]
GMS99C58	GMS99C58@PLCC44 [(SA244)]
GMS99C58@TQFP44 [(SA245A)]	

## LINKSMART

### E(E) PROM/FRAM/NVRAM

L24C02	L24C02@SSOP8 [(SA602A)]
L24C02@TSOP8 [(SA026)]	L24C04
L24C04@SSOP8 [(SA602A)]	L24C04@TSOP8 [(SA026)]
L29004C	L29004C@PLCC32 [(SA015A1T)]
L29004C@TSOP32 [(SA620)]	L29S160F@TSOP48 [(SA247-B005)]
L29S160F-B@TSOP48 [(SA247-B005)]	L29S400F@PSOP44 [(SA638)]
L29S400F@TSOP48 [(SA247-B005)]	L29S400F-B@PSOP44 [(SA638)]
L29S400F-B@TSOP48 [(SA247-B005)]	L29S800F@TSOP48 [(SA247-B005)]
L29S800F-B@TSOP48 [(SA247-B005)]	L29W800E@TSOP48 [(SA247-B005)]
L29W800E-B@TSOP48 [(SA247-B005)]	LST28001
LST28001@PLCC32 [(SA015A1T)]	LST28001@TSOP32 [(SA620)]
LST28002	LST28002@PLCC32 [(SA015A1T)]
LST28002@TSOP32 [(SA620)]	LST28004
LST28004@PLCC32 [(SA015A1T)]	LST28004@TSOP32 [(SA620)]

## MACRONIX

### E(E) PROM/FRAM/NVRAM

KH25L1005	KH25L1005(ISP) [ISP-HEADER01]
KH25L1005@SON8 [(SA683)]	
KH25L1005@SON8(ISP) [ISP-HEADER01]	
KH25L1005@SOP8 [(SA602A)]	
KH25L1005@SOP8(ISP) [ISP-HEADER01]	
KH25L1005A	KH25L1005A@SON8 [(SA683)]
KH25L1005A@SOP8 [(SA602A)]	
KH25L12805D@SON8(Fast Mode) [(SA684)]	
KH25L12805D@SOP16(Fast Mode) [(SA404)]	
KH25L12805N@SOP16 [(SA404)]	
KH25L12805N@SOP16(Fast Mode) [(SA404)]	
KH25L1602@SOP28 [(SA630)]	KH25L1605@SON8 [(SA684)]
KH25L1605@SON8(Fast Mode) [(SA684)]	
KH25L1605@SOP16 [(SA404)]	
KH25L1605@SOP16(Fast Mode) [(SA404)]	
KH25L1605A@SON8 [(SA684)]	
KH25L1605A@SON8(Fast Mode) [(SA684)]	
KH25L1605A@SOP16 [(SA404)]	
KH25L1605A@SOP16(Fast Mode) [(SA404)]	
KH25L1605A@SOP8 [(SA023A)]	
KH25L1605A@SOP8(Fast Mode) [(SA023A)]	
KH25L1605D@SON8 [(SA684)]	
KH25L1605D@SON8(Fast Mode) [(SA683)]	
KH25L1605D@SOP16 [(SA404)]	
KH25L1605D@SOP16(Fast Mode) [(SA404)]	
KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]	
KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]	
KH25L1636DMI@SOP8 [(SA602A)]	KH25L1636DM2I@SOP8 [(SA605B)]
KH25L1636DMI@SOP16 [(SA404)]	KH25L1636DZNI@WSON8 [(SA683)]
KH25L2005	KH25L2005(ISP) [ISP-HEADER01]
KH25L2005@SON8 [(SA683)]	
KH25L2005@SON8(ISP) [ISP-HEADER01]	
KH25L2005@SOP8 [(SA602A)]	
KH25L2005@SOP8(ISP) [ISP-HEADER01]	
KH25L2025	KH25L2025@SON8 [(SA683)]
KH25L2025@SOP8 [(SA602A)]	KH25L3202@SOP32 [(SA438T)]
KH25L3205@SOP16 [(SA404)]	
KH25L3205@SOP16(Fast Mode) [(SA404)]	
KH25L3205@SOP8 [(SA023A)]	
KH25L3205@SOP8(Fast Mode) [(SA023A)]	

KH25L3205A@SON8 [(SA684)]  
 KH25L3205A@SON8(Fast Mode) [(SA684)]  
 KH25L3205A@SOP16 [(SA404)]  
 KH25L3205A@SOP16(Fast Mode) [(SA404)]  
 KH25L3205A@SOP8 [(SA023A)]  
 KH25L3205A@SOP8(Fast Mode) [(SA023A)]  
 KH25L3205D@SON8(Fast Mode) [(SA683)]  
 KH25L3205D@SOP16 [(SA404)]  
 KH25L3205D@SOP16(Fast Mode) [(SA404)]  
 KH25L3205D@SOP8 [(SA023A)]  
 KH25L3205D@SOP8(Fast Mode) [(SA605B)]  
 KH25L3236DM2I@SOP8 [(SA605B)] KH25L3236DMI@SOP16 [(SA404)]  
 KH25L3236DZNI@WSON8 [(SA683)] KH25L4005  
 KH25L4005(150mil)@SOP8 [(SA602A)]  
 KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005(209mil)@SOP8 [(SA023A)]  
 KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005(ISP) [ISP-HEADER01] KH25L4005@SON8 [(SA683)]  
 KH25L4005@SON8(ISP) [ISP-HEADER01]  
 KH25L4005A  
 KH25L4005A(150mil)@SOP8 [(SA602A)]  
 KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005A(209mil)@SOP8 [(SA023A)]  
 KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005A(ISP) [ISP-HEADER01] KH25L4005A@SON8 [(SA683)]  
 KH25L4005A@SON8(ISP) [ISP-HEADER01]  
 KH25L4025A  
 KH25L4025A(150mil)@SOP8 [(SA602A)]  
 KH25L4025A(209mil)@SOP8 [(SA023A)]  
 KH25L4025A@SON8 [(SA683)] KH25L512@SON8 [(SA683)]  
 KH25L512@SOP8 [(SA602A)] KH25L512A  
 KH25L512A@SON8 [(SA683)] KH25L512A@SOP8 [(SA602A)]  
 KH25L6402@SOP32 [(SA438T)] KH25L6402A@SOP28 [(SA630)]  
 KH25L6405@SOP16 [(SA404)]  
 KH25L6405@SOP16(Fast Mode) [(SA404)]  
 KH25L6405@SOP8 [(SA023A)]  
 KH25L6405@SOP8(Fast Mode) [(SA023A)]  
 KH25L6405D@SON8(Fast Mode) [(SA684)]  
 KH25L6405D@SOP16 [(SA404)]  
 KH25L6405D@SOP16(Fast Mode) [(SA404)]  
 KH25L6405D@SOP8 [(SA023A)] KH25L8005  
 KH25L8005(150mil)@SOP8 [(SA602A)]  
 KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L8005(209mil)@SOP8 [(SA023A)]  
 KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8 [(SA683)]  
 KH25L8005@SON8(ISP) [ISP-HEADER01]  
 KH25L802@SOP28 [(SA630)] KH25L8025  
 KH25L8025(150mil)@SOP8 [(SA602A)]  
 KH25L8025(209mil)@SOP8 [(SA023A)]  
 KH25L8025@SON8 [(SA683)] KH25L8036D  
 KH25L8036D@SOP16 [(SA404)]  
 KH25L8036D@SOP8[150 mil] [(SA602A)]  
 KH25L8036D@SOP8[200 mil] [(SA023A)]  
 KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32 [(SA015A1T)]  
 KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32 [(SA015A1T)]  
 KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40 [(SA409T)]  
 KH29LV008CT@TSOP40 [(SA409T)] KH29LV040C  
 KH29LV040C@PLCC32 [(SA015A1T)]  
 KH29LV160CBT@TSOP48 [(SA247-B005)]  
 KH29LV160CTT@TSOP48 [(SA247-B005)]  
 KH29LV160DBT@TSOP48 [(SA247-B005)]  
 KH29LV160DTT@TSOP48 [(SA247-B005)]  
 KH29LV320CBT@TSOP48 [(SA247-B005)]  
 KH29LV320CTT@TSOP48 [(SA247-B005)]  
 KH29LV320DBT@TSOP48 [(SA247-B005)]  
 KH29LV320DTT@TSOP48 [(SA247-B005)]  
 KH29LV400CBT@TSOP48 [(SA247-B005)]  
 KH29LV400CTT@TSOP48 [(SA247-B005)]  
 KH29LV640DBT@TSOP48 [(SA247-B005)]  
 KH29LV640DTT@TSOP48 [(SA247-B005)]  
 KH29LV800CBT@TSOP48 [(SA247-B005)]  
 KH29LV800CTT@TSOP48 [(SA247-B005)]  
 MX25L1005 KH25L1005(ISP) [ISP-HEADER01]  
 MX25L1005@SON8 [(SA683)]  
 MX25L1005@SON8(ISP) [ISP-HEADER01]  
 MX25L1005@SOP8 [(SA602A)]  
 MX25L1005@SOP8(ISP) [ISP-HEADER01]  
 MX25L1005A  
 MX25L1005A@SOP8 [(SA602A)] MX25L1005A@SON8 [(SA683)]  
 MX25L1005C MX25L1005C  
 MX25L1005C@SON8 [(SA683)] MX25L1005C@SOP8 [(SA602A)]

```

MX25L1021E@SOP8 [(SA602A)]
MX25L12805D@SON8(512bit OTP) [(SA684)]
MX25L12805D@SON8(Fast Mode) [(SA684)]
MX25L12805D@SOP16(512bit OTP) [(SA404)]
MX25L12805D@SOP16(Fast Mode) [(SA404)]
MX25L12805N@SOP16 [(SA404)]
MX25L12805N@SOP16(Fast Mode) [(SA404)]
MX25L12845E@SOP16 [(SA404)] MX25L12845E@WSON8 [(SA684)]
MX25L12855E@SOP16 [(SA404)] MX25L12855E@TFBGA24 [(TA088)]
MX25L12865E@SOP16 [(SA404)] MX25L12865E@SOP8 [(SA605A)]
MX25L12865E@WSON8 [(SA684)] MX25L1602@SOP28 [(SA630)]
MX25L1605@SON8 [(SA684)]
MX25L1605@SON8(Fast Mode) [(SA684)]
MX25L1605@SOP16 [(SA404)]
MX25L1605@SOP16(Fast Mode) [(SA404)]
MX25L1605A@SON8 [(SA684)]
MX25L1605A@SON8(Fast Mode) [(SA684)]
MX25L1605A@SOP16 [(SA404)]
MX25L1605A@SOP16(Fast Mode) [(SA404)]
MX25L1605A@SOP8 [(SA023A)]
MX25L1605A@SOP8(Fast Mode) [(SA023A)]
MX25L1605D@SON8 [(SA684)]
MX25L1605D@SON8(512bit OTP) [(SA683)]
MX25L1605D@SON8(Fast Mode) [(SA683)]
MX25L1605D@SOP16 [(SA404)]
MX25L1605D@SOP16(512bit OTP) [(SA404)]
MX25L1605D@SOP16(Fast Mode) [(SA404)]
MX25L1605D@SOP8(150)(512bit OTP) [(SA602A)]
MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
MX25L1605D@SOP8(200)(512bit OTP) [(SA605B)]
MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
MX25L1605D@USON8 [(SA744)]
MX25L1605D@USON8(Fast Mode) [(SA744)]
MX25L1606E MX25L1606E@SOP16 [(SA404)]
MX25L1606E@SOP8(150 mil) [(SA602A)]
MX25L1606E@SOP8(200 mil) [(SA605A)]
MX25L1606E@USON8 [(SA744)] MX25L1606E@WSON8 [(SA683)]
MX25L1615D@SOP16 [(SA404)] MX25L1615D@SOP8 [(SA023A)]
MX25L1633E@SOP16 [(SA404)] MX25L1633E@SOP8 [(SA605A)]
MX25L1633E@WSON8 [(SA683)] MX25L1635DMI@SOP8 [(SA602A)]
MX25L1635DMI@SOP8 [(SA605B)] MX25L1635DMI@SOP16 [(SA404)]
MX25L1635DZNI@WSON8 [(SA683)] MX25L1636DMI@SOP8 [(SA602A)]
MX25L1636DMI@SOP8 [(SA605B)] MX25L1636DMI@SOP16 [(SA404)]
MX25L1636DZNI@WSON8 [(SA683)] MX25L1655D@SOP8 [(SA023A)]
MX25L1655D@TFBGA24 [(TA088)] MX25L2005
MX25L2005(ISP) [ISP-HEADER01] MX25L2005@SON8 [(SA683)]
MX25L2005@SON8(ISP) [ISP-HEADER01]
MX25L2005@SOP8 [(SA602A)]
MX25L2005@SOP8(ISP) [ISP-HEADER01]
MX25L2025 MX25L2025@SON8 [(SA683)]
MX25L2025@SOP8 [(SA602A)] MX25L2026C@SOP8 [(SA602A)]
MX25L2026E@SOP8 [(SA602A)] MX25L2026E@WSON8 [(SA683)]
MX25L3202@SOP32 [(SA438T)] MX25L3205@SOP16 [(SA404)]
MX25L3205@SOP16(Fast Mode) [(SA404)]
MX25L3205@SOP8 [(SA023A)]
MX25L3205@SOP8(Fast Mode) [(SA023A)]
MX25L3205A@SON8 [(SA684)]
MX25L3205A@SON8(Fast Mode) [(SA684)]
MX25L3205A@SOP16 [(SA404)]
MX25L3205A@SOP16(Fast Mode) [(SA404)]
MX25L3205A@SOP16(Parallel Mode) [(SA404)]
MX25L3205A@SOP8 [(SA023A)]
MX25L3205A@SOP8(Fast Mode) [(SA023A)]
MX25L3205D@SON8(512bit OTP) [(SA683)]
MX25L3205D@SON8(Fast Mode) [(SA683)]
MX25L3205D@SOP16 [(SA404)]
MX25L3205D@SOP16(512bit OTP) [(SA404)]
MX25L3205D@SOP16(Fast Mode) [(SA404)]
MX25L3205D@SOP8 [(SA023A)]
MX25L3205D@SOP8(512bit OTP) [(SA605B)]
MX25L3205D@SOP8(Fast Mode) [(SA605B)]
MX25L3205D@USON8 [(SA744)]
MX25L3205D@USON8(Fast Mode) [(SA744)]
MX25L3206E MX25L3206E@SOP16 [(SA404)]
MX25L3206E@SOP8 [(SA023A)] MX25L3206E@USON8 [(SA744)]
MX25L3206E@WSON8 [(SA683)] MX25L3215D@SOP16 [(SA404)]
MX25L3215D@SOP8 [(SA023A)] MX25L3235DMI@SOP8 [(SA605B)]
MX25L3235DMI@SOP16 [(SA404)] MX25L3235DZNI@WSON8 [(SA683)]
MX25L3236DMI@SOP8 [(SA605B)] MX25L3236DMI@SOP16 [(SA404)]
MX25L3236DZNI@WSON8 [(SA683)] MX25L3237D@SOP16 [(SA404)]
MX25L3237D@WSON8 [(SA683)] MX25L3255D@SOP8 [(SA023A)]

```

```

MX25L3255D@TFBGA24 [(TA088)] MX25L4005
MX25L4005(150mil)@SOP8 [(SA602A)]
MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]
MX25L4005(209mil)@SOP8 [(SA023A)]
MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]
MX25L4005(ISP) [ISP-HEADER01] MX25L4005@SON8 [(SA683)]
MX25L4005@SON8(ISP) [ISP-HEADER01]
MX25L4005A
MX25L4005A(150mil)@SOP8 [(SA602A)]
MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]
MX25L4005A(209mil)@SOP8 [(SA023A)]
MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]
MX25L4005A(ISP) [ISP-HEADER01] MX25L4005A@SON8 [(SA683)]
MX25L4005A@SON8(ISP) [ISP-HEADER01]
MX25L4005C
MX25L4005C(150mil)@SOP8 [(SA602A)]
MX25L4005C(209mil)@SOP8 [(SA023A)]
MX25L4005C@SON8 [(SA683)] MX25L4025@SOP8 [(SA602A)]
MX25L4025A
MX25L4025A(150mil)@SOP8 [(SA602A)]
MX25L4025A(209mil)@SOP8 [(SA023A)]
MX25L4025A@SON8 [(SA683)] MX25L512@SON8 [(SA683)]
MX25L512@SOP8 [(SA602A)] MX25L5121E@SOP8 [(SA602A)]
MX25L5121E@TSSOP8 [(SA026)] MX25L512A
MX25L512A@SON8 [(SA683)] MX25L512A@SOP8 [(SA602A)]
MX25L512C MX25L512C@SON8 [(SA683)]
MX25L512C@SOP8 [(SA602A)] MX25L6402@SOP32 [(SA438T)]
MX25L6402A@SOP28 [(SA630)] MX25L6405@SOP16 [(SA404)]
MX25L6405@SOP16(Fast Mode) [(SA404)]
MX25L6405@SOP8 [(SA023A)]
MX25L6405@SOP8(Fast Mode) [(SA023A)]
MX25L6405D@SON8(512bit OTP) [(SA684)]
MX25L6405D@SON8(Fast Mode) [(SA684)]
MX25L6405D@SOP16 [(SA404)]
MX25L6405D@SOP16(512bit OTP) [(SA404)]
MX25L6405D@SOP16(Fast Mode) [(SA404)]
MX25L6405D@SOP8 [(SA023A)] MX25L6415D@SOP16 [(SA404)]
MX25L6415D@SOP8 [(SA023A)] MX25L6445E@SOP16 [(SA404)]
MX25L6445E@SOP8 [(SA023A)] MX25L6445E@WSON8 [(SA684)]
MX25L6446E@SOP16 [(SA404)] MX25L6446E@SOP8 [(SA023A)]
MX25L6446E@WSON8 [(SA684)] MX25L6455E@SOP16 [(SA404)]
MX25L6455E@SOP8 [(SA023A)] MX25L6455E@TFBGA24 [(TA088)]
MX25L6465E@SOP16 [(SA404)] MX25L6465E@SOP8 [(SA023A)]
MX25L6465E@WSON8 [(SA684)] MX25L8005
MX25L8005(150mil)@SOP8 [(SA602A)]
MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]
MX25L8005(209mil)@SOP8 [(SA023A)]
MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]
MX25L8005(ISP) [ISP-HEADER01] MX25L8005@SON8 [(SA683)]
MX25L8005@SON8(ISP) [ISP-HEADER01]
MX25L8006
MX25L8006@SOP8(150 mil) [(SA602A)]
MX25L8006@SOP8(200 mil) [(SA605A)]
MX25L8006@USON8 [(SA744)] MX25L8006@WSON8 [(SA683)]
MX25L8006E
MX25L8006E@SOP8(150 mil) [(SA602A)]
MX25L8006E@SOP8(200 mil) [(SA605A)]
MX25L8006E@USON8 [(SA744)] MX25L8006E@WSON8 [(SA683)]
MX25L802@SOP28 [(SA630)] MX25L8025
MX25L8025(150mil)@SOP8 [(SA602A)]
MX25L8025(209mil)@SOP8 [(SA023A)]
MX25L8025@SON8 [(SA683)] MX25L8036D
MX25L8036D@SOP16 [(SA602A)]
MX25L8036D@SOP8[150 mil] [(SA602A)]
MX25L8036D@SOP8[200 mil] [(SA023A)]
MX25L8036D@WSON8 [(SA683)] MX25U1635@SOIC8 [(SA602A)]
MX25U1635@USON8(4*4mm) [(SA744)] MX25U1635@USON8(6*5mm) [(SA683)]
MX25U4035@SOIC8 [(SA602A)] MX25U4035@USON8(4*4mm) [(SA744)]
MX25U4035@USON8(6*5mm) [(SA683)] MX25U8035@SOIC8 [(SA602A)]
MX25U8035@USON8(4*4mm) [(SA744)] MX25U8035@USON8(6*5mm) [(SA683)]
MX25V512@USON8 [(SA724)] MX26C1000B
MX26C1000B@PLCC32 [(SA015A1T)] MX26C1000B@SOIC32 [(SA603)]
MX26C1000B@TSOP32 [(SA410T)] MX26C2000B
MX26C2000B@PLCC32 [(SA015A1T)] MX26C2000B@SOIC32 [(SA603)]
MX26C2000B@TSOP32 [(SA410T)] MX26C512A
MX26C512A@PLCC32 [(SA015A1T)] MX26C512A@SOIC28 [(SA630)]
MX26C512A@TSOP28 [(SA430T)]
MX26F128J3TC@TSOP56 [(SA628-B018)]
MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]
MX26F640J3TC@TSOP56 [(SA628-B018)]
MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]

```

MX26L12711MC@PSOP44 [(SA638)]	MX26L12811MC@PSOP44 [(SA638)]
MX26L6419T@TSOP48 [(SA247-B005)]	MX26L6420@PSOP44 [(SA638)]
MX26L6420@TSOP48 [(SA247-B005)]	MX26LV004B@PLCC32 [(SA015A1T)]
MX26LV004B@TSOP40 [(SA409T)]	MX26LV004T@PLCC32 [(SA015A1T)]
MX26LV004T@TSOP40 [(SA409T)]	MX26LV008B@TSOP40 [(SA409T)]
MX26LV008T@TSOP40 [(SA409T)]	
MX26LV040(QC)@PLCC32 [(SA015A1T)]	
MX26LV040(TC)@TSOP32 [(SA410T)]	
MX26LV160BT@TSOP48 [(SA247-B005)]	
MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV160TT@TSOP48 [(SA247-B005)]	
MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV400BT@TSOP48 [(SA247-B005)]	
MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV400TT@TSOP48 [(SA247-B005)]	
MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]	
MX26LV800BM@PSOP44 [(SA638)]	
MX26LV800BT@TSOP48 [(SA247-B005)]	
MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800TM@PSOP44 [(SA638)]	
MX26LV800TT@TSOP48 [(SA247-B005)]	
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX27C1000	MX27C1000@PLCC32 [(SA015A1T)]
MX27C1000@SOIC32 [(SA603)]	MX27C1000@TSOP32 [(SA410T)]
MX27C1000A	MX27C1000A@PLCC32 [(SA015A1T)]
MX27C1000A@SOIC32 [(SA603)]	MX27C1000A@TSOP32 [(SA410T)]
MX27C1001	MX27C1001@PLCC32 [(SA015A1T)]
MX27C1001@SOIC32 [(SA603)]	MX27C1001@TSOP32 [(SA410T)]
MX27C1024	MX27C1024@PLCC44 [(SA244)]
MX27C1024@TSOP40 [(SA409T)]	MX27C1024A
MX27C1024A@PLCC44 [(SA244)]	MX27C1024A@TSOP40 [(SA409T)]
MX27C1024B	MX27C1024B@PLCC44 [(SA244)]
MX27C1024B@TSOP40 [(SA409T)]	MX27C1100
MX27C2000	MX27C2000@PLCC32 [(SA015A1T)]
MX27C2000@SOIC32 [(SA603)]	MX27C2000@TSOP32 [(SA410T)]
MX27C2000A	MX27C2000A@PLCC32 [(SA015A1T)]
MX27C2000A@SOIC32 [(SA603)]	MX27C2000A@TSOP32 [(SA410T)]
MX27C2048	MX27C2048@PLCC44 [(SA244)]
MX27C2048@TSOP40 [(SA409T)]	MX27C2100
MX27C256	MX27C256@PLCC32 [(SA015A1T)]
MX27C4000	MX27C4000@PLCC32 [(SA015A1T)]
MX27C4000@SOIC32 [(SA603)]	MX27C4000@TSOP32 [(SA410T)]
MX27C4000A	MX27C4000A@PLCC32 [(SA015A1T)]
MX27C4000A@SOIC32 [(SA603)]	MX27C4000A@TSOP32 [(SA410T)]
MX27C4096	MX27C4096@PLCC44 [(SA244)]
MX27C4100	MX27C4111
MX27C512	MX27C512@PLCC32 [(SA015A1T)]
MX27C516	MX27C516@PLCC44 [(SA244)]
MX27C516@TSOP40 [(SA409T)]	MX27C8000
MX27C8000@PLCC32 [(SA015A1T)]	MX27C8000@SOIC32 [(SA603)]
MX27C8000@TSOP32 [(SA410T)]	MX27C8000A
MX27C8000A@PLCC32 [(SA015A1T)]	MX27C8000A@SOIC32 [(SA603)]
MX27C8000A@TSOP32 [(SA410T)]	MX27C8100
MX27C8100@PSOP44 [(SA638)]	MX27C8111
MX27C8111@PSOP44 [(SA638)]	MX27L1000
MX27L1000@PLCC32 [(SA015A1T)]	MX27L1000@TSOP32 [(SA410T)]
MX27L2000	MX27L2000@PLCC32 [(SA015A1T)]
MX27L2000@TSOP32 [(SA410T)]	MX27L256
MX27L256@PLCC32 [(SA015A1T)]	MX27L256@TSOP32 [(SA430T)]
MX27L4000	MX27L4000@PLCC32 [(SA015A1T)]
MX27L4000@TSOP32 [(SA410T)]	MX27L4096
MX27L4096@PLCC44 [(SA244)]	MX27L512
MX27L512@PLCC32 [(SA015A1T)]	MX27L512@TSOP28 [(SA430T)]
MX28F002B@TSOP40 [(SA409T)]	MX28F002T@TSOP40 [(SA409T)]
MX28F1000	MX28F1000@PLCC32 [(SA015A1T)]
MX28F1000@SOP32 [(SA603)]	MX28F1000@TSOP32 [(SA410T)]
MX28F1000P	MX28F1000P@PLCC32 [(SA015A1T)]
MX28F1000P@TSOP32 [(SA410T)]	
MX28F160C3BT@TSOP48 [(SA247-B005)]	
MX28F160C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F160C3TT@TSOP48 [(SA247-B005)]	
MX28F160C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F2000	MX28F2000@PLCC32 [(SA015A1T)]
MX28F2000@TSOP32 [(SA410T)]	MX28F2000P
MX28F2000P@PLCC32 [(SA015A1T)]	MX28F2000P@TSOP32 [(SA410T)]

MX28F2100B@PSOP44 [(SA638)]                   MX28F2100B@TSOP48 [(SA247-B005)]  
 MX28F2100T@PSOP44 [(SA638)]                   MX28F2100T@TSOP48 [(SA247-B005)]  
 MX28F4000                                       MX28F4000@PLCC32 [(SA015A1T)]  
 MX28F4000@TSOP32 [(SA410T)]  
 MX28F640C3BT@TSOP48 [(SA247-B005)]  
 MX28F640C3BX@uBGA48 [(SA634A-B005A-Y048F001)]  
 MX28F640C3TT@TSOP48 [(SA247-B005)]  
 MX28F640C3TX@uBGA48 [(SA634A-B005A-Y048F001)]  
 MX29F001B                                       MX29F001B@PLCC32 [(SA015A1T)]  
 MX29F001B@TSOP32 [(SA410T)]                   MX29F001T  
 MX29F001T@PLCC32 [(SA015A1T)]               MX29F001T@TSOP32 [(SA410T)]  
 MX29F002B                                       MX29F002B@PLCC32 [(SA015A1T)]  
 MX29F002B@TSOP32 [(SA410T)]                   MX29F002NB  
 MX29F002NB@PLCC32 [(SA015A1T)]               MX29F002NB@TSOP32 [(SA410T)]  
 MX29F002NT                                      MX29F002NT@PLCC32 [(SA015A1T)]  
 MX29F002NT@TSOP32 [(SA410T)]               MX29F002T  
 MX29F002T@PLCC32 [(SA015A1T)]               MX29F002T@TSOP32 [(SA410T)]  
 MX29F004B                                       MX29F004B@PLCC32 [(SA015A1T)]  
 MX29F004B@TSOP32 [(SA410T)]                   MX29F004T  
 MX29F004T@PLCC32 [(SA015A1T)]               MX29F004T@TSOP32 [(SA410T)]  
 MX29F016@PSOP44 [(SA638)]                   MX29F016@TSOP40 [(SA409T)]  
 MX29F016@TSOP48 [(SA247-B005)]               MX29F022B  
 MX29F022B@PLCC32 [(SA015A1T)]               MX29F022B@TSOP32 [(SA410T)]  
 MX29F022NB                                      MX29F022NB@PLCC32 [(SA015A1T)]  
 MX29F022NB@TSOP32 [(SA410T)]               MX29F022NT  
 MX29F022NT@PLCC32 [(SA015A1T)]               MX29F022NT@TSOP32 [(SA410T)]  
 MX29F022T                                       MX29F022T@PLCC32 [(SA015A1T)]  
 MX29F022T@TSOP32 [(SA410T)]               MX29F040  
 MX29F040@PLCC32 [(SA015A1T)]               MX29F040@TSOP32 [(SA410T)]  
 MX29F040C                                       MX29F040C@PLCC32 [(SA015A1T)]  
 MX29F040C@TSOP32 [(SA410T)]                   MX29F080@PSOP44 [(SA638)]  
 MX29F080@TSOP40 [(SA409T)]                   MX29F100B@PSOP44 [(SA638-B006)]  
 MX29F100B@TSOP48 [(SA247-B005)]               MX29F100T@PSOP44 [(SA638-B006)]  
 MX29F100T@TSOP48 [(SA247-B005)]               MX29F1610@PSOP44 [(SA638)]  
 MX29F1610@TSOP48 [(SA247-B005)]               MX29F1610A@PSOP44 [(SA638)]  
 MX29F1610A@TSOP48 [(SA247-B005)]               MX29F1610B@TSOP48 [(SA247-B005)]  
 MX29F1611@PSOP44 [(SA638)]                   MX29F1615  
 MX29F200B@PSOP44 [(SA638-B006)]               MX29F200B@TSOP48 [(SA247-B005)]  
 MX29F200CB@PSOP44 [(SA638)]                   MX29F200CB@TSOP48 [(SA247-B005)]  
 MX29F200CT@PSOP44 [(SA638)]                   MX29F200CT@TSOP48 [(SA247-B005)]  
 MX29F200T@PSOP44 [(SA638-B006)]               MX29F200T@TSOP48 [(SA247-B005)]  
 MX29F4000                                       MX29F400B@PSOP44 [(SA638-B006)]  
 MX29F400B@TSOP48 [(SA247-B005)]               MX29F400CB@PSOP44 [(SA638)]  
 MX29F400CB@TSOP48 [(SA247-B005)]               MX29F400CT@PSOP44 [(SA638)]  
 MX29F400CT@TSOP48 [(SA247-B005)]               MX29F400T@PSOP44 [(SA638-B006)]  
 MX29F400T@TSOP48 [(SA247-B005)]               MX29F800B@PSOP44 [(SA638-B006)]  
 MX29F800B@TSOP48 [(SA247-B005)]               MX29F800CBM@PSOP44 [(SA638)]  
 MX29F800CBT@TSOP48 [(SA247-B005)]  
 MX29F800CBXB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29F800CTM@PSOP44 [(SA638)]  
 MX29F800CTT@TSOP48 [(SA247-B005)]  
 MX29F800CTXB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29F800T@PSOP44 [(SA638-B006)]               MX29F800T@TSOP48 [(SA247-B005)]  
 MX29GA128EHXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GA128EHXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GA128ELXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GA128ELXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GA129EHXC@FBGA64 [(SA655E-B130A-T064F001Y)]  
 MX29GA129EHXF@FBGA64 [(SA655G-B130A-T064F001Y)]  
 MX29GA129ELXC@FBGA64 [(SA655E-B130A-T064F001Y)]  
 MX29GA129ELXF@FBGA64 [(SA655G-B130A-T064F001Y)]  
 MX29GA256EHXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GA256EHXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GA256ELXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GA256ELXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GA257EHXC@FBGA64 [(SA655E-B130A-T064F001Y)]  
 MX29GA257EHXF@FBGA64 [(SA655G-B130A-T064F001Y)]  
 MX29GA257ELXC@FBGA64 [(SA655E-B130A-T064F001Y)]  
 MX29GA257ELXF@FBGA64 [(SA655G-B130A-T064F001Y)]  
 MX29GL128EDT2@TSOP56 [(SA628-B102)]  
 MX29GL128EDXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL128EHT2@TSOP56 [(SA628-B102)]  
 MX29GL128EHXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GL128EHXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL128ELT2@TSOP56 [(SA628-B102)]  
 MX29GL128ELXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GL128ELXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL128EUT2@TSOP56 [(SA628-B102)]  
 MX29GL128EUXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL256EHT2@TSOP56 [(SA628-B102)]  
 MX29GL256EHXC@FBGA64 [(SA655E-B099A-T064F001Y)]

MX29GL256EHXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL256ELT2@TSOP56 [(SA628-B102)]  
 MX29GL256ELXC@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29GL256ELXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL320EB@TSOP48 [(SA247)]  
 MX29GL320EBXE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29GL320EHT2@TSOP56 [(SA628-B102)]  
 MX29GL320EHXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL320ELT2@TSOP56 [(SA628-B102)]  
 MX29GL320ELXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL320ET@TSOP48 [(SA247)]  
 MX29GL320ETXE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29GL640EB@TSOP48 [(SA247)]  
 MX29GL640EHT2@TSOP56 [(SA628-B102)]  
 MX29GL640EHXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL640ELT2@TSOP56 [(SA628-B102)]  
 MX29GL640ELXF@FBGA64 [(SA655F-B099A-W064F001Y)]  
 MX29GL640ET@TSOP48 [(SA247)] MX29L1611@PSOP44 [(SA638)]  
 MX29L1611@TSOP48 [(SA247-B005)] MX29L1611G  
 MX29L3211@PSOP44 [(SA638)] MX29L3211@TSOP48 [(SA247-B005)]  
 MX29LA128DB@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29LA128DT@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29LA128MB@TSOP56 [(SA628-B102)]  
 MX29LA128MT@TSOP56 [(SA628-B102)]  
 MX29LA129DB@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA129DT@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA129MH@TSOP56 [(SA628-B018)]  
 MX29LA129ML@TSOP56 [(SA628-B018)]  
 MX29LA320DH@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29LA320DL@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29LA320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LA320MB@TSOP48 [(SA247-B005)]  
 MX29LA320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LA320MT@TSOP48 [(SA247-B005)]  
 MX29LA321DH@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA321DL@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA321MB@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA321MB@TSOP56 [(SA628-B018)]  
 MX29LA321MH@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA321MH@TSOP56 [(SA628-B018)]  
 MX29LA321ML@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA321ML@TSOP56 [(SA628-B018)]  
 MX29LA321MT@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA321MT@TSOP56 [(SA628-B018)]  
 MX29LA640EH@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29LA640EL@FBGA64 [(SA655E-B099A-T064F001Y)]  
 MX29LA641DH@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LA641DL@FBGA64 [(SA655A-B054A-T064F001Y)]  
 MX29LV002CB@PLCC32 [(SA015A1T)] MX29LV002CB@TSOP32 [(SA410T)]  
 MX29LV002CT@PLCC32 [(SA015A1T)] MX29LV002CT@TSOP32 [(SA410T)]  
 MX29LV002NCB@PLCC32 [(SA015A1T)] MX29LV002NCB@TSOP32 [(SA410T)]  
 MX29LV002NCT@PLCC32 [(SA015A1T)] MX29LV002NCT@TSOP32 [(SA410T)]  
 MX29LV004B@PLCC32 [(SA015A1T)] MX29LV004B@TSOP40 [(SA409T)]  
 MX29LV004CB@PLCC32 [(SA015A1T)] MX29LV004CB@TSOP40 [(SA409T)]  
 MX29LV004CT@PLCC32 [(SA015A1T)] MX29LV004CT@TSOP40 [(SA409T)]  
 MX29LV004T@PLCC32 [(SA015A1T)] MX29LV004T@TSOP40 [(SA409T)]  
 MX29LV008B@TSOP40 [(SA409T)] MX29LV008BB@TSOP40 [(SA409T)]  
 MX29LV008BT@TSOP40 [(SA409T)] MX29LV008CB@TSOP40 [(SA409T)]  
 MX29LV008CT@TSOP40 [(SA409T)] MX29LV008T@TSOP40 [(SA409T)]  
 MX29LV017AT@TSOP40 [(SA409T)]  
 MX29LV017AX@CSP48 [(SA642G-B026A-T048F001)]  
 MX29LV017BT@TSOP40 [(SA409T)]  
 MX29LV017BX@CSP48 [(SA642G-B026A-T048F001)]  
 MX29LV033T@TSOP40 [(SA409T)] MX29LV040@PLCC32 [(SA015A1T)]  
 MX29LV040@TSOP32 [(SA410T)] MX29LV040C@PLCC32 [(SA015A1T)]  
 MX29LV040C@TSOP32 [(SA410T)]  
 MX29LV065BT@TSOP48 [(SA247-B005)]  
 MX29LV065BXB@FBGA63 [(SA642M-B026A-W048F001)]  
 MX29LV065M@TSOP48 [(SA247-B005)] MX29LV081@TSOP40 [(SA409T)]  
 MX29LV128DB@TSOP48 [(SA247-B005)]  
 MX29LV128DB@TSOP56 [(SA628-B102)]  
 MX29LV128DT@TSOP48 [(SA247-B005)]  
 MX29LV128DT@TSOP56 [(SA628-B102)]  
 MX29LV128MB@TSOP56 [(SA628-B102)]  
 MX29LV128MH@TSOP56 [(SA628-B102)]  
 MX29LV128ML@TSOP56 [(SA628-B102)]  
 MX29LV128MT@TSOP56 [(SA628-B102)]  
 MX29LV160AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160AB@PSOP44 [(SA638)]  
 MX29LV160AB@TSOP48 [(SA247-B005)]



MX29LV160AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160AT@PSOP44 [(SA638)]  
 MX29LV160AT@TSOP48 [(SA247-B005)]  
 MX29LV160B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160B@PSOP44 [(SA638)] MX29LV160B@TSOP48 [(SA247-B005)]  
 MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160BB@PSOP44 [(SA638)]  
 MX29LV160BB@TSOP48 [(SA247-B005)]  
 MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160BT@PSOP44 [(SA638)]  
 MX29LV160BT@TSOP48 [(SA247-B005)]  
 MX29LV160CBM@PSOP44 [(SA638)]  
 MX29LV160CBT@TSOP48 [(SA247-B005)]  
 MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160CTM@PSOP44 [(SA638)]  
 MX29LV160CTT@TSOP48 [(SA247-B005)]  
 MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160DBT@TSOP48 [(SA247-B005)]  
 MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160DBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160DTT@TSOP48 [(SA247-B005)]  
 MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160DTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV160T@PSOP44 [(SA638)] MX29LV160T@TSOP48 [(SA247-B005)]  
 MX29LV320ABT@TSOP48 [(SA247-B005)]  
 MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320ATT@TSOP48 [(SA247-B005)]  
 MX29LV320ATXB@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320ATXE@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320BT@TSOP48 [(SA247-B005)]  
 MX29LV320BXB@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320BXE@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CBT@TSOP48 [(SA247-B005)]  
 MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CTT@TSOP48 [(SA247-B005)]  
 MX29LV320DBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320DBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320DBT@TSOP48 [(SA247-B005)]  
 MX29LV320DTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320DTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320DTT@TSOP48 [(SA247-B005)]  
 MX29LV320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320MB@PSOP44 [(SA638)]  
 MX29LV320MB@TSOP48 [(SA247-B005)]  
 MX29LV320MH@TSOP56 [(SA628-B067)]  
 MX29LV320ML@TSOP56 [(SA628-B067)]  
 MX29LV320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320MT@PSOP44 [(SA638)]  
 MX29LV320MT@TSOP48 [(SA247-B005)]  
 MX29LV320TT@TSOP48 [(SA247-B005)]  
 MX29LV320TXB@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV320TXE@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV321DBT@TSOP48 [(SA247-B005)]  
 MX29LV321DBXB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV321DTT@TSOP48 [(SA247-B005)]  
 MX29LV321DTXB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV400B@PSOP44 [(SA638)] MX29LV400B@TSOP48 [(SA247-B005)]  
 MX29LV400BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV400BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
 MX29LV400CBM@PSOP44 [(SA638)]  
 MX29LV400CBT@TSOP48 [(SA247-B005)]  
 MX29LV400CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV400CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV400CTM@PSOP44 [(SA638)]  
 MX29LV400CTT@TSOP48 [(SA247-B005)]  
 MX29LV400CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV400CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29LV400T@PSOP44 [(SA638)] MX29LV400T@TSOP48 [(SA247-B005)]  
 MX29LV400TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]

MX29LV400TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV640BBT@TSOP48 [(SA247-B005)]  
MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BT@TSOP48 [(SA247-B005)]  
MX29LV640BTT@TSOP48 [(SA247-B005)]  
MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BUT@TSOP48 [(SA247-B005)]  
MX29LV640BUXB@FBGA63 [(SA642M-B026A-W048F001)]  
MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV640DBT@TSOP48 [(SA247-B005)]  
MX29LV640DBX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640DTT@TSOP48 [(SA247-B005)]  
MX29LV640DTX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640EBT@TSOP48 [(SA247-B005)]  
MX29LV640EBX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640ETT@TSOP48 [(SA247-B005)]  
MX29LV640ETX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MB@TSOP48 [(SA247-B005)]  
MX29LV640MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640MH@TSOP56 [(SA628-B067)]  
MX29LV640ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640ML@TSOP56 [(SA628-B067)]  
MX29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MT@TSOP48 [(SA247-B005)]  
MX29LV640TT@TSOP48 [(SA247-B005)]  
MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV641MH@TSOP48 [(SA247-B005)]  
MX29LV641ML@TSOP48 [(SA247-B005)]  
MX29LV800AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB@PSOP44 [(SA638)]  
MX29LV800AB@TSOP48 [(SA247-B005)]  
MX29LV800AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT@PSOP44 [(SA638)]  
MX29LV800AT@TSOP48 [(SA247-B005)]  
MX29LV800B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B@PSOP44 [(SA638)] MX29LV800B@TSOP48 [(SA247-B005)]  
MX29LV800CBM@PSOP44 [(SA638)]  
MX29LV800CBT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CBT@TSOP48 [(SA247-B005)]  
MX29LV800CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTM@PSOP44 [(SA638)]  
MX29LV800CTT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CTT@TSOP48 [(SA247-B005)]  
MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T@PSOP44 [(SA638)] MX29LV800T@TSOP48 [(SA247-B005)]  
MX29LW160BT@TSOP48 [(SA247-B005)]  
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW160TT@TSOP48 [(SA247-B005)]  
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161BT@TSOP48 [(SA247-B005)]  
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161TT@TSOP48 [(SA247-B005)]  
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320BT@TSOP48 [(SA247-B005)]  
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320TT@TSOP48 [(SA247-B005)]  
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321BT@TSOP48 [(SA247-B005)]  
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321TT@TSOP48 [(SA247-B005)]  
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29SL800CB@TSOP48 [(SA247-B005)]  
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]

MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
 MX29SL800CT@TSOP48 [(SA247-B005)]  
 MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
 MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1604C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1604C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69LW162BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW162TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW164BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW164TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW322BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW322TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW324BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW324TXB@CSP69 [(SA642A-B032A-Y096F001)]

## MICROCONTROLLER

MX10E8050I  
 MX10E8050I@TQFP44 [(SA245A)]  
 MX10EXA@TQFP44 [(SA245A)]  
 MX10F201FC@TQFP100(\*) [(TA010-B006)]  
 MX10F202FC@TQFP100(\*) [(TA010-B006)]  
 MX10FLCD  
 MX10FMAXD@PLCC44 [(SA244)]  
 MX10E8050I@PLCC44 [(SA244)]  
 MX10EXA@PLCC44 [(SA244)]  
 MX10FMAXD  
 MX10FMAXD@TQFP44 [(SA245A)]

## MAGNACHIP

### MICROCONTROLLER

GMS34004TK  
 GMS34004TW  
 GMS34112TK@SOIC20 [(SA404)]  
 GMS34140TK  
 GMS77C1000  
 GMS77C1001  
 GMS81604T  
 GMS81604T@SDIP42 [(SA028)]  
 GMS81608T@PLCC44 [(SA244)]  
 GMS87C1102  
 GMS87C1202  
 GMS87C1404  
 GMS87C1408  
 GMS87C2020@LQFP64 [(PEP+S616)]  
 GMS87C2020@SDIP64 [(PEP+S600A)]  
 GMS87C7008@LQFP64 [(PEP+S616)]  
 GMS87C7008@SDIP64 [(PEP+S600A)]  
 GMS87C7016@MQFP64 [(PEP+S618)]  
 HMS87C1404B  
 HMS87C1404B@SOIC28 [(SA404)]  
 HMS87C1408B@SDIP28 [(SA022A)]  
 HMS87C1416B  
 HMS87C1416B@SOIC28 [(SA404)]  
 HMS87C1516B  
 HMS87C1616B  
 HMS87C1716B@SDIP42 [(SA028)]  
 HMS87C1816B@TQFP44 [(SA245A)]  
 MC80F0504@SOP16 [(SA715)]  
 MC80F0504[153mil]@SOP16 [(SA602)]  
 MC80F0604  
 MC80F0604@SSOP20 [(SA626A)]  
 MC80F0704@QFN28 [(SA697)]  
 MC80F0708  
 MC80F0708@SOP28 [(SA715)]  
 MC80F0804@SOP32 [(SA715)]  
 MC80F0808@SOP32 [(SA715)]  
 GMS34004TM  
 GMS34112TK  
 GMS34112TK@SSOP20 [(SA626A)]  
 GMS34140TK@SOIC24 [(SA404)]  
 GMS77C1000@SOIC20 [(SA404)]  
 GMS77C1001@SOIC20 [(SA404)]  
 GMS81604T@PLCC44 [(SA244)]  
 GMS81608T  
 GMS81608T@SDIP42 [(SA028)]  
 GMS87C1102@SOP16 [(SA404)]  
 GMS87C1202@SOP20 [(SA404)]  
 GMS87C1404@SDIP28 [(SA022A)]  
 GMS87C1408@SDIP28 [(SA022A)]  
 GMS87C2020@MQFP64 [(PEP+S618)]  
 GMS87C5108@PQFP80 [(PEP+S611A)]  
 GMS87C7008@MQFP64 [(PEP+S618)]  
 GMS87C7016@LQFP64 [(PEP+S616)]  
 GMS87C7016@SDIP64 [(PEP+S600A)]  
 HMS87C1404B@SDIP28 [(SA022A)]  
 HMS87C1408B  
 HMS87C1408B@SOIC28 [(SA404)]  
 HMS87C1416B@SDIP28 [(SA022A)]  
 HMS87C1508B  
 HMS87C1608B  
 HMS87C1708B@SDIP42 [(SA028)]  
 HMS87C1808B@TQFP44 [(SA245A)]  
 MC80F0504  
 MC80F0504@SSOP16 [(SA626A)]  
 MC80F0604@SOP20 [(SA715)]  
 MC80F0704  
 MC80F0704@SOP28 [(SA715)]  
 MC80F0708@QFN28 [(SA697)]  
 MC80F0804@SDIP32 [(SA653)]  
 MC80F0808@SDIP32 [(SA653)]

## MAXIM

### E(E) PROM/FRAM/NVRAM

DS1220AB	DS1220AD
DS1220Y	DS1225AB
DS1225AD	DS1225D
DS1225E	DS1225Y
DS1230AB	DS1230W
DS1230Y	DS1235AB
DS1235Y	DS1243Y
DS1244	DS1244Y
DS1245AB	DS1245EE
DS1245P	DS1245W
DS1245Y	DS1248P
DS1248W	DS1248Y
DS1249AB	DS1249W
DS1249Y	DS1250AB
DS1250W	DS1250Y
DS1251AB	DS1251W
DS1251Y	DS1256P
DS1256W	DS1256Y
DS1258AB	DS1258W
DS1258Y	DS1265AB
DS1265W	DS1265Y
DS1270AB	DS1270W
DS1270Y	DS1284
DS1284N	DS1284Q@PLCC28 [(SA008A)]
DS1284QN@PLCC28 [(SA008A)]	DS1286
DS1286I	DS1287
DS1287A	DS12887
DS12887A	DS12C887
DS12C887A	DS1386(32K)
DS1386(8K)	DS1485
DS1485@SOIC28 [(SA630)]	DS1488
DS1501	DS1511
DS1553	DS1553W
DS1554	DS1554W
DS1556	DS1642
DS1643	DS1644
DS1644P	DS1644PS [(PEP+S414T)]
DS1645AB	DS1645EE
DS1645Y	DS1646
DS1647	DS1647LPM
DS1650AB	DS1650Y
DS1687-3	DS1687-5
DS17287-3	DS17287-5
DS1742	DS1742W
DS1743	DS1743P
DS1743W	DS1743WP
DS1744	DS1744P
DS1744W	DS1744WP
DS1746	DS1747
DS1747P	DS1747PS [(PEP+S414T)]
DS1747W	DS1747WP
DS1747WPS [(PEP+S414T)]	DS17487-3
DS17487-5	DS17887-3
DS17887-5	DS2430A@TO-92
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-92
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6 [(SA602A)]
DS2433@PR-35	DS2433S(3.9)@SOIC8 [(SA602A)]
DS2433S(5.5)@SOIC8 [(SA605A)]	DS2502
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8 [(SA602A)]
DS2502UNW	DS2502UNW@SOIC8 [(SA602A)]
DS2502UNW@TSOC6 [(SA602A)]	DS2506
DS2506S@SOIC8 [(SA023A)]	DS4510@uSOP10
DS4520@TSSOP16 [(SA026)]	DS4550@TSSOP20 [(SA026)]
MAX9668@QFN20 [(SA759-B006)]	MAX9669@QFN28 [(SA697A-B006)]

## MICROCONTROLLER

DS87C520	DS87C520@PLCC44 [(SA244)]
DS87C520@TQFP44 [(SA245A)]	DS87C530@PLCC52 [(PEP+S415T)]
DS87C550@PLCC68 [(PEP+S414T)]	DS89C420(rev.A)
DS89C420(rev.A)@PLCC44 [(SA244)]	
DS89C420(rev.A)@TQFP44 [(SA245A)]	
MAX7652CCB@TQFP64 [(PEP+S616)]	MAX7652ECB@TQFP64 [(PEP+S616)]

## MAXWELL

**E (E) PROM/FRAM/NVRAM**

27C010T@LDFP32 [(SA438T)]	28C010
28C010@PLCC32 [(SA015A1T)]	28C010@TSOP32 [(SA438T)]
28C010T	28C010T@PLCC32 [(SA015A1T)]
28C010T@TSOP32 [(SA438T)]	28C011
28C011@PLCC32 [(SA015A1T)]	28C011@TSOP32 [(SA438T)]
28C011T	28C011T@PLCC32 [(SA015A1T)]
28C011T@TSOP32 [(SA438T)]	

**MEGAWIN****E (E) PROM/FRAM/NVRAM**

MM25SB512@SOIC8 [(SA602A)]	MM29F040
MM29F040@PLCC32 [(SA015A1T)]	MM29F040@TSOP32 [(SA410T)]
MM29LF040	MM29LF040@PLCC32 [(SA015A1T)]
MM29LF040@TSOP32 [(SA410T)]	

**MICROCONTROLLER**

MPC82G516AD@LQFP48 [(SA248)]	MPC82G516AE
MPC82G516AF@PLCC44 [(SA244)]	MPC82G516AF@PQFP44 [(SA675)]
MPC89E515AE	MPC89E515AF@PQFP44 [(SA675)]
MPC89E515AP@PLCC44 [(SA244)]	MPC89E51AE
MPC89E51AF@PQFP44 [(SA675)]	MPC89E51AP@PLCC44 [(SA244)]
MPC89E52AE	MPC89E52AF@PQFP44 [(SA675)]
MPC89E52AP@PLCC44 [(SA244)]	MPC89E53AE
MPC89E53AF@PQFP44 [(SA675)]	MPC89E53AP@PLCC44 [(SA244)]
MPC89E54AE	MPC89E54AF@PQFP44 [(SA675)]
MPC89E54AP@PLCC44 [(SA244)]	MPC89E58AE
MPC89E58AF@PQFP44 [(SA675)]	MPC89E58AP@PLCC44 [(SA244)]
MPC89L515AE	MPC89L515AF@PQFP44 [(SA675)]
MPC89L515AP@PLCC44 [(SA244)]	MPC89L516X2
MPC89L516X2@PLCC44 [(SA244)]	MPC89L516X2@TQFP44 [(SA245A)]
MPC89L51AE	MPC89L51AF@PQFP44 [(SA675)]
MPC89L51AP@PLCC44 [(SA244)]	MPC89L52AE
MPC89L52AF@PQFP44 [(SA675)]	MPC89L52AP@PLCC44 [(SA244)]
MPC89L53AE	MPC89L53AF@PQFP44 [(SA675)]
MPC89L53AP@PLCC44 [(SA244)]	MPC89L54AE
MPC89L54AF@PQFP44 [(SA675)]	MPC89L54AP@PLCC44 [(SA244)]
MPC89L556X2	MPC89L556X2@PLCC44 [(SA244)]
MPC89L556X2@TQFP44 [(SA245A)]	MPC89L58AE
MPC89L58AF@PQFP44 [(SA675)]	MPC89L58AP@PLCC44 [(SA244)]

**MEMOCOM****E (E) PROM/FRAM/NVRAM**

KI01602AB (Gal)@FBGA66 [(SA642R-B023A-T096F001Y)]
KI01602AB (Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]
KI01602AT (Gal)@FBGA66 [(SA642R-B023A-T096F001Y)]
KI01602AT (Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]
KI01604AB (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI01604AB (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI01604AT (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI01604AT (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI01608AB (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI01608AB (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI01608AT (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI01608AT (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI03204AB (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03204AB (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI03204AT (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03204AT (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI03204BB@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03204BT@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03208AB (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03208AB (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI03208AT (Gal)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03208AT (Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI03208BB@FBGA58 [(SA642R-B023A-T096F001Y)]
KI03208BT@FBGA58 [(SA642R-B023A-T096F001Y)]

```

KIP2832AU(Ha1)@FBGA88 [(SA642R-B300A-T096F001Y)]
KIP2864AU(Ha1)@FBGA88 [(SA642R-B300A-T096F001Y)]
KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03204CB@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03204CT@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03208BB@FBGA56 [(SA642P-B207A-W056F001Y)]
KS03208BT@FBGA56 [(SA642P-B207A-W056F001Y)]
KSP2832AU(Hs1)@FBGA64 [(SA642A-B079-Y096F001Y)]
KSP2864AU(Hs1)@FBGA64 [(SA642A-B079-Y096F001Y)]
KSP3216BB@FBGA56 [(SA642P-B207A-W056F001Y)]
KSP3216BT@FBGA56 [(SA642P-B207A-W056F001Y)]
KSP6416BB@FBGA56 [(SA642P-B347A-W056F001Y)]
KSP6416BT@FBGA56 [(SA642P-B347A-W056F001Y)]
KSP6432AB@FBGA56 [(SA642P-B347A-W056F001Y)]
KSP6432AT@FBGA56 [(SA642P-B347A-W056F001Y)]

```

## MICON

### MICROCONTROLLER

```

MDT10P21(dip18)
MDT10P21(dip22)
MDT10P21@SOP20 [(SA404A)]
MDT10P22(dip18)
MDT10P22(dip22)
MDT10P22@SOP20 [(SA404A)]
MDT10P23(dip18)
MDT10P23(dip22)
MDT10P23@SOP20 [(SA404A)]
MDT10P61
MDT10P61@SSOP20 [(SA626A)]
MDT2005@SOP18 [(SA404A)]
MDT2010
MDT2010@SSOP20 [(SA626A)]
MDT2020@SOP28 [(SA404A)]
MDT2030
MDT2030@SSOP20 [(SA626A)]
MDT2050@SOP18 [(SA404A)]
MDT2051
MDT2051@SSOP20 [(SA626A)]
MDT2060@SOP18 [(SA404A)]

MDT10P21(dip20)
MDT10P21@SOP18 [(SA404A)]
MDT10P21@SOP24 [(SA404A)]
MDT10P22(dip20)
MDT10P22@SOP18 [(SA404A)]
MDT10P22@SOP24 [(SA404A)]
MDT10P23(dip20)
MDT10P23@SOP18 [(SA404A)]
MDT10P23@SOP24 [(SA404A)]
MDT10P61@SOP18 [(SA404A)]
MDT2005
MDT2005@SSOP20 [(SA626A)]
MDT2010@SOP18 [(SA404A)]
MDT2020
MDT2020@SSOP28 [(SA626A)]
MDT2030@SOP18 [(SA404A)]
MDT2050
MDT2050@SSOP20 [(SA626A)]
MDT2051@SOP18 [(SA404A)]
MDT2060
MDT2060@SSOP20 [(SA626A)]

```

## MICROCHIP

### E(E) PROM/FRAM/NVRAM

```

24AA00
24AA00@SOT-23 [(SA717)]
24AA01
24AA01@TSSOP8 [(SA026)]
24AA014@SOIC8 [(SA602A)]
24AA02
24AA02@MSOP8 [(SA666)]
24AA02@SOT-23-5 [(SA717)]
24AA024
24AA024@MSOP8 [(SA666)]
24AA024@TSSOP8 [(SA026)]
24AA025@DFN8 [(SA694)]
24AA025@SOIC8 [(SA602A)]
24AA04
24AA04@TSSOP8 [(SA026)]
24AA08@SOIC8 [(SA602A)]
24AA1025
24AA1025@TSSOP8 [(SA026)]
24AA128@MSOP8 [(SA666)]
24AA128@TSSOP14 [(SA026)]
24AA16
24AA00@SOIC8 [(SA602A)]
24AA00@TSSOP8 [(SA026)]
24AA01@SOIC8 [(SA602A)]
24AA014
24AA014@TSSOP8 [(SA026)]
24AA02@DFN8 [(SA694)]
24AA02@SOIC8 [(SA602A)]
24AA02@TSSOP8 [(SA026)]
24AA024@DFN8 [(SA694)]
24AA024@SOIC8 [(SA602A)]
24AA025
24AA025@MSOP8 [(SA666)]
24AA025@TSSOP8 [(SA026)]
24AA04@SOIC8 [(SA602A)]
24AA08
24AA08@TSSOP8 [(SA026)]
24AA1025@SOIC8 [(SA602A)]
24AA128
24AA128@SOIC8 [(SA602A)]
24AA128@TSSOP8 [(SA026)]
24AA16@SOIC8 [(SA602A)]

```

24AA16@TSSOP8 [(SA026)]	24AA164
24AA164@SOIC8 [(SA602A)]	24AA164@TSSOP8 [(SA026)]
24AA174	24AA174@SOIC8 [(SA602A)]
24AA174@TSSOP8 [(SA026)]	24AA256
24AA256@MSOP8 [(SA666)]	24AA256@SOIC8 [(SA605A)]
24AA256@TSSOP14 [(SA026)]	24AA256@TSSOP8 [(SA026)]
24AA32	24AA32(Rotated)@TSSOP8 [(SA026)]
24AA32@MSOP8 [(SA666)]	24AA32@SOIC8 [(SA602A)]
24AA32@TSSOP8 [(SA026)]	24AA32A
24AA32A(Rotated)@TSSOP8 [(SA026)]	24AA32A@SOIC8 [(SA602A)]
24AA32A@MSOP8 [(SA666)]	24AA512
24AA32A@TSSOP8 [(SA026)]	24AA512@SOIC8 [(SA605A)]
24AA512@DFN8 [(SA683)]	24AA515
24AA512@TSSOP14 [(SA602)]	24AA52
24AA515@SOIC8 [(SA605A)]	24AA52@MSOP8 [(SA666)]
24AA52@DFN8 [(SA694)]	24AA52@TSSOP8 [(SA026)]
24AA52@SOIC8 [(SA602A)]	24AA64(Rotated)@TSSOP8 [(SA026)]
24AA64	24AA64@SOIC8 [(SA602A)]
24AA64@MSOP8 [(SA666)]	24AA65
24AA64@TSSOP8 [(SA026)]	24AA65@TSSOP8 [(SA026)]
24AA65@SOIC8 [(SA602A)]	24C00@SOIC8 [(SA602A)]
24C00	24C00@TSSOP8 [(SA026)]
24C00@SOT-23 [(SA717)]	24C01A
24C01	24C01C
24C01A@SOIC8 [(SA602A)]	24C01C@TSSOP8 [(SA026)]
24C01C@SOIC8 [(SA602A)]	24C02A
24C02	24C02C
24C02A@SOIC8 [(SA602A)]	24C02C@TSSOP8 [(SA026)]
24C02C@SOIC8 [(SA602A)]	24C04A
24C04	24C04A@TSSOP8 [(SA026)]
24C04A@SOIC8 [(SA602A)]	24C08@SOIC8 [(SA602A)]
24C08	24C08B@SOIC8 [(SA602A)]
24C08B	24C16@SOIC8 [(SA602A)]
24C16	24C16B@SOIC8 [(SA602A)]
24C16B	24C32@SOIC8 [(SA602A)]
24C32	24C64@SOIC8 [(SA602A)]
24C64	24C65
24C64@TSSOP8 [(SA026)]	24FC1025
24C65@SOIC8 [(SA602A)]	24FC1025@TSSOP8 [(SA026)]
24FC1025@SOIC8 [(SA602A)]	24FC128@MSOP8 [(SA666)]
24FC128	24FC128@TSSOP14 [(SA026)]
24FC128@SOIC8 [(SA602A)]	24FC256
24FC128@TSSOP8 [(SA026)]	24FC256@SOIC8 [(SA605A)]
24FC256@MSOP8 [(SA666)]	24FC256@TSSOP8 [(SA026)]
24FC256@TSSOP14 [(SA026)]	24FC32@SOIC8 [(SA602A)]
24FC32	24FC512@DFN8 [(SA683)]
24FC512	24FC512@TSSOP14 [(SA602)]
24FC512@SOIC8 [(SA605A)]	24FC515@SOIC8 [(SA605A)]
24FC515	24FC65@SOIC8 [(SA605A)]
24FC65	24LC00@SOIC8 [(SA602A)]
24LC00	24LC00@TSSOP8 [(SA026)]
24LC00@SOT-23 [(SA717)]	24LC014
24LC01	24LC014@TSSOP8 [(SA026)]
24LC014@SOIC8 [(SA602A)]	24LC01B@SOIC8 [(SA602A)]
24LC01B	24LC02
24LC01B@TSSOP8 [(SA026)]	24LC024@SOIC8 [(SA602A)]
24LC024	24LC025
24LC024@TSSOP8 [(SA026)]	24LC025@TSSOP8 [(SA026)]
24LC025@SOIC8 [(SA602A)]	24LC02B@DFN8 [(SA694)]
24LC02B	24LC02B@SOIC8 [(SA602A)]
24LC02B@MSOP8 [(SA666)]	24LC02B@TSSOP8 [(SA026)]
24LC02B@SOT-23-5 [(SA717)]	24LC04B
24LC04	24LC04B@TSSOP8 [(SA026)]
24LC04B@SOIC8 [(SA602A)]	24LC08B
24LC08	24LC08B@TSSOP8 [(SA026)]
24LC08B@SOIC8 [(SA602A)]	24LC1025@SOIC8 [(SA602A)]
24LC1025	24LC128
24LC1025@TSSOP8 [(SA026)]	24LC128@SOIC8 [(SA605A)]
24LC128@MSOP8 [(SA666)]	24LC128@TSSOP8 [(SA026)]
24LC128@TSSOP14 [(SA026)]	24LC16@MSOP8 [(SA605A)]
24LC16	24LC164
24LC16@SOIC8 [(SA602A)]	24LC16B
24LC164@SOIC8 [(SA602A)]	24LC16B@TSSOP8 [(SA026)]
24LC16B@SOIC8 [(SA602A)]	24LC174@SOIC8 [(SA602A)]
24LC174	24LC21@SOIC8 [(SA602A)]
24LC21	24LC21A@SOIC8 [(SA602A)]
24LC21A	24LC22A@SOIC8 [(SA602A)]
24LC22A	24LC256@MSOP8 [(SA666)]
24LC256	24LC256@TSSOP14 [(SA026)]
24LC256@SOIC8 [(SA605A)]	24LC32
24LC256@TSSOP8 [(SA026)]	

24LC32@SOIC8 [(SA602A)]	24LC32A
24LC32A@SOIC8 [(SA602A)]	24LC32A@TSSOP8 [(SA026)]
24LC512	24LC512@DFN8 [(SA683)]
24LC512@SOIC8 [(SA605A)]	24LC512@TSSOP14 [(SA602)]
24LC515	24LC515@SOIC8 [(SA605A)]
24LC64	24LC64(Rotated)@TSSOP8 [(SA026)]
24LC64@MSOP8 [(SA605A)]	24LC64@SOIC8 [(SA602A)]
24LC64@TSSOP8 [(SA026)]	24LC65
24LC65@SOIC8 [(SA602A)]	24LCS21
24LCS21@SOIC8 [(SA602A)]	24LCS21A
24LCS21A@SOIC8 [(SA602A)]	24LCS22
24LCS22@SOIC8 [(SA602A)]	24LCS22A
24LCS22A@SOIC8 [(SA602A)]	24LCS52
24LCS52@DFN8 [(SA694)]	24LCS52@MSOP8 [(SA666)]
24LCS52@SOIC8 [(SA602A)]	24LCS52@TSSOP8 [(SA026)]
25AA010A	25AA010A@DFN8 [(SA683)]
25AA010A@MSOP8 [(SA605A)]	25AA010A@SOIC8 [(SA602A)]
25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8 [(SA026)]
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	25AA020A@DFN8 [(SA683)]
25AA020A	25AA020A@SOIC8 [(SA602A)]
25AA020A@MSOP8 [(SA605A)]	25AA020A@TSSOP8 [(SA026)]
25AA020A@SOT-23 [(SA698)]	25AA040@SOIC8 [(SA602A)]
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	25AA040A
25AA040	25AA040A@MSOP8 [(SA605A)]
25AA040@TSSOP8 [(SA026)]	25AA040A@SOT-23 [(SA698)]
25AA040A@DFN8 [(SA683)]	25AA080@SOIC8 [(SA602A)]
25AA040A@SOIC8 [(SA602A)]	25AA080A@MSOP8 [(SA605A)]
25AA040A@TSSOP8 [(SA026)]	25AA080A@TSSOP8 [(SA026)]
25AA040A[X-Rotated]@TSSOP8 [(SA026)]	25AA080B@MSOP8 [(SA605A)]
25AA080	25AA080B@TSSOP8 [(SA026)]
25AA080A	25AA1024@DFN8 [(SA683)]
25AA080A@SOIC8 [(SA602A)]	25AA1024@SOIJ8 [(SA605)]
25AA080B	25AA128@DFN8 [(SA683)]
25AA080B@SOIC8 [(SA602A)]	25AA128@SOIC8(5.4) [(SA605A)]
25AA1024	25AA160@SOIC8 [(SA602A)]
25AA1024@SOIC8 [(SA602A)]	25AA160A@MSOP8 [(SA605A)]
25AA128	25AA160A@TSSOP8 [(SA026)]
25AA128@SOIC8(4.0) [(SA602A)]	25AA160B@MSOP8 [(SA605A)]
25AA128@TSSOP8 [(SA026)]	25AA160B@TSSOP8 [(SA026)]
25AA128[X-Rotated]@TSSOP8 [(SA026)]	25AA256@DFN8 [(SA683)]
25AA160	25AA256@SOIC8(5.4) [(SA605A)]
25AA160A	25AA320@SOIC8 [(SA602A)]
25AA160A@SOIC8 [(SA602A)]	25AA320@TSSOP8 [(SA026)]
25AA160B	25AA512@DFN8 [(SA683)]
25AA160B@SOIC8 [(SA602A)]	25AA512@SOIJ8 [(SA605)]
25AA256	25AA640@SOIC8 [(SA602A)]
25AA256@SOIC8(4.0) [(SA602A)]	25C040
25AA256@TSSOP8 [(SA026)]	25C040@TSSOP8 [(SA026)]
25AA256[X-Rotated]@TSSOP8 [(SA026)]	25C080@SOIC8 [(SA602A)]
25AA320	25C160@SOIC8 [(SA602A)]
25AA320@TSSOP14 [(SA026)]	25C320@SOIC8 [(SA602A)]
25AA512	25C320@TSSOP8 [(SA026)]
25AA512@SOIC8 [(SA602A)]	25C640@SOIC8 [(SA602A)]
25AA640	25C010A
25AA640@TSSOP8 [(SA026)]	25C010A@MSOP8 [(SA605A)]
25C040@SOIC8 [(SA602A)]	25C010A@SOT-23 [(SA698)]
25C080	25LC020A@DFN8 [(SA683)]
25C160	25LC020A@SOIC8 [(SA602A)]
25C320	25LC020A@TSSOP8 [(SA026)]
25C320@TSSOP14 [(SA026)]	25LC020A[X-Rotated]@TSSOP8 [(SA026)]
25C640	25LC040
25C640@TSSOP8 [(SA026)]	25LC040@TSSOP8 [(SA026)]
25LC010A@DFN8 [(SA683)]	25LC040A@DFN8 [(SA683)]
25LC010A@SOIC8 [(SA602A)]	25LC040A@MSOP8 [(SA605A)]
25LC010A@TSSOP8 [(SA026)]	25LC040A@SOT-23 [(SA698)]
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	25LC040A@SOIC8 [(SA602A)]
25LC020A	25LC080@SOIC8 [(SA602A)]
25LC020A@MSOP8 [(SA605A)]	25LC080A@MSOP8 [(SA605A)]
25LC020A@SOT-23 [(SA698)]	25LC080A@TSSOP8 [(SA026)]
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	25LC080B@MSOP8 [(SA605A)]
25LC040	25LC080B@TSSOP8 [(SA026)]
25LC040@TSSOP8 [(SA026)]	25LC080@SOIC8 [(SA602A)]
25LC040A@DFN8 [(SA683)]	25LC080A@MSOP8 [(SA605A)]
25LC040A@SOIC8 [(SA602A)]	25LC080A@TSSOP8 [(SA026)]
25LC040A@TSSOP8 [(SA026)]	25LC080B@MSOP8 [(SA605A)]
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	25LC080B@TSSOP8 [(SA026)]
25LC080	
25LC080A	
25LC080A@SOIC8 [(SA602A)]	
25LC080B	
25LC080B@SOIC8 [(SA602A)]	



25LC1024	25LC1024@DFN8 [(SA683)]
25LC1024@SOIC8 [(SA602A)]	25LC1024@SOIJ8 [(SA605)]
25LC128	25LC128@DFN8 [(SA683)]
25LC128@SOIC8(4.0) [(SA602A)]	25LC128@SOIC8(5.4) [(SA605A)]
25LC128@TSSOP8 [(SA026)]	
25LC128[X-Rotated]@TSSOP8 [(SA026)]	
25LC160	25LC160@SOIC8 [(SA602A)]
25LC160A	25LC160A@MSOP8 [(SA605A)]
25LC160A@SOIC8 [(SA602A)]	25LC160A@TSSOP8 [(SA026)]
25LC160B	25LC160B@MSOP8 [(SA605A)]
25LC160B@SOIC8 [(SA602A)]	25LC160B@TSSOP8 [(SA026)]
25LC256	25LC256@DFN8 [(SA683)]
25LC256@SOIC8(4.0) [(SA602A)]	25LC256@SOIC8(5.4) [(SA605A)]
25LC256@TSSOP8 [(SA026)]	
25LC256[X-Rotated]@TSSOP8 [(SA026)]	
25LC320	25LC320(SN)@SOIC8 [(SA602A)]
25LC320@TSSOP14 [(SA026)]	25LC320@TSSOP8 [(SA026)]
25LC512	25LC512@DFN8 [(SA683)]
25LC512@SOIC8 [(SA602A)]	25LC512@SOIJ8 [(SA605)]
25LC640	25LC640@SOIC8 [(SA602A)]
25LC640@TSSOP8 [(SA026)]	27256
27256@PLCC32 [(SA015A1T)]	27C128
27C128@PLCC32 [(SA015A1T)]	27C128A
27C128A@PLCC32 [(SA015A1T)]	27C256
27C256@PLCC32 [(SA015A1T)]	27C32A
27C512	27C512@PLCC32 [(SA015A1T)]
27C512A	27C512A@PLCC32 [(SA015A1T)]
27C513	27C64
27C64@PLCC32 [(SA015A1T)]	27C64@SOIC28 [(SA404)]
27HC1616	27HC1616@PLCC44 [(SA244)]
27HC1616L	27HC1616L@PLCC44 [(SA244)]
27HC191	27HC191@PLCC28 [(SA008A)]
27HC191@SOIC24 [(SA404)]	27HC256
27HC256@PLCC32 [(SA015A1T)]	27HC256L
27HC256L@PLCC32 [(SA015A1T)]	27HC291
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24 [(SA404)]
27HC416	27HC64
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28 [(SA404)]
27HC641	27HC641@PLCC28 [(SA008A)]
27HC641@SOIC24 [(SA404)]	27HC641L
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24 [(SA404)]
27HC64L	27HC64L@PLCC32 [(SA015A1T)]
27HC64L@SOIC28 [(SA404)]	27LV256
27LV256@PLCC32 [(SA015A1T)]	27LV64
2817	2864
2864@PLCC32 [(SA015A1T)]	28C04
28C04@PLCC32 [(SA015A1T)]	28C04@SOIC24 [(SA404)]
28C04A	28C04A@PLCC32 [(SA015A1T)]
28C04A@SOIC24 [(SA404)]	28C04AF
28C04AF@PLCC32 [(SA015A1T)]	28C04AF@SOIC24 [(SA404)]
28C04F	28C04F@PLCC32 [(SA015A1T)]
28C04F@SOIC24 [(SA404)]	28C16
28C16@PLCC32 [(SA015A1T)]	28C16@SOIC24 [(SA404)]
28C16A	28C16A@PLCC32 [(SA015A1T)]
28C16A@SOIC24 [(SA404)]	28C16AF
28C16AF@PLCC32 [(SA015A1T)]	28C16AF@SOIC24 [(SA404)]
28C16F	28C16F@PLCC32 [(SA015A1T)]
28C16F@SOIC24 [(SA404)]	28C17
28C17@PLCC32 [(SA015A1T)]	28C17@SOIC28 [(SA404)]
28C17A	28C17A@PLCC32 [(SA015A1T)]
28C17A@SOIC28 [(SA404)]	28C17AF
28C17AF@PLCC32 [(SA015A1T)]	28C17AF@SOIC28 [(SA404)]
28C17F	28C17F@PLCC32 [(SA015A1T)]
28C17F@SOIC28 [(SA404)]	28C256
28C256@PLCC32 [(SA015A1T)]	28C256F
28C256F@PLCC32 [(SA015A1T)]	28C64A
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28 [(SA404)]
28C64A@TSOP32 [(SA410T)]	28C64AF
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28 [(SA404)]
28LV64A	28LV64A@PLCC32 [(SA015A1T)]
28LV64A@SOIC28 [(SA404)]	28PC64
28PC64@PLCC32 [(SA015A1T)]	59C11
59C11@SOIC8 [(SA602A)]	85C72
85C72@SOIC8 [(SA602A)]	85C82
85C82@SOIC8 [(SA602A)]	85C92
85C92@SOIC8 [(SA602A)]	93AA46(08bit)
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46(16bit)
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A(08bit)
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8 [(SA666)]
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23 [(SA717)]
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B(16bit)

```

93AA46B(16bit)@DFN8 [(BBBB)]
93AA46B(16bit)@SOIC8 [(SA602A)]
93AA46B(16bit)@TSSOP8 [(SA026)]
93AA46C(08bit)@DFN8 [(BBBB)]
93AA46C(08bit)@SOIC8 [(SA602A)]
93AA46C(16bit)
93AA46C(16bit)@MSOP8 [(SA666)]
93AA46C(16bit)@TSSOP8 [(SA026)]
93AA56(08bit)@SOIC8 [(SA602A)]
93AA56(16bit)@SOIC8 [(SA602A)]
93AA56A(08bit)@DFN8 [(BBBB)]
93AA56A(08bit)@SOIC8 [(SA602A)]
93AA56A(08bit)@TSSOP8 [(SA026)]
93AA56B(16bit)@DFN8 [(BBBB)]
93AA56B(16bit)@SOIC8 [(SA602A)]
93AA56B(16bit)@TSSOP8 [(SA026)]
93AA56C(08bit)@DFN8 [(BBBB)]
93AA56C(08bit)@SOIC8 [(SA602A)]
93AA56C(16bit)
93AA56C(16bit)@MSOP8 [(SA666)]
93AA56C(16bit)@TSSOP8 [(SA026)]
93AA66(08bit)@SOIC8 [(SA602A)]
93AA66(16bit)@SOIC8 [(SA602A)]
93AA66A(08bit)@DFN8 [(BBBB)]
93AA66A(08bit)@SOIC8 [(SA602A)]
93AA66A(08bit)@TSSOP8 [(SA026)]
93AA66B(16bit)@DFN8 [(BBBB)]
93AA66B(16bit)@SOIC8 [(SA602A)]
93AA66B(16bit)@TSSOP8 [(SA026)]
93AA66C(08bit)@DFN8 [(BBBB)]
93AA66C(08bit)@SOIC8 [(SA602A)]
93AA66C(16bit)
93AA66C(16bit)@MSOP8 [(SA666)]
93AA66C(16bit)@TSSOP8 [(SA026)]
93AA76(08bit)@SOIC8 [(SA602A)]
93AA76(16bit)@SOIC8 [(SA602A)]
93AA76A(08bit)@DFN8 [(BBBB)]
93AA76A(08bit)@SOIC8 [(SA602A)]
93AA76A(08bit)@TSSOP8 [(SA026)]
93AA76B(16bit)@DFN8 [(BBBB)]
93AA76B(16bit)@SOIC8 [(SA602A)]
93AA76B(16bit)@TSSOP8 [(SA026)]
93AA76C(08bit)@DFN8 [(BBBB)]
93AA76C(08bit)@SOIC8 [(SA602A)]
93AA76C(16bit)
93AA76C(16bit)@MSOP8 [(SA666)]
93AA76C(16bit)@TSSOP8 [(SA026)]
93AA86(08bit)@SOIC8 [(SA602A)]
93AA86(16bit)@SOIC8 [(SA602A)]
93AA86A(08bit)@DFN8 [(BBBB)]
93AA86A(08bit)@SOIC8 [(SA602A)]
93AA86A(08bit)@TSSOP8 [(SA026)]
93AA86B(16bit)@DFN8 [(BBBB)]
93AA86B(16bit)@SOIC8 [(SA602A)]
93AA86B(16bit)@TSSOP8 [(SA026)]
93AA86C(08bit)@DFN8 [(BBBB)]
93AA86C(08bit)@SOIC8 [(SA602A)]
93AA86C(16bit)
93AA86C(16bit)@MSOP8 [(SA666)]
93AA86C(16bit)@TSSOP8 [(SA026)]
93C06(08bit)@SOIC8 [(SA602A)]
93C06(16bit)@SOIC8 [(SA602A)]
93C46(08bit)@SOIC8 [(SA602A)]
93C46(16bit)@SOIC8 [(SA602A)]
93C46A(08bit)@DFN8 [(BBBB)]
93C46A(08bit)@SOIC8 [(SA602A)]
93C46A(08bit)@TSSOP8 [(SA026)]
93C46B(16bit)@DFN8 [(BBBB)]
93C46B(16bit)@SOIC8 [(SA602A)]
93C46B(16bit)@TSSOP8 [(SA026)]
93C46C(08bit)@DFN8 [(BBBB)]
93C46C(08bit)@SOIC8 [(SA602A)]
93C46C(16bit)
93C46C(16bit)@MSOP8 [(SA666)]
93C46C(16bit)@TSSOP8 [(SA026)]
93C56(08bit)@SOIC8 [(SA602A)]
93C56(16bit)@SOIC8 [(SA602A)]
93C56A(08bit)@DFN8 [(BBBB)]
93C56A(08bit)@SOIC8 [(SA602A)]
93C56A(08bit)@TSSOP8 [(SA026)]
93C56B(16bit)@DFN8 [(BBBB)]
93AA46B(16bit)@MSOP8 [(SA666)]
93AA46B(16bit)@SOT-23 [(SA717)]
93AA46C(08bit)
93AA46C(08bit)@MSOP8 [(SA666)]
93AA46C(08bit)@TSSOP8 [(SA026)]
93AA46C(16bit)@DFN8 [(BBBB)]
93AA46C(16bit)@SOIC8 [(SA602A)]
93AA56(08bit)
93AA56(16bit)
93AA56A(08bit)
93AA56A(08bit)@MSOP8 [(SA666)]
93AA56A(08bit)@SOT-23 [(SA717)]
93AA56B(16bit)
93AA56B(16bit)@MSOP8 [(SA666)]
93AA56B(16bit)@SOT-23 [(SA717)]
93AA56C(08bit)
93AA56C(08bit)@MSOP8 [(SA666)]
93AA56C(08bit)@TSSOP8 [(SA026)]
93AA56C(16bit)@DFN8 [(BBBB)]
93AA56C(16bit)@SOIC8 [(SA602A)]
93AA66(08bit)
93AA66(16bit)
93AA66A(08bit)
93AA66A(08bit)@MSOP8 [(SA666)]
93AA66A(08bit)@SOT-23 [(SA717)]
93AA66B(16bit)
93AA66B(16bit)@MSOP8 [(SA666)]
93AA66B(16bit)@SOT-23 [(SA717)]
93AA66C(08bit)
93AA66C(08bit)@MSOP8 [(SA666)]
93AA66C(08bit)@TSSOP8 [(SA026)]
93AA66C(16bit)@DFN8 [(BBBB)]
93AA66C(16bit)@SOIC8 [(SA602A)]
93AA76(08bit)
93AA76(16bit)
93AA76A(08bit)
93AA76A(08bit)@MSOP8 [(SA666)]
93AA76A(08bit)@SOT-23 [(SA717)]
93AA76B(16bit)
93AA76B(16bit)@MSOP8 [(SA666)]
93AA76B(16bit)@SOT-23 [(SA717)]
93AA76C(08bit)
93AA76C(08bit)@MSOP8 [(SA666)]
93AA76C(08bit)@TSSOP8 [(SA026)]
93AA76C(16bit)@DFN8 [(BBBB)]
93AA76C(16bit)@SOIC8 [(SA602A)]
93AA86(08bit)
93AA86(16bit)
93AA86A(08bit)
93AA86A(08bit)@MSOP8 [(SSA666)]
93AA86A(08bit)@SOT-23 [(SA717)]
93AA86B(16bit)
93AA86B(16bit)@MSOP8 [(SA666)]
93AA86B(16bit)@SOT-23 [(SA717)]
93AA86C(08bit)
93AA86C(08bit)@MSOP8 [(SA666)]
93AA86C(08bit)@TSSOP8 [(SA026)]
93AA86C(16bit)@DFN8 [(BBBB)]
93AA86C(16bit)@SOIC8 [(SA602A)]
93C06(08bit)
93C06(16bit)
93C46(08bit)
93C46(16bit)
93C46A(08bit)
93C46A(08bit)@MSOP8 [(SA666)]
93C46A(08bit)@SOT-23 [(SA717)]
93C46B(16bit)
93C46B(16bit)@MSOP8 [(SA666)]
93C46B(16bit)@SOT-23 [(SA717)]
93C46C(08bit)
93C46C(08bit)@MSOP8 [(SA666)]
93C46C(08bit)@TSSOP8 [(SA026)]
93C46C(16bit)@DFN8 [(BBBB)]
93C46C(16bit)@SOIC8 [(SA602A)]
93C56(08bit)
93C56(16bit)
93C56A(08bit)
93C56A(08bit)@MSOP8 [(SA666)]
93C56A(08bit)@SOT-23 [(SA717)]
93C56B(16bit)
93C56B(16bit)@MSOP8 [(SA666)]

```

```

93C56B(16bit)@SOIC8 [(SA602A)]      93C56B(16bit)@SOT-23 [(SA717)]
93C56B(16bit)@TSSOP8 [(SA026)]      93C56C(08bit)
93C56C(08bit)@DFN8 [(BBBB)]          93C56C(08bit)@MSOP8 [(SA666)]
93C56C(08bit)@SOIC8 [(SA602A)]      93C56C(08bit)@TSSOP8 [(SA026)]
93C56C(16bit)                          93C56C(16bit)@DFN8 [(BBBB)]
93C56C(16bit)@MSOP8 [(SA666)]        93C56C(16bit)@SOIC8 [(SA602A)]
93C56C(16bit)@TSSOP8 [(SA026)]      93C66(08bit)
93C66(08bit)@SOIC8 [(SA602A)]        93C66(16bit)
93C66(16bit)@SOIC8 [(SA602A)]        93C66A(08bit)
93C66A(08bit)@DFN8 [(BBBB)]          93C66A(08bit)@MSOP8 [(SA666)]
93C66A(08bit)@SOIC8 [(SA602A)]      93C66A(08bit)@SOT-23 [(SA717)]
93C66A(08bit)@TSSOP8 [(SA026)]      93C66B(16bit)
93C66B(16bit)@DFN8 [(BBBB)]          93C66B(16bit)@MSOP8 [(SA666)]
93C66B(16bit)@SOIC8 [(SA602A)]      93C66B(16bit)@SOT-23 [(SA717)]
93C66B(16bit)@TSSOP8 [(SA026)]      93C66C(08bit)
93C66C(08bit)@DFN8 [(BBBB)]          93C66C(08bit)@MSOP8 [(SA666)]
93C66C(08bit)@SOIC8 [(SA602A)]      93C66C(08bit)@TSSOP8 [(SA026)]
93C66C(16bit)                          93C66C(16bit)@DFN8 [(BBBB)]
93C66C(16bit)@MSOP8 [(SA666)]        93C66C(16bit)@SOIC8 [(SA602A)]
93C66C(16bit)@TSSOP8 [(SA026)]      93C76(08bit)
93C76(08bit)@SOIC8 [(SA602A)]        93C76(16bit)
93C76(16bit)@SOIC8 [(SA602A)]        93C76A(08bit)
93C76A(08bit)@DFN8 [(BBBB)]          93C76A(08bit)@MSOP8 [(SA666)]
93C76A(08bit)@SOIC8 [(SA602A)]      93C76A(08bit)@SOT-23 [(SA717)]
93C76A(08bit)@TSSOP8 [(SA026)]      93C76B(16bit)
93C76B(16bit)@DFN8 [(BBBB)]          93C76B(16bit)@MSOP8 [(SA666)]
93C76B(16bit)@SOIC8 [(SA602A)]      93C76B(16bit)@SOT-23 [(SA717)]
93C76B(16bit)@TSSOP8 [(SA026)]      93C76C(08bit)
93C76C(08bit)@DFN8 [(BBBB)]          93C76C(08bit)@MSOP8 [(SA666)]
93C76C(08bit)@SOIC8 [(SA602A)]      93C76C(08bit)@TSSOP8 [(SA026)]
93C76C(16bit)                          93C76C(16bit)@DFN8 [(BBBB)]
93C76C(16bit)@MSOP8 [(SA666)]        93C76C(16bit)@SOIC8 [(SA602A)]
93C76C(16bit)@TSSOP8 [(SA026)]      93C86(08bit)
93C86(08bit)@SOIC8 [(SA602A)]        93C86(16bit)
93C86(16bit)@SOIC8 [(SA602A)]        93C86A(08bit)
93C86A(08bit)@DFN8 [(BBBB)]          93C86A(08bit)@MSOP8 [(SA666)]
93C86A(08bit)@SOIC8 [(SA602A)]      93C86A(08bit)@SOT-23 [(SA717)]
93C86A(08bit)@TSSOP8 [(SA026)]      93C86B(16bit)
93C86B(16bit)@DFN8 [(BBBB)]          93C86B(16bit)@MSOP8 [(SA666)]
93C86B(16bit)@SOIC8 [(SA602A)]      93C86B(16bit)@SOT-23 [(SA717)]
93C86B(16bit)@TSSOP8 [(SA026)]      93C86C(08bit)
93C86C(08bit)@DFN8 [(BBBB)]          93C86C(08bit)@MSOP8 [(SA666)]
93C86C(08bit)@SOIC8 [(SA602A)]      93C86C(08bit)@TSSOP8 [(SA026)]
93C86C(16bit)                          93C86C(16bit)@DFN8 [(BBBB)]
93C86C(16bit)@MSOP8 [(SA666)]        93C86C(16bit)@SOIC8 [(SA602A)]
93C86C(16bit)@TSSOP8 [(SA026)]      93LC46(08bit)
93LC46(08bit)@SOIC8 [(SA602A)]        93LC46(16bit)
93LC46(16bit)@SOIC8 [(SA602A)]        93LC46A(08bit)
93LC46A(08bit)@DFN8 [(BBBB)]          93LC46A(08bit)@MSOP8 [(SA666)]
93LC46A(08bit)@SOIC8 [(SA602A)]      93LC46A(08bit)@SOT-23 [(SA717)]
93LC46A(08bit)@TSSOP8 [(SA026)]      93LC46B(16bit)
93LC46B(16bit)@DFN8 [(BBBB)]          93LC46B(16bit)@MSOP8 [(SA666)]
93LC46B(16bit)@SOIC8 [(SA602A)]      93LC46B(16bit)@SOT-23 [(SA717)]
93LC46B(16bit)@TSSOP8 [(SA026)]      93LC46BX
93LC46BX@SOIC8 [(SA602A)]            93LC46C(08bit)
93LC46C(08bit)@DFN8 [(BBBB)]          93LC46C(08bit)@MSOP8 [(SA666)]
93LC46C(08bit)@SOIC8 [(SA602A)]      93LC46C(08bit)@TSSOP8 [(SA026)]
93LC46C(16bit)                          93LC46C(16bit)@DFN8 [(BBBB)]
93LC46C(16bit)@MSOP8 [(SA666)]        93LC46C(16bit)@SOIC8 [(SA602A)]
93LC46C(16bit)@TSSOP8 [(SA026)]      93LC56(08bit)
93LC56(08bit)@SOIC8 [(SA602A)]        93LC56(16bit)
93LC56(16bit)@SOIC8 [(SA602A)]        93LC56A(08bit)
93LC56A(08bit)@DFN8 [(BBBB)]          93LC56A(08bit)@MSOP8 [(SA666)]
93LC56A(08bit)@SOIC8 [(SA602A)]      93LC56A(08bit)@SOT-23 [(SA717)]
93LC56A(08bit)@TSSOP8 [(SA026)]      93LC56B(16bit)
93LC56B(16bit)@DFN8 [(BBBB)]          93LC56B(16bit)@MSOP8 [(SA666)]
93LC56B(16bit)@SOIC8 [(SA602A)]      93LC56B(16bit)@SOT-23 [(SA717)]
93LC56B(16bit)@TSSOP8 [(SA026)]      93LC56BX
93LC56BX@SOIC8 [(SA602A)]            93LC56C(08bit)
93LC56C(08bit)@DFN8 [(BBBB)]          93LC56C(08bit)@MSOP8 [(SA666)]
93LC56C(08bit)@SOIC8 [(SA602A)]      93LC56C(08bit)@TSSOP8 [(SA026)]
93LC56C(16bit)                          93LC56C(16bit)@DFN8 [(BBBB)]
93LC56C(16bit)@MSOP8 [(SA666)]        93LC56C(16bit)@SOIC8 [(SA602A)]
93LC56C(16bit)@TSSOP8 [(SA026)]      93LC66(08bit)
93LC66(08bit)@SOIC8 [(SA602A)]        93LC66(16bit)
93LC66(16bit)@SOIC8 [(SA602A)]        93LC66A(08bit)
93LC66A(08bit)@DFN8 [(BBBB)]          93LC66A(08bit)@MSOP8 [(SA666)]
93LC66A(08bit)@SOIC8 [(SA602A)]      93LC66A(08bit)@SOT-23 [(SA717)]
93LC66A(08bit)@TSSOP8 [(SA026)]      93LC66B(16bit)
93LC66B(16bit)@DFN8 [(BBBB)]          93LC66B(16bit)@MSOP8 [(SA666)]
93LC66B(16bit)@SOIC8 [(SA602A)]      93LC66B(16bit)@SOT-23 [(SA717)]

```

93LC66B(16bit)@TSSOP8 [(SA026)]	93LC66BX
93LC66BX@SOIC8 [(SA602A)]	93LC66C(08bit)
93LC66C(08bit)@DFN8 [(BBBB)]	93LC66C(08bit)@MSOP8 [(SA666)]
93LC66C(08bit)@SOIC8 [(SA602A)]	93LC66C(08bit)@TSSOP8 [(SA026)]
93LC66C(16bit)	93LC66C(16bit)@DFN8 [(BBBB)]
93LC66C(16bit)@MSOP8 [(SA666)]	93LC66C(16bit)@SOIC8 [(SA602A)]
93LC66C(16bit)@TSSOP8 [(SA026)]	93LC76(08bit)
93LC76(08bit)@SOIC8 [(SA602A)]	93LC76(16bit)
93LC76(16bit)@SOIC8 [(SA602A)]	93LC76A(08bit)
93LC76A(08bit)@DFN8 [(BBBB)]	93LC76A(08bit)@MSOP8 [(SA666)]
93LC76A(08bit)@SOIC8 [(SA602A)]	93LC76A(08bit)@SOT-23 [(SA717)]
93LC76A(08bit)@TSSOP8 [(SA026)]	93LC76B(16bit)
93LC76B(16bit)@DFN8 [(BBBB)]	93LC76B(16bit)@MSOP8 [(SA666)]
93LC76B(16bit)@SOIC8 [(SA602A)]	93LC76B(16bit)@SOT-23 [(SA717)]
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C(08bit)
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8 [(SA666)]
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8 [(SA026)]
93LC76C(16bit)	93LC76C(16bit)@DFN8 [(BBBB)]
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8 [(SA602A)]
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86(08bit)
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86(16bit)
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A(08bit)
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8 [(SSA666)]
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23 [(SA717)]
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B(16bit)
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8 [(SA666)]
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23 [(SA717)]
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C(08bit)
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8 [(SA666)]
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8 [(SA026)]
93LC86C(16bit)	93LC86C(16bit)@DFN8 [(BBBB)]
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8 [(SA602A)]
93LC86C(16bit)@TSSOP8 [(SA026)]	93LCS46
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8 [(SA602A)]
93LCS56	93LCS56@SOIC14 [(SA026)]
93LCS56@SOIC8 [(SA602A)]	93LCS66
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8 [(SA602A)]
ER5911	ER5911@SOIC8 [(SA602A)]
HCS101	HCS101SN@SOIC8 [(SA602A)]
HCS200	HCS200SN@SOIC8 [(SA602A)]
HCS300	HCS300SN@SOIC8 [(SA602A)]
HCS301	HCS301SN@SOIC8 [(SA602A)]
HCS320	HCS320SN@SOIC8 [(SA602A)]
HCS360	HCS360SN@SOIC8 [(SA602A)]
HCS361	HCS361SN@SOIC8 [(SA602A)]

## MICROCONTROLLER

MCP25020	
MCP25020(150mil)@SOIC14 [(SA602)]	
MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25020(208mil)@SOIC14 [(SA404)]	
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25020(ISP) [ISP-HEADER01]	MCP25025
MCP25025(150mil)@SOIC14 [(SA602)]	
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25025(208mil)@SOIC14 [(SA404)]	
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25025(ISP) [ISP-HEADER01]	MCP25050
MCP25050(150mil)@SOIC14 [(SA602)]	
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25050(208mil)@SOIC14 [(SA404)]	
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25050(ISP) [ISP-HEADER01]	MCP25055
MCP25055(150mil)@SOIC14 [(SA602)]	
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25055(208mil)@SOIC14 [(SA404)]	
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25055(ISP) [ISP-HEADER01]	PIC10F200
PIC10F200(ISP) [ISP-HEADER01]	PIC10F200@SOT6 [(SA717)]
PIC10F200@SOT6(ISP) [ISP-HEADER01]	
PIC10F202	PIC10F202(ISP) [ISP-HEADER01]
PIC10F202@SOT6 [(SA717)]	
PIC10F202@SOT6(ISP) [ISP-HEADER01]	
PIC10F204	PIC10F204(ISP) [ISP-HEADER01]
PIC10F204@SOT6 [(SA717)]	
PIC10F204@SOT6(ISP) [ISP-HEADER01]	
PIC10F206	PIC10F206(ISP) [ISP-HEADER01]
PIC10F206@SOT6 [(SA717)]	

```

PIC10F206@SOT6(ISP) [ISP-HEADER01]
PIC10F220 PIC10F220(ISP) [ISP-HEADER01]
PIC10F220@SOT6 [(SA717)]
PIC10F220@SOT6(ISP) [ISP-HEADER01]
PIC10F222 PIC10F222(ISP) [ISP-HEADER01]
PIC10F222@SOT6 [(SA717)]
PIC10F222@SOT6(ISP) [ISP-HEADER01]
PIC12C508 PIC12C508(ISP) [ISP-HEADER01]
PIC12C508@SOIC8 [(SA605A)]
PIC12C508@SOIC8(ISP) [ISP-HEADER01]
PIC12C508A PIC12C508A(ISP) [ISP-HEADER01]
PIC12C508A(SM)@SOIC8 [(SA605A)]
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C508A(SN)@SOIC8 [(SA602A)]
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509 PIC12C509(ISP) [ISP-HEADER01]
PIC12C509(SM)@SOIC8 [(SA605A)]
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509(SN)@SOIC8 [(SA602A)]
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A PIC12C509A(ISP) [ISP-HEADER01]
PIC12C509A(SM)@SOIC8 [(SA605A)]
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A(SN)@SOIC8 [(SA602A)]
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12C509A@DFN8 [(SA683)]
PIC12C509A@DFN8(ISP) [ISP-HEADER01]
PIC12C671 PIC12C671(ISP) [ISP-HEADER01]
PIC12C671@DFN8 [(SA683)]
PIC12C671@DFN8(ISP) [ISP-HEADER01]
PIC12C671@SOIC8 [(SA605A)]
PIC12C671@SOIC8(ISP) [ISP-HEADER01]
PIC12C672 PIC12C672(ISP) [ISP-HEADER01]
PIC12C672@DFN8 [(SA683)]
PIC12C672@DFN8(ISP) [ISP-HEADER01]
PIC12C672@SOIC8 [(SA605A)]
PIC12C672@SOIC8(ISP) [ISP-HEADER01]
PIC12CE518 PIC12CE518(ISP) [ISP-HEADER01]
PIC12CE518@SOIC8 [(SA605A)]
PIC12CE518@SOIC8(ISP) [ISP-HEADER01]
PIC12CE519 PIC12CE519(ISP) [ISP-HEADER01]
PIC12CE519(SM)@SOIC8 [(SA605A)]
PIC12CE519(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12CE519(SN)@SOIC8 [(SA602A)]
PIC12CE519(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12CE673 PIC12CE673(ISP) [ISP-HEADER01]
PIC12CE673@SOIC8 [(SA605A)]
PIC12CE673@SOIC8(ISP) [ISP-HEADER01]
PIC12CE674 PIC12CE674(ISP) [ISP-HEADER01]
PIC12CE674@SOIC8 [(SA605A)]
PIC12CE674@SOIC8(ISP) [ISP-HEADER01]
PIC12F508 PIC12F508(ISP) [ISP-HEADER01]
PIC12F508@MSOP8 [(SA666)]
PIC12F508@MSOP8(ISP) [ISP-HEADER01]
PIC12F508@SOIC8 [(SA602)]
PIC12F508@SOIC8(ISP) [ISP-HEADER01]
PIC12F509 PIC12F509(ISP) [ISP-HEADER01]
PIC12F509@MSOP8 [(SA666)]
PIC12F509@MSOP8(ISP) [ISP-HEADER01]
PIC12F509@SOIC8 [(SA602)]
PIC12F509@SOIC8(ISP) [ISP-HEADER01]
PIC12F510 PIC12F510(ISP) [ISP-HEADER01]
PIC12F510@MSOP8 [(SA666)]
PIC12F510@MSOP8(ISP) [ISP-HEADER01]
PIC12F510@SOIC8 [(SA605A)]
PIC12F510@SOIC8(ISP) [ISP-HEADER01]
PIC12F519 PIC12F519@DFN8 [(SA724)]
PIC12F519@SOIC8 [(SA602)]
PIC12F609 PIC12F609(ISP) [ISP-HEADER01]
PIC12F609@DFN8 [(SA703)]
PIC12F609@DFN8(ISP) [ISP-HEADER01]
PIC12F609@SOIC8 [(SA602A)]
PIC12F609@SOIC8(ISP) [ISP-HEADER01]
PIC12F615 PIC12F615(ISP) [ISP-HEADER01]
PIC12F615@DFN8 [(SA703)]
PIC12F615@DFN8(ISP) [ISP-HEADER01]
PIC12F615@SOIC8 [(SA602A)]
PIC12F615@SOIC8(ISP) [ISP-HEADER01]
PIC12F629 PIC12F629(ISP) [ISP-HEADER01]
PIC12F629(SM)@SOIC8 [(SA605A)]
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]

```

PIC12F629(SN)@SOIC8 [(SA602A)]  
 PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12F629@DFN8 [(SA683)]  
 PIC12F629@DFN8(ISP) [ISP-HEADER01]  
 PIC12F635 PIC12F635(ISP) [ISP-HEADER01]  
 PIC12F635(MD)@DFN8 [(SA744)]  
 PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]  
 PIC12F635(MF)@DFN8 [(SA683)]  
 PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]  
 PIC12F635(SM)@SOIC8 [(SA605A)]  
 PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12F635(SN)@SOIC8 [(SA602A)]  
 PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12F675 PIC12F675(ISP) [ISP-HEADER01]  
 PIC12F675(SM)@SOIC8 [(SA605A)]  
 PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12F675(SN)@SOIC8 [(SA602A)]  
 PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12F675@DFN8 [(SA683)]  
 PIC12F675@DFN8(ISP) [ISP-HEADER01]  
 PIC12F675@SSOP20 [(SA626A)]  
 PIC12F675@SSOP20(ISP) [ISP-HEADER01]  
 PIC12F683 PIC12F683(ISP) [ISP-HEADER01]  
 PIC12F683(MD)@DFN8 [(SA744)]  
 PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]  
 PIC12F683(MF)@DFN8 [(SA683)]  
 PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]  
 PIC12F683(SM)@SOIC8 [(SA605A)]  
 PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12F683(SN)@SOIC8 [(SA602A)]  
 PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12HV609 PIC12HV609(ISP) [ISP-HEADER01]  
 PIC12HV609@DFN8 [(SA703)]  
 PIC12HV609@DFN8(ISP) [ISP-HEADER01]  
 PIC12HV609@SOIC8 [(SA602A)]  
 PIC12HV609@SOIC8(ISP) [ISP-HEADER01]  
 PIC12HV615 PIC12HV615(ISP) [ISP-HEADER01]  
 PIC12HV615@DFN8 [(SA703)]  
 PIC12HV615@DFN8(ISP) [ISP-HEADER01]  
 PIC12HV615@SOIC8 [(SA602A)]  
 PIC12HV615@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC508 PIC12LC508(ISP) [ISP-HEADER01]  
 PIC12LC508@SOIC8 [(SA605A)]  
 PIC12LC508@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC508A PIC12LC508A(ISP) [ISP-HEADER01]  
 PIC12LC508A(SM)@SOIC8 [(SA605A)]  
 PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC508A(SN)@SOIC8 [(SA602A)]  
 PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC509 PIC12LC509(ISP) [ISP-HEADER01]  
 PIC12LC509(SM)@SOIC8 [(SA605A)]  
 PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC509(SN)@SOIC8 [(SA602A)]  
 PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC509A PIC12LC509A(ISP) [ISP-HEADER01]  
 PIC12LC509A(SM)@SOIC8 [(SA605A)]  
 PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC509A(SN)@SOIC8 [(SA602A)]  
 PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC671 PIC12LC671(ISP) [ISP-HEADER01]  
 PIC12LC671@DFN8 [(SA683)]  
 PIC12LC671@DFN8(ISP) [ISP-HEADER01]  
 PIC12LC671@SOIC8 [(SA605A)]  
 PIC12LC671@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LC672 PIC12LC672(ISP) [ISP-HEADER01]  
 PIC12LC672@DFN8 [(SA683)]  
 PIC12LC672@DFN8(ISP) [ISP-HEADER01]  
 PIC12LC672@SOIC8 [(SA605A)]  
 PIC12LC672@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LF508 PIC12LF508(ISP) [ISP-HEADER01]  
 PIC12LF508@MSOP8 [(SA666)]  
 PIC12LF508@MSOP8(ISP) [ISP-HEADER01]  
 PIC12LF508@SOIC8 [(SA602)]  
 PIC12LF508@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LF509 PIC12LF509(ISP) [ISP-HEADER01]  
 PIC12LF509@MSOP8 [(SA666)]  
 PIC12LF509@MSOP8(ISP) [ISP-HEADER01]  
 PIC12LF509@SOIC8 [(SA602)]  
 PIC12LF509@SOIC8(ISP) [ISP-HEADER01]  
 PIC12LF519 PIC12LF519@DFN8 [(SA724)]  
 PIC12LF519@MSOP8 [(SA666)] PIC12LF519@SOIC8 [(SA602)]

PIC14000	PIC14000(ISP) [ISP-HEADER01]
PIC14000@SOIC28 [(SA404)]	
PIC14000@SOIC28(ISP) [ISP-HEADER01]	
PIC14000@SSOP28 [(SA626A)]	
PIC14000@SSOP28(ISP) [ISP-HEADER01]	
PIC16C432	PIC16C432(ISP) [ISP-HEADER01]
PIC16C432@SSOP20 [(SA626A)]	
PIC16C432@SSOP20(ISP) [ISP-HEADER01]	
PIC16C433	PIC16C433(ISP) [ISP-HEADER01]
PIC16C433@SOIC18 [(SA404)]	
PIC16C433@SOIC18(ISP) [ISP-HEADER01]	
PIC16C505	PIC16C505@SOIC14 [(SA602)]
PIC16C52	PIC16C52@SOIC18 [(SA404)]
PIC16C54	PIC16C54@SOIC18 [(SA404)]
PIC16C54A	PIC16C54A@SOIC18 [(SA404)]
PIC16C54A@SSOP20 [(SA626A)]	PIC16C54B
PIC16C54B@SOIC18 [(SA404)]	PIC16C54B@SSOP20 [(SA626A)]
PIC16C54C	PIC16C54C@SOIC18 [(SA404)]
PIC16C54C@SSOP20 [(SA626A)]	PIC16C55
PIC16C55@SOIC28 [(SA404)]	PIC16C554
PIC16C554(ISP) [ISP-HEADER01]	PIC16C554@SOIC18 [(SA404)]
PIC16C554@SOIC18(ISP) [ISP-HEADER01]	
PIC16C554@SSOP20 [(SA626A)]	
PIC16C554@SSOP20(ISP) [ISP-HEADER01]	
PIC16C556	PIC16C556(ISP) [ISP-HEADER01]
PIC16C556@SOIC18 [(SA404)]	
PIC16C556@SOIC18(ISP) [ISP-HEADER01]	
PIC16C558	PIC16C558(ISP) [ISP-HEADER01]
PIC16C558@SOIC18 [(SA404)]	
PIC16C558@SOIC18(ISP) [ISP-HEADER01]	
PIC16C558@SSOP20 [(SA626A)]	
PIC16C558@SSOP20(ISP) [ISP-HEADER01]	
PIC16C55A	PIC16C55A@SOIC28 [(SA404)]
PIC16C55A@SSOP28 [(SA626A)]	PIC16C56
PIC16C56@SOIC18 [(SA404)]	PIC16C56A
PIC16C56A@SOIC18 [(SA404)]	PIC16C56A@SSOP20 [(SA626A)]
PIC16C57	PIC16C57@SOIC28 [(SA404)]
PIC16C57@SSOP28 [(SA626A)]	PIC16C57C
PIC16C57C@SOIC28 [(SA404)]	PIC16C57C@SSOP28 [(SA626A)]
PIC16C58	PIC16C58@SOIC18 [(SA404)]
PIC16C58A	PIC16C58A@SOIC18 [(SA404)]
PIC16C58A@SSOP20 [(SA626A)]	PIC16C58B
PIC16C58B@SOIC18 [(SA404)]	PIC16C58B@SSOP20 [(SA626A)]
PIC16C61	PIC16C61(ISP) [ISP-HEADER01]
PIC16C61@SOIC18 [(SA404)]	
PIC16C61@SOIC18(ISP) [ISP-HEADER01]	
PIC16C62	PIC16C62(ISP) [ISP-HEADER01]
PIC16C62@SOIC28 [(SA404)]	
PIC16C62@SOIC28(ISP) [ISP-HEADER01]	
PIC16C62@SSOP28 [(SA626A)]	
PIC16C62@SSOP28(ISP) [ISP-HEADER01]	
PIC16C620	PIC16C620(ISP) [ISP-HEADER01]
PIC16C620@SOIC18 [(SA404)]	
PIC16C620@SOIC18(ISP) [ISP-HEADER01]	
PIC16C620A	PIC16C620A(ISP) [ISP-HEADER01]
PIC16C620A@SOIC18 [(SA404)]	
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]	
PIC16C620A@SSOP20 [(SA626A)]	
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]	
PIC16C621	PIC16C621(ISP) [ISP-HEADER01]
PIC16C621@SOIC18 [(SA404)]	
PIC16C621@SOIC18(ISP) [ISP-HEADER01]	
PIC16C621A	PIC16C621A(ISP) [ISP-HEADER01]
PIC16C621A@SOIC18 [(SA404)]	
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]	
PIC16C621A@SSOP20 [(SA626A)]	
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]	
PIC16C622	PIC16C622(ISP) [ISP-HEADER01]
PIC16C622@SOIC18 [(SA404)]	
PIC16C622@SOIC18(ISP) [ISP-HEADER01]	
PIC16C622A	PIC16C622A(ISP) [ISP-HEADER01]
PIC16C622A@SOIC18 [(SA404)]	
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]	
PIC16C622A@SSOP20 [(SA626A)]	
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]	
PIC16C625	PIC16C625(ISP) [ISP-HEADER01]
PIC16C625@SOIC18 [(SA404)]	
PIC16C625@SOIC18(ISP) [ISP-HEADER01]	
PIC16C62A	PIC16C62A(ISP) [ISP-HEADER01]
PIC16C62A@SOIC28 [(SA404)]	
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]	

```

PIC16C62A@SSOP28 [(SA626A)]
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]
PIC16C62B                                     PIC16C62B(ISP) [ISP-HEADER01]
PIC16C62B@SOIC28 [(SA404)]
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]
PIC16C62B@SSOP28 [(SA626A)]
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]
PIC16C63                                     PIC16C63(ISP) [ISP-HEADER01]
PIC16C63@SOIC28 [(SA404)]
PIC16C63@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A                                     PIC16C63A(ISP) [ISP-HEADER01]
PIC16C63A@SOIC28 [(SA404)]
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A@SSOP28 [(SA626A)]
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]
PIC16C64                                     PIC16C64(ISP) [ISP-HEADER01]
PIC16C64@PLCC44 [(SA244)]
PIC16C64@PLCC44(ISP) [ISP-HEADER01]
PIC16C64@TQFP44 [(SA245A)]
PIC16C64@TQFP44(ISP) [ISP-HEADER01]
PIC16C641                                     PIC16C641@SOIC28 [(SA404)]
PIC16C641@SSOP28 [(SA626A)]
PIC16C641@SOIC28 [(SA404)]
PIC16C642@SSOP28 [(SA626A)]
PIC16C64A                                     PIC16C64A(ISP) [ISP-HEADER01]
PIC16C64A@PLCC44 [(SA244)]
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]
PIC16C64A@TQFP44 [(SA245A)]
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65                                     PIC16C65(ISP) [ISP-HEADER01]
PIC16C65@PLCC44 [(SA244)]
PIC16C65@PLCC44(ISP) [ISP-HEADER01]
PIC16C65@TQFP44 [(SA245A)]
PIC16C65@TQFP44(ISP) [ISP-HEADER01]
PIC16C65A                                     PIC16C65A(ISP) [ISP-HEADER01]
PIC16C65A@PLCC44 [(SA244)]
PIC16C65A@PLCC44(ISP) [ISP-HEADER01]
PIC16C65A@TQFP44 [(SA245A)]
PIC16C65A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65B                                     PIC16C65B(ISP) [ISP-HEADER01]
PIC16C65B@PLCC44 [(SA244)]
PIC16C65B@PLCC44(ISP) [ISP-HEADER01]
PIC16C65B@TQFP44 [(SA245A)]
PIC16C65B@TQFP44(ISP) [ISP-HEADER01]
PIC16C66                                     PIC16C66(ISP) [ISP-HEADER01]
PIC16C66@SOIC28 [(SA404)]
PIC16C66@SOIC28(ISP) [ISP-HEADER01]
PIC16C661                                     PIC16C661@PLCC44 [(SA244)]
PIC16C661@TQFP44 [(SA245A)]
PIC16C662@PLCC44 [(SA244)]
PIC16C662@TQFP44 [(SA245A)]
PIC16C67                                     PIC16C67(ISP) [ISP-HEADER01]
PIC16C67@PLCC44 [(SA244)]
PIC16C67@PLCC44(ISP) [ISP-HEADER01]
PIC16C67@TQFP44 [(SA245A)]
PIC16C67@TQFP44(ISP) [ISP-HEADER01]
PIC16C70                                     PIC16C70(ISP) [ISP-HEADER01]
PIC16C70@SOIC18 [(SA404)]
PIC16C70@SOIC18(ISP) [ISP-HEADER01]
PIC16C71                                     PIC16C71(ISP) [ISP-HEADER01]
PIC16C71@SOIC18 [(SA404)]
PIC16C71@SOIC18(ISP) [ISP-HEADER01]
PIC16C710                                     PIC16C710(ISP) [ISP-HEADER01]
PIC16C710@SOIC18 [(SA404)]
PIC16C710@SOIC18(ISP) [ISP-HEADER01]
PIC16C710@SSOP20 [(SA626A)]
PIC16C710@SSOP20(ISP) [ISP-HEADER01]
PIC16C711                                     PIC16C711(ISP) [ISP-HEADER01]
PIC16C711@SOIC18 [(SA404)]
PIC16C711@SOIC18(ISP) [ISP-HEADER01]
PIC16C711@SSOP20 [(SA626A)]
PIC16C711@SSOP20(ISP) [ISP-HEADER01]
PIC16C712                                     PIC16C712(ISP) [ISP-HEADER01]
PIC16C712@SOIC18 [(SA404)]
PIC16C712@SOIC18(ISP) [ISP-HEADER01]
PIC16C712@SSOP20 [(SA626A)]
PIC16C712@SSOP20(ISP) [ISP-HEADER01]
PIC16C715                                     PIC16C715@SOIC18 [(SA404)]
PIC16C715@SSOP20 [(SA626A)]
PIC16C716(ISP) [ISP-HEADER01]
PIC16C716@SOIC18 [(SA404)]
PIC16C716@SOIC18(ISP) [ISP-HEADER01]
PIC16C716@SSOP20 [(SA626A)]
PIC16C716@SSOP20(ISP) [ISP-HEADER01]

```



PIC16C717	PIC16C717(ISP) [ISP-HEADER01]
PIC16C717@SOIC18 [(SA404)]	
PIC16C717@SOIC18(ISP) [ISP-HEADER01]	
PIC16C717@SSOP20 [(SA626A)]	
PIC16C717@SSOP20(ISP) [ISP-HEADER01]	
PIC16C71A	PIC16C71A(ISP) [ISP-HEADER01]
PIC16C71A@SOIC18 [(SA404)]	
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]	
PIC16C72	PIC16C72(ISP) [ISP-HEADER01]
PIC16C72@SOIC28 [(SA404)]	
PIC16C72@SOIC28(ISP) [ISP-HEADER01]	
PIC16C72@SSOP28 [(SA626A)]	
PIC16C72@SSOP28(ISP) [ISP-HEADER01]	
PIC16C72A	PIC16C72A(ISP) [ISP-HEADER01]
PIC16C72A@SOIC28 [(SA404)]	
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]	
PIC16C72A@SSOP28 [(SA626A)]	
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]	
PIC16C73	PIC16C73(ISP) [ISP-HEADER01]
PIC16C73@SOIC28 [(SA404)]	
PIC16C73@SOIC28(ISP) [ISP-HEADER01]	
PIC16C73A	PIC16C73A(ISP) [ISP-HEADER01]
PIC16C73A@SOIC28 [(SA404)]	
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]	
PIC16C73B	PIC16C73B(ISP) [ISP-HEADER01]
PIC16C73B@SOIC28 [(SA404)]	
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]	
PIC16C73B@SSOP28 [(SA626A)]	
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]	
PIC16C74	PIC16C74(ISP) [ISP-HEADER01]
PIC16C74@PLCC44 [(SA244)]	
PIC16C74@PLCC44(ISP) [ISP-HEADER01]	
PIC16C74@TQFP44 [(SA245A)]	
PIC16C74@TQFP44(ISP) [ISP-HEADER01]	
PIC16C745	PIC16C745(ISP) [ISP-HEADER01]
PIC16C745@SOIC28 [(SA404)]	
PIC16C745@SOIC28(ISP) [ISP-HEADER01]	
PIC16C74A	PIC16C74A(ISP) [ISP-HEADER01]
PIC16C74A@PLCC44 [(SA244)]	
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]	
PIC16C74A@TQFP44 [(SA245A)]	
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]	
PIC16C74B	PIC16C74B(ISP) [ISP-HEADER01]
PIC16C74B@MQFP44 [(SA675)]	
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]	
PIC16C74B@PLCC44 [(SA244)]	
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]	
PIC16C74B@TQFP44 [(SA245A)]	
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]	
PIC16C76	PIC16C76(ISP) [ISP-HEADER01]
PIC16C76@SOIC28 [(SA404)]	
PIC16C76@SOIC28(ISP) [ISP-HEADER01]	
PIC16C765	PIC16C765(ISP) [ISP-HEADER01]
PIC16C765@PLCC44 [(SA244)]	
PIC16C765@PLCC44(ISP) [ISP-HEADER01]	
PIC16C765@TQFP44 [(SA245A)]	
PIC16C765@TQFP44(ISP) [ISP-HEADER01]	
PIC16C77	PIC16C77(ISP) [ISP-HEADER01]
PIC16C77@PLCC44 [(SA244)]	
PIC16C77@PLCC44(ISP) [ISP-HEADER01]	
PIC16C77@TQFP44 [(SA245A)]	
PIC16C77@TQFP44(ISP) [ISP-HEADER01]	
PIC16C770	PIC16C770(ISP) [ISP-HEADER01]
PIC16C770@SOIC20 [(SA404)]	
PIC16C770@SOIC20(ISP) [ISP-HEADER01]	
PIC16C770@SSOP20 [(SA626A)]	
PIC16C770@SSOP20(ISP) [ISP-HEADER01]	
PIC16C771	PIC16C771(ISP) [ISP-HEADER01]
PIC16C771@SOIC20 [(SA404)]	
PIC16C771@SOIC20(ISP) [ISP-HEADER01]	
PIC16C771@SSOP20 [(SA626A)]	
PIC16C771@SSOP20(ISP) [ISP-HEADER01]	
PIC16C773	PIC16C773(ISP) [ISP-HEADER01]
PIC16C773@SOIC28 [(SA404)]	
PIC16C773@SOIC28(ISP) [ISP-HEADER01]	
PIC16C773@SSOP28 [(SA626A)]	
PIC16C773@SSOP28(ISP) [ISP-HEADER01]	
PIC16C774	PIC16C774(ISP) [ISP-HEADER01]
PIC16C774@PLCC44 [(SA244)]	
PIC16C774@PLCC44(ISP) [ISP-HEADER01]	
PIC16C774@TQFP44 [(SA675)]	

```

PIC16C774@TQFP44(ISP) [ISP-HEADER01]
PIC16C781 PIC16C781(ISP) [ISP-HEADER01]
PIC16C781@SOIC20 [(SA404)]
PIC16C781@SOIC20(ISP) [ISP-HEADER01]
PIC16C781@SSOP20 [(SA626A)]
PIC16C781@SSOP20(ISP) [ISP-HEADER01]
PIC16C782 PIC16C782(ISP) [ISP-HEADER01]
PIC16C782@SOIC20 [(SA404)]
PIC16C782@SOIC20(ISP) [ISP-HEADER01]
PIC16C782@SSOP20 [(SA626A)]
PIC16C782@SSOP20(ISP) [ISP-HEADER01]
PIC16C84 PIC16C84(ISP) [ISP-HEADER01]
PIC16C84@SOIC18 [(SA404)]
PIC16C84@SOIC18(ISP) [ISP-HEADER01]
PIC16C923@PLCC68 [(PEP+S414T)]
PIC16C923@PLCC68(*) [(SA648-B6807)]
PIC16C923@PLCC68(ISP) [ISP-HEADER01]
PIC16C923@SDIP64 [(PEP+S600A)]
PIC16C923@SDIP64(ISP) [ISP-HEADER01]
PIC16C923@TQFP64 [(PEP+S616)]
PIC16C923@TQFP64(ISP) [ISP-HEADER01]
PIC16C924@PLCC68 [(PEP+S414T)]
PIC16C924@PLCC68(*) [(SA648-B6807)]
PIC16C924@PLCC68(ISP) [ISP-HEADER01]
PIC16C924@SDIP64 [(PEP+S600A)]
PIC16C924@SDIP64(ISP) [ISP-HEADER01]
PIC16C924@TQFP64 [(PEP+S616)]
PIC16C924@TQFP64(ISP) [ISP-HEADER01]
PIC16C925@PLCC68 [(PEP+S414T)]
PIC16C925@PLCC68(*) [(SA648-B6807)]
PIC16C925@PLCC68(ISP) [ISP-HEADER01]
PIC16C925@TQFP64 [(PEP+S616)]
PIC16C925@TQFP64(ISP) [ISP-HEADER01]
PIC16C926@PLCC68 [(PEP+S414T)]
PIC16C926@PLCC68(*) [(SA648-B6807)]
PIC16C926@PLCC68(ISP) [ISP-HEADER01]
PIC16C926@TQFP64 [(PEP+S616)]
PIC16C926@TQFP64(ISP) [ISP-HEADER01]
PIC16CE623 PIC16CE623(ISP) [ISP-HEADER01]
PIC16CE623@SOIC18 [(SA404)]
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]
PIC16CE624 PIC16CE624(ISP) [ISP-HEADER01]
PIC16CE624@SOIC18 [(SA404)]
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625 PIC16CE625(ISP) [ISP-HEADER01]
PIC16CE625@SOIC18 [(SA404)]
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625@SSOP20 [(SA626A)]
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]
PIC16CR83 PIC16CR83(ISP) [ISP-HEADER01]
PIC16CR83@SOIC18 [(SA404)]
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]
PIC16CR84 PIC16CR84(ISP) [ISP-HEADER01]
PIC16CR84@SOIC18 [(SA404)]
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]
PIC16F1933
PIC16F1933(ISP)(HV) [ISP-HEADER01]
PIC16F1933@QFN28 [(SA685-B006)]
PIC16F1933@QFN28(ISP)(HV) [ISP-HEADER01]
PIC16F1933@SOIC28 [(SA404)]
PIC16F1933@SOIC28(ISP)(HV) [ISP-HEADER01]
PIC16F1934
PIC16F1934(ISP)(HV) [ISP-HEADER01]
PIC16F1934@QFN44 [(SA737)]
PIC16F1934@QFN44(ISP)(HV) [ISP-HEADER01]
PIC16F1934@TQFP44 [(SA245)]
PIC16F1934@TQFP44(ISP)(HV) [ISP-HEADER01]
PIC16F1936
PIC16F1936(ISP)(HV) [ISP-HEADER01]
PIC16F1936@QFN28 [ordering number is marked above]
PIC16F1936@QFN28(ISP)(HV) [ISP-HEADER01]
PIC16F1936@SOIC28 [(SA404)]
PIC16F1936@SOIC28(ISP)(HV) [ISP-HEADER01]
PIC16F1937
PIC16F1937(ISP)(HV) [ISP-HEADER01]
PIC16F1937@QFN44 [(SA737)]
PIC16F1937@QFN44(ISP)(HV) [ISP-HEADER01]
PIC16F1937@TQFP44 [(SA245)]
PIC16F1937@TQFP44(ISP)(HV) [ISP-HEADER01]
PIC16F1938
PIC16F1938(ISP)(HV) [ISP-HEADER01]

```

PIC16F1938@QFN28 [ordering number is marked above]  
 PIC16F1938@QFN28(ISP)(HV) [ISP-HEADER01]  
 PIC16F1938@SOIC28 [(SA404)]  
 PIC16F1938@SOIC28(ISP)(HV) [ISP-HEADER01]  
 PIC16F1939  
 PIC16F1939(ISP)(HV) [ISP-HEADER01]  
 PIC16F1939@QFN44 [(SA737)]  
 PIC16F1939@QFN44(ISP)(HV) [ISP-HEADER01]  
 PIC16F1939@TQFP44 [(SA245)]  
 PIC16F1939@TQFP44(ISP)(HV) [ISP-HEADER01]  
 PIC16F505 PIC16F505(ISP) [ISP-HEADER01]  
 PIC16F505@SOIC14 [(SA602)]  
 PIC16F505@SOIC14(ISP) [ISP-HEADER01]  
 PIC16F505@TSSOP14 [(SA026)]  
 PIC16F505@TSSOP14(ISP) [ISP-HEADER01]  
 PIC16F506 PIC16F506(ISP) [ISP-HEADER01]  
 PIC16F506@SOIC14 [(SA602)]  
 PIC16F506@SOIC14(ISP) [ISP-HEADER01]  
 PIC16F506@TSSOP14 [(SA026)]  
 PIC16F506@TSSOP14(ISP) [ISP-HEADER01]  
 PIC16F526 PIC16F526@SOIC14 [(SA602)]  
 PIC16F526@TSSOP14 [(SA026)] PIC16F54  
 PIC16F54(ISP) [ISP-HEADER01] PIC16F54@SOIC18 [(SA404)]  
 PIC16F54@SOIC18(ISP) [ISP-HEADER01]  
 PIC16F54@SSOP20 [(SA626A)]  
 PIC16F54@SSOP20(ISP) [ISP-HEADER01]  
 PIC16F57 PIC16F57(ISP) [ISP-HEADER01]  
 PIC16F57@SOIC28 [(SA404)]  
 PIC16F57@SOIC28(ISP) [ISP-HEADER01]  
 PIC16F57@SSOP28 [(SA626A)]  
 PIC16F57@SSOP28(ISP) [ISP-HEADER01]  
 PIC16F59 PIC16F59(ISP) [ISP-HEADER01]  
 PIC16F59@PLCC44 [(SA244)]  
 PIC16F59@PLCC44(ISP) [ISP-HEADER01]  
 PIC16F59@TQFP44 [(SA245A)]  
 PIC16F59@TQFP44(ISP) [ISP-HEADER01]  
 PIC16F610 PIC16F610(ISP) [ISP-HEADER01]  
 PIC16F610@QFN16 [(SA727)]  
 PIC16F610@QFN16(ISP) [ISP-HEADER01]  
 PIC16F610@SOIC14 [(SA602)]  
 PIC16F610@SOIC14(ISP) [ISP-HEADER01]  
 PIC16F610@TSSOP14 [(SA026)]  
 PIC16F610@TSSOP14(ISP) [ISP-HEADER01]  
 PIC16F616 PIC16F616(ISP) [ISP-HEADER01]  
 PIC16F616@QFN16 [(SA727)]  
 PIC16F616@QFN16(ISP) [ISP-HEADER01]  
 PIC16F616@SOIC14 [(SA602)]  
 PIC16F616@SOIC14(ISP) [ISP-HEADER01]  
 PIC16F616@TSSOP14 [(SA026)]  
 PIC16F616@TSSOP14(ISP) [ISP-HEADER01]  
 PIC16F627 PIC16F627(ISP) [ISP-HEADER01]  
 PIC16F627@SOIC18 [(SA404)]  
 PIC16F627@SOIC18(ISP) [ISP-HEADER01]  
 PIC16F627@SSOP20 [(SA626A)]  
 PIC16F627@SSOP20(ISP) [ISP-HEADER01]  
 PIC16F627A PIC16F627A(ISP) [ISP-HEADER01]  
 PIC16F627A@SOIC18 [(SA404)]  
 PIC16F627A@SOIC18(ISP) [ISP-HEADER01]  
 PIC16F627A@SSOP20 [(SA626A)]  
 PIC16F627A@SSOP20(ISP) [ISP-HEADER01]  
 PIC16F628 PIC16F628(ISP) [ISP-HEADER01]  
 PIC16F628@SOIC18 [(SA404)]  
 PIC16F628@SOIC18(ISP) [ISP-HEADER01]  
 PIC16F628@SSOP20 [(SA626A)]  
 PIC16F628@SSOP20(ISP) [ISP-HEADER01]  
 PIC16F628A PIC16F628A(ISP) [ISP-HEADER01]  
 PIC16F628A@SOIC18 [(SA404)]  
 PIC16F628A@SOIC18(ISP) [ISP-HEADER01]  
 PIC16F628A@SSOP20 [(SA626A)]  
 PIC16F628A@SSOP20(ISP) [ISP-HEADER01]  
 PIC16F630 PIC16F630(ISP) [ISP-HEADER01]  
 PIC16F630@SOIC14 [(SA602)]  
 PIC16F630@SOIC14(ISP) [ISP-HEADER01]  
 PIC16F630@TSSOP14 [(SA026)]  
 PIC16F630@TSSOP14(ISP) [ISP-HEADER01]  
 PIC16F631 PIC16F631(ISP) [ISP-HEADER01]  
 PIC16F631@QFN20 [(SA692)]  
 PIC16F631@QFN20(ISP) [ISP-HEADER01]  
 PIC16F631@SOIC20 [(SA404)]  
 PIC16F631@SOIC20(ISP) [ISP-HEADER01]  
 PIC16F631@SSOP20 [(SA626A)]

```

PIC16F631@SSOP20(ISP) [ISP-HEADER01]
PIC16F636                                     PIC16F636(ISP) [ISP-HEADER01]
PIC16F636@QFN16 [(SA727)]
PIC16F636@QFN16(ISP) [ISP-HEADER01]
PIC16F636@SOIC14 [(SA602)]
PIC16F636@SOIC14(ISP) [ISP-HEADER01]
PIC16F636@TSSOP14 [(SA026)]
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]
PIC16F639                                     PIC16F639(ISP) [ISP-HEADER01]
PIC16F639@QFN20 [(SA692)]
PIC16F639@QFN20(ISP) [ISP-HEADER01]
PIC16F639@SOIC20 [(SA404)]
PIC16F639@SOIC20(ISP) [ISP-HEADER01]
PIC16F639@SSOP20 [(SA626A)]
PIC16F639@SSOP20(ISP) [ISP-HEADER01]
PIC16F648A                                     PIC16F648A(ISP) [ISP-HEADER01]
PIC16F648A@SOIC18 [(SA404)]
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]
PIC16F648A@SSOP20 [(SA626A)]
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]
PIC16F676                                     PIC16F676(ISP) [ISP-HEADER01]
PIC16F676@SOIC14 [(SA602)]
PIC16F676@SOIC14(ISP) [ISP-HEADER01]
PIC16F676@TSSOP14 [(SA026)]
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]
PIC16F677                                     PIC16F677(ISP) [ISP-HEADER01]
PIC16F677@QFN20 [(SA692)]
PIC16F677@QFN20(ISP) [ISP-HEADER01]
PIC16F677@SOIC20 [(SA404)]
PIC16F677@SOIC20(ISP) [ISP-HEADER01]
PIC16F677@SSOP20 [(SA626A)]
PIC16F677@SSOP20(ISP) [ISP-HEADER01]
PIC16F684                                     PIC16F684(ISP) [ISP-HEADER01]
PIC16F684@QFN16 [(SA727)]
PIC16F684@QFN16(ISP) [ISP-HEADER01]
PIC16F684@SOIC14 [(SA602)]
PIC16F684@SOIC14(ISP) [ISP-HEADER01]
PIC16F684@TSSOP14 [(SA026)]
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]
PIC16F685                                     PIC16F685(ISP) [ISP-HEADER01]
PIC16F685@QFN20 [(SA692)]
PIC16F685@QFN20(ISP) [ISP-HEADER01]
PIC16F685@SOIC20 [(SA404)]
PIC16F685@SOIC20(ISP) [ISP-HEADER01]
PIC16F685@SSOP20 [(SA626A)]
PIC16F685@SSOP20(ISP) [ISP-HEADER01]
PIC16F687                                     PIC16F687(ISP) [ISP-HEADER01]
PIC16F687@QFN20 [(SA692)]
PIC16F687@QFN20(ISP) [ISP-HEADER01]
PIC16F687@SOIC20 [(SA404)]
PIC16F687@SOIC20(ISP) [ISP-HEADER01]
PIC16F687@SSOP20 [(SA626A)]
PIC16F687@SSOP20(ISP) [ISP-HEADER01]
PIC16F688                                     PIC16F688(ISP) [ISP-HEADER01]
PIC16F688@QFN16 [(SA727)]
PIC16F688@QFN16(ISP) [ISP-HEADER01]
PIC16F688@SOIC14 [(SA602)]
PIC16F688@SOIC14(ISP) [ISP-HEADER01]
PIC16F688@TSSOP14 [(SA026)]
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]
PIC16F689                                     PIC16F689(ISP) [ISP-HEADER01]
PIC16F689@QFN20 [(SA692)]
PIC16F689@QFN20(ISP) [ISP-HEADER01]
PIC16F689@SOIC20 [(SA404)]
PIC16F689@SOIC20(ISP) [ISP-HEADER01]
PIC16F689@SSOP20 [(SA626A)]
PIC16F689@SSOP20(ISP) [ISP-HEADER01]
PIC16F690                                     PIC16F690(ISP) [ISP-HEADER01]
PIC16F690@QFN20 [(SA692)]
PIC16F690@QFN20(ISP) [ISP-HEADER01]
PIC16F690@SOIC20 [(SA404)]
PIC16F690@SOIC20(ISP) [ISP-HEADER01]
PIC16F690@SSOP20 [(SA626A)]
PIC16F690@SSOP20(ISP) [ISP-HEADER01]
PIC16F716                                     PIC16F716(ISP) [ISP-HEADER01]
PIC16F716@SOIC18 [(SA404)]
PIC16F716@SOIC18(ISP) [ISP-HEADER01]
PIC16F716@SSOP20 [(SA626A)]
PIC16F716@SSOP20(ISP) [ISP-HEADER01]
PIC16F72                                     PIC16F72(ISP) [ISP-HEADER01]
PIC16F72@QFN28 [(SA685-B006)]

```

```

PIC16F72@QFN28(ISP) [ISP-HEADER01]
PIC16F72@SOIC28 [(SA404)]
PIC16F72@SOIC28(ISP) [ISP-HEADER01]
PIC16F72@SSOP28 [(SA626A)]
PIC16F72@SSOP28(ISP) [ISP-HEADER01]
PIC16F722 PIC16F722@QFN28 [(SA685-B006)]
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28 [(SA626A)]
PIC16F723 PIC16F723@QFN28 [(SA685-B006)]
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28 [(SA626A)]
PIC16F724 PIC16F724@QFN44 [(SA737)]
PIC16F724@TQFP44 [(SA245A)] PIC16F726
PIC16F726@QFN28 [(SA685-B006)] PIC16F726@SOIC28 [(SA404)]
PIC16F726@SSOP28 [(SA626A)] PIC16F727
PIC16F727@QFN44 [(SA737)] PIC16F727@TQFP44 [(SA245A)]
PIC16F73 PIC16F73(ISP) [ISP-HEADER01]
PIC16F73@QFN28 [(SA685-B006)] PIC16F73@SOIC28 [(SA404)]
PIC16F73@SOIC28(ISP) [ISP-HEADER01]
PIC16F73@SSOP28 [(SA626A)]
PIC16F73@SSOP28(ISP) [ISP-HEADER01]
PIC16F737 PIC16F737(ISP) [ISP-HEADER01]
PIC16F737@SOIC28 [(SA404)]
PIC16F737@SOIC28(ISP) [ISP-HEADER01]
PIC16F737@SSOP28 [(SA626A)]
PIC16F737@SSOP28(ISP) [ISP-HEADER01]
PIC16F74 PIC16F74(ISP) [ISP-HEADER01]
PIC16F74@PLCC44 [(SA244)]
PIC16F74@PLCC44(ISP) [ISP-HEADER01]
PIC16F74@TQFP44 [(SA245A)]
PIC16F74@TQFP44(ISP) [ISP-HEADER01]
PIC16F747 PIC16F747(ISP) [ISP-HEADER01]
PIC16F747@TQFP44 [(SA245A)]
PIC16F747@TQFP44(ISP) [ISP-HEADER01]
PIC16F76 PIC16F76(ISP) [ISP-HEADER01]
PIC16F76@QFN28 [(SA685-B006)] PIC16F76@SOIC28 [(SA404)]
PIC16F76@SOIC28(ISP) [ISP-HEADER01]
PIC16F76@SSOP28 [(SA626A)]
PIC16F76@SSOP28(ISP) [ISP-HEADER01]
PIC16F767 PIC16F767(ISP) [ISP-HEADER01]
PIC16F767@SOIC28 [(SA404)]
PIC16F767@SOIC28(ISP) [ISP-HEADER01]
PIC16F767@SSOP28 [(SA626A)]
PIC16F767@SSOP28(ISP) [ISP-HEADER01]
PIC16F77 PIC16F77(ISP) [ISP-HEADER01]
PIC16F77@PLCC44 [(SA244)]
PIC16F77@PLCC44(ISP) [ISP-HEADER01]
PIC16F77@TQFP44 [(SA245A)]
PIC16F77@TQFP44(ISP) [ISP-HEADER01]
PIC16F777 PIC16F777(ISP) [ISP-HEADER01]
PIC16F777@TQFP44 [(SA245A)]
PIC16F777@TQFP44(ISP) [ISP-HEADER01]
PIC16F785 PIC16F785(ISP) [ISP-HEADER01]
PIC16F785@QFN20 [(SA692)]
PIC16F785@QFN20(ISP) [ISP-HEADER01]
PIC16F785@SOIC20 [(SA404)]
PIC16F785@SOIC20(ISP) [ISP-HEADER01]
PIC16F785@SSOP20 [(SA626A)]
PIC16F785@SSOP20(ISP) [ISP-HEADER01]
PIC16F818 PIC16F818(ISP) [ISP-HEADER01]
PIC16F818(LV)
PIC16F818(LV)@QFN28 [(SA685-B006)]
PIC16F818(LV)@SOIC18 [(SA404)] PIC16F818(LV)@SSOP20 [(SA626A)]
PIC16F818@QFN28 [(SA685-B006)]
PIC16F818@QFN28(ISP) [ISP-HEADER01]
PIC16F818@SOIC18 [(SA404)]
PIC16F818@SOIC18(ISP) [ISP-HEADER01]
PIC16F818@SSOP20 [(SA626A)]
PIC16F818@SSOP20(ISP) [ISP-HEADER01]
PIC16F819 PIC16F819(ISP) [ISP-HEADER01]
PIC16F819(LV)
PIC16F819(LV)@QFN28 [(SA685-B006)]
PIC16F819(LV)@SOIC18 [(SA404)] PIC16F819(LV)@SSOP20 [(SA626A)]
PIC16F819@QFN28 [(SA685-B006)]
PIC16F819@QFN28(ISP) [ISP-HEADER01]
PIC16F819@SOIC18 [(SA404)]
PIC16F819@SOIC18(ISP) [ISP-HEADER01]
PIC16F819@SSOP20 [(SA626A)]
PIC16F819@SSOP20(ISP) [ISP-HEADER01]
PIC16F83 PIC16F83(ISP) [ISP-HEADER01]
PIC16F83@SOIC18 [(SA404)]
PIC16F83@SOIC18(ISP) [ISP-HEADER01]
PIC16F84 PIC16F84(ISP) [ISP-HEADER01]

```

```

PIC16F84@SOIC18 [(SA404)]
PIC16F84@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A                                     PIC16F84A(ISP) [ISP-HEADER01]
PIC16F84A@SOIC18 [(SA404)]
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A@SSOP20 [(SA626A)]
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]
PIC16F87                                       PIC16F87(ISP) [ISP-HEADER01]
PIC16F87@QFN28 [(SA685-B006)]
PIC16F87@QFN28(ISP) [ISP-HEADER01]
PIC16F87@SOIC18 [(SA404)]
PIC16F87@SOIC18(ISP) [ISP-HEADER01]
PIC16F87@SSOP20 [(SA626A)]
PIC16F87@SSOP20(ISP) [ISP-HEADER01]
PIC16F870                                       PIC16F870(ISP) [ISP-HEADER01]
PIC16F870@SOIC28 [(SA404)]
PIC16F870@SOIC28(ISP) [ISP-HEADER01]
PIC16F870@SSOP28 [(SA626A)]
PIC16F870@SSOP28(ISP) [ISP-HEADER01]
PIC16F871                                       PIC16F871(ISP) [ISP-HEADER01]
PIC16F871@MQFP44 [(SA675)]
PIC16F871@MQFP44(ISP) [ISP-HEADER01]
PIC16F871@PLCC44 [(SA244)]
PIC16F871@PLCC44(ISP) [ISP-HEADER01]
PIC16F871@TQFP44 [(SA245A)]
PIC16F871@TQFP44(ISP) [ISP-HEADER01]
PIC16F872                                       PIC16F872(ISP) [ISP-HEADER01]
PIC16F872@SOIC28 [(SA404)]
PIC16F872@SOIC28(ISP) [ISP-HEADER01]
PIC16F872@SSOP28 [(SA626A)]
PIC16F872@SSOP28(ISP) [ISP-HEADER01]
PIC16F873                                       PIC16F873(ISP) [ISP-HEADER01]
PIC16F873@SOIC28 [(SA404)]
PIC16F873@SOIC28(ISP) [ISP-HEADER01]
PIC16F873A
PIC16F873A(ISP)(High-V) [ISP-HEADER01]
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@QFN28 [(SA685-B006)]
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SOIC28 [(SA404)]
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SSOP28 [(SA626A)]
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874                                       PIC16F874(ISP) [ISP-HEADER01]
PIC16F874@MQFP44 [(SA675)]
PIC16F874@MQFP44(ISP) [ISP-HEADER01]
PIC16F874@PLCC44 [(SA244)]
PIC16F874@PLCC44(ISP) [ISP-HEADER01]
PIC16F874@TQFP44 [(SA245A)]
PIC16F874@TQFP44(ISP) [ISP-HEADER01]
PIC16F874A
PIC16F874A(ISP)(High-V) [ISP-HEADER01]
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@PLCC44 [(SA244)]
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@TQFP44 [(SA245A)]
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876                                       PIC16F876(ISP) [ISP-HEADER01]
PIC16F876@SOIC28 [(SA404)]
PIC16F876@SOIC28(ISP) [ISP-HEADER01]
PIC16F876A
PIC16F876A(ISP)(High-V) [ISP-HEADER01]

```

```

PIC16F876A(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@QFN28 [(SA685-B006)]
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@SOIC28 [(SA404)]
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@SSOP28 [(SA626A)]
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877 PIC16F877(ISP) [ISP-HEADER01]
PIC16F877@MQFP44 [(SA675)]
PIC16F877@MQFP44(ISP) [ISP-HEADER01]
PIC16F877@PLCC44 [(SA244)]
PIC16F877@PLCC44(ISP) [ISP-HEADER01]
PIC16F877@TQFP44 [(SA245A)]
PIC16F877@TQFP44(ISP) [ISP-HEADER01]
PIC16F877A
PIC16F877A(ISP)(High-V) [ISP-HEADER01]
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877A@PLCC44 [(SA244)]
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877A@TQFP44 [(SA245A)]
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F88 PIC16F88(ISP) [ISP-HEADER01]
PIC16F88@QFN28 [(SA685-B006)]
PIC16F88@QFN28(ISP) [ISP-HEADER01]
PIC16F88@SOIC18 [(SA404)]
PIC16F88@SOIC18(ISP) [ISP-HEADER01]
PIC16F88@SSOP20 [(SA626A)]
PIC16F88@SSOP20(ISP) [ISP-HEADER01]
PIC16F882
PIC16F882(ISP)(High-V) [ISP-HEADER01]
PIC16F882(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@QFN28 [(SA685-B005)]
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SOIC28 [(SA404)]
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SSOP28 [(SA626A)]
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883
PIC16F883(ISP)(High-V) [ISP-HEADER01]
PIC16F883(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@QFN28 [(SA685-B005)]
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SOIC28 [(SA404)]
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SSOP28 [(SA626A)]
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F884
PIC16F884(ISP)(High-V) [ISP-HEADER01]
PIC16F884(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44 [(SA712)]
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44(ML) [(SA737)]
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@TQFP44 [(SA245A)]

```

```

PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F886
PIC16F886(ISP)(High-V) [ISP-HEADER01]
PIC16F886(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@QFN28 [(SA685-B005)]
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SOIC28 [(SA404)]
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SSOP28 [(SA626A)]
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F887
PIC16F887(ISP)(High-V) [ISP-HEADER01]
PIC16F887(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44 [(SA712)]
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44(ML) [(SA737)]
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@TQFP44 [(SA245A)]
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F913 PIC16F913(ISP) [ISP-HEADER01]
PIC16F913@QFN28 [(SA685-B006)]
PIC16F913@QFN28(ISP) [ISP-HEADER01]
PIC16F913@SOIC28 [(SA404)]
PIC16F913@SOIC28(ISP) [ISP-HEADER01]
PIC16F913@SSOP28 [(SA626A)]
PIC16F913@SSOP28(ISP) [ISP-HEADER01]
PIC16F914 PIC16F914(ISP) [ISP-HEADER01]
PIC16F914@QFN44 [(SA712)]
PIC16F914@QFN44(ISP) [ISP-HEADER01]
PIC16F914@QFN44(ML) [(SA737)]
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F914@TQFP44 [(SA245A)]
PIC16F914@TQFP44(ISP) [ISP-HEADER01]
PIC16F916 PIC16F916(ISP) [ISP-HEADER01]
PIC16F916@QFN28 [(SA685-B006)]
PIC16F916@QFN28(ISP) [ISP-HEADER01]
PIC16F916@SOIC28 [(SA404)]
PIC16F916@SOIC28(ISP) [ISP-HEADER01]
PIC16F916@SSOP28 [(SA626A)]
PIC16F916@SSOP28(ISP) [ISP-HEADER01]
PIC16F917 PIC16F917(ISP) [ISP-HEADER01]
PIC16F917@QFN44 [(SA712)]
PIC16F917@QFN44(ISP) [ISP-HEADER01]
PIC16F917@QFN44(ML) [(SA737)]
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F917@TQFP44 [(SA245A)]
PIC16F917@TQFP44(ISP) [ISP-HEADER01]
PIC16F946@TQFP64 [(PEP+S616)]
PIC16F946@TQFP64(*) [(SA732+B344)]
PIC16F946@TQFP64(ISP) [ISP-HEADER01]
PIC16HV540 PIC16HV540@SOIC18 [(SA404)]
PIC16HV540@SSOP20 [(SA626A)] PIC16HV610
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16 [(SA727)]
PIC16HV610@QFN16(ISP) [ISP-HEADER01]
PIC16HV610@SOIC14 [(SA602)]
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]
PIC16HV610@TSSOP14 [(SA026)]
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV616 PIC16HV616(ISP) [ISP-HEADER01]
PIC16HV616@QFN16 [(SA727)]
PIC16HV616@QFN16(ISP) [ISP-HEADER01]
PIC16HV616@SOIC14 [(SA602)]
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]
PIC16HV616@TSSOP14 [(SA026)]
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV785 PIC16HV785(ISP) [ISP-HEADER01]
PIC16HV785@QFN20 [(SA692)]
PIC16HV785@QFN20(ISP) [ISP-HEADER01]
PIC16HV785@SOIC20 [(SA404)]
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]
PIC16HV785@SSOP20 [(SA626A)]
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]
PIC16LC505 PIC16LC505@SOIC14 [(SA602)]
PIC16LC54A PIC16LC54A@SOIC18 [(SA404)]

```



PIC16LC54A@SSOP20 [(SA626A)]	PIC16LC54C
PIC16LC54C@SOIC18 [(SA404)]	PIC16LC54C@SSOP20 [(SA626A)]
PIC16LC554	PIC16LC554(ISP) [ISP-HEADER01]
PIC16LC554@SOIC18 [(SA404)]	
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC558	PIC16LC558(ISP) [ISP-HEADER01]
PIC16LC558@SOIC18 [(SA404)]	
PIC16LC558@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC56A	PIC16LC56A@SOIC18 [(SA404)]
PIC16LC56A@SSOP20 [(SA626A)]	PIC16LC58A
PIC16LC58A@SOIC18 [(SA404)]	PIC16LC58A@SSOP20 [(SA626A)]
PIC16LC58B	PIC16LC58B@SOIC18 [(SA404)]
PIC16LC58B@SSOP20 [(SA626A)]	PIC16LC620
PIC16LC620(ISP) [ISP-HEADER01]	PIC16LC620@SOIC18 [(SA404)]
PIC16LC620@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC620A	PIC16LC620A(ISP) [ISP-HEADER01]
PIC16LC620A@SOIC18 [(SA404)]	
PIC16LC620A@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC620A@SSOP20 [(SA626A)]	
PIC16LC620A@SSOP20(ISP) [ISP-HEADER01]	
PIC16LC621A	PIC16LC621A(ISP) [ISP-HEADER01]
PIC16LC621A@SOIC18 [(SA404)]	
PIC16LC621A@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC621A@SSOP20 [(SA626A)]	
PIC16LC621A@SSOP20(ISP) [ISP-HEADER01]	
PIC16LC622	PIC16LC622(ISP) [ISP-HEADER01]
PIC16LC622@SOIC18 [(SA404)]	
PIC16LC622@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC62A	PIC16LC62A(ISP) [ISP-HEADER01]
PIC16LC62A@SOIC28 [(SA404)]	
PIC16LC62A@SOIC28(ISP) [ISP-HEADER01]	
PIC16LC62A@SSOP28 [(SA626A)]	
PIC16LC62A@SSOP28(ISP) [ISP-HEADER01]	
PIC16LC62B	PIC16LC62B(ISP) [ISP-HEADER01]
PIC16LC62B@SOIC28 [(SA404)]	
PIC16LC62B@SOIC28(ISP) [ISP-HEADER01]	
PIC16LC62B@SSOP28 [(SA626A)]	
PIC16LC62B@SSOP28(ISP) [ISP-HEADER01]	
PIC16LC63	PIC16LC63(ISP) [ISP-HEADER01]
PIC16LC63@SOIC28 [(SA404)]	
PIC16LC63@SOIC28(ISP) [ISP-HEADER01]	
PIC16LC63A	PIC16LC63A(ISP) [ISP-HEADER01]
PIC16LC63A@SOIC28 [(SA404)]	
PIC16LC63A@SOIC28(ISP) [ISP-HEADER01]	
PIC16LC63A@SSOP28 [(SA626A)]	
PIC16LC63A@SSOP28(ISP) [ISP-HEADER01]	
PIC16LC64A	PIC16LC64A(ISP) [ISP-HEADER01]
PIC16LC64A@PLCC44 [(SA244)]	
PIC16LC64A@PLCC44(ISP) [ISP-HEADER01]	
PIC16LC64A@TQFP44 [(SA245A)]	
PIC16LC64A@TQFP44(ISP) [ISP-HEADER01]	
PIC16LC65A	PIC16LC65A(ISP) [ISP-HEADER01]
PIC16LC65A@PLCC44 [(SA244)]	
PIC16LC65A@PLCC44(ISP) [ISP-HEADER01]	
PIC16LC65A@TQFP44 [(SA245A)]	
PIC16LC65A@TQFP44(ISP) [ISP-HEADER01]	
PIC16LC65B	PIC16LC65B(ISP) [ISP-HEADER01]
PIC16LC65B@PLCC44 [(SA244)]	
PIC16LC65B@PLCC44(ISP) [ISP-HEADER01]	
PIC16LC65B@TQFP44 [(SA245A)]	
PIC16LC65B@TQFP44(ISP) [ISP-HEADER01]	
PIC16LC66	PIC16LC66(ISP) [ISP-HEADER01]
PIC16LC66@SOIC28 [(SA404)]	
PIC16LC66@SOIC28(ISP) [ISP-HEADER01]	
PIC16LC67	PIC16LC67(ISP) [ISP-HEADER01]
PIC16LC67@PLCC44 [(SA244)]	
PIC16LC67@PLCC44(ISP) [ISP-HEADER01]	
PIC16LC67@TQFP44 [(SA245A)]	
PIC16LC67@TQFP44(ISP) [ISP-HEADER01]	
PIC16LC71	PIC16LC71(ISP) [ISP-HEADER01]
PIC16LC71@SOIC18 [(SA404)]	
PIC16LC71@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC710	PIC16LC710(ISP) [ISP-HEADER01]
PIC16LC710@SOIC18 [(SA404)]	
PIC16LC710@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC710@SSOP20 [(SA626A)]	
PIC16LC710@SSOP20(ISP) [ISP-HEADER01]	
PIC16LC711	PIC16LC711(ISP) [ISP-HEADER01]
PIC16LC711@SOIC18 [(SA404)]	
PIC16LC711@SOIC18(ISP) [ISP-HEADER01]	
PIC16LC711@SSOP20 [(SA626A)]	

```

PIC16LC711@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC712 PIC16LC712 (ISP) [ISP-HEADER01]
PIC16LC712@SOIC18 [(SA404)]
PIC16LC712@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC712@SSOP20 [(SA626A)]
PIC16LC712@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC715 PIC16LC715@SOIC18 [(SA404)]
PIC16LC716 PIC16LC716 (ISP) [ISP-HEADER01]
PIC16LC716@SOIC18 [(SA404)]
PIC16LC716@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC716@SSOP20 [(SA626A)]
PIC16LC716@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC717 PIC16LC717 (ISP) [ISP-HEADER01]
PIC16LC717@SOIC18 [(SA404)]
PIC16LC717@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC717@SSOP20 [(SA626A)]
PIC16LC717@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC72 PIC16LC72 (ISP) [ISP-HEADER01]
PIC16LC72@SOIC28 [(SA404)]
PIC16LC72@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC72@SSOP28 [(SA626A)]
PIC16LC72@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC72A PIC16LC72A (ISP) [ISP-HEADER01]
PIC16LC72A@SOIC28 [(SA404)]
PIC16LC72A@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC72A@SSOP28 [(SA626A)]
PIC16LC72A@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC73A PIC16LC73A (ISP) [ISP-HEADER01]
PIC16LC73A@SOIC28 [(SA404)]
PIC16LC73A@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC73B PIC16LC73B (ISP) [ISP-HEADER01]
PIC16LC73B@SOIC28 [(SA404)]
PIC16LC73B@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC73B@SSOP28 [(SA626A)]
PIC16LC73B@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC74 PIC16LC74 (ISP) [ISP-HEADER01]
PIC16LC74@PLCC44 [(SA244)]
PIC16LC74@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC74@TQFP44 [(SA245A)]
PIC16LC74@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC74A PIC16LC74A (ISP) [ISP-HEADER01]
PIC16LC74A@PLCC44 [(SA244)]
PIC16LC74A@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC74A@TQFP44 [(SA245A)]
PIC16LC74A@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC74B PIC16LC74B (ISP) [ISP-HEADER01]
PIC16LC74B@MQFP44 [(SA675)]
PIC16LC74B@MQFP44 (ISP) [ISP-HEADER01]
PIC16LC74B@PLCC44 [(SA244)]
PIC16LC74B@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC74B@TQFP44 [(SA245A)]
PIC16LC74B@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC76 PIC16LC76 (ISP) [ISP-HEADER01]
PIC16LC76@SOIC28 [(SA404)]
PIC16LC76@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC77 PIC16LC77 (ISP) [ISP-HEADER01]
PIC16LC77@PLCC44 [(SA244)]
PIC16LC77@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC773 PIC16LC773 (ISP) [ISP-HEADER01]
PIC16LC773@SOIC28 [(SA404)]
PIC16LC773@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC773@SSOP28 [(SA626A)]
PIC16LC773@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC774 PIC16LC774 (ISP) [ISP-HEADER01]
PIC16LC774@PLCC44 [(SA244)]
PIC16LC774@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC774@TQFP44 [(SA675)]
PIC16LC774@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC84 PIC16LC84 (ISP) [ISP-HEADER01]
PIC16LC84@SOIC18 [(SA404)]
PIC16LC84@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC923@PLCC68 [(PEP+S414T)]
PIC16LC923@PLCC68 (*) [(SA648-B6807)]
PIC16LC923@PLCC68 (ISP) [ISP-HEADER01]
PIC16LC923@SDIP64 [(PEP+S600A)]
PIC16LC923@SDIP64 (ISP) [ISP-HEADER01]
PIC16LC923@TQFP64 [(PEP+S616)]
PIC16LC923@TQFP64 (ISP) [ISP-HEADER01]
PIC16LC924@PLCC68 [(PEP+S414T)]
PIC16LC924@PLCC68 (*) [(SA648-B6807)]
PIC16LC924@PLCC68 (ISP) [ISP-HEADER01]

```

```

PIC16LC924@SDIP64 [(PEP+S600A)]
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]
PIC16LC924@TQFP64 [(PEP+S616)]
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]
PIC16LC925@PLCC68 [(PEP+S414T)]
PIC16LC925@PLCC68(*) [(SA648-B6807)]
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]
PIC16LC925@TQFP64 [(PEP+S616)]
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]
PIC16LC926@PLCC68 [(PEP+S414T)]
PIC16LC926@PLCC68(*) [(SA648-B6807)]
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]
PIC16LC926@TQFP64 [(PEP+S616)]
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]
PIC16LCE623@SOIC18 [(SA404)]
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]
PIC16LCE623@SSOP20 [(SA626A)]
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]
PIC16LF1933
PIC16LF1933(ISP)(HV) [ISP-HEADER01]
PIC16LF1933@QFN28 [ordering number is marked above]
PIC16LF1933@QFN28(ISP)(HV) [ISP-HEADER01]
PIC16LF1933@SOIC28 [(SA404)]
PIC16LF1933@SOIC28(ISP)(HV) [ISP-HEADER01]
PIC16LF1934
PIC16LF1934(ISP)(HV) [ISP-HEADER01]
PIC16LF1934@QFN44 [(SA737)]
PIC16LF1934@QFN44(ISP)(HV) [ISP-HEADER01]
PIC16LF1934@TQFP44 [(SA245)]
PIC16LF1934@TQFP44(ISP)(HV) [ISP-HEADER01]
PIC16LF1936
PIC16LF1936(ISP)(HV) [ISP-HEADER01]
PIC16LF1936@QFN28 [ordering number is marked above]
PIC16LF1936@QFN28(ISP)(HV) [ISP-HEADER01]
PIC16LF1936@SOIC28 [(SA404)]
PIC16LF1936@SOIC28(ISP)(HV) [ISP-HEADER01]
PIC16LF1937
PIC16LF1937(ISP)(HV) [ISP-HEADER01]
PIC16LF1937@QFN44 [(SA737)]
PIC16LF1937@QFN44(ISP)(HV) [ISP-HEADER01]
PIC16LF1937@TQFP44 [(SA245)]
PIC16LF1937@TQFP44(ISP)(HV) [ISP-HEADER01]
PIC16LF1938
PIC16LF1938(ISP)(HV) [ISP-HEADER01]
PIC16LF1938@QFN28 [ordering number is marked above]
PIC16LF1938@QFN28(ISP)(HV) [ISP-HEADER01]
PIC16LF1938@SOIC28 [(SA404)]
PIC16LF1938@SOIC28(ISP)(HV) [ISP-HEADER01]
PIC16LF1939
PIC16LF1939(ISP)(HV) [ISP-HEADER01]
PIC16LF1939@QFN44 [(SA737)]
PIC16LF1939@QFN44(ISP)(HV) [ISP-HEADER01]
PIC16LF1939@TQFP44 [(SA245)]
PIC16LF1939@TQFP44(ISP)(HV) [ISP-HEADER01]
PIC16LF505 PIC16LF505(ISP) [ISP-HEADER01]
PIC16LF505@SOIC14 [(SA602)]
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]
PIC16LF505@TSSOP14 [(SA026)]
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]
PIC16LF506 PIC16LF506(ISP) [ISP-HEADER01]
PIC16LF506@SOIC14 [(SA602)]
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]
PIC16LF506@TSSOP14 [(SA026)]
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]
PIC16LF526 PIC16LF526@SOIC14 [(SA602)]
PIC16LF526@TSSOP14 [(SA026)] PIC16LF54
PIC16LF54(ISP) [ISP-HEADER01] PIC16LF54@SOIC18 [(SA404)]
PIC16LF54@SOIC18(ISP) [ISP-HEADER01]
PIC16LF54@SSOP20 [(SA626A)]
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]
PIC16LF57 PIC16LF57(ISP) [ISP-HEADER01]
PIC16LF57@SOIC28 [(SA404)]
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]
PIC16LF57@SSOP28 [(SA626A)]
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]
PIC16LF59 PIC16LF59(ISP) [ISP-HEADER01]
PIC16LF59@PLCC44 [(SA244)]
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]
PIC16LF59@TQFP44 [(SA245A)]
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]
PIC16LF627 PIC16LF627(ISP) [ISP-HEADER01]

```

PIC16LF627@SOIC18 [(SA404)]  
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627@SSOP20 [(SA626A)]  
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF627A PIC16LF627A(ISP) [ISP-HEADER01]  
PIC16LF627A@SOIC18 [(SA404)]  
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627A@SSOP20 [(SA626A)]  
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628 PIC16LF628(ISP) [ISP-HEADER01]  
PIC16LF628@SOIC18 [(SA404)]  
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628@SSOP20 [(SA626A)]  
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628A PIC16LF628A(ISP) [ISP-HEADER01]  
PIC16LF628A@SOIC18 [(SA404)]  
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628A@SSOP20 [(SA626A)]  
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF631 PIC16LF631(ISP) [ISP-HEADER01]  
PIC16LF631@QFN20 [(SA692)]  
PIC16LF631@QFN20(ISP) [ISP-HEADER01]  
PIC16LF631@SOIC20 [(SA404)]  
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF631@SSOP20 [(SA626A)]  
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF639 PIC16LF639(ISP) [ISP-HEADER01]  
PIC16LF639@QFN20 [(SA692)]  
PIC16LF639@QFN20(ISP) [ISP-HEADER01]  
PIC16LF639@SOIC20 [(SA404)]  
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF639@SSOP20 [(SA626A)]  
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF648A PIC16LF648A(ISP) [ISP-HEADER01]  
PIC16LF648A@SOIC18 [(SA404)]  
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF648A@SSOP20 [(SA626A)]  
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF677 PIC16LF677(ISP) [ISP-HEADER01]  
PIC16LF677@QFN20 [(SA692)]  
PIC16LF677@QFN20(ISP) [ISP-HEADER01]  
PIC16LF677@SOIC20 [(SA404)]  
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF677@SSOP20 [(SA626A)]  
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF685 PIC16LF685(ISP) [ISP-HEADER01]  
PIC16LF685@QFN20 [(SA692)]  
PIC16LF685@QFN20(ISP) [ISP-HEADER01]  
PIC16LF685@SOIC20 [(SA404)]  
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF685@SSOP20 [(SA626A)]  
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF687 PIC16LF687(ISP) [ISP-HEADER01]  
PIC16LF687@QFN20 [(SA692)]  
PIC16LF687@QFN20(ISP) [ISP-HEADER01]  
PIC16LF687@SOIC20 [(SA404)]  
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF687@SSOP20 [(SA626A)]  
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF689 PIC16LF689(ISP) [ISP-HEADER01]  
PIC16LF689@QFN20 [(SA692)]  
PIC16LF689@QFN20(ISP) [ISP-HEADER01]  
PIC16LF689@SOIC20 [(SA404)]  
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF689@SSOP20 [(SA626A)]  
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF690 PIC16LF690(ISP) [ISP-HEADER01]  
PIC16LF690@QFN20 [(SA692)]  
PIC16LF690@QFN20(ISP) [ISP-HEADER01]  
PIC16LF690@SOIC20 [(SA404)]  
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF690@SSOP20 [(SA626A)]  
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF716 PIC16LF716(ISP) [ISP-HEADER01]  
PIC16LF716@SOIC18 [(SA404)]  
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF716@SSOP20 [(SA626A)]  
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF72 PIC16LF72(ISP) [ISP-HEADER01]  
PIC16LF72@QFN28 [(SA685-B006)]  
PIC16LF72@QFN28(ISP) [ISP-HEADER01]

```

PIC16LF72@SOIC28 [(SA404)]
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]
PIC16LF72@SSOP28 [(SA626A)]
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]
PIC16LF722 PIC16LF722@QFN28 [(SA685-B006)]
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28 [(SA626A)]
PIC16LF723 PIC16LF723@QFN28 [(SA685-B006)]
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28 [(SA626A)]
PIC16LF724 PIC16LF724@QFN44 [(SA737)]
PIC16LF724@TQFP44 [(SA245A)] PIC16LF726
PIC16LF726@QFN28 [(SA685-B006)] PIC16LF726@SOIC28 [(SA404)]
PIC16LF726@SSOP28 [(SA626A)] PIC16LF727
PIC16LF727@QFN44 [(SA737)] PIC16LF727@TQFP44 [(SA245A)]
PIC16LF73 PIC16LF73(ISP) [ISP-HEADER01]
PIC16LF73@QFN28 [(SA685-B006)] PIC16LF73@SOIC28 [(SA404)]
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]
PIC16LF73@SSOP28 [(SA626A)]
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]
PIC16LF737 PIC16LF737(ISP) [ISP-HEADER01]
PIC16LF737@SOIC28 [(SA404)]
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]
PIC16LF737@SSOP28 [(SA626A)]
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]
PIC16LF74 PIC16LF74(ISP) [ISP-HEADER01]
PIC16LF74@PLCC44 [(SA244)]
PIC16LF74@PLCC44(ISP) [ISP-HEADER01]
PIC16LF74@TQFP44 [(SA245A)]
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]
PIC16LF747 PIC16LF747(ISP) [ISP-HEADER01]
PIC16LF747@TQFP44 [(SA245A)]
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]
PIC16LF76 PIC16LF76(ISP) [ISP-HEADER01]
PIC16LF76@QFN28 [(SA685-B006)] PIC16LF76@SOIC28 [(SA404)]
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]
PIC16LF76@SSOP28 [(SA626A)]
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]
PIC16LF767 PIC16LF767(ISP) [ISP-HEADER01]
PIC16LF767@SOIC28 [(SA404)]
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]
PIC16LF767@SSOP28 [(SA626A)]
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]
PIC16LF77 PIC16LF77(ISP) [ISP-HEADER01]
PIC16LF77@PLCC44 [(SA244)]
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]
PIC16LF77@TQFP44 [(SA245A)]
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]
PIC16LF777 PIC16LF777(ISP) [ISP-HEADER01]
PIC16LF777@TQFP44 [(SA245A)]
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]
PIC16LF818 PIC16LF818(ISP) [ISP-HEADER01]
PIC16LF818(LV)
PIC16LF818(LV)@QFN28 [(SA685-B006)]
PIC16LF818(LV)@SOIC18 [(SA404)] PIC16LF818(LV)@SSOP20 [(SA626A)]
PIC16LF818@QFN28 [(SA685-B006)]
PIC16LF818@QFN28(ISP) [ISP-HEADER01]
PIC16LF818@SOIC18 [(SA404)]
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]
PIC16LF818@SSOP20 [(SA626A)]
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]
PIC16LF819 PIC16LF819(ISP) [ISP-HEADER01]
PIC16LF819(LV)
PIC16LF819(LV)@QFN28 [(SA685-B006)]
PIC16LF819(LV)@SOIC18 [(SA404)] PIC16LF819(LV)@SSOP20 [(SA626A)]
PIC16LF819@QFN28 [(SA685-B006)]
PIC16LF819@QFN28(ISP) [ISP-HEADER01]
PIC16LF819@SOIC18 [(SA404)]
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]
PIC16LF819@SSOP20 [(SA626A)]
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]
PIC16LF83 PIC16LF83(ISP) [ISP-HEADER01]
PIC16LF83@SOIC18 [(SA404)]
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84 PIC16LF84(ISP) [ISP-HEADER01]
PIC16LF84@SOIC18 [(SA404)]
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A PIC16LF84A(ISP) [ISP-HEADER01]
PIC16LF84A@SOIC18 [(SA404)]
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A@SSOP20 [(SA626A)]
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF87 PIC16LF87(ISP) [ISP-HEADER01]

```

```

PIC16LF87@QFN28 [(SA685-B006)]
PIC16LF87@QFN28(ISP) [ISP-HEADER01]
PIC16LF87@SOIC18 [(SA404)]
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]
PIC16LF87@SSOP20 [(SA626A)]
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]
PIC16LF870 PIC16LF870(ISP) [ISP-HEADER01]
PIC16LF870@SOIC28 [(SA404)]
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]
PIC16LF870@SSOP28 [(SA626A)]
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]
PIC16LF871 PIC16LF871(ISP) [ISP-HEADER01]
PIC16LF871@MQFP44 [(SA245A)]
PIC16LF871@MQFP44(ISP) [ISP-HEADER01]
PIC16LF871@PLCC44 [(SA244)]
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]
PIC16LF871@TQFP44 [(SA245A)]
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]
PIC16LF872 PIC16LF872(ISP) [ISP-HEADER01]
PIC16LF872@SOIC28 [(SA404)]
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]
PIC16LF872@SSOP28 [(SA626A)]
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]
PIC16LF873 PIC16LF873(ISP) [ISP-HEADER01]
PIC16LF873@SOIC28 [(SA404)]
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]
PIC16LF873A
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@QFN28 [(SA685-B006)]
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SOIC28 [(SA404)]
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SSOP28 [(SA626A)]
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874 PIC16LF874(ISP) [ISP-HEADER01]
PIC16LF874@MQFP44 [(SA675)]
PIC16LF874@MQFP44(ISP) [ISP-HEADER01]
PIC16LF874@PLCC44 [(SA244)]
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]
PIC16LF874@TQFP44 [(SA245A)]
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]
PIC16LF874A
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@PLCC44 [(SA244)]
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@TQFP44 [(SA245A)]
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876 PIC16LF876(ISP) [ISP-HEADER01]
PIC16LF876@SOIC28 [(SA404)]
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]
PIC16LF876A
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@QFN28 [(SA685-B006)]
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]

```

```

PIC16LF876A@SOIC28 [(SA404)]
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@SSOP28 [(SA626A)]
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877 PIC16LF877(ISP) [ISP-HEADER01]
PIC16LF877@MQFP44 [(SA675)]
PIC16LF877@MQFP44(ISP) [ISP-HEADER01]
PIC16LF877@PLCC44 [(SA244)]
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]
PIC16LF877@TQFP44 [(SA245A)]
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]
PIC16LF877A
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877A@PLCC44 [(SA244)]
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877A@TQFP44 [(SA245A)]
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF88 PIC16LF88(ISP) [ISP-HEADER01]
PIC16LF88@QFN28 [(SA685-B006)]
PIC16LF88@QFN28(ISP) [ISP-HEADER01]
PIC16LF88@SOIC18 [(SA404)]
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]
PIC16LF88@SSOP20 [(SA626A)]
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]
PIC16LF913 PIC16LF913(ISP) [ISP-HEADER01]
PIC16LF913@QFN28 [(SA685-B006)]
PIC16LF913@QFN28(ISP) [ISP-HEADER01]
PIC16LF913@SOIC28 [(SA404)]
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]
PIC16LF913@SSOP28 [(SA626A)]
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]
PIC16LF914 PIC16LF914(ISP) [ISP-HEADER01]
PIC16LF914@QFN44 [(SA712)]
PIC16LF914@QFN44(ISP) [ISP-HEADER01]
PIC16LF914@QFN44(ML) [(SA737)]
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF914@TQFP44 [(SA245A)]
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]
PIC16LF916 PIC16LF916(ISP) [ISP-HEADER01]
PIC16LF916@QFN28 [(SA685-B006)]
PIC16LF916@QFN28(ISP) [ISP-HEADER01]
PIC16LF916@SOIC28 [(SA404)]
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]
PIC16LF916@SSOP28 [(SA626A)]
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]
PIC16LF917 PIC16LF917(ISP) [ISP-HEADER01]
PIC16LF917@QFN44 [(SA712)]
PIC16LF917@QFN44(ISP) [ISP-HEADER01]
PIC16LF917@QFN44(ML) [(SA737)]
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF917@TQFP44 [(SA245A)]
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]
PIC16LF946@TQFP64 [(PEP+S616)]
PIC16LF946@TQFP64(*) [(SA732+B344)]
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]
PIC16LV54A PIC16LV54A@SOIC18 [(SA404)]
PIC16LV54A@SSOP20 [(SA626A)] PIC16LV58A
PIC16LV58A@SOIC18 [(SA404)] PIC16LV58A@SSOP20 [(SA626A)]
PIC17C42 PIC17C42@PLCC44 [(SA244)]
PIC17C42@TQFP44 [(SA245A)] PIC17C42A
PIC17C42A@PLCC44 [(SA244)] PIC17C42A@TQFP44 [(SA245A)]
PIC17C43 PIC17C43@PLCC44 [(SA244)]
PIC17C43@TQFP44 [(SA245A)] PIC17C44
PIC17C44@PLCC44 [(SA244)] PIC17C44@TQFP44 [(SA245A)]
PIC17C752@PLCC68 [(PEP+S414T)] PIC17C752@TQFP64 [(PEP+S616)]
PIC17C756@PLCC68 [(PEP+S414T)] PIC17C756@TQFP64 [(PEP+S616)]

```

```

PIC17C756A@PLCC68 [(PEP+S414T)]      PIC17C756A@TQFP64 [(PEP+S616)]
PIC17C762@PLCC84 [(PEP+S416T)]      PIC17C766@PLCC84 [(PEP+S416T)]
PIC17LC42                             PIC17LC42@PLCC44 [(SA244)]
PIC17LC42@TQFP44 [(SA245A)]         PIC17LC42A
PIC17LC42A@PLCC44 [(SA244)]         PIC17LC42A@TQFP44 [(SA245A)]
PIC17LC43                             PIC17LC43@PLCC44 [(SA244)]
PIC17LC43@TQFP44 [(SA245A)]         PIC17LC44
PIC17LC44@PLCC44 [(SA244)]         PIC17LC44@TQFP44 [(SA245A)]
PIC17LC752@PLCC68 [(PEP+S414T)]     PIC17LC752@TQFP64 [(PEP+S616)]
PIC17LC756@PLCC68 [(PEP+S414T)]     PIC17LC756@TQFP64 [(PEP+S616)]
PIC17LC756A@PLCC68 [(PEP+S414T)]    PIC17LC756A@TQFP64 [(PEP+S616)]
PIC17LC762@PLCC84 [(PEP+S416T)]    PIC17LC766@PLCC84 [(PEP+S416T)]
PIC18C242                             PIC18C242@SOIC28 [(SA404)]
PIC18C252                             PIC18C252@SOIC28 [(SA404)]
PIC18C442                             PIC18C442@PLCC44 [(SA244)]
PIC18C442@TQFP44 [(SA245A)]         PIC18C452
PIC18C452@PLCC44 [(SA244)]         PIC18C452@TQFP44 [(SA245A)]
PIC18C658@PLCC68 [(PEP+S414T)]     PIC18C658@TQFP64 [(PEP+S616)]
PIC18C858@PLCC84 [(PEP+S416T)]     PIC18C858@TQFP80 [(PEP+S640B)]
PIC18F1220                             PIC18F1220(ISP) [ISP-HEADER01]
PIC18F1220@SOIC18 [(SA404)]
PIC18F1220@SOIC18(ISP) [ISP-HEADER01]
PIC18F1220@SSOP20 [(SA626A)]
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]
PIC18F1230                             PIC18F1230(ISP) [ISP-HEADER01]
PIC18F1230@QFN28 [(SA685-B006)]
PIC18F1230@QFN28(ISP) [ISP-HEADER01]
PIC18F1230@SOIC18 [(SA404)]
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]
PIC18F1230@SSOP20 [(SA626A)]
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]
PIC18F1320                             PIC18F1320(ISP) [ISP-HEADER01]
PIC18F1320@SOIC18 [(SA404)]
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]
PIC18F1320@SSOP20 [(SA626A)]
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]
PIC18F1330                             PIC18F1330(ISP) [ISP-HEADER01]
PIC18F1330@QFN28 [(SA685-B006)]
PIC18F1330@QFN28(ISP) [ISP-HEADER01]
PIC18F1330@SOIC18 [(SA404)]
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]
PIC18F1330@SSOP20 [(SA626A)]
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]
PIC18F1330-ICD@QFN28 [(SA685-B006)]
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]
PIC18F2220                             PIC18F2220(ISP) [ISP-HEADER01]
PIC18F2220@SOIC28 [(SA404)]
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]
PIC18F2221
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@QFN28 [(SA685-B006)]
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@SOIC28 [(SA404)]
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2320                             PIC18F2320(ISP) [ISP-HEADER01]
PIC18F2320@SOIC28 [(SA404)]
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]
PIC18F2321
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@QFN28 [(SA685-B006)]
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@SOIC28 [(SA404)]
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2331                             PIC18F2331(ISP) [ISP-HEADER01]
PIC18F2331@SOIC28 [(SA404)]
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]
PIC18F23K20
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@QFN28 [(SA685-B006)]
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SOIC28 [(SA404)]
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SSOP28 [(SA626A)]
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@QFN28 [(SA685-B006)]

```



```

PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@SOIC28 [(SA404)]
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F242          PIC18F242(ISP) [ISP-HEADER01]
PIC18F242@SOIC28 [(SA404)]
PIC18F242@SOIC28(ISP) [ISP-HEADER01]
PIC18F2420
PIC18F2420(ISP)(High-V) [ISP-HEADER01]
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]
PIC18F2420@QFN28 [(SA685-B006)]          PIC18F2420@SOIC28 [(SA404)]
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423
PIC18F2423(ISP)(High-V) [ISP-HEADER01]
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@QFN28 [(SA685-B006)]
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@SOIC28 [(SA404)]
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2431          PIC18F2431(ISP) [ISP-HEADER01]
PIC18F2431@SOIC28 [(SA404)]
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]
PIC18F2439          PIC18F2439(ISP) [ISP-HEADER01]
PIC18F2439@SOIC28 [(SA404)]
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]
PIC18F2450
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@QFN28 [(SA685-B006)]
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@SOIC28 [(SA404)]
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455
PIC18F2455(ISP)(High-V) [ISP-HEADER01]
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455@SOIC28 [(SA404)]
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458
PIC18F2458(ISP)(High-V) [ISP-HEADER01]
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458@SOIC28 [(SA404)]
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458@SSOP28 [(SA626A)]
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F248          PIC18F248(ISP) [ISP-HEADER01]
PIC18F248@SOIC28 [(SA404)]
PIC18F248@SOIC28(ISP) [ISP-HEADER01]
PIC18F2480
PIC18F2480(ISP)(High-V) [ISP-HEADER01]
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]
PIC18F2480@QFN28 [(SA685-B006)]
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2480@SOIC28 [(SA404)]
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24J10          PIC18F24J10(ISP) [ISP-HEADER01]
PIC18F24J10@QFN28 [(SA685-B006)]
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]
PIC18F24J10@SOIC28 [(SA404)]
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F24J10@SSOP28 [(SA626A)]
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F24K20
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@QFN28 [(SA685-B006)]
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@SOIC28 [(SA404)]
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@SSOP28 [(SA626A)]
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2510          PIC18F2510(ISP) [ISP-HEADER01]
PIC18F2510@QFN28 [(SA685-B006)]

```

```

PIC18F2510@QFN28(ISP) [ISP-HEADER01]
PIC18F2510@SOIC28 [(SA404)]
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]
PIC18F2515
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]
PIC18F2515@SOIC28 [(SA404)]
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F252
PIC18F252@SOIC28 [(SA404)]
PIC18F252@SOIC28(ISP) [ISP-HEADER01]
PIC18F2520
PIC18F2520(ISP)(High-V) [ISP-HEADER01]
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]
PIC18F2520@QFN28 [(SA685-B006)] PIC18F2520@SOIC28 [(SA404)]
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523
PIC18F2523(ISP)(High-V) [ISP-HEADER01]
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@QFN28 [(SA685-B006)]
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@SOIC28 [(SA404)]
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525@SOIC28 [(SA404)]
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2539
PIC18F2539@SOIC28 [(SA404)]
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]
PIC18F2550
PIC18F2550(ISP)(High-V) [ISP-HEADER01]
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]
PIC18F2550@SOIC28 [(SA404)]
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553
PIC18F2553(ISP)(High-V) [ISP-HEADER01]
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SOIC28 [(SA404)]
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SSOP28 [(SA626A)]
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F258
PIC18F258@SOIC28 [(SA404)]
PIC18F258@SOIC28(ISP) [ISP-HEADER01]
PIC18F2580
PIC18F2580(ISP)(High-V) [ISP-HEADER01]
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@QFN28 [(SA685-B006)]
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@SOIC28 [(SA404)]
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585
PIC18F2585(ISP)(High-V) [ISP-HEADER01]
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SDIP28 [(SA022A)]
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SOIC28 [(SA404)]
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25J10
PIC18F25J10@QFN28 [(SA685-B006)]
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]
PIC18F25J10@SOIC28 [(SA404)]
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F25J10@SSOP28 [(SA626A)]
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F25K20
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@QFN28 [(SA685-B006)]
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]

```

```

PIC18F25K20@SOIC28 [(SA404)]
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SSOP28 [(SA626A)]
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610@SOIC28 [(SA404)]
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620@SOIC28 [(SA404)]
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680
PIC18F2680(ISP)(High-V) [ISP-HEADER01]
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SDIP28 [(SA022A)]
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SOIC28 [(SA404)]
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682
PIC18F2682(ISP)(High-V) [ISP-HEADER01]
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@QFN28 [(SA685)]
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@SOIC28 [(SA404)]
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685
PIC18F2685(ISP)(High-V) [ISP-HEADER01]
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@QFN28 [(SA685)]
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@SOIC28 [(SA404)]
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20
PIC18F26K20(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@QFN28 [(SA685-B006)]
PIC18F26K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@SOIC28 [(SA404)]
PIC18F26K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@SSOP28 [(SA626A)]
PIC18F26K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F4220 PIC18F4220(ISP) [ISP-HEADER01]
PIC18F4220@QFN44 [(SA712)]
PIC18F4220@QFN44(ISP) [ISP-HEADER01]
PIC18F4220@QFN44(ML) [(SA737)]
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4220@TQFP44 [(SA245A)]
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]
PIC18F4221
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44 [(SA712)]
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44(ML) [(SA737)]
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@TQFP44 [(SA245A)]
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4320 PIC18F4320(ISP) [ISP-HEADER01]
PIC18F4320@QFN44 [(SA712)]
PIC18F4320@QFN44(ISP) [ISP-HEADER01]
PIC18F4320@QFN44(ML) [(SA737)]
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4320@TQFP44 [(SA245A)]
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]
PIC18F4321
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44 [(SA712)]
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44(ML) [(SA737)]
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]

```

```

PIC18F4321@TQFP44 [(SA245A)]
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4331 PIC18F4331(ISP) [ISP-HEADER01]
PIC18F4331@TQFP44 [(SA245A)]
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]
PIC18F43K20
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44 [(SA712)]
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML) [(SA737)]
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F43K20@TQFP44 [(SA245A)]
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44 [(SA712)]
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44(ML) [(SA737)]
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@TQFP44 [(SA245A)]
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F442 PIC18F442(ISP) [ISP-HEADER01]
PIC18F442@PLCC44 [(SA244)]
PIC18F442@PLCC44(ISP) [ISP-HEADER01]
PIC18F442@QFN44 [(SA737)] PIC18F442@TQFP44 [(SA245A)]
PIC18F442@TQFP44(ISP) [ISP-HEADER01]
PIC18F4420
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44 [(SA712)]
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44(ML) [(SA737)]
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@TQFP44 [(SA245A)]
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423
PIC18F4423(ISP)(High-V) [ISP-HEADER01]
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44 [(SA712)]
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML) [(SA737)]
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@TQFP44 [(SA245A)]
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4431 PIC18F4431(ISP) [ISP-HEADER01]
PIC18F4431@TQFP44 [(SA245A)]
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]
PIC18F4439 PIC18F4439(ISP) [ISP-HEADER01]
PIC18F4439@TQFP44 [(SA245A)]
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]
PIC18F4450
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44 [(SA712)]
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44(ML) [(SA737)]
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@TQFP44 [(SA245A)]
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455
PIC18F4455(ISP)(High-V) [ISP-HEADER01]
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44 [(SA712)]
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML) [(SA737)]
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@TQFP44 [(SA245A)]
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458
PIC18F4458(ISP)(High-V) [ISP-HEADER01]
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@QFN44 [(SA737)]
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]

```

```
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@TQFP44 [(SA245A)]
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F448 PIC18F448(ISP) [ISP-HEADER01]
PIC18F448@PLCC44 [(SA244)]
PIC18F448@PLCC44(ISP) [ISP-HEADER01]
PIC18F448@QFN44 [(SA737)] PIC18F448@TQFP44 [(SA245A)]
PIC18F448@TQFP44(ISP) [ISP-HEADER01]
PIC18F4480
PIC18F4480(ISP)(High-V) [ISP-HEADER01]
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44 [(SA712)]
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML) [(SA737)]
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@TQFP44 [(SA245A)]
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44J10 PIC18F44J10(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44 [(SA712)]
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44(ML) [(SA709)]
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F44J10@TQFP44 [(SA245A)]
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F44K20
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44 [(SA712)]
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML) [(SA737)]
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F44K20@TQFP44 [(SA245A)]
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4510 PIC18F4510(ISP) [ISP-HEADER01]
PIC18F4510@QFN44 [(SA712)]
PIC18F4510@QFN44(ISP) [ISP-HEADER01]
PIC18F4510@QFN44(ML) [(SA737)]
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4510@TQFP44 [(SA245A)]
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]
PIC18F4515
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44 [(SA712)]
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44(ML) [(SA737)]
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@TQFP44 [(SA245A)]
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F452 PIC18F452(ISP) [ISP-HEADER01]
PIC18F452@PLCC44 [(SA244)]
PIC18F452@PLCC44(ISP) [ISP-HEADER01]
PIC18F452@QFN44 [(SA737)] PIC18F452@TQFP44 [(SA245A)]
PIC18F452@TQFP44(ISP) [ISP-HEADER01]
PIC18F4520 PIC18F4520(ISP) [ISP-HEADER01]
PIC18F4520@QFN44 [(SA712)]
PIC18F4520@QFN44(ISP) [ISP-HEADER01]
PIC18F4520@QFN44(ML) [(SA737)]
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4520@TQFP44 [(SA245A)]
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]
PIC18F4523
PIC18F4523(ISP)(High-V) [ISP-HEADER01]
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@QFN44 [(SA712)]
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@QFN44(ML) [(SA737)]
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@TQFP44 [(SA245A)]
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]
```

```

PIC18F4525@QFN44 [(SA712)]
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@QFN44(ML) [(SA737)]
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@TQFP44 [(SA245A)]
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4539 PIC18F4539(ISP) [ISP-HEADER01]
PIC18F4539@TQFP44 [(SA245A)]
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]
PIC18F4550
PIC18F4550(ISP)(High-V) [ISP-HEADER01]
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@QFN44 [(SA712)]
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@QFN44(ML) [(SA737)]
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@TQFP44 [(SA245A)]
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553
PIC18F4553(ISP)(High-V) [ISP-HEADER01]
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@QFN44 [(SA737)]
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@TQFP44 [(SA245A)]
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F458 PIC18F458(ISP) [ISP-HEADER01]
PIC18F458@PLCC44 [(SA244)]
PIC18F458@PLCC44(ISP) [ISP-HEADER01]
PIC18F458@QFN44 [(SA737)] PIC18F458@TQFP44 [(SA245A)]
PIC18F458@TQFP44(ISP) [ISP-HEADER01]
PIC18F4580
PIC18F4580(ISP)(High-V) [ISP-HEADER01]
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44 [(SA712)]
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML) [(SA737)]
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@TQFP44 [(SA245A)]
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585
PIC18F4585(ISP)(High-V) [ISP-HEADER01]
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44 [(SA712)]
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML) [(SA737)]
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@TQFP44 [(SA245A)]
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45J10 PIC18F45J10(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44 [(SA712)]
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44(ML) [(SA709)]
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F45J10@TQFP44 [(SA245A)]
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F45K20
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44 [(SA712)]
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML) [(SA737)]
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F45K20@TQFP44 [(SA245A)]
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44 [(SA712)]

```

```
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44(ML) [(SA737)]
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@TQFP44 [(SA245A)]
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44 [(SA712)]
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44(ML) [(SA737)]
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@TQFP44 [(SA245A)]
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680
PIC18F4680(ISP)(High-V) [ISP-HEADER01]
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44 [(SA712)]
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML) [(SA737)]
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@TQFP44 [(SA245A)]
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682
PIC18F4682(ISP)(High-V) [ISP-HEADER01]
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44 [(SA712)]
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML) [(SA737)]
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@TQFP44 [(SA245A)]
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685
PIC18F4685(ISP)(High-V) [ISP-HEADER01]
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44 [(SA712)]
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML) [(SA737)]
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@TQFP44 [(SA245A)]
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20
PIC18F46K20(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20@QFN44 [(SA712)]
PIC18F46K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ML) [(SA737)]
PIC18F46K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F46K20@TQFP44 [(SA245A)]
PIC18F46K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F6310@TQFP64 [(PEP+S616)]
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]
PIC18F6390@TQFP64 [(PEP+S616)]
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]
PIC18F6393@TQFP64 [(PEP+S616)]
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J11@TQFP64 [(PEP+S616)]
PIC18F63J11@TQFP64(*) [(SA732+B340)]
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J90@TQFP64 [(PEP+S616)]
PIC18F63J90@TQFP64(*) [(SA732+B340)]
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6410@TQFP64 [(PEP+S616)]
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]
PIC18F6490@TQFP64 [(PEP+S616)]
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]
PIC18F6493@TQFP64 [(PEP+S616)]
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]
PIC18F64J11@TQFP64 [(PEP+S616)]
PIC18F64J11@TQFP64(*) [(SA732+B340)]
```

```

PIC18F64J11@TQFP64 (ISP) [ISP-HEADER01]
PIC18F64J90@TQFP64 [(PEP+S616)]
PIC18F64J90@TQFP64 (*) [(SA732+B340)]
PIC18F64J90@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6520@TQFP64 [(PEP+S616)]
PIC18F6520@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6525@TQFP64 [(PEP+S616)]
PIC18F6525@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6527@TQFP64 [(PEP+S616)]
PIC18F6527@TQFP64 (ISP)(High-V) [ISP-HEADER01]
PIC18F6527@TQFP64 (ISP)(Low-V) [ISP-HEADER01]
PIC18F6585@PLCC68 [(PEP+S414T)]
PIC18F6585@PLCC68 (ISP) [ISP-HEADER01]
PIC18F6585@TQFP64 [(PEP+S616)]
PIC18F6585@TQFP64 (ISP) [ISP-HEADER01]
PIC18F65J10@TQFP64 [(PEP+S616)]
PIC18F65J10@TQFP64 (*) [(SA732+B340)]
PIC18F65J10@TQFP64 (ISP)(Disable) [ISP-HEADER01]
PIC18F65J10@TQFP64 (ISP)(Enable) [ISP-HEADER01]
PIC18F65J11@TQFP64 [(PEP+S616)]
PIC18F65J11@TQFP64 (*) [(SA732+B340)]
PIC18F65J11@TQFP64 (ISP) [ISP-HEADER01]
PIC18F65J15@TQFP64 [(PEP+S616)]
PIC18F65J15@TQFP64 (*) [(SA732+B340)]
PIC18F65J15@TQFP64 (ISP)(Disable) [ISP-HEADER01]
PIC18F65J15@TQFP64 (ISP)(Enable) [ISP-HEADER01]
PIC18F65J50@TQFP64 [(PEP+S616)]
PIC18F65J50@TQFP64 (*) [(SA732+B340)]
PIC18F65J50@TQFP64 (ISP) [ISP-HEADER01]
PIC18F65J90@TQFP64 [(PEP+S616)]
PIC18F65J90@TQFP64 (*) [(SA732+B340)]
PIC18F65J90@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6620@TQFP64 [(PEP+S616)]
PIC18F6620@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6621@TQFP64 [(PEP+S616)]
PIC18F6621@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6622@TQFP64 [(PEP+S616)]
PIC18F6622@TQFP64 (ISP)(High-V) [ISP-HEADER01]
PIC18F6622@TQFP64 (ISP)(Low-V) [ISP-HEADER01]
PIC18F6627@TQFP64 [(PEP+S616)]
PIC18F6627@TQFP64 (ISP)(High-V) [ISP-HEADER01]
PIC18F6627@TQFP64 (ISP)(Low-V) [ISP-HEADER01]
PIC18F6628@TQFP64 [(PEP+S616)] PIC18F6680@PLCC68 [(PEP+S414T)]
PIC18F6680@PLCC68 (ISP) [ISP-HEADER01]
PIC18F6680@TQFP64 [(PEP+S616)]
PIC18F6680@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J10@TQFP64 [(PEP+S616)]
PIC18F66J10@TQFP64 (*) [(SA732+B340)]
PIC18F66J10@TQFP64 (ISP)(Disable) [ISP-HEADER01]
PIC18F66J10@TQFP64 (ISP)(Enable) [ISP-HEADER01]
PIC18F66J11@TQFP64 [(PEP+S616)]
PIC18F66J11@TQFP64 (*) [(SA732+B340)]
PIC18F66J11@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J15@TQFP64 [(PEP+S616)]
PIC18F66J15@TQFP64 (*) [(SA732+B340)]
PIC18F66J15@TQFP64 (ISP)(Disable) [ISP-HEADER01]
PIC18F66J15@TQFP64 (ISP)(Enable) [ISP-HEADER01]
PIC18F66J16@TQFP64 [(PEP+S616)]
PIC18F66J16@TQFP64 (*) [(SA732+B340)]
PIC18F66J16@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J50@TQFP64 [(PEP+S616)]
PIC18F66J50@TQFP64 (*) [(SA732+B340)]
PIC18F66J50@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J55@TQFP64 [(PEP+S616)]
PIC18F66J55@TQFP64 (*) [(SA732+B340)]
PIC18F66J55@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J60@TQFP64 [(PEP+S616)]
PIC18F66J60@TQFP64 (*) [(SA732+B340)]
PIC18F66J60@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J65@TQFP64 [(PEP+S616)]
PIC18F66J65@TQFP64 (*) [(SA732+B340)]
PIC18F66J65@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J90@TQFP64 [(PEP+S616)]
PIC18F66J90@TQFP64 (ISP) [ISP-HEADER01]
PIC18F66J93@TQFP64 [(PEP+S616)]
PIC18F66J93@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6720@TQFP64 [(PEP+S616)]
PIC18F6720@TQFP64 (ISP) [ISP-HEADER01]
PIC18F6722@TQFP64 [(PEP+S616)]
PIC18F6722@TQFP64 (ISP)(High-V) [ISP-HEADER01]
PIC18F6722@TQFP64 (ISP)(Low-V) [ISP-HEADER01]

```



```

PIC18F6723@TQFP64 [(PEP+S616)]          PIC18F67J10@TQFP64 [(PEP+S616)]
PIC18F67J10@TQFP64(*) [(SA732+B340)]
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F67J11@TQFP64 [(PEP+S616)]
PIC18F67J11@TQFP64(*) [(SA732+B340)]
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J50@TQFP64 [(PEP+S616)]
PIC18F67J50@TQFP64(*) [(SA732+B340)]
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J60@TQFP64 [(PEP+S616)]
PIC18F67J60@TQFP64(*) [(SA732+B340)]
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J90@TQFP64 [(PEP+S616)]
PIC18F67J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J93@TQFP64 [(PEP+S616)]
PIC18F67J93@TQFP64(ISP) [ISP-HEADER01]
PIC18F8310@TQFP80 [(PEP+S640B)]
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]
PIC18F8390@TQFP80 [(PEP+S640B)]
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]
PIC18F8393@TQFP80 [(PEP+S640B)]
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J11@TQFP80 [(PEP+S640B)]
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J90@TQFP80 [(PEP+S640B)]
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8410@TQFP80 [(PEP+S640B)]
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]
PIC18F8490@TQFP80 [(PEP+S640B)]
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]
PIC18F8493@TQFP80 [(PEP+S640B)]
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J11@TQFP80 [(PEP+S640B)]
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J90@TQFP80 [(PEP+S640B)]
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8520@TQFP80 [(PEP+S640B)]
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]
PIC18F8525@TQFP80 [(PEP+S640B)]
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]
PIC18F8527@TQFP80 [(PEP+S640B)]
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8585@TQFP80 [(PEP+S640B)]
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J10@TQFP80 [(PEP+S640B)]
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J11@TQFP80 [(PEP+S640B)]
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J15@TQFP80 [(PEP+S640B)]
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J50@TQFP80 [(PEP+S640B)]
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J90@TQFP80 [(PEP+S640B)]
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8620@TQFP80 [(PEP+S640B)]
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]
PIC18F8621@TQFP80 [(PEP+S640B)]
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]
PIC18F8622@TQFP80 [(PEP+S640B)]
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8627@TQFP80 [(PEP+S640B)]
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8628@TQFP80 [(PEP+S640B)]          PIC18F8680@TQFP80 [(PEP+S640B)]
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J10@TQFP80 [(PEP+S640B)]
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J11@TQFP80 [(PEP+S640B)]
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J15@TQFP80 [(PEP+S640B)]
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J16@TQFP80 [(PEP+S640B)]
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J50@TQFP80 [(PEP+S640B)]

```

```

PIC18F86J50@TQFP80 (ISP) [ISP-HEADER01]
PIC18F86J55@TQFP80 [(PEP+S640B)]
PIC18F86J55@TQFP80 (ISP) [ISP-HEADER01]
PIC18F86J60@TQFP80 [(PEP+S640B)]
PIC18F86J60@TQFP80 (ISP) [ISP-HEADER01]
PIC18F86J65@TQFP80 [(PEP+S640B)]
PIC18F86J65@TQFP80 (ISP) [ISP-HEADER01]
PIC18F86J90@TQFP80 [(PEP+S640B)]
PIC18F86J90@TQFP80 (ISP) [ISP-HEADER01]
PIC18F86J93@TQFP80 [(PEP+S640B)]
PIC18F86J93@TQFP80 (ISP) [ISP-HEADER01]
PIC18F8720@TQFP80 [(PEP+S640B)]
PIC18F8720@TQFP80 (ISP) [ISP-HEADER01]
PIC18F8722@TQFP80 [(PEP+S640B)]
PIC18F8722@TQFP80 (ISP)(High-V) [ISP-HEADER01]
PIC18F8722@TQFP80 (ISP)(Low-V) [ISP-HEADER01]
PIC18F8723@TQFP80 [(PEP+S640B)] PIC18F87J10@TQFP80 [(PEP+S640B)]
PIC18F87J10@TQFP80 (ISP)(Disable) [ISP-HEADER01]
PIC18F87J10@TQFP80 (ISP)(Enable) [ISP-HEADER01]
PIC18F87J11@TQFP80 [(PEP+S640B)]
PIC18F87J11@TQFP80 (ISP) [ISP-HEADER01]
PIC18F87J50@TQFP80 [(PEP+S640B)]
PIC18F87J50@TQFP80 (ISP) [ISP-HEADER01]
PIC18F87J60@TQFP80 [(PEP+S640B)]
PIC18F87J60@TQFP80 (ISP) [ISP-HEADER01]
PIC18F87J90@TQFP80 [(PEP+S640B)]
PIC18F87J90@TQFP80 (ISP) [ISP-HEADER01]
PIC18F87J93@TQFP80 [(PEP+S640B)]
PIC18F87J93@TQFP80 (ISP) [ISP-HEADER01]
PIC18F96J60@TQFP100 [(PEP+S604)]
PIC18F96J60@TQFP100 (ISP) [ISP-HEADER01]
PIC18F96J65@TQFP100 [(PEP+S604)]
PIC18F96J65@TQFP100 (ISP) [ISP-HEADER01]
PIC18F97J60@TQFP100 [(PEP+S604)]
PIC18F97J60@TQFP100 (ISP) [ISP-HEADER01]
PIC18LC452 PIC18LC452@PLCC44 [(SA244)]
PIC18LC452@TQFP44 [(SA245A)] PIC18LF1220
PIC18LF1220 (ISP) [ISP-HEADER01] PIC18LF1220@SOIC18 [(SA404)]
PIC18LF1220@SOIC18 (ISP) [ISP-HEADER01]
PIC18LF1220@SSOP20 [(SA626A)]
PIC18LF1220@SSOP20 (ISP) [ISP-HEADER01]
PIC18LF1320 PIC18LF1320 (ISP) [ISP-HEADER01]
PIC18LF1320@SOIC18 [(SA404)]
PIC18LF1320@SOIC18 (ISP) [ISP-HEADER01]
PIC18LF1320@SSOP20 [(SA626A)]
PIC18LF1320@SSOP20 (ISP) [ISP-HEADER01]
PIC18LF2220 PIC18LF2220 (ISP) [ISP-HEADER01]
PIC18LF2220@SOIC28 [(SA404)]
PIC18LF2220@SOIC28 (ISP) [ISP-HEADER01]
PIC18LF2221
PIC18LF2221 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@QFN28 [(SA685-B006)]
PIC18LF2221@QFN28 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@SOIC28 [(SA404)]
PIC18LF2221@SOIC28 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2320 PIC18LF2320 (ISP) [ISP-HEADER01]
PIC18LF2320@SOIC28 [(SA404)]
PIC18LF2320@SOIC28 (ISP) [ISP-HEADER01]
PIC18LF2321
PIC18LF2321 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@QFN28 [(SA685-B006)]
PIC18LF2321@QFN28 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@SOIC28 [(SA404)]
PIC18LF2321@SOIC28 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2331 PIC18LF2331 (ISP) [ISP-HEADER01]
PIC18LF2331@SOIC28 [(SA404)]
PIC18LF2331@SOIC28 (ISP) [ISP-HEADER01]
PIC18LF2410
PIC18LF2410 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@QFN28 [(SA685-B006)]
PIC18LF2410@QFN28 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@SOIC28 [(SA404)]
PIC18LF2410@SOIC28 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF242 PIC18LF242 (ISP) [ISP-HEADER01]
PIC18LF242@SOIC28 [(SA404)]
PIC18LF242@SOIC28 (ISP) [ISP-HEADER01]
PIC18LF2420
PIC18LF2420 (ISP)(High-V) [ISP-HEADER01]
PIC18LF2420 (ISP)(Low-V) [ISP-HEADER01]
PIC18LF2420@QFN28 [(SA685-B006)] PIC18LF2420@SOIC28 [(SA404)]
PIC18LF2420@SOIC28 (ISP)(High-V) [ISP-HEADER01]

```

```
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2431 PIC18LF2431(ISP) [ISP-HEADER01]
PIC18LF2431@SOIC28 [(SA404)]
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2439 PIC18LF2439(ISP) [ISP-HEADER01]
PIC18LF2439@SOIC28 [(SA404)]
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2450
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@QFN28 [(SA685-B006)]
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@SOIC28 [(SA404)]
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455@SOIC28 [(SA404)]
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF248 PIC18LF248(ISP) [ISP-HEADER01]
PIC18LF248@SOIC28 [(SA404)]
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2480
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@QFN28 [(SA685-B006)]
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@SOIC28 [(SA404)]
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-HEADER01]
PIC18LF24J10@QFN28 [(SA685-B006)]
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF24J10@SOIC28 [(SA404)]
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF24J10@SSOP28 [(SA626A)]
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2510 PIC18LF2510(ISP) [ISP-HEADER01]
PIC18LF2510@QFN28 [(SA685-B006)]
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]
PIC18LF2510@SOIC28 [(SA404)]
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2515
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2515@SOIC28 [(SA404)]
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF252 PIC18LF252(ISP) [ISP-HEADER01]
PIC18LF252@SOIC28 [(SA404)]
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2520
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2520@QFN28 [(SA685-B006)] PIC18LF2520@SOIC28 [(SA404)]
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525@SOIC28 [(SA404)]
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2539 PIC18LF2539(ISP) [ISP-HEADER01]
PIC18LF2539@SOIC28 [(SA404)]
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2550
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2550@SOIC28 [(SA404)]
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF258 PIC18LF258(ISP) [ISP-HEADER01]
PIC18LF258@SOIC28 [(SA404)]
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2580
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@QFN28 [(SA685-B006)]
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@SOIC28 [(SA404)]
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
```

PIC18LF2585  
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28 [(SA022A)]  
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28 [(SA404)]  
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-HEADER01]  
PIC18LF25J10@QFN28 [(SA685-B006)]  
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SOIC28 [(SA404)]  
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SSOP28 [(SA626A)]  
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2610  
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2610@SOIC28 [(SA404)]  
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620  
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620@SOIC28 [(SA404)]  
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680  
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28 [(SA022A)]  
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28 [(SA404)]  
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682  
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@QFN28 [(SA685)]  
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28 [(SA404)]  
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685  
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@QFN28 [(SA685)]  
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28 [(SA404)]  
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4220 PIC18LF4220(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44 [(SA712)]  
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44(ML) [(SA737)]  
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4220@TQFP44 [(SA245A)]  
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4221  
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44 [(SA712)]  
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44(ML) [(SA737)]  
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4221@TQFP44 [(SA245A)]  
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4320 PIC18LF4320(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44 [(SA712)]  
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44(ML) [(SA737)]  
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4320@TQFP44 [(SA245A)]  
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4321  
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44 [(SA712)]  
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44(ML) [(SA737)]  
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4321@TQFP44 [(SA245A)]  
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]

```

PIC18LF4331 PIC18LF4331(ISP) [ISP-HEADER01]
PIC18LF4331@TQFP44 [(SA245A)]
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4410
PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44 [(SA712)]
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44(ML) [(SA737)]
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4410@TQFP44 [(SA245A)]
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF442 PIC18LF442(ISP) [ISP-HEADER01]
PIC18LF442@PLCC44 [(SA244)]
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]
PIC18LF442@QFN44 [(SA737)] PIC18LF442@TQFP44 [(SA245A)]
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4420
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44 [(SA712)]
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44(ML) [(SA737)]
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4420@TQFP44 [(SA245A)]
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4431 PIC18LF4431(ISP) [ISP-HEADER01]
PIC18LF4431@TQFP44 [(SA245A)]
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4439 PIC18LF4439(ISP) [ISP-HEADER01]
PIC18LF4439@TQFP44 [(SA245A)]
PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4450
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44 [(SA712)]
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44(ML) [(SA737)]
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4450@TQFP44 [(SA245A)]
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44 [(SA712)]
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML) [(SA737)]
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4455@TQFP44 [(SA245A)]
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF448 PIC18LF448(ISP) [ISP-HEADER01]
PIC18LF448@PLCC44 [(SA244)]
PIC18LF448@PLCC44(ISP) [ISP-HEADER01]
PIC18LF448@QFN44 [(SA737)] PIC18LF448@TQFP44 [(SA245A)]
PIC18LF448@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4480
PIC18LF4480(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4480@QFN44 [(SA712)]
PIC18LF4480@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ML) [(SA737)]
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4480@TQFP44 [(SA245A)]
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF44J10 PIC18LF44J10(ISP) [ISP-HEADER01]
PIC18LF44J10@QFN44 [(SA712)]
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF44J10@QFN44(ML) [(SA709)]
PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF44J10@TQFP44 [(SA245A)]
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4510 PIC18LF4510(ISP) [ISP-HEADER01]
PIC18LF4510@QFN44 [(SA712)]
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]
PIC18LF4510@QFN44(ML) [(SA737)]
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4510@TQFP44 [(SA245A)]
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]

```

```

PIC18LF4515
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4515@QFN44 [(SA712)]
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4515@QFN44(ML) [(SA737)]
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4515@TQFP44 [(SA245A)]
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF452 PIC18LF452(ISP) [ISP-HEADER01]
PIC18LF452@PLCC44 [(SA244)]
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]
PIC18LF452@QFN44 [(SA737)] PIC18LF452@TQFP44 [(SA245A)]
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4520 PIC18LF4520(ISP) [ISP-HEADER01]
PIC18LF4520@QFN44 [(SA712)]
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]
PIC18LF4520@QFN44(ML) [(SA737)]
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4520@TQFP44 [(SA245A)]
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4525
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44 [(SA712)]
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44(ML) [(SA737)]
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4525@TQFP44 [(SA245A)]
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4539 PIC18LF4539(ISP) [ISP-HEADER01]
PIC18LF4539@TQFP44 [(SA245A)]
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4550
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44 [(SA712)]
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ML) [(SA737)]
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4550@TQFP44 [(SA245A)]
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF458 PIC18LF458(ISP) [ISP-HEADER01]
PIC18LF458@PLCC44 [(SA244)]
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]
PIC18LF458@QFN44 [(SA737)] PIC18LF458@TQFP44 [(SA245A)]
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4580
PIC18LF4580(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44 [(SA712)]
PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML) [(SA737)]
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4580@TQFP44 [(SA245A)]
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44 [(SA712)]
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML) [(SA737)]
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4585@TQFP44 [(SA245A)]
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF45J10 PIC18LF45J10(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44 [(SA712)]
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44(ML) [(SA709)]
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF45J10@TQFP44 [(SA245A)]
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4610
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]

```

```
PIC18LF4610@QFN44 [(SA712)]
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44(ML) [(SA737)]
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4610@TQFP44 [(SA245A)]
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44 [(SA712)]
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44(ML) [(SA737)]
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4620@TQFP44 [(SA245A)]
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44 [(SA712)]
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML) [(SA737)]
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4680@TQFP44 [(SA245A)]
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44 [(SA712)]
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML) [(SA737)]
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4682@TQFP44 [(SA245A)]
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44 [(SA712)]
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML) [(SA737)]
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4685@TQFP44 [(SA245A)]
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6310@TQFP64 [(PEP+S616)]
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6390@TQFP64 [(PEP+S616)]
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6393@TQFP64 [(PEP+S616)]
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J11@TQFP64 [(PEP+S616)]
PIC18LF63J11@TQFP64(*) [(SA732+B340)]
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J90@TQFP64 [(PEP+S616)]
PIC18LF63J90@TQFP64(*) [(SA732+B340)]
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6410@TQFP64 [(PEP+S616)]
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6490@TQFP64 [(PEP+S616)]
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6493@TQFP64 [(PEP+S616)]
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J11@TQFP64 [(PEP+S616)]
PIC18LF64J11@TQFP64(*) [(SA732+B340)]
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J90@TQFP64 [(PEP+S616)]
PIC18LF64J90@TQFP64(*) [(SA732+B340)]
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6520@TQFP64 [(PEP+S616)]
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6525@TQFP64 [(PEP+S616)]
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6527@TQFP64 [(PEP+S616)]
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
```

```

PIC18LF6585@PLCC68 [(PEP+S414T)]
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6585@TQFP64 [(PEP+S616)]
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J11@TQFP64 [(PEP+S616)]
PIC18LF65J11@TQFP64(*) [(SA732+B340)]
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J90@TQFP64 [(PEP+S616)]
PIC18LF65J90@TQFP64(*) [(SA732+B340)]
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6620@TQFP64 [(PEP+S616)]
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6621@TQFP64 [(PEP+S616)]
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6622@TQFP64 [(PEP+S616)]
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6627@TQFP64 [(PEP+S616)]
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6628@TQFP64 [(PEP+S616)] PIC18LF6680@PLCC68 [(PEP+S414T)]
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6680@TQFP64 [(PEP+S616)]
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6720@TQFP64 [(PEP+S616)]
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6722@TQFP64 [(PEP+S616)]
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6723@TQFP64 [(PEP+S616)] PIC18LF8310@TQFP80 [(PEP+S640B)]
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8390@TQFP80 [(PEP+S640B)]
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8393@TQFP80 [(PEP+S640B)]
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J11@TQFP80 [(PEP+S640B)]
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J90@TQFP80 [(PEP+S640B)]
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8410@TQFP80 [(PEP+S640B)]
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8490@TQFP80 [(PEP+S640B)]
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8493@TQFP80 [(PEP+S640B)]
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J11@TQFP80 [(PEP+S640B)]
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J90@TQFP80 [(PEP+S640B)]
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8520@TQFP80 [(PEP+S640B)]
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8525@TQFP80 [(PEP+S640B)]
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8527@TQFP80 [(PEP+S640B)]
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8585@TQFP80 [(PEP+S640B)]
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J11@TQFP80 [(PEP+S640B)]
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J90@TQFP80 [(PEP+S640B)]
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8620@TQFP80 [(PEP+S640B)]
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8621@TQFP80 [(PEP+S640B)]
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8622@TQFP80 [(PEP+S640B)]
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8627@TQFP80 [(PEP+S640B)]
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8628@TQFP80 [(PEP+S640B)] PIC18LF8680@TQFP80 [(PEP+S640B)]
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8720@TQFP80 [(PEP+S640B)]
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8722@TQFP80 [(PEP+S640B)]
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8723@TQFP80 [(PEP+S640B)]
PIC24HJ128GP206@TQFP64 [(PEP+S616)]

```



```

PIC24HJ128GP210@TQFP100 [(PEP+S604)]
PIC24HJ128GP306@TQFP64 [(PEP+S616)]
PIC24HJ128GP310@TQFP100 [(PEP+S604)]
PIC24HJ128GP506@TQFP64 [(PEP+S616)]
PIC24HJ128GP510@TQFP100 [(PEP+S604)]
PIC24HJ256GP206@TQFP64 [(PEP+S616)]
PIC24HJ256GP210@TQFP100 [(PEP+S604)]
PIC24HJ256GP610@TQFP100 [(PEP+S604)]
PIC24HJ64GP206@TQFP64 [(PEP+S616)]
PIC24HJ64GP210@TQFP100 [(PEP+S604)]
PIC24HJ64GP506@TQFP64 [(PEP+S616)]
PIC24HJ64GP510@TQFP100 [(PEP+S604)]
PIC30F2010 PIC30F2010(ISP) [ISP-HEADER01]
PIC30F2010@SDIP28 [(SA022A)]
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]
PIC30F2010@SOIC28 [(SA404)]
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]
PIC30F2011 PIC30F2011(ISP) [ISP-HEADER01]
PIC30F2011@QFN28 [(SA685-B006)]
PIC30F2011@QFN28(ISP) [ISP-HEADER01]
PIC30F2011@SDIP18 [(SA022A)]
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]
PIC30F2011@SOIC18 [(SA404)]
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]
PIC30F2012 PIC30F2012(ISP) [ISP-HEADER01]
PIC30F2012@QFN28 [(SA685-B006)]
PIC30F2012@QFN28(ISP) [ISP-HEADER01]
PIC30F2012@SDIP28 [(SA022A)]
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]
PIC30F2012@SOIC28 [(SA404)]
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]
PIC30F3010 PIC30F3010(ISP) [ISP-HEADER01]
PIC30F3010@QFN44 [(SA737)]
PIC30F3010@QFN44(ISP) [ISP-HEADER01]
PIC30F3010@SDIP28 [(SA022A)]
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]
PIC30F3010@SOIC28 [(SA404)]
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]
PIC30F3011 PIC30F3011(ISP) [ISP-HEADER01]
PIC30F3011@QFN44 [(SA737)]
PIC30F3011@QFN44(ISP) [ISP-HEADER01]
PIC30F3011@QFP44 [(SA245A)]
PIC30F3011@QFP44(ISP) [ISP-HEADER01]
PIC30F3012 PIC30F3012(ISP) [ISP-HEADER01]
PIC30F3012@QFN44 [(SA737)]
PIC30F3012@QFN44(ISP) [ISP-HEADER01]
PIC30F3012@QFP44 [(SA245A)]
PIC30F3012@QFP44(ISP) [ISP-HEADER01]
PIC30F3012@SDIP18 [(SA022A)]
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]
PIC30F3012@SOIC18 [(SA404)]
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]
PIC30F3013 PIC30F3013(ISP) [ISP-HEADER01]
PIC30F3013@QFN44 [(SA737)]
PIC30F3013@QFN44(ISP) [ISP-HEADER01]
PIC30F3013@QFP44 [(SA245A)]
PIC30F3013@QFP44(ISP) [ISP-HEADER01]
PIC30F3013@SDIP28 [(SA022A)]
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]
PIC30F3013@SOIC28 [(SA404)]
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]
PIC30F3014 PIC30F3014(ISP) [ISP-HEADER01]
PIC30F3014@QFN44 [(SA737)]
PIC30F3014@QFN44(ISP) [ISP-HEADER01]
PIC30F3014@QFP44 [(SA245A)]
PIC30F3014@QFP44(ISP) [ISP-HEADER01]
PIC30F4011 PIC30F4011(ISP) [ISP-HEADER01]
PIC30F4011@QFN44 [(SA737)]
PIC30F4011@QFN44(ISP) [ISP-HEADER01]
PIC30F4011@QFP44 [(SA245A)]
PIC30F4011@QFP44(ISP) [ISP-HEADER01]
PIC30F4012 PIC30F4012(ISP) [ISP-HEADER01]
PIC30F4012@QFN44 [(SA737)]
PIC30F4012@QFN44(ISP) [ISP-HEADER01]
PIC30F4012@SDIP28 [(SA022A)]
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]
PIC30F4012@SOIC28 [(SA404)]
PIC30F4012@SOIC28(ISP) [ISP-HEADER01]
PIC30F4013 PIC30F4013(ISP) [ISP-HEADER01]
PIC30F4013@QFN44 [(SA737)]
PIC30F4013@QFN44(ISP) [ISP-HEADER01]

```

```

PIC30F4013@QFP44 [(SA245A)]
PIC30F4013@QFP44(ISP) [ISP-HEADER01]
PIC30F5011@QFP64 [(PEP+S616)]
PIC30F5011@QFP64(ISP) [ISP-HEADER01]
PIC30F5013@QFP80 [(PEP+S640B)]
PIC30F5013@QFP80(ISP) [ISP-HEADER01]
PIC30F5015@QFP64 [(PEP+S616)]
PIC30F5015@QFP64(ISP) [ISP-HEADER01]
PIC30F5016@QFP80 [(PEP+S640B)]
PIC30F5016@QFP80(ISP) [ISP-HEADER01]
PIC30F6010@QFP80 [(PEP+S640B)]
PIC30F6010@QFP80(ISP) [ISP-HEADER01]
PIC30F6010@TQFP80 [(PEP+S704)]
PIC30F6010@TQFP80(ISP) [ISP-HEADER01]
PIC30F6010A@QFP80 [(PEP+S640B)]
PIC30F6010A@QFP80(fast) [(PEP+S640B)]
PIC30F6010A@QFP80(ISP) [ISP-HEADER01]
PIC30F6010A@TQFP80 [(PEP+S704)]
PIC30F6010A@TQFP80(fast) [(PEP+S704)]
PIC30F6010A@TQFP80(ISP) [ISP-HEADER01]
PIC30F6011@LQFP64 [(PEP+S625)]
PIC30F6011@LQFP64(ISP) [ISP-HEADER01]
PIC30F6011@QFP64 [(PEP+S616)]
PIC30F6011@QFP64(ISP) [ISP-HEADER01]
PIC30F6011A@QFP64 [(PEP+S616)]
PIC30F6011A@QFP64(ISP) [ISP-HEADER01]
PIC30F6012@QFP64 [(PEP+S616)]
PIC30F6012@QFP64(ISP) [ISP-HEADER01]
PIC30F6012A@QFP64 [(PEP+S616)]
PIC30F6012A@QFP64(ISP) [ISP-HEADER01]
PIC30F6013@QFP80 [(PEP+S640B)]
PIC30F6013@QFP80(ISP) [ISP-HEADER01]
PIC30F6013A@QFP80 [(PEP+S640B)]
PIC30F6013A@QFP80(ISP) [ISP-HEADER01]
PIC30F6014@QFP80 [(PEP+S640B)]
PIC30F6014@QFP80(ISP) [ISP-HEADER01]
PIC30F6014@TQFP80 [(PEP+S704)]
PIC30F6014@TQFP80(ISP) [ISP-HEADER01]
PIC30F6014A@QFP80 [(PEP+S640B)]
PIC30F6014A@QFP80(ISP) [ISP-HEADER01]
PIC30F6014A@TQFP80 [(PEP+S704)]
PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]
PIC30F6015@QFP64 [(PEP+S616)]
PIC30F6015@QFP64(ISP) [ISP-HEADER01]
PIC33FJ128GP206@TQFP64 [(PEP+S616)]
PIC33FJ128GP306@TQFP64 [(PEP+S616)]
PIC33FJ128GP310@TQFP100 [(PEP+S604)]
PIC33FJ128GP706@TQFP64 [(PEP+S616)]
PIC33FJ128GP708@TQFP80 [(PEP+S640B)]
PIC33FJ128GP710@TQFP100 [(PEP+S604)]
PIC33FJ128MC506@TQFP64 [(PEP+S616)]
PIC33FJ128MC510@TQFP100 [(PEP+S604)]
PIC33FJ128MC706@TQFP64 [(PEP+S616)]
PIC33FJ128MC708@TQFP80 [(PEP+S640B)]
PIC33FJ128MC710@TQFP100 [(PEP+S604)]
PIC33FJ256GP506@TQFP64 [(PEP+S616)]
PIC33FJ256GP510@TQFP100 [(PEP+S604)]
PIC33FJ256GP710@TQFP100 [(PEP+S604)]
PIC33FJ256MC510@TQFP100 [(PEP+S604)]
PIC33FJ256MC710@TQFP100 [(PEP+S604)]
PIC33FJ64GP206@TQFP64 [(PEP+S616)]
PIC33FJ64GP306@TQFP64 [(PEP+S616)]
PIC33FJ64GP310@TQFP100 [(PEP+S604)]
PIC33FJ64GP706@TQFP64 [(PEP+S616)]
PIC33FJ64GP708@TQFP80 [(PEP+S640B)]
PIC33FJ64GP710@TQFP100 [(PEP+S604)]
PIC33FJ64MC506@TQFP64 [(PEP+S616)]
PIC33FJ64MC508@TQFP80 [(PEP+S640B)]
PIC33FJ64MC510@TQFP100 [(PEP+S604)]
PIC33FJ64MC706@TQFP64 [(PEP+S616)]
PIC33FJ64MC710@TQFP100 [(PEP+S604)]
PS200
PS200@SOIC20 [(SA404)]
PS200@SSOP20 [(SA626A)]
rfPIC12C509AF@SSOP20 [(SA626A)]
rfPIC12C509AF@SSOP20(ISP) [ISP-HEADER01]
rfPIC12C509AG@SOIC18 [(SA404)]
rfPIC12C509AG@SOIC18(ISP) [ISP-HEADER01]
rfPIC12LC509AF@SSOP20 [(SA626A)]
rfPIC12LC509AF@SSOP20(ISP) [ISP-HEADER01]
rfPIC12LC509AG@SOIC18 [(SA404)]
PS200(ISP) [ISP-HEADER01]
PS200@SOIC20(ISP) [ISP-HEADER01]
PS200@SSOP20(ISP) [ISP-HEADER01]

```

rfPIC12LC509AG@SOIC18(ISP) [ISP-HEADER01]

**MICRON****E(E) PROM/FRAM/NVRAM**

```

MT28F002B1VG-B@TSOP40 [(SA409T)]      MT28F002B1VG-T@TSOP40 [(SA409T)]
MT28F002B3VG-B@TSOP40 [(SA409T)]      MT28F002B3VG-T@TSOP40 [(SA409T)]
MT28F002B5VG-B@TSOP40 [(SA409T)]      MT28F002B5VG-T@TSOP40 [(SA409T)]
MT28F002C1VG-T@TSOP40 [(SA409T)]      MT28F002C5VG-T@TSOP40 [(SA409T)]
MT28F002VG-B@TSOP40 [(SA409T)]         MT28F002VG-T@TSOP40 [(SA409T)]
MT28F004B1VG-B@TSOP40 [(SA409T)]      MT28F004B1VG-T@TSOP40 [(SA409T)]
MT28F004B3VG-B@TSOP40 [(SA409T)]      MT28F004B3VG-T@TSOP40 [(SA409T)]
MT28F004B5VG-B@TSOP40 [(SA409T)]      MT28F004B5VG-T@TSOP40 [(SA409T)]
MT28F004VG-B@TSOP40 [(SA409T)]         MT28F004VG-T@TSOP40 [(SA409T)]
MT28F008B1VG-B@TSOP40 [(SA409T)]      MT28F008B1VG-T@TSOP40 [(SA409T)]
MT28F008B3VG-B@TSOP40 [(SA409T)]      MT28F008B3VG-T@TSOP40 [(SA409T)]
MT28F008B5VG-B@TSOP40 [(SA409T)]      MT28F008B5VG-T@TSOP40 [(SA409T)]
MT28F016S3VG@TSOP40 [(SA409T)]         MT28F016S5VG@TSOP40 [(SA409T)]
MT28F1284W18BQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]
MT28F1284W18TQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]
MT28F128J3A(FW203)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(FW501)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(FW502)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(FW503)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(INTEL)@TSOP56 [(SA628-B018)]
MT28F128J3A(MICRON)@TSOP56 [(SA628-B018)]
MT28F160A18FF(BET)(FW712)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160A18FF(TET)(FW713)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160C34FD(BET)(FW614)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160C34FD(TET)(FW615)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160C3FD(BET)(FW610)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160C3FD(TET)(FW612)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160C3FD(BET)(FW611)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F160C3FD(TET)(FW613)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F162A3FD(BET)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F162A3FD(TET)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F200B1SGB@PSOP44 [(SA638)]          MT28F200B1SGT@PSOP44 [(SA638)]
MT28F200B1WGB@TSOP48 [(SA247-B005)]
MT28F200B1WGT@TSOP48 [(SA247-B005)]
MT28F200B3SGB@PSOP44 [(SA638)]          MT28F200B3SGT@PSOP44 [(SA638)]
MT28F200B3WGB@TSOP48 [(SA247-B005)]
MT28F200B3WGT@TSOP48 [(SA247-B005)]
MT28F200B5SGB@PSOP44 [(SA638)]          MT28F200B5SGT@PSOP44 [(SA638)]
MT28F200B5WGB@TSOP48 [(SA247-B005)]
MT28F200B5WGT@TSOP48 [(SA247-B005)]
MT28F320A18FF(BET)(FW722)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F320A18FF(TET)(FW723)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F320J3A(FW201)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(FW204)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(FW207)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(FW208)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(INTEL)@TSOP56 [(SA628-B018)]
MT28F320J3A(MICRON)@TSOP56 [(SA628-B018)]
MT28F321P18FG(BET)(FW820)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F321P18FG(TET)(FW821)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F321P20FG(BET)(FW810)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F321P20FG(TET)(FW818)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F321P20FG(BET)(FW811)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F321P20FG(TET)(FW819)@FBGA48 [(SA634A-B005A-Y048F001)]
MT28F322D18FH(BET)(FW536)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(BET)(FW538)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(BET)(FW542)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(BET)(FW556)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(TET)(FW535)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(TET)(FW537)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(TET)(FW543)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(TET)(FW557)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D18FH(TET)(FW558)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(BET)(FW547)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(BET)(FW549)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(BET)(FW550)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(BET)(FW552)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(TET)(FW546)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(TET)(FW548)@FBGA58 [(SA644A-B025A-Y056N001)]
MT28F322D20FH(TET)(FW551)@FBGA58 [(SA644A-B025A-Y056N001)]

```

MT28F322D20FH (TET) (FW553)@FBGA58 [(SA644A-B025A-Y056N001)]  
 MT28F322P3FJ (BET) (FW814)@FBGA48 [(SA634A-B005A-Y048F001)]  
 MT28F322P3FJ (BET) (FW816)@FBGA48 [(SA634A-B005A-Y048F001)]  
 MT28F322P3FJ (TET) (FW815)@FBGA48 [(SA634A-B005A-Y048F001)]  
 MT28F322P3FJ (TET) (FW817)@FBGA48 [(SA634A-B005A-Y048F001)]  
 MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44 [(SA638)]  
 MT28F400B1WGB@TSOP48 [(SA247-B005)]  
 MT28F400B1WGT@TSOP48 [(SA247-B005)]  
 MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44 [(SA638)]  
 MT28F400B3WGB@TSOP48 [(SA247-B005)]  
 MT28F400B3WGT@TSOP48 [(SA247-B005)]  
 MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44 [(SA638)]  
 MT28F400B5WGB@TSOP48 [(SA247-B005)]  
 MT28F400B5WGT@TSOP48 [(SA247-B005)]  
 MT28F640J3A (FW202) (I.)@FBGA64 [(SA655A-B054A-T064F001)]  
 MT28F640J3A (FW205) (M.)@FBGA64 [(SA655A-B054A-T064F001)]  
 MT28F640J3A (FW206) (I.)@FBGA64 [(SA655A-B054A-T064F001)]  
 MT28F640J3A (FW209) (M.)@FBGA64 [(SA655A-B054A-T064F001)]  
 MT28F640J3A (FW505) (I.)@FBGA64 [(SA655A-B054A-T064F001)]  
 MT28F640J3A (FW506) (M.)@FBGA64 [(SA655A-B054A-T064F001)]  
 MT28F640J3A (INTEL)@TSOP56 [(SA628-B018)]  
 MT28F640J3A (MICRON)@TSOP56 [(SA628-B018)]  
 MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44 [(SA638)]  
 MT28F800B1WGB@TSOP48 [(SA247-B005)]  
 MT28F800B1WGT@TSOP48 [(SA247-B005)]  
 MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44 [(SA638)]  
 MT28F800B3WGB@TSOP48 [(SA247-B005)]  
 MT28F800B3WGT@TSOP48 [(SA247-B005)]  
 MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44 [(SA638)]  
 MT28F800B5WGB@TSOP48 [(SA247-B005)]  
 MT28F800B5WGT@TSOP48 [(SA247-B005)]  
 MT29F1G08AACWP@TSOP48 [(SA247-B005)]  
 MT29F1G08ABAWP@TSOP48 [(SA247-B005)]  
 MT29F1G16ABAWP@TSOP48 [(SA247-B005)]  
 MT29F2G08AAAAGW@TSOP48 [(SA247-B005)]  
 MT29F2G08AABWP@TSOP48 [(SA247-B005)]  
 MT29F2G08AACWP@TSOP48 [(SA247-B005)]  
 MT29F4G08AAAAP@TSOP48 [(SA247-B005)]  
 MT29F4G08BAB@TSOP48 [(SA247-B005)]  
 MT29F8G08DAA@TSOP48 [(SA247-B005)]

#### DRAM & SRAM

MTSRAM@FBGA48 [(SA634A-B005A-Y048F001)]

## MICRONAS

#### MICROCONTROLLER

SDA555XFL@SDIP52 [(PEP+S627)]  
 SDA555XFL@SDIP52 (\*) [(SA627-B5603)]

## MICRON-CUSTOMER

#### E (E) PROM / FRAM / NVRAM

MT29F4G08AAAAP (sony)@TSOP48 [(SA247+B005)]

## MITSUBISHI

#### E (E) PROM / FRAM / NVRAM

M5L27128K	M5L2716
M5L27256K	M5L2732
M5L2732A	M5L27512
M5L27512K	M5L2764K
M5L27C512A	M5M27128P
M5M27256P	M5M27512P
M5M2764P	M5M27C100K
M5M27C100K@PLCC32 [(SA015A1T)]	M5M27C100K@TSOP32 [(SA410T)]

```

M5M27C100P
M5M27C100P@TSOP32 [(SA410T)]
M5M27C101JK@PLCC32 [(SA015A1T)]
M5M27C101K
M5M27C101K@TSOP32 [(SA410T)]
M5M27C101P@PLCC32 [(SA015A1T)]
M5M27C102K
M5M27C102P
M5M27C128K
M5M27C201K@PLCC32 [(SA015A1T)]
M5M27C202K
M5M27C256(K)
M5M27C256A(FP)
M5M27C256A(P)
M5M27C401K@PLCC32 [(SA015A1T)]
M5M27C402K
M5M27C512A(FP)
M5M27C512A(P)
M5M28F101@PLCC32 [(SA015A1T)]
M5M28F101@TSOP32 [(SA410T)]
M5M28F101A@PLCC32 [(SA015A1T)]
M5M28F101A@TSOP32 [(SA410T)]
M5M29FB160A@TSOP48 [(SA247-B005)]
M5M29FB800(FP)@PSOP44 [(SA638)]
M5M29FB800(VP)@TSOP48 [(SA247-B005)]
M5M29FT160A@TSOP48 [(SA247-B005)]
M5M29FT800(FP)@PSOP44 [(SA638)]
M5M29FT800(VP)@TSOP48 [(SA247-B005)]
M5M29GB160B(VP)@TSOP48 [(SA247-B005)]
M5M29GB320(VP)@TSOP48 [(SA247-B005)]
M5M29GB320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]
M5M29GT160B(VP)@TSOP48 [(SA247-B005)]
M5M29GT320(VP)@TSOP48 [(SA247-B005)]
M5M29GT320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]
M5M29JB160A@TSOP48 [(SA247-B005)]
M5M29JT160A@TSOP48 [(SA247-B005)]
M6M80011A
M6M80011A@SOIC16 [(SA023A)]
M6M80021@SOIC10 [(SA023A)]
M6M80041
M6MG3B641S16TP@TSOP52 [(SA657-B036)]
M6MG3T641S16TP@TSOP52 [(SA657-B036)]
M6MGB321S4TP@TSOP52 [(SA657-B036)]
M6MGB321S8TP@TSOP52 [(SA657-B036)]
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB331S8KT@TSOP52 [(SA657-B036)]
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB641S16TP@TSOP52 [(SA657-B036)]
M6MGB641S4TP@TSOP52 [(SA657-B036)]
M6MGB641S8TP@TSOP52 [(SA657-B036)]
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]
M6MGE157S4KT@TSOP52 [(SA657-B055)]
M6MGT321S4TP@TSOP52 [(SA657-B036)]
M6MGT321S8TP@TSOP52 [(SA657-B036)]
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT331S8KT@TSOP52 [(SA657-B036)]
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT641S16TP@TSOP52 [(SA657-B036)]
M6MGT641S4TP@TSOP52 [(SA657-B036)]
M6MGT641S8TP@TSOP52 [(SA657-B036)]
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]
M5M27C100P@PLCC32 [(SA015A1T)]
M5M27C101JK
M5M27C101JK@TSOP32 [(SA410T)]
M5M27C101K@PLCC32 [(SA015A1T)]
M5M27C101P
M5M27C101P@TSOP32 [(SA410T)]
M5M27C102K@PLCC44 [(SA244)]
M5M27C102P@PLCC44 [(SA244)]
M5M27C201K
M5M27C201K@TSOP32 [(SA410T)]
M5M27C202K@PLCC44 [(SA244)]
M5M27C256(P)
M5M27C256A(K)
M5M27C401K
M5M27C401K@TSOP32 [(SA410T)]
M5M27C512(FP)
M5M27C512A(K)
M5M28F101
M5M28F101@SOP32 [(SA438T)]
M5M28F101A
M5M28F101A@SOIC32 [(SA438T)]
M6M80011A@SOIC10 [(SA023A)]
M6M80021
M6M80021@SOIC16 [(SA023A)]
M6M80041@SOIC10 [(SA023A)]

```

## MICROCONTROLLER

```

M30240ECFP@QFP80(Renesas) [(PCA7302E1F-80)]
M30260F3AGP@QFP48 [(SA248)]
M30260F3VGP@QFP48 [(SA248)]
M30260F6TGP@QFP48 [(SA248)]
M30260F8AGP@QFP48 [(SA248)]
M30260F8VGP@QFP48 [(SA248)]
M30262F4GP@QFP48 [(SA248)]
M30262F8GP@QFP48 [(SA248)]
M30263F6AFP@SSOP42 [(SA775)]
M30280F6HP@QFP80(*) [(SA731-B230)]
M30260F3TGP@QFP48 [(SA248)]
M30260F6AGP@QFP48 [(SA248)]
M30260F6VGP@QFP48 [(SA248)]
M30260F8TGP@QFP48 [(SA248)]
M30262F3GP@QFP48 [(SA248)]
M30262F6GP@QFP48 [(SA248)]
M30263F3AFP@SSOP42 [(SA775)]
M30263F8AFP@SSOP42 [(SA775)]

```

M30280F8HP@QFP80(\*) [(SA731-B230)]  
M30280FAHP@QFP80(\*) [(SA731-B230)]  
M30280FATHP@QFP80(\*) [(SA731-B230)]  
M30280FAVHP@QFP80(\*) [(SA731-B230)]  
M30280FCHP@QFP80(\*) [(SA731-B230)]  
M30281F6HP@QFP64(\*) [(SA732-B315)]  
M30281F8HP@QFP64(\*) [(SA732-B315)]  
M30281FAHP@QFP64(\*) [(SA732-B315)]  
M30281FATHP@QFP64(\*) [(SA732-B315)]  
M30281FAVHP@QFP64(\*) [(SA732-B315)]  
M30281FCHP@QFP64(\*) [(SA732-B315)]  
M30290FAHP@QFP80(\*) [(SA731-B230)]  
M30290FATHP@QFP80(\*) [(SA731-B230)]  
M30290FAVHP@QFP80(\*) [(SA731-B230)]  
M30290FCHP@QFP80(\*) [(SA731-B230)]  
M30290FCTHP@QFP80(\*) [(SA731-B230)]  
M30290FCVHP@QFP80(\*) [(SA731-B230)]  
M30291F8HP@QFP64(\*) [(SA732-B315)]  
M30291F8THP@QFP64(\*) [(SA732-B315)]  
M30291F8VHP@QFP64(\*) [(SA732-B315)]  
M30291FAHP@QFP64(\*) [(SA732-B315)]  
M30291FATHP@QFP64(\*) [(SA732-B315)]  
M30291FAVHP@QFP64(\*) [(SA732-B315)]  
M30291FCHP@QFP64(\*) [(SA732-B315)]  
M30291FCTHP@QFP64(\*) [(SA732-B315)]  
M30291FCVHP@QFP64(\*) [(SA732-B315)]  
M30620ECFP@QFP100(Renesas) [(PCA7412F-100)]  
M30620ECFS@QFN100(Renesas) [(PCA7412L-100)]  
M30620ECGP@LQFP100(Renesas) [(PCA7412G-100)]  
M30620FCAFP@PQFP100(\*) [(TA012-B006)]  
M30620FCAGP@TQFP100(\*) [(TA013-B006)]  
M30620FCFP@PQFP100(\*) [(TA012-B006)]  
M30620FCGP@TQFP100(\*) [(TA013-B006)]  
M30621ECGP@QFP80(Renesas) [(PCA7413F-80)]  
M30622ECTFP@QFP100(Renesas) [(PCA7412F-100)]  
M30622F8FP@PQFP100(\*) [(TA012-B006)]  
M30622F8GP@TQFP100(\*) [(TA013-B006)]  
M30623ECTGP@QFP80(Renesas) [(PCA7413F-80)]  
M30624FGAFP@PQFP100(\*) [(TA012-B006)]  
M30624FGAGP@TQFP100(\*) [(TA013-B006)]  
M30624FGFP@PQFP100(\*) [(TA012-B006)]  
M30624FGGP@TQFP100(\*) [(TA013-B006)]  
M30626FHFP@PQFP100(\*) [(TA012-B006)]  
M30626FHGP@TQFP100(\*) [(TA013-B006)]  
M30627FHGP@PQFP128(\*) [(SA720-B228)]  
M3062LFGFP@PQFP100(\*) [(TA012-B006)]  
M3062LFGGP@TQFP100(\*) [(TA013-B006)]  
M306N4FCFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCGP@QFP100(\*) [(TA013-B006)]  
M306N4FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCTGP@QFP100(\*) [(TA013-B006)]  
M306N4FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCVGP@QFP100(\*) [(TA013-B006)]  
M306N4FGFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGGP@QFP100(\*) [(TA013-B006)]  
M306N4FGTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGTGP@QFP100(\*) [(TA013-B006)]  
M306N4FGVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGVGP@QFP100(\*) [(TA013-B006)]  
M306N5FCFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCGP@QFP100(\*) [(TA013-B006)]  
M306N5FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCTGP@QFP100(\*) [(TA013-B006)]  
M306N5FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCVGP@QFP100(\*) [(TA013-B006)]  
M306NKFHGP@QFP100(\*) [(TA013-B006)]  
M306NKFHTGP@QFP100(\*) [(TA013-B006)]  
M306NKFHVG@QFP100(\*) [(TA013-B006)]  
M306NKFJGP@QFP100(\*) [(TA013-B006)]  
M306NKFJTGP@QFP100(\*) [(TA013-B006)]  
M306NKFJVGP@QFP100(\*) [(TA013-B006)]  
M306NLFHGP@QFP100(\*) [(TA013-B006)]  
M306NLFHTGP@QFP100(\*) [(TA013-B006)]  
M306NLFHVG@QFP100(\*) [(TA013-B006)]  
M306NLFJGP@QFP100(\*) [(TA013-B006)]  
M306NLFJTGP@QFP100(\*) [(TA013-B006)]  
M306NLFJVGP@QFP100(\*) [(TA013-B006)]  
M306NMFHGP@QFP128(\*) [(SA720-B228)]  
M306NMFHTGP@QFP128(\*) [(SA720-B228)]  
M306NMFHVG@QFP128(\*) [(SA720-B228)]  
M306NMFJGP@QFP128(\*) [(SA720-B228)]

M306NMFJTGP@QFP128(\*) [(SA720-B228)]  
M306NMFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNFHGP@QFP128(\*) [(SA720-B228)]  
M306NNFHVGP@QFP128(\*) [(SA720-B228)]  
M306NNFJGP@QFP128(\*) [(SA720-B228)]  
M306NNFJTGP@QFP128(\*) [(SA720-B228)]  
M306NNFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNTFHGP@QFP128(\*) [(SA720-B228)]  
M306V0EEFFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V0EEFFS@QFN100(Renesas) [(PCA7412L-100)]  
M306V2EEFFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V2EEFFS@QFN100(Renesas) [(PCA7412L-100)]  
M34282E2GP [(SA026)] M34283G2GP [(SA026)]  
M34283G2GP (ISP) [ISP-HEADER01] M34508G4FP [(SA023A)]  
M34508G4GP [(SA026)] M34508G4HFP [(SA023A)]  
M34508G4HGP [(SA026)] M34509G4FP [(SA711-B005)]  
M34509G4HFP [(SA711-B005)]  
M34513E4FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34513E4SP@SDIP32(Renesas) [(PCA7442SP)]  
M34513E8FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34514E8FP@SSOP42(Renesas) [(PCA7441)]  
M34518E8FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34518E8SP@SDIP32(Renesas) [(PCA7442SP)]  
M34519E8FP@SSOP42(Renesas) [(PCA7441)]  
M34524EDFP@QFP64(Renesas) [(PCA7448)]  
M34551E8FP@QFP48(Renesas) [(PCA7414)]  
M34554EDFP@QFP64(Renesas) [(PCA7448)]  
M34559G6FP@QFP52 [(PEP-S673)]  
M34559G6FP@QFP52(\*) [(SA740+B342)]  
M3455AG8FP@QFP52 [(PEP-S673)]  
M3455AG8FP@QFP52(\*) [(SA740+B342)]  
M3455AGCFP@QFP52 [(PEP-S673)]  
M3455AGCFP@QFP52(\*) [(SA740+B342)]  
M34570E8FP@SSOP36(Renesas) [(PCA7425)]  
M34570EDFP@SSOP36(Renesas) [(PCA7425)]  
M34583EDFP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34584EDFP@SSOP42(Renesas) [(PCA7441)]  
M37136@SDIP52(\*) [(SA627-B5602)]  
M37150EFFF@SSOP42(Renesas) [(PCA7450FP)]  
M37151EFFF@SSOP42(Renesas) [(PCA7450FP)]  
M37160EFFF@SSOP42(Renesas) [(PCA7450FP)]  
M37161EFFF@SSOP42(Renesas) [(PCA7450FP)]  
M37516E6HKP@QFN44(Renesas) [(PCA7446)]  
M37516E6HP@LQFP48(Renesas) [(PCA7419)]  
M37531E4FP@SSOP36 [(SA775)] M37531E8FP@SSOP36 [(SA775)]  
M37540E2FP@SSOP36(Renesas) [(PCA7435FPG02)]  
M37540E2GP@LQFP32(Renesas) [(PCA7435GPG03)]  
M37540E2SP@SDIP32(Renesas) [(PCA7435SPG02)]  
M37540E8FP@SSOP36(Renesas) [(PCA7435FPG02)]  
M37540E8GP@LQFP32(Renesas) [(PCA7435GPG03)]  
M37540E8SP@SDIP32(Renesas) [(PCA7435SPG02)]  
M37544G2(GP)@LQFP32 [(SA663)] M37544G2(SP)@SDIP32 [(SA653)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32 [(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36 [(SA645)]  
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20 [(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SSOP24 [(SA711)]  
M37549G1SP@SDIP24 [(SA653)] M37549G2FP@SSOP24 [(SA711)]  
M37549G2SP@SDIP24 [(SA653)] M37549G3FP@SSOP24 [(SA711)]  
M37549G3SP@SDIP24 [(SA653)]  
M37560EFDFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M37560EFFF@QFN100(Renesas) [(PCA4738L-100A)]  
M37560EFFF@QFP100(Renesas) [(PCA4738F-100A)]

M37560EFGP@LQFP100(Renesas) [(PCA4738G-100A)]  
M37630E4FP@QFP44(Renesas) [(PCA7430)]  
M37630E4FS@QFN80(Renesas) [(PCA7431)]  
M37640E8FP@QFP80(Renesas) [(PCA7440FP)]  
M37640E8FS@QFN80(Renesas) [(PCA7440FS)]  
M37733EHBFP@QFP80(Renesas) [(PCA4774G05)]  
M37733EHBFS@QFN80(Renesas) [(PCA4708G05)]  
M37735EHBFP@QFP80(Renesas) [(PCA4774G05)]  
M37735EHBFS@QFN80(Renesas) [(PCA4708G05)]  
M37736EHBGP@QFP100(Renesas) [(PCA7422GPG02)]  
M37736EHBGS@QFN100(Renesas) [(PCA7422GSG02)]  
M37751E6CFP@QFP80(Renesas) [(PCA4774G05)]  
M37751E6CFS@QFN80(Renesas) [(PCA4708G05)]  
M37751F6CFP@QFP80(Renesas) [(PCA4774G05)]  
M38027E8DFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8DXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8FS@LCC64(Mitsubishi) [(BBBB)]  
M38027E8SP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8SS@DIP64(Mitsubishi) [(BBBB)]  
M38027E8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8-XXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027M8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38039FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38039FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38039FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38049FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38049FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38049FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38223E4FP@QFP80(Renesas) [(PCA4738F-80A)]  
M38223E4FS@QFN80(Renesas) [(PCA4738L-80A)]  
M38223E4GF@QFP80(Renesas) [(PCA4738G-80A)]  
M38223E4HP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38227ECFP@QFP80(Renesas) [(PCA4738F-80A)]  
M38227ECFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38227ECHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38234G4 (FP)@PQFP80 [(SA730+B191)]  
M38234G4 (HP)@TQFP80 [(SA731+B192)]  
M38235G6 (FP)@PQFP80 [(SA730+B191)]  
M38235G6 (HP)@TQFP80 [(SA731+B192)]  
M38238G8 (FP)@PQFP80 [(SA730+B191)]  
M38238G8 (HP)@TQFP80 [(SA731+B192)]  
M38239GC (FP)@PQFP80 [(SA730+B191)]  
M38239GC (HP)@TQFP80 [(SA731+B192)]  
M3823AGF (FP)@PQFP80 [(SA730+B191)]  
M3823AGF (HP)@TQFP80 [(SA731+B192)]  
M38267E8FP@QFP100(Renesas) [(PCA4738F-100A)]  
M38267E8GP@LQFP100(Renesas) [(PCA4738G-100A)]  
M3826AEFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M3826AEFFS@QFN100(Renesas) [(PCA4738L-100A)]  
M3826AEFGP@LQFP100(Renesas) [(PCA4738G-100A)]  
M38503G4A (FP)@SSOP42 [(SA645)] M38503G4A (SP)@SDIP42 [(SA028)]  
M38504E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38504E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38504E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38507F8 (FP)@SSOP42 [(SA645)] M38507F8 (SP)@SDIP42 [(SA028)]  
M38514E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38514E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38514E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38588G6 (FP)@SSOP42 [(SA645)] M38588G6 (SP)@SDIP42 [(SA028)]  
M38588G8 (FP)@SSOP42 [(SA645)] M38588G8 (SP)@SDIP42 [(SA028)]  
M38588GC (FP)@SSOP42 [(SA645)] M38588GC (SP)@SDIP42 [(SA028)]  
M38867E8AFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38867E8AHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38869FFAGP@QFP80(Renesas) [(PCA4738GF-80)]  
M38869FFAHP@LQFP80(Renesas) [(PCA4738HF-80)]  
M38B79FFFP@QFP100(Renesas) [(PCA7438FF-100)]  
M38C13E6FP@LQFP64(Renesas) [(PCA7438F-64A)]  
M38C13E6HP@QFP64(Renesas) [(PCA7438H-64A)]  
M38C89EFP@LQFP144(Renesas) [(PCA7447FP)]  
M38D24G4FP@TQFP64 [(PEP+S625A)] M38D24G4HP@TQFP64 [(PEP+S616)]  
M38D24G6FP@TQFP64 [(PEP+S625A)] M38D24G6HP@TQFP64 [(PEP+S616)]  
M38D28G8FP@TQFP64 [(PEP+S625A)] M38D28G8HP@TQFP64 [(PEP+S616)]  
M38D29GCFP@TQFP64 [(PEP+S625A)] M38D29GCHP@TQFP64 [(PEP+S616)]  
M38D29GFHP@TQFP64 [(PEP+S625A)] M38D29GFHP@TQFP64 [(PEP+S616)]  
M3NN00FETGP@QFP100(\*) [(TA013-B006)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32 (ISP) [ISP-HEADER01]



```
R5F21103DFP@TQFP32 [(SA663+B005)]
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21103FP@TQFP32 [(SA663+B005)]
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]
R5F21104DFP@TQFP32 [(SA663+B005)]
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21104FP@TQFP32 [(SA663+B005)]
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]
R5F21112DFP@TQFP32 [(SA663+B005)]
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21112FP@TQFP32 [(SA663+B005)]
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]
R5F21113DFP@TQFP32 [(SA663+B005)]
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21113FP@TQFP32 [(SA663+B005)]
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFP@TQFP32 [(SA663+B005)]
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FP@TQFP32 [(SA663+B005)]
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FP@TQFP32 [(SA663+B005)]
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FP@TQFP32 [(SA663+B005)]
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FP@TQFP32 [(SA663+B005)]
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FP@TQFP32 [(SA663+B005)]
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FP@TQFP32 [(SA663+B005)]
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FP@TQFP32 [(SA663+B005)]
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]
R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
```

R5F21183DD@SDIP20(single wire) [(SA725-B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026-B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697-B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697-B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026-B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]

R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]

R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697-B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026-B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725-B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026-B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026-B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725-B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026-B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697-B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026-B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725-B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026-B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697-B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026-B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]

R5F211B4DD@SDIP20 [(SA725-B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026-B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697-B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026-B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218KFP@TQFP48 [(SA248-B005)]  
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AJFP@TQFP48 [(SA248-B005)]  
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AKFP@TQFP48 [(SA248-B005)]  
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CJFP@TQFP48 [(SA248-B005)]  
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CKFP@TQFP48 [(SA248-B005)]  
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226JFP@TQFP48 [(SA248-B005)]

```

R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21244SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(single) [(PEP-S673)]
R5F21244SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART) [(PEP+S673)]
R5F21244SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21244SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21244SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single) [(PEP-S673)]
R5F21244SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART) [(PEP+S673)]
R5F21244SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21245SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21245SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(single) [(PEP-S673)]
R5F21245SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]

```

```
R5F21245SDFP@TQFP52(UART) [(PEP+S673)]
R5F21245SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21245SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21245SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(single) [(PEP-S673)]
R5F21245SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(UART) [(PEP+S673)]
R5F21245SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21246SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21246SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single) [(PEP-S673)]
R5F21246SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART) [(PEP+S673)]
R5F21246SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21246SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21246SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single) [(PEP-S673)]
R5F21246SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART) [(PEP+S673)]
R5F21246SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21247SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21247SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single) [(PEP-S673)]
R5F21247SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART) [(PEP+S673)]
R5F21247SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21247SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21247SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single) [(PEP-S673)]
R5F21247SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART) [(PEP+S673)]
R5F21247SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21248SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21248SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single) [(PEP-S673)]
R5F21248SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART) [(PEP+S673)]
R5F21248SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21248SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21248SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single) [(PEP-S673)]
R5F21248SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART) [(PEP+S673)]
R5F21248SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21254SDFP@TQFP52 [(PEP-S673)]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single wire) [(PEP+S673)]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART mode) [(PEP+S673)]
R5F21254SNFP@TQFP52 [(PEP-S673)]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single wire) [(PEP+S673)]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART mode) [(PEP+S673)]
R5F21256SDFP@TQFP52 [(PEP-S673)]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single wire) [(PEP+S673)]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART mode) [(PEP+S673)]
R5F21256SNFP@TQFP52 [(PEP-S673)]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single wire) [(PEP+S673)]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART mode) [(PEP+S673)]
R5F21257SDFP@TQFP52 [(PEP-S673)]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single wire) [(PEP+S673)]
```

R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21257SNFP@TQFP52 [(PEP-S673)]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21258SDFP@TQFP52 [(PEP-S673)]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21258SNFP@TQFP52 [(PEP-S673)]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]



R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]

R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]

```
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single wire) [(SA663)]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART mode) [(SA663)]
R5F21274SKFP@QFP32 [(SA663)]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single wire) [(SA663)]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART mode) [(SA663)]
R5F21274SNFP@QFP32 [(SA663)]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single wire) [(SA663)]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART mode) [(SA663)]
R5F21275DFP@QFP32 [(SA663)]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single wire) [(SA663)]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART mode) [(SA663)]
R5F21275JFP@QFP32 [(SA663)]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single wire) [(SA663)]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART mode) [(SA663)]
R5F21275KFP@QFP32 [(SA663)]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single wire) [(SA663)]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART mode) [(SA663)]
R5F21275NFP@QFP32 [(SA663)]
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single wire) [(SA663)]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART mode) [(SA663)]
R5F21275SDFP@QFP32 [(SA663)]
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(single wire) [(SA663)]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART mode) [(SA663)]
R5F21275SJFP@QFP32 [(SA663)]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single wire) [(SA663)]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART mode) [(SA663)]
R5F21275SKFP@QFP32 [(SA663)]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single wire) [(SA663)]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART mode) [(SA663)]
R5F21275SNFP@QFP32 [(SA663)]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single wire) [(SA663)]
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(UART mode) [(SA663)]
R5F21276DFP@QFP32 [(SA663)]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single wire) [(SA663)]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART mode) [(SA663)]
R5F21276JFP@QFP32 [(SA663)]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single wire) [(SA663)]
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(UART mode) [(SA663)]
R5F21276KFP@QFP32 [(SA663)]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single wire) [(SA663)]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART mode) [(SA663)]
R5F21276NFP@QFP32 [(SA663)]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single wire) [(SA663)]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(UART mode) [(SA663)]
R5F21276SDFP@QFP32 [(SA663)]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single wire) [(SA663)]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART mode) [(SA663)]
R5F21276SJFP@QFP32 [(SA663)]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
```

R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJS@SOIC20 [(SA026)]  
R5F21282SJS@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJS@SOIC20(single wire) [(SA026)]  
R5F21282SJS@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJS@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNP@SOIC20 [(SA026)]  
R5F21282SNP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNP@SOIC20(single wire) [(SA026)]  
R5F21282SNP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJS@SOIC20 [(SA026)]  
R5F21284SJS@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJS@SOIC20(single wire) [(SA026)]

R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64 [(SA768-B251)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(single wire) [(SA768-B251)]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SDFP@TQFP64 [(SA732-B251)]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single wire) [(SA732-B251)]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A7SNFA@TQFP64 [(SA768-B251)]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single wire) [(SA768-B251)]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SNFP@TQFP64 [(SA732-B251)]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single wire) [(SA732-B251)]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SDFA@TQFP64 [(SA768-B251)]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single wire) [(SA768-B251)]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SDFP@TQFP64 [(SA732-B251)]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single wire) [(SA732-B251)]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SNFA@TQFP64 [(SA768-B251)]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single wire) [(SA768-B251)]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SNFP@TQFP64 [(SA732-B251)]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single wire) [(SA732-B251)]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASDFA@TQFP64 [(SA768-B251)]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single wire) [(SA768-B251)]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASDFP@TQFP64 [(SA732-B251)]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single wire) [(SA732-B251)]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASNFA@TQFP64 [(SA768-B251)]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single wire) [(SA768-B251)]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASNFP@TQFP64 [(SA732-B251)]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single wire) [(SA732-B251)]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSDFA@TQFP64 [(SA768-B251)]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single wire) [(SA768-B251)]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSDFP@TQFP64 [(SA732-B251)]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single wire) [(SA732-B251)]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART mode) [(SA732+B251)]

R5F212ACSNFA@TQFP64 [(SA768-B251)]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single wire) [(SA768-B251)]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSNFP@TQFP64 [(SA732-B251)]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single wire) [(SA732-B251)]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SDFA@TQFP64 [(SA768-B251)]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SDFP@TQFP64 [(SA732-B251)]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SNFA@TQFP64 [(SA768-B251)]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SNFP@TQFP64 [(SA732-B251)]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SDFA@TQFP64 [(SA768-B251)]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SDFP@TQFP64 [(SA732-B251)]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SNFA@TQFP64 [(SA768-B251)]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SNFP@TQFP64 [(SA732-B251)]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASDFA@TQFP64 [(SA768-B251)]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASDFP@TQFP64 [(SA732-B251)]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASNFA@TQFP64 [(SA768-B251)]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASNFP@TQFP64 [(SA732-B251)]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSDFA@TQFP64 [(SA768-B251)]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSDFP@TQFP64 [(SA732-B251)]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSNFA@TQFP64 [(SA768-B251)]

R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSNFP@TQFP64 [(SA732-B251)]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212C7SDFP@TQFP80 [(SA731-B249)]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single wire) [(SA731-B249)]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C7SNFP@TQFP80 [(SA731-B249)]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single wire) [(SA731-B249)]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SDFP@TQFP80 [(SA731-B249)]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single wire) [(SA731-B249)]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SNFP@TQFP80 [(SA731-B249)]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single wire) [(SA731-B249)]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASDFP@TQFP80 [(SA731-B249)]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single wire) [(SA731-B249)]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASNFP@TQFP80 [(SA731-B249)]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single wire) [(SA731-B249)]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSDFP@TQFP80 [(SA731-B249)]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single wire) [(SA731-B249)]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSNFP@TQFP80 [(SA731-B249)]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single wire) [(SA731-B249)]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SDFP@TQFP80 [(SA731-B249)]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SNFP@TQFP80 [(SA731-B249)]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SDFP@TQFP80 [(SA731-B249)]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SNFP@TQFP80 [(SA731-B249)]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASDFP@TQFP80 [(SA731-B249)]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASNFP@TQFP80 [(SA731-B249)]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSDFP@TQFP80 [(SA731-B249)]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]



R5F212DCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSNFP@TQFP80 [(SA731-B249)]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026-B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H1SNSP@TSSOP20 [(SA026-B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SDSP@TSSOP20 [(SA725-B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212H2SNSP@TSSOP20 [(SA725-B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SDSP@TSSOP20 [(SA026-B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J0SNSP@TSSOP20 [(SA026-B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J1SDSP@TSSOP20 [(SA026-B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)]  
R5F212J1SNSP@TSSOP20 [(SA026-B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)]  
R5F212K2SDFP@QFP32 [(SA663-B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K2SNFP@QFP32 [(SA663-B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]  
R5F212K4SDFP@QFP32 [(SA663-B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]  
R5F212K4SNFP@QFP32 [(SA663-B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]  
R5F212L2SDFP@QFP32 [(SA663-B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L2SNFP@QFP32 [(SA663-B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SDFP@QFP32 [(SA663-B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SNFP@QFP32 [(SA663-B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]  
R5F363A6DFA@PQFP100 (\*) [(TA012-B006)]  
R5F363A6DFB@PQFP100 (\*) [(TA013-B006)]  
R5F363A6NFA@PQFP100 (\*) [(TA012-B006)]  
R5F363A6NFB@PQFP100 (\*) [(TA013-B006)]  
R5F363AEDFA@PQFP100 (\*) [(TA012-B006)]  
R5F363AEDFB@PQFP100 (\*) [(TA013-B006)]  
R5F363AENFA@PQFP100 (\*) [(TA012-B006)]

```

R5F363AENFB@PQFP100 (*) [(TA013-B006)]
R5F363AKDFA@PQFP100 (*) [(TA012-B006)]
R5F363AKDFB@PQFP100 (*) [(TA013-B006)]
R5F363AKNFA@PQFP100 (*) [(TA012-B006)]
R5F363AKNFB@PQFP100 (*) [(TA013-B006)]
R5F363AMDFA@PQFP100 (*) [(TA012-B006)]
R5F363AMDFB@PQFP100 (*) [(TA013-B006)]
R5F363AMNFA@PQFP100 (*) [(TA012-B006)]
R5F363AMNFB@PQFP100 (*) [(TA013-B006)]
R5F36406DFA@PQFP100 (*) [(TA012-B006)]
R5F36406DFB@PQFP100 (*) [(TA013-B006)]
R5F36406NFA@PQFP100 (*) [(TA012-B006)]
R5F36406NFB@PQFP100 (*) [(TA013-B006)]
R5F3640DDFA@PQFP100 (*) [(TA012-B006)]
R5F3640DDFB@PQFP100 (*) [(TA013-B006)]
R5F3640DNFA@PQFP100 (*) [(TA012-B006)]
R5F3640DNFB@PQFP100 (*) [(TA013-B006)]
R5F3640MDFA@PQFP100 (*) [(TA012-B006)]
R5F3640MDFB@PQFP100 (*) [(TA013-B006)]
R5F3640MNFA@PQFP100 (*) [(TA012-B006)]
R5F3640MNFB@PQFP100 (*) [(TA013-B006)]
R5F364A6DFA@PQFP100 (*) [(TA012-B006)]
R5F364A6DFB@PQFP100 (*) [(TA013-B006)]
R5F364A6NFA@PQFP100 (*) [(TA012-B006)]
R5F364A6NFB@PQFP100 (*) [(TA013-B006)]
R5F364AEDFA@PQFP100 (*) [(TA012-B006)]
R5F364AEDFB@PQFP100 (*) [(TA013-B006)]
R5F364AENFA@PQFP100 (*) [(TA012-B006)]
R5F364AENFB@PQFP100 (*) [(TA013-B006)]
R5F364AMDFA@PQFP100 (*) [(TA012-B006)]
R5F364AMDFB@PQFP100 (*) [(TA013-B006)]
R5F364AMNFA@PQFP100 (*) [(TA012-B006)]
R5F364AMNFB@PQFP100 (*) [(TA013-B006)]
R5F36506DFA@PQFP100 (*) [(TA012-B006)]
R5F36506DFB@PQFP100 (*) [(TA013-B006)]
R5F36506NFA@PQFP100 (*) [(TA012-B006)]
R5F36506NFB@PQFP100 (*) [(TA013-B006)]
R5F3650EDFA@PQFP100 (*) [(TA012-B006)]
R5F3650EDFB@PQFP100 (*) [(TA013-B006)]
R5F3650ENFA@PQFP100 (*) [(TA012-B006)]
R5F3650ENFB@PQFP100 (*) [(TA013-B006)]
R5F3650KDFA@PQFP100 (*) [(TA012-B006)]
R5F3650KDFB@PQFP100 (*) [(TA013-B006)]
R5F3650KNFA@PQFP100 (*) [(TA012-B006)]
R5F3650KNFB@PQFP100 (*) [(TA013-B006)]
R5F3650MDFA@PQFP100 (*) [(TA012-B006)]
R5F3650MDFB@PQFP100 (*) [(TA013-B006)]
R5F3650MNFA@PQFP100 (*) [(TA012-B006)]
R5F3650MNFB@PQFP100 (*) [(TA013-B006)]
R5F3650NDFA@PQFP100 (*) [(TA012-B006)]
R5F3650NDFB@PQFP100 (*) [(TA013-B006)]
R5F3650NNFA@PQFP100 (*) [(TA012-B006)]
R5F3650NNFB@PQFP100 (*) [(TA013-B006)]
R5F3650RDFA@PQFP100 (*) [(TA012-B006)]
R5F3650RDFB@PQFP100 (*) [(TA013-B006)]
R5F3650RNFA@PQFP100 (*) [(TA012-B006)]
R5F3650RNFB@PQFP100 (*) [(TA013-B006)]
R5F3650TDFA@PQFP100 (*) [(TA012-B006)]
R5F3650TDFB@PQFP100 (*) [(TA013-B006)]
R5F3650TNFA@PQFP100 (*) [(TA012-B006)]
R5F3650TNFB@PQFP100 (*) [(TA013-B006)]
R5F3651EDFC@PQFP128 (*) [(SA720-B228)]
R5F3651ENFC@PQFP128 (*) [(SA720-B228)]
R5F3651KDFC@PQFP128 (*) [(SA720-B228)]
R5F3651KNFC@PQFP128 (*) [(SA720-B228)]
R5F3651MDFC@PQFP128 (*) [(SA720-B228)]
R5F3651MNFC@PQFP128 (*) [(SA720-B228)]
R5F3651NDFC@PQFP128 (*) [(SA720-B228)]
R5F3651NNFC@PQFP128 (*) [(SA720-B228)]
R5F3651RDFC@PQFP128 (*) [(SA720-B228)]
R5F3651RNFC@PQFP128 (*) [(SA720-B228)]
R5F3651TDFC@PQFP128 (*) [(SA720-B228)]
R5F3651TNFC@PQFP128 (*) [(SA720-B228)]

```

## MMI

### PLD

PLS167	PLS167@PLCC28 [(SA008A)]
PLS167A	PLS167A@PLCC28 [(SA008A)]
PLS167B	PLS167B@PLCC28 [(SA008A)]
PLS168	PLS168@PLCC28 [(SA008A)]
PLS168A	PLS168A@PLCC28 [(SA008A)]
PLS168B	PLS168B@PLCC28 [(SA008A)]

## MOSEL-VITELIC

### E(E) PROM/FRAM/NVRAM

V29C31004B	V29C31004B@PLCC32 [(SA015A1T)]
V29C31004B@TSOP32 [(SA410T)]	V29C31004T
V29C31004T@PLCC32 [(SA015A1T)]	V29C31004T@TSOP32 [(SA410T)]
V29C51000B	V29C51000B@PLCC32 [(SA015A1T)]
V29C51000T	V29C51000T@PLCC32 [(SA015A1T)]
V29C51001B	V29C51001B@PLCC32 [(SA015A1T)]
V29C51001B@TSOP32 [(SA410T)]	V29C51001T
V29C51001T@PLCC32 [(SA015A1T)]	V29C51001T@TSOP32 [(SA410T)]
V29C51002B	V29C51002B@PLCC32 [(SA015A1T)]
V29C51002B@TSOP32 [(SA410T)]	V29C51002T
V29C51002T@PLCC32 [(SA015A1T)]	V29C51002T@TSOP32 [(SA410T)]
V29C51004B	V29C51004B@PLCC32 [(SA015A1T)]
V29C51004B@TSOP32 [(SA410T)]	V29C51004T
V29C51004T@PLCC32 [(SA015A1T)]	V29C51004T@TSOP32 [(SA410T)]
V29LC51000	V29LC51000@PLCC32 [(SA015A1T)]
V29LC51001	V29LC51001@PLCC32 [(SA015A1T)]
V29LC51002	V29LC51002@PLCC32 [(SA015A1T)]

### MICROCONTROLLER

MSU1958	MSU1958@PLCC44 [(SA244)]
MSU1958@TQFP44 [(SA245A)]	MSU2952
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44 [(SA245A)]
MSU2958	MSU2958@PLCC44 [(SA244)]
MSU2958@TQFP44 [(SA245A)]	MSU2964
MSU2964@PLCC44 [(SA244)]	MSU2964@TQFP44 [(SA245A)]

## MOSTEK

### E(E) PROM/FRAM/NVRAM

ET2716	ETC2716
ETC2732	MK2716
MK2764	MK48C02
MK48C12	MK48T02
MK48T08	MK48T12
MK48T12B	MK48T18
MK48Z02	MK48Z08
MK48Z12	MK48Z12B
MK48Z18	

## MOTOROLA

### E(E) PROM/FRAM/NVRAM

MC68764	MC68766
MCM2716	

### DRAM & SRAM

MCM2018A	MCM2018A@PLCC32 [(SA015A1T)]
MCM60256A	MCM60256A@SOIC28 [(SA630)]
MCM60256AC	MCM60256AC@SOIC28 [(SA630)]
MCM60256AV	MCM60256AV@SOIC28 [(SA630)]
MCM60L256A	MCM60L256A@SOIC28 [(SA630)]
MCM60L256AC	MCM60L256AC@SOIC28 [(SA630)]
MCM60L256AV	MCM60L256AV@SOIC28 [(SA630)]
MCM6206	MCM6206@SOIC28 [(SA630)]

MCM6206C	MCM6206C@SOIC28 [(SA630)]
MCM6207	MCM6207@SOJ24 [(SA646)]
MCM6207C	MCM6207C@SOJ24 [(SA646)]
MCM6208	MCM6208@SOJ24 [(SA646)]
MCM6208C	MCM6208C@SOJ24 [(SA646)]
MCM6209	MCM6209@SOJ28 [(SA646)]
MCM6209C	MCM6209C@SOJ28 [(SA646)]
MCM6229	MCM6229(300m)@SOJ28 [(SA646)]
MCM6229(400m)@SOJ28 [(SA661)]	MCM6229A
MCM6229A(300m)@SOJ28 [(SA646)]	MCM6229A(400m)@SOJ28 [(SA661)]
MCM6264	MCM6264@SOIC28 [(SA630)]
MCM6264C	MCM6264C@SOIC28 [(SA630)]
MCM6268	MCM6269
MCM6287	MCM6287@SOJ24 [(SA646)]
MCM6288	MCM6288@SOJ22 [(SA646)]
MCM6288B	MCM6288B@SOJ22 [(SA646)]
MCM6288C	MCM6288C@SOJ22 [(SA646)]
MCM6290	MCM6290@SOJ24 [(SA646)]
MCM6290B	MCM6290B@SOJ24 [(SA646)]
MCM6290C	MCM6290C@SOJ24 [(SA646)]
MCM62L07	MCM62L07@SOJ24 [(SA646)]
MCM62L08	MCM62L08@SOJ24 [(SA646)]
MCM62L09	MCM62L09@SOJ28 [(SA646)]
MCM6706	MCM6706@SOIC28 [(SA630)]
MCM6706A	MCM6706A@SOJ28 [(SA646)]
MCM6708A	MCM6708A@SOJ24 [(SA646)]
MCM6709A	MCM6709A@SOJ28 [(SA646)]

## MICROCONTROLLER

68HC711E9MFN2@PLCC52(*) [(SA647-B5202)]	
68HC711E9MFNE2@PLCC52(*) [(SA647-B5202)]	
68HC711E9VFN2@PLCC52(*) [(SA647-B5202)]	
68HC711E9VFNE2@PLCC52(*) [(SA647-B5202)]	
DSP56F801(FA60)@TQFP48 [(SA248)]	
DSP56F801(FA60E)@TQFP48 [(SA248)]	
DSP56F801(FA80)@TQFP48 [(SA248)]	
DSP56F801(FA80E)@TQFP48 [(SA248)]	
DSP56F802(TA60)@TQFP32 [(SA663)]	
DSP56F802(TA60E)@TQFP32 [(SA663)]	
DSP56F802(TA80)@TQFP32 [(SA663)]	
DSP56F802(TA80E)@TQFP32 [(SA663)]	
DSP56F803(BU80)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F803(BU80E)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F805(FV80)@TQFP144(JTAG) [ISP-HEADER01]	
DSP56F805(FV80E)@TQFP144(JTAG) [ISP-HEADER01]	
DSP56F807(PY80)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F807(PY80E)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F807(VF80)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F807(VF80E)@LQFP160(JTAG) [ISP-HEADER01]	
DSP56F826(BU80)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F826(BU80E)@TQFP100(JTAG) [ISP-HEADER01]	
DSP56F827(FG80)@TQFP128(JTAG) [ISP-HEADER01]	
DSP56F827(FG80E)@TQFP128(JTAG) [ISP-HEADER01]	
MC56F8011VF AE@QFP32 [(SA663+B005)]	
MC56F8013VF AE@QFP32 [(SA663+B005)]	
MC56F8014VF AE@QFP32 [(SA663+B005)]	
MC56F8023MFAE@QFP32 [(SA663+B005)]	
MC56F8023VF AE@QFP32 [(SA663+B005)]	
MC56F8025VLD@QFP44 [(SA245A+B005)]	
MC56F8036MFAE@QFP48 [(SA248+B005)]	
MC56F8036VF AE@QFP48 [(SA248+B005)]	
MC56F8037VLH@QFP64 [(PEP+S616)]	
MC56F8122VFA@TQFP48 [(SA248+B005)]	
MC56F8122VF AE@TQFP48 [(SA248+B005)]	
MC56F8123VFB@TQFP64 [(PEP+S616)]	
MC56F8123VFB E@TQFP64 [(PEP+S616)]	
MC56F8322MFA60@TQFP48 [(SA248+B005)]	
MC56F8322MFAE@TQFP48 [(SA248+B005)]	
MC56F8322VFA60@TQFP48 [(SA248+B005)]	
MC56F8322VF AE@TQFP48 [(SA248+B005)]	
MC56F8323MFB60@TQFP64 [(PEP+S616)]	
MC56F8323MFB E@TQFP64 [(PEP+S616)]	
MC56F8323VFB60@TQFP64 [(PEP+S616)]	
MC56F8323VFB E@TQFP64 [(PEP+S616)]	
MC68705R3	MC68705R5
MC68705U3	MC68705U5
MC68HC11A0	MC68HC11A0@PLCC52 [(PEP+S415T)]
MC68HC11A1	MC68HC11A1@PLCC52 [(PEP+S415T)]

MC68HC11A8 MC68HC11A8@PLCC52 [(PEP+S415T)]  
 MC68HC11E1@PLCC52 [(PEP+S415T)]  
 MC68HC11E1@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E1@QFP52 [(PEP+S673)] MC68HC11E20@PLCC52 [(PEP+S415T)]  
 MC68HC11E20@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E20@QFP52 [(PEP+S673)] MC68HC11E9@PLCC52 [(PEP+S415T)]  
 MC68HC11E9@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E9@QFP52 [(PEP+S673)] MC68HC11F1@PLCC68 [(PEP+S414T)]  
 MC68HC11K1@PLCC84 [(PEP+S416T)]  
 MC68HC11K1@TQFP80(\*) [(TA031-B006)]  
 MC68HC11P1@PLCC84(\*) [(SA649-B8405)]  
 MC68HC705B16@PLCC52 [(PEP+S415T)]  
 MC68HC705B16@TQFP64 [(PEP+S625A)]  
 MC68HC705B16@TQFP64(\*) [(SA668+B204)]  
 MC68HC705B16N@PLCC52 [(PEP+S415T)]  
 MC68HC705B16N@TQFP64 [(PEP+S625A)]  
 MC68HC705B16N@TQFP64(\*) [(SA668+B204)]  
 MC68HC705B5@PLCC52 [(PEP+S415T)] MC68HC705C4  
 MC68HC705C4@PLCC44 [(SA244)] MC68HC705C4A  
 MC68HC705C4A@PLCC44 [(SA244)] MC68HC705C8  
 MC68HC705C8@PLCC44 [(SA244)] MC68HC705C8@SDIP42 [SA028]  
 MC68HC705C8@TQFP44 [(SA245A)] MC68HC705C8A  
 MC68HC705C8A@PLCC44 [(SA244)] MC68HC705C8A@SDIP42 [SA028]  
 MC68HC705C8A@TQFP44 [(SA245A)] MC68HC705C9A  
 MC68HC705C9A@PLCC44 [(SA244)] MC68HC705C9A@TQFP44 [(SA245A)]  
 MC68HC705J1A(CDW)@SOIC20 [(SA404)]  
 MC68HC705J1A(CSD)@SSOP20 [(SA626A)]  
 MC68HC705J1A(P) MC68HC705J2(Emulation)  
 MC68HC705J2(Emulation)@SOIC20 [(SA404)]  
 MC68HC705J2(Emulation)@SSOP20 [(SA626A)]  
 MC68HC705J2(Native)  
 MC68HC705J2(Native)@SOIC20 [(SA404)]  
 MC68HC705J2(Native)@SSOP20 [(SA626A)]  
 MC68HC705KJ1 MC68HC705KJ1@SOIC16 [(SA404)]  
 MC68HC705P6(CDW)@SOIC28 [(SA404)]  
 MC68HC705P6(CP)  
 MC68HC705P6A(CDW)@SOIC28 [(SA404)]  
 MC68HC705P6A(CP) MC68HC705P9  
 MC68HC705P9@SOIC28 [(SA404)] MC68HC705SR3  
 MC68HC705SR3@SDIP42 [(SA028)] MC68HC705SR3@TQFP44 [(SA245A)]  
 MC68HC711D3 MC68HC711D3@PLCC44 [(SA244)]  
 MC68HC711D3@TQFP44 [(SA675)]  
 MC68HC711E20@PLCC52 [(PEP+S415T)]  
 MC68HC711E20@TQFP64 [(PEP+S625A)]  
 MC68HC711E9(4.5V)@PLCC52 [(SA647-B5202)]  
 MC68HC711E9@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711E9CFN(4.5V)@PLCC52 [(SA647-B5202)]  
 MC68HC711E9CFN2@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711E9CFN3@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711E9CFNE2@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711E9CFNE3@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711E9-FN@PLCC52(\*) [(SA647-B5202)]  
 MC68HC711K4@PLCC84 [(PEP+S416T)]  
 MC68HC711K4@TQFP80(\*) [(TA031-B006)]  
 MC68HC711KA2@PLCC68 [(PEP+S414T)]  
 MC68HC711KA4@PLCC68 [(PEP+S414T)]  
 MC68HC711KS2@PLCC68 [(PEP+S414T)]  
 MC68HC711L6@TQFP64 [(SA668+B188)]  
 MC68HC711P2@PLCC84(\*) [(SA649-B8405)]  
 MC68HC811E2@PLCC52 [(PEP+S415T)] MC68HC811E2CP2  
 MC68HC811E2MP2 MC68HC811E2P2  
 MC68HC811E2VP2  
 MC68HC812A4CPV@TQFP112(\*) [(SA719+B210)]  
 MC68HC812A4CPVE@TQFP112(\*) [(SA719+B210)]  
 MC68HC812A4MPV@TQFP112(\*) [(SA719+B210)]  
 MC68HC812A4MPVE@TQFP112(\*) [(SA719+B210)]  
 MC68HC908AB32CFU@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AB32MFU@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
 MC68HC908AP16CB@SDIP42 [(SA028)]  
 MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
 MC68HC908AP16CFA@LQFP48 [(SA248)]  
 MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP16CFB@TQFP44 [(SA675)]  
 MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
 MC68HC908AP32CB@SDIP42 [(SA028)]  
 MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
 MC68HC908AP32CFA@LQFP48 [(SA248)]  
 MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP32CFB@TQFP44 [(SA675)]  
 MC68HC908AP64CB@SDIP42 [(SA028)]

MC68HC908AP64CFA@LQFP48 [(SA248)]  
 MC68HC908AP64CFB@TQFP44 [(SA675)]  
 MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
 MC68HC908AP8CB@SDIP42 [(SA028)]  
 MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]  
 MC68HC908AP8CFA@LQFP48 [(SA248)]  
 MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP8CFB@TQFP44 [(SA675)]  
 MC68HC908AS32A(CFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS32A(MFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS32A(VFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(CFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60(MFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60(VFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60A(CFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60A(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60A(MFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60A(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60A(VFN)@PLCC52 [(PEP+S415T)]  
 MC68HC908AS60A(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ32A(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ32A(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ32A(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60A(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60A(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60A(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908BD48IB@SDIP42 [(SA028)]  
 MC68HC908BD48IFB@TQFP44 [(SA675)]  
 MC68HC908EY16CFA@TQFP32 [(SA663)]  
 MC68HC908EY16MFA@TQFP32 [(SA663)]  
 MC68HC908EY16VFA@TQFP32 [(SA663)]  
 MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32 [(SA663)]  
 MC68HC908EY8VFA@TQFP32 [(SA663)] MC68HC908GP32  
 MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44 [(SA675)]  
 MC68HC908GR16CFA@TQFP48 [(SA248)]  
 MC68HC908GR16CFJ@TQFP32 [(SA663)]  
 MC68HC908GR16MFA@TQFP48 [(SA248)]  
 MC68HC908GR16MFJ@TQFP32 [(SA663)]  
 MC68HC908GR16VFA@TQFP48 [(SA248)]  
 MC68HC908GR16VFJ@TQFP32 [(SA663)]  
 MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32 [(SA663)]  
 MC68HC908GR4CP MC68HC908GR4MDW@SOIC28 [(SA404)]  
 MC68HC908GR4MFA@TQFP32 [(SA663)] MC68HC908GR4MP  
 MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32 [(SA663)]  
 MC68HC908GR4VP MC68HC908GR8CDW@SOIC28 [(SA404)]  
 MC68HC908GR8CFA@TQFP32 [(SA663)] MC68HC908GR8CP  
 MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32 [(SA663)]  
 MC68HC908GR8MP MC68HC908GR8VDW@SOIC28 [(SA404)]  
 MC68HC908GR8VFA@TQFP32 [(SA663)] MC68HC908GR8VP  
 MC68HC908GT16@SDIP42 [(SA028)] MC68HC908GT16@TQFP44 [(SA675)]  
 MC68HC908GT8CB@SDIP42 [(SA028)] MC68HC908GT8CFB@TQFP44 [(SA675)]  
 MC68HC908GZ16(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ16(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ16(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ16(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ16(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ16(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(VFJ)@TQFP32 [(SA663)]

MC68HC908GZ8 (CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8 (CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8 (MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8 (MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8 (VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8 (VFJ)@TQFP32 [(SA663)]  
 MC68HC908JB12 (DW)@SOIC28 [(SA404)]  
 MC68HC908JB12 (JDW)@SOIC20 [(SA404)]  
 MC68HC908JB16 (DW)@SOIC28 [(SA404)]  
 MC68HC908JB16 (FA)@QFP32 [(SA663)]  
 MC68HC908JB16 (JDW)@SOIC20 [(SA404)]  
 MC68HC908JB8  
 MC68HC908JB8@SOIC28 [(SA404)]  
 MC68HC908JK1CDW@SOIC20 [(SA404)]  
 MC68HC908JK1ECDW@SOIC20 [(SA404)]  
 MC68HC908JK1ECP  
 MC68HC908JK1EMDW@SOIC20 [(SA404)]  
 MC68HC908JK1EMP  
 MC68HC908JK1MP  
 MC68HC908JK3CP  
 MC68HC908JK3ECDW@SOIC20 [(SA404)]  
 MC68HC908JK3ECP  
 MC68HC908JK3EMDW@SOIC20 [(SA404)]  
 MC68HC908JK3EMP  
 MC68HC908JK3MP  
 MC68HC908JK8@SOIC20 [(SA404)]  
 MC68HC908JL3CFA@TQFP48 [(SA248)]  
 MC68HC908JL3ECDW@SOIC28 [(SA404)]  
 MC68HC908JL3ECFA@TQFP48 [(SA248)]  
 MC68HC908JL3ECP  
 MC68HC908JL3EMDW@SOIC28 [(SA404)]  
 MC68HC908JL3EMFA@TQFP48 [(SA248)]  
 MC68HC908JL3EMP  
 MC68HC908JL3MFA@TQFP48 [(SA248)]  
 MC68HC908JL8 (dip20)  
 MC68HC908JL8@LQFP32 [(SA663)]  
 MC68HC908JL8@SOIC20 [(SA404)]  
 MC68HC908KX2 (CDW)@SOIC16 [(SA404)]  
 MC68HC908KX2 (CP)  
 MC68HC908KX2 (MDW)@SOIC16 [(SA404)]  
 MC68HC908KX2 (MP)  
 MC68HC908KX2 (VDW)@SOIC16 [(SA404)]  
 MC68HC908KX2 (VP)  
 MC68HC908KX8 (CDW)@SOIC16 [(SA404)]  
 MC68HC908KX8 (CP)  
 MC68HC908KX8 (MDW)@SOIC16 [(SA404)]  
 MC68HC908KX8 (MP)  
 MC68HC908KX8 (VDW)@SOIC16 [(SA404)]  
 MC68HC908KX8 (VP)  
 MC68HC908LB8CDWE@SOIC20 [(SA404)]  
 MC68HC908LB8CPE  
 MC68HC908LB8MDWE (S)@SOIC20  
 MC68HC908LB8MDWE@SOIC20 [(SA404)]  
 MC68HC908LB8MPE  
 MC68HC908LB8VDWE (S)@SOIC20  
 MC68HC908LB8VDWE@SOIC20 [(SA404)]  
 MC68HC908LB8VPE  
 MC68HC908LD60IFU@QFP64 [(PEP+S625)]  
 MC68HC908LD64IFU@QFP64 [(PEP+S625)]  
 MC68HC908LJ12CFB@TQFP52 [(PEP-S673)]  
 MC68HC908LJ12CFBE@TQFP52 [(PEP-S673)]  
 MC68HC908LJ12CFU@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ12CFU@TQFP64 (\*) [(SA757-B331)]  
 MC68HC908LJ12CFUE@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ12CFUE@TQFP64 (\*) [(SA757-B331)]  
 MC68HC908LJ12CPB@TQFP64 [(PEP-S616)]  
 MC68HC908LJ12CPBE@TQFP64 [(PEP-S616)]  
 MC68HC908LJ24CFQ@TQFP80 [(PEP-S615B)]  
 MC68HC908LJ24CFQE@TQFP80 [(PEP-S615B)]  
 MC68HC908LJ24CFU@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ24CFU@TQFP64 (\*) [(SA757-B331)]  
 MC68HC908LJ24CFUE@TQFP64 [(PEP-S625A)]  
 MC68HC908LJ24CFUE@TQFP64 (\*) [(SA757-B331)]  
 MC68HC908LJ24CPB@TQFP64 [(PEP-S616)]  
 MC68HC908LJ24CPBE@TQFP64 [(PEP-S616)]  
 MC68HC908LJ24CPK@TQFP80 [(PEP-S640B)]  
 MC68HC908LJ24CPKE@TQFP80 [(PEP-S640B)]  
 MC68HC908LK24CFQ@TQFP80 [(PEP-S615B)]  
 MC68HC908LK24CFQE@TQFP80 [(PEP-S615B)]  
 MC68HC908LK24CFU@TQFP64 [(PEP-S625A)]  
 MC68HC908LK24CFU@TQFP64 (\*) [(SA757-B331)]

MC68HC908JB8@SOIC20 [(SA404)]  
 MC68HC908JB8@TQFP44 [(SA675)]  
 MC68HC908JK1CP  
 MC68HC908JK1MDW@SOIC20 [(SA404)]  
 MC68HC908JK3CDW@SOIC20 [(SA404)]  
 MC68HC908JK3MDW@SOIC20 [(SA404)]  
 MC68HC908JK8  
 MC68HC908JL3CDW@SOIC28 [(SA404)]  
 MC68HC908JL3CP  
 MC68HC908JL3MDW@SOIC28 [(SA404)]  
 MC68HC908JL3MP  
 MC68HC908JL8 (dip28)  
 MC68HC908JL8@SDIP32 [(SA653)]  
 MC68HC908JL8@SOIC28 [(SA404)]

MC68HC908LB8CDWE (S)@SOIC20  
 MC68HC908LB8CPE (S)  
 MC68HC908LB8MPE (S)  
 MC68HC908LB8VPE (S)

MC68HC908LK24CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LK24CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CPB@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPK@TQFP80 [(PEP-S640B)]  
MC68HC908LK24CPKE@TQFP80 [(PEP-S640B)]  
MC68HC908LV8CPBE@TQFP52 [(PEP+S673)]  
MC68HC908MR16(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(CB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR16(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR16(CFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908MR16(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(VB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR16(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR16(VFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(CB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(CFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(VB)@SDIP56(\*) [(SA627+B5604)]  
MC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(VFU)@TQFP64(\*) [(SA757+B331)]  
MC68HC908QB4(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(CDW)@SOIC16 [(SA404)]  
MC68HC908QB4(CP)  
MC68HC908QB4(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(MDW)@SOIC16 [(SA404)]  
MC68HC908QB4(MP)  
MC68HC908QB4(VDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(VDW)@SOIC16 [(SA404)]  
MC68HC908QB4(VP)  
MC68HC908QB8(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(CDW)@SOIC16 [(SA404)]  
MC68HC908QB8(CP)  
MC68HC908QB8(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(MDW)@SOIC16 [(SA404)]  
MC68HC908QB8(MP)  
MC68HC908QB8(VDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(VDW)@SOIC16 [(SA404)]  
MC68HC908QB8(VP)  
MC68HC908QC16(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDX)@SOIC16 [(SA404)]  
MC68HC908QC16(CDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(CDY)@SOIC20 [(SA404)]  
MC68HC908QC16(CDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(CDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(CDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(MDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDX)@SOIC16 [(SA404)]  
MC68HC908QC16(MDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(MDY)@SOIC20 [(SA404)]  
MC68HC908QC16(MDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(MDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(MDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(VDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDX)@SOIC16 [(SA404)]  
MC68HC908QC16(VDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(VDY)@SOIC20 [(SA404)]  
MC68HC908QC16(VDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(VDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(VDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDSE)@TSSOP20 [(SA643)]



MC68HC908QC4 (CDT)@TSSOP16 [(SA643)]  
 MC68HC908QC4 (CDTE)@TSSOP16 [(SA643)]  
 MC68HC908QC4 (CDX)@SOIC16 [(SA404)]  
 MC68HC908QC4 (CDXE)@SOIC16 [(SA404)]  
 MC68HC908QC4 (CDY)@SOIC20 [(SA404)]  
 MC68HC908QC4 (CDYE)@SOIC20 [(SA404)]  
 MC68HC908QC4 (CDZ)@SOIC28 [(SA404)]  
 MC68HC908QC4 (CDZE)@SOIC28 [(SA404)]  
 MC68HC908QC4 (MDR)@TSSOP28 [(SA643)]  
 MC68HC908QC4 (MDRE)@TSSOP28 [(SA643)]  
 MC68HC908QC4 (MDS)@TSSOP20 [(SA643)]  
 MC68HC908QC4 (MDSE)@TSSOP20 [(SA643)]  
 MC68HC908QC4 (MDT)@TSSOP16 [(SA643)]  
 MC68HC908QC4 (MDTE)@TSSOP16 [(SA643)]  
 MC68HC908QC4 (MDX)@SOIC16 [(SA404)]  
 MC68HC908QC4 (MDXE)@SOIC16 [(SA404)]  
 MC68HC908QC4 (MDY)@SOIC20 [(SA404)]  
 MC68HC908QC4 (MDYE)@SOIC20 [(SA404)]  
 MC68HC908QC4 (MDZ)@SOIC28 [(SA404)]  
 MC68HC908QC4 (MDZE)@SOIC28 [(SA404)]  
 MC68HC908QC4 (VDR)@TSSOP28 [(SA643)]  
 MC68HC908QC4 (VDRE)@TSSOP28 [(SA643)]  
 MC68HC908QC4 (VDS)@TSSOP20 [(SA643)]  
 MC68HC908QC4 (VDSE)@TSSOP20 [(SA643)]  
 MC68HC908QC4 (VDT)@TSSOP16 [(SA643)]  
 MC68HC908QC4 (VDTE)@TSSOP16 [(SA643)]  
 MC68HC908QC4 (VDX)@SOIC16 [(SA404)]  
 MC68HC908QC4 (VDXE)@SOIC16 [(SA404)]  
 MC68HC908QC4 (VDY)@SOIC20 [(SA404)]  
 MC68HC908QC4 (VDYE)@SOIC20 [(SA404)]  
 MC68HC908QC4 (VDZ)@SOIC28 [(SA404)]  
 MC68HC908QC4 (VDZE)@SOIC28 [(SA404)]  
 MC68HC908QC8 (CDR)@TSSOP28 [(SA643)]  
 MC68HC908QC8 (CDRE)@TSSOP28 [(SA643)]  
 MC68HC908QC8 (CDS)@TSSOP20 [(SA643)]  
 MC68HC908QC8 (CDSE)@TSSOP20 [(SA643)]  
 MC68HC908QC8 (CDT)@TSSOP16 [(SA643)]  
 MC68HC908QC8 (CDTE)@TSSOP16 [(SA643)]  
 MC68HC908QC8 (CDX)@SOIC16 [(SA404)]  
 MC68HC908QC8 (CDXE)@SOIC16 [(SA404)]  
 MC68HC908QC8 (CDY)@SOIC20 [(SA404)]  
 MC68HC908QC8 (CDYE)@SOIC20 [(SA404)]  
 MC68HC908QC8 (CDZ)@SOIC28 [(SA404)]  
 MC68HC908QC8 (CDZE)@SOIC28 [(SA404)]  
 MC68HC908QC8 (MDR)@TSSOP28 [(SA643)]  
 MC68HC908QC8 (MDRE)@TSSOP28 [(SA643)]  
 MC68HC908QC8 (MDS)@TSSOP20 [(SA643)]  
 MC68HC908QC8 (MDSE)@TSSOP20 [(SA643)]  
 MC68HC908QC8 (MDT)@TSSOP16 [(SA643)]  
 MC68HC908QC8 (MDTE)@TSSOP16 [(SA643)]  
 MC68HC908QC8 (MDX)@SOIC16 [(SA404)]  
 MC68HC908QC8 (MDXE)@SOIC16 [(SA404)]  
 MC68HC908QC8 (MDY)@SOIC20 [(SA404)]  
 MC68HC908QC8 (MDYE)@SOIC20 [(SA404)]  
 MC68HC908QC8 (MDZ)@SOIC28 [(SA404)]  
 MC68HC908QC8 (MDZE)@SOIC28 [(SA404)]  
 MC68HC908QC8 (VDR)@TSSOP28 [(SA643)]  
 MC68HC908QC8 (VDRE)@TSSOP28 [(SA643)]  
 MC68HC908QC8 (VDS)@TSSOP20 [(SA643)]  
 MC68HC908QC8 (VDSE)@TSSOP20 [(SA643)]  
 MC68HC908QC8 (VDT)@TSSOP16 [(SA643)]  
 MC68HC908QC8 (VDTE)@TSSOP16 [(SA643)]  
 MC68HC908QC8 (VDX)@SOIC16 [(SA404)]  
 MC68HC908QC8 (VDXE)@SOIC16 [(SA404)]  
 MC68HC908QC8 (VDY)@SOIC20 [(SA404)]  
 MC68HC908QC8 (VDYE)@SOIC20 [(SA404)]  
 MC68HC908QC8 (VDZ)@SOIC28 [(SA404)]  
 MC68HC908QC8 (VDZE)@SOIC28 [(SA404)]  
 MC68HC908QF4 (CFJ)@TQFP32 [(SA663)]  
 MC68HC908QF4 (FJ)@TQFP32 [(SA663)]  
 MC68HC908QL2 (CDT)@TSSOP16 [(SA643)]  
 MC68HC908QL2 (CDW)@SOIC16 [(SA404)]  
 MC68HC908QL2 (MDT)@TSSOP16 [(SA643)]  
 MC68HC908QL2 (MDW)@SOIC16 [(SA404)]  
 MC68HC908QL2 (VDT)@TSSOP16 [(SA643)]  
 MC68HC908QL2 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QL3 (CDT)@TSSOP16 [(SA643)]  
 MC68HC908QL3 (CDW)@SOIC16 [(SA404)]  
 MC68HC908QL3 (MDT)@TSSOP16 [(SA643)]  
 MC68HC908QL3 (MDW)@SOIC16 [(SA404)]  
 MC68HC908QL3 (VDT)@TSSOP16 [(SA643)]

MC68HC908QL3 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QL4 (CDT)@TSSOP16 [(SA643)]  
 MC68HC908QL4 (CDW)@SOIC16 [(SA404)]  
 MC68HC908QL4 (MDT)@TSSOP16 [(SA643)]  
 MC68HC908QL4 (MDW)@SOIC16 [(SA404)]  
 MC68HC908QL4 (VDT)@TSSOP16 [(SA643)]  
 MC68HC908QL4 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QT1ACFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT1AMFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT1AVFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT1CDW@SOIC8 [(SA605A)]  
 MC68HC908QT1CFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT1CP MC68HC908QT1MDW@SOIC8 [(SA605A)]  
 MC68HC908QT1MFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT1MP MC68HC908QT1VDW@SOIC8 [(SA605A)]  
 MC68HC908QT1VFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT1VP  
 MC68HC908QT2ACFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT2AMFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT2AVFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT2CDW@SOIC8 [(SA605A)]  
 MC68HC908QT2CFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT2CP MC68HC908QT2MDW@SOIC8 [(SA605A)]  
 MC68HC908QT2MFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT2MP MC68HC908QT2VDW@SOIC8 [(SA605A)]  
 MC68HC908QT2VFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT2VP  
 MC68HC908QT4ACFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT4AMFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT4AVFQE@DFN8 [(SA744-B006)]  
 MC68HC908QT4CDW@SOIC8 [(SA605A)]  
 MC68HC908QT4CFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT4CP MC68HC908QT4MDW@SOIC8 [(SA605A)]  
 MC68HC908QT4MFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT4MP MC68HC908QT4VDW@SOIC8 [(SA605A)]  
 MC68HC908QT4VFQ@DFN8 [(SA744-B006)]  
 MC68HC908QT4VP  
 MC68HC908QY1CDT@TSSOP16 [(SA026)]  
 MC68HC908QY1CDW@SOIC16 [(SA404)] MC68HC908QY1CP  
 MC68HC908QY1MDT@TSSOP16 [(SA026)]  
 MC68HC908QY1MDW@SOIC16 [(SA404)] MC68HC908QY1MP  
 MC68HC908QY1VDT@TSSOP16 [(SA026)]  
 MC68HC908QY1VDW@SOIC16 [(SA404)] MC68HC908QY1VP  
 MC68HC908QY2CDT@TSSOP16 [(SA026)]  
 MC68HC908QY2CDW@SOIC16 [(SA404)] MC68HC908QY2CP  
 MC68HC908QY2MDT@TSSOP16 [(SA026)]  
 MC68HC908QY2MDW@SOIC16 [(SA404)] MC68HC908QY2MP  
 MC68HC908QY2VDT@TSSOP16 [(SA026)]  
 MC68HC908QY2VDW@SOIC16 [(SA404)] MC68HC908QY2VP  
 MC68HC908QY4CDT@TSSOP16 [(SA026)]  
 MC68HC908QY4CDW@SOIC16 [(SA404)] MC68HC908QY4CP  
 MC68HC908QY4MDT@TSSOP16 [(SA026)]  
 MC68HC908QY4MDW@SOIC16 [(SA404)] MC68HC908QY4MP  
 MC68HC908QY4VDT@TSSOP16 [(SA026)]  
 MC68HC908QY4VDW@SOIC16 [(SA404)] MC68HC908QY4VP  
 MC68HC908QY8 (CDT)@TSSOP16 [(SA026)]  
 MC68HC908QY8 (CDW)@SOIC16 [(SA404)]  
 MC68HC908QY8 (CP)  
 MC68HC908QY8 (MDT)@TSSOP16 [(SA026)]  
 MC68HC908QY8 (MDW)@SOIC16 [(SA404)]  
 MC68HC908QY8 (MP)  
 MC68HC908QY8 (VDT)@TSSOP16 [(SA026)]  
 MC68HC908QY8 (VDW)@SOIC16 [(SA404)]  
 MC68HC908QY8 (VP)  
 MC68HC908RF2 (CFA)@TQFP32 [(SA663)]  
 MC68HC908RF2 (MFA)@TQFP32 [(SA663)]  
 MC68HC908SR12 (CB)@SDIP42 [(SA028)]  
 MC68HC908SR12 (CFA)@TQFP48 [(SA248)]  
 MC68HC908SR12 (MB)@SDIP42 [(SA028)]  
 MC68HC908SR12 (MFA)@TQFP48 [(SA248)]  
 MC68HC912B32 (CFU8)@TQFP80 (\*) [(TA045-B006)]  
 MC68HC912B32 (MFU8)@TQFP80 (\*) [(TA045-B006)]  
 MC68HC912B32 (VFU8)@TQFP80 (\*) [(TA045-B006)]  
 MC68HC912BC32 (CFU8)@TQFP80 (\*) [(TA045-B006)]  
 MC68HC912BC32 (MFU8)@TQFP80 (\*) [(TA045-B006)]  
 MC68HC912BC32 (VFU8)@TQFP80 (\*) [(TA045-B006)]  
 MC68HCP11E1@PLCC52 [(PEP+S415T)]  
 MC68HCP11E1@PLCC52 (\*) [(SA647-B5202)]  
 MC68HCP11E1@QFP52 [(PEP+S673)]  
 MC68HRC908JK1CDW@SOIC20 [(SA404)]  
 MC68HRC908JK1CP

MC68HRC908JK1ECDW@SOIC20 [(SA404)]	
MC68HRC908JK1ECP	
MC68HRC908JK1EMDW@SOIC20 [(SA404)]	
MC68HRC908JK1EMP	
MC68HRC908JK1MDW@SOIC20 [(SA404)]	
MC68HRC908JK1MP	
MC68HRC908JK3CDW@SOIC20 [(SA404)]	
MC68HRC908JK3CP	
MC68HRC908JK3ECDW@SOIC20 [(SA404)]	
MC68HRC908JK3ECP	
MC68HRC908JK3EMDW@SOIC20 [(SA404)]	
MC68HRC908JK3EMP	
MC68HRC908JK3MDW@SOIC20 [(SA404)]	
MC68HRC908JK3MP	MC68HRC908JK8
MC68HRC908JK8@SOIC20 [(SA404)]	
MC68HRC908JL3CDW@SOIC28 [(SA404)]	
MC68HRC908JL3CFA@TQFP48 [(SA248)]	
MC68HRC908JL3CP	
MC68HRC908JL3ECDW@SOIC28 [(SA404)]	
MC68HRC908JL3ECFA@TQFP48 [(SA248)]	
MC68HRC908JL3ECP	
MC68HRC908JL3EMDW@SOIC28 [(SA404)]	
MC68HRC908JL3EMFA@TQFP48 [(SA248)]	
MC68HRC908JL3EMP	
MC68HRC908JL3MDW@SOIC28 [(SA404)]	
MC68HRC908JL3MFA@TQFP48 [(SA248)]	
MC68HRC908JL3MP	MC68HRC908JL8(dip20)
MC68HRC908JL8(dip28)	MC68HRC908JL8@LQFP32 [(SA663)]
MC68HRC908JL8@SDIP32 [(SA653)]	MC68HRC908JL8@SOIC20 [(SA404)]
MC68HRC908JL8@SOIC28 [(SA404)]	MC68HSC705C8A
MC68HSC705C8A@PLCC44 [(SA244)]	MC68HSC705C8A@SDIP42 [SA028]
MC68HSC705C8A@TQFP44 [(SA245A)]	
MC68S711E9@PLCC52(*) [(SA647-B5202)]	
MC68S711E9-FN@PLCC52(*) [(SA647-B5202)]	
MC908AB32CFUE@TQFP64(*) [(TA011-B006)]	
MC908AB32MFUE@TQFP64(*) [(TA011-B006)]	
MC908AP16CBE@SDIP42 [(SA028)]	MC908AP16CFAE@LQFP48 [(SA248)]
MC908AP16CFBE@TQFP44 [(SA675)]	MC908AP32CBE@SDIP42 [(SA028)]
MC908AP32CFAE@LQFP48 [(SA248)]	MC908AP32CFBE@TQFP44 [(SA675)]
MC908AP64CBE@SDIP42 [(SA028)]	MC908AP64CFAE@LQFP48 [(SA248)]
MC908AP64CFBE@TQFP44 [(SA675)]	MC908AP8CBE@SDIP42 [(SA028)]
MC908AP8CFAE@LQFP48 [(SA248)]	MC908AP8CFBE@TQFP44 [(SA675)]
MC908BD48IBE@SDIP42 [(SA028)]	MC908BD48IFBE@TQFP44 [(SA675)]
MC908EY16ACFJE@TQFP32 [(SA663)]	MC908EY16AKFJE@TQFP32 [(SA663)]
MC908EY16AMFJE@TQFP32 [(SA663)]	MC908EY16AVFJE@TQFP32 [(SA663)]
MC908EY8ACFJE@TQFP32 [(SA663)]	MC908EY8AKFJE@TQFP32 [(SA663)]
MC908EY8AMFJE@TQFP32 [(SA663)]	MC908EY8AVFJE@TQFP32 [(SA663)]
MC908JL16CDWE@SOIC28 [(SA404)]	MC908JL16CFJE@LQFP32 [(SA663)]
MC908JL16CPE	MC908JL16CSPE@SDIP32 [(SA653)]
MC908QT1ACDWE@SOIC8 [(SA605A)]	MC908QT1ACPE
MC908QT1AMDWE@SOIC8 [(SA605A)]	MC908QT1AMPE
MC908QT1AVDWE@SOIC8 [(SA605A)]	MC908QT1AVPE
MC908QT2ACDWE@SOIC8 [(SA605A)]	MC908QT2ACPE
MC908QT2AMDWE@SOIC8 [(SA605A)]	MC908QT2AMPE
MC908QT2AVDWE@SOIC8 [(SA605A)]	MC908QT2AVPE
MC908QT4ACDWE@SOIC8 [(SA605A)]	MC908QT4ACPE
MC908QT4AMDWE@SOIC8 [(SA605A)]	MC908QT4AMPE
MC908QT4AVDWE@SOIC8 [(SA605A)]	MC908QT4AVPE
MC908QY1ACDTE@TSSOP16 [(SA026)]	MC908QY1ACDWE@SOIC16 [(SA404)]
MC908QY1ACPE	MC908QY1AMDTE@TSSOP16 [(SA026)]
MC908QY1AMDWE@SOIC16 [(SA404)]	MC908QY1AMPE
MC908QY1AVDTE@TSSOP16 [(SA026)]	MC908QY1AVDWE@SOIC16 [(SA404)]
MC908QY1AVPE	MC908QY2ACDTE@TSSOP16 [(SA026)]
MC908QY2ACDWE@SOIC16 [(SA404)]	MC908QY2ACPE
MC908QY2AMDTE@TSSOP16 [(SA026)]	MC908QY2AMDWE@SOIC16 [(SA404)]
MC908QY2AMPE	MC908QY2AVDTE@TSSOP16 [(SA026)]
MC908QY2AVDWE@SOIC16 [(SA404)]	MC908QY2AVPE
MC908QY4ACDTE@TSSOP16 [(SA026)]	MC908QY4ACDWE@SOIC16 [(SA404)]
MC908QY4ACPE	MC908QY4AMDTE@TSSOP16 [(SA026)]
MC908QY4AMDWE@SOIC16 [(SA404)]	MC908QY4AMPE
MC908QY4AVDTE@TSSOP16 [(SA026)]	MC908QY4AVDWE@SOIC16 [(SA404)]
MC908QY4AVPE	
MC912D60ACFU8@TQFP80(*) [(TA034-B006)]	
MC912D60ACPV8@TQFP112(*) [(TA035+B084)]	
MC912D60AMFU8@TQFP80(*) [(TA034-B006)]	
MC912D60AMPV8@TQFP112(*) [(TA035+B084)]	
MC912D60AVFU8@TQFP80(*) [(TA034-B006)]	
MC912D60AVPV8@TQFP112(*) [(TA035+B084)]	
MC912D60CCFU8@TQFP80(*) [(TA034-B006)]	
MC912D60CCPV8@TQFP112(*) [(TA035+B084)]	
MC912D60CMFU8@TQFP80(*) [(TA034-B006)]	

MC912D60CMPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60CVFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60CVPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60PCFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60PCPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60PMFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60PMPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60PVFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60PVPV8@TQFP112(\*) [(TA035+B084)]  
 MC912DG128ACPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128AMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128AVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128CCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128CMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128CVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128PCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128PMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DG128PVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128ACPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128AMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128AVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128CCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128CMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128CVPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128PCPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128PMPV@TQFP112(\*) [(TA035+B084)]  
 MC912DT128PVPV@TQFP112(\*) [(TA035+B084)]  
 MC9RS08KA1CPC [(SA726+B179)]  
 MC9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
 MC9RS08KA2CPC [(SA726+B179)]  
 MC9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
 MC9RS08KA4CPG MC9RS08KA4CPJ  
 MC9RS08KA4CTG@TSSOP16 [(SA026+B349)]  
 MC9RS08KA4CWG@SOIC16 [(SA404+B349)]  
 MC9RS08KA4CWJ@SOIC20 [(SA404+B348)]  
 MC9RS08KA8CPG MC9RS08KA8CPJ  
 MC9RS08KA8CTG@TSSOP16 [(SA026+B349)]  
 MC9RS08KA8CWG@SOIC16 [(SA404+B349)]  
 MC9RS08KA8CWJ@SOIC20 [(SA404+B348)]  
 MC9S08AC16CFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16CFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16CFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16CFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16MFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16MFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16MFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16MFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16VFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16VFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC16VFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC16VFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32CFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32CFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32CFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32CFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32CFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32CFUE@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32CPU@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32CPUE@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32MFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32MFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32MFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32MFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32MFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32MFUE@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32MPU@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32MPUE@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32VFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32VFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC32VFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32VFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC32VFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32VFUE@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC32VPU@QFP64(\*) [(SA732-B196)]  
 MC9S08AC32VPUE@QFP64(\*) [(SA732-B196)]  
 MC9S08AC48CFD@QFN48(\*) [(SA696-B198)]  
 MC9S08AC48CFDE@QFN48(\*) [(SA696-B198)]  
 MC9S08AC48CFG@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC48CFGE@LQFP44(\*) [(SA245-B4404)]  
 MC9S08AC48CFU@LQFP64(\*) [(SA757-B196)]  
 MC9S08AC48CFUE@LQFP64(\*) [(SA757-B196)]

MC9S08AC48CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AC48CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AC48MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC48MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC48MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC48MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC48MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC48MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC48MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AC48MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AC48VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC48VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC48VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC48VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC48VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC48VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC48VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AC48VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AC60CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC60CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC60CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC60CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC60CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC60CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC60CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AC60CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AC60MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC60MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC60MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC60MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC60MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC60MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC60MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AC60MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AC60VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC60VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC60VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC60VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC60VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC60VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AC60VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AC60VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AC8CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC8CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC8CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC8CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC8MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC8MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC8MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC8MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC8VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AC8VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AC8VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AC8VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW16CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW16CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW16CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW16CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW16CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW16MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW16MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW16MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW16MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW16MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW16MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW16VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW16VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW16VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW16VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW16VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW16VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW16VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32CFG@LQFP44 (\*) [(SA245-B4404)]

MC9S08AW32CFGE@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32CFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32MFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW32VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW32VFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW32VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW32VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48CFGE@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48CFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48MFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW48VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW48VFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW48VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW48VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60CFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60CFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60CFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60CFGE@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60CFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60CFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60CPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60CPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60MFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60MFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60MFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60MFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60MFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60MPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60MPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60VFD@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60VFDE@QFN48 (\*) [(SA696-B198)]  
MC9S08AW60VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60VFG@LQFP44 (\*) [(SA245-B4404)]  
MC9S08AW60VFU@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60VFUE@LQFP64 (\*) [(SA757-B196)]  
MC9S08AW60VPU@QFP64 (\*) [(SA732-B196)]  
MC9S08AW60VPUE@QFP64 (\*) [(SA732-B196)]  
MC9S08GB32ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB32ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB32CFU@LQFP64 [(TA066-B006)]  
MC9S08GB32CFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60CFU@LQFP64 [(TA066-B006)]  
MC9S08GB60CFUE@LQFP64 [(TA066-B006)]  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFC@MLF32 [(SA686-B231)]  
MC9S08GT16ACFCE@MLF32 [(SA686-B231)]

MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFC@MLF32 [(SA686-B231)]  
MC9S08GT16AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]  
MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT60ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFD@QFN48 [(SA696-B166)]  
MC9S08GT60ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT60CB@SDIP42 [(SA028-B167)]  
MC9S08GT60CBE@SDIP42 [(SA028-B167)]  
MC9S08GT60CFB@LQFP44 [(SA675-B168)]  
MC9S08GT60CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60CFD@QFN48 [(SA696-B166)]  
MC9S08GT60CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFC@MLF32 [(SA686-B231)]  
MC9S08GT8ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFC@MLF32 [(SA686-B231)]  
MC9S08GT8AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
MC9S08JM16CGT@QFN48 (\*) [(SA696+B310)]  
MC9S08JM16CGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM16CLD@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM16CLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM16MGT@QFN48 (\*) [(SA696+B310)]  
MC9S08JM16MGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM16MLD@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM16MLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM16VGT@QFN48 (\*) [(SA696+B310)]  
MC9S08JM16VGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM16VLD@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM16VLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32CGT@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32CGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32CLD@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32CLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32CLH@QFP64 (\*) [(SA732+B311)]  
MC9S08JM32CLHE@QFP64 (\*) [(SA732+B311)]  
MC9S08JM32CQH@TQFP64 (\*) [(SA668+B311)]  
MC9S08JM32CQHE@TQFP64 (\*) [(SA668+B311)]  
MC9S08JM32MGT@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32MGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32MLD@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32MLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32MLH@QFP64 (\*) [(SA732+B311)]  
MC9S08JM32MLHE@QFP64 (\*) [(SA732+B311)]  
MC9S08JM32MQH@TQFP64 (\*) [(SA668+B311)]  
MC9S08JM32MQHE@TQFP64 (\*) [(SA668+B311)]  
MC9S08JM32VGT@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32VGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32VLD@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32VLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM32VLH@QFP64 (\*) [(SA732+B311)]  
MC9S08JM32VLHE@QFP64 (\*) [(SA732+B311)]  
MC9S08JM32VQH@TQFP64 (\*) [(SA668+B311)]  
MC9S08JM32VQHE@TQFP64 (\*) [(SA668+B311)]  
MC9S08JM60CGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM60CLDE@QFP44 (\*) [(SA245A+B4405)]  
MC9S08JM60CLHE@QFP64 (\*) [(SA732+B311)]

```

MC9S08JM60CQHE@TQFP64(*) [(SA668+B311)]
MC9S08JM8CGT@QFN48(*) [(SA696+B310)]
MC9S08JM8CGTE@QFN48(*) [(SA696+B310)]
MC9S08JM8CLD@QFP44(*) [(SA245A+B4405)]
MC9S08JM8CLDE@QFP44(*) [(SA245A+B4405)]
MC9S08JM8MGT@QFN48(*) [(SA696+B310)]
MC9S08JM8MGTE@QFN48(*) [(SA696+B310)]
MC9S08JM8MLD@QFP44(*) [(SA245A+B4405)]
MC9S08JM8MLDE@QFP44(*) [(SA245A+B4405)]
MC9S08JM8VGT@QFN48(*) [(SA696+B310)]
MC9S08JM8VGTE@QFN48(*) [(SA696+B310)]
MC9S08JM8VLD@QFP44(*) [(SA245A+B4405)]
MC9S08JM8VLDE@QFP44(*) [(SA245A+B4405)]
MC9S08QA2CDN@SOIC8 [(SA602A+B179)]
MC9S08QA2CDNE@SOIC8 [(SA602A+B179)]
MC9S08QA2CFQ@DFN8 [(SA744+B248)]
MC9S08QA2CFQE@DFN8 [(SA744+B248)]
MC9S08QA2CPA MC9S08QA2CPAE
MC9S08QA2MDN@SOIC8 [(SA602A+B179)]
MC9S08QA2MDNE@SOIC8 [(SA602A+B179)]
MC9S08QA2MFQ@DFN8 [(SA744+B248)]
MC9S08QA2MFQE@DFN8 [(SA744+B248)]
MC9S08QA2MPA MC9S08QA2MPAE
MC9S08QA2VDN@SOIC8 [(SA602A+B179)]
MC9S08QA2VDNE@SOIC8 [(SA602A+B179)]
MC9S08QA2VFQ@DFN8 [(SA744+B248)]
MC9S08QA2VFQE@DFN8 [(SA744+B248)]
MC9S08QA2VPA MC9S08QA2VPAE
MC9S08QA4CDN@SOIC8 [(SA602A+B179)]
MC9S08QA4CDNE@SOIC8 [(SA602A+B179)]
MC9S08QA4CFQ@DFN8 [(SA744+B248)]
MC9S08QA4CFQE@DFN8 [(SA744+B248)]
MC9S08QA4CPA MC9S08QA4CPAE
MC9S08QA4MDN@SOIC8 [(SA602A+B179)]
MC9S08QA4MDNE@SOIC8 [(SA602A+B179)]
MC9S08QA4MFQ@DFN8 [(SA744+B248)]
MC9S08QA4MFQE@DFN8 [(SA744+B248)]
MC9S08QA4MPA MC9S08QA4MPAE
MC9S08QA4VDN@SOIC8 [(SA602A+B179)]
MC9S08QA4VDNE@SOIC8 [(SA602A+B179)]
MC9S08QA4VFQ@DFN8 [(SA744+B248)]
MC9S08QA4VFQE@DFN8 [(SA744+B248)]
MC9S08QA4VPA MC9S08QA4VPAE
MC9S08QD2CPC [(SA726+B179)]
MC9S08QD2CSC@SOIC8 [(SA602A+B179)]
MC9S08QD2MPC [(SA726+B179)]
MC9S08QD2MSC@SOIC8 [(SA602A+B179)]
MC9S08QD2VPC [(SA726+B179)]
MC9S08QD2VSC@SOIC8 [(SA602A+B179)]
MC9S08QD4CPC [(SA726+B179)]
MC9S08QD4CSC@SOIC8 [(SA602A+B179)]
MC9S08QD4MPC [(SA726+B179)]
MC9S08QD4MSC@SOIC8 [(SA602A+B179)]
MC9S08QD4VPC [(SA726+B179)]
MC9S08QD4VSC@SOIC8 [(SA602A+B179)]
MC9S08QG4CDNE@SOIC8 [(SA602A+B179)]
MC9S08QG4CDTE@TSSOP16 [(SA026+B182)]
MC9S08QG4CFQE@QFN16 [(SA747+B247)]
MC9S08QG4CFQE@DFN8 [(SA744+B248)]
MC9S08QG4CPAE [(SA726+B179)]
MC9S08QG8CDNE@SOIC8 [(SA602A+B179)]
MC9S08QG8CDTE@TSSOP16 [(SA026+B182)]
MC9S08QG8CFQE@QFN16 [(SA747+B247)]
MC9S08QG8CFQE@DFN8 [(SA744+B248)]
MC9S08QG8CPBE [(SA726+B182)]
MC9S08RC16CFJ@LQFP32 [(SA663)]
MC9S08RC16FJ@LQFP32 [(SA663)]
MC9S08RC16FJ@LQFP32 [(SA663)]
MC9S08RC32CFJ@LQFP32 [(SA663)]
MC9S08RC32FJ@LQFP32 [(SA663)]
MC9S08RC60CFJ@LQFP32 [(SA663)]
MC9S08RC60FJ@LQFP32 [(SA663)]
MC9S08RC8CFJ@LQFP32 [(SA663)]
MC9S08RC8FJ@LQFP32 [(SA663)]
MC9S08RD16CFG@LQFP44 [(SA245A)]
MC9S08RD16CP MC9S08RC16CFG@LQFP44 [(SA245A)]
MC9S08RD16FG@LQFP44 [(SA245A)]
MC9S08RD16P MC9S08RC16FG@LQFP44 [(SA245A)]
MC9S08RD32CFG@LQFP44 [(SA245A)]
MC9S08RD32CP MC9S08RC32CFG@LQFP44 [(SA245A)]
MC9S08RD32FG@LQFP44 [(SA245A)]
MC9S08RD32P MC9S08RC32FG@LQFP44 [(SA245A)]
MC9S08RD60CDW@SOIC28 [(SA404)]
MC9S08RD16CDW@SOIC28 [(SA404)]
MC9S08RD16CFJ@LQFP32 [(SA663)]
MC9S08RD32CDW@SOIC28 [(SA404)]
MC9S08RD32CFJ@LQFP32 [(SA663)]
MC9S08RD32DW@SOIC28 [(SA404)]
MC9S08RD32FJ@LQFP32 [(SA663)]
MC9S08RD60CDW@SOIC28 [(SA404)]

```



MC9S08RD60CFG@LQFP44 [(SA245A)]      MC9S08RD60CFJ@LQFP32 [(SA663)]  
 MC9S08RD60CP      MC9S08RD60DW@SOIC28 [(SA404)]  
 MC9S08RD60FG@LQFP44 [(SA245A)]      MC9S08RD60FJ@LQFP32 [(SA663)]  
 MC9S08RD60P      MC9S08RD8CDW@SOIC28 [(SA404)]  
 MC9S08RD8CFG@LQFP44 [(SA245A)]      MC9S08RD8CFJ@LQFP32 [(SA663)]  
 MC9S08RD8CP      MC9S08RD8DW@SOIC28 [(SA404)]  
 MC9S08RD8FG@LQFP44 [(SA245A)]      MC9S08RD8FJ@LQFP32 [(SA663)]  
 MC9S08RD8P      MC9S08RE16CFG@LQFP44 [(SA245A)]  
 MC9S08RE16CFJ@LQFP32 [(SA663)]      MC9S08RE16FG@LQFP44 [(SA245A)]  
 MC9S08RE16FJ@LQFP32 [(SA663)]      MC9S08RE32CFG@LQFP44 [(SA245A)]  
 MC9S08RE32CFJ@LQFP32 [(SA663)]      MC9S08RE32FG@LQFP44 [(SA245A)]  
 MC9S08RE32FJ@LQFP32 [(SA663)]      MC9S08RE60CFG@LQFP44 [(SA245A)]  
 MC9S08RE60CFJ@LQFP32 [(SA663)]      MC9S08RE60FG@LQFP44 [(SA245A)]  
 MC9S08RE60FJ@LQFP32 [(SA663)]      MC9S08RE8CFG@LQFP44 [(SA245A)]  
 MC9S08RE8CFJ@LQFP32 [(SA663)]      MC9S08RE8FG@LQFP44 [(SA245A)]  
 MC9S08RE8FJ@LQFP32 [(SA663)]      MC9S08RG32CFG@LQFP44 [(SA245A)]  
 MC9S08RG32CFJ@LQFP32 [(SA663)]      MC9S08RG32FG@LQFP44 [(SA245A)]  
 MC9S08RG32FJ@LQFP32 [(SA663)]      MC9S08RG60CFG@LQFP44 [(SA245A)]  
 MC9S08RG60CFJ@LQFP32 [(SA663)]      MC9S08RG60FG@LQFP44 [(SA245A)]  
 MC9S08RG60FJ@LQFP32 [(SA663)]  
 MC9S08SG4CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG4CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG4MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG4MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG4VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG4VTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG8CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG8CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG8MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG8MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SG8VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SG8VTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH4CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH4CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH4MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH4MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH4VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH4VTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH8CSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH8CTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH8MSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH8MTG@TSSOP16 [(SA026+B182)]  
 MC9S08SH8VSC@SOIC8 [(SA602A+B179)]  
 MC9S08SH8VTG@TSSOP16 [(SA026+B182)]  
 MC9S12A128BCFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128BMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128BVFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128BVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A128VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A128VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256BCFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256BMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256BVFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256BVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A256VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A256VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12A64CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64CPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12A64FU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64MPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12A64PV@TQFP112(\*) [(TA037-B006)]  
 MC9S12A64VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12A64VPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B128CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B128CPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B128MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B128MPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B128VFU@TQFP80(\*) [(TA015-B006)]

MC9S12B128VPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B64CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B64CPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B64MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B64MPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12B64VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12B64VPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12C128CFA@TQFP48 [(SA248)]  
 MC9S12C128CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C128CPB@TQFP52 [(PEP+S673)]  
 MC9S12C128MFA@TQFP48 [(SA248)]  
 MC9S12C128MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C128MPB@TQFP52 [(PEP+S673)]  
 MC9S12C128VFA@TQFP48 [(SA248)]  
 MC9S12C128VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C128VPB@TQFP52 [(PEP+S673)]  
 MC9S12C32CFA16@TQFP48 [(SA248)] MC9S12C32CFA25@TQFP48 [(SA248)]  
 MC9S12C32CFU16@TQFP80(\*) [(TA015-B006)]  
 MC9S12C32CFU25@TQFP80(\*) [(TA015-B006)]  
 MC9S12C32CPB16@TQFP52 [(PEP+S673)]  
 MC9S12C32CPB25@TQFP52 [(PEP+S673)]  
 MC9S12C32MFA16@TQFP48 [(SA248)] MC9S12C32MFA25@TQFP48 [(SA248)]  
 MC9S12C32MFU16@TQFP80(\*) [(TA015-B006)]  
 MC9S12C32MFU25@TQFP80(\*) [(TA015-B006)]  
 MC9S12C32MPB16@TQFP52 [(PEP+S673)]  
 MC9S12C32MPB25@TQFP52 [(PEP+S673)]  
 MC9S12C32VFA16@TQFP48 [(SA248)] MC9S12C32VFA25@TQFP48 [(SA248)]  
 MC9S12C32VFU16@TQFP80(\*) [(TA015-B006)]  
 MC9S12C32VFU25@TQFP80(\*) [(TA015-B006)]  
 MC9S12C32VPB16@TQFP52 [(PEP+S673)]  
 MC9S12C32VPB25@TQFP52 [(PEP+S673)]  
 MC9S12C64CFA@TQFP48 [(SA248)]  
 MC9S12C64CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C64CPB@TQFP52 [(PEP+S673)] MC9S12C64MFA@TQFP48 [(SA248)]  
 MC9S12C64MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C64MPB@TQFP52 [(PEP+S673)] MC9S12C64VFA@TQFP48 [(SA248)]  
 MC9S12C64VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C64VPB@TQFP52 [(PEP+S673)] MC9S12C96CFA@TQFP48 [(SA248)]  
 MC9S12C96CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C96CPB@TQFP52 [(PEP+S673)] MC9S12C96MFA@TQFP48 [(SA248)]  
 MC9S12C96MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C96MPB@TQFP52 [(PEP+S673)] MC9S12C96VFA@TQFP48 [(SA248)]  
 MC9S12C96VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12C96VPB@TQFP52 [(PEP+S673)]  
 MC9S12D64CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12D64CPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12D64FU@TQFP80(\*) [(TA015-B006)]  
 MC9S12D64MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12D64MPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12D64PV@TQFP112(\*) [(TA037-B006)]  
 MC9S12D64VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12D64VPV@TQFP112(\*) [(TA037-B006)]  
 MC9S12DB128BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DB128BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DB128BVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DB128CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DB128MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DB128VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128BCFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128BMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128BVFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128BVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128ECFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128ECPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128EMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128EMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128EVFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128EVPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG128VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG128VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG256BCFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG256BCPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG256BMFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12DG256BMPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12DG256BVFU@TQFP80(\*) [(TA015-B006)]

MC9S12DG256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64CPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DJ64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DJ64PV@TQFP112(\*) [(TA037-B006)]  
MC9S12DJ64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64VPV@TQFP112(\*) [(TA037-B006)]  
MC9S12DP256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256MFU@TQFP80(\*) [(TA015-B006)]

MC9S12DT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12E128CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E32CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12GC128CFA@TQFP48 [(SA248)]  
MC9S12GC128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128CPB@TQFP52 [(PEP+S673)]  
MC9S12GC128MFA@TQFP48 [(SA248)]  
MC9S12GC128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128MPB@TQFP52 [(PEP+S673)]  
MC9S12GC128VFA@TQFP48 [(SA248)]  
MC9S12GC128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128VPB@TQFP52 [(PEP+S673)]  
MC9S12GC16CFA@TQFP48 [(SA248)]  
MC9S12GC16CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16CPB@TQFP52 [(PEP+S673)]  
MC9S12GC16MFA@TQFP48 [(SA248)]  
MC9S12GC16MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16MPB@TQFP52 [(PEP+S673)]  
MC9S12GC16VFA@TQFP48 [(SA248)]  
MC9S12GC16VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16VPB@TQFP52 [(PEP+S673)]  
MC9S12GC32CFA@TQFP48 [(SA248)]  
MC9S12GC32CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32CPB@TQFP52 [(PEP+S673)]  
MC9S12GC32MFA@TQFP48 [(SA248)]  
MC9S12GC32MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32MPB@TQFP52 [(PEP+S673)]  
MC9S12GC32VFA@TQFP48 [(SA248)]  
MC9S12GC32VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32VPB@TQFP52 [(PEP+S673)]  
MC9S12GC64CFA@TQFP48 [(SA248)]  
MC9S12GC64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64CPB@TQFP52 [(PEP+S673)]  
MC9S12GC64MFA@TQFP48 [(SA248)]  
MC9S12GC64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64MPB@TQFP52 [(PEP+S673)]  
MC9S12GC64VFA@TQFP48 [(SA248)]  
MC9S12GC64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64VPB@TQFP52 [(PEP+S673)]

MC9S12GC96CFA@TQFP48 [(SA248)]  
MC9S12GC96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96CPB@TQFP52 [(PEP+S673)]  
MC9S12GC96MFA@TQFP48 [(SA248)]  
MC9S12GC96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96MPB@TQFP52 [(PEP+S673)]  
MC9S12GC96VFA@TQFP48 [(SA248)]  
MC9S12GC96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96VPB@TQFP52 [(PEP+S673)]  
MC9S12HN64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12KG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12KG256CPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12KG256MPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12KG256VPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KT256CPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KT256MPV@LQFP112(\*) [(TA037-B084)]  
MC9S12KT256VPV@LQFP112(\*) [(TA037-B084)]  
MC9S12NE64CPV@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64CPVE@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64VTU@TQFP80(\*) [(TA085-B006)]  
MC9S12NE64VTUE@TQFP80(\*) [(TA085-B006)]  
MC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
MC9S12XA128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MPV@TQFP112(\*) [(TA037-B084)]

MC9S12XA128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CFV@LQFP144(\*) [(SA681-B14412)]

MC9S12XD256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD64CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CAG@LQFP144(\*) [(SA681-B14412)]

MC9S12XDT384CAL@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT384CFV@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT384CPU@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT384CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT384MAA@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT384MAG@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT384MAL@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT384MFV@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT384MPU@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT384MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT384VAA@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT384VAG@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT384VAL@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT384VFFV@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT384VPV@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT384VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT512CAA@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT512CAG@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT512CAL@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT512CFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT512CFV@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT512CPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT512MAA@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT512MAG@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT512MAL@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT512MFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT512MFV@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT512MPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT512VAA@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT512VAG@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT512VAL@TQFP112(\*) [(TA037-B084)]  
 MC9S12XDT512VFU@TQFP80(\*) [(TA015-B006)]  
 MC9S12XDT512VFFV@LQFP144(\*) [(SA681-B14412)]  
 MC9S12XDT512VPV@TQFP112(\*) [(TA037-B084)]  
 MC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
 MC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
 MC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
 MCHC908JW32FAE@LQFP48 [(SA248+B005)]  
 MCHC908JW32FC@TQFN48 [(SA696+B006)]  
 P912XDG128CAA@TQFP80(\*) [(TA015-B006)]  
 P912XDG128CAL@TQFP112(\*) [(TA037-B084)]  
 P912XDG128CFU@TQFP80(\*) [(TA015-B006)]  
 P912XDG128CPV@TQFP112(\*) [(TA037-B084)]  
 P912XDG128MAA@TQFP80(\*) [(TA015-B006)]  
 P912XDG128MAL@TQFP112(\*) [(TA037-B084)]  
 P912XDG128MFU@TQFP80(\*) [(TA015-B006)]  
 P912XDG128MPV@TQFP112(\*) [(TA037-B084)]  
 P912XDG128VAA@TQFP80(\*) [(TA015-B006)]  
 P912XDG128VAL@TQFP112(\*) [(TA037-B084)]  
 P912XDG128VFU@TQFP80(\*) [(TA015-B006)]  
 P912XDG128VPV@TQFP112(\*) [(TA037-B084)]  
 P9RS08KA1CPC [(SA726+B179)]  
 P9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
 P9RS08KA2CPC [(SA726+B179)]  
 P9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
 PC56F8011VFAE@QFP32 [(SA663+B005)]  
 PC56F8013VFAE@QFP32 [(SA663+B005)]  
 PC56F8014VFAE@QFP32 [(SA663+B005)]  
 PC68HC908GP32 PC68HC908GP32@SDIP42 [(SA028)]  
 PC68HC908GP32@TQFP44 [(SA675)]  
 PC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
 PC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
 PC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
 PC9S12XF128@QFP112(\*) [(SA719-B253)]  
 PC9S12XF128@QFP144(\*) [(SA681-B14411)]  
 PC9S12XF128@QFP64(\*) [(SA732-B252)]



PC9S12XF256@QFP112(\*) [(SA719-B253)]  
 PC9S12XF256@QFP144(\*) [(SA681-B14411)]  
 PC9S12XF256@QFP64(\*) [(SA732-B252)]  
 PC9S12XF384@QFP112(\*) [(SA719-B253)]  
 PC9S12XF384@QFP144(\*) [(SA681-B14411)]  
 PC9S12XF384@QFP64(\*) [(SA732-B252)]  
 PC9S12XF512@QFP112(\*) [(SA719-B253)]  
 PC9S12XF512@QFP144(\*) [(SA681-B14411)]  
 PC9S12XF512@QFP64(\*) [(SA732-B252)]  
 PC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
 S9S08AW16ACFT@QFN48(\*) [(SA696-B198)]  
 S9S08AW16ACLS@QFP44(\*) [(SA245-B4404)]  
 S9S08AW16AMFT@QFN48(\*) [(SA696-B198)]  
 S9S08AW16AMLS@QFP44(\*) [(SA245-B4404)]  
 S9S08AW16AVFT@QFN48(\*) [(SA696-B198)]  
 S9S08AW16AVLS@QFP44(\*) [(SA245-B4404)]  
 S9S08AW8ACFT@QFN48(\*) [(SA696-B198)]  
 S9S08AW8ACLS@QFP44(\*) [(SA245-B4404)]  
 S9S08AW8AMFT@QFN48(\*) [(SA696-B198)]  
 S9S08AW8AMLS@QFP44(\*) [(SA245-B4404)]  
 S9S08AW8AVFT@QFN48(\*) [(SA696-B198)]  
 S9S08AW8AVLS@QFP44(\*) [(SA245-B4404)]  
 XC68HC705P6A(CDW)@SOIC28 [(SA404)]  
 XC68HC711D3 XC68HC711D3@PLCC44 [(SA244)]  
 XC68HC711D3@TQFP44 [(SA675)]  
 XC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
 XC68HC908MR32(CB)@SDIP56(\*) [(SA627+B5604)]  
 XC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
 XC68HC908MR32(CFU)@TQFP64(\*) [(SA757+B331)]  
 XC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
 XC68HC908MR32(VB)@SDIP56(\*) [(SA627+B5604)]  
 XC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
 XC68HC908MR32(VFU)@TQFP64(\*) [(SA757+B331)]  
 XC68HSC705C9A XC68HSC705C9A@PLCC44 [(SA244)]  
 XC68HSC705C9A@TQFP44 [(SA245A)]

## MYSON

### MICROCONTROLLER

CS8954F@PQFP44 [(SA675)] CS8954MV@PLCC44 [(SA244)]  
 CS8955F@PQFP44 [(SA675)] CS8955G@LQFP48 [(SA248)]  
 CS8955HF@PQFP44 [(SA675)] CS8955HG@LQFP48 [(SA248)]  
 CS8955HN CS8955HV@PLCC44 [(SA244)]  
 CS8955N CS8955V@PLCC44 [(SA244)]  
 MTV212MN32 MTV212MN64I  
 MTV212MS32@SDIP42 [(SA028)] MTV212MS64I@SDIP42 [(SA028)]  
 MTV212MV32@PLCC44 [(SA244)] MTV212MV64I@PLCC44 [(SA244)]  
 MTV230GMF@TQFP44 [(SA245A)] MTV230GMS@SDIP42 [(SA028)]  
 MTV230GMV@PLCC44 [(SA244)] MTV230MF@TQFP44 [(SA245A)]  
 MTV230MS@SDIP42 [(SA028)] MTV230MV@PLCC44 [(SA244)]  
 MTV230PMF@TQFP44 [(SA245A)] MTV230PMS@SDIP42 [(SA028)]  
 MTV230PMV@PLCC44 [(SA244)] MTV312MN64(AG VERSION)  
 MTV312MN64(AJ VERSION)  
 MTV312MS64(AG VERSION)@SDIP42 [(SA028)]  
 MTV312MS64(AJ VERSION)@SDIP42 [(SA028)]  
 MTV312MV64(AG VERSION)@PLCC44 [(SA244)]  
 MTV312MV64(AJ VERSION)@PLCC44 [(SA244)]  
 MTV412MF128@PQFP44 [(SA245A)] MTV412MS128@SDIP42 [(SA028)]  
 MTV412MV128@PLCC44 [(SA244)] MTV416GMF@TQFP44 [(SA675)]

```
MTV416GMG@TQFP48 [(SA248)]           MTV416GMV@PLCC44 [(SA244)]
MTV416MF@TQFP44 [(SA675)]           MTV416MG@TQFP48 [(SA248)]
MTV416MV@PLCC44 [(SA244)]           MTV416PMF@TQFP44 [(SA675)]
MTV416PMG@TQFP48 [(SA248)]         MTV416PMV@PLCC44 [(SA244)]
MTV512MF(A1 VERSION)@TQFP44 [(SA245A)]
MTV512MF(A3 VERSION)@TQFP44 [(SA245A)]
MTV512MV(A1 VERSION)@PLCC44 [(SA244)]
MTV512MV(A3 VERSION)@PLCC44 [(SA244)]
```

## MYSON-CUSTOMER

### MICROCONTROLLER

```
MTV416GMV@PLCC44 [(SA245)]
```

## NANTRONICS

### E(E) PROM/FRAM/NVRAM

```
NS29LV032FB@FBGA48 [(SA642G-B026A-T048F001Y)]
NS29LV032FB@TSOP48 [(SA247-B005)]
NS29LV032FT@FBGA48 [(SA642G-B026A-T048F001Y)]
NS29LV032FT@TSOP48 [(SA247-B005)]
```

## NEC

### E(E) PROM/FRAM/NVRAM

```
D2716D                               uPD271000
uPD271000@PLCC32 [(SA015A1T)]       uPD271000@TSOP32 [(SA410T)]
uPD27128                             uPD27128(C)
uPD27128(D)                          uPD2716
uPD27256                             uPD27256(C)
uPD27256(D)                          uPD27256A
uPD27256A(C)                         uPD27256A(D)
uPD2732                              uPD2732A
uPD27512                             uPD27512ACT
uPD27512AD                           uPD2764
uPD2764C                              uPD2764D
uPD27C1000                           uPD27C1000@PLCC32 [(SA015A1T)]
uPD27C1000@TSOP32 [(SA410T)]        uPD27C1000A
uPD27C1000A@PLCC32 [(SA015A1T)]    uPD27C1000A@TSOP32 [(SA410T)]
uPD27C1000AD                         uPD27C1000AD@PLCC32 [(SA015A1T)]
uPD27C1000AD@TSOP32 [(SA410T)]     uPD27C1001
uPD27C1001@PLCC32 [(SA015A1T)]     uPD27C1001@TSOP32 [(SA410T)]
uPD27C1001A                          uPD27C1001A@PLCC32 [(SA015A1T)]
uPD27C1001A@TSOP32 [(SA410T)]      uPD27C1001D
uPD27C1001D@PLCC32 [(SA015A1T)]    uPD27C1001D@TSOP32 [(SA410T)]
uPD27C1024                           uPD27C1024A
uPD27C2001                           uPD27C2001@PLCC32 [(SA015A1T)]
uPD27C2001@TSOP32 [(SA410T)]       uPD27C2001D
uPD27C2001D@PLCC32 [(SA015A1T)]    uPD27C2001D@TSOP32 [(SA410T)]
uPD27C210                             uPD27C256
uPD27C256A                           uPD27C400
uPD27C4001                           uPD27C4001@PLCC32 [(SA015A1T)]
uPD27C4001@TSOP32 [(SA410T)]       uPD27C4096
uPD27C512                             uPD27C64(C)
uPD27C64(D)                          uPD27C8000
uPD27C8001                           uPD27C8001@PLCC32 [(SA015A1T)]
uPD27C8001@TSOP32 [(SA410T)]       uPD28C04
uPD28C04@SOIC24 [(SA404)]           uPD28C05
uPD28C05@SOIC24 [(SA404)]           uPD28C256
uPD28C64                             uPD28C64@SOIC28 [(SA404)]
uPD29F008CB@TSOP40 [(SA409T)]      uPD29F008CT@TSOP40 [(SA409T)]
```

### DRAM & SRAM

```
PD4361B                               PD4361B@SOJ24 [(SA646)]
```

## MICROCONTROLLER

```

uPD70P3000@QFP100 [(PEP+S604)]
uPD75P0016@SDIP42 [(SA028)]
uPD75P0076CU@SDIP42 [(SA028)]
uPD75P008CU@SDIP42 [(SA028)]
uPD75P108CW@SDIP64 [(PEP+S600A)]
uPD75P116CW@SDIP64 [(PEP+S600A)]
uPD75P218CW@PQFP64 [(PEP+S618)]
uPD75P3018AGC@TQFP80 [(PEP+S615B)]
uPD75P3018AGK@TQFP80 [(PEP+S640B)]
uPD75P3018GC@TQFP80 [(PEP+S615B)]
uPD75P3018GK@TQFP80 [(PEP+S640B)]
uPD75P3036GC@TQFP80 [(PEP+S615B)]
uPD75P3036GK@TQFP80 [(PEP+S640B)]
uPD75P308GF@PQFP80 [(PEP+S611A)]
uPD75P316AGF@PQFP80 [(PEP+S611A)]
uPD75P316BGC@PQFP80 [(PEP+S611A)]
uPD75P316BGK@PQFP80 [(PEP+S611A)]
uPD75P316GF@PQFP80 [(PEP+S611A)]
uPD75P54CS
uPD75P64CS
uPD78F0101HMC(A)@SSOP30 [(SA689)]
uPD78F0101HMC(A1)@SSOP30 [(SA689)]
uPD78F0101HMC@SSOP30 [(SA689)]
uPD78F0102HMC(A)@SSOP30 [(SA689)]
uPD78F0102HMC(A1)@SSOP30 [(SA689)]
uPD78F0102HMC@SSOP30 [(SA689)]
uPD78F0103HMC(A)@SSOP30 [(SA689)]
uPD78F0103HMC(A1)@SSOP30 [(SA689)]
uPD78F0103HMC@SSOP30 [(SA689)]
uPD78F0103M1MCA@SSOP30 [(SA689)]
uPD78F0103M1MCA1@SSOP30 [(SA689)]
uPD78F0103M2MCA@SSOP30 [(SA689)]
uPD78F0103M2MCA1@SSOP30 [(SA689)]
uPD78F0103M3MCA@SSOP30 [(SA689)]
uPD78F0103M3MCA1@SSOP30 [(SA689)]
uPD78F0103M4MCA@SSOP30 [(SA689)]
uPD78F0103M4MCA1@SSOP30 [(SA689)]
uPD78F0103M5MCA@SSOP30 [(SA689)]
uPD78F0103M5MCA1@SSOP30 [(SA689)]
uPD78F0103M6MCA@SSOP30 [(SA689)]
uPD78F0103M6MCA1@SSOP30 [(SA689)]
uPD78F0103N1MCA@TQFP64 [(S616)]
uPD78F0103N1MCA1@TQFP64 [(S616)]
uPD78F0103N2MCA@TQFP64 [(S616)]
uPD78F0103N2MCA1@TQFP64 [(S616)]
uPD78F0103N3MCA@TQFP64 [(S616)]
uPD78F0103N3MCA1@TQFP64 [(S616)]
uPD78F0103N4MCA@TQFP64 [(S616)]
uPD78F0103N4MCA1@TQFP64 [(S616)]
uPD78F0103N5MCA@TQFP64 [(S616)]
uPD78F0103N5MCA1@TQFP64 [(S616)]
uPD78F0103N6MCA@TQFP64 [(S616)]
uPD78F0103N6MCA1@TQFP64 [(S616)]
uPD78F0112HGB(A)@LQFP44 [(SA245A)]
uPD78F0112HGB(A1)@LQFP44 [(SA245A)]
uPD78F0112HGB@LQFP44 [(SA245A)]
uPD78F0113HGB(A)@LQFP44 [(SA245A)]
uPD78F0113HGB(A1)@LQFP44 [(SA245A)]
uPD78F0113HGB@LQFP44 [(SA245A)]
uPD78F0114HDGB(A)@LQFP44 [(SA245A)]
uPD78F0114HDGB(A1)@LQFP44 [(SA245A)]
uPD78F0114HDGB@LQFP44 [(SA245A)]
uPD78F0114HGB(A)@LQFP44 [(SA245A)]
uPD78F0114HGB(A1)@LQFP44 [(SA245A)]
uPD78F0114HGB@LQFP44 [(SA245A)]
uPD78F0122HGB(A)@LQFP52 [(PEP+S673)]
uPD78F0122HGB(A1)@LQFP52 [(PEP+S673)]
uPD78F0122HGB@LQFP52 [(PEP+S673)]
uPD78F0123HGB(A)@LQFP52 [(PEP+S673)]
uPD78F0123HGB(A1)@LQFP52 [(PEP+S673)]
uPD78F0123HGB@LQFP52 [(PEP+S673)]
uPD78F0124HDGB(A)@LQFP52 [(PEP+S673)]
uPD78F0124HDGB(A1)@LQFP52 [(PEP+S673)]
uPD78F0124HDGB@LQFP52 [(PEP+S673)]
uPD78F0124HGB(A)@LQFP52 [(PEP+S673)]
uPD78F0124HGB(A1)@LQFP52 [(PEP+S673)]
uPD78F0124HGB@LQFP52 [(PEP+S673)]
uPD78F0132HGB(A)@LQFP64 [(PEP+S616)]
uPD78F0132HGB(A1)@LQFP64 [(PEP+S616)]
uPD78F0132HGB@LQFP64 [(PEP+S616)]
uPD78F0132HGC(A)@LQFP64 [(PEP+S621)]
uPD70P3002@QFP100 [(PEP+S604)]
uPD75P0016@TQFP44 [(SA675)]
uPD75P0076GT@SOP42 [(SA645)]
uPD75P008GB@TQFP44 [(SA245A)]
uPD75P108GF@PQFP64 [(PEP+S618)]
uPD75P116GF@PQFP64 [(PEP+S618)]
uPD75P218CW@SDIP64 [(PEP+S600A)]
uPD75P328GC@QFP80 [(PEP+S615B)]
uPD75P54G@SOP20 [(SA626A)]
uPD75P64G@SOP20 [(SA626A)]
uPD78F0103M1MC@SSOP30 [(SA689)]
uPD78F0103M2MCA@SSOP30 [(SA689)]
uPD78F0103M3MCA@SSOP30 [(SA689)]
uPD78F0103M4MCA@SSOP30 [(SA689)]
uPD78F0103M5MCA@SSOP30 [(SA689)]
uPD78F0103M6MCA@SSOP30 [(SA689)]
uPD78F0103N1MCA@TQFP64 [(S616)]
uPD78F0103N2MC@TQFP64 [(S616)]
uPD78F0103N2MCA1@TQFP64 [(S616)]
uPD78F0103N3MCA@TQFP64 [(S616)]
uPD78F0103N4MC@TQFP64 [(S616)]
uPD78F0103N4MCA1@TQFP64 [(S616)]
uPD78F0103N5MCA@TQFP64 [(S616)]
uPD78F0103N6MC@TQFP64 [(S616)]
uPD78F0103N6MCA1@TQFP64 [(S616)]

```

uPD78F0132HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0132HGC@LQFP64 [(PEP+S621)]  
uPD78F0132HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0132HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0132HGK@LQFP64 [(PEP+S680)]  
uPD78F0133HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0133HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0133HGB@LQFP64 [(PEP+S616)]  
uPD78F0133HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0133HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0133HGC@LQFP64 [(PEP+S621)]  
uPD78F0133HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0133HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0133HGK@LQFP64 [(PEP+S680)]  
uPD78F0134HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0134HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0134HGB@LQFP64 [(PEP+S616)]  
uPD78F0134HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0134HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0134HGC@LQFP64 [(PEP+S621)]  
uPD78F0134HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0134HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0134HGK@LQFP64 [(PEP+S680)]  
uPD78F0134M1GB@LQFP64 [(PEP+S616)]  
uPD78F0134M1GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M1GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M1GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M1GC@LQFP64 [(PEP+S621)]  
uPD78F0134M1GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M1GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M1GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M1GK@TQFP64 [(PEP+S680)]  
uPD78F0134M1GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M1GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M1GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M2GB@LQFP64 [(PEP+S616)]  
uPD78F0134M2GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M2GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M2GC@LQFP64 [(PEP+S621)]  
uPD78F0134M2GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M2GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M2GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M2GK@TQFP64 [(PEP+S680)]  
uPD78F0134M2GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M2GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M2GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M3GB@LQFP64 [(PEP+S616)]  
uPD78F0134M3GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M3GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M3GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M3GC@LQFP64 [(PEP+S621)]  
uPD78F0134M3GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M3GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M3GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M3GK@TQFP64 [(PEP+S680)]  
uPD78F0134M3GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M3GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M3GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M4GB@LQFP64 [(PEP+S616)]  
uPD78F0134M4GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M4GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M4GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M4GC@LQFP64 [(PEP+S621)]  
uPD78F0134M4GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M4GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M4GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M4GK@TQFP64 [(PEP+S680)]  
uPD78F0134M4GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M4GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M4GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M5GB@LQFP64 [(PEP+S616)]  
uPD78F0134M5GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M5GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M5GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M5GC@LQFP64 [(PEP+S621)]  
uPD78F0134M5GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M5GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M5GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M5GK@TQFP64 [(PEP+S680)]  
uPD78F0134M5GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M5GKA@TQFP64 [(PEP+S680)]

uPD78F0134M5GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M6GB@LQFP64 [(PEP+S616)]  
uPD78F0134M6GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M6GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M6GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M6GC@LQFP64 [(PEP+S621)]  
uPD78F0134M6GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M6GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M6GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M6GK@TQFP64 [(PEP+S680)]  
uPD78F0134M6GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M6GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M6GKA1@TQFP64 [(PEP+S680)]  
uPD78F0136HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0136HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0136HGB@LQFP64 [(PEP+S616)]  
uPD78F0136HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0136HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0136HGC@LQFP64 [(PEP+S621)]  
uPD78F0136HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0136HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0136HGK@LQFP64 [(PEP+S680)]  
uPD78F0138HDGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0138HDGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0138HDGB@LQFP64 [(PEP+S616)]  
uPD78F0138HDGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0138HDGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0138HDGC@LQFP64 [(PEP+S621)]  
uPD78F0138HDGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0138HDGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0138HDGK@LQFP64 [(PEP+S680)]  
uPD78F0138HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0138HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0138HGB@LQFP64 [(PEP+S616)]  
uPD78F0138HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0138HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0138HGC@LQFP64 [(PEP+S621)]  
uPD78F0138HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0138HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0138HGK@LQFP64 [(PEP+S680)]  
uPD78F0138M1GB@LQFP64 [(PEP+S616)]  
uPD78F0138M1GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M1GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M1GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M1GC@LQFP64 [(PEP+S621)]  
uPD78F0138M1GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M1GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M1GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M1GK@TQFP64 [(PEP+S680)]  
uPD78F0138M1GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M1GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M1GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M1GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M2GB@LQFP64 [(PEP+S616)]  
uPD78F0138M2GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M2GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M2GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M2GC@LQFP64 [(PEP+S621)]  
uPD78F0138M2GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M2GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M2GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M2GK@TQFP64 [(PEP+S680)]  
uPD78F0138M2GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M2GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M2GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M2GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M3GB@LQFP64 [(PEP+S616)]  
uPD78F0138M3GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M3GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M3GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M3GC@LQFP64 [(PEP+S621)]  
uPD78F0138M3GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M3GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M3GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M3GK@TQFP64 [(PEP+S680)]  
uPD78F0138M3GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M3GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M3GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M3GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M4GB@LQFP64 [(PEP+S616)]  
uPD78F0138M4GB\_A@LQFP64 [(PEP+S616)]

```

uPD78F0138M4GBA@LQFP64 [(PEP+S616)]
uPD78F0138M4GBA1@LQFP64 [(PEP+S616)]
uPD78F0138M4GC@LQFP64 [(PEP+S621)]
uPD78F0138M4GC_A@LQFP64 [(PEP+S621)]
uPD78F0138M4GCA@LQFP64 [(PEP+S621)]
uPD78F0138M4GCA1@LQFP64 [(PEP+S621)]
uPD78F0138M4GK@TQFP64 [(PEP+S680)]
uPD78F0138M4GK@TQFP64(*) [(SA739+B222)]
uPD78F0138M4GK_A@TQFP64 [(PEP+S680)]
uPD78F0138M4GKA@TQFP64 [(PEP+S680)]
uPD78F0138M4GKA1@TQFP64 [(PEP+S680)]
uPD78F0138M5GB@LQFP64 [(PEP+S616)]
uPD78F0138M5GB_A@LQFP64 [(PEP+S616)]
uPD78F0138M5GBA@LQFP64 [(PEP+S616)]
uPD78F0138M5GBA1@LQFP64 [(PEP+S616)]
uPD78F0138M5GC@LQFP64 [(PEP+S621)]
uPD78F0138M5GC_A@LQFP64 [(PEP+S621)]
uPD78F0138M5GCA@LQFP64 [(PEP+S621)]
uPD78F0138M5GCA1@LQFP64 [(PEP+S621)]
uPD78F0138M5GK@TQFP64 [(PEP+S680)]
uPD78F0138M5GK@TQFP64(*) [(SA739+B222)]
uPD78F0138M5GK_A@TQFP64 [(PEP+S680)]
uPD78F0138M5GKA@TQFP64 [(PEP+S680)]
uPD78F0138M5GKA1@TQFP64 [(PEP+S680)]
uPD78F0138M6GB@LQFP64 [(PEP+S616)]
uPD78F0138M6GB_A@LQFP64 [(PEP+S616)]
uPD78F0138M6GBA@LQFP64 [(PEP+S616)]
uPD78F0138M6GBA1@LQFP64 [(PEP+S616)]
uPD78F0138M6GC@LQFP64 [(PEP+S621)]
uPD78F0138M6GC_A@LQFP64 [(PEP+S621)]
uPD78F0138M6GCA@LQFP64 [(PEP+S621)]
uPD78F0138M6GCA1@LQFP64 [(PEP+S621)]
uPD78F0138M6GK@TQFP64 [(PEP+S680)]
uPD78F0138M6GK@TQFP64(*) [(SA739+B222)]
uPD78F0138M6GK_A@TQFP64 [(PEP+S680)]
uPD78F0138M6GKA@TQFP64 [(PEP+S680)]
uPD78F0138M6GKA1@TQFP64 [(PEP+S680)]
uPD78F013M2GBA@LQFP64 [(PEP+S616)]
uPD78F0500FC@FLGA36 [(4X4BGA)]
uPD78F0500MC@SSOP30 [(SA689)]
uPD78F0501MC(A)@SSOP30 [(SA689)]
uPD78F0502FC@FLGA36 [(4X4BGA)]
uPD78F0502MC@SSOP30 [(SA689)]
uPD78F0503DMC(A)@SSOP30 [(SA689)]
uPD78F0503DMC@SSOP30 [(SA689)]
uPD78F0503MC(A)@SSOP30 [(SA689)]
uPD78F0511GA(A)@TQFP48 [(SA248)]
uPD78F0511GA(A2)@TQFP48 [(SA248)]
uPD78F0511GA@TQFP48 [(SA248)]
uPD78F0511GB(A)@TQFP44 [(SA245A)]
uPD78F0511GB(A2)@TQFP44 [(SA245A)]
uPD78F0511GB@TQFP44 [(SA245A)]
uPD78F0511GB@TQFP44 [(SA245A)]
uPD78F0511MC@SSOP38 [(SA689)]
uPD78F0512GA(A)@TQFP48 [(SA248)]
uPD78F0512GA(A2)@TQFP48 [(SA248)]
uPD78F0512GA@TQFP48 [(SA248)]
uPD78F0512GB(A)@TQFP44 [(SA245A)]
uPD78F0512GB(A2)@TQFP44 [(SA245A)]
uPD78F0512GB@TQFP44 [(SA245A)]
uPD78F0512GB@TQFP44 [(SA245A)]
uPD78F0512MC@SSOP38 [(SA689)]
uPD78F0513DGA(A)@TQFP48 [(SA248)]
uPD78F0513DGA(A2)@TQFP48 [(SA248)]
uPD78F0513DGA@TQFP48 [(SA248)]
uPD78F0513DGB(A)@TQFP44 [(SA245A)]
uPD78F0513DGB(A2)@TQFP44 [(SA245A)]
uPD78F0513DGB@TQFP44 [(SA245A)]
uPD78F0513DGB@TQFP44 [(SA245A)]
uPD78F0513DMC@SSOP38 [(SA689)]
uPD78F0513GA(A)@TQFP48 [(SA248)]
uPD78F0513GA(A2)@TQFP48 [(SA248)]
uPD78F0513GA@TQFP48 [(SA248)]
uPD78F0513GB(A)@TQFP44 [(SA245A)]
uPD78F0513GB(A2)@TQFP44 [(SA245A)]
uPD78F0513GB@TQFP44 [(SA245A)]
uPD78F0513GB@TQFP44 [(SA245A)]
uPD78F0513MC@SSOP38 [(SA689)]
uPD78F0514GA(A)@TQFP48 [(SA248)]
uPD78F0514GA(A2)@TQFP48 [(SA248)]
uPD78F0514GA@TQFP48 [(SA248)]
uPD78F0514GB(A)@TQFP44 [(SA245A)]
uPD78F0514GB(A2)@TQFP44 [(SA245A)]
uPD78F0514GB@TQFP44 [(SA245A)]
uPD78F0514GB@TQFP44 [(SA245A)]
uPD78F0514MC@SSOP38 [(SA689)]
uPD78F0515GA(A)@TQFP48 [(SA248)]
uPD78F0515GA(A2)@TQFP48 [(SA248)]
uPD78F0515GA@TQFP48 [(SA248)]
uPD78F0515GB(A)@TQFP44 [(SA245A)]
uPD78F0515GB(A2)@TQFP44 [(SA245A)]

```

uPD78F0515GB@TQFP44 [(SA245A)]      uPD78F0515MC@SSOP38 [(SA689)]  
uPD78F0521GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0521GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0521GB@LQFP52 [(PEP+S673)]  
uPD78F0522GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0522GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0522GB@LQFP52 [(PEP+S673)]  
uPD78F0523DGB(A)@LQFP52 [(PEP+S673)]  
uPD78F0523DGB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0523DGB@LQFP52 [(PEP+S673)]  
uPD78F0523GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0523GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0523GB@LQFP52 [(PEP+S673)]  
uPD78F0524GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0524GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0524GB@LQFP52 [(PEP+S673)]  
uPD78F0525GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0525GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0525GB@LQFP52 [(PEP+S673)]  
uPD78F0526GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0526GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0526GB@LQFP52 [(PEP+S673)]  
uPD78F0527GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0527GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0527GB@LQFP52 [(PEP+S673)]  
uPD78F0531GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0531GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0531GB@LQFP64 [(PEP+S616)]  
uPD78F0531GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0531GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0531GC@LQFP64 [(PEP+S621)]  
uPD78F0531GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0531GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0531GK@LQFP64 [(PEP+S680)]  
uPD78F0532GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0532GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0532GB@LQFP64 [(PEP+S616)]  
uPD78F0532GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0532GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0532GC@LQFP64 [(PEP+S621)]  
uPD78F0532GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0532GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0532GK@LQFP64 [(PEP+S680)]  
uPD78F0533DGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0533DGB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0533DGB@LQFP64 [(PEP+S616)]  
uPD78F0533DGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0533DGC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0533DGC@LQFP64 [(PEP+S621)]  
uPD78F0533DGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0533DGK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0533DGK@LQFP64 [(PEP+S680)]  
uPD78F0533GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0533GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0533GB@LQFP64 [(PEP+S616)]  
uPD78F0533GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0533GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0533GC@LQFP64 [(PEP+S621)]  
uPD78F0533GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0533GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0533GK@LQFP64 [(PEP+S680)]  
uPD78F0534GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0534GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0534GB@LQFP64 [(PEP+S616)]  
uPD78F0534GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0534GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0534GC@LQFP64 [(PEP+S621)]  
uPD78F0534GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0534GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0534GK@LQFP64 [(PEP+S680)]  
uPD78F0535GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0535GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0535GB@LQFP64 [(PEP+S616)]  
uPD78F0535GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0535GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0535GC@LQFP64 [(PEP+S621)]  
uPD78F0535GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0535GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0535GK@LQFP64 [(PEP+S680)]  
uPD78F0536GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0536GB(A2)@LQFP64 [(PEP+S616)]

```

uPD78F0536GB@LQFP64 [(PEP+S616)]
uPD78F0536GC(A)@LQFP64 [(PEP+S621)]
uPD78F0536GC(A2)@LQFP64 [(PEP+S621)]
uPD78F0536GC@LQFP64 [(PEP+S621)]
uPD78F0536GK(A)@LQFP64 [(PEP+S680)]
uPD78F0536GK(A2)@LQFP64 [(PEP+S680)]
uPD78F0536GK@LQFP64 [(PEP+S680)]
uPD78F0537DGB(A)@LQFP64 [(PEP+S616)]
uPD78F0537DGB(A2)@LQFP64 [(PEP+S616)]
uPD78F0537DGB@LQFP64 [(PEP+S616)]
uPD78F0537DGC(A)@LQFP64 [(PEP+S621)]
uPD78F0537DGC(A2)@LQFP64 [(PEP+S621)]
uPD78F0537DGC@LQFP64 [(PEP+S621)]
uPD78F0537DGK(A)@LQFP64 [(PEP+S680)]
uPD78F0537DGK(A2)@LQFP64 [(PEP+S680)]
uPD78F0537DGK@LQFP64 [(PEP+S680)]
uPD78F0537GB(A)@LQFP64 [(PEP+S616)]
uPD78F0537GB(A2)@LQFP64 [(PEP+S616)]
uPD78F0537GB@LQFP64 [(PEP+S616)]
uPD78F0537GC(A)@LQFP64 [(PEP+S621)]
uPD78F0537GC(A2)@LQFP64 [(PEP+S621)]
uPD78F0537GC@LQFP64 [(PEP+S621)]
uPD78F0537GK(A)@LQFP64 [(PEP+S680)]
uPD78F0537GK(A2)@LQFP64 [(PEP+S680)]
uPD78F0537GK@LQFP64 [(PEP+S680)]
uPD78F0544GC(A)@LQFP80 [(PEP+S704)]
uPD78F0544GC(A2)@LQFP80 [(PEP+S704)]
uPD78F0544GC@LQFP80 [(PEP+S704)]
uPD78F0544GK(A)@LQFP80 [(PEP+S640B)]
uPD78F0544GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F0544GK@LQFP80 [(PEP+S640B)]
uPD78F0545GC(A)@LQFP80 [(PEP+S704)]
uPD78F0545GC(A2)@LQFP80 [(PEP+S704)]
uPD78F0545GC@LQFP80 [(PEP+S704)]
uPD78F0545GK(A)@LQFP80 [(PEP+S640B)]
uPD78F0545GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F0545GK@LQFP80 [(PEP+S640B)]
uPD78F0546GC(A)@LQFP80 [(PEP+S640B)]
uPD78F0546GC(A)@LQFP80(*) [(SA722+B219)]
uPD78F0546GC@LQFP80 [(PEP+S640B)]
uPD78F0546GC@LQFP80(*) [(SA722+B219)]
uPD78F0546GK(A)@LQFP80 [(PEP+S640B)]
uPD78F0546GK(A)@LQFP80(*) [(SA731+B219)]
uPD78F0546GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F0546GK@LQFP80 [(PEP+S640B)]
uPD78F0546GK@LQFP80(*) [(SA731+B219)]
uPD78F0547DGC(A)@LQFP80 [(PEP+S704)]
uPD78F0547DGC(A2)@LQFP80 [(PEP+S704)]
uPD78F0547DGC@LQFP80 [(PEP+S704)]
uPD78F0547DGK(A)@LQFP80 [(PEP+S640B)]
uPD78F0547DGK(A2)@LQFP80 [(PEP+S640B)]
uPD78F0547DGK@LQFP80 [(PEP+S640B)]
uPD78F0547GC(A)@LQFP80 [(PEP+S704)]
uPD78F0547GC(A2)@LQFP80 [(PEP+S704)]
uPD78F0547GC@LQFP80 [(PEP+S704)]
uPD78F0547GK(A)@LQFP80 [(PEP+S640B)]
uPD78F0547GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F0547GK@LQFP80 [(PEP+S640B)]
uPD78F0820B(A)@LQFP100(*) [(SA718+B221)]
uPD78F0820B@LQFP100(*) [(SA718+B221)]
uPD78F0822B(A)@LQFP100 [(PEP+S604)]
uPD78F0822B(A)@LQFP100(*) [(SA718+B221)]
uPD78F0822B@LQFP100 [(PEP+S604)]
uPD78F0822B@LQFP100(*) [(SA718+B221)]
uPD78F8500FC@FLGA36 [(4X4BGA)] uPD78F8500MC(A)@SSOP30 [(SA689)]
uPD78F8500MC@SSOP30 [(SA689)] uPD78F8501FC@FLGA36 [(4X4BGA)]
uPD78F8501MC(A)@SSOP30 [(SA689)] uPD78F8501MC@SSOP30 [(SA689)]
uPD78F8502FC@FLGA36 [(4X4BGA)] uPD78F8502MC(A)@SSOP30 [(SA689)]
uPD78F8502MC@SSOP30 [(SA689)] uPD78F8503DFC@FLGA36 [(4X4BGA)]
uPD78F8503DMC(A)@SSOP30 [(SA689)]
uPD78F8503DMC@SSOP30 [(SA689)] uPD78F8503FC@FLGA36 [(4X4BGA)]
uPD78F8503MC(A)@SSOP30 [(SA689)] uPD78F8503MC@SSOP30 [(SA689)]
uPD78F8511GA(A)@TQFP48 [(SA248)]
uPD78F8511GA(A2)@TQFP48 [(SA248)]
uPD78F8511GA@TQFP48 [(SA248)]
uPD78F8511GB(A)@TQFP44 [(SA245A)]
uPD78F8511GB(A2)@TQFP44 [(SA245A)]
uPD78F8511GB@TQFP44 [(SA245A)] uPD78F8511MC@SSOP38 [(SA689)]
uPD78F8512GA(A)@TQFP48 [(SA248)]
uPD78F8512GA(A2)@TQFP48 [(SA248)]
uPD78F8512GA@TQFP48 [(SA248)]

```



```

uPD78F8512GB(A)@TQFP44 [(SA245A)]
uPD78F8512GB(A2)@TQFP44 [(SA245A)]
uPD78F8512GB@TQFP44 [(SA245A)] uPD78F8512MC@SSOP38 [(SA689)]
uPD78F8513DGA(A)@TQFP48 [(SA248)]
uPD78F8513DGA(A2)@TQFP48 [(SA248)]
uPD78F8513DGA@TQFP48 [(SA248)]
uPD78F8513DGB(A)@TQFP44 [(SA245A)]
uPD78F8513DGB(A2)@TQFP44 [(SA245A)]
uPD78F8513DGB@TQFP44 [(SA245A)] uPD78F8513DMC@SSOP38 [(SA689)]
uPD78F8513GA(A)@TQFP48 [(SA248)]
uPD78F8513GA(A2)@TQFP48 [(SA248)]
uPD78F8513GA@TQFP48 [(SA248)]
uPD78F8513GB(A)@TQFP44 [(SA245A)]
uPD78F8513GB(A2)@TQFP44 [(SA245A)]
uPD78F8513GB@TQFP44 [(SA245A)] uPD78F8513MC@SSOP38 [(SA689)]
uPD78F8514GA(A)@TQFP48 [(SA248)]
uPD78F8514GA(A2)@TQFP48 [(SA248)]
uPD78F8514GA@TQFP48 [(SA248)]
uPD78F8514GB(A)@TQFP44 [(SA245A)]
uPD78F8514GB(A2)@TQFP44 [(SA245A)]
uPD78F8514GB@TQFP44 [(SA245A)] uPD78F8514MC@SSOP38 [(SA689)]
uPD78F8515GA(A)@TQFP48 [(SA248)]
uPD78F8515GA(A2)@TQFP48 [(SA248)]
uPD78F8515GA@TQFP48 [(SA248)]
uPD78F8515GB(A)@TQFP44 [(SA245A)]
uPD78F8515GB(A2)@TQFP44 [(SA245A)]
uPD78F8515GB@TQFP44 [(SA245A)] uPD78F8515MC@SSOP38 [(SA689)]
uPD78F8521GB(A)@LQFP52 [(PEP+S673)]
uPD78F8521GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8521GB@LQFP52 [(PEP+S673)]
uPD78F8522GB(A)@LQFP52 [(PEP+S673)]
uPD78F8522GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8522GB@LQFP52 [(PEP+S673)]
uPD78F8523DGB(A)@LQFP52 [(PEP+S673)]
uPD78F8523DGB(A2)@LQFP52 [(PEP+S673)]
uPD78F8523DGB@LQFP52 [(PEP+S673)]
uPD78F8523GB(A)@LQFP52 [(PEP+S673)]
uPD78F8523GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8523GB@LQFP52 [(PEP+S673)]
uPD78F8524GB(A)@LQFP52 [(PEP+S673)]
uPD78F8524GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8524GB@LQFP52 [(PEP+S673)]
uPD78F8525GB(A)@LQFP52 [(PEP+S673)]
uPD78F8525GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8525GB@LQFP52 [(PEP+S673)]
uPD78F8526GB(A)@LQFP52 [(PEP+S673)]
uPD78F8526GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8526GB@LQFP52 [(PEP+S673)]
uPD78F8527GB(A)@LQFP52 [(PEP+S673)]
uPD78F8527GB(A2)@LQFP52 [(PEP+S673)]
uPD78F8527GB@LQFP52 [(PEP+S673)]
uPD78F8531GB(A)@LQFP64 [(PEP+S616)]
uPD78F8531GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8531GB@LQFP64 [(PEP+S616)]
uPD78F8531GC(A)@LQFP64 [(PEP+S621)]
uPD78F8531GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8531GC@LQFP64 [(PEP+S621)]
uPD78F8531GK(A)@LQFP64 [(PEP+S680)]
uPD78F8531GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8531GK@LQFP64 [(PEP+S680)]
uPD78F8532GB(A)@LQFP64 [(PEP+S616)]
uPD78F8532GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8532GB@LQFP64 [(PEP+S616)]
uPD78F8532GC(A)@LQFP64 [(PEP+S621)]
uPD78F8532GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8532GC@LQFP64 [(PEP+S621)]
uPD78F8532GK(A)@LQFP64 [(PEP+S680)]
uPD78F8532GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8532GK@LQFP64 [(PEP+S680)]
uPD78F8533DGB(A)@LQFP64 [(PEP+S616)]
uPD78F8533DGB(A2)@LQFP64 [(PEP+S616)]
uPD78F8533DGB@LQFP64 [(PEP+S616)]
uPD78F8533DGC(A)@LQFP64 [(PEP+S621)]
uPD78F8533DGC(A2)@LQFP64 [(PEP+S621)]
uPD78F8533DGC@LQFP64 [(PEP+S621)]
uPD78F8533DGK(A)@LQFP64 [(PEP+S680)]
uPD78F8533DGK(A2)@LQFP64 [(PEP+S680)]
uPD78F8533DGK@LQFP64 [(PEP+S680)]
uPD78F8533GB(A)@LQFP64 [(PEP+S616)]
uPD78F8533GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8533GB@LQFP64 [(PEP+S616)]

```

```

uPD78F8533GC(A)@LQFP64 [(PEP+S621)]
uPD78F8533GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8533GC@LQFP64 [(PEP+S621)]
uPD78F8533GK(A)@LQFP64 [(PEP+S680)]
uPD78F8533GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8533GK@LQFP64 [(PEP+S680)]
uPD78F8534GB(A)@LQFP64 [(PEP+S616)]
uPD78F8534GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8534GB@LQFP64 [(PEP+S616)]
uPD78F8534GC(A)@LQFP64 [(PEP+S621)]
uPD78F8534GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8534GC@LQFP64 [(PEP+S621)]
uPD78F8534GK(A)@LQFP64 [(PEP+S680)]
uPD78F8534GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8534GK@LQFP64 [(PEP+S680)]
uPD78F8535GB(A)@LQFP64 [(PEP+S616)]
uPD78F8535GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8535GB@LQFP64 [(PEP+S616)]
uPD78F8535GC(A)@LQFP64 [(PEP+S621)]
uPD78F8535GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8535GC@LQFP64 [(PEP+S621)]
uPD78F8535GK(A)@LQFP64 [(PEP+S680)]
uPD78F8535GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8535GK@LQFP64 [(PEP+S680)]
uPD78F8536GB(A)@LQFP64 [(PEP+S616)]
uPD78F8536GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8536GB@LQFP64 [(PEP+S616)]
uPD78F8536GC(A)@LQFP64 [(PEP+S621)]
uPD78F8536GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8536GC@LQFP64 [(PEP+S621)]
uPD78F8536GK(A)@LQFP64 [(PEP+S680)]
uPD78F8536GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8536GK@LQFP64 [(PEP+S680)]
uPD78F8537DGB(A)@LQFP64 [(PEP+S616)]
uPD78F8537DGB(A2)@LQFP64 [(PEP+S616)]
uPD78F8537DGB@LQFP64 [(PEP+S616)]
uPD78F8537DGC(A)@LQFP64 [(PEP+S621)]
uPD78F8537DGC(A2)@LQFP64 [(PEP+S621)]
uPD78F8537DGC@LQFP64 [(PEP+S621)]
uPD78F8537DGK(A)@LQFP64 [(PEP+S680)]
uPD78F8537DGK(A2)@LQFP64 [(PEP+S680)]
uPD78F8537DGK@LQFP64 [(PEP+S680)]
uPD78F8537GB(A)@LQFP64 [(PEP+S616)]
uPD78F8537GB(A2)@LQFP64 [(PEP+S616)]
uPD78F8537GB@LQFP64 [(PEP+S616)]
uPD78F8537GC(A)@LQFP64 [(PEP+S621)]
uPD78F8537GC(A2)@LQFP64 [(PEP+S621)]
uPD78F8537GC@LQFP64 [(PEP+S621)]
uPD78F8537GK(A)@LQFP64 [(PEP+S680)]
uPD78F8537GK(A2)@LQFP64 [(PEP+S680)]
uPD78F8537GK@LQFP64 [(PEP+S680)]
uPD78F8544GC(A)@LQFP80 [(PEP+S704)]
uPD78F8544GC(A2)@LQFP80 [(PEP+S704)]
uPD78F8544GC@LQFP80 [(PEP+S704)]
uPD78F8544GK(A)@LQFP80 [(PEP+S640B)]
uPD78F8544GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F8544GK@LQFP80 [(PEP+S640B)]
uPD78F8545GC(A)@LQFP80 [(PEP+S704)]
uPD78F8545GC(A2)@LQFP80 [(PEP+S704)]
uPD78F8545GC@LQFP80 [(PEP+S704)]
uPD78F8545GK(A)@LQFP80 [(PEP+S640B)]
uPD78F8545GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F8545GK@LQFP80 [(PEP+S640B)]
uPD78F8546GK(A)@LQFP80 [(PEP+S640B)]
uPD78F8546GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F8546GK@LQFP80 [(PEP+S640B)]
uPD78F8547DGC(A)@LQFP80 [(PEP+S704)]
uPD78F8547DGC(A2)@LQFP80 [(PEP+S704)]
uPD78F8547DGC@LQFP80 [(PEP+S704)]
uPD78F8547DGK(A)@LQFP80 [(PEP+S640B)]
uPD78F8547DGK(A2)@LQFP80 [(PEP+S640B)]
uPD78F8547DGK@LQFP80 [(PEP+S640B)]
uPD78F8547GC(A)@LQFP80 [(PEP+S704)]
uPD78F8547GC(A2)@LQFP80 [(PEP+S704)]
uPD78F8547GC@LQFP80 [(PEP+S704)]
uPD78F8547GK(A)@LQFP80 [(PEP+S640B)]
uPD78F8547GK(A2)@LQFP80 [(PEP+S640B)]
uPD78F8547GK@LQFP80 [(PEP+S640B)]
uPD78F9026@SDIP42 [(SA028)]
uPD78F9026A@SDIP42 [(SA028)]
uPD78F9026B@SDIP42 [(SA028)]
uPD78F9026@TQFP44 [(SA245A)]
uPD78F9026A@TQFP44 [(SA245A)]
uPD78F9026B@TQFP44 [(SA245A)]

```

```

uPD78F9046@SDIP42 [(SA028)]          uPD78F9046@TQFP44 [(SA245A)]
uPD78F9046A@SDIP42 [(SA028)]        uPD78F9046A@TQFP44 [(SA245A)]
uPD78F9046B@SDIP42 [(SA028)]        uPD78F9046B@TQFP44 [(SA245A)]
uPD78F9076@SSOP30 [(SA689)]         uPD78F9076A@SSOP30 [(SA689)]
uPD78F9076AMC@SSOP30 [(SA689)]      uPD78F9076MC@SSOP30 [(SA689)]
uPD78P054FGC@QFP80 [(PEP+S615B)]
uPD78P054FGC@QFP80(*) [(SA722+B328)]
uPD78P054FGK@TQFP80 [(PEP+S640B)]
uPD78P054FGK@TQFP80(*) [(SA731+B218)]
uPD78P054GC@QFP80 [(PEP+S615B)]
uPD78P054GC@QFP80(*) [(SA722+B328)]
uPD78P054GK@TQFP80 [(PEP+S640B)]
uPD78P054GK@TQFP80(*) [(SA731+B218)]
uPD78P054YGC@QFP80 [(PEP+S615B)]
uPD78P054YGC@QFP80(*) [(SA722+B328)]
uPD78P054YGK@TQFP80 [(PEP+S640B)]
uPD78P054YGK@TQFP80(*) [(SA731+B218)]
uPD78P058FGC@QFP80 [(PEP+S615B)]
uPD78P058FGC@QFP80(*) [(SA722+B328)]
uPD78P058FGK@TQFP80 [(PEP+S640B)]
uPD78P058FGK@TQFP80(*) [(SA731+B218)]
uPD78P058GC@QFP80 [(PEP+S615B)]
uPD78P058GC@QFP80(*) [(SA722+B328)]
uPD78P058GK@TQFP80 [(PEP+S640B)]
uPD78P058GK@TQFP80(*) [(SA731+B218)]
uPD78P058YGC@QFP80 [(PEP+S615B)]
uPD78P058YGC@QFP80(*) [(SA722+B328)]
uPD78P058YGK@TQFP80 [(PEP+S640B)]
uPD78P058YGK@TQFP80(*) [(SA731+B218)]
uPD78P083@SDIP42 [(SA028)]          uPD78P083@TQFP44 [(SA245A)]
uPD78P083A@SDIP42 [(SA028)]         uPD78P083A@TQFP44 [(SA245A)]
uPD78P214CW@SDIP64 [(PEP+S600A)]    uPD78P4038GC@QFP80 [(PEP+S615B)]
uPD78P4038GC-A@QFP80 [(PEP+S615B)]
uPD78P4038GK@TQFP80 [(PEP+S640B)]
uPD78P4038GK-A@TQFP80 [(PEP+S640B)]
uPD78P9014CT@SDIP28 [(SA022A)]     uPD78P9014GT@SOIC28 [(SA404)]
uPD8741A                             uPD8748
uPD8748H                             uPD8748HD
uPD8749H

```

## NEXFLASH

### E(E) PROM/FRAM/NVRAM

```

NX25B40(Bottom Boot)@MLP8 [(SA683)]
NX25B40(Bottom Boot)@SOIC8 [(SA602A)]
NX25B40(Top Boot)@MLP8 [(SA683)]
NX25B40(Top Boot)@SOIC8 [(SA602A)]
NX25P10@MLP8 [(SA683)]              NX25P10@SOIC8 [(SA602A)]
NX25P16@MLP8 [(SA683)]              NX25P16@MLP8(ISP) [ISP-HEADER01]
NX25P16@SOIC16 [(SA404)]
NX25P16@SOIC16(ISP) [ISP-HEADER01]
NX25P16@SOIC8 [(SA023A)]
NX25P16@SOIC8(ISP) [ISP-HEADER01]
NX25P20@MLP8 [(SA683)]              NX25P20@SOIC8 [(SA602A)]
NX25P32@MLP8 [(SA683)]              NX25P32@MLP8(ISP) [ISP-HEADER01]
NX25P32@SOIC16 [(SA404)]
NX25P32@SOIC16(ISP) [ISP-HEADER01]
NX25P40@MLP8 [(SA683)]              NX25P40@SOIC8 [(SA602A)]
NX25P64@MLP8 [(SA683)]              NX25P64@MLP8(ISP) [ISP-HEADER01]
NX25P64@SOIC16 [(SA404)]
NX25P64@SOIC16(ISP) [ISP-HEADER01]
NX25P80@MLP8 [(SA683)]              NX25P80@SOIC8 [(SA602A)]
NX29F010                             NX29F010@PLCC32 [(SA015A1T)]
NX29F010@TSOP32 [(SA410T)]

```

## NJRC

### E(E) PROM/FRAM/NVRAM

```

NJU26040V                             NJU26040V@SSOP32 [(SA626A)]

```

# NOVATEK

## MICROCONTROLLER

NT68F631@PLCC44 [(SA244)]	NT68F631@SDIP42 [(SA028)]
NT68F631ALG@PLCC44 [(SA244)]	NT68F631AUG@SDIP42 [(SA028)]
NT68F631L@PLCC44 [(SA244)]	NT68F631LG@PLCC44 [(SA244)]
NT68F631U@SDIP42 [(SA028)]	NT68F631UG@SDIP42 [(SA028)]
NT68F632@PLCC44 [(SA244)]	NT68F632@SDIP42 [(SA028)]
NT68F632ALG@PLCC44 [(SA244)]	NT68F632AUG@SDIP42 [(SA028)]
NT68F632L@PLCC44 [(SA244)]	NT68F632LG@PLCC44 [(SA244)]
NT68F632U@SDIP42 [(SA028)]	NT68F632UG@SDIP42 [(SA028)]
NT68F633@PLCC44 [(SA244)]	NT68F633@SDIP42 [(SA028)]
NT68F633L@PLCC44 [(SA244)]	NT68F633LG@PLCC44 [(SA244)]
NT68F633U@SDIP42 [(SA028)]	NT68F633UG@SDIP42 [(SA028)]
NT68F636@PLCC44 [(SA244)]	NT68F636@SDIP42 [(SA028)]
NT68F636L@PLCC44 [(SA244)]	NT68F636LG@PLCC44 [(SA244)]
NT68F636U@SDIP42 [(SA028)]	NT68F636UG@SDIP42 [(SA028)]
NT68F63L(0444)@PLCC44 [(SA244)]	NT68F63L(0444)@SDIP42 [(SA028)]
NT68F63L(0448)@PLCC44 [(SA244)]	NT68F63L(0448)@SDIP42 [(SA028)]
NT68F63L(0523)@PLCC44 [(SA244)]	NT68F63L(0523)@SDIP42 [(SA028)]
NT68F63L@PLCC44 [(SA244)]	NT68F63LA@PLCC44 [(SA244)]
NT68F63LG@PLCC44 [(SA244)]	NT68F63LGG@PLCC44 [(SA244)]
NT68F63U@SDIP42 [(SA028)]	NT68F63UA@SDIP42 [(SA028)]
NT68F63UG@SDIP42 [(SA028)]	NT68F63UGG@SDIP42 [(SA028)]

# NSC

## E(E) PROM/FRAM/NVRAM

2864	MM2716
MM2716E	NM24C02
NM24C02@SOIC8 [(SA602A)]	NM24C02@TSOP8 [(SA026)]
NM24C02L	NM24C02L@SOIC8 [(SA602A)]
NM24C02L@TSOP8 [(SA026)]	NM24C03
NM24C03@SOIC8 [(SA602A)]	NM24C03@TSOP8 [(SA026)]
NM24C04	NM24C04@SOIC8 [(SA602A)]
NM24C04@TSOP8 [(SA026)]	NM24C05
NM24C05@SOIC8 [(SA602A)]	NM24C05@TSOP8 [(SA026)]
NM24C08	NM24C08@SOIC8 [(SA602A)]
NM24C09	NM24C09@SOIC8 [(SA602A)]
NM24C16	NM24C16@SOIC8 [(SA602A)]
NM24C17	NM24C17@SOIC8 [(SA602A)]
NM25C04	NM25C04@SOIC16 [(SA602)]
NM25C04@SOIC8 [(SA602A)]	NM25C04@TSSOP14 [(SA026)]
NM25C04@TSSOP8 [(SA026)]	NM27C010
NM27C010@PLCC32 [(SA015A1T)]	NM27C010@TSOP32 [(SA410T)]
NM27C010Q	NM27C010Q@PLCC32 [(SA015A1T)]
NM27C010Q@TSOP32 [(SA410T)]	NM27C020
NM27C020@PLCC32 [(SA015A1T)]	NM27C020@TSOP32 [(SA410T)]
NM27C020Q	NM27C020Q@PLCC32 [(SA015A1T)]
NM27C020Q@TSOP32 [(SA410T)]	NM27C040
NM27C040@PLCC32 [(SA015A1T)]	NM27C040@TSOP32 [(SA410T)]
NM27C1023	NM27C128
NM27C128@PLCC32 [(SA015A1T)]	NM27C210
NM27C210@PLCC44 [(SA244)]	NM27C210Q
NM27C210Q@PLCC44 [(SA244)]	NM27C240
NM27C240@PLCC44 [(SA244)]	NM27C256
NM27C256@PLCC32 [(SA015A1T)]	NM27C400
NM27C512	NM27C512@PLCC32 [(SA015A1T)]
NM27C512Q	NM27C512Q@PLCC32 [(SA015A1T)]
NM27C64Q	NM27C64Q@PLCC32 [(SA015A1T)]
NM27CP256	NM27CP256@PLCC32 [(SA015A1T)]
NM27LC010	NM27LC010@PLCC32 [(SA015A1T)]
NM27LC010@TSOP32 [(SA410T)]	NM27LC256
NM27LC256@PLCC32 [(SA015A1T)]	NM27LC512
NM27LC512@PLCC32 [(SA015A1T)]	NM27LC64
NM27LC64@PLCC32 [(SA015A1T)]	NM27LV010
NM27LV010@PLCC32 [(SA015A1T)]	NM27LV010@TSOP32 [(SA410T)]
NM27LV210	NM27LV210@PLCC44 [(SA244)]
NM27LV512	NM27LV512@PLCC32 [(SA015A1T)]
NM27LV512@TSOP32 [(SA410T)]	NM27P040
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32 [(SA410T)]
NM27P210	NM27P210@PLCC44 [(SA244)]
NM27P512	NM27P512@PLCC32 [(SA015A1T)]
NM59C11	NM59C11@SOIC8 [(SA602A)]

NM93C06(08bit)	NM93C06(08bit)@SOIC8 [(SA602A)]
NM93C06(16bit)	NM93C06(16bit)@SOIC8 [(SA602A)]
NM93C46	NM93C46@SOIC8 [(SA602A)]
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8 [(SA602A)]
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8 [(SA602A)]
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [(SA602A)]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C46L	NM93C46L@SOIC8 [(SA602A)]
NM93C46LZ	NM93C46LZ@SOIC8 [(SA602A)]
NM93C56	NM93C56@SOIC8 [(SA602A)]
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8 [(SA602A)]
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8 [(SA602A)]
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [(SA602A)]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(08bit)	
NM93C56ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(16bit)	
NM93C56ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C56L	NM93C56L@SOIC8 [(SA602A)]
NM93C56LZ	NM93C56LZ@SOIC8 [(SA602A)]
NM93C66	NM93C66@SOIC8 [(SA602A)]
NM93C66A	NM93C66A(08bit)
NM93C66A(08bit)@SOIC8 [(SA602A)]	NM93C66A@SOIC8 [(SA602A)]
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [(SA602A)]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C66L	NM93C66L@SOIC8 [(SA602A)]
NM93C66LZ	NM93C66LZ@SOIC8 [(SA602A)]
NM93C86(16bit)	NM93C86(16bit)@SOIC8 [(SA602A)]
NM93C86A	NM93C86A(08bit)
NM93C86A(08bit)@SOIC8 [(SA602A)]	NM93C86A@SOIC8 [(SA602A)]
NM93C86AL(08bit)	
NM93C86AL(08bit)@SOIC8 [(SA602A)]	
NM93C86AL(16bit)	
NM93C86AL(16bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(08bit)	
NM93C86ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(16bit)	
NM93C86ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C86L	NM93C86L@SOIC8 [(SA602A)]
NM93C86LZ	NM93C86LZ@SOIC8 [(SA602A)]
NM93CS06(M8)@SOIC8 [(SA602A)]	NM93CS06(MT8)@TSSOP8 [(SA026)]
NM93CS06(N)	NM93CS46(M8)@SOIC8 [(SA602A)]
NM93CS46(MT8)@TSSOP8 [(SA026)]	NM93CS46(N)
NM93CS56(M8)@SOIC8 [(SA602A)]	NM93CS56(MT8)@TSSOP8 [(SA026)]
NM93CS56(N)	NM93CS66(M8)@SOIC8 [(SA602A)]
NM93CS66(MT8)@TSSOP8 [(SA026)]	NM93CS66(N)
NMC2732	NMC2732B
NMC2732H	NMC27C010
NMC27C010@PLCC32 [(SA015A1T)]	NMC27C010@TSOP32 [(SA410T)]
NMC27C1024	NMC27C1024@PLCC44 [(SA244)]
NMC27C128B	NMC27C128B@PLCC32 [(SA015A1T)]
NMC27C128BN	NMC27C128BN@PLCC32 [(SA015A1T)]
NMC27C128BQ	NMC27C128BQ@PLCC32 [(SA015A1T)]
NMC27C128CQ	NMC27C128Q
NMC27C16	NMC27C16BQ
NMC27C16BQE	NMC27C16H
NMC27C16HQ	NMC27C16Q
NMC27C210	NMC27C210@PLCC44 [(SA244)]
NMC27C210Q	NMC27C210Q@PLCC44 [(SA244)]
NMC27C256B	NMC27C256B@PLCC32 [(SA015A1T)]
NMC27C256BN	NMC27C256BQE
NMC27C256BQM	NMC27C256Q
NMC27C256Q@PLCC32 [(SA015A1T)]	NMC27C32
NMC27C32B	NMC27C32BQ
NMC27C32E	NMC27C32EH
NMC27C32H	NMC27C512
NMC27C512@PLCC32 [(SA015A1T)]	NMC27C512A

NMC27C512A@PLCC32 [(SA015A1T)]	NMC27C512AN
NMC27C512AN@PLCC32 [(SA015A1T)]	NMC27C64
NMC27C64@PLCC32 [(SA015A1T)]	NMC27C64BN
NMC27C64N	NMC27CP128
NMC27CP256	NMC27CP64
NMC59C11	NMC59C11@SOIC8 [(SA602A)]
NMC87C257Q	NMC87C257Q@PLCC32
NMC87C257V	NMC87C257V@PLCC32
NMC9306	NMC9306@SOIC8 [(SA602A)]
NMC9307	NMC9307@SOIC8 [(SA602A)]
NMC9346	NMC9346@SOIC8 [(SA602A)]
NMC93C56	NMC93C56@SOIC14 [(SA602)]
NMC93C56@SOIC8 [(SA602A)]	NMC93C66
NMC93C66@SOIC14 [(SA602)]	NMC93C86A
NMC93C86A@SOIC14 [(SA602)]	NMC93C86A@SOIC8 [(SA602A)]
NMC93CS06(M14)@SOIC14 [(SA602)]	NMC93CS06(N)
NMC93CS46(M14)@SOIC14 [(SA602)]	NMC93CS46(N)
NMC93CS56(M14)@SOIC14 [(SA602)]	NMC93CS56(N)
NMC93CS66(M14)@SOIC14 [(SA602)]	NMC93CS66(N)
NMC93S06(M14)@SOIC14 [(SA602)]	NMC93S06(N)
NMC9817	NMC9817A
NS2816A	NS9816A

**BPROM**

DM54LS471	DM54LS471@PLCC20 [(SA001A)]
DM54S188	DM54S188A
DM54S287	DM54S287A
DM54S288	DM54S288A
DM54S387	DM54S387A
DM54S471	DM54S471@PLCC20 [(SA001A)]
DM54S472	DM54S472@PLCC20 [(SA001A)]
DM54S472A	DM54S472A@PLCC20 [(SA001A)]
DM54S472B	DM54S472B@PLCC20 [(SA001A)]
DM54S473	DM54S473@PLCC20 [(SA001A)]
DM54S473A	DM54S473A@PLCC20 [(SA001A)]
DM54S474	DM54S474A
DM54S474B	DM54S475
DM54S475A	DM54S570
DM54S570A	DM54S571
DM54S571A	DM54S571B
DM54S572	DM54S572A
DM54S573	DM54S573A
DM54S573B	DM74LS471
DM74LS471@PLCC20 [(SA001A)]	DM74S188
DM74S188A	DM74S287
DM74S287A	DM74S288
DM74S288A	DM74S387
DM74S387A	DM74S471
DM74S471@PLCC20 [(SA001A)]	DM74S472
DM74S472@PLCC20 [(SA001A)]	DM74S472A
DM74S472A@PLCC20 [(SA001A)]	DM74S472B
DM74S472B@PLCC20 [(SA001A)]	DM74S473
DM74S473@PLCC20 [(SA001A)]	DM74S473A
DM74S473A@PLCC20 [(SA001A)]	DM74S474
DM74S474A	DM74S474B
DM74S475	DM74S475A
DM74S570	DM74S570A
DM74S571	DM74S571A
DM74S571B	DM74S572
DM74S572A	DM74S573
DM74S573A	DM74S573B
DM77S184	DM77S185
DM77S185A	DM77S185B
DM87S184	DM87S185
DM87S185A	DM87S185B

**PLD**

GAL16V8	GAL16V8@PLCC20 [(SA001A)]
GAL16V8A	GAL16V8A@PLCC20 [(SA001A)]
GAL20V8	GAL20V8@PLCC28 [(SA008A)]
GAL20V8A	GAL20V8A@PLCC28 [(SA008A)]
GAL20V8QS	GAL20V8QS@PLCC28 [(SA008A)]
PAL20RA10	

**MICROCONTROLLER**

COP820 (CJMHD)	COP820 (CJMHEA)@SOIC28 [(SA404)]
COP822 (CJMHD)	COP842 (CMHD)
COP8640 (CMHD)	COP8640 (CMHEA)@SOIC28 [(SA404)]
COP8642 (CMHD)	COP8780 (CD)
COP8780 (CEL)@PLCC44 [(SA244)]	COP8780 (CJ)
COP8780 (CN)	COP8780 (CV)@PLCC44 [(SA244)]
COP8781 (CD)	COP8781 (CJ)
COP8781 (CMC)@SOIC28 [(SA404)]	COP8781 (CN)
COP8781 (CWM)@SOIC28 [(SA404)]	COP8782 (CD)
COP8782 (CJ)	COP8782 (CMC)@SOIC20 [(SA404)]
COP8782 (CN)	COP8782 (CWM)@SOIC20 [(SA404)]
COP87L20	COP87L20@SOIC28 [(SA404)]
COP87L22	COP87L22@SOIC20 [(SA404)]
COP87L40	COP87L40@SOIC28 [(SA404)]
COP87L42	COP87L42@SOIC20 [(SA404)]
COP87L84	COP87L84@SOIC28 [(SA404)]
COP87L84BC	COP87L84BC@SOIC28 [(SA404)]
COP87L88	COP87L88@PLCC44 [(SA244)]
COP87L88@PLCC68 [(PEP+S414T)]	COP87L88@TQFP44 [(SA245A)]
COP87L88EB@PLCC44 [(SA244)]	COP87L88EB@PLCC68 [(PEP+S414T)]
COP87L88GW@PLCC68 [(PEP+S414T)]	COP880 (CMHD)
COP880 (CMHEL)@PLCC44 [(SA244)]	COP881 (CMHD)
COP881 (CMHEA)@SOIC28 [(SA404)]	COP884 (CFMHD)
COP884 (CFMHEA)@SOIC28 [(SA404)]	COP884 (CGMHD)
COP884 (CGMHEA)@SOIC28 [(SA404)]	COP884 (CLMHD)
COP884 (CLMHEA)@SOIC28 [(SA404)]	COP884 (CSMHD)
COP884 (CSMHEA)@SOIC28 [(SA404)]	COP884 (EGMHD)
COP884 (EGMHEA)@SOIC28 [(SA404)]	COP888 (CFMHD)
COP888 (CFMHEL)@PLCC44 [(SA244)]	COP888 (CGMHD)
COP888 (CGMHEL)@PLCC44 [(SA244)]	COP888 (CLMHD)
COP888 (CLMHEL)@PLCC44 [(SA244)]	COP888 (CSMHD)
COP888 (CSMHEL)@PLCC44 [(SA244)]	COP888 (EGMHD)
COP888 (EGMHEL)@PLCC44 [(SA244)]	COP8ACC720
COP8ACC720@SOIC20 [(SA404)]	COP8ACC728
COP8ACC728@SOIC28 [(SA404)]	COP8ALE728
COP8ALE728@SOIC28 [(SA404)]	COP8AXE9
COP8AXE9@SOIC28 [(SA404)]	COP8CBE9@PLCC44 [(SA244)]
COP8CBE9@TQFP44 [(SA245)]	COP8CBR9@PLCC44 [(SA244)]
COP8CBR9@PLCC68 [(PEP+S414T)]	COP8CBR9@TQFP44 [(SA245)]
COP8CCE9@PLCC44 [(SA244)]	COP8CCE9@TQFP44 [(SA245)]
COP8CCR9@PLCC44 [(SA244)]	COP8CCR9@PLCC68 [(PEP+S414T)]
COP8CCR9@TQFP44 [(SA245)]	COP8CDR9@PLCC44 [(SA244)]
COP8CDR9@PLCC68 [(PEP+S414T)]	COP8CDR9@TQFP44 [(SA245)]
COP8CX9@PLCC44 [(SA244)]	COP8CXG9@PLCC44 [(SA244)]
COP8SAA716	COP8SAA716@SOIC16 [(SA404)]
COP8SAA720	COP8SAA720@SOIC20 [(SA404)]
COP8SAA728	COP8SAA728@PLCC28 [(SA008A)]
COP8SAA728@SOIC28 [(SA404)]	COP8SAA740
COP8SAA740@SOIC40 [(SA638)]	COP8SAA744@PLCC44 [(SA244)]
COP8SAA744@TQFP44 [(SA245A)]	COP8SAB716
COP8SAB716@SOIC16 [(SA404)]	COP8SAB720
COP8SAB720@SOIC20 [(SA404)]	COP8SAB728
COP8SAB728@PLCC28 [(SA008A)]	COP8SAB728@SOIC28 [(SA404)]
COP8SAB740	COP8SAB740@SOIC40 [(SA638)]
COP8SAB744@PLCC44 [(SA244)]	COP8SAB744@TQFP44 [(SA245A)]
COP8SAC716	COP8SAC716@SOIC16 [(SA404)]
COP8SAC720	COP8SAC720@SOIC20 [(SA404)]
COP8SAC728	COP8SAC728@PLCC28 [(SA008A)]
COP8SAC728@SOIC28 [(SA404)]	COP8SAC740
COP8SAC740@SOIC40 [(SA638)]	COP8SAC744@PLCC44 [(SA244)]
COP8SAC744@TQFP44 [(SA245A)]	COP8SBE9@PLCC44 [(SA244)]
COP8SBE9@PLCC68 [(PEP+S414T)]	COP8SBR9@PLCC44 [(SA244)]
COP8SBR9@PLCC68 [(PEP+S414T)]	COP8SBR9@TQFP44 [(SA245)]
COP8SCE9@PLCC44 [(SA244)]	COP8SCE9@PLCC68 [(PEP+S414T)]
COP8SCR9@PLCC44 [(SA244)]	COP8SCR9@PLCC68 [(PEP+S414T)]
COP8SCR9@TQFP44 [(SA245)]	COP8SDR9@PLCC44 [(SA244)]
COP8SDR9@PLCC68 [(PEP+S414T)]	COP8SDR9@TQFP44 [(SA245)]
COP8SGE720	COP8SGE720@SOIC20 [(SA404)]
COP8SGE728	COP8SGE728@SOIC28 [(SA404)]
COP8SGE740	COP8SGE740@SOIC40 [(SA638)]
COP8SGE744@PLCC44 [(SA244)]	COP8SGE744@TQFP44 [(SA245A)]
COP8SGR720	COP8SGR720@SOIC20 [(SA404)]
COP8SGR728	COP8SGR728@SOIC28 [(SA404)]
COP8SGR740	COP8SGR740@SOIC40 [(SA638)]
COP8SGR744@PLCC44 [(SA244)]	COP8SGR744@TQFP44 [(SA245A)]
COP943 (CMHD)	

NTE

**E(E) PROM/FRAM/NVRAM**

NTE2532 NTE2532A  
NTE25L32

**NUMONYX****E(E) PROM/FRAM/NVRAM**

JS28F256J3C@TSOP56 [(SA628-B018)]  
JS28F256J3D@TSOP56 [(SA628-B018)]  
M25PX32@SOIC16 [(SA404)] M25PX32@SOIC8 [(SA023A)]  
M25PX32@VDFPN8 [(SA683)] M25PX64@SOIC16 [(SA404)]  
M25PX64@TBGA24 [(SA778)] M25PX64@VDFPN8 [(SA684)]  
N25Q128@BGA24 [(SA778)] N25Q128@SOIC16 [(SA404)]  
N25Q128@VDFPN8 [(SA684)]  
PC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
PC28F256J3D@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256J3D@FBGA64 [(SA655M-B054A-T064F001Y)]  
TE28F256J3C@TSOP56 [(SA628-B018)]  
TE28F256J3D@TSOP56 [(SA628-B018)]

**NUVOTON****MICROCONTROLLER**

N79E342AKG N79E342ASG@SOP16 [(SA404)]  
N79E342RAKG N79E342RASG@SOP16 [(SA404)]  
N79E352AEG N79E352AFG@TQFP44 [(SA245)]  
N79E352ALG@TQFP48 [(SA248)] N79E352APG@PLCC44 [(SA244)]  
N79E8213AKG N79E8213ASG@SOP20 [(SA404)]  
N79E8213RAKG N79E8213RASG@SOP20 [(SA404)]  
W78E051C W78E051C@PLCC44 [(SA244)]  
W78E051C@TQFP44 [(SA245A)] W78E051DDG  
W78E051DFG@TQFP44 [(SA245A)]  
W78E051DLG@TQFP48 [(SA248A-B005)]  
W78E051DPG@PLCC44 [(SA244)] W78E052C  
W78E052C@PLCC44 [(SA244)] W78E052C@TQFP44 [(SA245A)]  
W78E052DDG W78E052DFG@TQFP44 [(SA245A)]  
W78E052DLG@TQFP48 [(SA248A-B005)]  
W78E052DPG@PLCC44 [(SA244)] W78E054C  
W78E054C@PLCC44 [(SA244)] W78E054C@TQFP44 [(SA245A)]  
W78E054DDG W78E054DFG@TQFP44 [(SA245A)]  
W78E054DLG@TQFP48 [(SA248A-B005)]  
W78E054DPG@PLCC44 [(SA244)] W78E058DDG  
W78E058DFG@TQFP44 [(SA245A)]  
W78E058DLG@TQFP48 [(SA248A-B005)]  
W78E058DPG@PLCC44 [(SA244)] W78E516DDG  
W78E516DFG@TQFP44 [(SA245A)]  
W78E516DLG@TQFP48 [(SA248A-B005)]  
W78E516DPG@PLCC44 [(SA244)] W78E51C  
W78E51C@PLCC44 [(SA244)] W78E51C@TQFP44 [(SA245A)]  
W78E52C W78E52C@PLCC44 [(SA244)]  
W78E52C@TQFP44 [(SA245A)] W78E54C  
W78E54C@PLCC44 [(SA244)] W78E54C@TQFP44 [(SA245A)]  
W78I051DDG W78I051DFG@TQFP44 [(SA245A)]  
W78I051DLG@TQFP48 [(SA248A-B005)]  
W78I051DPG@PLCC44 [(SA244)] W78I052DDG  
W78I052DFG@TQFP44 [(SA245A)]  
W78I052DLG@TQFP48 [(SA248A-B005)]  
W78I052DPG@PLCC44 [(SA244)] W78I054DDG  
W78I054DFG@TQFP44 [(SA245A)]  
W78I054DLG@TQFP48 [(SA248A-B005)]  
W78I054DPG@PLCC44 [(SA244)] W78L051C  
W78L051C@PLCC44 [(SA244)] W78L051C@TQFP44 [(SA245A)]  
W78L052C W78L052C@PLCC44 [(SA244)]  
W78L052C@TQFP44 [(SA245A)] W78L054C  
W78L054C@PLCC44 [(SA244)] W78L054C@TQFP44 [(SA245A)]  
W78LE51C W78LE51C@PLCC44 [(SA244)]  
W78LE51C@TQFP44 [(SA245A)] W78LE52C  
W78LE52C@PLCC44 [(SA244)] W78LE52C@TQFP44 [(SA245A)]  
W78LE54C W78LE54C@PLCC44 [(SA244)]



W78LE54C@TQFP44 [(SA245A)]  
 W83L951ADG@LQFP128(\*) [(TA056-B006)]

## NXP

### MICROCONTROLLER

LPC2101FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2102FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2103FA44@PLCC44(\*) [(SA244-B4403)]  
 LPC2103FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2104BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2105BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2106BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2114FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2119FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2124FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2129FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2132FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2132FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2134FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2134FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2136FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2136FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2138FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2138FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2141FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2141FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2142FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2142FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2144FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2144FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2146FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2146FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2148FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2148FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2194HBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2212HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2214FBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2214HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2292FBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2292HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2294FBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2294HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2364@LQFP100(\*) [(SA718+B243)]  
 LPC2365@LQFP100(\*) [(SA718+B243)]  
 LPC2366@LQFP100(\*) [(SA718+B243)]  
 LPC2366@LQFP100(\*) (new) [(SA718+B243)]  
 LPC2368@LQFP100(\*) [(SA718+B243)]  
 LPC2368@LQFP100(\*) (new) [(SA773+B243)]  
 P83C660X2@PLCC44 [(SA244)] P83C660X2@TQFP44 [(SA245A)]  
 P83C661X2@PLCC44 [(SA244)] P83C661X2@TQFP44 [(SA245A)]  
 P87C054@SDIP42 [(SA028)] P87C055@SDIP42 [(SA028)]  
 P87C451@PLCC68 [(PEP+S414T)] P87C451@SDIP64 [(PEP+S600A)]  
 P87C453@PLCC68 [(PEP+S414T)] P87C51  
 P87C51@PLCC44 [(SA244)] P87C51@TQFP44 [(SA245A)]  
 P87C51FA P87C51FA@PLCC44 [(SA244)]  
 P87C51FA@TQFP44 [(SA245A)] P87C51FB  
 P87C51FB@PLCC44 [(SA244)] P87C51FB@TQFP44 [(SA245A)]  
 P87C51FC P87C51FC@PLCC44 [(SA244)]  
 P87C51FC@TQFP44 [(SA245A)] P87C51MA2@PLCC44 [(SA244)]  
 P87C51MB2@PLCC44 [(SA244)] P87C51MC2@PLCC44 [(SA244)]  
 P87C51RA+ P87C51RA+@PLCC44 [(SA244)]  
 P87C51RA+@TQFP44 [(SA245A)] P87C51RA2  
 P87C51RA2@PLCC44 [(SA244)] P87C51RA2@TQFP44 [(SA245A)]  
 P87C51RB+ P87C51RB+@PLCC44 [(SA244)]  
 P87C51RB+@TQFP44 [(SA245A)] P87C51RB2  
 P87C51RB2@PLCC44 [(SA244)] P87C51RB2@TQFP44 [(SA245A)]  
 P87C51RC+ P87C51RC+@PLCC44 [(SA244)]  
 P87C51RC+@TQFP44 [(SA245A)] P87C51RC2  
 P87C51RC2@PLCC44 [(SA244)] P87C51RC2@TQFP44 [(SA245A)]  
 P87C51RD+ P87C51RD+@PLCC44 [(SA244)]  
 P87C51RD+@TQFP44 [(SA245A)] P87C51RD2  
 P87C51RD2@PLCC44 [(SA244)] P87C51RD2@TQFP44 [(SA245A)]  
 P87C51SB P87C51SB@PLCC44 [(SA244)]

P87C51SB@TQFP44 [(SA245A)]	P87C51SF
P87C51SF@PLCC44 [(SA244)]	P87C51SF@TQFP44 [(SA245A)]
P87C51UB	P87C51UB@PLCC44 [(SA244)]
P87C51UB@TQFP44 [(SA245A)]	P87C51UF
P87C51UF@PLCC44 [(SA244)]	P87C51UF@TQFP44 [(SA245A)]
P87C51X2	P87C51X2@PLCC44 [(SA244)]
P87C51X2@TQFP44 [(SA245A)]	P87C52
P87C52@PLCC44 [(SA244)]	P87C52@TQFP44 [(SA245A)]
P87C524	P87C524@PLCC44 [(SA244)]
P87C524@TQFP44 [(SA245A)]	P87C528
P87C528@PLCC44 [(SA244)]	P87C528@TQFP44 [(SA245A)]
P87C52SB	P87C52SB@PLCC44 [(SA244)]
P87C52SB@TQFP44 [(SA245A)]	P87C52SF
P87C52SF@PLCC44 [(SA244)]	P87C52SF@TQFP44 [(SA675)]
P87C52UB	P87C52UB@PLCC44 [(SA244)]
P87C52UB@TQFP44 [(SA245A)]	P87C52UF
P87C52UF@PLCC44 [(SA244)]	P87C52UF@TQFP44 [(SA245A)]
P87C52X2	P87C52X2@PLCC44 [(SA244)]
P87C52X2@TQFP44 [(SA245A)]	P87C54
P87C54@PLCC44 [(SA244)]	P87C54@TQFP44 [(SA245A)]
P87C54SB	P87C54SB@PLCC44 [(SA244)]
P87C54SB@TQFP44 [(SA245A)]	P87C54SF
P87C54SF@PLCC44 [(SA244)]	P87C54SF@TQFP44 [(SA245A)]
P87C54UB	P87C54UB@PLCC44 [(SA244)]
P87C54UB@TQFP44 [(SA245A)]	P87C54UF
P87C54UF@PLCC44 [(SA244)]	P87C54UF@TQFP44 [(SA245A)]
P87C54X2	P87C54X2@PLCC44 [(SA244)]
P87C54X2@TQFP44 [(SA245A)]	P87C550
P87C550@PLCC44 [(SA244)]	P87C552@PLCC68 (*) [(SA648-B6806)]
P87C552@PLCC68 (*) [(SA648-B6806)]	P87C554@LQFP64 [(PEP+S616)]
P87C554@LQFP64 [(PEP+S616)]	P87C554@PLCC68 (*) [(SA648-B6806)]
P87C554@PLCC68 (*) [(SA648-B6806)]	P87C557E8@PQFP80 [(PEP+S611A)]
P87C557E8@PQFP80 [(PEP+S611A)]	P87C575@PLCC44 [(SA244)]
P87C575@PLCC44 [(SA244)]	P87C576
P87C576	P87C576@TQFP44 [(SA245A)]
P87C576@TQFP44 [(SA245A)]	P87C58@PLCC44 [(SA244)]
P87C58@PLCC44 [(SA244)]	P87C58SB
P87C58SB	P87C58SB@TQFP44 [(SA245A)]
P87C58SB@TQFP44 [(SA245A)]	P87C58UB@PLCC44 [(SA244)]
P87C58UB@PLCC44 [(SA244)]	P87C58X2
P87C58X2	P87C58X2@TQFP44 [(SA245A)]
P87C58X2@TQFP44 [(SA245A)]	P87C591@PLCC44 [(SA244)]
P87C591@PLCC44 [(SA244)]	P87C592@PLCC68 [(PEP+S414T)]
P87C592@PLCC68 [(PEP+S414T)]	P87C652@PLCC44 [(SA244)]
P87C652@PLCC44 [(SA244)]	P87C654
P87C654	P87C654@TQFP44 [(SA245A)]
P87C654@TQFP44 [(SA245A)]	P87C660X2@TQFP44 [(SA245A)]
P87C660X2@TQFP44 [(SA245A)]	P87C661X2@TQFP44 [(SA245A)]
P87C661X2@TQFP44 [(SA245A)]	P87C748@PLCC28 [(SA008A)]
P87C748@PLCC28 [(SA008A)]	P87C749@PLCC28 [(SA008A)]
P87C749@PLCC28 [(SA008A)]	P87C750@PLCC28 [(SA008A)]
P87C750@PLCC28 [(SA008A)]	P87C751
P87C751	P87C751@SSOP24 [(SA626A)]
P87C751@SSOP24 [(SA626A)]	P87C752@PLCC28 [(SA008A)]
P87C752@PLCC28 [(SA008A)]	P87C754
P87C754	P87C754@SSOP28 [(SA626A)]
P87C754@SSOP28 [(SA626A)]	P87CL52X2@PLCC44 [(SA244)]
P87CL52X2@PLCC44 [(SA244)]	P87CL54X2
P87CL54X2	P87CL54X2@TQFP44 [(SA245A)]
P87CL54X2@TQFP44 [(SA245A)]	P87L51FA@PLCC44 [(SA244)]
P87L51FA@PLCC44 [(SA244)]	P87L51FB
P87L51FB	P87L51FB@TQFP44 [(SA245A)]
P87L51FB@TQFP44 [(SA245A)]	P87LPC759 (ISP) [ISP-HEADER01]
P87LPC759 (ISP) [ISP-HEADER01]	P87LPC760 (ISP) [ISP-HEADER01]
P87LPC760 (ISP) [ISP-HEADER01]	P87LPC761 (ISP) [ISP-HEADER01]
P87LPC761 (ISP) [ISP-HEADER01]	P87LPC762 (ISP) [ISP-HEADER01]
P87LPC762 (ISP) [ISP-HEADER01]	P87LPC762@PLCC44 [(SA244)]
P87LPC762@PLCC44 [(SA244)]	P87LPC762@PLCC44 (ISP) [ISP-HEADER01]
P87LPC762@PLCC44 (ISP) [ISP-HEADER01]	P87LPC762@SOIC20 [(SA404)]
P87LPC762@SOIC20 [(SA404)]	P87LPC762@SOIC20 (ISP) [ISP-HEADER01]
P87LPC762@SOIC20 (ISP) [ISP-HEADER01]	P87LPC764 (ISP) [ISP-HEADER01]
P87LPC764 (ISP) [ISP-HEADER01]	P87LPC764@PLCC44 [(SA244)]
P87LPC764@PLCC44 [(SA244)]	P87LPC764@PLCC44 (ISP) [ISP-HEADER01]
P87LPC764@PLCC44 (ISP) [ISP-HEADER01]	P87LPC764@SOIC20 [(SA404)]
P87LPC764@SOIC20 [(SA404)]	P87LPC764@SOIC20 (ISP) [ISP-HEADER01]
P87LPC764@SOIC20 (ISP) [ISP-HEADER01]	P87LPC764@TSSOP20 [(SA643)]
P87LPC764@TSSOP20 [(SA643)]	P87LPC764@TSSOP20 (ISP) [ISP-HEADER01]
P87LPC764@TSSOP20 (ISP) [ISP-HEADER01]	P87LPC767
P87LPC767	P87LPC767 (ISP) [ISP-HEADER01]
P87LPC767 (ISP) [ISP-HEADER01]	P87LPC767@PLCC44 [(SA244)]
P87LPC767@PLCC44 [(SA244)]	

```

P87LPC767@PLCC44 (ISP) [ISP-HEADER01]
P87LPC767@SOIC20 [(SA404)]
P87LPC767@SOIC20 (ISP) [ISP-HEADER01]
P87LPC768                                P87LPC768 (ISP) [ISP-HEADER01]
P87LPC768@SOIC20 [(SA404)]
P87LPC768@SOIC20 (ISP) [ISP-HEADER01]
P87LPC769                                P87LPC769 (ISP) [ISP-HEADER01]
P87LPC769@PLCC44 [(SA244)]
P87LPC769@PLCC44 (ISP) [ISP-HEADER01]
P87LPC769@SOIC20 [(SA404)]
P87LPC769@SOIC20 (ISP) [ISP-HEADER01]
P87LPC778                                P87LPC778 (ISP) [ISP-HEADER01]
P87LPC778@TSSOP20 [(SA026)]
P87LPC778@TSSOP20 (ISP) [ISP-HEADER01]
P87LPC779                                P87LPC779 (ISP) [ISP-HEADER01]
P87LPC779@TSSOP20 [(SA643)]
P87LPC779@TSSOP20 (ISP) [ISP-HEADER01]
P89C138                                P89C138@PLCC44 [(SA244)]
P89C138@TQFP44 [(SA245A)]
P89C238@PLCC44 [(SA244)]
P89C238                                P89C238
P89C238@TQFP44 [(SA245A)]
P89C51B                                P89C51B@PLCC44 [(SA244)]
P89C51B@TQFP44 [(SA245A)]
P89C51RA+@PLCC44 [(SA244)]
P89C51RA+                                P89C51RA+
P89C51RA+@TQFP44 [(SA245A)]
P89C51RA2B                                P89C51RA2B@PLCC44 [(SA244)]
P89C51RA2B@TQFP44 [(SA245A)]
P89C51RB+@PLCC44 [(SA244)]
P89C51RB+                                P89C51RB+
P89C51RB+@TQFP44 [(SA245A)]
P89C51RB2B                                P89C51RB2B@PLCC44 [(SA244)]
P89C51RB2B@TQFP44 [(SA245A)]
P89C51RB2H@PLCC44 [(SA244)]
P89C51RB2H                                P89C51RB2H
P89C51RB2H@TQFP44 [(SA245A)]
P89C51RC+                                P89C51RC+@PLCC44 [(SA244)]
P89C51RC+@TQFP44 [(SA245A)]
P89C51RC2B@PLCC44 [(SA244)]
P89C51RC2B                                P89C51RC2B
P89C51RC2B@TQFP44 [(SA245A)]
P89C51RC2H@PLCC44 [(SA244)]
P89C51RC2H                                P89C51RC2H
P89C51RC2H@TQFP44 [(SA245A)]
P89C51RD+@PLCC44 [(SA244)]
P89C51RD+                                P89C51RD+
P89C51RD+@TQFP44 [(SA245A)]
P89C51RD2B                                P89C51RD2B@PLCC44 [(SA244)]
P89C51RD2B@TQFP44 [(SA245A)]
P89C51RD2H@PLCC44 [(SA244)]
P89C51RD2H                                P89C51RD2H
P89C51RD2H@TQFP44 [(SA245A)]
P89C51UB                                P89C51UB@PLCC44 [(SA244)]
P89C51UB@TQFP44 [(SA245A)]
P89C51UF@PLCC44 [(SA244)]
P89C51UF                                P89C51UF
P89C51UF@TQFP44 [(SA245A)]
P89C51X2                                P89C51X2@PLCC44 [(SA244)]
P89C51X2@TQFP44 [(SA245A)]
P89C51X2B                                P89C51X2B
P89C51X2B@PLCC44 [(SA244)]
P89C51X2B@TQFP44 [(SA245A)]
P89C51X2F                                P89C51X2F@PLCC44 [(SA244)]
P89C51X2F@TQFP44 [(SA245A)]
P89C52@PLCC44 [(SA244)]
P89C52                                P89C52
P89C52@TQFP44 [(SA245A)]
P89C52B@PLCC44 [(SA244)]
P89C52B                                P89C52B
P89C52B@TQFP44 [(SA245A)]
P89C52UB@PLCC44 [(SA244)]
P89C52UB                                P89C52UB
P89C52UB@TQFP44 [(SA245A)]
P89C52UF@PLCC44 [(SA244)]
P89C52UF                                P89C52UF
P89C52UF@TQFP44 [(SA245A)]
P89C52X2@PLCC44 [(SA244)]
P89C52X2                                P89C52X2
P89C52X2@TQFP44 [(SA245A)]
P89C52X2B@PLCC44 [(SA244)]
P89C52X2B                                P89C52X2B
P89C52X2B@TQFP44 [(SA245A)]
P89C52X2F                                P89C52X2F
P89C52X2F@TQFP44 [(SA245A)]
P89C536@PLCC44 [(SA244)]
P89C536                                P89C536
P89C536@PLCC44 [(SA244)]
P89C54                                P89C54
P89C54@TQFP44 [(SA245A)]
P89C54B@PLCC44 [(SA244)]
P89C54B                                P89C54B
P89C54B@TQFP44 [(SA245A)]
P89C54UB@PLCC44 [(SA244)]
P89C54UB                                P89C54UB
P89C54UB@TQFP44 [(SA245A)]
P89C54UF@PLCC44 [(SA244)]
P89C54UF                                P89C54UF
P89C54UF@TQFP44 [(SA245A)]
P89C54X2                                P89C54X2@PLCC44 [(SA244)]
P89C54X2@TQFP44 [(SA245A)]
P89C54X2B@PLCC44 [(SA244)]
P89C54X2B                                P89C54X2B
P89C54X2B@TQFP44 [(SA245A)]
P89C54X2F                                P89C54X2F@PLCC44 [(SA244)]
P89C54X2F@TQFP44 [(SA245A)]
P89C58@PLCC44 [(SA244)]
P89C58                                P89C58
P89C58@TQFP44 [(SA245A)]
P89C58B@PLCC44 [(SA244)]
P89C58B                                P89C58B
P89C58B@TQFP44 [(SA245A)]
P89C58UB@PLCC44 [(SA244)]
P89C58UB                                P89C58UB
P89C58UB@TQFP44 [(SA245A)]
P89C58UF@PLCC44 [(SA244)]
P89C58UF                                P89C58UF
P89C58UF@TQFP44 [(SA245A)]
P89C58X2@PLCC44 [(SA244)]
P89C58X2                                P89C58X2
P89C58X2@TQFP44 [(SA245A)]
P89C58X2B@PLCC44 [(SA244)]
P89C58X2B                                P89C58X2B
P89C58X2B@TQFP44 [(SA245A)]
P89C58X2F                                P89C58X2F
P89C58X2F@TQFP44 [(SA245A)]
P89C60X2                                P89C60X2@PLCC44 [(SA244)]
P89C60X2@TQFP44 [(SA245A)]
P89C61X2@PLCC44 [(SA244)]
P89C61X2                                P89C61X2
P89C61X2@TQFP44 [(SA245A)]

```

```

P89C660
P89C660@TQFP44 [(SA245A)]
P89C662@PLCC44 [(SA244)]
P89C664
P89C664@TQFP44 [(SA245A)]
P89C668@PLCC44 [(SA244)]
P89C669
P89C669@PLCC44 [(SA244)]
P89C738@PLCC44 [(SA244)]
P89C838
P89C838@TQFP44 [(SA245A)]
P89CV51RB2@TQFP44 [(SA245A)]
P89CV51RC2@TQFP44 [(SA245A)]
P89CV51RD2@TQFP44 [(SA245A)]
P89LPC901(FD)(ISP) [ISP-HEADER01]
P89LPC901(FN)
P89LPC901(FN)(ISP) [ISP-HEADER01]
P89LPC902(FD) [(SA602A)]
P89LPC902(FD)(ISP) [ISP-HEADER01]
P89LPC902(FN)
P89LPC902(FN)(ISP) [ISP-HEADER01]
P89LPC903(FD) [(SA602A)]
P89LPC903(FD)(ISP) [ISP-HEADER01]
P89LPC904(FD) [(SA605A)]
P89LPC904(FD)(ISP) [ISP-HEADER01]
P89LPC904(FN)
P89LPC904(FN)(ISP) [ISP-HEADER01]
P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9151(FDH)@TSSOP14 [(SA643)]
P89LPC9151(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC9161(FDH)@TSSOP16 [(SA643)]
P89LPC9161(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC9171(FDH)@TSSOP16 [(SA643)]
P89LPC9171(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC9201(FDH)@TSSOP20 [(SA643)]
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9201(FN)
P89LPC9201(FN)(ISP) [ISP-HEADER01]
P89LPC920A1(FDH)@TSSOP20 [(SA643)]
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920A1(FN)
P89LPC920A1(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC9211(FDH)@TSSOP20 [(SA643)]
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9211(FN)
P89LPC9211(FN)(ISP) [ISP-HEADER01]
P89LPC921A1(FDH)@TSSOP20 [(SA643)]
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89C660@PLCC44 [(SA244)]
P89C662
P89C662@TQFP44 [(SA245A)]
P89C664@PLCC44 [(SA244)]
P89C668
P89C668@TQFP44 [(SA245A)]
P89C669@LQFP44 [(SA245A)]
P89C738
P89C738@TQFP44 [(SA245A)]
P89C838@PLCC44 [(SA244)]
P89CV51RB2@PLCC44 [(SA244)]
P89CV51RC2@PLCC44 [(SA244)]
P89CV51RD2@PLCC44 [(SA244)]
P89LPC901(FD) [(SA602A)]

```

```

P89LPC921A1(FN)
P89LPC921A1(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221A1(FN)
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]
P89LPC922A1(FDH)@TSSOP20 [(SA643)]
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922A1(FN)
P89LPC922A1(FN)(ISP) [ISP-HEADER01]
P89LPC924(FDH)@TSSOP20 [(SA643)]
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924(FN)
P89LPC924(FN)(ISP) [ISP-HEADER01]
P89LPC9241(FDH)@TSSOP20 [(SA643)]
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9241(FN)
P89LPC9241(FN)(ISP) [ISP-HEADER01]
P89LPC924A1(FDH)@TSSOP20 [(SA643)]
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924A1(FN)
P89LPC924A1(FN)(ISP) [ISP-HEADER01]
P89LPC925(FDH)@TSSOP20 [(SA643)]
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925(FN)
P89LPC925(FN)(ISP) [ISP-HEADER01]
P89LPC9251(FDH)@TSSOP20 [(SA643)]
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9251(FN)
P89LPC9251(FN)(ISP) [ISP-HEADER01]
P89LPC925A1(FDH)@TSSOP20 [(SA643)]
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925A1(FN)
P89LPC925A1(FN)(ISP) [ISP-HEADER01]
P89LPC930(BA)@PLCC28 [(SA008A)]
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC930(BDH)@TSSOP28 [(SA643)]
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9301(BA)@PLCC28 [(SA008A)]
P89LPC9301(BDH)@TSSOP28 [(SA643)]
P89LPC931(BA)@PLCC28 [(SA008A)]
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC931(BDH)@TSSOP28 [(SA643)]
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9311(BA)@PLCC28 [(SA008A)]
P89LPC9311(BDH)@TSSOP28 [(SA643)]
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28 [(SA643)]
P89LPC93201(BA)@PLCC28 [(SA008A)]
P89LPC93201(BDH)@TSSOP28 [(SA643)]
P89LPC93201(FA)@PLCC28 [(SA008A)]
P89LPC93201(FDH)@TSSOP28 [(SA643)]
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(HDH)@TSSOP28 [(SA643)]
P89LPC9331(BDH)@TSSOP28 [(SA643)]
P89LPC9331(FDH)@TSSOP28 [(SA643)]
P89LPC9331(HDH)@TSSOP28 [(SA643)]

```

P89LPC934 (BDH)@TSSOP28 [(SA643)]  
P89LPC934 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC934 (FDH)@TSSOP28 [(SA643)]  
P89LPC934 (FDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC93401 (FDH)@TSSOP28 [(SA643)]  
P89LPC93401V  
P89LPC9341 (BDH)@TSSOP28 [(SA643)]  
P89LPC9341 (FDH)@TSSOP28 [(SA643)]  
P89LPC9341V P89LPC935 (BA)@PLCC28 [(SA008A)]  
P89LPC935 (BA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC935 (BDH)@TSSOP28 [(SA643)]  
P89LPC935 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC935 (FA)@PLCC28 [(SA008A)]  
P89LPC935 (FA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC935 (FDH)@TSSOP28 [(SA643)]  
P89LPC935 (FDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC935 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935 (FHN)@HVQFN28 (ISP) [ISP-HEADER01]  
P89LPC93501 (BA)@PLCC28 [(SA008A)]  
P89LPC93501 (BDH)@TSSOP28 [(SA643)]  
P89LPC93501 (FA)@PLCC28 [(SA008A)]  
P89LPC93501 (FDH)@TSSOP28 [(SA643)]  
P89LPC93501 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351 (BA)@PLCC28 [(SA008A)]  
P89LPC9351 (BDH)@TSSOP28 [(SA643)]  
P89LPC9351 (FA)@PLCC28 [(SA008A)]  
P89LPC9351 (FDH)@TSSOP28 [(SA643)]  
P89LPC9351 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936 (FA)@PLCC28 [(SA008A)]  
P89LPC936 (FA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC936 (FDH)@TSSOP28 [(SA643)]  
P89LPC936 (FDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC9361 (FA)@PLCC28 [(SA008A)]  
P89LPC9361 (FDH)@TSSOP28 [(SA643)]  
P89LPC938 (FA)@PLCC28 [(SA008A)]  
P89LPC938 (FA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC938 (FDH)@TSSOP28 [(SA643)]  
P89LPC938 (FDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC938 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938 (FHN)@HVQFN28 (ISP) [ISP-HEADER01]  
P89LPC93801 (BA)@PLCC28 [(SA008A)]  
P89LPC93801 (BDH)@TSSOP28 [(SA643)]  
P89LPC93801 (FA)@PLCC28 [(SA008A)]  
P89LPC93801 (FDH)@TSSOP28 [(SA643)]  
P89LPC93801 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381 (BA)@PLCC28 [(SA008A)]  
P89LPC9381 (BDH)@TSSOP28 [(SA643)]  
P89LPC9381 (FA)@PLCC28 [(SA008A)]  
P89LPC9381 (FDH)@TSSOP28 [(SA643)]  
P89LPC9381 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401 (FBD)@LQFP64 [(PEP+S616)]  
P89LPC9401 (FBD)@LQFP64 (ISP) [ISP-HEADER01]  
P89LPC9402 (FBD)@LQFP64 [(PEP+S616)]  
P89LPC9402 (FBD)@LQFP64 (ISP) [ISP-HEADER01]  
P89LPC9408 (FBD)@LQFP64 [(PEP+S625)]  
P89LPC9408 (FBD)@LQFP64 (ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44 (ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48 (ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44 (ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]  
P89LPC954@LQFP44 (ISP) [ISP-HEADER01]  
P89LPC954@LQFP48 [(SA248)]  
P89LPC954@LQFP48 (ISP) [ISP-HEADER01]  
P89LPC954@PLCC44 [(SA244)]  
P89LPC954@PLCC44 (ISP) [ISP-HEADER01]  
P89LPC970FDH@SSOP20 [(SA643)] P89LPC970FN  
P89LPC971FDH@SSOP20 [(SA643)] P89LPC971FN  
P89LPC972FDH@SSOP20 [(SA643)] P89LPC972FN  
P89LPC980FDH@SSOP28 [(SA643)] P89LPC982FDH@SSOP28 [(SA643)]  
P89LPC983FA@PLCC28 [(SA008A)] P89LPC984FA@PLCC28 [(SA008A)]  
P89LV51RB2 P89LV51RB2@PLCC44 [(SA244)]  
P89LV51RB2@TQFP44 [(SA245A)] P89LV51RC2  
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44 [(SA245A)]  
P89LV51RD2 P89LV51RD2 (new)  
P89LV51RD2 (new)@PLCC44 [(SA244)]  
P89LV51RD2 (new)@TQFP44 [(SA245A)]  
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44 [(SA245A)]  
P89LV51RD2BA (new)@PLCC44 [(SA244)]

P89LV51RD2BA@PLCC44 [(SA244)]  
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2BBC@TQFP44 [(SA245A)] P89LV51RD2BN  
P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [(SA244)]  
P89LV51RD2FA@PLCC44 [(SA244)]  
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2FBC@TQFP44 [(SA245A)] P89LV51RD2FN  
P89LV51RD2FN(new) P89V51RB2  
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44 [(SA245A)]  
P89V51RC2 P89V51RC2@PLCC44 [(SA244)]  
P89V51RC2@TQFP44 [(SA245A)] P89V51RD2  
P89V51RD2(new) P89V51RD2(new)@PLCC44 [(SA244)]  
P89V51RD2@TQFP44 [(SA245A)] P89V51RD2@PLCC44 [(SA244)]  
P89V51RD2@TQFP44 [(SA245A)]  
P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)] P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)] P89V51RD2FN  
P89V51RD2FN(new) P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44 [(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44 [(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44 [(SA245A)]  
P89V664@PLCC44 [(SA244)] P89V664@TQFP44 [(SA245A)]  
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44 [(SA245A)]  
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44 [(SA245A)]  
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44 [(SA245A)]  
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44 [(SA245A)]  
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44 [(SA245A)]  
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44 [(SA245A)]  
PXAS37@PLCC68 [(PEP+S414T)] PXAS37@PQFP80 [(PEP+S640B)]  
TDA11105PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11106PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11112PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11115PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11116PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11125PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11126PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11135PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11136PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11142PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11145PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11146PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11155PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11156PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12135PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12136PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12155PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12156PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12165PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12166PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12175PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12176PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12185PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12186PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12195PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12196PS/N1/3@SDIP64(\*) [(SA736+B215)]  
UOCIIIN1A-128K@QIP90 [(TA025)]  
UOCIIIN1A-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1A-256K@QIP90 [(TA025)]  
UOCIIIN1A-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-128K@QIP90 [(TA025)]  
UOCIIIN1B-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-256K@QIP90 [(TA025)]  
UOCIIIN1B-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-256K@TQFP128(facedown) [(TA024-B115)]

UOCIIIN1D-128K@QIP90 [(TA025)]  
 UOCIIIN1D-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1D-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1D-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1D-256K@QIP90 [(TA025)]  
 UOCIIIN1D-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1D-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1D-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1E-128K@QIP90 [(TA025)]  
 UOCIIIN1E-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1E-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1E-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1E-256K@QIP90 [(TA025)]  
 UOCIIIN1E-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1E-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1E-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1F-128K@QIP90 [(TA025)]  
 UOCIIIN1F-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1F-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1F-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1F-256K@QIP90 [(TA025)]  
 UOCIIIN1F-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1F-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1F-256K@TQFP128(facedown) [(TA024-B115)]

## OKI

### E(E) PROM/FRAM/NVRAM

MR27C1602B	MR27C1602B@PSOP44 [(SA638)]
MR27V1602D	MR27V1602D@PSOP44 [(SA638)]
MR27V1602D@TSOP44 [(SA645)]	MR27V1602D@TSOP48 [(SA247-B005)]
MR27V1602E	MR27V1602E@PSOP44 [(SA638)]
MR27V1602E@TSOP44 [(SA645)]	MR27V1602E@TSOP48 [(SA247-B005)]
MR27V1602F	MR27V1602F@PSOP44 [(SA638)]
MR27V1602F@TSOP44 [(SA645)]	MR27V1602F@TSOP48 [(SA247-B005)]
MR27V1652D	MR27V1652D@PSOP44 [(SA638)]
MR27V1652D@TSOP44 [(SA645)]	MR27V1652D@TSOP48 [(SA247-B005)]
MR27V3202F@TSOP44 [(SA645)]	MR27V3202F@TSOP48 [(SA247-B005)]
MR27V401D	MR27V401D@PSOP32 [(SA638)]
MR27V401D@TSOP32 [(SA620)]	MR27V401E
MR27V401E@PSOP32 [(SA638)]	MR27V401E@TSOP32 [(SA620)]
MR27V402D	MR27V402D@PSOP40 [(SA661)]
MR27V402D@TSOP44 [(SA645)]	MR27V402E
MR27V402E@PSOP40 [(SA661)]	MR27V402E@TSOP44 [(SA645)]
MR27V402F@SOJ42 [(SA661)]	MR27V6402D@PSOP44 [(SA638)]
MR27V6402D@TSOP44 [(SA645)]	MR27V6402D@TSOP48 [(SA247-B005)]
MR27V6402G@PSOP44 [(SA638)]	MR27V6402G@TSOP44 [(SA645)]
MR27V6402G@TSOP48 [(SA247-B005)]	MR27V802D
MR27V802D@PSOP44 [(SA638)]	MR27V802D@TSOP44 [(SA645)]
MR27V802F@PSOP44 [(SA638)]	MR27V802F@TSOP44 [(SA645)]
MR27V802F@TSOP48 [(SA247-B005)]	MR27V852D
MR27V852D@PSOP44 [(SA638)]	MR27V852D@TSOP44 [(SA645)]
MR27V852E	MR27V852E@SOJ42 [(SA661)]
MSM16812(08bit)	MSM16812(08bit)@SOIC8 [(SA602A)]
MSM271000	MSM271000@PLCC32 [(SA015A1T)]
MSM271000@TSOP32 [(SA410T)]	MSM27128
MSM27128A	MSM27128AS
MSM27128AZB-RS	MSM2716
MSM27256	MSM27256AS
MSM27256ZB-RS	MSM2732
MSM2732A	MSM27512
MSM27512AS	MSM27512ZB-RS
MSM2764	MSM2764A
MSM2764AS	MSM2764AZB-RS
MSM2764RS	MSM27C1024
MSM27C1024AS	MSM27C128
MSM27C128AZB-RS	MSM27C1602CZ
MSM27C1602CZ@PSOP44 [(SA638)]	
MSM27C1602CZ@TSOP48 [(SA247-B005)]	MSM27C1652CZ@PSOP44 [(SA638)]
MSM27C1652CZ	
MSM27C1652CZ@TSOP48 [(SA247-B005)]	
MSM27C256	MSM27C256A
MSM27C256H	MSM27C256HZB
MSM27C256ZB	MSM27C64AS
MSM27C802CZ	MSM27C802CZ@PSOP44 [(SA638)]
MSM27C802CZ@TSOP44 [(SA645)]	MSM27C852CZ



MSM27C852CZ@PSOP44 [(SA638)]  
MSM2816A(RS)

MSM27C852CZ@TSOP44 [(SA645)]  
MSM28C16A

**DRAM & SRAM**

MSM51256  
MSM51257AL  
MSM51257ALL  
MSM5165AL  
MSM5188

MSM51256@SOIC28 [(SA630)]  
MSM51257AL@SOIC28 [(SA630)]  
MSM51257ALL@SOIC28 [(SA630)]  
MSM5165AL@SOIC28 [(SA630)]  
MSM5188@SOJ22 [(SA646)]

**ON Semiconductor**

**E(E) PROM/FRAM/NVRAM**

CAT1320  
CAT1320@TDFN8  
CAT1321  
CAT1321@TDFN8  
CAT14002@SOIC8 [(SA602A)]  
CAT14008@SOIC8 [(SA602A)]  
CAT15002@SOIC8 [(SA602A)]  
CAT15008@SOIC8 [(SA602A)]  
CAT1640  
CAT1640@TDFN8  
CAT1641  
CAT1641@TDFN8  
CAT24AA01@SOIC8 [(SA602A)]  
CAT24AA02@SOIC8 [(SA602A)]  
CAT24AA04@SOIC8 [(SA602A)]  
CAT24AA08@SOIC8 [(SA602A)]  
CAT24AA16@SOIC8 [(SA602A)]  
CAT34TS02@TDFN8 [ordering number is

CAT1320@SOIC8 [(SA602A)]  
CAT1320@TSSOP8 [(SA026)]  
CAT1321@SOIC8 [(SA602A)]  
CAT1321@TSSOP8 [(SA026)]  
CAT14004@SOIC8 [(SA602A)]  
CAT14016@SOIC8 [(SA602A)]  
CAT15004@SOIC8 [(SA602A)]  
CAT15016@SOIC8 [(SA602A)]  
CAT1640@SOIC8 [(SA602A)]  
CAT1640@TSSOP8 [(SA026)]  
CAT1641@SOIC8 [(SA602A)]  
CAT1641@TSSOP8 [(SA026)]  
CAT24AA01@TSOT-23 [(SA717)]  
CAT24AA02@TSOT-23 [(SA717)]  
CAT24AA04@TSOT-23 [(SA717)]  
CAT24AA08@TSOT-23 [(SA717)]  
CAT24AA16@TSOT-23 [(SA717)]  
marked above]

**PARALLAX**

**MICROCONTROLLER**

SX20AC/SS/G@SSOP20 [(SA626A)]  
SX28AC/DP  
SX28AC/SS/G@SSOP28 [(SA626A)]  
SX48BD/G@TQFP48 [(SA248)]

SX20AC/SS@SSOP20 [(SA626A)]  
SX28AC/DP/G  
SX28AC/SS@SSOP28 [(SA626A)]  
SX48BD@TQFP48 [(SA248)]

**PFLASH(MSTAR)**

**E(E) PROM/FRAM/NVRAM**

PS25LV010A@SOIC8 [(SA602A)]  
PS25LV020@SOIC8 [(SA602A)]  
PS25LV040@SOIC8 [(SA605A)]  
PS25LV080@SOIC8 [(SA605A)]

PS25LV010A@WSON8 [(SA683)]  
PS25LV020@WSON8 [(SA683)]  
PS25LV040@WSON8 [(SA683)]  
PS25LV080@WSON8 [(SA683)]

**PHILIPS**

**E(E) PROM/FRAM/NVRAM**

27C010  
27C010@TSOP32 [(SA410T)]  
27C040@PLCC32 [(SA015A1T)]  
27C210  
27C240  
27C256  
27C32  
27C512@PLCC32 [(SA015A1T)]  
27C64@PLCC32 [(SA015A1T)]  
27C64A@PLCC32 [(SA015A1T)]  
27C64AF@PLCC32 [(SA015A1T)]

27C010@PLCC32 [(SA015A1T)]  
27C040  
27C040@TSOP32 [(SA410T)]  
27C210@PLCC44 [(SA244)]  
27C240@PLCC44 [(SA244)]  
27C256@PLCC32 [(SA015A1T)]  
27C512  
27C64  
27C64A  
27C64AF  
27HC641

27HC641@PLCC28 [(SA008A)]	27PC32
PCA24S08@SOIC8 [(SA602A)]	PCA24S08@TSSOP8 [(SA026)]
PCA8574 (P)	PCA8574(T)@SOIC16 [(SA404)]
PCA8574 (TS)@SSOP20 [(SA026)]	PCA8574A (P)
PCA8574A (T)@SOIC16 [(SA404)]	PCA8574A(TS)@SSOP20 [(SA026)]
PCA8581	PCA8581@SOIC8 [(SA602A)]
PCA8581C	PCA8581C@SOIC8 [(SA602A)]
PCA8582A	PCA8582A@SOIC8 [(SA602A)]
PCA8582B	PCA8582B@SOIC8 [(SA602A)]
PCA8582C	PCA8582C@SOIC8 [(SA602A)]
PCA8582D	PCA8582D@SOIC8 [(SA602A)]
PCA8582E	PCA8582E@SOIC8 [(SA602A)]
PCA9500@HQVFN16	PCA9500@SOIC16 [(SA404)]
PCA9500@TSSOP16 [(SA026)]	PCA9501@HQVFN20
PCA9501@SOIC20 [(SA404)]	PCA9501@TSSOP20 [(SA026)]
PCA9561D@SOP20 [(SA404)]	PCA9561W@TSSOP20 [(SA026)]
PCD8581	PCD8581@SOIC8 [(SA602A)]
PCD8581C	PCD8581C@SOIC8 [(SA602A)]
PCD8582A	PCD8582A@SOIC8 [(SA602A)]
PCD8582B	PCD8582B@SOIC8 [(SA602A)]
PCD8582C	PCD8582C@SOIC8 [(SA602A)]
PCD8582D	PCD8582D@SOIC8 [(SA602A)]
PCD8582E	PCD8582E@SOIC8 [(SA602A)]
PCF85102C	PCF85102C@SOIC8 [(SA602A)]
PCF85103C	PCF85103C@SOIC8 [(SA602A)]
PCF85116	PCF85116@SOIC8 [(SA602A)]
PCF8581	PCF8581@SOIC8 [(SA602A)]
PCF8581C	PCF8581C@SOIC8 [(SA602A)]
PCF8582A	PCF8582A@SOIC8 [(SA602A)]
PCF8582B	PCF8582B@SOIC8 [(SA602A)]
PCF8582C	PCF8582C@SOIC8 [(SA602A)]
PCF8582D	PCF8582D@SOIC8 [(SA602A)]
PCF8582E	PCF8582E@SOIC8 [(SA602A)]
PCF8594	PCF8594@SOIC8 [(SA602A)]
PCF8594C	PCF8594C@SOIC8 [(SA602A)]
PCF8594D	PCF8594D@SOIC8 [(SA602A)]
PCF8594E	PCF8594E@SOIC8 [(SA602A)]
PCF8598	PCF8598@SOIC8 [(SA605A)]
PCF8598C	PCF8598C@SOIC8 [(SA605A)]
PCF8598D	PCF8598D@SOIC8 [(SA605A)]
PCF8598E	PCF8598E@SOIC8 [(SA605A)]

**BPROM**

82S126	82S126A
82S129	82S129A
82S130	82S130A
82S131	82S131A
82S140	82S141
82S191	82S191A
82S191B	82S191C
N82LS135	N82LS135@PLCC20 [(SA001A)]
N82S123	N82S123A
N82S135	N82S135@PLCC20 [(SA001A)]
N82S136	N82S137
N82S137A	N82S137B
N82S137C	N82S146
N82S146@PLCC20 [(SA001A)]	N82S147
N82S147@PLCC20 [(SA001A)]	N82S147A
N82S147A@PLCC20 [(SA001A)]	N82S147B
N82S147B@PLCC20 [(SA001A)]	N82S167
N82S184	N82S184A
N82S185	N82S185A
N82S185B	N82S185C
N82S23	N82S23A

**PLD**

82S100	82S101
82S105	82S105A@PLCC28 [(SA008A)]
82S152	82S152@PLCC20 [(SA001A)]
82S153	82S153@PLCC20 [(SA001A)]
82S155	82S155@PLCC20 [(SA001A)]
82S157	82S157@PLCC20 [(SA001A)]
82S159	82S159@PLCC20 [(SA001A)]
82S167	82S167@PLCC28 [(SA008A)]
82S168	82S168@PLCC28 [(SA008A)]
82S173	82S173@PLCC28 [(SA008A)]

82S179	82S179@PLCC28 [(SA008A)]
PLS100	PLS100@PLCC28 [(SA008A)]
PLS101	PLS101@PLCC28 [(SA008A)]
PLS104	PLS104@PLCC28 [(SA008A)]
PLS104A	PLS104A@PLCC28 [(SA008A)]
PLS105	PLS105@PLCC28 [(SA008A)]
PLS105A	PLS105A@PLCC28 [(SA008A)]
PLS152	PLS152@PLCC20 [(SA001A)]
PLS153	PLS153@PLCC20 [(SA001A)]
PLS153A	PLS153A@PLCC20 [(SA001A)]
PLS155	PLS155@PLCC20 [(SA001A)]
PLS157	PLS157@PLCC20 [(SA001A)]
PLS159	PLS159@PLCC20 [(SA001A)]
PLS159A	PLS159A@PLCC20 [(SA001A)]
PLS167	PLS167@PLCC28 [(SA008A)]
PLS167A	PLS167A@PLCC28 [(SA008A)]
PLS168	PLS168@PLCC28 [(SA008A)]
PLS168A	PLS168A@PLCC28 [(SA008A)]
PLS173	PLS173@PLCC28 [(SA008A)]
PLS179	PLS179@PLCC28 [(SA008A)]
PLUS105	PLUS105@PLCC28 [(SA008A)]
PZ3032@PLCC44 [(SA244)]	PZ3032@TQFP44 [(SA245A)]
PZ3032CS@PLCC44 [(SA244)]	PZ3032CS@TQFP44 [(SA245A)]
PZ3064@PLCC44 [(SA244)]	PZ3064@PLCC68 [(PEP+S414T)]
PZ3064@PLCC84 [(PEP+S416T)]	PZ3064@PQFP100 [(PEP+S427)]
PZ3064@TQFP100 [(PEP+S604)]	PZ3064@TQFP44 [(SA245A)]
PZ3128@PLCC84 [(PEP+S416T)]	PZ3128@PQFP100 [(PEP+S427)]
PZ3128@TQFP100 [(PEP+S604)]	PZ5032@PLCC44 [(SA244)]
PZ5032@TQFP44 [(SA245A)]	PZ5032CS@PLCC44 [(SA244)]
PZ5032CS@TQFP44 [(SA245A)]	PZ5064@PLCC44 [(SA244)]
PZ5064@PLCC68 [(PEP+S414T)]	PZ5064@PLCC84 [(PEP+S416T)]
PZ5064@PQFP100 [(PEP+S427)]	PZ5064@TQFP100 [(PEP+S604)]
PZ5064@TQFP44 [(SA245A)]	PZ5128@PLCC84 [(PEP+S416T)]
PZ5128@PQFP100 [(PEP+S427)]	PZ5128@TQFP100 [(PEP+S604)]

## MICROCONTROLLER

LPC21101FBD48@LQFP48 (*) [(SA248-B4801)]
LPC21102FBD48@LQFP48 (*) [(SA248-B4801)]
LPC21103FA44@PLCC44 (*) [(SA244-B4403)]
LPC21103FBD48@LQFP48 (*) [(SA248-B4801)]
LPC21104BBD48@LQFP48 (*) [(SA248-B4801)]
LPC21105BBD48@LQFP48 (*) [(SA248-B4801)]
LPC21106BBD48@LQFP48 (*) [(SA248-B4801)]
LPC21114FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21119FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21124FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21129FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21131FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21131FBD64@LQFP64 (**) [(SA732-B330)]
LPC21132FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21132FBD64@LQFP64 (**) [(SA732-B330)]
LPC21134FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21134FBD64@LQFP64 (**) [(SA732-B330)]
LPC21136FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21136FBD64@LQFP64 (**) [(SA732-B330)]
LPC21138FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21138FBD64@LQFP64 (**) [(SA732-B330)]
LPC21141FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21141FBD64@LQFP64 (**) [(SA732-B330)]
LPC21142FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21142FBD64@LQFP64 (**) [(SA732-B330)]
LPC21144FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21144FBD64@LQFP64 (**) [(SA732-B330)]
LPC21146FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21146FBD64@LQFP64 (**) [(SA732-B330)]
LPC21148FBD64@LQFP64 (*) [(TA027-B4801)]
LPC21148FBD64@LQFP64 (**) [(SA732-B330)]
LPC2194HBD64@LQFP64 (*) [(TA027-B4801)]
LPC2212HBD144@LQFP144 (*) [(TA044-B4802)]
LPC2214FBD144@LQFP144 (*) [(TA044-B4802)]
LPC2214HBD144@LQFP144 (*) [(TA044-B4802)]
LPC2292FBD144@LQFP144 (*) [(TA044-B4802)]
LPC2292HBD144@LQFP144 (*) [(TA044-B4802)]
LPC2294FBD144@LQFP144 (*) [(TA044-B4802)]
LPC2294HBD144@LQFP144 (*) [(TA044-B4802)]
LPC2364@LQFP100 (*) [(SA718+B243)]
LPC2365@LQFP100 (*) [(SA718+B243)]
LPC2366@LQFP100 (*) [(SA718+B243)]

LPC2366@LQFP100(*) (new) [(SA718+B243)]	
LPC2368@LQFP100(*) [(SA718+B243)]	
LPC2368@LQFP100(*) (new) [(SA773+B243)]	
P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44 [(SA245A)]
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44 [(SA245A)]
P87C054@SDIP42 [(SA028)]	P87C055@SDIP42 [(SA028)]
P87C451@PLCC68 [(PEP+S414T)]	P87C451@SDIP64 [(PEP+S600A)]
P87C453@PLCC68 [(PEP+S414T)]	P87C51
P87C51@PLCC44 [(SA244)]	P87C51@TQFP44 [(SA245A)]
P87C51FA	P87C51FA@PLCC44 [(SA244)]
P87C51FA@TQFP44 [(SA245A)]	P87C51FB
P87C51FB@PLCC44 [(SA244)]	P87C51FB@TQFP44 [(SA245A)]
P87C51FC	P87C51FC@PLCC44 [(SA244)]
P87C51FC@TQFP44 [(SA245A)]	P87C51MA2@PLCC44 [(SA244)]
P87C51MB2@PLCC44 [(SA244)]	P87C51MC2@PLCC44 [(SA244)]
P87C51RA+	P87C51RA+@PLCC44 [(SA244)]
P87C51RA+@TQFP44 [(SA245A)]	P87C51RA2
P87C51RA2@PLCC44 [(SA244)]	P87C51RA2@TQFP44 [(SA245A)]
P87C51RB+	P87C51RB+@PLCC44 [(SA244)]
P87C51RB+@TQFP44 [(SA245A)]	P87C51RB2
P87C51RB2@PLCC44 [(SA244)]	P87C51RB2@TQFP44 [(SA245A)]
P87C51RC+	P87C51RC+@PLCC44 [(SA244)]
P87C51RC+@TQFP44 [(SA245A)]	P87C51RC2
P87C51RC2@PLCC44 [(SA244)]	P87C51RC2@TQFP44 [(SA245A)]
P87C51RD+	P87C51RD+@PLCC44 [(SA244)]
P87C51RD+@TQFP44 [(SA245A)]	P87C51RD2
P87C51RD2@PLCC44 [(SA244)]	P87C51RD2@TQFP44 [(SA245A)]
P87C51SB	P87C51SB@PLCC44 [(SA244)]
P87C51SB@TQFP44 [(SA245A)]	P87C51SF
P87C51SF@PLCC44 [(SA244)]	P87C51SF@TQFP44 [(SA245A)]
P87C51UB	P87C51UB@PLCC44 [(SA244)]
P87C51UB@TQFP44 [(SA245A)]	P87C51UF
P87C51UF@PLCC44 [(SA244)]	P87C51UF@TQFP44 [(SA245A)]
P87C51X2	P87C51X2@PLCC44 [(SA244)]
P87C51X2@TQFP44 [(SA245A)]	P87C52
P87C52@PLCC44 [(SA244)]	P87C52@TQFP44 [(SA245A)]
P87C524	P87C524@PLCC44 [(SA244)]
P87C524@TQFP44 [(SA245A)]	P87C528
P87C528@PLCC44 [(SA244)]	P87C528@TQFP44 [(SA245A)]
P87C52SB	P87C52SB@PLCC44 [(SA244)]
P87C52SB@TQFP44 [(SA245A)]	P87C52SF
P87C52SF@PLCC44 [(SA244)]	P87C52SF@TQFP44 [(SA675)]
P87C52UB	P87C52UB@PLCC44 [(SA244)]
P87C52UB@TQFP44 [(SA245A)]	P87C52UF
P87C52UF@PLCC44 [(SA244)]	P87C52UF@TQFP44 [(SA245A)]
P87C52X2	P87C52X2@PLCC44 [(SA244)]
P87C52X2@TQFP44 [(SA245A)]	P87C54
P87C54@PLCC44 [(SA244)]	P87C54@TQFP44 [(SA245A)]
P87C54SB	P87C54SB@PLCC44 [(SA244)]
P87C54SB@TQFP44 [(SA245A)]	P87C54SF
P87C54SF@PLCC44 [(SA244)]	P87C54SF@TQFP44 [(SA245A)]
P87C54UB	P87C54UB@PLCC44 [(SA244)]
P87C54UB@TQFP44 [(SA245A)]	P87C54UF
P87C54UF@PLCC44 [(SA244)]	P87C54UF@TQFP44 [(SA245A)]
P87C54X2	P87C54X2@PLCC44 [(SA244)]
P87C54X2@TQFP44 [(SA245A)]	P87C550
P87C550@PLCC44 [(SA244)]	P87C552@PLCC68 [(PEP+S414T)]
P87C552@PLCC68(*) [(SA648-B6806)]	
P87C554@LQFP64 [(PEP+S616)]	P87C554@PLCC68 [(PEP+S414T)]
P87C554@PLCC68(*) [(SA648-B6806)]	
P87C557E8@PQFP80 [(PEP+S611A)]	
P87C575@PLCC44 [(SA244)]	P87C575
P87C576	P87C575@TQFP44 [(SA245A)]
P87C576@TQFP44 [(SA245A)]	P87C576@PLCC44 [(SA244)]
P87C58@PLCC44 [(SA244)]	P87C58
P87C58SB	P87C58@TQFP44 [(SA245A)]
P87C58SB@TQFP44 [(SA245A)]	P87C58SB@PLCC44 [(SA244)]
P87C58UB@PLCC44 [(SA244)]	P87C58UB
P87C58X2	P87C58UB@TQFP44 [(SA245A)]
P87C58X2@TQFP44 [(SA245A)]	P87C58X2@PLCC44 [(SA244)]
P87C591@TQFP44 [(SA245A)]	P87C591@PLCC44 [(SA244)]
P87C652	P87C592@PLCC68 [(PEP+S414T)]
P87C652@TQFP44 [(SA245A)]	P87C652@PLCC44 [(SA244)]
P87C654@PLCC44 [(SA244)]	P87C654
P87C660X2@PLCC44 [(SA244)]	P87C654@TQFP44 [(SA245A)]
P87C661X2@PLCC44 [(SA244)]	P87C660X2@TQFP44 [(SA245A)]
P87C748	P87C661X2@TQFP44 [(SA245A)]
P87C749	P87C748@PLCC28 [(SA008A)]
P87C750	P87C749@PLCC28 [(SA008A)]
P87C750@SSOP24 [(SA626A)]	P87C750@PLCC28 [(SA008A)]
P87C751@PLCC28 [(SA008A)]	P87C751
	P87C751@SSOP24 [(SA626A)]

P87C752	P87C752@PLCC28 [(SA008A)]
P87C752@SSOP28 [(SA626A)]	P87C754
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28 [(SA626A)]
P87CL52X2	P87CL52X2@PLCC44 [(SA244)]
P87CL52X2@TQFP44 [(SA245A)]	P87CL54X2
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44 [(SA245A)]
P87L51FA	P87L51FA@PLCC44 [(SA244)]
P87L51FA@TQFP44 [(SA245A)]	P87L51FB
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44 [(SA245A)]
P87LPC759	P87LPC759 (ISP) [ISP-HEADER01]
P87LPC760	P87LPC760 (ISP) [ISP-HEADER01]
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14 (ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761 (ISP) [ISP-HEADER01]
P87LPC762	P87LPC762 (ISP) [ISP-HEADER01]
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44 (ISP) [ISP-HEADER01]	
P87LPC762@SOIC20 [(SA404)]	
P87LPC762@SOIC20 (ISP) [ISP-HEADER01]	
P87LPC764	P87LPC764 (ISP) [ISP-HEADER01]
P87LPC764@PLCC44 [(SA244)]	
P87LPC764@PLCC44 (ISP) [ISP-HEADER01]	
P87LPC764@SOIC20 [(SA404)]	
P87LPC764@SOIC20 (ISP) [ISP-HEADER01]	
P87LPC764@TSSOP20 [(SA643)]	
P87LPC764@TSSOP20 (ISP) [ISP-HEADER01]	
P87LPC767	P87LPC767 (ISP) [ISP-HEADER01]
P87LPC767@PLCC44 [(SA244)]	
P87LPC767@PLCC44 (ISP) [ISP-HEADER01]	
P87LPC767@SOIC20 [(SA404)]	
P87LPC767@SOIC20 (ISP) [ISP-HEADER01]	
P87LPC768	P87LPC768 (ISP) [ISP-HEADER01]
P87LPC768@SOIC20 [(SA404)]	
P87LPC768@SOIC20 (ISP) [ISP-HEADER01]	
P87LPC769	P87LPC769 (ISP) [ISP-HEADER01]
P87LPC769@PLCC44 [(SA244)]	
P87LPC769@PLCC44 (ISP) [ISP-HEADER01]	
P87LPC769@SOIC20 [(SA404)]	
P87LPC769@SOIC20 (ISP) [ISP-HEADER01]	
P87LPC778	P87LPC778 (ISP) [ISP-HEADER01]
P87LPC778@TSSOP20 [(SA026)]	
P87LPC778@TSSOP20 (ISP) [ISP-HEADER01]	
P87LPC779	P87LPC779 (ISP) [ISP-HEADER01]
P87LPC779@TSSOP20 [(SA643)]	
P87LPC779@TSSOP20 (ISP) [ISP-HEADER01]	
P89C138	P89C138@PLCC44 [(SA244)]
P89C138@TQFP44 [(SA245A)]	P89C238
P89C238@PLCC44 [(SA244)]	P89C238@TQFP44 [(SA245A)]
P89C51B	P89C51B@PLCC44 [(SA244)]
P89C51B@TQFP44 [(SA245A)]	P89C51RA+
P89C51RA+@PLCC44 [(SA244)]	P89C51RA+@TQFP44 [(SA245A)]
P89C51RA2B	P89C51RA2B@PLCC44 [(SA244)]
P89C51RA2B@TQFP44 [(SA245A)]	P89C51RB+
P89C51RB+@PLCC44 [(SA244)]	P89C51RB+@TQFP44 [(SA245A)]
P89C51RB2B	P89C51RB2B@PLCC44 [(SA244)]
P89C51RB2B@TQFP44 [(SA245A)]	P89C51RB2H
P89C51RB2H@PLCC44 [(SA244)]	P89C51RB2H@TQFP44 [(SA245A)]
P89C51RC+	P89C51RC+@PLCC44 [(SA244)]
P89C51RC+@TQFP44 [(SA245A)]	P89C51RC2B
P89C51RC2B@PLCC44 [(SA244)]	P89C51RC2B@TQFP44 [(SA245A)]
P89C51RC2H	P89C51RC2H@PLCC44 [(SA244)]
P89C51RC2H@TQFP44 [(SA245A)]	P89C51RD+
P89C51RD+@PLCC44 [(SA244)]	P89C51RD+@TQFP44 [(SA245A)]
P89C51RD2B	P89C51RD2B@PLCC44 [(SA244)]
P89C51RD2B@TQFP44 [(SA245A)]	P89C51RD2H
P89C51RD2H@PLCC44 [(SA244)]	P89C51RD2H@TQFP44 [(SA245A)]
P89C51UB	P89C51UB@PLCC44 [(SA244)]
P89C51UB@TQFP44 [(SA245A)]	P89C51UF
P89C51UF@PLCC44 [(SA244)]	P89C51UF@TQFP44 [(SA245A)]
P89C51X2	P89C51X2@PLCC44 [(SA244)]
P89C51X2@TQFP44 [(SA245A)]	P89C51X2B
P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44 [(SA245A)]
P89C51X2F	P89C51X2F@PLCC44 [(SA244)]
P89C51X2F@TQFP44 [(SA245A)]	P89C52
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44 [(SA245A)]
P89C52B	P89C52B@PLCC44 [(SA244)]
P89C52B@TQFP44 [(SA245A)]	P89C52UB
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44 [(SA245A)]
P89C52UF	P89C52UF@PLCC44 [(SA244)]
P89C52UF@TQFP44 [(SA245A)]	P89C52X2
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44 [(SA245A)]

```

P89C52X2B
P89C52X2B@TQFP44 [(SA245A)]
P89C52X2F@PLCC44 [(SA244)]
P89C536@PLCC44 [(SA244)]
P89C54
P89C54@TQFP44 [(SA245A)]
P89C54B@PLCC44 [(SA244)]
P89C54UB
P89C54UB@TQFP44 [(SA245A)]
P89C54UF@PLCC44 [(SA244)]
P89C54X2
P89C54X2@TQFP44 [(SA245A)]
P89C54X2B@PLCC44 [(SA244)]
P89C54X2F
P89C54X2F@TQFP44 [(SA245A)]
P89C58@PLCC44 [(SA244)]
P89C58B
P89C58B@TQFP44 [(SA245A)]
P89C58UB@PLCC44 [(SA244)]
P89C58UF
P89C58UF@TQFP44 [(SA245A)]
P89C58X2@PLCC44 [(SA244)]
P89C58X2B
P89C58X2B@TQFP44 [(SA245A)]
P89C58X2F@PLCC44 [(SA244)]
P89C60X2
P89C60X2@TQFP44 [(SA245A)]
P89C61X2@PLCC44 [(SA244)]
P89C660
P89C660@TQFP44 [(SA245A)]
P89C662@PLCC44 [(SA244)]
P89C664
P89C664@TQFP44 [(SA245A)]
P89C668@PLCC44 [(SA244)]
P89C669
P89C669@PLCC44 [(SA244)]
P89C738@PLCC44 [(SA244)]
P89C838
P89C838@TQFP44 [(SA245A)]
P89CV51RB2@TQFP44 [(SA245A)]
P89CV51RC2@TQFP44 [(SA245A)]
P89CV51RD2@TQFP44 [(SA245A)]
P89LPC901(FD)(ISP) [ISP-HEADER01]
P89LPC901(FN)
P89LPC901(FN)(ISP) [ISP-HEADER01]
P89LPC902(FD) [(SA602A)]
P89LPC902(FD)(ISP) [ISP-HEADER01]
P89LPC902(FN)
P89LPC902(FN)(ISP) [ISP-HEADER01]
P89LPC903(FD) [(SA602A)]
P89LPC903(FD)(ISP) [ISP-HEADER01]
P89LPC904(FD) [(SA605A)]
P89LPC904(FD)(ISP) [ISP-HEADER01]
P89LPC904(FN)
P89LPC904(FN)(ISP) [ISP-HEADER01]
P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9151(FDH)@TSSOP14 [(SA643)]
P89LPC9151(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89C52X2B@PLCC44 [(SA244)]
P89C52X2F
P89C52X2F@TQFP44 [(SA245A)]
P89C538@PLCC44 [(SA244)]
P89C54@PLCC44 [(SA244)]
P89C54B
P89C54B@TQFP44 [(SA245A)]
P89C54UB@PLCC44 [(SA244)]
P89C54UF
P89C54UF@TQFP44 [(SA245A)]
P89C54X2@PLCC44 [(SA244)]
P89C54X2B
P89C54X2B@TQFP44 [(SA245A)]
P89C54X2F@PLCC44 [(SA244)]
P89C58
P89C58@TQFP44 [(SA245A)]
P89C58B@PLCC44 [(SA244)]
P89C58UB
P89C58UB@TQFP44 [(SA245A)]
P89C58UF@PLCC44 [(SA244)]
P89C58X2
P89C58X2@TQFP44 [(SA245A)]
P89C58X2B@PLCC44 [(SA244)]
P89C58X2F
P89C58X2F@TQFP44 [(SA245A)]
P89C60X2@PLCC44 [(SA244)]
P89C61X2
P89C61X2@TQFP44 [(SA245A)]
P89C660@PLCC44 [(SA244)]
P89C662
P89C662@TQFP44 [(SA245A)]
P89C664@PLCC44 [(SA244)]
P89C668
P89C668@TQFP44 [(SA245A)]
P89C669@LQFP44 [(SA245A)]
P89C738
P89C738@TQFP44 [(SA245A)]
P89C838@PLCC44 [(SA244)]
P89CV51RB2@PLCC44 [(SA244)]
P89CV51RC2@PLCC44 [(SA244)]
P89CV51RD2@PLCC44 [(SA244)]
P89LPC901(FD) [(SA602A)]

```

P89LPC9161(FDH)@TSSOP16 [(SA643)]  
P89LPC9161(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC9171(FDH)@TSSOP16 [(SA643)]  
P89LPC9171(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC9201(FDH)@TSSOP20 [(SA643)]  
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9201(FN)  
P89LPC9201(FN)(ISP) [ISP-HEADER01]  
P89LPC920A1(FDH)@TSSOP20 [(SA643)]  
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920A1(FN)  
P89LPC920A1(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC9211(FDH)@TSSOP20 [(SA643)]  
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9211(FN)  
P89LPC9211(FN)(ISP) [ISP-HEADER01]  
P89LPC921A1(FDH)@TSSOP20 [(SA643)]  
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921A1(FN)  
P89LPC921A1(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]  
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221A1(FN)  
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]  
P89LPC922A1(FDH)@TSSOP20 [(SA643)]  
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922A1(FN)  
P89LPC922A1(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC9241(FDH)@TSSOP20 [(SA643)]  
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9241(FN)  
P89LPC9241(FN)(ISP) [ISP-HEADER01]  
P89LPC924A1(FDH)@TSSOP20 [(SA643)]  
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924A1(FN)  
P89LPC924A1(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC9251(FDH)@TSSOP20 [(SA643)]  
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9251(FN)  
P89LPC9251(FN)(ISP) [ISP-HEADER01]  
P89LPC925A1(FDH)@TSSOP20 [(SA643)]  
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925A1(FN)  
P89LPC925A1(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9301(BA)@PLCC28 [(SA008A)]  
P89LPC9301(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9311(BA)@PLCC28 [(SA008A)]

P89LPC9311(BDH)@TSSOP28 [(SA643)]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(BA)@PLCC28 [(SA008A)]  
P89LPC93201(BDH)@TSSOP28 [(SA643)]  
P89LPC93201(FA)@PLCC28 [(SA008A)]  
P89LPC93201(FDH)@TSSOP28 [(SA643)]  
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9321(BA)@PLCC28 [(SA008A)]  
P89LPC9321(BDH)@TSSOP28 [(SA643)]  
P89LPC9321(FA)@PLCC28 [(SA008A)]  
P89LPC9321(FDH)@TSSOP28 [(SA643)]  
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(HDH)@TSSOP28 [(SA643)]  
P89LPC9331(BDH)@TSSOP28 [(SA643)]  
P89LPC9331(FDH)@TSSOP28 [(SA643)]  
P89LPC9331(HDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC93401(FDH)@TSSOP28 [(SA643)]  
P89LPC93401V  
P89LPC9341(BDH)@TSSOP28 [(SA643)]  
P89LPC9341(FDH)@TSSOP28 [(SA643)]  
P89LPC9341V P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC9361(FA)@PLCC28 [(SA008A)]  
P89LPC9361(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]  
P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64 [(PEP+S616)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9402(FBD)@LQFP64 [(PEP+S616)]



P89LPC9402(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64 [(PEP+S625)]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]  
P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP48 [(SA248)]  
P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
P89LPC954@PLCC44 [(SA244)]  
P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
P89LPC970FDH@SSOP20 [(SA643)] P89LPC970FN  
P89LPC971FDH@SSOP20 [(SA643)] P89LPC971FN  
P89LPC972FDH@SSOP20 [(SA643)] P89LPC972FN  
P89LPC980FDH@SSOP28 [(SA643)] P89LPC982FDH@SSOP28 [(SA643)]  
P89LPC983FA@PLCC28 [(SA008A)] P89LPC984FA@PLCC28 [(SA008A)]  
P89LV51RB2 P89LV51RB2@PLCC44 [(SA244)]  
P89LV51RB2@TQFP44 [(SA245A)] P89LV51RC2  
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44 [(SA245A)]  
P89LV51RD2 P89LV51RD2(new)  
P89LV51RD2(new)@PLCC44 [(SA244)] P89LV51RD2@TQFP44 [(SA245A)]  
P89LV51RD2(new)@TQFP44 [(SA245A)]  
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44 [(SA245A)]  
P89LV51RD2BA(new)@PLCC44 [(SA244)]  
P89LV51RD2BA@PLCC44 [(SA244)]  
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2BBC@TQFP44 [(SA245A)] P89LV51RD2BN  
P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [(SA244)]  
P89LV51RD2FA@PLCC44 [(SA244)]  
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
P89LV51RD2FBC@TQFP44 [(SA245A)] P89LV51RD2FN  
P89LV51RD2FN(new) P89V51RB2  
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44 [(SA245A)]  
P89V51RC2 P89V51RC2@PLCC44 [(SA244)]  
P89V51RC2@TQFP44 [(SA245A)] P89V51RD2  
P89V51RD2(new) P89V51RD2(new)@PLCC44 [(SA244)]  
P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44 [(SA244)]  
P89V51RD2@TQFP44 [(SA245A)]  
P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)] P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)] P89V51RD2FN  
P89V51RD2FN(new) P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44 [(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44 [(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44 [(SA245A)]  
P89V664@PLCC44 [(SA244)] P89V664@TQFP44 [(SA245A)]  
PSD301@PLCC44 [(SA244)] PSD301L@PLCC44 [(SA244)]  
PSD302@PLCC44 [(SA244)] PSD302L@PLCC44 [(SA244)]  
PSD303@PLCC44 [(SA244)] PSD303L@PLCC44 [(SA244)]  
PSD311@PLCC44 [(SA244)] PSD311L@PLCC44 [(SA244)]  
PSD312@PLCC44 [(SA244)] PSD312L@PLCC44 [(SA244)]  
PSD313@PLCC44 [(SA244)] PSD313@TQFP44 [(SA245A)]  
PSD313-B@PLCC44 [(SA244)] PSD313-B@TQFP44 [(SA245A)]  
PSD313L@PLCC44 [(SA244)] PSD313L@TQFP44 [(SA245A)]  
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44 [(SA245A)]  
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44 [(SA245A)]  
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44 [(SA245A)]  
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44 [(SA245A)]  
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44 [(SA245A)]  
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44 [(SA245A)]  
PXAS37@PLCC68 [(PEP+S414T)] PXAS37@PQFP80 [(PEP+S640B)]  
TDA11105PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11106PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11112PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11115PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11116PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11125PS/N1/3@SDIP64(\*) [(SA736+B215)]

TDA11126PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11135PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11136PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11142PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11145PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11146PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11155PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA11156PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12135PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12136PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12155PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12156PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12165PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12166PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12175PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12176PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12185PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12186PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12195PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 TDA12196PS/N1/3@SDIP64(\*) [(SA736+B215)]  
 UOCIIIN1A-128K@QIP90 [(TA025)]  
 UOCIIIN1A-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1A-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1A-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1A-256K@QIP90 [(TA025)]  
 UOCIIIN1A-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1A-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1A-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1B-128K@QIP90 [(TA025)]  
 UOCIIIN1B-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1B-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1B-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1B-256K@QIP90 [(TA025)]  
 UOCIIIN1B-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1B-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1B-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1D-128K@QIP90 [(TA025)]  
 UOCIIIN1D-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1D-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1D-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1D-256K@QIP90 [(TA025)]  
 UOCIIIN1D-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1D-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1D-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1E-128K@QIP90 [(TA025)]  
 UOCIIIN1E-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1E-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1E-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1E-256K@QIP90 [(TA025)]  
 UOCIIIN1E-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1E-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1E-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1F-128K@QIP90 [(TA025)]  
 UOCIIIN1F-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1F-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1F-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1F-256K@QIP90 [(TA025)]  
 UOCIIIN1F-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1F-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1F-256K@TQFP128(facedown) [(TA024-B115)]

## PJ

### E(E) PROM/FRAM/NVRAM

PJ24C02 PJ24C02@SOIC8 [(SA602A)]  
 PJ24C02@TSSOP8 [(SA026)]

## PMC

### E(E) PROM/FRAM/NVRAM

PM24C64 PM24C64@SOIC8 [(SA602A)]  
 PM24C64@TSOP8 [(SA026)] PM25LD010C(B)@SOIC8 [(SA023A)]

PM25LD010C(Q)@WSON8 [(SA683)]	PM25LD010C(S)@SOIC8 [(SA602A)]
PM25LD512(B)@SOIC8 [(SA023A)]	PM25LD512(Q)@WSON8 [(SA683)]
PM25LD512(S)@SOIC8 [(SA602A)]	PM25LV010(B)@SOIC8 [(SA023A)]
PM25LV010(Q)@WSON8 [(SA683)]	PM25LV010(S)@SOIC8 [(SA602A)]
PM25LV010A@SOIC8 [(SA602A)]	PM25LV010A@WSON8 [(SA683)]
PM25LV016@SOIC8 [(SA605A)]	PM25LV016@WSON8 [(SA683)]
PM25LV016A@SOIC8 [(SA605A)]	PM25LV016A@WSON8 [(SA683)]
PM25LV020(B)@SOIC8 [(SA023A)]	PM25LV020(Q)@WSON8 [(SA683)]
PM25LV020(S)@SOIC8 [(SA602A)]	PM25LV040(B)@SOIC8 [(SA023A)]
PM25LV040(Q)@WSON8 [(SA683)]	PM25LV040(S)@SOIC8 [(SA602A)]
PM25LV080@SOIC8 [(SA605A)]	PM25LV080@WSON8 [(SA683)]
PM25LV080A@SOIC8 [(SA605A)]	PM25LV080A@WSON8 [(SA683)]
PM25LV512(B)@SOIC8 [(SA023A)]	PM25LV512(Q)@WSON8 [(SA683)]
PM25LV512(S)@SOIC8 [(SA602A)]	PM25LV512A(B)@SOIC8 [(SA023A)]
PM25LV512A(Q)@WSON8 [(SA683)]	PM25LV512A(S)@SOIC8 [(SA602A)]
PM25LV512A@TSSOP8 [(SA026)]	PM29F002B
PM29F002B@PLCC32 [(SA015A1T)]	PM29F002T
PM29F002T@PLCC32 [(SA015A1T)]	PM29F004B
PM29F004B@PLCC32 [(SA015A1T)]	PM29F004T
PM29F004T@PLCC32 [(SA015A1T)]	PM29LV002B
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32 [(SA620)]
PM29LV002T	PM29LV002T@PLCC32 [(SA015A1T)]
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32 [(SA015A1T)]
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32 [(SA015A1T)]
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32 [(SA015A1T)]
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32 [(SA015A1T)]
PM29LV104RT@VSOP32 [(SA620)]	PM37LV512
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32 [(SA620)]
PM39F010	PM39F010@PLCC32 [(SA015A1T)]
PM39F010@VSOP32 [(SA620)]	PM39F020
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32 [(SA620)]
PM39F040	PM39F040@PLCC32 [(SA015A1T)]
PM39F040@VSOP32 [(SA620)]	PM39LV010@PLCC32 [(SA015A1T)]
PM39LV010@VSOP32 [(SA620)]	PM39LV010R@PLCC32 [(SA015A1T)]
PM39LV010R@VSOP32 [(SA620)]	PM39LV020@PLCC32 [(SA015A1T)]
PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32 [(SA015A1T)]
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32 [(SA015A1T)]
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32 [(SA015A1T)]
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32 [(SA015A1T)]
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32 [(SA620)]
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32 [(SA620)]
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32 [(SA620)]

## POLYSTAK

### E(E) PROM/FRAM/NVRAM

MTCOUFE0CF3@FBGA137 [(SA700C-B153A-Y137F001N)]

## PSS

### E(E) PROM/FRAM/NVRAM

PS24C256	PS24C256@SOIC8 [(SA602A)]
PS29FS001	PS29FS001@PLCC32 [(SA015A1T)]
PS29FS001@TSOP32 [(SA410T)]	PS29FS001@VSOP32 [(SA620)]
PS29LP001	PS29LP001@PLCC32 [(SA015A1T)]
PS29LP001@VSOP32 [(SA620)]	

## PTC

### E(E) PROM/FRAM/NVRAM

PT28C020	PT28C020@PLCC32 [(SA015A1T)]
PT28C040	PT28C040@PLCC32 [(SA015A1T)]
PT29C020	PT29C020@PLCC32 [(SA015A1T)]
PT29C040	PT29C040@PLCC32 [(SA015A1T)]

**MICROCONTROLLER**

PT89316	PT89316@PLCC44 [(SA244)]
PT89316@TQFP44 [(SA245A)]	PT8932
PT8932@PLCC44 [(SA244)]	PT8932@TQFP44 [(SA245)]
PT8936	PT8936@PLCC44 [(SA244)]
PT8936@TQFP44 [(SA245A)]	PT8956
PT8956@PLCC44 [(SA244)]	PT8956@TQFP44 [(SA245A)]

**QIXIN****MICROCONTROLLER**

LS2051	LS2051@SOIC20 [(SA404)]
--------	-------------------------

**Quick Pulse****E(E) PROM/FRAM/NVRAM**

27010	27011
27040	27128A
27210	27256
27512	2764A

**RAMTRON****E(E) PROM/FRAM/NVRAM**

FM1208	FM1208@SOIC24 [(SA404)]
FM1608	FM1608@SOIC28 [(SA404)]
FM1808	FM1808@SOIC28 [(SA404)]
FM18L08	FM18L08@SOIC28 [(SA404)]
FM24164	FM24164@SOIC8 [(SA602A)]
FM24C04(P)	FM24C04(S)@SOP8 [(SA602A)]
FM24C04A(P)	FM24C04A(S)@SOP8 [(SA602A)]
FM24C16(P)	FM24C16(S)@SOP8 [(SA602A)]
FM24C16A(P)	FM24C16A(S)@SOP8 [(SA602A)]
FM24C256@SOIC8 [(SA605A)]	FM24C512@SOIC8 [(SA602A)]
FM24C64	FM24C64@SOIC8 [(SA602A)]
FM24CL04	FM24CL04@SOIC8 [(SA602A)]
FM24CL16	FM24CL16@SOIC8 [(SA602A)]
FM24CL64@SOIC8 [(SA602A)]	FM25040
FM25040@SOIC8 [(SA602A)]	FM25160
FM25160@SOIC8 [(SA602A)]	FM25640
FM25640@SOIC8 [(SA602A)]	FM25C160
FM25C160@SOIC8 [(SA602A)]	FM25CL04@SOIC8 [(SA602A)]
FM25CL64	FM25CL64@SOIC8 [(SA602A)]
FM25L16	FM25L16@SOIC8 [(SA602A)]
FM25L256	FM25L256@SOIC8 [(SA602A)]
FM25L256@TDFN8 [(BBBB)]	FM25L512
FM25L512@SOIC8 [(SA602A)]	FM25W256@SOIC8 [(SA602A)]
FM30C256@SOIC20 [(SA404)]	FM3104@SOIC14 [(SA602)]
FM3116@SOIC14 [(SA602)]	FM31256@SOIC14 [(SA602)]
FM3164@SOIC14 [(SA602)]	FM32256G@SOIC14 [(SA602)]
FM32256S@SOIC14 [(SA602)]	FM3264G@SOIC14 [(SA602)]
FM3264S@SOIC14 [(SA602)]	FM3808
FM3808@TSOP32 [(SA620)]	

**MICROCONTROLLER**

VMX51C900	VMX51C900@PLCC44 [(SA244)]
VMX51C900@TQFP44 [(SA245A)]	VRS1000
VRS1000@PLCC44 [(SA244)]	VRS1000@TQFP44 [(SA245A)]
VRS1100	VRS1100@PLCC44 [(SA244)]
VRS1100@TQFP44 [(SA245A)]	VRS51C1000
VRS51C1000@PLCC44 [(SA244)]	VRS51C1000@TQFP44 [(SA245A)]
VRS51C1100	VRS51C1100@PLCC44 [(SA244)]
VRS51C1100@TQFP44 [(SA245A)]	VRS51C540
VRS51C540@PLCC44 [(SA244)]	VRS51C540@TQFP44 [(SA245A)]
VRS51C550	VRS51C550@PLCC44 [(SA244)]

VRS51C550@TQFP44 [(SA245A)]	VRS51C560
VRS51C560@PLCC44 [(SA244)]	VRS51C560@TQFP44 [(SA245A)]
VRS51C570	VRS51C570@PLCC44 [(SA244)]
VRS51C570@TQFP44 [(SA245A)]	VRS51C580
VRS51C580@PLCC44 [(SA244)]	VRS51C580@TQFP44 [(SA245A)]
VRS51C700	VRS51C700@PLCC44 [(SA244)]
VRS51C700@TQFP44 [(SA245A)]	VRS51L1050
VRS51L1050@PLCC44 [(SA244)]	VRS51L1050@TQFP44 [(SA245A)]
VRS51L540	VRS51L540@PLCC44 [(SA244)]
VRS51L540@TQFP44 [(SA245A)]	VRS51L550
VRS51L550@PLCC44 [(SA244)]	VRS51L550@TQFP44 [(SA245A)]
VRS51L560	VRS51L560@PLCC44 [(SA244)]
VRS51L560@TQFP44 [(SA245A)]	VRS51L570
VRS51L570@PLCC44 [(SA244)]	VRS51L570@TQFP44 [(SA245A)]
VRS51L580	VRS51L580@PLCC44 [(SA244)]
VRS51L580@TQFP44 [(SA245A)]	VRS51X540
VRS51X540@PLCC44 [(SA244)]	VRS51X540@TQFP44 [(SA245A)]
VRS51X550	VRS51X550@PLCC44 [(SA244)]
VRS51X550@TQFP44 [(SA245A)]	VRS51X560
VRS51X560@PLCC44 [(SA244)]	VRS51X560@TQFP44 [(SA245A)]
VRS51X570	VRS51X570@PLCC44 [(SA244)]
VRS51X570@TQFP44 [(SA245A)]	VRS51X580
VRS51X580@PLCC44 [(SA244)]	VRS51X580@TQFP44 [(SA245A)]
VRS540	VRS540@PLCC44 [(SA244)]
VRS540@TQFP44 [(SA245A)]	VRS550
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44 [(SA245A)]
VRS560	VRS560@PLCC44 [(SA244)]
VRS560@TQFP44 [(SA245A)]	VRS570
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44 [(SA245A)]
VRS580	VRS580@PLCC44 [(SA244)]
VRS580@TQFP44 [(SA245A)]	VRS700
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44 [(SA245A)]
VRS900	VRS900@PLCC44 [(SA244)]
VRS900@TQFP44 [(SA245A)]	

## RATO

### E (E) PROM / FRAM / NVRAM

RT24A02	RT24A02@SOIC8 [(SA602A)]
RT24A02@TSSOP8 [(SA026)]	RT24A04
RT24A04@SOIC8 [(SA602A)]	RT24A04@TSSOP8 [(SA026)]
RT24A08	RT24A08@SOIC8 [(SA602A)]
RT24A08@TSSOP8 [(SA026)]	RT24A16
RT24A16@SOIC8 [(SA602A)]	RT24A16@TSSOP8 [(SA026)]
RT93C46B(16bit)	RT93C46B(16bit)@SOIC8 [(SA602A)]
RT93C46B(16bit)@TSSOP8 [(SA026)]	RT93LC46(08bit)
RT93LC46(08bit)@SOIC8 [(SA602A)]	RT93LC46(08bit)@TSSOP8 [(SA026)]
RT93LC46(16bit)	RT93LC46(16bit)@SOIC8 [(SA602A)]
RT93LC46(16bit)@TSSOP8 [(SA026)]	

## RAYDIUM

### E (E) PROM / FRAM / NVRAM

RM24C02@SOP8 [(SA602A)]	RM24C04@SOP8 [(SA602A)]
RM24C08@SOP8 [(SA602A)]	RM24C128@SOP8 [(SA602A)]
RM24C16@SOP8 [(SA602A)]	RM24C32@SOP8 [(SA602A)]
RM24C64@SOP8 [(SA602A)]	

## RENESAS

### E (E) PROM / FRAM / NVRAM

HN29A128A0A@CSP95 [(SA642S-B066A-T064F001Y)]	
HN29A128A0A@TSOP48 [(SA247-B005)]	
HN29V128A0A@CSP95 [(SA642S-B066A-T064F001Y)]	
HN29V128A0A@TSOP48 [(SA247-B005)]	
HN29V256A0B@CSP95 [(SA642S-B066A-T064F001Y)]	
HN29V256A1B@CSP95 [(SA642S-B066A-T064F001Y)]	
HN58C256A(FP)@SOP28 [(SA630)]	HN58C256A(P)

HN58C256A(T)@TSOP28 [(SA643)]	HN58C257A(T)@TSOP32 [(SA620)]
HN58V24256	HN58V24256@SOIC8 [(SA602A)]
HN58V24256@TSSOP14 [(SA026)]	HN58V24512
HN58V24512@SOIC8 [(SA602A)]	HN58W241000
HN58W241000@SOIC8 [(SA602A)]	HN58X2402
HN58X2402@SOIC8 [(SA602A)]	HN58X2402@TSSOP8 [(SA026)]
HN58X2404	HN58X2404@SOIC8 [(SA602A)]
HN58X2404@TSSOP8 [(SA026)]	HN58X2408
HN58X2408@SOIC8 [(SA602A)]	HN58X2408@TSSOP8 [(SA026)]
HN58X24128	HN58X24128@SOIC8 [(SA602A)]
HN58X2416	HN58X2416@SOIC8 [(SA602A)]
HN58X2416@TSSOP8 [(SA026)]	HN58X24256
HN58X24256@SOIC8 [(SA602A)]	HN58X2432
HN58X2432@SOIC8 [(SA602A)]	HN58X2432@TSSOP8 [(SA026)]
HN58X24512	HN58X24512@SOIC8 [(SA602A)]
HN58X2464	HN58X2464@SOIC8 [(SA602A)]
HN58X2464@TSSOP8 [(SA026)]	HN58X2502@SOIC8 [(SA602A)]
HN58X2502@TSSOP8 [(SA026)]	HN58X2504@SOIC8 [(SA602A)]
HN58X2504@TSSOP8 [(SA026)]	HN58X25128@SOIC8 [(SA602A)]
HN58X25128@TSSOP14 [(SA026)]	HN58X25256@SOIC8 [(SA602A)]
HN58X25256@TSSOP14 [(SA026)]	HN58X2532@SOIC8 [(SA602A)]
HN58X2532@TSSOP8 [(SA026)]	HN58X2564@SOIC8 [(SA602A)]
HN58X2564@TSSOP8 [(SA026)]	M5L2732
M5L2732A	
M5M29KB331(AVP)@TSOP48 [(SA247-B005)]	
M5M29KB641(AVP)@TSOP48 [(SA247-B005)]	
M5M29KE131BTP@TSOP52 [(SA657-B117)]	
M5M29KE131BV@TSOP48 [(SA247-B005)]	
M5M29KT331(AVP)@TSOP48 [(SA247-B005)]	
M5M29KT641(AVP)@TSOP48 [(SA247-B005)]	
M6MG3B641S16TP@TSOP52 [(SA657-B036)]	
M6MG3T641S16TP@TSOP52 [(SA657-B036)]	
M6MGB321S4TP@TSOP52 [(SA657-B036)]	
M6MGB321S8TP@TSOP52 [(SA657-B036)]	
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]	
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]	
M6MGB331S8KT@TSOP52 [(SA657-B036)]	
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]	
M6MGB641S16TP@TSOP52 [(SA657-B036)]	
M6MGB641S4TP@TSOP52 [(SA657-B036)]	
M6MGB641S8TP@TSOP52 [(SA657-B036)]	
M6MGB647M34CKT@TSOP52 [(SA657-B036)]	
M6MGB64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]	
M6MGB64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]	
M6MGB64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]	
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]	
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]	
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]	
M6MGD13TW34DWG@CSP72 [(SA642F-B064A-T064F001)]	
M6MGD13TW34DWG@CSP72(fast speed) [(SA642F-B064A-T064F001)]	
M6MGE157S4KT@TSOP52 [(SA657-B055)]	
M6MGT321S4TP@TSOP52 [(SA657-B036)]	
M6MGT321S8TP@TSOP52 [(SA657-B036)]	
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]	
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]	
M6MGT331S8KT@TSOP52 [(SA657-B036)]	
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]	
M6MGT641S16TP@TSOP52 [(SA657-B036)]	
M6MGT641S4TP@TSOP52 [(SA657-B036)]	
M6MGT641S8TP@TSOP52 [(SA657-B036)]	
M6MGT647M34CKT@TSOP52 [(SA657-B036)]	
M6MGT64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]	
M6MGT64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]	
M6MGT64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]	
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]	
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]	
R1EX24002A@SOP8 [(SA602A)]	R1EX24002A@TSSOP8 [(SA026)]
R1EX24004A@SOP8 [(SA602A)]	R1EX24004A@TSSOP8 [(SA026)]
R1EX24008A@SOP8 [(SA602A)]	R1EX24008A@TSSOP8 [(SA026)]
R1EX24016A@SOP8 [(SA602A)]	R1EX24016A@TSSOP8 [(SA026)]
R1EX24032A@SOP8 [(SA602A)]	R1EX24032A@TSSOP8 [(SA026)]
R1EX24064A@SOP8 [(SA602A)]	R1EX24064A@TSSOP8 [(SA026)]
R1EX24128A@SOP8 [(SA602A)]	R1EX24128A@TSSOP8 [(SA026)]
R1EX24256A@SOP8 [(SA602A)]	R1EX24256A@TSSOP8 [(SA026)]
R1EX24512A@SOP8 [(SA602A)]	R1EX24512A@TSSOP8 [(SA026)]
V128128A0E@CSP95 [(SA642A-B105A-Y096N001)]	

## DRAM &amp; SRAM

R1LV0408C@SOP32 [(SA438T)]                    R1LV0408C@STSOP32 [(SA620)]  
 R1LV0408C@TSOP32 [(SA410T)]

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]                    HD4074344@SOIC28 [(SA404)]  
 HD4074394@SDIP28 [(SA022A)]                    HD4074394@SOIC28 [(SA404)]  
 HD6472357F@PQFP128(\*) [(SA720+B262)]  
 HD6472655F@PQFP128(\*) [(SA720+B175)]  
 HD6472655TE@TQFP128(\*) [(SA721+B174)]  
 HD6472655VF@PQFP128(\*) [(SA720+B175)]  
 HD6472655VTE@TQFP128(\*) [(SA721+B174)]  
 HD6473228P@SDIP64(\*) [(SA736-B229)]  
 HD6473238P@SDIP64(\*) [(SA736-B229)]  
 HD6473258P@SDIP64(\*) [(SA736-B229)]  
 HD6473308@PLCC84(\*) [(SA649-B8406)]  
 HD6473644@TQFP64 [(PEP+S621)]  
 HD64738024F(FP-80B)(\*) [(TA006-B006)]  
 HD64738024H(FP-80A)(\*) [(TA008-B006)]  
 HD64738024W(TFP-80C)(\*) [(TA007-B006)]  
 HD6473877H@TQFP100(\*) [(SA718+B202)]  
 HD6475328@PLCC84(\*) [(SA649-B8404)]  
 HD6475348@PLCC84(\*) [(SA649-B8404)]  
 HD6477034F@QFP112(\*) [(SA738+B213)]  
 HD64F2110BFA@QFP100(\*) [(SA718-B299)]  
 HD64F2110BTE@QFP100(\*) [(SA718-B299)]  
 HD64F2110BVFA@QFP100(\*) [(SA718-B299)]  
 HD64F2110BVTE@QFP100(\*) [(SA718-B299)]  
 HD64F2132RFA@QFP80 [(PEP+S615B)]            HD64F2132RTF@QFP80 [(PEP+S640B)]  
 HD64F2132RVFA@QFP80 [(PEP+S615B)]  
 HD64F2132RVTF@QFP80 [(PEP+S640B)]  
 HD64F2138AFA@TQFP80 [(PEP+S615B)]  
 HD64F2138ATF@TQFP80 [(PEP+S640B)]  
 HD64F2140BVFA@TQFP100 [(PEP+S604)]  
 HD64F2140BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2140BVTE@TQFP100 [(PEP+S604)]  
 HD64F2140BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2141BVFA@TQFP100 [(PEP+S604)]  
 HD64F2141BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2141BVTE@TQFP100 [(PEP+S604)]  
 HD64F2141BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RFA@TQFP100 [(PEP+S604)]  
 HD64F2142RFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RTE@TQFP100 [(PEP+S604)]  
 HD64F2142RTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RVFA@TQFP100 [(PEP+S604)]  
 HD64F2142RVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2142RVTE@TQFP100 [(PEP+S604)]  
 HD64F2142RVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144AFA@TQFP100 [(PEP+S604)]  
 HD64F2144AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144ATE@TQFP100 [(PEP+S604)]  
 HD64F2144ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144AVFA@TQFP100 [(PEP+S604)]  
 HD64F2144AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144AVTE@TQFP100 [(PEP+S604)]  
 HD64F2144AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144FA@TQFP100 [(PEP+S604)]  
 HD64F2144FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144TE@TQFP100 [(PEP+S604)]  
 HD64F2144TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144VFA@TQFP100 [(PEP+S604)]  
 HD64F2144VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2144VTE@TQFP100 [(PEP+S604)]  
 HD64F2144VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2145BVFA@TQFP100 [(PEP+S604)]  
 HD64F2145BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2145BVTE@TQFP100 [(PEP+S604)]  
 HD64F2145BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147AFA@TQFP100 [(PEP+S604)]  
 HD64F2147AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147ATE@TQFP100 [(PEP+S604)]  
 HD64F2147ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147AVFA@TQFP100 [(PEP+S604)]  
 HD64F2147AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147AVTE@TQFP100 [(PEP+S604)]  
 HD64F2147AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
 HD64F2147NFA@TQFP100 [(PEP+S604)]  
 HD64F2147NFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]

```

HD64F2147NTE@TQFP100 [(PEP+S604)]
HD64F2147NTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2147NVFA@TQFP100 [(PEP+S604)]
HD64F2147NVFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2147NVTE@TQFP100 [(PEP+S604)]
HD64F2147NVTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148AFA@TQFP100 [(PEP+S604)]
HD64F2148AFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148ATE@TQFP100 [(PEP+S604)]
HD64F2148ATE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148AVFA@TQFP100 [(PEP+S604)]
HD64F2148AVFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148AVTE@TQFP100 [(PEP+S604)]
HD64F2148AVTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148BFA@TQFP100 [(PEP+S604)]
HD64F2148BFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148BTE@TQFP100 [(PEP+S604)]
HD64F2148BTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148BVFA@TQFP100 [(PEP+S604)]
HD64F2148BVFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148BVTE@TQFP100 [(PEP+S604)]
HD64F2148BVTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148FA@TQFP100 [(PEP+S604)]
HD64F2148FA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148TE@TQFP100 [(PEP+S604)]
HD64F2148TE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148VFA@TQFP100 [(PEP+S604)]
HD64F2148VFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2148VTE@TQFP100 [(PEP+S604)]
HD64F2148VTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2149YFA@TQFP100 [(PEP+S604)]
HD64F2149YFA@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2149YTE@TQFP100 [(PEP+S604)]
HD64F2149YTE@TQFP100(*) [(SA718+B187 or TA068+B006)]
HD64F2166VTE33@TQFP144(*) [(TA047-B084)]
HD64F2167VTE33@TQFP144(*) [(TA047-B084)]
HD64F2168VTE33@TQFP144(*) [(TA047-B084)]
HD64F2177VTE33@TQFP144(*) [(TA047-B084)]
HD64F2265FA13@TQFP100 [(PEP+S604)]
HD64F2265FA20@TQFP100 [(PEP+S604)]
HD64F2265TE13@TQFP100 [(PEP+S604)]
HD64F2265TE20@TQFP100 [(PEP+S604)]
HD64F2265TF13@TQFP100 [(PEP+S604)]
HD64F2265TF20@TQFP100 [(PEP+S604)]
HD64F2266FA13@TQFP100 [(PEP+S604)]
HD64F2266FA20@TQFP100 [(PEP+S604)]
HD64F2266TE13@TQFP100 [(PEP+S604)]
HD64F2266TE20@TQFP100 [(PEP+S604)]
HD64F2266TF13@TQFP100 [(PEP+S604)]
HD64F2266TF20@TQFP100 [(PEP+S604)]
HD64F2268FA13@TQFP100 [(PEP+S604)]
HD64F2268FA20@TQFP100 [(PEP+S604)]
HD64F2268TE13@TQFP100 [(PEP+S604)]
HD64F2268TE20@TQFP100 [(PEP+S604)]
HD64F2268TF13@TQFP100 [(PEP+S604)]
HD64F2268TF20@TQFP100 [(PEP+S604)]
HD64F2280@PQFP100(*) [(TA046-B006)]
HD64F2282@PQFP100(*) [(TA046-B006)]
HD64F2326VF@PQFP128(*) [(SA720+B281)]
HD64F2326VTE@TQFP120(*) [(SA721+B282)]
HD64F2328BVF@PQFP128(*) [(SA720+B281)]
HD64F2328BVTE@TQFP120(*) [(SA721+B282)]
HD64F2328VF@PQFP128(*) [(SA720+B281)]
HD64F2328VTE@TQFP120(*) [(SA721+B282)]
HD64F2329BVF@PQFP128(*) [(SA720+B281)]
HD64F2329BVTE@TQFP120(*) [(SA721+B282)]
HD64F2329EVF@PQFP128(*) [(SA720+B281)]
HD64F2329EVTE@TQFP120(*) [(SA721+B282)]
HD64F2329VF@PQFP128(*) [(SA720+B281)]
HD64F2329VTE@TQFP120(*) [(SA721+B282)]
HD64F2338VF@TQFP144(*) [(SA681+B14415)]
HD64F2339EVF@TQFP144(*) [(SA681+B14415)]
HD64F2339VF@TQFP144(*) [(SA681+B14415)]
HD64F2357F@PQFP128(*) [(SA720+B193A)]
HD64F2357TE@QFP120(*) [(SA721+B194)]
HD64F2377@TQFP144(*) [(SA681-B14408)]
HD64F2377R@TQFP144(*) [(SA681-B14408)]
HD64F2398F@PQFP128(*) [(SA720+B193B)]
HD64F2398TE@QFP120(*) [(SA721+B194)]
HD64F2505FC26@QFP144(*) [(SA681+B14403)]
HD64F2506FC26@QFP144(*) [(SA681+B14403)]

```



HD64F2551FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2552FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2556FC20@QFP144(\*) [(SA681+B14403)]  
HD64F2612FA20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F24@TQFP80(\*) [(SA722+B176)]  
HD64F2646RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2648RFC20@QFP144 [(SA681+B14404)]  
HD64F2649FC20@QFP144(\*) [(SA681+B14404)]  
HD64F2667VFC33@QFP144(\*) [(SA681+B14402)]  
HD64F3024F@TQFP100(\*) [(TA029-B006)]  
HD64F3024FP@PQFP100(\*) [(TA030-B006)]  
HD64F3024TE@TQFP100(\*) [(TA029-B006)]  
HD64F3026F@TQFP100(\*) [(TA029-B006)]  
HD64F3026FP@PQFP100(\*) [(TA030-B006)]  
HD64F3026TE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048F@TQFP100(\*) [(TA067+B006)]  
HD64F3048TF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VTF@TQFP100(\*) [(TA067+B006)]  
HD64F3052BF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052F@TQFP100(\*) [(TA029-B006)]  
HD64F3052TE@TQFP100(\*) [(TA029-B006)]  
HD64F3062BF@TQFP100(\*) [(TA029-B006)]  
HD64F3062BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062F@TQFP100(\*) [(TA029-B006)]  
HD64F3062FP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062TE@TQFP100(\*) [(TA029-B006)]  
HD64F3064BF@TQFP100(\*) [(TA029-B006)]  
HD64F3064BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3064BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3064F@TQFP100(\*) [(TA029-B006)]  
HD64F3064FP@PQFP100(\*) [(TA030-B006)]  
HD64F3064TE@TQFP100(\*) [(TA029-B006)]  
HD64F3067F@TQFP100(\*) [(TA029-B006)]  
HD64F3067FP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067TE@TQFP100(\*) [(TA029-B006)]  
HD64F3068F@TQFP100(\*) [(TA029-B006)]  
HD64F3068TE@TQFP100(\*) [(TA029-B006)]  
HD64F3069F@TQFP100(\*) [(SA718+B271)]  
HD64F3069RF@TQFP100(\*) [(SA718+B271)]  
HD64F3069RTE@TQFP100(\*) [(SA718+B271)]  
HD64F3069TE@TQFP100(\*) [(SA718+B271)]  
HD64F3334YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3334YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3337YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3394YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3397CP17@PLCC84(\*) [(SA649-B8402)]  
HD64F3397F17@TQFP80(\*) [(TA018-B006)]  
HD64F3397FLH17@TQFP80(\*) [(TA018-B006)]

HD64F3397TF17@TQFP80(\*) [(TA019-B006)]  
 HD64F3397TFLH17@TQFP80(\*) [(TA019-B006)]  
 HD64F3434F@QFP100(\*) [(SA718+B306)]  
 HD64F3434TF@QFP100(\*) [(SA718+B306)]  
 HD64F3437F@QFP100(\*) [(SA718+B306)]  
 HD64F3437TF@QFP100(\*) [(SA718+B306)]  
 HD64F36012FX@TQFP48 [(SA671)] HD64F36012FY@TQFP48 [(SA248)]  
 HD64F36012GFP@TQFP64(\*) [(SA732+B313)]  
 HD64F36012GF@TQFP48 [(SA671)] HD64F36012GFY@TQFP48 [(SA248)]  
 HD64F36014FX@TQFP48 [(SA671)] HD64F36014FY@TQFP48 [(SA248)]  
 HD64F36014GFP@TQFP64(\*) [(SA732+B313)]  
 HD64F36014GF@TQFP48 [(SA671)] HD64F36014GFY@TQFP48 [(SA248)]  
 HD64F36022FX@TQFP48 [(SA671)] HD64F36022FY@TQFP48 [(SA248)]  
 HD64F36022GFP@TQFP64(\*) [(SA732+B313)]  
 HD64F36022GF@TQFP48 [(SA671)] HD64F36022GFY@TQFP48 [(SA248)]  
 HD64F36024FX@TQFP48 [(SA671)] HD64F36024FY@TQFP48 [(SA248)]  
 HD64F36024GFP@TQFP64(\*) [(SA732+B313)]  
 HD64F36024GF@TQFP48 [(SA671)] HD64F36024GFY@TQFP48 [(SA248)]  
 HD64F36034FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36034GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36034GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36034H@TQFP64(\*) [(TA042-B006)]  
 HD64F36037FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36037GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36037GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36037H@TQFP64(\*) [(TA042-B006)]  
 HD64F36054FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36054GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36054GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36054H@TQFP64(\*) [(TA042-B006)]  
 HD64F36057FZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36057GFZ@TQFP64(\*) [(TA043-B006)]  
 HD64F36057GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36057H@TQFP64(\*) [(TA042-B006)]  
 HD64F36064GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F36064GH@TQFP64(\*) [(TA042-B006)]  
 HD64F36074GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36074GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36074GH@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36074GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36074LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36074LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36074LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36074LHZW@QFP64(\*) [(SA732-B235)]  
 HD64F36077GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36077GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36077GH@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36077GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36077LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36077LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36077LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36077LHZW@QFP64(\*) [(SA732-B235)]  
 HD64F36078GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36078GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36078GH@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHV@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHZ@QFP64(\*) [(SA757-B235)]  
 HD64F36078GHZW@QFP64(\*) [(SA757-B235)]  
 HD64F36078LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LHV@QFP64(\*) [(SA732-B235)]  
 HD64F36078LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LHZ@QFP64(\*) [(SA732-B235)]  
 HD64F36078LHZW@QFP64(\*) [(SA732-B235)]  
 HD64F36079GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36079GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36079GH@QFP64(\*) [(SA757-B235)]

```

HD64F36079GHV@QFP64(*) [(SA757-B235)]
HD64F36079GHW@QFP64(*) [(SA757-B235)]
HD64F36079GHZ@QFP64(*) [(SA757-B235)]
HD64F36079GHZW@QFP64(*) [(SA757-B235)]
HD64F36079LFZ@LQFP64(*) [(SA732-B235)]
HD64F36079LFZW@LQFP64(*) [(SA732-B235)]
HD64F36079LH@LQFP64(*) [(SA732-B235)]
HD64F36079LHV@QFP64(*) [(SA732-B235)]
HD64F36079LHW@LQFP64(*) [(SA732-B235)]
HD64F36079LHZ@QFP64(*) [(SA732-B235)]
HD64F36079LHZW@QFP64(*) [(SA732-B235)]
HD64F36087FP@LQFP64(*) [(SA732-B235)]
HD64F36087H@QFP64(*) [(SA757-B235)]
HD64F3642AH@QFP64(*) [(SA668+B275)]
HD64F3642AP@SDIP64(*) [(SA736+B274)]
HD64F3642AW@QFP80(*) [(SA731+B276)]
HD64F3643H@QFP64(*) [(SA668+B275)]
HD64F3643P@SDIP64(*) [(SA736+B274)]
HD64F3643W@QFP80(*) [(SA731+B276)]
HD64F3644H@QFP64(*) [(SA668+B275)]
HD64F3644P@SDIP64(*) [(SA736+B274)]
HD64F3644W@QFP80(*) [(SA731+B276)]
HD64F3664BP@SDIP42 [(SA028)] HD64F3664FP@TQFP64 [(PEP+S616)]
HD64F3664FP@TQFP64(*) [(SA732+B224)]
HD64F3664FX@TQFP48 [(SA671)] HD64F3664FY@TQFP48 [(SA248)]
HD64F3664H@TQFP64 [(PEP+S621)] HD64F3664FP@TQFP64 [(PEP+S616)]
HD64F3684FP@TQFP64(*) [(TA043-B006)]
HD64F3684GFP@TQFP64 [(PEP+S616)]
HD64F3684GFP@TQFP64(*) [(TA043-B006)]
HD64F3684GH@TQFP64 [(PEP+S621)]
HD64F3684GH@TQFP64(*) [(TA042-B006)]
HD64F3684H@TQFP64 [(PEP+S621)]
HD64F3684H@TQFP64(*) [(TA042-B006)]
HD64F3687FP@TQFP64 [(PEP+S616)]
HD64F3687FP@TQFP64(*) [(TA043-B006)]
HD64F3687GFP@TQFP64 [(PEP+S616)]
HD64F3687GFP@TQFP64(*) [(TA043-B006)]
HD64F3687GH@TQFP64 [(PEP+S621)]
HD64F3687GH@TQFP64(*) [(TA042-B006)]
HD64F3687H@TQFP64 [(PEP+S621)]
HD64F3687H@TQFP64(*) [(TA042-B006)]
HD64F36902G@LQFP32 [(SA663)] HD64F36902G@SOP32 [(SA682)]
HD64F36912G@LQFP32 [(SA663)] HD64F36912G@SOP32 [(SA682)]
HD64F3694FP@TQFP64 [(PEP+S616)] HD64F3694FX@TQFP48 [(SA671)]
HD64F3694FY@TQFP48 [(SA248)] HD64F3694GFP@TQFP64 [(PEP+S616)]
HD64F3694GF@TQFP48 [(SA671)] HD64F3694GFY@TQFP48 [(SA248)]
HD64F3694GH@TQFP64 [(PEP+S621)] HD64F3694H@TQFP64 [(PEP+S621)]
HD64F38002FPA@TQFP64 [(PEP+S625A)]
HD64F38002FPE@TQFP64 [(PEP+S616)]
HD64F38004FPA@TQFP64 [(PEP+S625A)]
HD64F38004FPE@TQFP64 [(PEP+S616)]
HD64F38024F(FP-80B)@PQFP80 [(PEP+S611A)]
HD64F38024F(FP-80B)@PQFP80(*) [(TA003-B006)]
HD64F38024H(FP-80A)@TQFP80 [(PEP+S615B)]
HD64F38024H(FP-80A)@TQFP80(*) [(TA005-B006)]
HD64F38024RF(FP-80B)@PQFP80 [(PEP+S611A)]
HD64F38024RF(FP-80B)@PQFP80(*) [(TA003-B006)]
HD64F38024RH(FP-80A)@TQFP80 [(PEP+S615B)]
HD64F38024RH(FP-80A)@TQFP80(*) [(TA005-B006)]
HD64F38024RW(TFP-80C)@TQFP80 [(PEP+S640B)]
HD64F38024RW(TFP-80C)@TQFP80(*) [(TA004-B006)]
HD64F38024W(TFP-80C)@TQFP80 [(PEP+S640B)]
HD64F38024W(TFP-80C)@TQFP80(*) [(TA004-B006)]
HD64F38102FPA@TQFP64 [(PEP+S625A)]
HD64F38102FPE@TQFP64 [(PEP+S616)]
HD64F38104FPA@TQFP64 [(PEP+S625A)]
HD64F38104FPE@TQFP64 [(PEP+S616)]
HD64F38124F(FP-80B)@PQFP80 [(PEP+S611A)]
HD64F38124F(FP-80B)@PQFP80(*) [(TA003-B006)]
HD64F38124H(FP-80A)@TQFP80 [(PEP+S615B)]
HD64F38124H(FP-80A)@TQFP80(*) [(TA005-B006)]
HD64F38124W(TFP-80C)@TQFP80 [(PEP+S640B)]
HD64F38124W(TFP-80C)@TQFP80(*) [(TA004-B006)]
HD64F39802G@SDIP32 [(SA653)]
HD64F7044F@QFP112(*) [(SA755+B278)]
HD64F7046F@QFP80(*) [(TA014+B006)]
HD64F7047@QFP100(*) [(SA718+B172)]
M30260F3AGP@QFP48 [(SA248)] M30260F3TGP@QFP48 [(SA248)]
M30260F3VGP@QFP48 [(SA248)] M30260F6AGP@QFP48 [(SA248)]
M30260F6TGP@QFP48 [(SA248)] M30260F6VGP@QFP48 [(SA248)]
M30260F8AGP@QFP48 [(SA248)] M30260F8TGP@QFP48 [(SA248)]

```

```

M30260F8VGP@QFP48 [(SA248)]
M30262F4GP@QFP48 [(SA248)]
M30262F8GP@QFP48 [(SA248)]
M30263F6AFP@SSOP42 [(SA775)]
M30280F6HP@QFP80 [(SA731-B230)]
M30280FAHP@QFP80 [(SA731-B230)]
M30280FAVHP@QFP80 [(SA731-B230)]
M30281F6HP@QFP64 [(SA732-B315)]
M30281FAHP@QFP64 [(SA732-B315)]
M30281FAVHP@QFP64 [(SA732-B315)]
M30290FAHP@QFP80 [(SA731-B230)]
M30290FAVHP@QFP80 [(SA731-B230)]
M30290FCTHP@QFP80 [(SA731-B230)]
M30291F8HP@QFP64(*) [(SA732-B315)]
M30291F8THP@QFP64(*) [(SA732-B315)]
M30291F8VHP@QFP64(*) [(SA732-B315)]
M30291FAHP@QFP64(*) [(SA732-B315)]
M30291FATHP@QFP64(*) [(SA732-B315)]
M30291FAVHP@QFP64(*) [(SA732-B315)]
M30291FCHP@QFP64(*) [(SA732-B315)]
M30291FCTHP@QFP64(*) [(SA732-B315)]
M30291FCVHP@QFP64(*) [(SA732-B315)]
M30620FCAFP@PQFP100(*) [(TA012-B006)]
M30620FCAGP@TQFP100(*) [(TA013-B006)]
M30620FCPPFP@PQFP100(*) [(TA012-B006)]
M30620FCPGP@TQFP100(*) [(TA013-B006)]
M30622F8PFP@PQFP100(*) [(TA012-B006)]
M30622F8PGP@TQFP100(*) [(TA013-B006)]
M30624FGAFP@PQFP100(*) [(TA012-B006)]
M30624FGAGP@TQFP100(*) [(TA013-B006)]
M30624FGPPFP@PQFP100(*) [(TA012-B006)]
M30624FGPGP@TQFP100(*) [(TA013-B006)]
M30626FHPPFP@PQFP100(*) [(TA012-B006)]
M30626FHPPGP@TQFP100(*) [(TA013-B006)]
M30627FHPPGP@PQFP128(*) [(SA720-B228)]
M3062LFGPPFP@PQFP100(*) [(TA012-B006)]
M3062LFGPGP@TQFP100(*) [(TA013-B006)]
M306N4FCFP@PQFP100(*) [(TA012-B006)]
M306N4FCGP@QFP100(*) [(TA013-B006)]
M306N4FCTFP@PQFP100(*) [(TA012-B006)]
M306N4FCTGP@QFP100(*) [(TA013-B006)]
M306N4FCVFP@PQFP100(*) [(TA012-B006)]
M306N4FCVGP@QFP100(*) [(TA013-B006)]
M306N4FGFP@PQFP100(*) [(TA012-B006)]
M306N4FGGP@QFP100(*) [(TA013-B006)]
M306N4FGTFF@PQFP100(*) [(TA012-B006)]
M306N4FGTGP@QFP100(*) [(TA013-B006)]
M306N4FGVFP@PQFP100(*) [(TA012-B006)]
M306N4FGVGP@QFP100(*) [(TA013-B006)]
M306N5FCFP@PQFP100(*) [(TA012-B006)]
M306N5FCGP@QFP100(*) [(TA013-B006)]
M306N5FCTFP@PQFP100(*) [(TA012-B006)]
M306N5FCTGP@QFP100(*) [(TA013-B006)]
M306N5FCVFP@PQFP100(*) [(TA012-B006)]
M306N5FCVGP@QFP100(*) [(TA013-B006)]
M306NKFHGP@QFP100(*) [(TA013-B006)]
M306NKFHTGP@QFP100(*) [(TA013-B006)]
M306NKFHVGP@QFP100(*) [(TA013-B006)]
M306NKFJGP@QFP100(*) [(TA013-B006)]
M306NKFJTGP@QFP100(*) [(TA013-B006)]
M306NKFJVGP@QFP100(*) [(TA013-B006)]
M306NLFHGP@QFP100(*) [(TA013-B006)]
M306NLFHTGP@QFP100(*) [(TA013-B006)]
M306NLFHVGP@QFP100(*) [(TA013-B006)]
M306NLFJGP@QFP100(*) [(TA013-B006)]
M306NLFJTGP@QFP100(*) [(TA013-B006)]
M306NLFJVGP@QFP100(*) [(TA013-B006)]
M306NMFHGP@QFP128(*) [(SA720-B228)]
M306NMFHTGP@QFP128(*) [(SA720-B228)]
M306NMFHVGP@QFP128(*) [(SA720-B228)]
M306NMFJGP@QFP128(*) [(SA720-B228)]
M306NMFJTGP@QFP128(*) [(SA720-B228)]
M306NMFJVGP@QFP128(*) [(SA720-B228)]
M306NNFHGP@QFP128(*) [(SA720-B228)]
M306NNFHVGP@QFP128(*) [(SA720-B228)]
M306NNFJGP@QFP128(*) [(SA720-B228)]
M306NNFJTGP@QFP128(*) [(SA720-B228)]
M306NNFJVGP@QFP128(*) [(SA720-B228)]
M306NNTFHGP@QFP128(*) [(SA720-B228)]
M34282E2GP [(SA026)]
M34283G2GP (ISP) [ISP-HEADER01]
M30262F3GP@QFP48 [(SA248)]
M30262F6GP@QFP48 [(SA248)]
M30263F3AFP@SSOP42 [(SA775)]
M30263F8AFP@SSOP42 [(SA775)]
M30280F8HP@QFP80 [(SA731-B230)]
M30280FATHP@QFP80 [(SA731-B230)]
M30280FCHP@QFP80 [(SA731-B230)]
M30281F8HP@QFP64 [(SA732-B315)]
M30281FATHP@QFP64 [(SA732-B315)]
M30281FCHP@QFP64 [(SA732-B315)]
M30290FATHP@QFP80 [(SA731-B230)]
M30290FCHP@QFP80 [(SA731-B230)]
M30290FCVHP@QFP80 [(SA731-B230)]
M34283G2GP [(SA026)]
M34508G4FP [(SA023A)]

```

```

M34508G4GP [(SA026)] M34508G4HFP [(SA023A)]
M34508G4HGP [(SA026)] M34509G4FPP [(SA711-B005)]
M34509G4HFP [(SA711-B005)] M34559G6FPP@QFP52 [(PEP-S673)]
M34559G6FPP@QFP52(*) [(SA740+B342)]
M3455AG8FPP@QFP52 [(PEP-S673)]
M3455AG8FPP@QFP52(*) [(SA740+B342)]
M3455AGCFPP@QFP52 [(PEP-S673)]
M3455AGCFPP@QFP52(*) [(SA740+B342)]
M37531E4FPP@SSOP36 [(SA775)] M37531E8FPP@SSOP36 [(SA775)]
M37544G2(GP)@LQFP32 [(SA663)] M37544G2(SP)@SDIP32 [(SA653)]
M37544G2A(GP)@LQFP32 [(SA663)]
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]
M37544G2A(SP)@SDIP32 [(SA653)]
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32 [(SA663)]
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36 [(SA645)]
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]
M37546G2(GP)@LQFP32 [(SA663)]
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]
M37546G2(SP)@SDIP32 [(SA653)]
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]
M37546G4(FP)@SSOP36 [(SA645)]
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]
M37546G4(GP)@LQFP32 [(SA663)]
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]
M37546G4(SP)@SDIP32 [(SA653)]
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]
M37547G2(FP)@SSOP36 [(SA645)]
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]
M37547G4(FP)@SSOP36 [(SA645)]
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20 [(SA026)]
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FPP@SSOP24 [(SA711)]
M37549G1SP@SDIP24 [(SA653)] M37549G2FPP@SSOP24 [(SA711)]
M37549G2SP@SDIP24 [(SA653)] M37549G3FPP@SSOP24 [(SA711)]
M37549G3SP@SDIP24 [(SA653)]
M38234G4(FP)@PQFP80 [(SA730+B191)]
M38234G4(HP)@TQFP80 [(SA731+B192)]
M38235G6(FP)@PQFP80 [(SA730+B191)]
M38235G6(HP)@TQFP80 [(SA731+B192)]
M38238G8(FP)@PQFP80 [(SA730+B191)]
M38238G8(HP)@TQFP80 [(SA731+B192)]
M38239GC(FP)@PQFP80 [(SA730+B191)]
M38239GC(HP)@TQFP80 [(SA731+B192)]
M3823AGF(FP)@PQFP80 [(SA730+B191)]
M3823AGF(HP)@TQFP80 [(SA731+B192)]
M38503G4A(FP)@SSOP42 [(SA645)] M38503G4A(SP)@SDIP42 [(SA028)]
M38507F8(FP)@SSOP42 [(SA645)] M38507F8(SP)@SDIP42 [(SA028)]
M38588G6(FP)@SSOP42 [(SA645)] M38588G6(SP)@SDIP42 [(SA028)]
M38588G8(FP)@SSOP42 [(SA645)] M38588G8(SP)@SDIP42 [(SA028)]
M38588GC(FP)@SSOP42 [(SA645)] M38588GC(SP)@SDIP42 [(SA028)]
M38859@TQFP80 [(PEP+S640B)] M38D24G4FPP@TQFP64 [(PEP+S625A)]
M38D24G4HP@TQFP64 [(PEP+S616)] M38D24G6FPP@TQFP64 [(PEP+S625A)]
M38D24G6HP@TQFP64 [(PEP+S616)] M38D28G8FPP@TQFP64 [(PEP+S625A)]
M38D28G8HP@TQFP64 [(PEP+S616)] M38D29GCFPP@TQFP64 [(PEP+S625A)]
M38D29GCHFP@TQFP64 [(PEP+S616)] M38D29GFFPP@TQFP64 [(PEP+S625A)]
M38D29GFHP@TQFP64 [(PEP+S616)]
M3NN00FETGP@QFP100(*) [(TA013-B006)]
R4F2463VTE34DV@TQFP144(*) [(SA748-B14419)]
R4F2463VTE34V@TQFP144(*) [(SA748-B14419)]
R5F21102DFPP@TQFP32 [(SA663+B005)]
R5F21102DFPP@TQFP32(ISP) [ISP-HEADER01]
R5F21102FPP@TQFP32 [(SA663+B005)]
R5F21102FPP@TQFP32(ISP) [ISP-HEADER01]
R5F21103DFPP@TQFP32 [(SA663+B005)]
R5F21103DFPP@TQFP32(ISP) [ISP-HEADER01]
R5F21103FPP@TQFP32 [(SA663+B005)]
R5F21103FPP@TQFP32(ISP) [ISP-HEADER01]
R5F21104DFPP@TQFP32 [(SA663+B005)]
R5F21104DFPP@TQFP32(ISP) [ISP-HEADER01]
R5F21104FPP@TQFP32 [(SA663+B005)]
R5F21104FPP@TQFP32(ISP) [ISP-HEADER01]
R5F21112DFPP@TQFP32 [(SA663+B005)]
R5F21112DFPP@TQFP32(ISP) [ISP-HEADER01]
R5F21112FPP@TQFP32 [(SA663+B005)]
R5F21112FPP@TQFP32(ISP) [ISP-HEADER01]
R5F21113DFPP@TQFP32 [(SA663+B005)]
R5F21113DFPP@TQFP32(ISP) [ISP-HEADER01]
R5F21113FPP@TQFP32 [(SA663+B005)]
R5F21113FPP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFPP@TQFP32 [(SA663+B005)]

```

```
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FF@TQFP32 [(SA663+B005)]
R5F21114FF@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FF@TQFP32 [(SA663+B005)]
R5F21122FF@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FF@TQFP32 [(SA663+B005)]
R5F21123FF@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FF@TQFP32 [(SA663+B005)]
R5F21124FF@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FF@TQFP32 [(SA663+B005)]
R5F21132FF@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FF@TQFP32 [(SA663+B005)]
R5F21133FF@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FF@TQFP32 [(SA663+B005)]
R5F21134FF@TQFP32(ISP) [ISP-HEADER01]
R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
```

R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]

R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]



```
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
```

R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218KFP@TQFP48 [(SA248-B005)]  
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AJFP@TQFP48 [(SA248-B005)]  
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121AKFP@TQFP48 [(SA248-B005)]  
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CJFP@TQFP48 [(SA248-B005)]  
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2121CKFP@TQFP48 [(SA248-B005)]  
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226JFP@TQFP48 [(SA248-B005)]  
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21226KFP@TQFP48 [(SA248-B005)]  
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227JFP@TQFP48 [(SA248-B005)]  
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21227KFP@TQFP48 [(SA248-B005)]  
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228JFP@TQFP48 [(SA248-B005)]  
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21228KFP@TQFP48 [(SA248-B005)]  
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]

```

R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21244SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(single) [(PEP-S673)]
R5F21244SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART) [(PEP+S673)]
R5F21244SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21244SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21244SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single) [(PEP-S673)]
R5F21244SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART) [(PEP+S673)]
R5F21244SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21245SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21245SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(single) [(PEP-S673)]
R5F21245SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(UART) [(PEP+S673)]
R5F21245SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21245SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21245SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(single) [(PEP-S673)]
R5F21245SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(UART) [(PEP+S673)]
R5F21245SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21246SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21246SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single) [(PEP-S673)]
R5F21246SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART) [(PEP+S673)]

```

```
R5F21246SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21246SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21246SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single) [(PEP-S673)]
R5F21246SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART) [(PEP+S673)]
R5F21246SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21247SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21247SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single) [(PEP-S673)]
R5F21247SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART) [(PEP+S673)]
R5F21247SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21247SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21247SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single) [(PEP-S673)]
R5F21247SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART) [(PEP+S673)]
R5F21247SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21248SDFP@TQFP52(parallel) [(PEP-S673)]
R5F21248SDFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single) [(PEP-S673)]
R5F21248SDFP@TQFP52(single)(*) [(SA740-B225)]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART) [(PEP+S673)]
R5F21248SDFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21248SNFP@TQFP52(parallel) [(PEP-S673)]
R5F21248SNFP@TQFP52(parallel)(*) [(SA740-B225)]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single) [(PEP-S673)]
R5F21248SNFP@TQFP52(single)(*) [(SA740-B225)]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART) [(PEP+S673)]
R5F21248SNFP@TQFP52(UART)(*) [(SA740+B225)]
R5F21254SDFP@TQFP52 [(PEP-S673)]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single wire) [(PEP+S673)]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART mode) [(PEP+S673)]
R5F21254SNFP@TQFP52 [(PEP-S673)]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single wire) [(PEP+S673)]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART mode) [(PEP+S673)]
R5F21256SDFP@TQFP52 [(PEP-S673)]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single wire) [(PEP+S673)]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART mode) [(PEP+S673)]
R5F21256SNFP@TQFP52 [(PEP-S673)]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single wire) [(PEP+S673)]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART mode) [(PEP+S673)]
R5F21257SDFP@TQFP52 [(PEP-S673)]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single wire) [(PEP+S673)]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART mode) [(PEP+S673)]
R5F21257SNFP@TQFP52 [(PEP-S673)]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single wire) [(PEP+S673)]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART mode) [(PEP+S673)]
R5F21258SDFP@TQFP52 [(PEP-S673)]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single wire) [(PEP+S673)]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART mode) [(PEP+S673)]
R5F21258SNFP@TQFP52 [(PEP-S673)]
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(single wire) [(PEP+S673)]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART mode) [(PEP+S673)]
```

```
R5F21262DFP@QFP32 [(SA663)]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single wire) [(SA663)]
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(UART mode) [(SA663)]
R5F21262JFP@QFP32 [(SA663)]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single wire) [(SA663)]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART mode) [(SA663)]
R5F21262KFP@QFP32 [(SA663)]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single wire) [(SA663)]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART mode) [(SA663)]
R5F21262NFP@QFP32 [(SA663)]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single wire) [(SA663)]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART mode) [(SA663)]
R5F21262SDFP@QFP32 [(SA663)]
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single wire) [(SA663)]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART mode) [(SA663)]
R5F21262SJFP@QFP32 [(SA663)]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single wire) [(SA663)]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART mode) [(SA663)]
R5F21262SKFP@QFP32 [(SA663)]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single wire) [(SA663)]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART mode) [(SA663)]
R5F21262SNFP@QFP32 [(SA663)]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single wire) [(SA663)]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART mode) [(SA663)]
R5F21264DFP@QFP32 [(SA663)]
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single wire) [(SA663)]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART mode) [(SA663)]
R5F21264JFP@QFP32 [(SA663)]
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(single wire) [(SA663)]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART mode) [(SA663)]
R5F21264KFP@QFP32 [(SA663)]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single wire) [(SA663)]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART mode) [(SA663)]
R5F21264NFP@QFP32 [(SA663)]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single wire) [(SA663)]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART mode) [(SA663)]
R5F21264SDFP@QFP32 [(SA663)]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single wire) [(SA663)]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(UART mode) [(SA663)]
R5F21264SJFP@QFP32 [(SA663)]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single wire) [(SA663)]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART mode) [(SA663)]
R5F21264SKFP@QFP32 [(SA663)]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single wire) [(SA663)]
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(UART mode) [(SA663)]
R5F21264SNFP@QFP32 [(SA663)]
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(single wire) [(SA663)]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART mode) [(SA663)]
R5F21265DFP@QFP32 [(SA663)]
```

R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]

```
R5F21272DFP@QFP32(single wire) [(SA663)]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(UART mode) [(SA663)]
R5F21272JFP@QFP32 [(SA663)]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single wire) [(SA663)]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART mode) [(SA663)]
R5F21272KFP@QFP32 [(SA663)]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single wire) [(SA663)]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART mode) [(SA663)]
R5F21272NFP@QFP32 [(SA663)]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single wire) [(SA663)]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART mode) [(SA663)]
R5F21272SDFP@QFP32 [(SA663)]
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(single wire) [(SA663)]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART mode) [(SA663)]
R5F21272SJFP@QFP32 [(SA663)]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single wire) [(SA663)]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART mode) [(SA663)]
R5F21272SKFP@QFP32 [(SA663)]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single wire) [(SA663)]
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART mode) [(SA663)]
R5F21272SNFP@QFP32 [(SA663)]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single wire) [(SA663)]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART mode) [(SA663)]
R5F21274DFP@QFP32 [(SA663)]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single wire) [(SA663)]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART mode) [(SA663)]
R5F21274JFP@QFP32 [(SA663)]
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(single wire) [(SA663)]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART mode) [(SA663)]
R5F21274KFP@QFP32 [(SA663)]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single wire) [(SA663)]
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART mode) [(SA663)]
R5F21274NFP@QFP32 [(SA663)]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single wire) [(SA663)]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART mode) [(SA663)]
R5F21274SDFP@QFP32 [(SA663)]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single wire) [(SA663)]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART mode) [(SA663)]
R5F21274SJFP@QFP32 [(SA663)]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single wire) [(SA663)]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART mode) [(SA663)]
R5F21274SKFP@QFP32 [(SA663)]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single wire) [(SA663)]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART mode) [(SA663)]
R5F21274SNFP@QFP32 [(SA663)]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single wire) [(SA663)]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART mode) [(SA663)]
R5F21275DFP@QFP32 [(SA663)]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single wire) [(SA663)]
```

R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]



R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]

```
R5F21292JSP@SOIC20 [(SA026)]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single wire) [(SA026)]
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(UART mode) [(SA026)]
R5F21292KSP@SOIC20 [(SA026)]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single wire) [(SA026)]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART mode) [(SA026)]
R5F21292NSP@SOIC20 [(SA026)]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single wire) [(SA026)]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART mode) [(SA026)]
R5F21292SDSP@SOIC20 [(SA026)]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single wire) [(SA026)]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART mode) [(SA026)]
R5F21292SJSP@SOIC20 [(SA026)]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single wire) [(SA026)]
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART mode) [(SA026)]
R5F21292SKSP@SOIC20 [(SA026)]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single wire) [(SA026)]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART mode) [(SA026)]
R5F21292SNSP@SOIC20 [(SA026)]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single wire) [(SA026)]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART mode) [(SA026)]
R5F21294DSP@SOIC20 [(SA026)]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single wire) [(SA026)]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART mode) [(SA026)]
R5F21294JSP@SOIC20 [(SA026)]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single wire) [(SA026)]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART mode) [(SA026)]
R5F21294KSP@SOIC20 [(SA026)]
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single wire) [(SA026)]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART mode) [(SA026)]
R5F21294NSP@SOIC20 [(SA026)]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single wire) [(SA026)]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART mode) [(SA026)]
R5F21294SDSP@SOIC20 [(SA026)]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single wire) [(SA026)]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART mode) [(SA026)]
R5F21294SJSP@SOIC20 [(SA026)]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single wire) [(SA026)]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART mode) [(SA026)]
R5F21294SKSP@SOIC20 [(SA026)]
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single wire) [(SA026)]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART mode) [(SA026)]
R5F21294SNSP@SOIC20 [(SA026)]
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(single wire) [(SA026)]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART mode) [(SA026)]
R5F212A7SDFA@TQFP64 [(SA768-B251)]
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(single wire) [(SA768-B251)]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART mode) [(SA768+B251)]
R5F212A7SDFP@TQFP64 [(SA732-B251)]
```

```
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single wire) [(SA732-B251)]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART mode) [(SA732+B251)]
R5F212A7SNFA@TQFP64 [(SA768-B251)]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single wire) [(SA768-B251)]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART mode) [(SA768+B251)]
R5F212A7SNFP@TQFP64 [(SA732-B251)]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single wire) [(SA732-B251)]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART mode) [(SA732+B251)]
R5F212A8SDFA@TQFP64 [(SA768-B251)]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single wire) [(SA768-B251)]
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(UART mode) [(SA768+B251)]
R5F212A8SDFP@TQFP64 [(SA732-B251)]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single wire) [(SA732-B251)]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART mode) [(SA732+B251)]
R5F212A8SNFA@TQFP64 [(SA768-B251)]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single wire) [(SA768-B251)]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART mode) [(SA768+B251)]
R5F212A8SNFP@TQFP64 [(SA732-B251)]
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(single wire) [(SA732-B251)]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART mode) [(SA732+B251)]
R5F212AASDFA@TQFP64 [(SA768-B251)]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single wire) [(SA768-B251)]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART mode) [(SA768+B251)]
R5F212AASDFP@TQFP64 [(SA732-B251)]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single wire) [(SA732-B251)]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART mode) [(SA732+B251)]
R5F212AASNFA@TQFP64 [(SA768-B251)]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single wire) [(SA768-B251)]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART mode) [(SA768+B251)]
R5F212AASNFP@TQFP64 [(SA732-B251)]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single wire) [(SA732-B251)]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART mode) [(SA732+B251)]
R5F212ACSDFA@TQFP64 [(SA768-B251)]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single wire) [(SA768-B251)]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART mode) [(SA768+B251)]
R5F212ACSDFP@TQFP64 [(SA732-B251)]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single wire) [(SA732-B251)]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART mode) [(SA732+B251)]
R5F212ACSNFA@TQFP64 [(SA768-B251)]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single wire) [(SA768-B251)]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART mode) [(SA768+B251)]
R5F212ACSNFP@TQFP64 [(SA732-B251)]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single wire) [(SA732-B251)]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART mode) [(SA732+B251)]
R5F212B7SDFA@TQFP64 [(SA768-B251)]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single wire) [(SA768+B251)]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART mode) [(SA768+B251)]
R5F212B7SDFP@TQFP64 [(SA732-B251)]
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
```

R5F212B7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SNFA@TQFP64 [(SA768-B251)]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SNFP@TQFP64 [(SA732-B251)]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SDFA@TQFP64 [(SA768-B251)]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SDFP@TQFP64 [(SA732-B251)]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SNFA@TQFP64 [(SA768-B251)]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SNFP@TQFP64 [(SA732-B251)]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASDFA@TQFP64 [(SA768-B251)]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASDFP@TQFP64 [(SA732-B251)]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASNFA@TQFP64 [(SA768-B251)]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASNFP@TQFP64 [(SA732-B251)]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSDFA@TQFP64 [(SA768-B251)]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSDFP@TQFP64 [(SA732-B251)]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSNFA@TQFP64 [(SA768-B251)]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSNFP@TQFP64 [(SA732-B251)]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212C7SDFP@TQFP80 [(SA731-B249)]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single wire) [(SA731-B249)]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C7SNFP@TQFP80 [(SA731-B249)]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single wire) [(SA731-B249)]

```
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212C8SDFP@TQFP80 [(SA731-B249)]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single wire) [(SA731-B249)]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212C8SNFP@TQFP80 [(SA731-B249)]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single wire) [(SA731-B249)]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212CASDFP@TQFP80 [(SA731-B249)]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single wire) [(SA731-B249)]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212CASNFP@TQFP80 [(SA731-B249)]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single wire) [(SA731-B249)]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212CCSDFP@TQFP80 [(SA731-B249)]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single wire) [(SA731-B249)]
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212CCSNFP@TQFP80 [(SA731-B249)]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single wire) [(SA731-B249)]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212D7SDFP@TQFP80 [(SA731-B249)]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single wire) [(SA731+B249)]
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212D7SNFP@TQFP80 [(SA731-B249)]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single wire) [(SA731+B249)]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212D8SDFP@TQFP80 [(SA731-B249)]
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(single wire) [(SA731+B249)]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212D8SNFP@TQFP80 [(SA731-B249)]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single wire) [(SA731+B249)]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212DASDFP@TQFP80 [(SA731-B249)]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single wire) [(SA731+B249)]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212DASNFP@TQFP80 [(SA731-B249)]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single wire) [(SA731+B249)]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212DCSDFP@TQFP80 [(SA731-B249)]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single wire) [(SA731+B249)]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART mode) [(SA731+B249)]
R5F212DCSNFP@TQFP80 [(SA731-B249)]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single wire) [(SA731+B249)]
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(UART mode) [(SA731+B249)]
R5F212G4SDFP@QFP32 [(SA663)]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single wire) [(SA663)]
R5F212G4SNFP@QFP32 [(SA663)]
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single wire) [(SA663)]
R5F212G5SDFP@QFP32 [(SA663)]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single wire) [(SA663)]
```

```
R5F212G5SNFP@QFP32 [(SA663)]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single wire) [(SA663)]
R5F212G6SDFP@QFP32 [(SA663)]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single wire) [(SA663)]
R5F212G6SNFP@QFP32 [(SA663)]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single wire) [(SA663)]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire) [(SA026-B001)]
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire) [(SA026-B001)]
R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire) [(SA026-B001)]
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire) [(SA026-B001)]
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire) [(SA026-B001)]
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire) [(SA026-B001)]
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire) [(SA026-B001)]
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire) [(SA026-B001)]
R5F212K2SDFP@QFP32 [(SA663-B005)]
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]
R5F212K4SDFP@QFP32 [(SA663-B005)]
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]
R5F212K4SNFP@QFP32 [(SA663-B005)]
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]
R5F212L2SDFP@QFP32 [(SA663-B005)]
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L2SNFP@QFP32 [(SA663-B005)]
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SDFP@QFP32 [(SA663-B005)]
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SNFP@QFP32 [(SA663-B005)]
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]
R5F363A6DFA@PQFP100(*) [(TA012-B006)]
R5F363A6DFB@PQFP100(*) [(TA013-B006)]
R5F363A6NFA@PQFP100(*) [(TA012-B006)]
R5F363A6NFB@PQFP100(*) [(TA013-B006)]
R5F363AEDFA@PQFP100(*) [(TA012-B006)]
R5F363AEDFB@PQFP100(*) [(TA013-B006)]
R5F363AENFA@PQFP100(*) [(TA012-B006)]
R5F363AENFB@PQFP100(*) [(TA013-B006)]
R5F363AKDFA@PQFP100(*) [(TA012-B006)]
R5F363AKDFB@PQFP100(*) [(TA013-B006)]
R5F363AKNFA@PQFP100(*) [(TA012-B006)]
R5F363AKNFB@PQFP100(*) [(TA013-B006)]
R5F363AMDFA@PQFP100(*) [(TA012-B006)]
R5F363AMDFB@PQFP100(*) [(TA013-B006)]
R5F363AMNFA@PQFP100(*) [(TA012-B006)]
R5F363AMNFB@PQFP100(*) [(TA013-B006)]
R5F36406DFA@PQFP100(*) [(TA012-B006)]
R5F36406DFB@TQFP100(*) [(TA013-B006)]
R5F36406NFA@PQFP100(*) [(TA012-B006)]
R5F36406NFB@TQFP100(*) [(TA013-B006)]
R5F3640DDFA@PQFP100(*) [(TA012-B006)]
R5F3640DDFB@TQFP100(*) [(TA013-B006)]
R5F3640DNFA@PQFP100(*) [(TA012-B006)]
R5F3640DNFB@TQFP100(*) [(TA013-B006)]
```

```

R5F3640MDFA@PQFP100 (*) [(TA012-B006)]
R5F3640MDFB@TQFP100 (*) [(TA013-B006)]
R5F3640MNFA@PQFP100 (*) [(TA012-B006)]
R5F3640MNF@TQFP100 (*) [(TA013-B006)]
R5F364A6DFA@PQFP100 (*) [(TA012-B006)]
R5F364A6DFB@PQFP100 (*) [(TA013-B006)]
R5F364A6NFA@PQFP100 (*) [(TA012-B006)]
R5F364A6NFB@PQFP100 (*) [(TA013-B006)]
R5F364AEDFA@PQFP100 (*) [(TA012-B006)]
R5F364AEDFB@PQFP100 (*) [(TA013-B006)]
R5F364AENFA@PQFP100 (*) [(TA012-B006)]
R5F364AENFB@PQFP100 (*) [(TA013-B006)]
R5F364AMDFA@PQFP100 (*) [(TA012-B006)]
R5F364AMDFB@PQFP100 (*) [(TA013-B006)]
R5F364AMNFA@PQFP100 (*) [(TA012-B006)]
R5F364AMNFB@PQFP100 (*) [(TA013-B006)]
R5F36506DFA@PQFP100 (*) [(TA012-B006)]
R5F36506DFB@TQFP100 (*) [(TA013-B006)]
R5F36506NFA@PQFP100 (*) [(TA012-B006)]
R5F36506NFB@TQFP100 (*) [(TA013-B006)]
R5F3650EDFA@PQFP100 (*) [(TA012-B006)]
R5F3650EDFB@TQFP100 (*) [(TA013-B006)]
R5F3650ENFA@PQFP100 (*) [(TA012-B006)]
R5F3650ENFB@TQFP100 (*) [(TA013-B006)]
R5F3650KDFA@PQFP100 (*) [(TA012-B006)]
R5F3650KDFB@TQFP100 (*) [(TA013-B006)]
R5F3650KNFA@PQFP100 (*) [(TA012-B006)]
R5F3650KNFB@TQFP100 (*) [(TA013-B006)]
R5F3650MDFA@PQFP100 (*) [(TA012-B006)]
R5F3650MDFB@TQFP100 (*) [(TA013-B006)]
R5F3650MNFA@PQFP100 (*) [(TA012-B006)]
R5F3650MNF@TQFP100 (*) [(TA013-B006)]
R5F3650NDFA@PQFP100 (*) [(TA012-B006)]
R5F3650NDFB@PQFP100 (*) [(TA013-B006)]
R5F3650NNFA@PQFP100 (*) [(TA012-B006)]
R5F3650NNFB@PQFP100 (*) [(TA013-B006)]
R5F3650RDFA@PQFP100 (*) [(TA012-B006)]
R5F3650RDFB@TQFP100 (*) [(TA013-B006)]
R5F3650RNFA@PQFP100 (*) [(TA012-B006)]
R5F3650RNFB@TQFP100 (*) [(TA013-B006)]
R5F3650TDFA@PQFP100 (*) [(TA012-B006)]
R5F3650TDFB@TQFP100 (*) [(TA013-B006)]
R5F3650TNFA@PQFP100 (*) [(TA012-B006)]
R5F3650TNFB@TQFP100 (*) [(TA013-B006)]
R5F3651EDFC@PQFP128 (*) [(SA720-B228)]
R5F3651ENFC@PQFP128 (*) [(SA720-B228)]
R5F3651KDFC@PQFP128 (*) [(SA720-B228)]
R5F3651KNFC@PQFP128 (*) [(SA720-B228)]
R5F3651MDFC@PQFP128 (*) [(SA720-B228)]
R5F3651MNFC@PQFP128 (*) [(SA720-B228)]
R5F3651NDFC@PQFP128 (*) [(SA720-B228)]
R5F3651NNFC@PQFP128 (*) [(SA720-B228)]
R5F3651RDFC@PQFP128 (*) [(SA720-B228)]
R5F3651RNFC@PQFP128 (*) [(SA720-B228)]
R5F3651TDFC@PQFP128 (*) [(SA720-B228)]
R5F3651TNFC@PQFP128 (*) [(SA720-B228)]

```

## RICOH

### E (E) PROM / FRAM / NVRAM

```

RD27C256 RD27C32
RD27C64

```

### PLD

```

EPL16P8 EPL16P8@PLCC20 [(SA001A)]
EPL16RP4 EPL16RP4@PLCC20 [(SA001A)]
EPL16RP6 EPL16RP6@PLCC20 [(SA001A)]
EPL16RP8 EPL16RP8@PLCC20 [(SA001A)]

```

## ROCKWELL

## E (E) PROM/FRAM/NVRAM

R2764	R2764C
R2764P	R27C64
R2816	R5213
R52B13	R52B33

## ROHM

## E (E) PROM/FRAM/NVRAM

BR24A01A (F) [(SA602A)]	BR24A01A (FJ) [(SA602A)]
BR24A02 (F) [(SA602A)]	BR24A02 (FJ) [(SA602A)]
BR24A04 (F) [(SA602A)]	BR24A04 (FJ) [(SA602A)]
BR24A08 (F) [(SA602A)]	BR24A08 (FJ) [(SA602A)]
BR24A16 (F) [(SA602A)]	BR24A16 (FJ) [(SA602A)]
BR24A32 (F) [(SA602A)]	BR24A32 (FJ) [(SA602A)]
BR24A64 (F) [(SA602A)]	BR24A64 (FJ) [(SA602A)]
BR24C01@SOP8 [(SA602A)]	BR24C01@TSSOP8 [(SA026)]
BR24C01@TSSOP8 (3*3mm) [(SA666)]	BR24C01A
BR24C01A (F) [(SA602A)]	BR24C01A (FJ) [(SA602A)]
BR24C01A (FV) [(SA026)]	BR24C02
BR24C02 (F) [(SA602A)]	BR24C02 (FJ) [(SA602A)]
BR24C02 (FV) [(SA026)]	BR24C02@SOP8 [(SA602A)]
BR24C02@TSSOP8 [(SA026)]	BR24C02@TSSOP8 (3*3mm) [(SA666)]
BR24C04	BR24C04 (F) [(SA602A)]
BR24C04 (FJ) [(SA602A)]	BR24C04 (FV) [(SA026)]
BR24C04@SOP8 [(SA602A)]	BR24C04@TSSOP8 [(SA026)]
BR24C04@TSSOP8 (3*3mm) [(SA666)]	BR24C08
BR24C08 (F) [(SA602A)]	BR24C08 (FJ) [(SA602A)]
BR24C08 (FV) [(SA026)]	BR24C08@SOP8 [(SA602A)]
BR24C08@TSSOP8 [(SA026)]	BR24C08@TSSOP8 (3*3mm) [(SA666)]
BR24C16	BR24C16 (F) [(SA602A)]
BR24C16 (FJ) [(SA602A)]	BR24C16 (FV) [(SA026)]
BR24C21	BR24C21 (F) [(SA602A)]
BR24C21 (FJ) [(SA602A)]	BR24C21 (FV) [(SA026)]
BR24C32	BR24C32 (F) [(SA602A)]
BR24C64	BR24C64 (F) [(SA602A)]
BR24E16	BR24E16 (F) [(SA602A)]
BR24E16 (FJ) [(SA602A)]	BR24E16 (FV) [(SA026)]
BR24G32	BR24G32 (F) [(SA602A)]
BR24G32 (FJ) [(SA602A)]	BR24G32 (FV) [(SA026)]
BR24G32 (FVT) [(SA026)]	BR24L01A
BR24L01A (F) [(SA602A)]	BR24L01A (FJ) [(SA602A)]
BR24L01A (FV) [(SA026)]	BR24L01A (FVM) [(SA666)]
BR24L02	BR24L02 (F) [(SA602A)]
BR24L02 (FJ) [(SA602A)]	BR24L02 (FV) [(SA026)]
BR24L02 (FVM) [(SA666)]	BR24L04
BR24L04 (F) [(SA602A)]	BR24L04 (FJ) [(SA602A)]
BR24L04 (FV) [(SA026)]	BR24L04 (FVM) [(SA666)]
BR24L08	BR24L08 (F) [(SA602A)]
BR24L08 (FJ) [(SA602A)]	BR24L08 (FV) [(SA026)]
BR24L08 (FVM) [(SA666)]	BR24L16
BR24L16 (F) [(SA602A)]	BR24L16 (FJ) [(SA602A)]
BR24L16 (FV) [(SA026)]	BR24L16 (FVM) [(SA666)]
BR24L32	BR24L32 (F) [(SA602A)]
BR24L32 (FJ) [(SA602A)]	BR24L32 (FV) [(SA026)]
BR24L64	BR24L64 (F) [(SA602A)]
BR24L64 (FJ) [(SA602A)]	BR24L64 (FV) [(SA026)]
BR24S08 (F) [(SA602A)]	BR24S08 (FJ) [(SA602A)]
BR24S08 (FV) [(SA026)]	BR24S08 (FVJ) [(SA026)]
BR24S08 (FVM) [(SA666)]	BR24S08 (FVT) [(SA026)]
BR24S128	BR24S128 (F) [(SA602A)]
BR24S128 (FJ) [(SA602A)]	BR24S128 (FV) [(SA026)]
BR24S128 (NUX) [(SA724)]	BR24S16
BR24S16 (F) [(SA602A)]	BR24S16 (FJ) [(SA602A)]
BR24S16 (FV) [(SA026)]	BR24S16 (FVM) [(SA666)]
BR24S256	BR24S256 (F) [(SA602A)]
BR24S256 (FJ) [(SA602A)]	BR24S256 (FV) [(SA026)]
BR24S256 (NUX) [(SA724)]	BR24S32
BR24S32 (F) [(SA602A)]	BR24S32 (FJ) [(SA602A)]
BR24S32 (FV) [(SA026)]	BR24S32 (NUX) [(SA724)]
BR24S64	BR24S64 (F) [(SA602A)]
BR24S64 (FJ) [(SA602A)]	BR24S64 (FV) [(SA026)]
BR24S64 (NUX) [(SA724)]	BR25010@SOIC8 [(SA602A)]
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8 [(SA602A)]
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8 [(SA602A)]



BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8 [(SA602A)]
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8 [(SA602A)]
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8 [(SA602A)]
BR25H010(F) [(SA602A)]	BR25H010(FJ) [(SA602A)]
BR25H020(F) [(SA602A)]	BR25H020(FJ) [(SA602A)]
BR25H040(F) [(SA602A)]	BR25H040(FJ) [(SA602A)]
BR25H080(F) [(SA602A)]	BR25H080(FJ) [(SA602A)]
BR25H080(FVT) [(SA026)]	BR25H160(F) [(SA602A)]
BR25H160(FJ) [(SA602A)]	BR25H160(FVT) [(SA026)]
BR25H320(F) [(SA602A)]	BR25H320(FJ) [(SA602A)]
BR25H320(FVT) [(SA026)]	BR25L010
BR25L010(F) [(SA602A)]	BR25L010(FJ) [(SA602A)]
BR25L010(FV) [(SA026)]	BR25L010(FVM) [(SA666)]
BR25L020	BR25L020(F) [(SA602A)]
BR25L020(FJ) [(SA602A)]	BR25L020(FV) [(SA026)]
BR25L020(FVM) [(SA666)]	BR25L040
BR25L040(F) [(SA602A)]	BR25L040(FJ) [(SA602A)]
BR25L040(FV) [(SA026)]	BR25L040(FVM) [(SA666)]
BR25L080	BR25L080(F) [(SA602A)]
BR25L080(FJ) [(SA602A)]	BR25L080(FV) [(SA026)]
BR25L160	BR25L160(F) [(SA602A)]
BR25L160(FJ) [(SA602A)]	BR25L160(FV) [(SA026)]
BR25L320	BR25L320(F) [(SA602A)]
BR25L320(FJ) [(SA602A)]	BR25L320(FV) [(SA026)]
BR25L640	BR25L640(F) [(SA602A)]
BR25L640(FJ) [(SA602A)]	BR25L640(FV) [(SA026)]
BR34C02A [(SA026)]	BR34L02
BR34L02(F) [(SA602A)]	BR34L02(FJ) [(SA602A)]
BR34L02(FV) [(SA026)]	BR34L02(FVM) [(SA666)]
BR9010	BR9010(F) [(SA602A)]
BR9010(FV) [(SA026)]	BR9010(RFV) [(SA026)]
BR9010(RFVM) [(SA666)]	BR9016
BR9016(F) [(SA602A)]	BR9016(RFV) [(SA026)]
BR9016A(F) [(SA602A)]	BR9016A(RFV) [(SA026)]
BR9016A(RFVM) [(SA666)]	BR9020
BR9020(F) [(SA602A)]	BR9020(FV) [(SA026)]
BR9020(RFV) [(SA026)]	BR9020(RFVM) [(SA666)]
BR9040	BR9040(F) [(SA602A)]
BR9040(FV) [(SA026)]	BR9040(RFV) [(SA026)]
BR9040(RFVM) [(SA666)]	BR9080
BR9080(F) [(SA602A)]	BR9080(RFV) [(SA026)]
BR9080A	BR9080A(F) [(SA602A)]
BR9080A(FV) [(SA026)]	BR9080A(RFV) [(SA026)]
BR9080A(RFVM) [(SA666)]	BR93A46(F) [(SA602A)]
BR93A46(FJ) [(SA602A)]	BR93A46(RF) [(SA602A)]
BR93A46(RFJ) [(SA602A)]	BR93A56(F) [(SA602A)]
BR93A56(FJ) [(SA602A)]	BR93A56(RF) [(SA602A)]
BR93A56(RFJ) [(SA602A)]	BR93A66(F) [(SA602A)]
BR93A66(FJ) [(SA602A)]	BR93A66(RF) [(SA602A)]
BR93A66(RFJ) [(SA602A)]	BR93A76(F) [(SA602A)]
BR93A76(FJ) [(SA602A)]	BR93A76(RF) [(SA602A)]
BR93A76(RFJ) [(SA602A)]	BR93A86(F) [(SA602A)]
BR93A86(FJ) [(SA602A)]	BR93A86(RF) [(SA602A)]
BR93A86(RFJ) [(SA602A)]	BR93C46
BR93C46(F) [(SA602A)]	BR93C46(FJ) [(SA602A)]
BR93C46(FV) [(SA026)]	BR93C46(RF) [(SA602A)]
BR93C46(RFJ) [(SA602A)]	BR93C56
BR93C56(F) [(SA602A)]	BR93C56(FJ) [(SA602A)]
BR93C56(FV) [(SA026)]	BR93C56(RF) [(SA602A)]
BR93C56(RFJ) [(SA602A)]	BR93C66
BR93C66(F) [(SA602A)]	BR93C66(FJ) [(SA602A)]
BR93C66(FV) [(SA026)]	BR93C66(RF) [(SA602A)]
BR93C66(RFJ) [(SA602A)]	BR93H46(RF) [(SA602A)]
BR93H46(RFJ) [(SA602A)]	BR93H56(RF) [(SA602A)]
BR93H56(RFJ) [(SA602A)]	BR93H66(RF) [(SA602A)]
BR93H66(RFJ) [(SA602A)]	BR93H76(RF) [(SA602A)]
BR93H76(RFJ) [(SA602A)]	BR93H86(RF) [(SA602A)]
BR93H86(RFJ) [(SA602A)]	BR93L46
BR93L46(F) [(SA602A)]	BR93L46(FJ) [(SA602A)]
BR93L46(FV) [(SA026)]	BR93L46(RF) [(SA602A)]
BR93L46(RFJ) [(SA602A)]	BR93L56
BR93L56(F) [(SA602A)]	BR93L56(FJ) [(SA602A)]
BR93L56(FV) [(SA026)]	BR93L56(RF) [(SA602A)]
BR93L56(RFJ) [(SA602A)]	BR93L66
BR93L66(F) [(SA602A)]	BR93L66(FJ) [(SA602A)]
BR93L66(FV) [(SA026)]	BR93L66(RF) [(SA602A)]
BR93L66(RFJ) [(SA602A)]	BR93L76(F) [(SA602A)]
BR93L76(FJ) [(SA602A)]	BR93L76(RF) [(SA602A)]
BR93L76(RFJ) [(SA602A)]	BR93L76(RFV) [(SA026A)]
BR93L76(RFVJ) [(SA666A)]	BR93L76(RFVM) [(SA666A)]
BR93L76(RFVT) [(SA026A)]	BR93L86(F) [(SA602A)]

BR93L86(FJ) [(SA602A)]	BR93L86(RF) [(SA602A)]
BR93L86(RFJ) [(SA602A)]	BR93L86(RFV) [(SA026A)]
BR93L86(RFVJ) [(SA666A)]	BR93L86(RFVM) [(SA666A)]
BR93L86(RFVT) [(SA026A)]	BR93LC46
BR93LC46(F) [(SA602A)]	BR93LC46(FJ) [(SA602A)]
BR93LC46(FV) [(SA026)]	BR93LC46(RF) [(SA602A)]
BR93LC46(RFJ) [(SA602A)]	BR93LC56
BR93LC56(F) [(SA602A)]	BR93LC56(FJ) [(SA602A)]
BR93LC56(FV) [(SA026)]	BR93LC56(RF) [(SA602A)]
BR93LC56(RFJ) [(SA602A)]	BR93LC66
BR93LC66(F) [(SA602A)]	BR93LC66(FJ) [(SA602A)]
BR93LC66(FV) [(SA026)]	BR93LC66(RF) [(SA602A)]
BR93LC66(RFJ) [(SA602A)]	BR93LL46(F) [(SA602A)]
BR93LL46(FV) [(SA026)]	BR95010(3*3)@TSSOP8 [(SA666)]
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8 [(SA026)]
BR95020(3*3)@TSSOP8 [(SA666)]	BR95020@SO8 [(SA602A)]
BR95020@TSSOP8 [(SA026)]	BR95040(3*3)@TSSOP8 [(SA666)]
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8 [(SA026)]
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8 [(SA026)]
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8 [(SA026)]

## SAIFUN

### E(E) PROM/FRAM/NVRAM

SA24C1024	SA24C1024@SOIC8 [(SA602A)]
SA24C512	SA24C512@SOIC8 [(SA602A)]
SA24C512@TSSOP8 [(SA026)]	SA25C020
SA25C020@MLF8 [(SA683)]	SA25C020@SOIC8 [(SA602A)]
SA25C040	SA25C040@MLF8 [(SA683)]
SA25C040@SOIC8 [(SA602A)]	SA25C080
SA25C080@MLF8 [(SA683)]	SA25C080@SOIC8 [(SA602A)]
SA25C1024(H)	SA25C1024(H)@CSP8 [(SA683)]
SA25C1024(H)@SOIC8 [(SA602A)]	SA25C1024(L)
SA25C1024(L)@CSP8 [(SA683)]	SA25C1024(L)@SOIC8 [(SA602A)]
SA25C512(H)	SA25C512(H)@CSP8 [(SA683)]
SA25C512(H)@SOIC8 [(SA602A)]	SA25C512(L)
SA25C512(L)@CSP8 [(SA683)]	SA25C512(L)@SOIC8 [(SA602A)]
SA25F005	SA25F005@MLF8 [(SA683)]
SA25F005@SOIC8 [(SA602A)]	SA25F010
SA25F010@MLF8 [(SA683)]	SA25F010@SOIC8 [(SA602A)]
SA25F020	SA25F020@MLF8 [(SA683)]
SA25F020@SOIC8 [(SA602A)]	SA25F040
SA25F040@MLF8 [(SA683)]	SA25F040@SOIC8 [(SA602A)]
SA25F080	SA25F080@MLF8 [(SA683)]
SA25F080@SOIC8 [(SA602A)]	SA25F160
SA25F160(ISP) [ISP-HEADER01]	SA25F160@MLF8 [(SA683)]
SA25F160@MLF8(ISP) [ISP-HEADER01]	
SA25F160@SOIC16 [(SA602)]	
SA25F160@SOIC16(ISP) [ISP-HEADER01]	

## SAMSUNG

### E(E) PROM/FRAM/NVRAM

K521F57ACM@FBGA107 [(SA642V-B133-T096F001Y)]
K5A3240CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3240CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3240YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3240YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3240YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3240YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3281CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3281CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3340YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3340YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3340YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3340YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3380YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3380YBC@TBGA69 [(SA642A-B032A-Y096F001)]

K5A3380YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
 K5A3380YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
 K5A6317CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 K5A6317CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 K5D1212DCM@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 K5D1213ACE@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1213ACJ@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1213ACM@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D12571CM-D090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D1257ACB-D090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D1257ACF@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D1257DCA-D090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D1257DCMD090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D1258ACB@FBGA137 [(SA700G-B153A-Y137F001Y)]  
 K5D1258DCA@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1258DCM@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1G12DCM@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D1G13ACD@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1G13ACH@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1G1GACA@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1G58ACA@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D5613HCMD075@FBGA137 [(SA700E-B153-M137F001Y)]  
 K5D5613VCM075@FBGA137 [(SA700E-B153-M137F001Y)]  
 K5D5629ACCD090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D5657ACAD090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D5657ACBD090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5D5657DCAD090@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5E1212ACJ@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5E1257ACM@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5E1G12ACC@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5E1G12ACG@FBGA107 [(SA642V-B133-T096F001Y)]  
 K5J6316CBM@FBGA69 [(SA642A-B032A-Y096F001)]  
 K5J6316CTM@FBGA69 [(SA642A-B032A-Y096F001)]  
 K5J6332CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 K5J6332CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 K5L2731CAA@FBGA64 [(SA642A-B079A-Y096F001Y)]  
 K5L2731CAM@FBGA64 [(SA642A-B079A-Y096F001Y)]  
 K5L2763CAA@FBGA64 [(SA642A-B079A-Y096F001Y)]  
 K5L2763CAM@FBGA64 [(SA642A-B079A-Y096F001Y)]  
 K5L2864ABM@FBGA115 [(SA664A-B189A-W115F001Y)]  
 K5L2864ATM@FBGA115 [(SA664A-B189A-W115F001Y)]  
 K5L2931CAM@FBGA73 [(SA642A-B079A-Y096F001Y)]  
 K5L3216CAM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 K5L3316CAM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
 K5L5563CAA@FBGA84 [(SA642A-B158A-Y096F001Y)]  
 K5L6331CAA@FBGA56 [(SA642P-B032A-W056F001Y)]  
 K5L6631CAA@FBGA56 [(SA642P-B032A-W056F001Y)]  
 K5N3217ABM@FBGA56 [(SA733A-B212A-M056F001Y)]  
 K5N3217ATM@FBGA56 [(SA733A-B212A-M056F001Y)]  
 K5N5629ABA@FBGA56 [(SA733A-B212A-M056F001Y)]  
 K5N5629ATA@FBGA56 [(SA733A-B212A-M056F001Y)]  
 K8D1716UBC@FBGA48 [(SA642N-B026A-W048F001N)]  
 K8D1716UBC@TSOP48 [(SA247-B005)]  
 K8D1716UTC@FBGA48 [(SA642N-B026A-W048F001N)]  
 K8D1716UTC@TSOP48 [(SA247-B005)]  
 K8D3216UBB@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D3216UBB@TSOP48 [(SA247-B005)]  
 K8D3216UBC@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D3216UBC@TSOP48 [(SA247-B005)]  
 K8D3216UTB@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D3216UTB@TSOP48 [(SA247-B005)]  
 K8D3216UTC@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D3216UTC@TSOP48 [(SA247-B005)]  
 K8D3316UBC@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D3316UBC@TSOP48 [(SA247-B005)]  
 K8D3316UTC@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D3316UTC@TSOP48 [(SA247-B005)]  
 K8D6316UBM@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D6316UBM@TSOP48 [(SA247-B005)]  
 K8D6316UTM@FBGA48 [(SA642N-B026A-W048F001Y)]  
 K8D6316UTM@TSOP48 [(SA247-B005)]  
 K8P3215UQB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 K8P3215UQB@FBGA64 [(SA655F-B099A-W064F001Y)]  
 K8P3215UQB@TSOP48 [(SA247-B005)]  
 K8P5516UZB@FBGA64 [(SA644F-B099A-T064F001Y)]  
 K8P5516UZB@TSOP56 [(SA628-B102)] K8P5615UQA@TSOP56 [(SA628-B102)]  
 K8P6415UQB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 K8P6415UQB@FBGA64 [(SA655F-B099A-W064F001Y)]  
 K8P6415UQB@TSOP48 [(SA247-B005)] K8Q2815UQB@TSOP56 [(SA628+B102)]  
 K9F1208R0B@TSOP48 [(SA247-B005)]  
 K9F1208R0C@FBGA63 [(SA642LL-B280-M063F001N)]

K9F1208U0A@TSOP48 [(SA247-B005)]  
 K9F1208U0B@FBGA63 [(SA642LL-B026-M063F001N)]  
 K9F1208U0B@TSOP48 [(SA247-B005)]  
 K9F1208U0C@FBGA63 [(SA642LL-B026-M063F001N)]  
 K9F1208U0C@TSOP48 [(SA247-B005)] K9F1208U0M@TSOP48 [(SA247-B005)]  
 K9F1216U0A@TSOP48 [(SA247-B005)] K9F1G08Q0M@TSOP48 [(SA247-B005)]  
 K9F1G08R0A-JIB0@FBGA63 [(SA642V-B026-T096F001)]  
 K9F1G08R0B@FBGA63 [(SA642KK-B026A-W048F001Y)]  
 K9F1G08U0A@FBGA63 [(SA642NN-B026A-W063F001Y)]  
 K9F1G08U0A@TSOP48 [(SA247-B005)] K9F1G08U0B@TSOP48 [(SA247-B005)]  
 K9F1G08U0C@TSOP48 [(SA247-B005)] K9F1G08U0M@TSOP48 [(SA247-B005)]  
 K9F1G16D0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16D0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16D0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16D0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F2808U0C@TSOP48 [(SA247-B005)]  
 K9F2G08R0A@FBGA63 [(SA642V-B280A-T096F001)]  
 K9F2G08U0A@TSOP48 [(SA247-B005)] K9F2G08U0M@TSOP48 [(SA247-B005)]  
 K9F4008W0A@TSOP44 [(SA645)] K9F4G08U0A@TSOP48 [(SA247-B005)]  
 K9F4G08U0M@TSOP48 [(SA247-B005)]  
 K9F5608R0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
 K9F5608U0B(partition)@TSOP48 [(SA247-B005)]  
 K9F5608U0B@TSOP48 [(SA247-B005)]  
 K9F5608U0C(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
 K9F5608U0C(partition)@TSOP48 [(SA247-B005)]  
 K9F5608U0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
 K9F5608U0C@TSOP48 [(SA247-B005)]  
 K9F5608U0D(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
 K9F5608U0D(partition)@TSOP48 [(SA247-B005)]  
 K9F5608U0D(partition)@WSOP48 [(SA765)]  
 K9F5608U0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
 K9F5608U0D@TSOP48 [(SA247-B005)] K9F5608U0D@WSOP48 [(SA765)]  
 K9F6408U0C@TSOP44 [(SA645-B005)] K9F8G08U0A@TSOP48 [(SA247-B005)]  
 K9F8G08U0M@TSOP48 [(SA247-B005)] K9G4G08U0A@TSOP48 [(SA247-B005)]  
 K9G8G08U0M@TSOP48 [(SA247-B005)] K9GAG08U0M@TSOP48 [(SA247-B005)]  
 K9HBG08U1M@TSOP48 [(SA247-B005)]  
 K9K1208D0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
 K9K1208U0A@TSOP48 [(SA247-B005)] K9K1208U0M@TSOP48 [(SA247-B005)]  
 K9K1216Q0C@FBGA63 [(SA664A-B114-W115F001)]  
 K9K1G08U0B-JIB0@FBGA63 [(SA642LL-B026A-M063F001Y)]  
 K9K1G08U0M@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M@TSOP48 [(SA247-B005)] K9K4G08Q0M@TSOP48 [(SA247-B005)]  
 K9K4G08U0M@TSOP48 [(SA247-B005)]  
 K9K4G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9K4G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9K4G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9K4G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9K4G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9K4G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9K4G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9K4G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9K8G08U0A@TSOP48 [(SA247-B005)] K9L8G08U0M@TSOP48 [(SA247-B005)]  
 K9LAG08U0M@TSOP48 [(SA247-B005)] K9LAG08U1M@TSOP48 [(SA247-B005)]  
 K9LBG08U0M@TSOP48 [(SA247-B005)] K9T1G08U0M@TSOP48 [(SA247-B005)]  
 K9W8G08U1M(PCB0)@TSOP48 [(SA247-B005)]  
 K9W8G08U1M(PIB0)@TSOP48 [(SA247-B005)]  
 K9WAG08U1A@TSOP48 [(SA247+B005)]  
 KAD060300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD060300C@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD060700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
 KAD070300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD070700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
 KAD090300B@TBGA69 [(SA642A-B039A-Y096F001)]

KAD100300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAG00K007A-DGG5@FBGA107 [(SA642V-B133-T096F001Y)]  
 KAL00R00KM-DG55@FBGA137 [(SA700B-B153A-P137F001Y)]  
 KAL00T00UM@FBGA137 [(SA700C-B153A-M137F001Y)]  
 KAL00X00UA-DJYY@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KAL00X00UM-DJYY@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KAP17WG00M(Nor)@FBGA167 [(SA700A-B149A-P164F001Y)]  
 KBE00500AM-D437@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KBE00F003A-D411@FBGA107 [(SA642V-B133-T096F001Y)]  
 KBE00G005M-D411@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KBE00S005M-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
 KBE00S00AM-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
 KFG1216Q2B-DEB8@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2A-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2A-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2B-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2B-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG5616D1M@FBGA63 [(SA642A-B026A-Y096N001)]  
 KFG5616Q1M@FBGA63 [(SA642A-B026A-Y096N001)]  
 KFG5616U1M@FBGA63 [(SA642A-B026A-Y096N001)]  
 KM2816A KM2816AI  
 KM2817A KM2817AI  
 KM2864A KM2864AH  
 KM2865A KM2865AH  
 KM28C16 KM28C16@PLCC32 [(SA015A1T)]  
 KM28C16I KM28C16I@PLCC32 [(SA015A1T)]  
 KM28C17 KM28C17@PLCC32 [(SA015A1T)]  
 KM28C17I KM28C17I@PLCC32 [(SA015A1T)]  
 KM28C256 KM28C256@PLCC32 [(SA015A1T)]  
 KM28C256I KM28C256I@PLCC32 [(SA015A1T)]  
 KM28C64 KM28C64@PLCC32 [(SA015A1T)]  
 KM28C64A KM28C64A@PLCC32 [(SA015A1T)]  
 KM28C64B KM28C64B@PLCC32 [(SA015A1T)]  
 KM28C64I KM28C64I@PLCC32 [(SA015A1T)]  
 KM28C65 KM28C65@PLCC32 [(SA015A1T)]  
 KM28C65A KM28C65A@PLCC32 [(SA015A1T)]  
 KM28C65I KM28C65I@PLCC32 [(SA015A1T)]  
 KM29U128T@TSOP48 [(SA247-B005)] KM29W32000AIT@TSOP44 [(SA645)]  
 KM29W32000AT@TSOP44(DWB) [(SA645)]  
 KM29W32000AT@TSOP44(ZMQ) [(SA645)]  
 KM93C06(08bit) KM93C06(16bit)  
 KM93C06(G)(08bit)@SOIC8 [(SA602A)]  
 KM93C06(G)(16bit)@SOIC8 [(SA602A)]  
 KM93C06(GD)(08bit)@SOIC8 [(SA602A)]  
 KM93C06(GD)(16bit)@SOIC8 [(SA602A)]  
 KM93C07(08bit) KM93C07(16bit)  
 KM93C07(G)(08bit)@SOIC8 [(SA602A)]  
 KM93C07(G)(16bit)@SOIC8 [(SA602A)]  
 KM93C07(GD)(08bit)@SOIC8 [(SA602A)]  
 KM93C07(GD)(16bit)@SOIC8 [(SA602A)]  
 KM93C46V KM93C46V(G)@SOIC8 [(SA602A)]  
 KM93C46V(GD)@SOIC8 [(SA602A)] KM93C47V  
 KM93C47V(G)@SOIC8 [(SA602A)] KM93C47V(GD)@SOIC8 [(SA602A)]  
 KM93C56V KM93C56V(G)@SOIC8 [(SA602A)]  
 KM93C56V(GD)@SOIC8 [(SA602A)] KM93C57V  
 KM93C57V(G)@SOIC8 [(SA602A)] KM93C57V(GD)@SOIC8 [(SA602A)]  
 KM93C66V KM93C66V(G)@SOIC8 [(SA602A)]  
 KM93C66V(GD)@SOIC8 [(SA602A)] KM93C67V  
 KM93C67V(G)@SOIC8 [(SA602A)] KM93C67V(GD)@SOIC8 [(SA602A)]  
 KS24C010 KS24C010@SOIC8 [(SA602A)]  
 KS24C010@TSSOP8 [(SA026)]  
 KS24C011@SOIC8 [(SA602A)]  
 KS24C011@TSSOP8 [(SA026)]  
 KS24C020 KS24C020@SOIC8 [(SA602A)]  
 KS24C020@TSSOP8 [(SA026)]  
 KS24C021@SOIC8 [(SA602A)]  
 KS24C021@TSSOP8 [(SA026)]  
 KS24C040 KS24C040@SOIC8 [(SA602A)]  
 KS24C040@TSSOP8 [(SA026)]  
 KS24C041@SOIC8 [(SA602A)]  
 KS24C041@TSSOP8 [(SA026)]  
 KS24C080 KS24C080@SOIC8 [(SA602A)]  
 KS24C080@TSSOP8 [(SA026)]  
 KS24C081@SOIC8 [(SA602A)]  
 KS24C081@TSSOP8 [(SA026)]  
 S524A40X10 S524A40X10@SOP8 [(SA602A)]  
 S524A40X10@TSSOP8 [(SA026)]  
 S524A40X11@SOP8 [(SA602A)]  
 S524A40X11@TSSOP8 [(SA026)]  
 S524A40X20 S524A40X20@SOP8 [(SA602A)]  
 S524A40X20@TSSOP8 [(SA026)]  
 S524A40X21@SOP8 [(SA602A)]  
 S524A40X21@TSSOP8 [(SA026)]  
 S524A40X40 S524A40X40@SOP8 [(SA602A)]  
 S524A40X40@TSSOP8 [(SA026)]  
 S524A40X41@SOP8 [(SA602A)]  
 S524A40X41@TSSOP8 [(SA026)]  
 S524A60X51 S524A60X51@SOP8 [(SA602A)]

S524A60X51@TSSOP8 [(SA026)]	S524A60X81
S524A60X81@SOP8 [(SA602A)]	S524A60X81@TSSOP8 [(SA026)]
S524AB0X91	S524AB0X91@SOP8 [(SA602A)]
S524AB0X91@TSSOP8 [(SA026)]	S524AB0XB1
S524AB0XB1@SOP8 [(SA602A)]	S524AB0XB1@TSSOP8 [(SA026)]
S524AD0XD1	S524AD0XD1@SOP8 [(SA602A)]
S524AD0XD1@TSSOP8 [(SA026)]	S524AD0XF1
S524AD0XF1@SOP8 [(SA602A)]	S524AD0XF1@TSSOP8 [(SA026)]
S524C20D11	S524C20D11@SOP8 [(SA602A)]
S524C20D11@TSSOP8 [(SA026)]	S524C20D21
S524C20D21@SOP8 [(SA602A)]	S524C20D21@TSSOP8 [(SA026)]
S524C80D41	S524C80D41@SOP8 [(SA602A)]
S524C80D41@TSSOP8 [(SA026)]	S524C80D81
S524C80D81@SOP8 [(SA602A)]	S524C80D81@TSSOP8 [(SA026)]
S524L50X51	S524L50X51@SOP8 [(SA602A)]
S524L50X51@TSSOP8 [(SA026)]	S524LB0X91
S524LB0X91@SOP8 [(SA602A)]	S524LB0X91@TSSOP8 [(SA026)]
S524LB0XB1	S524LB0XB1@SOP8 [(SA602A)]
S524LB0XB1@TSSOP8 [(SA026)]	

**DRAM & SRAM**

KM61257	KM61257@SOJ24 [(SA646)]
KM61257L	KM61257L@SOJ24 [(SA646)]
KM6165	KM6165@SOJ24 [(SA646)]
KM6165L	KM6165L@SOJ24 [(SA646)]
KM62256A	KM62256A@SOIC28 [(SA630)]
KM62256AL	KM62256AL@SOIC28 [(SA630)]
KM6264A	KM6264A@SOIC28 [(SA630)]
KM6264AL	KM6264AL@SOIC28 [(SA630)]
KM64257	KM64257@SOJ24 [(SA646)]
KM64257L	KM64257L@SOJ24 [(SA646)]
KM6465LP	KM6465LP@SOJ22 [(SA646)]
KM6465P	KM68257LP
KM68257LP@SOIC28 [(SA630)]	KM68257P
KM68257P@SOIC28 [(SA630)]	KM6865LP
KM6865LP@SOIC28 [(SA630)]	KM6865P
KM6865P@SOIC28 [(SA630)]	

**PLD**

CPL16L8	CPL16L8@PLCC20 [(SA001A)]
CPL16L8L	CPL16L8L@PLCC20 [(SA001A)]
CPL16R4	CPL16R4@PLCC20 [(SA001A)]
CPL16R4L	CPL16R4L@PLCC20 [(SA001A)]
CPL16R6	CPL16R6@PLCC20 [(SA001A)]
CPL16R6L	CPL16R6L@PLCC20 [(SA001A)]
CPL16R8	CPL16R8@PLCC20 [(SA001A)]
CPL16R8L	CPL16R8L@PLCC20 [(SA001A)]
CPL20L10	CPL20L10@PLCC28 [(SA008A)]
CPL20L10L	CPL20L10L@PLCC28 [(SA008A)]

**MICROCONTROLLER**

S3F84I8@QFP44 [(SA769)]	S3F84I8@SDIP42 [(SA028)]
S3F84I9@QFP44 [(SA769)]	S3F84I9@SDIP42 [(SA028)]
S3F84P4	S3F84P4@SOP8 [(SA602A+B003)]
S3F9444	S3F9444@SOP8 [(SA602A+B003)]
S3F9454(dip16)	S3F9454(dip20)
S3F9454@SOP20 [(SA404+B005)]	S3F9488@QFP44 [(SA245A)]
S3F9488@SDIP32 [(SA653)]	S3F9488@SDIP42 [(SA028)]
S3F9488@SOP32 [(SA630)]	S3F9498@SDIP30 [(SA653)]
S3F9498@SDIP32 [(SA653)]	S3F9498@SOP28 [(SA630)]
S3F9498@SOP32 [(SA630)]	S3P414@QFP44 [(SA675)]
S3P434@QFP44 [(SA675)]	S3P7048@QFP44 [(SA675)]
S3P7048@SDIP42 [(SA028)]	S3P70F4@SDIP30 [(SA653)]
S3P70F4@SOP32 [(SA630)]	S3P7235@PQFP80 [(PEP+S611A)]
S3P7238@PQFP80 [(PEP+S611A)]	S3P72F5@PQFP100 [(PEP+S427)]
S3P72K8@PQFP80 [(PEP+S611A)]	S3P72N5@PQFP80 [(PEP+S611A)]
S3P72N8@PQFP80 [(PEP+S611A)]	S3P72P9@PQFP100 [(PEP+S427)]
S3P72Q5@PQFP100 [(PEP+S427)]	S3P7324@PQFP64 [(PEP+S611A)]
S3P7335@PQFP80 [(PEP+S611A)]	S3P7414@SDIP42 [(SA028)]
S3P7424@SDIP30 [(SA653)]	S3P7424@SOP28 [(SA630)]
S3P7434@SDIP42 [(SA028)]	S3P7528@QFP44 [(SA675)]
S3P7528@SDIP42 [(SA028)]	S3P7538@SDIP30 [(SA653)]
S3P7538@SOP32 [(SA630)]	S3P7565@PQFP100 [(PEP+S427)]
S3P8469@PQFP64 [(PEP+S611A)]	S3P8469@SDIP64 [(PEP+S600A)]

S3P8475@QFP44 [(SA675)]	S3P8475@SDIP42 [(SA028)]
S3P848A@PQFP64 [(PEP+S611A)]	S3P848A@SDIP64 [(PEP+S600A)]
S3P863A@SDIP42 [(SA028)]	S3P863A@TQFP44 [(SA245A)]
S3P9004	S3P9004@TQFP44 [(SA245A)]
S3P9014	S3P9014@TQFP44 [(SA245A)]
S3P9228@QFP44 [(SA675)]	S3P9228@SDIP42 [(SA028)]
S3P9428@SDIP30 [(SA653)]	S3P9428@SOP28 [(SA630)]
S3P9428@SOP32 [(SA630)]	S3P9434(dip16)
S3P9434(dip18)	S3P9434(dip20)
S3P9434@SOP20 [(SA404)]	

## SAMSUNG-CUSTOMER

### E(E)PROM/FRAM/NVRAM

K5D1G13ACD(Y-G8)@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1G13ACD(Y-M8)@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K5D1G58ACA(YYD)@FBGA137 [(SA700E-B153A-M137F001Y)]  
 K9F1208U0A(DD)@TSOP48 [(SA247-B005)]  
 K9F1208U0A(MLTATL)@TSOP48 [(SA247-B005)]  
 K9F1208U0B(DD)@TSOP48 [(SA247-B005)]  
 K9F1208U0B(HC)@TSOP48 [(SA247-B005)]  
 K9F1208U0B(LM)@TSOP48 [(SA247-B005)]  
 K9F1208U0C(DD)@TSOP48 [(SA247-B005)]  
 K9F1208U0M(DD)@TSOP48 [(SA247-B005)]  
 K9F1208U0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1208U0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G08Q0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G08Q0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G08U0A(AMLOGIC)@TSOP48 [(SA247-B005)]  
 K9F1G08U0A(DD)@TSOP48 [(SA247-B005)]  
 K9F1G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
 K9F1G08U0A(TZ)@TSOP48 [(SA247-B005)]  
 K9F1G08U0B(MV)@TSOP48 [(SA247-B005)]  
 K9F1G08U0B(TZ)@TSOP48 [(SA247-B005)]  
 K9F1G08U0M(DD5)@TSOP48 [(SA247+B005)]  
 K9F1G08U0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G08U0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16DOM(PCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16DOM(PIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16DOM(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16DOM(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9F1G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9F2G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
 K9F2G08U0A(YYD)@TSOP48 [(SA247-B005)]  
 K9F2G08U0A(ZX)@TSOP48 [(SA247-B005)]  
 K9F2G08U0M(PCB0)(DD)@TSOP48 [(SA247-B005)]  
 K9F2G08U0M(ShangHai)@TSOP48 [(SA247-B005)]  
 K9F2G08U0M(YYD)@TSOP48 [(SA247-B005)]  
 K9F4G08U0A(JB)@TSOP48 [(SA247+B005)]  
 K9F4G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
 K9F4G08U0A(WS)@TSOP48 [(SA247-B005)]  
 K9F4G08U0M(DD5)@TSOP48 [(SA247+B005)]  
 K9F4G08U0M(PCB0)(DD)@TSOP48 [(SA247-B005)]  
 K9F4G08U0M(SH-EV)@TSOP48 [(SA247-B005)]  
 K9F5608U0B(DD)@TSOP48 [(SA247-B005)]  
 K9F5608U0B(QJ)@TSOP48 [(SA247-B005)]  
 K9F5608U0C(DD)@TSOP48 [(SA247-B005)]  
 K9F5608U0D(ASUS)@TSOP48 [(SA245-B005)]  
 K9F5608U0D(DD)@TSOP48 [(SA247-B005)]  
 K9F5608U0D(RS)@TSOP48 [(SA247-B005)]  
 K9F6408U0B(SH51)@TSOP44 [(SA645-B005)]  
 K9F6408U0C(SH51)@TSOP44 [(SA645-B005)]  
 K9F8G08U0A(ZX)@TSOP48 [(SA247-B005)]  
 K9G4G08U0A(OMB)@TSOP48 [(SA247-B005)]  
 K9G8G08U0M(DD)@TSOP48 [(SA247-B005)]  
 K9G8G08U0M(DD5)@TSOP48 [(SA247-B005)]  
 K9G8G08U0M(KD)@TSOP48 [(SA247-B005)]  
 K9G8G08U0M(MLTATL)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(DD)@TSOP48 [(SA247-B005)]

K9GAG08U0M(DD5)@TSOP48 [(SA247-B005)]  
 K9GAG08U0M(Malata)@TSOP48 [(SA247-B005)]  
 K9HBG08U1A(CH)@TSOP48 [(SA247-B005)]  
 K9HBG08U1M(CH)@TSOP48 [(SA247-B005)]  
 K9K1208D0C(XM)@FBGA63 [(SA664A-B114-W115F001)]  
 K9K1G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
 K9K1G08U0B-JIB0(Wistron)@FBGA63 [(SA642LL-B026A-M063F001Y)]  
 K9K1G08U0M@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9K2G08Q0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(PCB0)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(PIB0)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(YCB0)@TSOP48 [(SA247-B005)]  
 K9K2G08U0M(YIB0)@TSOP48 [(SA247-B005)]  
 K9K4G08U0M(YYD)@TSOP48 [(SA247-B005)]  
 K9K8G08U0A(AMOI)@TSOP48 [(SA247+B005)]  
 K9K8G08U0A(DD)@TSOP48 [(SA247-B005)]  
 K9K8G08U0A(DD5)@TSOP48 [(SA247+B005)]  
 K9K8G08U0A(FX)@TSOP48 [(SA247+B005)]  
 K9K8G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
 K9K8G08U0A(SY)@TSOP48 [(SA247+B005)]  
 K9LAG08U0M(DD)@TSOP48 [(SA247-B005)]  
 K9LAG08U0M(KD)@TSOP48 [(SA247-B005)]  
 K9NBG08U5M(DD)@TSOP48 [(SA247-B005)]  
 K9W8G08U1M(DD)@TSOP48 [(SA247-B005)]  
 K9WAG08U1A(DD)@TSOP48 [(SA247-B005)]  
 K9WAG08U1A(JB)@TSOP48 [(SA247+B005)]  
 K9WAG08U1A(MLT)@TSOP48 [(SA247+B005)]  
 K9WAG08U1M(DD5)@TSOP48 [(SA247+B005)]  
 KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]  
 KBE00F003A-D411(AMOI)@FBGA107 [(SA642V-B133-T096F001Y)]  
 KM29W32000AT(SH51)@TSOP44 [(SA645-B005)]

## SANYO

### E(E) PROM/FRAM/NVRAM

LE24C041	LE24C041@MFP8 [(SA654)]
LE24C042	LE24C042@MFP8 [(SA654)]
LE24C081	LE24C081@MFP8 [(SA654)]
LE24C082	LE24C082@MFP8 [(SA654)]
LE24C161	LE24C161@MFP8 [(SA654)]
LE24C162	LE24C162@MFP8 [(SA654)]
LE24C322@MFP8 [(SA654)]	LE24C322@WLP6 [(SA698)]
LE24L322@MFP8 [(SA654)]	LE25FU106BMA@MFP8 [(SA654)]
LE25FU106BTT@MSOP8 [(SA654)]	LE25FU406BMA@MFP8 [(SA602A)]
LE25FU406BTT@MSOP8 [(SA654)]	LE25FV055T@MSOP8 [(SA654)]
LE25FV101T@MSOP8 [(SA654)]	LE25FV105T@MSOP8 [(SA654)]
LE25FV201T@MSOP8 [(SA654)]	LE25FV401T@MSOP8 [(SA654)]
LE25FV411T@MSOP8 [(SA654)]	LE25FV451T@VSOP32 [(SA620)]
LE25FW056FN@VSON8 [(SA683)]	LE25FW056MA@MFP8 [(SA602A)]
LE25FW106M@SOP8 [(SA602A)]	LE25FW106T@MSOP8 [(SA654)]
LE25FW1606FN@VSON8 [(SA683)]	LE25FW203ATT@MSOP8 [(SA654)]
LE25FW206M@SOP8 [(SA602A)]	LE25FW206T@MSOP8 [(SA654)]
LE25FW406BMA@MFP8 [(SA602A)]	LE25FW406BTT@MSOP8 [(SA654)]
LE25FW406M@SOP8 [(SA602A)]	LE25FW406T@MSOP8 [(SA654)]
LE25FW806M@SOP8 [(SA602A)]	LE25FW806T@MSOP8 [(SA654)]
LE26CW006@WLP6 [(SA698)]	LE28BW168T@TSOP48 [(SA247-B005)]
LE28C1001AM@SOP32 [(SA687)]	LE28C1001AT@TSOP32 [(SA410T)]
LE28C1001ATS@VSOP32 [(SA620)]	LE28C1001DT@TSOP32 [(SA410T)]
LE28C1001DTS@VSOP32 [(SA620)]	LE28CV1001AT@TSOP32 [(SA410T)]
LE28CV1001ATS@VSOP32 [(SA620)]	LE28CV1001DT@TSOP32 [(SA410T)]
LE28CV1001DTS@VSOP32 [(SA620)]	LE28CW1001DT@TSOP32 [(SA410T)]
LE28CW1001DTS@VSOP32 [(SA620)]	
LE28DW1621T@FBGA63 [(SA642A-B026A-Y096F001)]	
LE28DW1621T@TSOP48 [(SA247-B005)]	
LE28DW3218AM@PSOP44 [(SA638-B005)]	
LE28DW8102T@TSOP48 [(SA637)]	
LE28DW8163T@TSOP48 [(SA247-B005)]	
LE28F1101T@TSOP40 [(SA623)]	LE28F1601T@TSOP40 [(SA409T)]
LE28F2001ATS@TSOP32 [(SA410T)]	LE28F4001ATS@TSOP32 [(SA410T)]
LE28F4001M@SSOP32 [(SA438T)]	LE28F8001T@TSOP40 [(SA409T)]
LE28FU4101T@TSOP48 [(SA247-B005)]	
LE28FV1101T@TSOP40 [(SA623)]	LE28FV1601T@TSOP40 [(SA409T)]
LE28FV2001ATS@TSOP32 [(SA410T)]	LE28FV4001ATS@TSOP32 [(SA410T)]



```

LE28FV4001CTS@TSOP32 [(SA410T)]      LE28FV4001M@SSOP32 [(SA438T)]
LE28FV4001T@TSOP40 [(SA409T)]
LE28FV4101T@TSOP48 [(SA247-B005)]
LE28FV8001T@TSOP40 [(SA409T)]
LE28FW1633FB@FBGA48 [(SA642G-B026A-T048F001Y)]
LE28FW1633FT@FBGA48 [(SA642G-B026A-T048F001Y)]
LE28FW1633TB@TSOP48 [(SA247-B005)]
LE28FW1633TT@TSOP48 [(SA247-B005)]
LE28FW4101T@TSOP48 [(SA247-B005)]
LE28FW8201T@TSOP48 [(SA247-B005)]
LE28FW8203TB@FBGA48 [(SA642B-B026A-Y072F001)]
LE28FW8203TB@TSOP48 [(SA247-B005)]
LE28FW8203TT@FBGA48 [(SA642B-B026A-Y072F001)]
LE28FW8203TT@TSOP48 [(SA247-B005)]
    
```

## SCENIX

### MICROCONTROLLER

```

SX20AC/SS/G@SSOP20 [(SA626A)]      SX20AC/SS@SSOP20 [(SA626A)]
SX28AC/DP                               SX28AC/DP/G
SX28AC/SS/G@SSOP28 [(SA626A)]      SX28AC/SS@SSOP28 [(SA626A)]
SX48BD/G@TQFP48 [(SA248)]          SX48BD@TQFP48 [(SA248)]
    
```

## SEEQ

### E(E) PROM/FRAM/NVRAM

```

27128                                27256
2764                                  27C256
2804                                  2804A
2816A                                  2816AH
5213                                  52B13
52B13H                                52B23
52B23H                                52B33
52B33H                                5516A
5516AH                                5517A
5517AH                                DE2817A
DE2817A@PLCC32 [(SA015A1T)]        DE2817AH
DE2817AH@PLCC32 [(SA015A1T)]        DQ2817A
DQ2817A@PLCC32 [(SA015A1T)]        DQ2817AH
DQ2817AH@PLCC32 [(SA015A1T)]        DQ2864
DQ2864@PLCC32 [(SA015A1T)]        DQ2864H
DQ2864H@PLCC32 [(SA015A1T)]        DQ28C256
DQ28C256@PLCC32 [(SA015A1T)]        DQ28C64
DQ28C64@PLCC32 [(SA015A1T)]        DQ28C64A
DQ28C64A@PLCC32 [(SA015A1T)]        DQ28C65
DQ28C65@PLCC32 [(SA015A1T)]        DQ52B13
DQ52B13H                              E28C64
E28C64@PLCC32 [(SA015A1T)]        E52B13
E52B13H                              E52B23
E52B23H                              E52B33
E52B33H                              M28C64
M28C64@PLCC32 [(SA015A1T)]        M52B13
M52B13H                              M52B23
M52B23H                              M52B33
M52B33H                              PQ2864
PQ2864@PLCC32 [(SA015A1T)]        PQ2864H
PQ2864H@PLCC32 [(SA015A1T)]        PQ28C64
PQ28C64@PLCC32 [(SA015A1T)]        PQ28C65
PQ28C65@PLCC32 [(SA015A1T)]
    
```

### PLD

```

PALCE26V12H/4                        PALCE26V12H/4@PLCC28 [(SA008A)]
PALCE26V12H/4@SOIC28 [(SA404)]      PALCE26V12H-15
PALCE26V12H-15@PLCC28 [(SA008A)]    PALCE26V12H-15@SOIC28 [(SA404)]
PALCE26V12H-20                       PALCE26V12H-20@PLCC28 [(SA008A)]
PALCE26V12H-20@SOIC28 [(SA404)]      PALCE26V12H-25
PALCE26V12H-25@PLCC28 [(SA008A)]    PALCE26V12H-25@SOIC28 [(SA404)]
    
```

**SEIKO****E (E) PROM / FRAM / NVRAM**

```

S-22H10
S-22H12
S-22S10
S-22S12
S-24C01A (DP)
S-24C01A (FJA)@SOIC8 [ (SA602A) ]
S-24C01B (FJ)@SOIC8 [ (SA602A) ]
S-24C02A (DPA)
S-24C02B (DP)
S-24C04A (DP)
S-24C04A (FJA)@SOIC8 [ (SA602A) ]
S-24C04B (FJ)@SOIC8 [ (SA602A) ]
S-24C08A (FJA)@SOIC8 [ (SA602A) ]
S-24C16A (FJA)@SOIC8 [ (SA602A) ]
S-24CS01A (FJ)@SOIC8 [ (SA602A) ]
S-24CS02A (DP)
S-24CS02A (FT)@TSSOP8 [ (SA026) ]
S-24CS04A (FJ)@SOIC8 [ (SA602A) ]
S-24CS08A (DP)
S-24CS08A (FT)@TSSOP8 [ (SA026) ]
S-24CS16A (FJ)@SOIC8 [ (SA602A) ]
S-24CS64A (FJ)@SOIC8 [ (SA602A) ]
S-24H45
S-24S45
S-25A010A@SOP8 [ (SA602A) ]
S-25A040A@SOP8 [ (SA602A) ]
S-25A160A@SOP8 [ (SA602A) ]
S-25A640A@SOP8 [ (SA602A) ]
S-25C010A@TSSOP8 [ (SA026) ]
S-25C020A@TSSOP8 [ (SA026) ]
S-25C040A@TSSOP8 [ (SA026) ]
S-25C080A@TSSOP8 [ (SA026) ]
S-25C160A@TSSOP8 [ (SA026) ]
S-25C320A@TSSOP8 [ (SA026) ]
S-25C640A@TSSOP8 [ (SA026) ]
S-29130A (DFJA)@SOIC8 [ (SA602A) ]
S-29130A (FJA)@SOIC8 [ (SA602A) ]
S-29131A (FJA)@SOIC8 [ (SA602A) ]
S-29190A (FJA)@SOIC8 [ (SA602A) ]
S-29191A (FJA)@SOIC8 [ (SA602A) ]
S-29194A (FJA)@SOIC8 [ (SA602A) ]
S-29220A (DPA)
S-29221A (DPA)
S-29230A (DFJA)@SOIC8 [ (SA602A) ]
S-29230A (FJA)@SOIC8 [ (SA602A) ]
S-29231A (FJA)@SOIC8 [ (SA602A) ]
S-29290A (FJA)@SOIC8 [ (SA602A) ]
S-29291A (FJA)@SOIC8 [ (SA602A) ]
S-29294A (FJA)@SOIC8 [ (SA602A) ]
S-29330A (DPA)
S-29331A (DPA)
S-29390A (DPA)
S-29391A (DPA)
S-29394A (DPA)
S-29430A
S-29530A
S-29630A
S-29L130A (DFE)@SOIC8 [ (SA602A) ]
S-29L130A (FS)@SSOP8 [ (SA026) ]
S-29L131A (FS)@SSOP8 [ (SA026) ]
S-29L194A (FS)@TSSOP8 [ (SA026) ]
S-29L220A (FE)@SOIC8 [ (SA602A) ]
S-29L221A (DFE)@SOIC8 [ (SA602A) ]
S-29L294A (DFE)@SOIC8 [ (SA602A) ]
S-29L330A (DFE)@SOIC8 [ (SA602A) ]
S-29L330A (FS)@SSOP8 [ (SA026) ]
S-29L331A (FS)@SSOP8 [ (SA026) ]
S-29L394A (FS)@TSSOP8 [ (SA026) ]
S-29U130A (FS)@SSOP8 [ (SA026) ]
S-29U131A (FS)@SSOP8 [ (SA026) ]
S-29U194A (FS)@TSSOP8 [ (SA026) ]
S-29U220A (FS)@SSOP8 [ (SA026) ]
S-29U221A (FS)@SSOP8 [ (SA026) ]
S-29U294A (FS)@TSSOP8 [ (SA026) ]
S-29U330A (FS)@SSOP8 [ (SA026) ]
S-22H10@SOP18 [ (SA404) ]
S-22H12@SOP18 [ (SA404) ]
S-22S10@SOP18 [ (SA404) ]
S-22S12@SOP18 [ (SA404) ]
S-24C01A (DPA)
S-24C01B (DP)
S-24C02A (DP)
S-24C02A (FJA)@SOIC8 [ (SA602A) ]
S-24C02B (FJ)@SOIC8 [ (SA602A) ]
S-24C04A (DPA)
S-24C04B (DP)
S-24C08A (DPA)
S-24C16A (DPA)
S-24CS01A (DP)
S-24CS01A (FT)@TSSOP8 [ (SA026) ]
S-24CS02A (FJ)@SOIC8 [ (SA602A) ]
S-24CS04A (DP)
S-24CS04A (FT)@TSSOP8 [ (SA026) ]
S-24CS08A (FJ)@SOIC8 [ (SA602A) ]
S-24CS16A (DP)
S-24CS16A (FT)@TSSOP8 [ (SA026) ]
S-24CS64A (FT)@TSSOP8 [ (SA026) ]
S-24H45@SOP8 [ (SA605A) ]
S-24S45@SOP8 [ (SA605A) ]
S-25A020A@SOP8 [ (SA602A) ]
S-25A080A@SOP8 [ (SA602A) ]
S-25A320A@SOP8 [ (SA602A) ]
S-25C010A@SOP8 [ (SA602A) ]
S-25C020A@SOP8 [ (SA602A) ]
S-25C040A@SOP8 [ (SA602A) ]
S-25C080A@SOP8 [ (SA602A) ]
S-25C160A@SOP8 [ (SA602A) ]
S-25C320A@SOP8 [ (SA602A) ]
S-25C640A@SOP8 [ (SA602A) ]
S-2817A@SOP28 [ (SA630) ]
S-29130A (DPA)
S-29131A (DPA)
S-29190A (DPA)
S-29191A (DPA)
S-29194A (DPA)
S-29220A (DFJA)@SOIC8 [ (SA602A) ]
S-29220A (FJA)@SOIC8 [ (SA602A) ]
S-29221A (FJA)@SOIC8 [ (SA602A) ]
S-29230A (DPA)
S-29231A (DPA)
S-29290A (DPA)
S-29291A (DPA)
S-29294A (DPA)
S-29330A (DFJA)@SOIC8 [ (SA602A) ]
S-29330A (FJA)@SOIC8 [ (SA602A) ]
S-29331A (FJA)@SOIC8 [ (SA602A) ]
S-29390A (FJA)@SOIC8 [ (SA602A) ]
S-29391A (FJA)@SOIC8 [ (SA602A) ]
S-29394A (FJA)@SOIC8 [ (SA602A) ]
S-29430A@SOIC8 [ (SA602A) ]
S-29530A@SOIC8 [ (SA602A) ]
S-29630A@SOIC8 [ (SA602A) ]
S-29L130A (FE)@SOIC8 [ (SA602A) ]
S-29L131A (DFE)@SOIC8 [ (SA602A) ]
S-29L194A (DFE)@SOIC8 [ (SA602A) ]
S-29L220A (DFE)@SOIC8 [ (SA602A) ]
S-29L220A (FS)@SSOP8 [ (SA026) ]
S-29L221A (FS)@SSOP8 [ (SA026) ]
S-29L294A (FS)@TSSOP8 [ (SA026) ]
S-29L330A (FE)@SOIC8 [ (SA602A) ]
S-29L331A (DFE)@SOIC8 [ (SA602A) ]
S-29L394A (DFE)@SOIC8 [ (SA602A) ]
S-29U130A (DFE)@SOIC8 [ (SA602A) ]
S-29U131A (DFE)@SOIC8 [ (SA602A) ]
S-29U194A (DFE)@SOIC8 [ (SA602A) ]
S-29U220A (DFE)@SOIC8 [ (SA602A) ]
S-29U221A (DFE)@SOIC8 [ (SA602A) ]
S-29U294A (DFE)@SOIC8 [ (SA602A) ]
S-29U330A (DFE)@SOIC8 [ (SA602A) ]
S-29U331A (DFE)@SOIC8 [ (SA602A) ]

```

S-29U331A(FS)@SSOP8 [(SA026)]	S-29U394A(DFE)@SOIC8 [(SA602A)]
S-29U394A(FS)@TSSOP8 [(SA026)]	S-29Z330A(DFJA)@SOIC8 [(SA602A)]
S-29Z330A(FS)@SSOP8 [(SA026)]	S-29Z430A(DFJA)@SOIC8 [(SA602A)]
S-29Z430A(FS)@SSOP8 [(SA026)]	S-93A46A(D0A)@SOIC8 [(SA602A)]
S-93A56A(D0A)@SOIC8 [(SA602A)]	S-93A66A(D0A)@SOIC8 [(SA602A)]
S-93A66A(FJ)@SOIC8 [(SA602A)]	S-93A86A@SOIC8 [(SA602A)]
S-93C46A(DFJ)@SOIC8 [(SA602A)]	S-93C46A(DP)
S-93C46A(FJ)@SOIC8 [(SA602A)]	S-93C46A(FT)@TSSOP8 [(SA026)]
S-93C46B(DP)	S-93C46B(FJ)@SOIC8 [(SA602A)]
S-93C46B(FT)@TSSOP8 [(SA026)]	S-93C56A(DFJ)@SOIC8 [(SA602A)]
S-93C56A(DP)	S-93C56A(FJ)@SOIC8 [(SA602A)]
S-93C56A(FT)@TSSOP8 [(SA026)]	S-93C56B(DP)
S-93C56B(FJ)@SOIC8 [(SA602A)]	S-93C56B(FT)@TSSOP8 [(SA026)]
S-93C66A(DFJ)@SOIC8 [(SA602A)]	S-93C66A(DP)
S-93C66A(FJ)@SOIC8 [(SA602A)]	S-93C66A(FT)@TSSOP8 [(SA026)]
S-93C66B(DP)	S-93C66B(FJ)@SOIC8 [(SA602A)]
S-93C66B(FT)@TSSOP8 [(SA026)]	S-93C76A(DP)
S-93C76A(FJ)@SOIC8 [(SA602A)]	S-93C76A(FT)@TSSOP8 [(SA026)]
S-93C86A(DP)	S-93C86A(FJ)@SOIC8 [(SA602A)]
S-93C86A(FT)@TSSOP8 [(SA026)]	S-93C86B@SOIC8 [(SA602A)]
S-93C86B@TSSOP8 [(SA026)]	S-93L46A(D0I)@SOIC8 [(SA602A)]
S-93L56A(D0I)@SOIC8 [(SA602A)]	S-93L66A(D0I)@SOIC8 [(SA602A)]
S-93L76A(D0I)@SOIC8 [(SA602A)]	

## SGS-THOMSON

### E (E) PROM/FRAM/NVRAM

ET2716	ETC2716
ETC2732	M24128
M24128@SOIC8 [(SA602A)]	M24164
M24164@SOIC8 [(SA602A)]	M24256
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8 [(SA605A)]
M24512	M24512@SOIC8 [(SA605A)]
M24512@TSOP8 [(SA026)]	M24C04
M24C04@SOIC8 [(SA602A)]	M24C08
M24C08@SOIC8 [(SA602A)]	M24C08W
M24C08W@SOIC8 [(SA602A)]	M24C08W@TSOP8 [(SA026)]
M24C64(BN)	M24C64(DL)@TSSOP14 [(SA026)]
M24C64(DW)@TSSOP8 [(SA602A)]	M24C64(MN)@SOIC8 [(SA605A)]
M24C64(MW)@SOIC8 [(SA602A)]	M27128A
M2716	M27256
M27256A	M2732A
M27512	M2764
M2764A	M27C1000
M27C1000@PLCC32 [(SA015A1T)]	M27C1000@TSOP32 [(SA410T)]
M27C1001	M27C1001@PLCC32 [(SA015A1T)]
M27C1001@TSOP32 [(SA410T)]	M27C1024
M27C1024@PLCC44 [(SA244)]	M27C160
M27C160@PLCC44 [(SA244)]	M27C160@PSOP44 [(SA638)]
M27C2001	M27C2001@PLCC32 [(SA015A1T)]
M27C2001@TSOP32 [(SA410T)]	M27C202
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40 [(SA409T)]
M27C256B	M27C256B@PLCC32 [(SA015A1T)]
M27C400	M27C4001
M27C4001@PLCC32 [(SA015A1T)]	M27C4001@TSOP32 [(SA410T)]
M27C4002	M27C4002@PLCC44 [(SA244)]
M27C405	M27C405@PLCC32 [(SA015A1T)]
M27C405@TSOP32 [(SA410T)]	M27C512
M27C512@PLCC32 [(SA015A1T)]	M27C516
M27C516@PLCC44 [(SA244)]	M27C64A
M27C64A@PLCC32 [(SA015A1T)]	M27C800
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44 [(SA638)]
M27C801	M27C801@PLCC32 [(SA015A1T)]
M27C801@TSOP32 [(SA410T)]	M27HC641
M27HC641@PLCC28 [(SA008A)]	M27HC642
M27HC642@PLCC28 [(SA008A)]	M27V101
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32 [(SA410T)]
M27V201	M27V201@PLCC32 [(SA015A1T)]
M27V201@TSOP32 [(SA410T)]	M27V401
M27V401@PLCC32 [(SA015A1T)]	M27V401@TSOP32 [(SA410T)]
M27V402	M27V402@PLCC44 [(SA244)]
M27V402@TSOP40 [(SA409T)]	M27V512
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28 [(SA430T)]
M27V800	M27V800@PLCC44 [(SA244)]
M27V801	M27V801@PLCC32 [(SA015A1T)]
M27V801@TSOP32 [(SA410T)]	M27W201

M27W201@PLCC32 [(SA015A1T)]	M27W201@TSOP32 [(SA410T)]
M28010	M28010@PLCC32 [(SA015A1T)]
M28010@TSOP32 [(SA410T)]	M28C16@PLCC32 [(SA015A1T)]
M28C64C	M28C64C@PLCC32 [(SA015A1T)]
M28C64C@SOIC28 [(SA404)]	M28C64C@TSOP28 [(SA430T)]
M28F101	M28F101@PLCC32 [(SA015A1T)]
M28F101@TSOP32 [(SA410T)]	M28F102
M28F102@PLCC44 [(SA244)]	M28F102@TSOP40 [(SA409T)]
M28F201	M28F201@PLCC32 [(SA015A1T)]
M28F201@TSOP32 [(SA410T)]	M28F211@TSOP40 [(SA409T)]
M28F220@PSOP44 [(SA638)]	M28F220@TSOP48 [(SA247-B005)]
M28F256	M28F256@PLCC32 [(SA015A1T)]
M28F256@TSOP32 [(SA410T)]	M28F411@TSOP40 [(SA409T)]
M28F512	M28F512@PLCC32 [(SA015A1T)]
M28F512@TSOP32 [(SA410T)]	M29F002B
M29F002B@PLCC32 [(SA015A1T)]	M29F002B@TSOP32 [(SA410T)]
M29F002T	M29F002T@PLCC32 [(SA015A1T)]
M29F002T@TSOP32 [(SA410T)]	M29F040
M29F040@PLCC32 [(SA015A1T)]	M29F040@TSOP32 [(SA410T)]
M29F040B	M29F040B@PLCC32 [(SA015A1T)]
M29F040B@TSOP32 [(SA410T)]	M29F100B@PSOP44 [(SA638-B006)]
M29F100B@TSOP48 [(SA247-B005)]	M29F100T@PSOP44 [(SA638-B006)]
M29F100T@TSOP48 [(SA247-B005)]	M29F102B@PLCC44 [(SA244)]
M29F102B@TSOP40 [(SA623)]	M29F102BB@PLCC44 [(SA244)]
M29F102BB@TSOP40 [(SA623)]	M29F200B@PSOP44 [(SA638-B006)]
M29F200B@TSOP48 [(SA247-B005)]	M29F200T@PSOP44 [(SA638-B006)]
M29F200T@TSOP48 [(SA247-B005)]	M29F400B@PSOP44 [(SA638-B006)]
M29F400B@TSOP48 [(SA247-B005)]	M29F400T@PSOP44 [(SA638-B006)]
M29F400T@TSOP48 [(SA247-B005)]	M29V040@PLCC32 [(SA015A1T)]
M29V040@TSOP32 [(SA410T)]	M29W008B@TSOP40 [(SA409T)]
M29W008T@TSOP40 [(SA409T)]	M29W040@PLCC32 [(SA015A1T)]
M29W040@TSOP32 [(SA410T)]	M29W400B@PSOP44 [(SA638)]
M29W400B@TSOP48 [(SA247-B005)]	M29W400T@PLCC44 [(SA638)]
M29W400T@TSOP48 [(SA247-B005)]	M29W512B@PLCC32 [(SA015A1T)]
M29W512B@TSOP32 [(SA620)]	M29W800B@PSOP44 [(SA638)]
M29W800B@TSOP48 [(SA247-B005)]	M29W800T@PSOP44 [(SA638)]
M29W800T@TSOP48 [(SA247-B005)]	M48T35
M48T35@SOIC28 [(SA404)]	M48T35Y
M48T35Y@SOIC28 [(SA404)]	M48T59
M48T59@SOIC28 [(SA404)]	M48T59Y
M48T59Y@SOIC28 [(SA404)]	M48Z128
M48Z128Y	M48Z30
M48Z30Y	M48Z32
M48Z32Y	M50FW080@PLCC32 [(SA015A1T)]
M50FW080@TSOP40 [(SA409T)]	M50FW080@VSOP32 [(SA620)]
M87C257	M87C257@PLCC32 [(SA015A1T)]
M93C06(08bit)	M93C06(08bit)@SOIC8 [(SA602A)]
M93C06(16bit)	M93C06(16bit)@SOIC8 [(SA602A)]
M93S46	M93S46@SOIC8 [(SA602A)]
M93S46@TSSOP8 [(SA026)]	M95P02
M95P02@SOIC8 [(SA602A)]	M95P04
M95P04@SOIC8 [(SA602A)]	M95P08
M95P08@SOIC8 [(SA602A)]	MK48C02
MK48C02B	MK48C12
MK48C12B	MK48T02
MK48T02B	MK48T08
MK48T12	MK48T12B
MK48T18	MK48Z02
MK48Z02B	MK48Z08
MK48Z12	MK48Z12B
MK48Z18	MKI48Z02
MKI48Z02B	MKI48Z12
MKI48Z12B	MKI48Z18
ST24C01	ST24C01@SOIC8 [(SA602A)]
ST24C02A	ST24C02A@SOIC8 [(SA602A)]
ST24C16	ST24C16@SOIC8 [(SA602A)]
ST24W01	ST24W01@SOIC8 [(SA602A)]
ST24W02	ST24W02@SOIC8 [(SA602A)]
ST24W04C	ST24W04C@SOIC8 [(SA602A)]
ST27128A	ST27256
ST2764A	ST27C256
ST93C06(08bit)	ST93C06(08bit)@SOIC8 [(SA602A)]
ST93C06(16bit)	ST93C06(16bit)@SOIC8 [(SA602A)]
ST93CS46	ST93CS46@SOIC8 [(SA602A)]
TS27C256	TS27C64
TS27C64@PLCC32 [(SA015A1T)]	TS27C64A
TS27C64A@PLCC32 [(SA015A1T)]	TS28C16A
TS28C17A	

## PLD

GAL16V8  
GAL20V8GAL16V8A  
GAL20V8A

## SHARP

## E(E) PROM/FRAM/NVRAM

LH28F002SCHN@PSOP44 [(SA638)] LH28F002SCHT@TSOP40 [(SA409T)]  
LH28F002SCN@PSOP44 [(SA638)] LH28F002SCT@TSOP40 [(SA409T)]  
LH28F004BVE(BT)@TSOP40 [(SA409T)]  
LH28F004BVE(TT)@TSOP40 [(SA409T)]  
LH28F004BVHS(BT)@VSOP40 [(SA623)]  
LH28F004BVHS(TT)@VSOP40 [(SA623)]  
LH28F004BVT(BT)@TSOP40 [(SA409T)]  
LH28F004BVT(TT)@TSOP40 [(SA409T)]  
LH28F004SCHN@PSOP44 [(SA638)] LH28F004SCHS@VSOP40 [(SA623)]  
LH28F004SCHT@TSOP40 [(SA409T)] LH28F004SCN@PSOP44 [(SA638)]  
LH28F004SCS@VSOP40 [(SA623)] LH28F004SCT@TSOP40 [(SA409T)]  
LH28F008BJT(BTLZ1)@TSOP40 [(SA409T)]  
LH28F008BJT(TB)@TSOP40 [(SA409T)]  
LH28F008BJT(TT)@TSOP40 [(SA409T)]  
LH28F008BJT(TTLZ2)@TSOP40 [(SA409T)]  
LH28F008BVT(BT)@TSOP40 [(SA409T)]  
LH28F008BVT(TT)@TSOP40 [(SA409T)]  
LH28F008SAN@PSOP44 [(SA638)] LH28F008SAR@RTSOP40 [(SA409T)]  
LH28F008SAT@TSOP40 [(SA409T)]  
LH28F008SCH(L85)@RTSOP40 [(SA409T)]  
LH28F008SCH-L@TSOP40 [(SA409T)] LH28F008SCHN@PSOP44 [(SA638)]  
LH28F008SCH-V@TSOP40 [(SA409T)]  
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]  
LH28F008SCN@PSOP44 [(SA638)] LH28F008SCN-L@PSOP44 [(SA638)]  
LH28F008SCT@TSOP40 [(SA409T)] LH28F008SCT-L@TSOP40 [(SA409T)]  
LH28F008SCT-V@TSOP40 [(SA409T)] LH28F008SCV@TSOP40 [(SA409T)]  
LH28F016SA@TSOP56 [(SA628-B011)] LH28F016SC@PSOP44 [(SA638)]  
LH28F016SCR(L95)@RTSOP40 [(SA409T)]  
LH28F016SCT-L95@TSOP40 [(SA409T)]  
LH28F016SUT@TSOP56 [(SA628-B011)]  
LH28F128BFHBD@CSP72 [(SA642E-B052A-T072F001)]  
LH28F128BFHE@TSOP48 [(SA247-B005)]  
LH28F128BFHT(PBTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTLITA)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PWTL80)@TSOP56 [(SA628-B045)]  
LH28F128BFND@PSOP44 [(SA638)]  
LH28F128SPHTD@TSOP56 [(SA628-B018)]  
LH28F160BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGE(B)@TSOP48 [(SA247-B005)]  
LH28F160BGE(T)@TSOP48 [(SA247-B005)]  
LH28F160BJBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJD  
LH28F160BJEB@TSOP48 [(SA247-B005)]  
LH28F160BJET@TSOP48 [(SA247-B005)]  
LH28F160BJHBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHEB@TSOP48 [(SA247-B005)]  
LH28F160BJHET@TSOP48 [(SA247-B005)]  
LH28F160BVE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160BVEB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVEB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVHE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVHE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160S3HNS@SSOP56 [(SA629A-B013)]  
LH28F160S3HT@TSOP56 [(SA628-B011)]  
LH28F160S3NS@SSOP56 [(SA629A-B013)]  
LH28F160S3T@TSOP56 [(SA628-B011)]  
LH28F160S5HNS@SSOP56 [(SA629A-B013)]  
LH28F160S5HT@TSOP56 [(SA628-B011)]  
LH28F160S5NS@SSOP56 [(SA629A-B013)]  
LH28F160S5T@TSOP56 [(SA628-B011)]  
LH28F160SKT@TSOP56 [(SA628-B011)]  
LH28F320BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFE(PT)@TSOP48 [(SA247-B005)]

LH28F320BFHB(PB)@FBGA48 [(SA642B-B029A-Y072F001)]  
 LH28F320BFHB(PT)@FBGA48 [(SA642B-B029A-Y072F001)]  
 LH28F320BFHE(PB)@TSOP48 [(SA247-B005)]  
 LH28F320BFHE(PBTLZ2)@TSOP48 [(SA247-B005)]  
 LH28F320BFHE(PT)@TSOP48 [(SA247-B005)]  
 LH28F320BFHE(PTTL0)@TSOP48 [(SA247-B005)]  
 LH28F320BFHE(PTTLZ1)@TSOP48 [(SA247-B005)]  
 LH28F320BFHG(PBTLZL)@FBGA48 [(SA634A-B005A-Y048F001)]  
 LH28F320BFHG(PBTLZN)@FBGA48 [(SA634A-B005A-Y048F001)]  
 LH28F320BFHG(PTTLZ3)@FBGA48 [(SA634A-B005A-Y048F001)]  
 LH28F320BFHG(PTTLZK)@FBGA48 [(SA634A-B005A-Y048F001)]  
 LH28F320BFHG(PTTLZM)@FBGA48 [(SA634A-B005A-Y048F001)]  
 LH28F320BJD  
 LH28F320BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F320BJE(PB)@TSOP48 [(SA247-B005)]  
 LH28F320BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F320BJE(PT)@TSOP48 [(SA247-B005)]  
 LH28F320BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F320BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F320BJN@PSOP44 [(SA638)]  
 LH28F320S3HNS@SSOP56 [(SA629A-B013)]  
 LH28F320S3HT@TSOP56 [(SA628-B011)]  
 LH28F320S3NS@SSOP56 [(SA629A-B013)]  
 LH28F320S3T@TSOP56 [(SA628-B011)]  
 LH28F320S3TD@TSOP56 [(SA628-B011)]  
 LH28F320S5HNS@SSOP56 [(SA629A-B013)]  
 LH28F320S5HT@TSOP56 [(SA628-B011)]  
 LH28F320S5NS@SSOP56 [(SA629A-B013)]  
 LH28F320S5T@TSOP56 [(SA628-B011)]  
 LH28F320SKTD@TSOP56 [(SA628-B011)]  
 LH28F400BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BGE(B)@TSOP48 [(SA247-B005)]  
 LH28F400BGE(T)@TSOP48 [(SA247-B005)]  
 LH28F400BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BGHE(B)@TSOP48 [(SA247-B005)]  
 LH28F400BGHE(T)@TSOP48 [(SA247-B005)]  
 LH28F400BGN(B)@PSOP44 [(SA638)] LH28F400BGN(T)@PSOP44 [(SA638)]  
 LH28F400BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BVE(B)@TSOP48 [(SA247-B005)]  
 LH28F400BVE(T)@TSOP48 [(SA247-B005)]  
 LH28F400BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F400BVHE(B)@TSOP48 [(SA247-B005)]  
 LH28F400BVHE(T)@TSOP48 [(SA247-B005)]  
 LH28F400BVN(B)@PSOP44 [(SA638)] LH28F400BVN(T)@PSOP44 [(SA638)]  
 LH28F640BFE(PB)@TSOP48 [(SA247-B005)]  
 LH28F640BFE(PT)@TSOP48 [(SA247-B005)]  
 LH28F640BFHB(PB)@FBGA60 [(SA642B-B029A-Y072F001)]  
 LH28F640BFHB(PT)@FBGA60 [(SA642B-B029A-Y072F001)]  
 LH28F640BFHE(PB)@TSOP48 [(SA247-B005)]  
 LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]  
 LH28F640BFHE(PTTLHIA)@TSOP48 [(SA247-B005)]  
 LH28F640BFHG@FBGA48 [(SA714D-B026A-W048F001Y)]  
 LH28F640BNHG@CSP56 [(SA644A-B025A-Y056F001)]  
 LH28F640SPHT@TSOP56 [(SA628-B018)]  
 LH28F800BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BGE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BGE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BGHE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BGHE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BGN(B)@PSOP44 [(SA638)] LH28F800BGN(T)@PSOP44 [(SA638)]  
 LH28F800BH-B@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PB)@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PT)@TSOP48 [(SA247-B005)]  
 LH28F800BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJHG(PB)(OTP)@CSP48 [(SA634A-B005A-Y048F001)]  
 LH28F800BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BV-B@TSOP48 [(SA247-B005)]  
 LH28F800BVE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BVE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BVE(TV85)@TSOP48 [(SA247-B005)]

LH28F800BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVHB@TSOP48 [(SA247-B005)]  
 LH28F800BVHE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BVHE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BVHT@TSOP48 [(SA247-B005)]  
 LH28F800BVN(B)@PSOP44 [(SA638)]      LH28F800BVN(T)@PSOP44 [(SA638)]  
 LH28F800BVN(TV85)@PSOP44 [(SA638)]  
 LH28F800BV-T@TSOP48 [(SA247-B005)]  
 LH28F800SG(L100)@TSOP48 [(SA247)]  
 LH28F800SG(L120)@TSOP48 [(SA247)]  
 LH28F800SG(L70)@TSOP48 [(SA247)]      LH28F800SG(L80)@TSOP48 [(SA247)]  
 LH28F800SG(L85)@TSOP48 [(SA247)]  
 LH28F800SGH(L100)@TSOP48 [(SA247)]  
 LH28F800SGH(L120)@TSOP48 [(SA247)]  
 LH28F800SGH(L70)@TSOP48 [(SA247)]  
 LH28F800SGH(L80)@TSOP48 [(SA247)]  
 LH28F800SGH(L85)@TSOP48 [(SA247)]  
 LH28F800SUT@TSOP56 [(SA628-B011)]  
 LHF00L03@PLCC32 [(SA015A1T)]      LHF00L04@TSOP40 [(SA409T)]  
 LHF00L06@TSOP40 [(SA409T)]      LHF00L07@PLCC32 [(SA015A1T)]  
 LHF00L08(LH28F320T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L09(LH28F320B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L10(LH28F320T)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 LHF00L11(LH28F320B)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 LHF00L12(LH28F320T)@TSOP48 [(SA247-B005)]  
 LHF00L13(LH28F320B)@TSOP48 [(SA247-B005)]  
 LHF00L14(LH28F320T)@TSOP48 [(SA247-B005)]  
 LHF00L15(LH28F320B)@TSOP48 [(SA247-B005)]  
 LHF00L24(LH28F160T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L25(LH28F160B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L28(LH28F160T)@TSOP48 [(SA247-B005)]  
 LHF00L29(LH28F160B)@TSOP48 [(SA247-B005)]  
 LHF00L30(LH28F160T)@TSOP48 [(SA247-B005)]  
 LHF00L31(LH28F160B)@TSOP48 [(SA247-B005)]  
 LRS1311@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1311A@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1315@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1316@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1317@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1320@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1320A@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1329@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1329A@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1330A@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1331@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1331B@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1331C@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1336@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1339@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1341@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1342@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1348B@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1350@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1356@FBGA72 [(SA642E-B069A-T072F001)]  
 LRS1360@FBGA72 [(SA642B-B023A-Y072F001)]  
 LRS1360C@FBGA72 [(SA642B-B023A-Y072F001)]  
 LRS1370@FBGA72 [(SA642B-B023A-Y072F001)]  
 LRS1370B@FBGA72 [(SA642B-B023A-Y072F001)]  
 LRS1380@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1381@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1382@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1383@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1383C@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1383F@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1384@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1385@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1386@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1387@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1391@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1392A@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1393A@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS1393C@FBGA72 [(SA642E-B023A-T072F001N)]  
 LRS1395@FBGA72 [(SA642E-B052A-T072F001)]  
 LRS1396@TSOP56 [(SA628-B178)]  
 LRS13A0@FBGA72 [(SA642E-B052A-T072F001)]  
 LRS13A1@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS13A2@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS13A3@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS13A4@FBGA72 [(SA642E-B023A-T072F001)]  
 LRS13A5@FBGA72 [(SA642E-B023A-T072F001)]

LRS13A6@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A8@TSOP56 [ ( SA628-B216 ) ]  
LRS1805A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1806A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1806F@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1807A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1808A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1811@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1812@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1816@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1816A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1822@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1825@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1826@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1826A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1827@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1828@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1829@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1832@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1844@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1845@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1850@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1851@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1852@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1853@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1871@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1872@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1875@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1876@FBGA72 [ ( SA642B-B023A-Y072F001Y ) ]  
LRS18B0@FBGA72 [ ( SA642E-B141A-T072F001Y ) ]  
LRS18BK@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
LRS18BL@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
LRS18BS@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]

## SHARP-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

LH28F640BFHE ( PT ) @ TSOP48 [ ( SA247-B005 ) ]

## SIEMENS

### E ( E ) PROM / FRAM / NVRAM

SDA2526	SDA2526@SOIC8 [ ( SA602A ) ]
SDA2546	SDA2546@SOIC8 [ ( SA602A ) ]
SDA25X26	SDA25X26@SOIC8 [ ( SA602A ) ]
SDA25X46	SDA25X46@SOIC8 [ ( SA602A ) ]
SDE2526	SDE2526@SOIC8 [ ( SA602A ) ]
SDE2546	SDE2546@SOIC8 [ ( SA602A ) ]
SDE25X26	SDE25X26@SOIC8 [ ( SA602A ) ]
SDE25X46	SDE25X46@SOIC8 [ ( SA602A ) ]
SLA24C01	SLA24C01@SOIC8 [ ( SA602A ) ]
SLA24C02	SLA24C02@SOIC8 [ ( SA602A ) ]
SLA24C04	SLA24C04@SOIC8 [ ( SA602A ) ]
SLA24C08	SLA24C08@SOIC8 [ ( SA602A ) ]
SLA24C16	SLA24C16@SOIC8 [ ( SA602A ) ]
SLA24C164	SLA24C164@SOIC8 [ ( SA602A ) ]
SLA24C32	SLA24C32@SOIC8 [ ( SA602A ) ]
SLA24C64	SLA24C64@SOIC8 [ ( SA602A ) ]
SLA25010	SLA25010@SOIC8 [ ( SA602A ) ]
SLA25020	SLA25020@SOIC8 [ ( SA602A ) ]
SLA25040	SLA25040@SOIC8 [ ( SA602A ) ]
SLA25080	SLA25080@SOIC8 [ ( SA602A ) ]
SLA25160	SLA25160@SOIC8 [ ( SA602A ) ]
SLE24C01	SLE24C01@SOIC8 [ ( SA602A ) ]
SLE24C02	SLE24C02@SOIC8 [ ( SA602A ) ]
SLE24C04	SLE24C04@SOIC8 [ ( SA602A ) ]
SLE24C08	SLE24C08@SOIC8 [ ( SA602A ) ]
SLE24C16	SLE24C16@SOIC8 [ ( SA602A ) ]
SLE24C164	SLE24C164@SOIC8 [ ( SA602A ) ]
SLE24C32	SLE24C32@SOIC8 [ ( SA602A ) ]
SLE24C64	SLE24C64@SOIC8 [ ( SA602A ) ]
SLE25010	SLE25010@SOIC8 [ ( SA602A ) ]



SLE25020	SLE25020@SOIC8 [(SA602A)]
SLE25040	SLE25040@SOIC8 [(SA602A)]
SLE25080	SLE25080@SOIC8 [(SA602A)]
SLE25160	SLE25160@SOIC8 [(SA602A)]

**MICROCONTROLLER**

SAB-C504-2EM@TQFP44 [(SA245A)]	SAB-C505A-4EM@TQFP44 [(SA245A)]
SAB-C505CA-4EM@TQFP44 [(SA245A)]	
SAB-C505L-4EM@PQFP80 [(PEP+S611A)]	
SAB-C508-4EM@TQFP64 [(PEP+S625A)]	
SAB-C508-4EP@SDIP64 [(PEP+S600A)]	
SAB-C515C-8EM@TQFP80 [(PEP+S615B)]	
SAB-C540U-1EN@PLCC44 [(SA244)]	
SAB-C540U-1EP@SDIP52 [(PEP+S600A)]	
SAB-C541U-1EN@PLCC44 [(SA244)]	
SAB-C541U-1EP@SDIP52 [(PEP+S600A)]	
SAF-C164CI-8EM@TQFP80 [(PEP+S615B)]	
SAF-C504-2EM@TQFP44 [(SA245A)]	SAF-C505A-4EM@TQFP44 [(SA245A)]
SAF-C505CA-4EM@TQFP44 [(SA245A)]	
SAF-C505L-4EM@PQFP80 [(PEP+S611A)]	
SAF-C508-4EM@TQFP64 [(PEP+S616)]	
SAF-C508-4EP@SDIP64 [(PEP+S600A)]	
SAF-C513AO-2EM@TQFP44 [(SA245A)]	SAF-C513AO-2EN@PLCC44 [(SA244)]
SAF-C513AO-2EP	
SAF-C515C-8EM@TQFP80 [(PEP+S615B)]	
SAF-XC164CM-4F20F@TQFP64 [(PEP+S616)]	
SAF-XC164CM-4F40F@TQFP64 [(PEP+S616)]	
SAF-XC164CM-8F20F@TQFP64 [(PEP+S616)]	
SAF-XC164CM-8F40F@TQFP64 [(PEP+S616)]	
SAF-XC164CS-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164CS-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC164D-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164D-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164D-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164D-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC164N-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164N-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164N-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164N-8F40F@TQFP100 [(PEP+S604)]	
SAF-XC164S-16F20F@TQFP100 [(PEP+S604)]	
SAF-XC164S-16F40F@TQFP100 [(PEP+S604)]	
SAF-XC164S-8F20F@TQFP100 [(PEP+S604)]	
SAF-XC164S-8F40F@TQFP100 [(PEP+S604)]	
SAH-C504-2EM@TQFP44 [(SA245A)]	SAH-C505A-4EM@TQFP44 [(SA245A)]
SAH-C505CA-4EM@TQFP44 [(SA245A)]	
SAK-C164CI-8EM@TQFP80 [(PEP+S615B)]	
SAK-C504-2EM@TQFP44 [(SA245A)]	SAK-C505A-4EM@TQFP44 [(SA245A)]
SAK-C505CA-4EM@TQFP44 [(SA245A)]	
SAK-C505L-4EM@PQFP80 [(PEP+S611A)]	
SAK-C515C-8EM@TQFP80 [(PEP+S615B)]	
SAK-XC164CM-4F20F@TQFP64 [(PEP+S616)]	
SAK-XC164CM-4F40F@TQFP64 [(PEP+S616)]	
SAK-XC164CM-8F20F@TQFP64 [(PEP+S616)]	
SAK-XC164CM-8F40F@TQFP64 [(PEP+S616)]	
SAK-XC164CS-16F20F@TQFP100 [(PEP+S604)]	
SAK-XC164CS-16F40F@TQFP100 [(PEP+S604)]	
SAK-XC164CS-8F20F@TQFP100 [(PEP+S604)]	
SAK-XC164CS-8F40F@TQFP100 [(PEP+S604)]	

**SIGNETICS****E(E) PROM/FRAM/NVRAM**

27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C040
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32 [(SA410T)]
27C210	27C210@PLCC44 [(SA244)]
27C240	27C240@PLCC44 [(SA244)]
27C256	27C256@PLCC32 [(SA015A1T)]
27C512	27C512@PLCC32 [(SA015A1T)]
27C64A	27C64A@PLCC32 [(SA015A1T)]
27HC641	27HC641@PLCC28 [(SA008A)]
27HC642	27HC642@PLCC28 [(SA008A)]

PCA8582A	PCA8582A@SOIC8 [(SA602A)]
PCA8582B	PCA8582B@SOIC8 [(SA602A)]
PCA8582C	PCA8582C@SOIC8 [(SA602A)]
PCA8582D	PCA8582D@SOIC8 [(SA602A)]
PCA8582E	PCA8582E@SOIC8 [(SA602A)]
PCD8582A	PCD8582A@SOIC8 [(SA602A)]
PCD8582B	PCD8582B@SOIC8 [(SA602A)]
PCD8582C	PCD8582C@SOIC8 [(SA602A)]
PCD8582D	PCD8582D@SOIC8 [(SA602A)]
PCD8582E	PCD8582E@SOIC8 [(SA602A)]
PCF8582A	PCF8582A@SOIC8 [(SA602A)]
PCF8582B	PCF8582B@SOIC8 [(SA602A)]
PCF8582C	PCF8582C@SOIC8 [(SA602A)]
PCF8582D	PCF8582D@SOIC8 [(SA602A)]
PCF8582E	PCF8582E@SOIC8 [(SA602A)]
PCF8594	PCF8594@SOIC8 [(SA602A)]
PCF8594C	PCF8594C@SOIC8 [(SA602A)]
PCF8594D	PCF8594D@SOIC8 [(SA602A)]
PCF8594E	PCF8594E@SOIC8 [(SA602A)]
PCF8598	PCF8598@SOIC8 [(SA605A)]
PCF8598C	PCF8598C@SOIC8 [(SA605A)]
PCF8598D	PCF8598D@SOIC8 [(SA605A)]
PCF8598E	PCF8598E@SOIC8 [(SA605A)]

**BPROM**

82LS135	82LS135@PLCC20 [(SA001A)]
82S123	82S123A
82S126	82S126A
82S129	82S129A
82S135	82S135@PLCC20 [(SA001A)]
82S136	82S137
82S137A	82S137B
82S137C	82S140
82S141	82S146
82S146@PLCC20 [(SA001A)]	82S147
82S147@PLCC20 [(SA001A)]	82S147A
82S147A@PLCC20 [(SA001A)]	82S147B
82S147B@PLCC20 [(SA001A)]	82S167
82S184	82S184A
82S185	82S185A
82S185B	82S185C
82S191	82S191A
82S191B	82S191C
82S23	82S23A

**PLD**

82S100	82S101
82S105	82S105A@PLCC28 [(SA008A)]
82S152	82S152@PLCC20 [(SA001A)]
82S153	82S153@PLCC20 [(SA001A)]
82S155	82S155@PLCC20 [(SA001A)]
82S157	82S157@PLCC20 [(SA001A)]
82S159	82S159@PLCC20 [(SA001A)]
82S167	82S167@PLCC28 [(SA008A)]
82S168	82S168@PLCC28 [(SA008A)]
82S173	82S173@PLCC28 [(SA008A)]
82S179	82S179@PLCC28 [(SA008A)]
PLS100	PLS100@PLCC28 [(SA008A)]
PLS101	PLS101@PLCC28 [(SA008A)]
PLS104	PLS104@PLCC28 [(SA008A)]
PLS104A	PLS104A@PLCC28 [(SA008A)]
PLS105	PLS105@PLCC28 [(SA008A)]
PLS105A	PLS105A@PLCC28 [(SA008A)]
PLS152	PLS152@PLCC20 [(SA001A)]
PLS153	PLS153@PLCC20 [(SA001A)]
PLS153A	PLS153A@PLCC20 [(SA001A)]
PLS155	PLS155@PLCC20 [(SA001A)]
PLS157	PLS157@PLCC20 [(SA001A)]
PLS159	PLS159@PLCC20 [(SA001A)]
PLS159A	PLS159A@PLCC20 [(SA001A)]
PLS167	PLS167@PLCC28 [(SA008A)]
PLS167A	PLS167A@PLCC28 [(SA008A)]
PLS168	PLS168@PLCC28 [(SA008A)]
PLS168A	PLS168A@PLCC28 [(SA008A)]
PLS173	PLS173@PLCC28 [(SA008A)]
PLS179	PLS179@PLCC28 [(SA008A)]

PLUS105 PLUS105@PLCC28 [(SA008A)]

## MICROCONTROLLER

PSD301@PLCC44 [(SA244)]	PSD301L@PLCC44 [(SA244)]
PSD302@PLCC44 [(SA244)]	PSD302L@PLCC44 [(SA244)]
PSD303@PLCC44 [(SA244)]	PSD303L@PLCC44 [(SA244)]
PSD311@PLCC44 [(SA244)]	PSD311L@PLCC44 [(SA244)]
PSD312@PLCC44 [(SA244)]	PSD312L@PLCC44 [(SA244)]
PSD313@PLCC44 [(SA244)]	PSD313@TQFP44 [(SA245A)]
PSD313-B@PLCC44 [(SA244)]	PSD313-B@TQFP44 [(SA245A)]
PSD313L@PLCC44 [(SA244)]	PSD313L@TQFP44 [(SA245A)]
S87C054@SDIP42 [(SA028)]	S87C055@SDIP42 [(SA028)]
S87C451@PLCC68 [(PEP+S414T)]	S87C451@SDIP64 [(PEP+S600A)]
S87C453@PLCC68 [(PEP+S414T)]	S87C51
S87C51@PLCC44 [(SA244)]	S87C51@TQFP44 [(SA245A)]
S87C51FA	S87C51FA@PLCC44 [(SA244)]
S87C51FA@TQFP44 [(SA245A)]	S87C51FB
S87C51FB@PLCC44 [(SA244)]	S87C51FB@TQFP44 [(SA245A)]
S87C51FC	S87C51FC@PLCC44 [(SA244)]
S87C51FC@TQFP44 [(SA245A)]	S87C52
S87C52@PLCC44 [(SA244)]	S87C52@TQFP44 [(SA245A)]
S87C524	S87C524@PLCC44 [(SA244)]
S87C524@TQFP44 [(SA245A)]	S87C528
S87C528@PLCC44 [(SA244)]	S87C528@TQFP44 [(SA245A)]
S87C54	S87C54@PLCC44 [(SA244)]
S87C54@TQFP44 [(SA245A)]	S87C550
S87C550@PLCC44 [(SA244)]	S87C552@PLCC68 [(PEP+S414T)]
S87C552@PLCC68 (*) [(SA648-B6806)]	
S87C554@PLCC68 [(PEP+S414T)]	
S87C554@PLCC68 (*) [(SA648-B6806)]	
S87C575	S87C575@PLCC44 [(SA244)]
S87C575@TQFP44 [(SA245A)]	S87C576
S87C576@PLCC44 [(SA244)]	S87C576@TQFP44 [(SA245A)]
S87C58	S87C58@PLCC44 [(SA244)]
S87C58@TQFP44 [(SA245A)]	S87C591@PLCC44 [(SA244)]
S87C591@TQFP44 [(SA245A)]	S87C592@PLCC68 [(PEP+S414T)]
S87C652	S87C652@PLCC44 [(SA244)]
S87C652@TQFP44 [(SA245A)]	S87C654
S87C654@PLCC44 [(SA244)]	S87C654@TQFP44 [(SA245A)]
S87C748	S87C748@PLCC28 [(SA008A)]
S87C749	S87C749@PLCC28 [(SA008A)]
S87C750	S87C750@PLCC28 [(SA008A)]
S87C750@SSOP24 [(SA626A)]	S87C751
S87C751@PLCC28 [(SA008A)]	S87C751@SSOP24 [(SA626A)]
S87C752	S87C752@PLCC28 [(SA008A)]
S87C752@SSOP28 [(SA626A)]	S87C754
S87C754@PLCC28 [(SA008A)]	S87C754@SSOP28 [(SA626A)]
S87L51FA	S87L51FA@PLCC44 [(SA244)]
S87L51FA@TQFP44 [(SA245A)]	S87L51FB
S87L51FB@PLCC44 [(SA244)]	S87L51FB@TQFP44 [(SA245A)]

## Silicon Laboratories

## MICROCONTROLLER

C8051F000@TQFP64 [(PEP+S616)]	
C8051F000@TQFP64 (*) [(SA732+B335)]	
C8051F000@TQFP64 (ISP) [(PEP+S616)]	
C8051F001@TQFP48 [(SA248)]	C8051F001@TQFP48 (ISP) [(SA248)]
C8051F002@TQFP32 [(SA663)]	C8051F002@TQFP32 (ISP) [(SA663)]
C8051F005@TQFP64 [(PEP+S616)]	
C8051F005@TQFP64 (*) [(SA732+B335)]	
C8051F005@TQFP64 (ISP) [(PEP+S616)]	
C8051F006@TQFP48 [(SA248)]	C8051F006@TQFP48 (ISP) [(SA248)]
C8051F007@TQFP32 [(SA663)]	C8051F007@TQFP32 (ISP) [(SA663)]
C8051F010@TQFP64 [(PEP+S616)]	
C8051F010@TQFP64 (*) [(SA732+B335)]	
C8051F010@TQFP64 (ISP) [(PEP+S616)]	
C8051F011@TQFP48 [(SA248)]	C8051F011@TQFP48 (ISP) [(SA248)]
C8051F012@TQFP32 [(SA663)]	C8051F012@TQFP32 (ISP) [(SA663)]
C8051F015@TQFP64 [(PEP+S616)]	
C8051F015@TQFP64 (*) [(SA732+B335)]	
C8051F015@TQFP64 (ISP) [(PEP+S616)]	
C8051F016@TQFP48 [(SA248)]	C8051F016@TQFP48 (ISP) [(SA248)]
C8051F017@TQFP32 [(SA663)]	C8051F017@TQFP32 (ISP) [(SA663)]

```

C8051F018@TQFP64 [(PEP+S616)]
C8051F018@TQFP64(*) [(SA732+B335)]
C8051F018@TQFP64(ISP) [(PEP+S616)]
C8051F019@TQFP48 [(SA248)] C8051F019@TQFP48(ISP) [(SA248)]
C8051F020@TQFP100 [(PEP+S604)]
C8051F020@TQFP100(ISP) [ISP-HEADER01]
C8051F021@TQFP64 [(PEP+S616)]
C8051F021@TQFP64(*) [(TA050-B005)]
C8051F021@TQFP64(ISP) [ISP-HEADER01]
C8051F022@TQFP100 [(PEP+S604)]
C8051F022@TQFP100(ISP) [ISP-HEADER01]
C8051F023@TQFP64 [(PEP+S616)]
C8051F023@TQFP64(*) [(TA050-B005)]
C8051F023@TQFP64(ISP) [ISP-HEADER01]
C8051F040@TQFP100 [(PEP+S604)]
C8051F040@TQFP100(ISP) [ISP-HEADER01]
C8051F041@TQFP64 [(PEP+S616)]
C8051F041@TQFP64(*) [(TA050-B005)]
C8051F041@TQFP64(ISP) [ISP-HEADER01]
C8051F042@TQFP100 [(PEP+S604)]
C8051F042@TQFP100(ISP) [ISP-HEADER01]
C8051F043@TQFP64 [(PEP+S616)]
C8051F043@TQFP64(*) [(TA050-B005)]
C8051F043@TQFP64(ISP) [ISP-HEADER01]
C8051F044@TQFP100 [(PEP+S604)]
C8051F044@TQFP100(ISP) [ISP-HEADER01]
C8051F045@TQFP64 [(PEP+S616)]
C8051F045@TQFP64(*) [(TA050-B005)]
C8051F045@TQFP64(ISP) [ISP-HEADER01]
C8051F046@TQFP100 [(PEP+S604)]
C8051F046@TQFP100(ISP) [ISP-HEADER01]
C8051F047@TQFP64 [(PEP+S616)]
C8051F047@TQFP64(*) [(TA050-B005)]
C8051F047@TQFP64(ISP) [ISP-HEADER01]
C8051F060@TQFP100 [(PEP+S604)] C8051F061@TQFP64 [(PEP+S616)]
C8051F062@TQFP100 [(PEP+S604)] C8051F063@TQFP64 [(PEP+S616)]
C8051F064@TQFP100 [(PEP+S604)] C8051F065@TQFP64 [(PEP+S616)]
C8051F066@TQFP100 [(PEP+S604)] C8051F067@TQFP64 [(PEP+S616)]
C8051F120@TQFP100 [(PEP+S604)]
C8051F120-GQ@TQFP100 [(PEP+S604)]
C8051F121@TQFP64 [(PEP+S616)] C8051F121-GQ@TQFP64 [(PEP+S616)]
C8051F122@TQFP100 [(PEP+S604)]
C8051F122-GQ@TQFP100 [(PEP+S604)]
C8051F123@TQFP64 [(PEP+S616)] C8051F123-GQ@TQFP64 [(PEP+S616)]
C8051F124@TQFP100 [(PEP+S604)]
C8051F124-GQ@TQFP100 [(PEP+S604)]
C8051F125@TQFP64 [(PEP+S616)] C8051F125-GQ@TQFP64 [(PEP+S616)]
C8051F126@TQFP100 [(PEP+S604)]
C8051F126-GQ@TQFP100 [(PEP+S604)]
C8051F127@TQFP64 [(PEP+S616)] C8051F127-GQ@TQFP64 [(PEP+S616)]
C8051F130@TQFP100 [(PEP+S604)]
C8051F130-GQ@TQFP100 [(PEP+S604)]
C8051F131@TQFP64 [(PEP+S616)] C8051F131-GQ@TQFP64 [(PEP+S616)]
C8051F132@TQFP100 [(PEP+S604)]
C8051F132-GQ@TQFP100 [(PEP+S604)]
C8051F133@TQFP64 [(PEP+S616)] C8051F133-GQ@TQFP64 [(PEP+S616)]
C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48 [(SA248)]
C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48 [(SA248)]
C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32 [(SA663)]
C8051F236@TQFP48 [(SA248)] C8051F300 [(SA695A)]
C8051F301 [(SA695A)] C8051F302 [(SA695A)]
C8051F303 [(SA695A)] C8051F304 [(SA695A)]
C8051F305 [(SA695A)] C8051F310@TQFP32 [(SA663)]
C8051F310-GQ@TQFP32 [(SA663)] C8051F311@QFN28 [(SA697-B006)]
C8051F311-GM@QFN28 [(SA697-B006)]
C8051F312@TQFP32 [(SA663)] C8051F312-GQ@TQFP32 [(SA663)]
C8051F313@QFN28 [(SA697-B006)]
C8051F313-GM@QFN28 [(SA697-B006)]
C8051F314@TQFP32 [(SA663)] C8051F314-GQ@TQFP32 [(SA663)]
C8051F315@QFN28 [(SA697-B006)]
C8051F315-GM@QFN28 [(SA697-B006)]
C8051F316-GM@QFN24 [(SA710-B006)]
C8051F317-GM@QFN24 [(SA710-B006)]
C8051F320@TQFP32 [(SA663)] C8051F321@QFN28 [(SA697-B006)]
C8051F326@QFN28 [(SA697-B006)]
C8051F326-GQ@QFN28 [(SA697-B006)]
C8051F327@QFN28 [(SA697-B006)]
C8051F327-GQ@QFN28 [(SA697-B006)]
C8051F330@MLP20 [(SA692)] C8051F330D
C8051F331@MLP20 [(SA692)] C8051F332-GM@MLP20 [(SA692)]
C8051F333-GM@MLP20 [(SA692)] C8051F334-GM@MLP20 [(SA692)]

```

C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20 [(SA692)]
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24 [(SA710)]
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48 [(SA248)]
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32 [(SA663)]
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48 [(SA248)]
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32 [(SA663)]
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32 [(SA663)]
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F360@QFP48 [(SA248)]	C8051F361@QFP32 [(SA663)]
C8051F362@QFN28 [(SA697)]	C8051F363@QFP48 [(SA248)]
C8051F364@QFP32 [(SA663)]	C8051F365@QFN28 [(SA697)]
C8051F366@QFP32 [(SA663)]	C8051F367@QFN28 [(SA697)]
C8051F368@QFP32 [(SA663)]	C8051F369@QFN28 [(SA697)]
C8051F410-GQ@LQFP32 [(SA663)]	C8051F411-GM@QFN28 [(SA697)]
C8051F412-GQ@LQFP32 [(SA663)]	C8051F413-GM@QFN28 [(SA697)]
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10 [(SA695A)]
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10 [(SA695A)]
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10 [(SA695A)]
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20 [(SA026)]
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20 [(SA026)]
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20 [(SA026)]
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20 [(SA026)]
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20 [(SA026)]
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20 [(SA026)]
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
C8051T600@QFN11 [(SA695A)]	C8051T600@SOIC14 [(SA602)]
C8051T601@QFN11 [(SA695A)]	C8051T601@SOIC14 [(SA602)]
C8051T602@QFN11 [(SA695A)]	C8051T602@SOIC14 [(SA602)]
C8051T603@QFN11 [(SA695A)]	C8051T603@SOIC14 [(SA602)]
C8051T604@QFN11 [(SA695A)]	C8051T604@SOIC14 [(SA602)]
C8051T605@QFN11 [(SA695A)]	C8051T605@SOIC14 [(SA602)]
SI8250@LQFP32 [(SA663)]	SI8250@QFN28 [(SA697)]
SI8251@LQFP32 [(SA663)]	SI8251@QFN28 [(SA697)]
SI8252@LQFP32 [(SA663)]	SI8252@QFN28 [(SA697)]

## SILICON7

### E (E) PROM / FRAM / NVRAM

SV4E1602UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1602UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1604UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1604UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1608UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1608UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3204UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3204UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3208UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3208UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3216UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3216UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4F1602UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1602UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1604UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1604UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1608UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1608UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3204UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3204UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3208UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3208UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3216UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3216UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV5C2832UCR@FBGA72 [(SA642E-B052A-T072F001)]
SV5C3238UBA(NO EFP)@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C3238UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C3238UTA(NO EFP)@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C3238UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C6416UBB(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]

```

SV5C6416UBB@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UBR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UBR@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTB(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTB@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTR@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6432UBR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6432UTR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5D2832UCA@FBGA88 [(SA642A-B081A-Y096F001)]
SV6C2832UBA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C2832UTA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6416UBA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6416UTA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6432UBA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6432UTA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6D2832UBA@FBGA88 [(SA642A-B124A-Y096F001Y)]
SV6D2832UTA@FBGA88 [(SA642A-B124A-Y096F001Y)]
SV7C1602UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1602UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1604UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1604UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1608UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1608UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3204UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3204UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3208UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3208UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3216UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3216UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7E1602UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1602UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1604UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1604UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1608UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1608UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3204UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3204UBAL@FBGA56 [(SA642P-B207A-Y096F001Y)]
SV7E3204UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3204UTAL@FBGA56 [(SA642P-B207A-Y096F001Y)]
SV7E3208UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3208UBALC@FBGA56 [(SA642P-B207A-Y096F001Y)]
SV7E3208UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3208UTALC@FBGA56 [(SA642P-B207A-Y096F001Y)]
SV7E3216UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3216UBALC@FBGA56 [(SA642P-B207A-Y096F001Y)]
SV7E3216UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3216UTALC@FBGA56 [(SA642P-B207A-Y096F001Y)]

```

## SIMTEK

### E(E) PROM/FRAM/NVRAM

```

STK10C48
STK10C48@SOIC28(300 mil) [(SA404)]
STK10C48@SOIC28(350 mil) [(SA630)]
STK10C68
STK10C68@SOIC28(350 mil) [(SA630)]
STK10C68@PLCC28 [(SA008A)]
STK11C48
STK11C48@SOIC28(300 mil) [(SA404)]
STK11C48@SOIC28(350 mil) [(SA630)]
STK11C68
STK11C68@SOIC28(350 mil) [(SA630)]
STK11C68@PLCC28 [(SA008A)]
STK11C88
STK11C88(3V)@SOIC28(300 mil) [(SA404)]
STK11C88(3V)@SOIC28(350 mil) [(SA630)]
STK11C88@SOIC28(300 mil) [(SA404)]
STK11C88@SOIC28(350 mil) [(SA630)]
STK12C68
STK12C68@SOIC28(350 mil) [(SA630)]
STK12C68@PLCC28 [(SA008A)]
STK14C88
STK14C88(3V)@PLCC32 [(SA015A1T)]
STK14C88(3V)@SOIC32(300 mil) [(SA715)]
STK14C88(3V)@SOIC32(350 mil) [(SA630)]
STK14C88@PLCC32 [(SA015A1T)]
STK14C88@SOIC32(300 mil) [(SA715)]
STK14C88@SOIC32(350 mil) [(SA630)]
STK14CA8
STK14CA8@SOIC32 [(SA715)]

```

STK14CA8@SSOP48 [(SA669)]	STK14D88@SOIC32 [(SA715)]
STK14D88@SSOP48 [(SA669)]	STK15C68
STK15C68@SOIC28(350 mil) [(SA630)]	
STK15C88	
STK15C88@SOIC28(300 mil) [(SA404)]	
STK15C88@SOIC28(350 mil) [(SA630)]	
STK16C68	STK16C88
STK16C88(3V)	STK16CA8
STK20C04	STK22C48
STK22C48@SOIC28(300 mil) [(SA404)]	
STK22C48@SOIC28(350 mil) [(SA630)]	
STK25C48	

## SIRF

### E (E) PROM/FRAM/NVRAM

GSC3F(LP)-7979@FBGA140 [(SA678G-B190A-M140F001Y)]  
 GSC3F(LP)-7989@FBGA140 [(SA678G-B190A-M140F001Y)]  
 GSC3F-7879@FBGA140 [(SA678G-B190A-M140F001Y)]

## SMOS

### E (E) PROM/FRAM/NVRAM

SPM27128	SPM27128C
SPM27C256	SPM27C64
SPM27C64H	

## SONIX

### MICROCONTROLLER

SN8P1504	SN8P1504@SOP18 [(SA404)]
SN8P1504@SOP28 [(SA404)]	SN8P1506
SN8P1507@TQFP44 [(SA245A)]	SN8P1602
SN8P1602@SOP18 [(SA404)]	SN8P1602@SSOP20 [(SA674-B005)]
SN8P1603	SN8P1603@SOP18 [(SA404)]
SN8P1603@SSOP20 [(SA674-B005)]	SN8P1604
SN8P1604@SOP28 [(SA404)]	SN8P1702
SN8P1702@SOP18 [(SA404)]	SN8P1702@SSOP20 [(SA674-B005)]
SN8P1704A	SN8P1704A@SOP28 [(SA404)]
SN8P1704B	SN8P1704B@SOP28 [(SA404)]
SN8P1706A	SN8P1706B
SN8P1707A	SN8P1707A@TQFP44 [(SA245A)]
SN8P1707B@TQFP44 [(SA245A)]	SN8P1708A
SN8P1708A@SSOP48 [(SA669)]	SN8P1708B
SN8P1708B@SSOP48 [(SA669)]	SN8P1714
SN8P1714@SOP18 [(SA404)]	SN8P1714@SOP28 [(SA404)]
SN8P1716	SN8P1717@TQFP44 [(SA245A)]
SN8P2501AP	SN8P2501AS@SOP14 [(SA602)]
SN8P2501AX@TSSOP16 [(SA026)]	SN8P2501BP
SN8P2501BS@SOP14 [(SA602)]	SN8P2501BX@TSSOP16 [(SA026)]
SN8P2502AP	SN8P2502AS@SOP14 [(SA602)]
SN8P2502AX@TSSOP16 [(SA026)]	SN8P2502BP
SN8P2502BS@SOP14 [(SA602)]	SN8P2502BX@TSSOP16 [(SA026)]
SN8P2504AP	SN8P2504AS@SOP14 [(SA602)]
SN8P2504AX@TSSOP16 [(SA026)]	SN8P2504BP
SN8P2504BS@SOP14 [(SA602)]	SN8P2504BX@TSSOP16 [(SA026)]
SN8P2602AP	SN8P2602AS@SOP18 [(SA023A)]
SN8P2602AX@SSOP20 [(SA674)]	SN8P2602BP
SN8P2602BS@SOP18 [(SA023A)]	SN8P2602BX@SSOP20 [(SA674)]
SN8P2603AP	SN8P2603AS@SOP18 [(SA023A)]
SN8P2603AX@SSOP20 [(SA674)]	SN8P2603BP
SN8P2603BS@SOP18 [(SA023A)]	SN8P2603BX@SSOP20 [(SA674)]
SN8P26042AP	SN8P26042AS@SOP20 [(SA023A)]
SN8P26042AX@SSOP20 [(SA674)]	SN8P26042BP
SN8P26042BS@SOP20 [(SA023A)]	SN8P26042BX@SSOP20 [(SA674)]
SN8P26042P	SN8P26042S@SOP20 [(SA023A)]
SN8P26042X@SSOP20 [(SA674)]	SN8P2604AK
SN8P2604AS@SOP28 [(SA404)]	SN8P2604AX@SSOP28 [(SA626A)]

SN8P2604BK	SN8P2604BS@SOP28 [(SA404)]
SN8P2604BX@SSOP28 [(SA626A)]	SN8P2604K
SN8P2604S@SOP28 [(SA404)]	SN8P2604X@SSOP28 [(SA626A)]
SN8P2606P	SN8P2608P
SN8P2608X@SSOP48 [(SA669)]	SN8P2622P
SN8P2622S@SOP18 [(SA023A)]	SN8P2622X@SSOP20 [(SA674)]
SN8P2624K	SN8P2624S@SOP28 [(SA404)]
SN8P2624X@SSOP28 [(SA626A)]	SN8P2704AK@SDIP28 [(SA653)]
SN8P2704AP	SN8P2704AS@SOP28 [(SA723)]
SN8P2705AP	SN8P2705AS@SOP32 [(SA687)]
SN8P2706AP	SN8P2707AQ@QFP44 [(SA245A)]
SN8P2708AP	SN8P2708AQ@LQFP48 [(SA248)]
SN8P2708AX@TSOP48 [(SA669)]	SN8P2722P
SN8P2722S@SOP20 [(SA023A)]	SN8P2722X@SSOP20 [(SA674)]

## SONY

### E (E) PROM/FRAM/NVRAM

CXK1011M@SOIC8 [(SA602A)]	CXK1011P
CXK1012P	CXK1013P
CXK1023P	CXK27C4001

### DRAM & SRAM

CXK581000	CXK581000@SOIC32 [(SA630)]
-----------	----------------------------

## SPACE ELECTRONICS[SEI]

### E (E) PROM/FRAM/NVRAM

28C010	28C010@PLCC32 [(SA015A1T)]
28C010@TSOP32 [(SA410T)]	28C010T
28C010T@PLCC32 [(SA015A1T)]	28C010T@TSOP32 [(SA410T)]
28C011	28C011@PLCC32 [(SA015A1T)]
28C011@TSOP32 [(SA410T)]	28C011T
28C011T@PLCC32 [(SA015A1T)]	28C011T@TSOP32 [(SA410T)]

## SPANSION

### E (E) PROM/FRAM/NVRAM

AM29BL162CB@SSOP56 [(SA629A-B022)]
AM29BL802CB@SSOP56 [(SA629A-B022)]
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DB@TSOP48 [(SA247-B005)]
AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DT@TSOP48 [(SA247-B005)]
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@TSOP48 [(SA247-B005)]
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CT@TSOP48 [(SA247-B005)]
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DB@TSOP48 [(SA247-B005)]
AM29DL162DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DT@TSOP48 [(SA247-B005)]
AM29DL162DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@TSOP48 [(SA247-B005)]



AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

```

AM29DL324GT@FBGA63 [(SA642L-B026A-W080F001Y)]
AM29DL324GT@FBGA64 [(SA655D-B044A-W064F001Y)]
AM29DL324GT@TSOP48 [(SA247-B005)]
AM29DL400BB@PSOP44 [(SA638-B006)]
AM29DL400BB@TSOP48 [(SA247-B005)]
AM29DL400BT@PLCC44 [(SA638-B006)]
AM29DL400BT@TSOP48 [(SA247-B005)]
AM29DL640D@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL640D@TSOP48 [(SA247-B005)]
AM29DL640G@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL640G@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL640G@TSOP48 [(SA247-B005)]
AM29DL642G@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-B005)]
AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29DL800BB@PSOP44 [(SA638)]
AM29DL800BB@TSOP48 [(SA247-B005)]
AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29DL800BT@PSOP44 [(SA638)]
AM29DL800BT@TSOP48 [(SA247-B005)]
AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]
AM29DS163CB@TSOP48 [(SA247-B005)]
AM29DS163CT@TSOP48 [(SA247-B005)]
AM29DS163DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DS163DB@TSOP48 [(SA247-B005)]
AM29DS163DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DS163DT@TSOP48 [(SA247-B005)]
AM29DS323DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DS323DB@TSOP48 [(SA247-B005)]
AM29DS323DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DS323DT@TSOP48 [(SA247-B005)]
AM29F002B AM29F002B@PLCC32 [(SA015A1T)]
AM29F002B@TSOP32 [(SA410T)] AM29F002BB
AM29F002BB@PLCC32 [(SA015A1T)] AM29F002BB@TSOP32 [(SA410T)]
AM29F002BT AM29F002BT@PLCC32 [(SA015A1T)]
AM29F002BT@TSOP32 [(SA410T)] AM29F002NB
AM29F002NB@PLCC32 [(SA015A1T)] AM29F002NB@TSOP32 [(SA410T)]
AM29F002NBB AM29F002NBB@PLCC32 [(SA015A1T)]
AM29F002NBB@TSOP32 [(SA410T)] AM29F002NBT
AM29F002NBT@PLCC32 [(SA015A1T)] AM29F002NBT@TSOP32 [(SA410T)]
AM29F002NT AM29F002NT@PLCC32 [(SA015A1T)]
AM29F002NT@TSOP32 [(SA410T)] AM29F002T
AM29F002T@PLCC32 [(SA015A1T)] AM29F002T@TSOP32 [(SA410T)]
AM29F004BB@PLCC32 [(SA015A1T)] AM29F004BB@TSOP32 [(SA410T)]
AM29F004BT@PLCC32 [(SA015A1T)] AM29F004BT@TSOP32 [(SA410T)]
AM29F010 AM29F010@PLCC32 [(SA015A1T)]
AM29F010@TSOP32 [(SA410T)] AM29F010A
AM29F010A@PLCC32 [(SA015A1T)] AM29F010A@TSOP32 [(SA410T)]
AM29F010B AM29F010B@PLCC32 [(SA015A1T)]
AM29F010B@TSOP32 [(SA410T)] AM29F016@PSOP44 [(SA638)]
AM29F016@TSOP40 [(SA409T)] AM29F016@TSOP48 [(SA247-B005)]
AM29F016B@PSOP44 [(SA638)] AM29F016B@TSOP40 [(SA409T)]
AM29F016B@TSOP48 [(SA247-B005)]
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]
AM29F016D@PSOP44 [(SA638)] AM29F016D@TSOP40 [(SA409T)]
AM29F016D@TSOP48 [(SA247-B005)] AM29F017B@TSOP48 [(SA247-B005)]
AM29F017D@TSOP40 [(SA409T)] AM29F017D@TSOP48 [(SA247-B005)]
AM29F032B@PSOP44 [(SA638)] AM29F032B@TSOP40 [(SA409T)]
AM29F040 AM29F040@PLCC32 [(SA015A1T)]
AM29F040@TSOP32 [(SA410T)] AM29F040A
AM29F040A@PLCC32 [(SA015A1T)] AM29F040A@TSOP32 [(SA410T)]
AM29F040B
AM29F040B(Reverse)@TSOP32 [(SA410T)]
AM29F040B@PLCC32 [(SA015A1T)] AM29F040B@TSOP32 [(SA410T)]
AM29F080@PSOP44 [(SA638)] AM29F080@TSOP40 [(SA409T)]
AM29F080B@PSOP44 [(SA638)] AM29F080B@TSOP40 [(SA409T)]
AM29F100BE@PSOP44 [(SA638-B006)] AM29F100BE@TSOP48 [(SA247-B005)]
AM29F100BS@PSOP44 [(SA638-B006)] AM29F100BS@TSOP48 [(SA247-B005)]
AM29F100TE@PSOP44 [(SA638-B006)] AM29F100TE@TSOP48 [(SA247-B005)]
AM29F100TS@PSOP44 [(SA638-B006)] AM29F100TS@TSOP48 [(SA247-B005)]
AM29F160DB@TSOP48 [(SA247-B005)] AM29F160DT@TSOP48 [(SA247-B005)]
AM29F200AB@PSOP44 [(SA638-B006)] AM29F200AB@TSOP48 [(SA247-B005)]
AM29F200AT@PSOP44 [(SA638-B006)] AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)] AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)] AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)] AM29F200BS@TSOP48 [(SA247-B005)]
AM29F200BT@PSOP44 [(SA638-B006)] AM29F200BT@TSOP48 [(SA247-B005)]
AM29F200TE@PSOP44 [(SA638-B006)] AM29F200TE@TSOP48 [(SA247-B005)]
AM29F200TS@PSOP44 [(SA638-B006)] AM29F200TS@TSOP48 [(SA247-B005)]
AM29F400AB@PSOP44 [(SA638-B006)] AM29F400AB@TSOP48 [(SA247-B005)]
AM29F400AT@PSOP44 [(SA638-B006)] AM29F400AT@TSOP48 [(SA247-B005)]

```

AM29F400BB@PSOP44 [(SA638-B006)] AM29F400BB@TSOP48 [(SA247-B005)]  
 AM29F400BBE@PSOP44 [(SA638-B006)]  
 AM29F400BBE@TSOP48 [(SA247-B005)]  
 AM29F400BBF@PSOP44 [(SA638-B006)]  
 AM29F400BBF@TSOP48 [(SA247-B005)]  
 AM29F400BBS@PSOP44 [(SA638-B006)]  
 AM29F400BBS@TSOP48 [(SA247-B005)]  
 AM29F400BE@PSOP44 [(SA638-B006)] AM29F400BE@TSOP48 [(SA247-B005)]  
 AM29F400BF@PSOP44 [(SA638-B006)] AM29F400BF@TSOP48 [(SA247-B005)]  
 AM29F400BS@PSOP44 [(SA638-B006)] AM29F400BS@TSOP48 [(SA247-B005)]  
 AM29F400BT@PSOP44 [(SA638-B006)] AM29F400BT@TSOP48 [(SA247-B005)]  
 AM29F400BTE@PSOP44 [(SA638-B006)]  
 AM29F400BTE@TSOP48 [(SA247-B005)]  
 AM29F400BTF@PSOP44 [(SA638-B006)]  
 AM29F400BTF@TSOP48 [(SA247-B005)]  
 AM29F400BTS@PSOP44 [(SA638-B006)]  
 AM29F400BTS@TSOP48 [(SA247-B005)]  
 AM29F800B@PSOP44 [(SA638-B006)] AM29F800B@TSOP48 [(SA247-B005)]  
 AM29F800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29F800BB@PSOP44 [(SA638-B006)] AM29F800BB@TSOP48 [(SA247-B005)]  
 AM29F800BBF@PSOP44 [(SA638-B006)]  
 AM29F800BBF@TSOP48 [(SA247-B005)]  
 AM29F800BF@PSOP44 [(SA638-B006)] AM29F800BF@TSOP48 [(SA247-B005)]  
 AM29F800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29F800BT@PSOP44 [(SA638-B006)] AM29F800BT@TSOP48 [(SA247-B005)]  
 AM29F800BTF@PSOP44 [(SA638-B006)]  
 AM29F800BTF@TSOP48 [(SA247-B005)]  
 AM29F800T@PSOP44 [(SA638-B006)] AM29F800T@TSOP48 [(SA247-B005)]  
 AM29F800TB@PSOP44 [(SA638-B006)] AM29F800TB@TSOP48 [(SA247-B005)]  
 AM29F800TF@PSOP44 [(SA638-B006)] AM29F800TF@TSOP48 [(SA247-B005)]  
 AM29LL800B@TSOP48 [(SA247-B005)]  
 AM29LL800BB@TSOP48 [(SA247-B005)]  
 AM29LL800BT@TSOP48 [(SA247-B005)]  
 AM29LL800T@TSOP48 [(SA247-B005)]  
 AM29LV001BB@TSOP32 [(SA410T)] AM29LV001BB@PLCC32 [(SA015A1T)]  
 AM29LV001BT@TSOP32 [(SA410T)] AM29LV001BT@PLCC32 [(SA015A1T)]  
 AM29LV001BT@TSOP32 [(SA410T)] AM29LV002@TSOP40 [(SA409T)]  
 AM29LV002B@TSOP40 [(SA409T)] AM29LV002BB@TSOP40 [(SA409T)]  
 AM29LV002BT@TSOP40 [(SA409T)] AM29LV004B@PSOP44 [(SA638)]  
 AM29LV004B@TSOP40 [(SA409T)] AM29LV004BB@TSOP40 [(SA409T)]  
 AM29LV004BT@TSOP40 [(SA409T)] AM29LV004T@PSOP44 [(SA638)]  
 AM29LV004T@TSOP40 [(SA409T)] AM29LV008B@PSOP44 [(SA638)]  
 AM29LV008B@TSOP40 [(SA409T)] AM29LV008BB@TSOP40 [(SA409T)]  
 AM29LV008BT@TSOP40 [(SA409T)] AM29LV008T@PSOP44 [(SA638)]  
 AM29LV008T@TSOP40 [(SA409T)] AM29LV010B@PLCC32 [(SA015A1T)]  
 AM29LV010B@TSOP32 [(SA410T)] AM29LV017B@TSOP40 [(SA409T)]  
 AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29LV017D@TSOP40 [(SA409T)] AM29LV020B@PLCC32 [(SA015A1T)]  
 AM29LV020B@TSOP32 [(SA410T)]  
 AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]  
 AM29LV033C@TSOP40 [(SA409T)]  
 AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29LV033MU@TSOP40 [(SA409T)] AM29LV040B@PLCC32 [(SA015A1T)]  
 AM29LV040B@TSOP32 [(SA410T)] AM29LV040E@PLCC32 [(SA015A1T)]  
 AM29LV040E@TSOP32 [(SA410T)] AM29LV040J@PLCC32 [(SA015A1T)]  
 AM29LV040J@TSOP32 [(SA410T)]  
 AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]  
 AM29LV065D@TSOP48 [(SA247-B005)]  
 AM29LV065MU@FBGA63 [(SA642C-B026A-Y056F001)]  
 AM29LV065MU@TSOP48 [(SA247-B005)]  
 AM29LV080@TSOP40 [(SA409T)] AM29LV081@TSOP40 [(SA409T)]  
 AM29LV081B@TSOP40 [(SA409T)] AM29LV116BB@TSOP40 [(SA409T)]  
 AM29LV116BT@TSOP40 [(SA409T)] AM29LV116DB@TSOP40 [(SA409T)]  
 AM29LV116DT@TSOP40 [(SA409T)]  
 AM29LV128MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
 AM29LV128MH@TSOP56 [(SA628-B067)]  
 AM29LV128ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
 AM29LV128ML@TSOP56 [(SA628-B067)]  
 AM29LV160BB@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160BB@PSOP44 [(SA638)]  
 AM29LV160BB@TSOP48 [(SA247-B005)]  
 AM29LV160BT@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160BT@PSOP44 [(SA638)]  
 AM29LV160BT@TSOP48 [(SA247-B005)]  
 AM29LV160DB (REVERSE)@TSOP48 [(SA247-B005)]  
 AM29LV160DB@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160DB@PSOP44 [(SA638)]  
 AM29LV160DB@TSOP48 [(SA247-B005)]  
 AM29LV160DT (REVERSE)@TSOP48 [(SA247-B005)]  
 AM29LV160DT@FBGA48 [(SA642HH-B026A-W048F001Y)]  
 AM29LV160DT@PSOP44 [(SA638)]  
 AM29LV160DT@TSOP48 [(SA247-B005)]

AM29LV160MB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29LV160MB@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV160MB@PSOP44 [ (SA638) ]  
 AM29LV160MB@TSOP48 [ (SA247-B005) ]  
 AM29LV160MT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29LV160MT@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV160MT@PSOP44 [ (SA638) ]  
 AM29LV160MT@TSOP48 [ (SA247-B005) ]  
 AM29LV200B@PSOP44 [ (SA638-B006) ] AM29LV200B@TSOP48 [ (SA247-B005) ]  
 AM29LV200BB@PSOP44 [ (SA638-B006) ]  
 AM29LV200BB@TSOP48 [ (SA247-B005) ]  
 AM29LV200BE@PSOP44 [ (SA638-B006) ]  
 AM29LV200BE@TSOP48 [ (SA247-B005) ]  
 AM29LV200BF@PSOP44 [ (SA638-B006) ]  
 AM29LV200BF@TSOP48 [ (SA247-B005) ]  
 AM29LV200BS@PSOP44 [ (SA638-B006) ]  
 AM29LV200BS@TSOP48 [ (SA247-B005) ]  
 AM29LV200BT@PSOP44 [ (SA638-B006) ]  
 AM29LV200BT@TSOP48 [ (SA247-B005) ]  
 AM29LV200T@PSOP44 [ (SA638-B006) ] AM29LV200T@TSOP48 [ (SA247-B005) ]  
 AM29LV200TE@PSOP44 [ (SA638-B006) ]  
 AM29LV200TE@TSOP48 [ (SA247-B005) ]  
 AM29LV200TF@PSOP44 [ (SA638-B006) ]  
 AM29LV200TF@TSOP48 [ (SA247-B005) ]  
 AM29LV200TS@PSOP44 [ (SA638-B006) ]  
 AM29LV200TS@TSOP48 [ (SA247-B005) ]  
 AM29LV256MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
 AM29LV256MH@TSOP56 [ (SA628-B067) ]  
 AM29LV256ML@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
 AM29LV256ML@TSOP56 [ (SA628-B067) ]  
 AM29LV320DB@FBGA48 [ (SA642E-B026A-T072F001) ]  
 AM29LV320DB@TSOP48 [ (SA247-B005) ]  
 AM29LV320DT@FBGA48 [ (SA642E-B026A-T072F001) ]  
 AM29LV320DT@TSOP48 [ (SA247-B005) ]  
 AM29LV320FB@TSOP48 [ (SA247-B005) ]  
 AM29LV320FT@TSOP48 [ (SA247-B005) ]  
 AM29LV320MB@FBGA48 [ (SA642HH-B026A-T048F001Y) ]  
 AM29LV320MB@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV320MB@TSOP48 [ (SA247-B005) ]  
 AM29LV320MH@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV320MH@TSOP56 [ (SA628-B067) ]  
 AM29LV320ML@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV320ML@TSOP56 [ (SA628-B067) ]  
 AM29LV320MT@FBGA48 [ (SA642HH-B026A-T048F001Y) ]  
 AM29LV320MT@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV320MT@TSOP48 [ (SA247-B005) ]  
 AM29LV400B@PSOP44 [ (SA638-B006) ] AM29LV400B@TSOP48 [ (SA247-B005) ]  
 AM29LV400BB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 AM29LV400BB@PSOP44 [ (SA638-B006) ]  
 AM29LV400BB@TSOP48 [ (SA247-B005) ]  
 AM29LV400BT@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 AM29LV400BT@PSOP44 [ (SA638-B006) ]  
 AM29LV400BT@TSOP48 [ (SA247-B005) ]  
 AM29LV400T@PSOP44 [ (SA638-B006) ] AM29LV400T@TSOP48 [ (SA247-B005) ]  
 AM29LV640DH@SSOP56 [ (SA629A-B020) ]  
 AM29LV640DL@SSOP56 [ (SA629A-B020) ]  
 AM29LV640DU@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640DU@FBGA64 [ (SA655D-B044A-W064F001) ]  
 AM29LV640GU@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640GU@FBGA64 [ (SA655D-B044A-W064F001) ]  
 AM29LV640MB@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640MB@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV640MB@TSOP48 [ (SA247-B005) ]  
 AM29LV640MH@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV640MH@TSOP56 [ (SA628-B067) ]  
 AM29LV640ML@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV640ML@TSOP56 [ (SA628-B067) ]  
 AM29LV640MT@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640MT@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV640MT@TSOP48 [ (SA247-B005) ]  
 AM29LV640MU@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640MU@FBGA64 [ (SA655D-B044A-W064F001Y) ]  
 AM29LV641DH@TSOP48 [ (SA247-B005) ]  
 AM29LV641DHR@TSOP48 [ (SA247-B005) ]  
 AM29LV641DL@TSOP48 [ (SA247-B005) ]  
 AM29LV641DLR@TSOP48 [ (SA247-B005) ]  
 AM29LV641GH@TSOP48 [ (SA247-B005) ]  
 AM29LV641GHR@TSOP48 [ (SA247-B005) ]  
 AM29LV641GL@TSOP48 [ (SA247-B005) ]  
 AM29LV641GLR@TSOP48 [ (SA247-B005) ]  
 AM29LV641MH@TSOP48 [ (SA247-B005) ]

AM29LV641ML@TSOP48 [(SA247-B005)]  
 AM29LV642G@FBGA64 [(SA655A-B038A-T064N001)]  
 AM29LV652D@FBGA63 [(SA642M-B026A-W048F001Y)]  
 AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]  
 AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800BB@PSOP44 [(SA638-B006)]  
 AM29LV800BB@TSOP48 [(SA247-B005)]  
 AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800BT@PSOP44 [(SA638-B006)]  
 AM29LV800BT@TSOP48 [(SA247-B005)]  
 AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29LV800DB@PSOP44 [(SA638)]  
 AM29LV800DB@TSOP48 [(SA247-B005)]  
 AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
 AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29LV800DT@PSOP44 [(SA638)]  
 AM29LV800DT@TSOP48 [(SA247-B005)]  
 AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]  
 AM29N163DT@FBGA47 [(SA733A-B206A-M056F001N)]  
 AM29N323DT@FBGA47 [(SA733A-B206A-M056F001N)]  
 AM29N643GT@FBGA44 [(SA733A-B206A-M056F001Y)]  
 AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]  
 AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]  
 AM29PL160CB@PSOP44 [(SA638-B006)]  
 AM29PL160CB@TSOP48 [(SA247-B005)]  
 AM29PL160CT@PSOP44 [(SA638-B006)]  
 AM29PL160CT@TSOP48 [(SA247-B005)]  
 AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29SL160CB@TSOP48 [(SA247-B005)]  
 AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]  
 AM29SL160CT@TSOP48 [(SA247-B005)]  
 AM29SL400CB@TSOP48 [(SA247-B005)]  
 AM29SL400CT@TSOP48 [(SA247-B005)]  
 AM29SL800BB@TSOP48 [(SA247-B005)]  
 AM29SL800BT@TSOP48 [(SA247-B005)]  
 AM29SL800CB@TSOP48 [(SA247-B005)]  
 AM29SL800CT@TSOP48 [(SA247-B005)]  
 AM29SL800DB@TSOP48 [(SA247-B005)]  
 AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]  
 AM29SL800DT@TSOP48 [(SA247-B005)]  
 AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DTV@FBGA48 [(SA716A-B119B-M048F001Y)]  
 AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
 AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]  
 DS42514 (AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]  
 DS42515 (AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]  
 DS42516 (AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42546 (AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]  
 DS42553 (AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42585 (AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42587 (AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]  
 DS42629 (AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]  
 DS42677 (AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
 DS42678 (AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
 DS42689 (AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
 DS42690 (AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
 DS42695 (AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
 DS42696 (AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
 DS42701 (AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
 DS42725 (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
 DS42772A (AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
 M420000070 (AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
 M420000077 (AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
 M490000030 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M490000031 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M4900000K (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M4900000L (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]

MB84VD21082@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21082EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21083@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21083EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21084@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21084EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21091@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21091EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21092@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21092EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21093@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21093EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21094@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21094EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21183DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21183EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21183EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21184DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21184EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21184EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21191DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21191EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21191EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21192DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21192EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21192EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21193DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21193EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21193EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21194DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21194EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21194EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD22180FA@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22180FM@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22181A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22181EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22181EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22181FM@FBGA56 [ (SA642F-B032A-T064F001) ]  
MB84VD22182A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22182EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22182EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22183A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22183EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22183EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22184A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22184EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22184EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22184FM@FBGA56 [ (SA642E-B032A-T072F001) ]  
MB84VD22190FA@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22190FM@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22191A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22191EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22191EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22191FM@FBGA56 [ (SA642F-B032A-T064F001) ]  
MB84VD22192A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22192EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22192EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22193A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22193EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22193EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22194A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22194EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22194EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22194FM@FBGA56 [ (SA642E-B032A-T072F001) ]  
MB84VD22280FE@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22282EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22283EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22284EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22290FM@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22292EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22293EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22294EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22386EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22387EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22388EJ@FBGA71 [ (SA642F-B032A-T064F001) ]

MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]  
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]  
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161BD@TSOP48 [(SA247-B005)]  
MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@TSOP48 [(SA247-B005)]  
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@TSOP48 [(SA247-B005)]  
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BE@TSOP48 [(SA247-B005)]  
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TD@TSOP48 [(SA247-B005)]  
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TE@TSOP48 [(SA247-B005)]  
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BD@TSOP48 [(SA247-B005)]  
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BE@TSOP48 [(SA247-B005)]  
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TD@TSOP48 [(SA247-B005)]  
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TE@TSOP48 [(SA247-B005)]  
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BD@TSOP48 [(SA247-B005)]  
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BE@TSOP48 [(SA247-B005)]  
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TD@TSOP48 [(SA247-B005)]  
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TE@TSOP48 [(SA247-B005)]  
MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320BF@TSOP48 [(SA247-B005)]  
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320TF@TSOP48 [(SA247-B005)]  
MBM29DL321BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL321BD@TSOP48 [(SA247-B005)]  
MBM29DL321BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL321TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL321TD@TSOP48 [(SA247-B005)]  
MBM29DL321TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL322BD@TSOP48 [(SA247-B005)]  
MBM29DL322BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322BE@TSOP48 [(SA247-B005)]  
MBM29DL322TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL322TD@TSOP48 [(SA247-B005)]  
MBM29DL322TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL322TE@TSOP48 [(SA247-B005)]  
MBM29DL323BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL323BD@TSOP48 [(SA247-B005)]  
MBM29DL323BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL323BE@TSOP48 [(SA247-B005)]  
MBM29DL323BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL323BF@TSOP48 [(SA247-B005)]  
MBM29DL323TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL323TD@TSOP48 [(SA247-B005)]  
MBM29DL323TE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL323TE@TSOP48 [(SA247-B005)]  
MBM29DL323TF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL323TF@TSOP48 [(SA247-B005)]  
MBM29DL324BD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL324BD@TSOP48 [(SA247-B005)]  
MBM29DL324BE@FBGA63 [(SA642B-B026A-Y072F001)]  
MBM29DL324BE@TSOP48 [(SA247-B005)]  
MBM29DL324TD@FBGA63 [(SA642E-B026A-T072N001)]  
MBM29DL324TD@TSOP48 [(SA247-B005)]

```

MBM29DL324TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324TE@TSOP48 [(SA247-B005)]
MBM29DL32BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32BF@TSOP48 [(SA247-B005)]
MBM29DL32TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32TF@TSOP48 [(SA247-B005)]
MBM29DL34BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34BF@TSOP48 [(SA247-B005)]
MBM29DL34TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34TF@TSOP48 [(SA247-B005)]
MBM29DL400BB@PSOP44 [(SA638-B006)]
MBM29DL400BB@TSOP48 [(SA247-B005)]
MBM29DL400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400BC@PSOP44 [(SA638)]
MBM29DL400BC@TSOP48 [(SA247-B005)]
MBM29DL400BT@PSOP44 [(SA638-B006)]
MBM29DL400BT@TSOP48 [(SA247-B005)]
MBM29DL400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400TC@PSOP44 [(SA638)]
MBM29DL400TC@TSOP48 [(SA247-B005)]
MBM29DL640E@FBGA63 [(SA642C-B026A-Y056F001)]
MBM29DL640E@TSOP48 [(SA247-B005)]
MBM29DL64DF@FBGA48 [(SA642F-B026A-T064F001)]
MBM29DL64DF@TSOP48 [(SA247-B005)]
MBM29DL800B@PSOP44 [(SA638-B006)]
MBM29DL800B@TSOP48 [(SA247-B005)]
MBM29DL800BA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800BA@TSOP48 [(SA247-B005)]
MBM29DL800BB@PSOP44 [(SA638-B006)]
MBM29DL800BB@TSOP48 [(SA247-B005)]
MBM29DL800BT@PSOP44 [(SA638-B006)]
MBM29DL800BT@TSOP48 [(SA247-B005)]
MBM29DL800T@PSOP44 [(SA638-B006)]
MBM29DL800T@TSOP48 [(SA247-B005)]
MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800TA@TSOP48 [(SA247-B005)]
MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163BE@TSOP48 [(SA247-B005)]
MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163TE@TSOP48 [(SA247-B005)]
MBM29F001B MBM29F001B@PLCC32 [(SA015A1T)]
MBM29F001B@TSOP32 [(SA410T)] MBM29F001T
MBM29F001T@PLCC32 [(SA015A1T)] MBM29F001T@TSOP32 [(SA410T)]
MBM29F002B MBM29F002B@PLCC32 [(SA015A1T)]
MBM29F002B@TSOP32 [(SA410T)] MBM29F002NB
MBM29F002NB@PLCC32 [(SA015A1T)] MBM29F002NB@TSOP32 [(SA410T)]
MBM29F002NT MBM29F002NT@PLCC32 [(SA015A1T)]
MBM29F002NT@TSOP32 [(SA410T)] MBM29F002T
MBM29F002T@PLCC32 [(SA015A1T)] MBM29F002T@TSOP32 [(SA410T)]
MBM29F010 MBM29F010@PLCC32 [(SA015A1T)]
MBM29F010@TSOP32 [(SA410T)] MBM29F010A
MBM29F010A@PLCC32 [(SA015A1T)] MBM29F010A@TSOP32 [(SA410T)]
MBM29F016@PSOP44 [(SA638)] MBM29F016@TSOP40 [(SA409T)]
MBM29F016@TSOP48 [(SA247-B005)] MBM29F016A@PSOP44 [(SA638)]
MBM29F016A@TSOP40 [(SA409T)] MBM29F016A@TSOP48 [(SA247-B005)]
MBM29F016B@PSOP44 [(SA638)] MBM29F016B@TSOP40 [(SA409T)]
MBM29F016B@TSOP48 [(SA247-B005)] MBM29F017B@TSOP48 [(SA247-B005)]
MBM29F017D@TSOP40 [(SA409T)] MBM29F017D@TSOP48 [(SA247-B005)]
MBM29F032B@PSOP44 [(SA638)] MBM29F032B@TSOP40 [(SA409T)]
MBM29F033C@TSOP40 [(SA409T)] MBM29F040
MBM29F040@PLCC32 [(SA015A1T)] MBM29F040@TSOP32 [(SA410T)]
MBM29F040B MBM29F040B@PLCC32 [(SA015A1T)]
MBM29F040B@TSOP32 [(SA410T)] MBM29F040C@PLCC32 [(SA015A1T)]
MBM29F040C@TSOP32 [(SA410T)] MBM29F080@PSOP44 [(SA638)]
MBM29F080@TSOP40 [(SA409T)] MBM29F080A@TSOP48 [(SA247-B005)]
MBM29F080B@PSOP44 [(SA638)] MBM29F080B@TSOP40 [(SA409T)]
MBM29F100B@PSOP44 [(SA638-B006)] MBM29F100B@TSOP48 [(SA247-B005)]
MBM29F100T@PSOP44 [(SA638-B006)] MBM29F100T@TSOP48 [(SA247-B005)]
MBM29F160BE@TSOP48 [(SA247-B005)]
MBM29F160TE@TSOP48 [(SA247-B005)]
MBM29F200AB@PSOP44 [(SA638-B006)]
MBM29F200AB@TSOP48 [(SA247-B005)]
MBM29F200AT@PSOP44 [(SA638-B006)]
MBM29F200AT@TSOP48 [(SA247-B005)]
MBM29F200B@PSOP44 [(SA638-B006)] MBM29F200B@TSOP48 [(SA247-B005)]
MBM29F200T@PSOP44 [(SA638-B006)] MBM29F200T@TSOP48 [(SA247-B005)]
MBM29F400AB@PSOP44 [(SA638-B006)]
MBM29F400AB@TSOP48 [(SA247-B005)]
MBM29F400AT@PSOP44 [(SA638-B006)]
MBM29F400AT@TSOP48 [(SA247-B005)]
MBM29F400B@PSOP44 [(SA638-B006)] MBM29F400B@TSOP48 [(SA247-B005)]

```



```

MBM29F400BB@PSOP44 [(SA638-B006)]
MBM29F400BB@TSOP48 [(SA247-B005)]
MBM29F400BT@PSOP44 [(SA638-B006)]
MBM29F400BT@TSOP48 [(SA247-B005)]
MBM29F400T@PSOP44 [(SA638-B006)] MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)] MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BB@PSOP44 [(SA638-B006)]
MBM29F800BB@TSOP48 [(SA247-B005)]
MBM29F800BT@PSOP44 [(SA638-B006)]
MBM29F800BT@TSOP48 [(SA247-B005)]
MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]
MBM29LL800B@TSOP48 [(SA247-B005)]
MBM29LL800BB@TSOP48 [(SA247-B005)]
MBM29LL800BT@TSOP48 [(SA247-B005)]
MBM29LL800T@TSOP48 [(SA247-B005)]
MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001BB@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)] MBM29LV001T@TSOP32 [(SA410T)]
MBM29LV001TC@PLCC32 [(SA015A1T)] MBM29LV001TC@TSOP32 [(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)] MBM29LV002T@TSOP40 [(SA409T)]
MBM29LV004B@PSOP44 [(SA638)] MBM29LV004B@TSOP40 [(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)] MBM29LV004BT@TSOP40 [(SA409T)]
MBM29LV004T@PSOP44 [(SA638)] MBM29LV004T@TSOP40 [(SA409T)]
MBM29LV008B@PSOP44 [(SA638)] MBM29LV008B@TSOP40 [(SA409T)]
MBM29LV008BB@TSOP40 [(SA409T)] MBM29LV008BT@TSOP40 [(SA409T)]
MBM29LV008T@PSOP44 [(SA638)] MBM29LV008T@TSOP40 [(SA409T)]
MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40 [(SA409T)]
MBM29LV016B@TSOP40 [(SA409T)]
MBM29LV017@FBGA48 [(SA642B-B026A-T064F001)]
MBM29LV017@TSOP40 [(SA409T)] MBM29LV017B@TSOP40 [(SA409T)]
MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40 [(SA409T)]
MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40 [(SA409T)]
MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40 [(SA409T)]
MBM29LV160B@SON46 [(SA631)] MBM29LV160B@SON46(*)
MBM29LV160BB@PSOP44 [(SA638-B006)]
MBM29LV160BB@TSOP48 [(SA247-B005)]
MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160BE@TSOP48 [(SA247-B005)]
MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160BM@TSOP48 [(SA247-B005)]
MBM29LV160BT@PSOP44 [(SA638-B006)]
MBM29LV160BT@TSOP48 [(SA247-B005)]
MBM29LV160T@SON46 [(SA631)] MBM29LV160T@SON46(*)
MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TE@TSOP48 [(SA247-B005)]
MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TM@TSOP48 [(SA247-B005)]
MBM29LV200B@PSOP44 [(SA638-B006)]
MBM29LV200B@TSOP48 [(SA247-B005)]
MBM29LV200BB@PSOP44 [(SA638-B006)]
MBM29LV200BB@TSOP48 [(SA247-B005)]
MBM29LV200BC@PSOP44 [(SA638)]
MBM29LV200BC@TSOP48 [(SA247-B005)]
MBM29LV200BT@PSOP44 [(SA638-B006)]
MBM29LV200BT@TSOP48 [(SA247-B005)]
MBM29LV200T@PSOP44 [(SA638-B006)]
MBM29LV200T@TSOP48 [(SA247-B005)]
MBM29LV200TC@PSOP44 [(SA638)]
MBM29LV200TC@TSOP48 [(SA247-B005)]
MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320BE@TSOP48 [(SA247-B005)]
MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320TE@TSOP48 [(SA247-B005)]
MBM29LV400B@PSOP44 [(SA638-B006)]
MBM29LV400B@TSOP48 [(SA247-B005)]
MBM29LV400BB@PSOP44 [(SA638-B006)]
MBM29LV400BB@TSOP48 [(SA247-B005)]
MBM29LV400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400BC@PSOP44 [(SA638)]
MBM29LV400BC@TSOP48 [(SA247-B005)]
MBM29LV400BT@PSOP44 [(SA638-B006)]
MBM29LV400BT@TSOP48 [(SA247-B005)]
MBM29LV400T@PSOP44 [(SA638-B006)]
MBM29LV400T@TSOP48 [(SA247-B005)]
MBM29LV400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400TC@PSOP44 [(SA638)]
MBM29LV400TC@TSOP48 [(SA247-B005)]
MBM29LV650UE@TSOP48 [(SA247-B005)]
MBM29LV651UE@TSOP48 [(SA247-B005)]
MBM29LV652UE@FBGA63 [(SA642C-B026A-Y056F001)]

```

MBM29LV800B@PSOP44 [(SA638-B006)]  
 MBM29LV800B@SON46 [(SA631)] MBM29LV800B@SON46 (\*)  
 MBM29LV800B@TSOP48 [(SA247-B005)]  
 MBM29LV800BA@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800BA@PSOP44 [(SA638)]  
 MBM29LV800BA@TSOP48 [(SA247-B005)]  
 MBM29LV800BB@PSOP44 [(SA638-B006)]  
 MBM29LV800BB@TSOP48 [(SA247-B005)]  
 MBM29LV800BE@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800BE@PSOP44 [(SA638)]  
 MBM29LV800BE@TSOP48 [(SA247-B005)]  
 MBM29LV800BT@PSOP44 [(SA638-B006)]  
 MBM29LV800BT@TSOP48 [(SA247-B005)]  
 MBM29LV800T@PSOP44 [(SA638-B006)]  
 MBM29LV800T@SON46 [(SA631)] MBM29LV800T@SON46 (\*)  
 MBM29LV800T@TSOP48 [(SA247-B005)]  
 MBM29LV800TA@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800TA@PSOP44 [(SA638)]  
 MBM29LV800TA@TSOP48 [(SA247-B005)]  
 MBM29LV800TE@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV800TE@PSOP44 [(SA638)]  
 MBM29LV800TE@TSOP48 [(SA247-B005)]  
 MBM29PDS323B@FBGA63 [(SA642B-B026A-Y072F001)]  
 MBM29PDS323T@FBGA63 [(SA642B-B026A-Y072F001)]  
 MBM29PL12LM@TSOP56 [(SA628-B102)]  
 MBM29PL160BD@PSOP44 [(SA638)]  
 MBM29PL160BD@TSOP48 [(SA247-B005)]  
 MBM29PL160TD@PSOP44 [(SA638)]  
 MBM29PL160TD@TSOP48 [(SA247-B005)]  
 MBM29PL32BM@FBGA48 [(SA642G-B026A-T048F001)]  
 MBM29PL32BM@TSOP48 [(SA247-B005)]  
 MBM29PL32TM@FBGA48 [(SA642G-B026A-T048F001)]  
 MBM29PL32TM@TSOP48 [(SA247-B005)]  
 MBM29PL64LM@TSOP48 [(SA247-B005)]  
 MBM29PL64LM@TSOP56 [(SA628-B067)]  
 MBM29QM12DH@FBGA88 [(SA642J-B101A-W080F001)]  
 MBM29QM12DH@TSOP56 [(SA628-B097)]  
 MBM29SL160BD@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29SL160BD@TSOP48 [(SA247-B005)]  
 MBM29SL160TD@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29SL160TD@TSOP48 [(SA247-B005)]  
 MBM29SL800BB@TSOP48 [(SA247-B005)]  
 MBM29SL800BT@TSOP48 [(SA247-B005)]  
 PDL127H53V (AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL127H63V (AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL127H68V (AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL127H88V (AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H53V (AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H63V (AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H68V (AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H88V (AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PL032J55BAI12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J55BAI15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J55BAW12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J55BAW15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J55BFI12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J55BFI15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J55BFW12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J55BFW15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J60BAI12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J60BAI15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J60BAW12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J60BAW15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J60BFI12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J60BFI15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J60BFW12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J60BFW15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J70BAI12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J70BAI15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J70BAW12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J70BAW15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J70BFI12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J70BFI15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL032J70BFW12 (S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL032J70BFW15 (S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL064J55BAI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL064J55BAI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL064J55BAW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL064J55BAW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 PL064J55BFI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 PL064J55BFI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]

```

PL064J55BFW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J55BFW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BAI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BAI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BAW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BAW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BFI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BFI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BFW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BFW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BAI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BAI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BAW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BAW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BFI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BFI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BFW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BFW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL127J55BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J55BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J55BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J55BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
S19MN02GP30TFP00@TSOP48 [(SA247-B005)]
S19MN256P30TFP00@TSOP48 [(SA247-B005)]
S19MN512P30TFP00@TSOP48 [(SA247-B005)]
S25FL001D@SOIC8 [(SA602A)] S25FL001D@USON8 [(SA683)]
S25FL002A@SOIC8 [(SA605A)] S25FL002A@USON8 [(SA683)]
S25FL002D@SOIC8 [(SA602A)] S25FL002D@USON8 [(SA683)]
S25FL004A@SOIC8 [(SA605A)] S25FL004A@USON8 [(SA683)]
S25FL004D@SOIC8 [(SA602A)] S25FL004D@USON8 [(SA683)]
S25FL008A@SOIC8 [(SA605A)] S25FL008A@USON8 [(SA683)]
S25FL008D@SOIC8 [(SA602A)] S25FL008D@USON8 [(SA683)]
S25FL016A@SOIC16 [(SA404)]
S25FL016A@SOIC16(ISP) [ISP-HEADER01]
S25FL016A@SOIC8 [(SA605A)]
S25FL016A@SOIC8(ISP) [ISP-HEADER01]
S25FL016A@WSON8 [(SA684)]
S25FL016A@WSON8(ISP) [ISP-HEADER01]
S25FL016P@BGA24 [(SA778)] S25FL016P@SOIC16 [(SA404)]
S25FL016P@SOIC8 [(SA605A)] S25FL016P@WSON8 [(SA684)]
S25FL020A@SOIC8(4.0) [(SA602A)] S25FL020A@SOIC8(5.4) [(SA605A)]
S25FL020A@USON8 [(SA683)] S25FL032A@SOIC16 [(SA404)]
S25FL032A@SOIC16(ISP) [ISP-HEADER01]
S25FL032A@WSON8 [(SA684)]
S25FL032A@WSON8(ISP) [ISP-HEADER01]

```

S25FL032P@BGA24 [(SA778)] S25FL032P@WSON8 [(SA684)]  
 S25FL03PA@SOIC16 [(SA404)]  
 S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 S25FL040A(Bottom Boot)@USON8 [(SA683)]  
 S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]  
 S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]  
 S25FL040A(Top Boot)@USON8 [(SA683)]  
 S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4) [(SA605A)]  
 S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16 [(SA404)]  
 S25FL064A@SOIC16(ISP) [ISP-HEADER01]  
 S25FL064A@WSON8 [(SA684)]  
 S25FL064A@WSON8(ISP) [ISP-HEADER01]  
 S25FL064P@BGA24 [(SA778)] S25FL064P@SOIC16 [(SA404)]  
 S25FL064P@WSON8 [(SA684)] S25FL080A@SOIC8(4.0) [(SA602A)]  
 S25FL080A@SOIC8(5.4) [(SA605A)] S25FL080A@USON8 [(SA683)]  
 S25FL128P(256 KB)@SOIC16 [(SA404)]  
 S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]  
 S25FL128P(256 KB)@WSON8 [(SA684)]  
 S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]  
 S25FL128P(64 KB)@SOIC16 [(SA404)]  
 S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]  
 S25FL128P(64 KB)@WSON8 [(SA684)]  
 S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]  
 S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8 [(SA683)]  
 S29AD016DBFA01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFA02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFB01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFB02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFV01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFV02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DMFA01@PSOP44 [(SA638)] S29AD016DMFA02@PSOP44 [(SA638)]  
 S29AD016DMFB01@PSOP44 [(SA638)] S29AD016DMFB02@PSOP44 [(SA638)]  
 S29AD016DMFI01@PSOP44 [(SA638)] S29AD016DMFI02@PSOP44 [(SA638)]  
 S29AD016DMFV01@PSOP44 [(SA638)] S29AD016DMFV02@PSOP44 [(SA638)]  
 S29AD016DTFA01@TSOP48 [(SA247-B005)]  
 S29AD016DTFA02@TSOP48 [(SA247-B005)]  
 S29AD016DTFB01@TSOP48 [(SA247-B005)]  
 S29AD016DTFB02@TSOP48 [(SA247-B005)]  
 S29AD016DTFI01@TSOP48 [(SA247-B005)]  
 S29AD016DTFI02@TSOP48 [(SA247-B005)]  
 S29AD016DTFV01@TSOP48 [(SA247-B005)]  
 S29AD016DTFV02@TSOP48 [(SA247-B005)]  
 S29AL002BBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL002BBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL002BBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL002BBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL002BMAI01@PSOP44 [(SA638)] S29AL002BMAI02@PSOP44 [(SA638)]  
 S29AL002BMFI01@PSOP44 [(SA638)] S29AL002BMFI02@PSOP44 [(SA638)]  
 S29AL002BTAI01@TSOP48 [(SA247-B005)]  
 S29AL002BTAI02@TSOP48 [(SA247-B005)]  
 S29AL002BTFI01@TSOP48 [(SA247-B005)]  
 S29AL002BTFI02@TSOP48 [(SA247-B005)]  
 S29AL004BBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004BBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004BBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004BBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004BMAI01@PSOP44 [(SA638)] S29AL004BMAI02@PSOP44 [(SA638)]  
 S29AL004BMFI01@PSOP44 [(SA638)] S29AL004BMFI02@PSOP44 [(SA638)]  
 S29AL004BTAI01@TSOP48 [(SA247-B005)]  
 S29AL004BTAI02@TSOP48 [(SA247-B005)]  
 S29AL004BTFI01@TSOP48 [(SA247-B005)]  
 S29AL004BTFI02@TSOP48 [(SA247-B005)]  
 S29AL004DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBANR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBANR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL004DMAI01@PSOP44 [(SA638)] S29AL004DMAI02@PSOP44 [(SA638)]  
 S29AL004DMAN01@PSOP44 [(SA638)] S29AL004DMAN02@PSOP44 [(SA638)]  
 S29AL004DMANR1@PSOP44 [(SA638)] S29AL004DMANR2@PSOP44 [(SA638)]  
 S29AL004DMFI01@PSOP44 [(SA638)] S29AL004DMFI02@PSOP44 [(SA638)]

S29AL004DMFN01@PSOP44 [(SA638)] S29AL004DMFN02@PSOP44 [(SA638)]  
 S29AL004DMFNR1@PSOP44 [(SA638)] S29AL004DMFNR2@PSOP44 [(SA638)]  
 S29AL004DTAI01@TSOP48 [(SA247-B005)]  
 S29AL004DTAI02@TSOP48 [(SA247-B005)]  
 S29AL004DTAN01@TSOP48 [(SA247-B005)]  
 S29AL004DTAN02@TSOP48 [(SA247-B005)]  
 S29AL004DTANR1@TSOP48 [(SA247-B005)]  
 S29AL004DTANR2@TSOP48 [(SA247-B005)]  
 S29AL004DTFI01@TSOP48 [(SA247-B005)]  
 S29AL004DTFI02@TSOP48 [(SA247-B005)]  
 S29AL004DTFN01@TSOP48 [(SA247-B005)]  
 S29AL004DTFN02@TSOP48 [(SA247-B005)]  
 S29AL004DTFNR1@TSOP48 [(SA247-B005)]  
 S29AL004DTFNR2@TSOP48 [(SA247-B005)]  
 S29AL008DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBANR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBANR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008DMAI01@PSOP44 [(SA638)] S29AL008DMAI02@PSOP44 [(SA638)]  
 S29AL008DMAN01@PSOP44 [(SA638)] S29AL008DMAN02@PSOP44 [(SA638)]  
 S29AL008DMANR1@PSOP44 [(SA638)] S29AL008DMANR2@PSOP44 [(SA638)]  
 S29AL008DMFI01@PSOP44 [(SA638)] S29AL008DMFI02@PSOP44 [(SA638)]  
 S29AL008DMFN01@PSOP44 [(SA638)] S29AL008DMFN02@PSOP44 [(SA638)]  
 S29AL008DMFNR1@PSOP44 [(SA638)] S29AL008DMFNR2@PSOP44 [(SA638)]  
 S29AL008DTAI01@TSOP48 [(SA247-B005)]  
 S29AL008DTAI02@TSOP48 [(SA247-B005)]  
 S29AL008DTAN01@TSOP48 [(SA247-B005)]  
 S29AL008DTAN02@TSOP48 [(SA247-B005)]  
 S29AL008DTANR1@TSOP48 [(SA247-B005)]  
 S29AL008DTANR2@TSOP48 [(SA247-B005)]  
 S29AL008DTFI01@TSOP48 [(SA247-B005)]  
 S29AL008DTFI02@TSOP48 [(SA247-B005)]  
 S29AL008DTFN01@TSOP48 [(SA247-B005)]  
 S29AL008DTFN02@TSOP48 [(SA247-B005)]  
 S29AL008DTFNR1@TSOP48 [(SA247-B005)]  
 S29AL008DTFNR2@TSOP48 [(SA247-B005)]  
 S29AL008JBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL008JTFI01@TSOP48 [(SA247-B005)]  
 S29AL008JTFI02@TSOP48 [(SA247-B005)]  
 S29AL008JTFI03@TSOP48 [(SA247-B005)]  
 S29AL008JTFI04@TSOP48 [(SA247-B005)]  
 S29AL008JTFFI01@TSOP48 [(SA247-B005)]  
 S29AL008JTFFI02@TSOP48 [(SA247-B005)]  
 S29AL008JTFFI03@TSOP48 [(SA247-B005)]  
 S29AL008JTFFI04@TSOP48 [(SA247-B005)]  
 S29AL008JTFFIR1@TSOP48 [(SA247-B005)]  
 S29AL008JTFFIR2@TSOP48 [(SA247-B005)]  
 S29AL008JTFFNR1@TSOP48 [(SA247-B005)]  
 S29AL008JTFFNR2@TSOP48 [(SA247-B005)]  
 S29AL016DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AL016DMAI01@PSOP44 [(SA638)] S29AL016DMAI02@PSOP44 [(SA638)]  
 S29AL016DMAN01@PSOP44 [(SA638)] S29AL016DMAN02@PSOP44 [(SA638)]  
 S29AL016DMFI01@PSOP44 [(SA638)] S29AL016DMFI02@PSOP44 [(SA638)]  
 S29AL016DMFN01@PSOP44 [(SA638)] S29AL016DMFN02@PSOP44 [(SA638)]  
 S29AL016DTAI01@TSOP48 [(SA247-B005)]  
 S29AL016DTAI02@TSOP48 [(SA247-B005)]  
 S29AL016DTAN01@TSOP48 [(SA247-B005)]  
 S29AL016DTAN02@TSOP48 [(SA247-B005)]  
 S29AL016DTFI01@TSOP48 [(SA247-B005)]

S29AL016DTFI02@TSOP48 [(SA247-B005)]  
S29AL016DTFN01@TSOP48 [(SA247-B005)]  
S29AL016DTFN02@TSOP48 [(SA247-B005)]  
S29AL016JBF101@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBF102@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBF103@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBF104@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBF1R1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBF1R2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AL016JTFI01@TSOP48 [(SA247-B005)]  
S29AL016JTFI02(new)@TSOP48 [(SA247-B005)]  
S29AL016JTFI02@TSOP48 [(SA247-B005)]  
S29AL016JTFI03@TSOP48 [(SA247-B005)]  
S29AL016JTFI04@TSOP48 [(SA247-B005)]  
S29AL016JTF1R1@TSOP48 [(SA247-B005)]  
S29AL016JTF1R2@TSOP48 [(SA247-B005)]  
S29AL016JTFN01@TSOP48 [(SA247-B005)]  
S29AL016JTFN02@TSOP48 [(SA247-B005)]  
S29AL016JTFNR1@TSOP48 [(SA247-B005)]  
S29AL016JTFNR2@TSOP48 [(SA247-B005)]  
S29AL016MBAI01@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBAI02@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBAIR1@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBAIR2@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBFI01@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBFI02@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBF1R1@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MBF1R2@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29AL016MFAI01@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFAI02@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFFI01@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFFI02@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFF1R1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MFF1R2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29AL016MTAI01@TSOP48 [(SA247-B005)]  
S29AL016MTAI02@TSOP48 [(SA247-B005)]  
S29AL016MTAIR1@TSOP48 [(SA247-B005)]  
S29AL016MTAIR2@TSOP48 [(SA247-B005)]  
S29AL016MTFI01@TSOP48 [(SA247-B005)]  
S29AL016MTFI02@TSOP48 [(SA247-B005)]  
S29AL016MTF1R1@TSOP48 [(SA247-B005)]  
S29AL016MTF1R2@TSOP48 [(SA247-B005)]  
S29AL032DBAI00@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBAI03@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBAI04@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBFI00@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBFI03@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DBFI04@FBGA48 [(SA642Y-B026A-W048F001N)]  
S29AL032DTAI00@TSOP40 [(SA409T)]  
S29AL032DTAI03@TSOP48 [(SA247-B005)]  
S29AL032DTAI04@TSOP48 [(SA247-B005)]  
S29AL032DTFI00@TSOP40 [(SA409T)]  
S29AL032DTFI03@TSOP48 [(SA247-B005)]  
S29AL032DTFI04@TSOP48 [(SA247-B005)]  
S29GL016ABAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABAIW1@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016ABAIW2@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016ABFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABF1R1@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABF1R2@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABF1R3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABF1R4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL016ABFIW1@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016ABFIW2@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL016AFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL016AFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL016ATAI01@TSOP48 [(SA247-B005)]  
S29GL016ATAI02@TSOP48 [(SA247-B005)]  
S29GL016ATAI03@TSOP48 [(SA247-B005)]  
S29GL016ATAI04@TSOP48 [(SA247-B005)]  
S29GL016ATAIR1@TSOP48 [(SA247-B005)]  
S29GL016ATAIR2@TSOP48 [(SA247-B005)]  
S29GL016ATAIR3@TSOP48 [(SA247-B005)]  
S29GL016ATAIR4@TSOP48 [(SA247-B005)]  
S29GL016ATFI01@TSOP48 [(SA247-B005)]  
S29GL016ATFI02@TSOP48 [(SA247-B005)]  
S29GL016ATFI03@TSOP48 [(SA247-B005)]  
S29GL016ATFI04@TSOP48 [(SA247-B005)]  
S29GL016ATFIR1@TSOP48 [(SA247-B005)]  
S29GL016ATFIR2@TSOP48 [(SA247-B005)]  
S29GL016ATFIR3@TSOP48 [(SA247-B005)]  
S29GL016ATFIR4@TSOP48 [(SA247-B005)]  
S29GL032ABAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABAIR4(Normal)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABAIW3@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032ABAIW4@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032ABFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032ABFIW3@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032ABFIW4@FBGA56 [(SA642P-B032A-W056F001Y)]  
S29GL032AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIS2(29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032AFAIS4(29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIS2(29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032AFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032AFFIS4(29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032ATAIR1@TSOP56 [(SA628-B102)]  
S29GL032ATAIR2@TSOP56 [(SA628-B102)]  
S29GL032ATAIR3@TSOP48 [(SA247-B005)]  
S29GL032ATAIR4@TSOP48 [(SA247-B005)]  
S29GL032ATFIR1@TSOP56 [(SA628-B102)]  
S29GL032ATFIR2@TSOP56 [(SA628-B102)]  
S29GL032ATFIR3@TSOP48 [(SA247-B005)]  
S29GL032ATFIR4(Normal)@TSOP48 [(SA247-B005)]  
S29GL032ATFIR4@TSOP48 [(SA247-B005)]  
S29GL032MBACR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBACR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBACR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4@FBGA48 [(SA642G-B026A-T048F001Y)]

S29GL032MBFIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MFACR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFACS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MTACR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTACR0@TSOP40 [(SA409T)]  
S29GL032MTACR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR1@TSOP56 [(SA628-B067)]  
S29GL032MTACR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR2@TSOP56 [(SA628-B067)]  
S29GL032MTACR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR3@TSOP48 [(SA247-B005)]  
S29GL032MTACR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR4@TSOP48 [(SA247-B005)]  
S29GL032MTAIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTAIR0@TSOP40 [(SA409T)]  
S29GL032MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR1@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2@TSOP56 [(SA628-B067)]  
S29GL032MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR3@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4@TSOP48 [(SA247-B005)]  
S29GL032MTFCR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFCR0@TSOP40 [(SA409T)]  
S29GL032MTFCR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR1@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2(Mirror)@TSOP56 [(SA628-B067)]



S29GL032MTFCR2@TSOP56 [(SA628-B067)]  
S29GL032MTFCR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR3@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4@TSOP48 [(SA247-B005)]  
S29GL032MTFIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFIR0@TSOP40 [(SA409T)]  
S29GL032MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR1@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2@TSOP56 [(SA628-B067)]  
S29GL032MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR3@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBF103@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBF104@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NTAI01@TSOP56 [(SA628-B102)]  
S29GL032NTAI02@TSOP56 [(SA628-B102)]  
S29GL032NTAI03@TSOP48 [(SA247-B005)]  
S29GL032NTAI04@TSOP48 [(SA247-B005)]  
S29GL032NTAIR1@TSOP56 [(SA628-B102)]  
S29GL032NTAIR2@TSOP56 [(SA628-B102)]  
S29GL032NTAIR3@TSOP48 [(SA247-B005)]  
S29GL032NTAIR4@TSOP48 [(SA247-B005)]  
S29GL032NTAIV1@TSOP56 [(SA628-B102)]  
S29GL032NTAIV2@TSOP56 [(SA628-B102)]  
S29GL032NTFI01@TSOP56 [(SA628-B102)]  
S29GL032NTFI02@TSOP56 [(SA628-B102)]  
S29GL032NTFI03@TSOP48 [(SA247-B005)]  
S29GL032NTFI04@TSOP48 [(SA247-B005)]  
S29GL032NTFIR1@TSOP56 [(SA628-B102)]  
S29GL032NTFIR2@TSOP56 [(SA628-B102)]  
S29GL032NTFIR3@TSOP48 [(SA247-B005)]  
S29GL032NTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NTFIV1@TSOP56 [(SA628-B102)]  
S29GL032NTFIV2@TSOP56 [(SA628-B102)]  
S29GL064ABAIR3@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABAIR4@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABAIR5@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABFIR3@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABFIR4@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064ABFIR5@FBGA48 [(SA642B-B026A-Y072F001N)]  
S29GL064AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL064AFAIR5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIS2(29LV640MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064AFAIS4(29LV640MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIR5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIS2(29LV640MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064AFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064AFFIS4(29LV640MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064ATAIR1@TSOP56 [(SA628-B102)]  
S29GL064ATAIR2@TSOP56 [(SA628-B102)]  
S29GL064ATAIR3@TSOP48 [(SA247-B005)]  
S29GL064ATAIR4@TSOP48 [(SA247-B005)]  
S29GL064ATAIR6@TSOP48 [(SA247-B005)]  
S29GL064ATAIR7@TSOP48 [(SA247-B005)]  
S29GL064ATAIR8@TSOP48 [(SA247-B005)]  
S29GL064ATAIR9@TSOP48 [(SA247-B005)]  
S29GL064ATFIR1@TSOP56 [(SA628-B102)]  
S29GL064ATFIR2@TSOP56 [(SA628-B102)]  
S29GL064ATFIR3@TSOP48 [(SA247-B005)]  
S29GL064ATFIR4@TSOP48 [(SA247-B005)]  
S29GL064ATFIR6@TSOP48 [(SA247-B005)]  
S29GL064ATFIR7@TSOP48 [(SA247-B005)]  
S29GL064ATFIR8@TSOP48 [(SA247-B005)]  
S29GL064ATFIR9@TSOP48 [(SA247-B005)]  
S29GL064MBAIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR0@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR3@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFAIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(Normal)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MTAIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR0@TSOP48 [(SA247-B005)]  
S29GL064MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR1@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2@TSOP56 [(SA628-B067)]

S29GL064MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR3@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0@TSOP48 [(SA247-B005)]  
S29GL064MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR1@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2@TSOP56 [(SA628-B067)]  
S29GL064MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR3@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBF103@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBF104@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NTAI01@TSOP56 [(SA628-B102)]  
S29GL064NTAI02@TSOP56 [(SA628-B102)]  
S29GL064NTAI03@TSOP48 [(SA247-B005)]  
S29GL064NTAI04@TSOP48 [(SA247-B005)]  
S29GL064NTAI06@TSOP48 [(SA247-B005)]  
S29GL064NTAI07@TSOP48 [(SA247-B005)]  
S29GL064NTAIR1@TSOP56 [(SA628-B102)]  
S29GL064NTAIR2@TSOP56 [(SA628-B102)]  
S29GL064NTAIR3@TSOP48 [(SA247-B005)]  
S29GL064NTAIR4@TSOP48 [(SA247-B005)]  
S29GL064NTAIR6@TSOP48 [(SA247-B005)]  
S29GL064NTAIR7@TSOP48 [(SA247-B005)]  
S29GL064NTAIV1@TSOP56 [(SA628-B102)]  
S29GL064NTAIV2@TSOP56 [(SA628-B102)]  
S29GL064NTAIV6@TSOP48 [(SA247-B005)]  
S29GL064NTAIV7@TSOP48 [(SA247-B005)]  
S29GL064NTFI01@TSOP56 [(SA628-B102)]  
S29GL064NTFI02@TSOP56 [(SA628-B102)]  
S29GL064NTFI03@TSOP48 [(SA247-B005)]  
S29GL064NTFI04(Low)@TSOP48 [(SA247-B005)]  
S29GL064NTFI04@TSOP48 [(SA247-B005)]  
S29GL064NTFI06@TSOP48 [(SA247-B005)]  
S29GL064NTFI07@TSOP48 [(SA247-B005)]

S29GL064NTFIR1@TSOP56 [(SA628-B102)]  
S29GL064NTFIR2@TSOP56 [(SA628-B102)]  
S29GL064NTFIR3@TSOP48 [(SA247-B005)]  
S29GL064NTFIR4@TSOP48 [(SA247-B005)]  
S29GL064NTFIR6@TSOP48 [(SA247-B005)]  
S29GL064NTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NTFIV1@TSOP56 [(SA628-B102)]  
S29GL064NTFIV2@TSOP56 [(SA628-B102)]  
S29GL064NTFIV6@TSOP48 [(SA247-B005)]  
S29GL064NTFIV7@TSOP48 [(SA247-B005)]  
S29GL128MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL128MTAIR1@TSOP56 [(SA628-B067)]  
S29GL128MTAIR2@TSOP56 [(SA628-B067)]  
S29GL128MTFIR1@TSOP56 [(SA628-B067)]  
S29GL128MTFIR2@TSOP56 [(SA628-B067)]  
S29GL128NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAI1H@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAW01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAW02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFAWIH@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFI1H@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFW01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NFFW02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128NTAI01@TSOP56 [(SA628-B102)]  
S29GL128NTAI02@TSOP56 [(SA628-B102)]  
S29GL128NTAIR1@TSOP56 [(SA628-B102)]  
S29GL128NTAIR2@TSOP56 [(SA628-B102)]  
S29GL128NTAIV1@TSOP56 [(SA628-B102)]  
S29GL128NTAIV2@TSOP56 [(SA628-B102)]  
S29GL128NTAW01@TSOP56 [(SA628-B102)]  
S29GL128NTAW02@TSOP56 [(SA628-B102)]  
S29GL128NTFI01@TSOP56 [(SA628-B102)]  
S29GL128NTFI02@TSOP56 [(SA628-B102)]  
S29GL128NTFIR1@TSOP56 [(SA628-B102)]  
S29GL128NTFIR2@TSOP56 [(SA628-B102)]  
S29GL128NTFIV1@TSOP56 [(SA628-B102)]  
S29GL128NTFIV2@TSOP56 [(SA628-B102)]  
S29GL128NTFW01@TSOP56 [(SA628-B102)]  
S29GL128NTFW02@TSOP56 [(SA628-B102)]  
S29GL128PFACR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFACR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFAIS5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS6@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFASS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFASS7@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL128PFASS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFASS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFFCR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFCR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFFIS5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS6@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFSS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PFFSS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFSS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PFFSS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL128PTACR1@TSOP56 [(SA628-B102)]  
S29GL128PTACR2@TSOP56 [(SA628-B102)]  
S29GL128PTAI01@TSOP56 [(SA628-B102)]  
S29GL128PTAI02@TSOP56 [(SA628-B102)]  
S29GL128PTAIR1@TSOP56 [(SA628-B102)]  
S29GL128PTAIR2@TSOP56 [(SA628-B102)]  
S29GL128PTAIV1@TSOP56 [(SA628-B102)]  
S29GL128PTAIV2@TSOP56 [(SA628-B102)]  
S29GL128PTFCR1@TSOP56 [(SA628-B102)]  
S29GL128PTFCR2@TSOP56 [(SA628-B102)]  
S29GL128PTFI01@TSOP56 [(SA628-B102)]  
S29GL128PTFI02@TSOP56 [(SA628-B102)]  
S29GL128PTFIR1@TSOP56 [(SA628-B102)]  
S29GL128PTFIR2@TSOP56 [(SA628-B102)]  
S29GL128PTFIV1@TSOP56 [(SA628-B102)]  
S29GL128PTFIV2@TSOP56 [(SA628-B102)]  
S29GL256MR1@FBGA64 [(SA655C-B099A-W064F001Y)]  
S29GL256MR1@TSOP56 [(SA628-B067)]  
S29GL256MR2@FBGA64 [(SA655C-B099A-W064F001Y)]  
S29GL256MR2@TSOP56 [(SA628-B067)]  
S29GL256NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAI0H@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFI0H@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NTAI01@TSOP56 [(SA628-B102)]  
S29GL256NTAI02@TSOP56 [(SA628-B102)]  
S29GL256NTAIR1@TSOP56 [(SA628-B102)]  
S29GL256NTAIR2@TSOP56 [(SA628-B102)]  
S29GL256NTAIV1@TSOP56 [(SA628-B102)]  
S29GL256NTAIV2@TSOP56 [(SA628-B102)]  
S29GL256NTFI01@TSOP56 [(SA628-B102)]  
S29GL256NTFI02@TSOP56 [(SA628-B102)]  
S29GL256NTFIR1@TSOP56 [(SA628-B102)]  
S29GL256NTFIR2@TSOP56 [(SA628-B102)]  
S29GL256NTFIV1@TSOP56 [(SA628-B102)]  
S29GL256NTFIV2@TSOP56 [(SA628-B102)]  
S29GL256PFACR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFACR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL256PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFAIS5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS6@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFASS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFASS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFASS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFASS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFFCR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFCR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFFIS5@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS6@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFSS0@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFFSS7@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFSS8@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFSS9@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PTACR1@TSOP56 [(SA628-B102)]  
S29GL256PTACR2@TSOP56 [(SA628-B102)]  
S29GL256PTAI01@TSOP56 [(SA628-B102)]  
S29GL256PTAI02@TSOP56 [(SA628-B102)]  
S29GL256PTAIR1@TSOP56 [(SA628-B102)]  
S29GL256PTAIR2@TSOP56 [(SA628-B102)]  
S29GL256PTAIV1@TSOP56 [(SA628-B102)]  
S29GL256PTAIV2@TSOP56 [(SA628-B102)]  
S29GL256PTFCR1@TSOP56 [(SA628-B102)]  
S29GL256PTFCR2@TSOP56 [(SA628-B102)]  
S29GL256PTFI01@TSOP56 [(SA628-B102)]  
S29GL256PTFI02@TSOP56 [(SA628-B102)]  
S29GL256PTFIR1@TSOP56 [(SA628-B102)]  
S29GL256PTFIR2@TSOP56 [(SA628-B102)]  
S29GL256PTFIV1@TSOP56 [(SA628-B102)]  
S29GL256PTFIV2@TSOP56 [(SA628-B102)]  
S29GL512NFA01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFA02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFAV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFF01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFF02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NFFV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512NTA01@TSOP56 [(SA628-B102)]  
S29GL512NTA02@TSOP56 [(SA628-B102)]  
S29GL512NTAV1@TSOP56 [(SA628-B102)]  
S29GL512NTAV2@TSOP56 [(SA628-B102)]  
S29GL512NTF01@TSOP56 [(SA628-B102)]  
S29GL512NTF02@TSOP56 [(SA628-B102)]  
S29GL512NTFV1@TSOP56 [(SA628-B102)]  
S29GL512NTFV2@TSOP56 [(SA628-B102)]  
S29GL512PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFAIR1@FBGA64 [(SA655F-B287A-W064F001Y)]  
S29GL512PFAIR2@FBGA64 [(SA655F-B287A-W064F001Y)]

S29GL512PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFIR1@FBGA64 [(SA655F-B287A-W064F001Y)]  
S29GL512PFFIR2@FBGA64 [(SA655F-B287A-W064F001Y)]  
S29GL512PFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL512PTAI01@TSOP56 [(SA628-B102)]  
S29GL512PTAI02@TSOP56 [(SA628-B102)]  
S29GL512PTAIR1@TSOP56 [(SA628-B102)]  
S29GL512PTAIR2@TSOP56 [(SA628-B102)]  
S29GL512PTAIV1@TSOP56 [(SA628-B102)]  
S29GL512PTAIV2@TSOP56 [(SA628-B102)]  
S29GL512PTFI01@TSOP56 [(SA628-B102)]  
S29GL512PTFI02@TSOP56 [(SA628-B102)]  
S29GL512PTFIR1@TSOP56 [(SA628-B102)]  
S29GL512PTFIR2@TSOP56 [(SA628-B102)]  
S29GL512PTFIV1@TSOP56 [(SA628-B102)]  
S29GL512PTFIV2@TSOP56 [(SA628-B102)]  
S29JL032HBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI21@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI22@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI31@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI32@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI41@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBAI42@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF101@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF102@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF121@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF122@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF131@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF132@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF141@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HBF142@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29JL032HTAI01@TSOP48 [(SA247-B005)]  
S29JL032HTAI02@TSOP48 [(SA247-B005)]  
S29JL032HTAI21@TSOP48 [(SA247-B005)]  
S29JL032HTAI22@TSOP48 [(SA247-B005)]  
S29JL032HTAI31@TSOP48 [(SA247-B005)]  
S29JL032HTAI32@TSOP48 [(SA247-B005)]  
S29JL032HTAI41@TSOP48 [(SA247-B005)]  
S29JL032HTAI42@TSOP48 [(SA247-B005)]  
S29JL032HTFI01@TSOP48 [(SA247-B005)]  
S29JL032HTFI02@TSOP48 [(SA247-B005)]  
S29JL032HTFI21@TSOP48 [(SA247-B005)]  
S29JL032HTFI22@TSOP48 [(SA247-B005)]  
S29JL032HTFI31@TSOP48 [(SA247-B005)]  
S29JL032HTFI32@TSOP48 [(SA247-B005)]  
S29JL032HTFI41@TSOP48 [(SA247-B005)]  
S29JL032HTFI42@TSOP48 [(SA247-B005)]  
S29JL064HBAI00@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29JL064HBF100@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29JL064HTAI00@TSOP48 [(SA247-B005)]  
S29JL064HTAN00@TSOP48 [(SA247-B005)]  
S29JL064HTFI00@TSOP48 [(SA247-B005)]  
S29JL064HTFN00@TSOP48 [(SA247-B005)]  
S29NS016J0LBFW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS016J0LBJW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS016J0PBFW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS016J0PB JW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS032J0LBFW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS032J0LBJW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS032J0PBFW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS032J0PB JW00@FBGA44 [(SA733B-B206A-M044F001Y)]  
S29NS064J0LBAW00@FBGA44 [(SA733A-B206A-M056F001Y)]  
S29NS064J0LBFW00@FBGA44 [(SA733A-B206A-M056F001Y)]  
S29NS064J0LBJW00@FBGA44 [(SA733A-B206A-M056F001Y)]  
S29NS064J0PBAW00@FBGA44 [(SA733A-B206A-M056F001Y)]  
S29NS064J0PBFW00@FBGA44 [(SA733A-B206A-M056F001Y)]  
S29NS064J0PB JW00@FBGA44 [(SA733A-B206A-M056F001Y)]  
S29NS128J0LBAW00@FBGA48 [(SA733A-B206A-M056F001N)]  
S29NS128J0LBFW00@FBGA48 [(SA733A-B206A-M056F001N)]  
S29NS128J0LBJW00@FBGA48 [(SA733A-B206A-M056F001N)]  
S29NS128J0PBAW00@FBGA48 [(SA733A-B206A-M056F001N)]  
S29NS128J0PBFW00@FBGA48 [(SA733A-B206A-M056F001N)]  
S29NS128J0PB JW00@FBGA48 [(SA733A-B206A-M056F001N)]  
S29PL127J55TAI13@TSOP56 [(SA628-B097)]

S29PL127J55TAW13@TSOP56 [(SA628-B097)]  
S29PL127J55TFI13@TSOP56 [(SA628-B097)]  
S29PL127J55TFW13@TSOP56 [(SA628-B097)]  
S29PL127J60TAI13@TSOP56 [(SA628-B097)]  
S29PL127J60TAW13@TSOP56 [(SA628-B097)]  
S29PL127J60TFI13@TSOP56 [(SA628-B097)]  
S29PL127J60TFW13@TSOP56 [(SA628-B097)]  
S29PL127J70TAI13@TSOP56 [(SA628-B097)]  
S29PL127J70TAW13@TSOP56 [(SA628-B097)]  
S29PL127J70TFI13@TSOP56 [(SA628-B097)]  
S29PL127J70TFW13@TSOP56 [(SA628-B097)]  
S29VS016K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS016K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS016KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS016KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS032KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]  
S29VS064KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]  
S29WS064J0PBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBF100@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBF101@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0PBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFI00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFI01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J0SBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]  
S29WS064J1LABAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS064J1LABAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS064J1LABAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS064J1LABAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF100@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF101@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF110@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBF111@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW10@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0PBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFI00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFI01@FBGA84 [(SA642A-B093A-Y096F001Y)]



S29WS128J0SBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J0SBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128J1ABAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0LBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS128N0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0LBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S29WS256N0SBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]  
S30ML01GP30TFE00@TSOP48 [(SA247-B005)]  
S30ML01GP30TFE50@TSOP48 [(SA247-B005)]  
S30ML01GP50TFE01@TSOP48 [(SA247-B005)]  
S30ML01GP50TFE51@TSOP48 [(SA247-B005)]  
S30ML02GP30TFE00@TSOP48 [(SA247-B005)]  
S30ML02GP30TFE50@TSOP48 [(SA247-B005)]  
S30ML02GP50TFE01@TSOP48 [(SA247-B005)]  
S30ML02GP50TFE51@TSOP48 [(SA247-B005)]  
S30ML128P30TFE00@TSOP48 [(SA247-B005)]  
S30ML128P30TFE50@TSOP48 [(SA247-B005)]  
S30ML128P50TFE01@TSOP48 [(SA247+B005)]  
S30ML128P50TFE51@TSOP48 [(SA247+B005)]  
S30ML256P30TFE00@TSOP48 [(SA247-B005)]  
S30ML256P30TFE50@TSOP48 [(SA247-B005)]  
S30ML256P50TFE01@TSOP48 [(SA247+B005)]  
S30ML256P50TFE51@TSOP48 [(SA247+B005)]  
S30ML512P50TFE01@TSOP48 [(SA247+B005)]  
S30ML512P50TFE51@TSOP48 [(SA247+B005)]  
S30MS01GP25TFW00@TSOP48 [(SA247-B005)]  
S30MS01GP25TFW010@TSOP48 [(SA247-B005)]  
S30MS01GP25TFW50@TSOP48 [(SA247-B005)]  
S30MS01GP25TFW510@TSOP48 [(SA247-B005)]  
S70PL254J00BAW91@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BAW93@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BAWA1@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL254J00BAWA3@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFW91@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFW93@FBGA64 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFWA1@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL254J00BFWA3@FBGA84 [(SA642A-B079A-Y096F001)]  
S70PL512N00HAW53@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S70PL512N00HFW53@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S71AL016D02BAWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D02BAWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D02BFWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D02BFWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BAWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BAWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BFWB@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71AL016D04BFWT@FBGA56 [(SA642P-B032A-W056F001Y)]  
S71GL016A40BAW1J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL016A40BAW3J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL016A40BFW1J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL016A40BFW3J@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A08BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A40BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032A80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]

S71GL032A80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032AA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032M40BAIBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAIFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAIKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAIPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BAWPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFIPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWBQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWFQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWKQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032M40BFWPQ@FBGA56 [(SA642B-B032A-Y072F001)]  
S71GL032N40BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N40BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N40BHW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N40BHW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N80BHW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032N80BHW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BHW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL032NA0BHW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A08BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A0ABFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064A80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064AA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NA0BHW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NA0BHW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NB0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NB0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71GL064NB0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]



S71GL256NBOBAWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWAJ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAK@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAN@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAP@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NBOBFWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NBOBFWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL256NCOBAEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAEAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAEAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFEAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFEAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFEAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFEAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFWAT@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFWAU@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFWAY@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL256NCOBFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]  
S71GL512NBOBAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEJ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEK@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEN@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEP@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWET@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEU@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEY@FBGA84 [(SA642A-B108A-Y096N001)]  
S71GL512NBOBFWEZ@FBGA84 [(SA642A-B108A-Y096N001)]  
S71JL064H80BAW01 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW02 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW03 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW04 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW10 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW11 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064H80BAW12 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW01 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW02 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW10 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW11 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW12 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HBOBAW00 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HBOBAW01 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HBOBAW02 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL128HBOBAW00 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HBOBAW01 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HBOBAW02 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HBOBAW03 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HCOBAW00 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HCOBAW01 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HCOBAW02 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HCOBAW03 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]



S71PL064J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0S@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0T@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0V@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0W@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0X@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0Y@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J08BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064J80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAIQB@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BAWQB@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFIQB@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL064JB0BFWQB@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BAI9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JA0BAW9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JA0BFI9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JA0BFW9P@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JA0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAI97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BAI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAIQB@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127JB0BAW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BAW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BAWQB@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127JB0BFI97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BFI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFIQB@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127JB0BFW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BFW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JB0BFWQB@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127JCOBAI97@FBGA64 [(SA642P-B079A-W056F001Y)]

S71PL127JC0BAI9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BAW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BAW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BF197@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BF19U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BF19Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BFW97@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BFW9B@FBGA64 [(SA642P-B079A-W056F001Y)]  
S71PL127JC0BFW9U@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127JC0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]  
S71PL127NBOHAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NBOHAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NBOHFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NBOHFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NBOHHW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NCOHAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NCOHAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NCOHFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL127NCOHFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JA0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JA0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BAW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BFW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129JC0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NBOHAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NBOHAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NBOHFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NBOHFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NCOHAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NCOHAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NCOHFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL129NCOHFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S71PL191HBOBAI10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HBOBAW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HBOBF110@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HBOBFW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HCOBAI10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HCOBAW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HCOBF110@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL191HCOBFW10@FBGA73 [(SA642A-B079A-Y096N001)]  
S71PL193HBOBAI10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HBOBAW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HBOBF110@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HBOBFW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HCOBAI10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HCOBAW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HCOBF110@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL193HCOBFW10@FBGA73 [(SA664J-B236A-M116F001Y)]  
S71PL254HCOBAW00@FBGA84 [(SA642A-B079A-Y096N001)]  
S71PL254JB0BAIT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BAITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BAWT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BAWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFIT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFWT7@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JB0BFWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAITZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BAWTZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFITU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFITZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFWTU@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JC0BFWTZ@FBGA84 [(SA642A-B079A-Y096F001)]  
S71PL254JD0BAWTB@FBGA84 [(SA642A-B079A-Y096F001Y)]  
S71PL254JD0BFWTB@FBGA84 [(SA642A-B079A-Y096F001Y)]

S71PL256NC0HAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256NC0HAW5U@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256NC0HFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256NC0HFW5U@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256ND0GAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256ND0GFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256ND0HAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL256ND0HFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]  
 S71PL258HCOBAW00@FBGA84 [(SA642A-B088A-Y096N001)]  
 S71PL512ND0JAW5B@FBGA84 [(SA642A-B139A-Y096F001Y)]  
 S71PL512ND0JFW5B@FBGA84 [(SA642A-B158A-Y096F001Y)]  
 S71VS032K80ZJK01@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032K80ZJK03@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032KA0ZJK09@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032KA0ZJK0B@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032KA0ZJK11@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032KA0ZJK13@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032KA0ZJK19@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS032KA0ZJK1B@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK01@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK03@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK09@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK0B@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK11@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK13@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK19@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71VS064KA0ZJK1B@BGA44 [(SA733D-B212A-M044F001Y)]  
 S71WS064JA0BAI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JA0BAI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JA0BAW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JA0BAW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JA0BFI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JA0BFI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JA0BFW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JA0BFW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JB0BAI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JB0BAI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JB0BAW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JB0BAW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JB0BFI2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JB0BFI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS064JB0BFW2A@FBGA80 [(SA642T-B134A-W080F001Y)]  
 S71WS064JB0BFW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]  
 S71WS128JA0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JA0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JA0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JA0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JA0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JA0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JA0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JA0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JB0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JB0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JB0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]  
 S71WS128JB0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JB0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JB0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
 S71WS128JB0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JB0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JB0BFIAAY@FBGA84 [(SA642A-B086A-Y096F001)]  
 S71WS128JB0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JB0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JB0BFWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
 S71WS128JCOBAE9A@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBAIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JCOBAIAY@FBGA84 [(SA642A-B086A-Y096F001)]  
 S71WS128JCOBAWA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JCOBAWAY@FBGA84 [(SA642A-B086A-Y096F001)]  
 S71WS128JCOBFE9A@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBFIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JCOBFIAAY@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JCOBFIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]  
 S71WS128JCOBFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]  
 S71WS128JCOBFWAY@FBGA84 [(SA642A-B086A-Y096F001)]







S71WS512NC0BFWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]  
 S71WS512NC0BFWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]  
 S71WS512ND0BAIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BAWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEW@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWE@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S71WS512ND0BFIEWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
 S75PL127JBD0BAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBD0BAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBD0BFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBD0BFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEB0BAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEB0BAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEB0BFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEB0BFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCD0BAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCD0BAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCD0BFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCD0BFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCE0BAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCE0BAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCE0BFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JCE0BFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S98NS032JA0FW001@FBGA88 [(SA642A-B180A-Y096F001Y)]  
 S98PL191JD0AQ001@FBGA115 [(SA664A-B160A-W115F001Y)]  
 S98PL191JD0FQ001@FBGA115 [(SA664A-B160A-W115F001Y)]  
 S98PL191JDF0AQ001(Nor)@FBGA115 [(SA664A-B160A-W115F001Y)]  
 S98PL191JDF0FQ001(Nor)@FBGA115 [(SA664A-B160A-W115F001Y)]  
 S98WS128NBO-001@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 S98WS256NEFFW001(Nor)@FBGA115 [(SA642A-B139A-Y096N001N)]  
 S98WS512N0GFW002(Nor)@FBGA115 [(SA664J-B165A-M116F001Y)]  
 S98WS512N0GFW003(Nor)@FBGA115 [(SA664J-B165A-M116F001Y)]  
 S99-50001(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
 S99-50003(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
 S99-50005(2\*S29WS128H)@FBGA88 [(SA642A-B123A-Y096F001Y)]  
 S99-50011(2\*S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
 S99-50019(S29GL128N)@FBGA88 [(SA642W-B199A-W088F001Y)]  
 S99-50031(AM29BDS320)@FBGA56 [(SA644B-B025B-Y056F001Y)]  
 S99-50034-9N(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
 S99-50034-9P(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
 S99-50034-9Y(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
 S99-50034-9Z(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
 S99-50048(S29GL064N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
 S99-50052(S29GL128N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
 S99-50057(S29GL032A)@FBGA88 [(SA642W-B116A-W088F001Y)]  
 S99-50059(S29GL064A)@FBGA88 [(SA642A-B116A-Y096N001N)]  
 S99-50063(High)@FBGA137 [(SA678A-B151A-Y129F001Y)]  
 S99-50063(Low)@FBGA137 [(SA678A-B150A-Y129F001Y)]  
 S99-50066(S29GL032M)@FBGA88 [(SA642A-B116A-Y096N001N)]  
 S99-50073(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 S99-50074(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
 S99-50076(S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
 S99-50080(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 S99-50080-LF(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
 S99-50085(S29WS256N)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 S99-50087(S29WS128J)@FBGA88 [(SA642A-B154A-Y096F001Y)]  
 S99-50089(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
 S99-50109(2\*S29WS256N)@FBGA88 [(SA642A-B138A-Y096F001Y)]

S99-50111(S29AL016DFFI02)@FBGA64 [(SA655F-B099A-W064F001Y)]  
 S99-50121-9Y@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 S99-50121-9Y-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 S99-50121-9Z@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 S99-50121-9Z-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 S99-50134(S29GL128N)@FBGA88 [(SA642R-B199A-T096F001Y)]  
 S99-50149-0(Nand)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 S99-50149-0(Nor)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 S99-50149-2(Nand)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 S99-50149-2(Nor)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 S99-50149-3(Nand)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 S99-50149-3(Nor)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 S99-50158(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
 S99-50158-LF(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
 S99-50183(S29GL256N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
 S99PL128JC0BAWFC0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
 S99PL128JC0BAWNB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
 S99PL128JC0BAWT10@FBGA84 [(SA642A-B062A-Y096F001Y)]  
 S99PL128JC0BAWUB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
 S99PL193JB0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JB0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JB0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JB0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JC0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JC0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JC0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99PL193JC0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
 S99WS256NC0BAWA3@FBGA84 [(SA642A-B139A-Y096F001Y)]  
 S99WS256NC0BAWA7@FBGA84 [(SA642A-B139A-Y096F001Y)]  
 S99WS256NC0BFWA3@FBGA84 [(SA642A-B139A-Y096F001Y)]  
 S99WS256NC0BFWA7@FBGA84 [(SA642A-B139A-Y096F001Y)]

## SPANSION-CUSTOMER

### E(E) PROM/FRAM/NVRAM

41F60(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 52H70(S29WS128J)@FBGA88 [(SA642A-B154A-Y096F001Y)]  
 S71PL129JB0BFW9U(ZX)@FBGA64 [(SA642A-B079A-Y096F001Y)]  
 S75PL127JBEBAWKB(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEBAWKU(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEBFWKB(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
 S75PL127JBEBFWKU(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]

## SSSC

### MICROCONTROLLER

SSU7301 SSU7301@PLCC44 [(SA244)]  
 SSU7301@TQFP44 [(SA245A)]

## SST

### E(E) PROM/FRAM/NVRAM

SST25LF010@SOIC8(4.0) [(SA602A)] SST25LF010@SOIC8(5.4) [(SA605B)]  
 SST25LF010@WSO8 [(SA683)]  
 SST25LF010A@SOIC8(4.0) [(SA602A)]  
 SST25LF010A@SOIC8(5.4) [(SA605B)]  
 SST25LF010A@WSO8 [(SA683)]  
 SST25LF016A@SOIC8(4.0) [(SA602A)]  
 SST25LF016A@SOIC8(5.4) [(SA605A)]  
 SST25LF016A@WSO8 [(SA683)]  
 SST25LF016B@SOIC8(4.0) [(SA602A)]  
 SST25LF016B@SOIC8(5.4) [(SA605A)]  
 SST25LF016B@WSO8 [(SA683)] SST25LF020@SOIC8(4.0) [(SA602A)]  
 SST25LF020@SOIC8(5.4) [(SA605B)] SST25LF020@WSO8 [(SA683)]  
 SST25LF020A@SOIC8(4.0) [(SA602A)]  
 SST25LF020A@SOIC8(5.4) [(SA605B)]  
 SST25LF020A@WSO8 [(SA683)] SST25LF040@SOIC8(4.0) [(SA602A)]  
 SST25LF040@SOIC8(5.4) [(SA605B)] SST25LF040@WSO8 [(SA683)]

SST25LF040A@SOIC8(4.0) [(SA602A)]  
 SST25LF040A@SOIC8(5.4) [(SA605B)]  
 SST25LF040A@WSON8 [(SA683)]  
 SST25LF080@SOIC8(5.4) [(SA605B)]  
 SST25LF080A@SOIC8(4.0) [(SA602A)]  
 SST25LF080A@SOIC8(5.4) [(SA605B)]  
 SST25LF080A@WSON8 [(SA683)]  
 SST25VF010@SOIC8(5.4) [(SA605B)]  
 SST25VF010A@SOIC8(4.0) [(SA602A)]  
 SST25VF010A@SOIC8(5.4) [(SA605B)]  
 SST25VF010A@WSON8 [(SA683)]  
 SST25VF016B@SOIC8(4.0) [(SA602A)]  
 SST25VF016B@SOIC8(5.4) [(SA605A)]  
 SST25VF016B@WSON8 [(SA683)]  
 SST25VF020@SOIC8(5.4) [(SA605B)]  
 SST25VF032B@SOIC8(4.0) [(SA602A)]  
 SST25VF032B@SOIC8(5.4) [(SA605A)]  
 SST25VF032B@WSON8 [(SA683)]  
 SST25VF040@SOIC8(5.4) [(SA605B)]  
 SST25VF040B@SOIC8(4.0) [(SA602A)]  
 SST25VF040B@SOIC8(5.4) [(SA605A)]  
 SST25VF040B@WSON8 [(SA683)]  
 SST25VF064C@WSON8 [(SA684)]  
 SST25VF080@SOIC8(5.4) [(SA605B)]  
 SST25VF080B@SOIC8(4.0) [(SA602A)]  
 SST25VF080B@SOIC8(5.4) [(SA605A)]  
 SST25VF080B@WSON8 [(SA683)]  
 SST25VF512@SOIC8(5.4) [(SA605B)]  
 SST25VF512A@SOIC8(4.0) [(SA602A)]  
 SST25VF512A@SOIC8(5.4) [(SA605B)]  
 SST25VF512A@WSON8 [(SA683)]  
 SST25WF020@SOIC8 [(SA602A)]  
 SST25WF080@SOIC8 [(SA602A)]  
 SST27SF010  
 SST27SF010@TSOP32 [(SA410T)]  
 SST27SF020@PLCC32 [(SA015A1T)]  
 SST27SF256  
 SST27SF256@VSOP32 [(SA620)]  
 SST27SF512@PLCC32 [(SA015A1T)]  
 SST27VF010  
 SST27VF010@TSOP32 [(SA410T)]  
 SST27VF020@PLCC32 [(SA015A1T)]  
 SST27VF040  
 SST27VF040@TSOP32 [(SA410T)]  
 SST27VF256@PLCC32 [(SA015A1T)]  
 SST27VF512  
 SST27VF512@VSOP32 [(SA620)]  
 SST28EE011@PLCC32 [(SA015A1T)]  
 SST28LE011  
 SST28LE011@TSOP32 [(SA410T)]  
 SST28LF040@PLCC32 [(SA015A1T)]  
 SST28SF040  
 SST28SF040@TSOP32 [(SA410T)]  
 SST28SF040A@PLCC32 [(SA015A1T)]  
 SST28VE011  
 SST28VE011@TSOP32 [(SA410T)]  
 SST28VF040@PLCC32 [(SA015A1T)]  
 SST28VF040A  
 SST28VF040A@TSOP32 [(SA410T)]  
 SST29EE010@PLCC32 [(SA015A1T)]  
 SST29EE020  
 SST29EE020@TSOP32 [(SA410T)]  
 SST29EE512@PLCC32 [(SA015A1T)]  
 SST29LE010  
 SST29LE010@TSOP32 [(SA410T)]  
 SST29LE020@PLCC32 [(SA015A1T)]  
 SST29LE512  
 SST29LE512@TSOP32 [(SA410T)]  
 SST29SF010@PLCC32 [(SA015A1T)]  
 SST29SF020  
 SST29SF020@VSOP32 [(SA620)]  
 SST29SF040@PLCC32 [(SA015A1T)]  
 SST29SF512  
 SST29SF512@VSOP32 [(SA620)]  
 SST29VE010@PLCC32 [(SA015A1T)]  
 SST29VE020  
 SST29VE020@TSOP32 [(SA410T)]  
 SST29VE512@PLCC32 [(SA015A1T)]  
 SST29VF010  
 SST29VF010@VSOP32 [(SA620)]  
 SST29VF020@PLCC32 [(SA015A1T)]  
 SST25LF080@SOIC8(4.0) [(SA602A)]  
 SST25LF080@WSON8 [(SA683)]  
 SST25VF010@SOIC8(4.0) [(SA602A)]  
 SST25VF010@WSON8 [(SA683)]  
 SST25VF020@SOIC8(4.0) [(SA602A)]  
 SST25VF020@WSON8 [(SA683)]  
 SST25VF040@SOIC8(4.0) [(SA602A)]  
 SST25VF040@WSON8 [(SA683)]  
 SST25VF064C@SOIC16 [(SA404)]  
 SST25VF080@SOIC8(4.0) [(SA602A)]  
 SST25VF080@WSON8 [(SA683)]  
 SST25VF512@SOIC8(4.0) [(SA602A)]  
 SST25VF512@WSON8 [(SA683)]  
 SST25WF010@SOIC8 [(SA602A)]  
 SST25WF040@SOIC8 [(SA602A)]  
 SST25WF512@SOIC8 [(SA602A)]  
 SST27SF010@PLCC32 [(SA015A1T)]  
 SST27SF020  
 SST27SF020@TSOP32 [(SA410T)]  
 SST27SF256@PLCC32 [(SA015A1T)]  
 SST27SF512  
 SST27SF512@VSOP32 [(SA620)]  
 SST27VF010@PLCC32 [(SA015A1T)]  
 SST27VF020  
 SST27VF020@TSOP32 [(SA410T)]  
 SST27VF040@PLCC32 [(SA015A1T)]  
 SST27VF256  
 SST27VF256@VSOP32 [(SA620)]  
 SST27VF512@PLCC32 [(SA015A1T)]  
 SST28EE011  
 SST28EE011@TSOP32 [(SA410T)]  
 SST28LE011@PLCC32 [(SA015A1T)]  
 SST28LF040  
 SST28LF040@TSOP32 [(SA410T)]  
 SST28SF040@PLCC32 [(SA015A1T)]  
 SST28SF040A  
 SST28SF040A@TSOP32 [(SA410T)]  
 SST28VE011@PLCC32 [(SA015A1T)]  
 SST28VF040  
 SST28VF040@TSOP32 [(SA410T)]  
 SST28VF040A@PLCC32 [(SA015A1T)]  
 SST29EE010  
 SST29EE010@TSOP32 [(SA410T)]  
 SST29EE020@PLCC32 [(SA015A1T)]  
 SST29EE512  
 SST29EE512@TSOP32 [(SA410T)]  
 SST29LE010@PLCC32 [(SA015A1T)]  
 SST29LE020  
 SST29LE020@TSOP32 [(SA410T)]  
 SST29LE512@PLCC32 [(SA015A1T)]  
 SST29SF010  
 SST29SF010@VSOP32 [(SA620)]  
 SST29SF020@PLCC32 [(SA015A1T)]  
 SST29SF040  
 SST29SF040@VSOP32 [(SA620)]  
 SST29SF512@PLCC32 [(SA015A1T)]  
 SST29VE010  
 SST29VE010@TSOP32 [(SA410T)]  
 SST29VE020@PLCC32 [(SA015A1T)]  
 SST29VE512  
 SST29VE512@TSOP32 [(SA410T)]  
 SST29VF010@PLCC32 [(SA015A1T)]  
 SST29VF020  
 SST29VF020@VSOP32 [(SA620)]

```

SST29VF040                                SST29VF040@PLCC32 [(SA015A1T)]
SST29VF040@VSOP32 [(SA620)]              SST29VF512
SST29VF512@PLCC32 [(SA015A1T)]           SST29VF512@VSOP32 [(SA620)]
SST31LF021@VSOP32 [(SA620)]              SST31LF041@VSOP40 [(SA623)]
SST31LF041A@VSOP32 [(SA620)]             SST31LF043@VSOP40 [(SA623)]
SST31LF043A@VSOP32 [(SA620)]
SST32HF162@LFBGA48 [(SA655E-B026A-T064F001)]
SST32HF162@LFBGA48(SST adapter)          SST32HF162@TSOP48 [(SA247-B005)]
SST32HF1621C@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF1621C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1622C@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF1622C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF164@LFBGA48 [(SA655E-B026A-T064F001)]
SST32HF164@LFBGA48(SST adapter)          SST32HF164@TSOP48 [(SA247-B005)]
SST32HF1641@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1641@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1641C@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1641C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1642@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1642@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1642C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1642C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1681@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF1681@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1682@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF1682@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF200@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF201@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF202@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF324@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF324@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF324@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF3241@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3241@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3241C@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3241C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3242@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3242@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3242C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3242C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3244C@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF324C@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF324C@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF324C@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF328@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF328@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF328@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF3281@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3281@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3281C@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3281C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3282@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3282@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3282C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3282C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3284@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF328C@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF328C@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF328C@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF32A1@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF32A1@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF32A4@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF400@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF401@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF402@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF64161@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF64161C@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF6481@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF6481C@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF6482@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF6482@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF6482C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF6482C@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64A1@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64A1@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64A2@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF64A2@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64A2@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64B1@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64B1@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64B2@FBGA63 [(SA642I-B032A-W080F001Y)]

```

SST32HF64B2@FBGA64 [(SA642R-B023A-T096F001Y)]  
 SST32HF800@LFBGA48 [(SA642B-B026A-Y072F001)]  
 SST32HF802@LBGA48 [(SA655E-B026A-T064F001)]  
 SST32HF802@LFBGA48 [(SA642B-B026A-Y072F001)]  
 SST32HF802@LFBGA48(SST adapter)  
 SST34HF1601B@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1601B@TSOP48 [(SA247-B005)]  
 SST34HF1601C@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1601C@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1602C@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1602C@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1621@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1621A@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1621A@LFBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF1621C@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1621C@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1621S@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1622@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1622C@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1622C@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1622S@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF162C@LBGA48 [(SA655E-B026A-T064F001)]  
 SST34HF162G@LBGA48 [(SA655E-B026A-T064F001)]  
 SST34HF162G@LFBGA48 [(SA642G-B026A-T048F001)]  
 SST34HF1641@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1641A@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1641A@LFBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF1641C@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1641C@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1641D@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1641D@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1641J@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1641J@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF1641S@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1642@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1642C@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1642C@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1642D@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1642D@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1642S@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF164C@LBGA48 [(SA655E-B026A-T064F001)]  
 SST34HF164G@LBGA48 [(SA655E-B026A-T064F001)]  
 SST34HF164G@LFBGA48 [(SA642G-B026A-T048F001)]  
 SST34HF1681@LFBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1681@LFBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF1681D@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1681D@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF1681J@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF1681J@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF1682D@FBGA56 [(SA642E-B032A-T072F001)]  
 SST34HF1682D@FBGA62 [(SA642E-B023A-T072F001)]  
 SST34HF3243C@FBGA56 [(SA642I-B032A-W080F001Y)]  
 SST34HF3243C@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF3244@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF3244@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF3244C@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF3244C@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF3282@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF3282@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF3283@FBGA56 [(SA642I-B032A-W080F001Y)]  
 SST34HF3283@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF3284@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF3284@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34HF32A4@FBGA56 [(SA642R-B032A-T096F001Y)]  
 SST34HF32A4@FBGA62 [(SA642R-B023A-T096F001Y)]  
 SST34WA1601@FBGA44 [(SA733D-B206A-M044F001Y)]  
 SST34WA1602@FBGA44 [(SA733D-B206A-M044F001Y)]  
 SST36VF1601(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF1601(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST36VF1601@TSOP48 [(SA247-B005)]  
 SST36VF1601C@FBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1601C@TSOP48 [(SA247-B005)]  
 SST36VF1601E@FBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1601E@TSOP48 [(SA247-B005)]  
 SST36VF1601G@LFBGA56 [(SA642A-B032A)]  
 SST36VF1601G@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1601G@TSOP48 [(SA247-B005)]  
 SST36VF1602(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF1602(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST36VF1602@TSOP48 [(SA247-B005)]  
 SST36VF1602C@FBGA48 [(SA642G-B026A-T048F001)]

SST36VF1602C@TSOP48 [(SA247-B005)]  
 SST36VF1602E@FBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1602E@TSOP48 [(SA247-B005)]  
 SST36VF1602G@LFBGA56 [(SA642A-B032A)]  
 SST36VF1602G@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1602G@TSOP48 [(SA247-B005)]  
 SST36VF3203@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF3203@TSOP48 [(SA247-B005)]  
 SST36VF3204@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF3204@TSOP48 [(SA247-B005)]  
 SST37VF010  
 SST37VF010@VSOP32 [(SA620)] SST37VF010@PLCC32 [(SA015A1T)]  
 SST37VF020@PLCC32 [(SA015A1T)] SST37VF020  
 SST37VF020@VSOP32 [(SA620)]  
 SST37VF040 SST37VF040@PLCC32 [(SA015A1T)]  
 SST37VF040@VSOP32 [(SA620)] SST37VF512  
 SST37VF512@PLCC32 [(SA015A1T)] SST37VF512@VSOP32 [(SA620)]  
 SST38VF6401@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST38VF6401@TSOP48 [(SA247-B005)]  
 SST38VF6402@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST38VF6402@TSOP48 [(SA247-B005)]  
 SST38VF6403@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST38VF6403@TSOP48 [(SA247-B005)]  
 SST38VF6404@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST38VF6404@TSOP48 [(SA247-B005)]  
 SST39LF010@PLCC32 [(SA015A1T)]  
 SST39LF010@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39LF010@VSOP32 [(SA620)]  
 SST39LF010@WFBGA48 [(SA716A-B120A-M048F001Y)]  
 SST39LF016@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF016@TSOP40 [(SA409T)] SST39LF020@PLCC32 [(SA015A1T)]  
 SST39LF020@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39LF020@VSOP32 [(SA620)]  
 SST39LF020@WFBGA48 [(SA716A-B120A-M048F001Y)]  
 SST39LF040@PLCC32 [(SA015A1T)] SST39LF040@VSOP32 [(SA620)]  
 SST39LF080@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF080@TSOP40 [(SA409T)] SST39LF080Q@TSOP40 [(SA409T)]  
 SST39LF100@FBGA48 [(SA642B-B026A-Y072F001)]  
 SST39LF100@VSOP40 [(SA623)]  
 SST39LF160@TFBGA48 [(SA642B-B026A-Y072F001)]  
 SST39LF160@TSOP48 [(SA247-B005)]  
 SST39LF200A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF200A@TSOP48 [(SA247-B005)]  
 SST39LF200A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39LF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF400A@TSOP48 [(SA247-B005)]  
 SST39LF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39LF512@PLCC32 [(SA015A1T)] SST39LF512@VSOP32 [(SA620)]  
 SST39LF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF800A@TSOP48 [(SA247-B005)]  
 SST39LF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39LH010 SST39LH010@PLCC32 [(SA015A1T)]  
 SST39LH010@TSOP32 [(SA410T)] SST39LH040  
 SST39LH040@PLCC32 [(SA015A1T)] SST39LH040@TSOP32 [(SA410T)]  
 SST39LH512 SST39LH512@PLCC32 [(SA015A1T)]  
 SST39LH512@TSOP32 [(SA410T)] SST39SF010  
 SST39SF010@PLCC32 [(SA015A1T)] SST39SF010@VSOP32 [(SA620)]  
 SST39SF010A SST39SF010A@PLCC32 [(SA015A1T)]  
 SST39SF010A@VSOP32 [(SA620)] SST39SF020  
 SST39SF020@PLCC32 [(SA015A1T)] SST39SF020@VSOP32 [(SA620)]  
 SST39SF020A SST39SF020A@PLCC32 [(SA015A1T)]  
 SST39SF020A@VSOP32 [(SA620)] SST39SF020P  
 SST39SF020P@PLCC32 [(SA015A1T)] SST39SF020P@VSOP32 [(SA620)]  
 SST39SF040 SST39SF040@PLCC32 [(SA015A1T)]  
 SST39SF040@VSOP32 [(SA620)] SST39SF040P  
 SST39SF040P@PLCC32 [(SA015A1T)] SST39SF040P@VSOP32 [(SA620)]  
 SST39SF512 SST39SF512@PLCC32 [(SA015A1T)]  
 SST39SF512@VSOP32 [(SA620)] SST39SF512A  
 SST39SF512A@PLCC32 [(SA015A1T)] SST39SF512A@VSOP32 [(SA620)]  
 SST39VF010 SST39VF010@PLCC32 [(SA015A1T)]  
 SST39VF010@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39VF010@VSOP32 [(SA620)]  
 SST39VF016@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF016@TSOP40 [(SA409T)] SST39VF016Q@TSOP40 [(SA409T)]  
 SST39VF020 SST39VF020@PLCC32 [(SA015A1T)]  
 SST39VF020@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39VF020@VSOP32 [(SA620)] SST39VF020P  
 SST39VF020P@PLCC32 [(SA015A1T)] SST39VF020P@VSOP32 [(SA620)]  
 SST39VF040 SST39VF040@PLCC32 [(SA015A1T)]  
 SST39VF040@VSOP32 [(SA620)] SST39VF040P  
 SST39VF040P@PLCC32 [(SA015A1T)] SST39VF040P@VSOP32 [(SA620)]  
 SST39VF080@FBGA48 [(SA642G-B026A-T048F001Y)]



SST39VF080@TSOP40 [(SA409T)] SST39VF080Q@TSOP40 [(SA409T)]  
 SST39VF088@TSOP48 [(SA247-B005)]  
 SST39VF100@FBGA48 [(SA642B-B026A-Y072F001)]  
 SST39VF100@VSOP40 [(SA623)]  
 SST39VF160@TFBGA48 [(SA642B-B026A-Y072F001)]  
 SST39VF160@TSOP48 [(SA247-B005)]  
 SST39VF1601@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF1601@TSOP48 [(SA247-B005)]  
 SST39VF1601C@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF1601C@TSOP48 [(SA247-B005)]  
 SST39VF1602@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF1602@TSOP48 [(SA247-B005)]  
 SST39VF1602C@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF1602C@TSOP48 [(SA247-B005)]  
 SST39VF160Q@TSOP48 [(SA247-B005)]  
 SST39VF1681@TFBGA48 [(SA642B-B026A-Y072F001)]  
 SST39VF1681@TSOP48 [(SA247-B005)]  
 SST39VF1682@TFBGA48 [(SA642B-B026A-Y072F001)]  
 SST39VF1682@TSOP48 [(SA247-B005)]  
 SST39VF200A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF200A@TSOP48 [(SA247-B005)]  
 SST39VF200A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39VF320@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39VF320@TSOP48 [(SA247-B005)]  
 SST39VF3201@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF3201@TSOP48 [(SA247-B005)]  
 SST39VF3201B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF3201B@TSOP48 [(SA247-B005)]  
 SST39VF3202@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF3202@TSOP48 [(SA247-B005)]  
 SST39VF3202B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF3202B@TSOP48 [(SA247-B005)]  
 SST39VF400@TSOP48 [(SA247-B005)]  
 SST39VF400A(Low)@TSOP48 [(SA247)]  
 SST39VF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF400A@TSOP48 [(SA247-B005)]  
 SST39VF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39VF400Q@TSOP48 [(SA247-B005)]  
 SST39VF512 SST39VF512@PLCC32 [(SA015A1T)]  
 SST39VF512@VSOP32 [(SA620)]  
 SST39VF6401@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6401@TSOP48 [(SA247-B005)]  
 SST39VF6401B@FBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6401B@TSOP48 [(SA247-B005)]  
 SST39VF6402@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6402@TSOP48 [(SA247-B005)]  
 SST39VF6402B@FBGA48 [(SA642R-B026A-T096F001Y)]  
 SST39VF6402B@TSOP48 [(SA247-B005)]  
 SST39VF800@TSOP48 [(SA247-B005)]  
 SST39VF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF800A@TSOP48 [(SA247)]  
 SST39VF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39VF800Q@TSOP48 [(SA247-B005)]  
 SST39WF1601@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF1601@WFBGA48 [(SA716C-B119A-T048F001Y)]  
 SST39WF1602@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF1602@WFBGA48 [(SA716C-B119A-T048F001Y)]  
 SST39WF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800A(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
 SST39WF800A(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF800B(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
 SST39WF800B(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800B@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST45LF010@SOIC8 [(SA602A)] SST45LF010@WSON8 [(SA683)]  
 SST45VF010@SOIC8 [(SA602A)] SST45VF020@SOIC8 [(SA602A)]  
 SST45VF512@SOIC8 [(SA602A)] SST49LF002@PLCC32 [(SA015A1T)]  
 SST49LF002@VSOP32 [(SA620)] SST49LF002A@PLCC32 [(SA015A1T)]  
 SST49LF002A@VSOP32 [(SA620)] SST49LF002B@PLCC32 [(SA015A1T)]  
 SST49LF003A@PLCC32 [(SA015A1T)] SST49LF003A@VSOP32 [(SA620)]  
 SST49LF003B@PLCC32 [(SA015A1T)] SST49LF004@PLCC32 [(SA015A1T)]  
 SST49LF004@VSOP32 [(SA620)] SST49LF004A@PLCC32 [(SA015A1T)]  
 SST49LF004A@VSOP32 [(SA620)] SST49LF004B@PLCC32 [(SA015A1T)]  
 SST49LF004B@VSOP32 [(SA620)] SST49LF004B@VSOP40 [(SA409T)]  
 SST49LF004C@PLCC32 [(SA015A1T)] SST49LF004C@VSOP32 [(SA620)]  
 SST49LF008@PLCC32 [(SA015A1T)] SST49LF008@VSOP32 [(SA620)]  
 SST49LF008A@PLCC32 [(SA015A1T)] SST49LF008A@TSOP40 [(SA409T)]  
 SST49LF008A@VSOP32 [(SA620)] SST49LF008C@PLCC32 [(SA015A1T)]  
 SST49LF008C@VSOP32 [(SA620)] SST49LF016C@PLCC32 [(SA015A1T)]  
 SST49LF016C@TSOP40 [(SA409T)] SST49LF016C@VSOP32 [(SA620)]

SST49LF020@PLCC32 [(SA015A1T)]	SST49LF020@VSOP32 [(SA620)]
SST49LF020A@PLCC32 [(SA015A1T)]	SST49LF020A@VSOP32 [(SA620)]
SST49LF030A@PLCC32 [(SA015A1T)]	SST49LF030A@VSOP32 [(SA620)]
SST49LF040@PLCC32 [(SA015A1T)]	SST49LF040@VSOP32 [(SA620)]
SST49LF040A@PLCC32 [(SA015A1T)]	SST49LF040A@VSOP32 [(SA620)]
SST49LF040B@PLCC32 [(SA015A1T)]	SST49LF040B@TSOP40 [(SA409T)]
SST49LF040B@VSOP32 [(SA620)]	SST49LF080A@PLCC32 [(SA015A1T)]
SST49LF080A@VSOP32 [(SA620)]	SST49LF160C@PLCC32 [(SA015A1T)]
SST49LF160C@TSOP32 [(SA620)]	

**MICROCONTROLLER**

SST65P542R@SOIC28 [(SA404)]	SST89C54
SST89C54@PLCC44 [(SA244)]	SST89C54@TQFP44 [(SA245A)]
SST89C58	SST89C58@PLCC44 [(SA244)]
SST89C58@TQFP44 [(SA245A)]	SST89C58RC@PLCC44 [(SA244)]
SST89C58RC@TQFP44 [(SA245A)]	SST89C58RC@WQFN40 [(SA750A)]
SST89E516RD	SST89E516RD@PLCC44 [(SA244)]
SST89E516RD@TQFP44 [(SA245A)]	SST89E516RD2
SST89E516RD2@PLCC44 [(SA244)]	SST89E516RD2@TQFP44 [(SA245A)]
SST89E52RC	SST89E52RC@PLCC44 [(SA244)]
SST89E52RC@TQFP44 [(SA245A)]	SST89E52RD
SST89E52RD@PLCC44 [(SA244)]	SST89E52RD@TQFP44 [(SA245A)]
SST89E52RD2	SST89E52RD2@PLCC44 [(SA244)]
SST89E52RD2@TQFP44 [(SA245A)]	SST89E54RC
SST89E54RC@PLCC44 [(SA244)]	SST89E54RC@TQFP44 [(SA245A)]
SST89E54RD	SST89E54RD@PLCC44 [(SA244)]
SST89E54RD@TQFP44 [(SA245A)]	SST89E54RD2
SST89E54RD2@PLCC44 [(SA244)]	SST89E54RD2@TQFP44 [(SA245A)]
SST89E554RC	SST89E554RC@PLCC44 [(SA244)]
SST89E554RC@TQFP44 [(SA245A)]	SST89E564RD
SST89E564RD@PLCC44 [(SA244)]	SST89E564RD@TQFP44 [(SA245A)]
SST89E58RD	SST89E58RD@PLCC44 [(SA244)]
SST89E58RD@TQFP44 [(SA245A)]	SST89E58RD2
SST89E58RD2@PLCC44 [(SA244)]	SST89E58RD2@TQFP44 [(SA245A)]
SST89V516RD	SST89V516RD@PLCC44 [(SA244)]
SST89V516RD@TQFP44 [(SA245A)]	SST89V516RD2
SST89V516RD2@PLCC44 [(SA244)]	SST89V516RD2@TQFP44 [(SA245A)]
SST89V52RD	SST89V52RD@PLCC44 [(SA244)]
SST89V52RD@TQFP44 [(SA245A)]	SST89V52RD2
SST89V52RD2@PLCC44 [(SA244)]	SST89V52RD2@TQFP44 [(SA245A)]
SST89V54RD2	SST89V54RD2@PLCC44 [(SA244)]
SST89V54RD2@TQFP44 [(SA245A)]	SST89V554RC
SST89V554RC@PLCC44 [(SA244)]	SST89V554RC@TQFP44 [(SA245A)]
SST89V564RD	SST89V564RD@PLCC44 [(SA244)]
SST89V564RD@TQFP44 [(SA245A)]	SST89V58RD2
SST89V58RD2@PLCC44 [(SA244)]	SST89V58RD2@TQFP44 [(SA245A)]

**ST****E(E) PROM/FRAM/NVRAM**

ET2716	ETC2716
ETC2732	M24128
M24128@MLP8 [(SA724)]	M24128@SOIC8 [(SA602A)]
M24128@TSOP8 [(SA026)]	M24164
M24164@SOIC8 [(SA602A)]	M24256
M24256@MLP8 [(SA724)]	M24256@TSOP8 [(SA026)]
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8 [(SA605A)]
M24512	M24512@SOIC8 [(SA605A)]
M24512@TSOP8 [(SA026)]	M24C01
M24C01@MLP8 [(SA724)]	M24C01@SOIC8 [(SA602A)]
M24C01R	M24C01R@MLP8 [(SA724)]
M24C01R@SOIC8 [(SA602A)]	M24C01R@TSOP8 [(SA026)]
M24C01W	M24C01W@MLP8 [(SA724)]
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8 [(SA026)]
M24C02	M24C02@MLP8 [(SA724)]
M24C02@SOIC8 [(SA602A)]	M24C02R
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8 [(SA602A)]
M24C02R@TSOP8 [(SA026)]	M24C02W
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8 [(SA602A)]
M24C02W@TSOP8 [(SA026)]	M24C04
M24C04@MLP8 [(SA724)]	M24C04@SOIC8 [(SA602A)]
M24C04R	M24C04R@MLP8 [(SA724)]
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8 [(SA026)]
M24C04W	M24C04W@MLP8 [(SA724)]

M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8 [(SA026)]
M24C08	M24C08@MLP8 [(SA724)]
M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8 [(SA602A)]
M24C08@TSOP8 [(SA026)]	M24C08R
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8 [(SA695A)]
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8 [(SA026)]
M24C08W	M24C08W@MLP8 [(SA724)]
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8 [(SA602A)]
M24C08W@TSOP8 [(SA026)]	M24C128(BN)
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8 [(SA602A)]
M24C128@MLP8 [(SA724)]	M24C128B(BN)
M24C128B(MN)@SOIC8 [(SA605A)]	M24C128B(MW)@SOIC8 [(SA602A)]
M24C128B@MLP8 [(SA724)]	M24C16
M24C16@MLP8 [(SA724)]	M24C16@SOIC8 [(SA602A)]
M24C16R	M24C16R@MLP8 [(SA724)]
M24C16R@SOIC8 [(SA602A)]	M24C16R@TSOP8 [(SA026)]
M24C16W	M24C16W@MLP8 [(SA724)]
M24C16W@SOIC8 [(SA602A)]	M24C16W@TSOP8 [(SA026)]
M24C256(BN)	M24C256(MN)@SOIC8 [(SA605A)]
M24C256(MW)@SOIC8 [(SA602A)]	M24C256@MLP8 [(SA724)]
M24C256A(BN)	M24C256A(MN)@SOIC8 [(SA605A)]
M24C256A(MW)@SOIC8 [(SA602A)]	M24C256A@MLP8 [(SA724)]
M24C256B(BN)	M24C256B(MN)@SOIC8 [(SA605A)]
M24C256B(MW)@SOIC8 [(SA602A)]	M24C256B@MLP8 [(SA724)]
M24C256W(BN)	M24C256W(MN)@SOIC8 [(SA605A)]
M24C256W(MW)@SOIC8 [(SA602A)]	M24C256W@MLP8 [(SA724)]
M24C32(BN)	M24C32(DL)@TSSOP14 [(SA026)]
M24C32(DW)@TSSOP8 [(SA602A)]	M24C32(MN)@SOIC8 [(SA605A)]
M24C32(MW)@SOIC8 [(SA602A)]	M24C32@MLP8 [(SA724)]
M24C32W(BN)	M24C32W(DL)@TSSOP14 [(SA026)]
M24C32W(DW)@TSSOP8 [(SA602A)]	M24C32W(MN)@SOIC8 [(SA605A)]
M24C32W(MW)@SOIC8 [(SA602A)]	M24C32W@MLP8 [(SA724)]
M24C64(BN)	M24C64(DL)@TSSOP14 [(SA026)]
M24C64(DW)@TSSOP8 [(SA602A)]	M24C64(MN)@SOIC8 [(SA605A)]
M24C64(MW)@SOIC8 [(SA602A)]	M24C64@MLP8 [(SA724)]
M24C64W(BN)	M24C64W(DL)@TSSOP14 [(SA026)]
M24C64W(DW)@TSSOP8 [(SA602A)]	M24C64W(MN)@SOIC8 [(SA605A)]
M24C64W(MW)@SOIC8 [(SA602A)]	M24C64W@MLP8 [(SA724)]
M24CL04B	M24CL04B@MLP8 [(SA724)]
M24CL04B@SOIC8 [(SA602A)]	M24CL04B@TSOP8 [(SA026)]
M24E16	M24E32(BN)
M24E32(DW)@TSSOP8 [(SA602A)]	M24E32(MN)@SOIC8 [(SA605A)]
M24E32(MW)@SOIC8 [(SA602A)]	M24M01@LGA8 [(SA684)]
M24M01@SOIC8 [(SA023A)]	M24W01
M24W01@SOIC8 [(SA602A)]	M24W02
M24W02@SOIC8 [(SA602A)]	M24W04
M24W04@SOIC8 [(SA602A)]	M24W08
M24W08@SOIC8 [(SA602A)]	M24W16
M24W16@SOIC8 [(SA602A)]	M25C01
M25C02	M25C04
M25C08	M25C16
M25E16	M25P05@SOIC8 [(SA602A)]
M25P05@VQFPN8 [(SA683)]	M25P05-A@SOIC8 [(SA602A)]
M25P05-A@TSSOP8 [(SA026)]	M25P05-A@VDFPN8 [(SA684)]
M25P10@SOIC8 [(SA602A)]	M25P10@VQFPN8 [(SA683)]
M25P10-A@SOIC8 [(SA602A)]	M25P10-A@VFQFPN8 [(SA684)]
M25P128@SOIC16 [(SA404)]	
M25P128@SOIC16(ISP) [ISP-HEADER01]	
M25P128@VDFPN8 [(SA684)]	
M25P128@VDFPN8(ISP) [ISP-HEADER01]	
M25P16@SOIC16 [(SA404)]	
M25P16@SOIC16(ISP) [ISP-HEADER01]	
M25P16@SOIC8(150mil) [(SA602A)]	
M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]	
M25P16@SOIC8(200mil) [(SA605A)]	
M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]	
M25P16@VDFPN8 [(SA684)]	
M25P16@VDFPN8(ISP) [ISP-HEADER01]	
M25P16@VFQFPN8 [(SA683)]	
M25P16@VFQFPN8(ISP) [ISP-HEADER01]	
M25P20@SOIC8 [(SA602A)]	M25P20@SOIC8(ISP) [ISP-HEADER01]
M25P20@VFQFPN8 [(SA683)]	
M25P20@VFQFPN8(ISP) [ISP-HEADER01]	
M25P32(Fast Mode)@SOIC16 [(SA404)]	
M25P32(Fast Mode)@VQFPN8 [(SA684)]	
M25P32@SOIC16 [(SA404)]	
M25P32@SOIC16(ISP) [ISP-HEADER01]	
M25P32@SOIC8 [(SA605A)]	M25P32@SOIC8(ISP) [ISP-HEADER01]
M25P32@VDFPN8 [(SA684)]	
M25P32@VDFPN8(ISP) [ISP-HEADER01]	
M25P32@VFQFPN8 [(SA683)]	

M25P32@VFQFPN8 (ISP) [ISP-HEADER01]	
M25P40@SOIC8 [(SA602A)]	M25P40@SOIC8 (ISP) [ISP-HEADER01]
M25P40@VFQFPN8 [(SA683)]	
M25P40@VFQFPN8 (ISP) [ISP-HEADER01]	
M25P64 (Fast Mode)@SOIC16 [(SA404)]	
M25P64 (Fast Mode)@VDFPN8 [(SA684)]	
M25P64@SOIC16 [(SA404)]	
M25P64@SOIC16 (ISP) [ISP-HEADER01]	
M25P64@VDFPN8 [(SA684)]	
M25P64@VDFPN8 (ISP) [ISP-HEADER01]	
M25P80@SOIC16 [(SA404)]	
M25P80@SOIC16 (ISP) [ISP-HEADER01]	
M25P80@SOIC8 [(SA605A)]	M25P80@SOIC8 (ISP) [ISP-HEADER01]
M25P80@VFQFPN8 [(SA683)]	
M25P80@VFQFPN8 (ISP) [ISP-HEADER01]	
M25PE10@SOIC8 [(SA602A)]	
M25PE10@SOIC8 (ISP) [ISP-HEADER01]	
M25PE10@VQFPN8 [(SA683)]	
M25PE10@VQFPN8 (ISP) [ISP-HEADER01]	
M25PE16@SOIC8 [(SA023A)]	M25PE16@VQFPN8 [(SA683)]
M25PE20@SOIC8 [(SA602A)]	
M25PE20@SOIC8 (ISP) [ISP-HEADER01]	
M25PE20@VQFPN8 [(SA683)]	
M25PE20@VQFPN8 (ISP) [ISP-HEADER01]	
M25PE40@SOIC8 [(SA023A)]	
M25PE40@SOIC8 (ISP) [ISP-HEADER01]	
M25PE40@VQFPN8 [(SA683)]	
M25PE40@VQFPN8 (ISP) [ISP-HEADER01]	
M25PE80@SOIC8 [(SA023A)]	
M25PE80@SOIC8 (ISP) [ISP-HEADER01]	
M25PE80@VQFPN8 [(SA683)]	
M25PE80@VQFPN8 (ISP) [ISP-HEADER01]	
M25PX32@SOIC16 [(SA404)]	M25PX32@SOIC8 [(SA023A)]
M25PX32@VFQFPN8 [(SA683)]	M25PX64@SOIC16 [(SA404)]
M25PX64@TBGA24 [(SA778)]	M25PX64@VDFPN8 [(SA684)]
M25W01	M25W02
M25W04	M25W08
M25W16	M25W166
M27128A	M2716
M2716F1	M27256
M27256A	M2732A
M27512	M2764
M2764A	M27C1000
M27C1000@PLCC32 [(SA015A1T)]	M27C1000@TSOP32 [(SA410T)]
M27C1001	M27C1001@PLCC32 [(SA015A1T)]
M27C1001@TSOP32 [(SA410T)]	M27C1024
M27C1024@PLCC44 [(SA244)]	M27C128B
M27C16	M27C160
M27C160@PLCC44 [(SA244)]	M27C160@PSOP44 [(SA638)]
M27C160K	M27C160K@PLCC44 [(SA244)]
M27C160K@PSOP44 [(SA638)]	M27C2001
M27C2001@PLCC32 [(SA015A1T)]	M27C2001@TSOP32 [(SA410T)]
M27C202	M27C202@PLCC44 [(SA244)]
M27C202@TSOP40 [(SA409T)]	M27C256B
M27C256B@PLCC32 [(SA015A1T)]	M27C32
M27C322	M27C322@SDIP42 [(SA028)]
M27C400	M27C4001
M27C4001@PLCC32 [(SA015A1T)]	M27C4001@TSOP32 [(SA410T)]
M27C4002	M27C4002@PLCC44 [(SA244)]
M27C405	M27C405@PLCC32 [(SA015A1T)]
M27C405@TSOP32 [(SA410T)]	M27C512
M27C512@PLCC32 [(SA015A1T)]	M27C513
M27C516	M27C516@PLCC44 [(SA244)]
M27C64A	M27C64A@PLCC32 [(SA015A1T)]
M27C800	M27C800@PLCC44 [(SA244)]
M27C800@PSOP44 [(SA638)]	M27C801
M27C801@PLCC32 [(SA015A1T)]	M27C801@TSOP32 [(SA410T)]
M27HC641	M27HC641@PLCC28 [(SA008A)]
M27HC642	M27HC642@PLCC28 [(SA008A)]
M27V101	M27V101@PLCC32 [(SA015A1T)]
M27V101@TSOP32 [(SA410T)]	M27V102
M27V102@PLCC44 [(SA244)]	M27V160
M27V160@PLCC44 [(SA244)]	M27V160@PSOP44 [(SA638)]
M27V160K	M27V160K@PLCC44 [(SA244)]
M27V160K@PSOP44 [(SA638)]	M27V201
M27V201@PLCC32 [(SA015A1T)]	M27V201@TSOP32 [(SA410T)]
M27V256	M27V322
M27V322@SDIP42 [(SA028)]	M27V401
M27V401@PLCC32 [(SA015A1T)]	M27V401@TSOP32 [(SA410T)]
M27V402	M27V402@PLCC44 [(SA244)]
M27V402@TSOP40 [(SA409T)]	M27V405

M27V405@PLCC32 [(SA015A1T)]	M27V405@TSOP32 [(SA410T)]
M27V512	M27V512@PLCC32 [(SA015A1T)]
M27V512@TSOP28 [(SA430T)]	M27V800
M27V800@PLCC44 [(SA244)]	M27V801
M27V801@PLCC32 [(SA015A1T)]	M27V801@TSOP32 [(SA410T)]
M27W016@PSOP44 [(SA638)]	M27W016@TSOP48 [(SA247-B005)]
M27W032@PSOP44 [(SA638)]	M27W032@TSOP48 [(SA247-B005)]
M27W064@PSOP44 [(SA638)]	M27W064@TSOP48 [(SA247-B005)]
M27W101	M27W101@PLCC32 [(SA015A1T)]
M27W101@TSOP32 [(SA410T)]	M27W102
M27W102@PLCC44 [(SA244)]	M27W160
M27W160@PLCC44 [(SA244)]	M27W160@PSOP44 [(SA638)]
M27W201	M27W201@PLCC32 [(SA015A1T)]
M27W201@TSOP32 [(SA410T)]	M27W202
M27W202@PLCC44 [(SA244)]	M27W202@TSOP40 [(SA409T)]
M27W400	M27W400@PLCC44 [(SA244)]
M27W401	M27W401@PLCC32 [(SA015A1T)]
M27W401@TSOP32 [(SA410T)]	M27W402
M27W402@PLCC44 [(SA244)]	M27W402@TSOP40 [(SA409T)]
M27W512	M27W512@PLCC32 [(SA015A1T)]
M27W512@TSOP28 [(SA430T)]	M27W800
M27W800@PLCC44 [(SA244)]	M27W801
M27W801@PLCC32 [(SA015A1T)]	M27W801@TSOP32 [(SA410T)]
M28010	M28010@PLCC32 [(SA015A1T)]
M28010@TSOP32 [(SA410T)]	M28010R
M28010R@PLCC32 [(SA015A1T)]	M28010R@TSOP32 [(SA410T)]
M28010W	M28010W@PLCC32 [(SA015A1T)]
M28010W@TSOP32 [(SA410T)]	M28256
M28256@PLCC32 [(SA015A1T)]	M28256@TSOP28 [(SA430T)]
M28C010	M28C010@PLCC32 [(SA015A1T)]
M28C010@TSOP32 [(SA410T)]	M28C010R
M28C010R@PLCC32 [(SA015A1T)]	M28C010R@TSOP32 [(SA410T)]
M28C010W	M28C010W@PLCC32 [(SA015A1T)]
M28C010W@TSOP32 [(SA410T)]	M28C010W@PLCC32 [(SA015A1T)]
M28C17@SOIC28 [(SA404)]	M28C16@PLCC32 [(SA015A1T)]
M28C64@PLCC32 [(SA015A1T)]	M28C64
M28C64C	M28C64@TSOP28 [(SA430T)]
M28C64C@SOIC28 [(SA404)]	M28C64C@PLCC32 [(SA015A1T)]
M28C64X	M28C64C@TSOP28 [(SA430T)]
M28C64X@TSOP28 [(SA430T)]	M28C64X@PLCC32 [(SA015A1T)]
M28F101@PLCC32 [(SA015A1T)]	M28F101
M28F102	M28F101@TSOP32 [(SA410T)]
M28F102@TSOP40 [(SA409T)]	M28F102@PLCC44 [(SA244)]
M28F151@PLCC32 [(SA015A1T)]	M28F151
M28F201	M28F151@TSOP32 [(SA410T)]
M28F201@TSOP32 [(SA410T)]	M28F201@PLCC32 [(SA015A1T)]
M28F220@PSOP44 [(SA638)]	M28F211@TSOP40 [(SA409T)]
M28F221@TSOP40 [(SA409T)]	M28F220@TSOP48 [(SA247-B005)]
M28F256@PLCC32 [(SA015A1T)]	M28F256
M28F411@TSOP40 [(SA409T)]	M28F256@TSOP32 [(SA410T)]
M28F512	M28F421@TSOP40 [(SA409T)]
M28F512@TSOP32 [(SA410T)]	M28F512@PLCC32 [(SA015A1T)]
M28LV64@PLCC32 [(SA015A1T)]	M28LV64
M28R400CB@FBGA48 [(SA634A-B005A-Y048F001)]	M28LV64@TSOP28 [(SA430T)]
M28R400CT@FBGA48 [(SA634A-B005A-Y048F001)]	
M28V411@TSOP40 [(SA409T)]	M28V421@TSOP40 [(SA409T)]
M28W160B@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W160B@TSOP48 [(SA247-B005)]	
M28W160BB@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W160BB@TSOP48 [(SA247-B005)]	
M28W160BT@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W160BT@TSOP48 [(SA247-B005)]	
M28W160CB@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W160CB@TSOP48 [(SA247-B005)]	
M28W160CT@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W160CT@TSOP48 [(SA247-B005)]	
M28W160ECB@FBGA48 [(SA634A-B005A-Y048F001Y)]	
M28W160ECB@TSOP48 [(SA247-B005)]	
M28W160ECT@FBGA48 [(SA634A-B005A-Y048F001Y)]	
M28W160ECT@TSOP48 [(SA247-B005)]	
M28W160ESB@FBGA64 [(SA655E-B090A-T064F001Y)]	
M28W160EST@FBGA64 [(SA655E-B090A-T064F001Y)]	
M28W160FSB@FBGA64 [(SA655E-B090A-T064F001Y)]	
M28W160FST@FBGA64 [(SA655E-B090A-T064F001Y)]	
M28W160T@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W160T@TSOP48 [(SA247-B005)]	
M28W320CB@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W320CB@TSOP48 [(SA247-B005)]	
M28W320CT@FBGA48 [(SA634A-B005A-Y048F001)]	
M28W320CT@TSOP48 [(SA247-B005)]	
M28W320ECB@FBGA48 [(SA634A-B005A-Y048F001)]	

M28W320ECB@TSOP48 [(SA247-B005)]  
M28W320ECT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W320ECT@TSOP48 [(SA247-B005)]  
M28W320FCB@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W320FCB@TSOP48 [(SA247-B005)]  
M28W320FCT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W320FCT@TSOP48 [(SA247-B005)]  
M28W320FSB@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320FSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320FST@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320FST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320FSU(Double)@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320FSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HSB@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320HSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HST@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320HST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HSU(Double)@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W320HSU@FBGA47 [(SA714B-B026A-T048F001Y)]  
M28W320HSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640ECB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W640ECB@TSOP48 [(SA247-B005)]  
M28W640ECT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W640ECT@TSOP48 [(SA247-B005)]  
M28W640FCB@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W640FCB@TSOP48 [(SA247-B005)]  
M28W640FCT@FBGA48 [(SA634A-B005A-Y048F001Y)]  
M28W640FCT@TSOP48 [(SA247-B005)]  
M28W640FSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640FST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640FSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640HSB@FBGA48 [(SA714B-B026A-T048F001Y)]  
M28W640HSB@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640HST@FBGA48 [(SA714B-B026A-T048F001Y)]  
M28W640HST@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W640HSU@FBGA48 [(SA714B-B026A-T048F001Y)]  
M28W640HSU@FBGA64 [(SA655E-B090A-T064F001Y)]  
M28W800B@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800B@TSOP48 [(SA247-B005)]  
M28W800BB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800BB@TSOP48 [(SA247-B005)]  
M28W800BT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800BT@TSOP48 [(SA247-B005)]  
M28W800CB@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800CB@TSOP48 [(SA247-B005)]  
M28W800CT@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800CT@TSOP48 [(SA247-B005)]  
M28W800T@FBGA48 [(SA634A-B005A-Y048F001)]  
M28W800T@TSOP48 [(SA247-B005)]  
M29DW127G@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29DW127G@TSOP56 [(SA628-B102)]  
M29DW128F@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29DW128F@TSOP56 [(SA628-B102)]  
M29DW323DB@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW323DB@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW323DB@TSOP48 [(SA247-B005)]  
M29DW323DT@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW323DT@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW323DT@TSOP48 [(SA247-B005)]  
M29DW324DB@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW324DB@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW324DB@TSOP48 [(SA247-B005)]  
M29DW324DT@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW324DT@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW324DT@TSOP48 [(SA247-B005)]  
M29DW640D@FBGA63 [(SA642E-B026A-T072F001N)]  
M29DW640D@TSOP48 [(SA247-B005)]  
M29DW640F@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29DW640F@TSOP48 [(SA247-B005)]  
M29DW641F@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29DW641F@TSOP48 [(SA247-B005)] M29F002B  
M29F002B@PLCC32 [(SA015A1T)] M29F002B@TSOP32 [(SA410T)]  
M29F002BB M29F002BB@PLCC32 [(SA015A1T)]  
M29F002BB@TSOP32 [(SA410T)] M29F002BNT  
M29F002BNT@PLCC32 [(SA015A1T)] M29F002BNT@TSOP32 [(SA410T)]  
M29F002BT M29F002BT@PLCC32 [(SA015A1T)]  
M29F002BT@TSOP32 [(SA410T)] M29F002T  
M29F002T@PLCC32 [(SA015A1T)] M29F002T@TSOP32 [(SA410T)]  
M29F010B M29F010B@PLCC32 [(SA015A1T)]  
M29F010B@TSOP32 [(SA410T)] M29F016B@PSOP44 [(SA638)]  
M29F016B@TSOP40 [(SA409T)] M29F016D@PSOP44 [(SA638)]

M29F016D@TSOP40 [(SA409T)]	M29F032D@TSOP40 [(SA409T)]
M29F040	M29F040@PLCC32 [(SA015A1T)]
M29F040@TSOP32 [(SA410T)]	M29F040B
M29F040B@PLCC32 [(SA015A1T)]	M29F040B@TSOP32 [(SA410T)]
M29F080A@PSOP44 [(SA638)]	M29F080A@TSOP40 [(SA409T)]
M29F080D@PSOP44 [(SA638)]	M29F080D@TSOP40 [(SA409T)]
M29F100B@PSOP44 [(SA638-B006)]	M29F100B@TSOP48 [(SA247-B005)]
M29F100T@PSOP44 [(SA638-B006)]	M29F100T@TSOP48 [(SA247-B005)]
M29F102B@PLCC44 [(SA244)]	M29F102B@TSOP40 [(SA623)]
M29F102BB@PLCC44 [(SA244)]	M29F102BB@TSOP40 [(SA623)]
M29F160BB@TSOP48 [(SA247-B005)]	M29F160BT@TSOP48 [(SA247-B005)]
M29F200B@PSOP44 [(SA638-B006)]	M29F200B@TSOP48 [(SA247-B005)]
M29F200BB@PSOP44 [(SA638-B006)]	M29F200BB@TSOP48 [(SA247-B005)]
M29F200BT@PSOP44 [(SA638-B006)]	M29F200BT@TSOP48 [(SA247-B005)]
M29F200T@PSOP44 [(SA638-B006)]	M29F200T@TSOP48 [(SA247-B005)]
M29F400B@PSOP44 [(SA638-B006)]	M29F400B@TSOP48 [(SA247-B005)]
M29F400BB@PSOP44 [(SA638-B006)]	M29F400BB@TSOP48 [(SA247-B005)]
M29F400BT@PSOP44 [(SA638-B006)]	M29F400BT@TSOP48 [(SA247-B005)]
M29F400T@PSOP44 [(SA638-B006)]	M29F400T@TSOP48 [(SA247-B005)]
M29F512B@PLCC32 [(SA015A1T)]	M29F512B@TSOP32 [(SA620)]
M29F800AB@PSOP44 [(SA638-B006)]	M29F800AB@TSOP48 [(SA247-B005)]
M29F800AT@PSOP44 [(SA638-B006)]	M29F800AT@TSOP48 [(SA247-B005)]
M29F800DB@PSOP44 [(SA638)]	M29F800DB@TSOP48 [(SA247-B005)]
M29F800DT@PSOP44 [(SA638)]	M29F800DT@TSOP48 [(SA247-B005)]
M29KW016E@PSOP44 [(SA638)]	
M29KW016E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW016E@TSOP48 [(SA247-B005)]	
M29KW032E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW032E@TSOP48 [(SA247-B005)]	
M29KW064E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW064E@TSOP48 [(SA247-B005)]	M29V040@PLCC32 [(SA015A1T)]
M29V040@TSOP32 [(SA410T)]	M29W004B@TSOP40 [(SA409T)]
M29W004BB@TSOP40 [(SA409T)]	M29W004BT@TSOP40 [(SA409T)]
M29W004T@TSOP40 [(SA409T)]	M29W008AB@TSOP40 [(SA409T)]
M29W008AT@TSOP40 [(SA409T)]	M29W008B@TSOP40 [(SA409T)]
M29W008T@TSOP40 [(SA409T)]	M29W010B@PLCC32 [(SA015A1T)]
M29W010B@TSOP32 [(SA410T)]	
M29W017D@TFBGA48 [(SA642B-B026A-Y072F001)]	
M29W017D@TSOP40 [(SA409T)]	M29W022BB
M29W022BB@PLCC32 [(SA015A1T)]	M29W022BB@TSOP32 [(SA410T)]
M29W022BT	M29W022BT@PLCC32 [(SA015A1T)]
M29W022BT@TSOP32 [(SA410T)]	M29W040@PLCC32 [(SA015A1T)]
M29W040@TSOP32 [(SA410T)]	M29W040B@PLCC32 [(SA015A1T)]
M29W040B@TSOP32 [(SA410T)]	M29W102BB@TSOP40 [(SA623)]
M29W102BT@TSOP40 [(SA623)]	M29W116BB@TSOP40 [(SA409T)]
M29W116BT@TSOP40 [(SA409T)]	
M29W128FH@FBGA64 [(SA655E-B099A-T064F001Y)]	
M29W128FH@TSOP56 [(SA628-B102)]	
M29W128FL@FBGA64 [(SA655E-B099A-T064F001Y)]	
M29W128FL@TSOP56 [(SA628-B102)]	
M29W128GH@FBGA64 [(SA655E-B099A-T064F001Y)]	
M29W128GH@TSOP56 [(SA628-B102)]	
M29W128GL@FBGA64 [(SA655E-B099A-T064F001Y)]	
M29W128GL@TSOP56 [(SA628-B102)]	
M29W128GSH@FBGA64 [(SA655E-B099A-T064F001Y)]	
M29W128GSH@TSOP56 [(SA628-B102)]	
M29W128GSL@FBGA64 [(SA655E-B099A-T064F001Y)]	
M29W128GSL@TSOP56 [(SA628-B102)]	
M29W160BB@LBGA48 [(SA642G-B026A-T048F001Y)]	
M29W160BB@PSOP44 [(SA638)]	M29W160BB@TSOP48 [(SA247-B005)]
M29W160BT@LBGA48 [(SA642G-B026A-T048F001Y)]	
M29W160BT@PSOP44 [(SA638)]	M29W160BT@TSOP48 [(SA247-B005)]
M29W160DB@LBGA48 [(SA642G-B026A-T048F001Y)]	
M29W160DB@PSOP44 [(SA638)]	M29W160DB@TSOP48 [(SA247-B005)]
M29W160DT@LBGA48 [(SA642G-B026A-T048F001Y)]	
M29W160DT@PSOP44 [(SA638)]	M29W160DT@TSOP48 [(SA247-B005)]
M29W160EB@LBGA48 [(SA642G-B026A-T048F001Y)]	
M29W160EB@LBGA64 [(SA655F-B099A-W064F001Y)]	
M29W160EB@PSOP44 [(SA638)]	M29W160EB@TSOP48 [(SA247-B005)]
M29W160ET@LBGA48 [(SA642G-B026A-T048F001Y)]	
M29W160ET@LBGA64 [(SA655F-B099A-W064F001Y)]	
M29W160ET@PSOP44 [(SA638)]	M29W160ET@TSOP48 [(SA247-B005)]
M29W160FT@PSOP48 [(SA247-B005)]	M29W160FT@TSOP48 [(SA247-B005)]
M29W200BB@PSOP44 [(SA638)]	M29W200BB@TSOP48 [(SA247-B005)]
M29W200BT@PSOP44 [(SA638)]	M29W200BT@TSOP48 [(SA247-B005)]
M29W256GH@LFBGA64 [(SA655G-B099A-T064F001Y)]	
M29W256GH@TFBGA64 [(SA655E-B099A-T064F001Y)]	
M29W256GH@TSOP56 [(SA628-B102)]	
M29W256GL@LFBGA64 [(SA655G-B099A-T064F001Y)]	
M29W256GL@TFBGA64 [(SA655E-B099A-T064F001Y)]	
M29W256GL@TSOP56 [(SA628-B102)]	

M29W320DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W320DB@FBGA63 [(SA642DD-B026A-W063F001Y)]  
M29W320DB@TSOP48 [(SA247-B005)]  
M29W320DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W320DT@FBGA63 [(SA642DD-B026A-W063F001Y)]  
M29W320DT@TSOP48 [(SA247-B005)]  
M29W320EB@FBGA48 [(SA642G-B026A-T048F001)]  
M29W320EB@FBGA64 [(SA655F-B099A-W064F001Y)]  
M29W320EB@TSOP48 [(SA247-B005)]  
M29W320ET@FBGA48 [(SA642G-B026A-T048F001)]  
M29W320ET@FBGA64 [(SA655F-B099A-W064F001Y)]  
M29W320ET@TSOP48 [(SA247-B005)] M29W400B@PSOP44 [(SA638)]  
M29W400B@TSOP48 [(SA247-B005)]  
M29W400BB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400BB@PSOP44 [(SA638)] M29W400BB@TSOP48 [(SA247-B005)]  
M29W400BT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400BT@PSOP44 [(SA638)] M29W400BT@TSOP48 [(SA247-B005)]  
M29W400DB(ZA)@LBGA48 [(SA642N-B026A-W048F001Y)]  
M29W400DB(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400DB@PSOP44 [(SA638)] M29W400DB@TSOP48 [(SA247-B005)]  
M29W400DT(ZA)@LBGA48 [(SA642N-B026A-W048F001Y)]  
M29W400DT(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400DT@PSOP44 [(SA638)] M29W400DT@TSOP48 [(SA247-B005)]  
M29W400T@PSOP44 [(SA638)] M29W400T@TSOP48 [(SA247-B005)]  
M29W512B@PLCC32 [(SA015A1T)] M29W512B@TSOP32 [(SA620)]  
M29W640DB@FBGA63 [(SA642E-B026A-T072F001)]  
M29W640DB@TSOP48 [(SA247-B005)]  
M29W640DT@FBGA63 [(SA642E-B026A-T072F001)]  
M29W640DT@TSOP48 [(SA247-B005)]  
M29W640FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640FB@TSOP48 [(SA247-B005)]  
M29W640FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640FT@TSOP48 [(SA247-B005)]  
M29W640GB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GB@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GB@TSOP48 [(SA247-B005)] M29W640GB@TSOP56 [(SA628-B102)]  
M29W640GH@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GH@TSOP48 [(SA247-B005)] M29W640GH@TSOP56 [(SA628-B102)]  
M29W640GL@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GL@TSOP48 [(SA247-B005)] M29W640GL@TSOP56 [(SA628-B102)]  
M29W640GSB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSB@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSB@TSOP48 [(SA247-B005)] M29W640GSB@TSOP56 [(SA628-B102)]  
M29W640GSH@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSH@TSOP48 [(SA247-B005)] M29W640GSH@TSOP56 [(SA628-B102)]  
M29W640GSL@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSL@TSOP48 [(SA247-B005)] M29W640GSL@TSOP56 [(SA628-B102)]  
M29W640GST@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GST@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GST@TSOP48 [(SA247-B005)] M29W640GST@TSOP56 [(SA628-B102)]  
M29W640GT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GT@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GT@TSOP48 [(SA247-B005)] M29W640GT@TSOP56 [(SA628-B102)]  
M29W641DH@TSOP48 [(SA247-B005)] M29W641DL@TSOP48 [(SA247-B005)]  
M29W641DU@FBGA63 [(SA642E-B026A-T072F001)]  
M29W800AB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800AB@PSOP44 [(SA638)] M29W800AB@TSOP48 [(SA247-B005)]  
M29W800AT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800AT@PSOP44 [(SA638)] M29W800AT@TSOP48 [(SA247-B005)]  
M29W800B@PSOP44 [(SA638)] M29W800B@TSOP48 [(SA247-B005)]  
M29W800DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DB@PSOP44 [(SA638)] M29W800DB@TSOP48 [(SA247-B005)]  
M29W800DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DT@PSOP44 [(SA638)] M29W800DT@TSOP48 [(SA247-B005)]  
M29W800T@PSOP44 [(SA638)] M29W800T@TSOP48 [(SA247-B005)]  
M30L0R7000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R7000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0T8800B0@FBGA88 [(SA642R-B154A-T096F001Y)]  
M30L0T8800T0@FBGA88 [(SA642R-B154A-T096F001Y)]  
M30WR6600T0@LFPGA88 [(SA642A-B061A-Y096F001)]  
M30WR128B@LFPGA88 [(SA642A-B061A-Y096F001)]  
M34C02 M34C02@MSOP8 [(SA666)]  
M34C02@SOIC8 [(SA602A)] M34C02@TSOP8 [(SA026)]  
M34D32 M34D32@SOIC8 [(SA602A)]  
M34D32@TSSOP8 [(SA026)] M34D64



M34D64@SOIC8 [(SA602A)] M34D64@TSSOP8 [(SA026)]  
M34E02 M34E02@MSOP8 [(SA666)]  
M34E02@SOIC8 [(SA602A)] M34E02@TSOP8 [(SA026)]  
M35080 M35080@SOIC8 [(SA602A)]  
M36A0W5020B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5020T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B1@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T1@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36C0W5030B0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W5030T0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W5040B0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W5040T0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W6040B0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W6040T0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W6050B0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36C0W6050T0@FBGA56 [(SA642P-B079A-W048F001Y)]  
M36D0R5030B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36DR232A@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR232B@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432AD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432BD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36L0R7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B4@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050L1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050L2@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T4@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050U1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050U2@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060L1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060U1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060L0@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060U0@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0T7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B2@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T2@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050B3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B3@FBGA88 [(SA642R-B124A-T096F001Y)]

M36L0T8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T3@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36LLR8760B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870D0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870D1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870M0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870M1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870T0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870T1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36WOR5020B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5020B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5020T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5020T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5030U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR5040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5040B2@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5040B5@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36WOR5040B7@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36WOR5040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR5040L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR5040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5040T2@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR5040T5@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36WOR5040T7@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36WOR5040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR5040U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR5040U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040B3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040B7@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6040L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040T3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040T7@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6040U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6040U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6050B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050B3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050L0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6050L4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6050T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050T3@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36WOR6050U0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6050U4@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36WOR6050U5@TFBGA88 [(SA642R-B180-T096F001Y)]  
M36W0T5040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T5040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B3@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T0@FBGA88 [(SA642R-B112A-T096F001Y)]

```

M36W0T6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6040T3@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6050B3@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6050T3@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36W0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36W216B1@LFBGA66 [(SA642E-B041A-T072F001)]
M36W216T1@LFBGA66 [(SA642E-B041A-T072F001)]
M36W432B3@LFBGA66 [(SA642E-B041A-T072F001)]
M36W432T3@LFBGA66 [(SA642E-B041A-T072F001)]
M36W864BE@LFBGA67 [(SA642E-B041A-T072F001)]
M36W864TE@LFBGA67 [(SA642E-B041A-T072F001)]
M36WWR6650B0@LFBGA88 [(SA642A-B076A-Y096F001)]
M36WWR6650D0@LFBGA88 [(SA642A-B076A-Y096F001)]
M36WWR6650T0@LFBGA88 [(SA642A-B076A-Y096F001)]
M45PE10@SOIC8 [(SA602A)] M45PE10@VQFPN8 [(SA683)]
M45PE16@SOIC8 [(SA023A)] M45PE16@VQFPN8 [(SA683)]
M45PE20@SOIC8 [(SA602A)]
M45PE20@SOIC8 (ISP) [ISP-HEADER01]
M45PE20@VQFPN8 [(SA683)]
M45PE20@VQFPN8 (ISP) [ISP-HEADER01]
M45PE40@SOIC8 [(SA023A)]
M45PE40@SOIC8 (ISP) [ISP-HEADER01]
M45PE40@VQFPN8 [(SA683)]
M45PE40@VQFPN8 (ISP) [ISP-HEADER01]
M45PE80@SOIC16 [(SA023A)]
M45PE80@SOIC16 (ISP) [ISP-HEADER01]
M45PE80@SOIC8 [(SA023A)]
M45PE80@SOIC8 (ISP) [ISP-HEADER01]
M45PE80@VQFPN8 [(SA683)]
M45PE80@VQFPN8 (ISP) [ISP-HEADER01]
M48C02
M48C12
M48T02
M48T08
M48T128V
M48T129V
M48T12B
M48T30
M48T32
M48T35
M48T35AV
M48T35AY
M48T35Y
M48T512AV
M48T512V
M48T513V
M48T559
M48T559Y
M48T58
M48T58Y
M48T59
M48T59V
M48T59Y
M48Z02
M48Z08
M48Z12
M48Z128V
M48Z129V
M48Z12B
M48Z19
M48Z30Y
M48Z32Y
M48Z35@SOIC28 [(SA630)]
M48Z35Y@SOIC28 [(SA630)]
M48Z512AY
M48Z512Y
M48Z513V
M48Z513Y
M48Z58@SOIC28 [(SA404)]
M48Z58Y@SOIC28 [(SA404)]
M48Z59@SOIC28 [(SA404)]
M48Z59W@SOIC28 [(SA404)]
M48Z59Y@SOIC28 [(SA404)]
M50FLW040A@TSOP40 [(SA409T)]
M50FLW040B@PLCC32 [(SA015A1T)]
M50FLW040B@VSOP32 [(SA620)]
M50FLW080A@TSOP40 [(SA409T)]
M50FLW080B@PLCC32 [(SA015A1T)]
M50FLW080B@VSOP32 [(SA620)]
M50FW016@TSOP40 [(SA409T)]
M50FW040@PLCC32 [(SA015A1T)]
M48C02B
M48C12B
M48T02B
M48T12
M48T128Y
M48T129Y
M48T18
M48T30Y
M48T32Y
M48T35@SOIC28 [(SA404)]
M48T35AV@SOIC28 [(SA630)]
M48T35AY@SOIC28 [(SA630)]
M48T35Y@SOIC28 [(SA404)]
M48T512AY
M48T512Y
M48T513Y
M48T559@SOIC28 [(SA630)]
M48T559Y@SOIC28 [(SA630)]
M48T58@SOIC28 [(SA404)]
M48T58Y@SOIC28 [(SA404)]
M48T59@SOIC28 [(SA404)]
M48T59V@SOIC28 [(SA404)]
M48T59Y@SOIC28 [(SA404)]
M48Z02B
M48Z09
M48Z128
M48Z128Y
M48Z129Y
M48Z18
M48Z30
M48Z32
M48Z35
M48Z35Y
M48Z512AV
M48Z512V
M48Z513V
M48Z58
M48Z58Y
M48Z59
M48Z59W
M48Z59Y
M50FLW040A@PLCC32 [(SA015A1T)]
M50FLW040A@VSOP32 [(SA620)]
M50FLW040B@TSOP40 [(SA409T)]
M50FLW080A@PLCC32 [(SA015A1T)]
M50FLW080A@VSOP32 [(SA620)]
M50FLW080B@TSOP40 [(SA409T)]
M50FW002@PLCC32 [(SA015A1T)]
M50FW020@PLCC32 [(SA015A1T)]
M50FW040@TSOP40 [(SA409T)]

```

M50FW080@PLCC32 [(SA015A1T)] M50FW080@TSOP40 [(SA409T)]  
M50FW080@VSOP32 [(SA620)] M50LPW002@PLCC32 [(SA015A1T)]  
M50LPW012@PLCC32 [(SA015A1T)] M50LPW020@PLCC32 [(SA015A1T)]  
M50LPW040@PLCC32 [(SA015A1T)] M50LPW040@TSOP40 [(SA409T)]  
M50LPW041@PLCC32 [(SA015A1T)] M50LPW041@TSOP40 [(SA409T)]  
M50LPW080@PLCC32 [(SA015A1T)] M50LPW080@TSOP40 [(SA409T)]  
M50LPW116@TSOP40 [(SA409T)]  
M58LR128FB@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128FT@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GB@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GL@FBGA44 [(SA733A-B206A-M056F001Y)]  
M58LR128GT@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GU@FBGA44 [(SA733A-B206A-M056F001Y)]  
M58LR256GL@FBGA44 [(SA733C-B206A-M056F001N)]  
M58LR256GU@FBGA44 [(SA733C-B206A-M056F001N)]  
M58LT128GB@FBGA56 [(SA644A-B025B-Y072F001Y)]  
M58LT128GSB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT128GST@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT128GT@FBGA56 [(SA644A-B025B-Y072F001Y)]  
M58LT128HSB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT128HST@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256GB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256GT@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256JTB@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LT256JST@FBGA64 [(SA655E-B130A-T056F001Y)]  
M58LW032A@TSOP56 [(SA628-B031)]  
M58LW032C@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW032C@TSOP56 [(SA628-B031)]  
M58LW032D@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW032D@TSOP56 [(SA628-B018)]  
M58LW064C@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW064C@TSOP56 [(SA628-B063)]  
M58LW064D@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW064D@TSOP56 [(SA628-B018)] M58LW128A@TSOP56 [(SA628-B018)]  
M58WR016QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR016QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR064EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR064HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR128FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M59DR008E@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008E@TSOP48 [(SA247-B005)]  
M59DR008F@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008F@TSOP48 [(SA247-B005)]  
M59DR016C@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59DR016D@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59PW016@PSOP44 [(SA638)] M59PW016@SDIP42 [(SA028)]  
M59PW016@TSOP48 [(SA247-B005)] M59PW032@PSOP44 [(SA638)]  
M59PW032@PSOP44(Fast) [(SA638+B006)]  
M59PW032@TSOP48 [(SA247-B005)] M59PW064@PSOP44 [(SA638)]  
M59PW1282@PSOP44 [(SA638)]

```

M72DW64000B@FBGA73 [(SA642A-B032A-Y096F001Y)]
M72DW75000C@FBGA73 [(SA642A-B039A-Y096F001Y)]
M72DW75001C@FBGA73 [(SA642A-B032A-Y096F001Y)]
M72DW76001D@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52003BA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52003TA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52004BA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52004TA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW62000A@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW63000A@FBGA73 [(SA642A-B032A-Y096F001Y)]
M87C257
M93C06(08bit) M87C257@PLCC32 [(SA015A1T)]
M93C06(16bit) M93C06(08bit)@SOIC8 [(SA602A)]
M93C46(08bit) M93C06(16bit)@SOIC8 [(SA602A)]
M93C46(08bit)@MSOP8 [(SA666)] M93C46(08bit)@MLP8 [(SA694)]
M93C46(08bit)@TSSOP8 [(SA026)] M93C46(08bit)@SOIC8 [(SA602A)]
M93C46(16bit)@MLP8 [(SA694)] M93C46(16bit)
M93C46(16bit)@SOIC8 [(SA602A)] M93C46(16bit)@MSOP8 [(SA666)]
M93C46R(08bit) M93C46(16bit)@TSSOP8 [(SA026)]
M93C46R(08bit)@MSOP8 [(SA666)] M93C46R(08bit)@MLP8 [(SA694)]
M93C46R(08bit)@TSSOP8 [(SA026)] M93C46R(08bit)@SOIC8 [(SA602A)]
M93C46R(16bit)@MLP8 [(SA694)] M93C46R(16bit)
M93C46R(16bit)@SOIC8 [(SA602A)] M93C46R(16bit)@MSOP8 [(SA666)]
M93C46W(08bit) M93C46R(16bit)@TSSOP8 [(SA026)]
M93C46W(08bit)@MSOP8 [(SA666)] M93C46W(08bit)@MLP8 [(SA694)]
M93C46W(08bit)@TSSOP8 [(SA026)] M93C46W(08bit)@SOIC8 [(SA602A)]
M93C46W(16bit)@MLP8 [(SA694)] M93C46W(16bit)
M93C46W(16bit)@SOIC8 [(SA602A)] M93C46W(16bit)@MSOP8 [(SA666)]
M93C56(08bit) M93C46W(16bit)@TSSOP8 [(SA026)]
M93C56(08bit)@MSOP8 [(SA666)] M93C56(08bit)@MLP8 [(SA694)]
M93C56(08bit)@TSSOP8 [(SA026)] M93C56(08bit)@SOIC8 [(SA602A)]
M93C56(16bit)@MLP8 [(SA694)] M93C56(16bit)
M93C56(16bit)@SOIC8 [(SA602A)] M93C56(16bit)@MSOP8 [(SA666)]
M93C56R(08bit) M93C56(16bit)@TSSOP8 [(SA026)]
M93C56R(08bit)@MSOP8 [(SA666)] M93C56R(08bit)@MLP8 [(SA694)]
M93C56R(08bit)@TSSOP8 [(SA026)] M93C56R(08bit)@SOIC8 [(SA602A)]
M93C56R(16bit)@MLP8 [(SA694)] M93C56R(16bit)
M93C56R(16bit)@SOIC8 [(SA602A)] M93C56R(16bit)@MSOP8 [(SA666)]
M93C56W(08bit) M93C56R(16bit)@TSSOP8 [(SA026)]
M93C56W(08bit)@MSOP8 [(SA666)] M93C56W(08bit)@MLP8 [(SA694)]
M93C56W(08bit)@TSSOP8 [(SA026)] M93C56W(08bit)@SOIC8 [(SA602A)]
M93C56W(16bit)@MLP8 [(SA694)] M93C56W(16bit)
M93C56W(16bit)@SOIC8 [(SA602A)] M93C56W(16bit)@MSOP8 [(SA666)]
M93C66(08bit) M93C56W(16bit)@TSSOP8 [(SA026)]
M93C66(08bit)@MSOP8 [(SA666)] M93C66(08bit)@MLP8 [(SA694)]
M93C66(08bit)@TSSOP8 [(SA026)] M93C66(08bit)@SOIC8 [(SA602A)]
M93C66(16bit)@MLP8 [(SA694)] M93C66(16bit)
M93C66(16bit)@SOIC8 [(SA602A)] M93C66(16bit)@MSOP8 [(SA666)]
M93C66R(08bit) M93C66(16bit)@TSSOP8 [(SA026)]
M93C66R(08bit)@MSOP8 [(SA666)] M93C66R(08bit)@MLP8 [(SA694)]
M93C66R(08bit)@TSSOP8 [(SA026)] M93C66R(08bit)@SOIC8 [(SA602A)]
M93C66R(16bit)@MLP8 [(SA694)] M93C66R(16bit)
M93C66R(16bit)@SOIC8 [(SA602A)] M93C66R(16bit)@MSOP8 [(SA666)]
M93C66W(08bit) M93C66R(16bit)@TSSOP8 [(SA026)]
M93C66W(08bit)@MSOP8 [(SA666)] M93C66W(08bit)@MLP8 [(SA694)]
M93C66W(08bit)@TSSOP8 [(SA026)] M93C66W(08bit)@SOIC8 [(SA602A)]
M93C66W(16bit)@MLP8 [(SA694)] M93C66W(16bit)
M93C66W(16bit)@SOIC8 [(SA602A)] M93C66W(16bit)@MSOP8 [(SA666)]
M93C76(08bit) M93C66W(16bit)@TSSOP8 [(SA026)]
M93C76(08bit)@MSOP8 [(SA666)] M93C76(08bit)@MLP8 [(SA694)]
M93C76(08bit)@TSSOP8 [(SA026)] M93C76(08bit)@SOIC8 [(SA602A)]
M93C76(16bit)@MLP8 [(SA694)] M93C76(16bit)
M93C76(16bit)@SOIC8 [(SA602A)] M93C76(16bit)@MSOP8 [(SA666)]
M93C76R(08bit) M93C76(16bit)@TSSOP8 [(SA026)]
M93C76R(08bit)@MSOP8 [(SA666)] M93C76R(08bit)@MLP8 [(SA694)]
M93C76R(08bit)@TSSOP8 [(SA026)] M93C76R(08bit)@SOIC8 [(SA602A)]
M93C76R(16bit)@MLP8 [(SA694)] M93C76R(16bit)
M93C76R(16bit)@SOIC8 [(SA602A)] M93C76R(16bit)@MSOP8 [(SA666)]
M93C76W(08bit) M93C76R(16bit)@TSSOP8 [(SA026)]
M93C76W(08bit)@MSOP8 [(SA666)] M93C76W(08bit)@MLP8 [(SA694)]
M93C76W(08bit)@TSSOP8 [(SA026)] M93C76W(08bit)@SOIC8 [(SA602A)]
M93C76W(16bit)@MLP8 [(SA694)] M93C76W(16bit)
M93C76W(16bit)@SOIC8 [(SA602A)] M93C76W(16bit)@MSOP8 [(SA666)]
M93C86(08bit) M93C76W(16bit)@TSSOP8 [(SA026)]
M93C86(08bit)@MSOP8 [(SA666)] M93C86(08bit)@MLP8 [(SA694)]
M93C86(08bit)@TSSOP8 [(SA026)] M93C86(08bit)@SOIC8 [(SA602A)]
M93C86(16bit)@MLP8 [(SA694)] M93C86(16bit)
M93C86(16bit)@SOIC8 [(SA602A)] M93C86(16bit)@MSOP8 [(SA666)]
M93C86R(08bit) M93C86(16bit)@TSSOP8 [(SA026)]
M93C86R(08bit)@MSOP8 [(SA666)] M93C86R(08bit)@MLP8 [(SA694)]
M93C86R(08bit)@TSSOP8 [(SA026)] M93C86R(08bit)@SOIC8 [(SA602A)]
M93C86R(16bit)@MLP8 [(SA694)] M93C86R(16bit)
M93C86R(16bit)@SOIC8 [(SA602A)] M93C86R(16bit)@MSOP8 [(SA666)]
M93C86R(16bit)@TSSOP8 [(SA026)]

```

M93C86R(16bit)@MLP8 [(SA694)]	M93C86R(16bit)@MSOP8 [(SA666)]
M93C86R(16bit)@SOIC8 [(SA602A)]	M93C86R(16bit)@TSSOP8 [(SA026)]
M93C86W(08bit)	M93C86W(08bit)@MLP8 [(SA694)]
M93C86W(08bit)@MSOP8 [(SA666)]	M93C86W(08bit)@SOIC8 [(SA602A)]
M93C86W(08bit)@TSSOP8 [(SA026)]	M93C86W(16bit)
M93C86W(16bit)@MLP8 [(SA694)]	M93C86W(16bit)@MSOP8 [(SA666)]
M93C86W(16bit)@SOIC8 [(SA602A)]	M93C86W(16bit)@TSSOP8 [(SA026)]
M93CS566	M93CS566@SOIC8 [(SA602A)]
M93S46	M93S46@SOIC8 [(SA602A)]
M93S46@TSSOP8 [(SA026)]	M93S46R
M93S46R@SOIC8 [(SA602A)]	M93S46R@TSSOP8 [(SA026)]
M93S46W	M93S46W@SOIC8 [(SA602A)]
M93S46W@TSSOP8 [(SA026)]	M93S56
M93S56@SOIC8 [(SA602A)]	M93S56@TSSOP8 [(SA026)]
M93S56R	M93S56R@SOIC8 [(SA602A)]
M93S56R@TSSOP8 [(SA026)]	M93S56W
M93S56W@SOIC8 [(SA602A)]	M93S56W@TSSOP8 [(SA026)]
M93S66	M93S66@SOIC8 [(SA602A)]
M93S66@TSSOP8 [(SA026)]	M93S66R
M93S66R@SOIC8 [(SA602A)]	M93S66R@TSSOP8 [(SA026)]
M93S66W	M93S66W@SOIC8 [(SA602A)]
M93S66W@TSSOP8 [(SA026)]	M95010
M95010(ISP) [ISP-HEADER01]	M95010@SOIC8 [(SA602A)]
M95010@SOIC8(ISP) [ISP-HEADER01]	M95010@TSSOP8 [(SA026)]
M95010@TSSOP8(ISP) [ISP-HEADER01]	
M95020	M95020(ISP) [ISP-HEADER01]
M95020@SOIC8 [(SA602A)]	M95020@SOIC8(ISP) [ISP-HEADER01]
M95020@TSSOP8 [(SA026)]	
M95020@TSSOP8(ISP) [ISP-HEADER01]	
M95040	M95040(ISP) [ISP-HEADER01]
M95040@SOIC8 [(SA602A)]	M95040@SOIC8(ISP) [ISP-HEADER01]
M95040@TSSOP8 [(SA026)]	
M95040@TSSOP8(ISP) [ISP-HEADER01]	
M95080	M95080(ISP) [ISP-HEADER01]
M95080@SOIC8 [(SA602A)]	M95080@SOIC8(ISP) [ISP-HEADER01]
M95080@TSSOP14 [(SA026)]	
M95080@TSSOP14(ISP) [ISP-HEADER01]	
M95080@TSSOP8 [(SA026)]	
M95080@TSSOP8(ISP) [ISP-HEADER01]	
M95128	M95128(ISP) [ISP-HEADER01]
M95128@TSSOP14 [(SA026)]	
M95128@TSSOP14(ISP) [ISP-HEADER01]	
M95128@TSSOP8 [(SA026)]	
M95128@TSSOP8(ISP) [ISP-HEADER01]	
M95128[150mil]@SOIC8 [(SA602A)]	
M95128[150mil]@SOIC8(ISP) [ISP-HEADER01]	
M95128[200mil]@SOIC8 [(SA023A)]	
M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]	
M95160	M95160(ISP) [ISP-HEADER01]
M95160@SOIC8 [(SA602A)]	M95160@SOIC8(ISP) [ISP-HEADER01]
M95160@TSSOP14 [(SA026)]	
M95160@TSSOP14(ISP) [ISP-HEADER01]	
M95160@TSSOP8 [(SA026)]	
M95160@TSSOP8(ISP) [ISP-HEADER01]	
M95256	M95256(ISP) [ISP-HEADER01]
M95256@TSSOP14 [(SA026)]	
M95256@TSSOP14(ISP) [ISP-HEADER01]	
M95256@TSSOP8 [(SA026)]	
M95256@TSSOP8(ISP) [ISP-HEADER01]	
M95256[150mil]@SOIC8 [(SA602A)]	
M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]	
M95256[200mil]@SOIC8 [(SA023A)]	
M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]	
M95320	M95320(ISP) [ISP-HEADER01]
M95320@SOIC8 [(SA602A)]	M95320@SOIC8(ISP) [ISP-HEADER01]
M95320@TSSOP14 [(SA026)]	
M95320@TSSOP14(ISP) [ISP-HEADER01]	
M95320@TSSOP8 [(SA026)]	
M95320@TSSOP8(ISP) [ISP-HEADER01]	
M95512@SOIC8 [(SA602A)]	M95512@SOIC8(ISP) [ISP-HEADER01]
M95512@TSSOP8 [(SA026)]	
M95512@TSSOP8(ISP) [ISP-HEADER01]	
M95640	M95640(ISP) [ISP-HEADER01]
M95640@SOIC8 [(SA602A)]	M95640@SOIC8(ISP) [ISP-HEADER01]
M95640@TSSOP14 [(SA026)]	
M95640@TSSOP14(ISP) [ISP-HEADER01]	
M95640@TSSOP8 [(SA026)]	
M95640@TSSOP8(ISP) [ISP-HEADER01]	
M95M01[150mil]@SOIC8 [(SA602A)]	M95P02
M95P02@SOIC8 [(SA602A)]	M95P04
M95P04@SOIC8 [(SA602A)]	M95P08

M95P08@SOIC8 [(SA602A)]	MK48C02
MK48C02B	MK48C12
MK48C12B	MK48T02
MK48T02B	MK48T08
MK48T12	MK48T12B
MK48T18	MK48T32
MK48T32Y	MK48T35
MK48T35@SOIC28 [(SA630)]	MK48T35Y
MK48T35Y@SOIC28 [(SA630)]	MK48T512V
MK48T512Y	MK48Z02
MK48Z02B	MK48Z08
MK48Z12	MK48Z12B
MK48Z18	MK48Z32
MK48Z32Y	MK48Z35
MK48Z35@SOIC28 [(SA630)]	MK48Z35Y
MK48Z35Y@SOIC28 [(SA630)]	MK48Z512V
MK48Z512Y	MKI48Z02
MKI48Z02B	MKI48Z12
MKI48Z12B	MKI48Z18
NAND01GR3B2BZA6@FBGA63 [(SA642KK-B280-W048F001Y)]	
NAND01GW3A0AN6@TSOP48 [(SA247-B005)]	
NAND01GW3B2AN6@TSOP48 [(SA247-B005)]	
NAND01GW3B2BN6@TSOP48 [(SA247-B005)]	
NAND01GW3B2BZA6@FBGA63 [(SA642KK-B026-W048F001Y)]	
NAND01GW3M2AZC5E@FBGA137 [(SA700E-B153A-M137F001Y)]	
NAND02GR3B2CZA6@FBGA63 [(SA642NN-B026A-W063F001Y)]	
NAND02GR3B2DZA6@FBGA63 [(SA642KK-B280A-W048F001Y)]	
NAND02GW3B2AN6@TSOP48 [(SA247-B005)]	
NAND02GW3B2CN6@TSOP48 [(SA247-B005)]	
NAND02GW3B2CZA6@FBGA63 [(SA642NN-B026A-W063F001Y)]	
NAND04GW3B2BN6@TSOP48 [(SA247-B005)]	
NAND04GW3C2AN1@TSOP48 [(SA247-B005)]	
NAND08GW3B2AN6@TSOP48 [(SA247-B005)]	
NAND128W3A0AN6@TSOP48 [(SA247-B005)]	
NAND128W3A2BN6@TSOP48 [(SA247-B005)]	
NAND256R3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]	
NAND256R3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]	
NAND256W3A0AN6@TSOP48 [(SA247-B005)]	
NAND256W3A0AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]	
NAND256W3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]	
NAND256W3A2BN6@TSOP48 [(SA247-B005)]	
NAND256W3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]	
NAND512R3A2AZB6@TFBGA63 [(SA642KK-B026-W048F001Y)]	
NAND512R3A2AZB6E@TFBGA55 [(SA642R-B026-T096F001Y)]	
NAND512R3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]	
NAND512R3M0AZB5@FBGA107 [(SA642V-B133-T096F001Y)]	
NAND512W3A0AN6@TSOP48 [(SA247-B005)]	
NAND512W3A2BN6@TSOP48 [(SA247-B005)]	
NAND512W3A2CN6@TSOP48 [(SA247-B005)]	
NAND512W3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]	
NAND98R3M0AZBB5@FBGA107 [(SA642V-B133-T096F001Y)]	
NAND98R3M2AZBB5@FBGA107 [(SA642V-B133-T096F001Y)]	
NAND99R4M2AZBA5@BGA149 [(SA664G-B279-Y149F001Y)]	
NANDA9R4N2AZBA5@FBGA149 [(SA664G-B279-Y149F001Y)]	
NANDC9R4N0AZBA5E@FBGA149 [(SA664G-B279-Y149F001Y)]	
ST24C01	ST24C01@SOIC8 [(SA602A)]
ST24C02A	ST24C02A@SOIC8 [(SA602A)]
ST24C16	ST24C16@SOIC8 [(SA602A)]
ST24FC21	ST24FC21@SOIC8 [(SA602A)]
ST24FW21	ST24FW21@SOIC8 [(SA602A)]
ST24LC21B	ST24LC21B@SOIC8 [(SA602A)]
ST24LW21	ST24LW21@SOIC8 [(SA602A)]
ST24W01	ST24W01@SOIC8 [(SA602A)]
ST24W02	ST24W02@SOIC8 [(SA602A)]
ST24W04C	ST24W04C@SOIC8 [(SA602A)]
ST26C201	ST26C201@PLCC32 [(SA015A1T)]
ST26C201@TSOP32 [(SA410T)]	ST27128A
ST27256	ST2764A
ST27C256	ST93C06(08bit)
ST93C06(08bit)@SOIC8 [(SA602A)]	ST93C06(16bit)
ST93C06(16bit)@SOIC8 [(SA602A)]	ST93C46(08bit)
ST93C46(08bit)@SOIC8 [(SA602A)]	ST93C46(16bit)
ST93C46(16bit)@SOIC8 [(SA602A)]	ST93C46A(08bit)
ST93C46A(08bit)@SOIC8 [(SA602A)]	ST93C46A(16bit)
ST93C46A(16bit)@SOIC8 [(SA602A)]	ST93C46C(08bit)
ST93C46C(08bit)@SOIC8 [(SA602A)]	ST93C46C(16bit)
ST93C46C(16bit)@SOIC8 [(SA602A)]	ST93C46T(08bit)
ST93C46T(08bit)@SOIC8 [(SA602A)]	ST93C46T(16bit)
ST93C46T(16bit)@SOIC8 [(SA602A)]	ST93C47C(08bit)
ST93C47C(08bit)@SOIC8 [(SA602A)]	ST93C47C(16bit)
ST93C47C(16bit)@SOIC8 [(SA602A)]	ST93C47T(08bit)

ST93C47T(08bit)@SOIC8 [(SA602A)]	ST93C47T(16bit)
ST93C47T(16bit)@SOIC8 [(SA602A)]	ST93C56(08bit)
ST93C56(08bit)@SOIC8 [(SA602A)]	ST93C56(16bit)
ST93C56(16bit)@SOIC8 [(SA602A)]	ST93C56B(08bit)
ST93C56B(08bit)@SOIC8 [(SA602A)]	ST93C56B(16bit)
ST93C56B(16bit)@SOIC8 [(SA602A)]	ST93C56C(08bit)
ST93C56C(08bit)@SOIC8 [(SA602A)]	ST93C56C(16bit)
ST93C56C(16bit)@SOIC8 [(SA602A)]	ST93C57C(08bit)
ST93C57C(08bit)@SOIC8 [(SA602A)]	ST93C57C(16bit)
ST93C57C(16bit)@SOIC8 [(SA602A)]	ST93C66(08bit)
ST93C66(08bit)@SOIC8 [(SA602A)]	ST93C66(16bit)
ST93C66(16bit)@SOIC8 [(SA602A)]	ST93C67(08bit)
ST93C67(08bit)@SOIC8 [(SA602A)]	ST93C67(16bit)
ST93C67(16bit)@SOIC8 [(SA602A)]	ST93C76(08bit)
ST93C76(08bit)@SOIC8 [(SA602A)]	ST93C76(16bit)
ST93C76(16bit)@SOIC8 [(SA602A)]	ST93C86(08bit)
ST93C86(08bit)@SOIC8 [(SA602A)]	ST93C86(16bit)
ST93C86(16bit)@SOIC8 [(SA602A)]	ST93CS46
ST93CS46@SOIC8 [(SA602A)]	ST93CS47
ST93CS47@SOIC8 [(SA602A)]	ST93CS56
ST93CS56@SOIC8 [(SA602A)]	ST93CS566
ST93CS566@SOIC8 [(SA602A)]	ST93CS57
ST93CS57@SOIC8 [(SA602A)]	ST93CS66
ST93CS66@SOIC14 [(SA602)]	ST93CS67
ST93CS67@SOIC14 [(SA602)]	TS27C256
TS27C64	TS27C64@PLCC32 [(SA015A1T)]
TS27C64A	TS27C64A@PLCC32 [(SA015A1T)]
TS28C16A	TS28C17A

**MICROCONTROLLER**

PSD211R@PLCC44 [(SA244)]	PSD211R@TQFP44 [(SA245A)]
PSD301@PLCC44 [(SA244)]	PSD301@TQFP44 [(SA245A)]
PSD301B@PLCC44 [(SA244)]	PSD301L@PLCC44 [(SA244)]
PSD301L@TQFP44 [(SA245A)]	PSD301R@PLCC44 [(SA244)]
PSD301R@TQFP44 [(SA245A)]	PSD301RV@PLCC44 [(SA244)]
PSD301V@PLCC44 [(SA244)]	PSD302@PLCC44 [(SA244)]
PSD302@TQFP44 [(SA245A)]	PSD302B@PLCC44 [(SA244)]
PSD302B@PLCC44 (USA) [(SA411A)]	PSD302L@PLCC44 [(SA244)]
PSD302L@TQFP44 [(SA245A)]	PSD302R@PLCC44 [(SA244)]
PSD302R@TQFP44 [(SA245A)]	PSD302RV@PLCC44 [(SA244)]
PSD302V@PLCC44 [(SA244)]	PSD303@PLCC44 [(SA244)]
PSD303@TQFP44 [(SA245A)]	PSD303L@PLCC44 [(SA244)]
PSD303L@TQFP44 [(SA245A)]	PSD303R@PLCC44 [(SA244)]
PSD303R@TQFP44 [(SA245A)]	PSD303RV@PLCC44 [(SA244)]
PSD303V@PLCC44 [(SA244)]	PSD311@PLCC44 [(SA244)]
PSD311@TQFP44 [(SA245A)]	PSD311B@PLCC44 [(SA244)]
PSD311L@PLCC44 [(SA244)]	PSD311L@TQFP44 [(SA245A)]
PSD311R@PLCC44 [(SA244)]	PSD311R@TQFP44 [(SA245A)]
PSD311RV@PLCC44 [(SA244)]	PSD311V@PLCC44 [(SA244)]
PSD312@PLCC44 [(SA244)]	PSD312@TQFP44 [(SA245A)]
PSD312B@PLCC44 [(SA244)]	PSD312L@PLCC44 [(SA244)]
PSD312L@TQFP44 [(SA245A)]	PSD312R@PLCC44 [(SA244)]
PSD312R@TQFP44 [(SA245A)]	PSD312RV@PLCC44 [(SA244)]
PSD312V@PLCC44 [(SA244)]	PSD313@PLCC44 [(SA244)]
PSD313@TQFP44 [(SA245A)]	PSD313-B@PLCC44 [(SA244)]
PSD313-B@TQFP44 [(SA245A)]	PSD313L@PLCC44 [(SA244)]
PSD313L@TQFP44 [(SA245A)]	PSD313R@PLCC44 [(SA244)]
PSD313R@TQFP44 [(SA245A)]	PSD313RV@PLCC44 [(SA244)]
PSD313V@PLCC44 [(SA244)]	PSD813F1@PLCC52 [(PEP+S415T)]
PSD813F1@TQFP52 [(PEP+S662)]	
PSD813F1@TQFP52(*) [(TA071+B006)]	PSD813F1V@PLCC52 [(PEP+S415T)]
PSD813F1A@PLCC52 [(PEP+S415T)]	
PSD813F1V@TQFP52 [(PEP+S662)]	
PSD813F1V@TQFP52(*) [(TA071+B006)]	PSD813F2@PLCC52 [(PEP+S415T)]
PSD813F1VA@PLCC52 [(PEP+S415T)]	
PSD813F2@TQFP52 [(PEP+S662)]	
PSD813F2@TQFP52(*) [(TA071+B006)]	PSD813F2V@PLCC52 [(PEP+S415T)]
PSD813F2A@PLCC52 [(PEP+S415T)]	
PSD813F2V@TQFP52 [(PEP+S662)]	
PSD813F2V@TQFP52(*) [(TA071+B006)]	PSD813F3@PLCC52 [(PEP+S415T)]
PSD813F2VA@PLCC52 [(PEP+S415T)]	
PSD813F3@TQFP52 [(PEP+S662)]	
PSD813F3@TQFP52(*) [(TA071+B006)]	PSD813F3V@TQFP52 [(PEP+S662)]
PSD813F3V@PLCC52 [(PEP+S415T)]	
PSD813F3V@TQFP52(*) [(TA071+B006)]	PSD813F4@TQFP52 [(PEP+S662)]
PSD813F4@PLCC52 [(PEP+S415T)]	
PSD813F4@TQFP52(*) [(TA071+B006)]	PSD813F4V@TQFP52 [(PEP+S662)]
PSD813F4V@PLCC52 [(PEP+S415T)]	



PSD813F4V@TQFP52 (*) [(TA071+B006)]	
PSD813F5@PLCC52 [(PEP+S415T)]	PSD813F5@TQFP52 [(PEP+S662)]
PSD813F5@TQFP52 (*) [(TA071+B006)]	
PSD813F5V@PLCC52 [(PEP+S415T)]	PSD813F5V@TQFP52 [(PEP+S662)]
PSD813F5V@TQFP52 (*) [(TA071+B006)]	
PSD833F2@PLCC52 [(PEP+S415T)]	PSD833F2@PQFP52 [(PEP+S662)]
PSD833F2@TQFP52 (*) [(TA071+B006)]	
PSD833F2V@PLCC52 [(PEP+S415T)]	PSD833F2V@TQFP52 [(PEP+S662)]
PSD833F2V@TQFP52 (*) [(TA071+B006)]	
PSD834F2@PLCC52 [(PEP+S415T)]	PSD834F2@TQFP52 [(PEP+S662)]
PSD834F2V@PLCC52 [(PEP+S415T)]	PSD834F2V@TQFP52 [(PEP+S662)]
PSD853F2@PLCC52 [(PEP+S415T)]	PSD853F2@PQFP52 [(PEP+S662)]
PSD853F2@TQFP52 (*) [(TA071+B006)]	
PSD853F2V@PLCC52 [(PEP+S415T)]	PSD853F2V@TQFP52 [(PEP+S662)]
PSD853F2V@TQFP52 (*) [(TA071+B006)]	
PSD854F2@PLCC52 [(PEP+S415T)]	PSD854F2@TQFP52 [(PEP+S662)]
PSD854F2V@PLCC52 [(PEP+S415T)]	PSD854F2V@TQFP52 [(PEP+S662)]
ST62E01	ST62E01@SOIC16 [(SA404)]
ST62E01CF1	ST62E18CF1
ST62E20	ST62E20@SOIC20 [(SA404)]
ST62E20CF1	ST62E25
ST62E25@SOIC28 [(SA404)]	ST62E25CF1
ST62E28CF1	ST62E30BF1
ST62E32BF1@SDIP42 [(SA028)]	ST62E40BG1@PQFP80 [(PEP+S611A)]
ST62E42BG1@TQFP64 [(PEP+S621)]	ST62E46BG1@SDIP56 [(PEP+S627)]
ST62E60B	ST62E60B@SOIC20 [(SA404)]
ST62E62CF1	ST62E65B
ST62E65B@SOIC28 [(SA404)]	ST62E65CF1
ST62E80BG1@PQFP100 [(PEP+S427)]	ST62E85BG1@PQFP80 [(PEP+S611A)]
ST62T00	ST62T00@SOIC16 [(SA404)]
ST62T00C(B6)	ST62T00C(M6)@SOIC16 [(SA404)]
ST62T00C(N6)@SSOP16 [(SA626A)]	ST62T01
ST62T01@SOIC16 [(SA404)]	ST62T01C(B3)
ST62T01C(B6)	ST62T01C(M3)@SOIC16 [(SA404)]
ST62T01C(M6)@SOIC16 [(SA404)]	ST62T01C(N3)@SSOP16 [(SA626A)]
ST62T01C(N6)@SSOP16 [(SA626A)]	ST62T03
ST62T03@SOIC16 [(SA404)]	ST62T03C(B6)
ST62T03C(M3)@SOIC16 [(SA404)]	ST62T03C(M6)@SOIC16 [(SA404)]
ST62T03C(N6)@SSOP16 [(SA626A)]	ST62T08
ST62T08@SOIC20 [(SA404)]	ST62T08C(B6)
ST62T08C(M6)@SOIC20 [(SA404)]	ST62T09
ST62T09@SOIC20 [(SA404)]	ST62T09C(B3)
ST62T09C(B6)	ST62T09C(M3)@SOIC20 [(SA404)]
ST62T09C(M6)@SOIC20 [(SA404)]	ST62T10
ST62T10@SOIC20 [(SA404)]	ST62T10C(B6)
ST62T10C(M6)@SOIC20 [(SA404)]	ST62T15
ST62T15@SOIC28 [(SA404)]	ST62T15C(B6)
ST62T15C(M6)@SOIC28 [(SA404)]	ST62T18C(B6)
ST62T18C(M3)@SOIC20 [(SA404)]	ST62T18C(M6)@SOIC20 [(SA404)]
ST62T20	ST62T20@SOIC20 [(SA404)]
ST62T20C(B3)	ST62T20C(B6)
ST62T20C(M3)@SOIC20 [(SA404)]	ST62T20C(M6)@SOIC20 [(SA404)]
ST62T25	ST62T25@SOIC28 [(SA404)]
ST62T25C(B3)	ST62T25C(B6)
ST62T25C(M3)@SOIC28 [(SA404)]	ST62T25C(M6)@SOIC28 [(SA404)]
ST62T25C(N6)@SSOP28 [(SA626A)]	ST62T28C(B6)
ST62T28C(M3)@SOIC28 [(SA404)]	ST62T28C(M6)@SOIC28 [(SA404)]
ST62T28C(N6)@SSOP28 [(SA626A)]	ST62T30B(B3)
ST62T30B(B6)	ST62T30B(M6)@SOIC28 [(SA404)]
ST62T32B(B6)@SDIP42 [(SA028)]	
ST62T40B(Q6)@PQFP80 [(PEP+S611A)]	
ST62T42B(Q6)@TQFP64 [(PEP+S621)]	ST62T46B(Q6)@SDIP56 [(PEP+S627)]
ST62T52C(B6)	ST62T52C(M3)@SOIC16 [(SA404)]
ST62T52C(M6)@SOIC16 [(SA404)]	ST62T52C(N3)@SSOP16 [(SA626A)]
ST62T52C(N6)@SSOP16 [(SA626A)]	ST62T53B
ST62T53B@SOIC20 [(SA404)]	ST62T53C(B6)
ST62T53C(M6)@SOIC20 [(SA404)]	ST62T55C(B6)
ST62T55C(M6)@SOIC28 [(SA404)]	ST62T55C(N6)@SSOP28 [(SA626A)]
ST62T60B	ST62T60B@SOIC20 [(SA404)]
ST62T60C6	ST62T62C(B6)
ST62T62C(M3)@SOIC16 [(SA404)]	ST62T62C(M6)@SOIC16 [(SA404)]
ST62T62C(N3)@SSOP16 [(SA626A)]	ST62T62C(N6)@SSOP16 [(SA626A)]
ST62T63B	ST62T63B@SOIC20 [(SA404)]
ST62T63C(B6)	ST62T63C(M6)@SOIC20 [(SA404)]
ST62T65B	ST62T65B@SOIC28 [(SA404)]
ST62T65C(B3)	ST62T65C(B6)
ST62T65C(M3)@SOIC28 [(SA404)]	ST62T65C(M6)@SOIC28 [(SA404)]
ST62T65C(N6)@SSOP28 [(SA626A)]	
ST62T80B(Q6)@PQFP100 [(PEP+S427)]	
ST62T85B(Q6)@PQFP80 [(PEP+S611A)]	
ST63E73@SDIP42 [(SA028)]	ST63T73@SDIP42 [(SA028)]

ST72C104G1B@SDIP32 [(SA653)]	ST72C104G1M@SOIC28 [(SA404)]
ST72C104G2B@SDIP32 [(SA653)]	ST72C104G2M@SOIC28 [(SA404)]
ST72C124J2B@SDIP42 [(SA028)]	ST72C124J2T@TQFP44 [(SA245A)]
ST72C124J4B@SDIP42 [(SA028)]	ST72C124J4T@TQFP44 [(SA245A)]
ST72C215G1B@SDIP32 [(SA653)]	ST72C215G1M@SOIC28 [(SA404)]
ST72C215G2B@SDIP32 [(SA653)]	ST72C215G2M@SOIC28 [(SA404)]
ST72C216G1B@SDIP32 [(SA653)]	ST72C216G1M@SOIC28 [(SA404)]
ST72C216G2B@SDIP32 [(SA653)]	ST72C216G2M@SOIC28 [(SA404)]
ST72C254G1B@SDIP32 [(SA653)]	ST72C254G1M@SOIC28 [(SA404)]
ST72C254G2B@SDIP32 [(SA653)]	ST72C254G2M@SOIC28 [(SA404)]
ST72C314J2B@SDIP42 [(SA028)]	ST72C314J2T@TQFP44 [(SA245A)]
ST72C314J4B@SDIP42 [(SA028)]	ST72C314J4T@TQFP44 [(SA245A)]
ST72C314N2B@SDIP56 [(PEP+S627)]	ST72C314N2T@TQFP64 [(PEP+S625A)]
ST72C314N4B@SDIP56 [(PEP+S627)]	ST72C314N4T@TQFP64 [(PEP+S625A)]
ST72C334J2B@SDIP42 [(SA028)]	ST72C334J2T@TQFP44 [(SA245A)]
ST72C334J4B@SDIP42 [(SA028)]	ST72C334J4T@TQFP44 [(SA245A)]
ST72C334N2B@SDIP56 [(PEP+S627)]	ST72C334N2T@TQFP64 [(PEP+S625A)]
ST72C334N4B@SDIP56 [(PEP+S627)]	ST72C334N4T@TQFP64 [(PEP+S625A)]
ST72F260G1B6@SDIP32 [(SA653)]	ST72F260G1M6@SOIC28 [(SA404)]
ST72F262G1B6@SDIP32 [(SA653)]	ST72F262G1M6@SOIC28 [(SA404)]
ST72F262G2B6@SDIP32 [(SA653)]	ST72F262G2M6@SOIC28 [(SA404)]
ST72F264G1B6@SDIP32 [(SA653)]	ST72F264G1M6@SOIC28 [(SA404)]
ST72F264G2B6@SDIP32 [(SA653)]	
ST72F264G2H1@LFBGA36 [(SA642G-B026A-T048F001N)]	
ST72F264G2H6@LFBGA36 [(SA642G-B026A-T048F001N)]	
ST72F264G2M6@SOIC28 [(SA404)]	
ST72F321AR6T6@TQFP64 [(PEP+S616)]	
ST72F321AR6TA@TQFP64 [(PEP+S616)]	
ST72F321AR7T6@TQFP64 [(PEP+S616)]	
ST72F321AR7TA@TQFP64 [(PEP+S616)]	
ST72F321AR9T6@TQFP64 [(PEP+S616)]	
ST72F321AR9TA@TQFP64 [(PEP+S616)]	
ST72F321AR9TC@TQFP64 [(PEP+S616)]	
ST72F321BAR6T6@TQFP64 [(PEP+S616)]	
ST72F321BAR6TA@TQFP64 [(PEP+S616)]	
ST72F321BAR7T6@TQFP64 [(PEP+S616)]	
ST72F321BAR7TA@TQFP64 [(PEP+S616)]	
ST72F321BAR9T6@TQFP64 [(PEP+S616)]	
ST72F321BAR9TA@TQFP64 [(PEP+S616)]	
ST72F321BAR9TC@TQFP64 [(PEP+S616)]	
ST72F321BJ7T6@TQFP44 [(SA245A)]	ST72F321BJ7TA@TQFP44 [(SA245A)]
ST72F321BJ9T6@TQFP44 [(SA245A)]	ST72F321BJ9TA@TQFP44 [(SA245A)]
ST72F321BJ9TC@TQFP44 [(SA245A)]	
ST72F321BR6T6@TQFP64 [(PEP+S625A)]	
ST72F321BR6TA@TQFP64 [(PEP+S625A)]	
ST72F321BR7T6@TQFP64 [(PEP+S625A)]	
ST72F321BR7TA@TQFP64 [(PEP+S625A)]	
ST72F321BR9T6@TQFP64 [(PEP+S625A)]	
ST72F321BR9TA@TQFP64 [(PEP+S625A)]	
ST72F321BR9TC@TQFP64 [(PEP+S625A)]	
ST72F321J7T6@TQFP44 [(SA245A)]	ST72F321J7TA@TQFP44 [(SA245A)]
ST72F321J9T6@TQFP44 [(SA245A)]	ST72F321J9TA@TQFP44 [(SA245A)]
ST72F321J9TC@TQFP44 [(SA245A)]	
ST72F321R6T6@TQFP64 [(PEP+S625A)]	
ST72F321R6TA@TQFP64 [(PEP+S625A)]	
ST72F321R7T6@TQFP64 [(PEP+S625A)]	
ST72F321R7TA@TQFP64 [(PEP+S625A)]	
ST72F321R9T6@TQFP64 [(PEP+S625A)]	
ST72F321R9TA@TQFP64 [(PEP+S625A)]	
ST72F321R9TC@TQFP64 [(PEP+S625A)]	
ST72F324BJ2B5@SDIP42 [(SA028)]	ST72F324BJ2B6@SDIP42 [(SA028)]
ST72F324BJ2T3@TQFP44 [(SA245A)]	ST72F324BJ2T5@TQFP44 [(SA245A)]
ST72F324BJ2T6@TQFP44 [(SA245A)]	ST72F324BJ4B5@SDIP42 [(SA028)]
ST72F324BJ4B6@SDIP42 [(SA028)]	ST72F324BJ4T3@TQFP44 [(SA245A)]
ST72F324BJ4T6@TQFP44 [(SA245A)]	ST72F324BJ6B5@SDIP42 [(SA028)]
ST72F324BJ6B6@SDIP42 [(SA028)]	ST72F324BJ6T3@TQFP44 [(SA245A)]
ST72F324BJ6T6@TQFP44 [(SA245A)]	ST72F324BK2B5@SDIP32 [(SA653)]
ST72F324BK2B6@SDIP32 [(SA653)]	ST72F324BK2T3@TQFP32 [(SA663)]
ST72F324BK2T5@TQFP32 [(SA663)]	ST72F324BK2T6@TQFP32 [(SA663)]
ST72F324BK4B5@SDIP32 [(SA653)]	ST72F324BK4B6@SDIP32 [(SA653)]
ST72F324BK4T3@TQFP32 [(SA663)]	ST72F324BK4T6@TQFP32 [(SA663)]
ST72F324BK6B5@SDIP32 [(SA653)]	ST72F324BK6B6@SDIP32 [(SA653)]
ST72F324BK6T3@TQFP32 [(SA663)]	ST72F324BK6T6@TQFP32 [(SA663)]
ST72F324J2B5@SDIP42 [(SA028)]	
ST72F324J2B5@SDIP42 (ISP) [ISP-HEADER01]	
ST72F324J2T6@TQFP44 [(SA245A)]	
ST72F324J2T6@TQFP44 (ISP) [ISP-HEADER01]	
ST72F324J2TA@TQFP44 [(SA245A)]	
ST72F324J2TA@TQFP44 (ISP) [ISP-HEADER01]	
ST72F324J4B5@SDIP42 [(SA028)]	
ST72F324J4B5@SDIP42 (ISP) [ISP-HEADER01]	

ST72F324J4T6@TQFP44 [(SA245A)]  
 ST72F324J4T6@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324J4TA@TQFP44 [(SA245A)]  
 ST72F324J4TA@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324J6B5@SDIP42 [(SA028)]  
 ST72F324J6B5@SDIP42 (ISP) [ISP-HEADER01]  
 ST72F324J6T3@TQFP44 [(SA245A)]  
 ST72F324J6T3@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324J6T5@TQFP44 [(SA245A)]  
 ST72F324J6T5@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324J6T6@TQFP44 [(SA245A)]  
 ST72F324J6T6@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324J6TA@TQFP44 [(SA245A)]  
 ST72F324J6TA@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324J6TC@TQFP44 [(SA245A)]  
 ST72F324J6TC@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324K2B5@SDIP32 [(SA653)]  
 ST72F324K2B5@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324K2B6@SDIP32 [(SA653)]  
 ST72F324K2B6@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324K2T6@TQFP32 [(SA663)]  
 ST72F324K2T6@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K2TA@TQFP32 [(SA663)]  
 ST72F324K2TA@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K4B5@SDIP32 [(SA653)]  
 ST72F324K4B5@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324K4B6@SDIP32 [(SA653)]  
 ST72F324K4B6@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324K4T6@TQFP32 [(SA663)]  
 ST72F324K4T6@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K4TA@TQFP32 [(SA663)]  
 ST72F324K4TA@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K6B5@SDIP32 [(SA653)]  
 ST72F324K6B5@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324K6B6@SDIP32 [(SA653)]  
 ST72F324K6B6@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324K6T5@TQFP32 [(SA663)]  
 ST72F324K6T5@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K6T6@TQFP32 [(SA663)]  
 ST72F324K6T6@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K6TA@TQFP32 [(SA663)]  
 ST72F324K6TA@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324K6TC@TQFP32 [(SA663)]  
 ST72F324K6TC@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LJ2T5@TQFP44 [(SA245A)]  
 ST72F324LJ2T5@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LJ2T6@TQFP44 [(SA245A)]  
 ST72F324LJ2T6@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LJ4T5@TQFP44 [(SA245A)]  
 ST72F324LJ4T5@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LJ4T6@TQFP44 [(SA245A)]  
 ST72F324LJ4T6@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LJ6T5@TQFP44 [(SA245A)]  
 ST72F324LJ6T5@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LJ6T6@TQFP44 [(SA245A)]  
 ST72F324LJ6T6@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LJ6TA@TQFP44 [(SA245A)]  
 ST72F324LJ6TA@TQFP44 (ISP) [ISP-HEADER01]  
 ST72F324LK2T5@TQFP32 [(SA663)]  
 ST72F324LK2T5@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LK2T6@TQFP32 [(SA663)]  
 ST72F324LK2T6@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LK4T5@TQFP32 [(SA663)]  
 ST72F324LK4T5@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LK4T6@TQFP32 [(SA663)]  
 ST72F324LK4T6@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LK6B5@SDIP32 [(SA653)]  
 ST72F324LK6B5@SDIP32 (ISP) [ISP-HEADER01]  
 ST72F324LK6T5@TQFP32 [(SA663)]  
 ST72F324LK6T5@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LK6T6@TQFP32 [(SA663)]  
 ST72F324LK6T6@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F324LK6TA@TQFP32 [(SA663)]  
 ST72F324LK6TA@TQFP32 (ISP) [ISP-HEADER01]  
 ST72F325AR6T6@TQFP64 [(PEP+S616)]  
 ST72F325AR7T6@TQFP64 [(PEP+S616)]  
 ST72F325AR9T6@TQFP64 [(PEP+S616)]  
 ST72F325C4T6@TQFP48 [(SA248)] ST72F325C6T6@TQFP48 [(SA248)]  
 ST72F325C7T6@TQFP48 [(SA248)] ST72F325C9T6@TQFP48 [(SA248)]  
 ST72F325J4T6@TQFP44 [(SA245A)] ST72F325J6B5@SDIP42 [(SA028)]  
 ST72F325J6B6@SDIP42 [(SA028)]

```

ST72F325J6B6@SDIP42 ( ISP ) [ ISP-HEADER01 ]
ST72F325J6T6@TQFP44 [ ( SA245A ) ] ST72F325J7T6@TQFP44 [ ( SA245A ) ]
ST72F325J9T6@TQFP44 [ ( SA245A ) ] ST72F325K4B5@SDIP32 [ ( SA653 ) ]
ST72F325K4T6@TQFP32 [ ( SA663 ) ] ST72F325K6B5@SDIP32 [ ( SA653 ) ]
ST72F325K6B6@SDIP32 [ ( SA653 ) ]
ST72F325K6B6@SDIP32 ( ISP ) [ ISP-HEADER01 ]
ST72F325K6T6@TQFP32 [ ( SA663 ) ]
ST72F325R6T6@TQFP64 [ ( PEP+S625A ) ]
ST72F325R7T6@TQFP64 [ ( PEP+S625A ) ]
ST72F325R9T6@TQFP64 [ ( PEP+S625A ) ]
ST72F32AJ1B5@SDIP42 [ ( SA028 ) ] ST72F32AJ1B6@SDIP42 [ ( SA028 ) ]
ST72F32AJ1T5@TQFP44 [ ( SA245A ) ] ST72F32AJ1T6@TQFP44 [ ( SA245A ) ]
ST72F32AJ2B5@SDIP42 [ ( SA028 ) ] ST72F32AJ2B6@SDIP42 [ ( SA028 ) ]
ST72F32AJ2T5@TQFP44 [ ( SA245A ) ] ST72F32AJ2T6@TQFP44 [ ( SA245A ) ]
ST72F32AJ2TA@TQFP44 [ ( SA245A ) ] ST72F32AJ2TB@TQFP44 [ ( SA245A ) ]
ST72F32AJ2TC@TQFP44 [ ( SA245A ) ] ST72F32AK1B5@SDIP32 [ ( SA653 ) ]
ST72F32AK1B6@SDIP32 [ ( SA653 ) ] ST72F32AK1T5@TQFP32 [ ( SA663 ) ]
ST72F32AK1T6@TQFP32 [ ( SA663 ) ] ST72F32AK2B5@SDIP32 [ ( SA653 ) ]
ST72F32AK2B6@SDIP32 [ ( SA653 ) ] ST72F32AK2T5@TQFP32 [ ( SA663 ) ]
ST72F32AK2T6@TQFP32 [ ( SA663 ) ] ST72F32AK2TA@TQFP32 [ ( SA663 ) ]
ST72F32AK2TB@TQFP32 [ ( SA663 ) ] ST72F32AK2TC@TQFP32 [ ( SA663 ) ]
ST72F340K2T6@LQFP32 [ ( SA663 ) ] ST72F340K4T6@LQFP32 [ ( SA663 ) ]
ST72F340S2T6@LQFP44 [ ( SA245A ) ] ST72F340S4T6@LQFP44 [ ( SA245A ) ]
ST72F344K2T6@LQFP32 [ ( SA663 ) ] ST72F344K4T6@LQFP32 [ ( SA663 ) ]
ST72F344S2T6@LQFP44 [ ( SA245A ) ] ST72F344S4T6@LQFP44 [ ( SA245A ) ]
ST72F345C2T6@LQFP48 [ ( SA248 ) ] ST72F345C4T6@LQFP48 [ ( SA248 ) ]
ST72F361AR4T3@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR4T6@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR4TA@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR4TC@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR6T3@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR6T6@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR6TA@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR6TC@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR7T3@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR7T6@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR7TA@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR7TC@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR9T3@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR9T6@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR9TA@TQFP64 [ ( PEP+S616 ) ]
ST72F361AR9TC@TQFP64 [ ( PEP+S616 ) ]
ST72F361J4T3@TQFP44 [ ( SA245A ) ] ST72F361J4T6@TQFP44 [ ( SA245A ) ]
ST72F361J4TA@TQFP44 [ ( SA245A ) ] ST72F361J4TC@TQFP44 [ ( SA245A ) ]
ST72F361J6T3@TQFP44 [ ( SA245A ) ] ST72F361J6T6@TQFP44 [ ( SA245A ) ]
ST72F361J6TA@TQFP44 [ ( SA245A ) ] ST72F361J6TC@TQFP44 [ ( SA245A ) ]
ST72F361J7T3@TQFP44 [ ( SA245A ) ] ST72F361J7T6@TQFP44 [ ( SA245A ) ]
ST72F361J7TA@TQFP44 [ ( SA245A ) ] ST72F361J7TC@TQFP44 [ ( SA245A ) ]
ST72F361J9T3@TQFP44 [ ( SA245A ) ] ST72F361J9T6@TQFP44 [ ( SA245A ) ]
ST72F361J9TA@TQFP44 [ ( SA245A ) ] ST72F361J9TC@TQFP44 [ ( SA245A ) ]
ST72F361K4T3@TQFP32 [ ( SA663 ) ] ST72F361K4T6@TQFP32 [ ( SA663 ) ]
ST72F361K4TA@TQFP32 [ ( SA663 ) ] ST72F361K4TC@TQFP32 [ ( SA663 ) ]
ST72F361K6T3@TQFP32 [ ( SA663 ) ] ST72F361K6T6@TQFP32 [ ( SA663 ) ]
ST72F361K6TA@TQFP32 [ ( SA663 ) ] ST72F361K6TC@TQFP32 [ ( SA663 ) ]
ST72F361K7T3@TQFP32 [ ( SA663 ) ] ST72F361K7T6@TQFP32 [ ( SA663 ) ]
ST72F361K7TA@TQFP32 [ ( SA663 ) ] ST72F361K7TC@TQFP32 [ ( SA663 ) ]
ST72F361K9T3@TQFP32 [ ( SA663 ) ] ST72F361K9T6@TQFP32 [ ( SA663 ) ]
ST72F361K9TA@TQFP32 [ ( SA663 ) ] ST72F361K9TC@TQFP32 [ ( SA663 ) ]
ST72F361R4T3@TQFP64 [ ( PEP+S625A ) ]
ST72F361R4T6@TQFP64 [ ( PEP+S625A ) ]
ST72F361R4TA@TQFP64 [ ( PEP+S625A ) ]
ST72F361R4TC@TQFP64 [ ( PEP+S625A ) ]
ST72F361R6T3@TQFP64 [ ( PEP+S625A ) ]
ST72F361R6T6@TQFP64 [ ( PEP+S625A ) ]
ST72F361R6TA@TQFP64 [ ( PEP+S625A ) ]
ST72F361R6TC@TQFP64 [ ( PEP+S625A ) ]
ST72F361R7T3@TQFP64 [ ( PEP+S625A ) ]
ST72F361R7T6@TQFP64 [ ( PEP+S625A ) ]
ST72F361R7TA@TQFP64 [ ( PEP+S625A ) ]
ST72F361R7TC@TQFP64 [ ( PEP+S625A ) ]
ST72F361R9T3@TQFP64 [ ( PEP+S625A ) ]
ST72F361R9T6@TQFP64 [ ( PEP+S625A ) ]
ST72F361R9TA@TQFP64 [ ( PEP+S625A ) ]
ST72F361R9TC@TQFP64 [ ( PEP+S625A ) ]
ST72F521AR6T6@TQFP64 [ ( PEP+S616 ) ]
ST72F521AR6TC@TQFP64 [ ( PEP+S616 ) ]
ST72F521AR9T6@TQFP64 [ ( PEP+S616 ) ]
ST72F521AR9TC@TQFP64 [ ( PEP+S616 ) ]
ST72F521BAR6T6@TQFP64 [ ( PEP+S616 ) ]
ST72F521BAR6TC@TQFP64 [ ( PEP+S616 ) ]
ST72F521BAR9T6@TQFP64 [ ( PEP+S616 ) ]

```

```

ST72F521BAR9TC@TQFP64 [(PEP+S616)]
ST72F521BM9T3@TQFP80 [(PEP+S615B)]
ST72F521BM9T6@TQFP80 [(PEP+S615B)]
ST72F521BM9TC@TQFP80 [(PEP+S615B)]
ST72F521BR6T6@TQFP64 [(PEP+S625A)]
ST72F521BR6TC@TQFP64 [(PEP+S625A)]
ST72F521BR9T3@TQFP64 [(PEP+S625A)]
ST72F521BR9T6@TQFP64 [(PEP+S625A)]
ST72F521BR9TC@TQFP64 [(PEP+S625A)]
ST72F521M9T3@TQFP80 [(PEP+S615B)]
ST72F521M9T6@TQFP80 [(PEP+S615B)]
ST72F521M9TC@TQFP80 [(PEP+S615B)]
ST72F521R6T6@TQFP64 [(PEP+S625A)]
ST72F521R6TC@TQFP64 [(PEP+S625A)]
ST72F521R9T3@TQFP64 [(PEP+S625A)]
ST72F521R9T6@TQFP64 [(PEP+S625A)]
ST72F521R9TC@TQFP64 [(PEP+S625A)]
ST72F561AR4T3@TQFP64 [(PEP+S616)]
ST72F561AR4T6@TQFP64 [(PEP+S616)]
ST72F561AR4TA@TQFP64 [(PEP+S616)]
ST72F561AR4TC@TQFP64 [(PEP+S616)]
ST72F561AR6T3@TQFP64 [(PEP+S616)]
ST72F561AR6T6@TQFP64 [(PEP+S616)]
ST72F561AR6TA@TQFP64 [(PEP+S616)]
ST72F561AR6TC@TQFP64 [(PEP+S616)]
ST72F561AR7T3@TQFP64 [(PEP+S616)]
ST72F561AR7T6@TQFP64 [(PEP+S616)]
ST72F561AR7TA@TQFP64 [(PEP+S616)]
ST72F561AR7TC@TQFP64 [(PEP+S616)]
ST72F561AR9T3@TQFP64 [(PEP+S616)]
ST72F561AR9T6@TQFP64 [(PEP+S616)]
ST72F561AR9TA@TQFP64 [(PEP+S616)]
ST72F561AR9TC@TQFP64 [(PEP+S616)]
ST72F561J4T3@TQFP44 [(SA245A)]
ST72F561J4TA@TQFP44 [(SA245A)]
ST72F561J6T3@TQFP44 [(SA245A)]
ST72F561J6TA@TQFP44 [(SA245A)]
ST72F561J7T3@TQFP44 [(SA245A)]
ST72F561J7TA@TQFP44 [(SA245A)]
ST72F561J9T3@TQFP44 [(SA245A)]
ST72F561J9TA@TQFP44 [(SA245A)]
ST72F561K4T3@TQFP32 [(SA663)]
ST72F561K4TA@TQFP32 [(SA663)]
ST72F561K6T3@TQFP32 [(SA663)]
ST72F561K6TA@TQFP32 [(SA663)]
ST72F561K7T3@TQFP32 [(SA663)]
ST72F561K7TA@TQFP32 [(SA663)]
ST72F561K9T3@TQFP32 [(SA663)]
ST72F561K9TA@TQFP32 [(SA663)]
ST72F561R4T3@TQFP64 [(PEP+S625A)]
ST72F561R4T6@TQFP64 [(PEP+S625A)]
ST72F561R4TA@TQFP64 [(PEP+S625A)]
ST72F561R4TC@TQFP64 [(PEP+S625A)]
ST72F561R6T3@TQFP64 [(PEP+S625A)]
ST72F561R6T6@TQFP64 [(PEP+S625A)]
ST72F561R6TA@TQFP64 [(PEP+S625A)]
ST72F561R6TC@TQFP64 [(PEP+S625A)]
ST72F561R7T3@TQFP64 [(PEP+S625A)]
ST72F561R7T6@TQFP64 [(PEP+S625A)]
ST72F561R7TA@TQFP64 [(PEP+S625A)]
ST72F561R7TC@TQFP64 [(PEP+S625A)]
ST72F561R9T3@TQFP64 [(PEP+S625A)]
ST72F561R9T6@TQFP64 [(PEP+S625A)]
ST72F561R9TA@TQFP64 [(PEP+S625A)]
ST72F561R9TC@TQFP64 [(PEP+S625A)]
ST72F60D4U1@QFN40 [(SA750)]
ST72F60D4U1@QFN40 (ISP) [ISP-HEADER01]
ST72F60D6U1@QFN40 [(SA750)]
ST72F60D6U1@QFN40 (ISP) [ISP-HEADER01]
ST72F60E1M1@SOIC24 [(SA404)]
ST72F60E1M1@SOIC24 (ISP) [ISP-HEADER01]
ST72F60E2M1@SOIC24 [(SA404)]
ST72F60E2M1@SOIC24 (ISP) [ISP-HEADER01]
ST72F60E4M1@SOIC24 [(SA404)]
ST72F60E4M1@SOIC24 (ISP) [ISP-HEADER01]
ST72F60E6M1@SOIC24 [(SA404)]
ST72F60E6M1@SOIC24 (ISP) [ISP-HEADER01]
ST72F60K1U1@QFN40 [(SA750)]
ST72F60K1U1@QFN40 (ISP) [ISP-HEADER01]
ST72F60K2U1@QFN40 [(SA750)]
ST72F60K2U1@QFN40 (ISP) [ISP-HEADER01]
ST72F561J4T6@TQFP44 [(SA245A)]
ST72F561J4TC@TQFP44 [(SA245A)]
ST72F561J6T6@TQFP44 [(SA245A)]
ST72F561J6TC@TQFP44 [(SA245A)]
ST72F561J7T6@TQFP44 [(SA245A)]
ST72F561J7TC@TQFP44 [(SA245A)]
ST72F561J9T6@TQFP44 [(SA245A)]
ST72F561J9TC@TQFP44 [(SA245A)]
ST72F561K4T6@TQFP32 [(SA663)]
ST72F561K4TC@TQFP32 [(SA663)]
ST72F561K6T6@TQFP32 [(SA663)]
ST72F561K6TC@TQFP32 [(SA663)]
ST72F561K7T6@TQFP32 [(SA663)]
ST72F561K7TC@TQFP32 [(SA663)]
ST72F561K9T6@TQFP32 [(SA663)]
ST72F561K9TC@TQFP32 [(SA663)]

```

ST72F621J4B1@SDIP42 [(SA028)] ST72F621J4T1@TQFP44 [(SA245A)]  
 ST72F621K4B1@SDIP32 [(SA653)] ST72F621L4M1@SOIC34 [(SA658)]  
 ST72F622L2M1@SOIC34 [(SA658)] ST72F623F2B1  
 ST72F623F2M1@SOIC20 [(SA404)] ST72F63BD4U1@QFN40 [(SA750)]  
 ST72F63BD4U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F63BD6U1@QFN40 [(SA750)]  
 ST72F63BD6U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F63BE1M1@SOP24 [(SA404)]  
 ST72F63BE1M1@SOP24 (ISP) [ISP-HEADER01]  
 ST72F63BE2M1@SOP24 [(SA404)]  
 ST72F63BE2M1@SOP24 (ISP) [ISP-HEADER01]  
 ST72F63BE4M1@SOP24 [(SA404)]  
 ST72F63BE4M1@SOP24 (ISP) [ISP-HEADER01]  
 ST72F63BE6M1@SOP24 [(SA404)]  
 ST72F63BE6M1@SOP24 (ISP) [ISP-HEADER01]  
 ST72F63BH1T1@QFP48 [(SA248)]  
 ST72F63BH1T1@QFP48 (ISP) [ISP-HEADER01]  
 ST72F63BH2T1@QFP48 [(SA248)]  
 ST72F63BH2T1@QFP48 (ISP) [ISP-HEADER01]  
 ST72F63BH4T1@QFP48 [(SA248)]  
 ST72F63BH4T1@QFP48 (ISP) [ISP-HEADER01]  
 ST72F63BH6T1@QFP48 [(SA248)]  
 ST72F63BH6T1@QFP48 (ISP) [ISP-HEADER01]  
 ST72F63BK1B1@SOIC34 [(SA653)]  
 ST72F63BK1B1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK1M1@SOIC34 [(SA658)]  
 ST72F63BK1M1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK1U1@QFN40 [(SA750)]  
 ST72F63BK1U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F63BK2B1@SOIC34 [(SA653)]  
 ST72F63BK2B1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK2M1@SOIC34 [(SA658)]  
 ST72F63BK2M1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK2U1@QFN40 [(SA750)]  
 ST72F63BK2U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F63BK4B1@SOIC34 [(SA653)]  
 ST72F63BK4B1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK4M1@SOIC34 [(SA658)]  
 ST72F63BK4M1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK6B1@SOIC34 [(SA653)]  
 ST72F63BK6B1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F63BK6M1@SOIC34 [(SA658)]  
 ST72F63BK6M1@SOIC34 (ISP) [ISP-HEADER01]  
 ST72F651AR6T1@TQFP64 [(PEP+S616)]  
 ST72F651AR6T1@TQFP64 [(PEP+S616)]  
 ST72T101G1B@SDIP32 [(SA653)] ST72T101G1M@SOIC28 [(SA404)]  
 ST72T101G2B@SDIP32 [(SA653)] ST72T101G2M@SOIC28 [(SA404)]  
 ST72T121J2B@SDIP42 [(SA028)] ST72T121J2T@TQFP44 [(SA245A)]  
 ST72T121J4B@SDIP42 [(SA028)] ST72T121J4T@TQFP44 [(SA245A)]  
 ST72T141K2B@SDIP32 [(SA653)] ST72T141K2M@SSOP34 [(SA658)]  
 ST72T212G2B@SDIP32 [(SA653)] ST72T212G2M@SOIC28 [(SA404)]  
 ST72T213G1B@SDIP32 [(SA653)] ST72T213G1M@SOIC28 [(SA404)]  
 ST72T251G1B@SDIP32 [(SA653)] ST72T251G1M@SOIC28 [(SA404)]  
 ST72T251G2B@SDIP32 [(SA653)] ST72T251G2M@SOIC28 [(SA404)]  
 ST72T272K4B@SDIP32 [(SA653)] ST72T272K4M@SSOP34 [(SA658)]  
 ST72T311J2B@SDIP42 [(SA028)] ST72T311J2T@TQFP44 [(SA245A)]  
 ST72T311J4B@SDIP42 [(SA028)] ST72T311J4T@TQFP44 [(SA245A)]  
 ST72T311N2B@SDIP56 [(PEP+S627)] ST72T311N2T@TQFP64 [(PEP+S625A)]  
 ST72T311N4B@SDIP56 [(PEP+S627)] ST72T311N4T@TQFP64 [(PEP+S625A)]  
 ST72T311R6T@TQFP64 [(PEP+S625A)] ST72T311R7T@TQFP64 [(PEP+S625A)]  
 ST72T311R9T@TQFP64 [(PEP+S625A)] ST72T331J2B@SDIP42 [(SA028)]  
 ST72T331J2T@TQFP44 [(SA245A)] ST72T331J4B@SDIP42 [(SA028)]  
 ST72T331J4T@TQFP44 [(SA245A)] ST72T331N2B@SDIP56 [(PEP+S627)]  
 ST72T331N2T@TQFP64 [(PEP+S625A)] ST72T331N4B@SDIP56 [(PEP+S627)]  
 ST72T331N4T@TQFP64 [(PEP+S625A)]  
 ST72T371N4B@SDIP56 (\*) [(SA627-B5601)]  
 ST72T371N4T@TQFP64 [(PEP+S625A)] ST72T372J4B@SDIP42 [(SA028)]  
 ST72T511R6T@TQFP64 [(PEP+S625A)] ST72T511R7T@TQFP64 [(PEP+S625A)]  
 ST72T511R9T@TQFP64 [(PEP+S625A)] ST72T512R4T@TQFP64 [(PEP+S625A)]  
 ST72T532R4T@TQFP64 [(PEP+S625A)] ST72T631K4B1@SDIP32 [(SA653)]  
 ST72T631K4M1@SSOP34 [(SA658)] ST72T632K2B1@SDIP32 [(SA653)]  
 ST72T632K2M1@SSOP34 [(SA658)] ST72T633K1B1@SDIP32 [(SA653)]  
 ST72T633K1M1@SSOP34 [(SA658)]  
 ST72T671N6B@SDIP56 (\*) [(SA627-B5601)]  
 ST72T671N6T@TQFP64 [(PEP+S625A)]  
 ST72T751N9B@SDIP56 (\*) [(SA627-B5601)]  
 ST72T752J6B@SDIP42 [(SA028)] ST72T753L6M@SSOP34 [(SA658)]  
 ST72T771N9B@SDIP56 (\*) [(SA627-B5601)]  
 ST72T771R9T@TQFP64 [(PEP+S625A)] ST7FAUDIO@LQFP64 [(PEP+S616)]  
 ST7FAUDIO@LQFP64 (\*) [(SA732+B329)]  
 ST7FAUDIOAR9@LQFP64 [(PEP+S616)]

```

ST7FAUDIOAR9@LQFP64(*) [(SA732+B329)]
ST7FDALIF2M6@SOIC20 [(SA404)]
ST7FDALIF2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLI49MK1B6@SDIP32 [(SA653)]
ST7FLI49MK1T6@TQFP32 [(SA663)]
ST7FLIT10BF0B3
ST7FLIT10BF0B6
ST7FLIT10BF0M3@SOIC20 [(SA404)]
ST7FLIT10BF0M6@SOIC20 [(SA404)]
ST7FLIT10BF1B3
ST7FLIT10BF1M6@SOIC20 [(SA404)]
ST7FLIT10BF1M6@SOIC20 [(SA404)]
ST7FLIT10BY0B3
ST7FLIT10BY0B6
ST7FLIT10BY0M3@SOIC16 [(SA602)]
ST7FLIT10BY0M6@SOIC16 [(SA602)]
ST7FLIT10BY1B3
ST7FLIT10BY1M6@SOIC16 [(SA602)]
ST7FLIT10BY1M6@SOIC16 [(SA602)]
ST7FLIT15BF0B3
ST7FLIT15BF0B6
ST7FLIT15BF0M3@SOIC20 [(SA404)]
ST7FLIT15BF0M6@SOIC20 [(SA404)]
ST7FLIT15BF1B3
ST7FLIT15BF1M6@SOIC20 [(SA404)]
ST7FLIT15BF1M6@SOIC20 [(SA404)]
ST7FLIT15BF1U6TR@QFN20 [(BBBB)]
ST7FLIT15BY0B3
ST7FLIT15BY0M3@SOIC16 [(SA602)]
ST7FLIT15BY1B3
ST7FLIT15BY1M3@SOIC16 [(SA602)]
ST7FLIT15BY1M3@SOIC16 [(SA602)]
ST7FLIT19BF0B3
ST7FLIT19BF0B6
ST7FLIT19BF0M3@SOIC20 [(SA404)]
ST7FLIT19BF1B3
ST7FLIT19BF1M3@SOIC20 [(SA404)]
ST7FLIT19BF1M3@SOIC20 [(SA404)]
ST7FLIT19BF1U6TR@QFN20 [(BBBB)]
ST7FLIT19BY0B3
ST7FLIT19BY0M3@SOIC16 [(SA602)]
ST7FLIT19BY1B3
ST7FLIT19BY1M6@SOIC16 [(SA602)]
ST7FLIT19BY1M6@SOIC16 [(SA602)]
ST7FLITE02B6
ST7FLITE02B6(ISP) [ISP-HEADER01]
ST7FLITE02M6@SOIC16 [(SA602)]
ST7FLITE02M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE02Y0B6
ST7FLITE02Y0B6(ISP) [ISP-HEADER01]
ST7FLITE02Y0M6@SOIC16 [(SA602)]
ST7FLITE02Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE05B6
ST7FLITE05B6(ISP) [ISP-HEADER01]
ST7FLITE05M6@SOIC16 [(SA602)]
ST7FLITE05M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE05Y0B6
ST7FLITE05Y0B6(ISP) [ISP-HEADER01]
ST7FLITE05Y0M6@SOIC16 [(SA602)]
ST7FLITE05Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE09B6
ST7FLITE09B6(ISP) [ISP-HEADER01]
ST7FLITE09M6@SOIC16 [(SA602)]
ST7FLITE09M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE09Y0B6
ST7FLITE09Y0B6(ISP) [ISP-HEADER01]
ST7FLITE09Y0M6@SOIC16 [(SA602)]
ST7FLITE09Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE10F1B6
ST7FLITE10F1B6(ISP) [ISP-HEADER01]
ST7FLITE10F1M6@SOIC20 [(SA404)]
ST7FLITE10F1M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE15F1B6
ST7FLITE15F1B6(ISP) [ISP-HEADER01]
ST7FLITE15F1M6@SOIC20 [(SA404)]
ST7FLITE15F1M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE19F1B6
ST7FLITE19F1B6(ISP) [ISP-HEADER01]
ST7FLITE19F1M6@SOIC20 [(SA404)]
ST7FLITE19F1M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE20F2B6
ST7FLITE20F2B6(ISP) [ISP-HEADER01]
ST7FLITE20F2M6@SOIC20 [(SA404)]
ST7FLITE20F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE25F2B6
ST7FLITE25F2B6(ISP) [ISP-HEADER01]
ST7FLITE25F2M6@SOIC20 [(SA404)]
ST7FLITE25F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE29F2B6
ST7FLITE29F2B6(ISP) [ISP-HEADER01]
ST7FLITE29F2M6@SOIC20 [(SA404)]
ST7FLITE29F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE30F2B6
ST7FLITE30F2B6(ISP) [ISP-HEADER01]
ST7FLITE30F2M6@SOIC20 [(SA404)]
ST7FLITE30F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE35F2B6
ST7FLITE35F2B6(ISP) [ISP-HEADER01]
ST7FLITE35F2M6@SOIC20 [(SA404)]

```

```

ST7FLITE35F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE39F2B6
ST7FLITE39F2B6(ISP) [ISP-HEADER01]
ST7FLITE39F2M6@SOIC20 [(SA404)]
ST7FLITE39F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE49
ST7FLITE49@TQFP32 [(SA663)]
ST7FLITE49@QFN40 [(SA750)]
ST7FLITEBCM6@SOIC16 [(SA602)]
ST7FLITEBC
ST7FLITES0@SOIC16 [(SA602)]
ST7FLITES0
ST7FLITES2B6(ISP) [ISP-HEADER01]
ST7FLITES2M6@SOIC16 [(SA602)]
ST7FLITES2M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITES2Y0B6
ST7FLITES2Y0B6(ISP) [ISP-HEADER01]
ST7FLITES2Y0M6@SOIC16 [(SA602)]
ST7FLITES2Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITES5B6
ST7FLITES5B6(ISP) [ISP-HEADER01]
ST7FLITES5M6@SOIC16 [(SA602)]
ST7FLITES5M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITES5Y0B6
ST7FLITES5Y0B6(ISP) [ISP-HEADER01]
ST7FLITES5Y0M6@SOIC16 [(SA602)]
ST7FLITES5Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITEU05B3
ST7FLITEU05M3@SO8 [(SA602A)]
ST7FLITEU05M3TR@SO8 [(SA602A)]
ST7FLITEU05M6@SO8 [(SA602A)]
ST7FLITEU05M6TR@SO8 [(SA602A)]
ST7FLITEU05U3@DFN8 [(BBBB)]
ST7FLITEU05U3TR@DFN8 [(BBBB)]
ST7FLITEU05U6@DFN8 [(BBBB)]
ST7FLITEU05U6TR@DFN8 [(BBBB)]
ST7FLITEU09B3
ST7FLITEU09M3@SO8 [(SA602A)]
ST7FLITEU09M3TR@SO8 [(SA602A)]
ST7FLITEU09M6@SO8 [(SA602A)]
ST7FLITEU09M6TR@SO8 [(SA602A)]
ST7FLITEU09U3@DFN8 [(BBBB)]
ST7FLITEU09U3TR@DFN8 [(BBBB)]
ST7FLITEU09U6@DFN8 [(BBBB)]
ST7FLITEU09U6TR@DFN8 [(BBBB)]
ST7FLITEUS2B6
ST7FLITEUS2M6TR@SOIC8 [(SA602A)]
ST7FLITEUS2U6TR@DFN8 [(BBBB)]
ST7FLITEUS5B6
ST7FLITEUS5M6@SOIC8 [(SA602A)]
ST7FLITEUS5U6TR@DFN8 [(BBBB)]
ST7FLU05B6
ST7FLU05BAE
ST7FLU05BATRE
ST7FLU05BCE
ST7FLU05BCTRE
ST7FLU05M6@SOIC8 [(SA602A)]
ST7FLU05MATRE@SOIC8 [(SA602A)]
ST7FLU05MCE@SOIC8 [(SA602A)]
ST7FLU05MCTRE@SOIC8 [(SA602A)]
ST7FLU09B6
ST7FLU09BAE
ST7FLU09BATRE
ST7FLU09BCE
ST7FLU09BCTRE
ST7FLU09M6@SOIC8 [(SA602A)]
ST7FLU09MATRE@SOIC8 [(SA602A)]
ST7FLU09MCE@SOIC8 [(SA602A)]
ST7FLU09MCTRE@SOIC8 [(SA602A)]
ST7FLUS5B6
ST7FLUS5BAE
ST7FLUS5BATRE
ST7FLUS5BCE
ST7FLUS5BCTRE
ST7FLUS5M6@SOIC8 [(SA602A)]
ST7FLUS5MATRE@SOIC8 [(SA602A)]
ST7FLUS5MCE@SOIC8 [(SA602A)]
ST7FLUS5MCTRE@SOIC8 [(SA602A)]
ST7FMC1K2B6@SDIP32 [(SA653)]
ST7FMC1K2B6@SDIP32(ISP) [ISP-HEADER01]
ST7FMC1K2T3@TQFP32 [(SA663)]
ST7FMC1K2T3@TQFP32(ISP) [ISP-HEADER01]
ST7FMC1K2T6@TQFP32 [(SA663)]
ST7FMC1K2T6@TQFP32(ISP) [ISP-HEADER01]
ST7FMC1K2TC@TQFP32 [(SA663)]
ST7FMC1K2TC@TQFP32(ISP) [ISP-HEADER01]
ST7FMC1K4T6@TQFP32 [(SA663)]
ST7FMC1K4T6@TQFP32(ISP) [ISP-HEADER01]
ST7FMC1K6TC@TQFP32 [(SA663)]
ST7FMC1K6TC@TQFP32(ISP) [ISP-HEADER01]
ST7FMC2M9T6@LQFP80(ISP) [ISP-HEADER01]
ST7FMC2N6B6@SDIP56 [(PEP+S627)]
ST7FMC2N6B6@SDIP56(ISP) [ISP-HEADER01]
ST7FMC2R6T6@TQFP64 [(PEP+S625A)]
ST7FMC2R6T6@TQFP64(ISP) [ISP-HEADER01]
ST7FMC2R7T6@TQFP64 [(PEP+S625A)]
ST7FMC2R7T6@TQFP64(ISP) [ISP-HEADER01]
ST7FMC2S4T3@TQFP44 [(SA245A)]
ST7FMC2S4T3@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S4T6@TQFP44 [(SA245A)]
ST7FMC2S4T6@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S4TC@TQFP44 [(SA245A)]
ST7FMC2S4TC@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S5T6@TQFP44 [(SA245A)]
ST7FMC2S5T6@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S5TC@TQFP44 [(SA245A)]
ST7FMC2S5TC@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S6T3@TQFP44 [(SA245A)]

```



```

ST7FMC2S6T3@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S6T6@TQFP44 [(SA245A)]
ST7FMC2S6T6@TQFP44(ISP) [ISP-HEADER01]
ST7FMC2S6TC@TQFP44 [(SA245A)]
ST7FMC2S6TC@TQFP44(ISP) [ISP-HEADER01]
ST7FOXA0B6 ST7FOXA0M6@S08 [(SA602A)]
ST7FOXFB6 ST7FOXFLM6@SOIC20 [(SA404)]
ST7FOXFB6 ST7FOXFM6@SOIC20 [(SA404)]
ST7FOXK1B6@SDIP32 [(SA653)] ST7FOXK1T6@QFP32 [(SA663)]
ST7FOXK2B6@SDIP32 [(SA653)] ST7FOXK2T6@QFP32 [(SA663)]
ST7FOXU0B6 ST7FOXU0M6@S08 [(SA602A)]
ST7FSCR1E4M1@SOIC24(*) [(SA404-B140)]
ST7FSCR1R4T1@TQFP64(*) [(TA032-B006)]
ST92T165@TQFP64 [(PEP+S625)] STR910FM@QFP80 [(PEP+S640B)]
STR911FM@QFP80 [(PEP+S640B)] STR912FM@QFP80 [(PEP+S640B)]
uPSD3212A@TQFP52 [(PEP+S673)] uPSD3212A@TQFP80 [(PEP+S640B)]
uPSD3212AV@TQFP52 [(PEP+S673)] uPSD3212AV@TQFP80 [(PEP+S640B)]
uPSD3212B@TQFP52 [(PEP+S673)] uPSD3212B@TQFP80 [(PEP+S640B)]
uPSD3212BV@TQFP52 [(PEP+S673)] uPSD3212BV@TQFP80 [(PEP+S640B)]
uPSD3212C@TQFP52 [(PEP+S673)] uPSD3212C@TQFP80 [(PEP+S640B)]
uPSD3212CV@TQFP52 [(PEP+S673)] uPSD3212CV@TQFP80 [(PEP+S640B)]
uPSD3233B@TQFP52 [(PEP+S673)] uPSD3233B@TQFP80 [(PEP+S640B)]
uPSD3233BV@TQFP52 [(PEP+S673)] uPSD3233BV@TQFP80 [(PEP+S640B)]
uPSD3234A@TQFP52 [(PEP+S673)] uPSD3234A@TQFP80 [(PEP+S640B)]
uPSD3234BV@TQFP52 [(PEP+S673)] uPSD3234BV@TQFP80 [(PEP+S640B)]
uPSD3253B@TQFP52 [(PEP+S673)] uPSD3253B@TQFP80 [(PEP+S640B)]
uPSD3253BV@TQFP52 [(PEP+S673)] uPSD3253BV@TQFP80 [(PEP+S640B)]
uPSD3254A(new)@TQFP52 [(PEP+S673)] uPSD3254A@TQFP80 [(PEP+S640B)]
uPSD3254A(new)@TQFP80 [(PEP+S640B)]
uPSD3254A@TQFP52 [(PEP+S673)] uPSD3254A@TQFP80 [(PEP+S640B)]
uPSD3254BV(new)@TQFP52 [(PEP+S673)]
uPSD3254BV(new)@TQFP80 [(PEP+S640B)]
uPSD3254BV@TQFP52 [(PEP+S673)] uPSD3254BV@TQFP80 [(PEP+S640B)]
uPSD3312D@TQFP52 [(PEP+S673)] uPSD3312D@TQFP80 [(PEP+S640B)]
uPSD3312DB@TQFP52 [(PEP+S673)] uPSD3312DB@TQFP80 [(PEP+S640B)]
uPSD3312DV@TQFP52 [(PEP+S673)] uPSD3312DV@TQFP80 [(PEP+S640B)]
uPSD3312DVB@TQFP52 [(PEP+S673)] uPSD3312DVB@TQFP80 [(PEP+S640B)]
uPSD3333D@TQFP52 [(PEP+S673)] uPSD3333D@TQFP80 [(PEP+S640B)]
uPSD3333DB@TQFP52 [(PEP+S673)] uPSD3333DB@TQFP80 [(PEP+S640B)]
uPSD3333DV@TQFP52 [(PEP+S673)] uPSD3333DV@TQFP80 [(PEP+S640B)]
uPSD3333DVB@TQFP52 [(PEP+S673)] uPSD3333DVB@TQFP80 [(PEP+S640B)]
uPSD3334D@TQFP52 [(PEP+S673)] uPSD3334D@TQFP80 [(PEP+S640B)]
uPSD3334DB@TQFP52 [(PEP+S673)] uPSD3334DB@TQFP80 [(PEP+S640B)]
uPSD3334DV@TQFP52 [(PEP+S673)] uPSD3334DV@TQFP80 [(PEP+S640B)]
uPSD3334DVB@TQFP52 [(PEP+S673)] uPSD3334DVB@TQFP80 [(PEP+S640B)]
uPSD3354D@TQFP52 [(PEP+S673)] uPSD3354D@TQFP80 [(PEP+S640B)]
uPSD3354DB@TQFP52 [(PEP+S673)] uPSD3354DB@TQFP80 [(PEP+S640B)]
uPSD3354DV@TQFP52 [(PEP+S673)] uPSD3354DV@TQFP80 [(PEP+S640B)]
uPSD3354DVB@TQFP52 [(PEP+S673)] uPSD3354DVB@TQFP80 [(PEP+S640B)]
uPSD3422E@TQFP52 [(PEP+S673)] uPSD3422E@TQFP80 [(PEP+S640B)]
uPSD3422EB@TQFP52 [(PEP+S673)] uPSD3422EB@TQFP80 [(PEP+S640B)]
uPSD3422EV@TQFP52 [(PEP+S673)] uPSD3422EV@TQFP80 [(PEP+S640B)]
uPSD3422EVB@TQFP52 [(PEP+S673)] uPSD3422EVB@TQFP80 [(PEP+S640B)]
uPSD3433E@TQFP52 [(PEP+S673)] uPSD3433E@TQFP80 [(PEP+S640B)]
uPSD3433EB@TQFP52 [(PEP+S673)] uPSD3433EB@TQFP80 [(PEP+S640B)]
uPSD3433EV@TQFP52 [(PEP+S673)] uPSD3433EV@TQFP80 [(PEP+S640B)]
uPSD3433EVB@TQFP52 [(PEP+S673)] uPSD3433EVB@TQFP80 [(PEP+S640B)]
uPSD3434E@TQFP52 [(PEP+S673)]
uPSD3434E@TQFP52(new) [(PEP+S673)]
uPSD3434E@TQFP80 [(PEP+S640B)]
uPSD3434E@TQFP80(new) [(PEP+S640B)]
uPSD3434EB@TQFP52 [(PEP+S673)]
uPSD3434EB@TQFP52(new) [(PEP+S673)]
uPSD3434EB@TQFP80 [(PEP+S640B)]
uPSD3434EB@TQFP80(new) [(PEP+S640B)]
uPSD3434EV@TQFP52 [(PEP+S673)]
uPSD3434EV@TQFP52(new) [(PEP+S673)]
uPSD3434EV@TQFP80 [(PEP+S640B)]
uPSD3434EV@TQFP80(new) [(PEP+S640B)]
uPSD3434EVB@TQFP52 [(PEP+S673)]
uPSD3434EVB@TQFP52(new) [(PEP+S673)]
uPSD3434EVB@TQFP80 [(PEP+S640B)]
uPSD3434EVB@TQFP80(new) [(PEP+S640B)]
uPSD3454E@TQFP52 [(PEP+S673)]
uPSD3454E@TQFP52(new) [(PEP+S673)]
uPSD3454E@TQFP80 [(PEP+S640B)]
uPSD3454E@TQFP80(new) [(PEP+S640B)]
uPSD3454EB@TQFP52 [(PEP+S673)]
uPSD3454EB@TQFP52(new) [(PEP+S673)]
uPSD3454EB@TQFP80 [(PEP+S640B)]
uPSD3454EB@TQFP80(new) [(PEP+S640B)]

```

```

uPSD3454EV@TQFP52 [(PEP+S673)]
uPSD3454EV@TQFP52(new) [(PEP+S673)]
uPSD3454EV@TQFP80 [(PEP+S640B)]
uPSD3454EV@TQFP80(new) [(PEP+S640B)]
uPSD3454EVB@TQFP52 [(PEP+S673)]
uPSD3454EVB@TQFP52(new) [(PEP+S673)]
uPSD3454EVB@TQFP80 [(PEP+S640B)]
uPSD3454EVB@TQFP80(new) [(PEP+S640B)]
ZPSD211R@PLCC44 [(SA244)]
ZPSD211RV@PLCC44 [(SA244)]
ZPSD301@PLCC44 [(SA244)]
ZPSD301L@PLCC44 [(SA244)]
ZPSD301R@PLCC44 [(SA244)]
ZPSD301RL@PLCC44 [(SA244)]
ZPSD301RV@PLCC44 [(SA244)]
ZPSD301V@PLCC44 [(SA244)]
ZPSD302@PLCC44 [(SA244)]
ZPSD302B@PLCC44 [(SA244)]
ZPSD302L@PLCC44 [(SA244)]
ZPSD302R@PLCC44 [(SA244)]
ZPSD302RL@PLCC44 [(SA244)]
ZPSD302RV@PLCC44 [(SA244)]
ZPSD302V@PLCC44 [(SA244)]
ZPSD303@PLCC44 [(SA244)]
ZPSD303L@PLCC44 [(SA244)]
ZPSD303R@PLCC44 [(SA244)]
ZPSD303RL@PLCC44 [(SA244)]
ZPSD303RV@PLCC44 [(SA244)]
ZPSD303V@PLCC44 [(SA244)]
ZPSD311@PLCC44 [(SA244)]
ZPSD311L@PLCC44 [(SA244)]
ZPSD311R@PLCC44 [(SA244)]
ZPSD311RL@PLCC44 [(SA244)]
ZPSD311RV@PLCC44 [(SA244)]
ZPSD311V@PLCC44 [(SA244)]
ZPSD312@PLCC44 [(SA244)]
ZPSD312B@PLCC44 [(SA244)]
ZPSD312L@TQFP44 [(SA245A)]
ZPSD312R@TQFP44 [(SA245A)]
ZPSD312RL@TQFP44 [(SA245A)]
ZPSD312RV@TQFP44 [(SA245A)]
ZPSD312V@TQFP44 [(SA245A)]
ZPSD313@TQFP44 [(SA245A)]
ZPSD313L@TQFP44 [(SA245A)]
ZPSD313R@TQFP44 [(SA245A)]
ZPSD313RL@TQFP44 [(SA245A)]
ZPSD313RV@TQFP44 [(SA245A)]
ZPSD313V@TQFP44 [(SA245A)]
ZPSD813F4@PLCC52 [(PEP+S415T)]
ZPSD211R@TQFP44 [(SA245A)]
ZPSD211RV@TQFP44 [(SA245A)]
ZPSD301@TQFP44 [(SA245A)]
ZPSD301L@TQFP44 [(SA245A)]
ZPSD301R@TQFP44 [(SA245A)]
ZPSD301RL@TQFP44 [(SA245A)]
ZPSD301RV@TQFP44 [(SA245A)]
ZPSD301V@TQFP44 [(SA245A)]
ZPSD302@TQFP44 [(SA245A)]
ZPSD302B@PLCC44(USA) [(SA411A)]
ZPSD302L@TQFP44 [(SA245A)]
ZPSD302R@TQFP44 [(SA245A)]
ZPSD302RL@TQFP44 [(SA245A)]
ZPSD302RV@TQFP44 [(SA245A)]
ZPSD302V@TQFP44 [(SA245A)]
ZPSD303@TQFP44 [(SA245A)]
ZPSD303L@TQFP44 [(SA245A)]
ZPSD303R@TQFP44 [(SA245A)]
ZPSD303RL@TQFP44 [(SA245A)]
ZPSD303RV@TQFP44 [(SA245A)]
ZPSD303V@TQFP44 [(SA245A)]
ZPSD311@TQFP44 [(SA245A)]
ZPSD311L@TQFP44 [(SA245A)]
ZPSD311R@TQFP44 [(SA245A)]
ZPSD311RL@TQFP44 [(SA245A)]
ZPSD311RV@TQFP44 [(SA245A)]
ZPSD311V@TQFP44 [(SA245A)]
ZPSD312@TQFP44 [(SA245A)]
ZPSD312L@PLCC44 [(SA244)]
ZPSD312R@PLCC44 [(SA244)]
ZPSD312RL@PLCC44 [(SA244)]
ZPSD312RV@PLCC44 [(SA244)]
ZPSD312V@PLCC44 [(SA244)]
ZPSD313@PLCC44 [(SA244)]
ZPSD313L@PLCC44 [(SA244)]
ZPSD313R@PLCC44 [(SA244)]
ZPSD313RL@PLCC44 [(SA244)]
ZPSD313RV@PLCC44 [(SA244)]
ZPSD313V@PLCC44 [(SA244)]
ZPSD813F2@PLCC52 [(PEP+S415T)]

```

## STC

### MICROCONTROLLER

```

STC89C516RD
STC89C516RD@TQFP44 [(SA245A)]
STC89C58RD@PLCC44 [(SA244)]
STC89LE516AD
STC89LE516AD@TQFP44 [(SA245A)]
STC89LE516X2@PLCC44 [(SA244)]
STC89LE52AD
STC89LE52AD@TQFP44 [(SA675)]
STC89LE54AD@PLCC44 [(SA244)]
STC89LE556AD
STC89LE556AD@TQFP44 [(SA245A)]
STC89LE556X2@PLCC44 [(SA244)]
STC89LE58AD
STC89LE58AD@TQFP44 [(SA675)]
STC89LV516RD@PLCC44 [(SA244)]
STC89LV58RD
STC89LV58RD@TQFP44 [(SA245A)]
STC89C516RD@PLCC44 [(SA244)]
STC89C58RD
STC89C58RD@TQFP44 [(SA245A)]
STC89LE516AD@PLCC44 [(SA244)]
STC89LE516X2
STC89LE516X2@TQFP44 [(SA245A)]
STC89LE52AD@PLCC44 [(SA244)]
STC89LE54AD
STC89LE54AD@TQFP44 [(SA675)]
STC89LE556AD@PLCC44 [(SA244)]
STC89LE556X2
STC89LE556X2@TQFP44 [(SA245A)]
STC89LE58AD@PLCC44 [(SA244)]
STC89LV516RD
STC89LV516RD@TQFP44 [(SA245A)]
STC89LV58RD@PLCC44 [(SA244)]

```

## ST-CUSTOMER

### E(E) PROM / FRAM / NVRAM

M28W160ECB(Moto)@FBGA48 [(SA714A-B026A-M046F001Y)]  
 M28W160ECT(Moto)@FBGA48 [(SA714A-B026A-M046F001Y)]  
 M36L0R7050B0\_B1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
 M36L0R7050T0\_T1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
 M36L0R8060B3(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 M36L0R8060B5ZAQ(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 M58LR128FB\_GB(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 M58LR128FT\_GT(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 NAND01GW3B2BZA6(ASUS)@FBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND04GW3B2BN6(WS)@TSOP48 [(SA247-B005)]  
 NAND512R3A2(MLT)@FBGA63 [(SA642KK-B026-W0638F001Y)]  
 NANDA9R4N2AZBA5(UT)@FBGA149 [(SA664G-B279-Y149F001Y)]

## SUMMIT

### E(E) PROM/FRAM/NVRAM

S24022	S24022@SOIC8 [(SA602A)]
S24023	S24023@SOIC8 [(SA602A)]
S24042	S24042@SOIC8 [(SA602A)]
S24043	S24043@SOIC8 [(SA602A)]
S24162	S24162@SOIC8 [(SA602A)]
S24VP02	S24VP02@SOIC8 [(SA602A)]
S24VP04	S24VP04@SOIC8 [(SA602A)]
S24VP08	S24VP08@SOIC8 [(SA602A)]
S24VP16	S24VP16@SOIC8 [(SA602A)]
S93462(08bit)	S93462(08bit)@SOIC8 [(SA602A)]
S93462(16bit)	S93462(16bit)@SOIC8 [(SA602A)]
S93463(08bit)	S93463(08bit)@SOIC8 [(SA602A)]
S93463(16bit)	S93463(16bit)@SOIC8 [(SA602A)]
S93662(08bit)	S93662(08bit)@SOIC8 [(SA602A)]
S93662(16bit)	S93662(16bit)@SOIC8 [(SA602A)]
S93663(08bit)	S93663(08bit)@SOIC8 [(SA602A)]
S93663(16bit)	S93663(16bit)@SOIC8 [(SA602A)]
S93WD462(08bit)	S93WD462(08bit)@SOIC8 [(SA602A)]
S93WD462(16bit)	S93WD462(16bit)@SOIC8 [(SA602A)]
S93WD463(08bit)	S93WD463(08bit)@SOIC8 [(SA602A)]
S93WD463(16bit)	S93WD463(16bit)@SOIC8 [(SA602A)]
S93WD662(08bit)	S93WD662(08bit)@SOIC8 [(SA602A)]
S93WD662(16bit)	S93WD662(16bit)@SOIC8 [(SA602A)]
S93WD663(08bit)	S93WD663(08bit)@SOIC8 [(SA602A)]
S93WD663(16bit)	S93WD663(16bit)@SOIC8 [(SA602A)]

### MICROCONTROLLER

I-SMM465F-249@TQFP48(ISP) [ISP-HEADER01]  
 SMM465F-249@TQFP48 [(SA248)] SMM665BFC-266@TQFP48 [(SA248)]  
 SMM665BFC-266@TQFP48(ISP) [ISP-HEADER01]

## SUNPLUS

### E(E) PROM/FRAM/NVRAM

SPHE6400A SPHE6400A@SOIC8 [(SA602A)]

### MICROCONTROLLER

SPMC65P2102A(dip18)  
 SPMC65P2102A(dip18)(ISP) [ISP-HEADER01]  
 SPMC65P2102A@SOP18 [(SA404)]  
 SPMC65P2102A@SOP18(ISP) [ISP-HEADER01]  
 SPMC65P2104A(dip18)  
 SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]  
 SPMC65P2104A@SOP18 [(SA404)]  
 SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]  
 SPMC65P2202A(dip16)  
 SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]  
 SPMC65P2202A(dip20)  
 SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]  
 SPMC65P2202A@SOP16 [(SA404)]  
 SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]

SPMC65P2202A@SOP20 [(SA404)]  
 SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]  
 SPMC65P2204A(dip16)  
 SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]  
 SPMC65P2204A(dip20)  
 SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]  
 SPMC65P2204A@SOP16 [(SA404)]  
 SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]  
 SPMC65P2204A@SOP20 [(SA404)]  
 SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]  
 SPMC65P2404A(dip20)  
 SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]  
 SPMC65P2404A(dip28)  
 SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]  
 SPMC65P2404A@SOP20 [(SA404)]  
 SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]  
 SPMC65P2404A@SOP28 [(SA404)]  
 SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]  
 SPMC65P2408A(dip28)  
 SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]  
 SPMC65P2408A(dip32)  
 SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]  
 SPMC65P2408A@SOP28 [(SA404)]  
 SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]  
 SPMC65P2408A@SOP32 [(SA603)]  
 SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

## SYNCMOS

### E(E) PROM/FRAM/NVRAM

F29C31004B	F29C31004B@PLCC32 [(SA015A1T)]
F29C31004B@TSOP32 [(SA410T)]	F29C31004T
F29C31004T@PLCC32 [(SA015A1T)]	F29C31004T@TSOP32 [(SA410T)]
F29C51000B	F29C51000B@PLCC32 [(SA015A1T)]
F29C51000T	F29C51000T@PLCC32 [(SA015A1T)]
F29C51001B	F29C51001B@PLCC32 [(SA015A1T)]
F29C51001B@TSOP32 [(SA410T)]	F29C51001T
F29C51001T@PLCC32 [(SA015A1T)]	F29C51001T@TSOP32 [(SA410T)]
F29C51002B	F29C51002B@PLCC32 [(SA015A1T)]
F29C51002B@TSOP32 [(SA410T)]	F29C51002T
F29C51002T@PLCC32 [(SA015A1T)]	F29C51002T@TSOP32 [(SA410T)]
F29C51004B	F29C51004B@PLCC32 [(SA015A1T)]
F29C51004B@TSOP32 [(SA410T)]	F29C51004T
F29C51004T@PLCC32 [(SA015A1T)]	F29C51004T@TSOP32 [(SA410T)]
F29LC51000	F29LC51000@PLCC32 [(SA015A1T)]
F29LC51001	F29LC51001@PLCC32 [(SA015A1T)]
F29LC51002	F29LC51002@PLCC32 [(SA015A1T)]
S29C31001B	S29C31001B@PLCC32 [(SA015A1T)]
S29C31001B@TSOP32 [(SA410T)]	S29C31001T
S29C31001T@PLCC32 [(SA015A1T)]	S29C31001T@TSOP32 [(SA410T)]
S29C31002B	S29C31002B@PLCC32 [(SA015A1T)]
S29C31002B@TSOP32 [(SA410T)]	S29C31002T
S29C31002T@PLCC32 [(SA015A1T)]	S29C31002T@TSOP32 [(SA410T)]
S29C31004B	S29C31004B@PLCC32 [(SA015A1T)]
S29C31004B@TSOP32 [(SA410T)]	S29C31004T
S29C31004T@PLCC32 [(SA015A1T)]	S29C31004T@TSOP32 [(SA410T)]
S29C51001B	S29C51001B@PLCC32 [(SA015A1T)]
S29C51001B@TSOP32 [(SA410T)]	S29C51001T
S29C51001T@PLCC32 [(SA015A1T)]	S29C51001T@TSOP32 [(SA410T)]
S29C51002B	S29C51002B@PLCC32 [(SA015A1T)]
S29C51002B@TSOP32 [(SA410T)]	S29C51002T
S29C51002T@PLCC32 [(SA015A1T)]	S29C51002T@TSOP32 [(SA410T)]
S29C51004B	S29C51004B@PLCC32 [(SA015A1T)]
S29C51004B@TSOP32 [(SA410T)]	S29C51004T
S29C51004T@PLCC32 [(SA015A1T)]	S29C51004T@TSOP32 [(SA410T)]

### MICROCONTROLLER

MSU1958	MSU1958@PLCC44 [(SA244)]
MSU1958@TQFP44 [(SA245A)]	MSU2952
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44 [(SA245A)]
MSU2964	MSU2964@PLCC44 [(SA244)]
MSU2964@TQFP44 [(SA245A)]	SM2958
SM2958@PLCC44 [(SA244)]	SM2958@TQFP44 [(SA245A)]
SM2965	SM2965@PLCC44 [(SA244)]

SM2965@TQFP44 [(SA245A)]	SM59064
SM59064@PLCC44 [(SA244)]	SM59064@TQFP44 [(SA245A)]
SM59128C	SM59128C@PLCC44 [(SA244)]
SM59128C@TQFP44 [(SA245A)]	SM59128L
SM59128L@PLCC44 [(SA244)]	SM59128L@TQFP44 [(SA245A)]
SM5912C	SM5912C(ISP) [ISP-HEADER01]
SM5912C@PLCC44 [(SA244-B002)]	
SM5912C@PLCC44(ISP) [ISP-HEADER01]	
SM5912C@TQFP44 [(SA675-B005)]	
SM5912C@TQFP44(ISP) [ISP-HEADER01]	
SM5912L	SM5912L(ISP) [ISP-HEADER01]
SM5912L@PLCC44 [(SA244-B002)]	
SM5912L@PLCC44(ISP) [ISP-HEADER01]	
SM5912L@TQFP44 [(SA675-B005)]	
SM5912L@TQFP44(ISP) [ISP-HEADER01]	
SM59164	SM59164@PLCC44 [(SA244)]
SM59164@TQFP44 [(SA245A)]	SM5916C
SM5916C(ISP) [ISP-HEADER01]	SM5916C@PLCC44 [(SA244-B002)]
SM5916C@PLCC44(ISP) [ISP-HEADER01]	
SM5916C@TQFP44 [(SA675-B005)]	
SM5916C@TQFP44(ISP) [ISP-HEADER01]	
SM5916L	SM5916L(ISP) [ISP-HEADER01]
SM5916L@PLCC44 [(SA244-B002)]	
SM5916L@PLCC44(ISP) [ISP-HEADER01]	
SM5916L@TQFP44 [(SA675-B005)]	
SM5916L@TQFP44(ISP) [ISP-HEADER01]	
SM59264	SM59264@PLCC44 [(SA244)]
SM59264@TQFP44 [(SA245A)]	SM5964
SM5964@PLCC44 [(SA244)]	SM5964@TQFP44 [(SA245A)]
SM5964A	SM5964A@PLCC44 [(SA244)]
SM5964A@TQFP44 [(SA245A)]	SM5964AC
SM5964AC@PLCC44 [(SA244)]	SM5964AC@TQFP44 [(SA245A)]
SM5964AL	SM5964AL@PLCC44 [(SA244)]
SM5964AL@TQFP44 [(SA245A)]	SM5964C
SM5964C@PLCC44 [(SA244)]	SM5964C@TQFP44 [(SA245A)]
SM5964D0	SM5964D0@PLCC44 [(SA244)]
SM5964D0@TQFP44 [(SA245A)]	SM5964D0A
SM5964D0A@PLCC44 [(SA244)]	SM5964D0A@TQFP44 [(SA245A)]
SM5964D1A	SM5964D1A@PLCC44 [(SA244)]
SM5964D1A@TQFP44 [(SA245A)]	SM59D02G2C
SM59D02G2C(ISP) [ISP-HEADER01]	SM59D02G2C@LQFP44 [(SA675-B005)]
SM59D02G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D02G2C@PLCC44 [(SA244-B002)]	
SM59D02G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D02G2L	SM59D02G2L(ISP) [ISP-HEADER01]
SM59D02G2L@LQFP44 [(SA675-B005)]	
SM59D02G2L@LQFP44(ISP) [ISP-HEADER01]	
SM59D02G2L@PLCC44 [(SA244-B002)]	
SM59D02G2L@PLCC44(ISP) [ISP-HEADER01]	
SM59D03G2C	SM59D03G2C(ISP) [ISP-HEADER01]
SM59D03G2C@LQFP44 [(SA675-B005)]	
SM59D03G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D03G2C@PLCC44 [(SA244-B002)]	
SM59D03G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D03G2L	SM59D03G2L(ISP) [ISP-HEADER01]
SM59D03G2L@LQFP44 [(SA675-B005)]	
SM59D03G2L@LQFP44(ISP) [ISP-HEADER01]	
SM59D03G2L@PLCC44 [(SA244-B002)]	
SM59D03G2L@PLCC44(ISP) [ISP-HEADER01]	
SM59D04G2C	SM59D04G2C(ISP) [ISP-HEADER01]
SM59D04G2C@LQFP44 [(SA675-B005)]	
SM59D04G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D04G2C@PLCC44 [(SA244-B002)]	
SM59D04G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D04G2L	SM59D04G2L(ISP) [ISP-HEADER01]
SM59D04G2L@LQFP44 [(SA675-B005)]	
SM59D04G2L@LQFP44(ISP) [ISP-HEADER01]	
SM59D04G2L@PLCC44 [(SA244-B002)]	
SM59D04G2L@PLCC44(ISP) [ISP-HEADER01]	
SM59R08A2@TQFP64(*) [(SA732-B292)]	
SM59R16A2@TQFP64(*) [(SA732-B292)]	
SM7908	SM7908@PLCC44 [(SA244)]
SM7908@TQFP44 [(SA245A)]	SM79108
SM79108@PLCC44 [(SA244)]	SM79108@TQFP44 [(SA245A)]
SM79164	SM79164@PLCC44 [(SA244)]
SM79164@TQFP44 [(SA245A)]	SM79164L
SM79164L@PLCC44 [(SA244)]	SM79164L@TQFP44 [(SA245A)]
SM79164V	SM79164V@PLCC44 [(SA244)]
SM79164V@TQFP44 [(SA245A)]	SM7932
SM7932@PLCC44 [(SA244)]	SM7932@TQFP44 [(SA245A)]
SM7964	SM7964@PLCC44 [(SA244)]

SM7964@TQFP44 [(SA245A)]	SM894051
SM894051@SOIC20 [(SA023A)]	SM8951
SM8951@PLCC44 [(SA244)]	SM8951@TQFP44 [(SA245A)]
SM89516	SM89516@PLCC44 [(SA244)]
SM89516@TQFP44 [(SA245A)]	SM89516A
SM89516A@PLCC44 [(SA244)]	SM89516A@TQFP44 [(SA245A)]
SM89516AL	SM89516AL@PLCC44 [(SA244)]
SM89516AL@TQFP44 [(SA245A)]	SM89516B
SM89516B@PLCC44 [(SA244)]	SM89516B@TQFP44 [(SA245A)]
SM89516BL	SM89516BL@PLCC44 [(SA244)]
SM89516BL@TQFP44 [(SA245A)]	SM89516L
SM89516L@PLCC44 [(SA244)]	SM89516L@TQFP44 [(SA245A)]
SM8951A	SM8951A@PLCC44 [(SA244)]
SM8951A@TQFP44 [(SA245A)]	SM8951AL
SM8951AL@PLCC44 [(SA244)]	SM8951AL@TQFP44 [(SA245A)]
SM8951B	SM8951B@PLCC44 [(SA244)]
SM8951B@TQFP44 [(SA245A)]	SM8951BL
SM8951BL@PLCC44 [(SA244)]	SM8951BL@TQFP44 [(SA245A)]
SM8951L	SM8951L@PLCC44 [(SA244)]
SM8951L@TQFP44 [(SA245A)]	SM8952
SM8952@PLCC44 [(SA244)]	SM8952@TQFP44 [(SA245A)]
SM8952A	SM8952A@PLCC44 [(SA244)]
SM8952A@TQFP44 [(SA245A)]	SM8952AL
SM8952AL@PLCC44 [(SA244)]	SM8952AL@TQFP44 [(SA245A)]
SM8952B	SM8952B@PLCC44 [(SA244)]
SM8952B@TQFP44 [(SA245A)]	SM8952BL
SM8952BL@PLCC44 [(SA244)]	SM8952BL@TQFP44 [(SA245A)]
SM8952L	SM8952L@PLCC44 [(SA244)]
SM8952L@TQFP44 [(SA245A)]	SM8954
SM8954@PLCC44 [(SA244)]	SM8954@TQFP44 [(SA245A)]
SM8954A	SM8954A@PLCC44 [(SA244)]
SM8954A@TQFP44 [(SA245A)]	SM8954AL
SM8954AL@PLCC44 [(SA244)]	SM8954AL@TQFP44 [(SA245A)]
SM8954B	SM8954B@PLCC44 [(SA244)]
SM8954B@TQFP44 [(SA245A)]	SM8954BL
SM8954BL@PLCC44 [(SA244)]	SM8954BL@TQFP44 [(SA245A)]
SM8954L	SM8954L@PLCC44 [(SA244)]
SM8954L@TQFP44 [(SA245A)]	SM8958
SM8958@PLCC44 [(SA244)]	SM8958@TQFP44 [(SA245A)]
SM8958A	SM8958A@PLCC44 [(SA244)]
SM8958A@TQFP44 [(SA245A)]	SM8958AL
SM8958AL@PLCC44 [(SA244)]	SM8958AL@TQFP44 [(SA245A)]
SM8958B	SM8958B@PLCC44 [(SA244)]
SM8958B@TQFP44 [(SA245A)]	SM8958BL
SM8958BL@PLCC44 [(SA244)]	SM8958BL@TQFP44 [(SA245A)]
SM8958L	SM8958L@PLCC44 [(SA244)]
SM8958L@TQFP44 [(SA245A)]	SM89S16R1C
SM89S16R1C@PLCC44 [(SA244)]	SM89S16R1C@TQFP44 [(SA245A)]
SM89T04R1C	SM89T04R1C@PLCC44 [(SA244)]
SM89T04R1C@TQFP44 [(SA245A)]	SM89T04R1L
SM89T04R1L@PLCC44 [(SA244)]	SM89T04R1L@TQFP44 [(SA245A)]
SM89T08R1C	SM89T08R1C@PLCC44 [(SA244)]
SM89T08R1C@TQFP44 [(SA245A)]	SM89T08R1L
SM89T08R1L@PLCC44 [(SA244)]	SM89T08R1L@TQFP44 [(SA245A)]
SM89T16R1C	SM89T16R1C@PLCC44 [(SA244)]
SM89T16R1C@TQFP44 [(SA245A)]	SM89T16R1L
SM89T16R1L@PLCC44 [(SA244)]	SM89T16R1L@TQFP44 [(SA245A)]

## SYNERTEK

### E(E) PROM/FRAM/NVRAM

SY2716

## SYNTEK

### MICROCONTROLLER

STK6011BP1-3V@PLCC44 [(SA244)]	STK6011BP21-5V@PLCC44 [(SA244)]
STK6011BP5-3V@TQFP44 [(SA245A)]	STK6011P10-5V@LQFP48 [(SA248)]
STK6011P1-3V@PLCC44 [(SA244)]	STK6011P2-5V@PLCC44 [(SA244)]
STK6011P3-3V@SDIP42 [(SA028)]	STK6011P4-5V@SDIP42 [(SA028)]
STK6011P5-3V@PQFP44 [(SA245A)]	STK6011P6-5V@PQFP44 [(SA245A)]
STK6011P7-3V	STK6011P8-5V

STK6011P9-3V@LQFP48 [(SA248)]	STK6012BP1-3V@PLCC44 [(SA244)]
STK6012BP22-5V@PLCC44 [(SA244)]	STK6012BP5-3V@TQFP44 [(SA245A)]
STK6012P10-5V@LQFP48 [(SA248)]	STK6012P1-3V@PLCC44 [(SA244)]
STK6012P2-5V@PLCC44 [(SA244)]	STK6012P3-3V@SDIP42 [(SA028)]
STK6012P4-5V@SDIP42 [(SA028)]	STK6012P5-3V@PQFP44 [(SA245A)]
STK6012P6-5V@PQFP44 [(SA245A)]	STK6012P7-3V
STK6012P8-5V	STK6012P9-3V@LQFP48 [(SA248)]
STK6031@LQFP48 [(SA248)]	STK6031@PLCC44 [(SA244)]
STK6031@QFP44 [(SA245A)]	STK6032
STK6032@LQFP48 [(SA248)]	STK6032@PLCC44 [(SA244)]
STK6032@QFP44 [(SA245A)]	STK6033
STK6033@LQFP48 [(SA248)]	STK6033@PLCC44 [(SA244)]
STK6033@QFP44 [(SA245A)]	

## TDICOMS

### MICROCONTROLLER

TDS33X1@PLCC44 [(SA244)]	TDS33X1@TQFP44 [(SA245A)]
TDS33X2@PLCC44 [(SA244)]	TDS33X2@TQFP44 [(SA245A)]
TDS33X4@PLCC44 [(SA244)]	TDS33X4@TQFP44 [(SA245A)]
TDS33X8@PLCC44 [(SA244)]	TDS33X8@TQFP44 [(SA245A)]

## TECHCODE

### MICROCONTROLLER

T89C516	T89C516@PLCC44 [(SA244)]
T89C516@TQFP44 [(SA245A)]	T89C52
T89C52@PLCC44 [(SA244)]	T89C52@TQFP44 [(SA245A)]
T89C58	T89C58@PLCC44 [(SA244)]
T89C58@TQFP44 [(SA245A)]	

## TEKMOS

### E(E) PROM/FRAM/NVRAM

TK17LV040@PLCC20 [(SA001A)]

## TEMIC

### MICROCONTROLLER

T89C51RD2	T89C51RD2@PLCC44 [(SA244)]
T89C51RD2@PLCC68 [(PEP+S414T)]	T89C51RD2@TQFP44 [(SA245A)]
T89F64	T89F64@PLCC44 [(SA244)]
T89F64@TQFP44 [(SA245A)]	TS87C51RB2
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44 [(SA245A)]
TS87C51RC2	TS87C51RC2@PLCC44 [(SA244)]
TS87C51RC2@TQFP44 [(SA245A)]	TS87C51RD2
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44 [(SA245A)]
TS87C51U2	TS87C51U2@PLCC44 [(SA244)]
TS87C51U2@TQFP44 [(SA245A)]	TS87C52X2
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44 [(SA245A)]
TS87C54X2	TS87C54X2@PLCC44 [(SA244)]
TS87C54X2@TQFP44 [(SA245A)]	TS87C58X2
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44 [(SA245A)]
TSC71RBX2	TSC71RBX2@PLCC44 [(SA244)]
TSC71RBX2@TQFP44 [(SA245A)]	TSC71RCX2
TSC71RCX2@PLCC44 [(SA244)]	TSC71RCX2@TQFP44 [(SA245A)]
TSC71RDX2	TSC71RDX2@PLCC44 [(SA244)]
TSC71RDX2@PLCC68 [(PEP+S414T)]	TSC71RDX2@TQFP44 [(SA245A)]
TSC71RDX2@TQFP64 [(PEP+S417T)]	TSC87251A1@PLCC44 [(SA244)]
TSC87251G1	TSC87251G1@PLCC44 [(SA244)]
TSC87251G1A	TSC87251G1A@PLCC44 [(SA244)]
TSC87251G2D	TSC87251G2D@PLCC44 [(SA244)]
TSC87251G2D@TQFP44 [(SA245A)]	TSC87C51
TSC87C51@PLCC44 [(SA244)]	TSC87C51@TQFP44 [(SA245A)]

TSC87C52	TSC87C52@PLCC44 [(SA244)]
TSC87C52@TQFP44 [(SA245A)]	TSC87C54
TSC87C54@PLCC44 [(SA244)]	TSC87C54@TQFP44 [(SA245A)]
TSC87C58	TSC87C58@PLCC44 [(SA244)]
TSC87C58@TQFP44 [(SA245A)]	

## Terra Semiconductor

### E(E) PROM/FRAM/NVRAM

TS25L16AP	TS25L16AP@SOP8 [(SA023A)]
TS25L80AP	TS25L80AP@SOP8 [(SA023A)]

## TEST

### E(E) PROM/FRAM/NVRAM

K556PT5

## TEST-LOGIC

### MICROCONTROLLER

TL1008	TL1008@PLCC44 [(SA244)]
TL1008@TQFP44 [(SA245A)]	TL2008
TL2008@PLCC44 [(SA244)]	TL2008@TQFP44 [(SA245A)]
TL20164	TL20164@PLCC44 [(SA244)]
TL20164@TQFP44 [(SA245A)]	TL20164A
TL20164A@PLCC44 [(SA244)]	TL20164A@TQFP44 [(SA245A)]
TL20164L	TL20164L@PLCC44 [(SA244)]
TL20164L@TQFP44 [(SA245A)]	TL2032
TL2032@PLCC44 [(SA244)]	TL2032@TQFP44 [(SA245A)]
TL2054A	TL2054A@PLCC44 [(SA244)]
TL2054A@TQFP44 [(SA245A)]	TL2064
TL2064@PLCC44 [(SA244)]	TL2064@TQFP44 [(SA245A)]
TL40516	TL40516@PLCC44 [(SA244)]
TL40516@TQFP44 [(SA245A)]	TL40516A
TL40516A@PLCC44 [(SA244)]	TL40516A@TQFP44 [(SA245A)]
TL40516B	TL40516B@PLCC44 [(SA244)]
TL40516B@TQFP44 [(SA245A)]	TL4054
TL4054@PLCC44 [(SA244)]	TL4054@TQFP44 [(SA245A)]
TL4058	TL4058@PLCC44 [(SA244)]
TL4058@TQFP44 [(SA245A)]	TL4058A
TL4058A@PLCC44 [(SA244)]	TL4058A@TQFP44 [(SA245A)]

## TI

### E(E) PROM/FRAM/NVRAM

BQ4010	BQ4010Y
BQ4011	BQ4011Y
BQ4013	BQ4013Y
BQ4014	BQ4014Y
BQ4015	BQ4015Y
SMJ2516	SMJ2532
SMJ2532A	SMJ2564
SMJ2564@PLCC32 [(SA015A1T)]	SMJ2716
SMJ27C256	SMJ27C256@PLCC32 [(SA015A1T)]
SMJ27C512	SMJ27C512@PLCC32 [(SA015A1T)]
TMS2516	TMS2516JLW
TMS2532	TMS2532A
TMS2564	TMS2564@PLCC32 [(SA015A1T)]
TMS25L32	TMS27128
TMS27128A	TMS2716
TMS2732	TMS2732A
TMS2764	TMS27C010
TMS27C010@PLCC32 [(SA015A1T)]	TMS27C010@TSOP32 [(SA410T)]
TMS27C010A	TMS27C010A@PLCC32 [(SA015A1T)]



TMS27C010A@TSOP32 [(SA410T)]	TMS27C020
TMS27C020@PLCC32 [(SA015A1T)]	TMS27C020@TSOP32 [(SA410T)]
TMS27C040	TMS27C040@PLCC32 [(SA015A1T)]
TMS27C040@TSOP32 [(SA410T)]	TMS27C128
TMS27C128@PLCC32 [(SA015A1T)]	TMS27C2001
TMS27C2001@PLCC32 [(SA015A1T)]	TMS27C2001@TSOP32 [(SA410T)]
TMS27C210	TMS27C210@PLCC44 [(SA244)]
TMS27C210A	TMS27C210A@PLCC44 [(SA244)]
TMS27C240	TMS27C240@PLCC44 [(SA244)]
TMS27C256	TMS27C256@PLCC32 [(SA015A1T)]
TMS27C291	TMS27C291@PLCC28 [(SA008A)]
TMS27C292	TMS27C292@PLCC28 [(SA008A)]
TMS27C32	TMS27C512
TMS27C512@PLCC32 [(SA015A1T)]	TMS27C64
TMS27LV010A	TMS27LV010A@PLCC32 [(SA015A1T)]
TMS27LV010A@TSOP32 [(SA410T)]	TMS27P32A
TMS27P64	TMS27PC010
TMS27PC010@PLCC32 [(SA015A1T)]	TMS27PC010@TSOP32 [(SA410T)]
TMS27PC010A	TMS27PC010A@PLCC32 [(SA015A1T)]
TMS27PC010A@TSOP32 [(SA410T)]	TMS27PC020
TMS27PC020@PLCC32 [(SA015A1T)]	TMS27PC020@TSOP32 [(SA410T)]
TMS27PC040	TMS27PC040@PLCC32 [(SA015A1T)]
TMS27PC040@TSOP32 [(SA410T)]	TMS27PC128
TMS27PC128@PLCC32 [(SA015A1T)]	TMS27PC210
TMS27PC210@PLCC44 [(SA244)]	TMS27PC210A
TMS27PC210A@PLCC44 [(SA244)]	TMS27PC240
TMS27PC240@PLCC44 [(SA244)]	TMS27PC256
TMS27PC256@PLCC32 [(SA015A1T)]	TMS27PC291
TMS27PC291@PLCC28 [(SA008A)]	TMS27PC32
TMS27PC32A	TMS27PC512
TMS27PC512@PLCC32 [(SA015A1T)]	TMS27PC64
TMS28F010	TMS28F010@PLCC32 [(SA015A1T)]
TMS28F010@TSOP32 [(SA410T)]	TMS28F020
TMS28F020@PLCC32 [(SA015A1T)]	TMS28F020@TSOP32 [(SA410T)]
TMS28F200AF-B@PSOP44 [(SA638)]	
TMS28F200AF-B@TSOP48 [(SA247-B005)]	
TMS28F200AF-T@PSOP44 [(SA638)]	
TMS28F200AF-T@TSOP48 [(SA247-B005)]	
TMS28F200BZ-B@PSOP44 [(SA638)]	TMS28F200BZ-T@PSOP44 [(SA638)]
TMS28F210	TMS28F210@PLCC44 [(SA244)]
TMS28F210@TSOP40 [(SA409T)]	TMS28F400AF-B@PSOP44 [(SA638)]
TMS28F400AF-T@PSOP44 [(SA638)]	TMS28F400AS-B@PSOP44 [(SA638)]
TMS28F400AS-T@PSOP44 [(SA638)]	TMS28F400BZ-B@PSOP44 [(SA638)]
TMS28F400BZ-T@PSOP44 [(SA638)]	TMS28F512
TMS28F512@PLCC32 [(SA015A1T)]	TMS28F512@TSOP32 [(SA410T)]
TMS29F040	TMS29F040@PLCC32 [(SA015A1T)]
TMS29F040@TSOP32 [(SA410T)]	TMS29F259
TMS29F259@PLCC32 [(SA015A1T)]	TMS29F259@TSOP32 [(SA410T)]
TMS29F512	TMS29F512@PLCC32 [(SA015A1T)]
TMS29F512@TSOP32 [(SA410T)]	TMS87C257
TMS87C257@PLCC32 [(SA015A1T)]	

## PLD

EP1800@PLCC68 [(PEP+S414T)]	EP1810@PLCC68 [(PEP+S414T)]
EP1830@PLCC68 [(PEP+S414T)]	EP330
EP330@PLCC20 [(SA001A)]	EP910
EP910-P44 [(SA244)]	PAL16L8A
PAL16L8A@PLCC20 [(SA001A)]	PAL16L8A-2
PAL16L8A-2@PLCC20 [(SA001A)]	PAL16R4A
PAL16R4A@PLCC20 [(SA001A)]	PAL16R4A-2
PAL16R4A-2@PLCC20 [(SA001A)]	PAL16R6A
PAL16R6A@PLCC20 [(SA001A)]	PAL16R6A-2
PAL16R6A-2@PLCC20 [(SA001A)]	PAL16R8A
PAL16R8A@PLCC20 [(SA001A)]	PAL16R8A-2
PAL16R8A-2@PLCC20 [(SA001A)]	TIB82S167A
TIB82S167A@PLCC28 [(SA008A)]	TIB82S167B
TIB82S167B@PLCC28 [(SA008A)]	TIBPAL16L8-10
TIBPAL16L8-10@PLCC20 [(SA001A)]	TIBPAL16L8-15
TIBPAL16L8-15@PLCC20 [(SA001A)]	TIBPAL16L8-25
TIBPAL16L8-25@PLCC20 [(SA001A)]	TIBPAL16L8-5
TIBPAL16L8-5@PLCC20 [(SA001A)]	TIBPAL16L8-7
TIBPAL16L8-7@PLCC20 [(SA001A)]	TIBPAL16L8H-15
TIBPAL16L8H-15@PLCC20 [(SA001A)]	TIBPAL16R4-10
TIBPAL16R4-10@PLCC20 [(SA001A)]	TIBPAL16R4-5
TIBPAL16R4-5@PLCC20 [(SA001A)]	TIBPAL16R4-7
TIBPAL16R4-7@PLCC20 [(SA001A)]	TIBPAL16R4H-15
TIBPAL16R4H-15@PLCC20 [(SA001A)]	TIBPAL16R6-10
TIBPAL16R6-10@PLCC20 [(SA001A)]	TIBPAL16R6-5

```

TIBPAL16R6-5@PLCC20 [(SA001A)]          TIBPAL16R6-7
TIBPAL16R6-7@PLCC20 [(SA001A)]          TIBPAL16R6H-15
TIBPAL16R6H-15@PLCC20 [(SA001A)]        TIBPAL16R8-10
TIBPAL16R8-10@PLCC20 [(SA001A)]        TIBPAL16R8-5
TIBPAL16R8-5@PLCC20 [(SA001A)]        TIBPAL16R8-7
TIBPAL16R8-7@PLCC20 [(SA001A)]        TIBPAL16R8H-15
TIBPAL16R8H-15@PLCC20 [(SA001A)]       TIBPAL20L8-10
TIBPAL20L8-10@PLCC28 [(SA008A)]        TIBPAL20L8-15
TIBPAL20L8-15@PLCC28 [(SA008A)]        TIBPAL20L8-25
TIBPAL20L8-25@PLCC28 [(SA008A)]        TIBPAL20L8-5
TIBPAL20L8-5@PLCC28 [(SA008A)]        TIBPAL20L8-7
TIBPAL20L8-7@PLCC28 [(SA008A)]        TIBPAL20R4-10
TIBPAL20R4-10@PLCC28 [(SA008A)]        TIBPAL20R4-15
TIBPAL20R4-15@PLCC28 [(SA008A)]        TIBPAL20R4-25
TIBPAL20R4-25@PLCC28 [(SA008A)]        TIBPAL20R4-5
TIBPAL20R4-5@PLCC28 [(SA008A)]        TIBPAL20R4-7
TIBPAL20R4-7@PLCC28 [(SA008A)]        TIBPAL20R6-10
TIBPAL20R6-10@PLCC28 [(SA008A)]        TIBPAL20R6-15
TIBPAL20R6-15@PLCC28 [(SA008A)]        TIBPAL20R6-25
TIBPAL20R6-25@PLCC28 [(SA008A)]        TIBPAL20R6-5
TIBPAL20R6-5@PLCC28 [(SA008A)]        TIBPAL20R6-7
TIBPAL20R6-7@PLCC28 [(SA008A)]        TIBPAL20R8-10
TIBPAL20R8-10@PLCC28 [(SA008A)]        TIBPAL20R8-15
TIBPAL20R8-15@PLCC28 [(SA008A)]        TIBPAL20R8-25
TIBPAL20R8-25@PLCC28 [(SA008A)]        TIBPAL20R8-5
TIBPAL20R8-5@PLCC28 [(SA008A)]        TIBPAL20R8-7
TIBPAL20R8-7@PLCC28 [(SA008A)]        TIBPAL22V10
TIBPAL22V10@PLCC28 [(SA008A)]          TIBPAL22V10-10
TIBPAL22V10-10@PLCC28 [(SA008A)]       TIBPAL22V10-15
TIBPAL22V10-15@PLCC28 [(SA008A)]       TIBPAL22V10-20
TIBPAL22V10-20@PLCC28 [(SA008A)]       TIBPAL22V10-5
TIBPAL22V10-5@PLCC28 [(SA008A)]       TIBPAL22V10-7
TIBPAL22V10-7@PLCC28 [(SA008A)]       TIBPAL22V10A
TIBPAL22V10A@PLCC28 [(SA008A)]        TICPAL22V10Z(0 PWR)
TICPAL22V10Z(0 PWR)@PLCC28 [(SA008A)]
TICPAL22V10Z(TURBO)
TICPAL22V10Z(TURBO)@PLCC28 [(SA008A)]

```

## MICROCONTROLLER

```

BUF08821@SSOP20 [(SA643-B005)]          BUF16821A@SSOP28 [(SA643-B005)]
BUF16821B@SSOP28 [(SA643-B005)]        MSP430F110@SOIC20 [(SA404)]
MSP430F110@SOIC20(ISP) [ISP-HEADER01]
MSP430F110@TSSOP20 [(SA026)]
MSP430F110@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1101@SOIC20 [(SA404)]
MSP430F1101@SOIC20(ISP) [ISP-HEADER01]
MSP430F1101@TSSOP20 [(SA026)]
MSP430F1101@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1101A@QFN24 [(SA710)]
MSP430F1101A@QFN24(ISP) [ISP-HEADER01]
MSP430F1101A@SOIC20 [(SA404)]
MSP430F1101A@SOIC20(ISP) [ISP-HEADER01]
MSP430F1101A@TSSOP20 [(SA026)]
MSP430F1101A@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1111A@QFN24 [(SA710)]
MSP430F1111A@QFN24(ISP) [ISP-HEADER01]
MSP430F1111A@SOIC20 [(SA404)]
MSP430F1111A@SOIC20(ISP) [ISP-HEADER01]
MSP430F1111A@TSSOP20 [(SA026)]
MSP430F1111A@TSSOP20(ISP) [ISP-HEADER01]
MSP430F112@SOIC20 [(SA404)]
MSP430F112@SOIC20(ISP) [ISP-HEADER01]
MSP430F112@TSSOP20 [(SA026)]
MSP430F112@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1121@SOIC20 [(SA404)]
MSP430F1121@SOIC20(ISP) [ISP-HEADER01]
MSP430F1121@TSSOP20 [(SA026)]
MSP430F1121@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1121A@QFN24 [(SA710)]
MSP430F1121A@QFN24(ISP) [ISP-HEADER01]
MSP430F1121A@SOIC20 [(SA404)]
MSP430F1121A@SOIC20(ISP) [ISP-HEADER01]
MSP430F1121A@TSSOP20 [(SA026)]
MSP430F1121A@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1122@QFN32 [(SA686)]            MSP430F1122@SOIC20 [(SA404)]
MSP430F1122@SOIC20(ISP) [ISP-HEADER01]
MSP430F1122@TSSOP20 [(SA026)]
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]

```

MSP430F1132@QFN32 [(SA686)] MSP430F1132@SOIC20 [(SA404)]  
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1132@TSSOP20 [(SA026)]  
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F122@QFN32 [(SA686)] MSP430F122@SOIC28 [(SA404)]  
MSP430F122@TSSOP28 [(SA643)] MSP430F122@QFN32 [(SA686)]  
MSP430F122@SOIC28 [(SA404)]  
MSP430F122@SOIC28(ISP) [ISP-HEADER01]  
MSP430F122@TSSOP28 [(SA643)]  
MSP430F122@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F123@QFN32 [(SA686)] MSP430F123@SOIC28 [(SA404)]  
MSP430F123@TSSOP28 [(SA643)] MSP430F123@QFN32 [(SA686)]  
MSP430F123@SOIC28 [(SA404)]  
MSP430F123@SOIC28(ISP) [ISP-HEADER01]  
MSP430F123@TSSOP28 [(SA643)]  
MSP430F123@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F133@QFN64 [(PEP+S702)]  
MSP430F133@QFN64(ISP) [ISP-HEADER01]  
MSP430F133@TQFP64 [(PEP+S616)]  
MSP430F133@TQFP64(ISP) [ISP-HEADER01]  
MSP430F135@QFN64 [(PEP+S702)]  
MSP430F135@QFN64(ISP) [ISP-HEADER01]  
MSP430F135@TQFP64 [(PEP+S616)]  
MSP430F135@TQFP64(ISP) [ISP-HEADER01]  
MSP430F147@QFN64 [(PEP+S702)]  
MSP430F147@QFN64(ISP) [ISP-HEADER01]  
MSP430F147@TQFP64 [(PEP+S616)]  
MSP430F147@TQFP64(ISP) [ISP-HEADER01]  
MSP430F147l@QFN64 [(PEP+S702)]  
MSP430F147l@QFN64(ISP) [ISP-HEADER01]  
MSP430F147l@TQFP64 [(PEP+S616)]  
MSP430F147l@TQFP64(ISP) [ISP-HEADER01]  
MSP430F148@QFN64 [(PEP+S702)]  
MSP430F148@QFN64(ISP) [ISP-HEADER01]  
MSP430F148@TQFP64 [(PEP+S616)]  
MSP430F148@TQFP64(ISP) [ISP-HEADER01]  
MSP430F148l@QFN64 [(PEP+S702)]  
MSP430F148l@QFN64(ISP) [ISP-HEADER01]  
MSP430F148l@TQFP64 [(PEP+S616)]  
MSP430F148l@TQFP64(ISP) [ISP-HEADER01]  
MSP430F149@QFN64 [(PEP+S702)]  
MSP430F149@QFN64(ISP) [ISP-HEADER01]  
MSP430F149@TQFP64 [(PEP+S616)]  
MSP430F149@TQFP64(ISP) [ISP-HEADER01]  
MSP430F149l@QFN64 [(PEP+S702)]  
MSP430F149l@QFN64(ISP) [ISP-HEADER01]  
MSP430F149l@TQFP64 [(PEP+S616)]  
MSP430F149l@TQFP64(ISP) [ISP-HEADER01]  
MSP430F155@QFN64 [(PEP+S702)]  
MSP430F155@QFN64(ISP) [ISP-HEADER01]  
MSP430F155@TQFP64 [(PEP+S616)]  
MSP430F155@TQFP64(ISP) [ISP-HEADER01]  
MSP430F156@QFN64 [(PEP+S702)]  
MSP430F156@QFN64(ISP) [ISP-HEADER01]  
MSP430F156@TQFP64 [(PEP+S616)]  
MSP430F156@TQFP64(ISP) [ISP-HEADER01]  
MSP430F157@QFN64 [(PEP+S702)]  
MSP430F157@QFN64(ISP) [ISP-HEADER01]  
MSP430F157@TQFP64 [(PEP+S616)]  
MSP430F157@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1610@QFN64 [(PEP+S702)]  
MSP430F1610@QFN64(ISP) [ISP-HEADER01]  
MSP430F1610@TQFP64 [(PEP+S616)]  
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1611@QFN64 [(PEP+S702)]  
MSP430F1611@QFN64(ISP) [ISP-HEADER01]  
MSP430F1611@TQFP64 [(PEP+S616)]  
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1612@QFN64 [(PEP+S702)]  
MSP430F1612@QFN64(ISP) [ISP-HEADER01]  
MSP430F1612@TQFP64 [(PEP+S616)]  
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]  
MSP430F167@QFN64 [(PEP+S702)]  
MSP430F167@QFN64(ISP) [ISP-HEADER01]  
MSP430F167@TQFP64 [(PEP+S616)]  
MSP430F167@TQFP64(ISP) [ISP-HEADER01]  
MSP430F168@QFN64 [(PEP+S702)]  
MSP430F168@QFN64(ISP) [ISP-HEADER01]  
MSP430F168@TQFP64 [(PEP+S616)]  
MSP430F168@TQFP64(ISP) [ISP-HEADER01]  
MSP430F169@QFN64 [(PEP+S702)]

```
MSP430F169@QFN64(ISP) [ISP-HEADER01]
MSP430F169@TQFP64 [(PEP+S616)]
MSP430F169@TQFP64(ISP) [ISP-HEADER01]
MSP430F2001IN
MSP430F2001IN(ISP) [ISP-HEADER01]
MSP430F2001IN(SPW ISP) [ISP-HEADER01]
MSP430F2001IN(SPW) MSP430F2001IPW@TSSOP14 [(SA026)]
MSP430F2001IPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2001IPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2001IPW@TSSOP14(SPW) [(SA026)]
MSP430F2001IRSA@QFN16 [(SA727)]
MSP430F2001IRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2001IRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2001IRSA@QFN16(SPW) [(SA727)]
MSP430F2001TN
MSP430F2001TN(ISP) [ISP-HEADER01]
MSP430F2001TN(SPW ISP) [ISP-HEADER01]
MSP430F2001TN(SPW) MSP430F2001TPW@TSSOP14 [(SA026)]
MSP430F2001TPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2001TPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2001TPW@TSSOP14(SPW) [(SA026)]
MSP430F2001TRSA@QFN16 [(SA727)]
MSP430F2001TRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2001TRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2001TRSA@QFN16(SPW) [(SA727)]
MSP430F2002IN
MSP430F2002IN(ISP) [ISP-HEADER01]
MSP430F2002IN(SPW ISP) [ISP-HEADER01]
MSP430F2002IN(SPW) MSP430F2002IPW@TSSOP14 [(SA026)]
MSP430F2002IPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2002IPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2002IPW@TSSOP14(SPW) [(SA026)]
MSP430F2002IRSA@QFN16 [(SA727)]
MSP430F2002IRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2002IRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2002IRSA@QFN16(SPW) [(SA727)]
MSP430F2002TN
MSP430F2002TN(ISP) [ISP-HEADER01]
MSP430F2002TN(SPW ISP) [ISP-HEADER01]
MSP430F2002TN(SPW) MSP430F2002TPW@TSSOP14 [(SA026)]
MSP430F2002TPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2002TPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2002TPW@TSSOP14(SPW) [(SA026)]
MSP430F2002TRSA@QFN16 [(SA727)]
MSP430F2002TRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2002TRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2002TRSA@QFN16(SPW) [(SA727)]
MSP430F2003IN
MSP430F2003IN(ISP) [ISP-HEADER01]
MSP430F2003IN(SPW ISP) [ISP-HEADER01]
MSP430F2003IN(SPW) MSP430F2003IPW@TSSOP14 [(SA026)]
MSP430F2003IPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2003IPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2003IPW@TSSOP14(SPW) [(SA026)]
MSP430F2003IRSA@QFN16 [(SA727)]
MSP430F2003IRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2003IRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2003IRSA@QFN16(SPW) [(SA727)]
MSP430F2003TN
MSP430F2003TN(ISP) [ISP-HEADER01]
MSP430F2003TN(SPW ISP) [ISP-HEADER01]
MSP430F2003TN(SPW) MSP430F2003TPW@TSSOP14 [(SA026)]
MSP430F2003TPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2003TPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2003TPW@TSSOP14(SPW) [(SA026)]
MSP430F2003TRSA@QFN16 [(SA727)]
MSP430F2003TRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2003TRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2003TRSA@QFN16(SPW) [(SA727)]
MSP430F2011IN
MSP430F2011IN(ISP) [ISP-HEADER01]
MSP430F2011IN(SPW ISP) [ISP-HEADER01]
MSP430F2011IN(SPW) MSP430F2011IPW@TSSOP14 [(SA026)]
MSP430F2011IPW@TSSOP14(ISP) [ISP-HEADER01]
MSP430F2011IPW@TSSOP14(SPW ISP) [ISP-HEADER01]
MSP430F2011IPW@TSSOP14(SPW) [(SA026)]
MSP430F2011IRSA@QFN16 [(SA727)]
MSP430F2011IRSA@QFN16(ISP) [ISP-HEADER01]
MSP430F2011IRSA@QFN16(SPW ISP) [ISP-HEADER01]
MSP430F2011IRSA@QFN16(SPW) [(SA727)]
MSP430F2011TN
```

MSP430F2011TN(ISP) [ISP-HEADER01]  
MSP430F2011TN(SPW ISP) [ISP-HEADER01]  
MSP430F2011TN(SPW) MSP430F2011TPW@TSSOP14 [(SA026)]  
MSP430F2011TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2011TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2011TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2011TRSA@QFN16 [(SA727)]  
MSP430F2011TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2011TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2011TRSA@QFN16(SPW) [(SA727)]  
MSP430F2012IN  
MSP430F2012IN(ISP) [ISP-HEADER01]  
MSP430F2012IN(SPW ISP) [ISP-HEADER01]  
MSP430F2012IN(SPW) MSP430F2012IPW@TSSOP14 [(SA026)]  
MSP430F2012IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2012IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2012IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2012IRSA@QFN16 [(SA727)]  
MSP430F2012IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2012IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2012IRSA@QFN16(SPW) [(SA727)]  
MSP430F2012TN  
MSP430F2012TN(ISP) [ISP-HEADER01]  
MSP430F2012TN(SPW ISP) [ISP-HEADER01]  
MSP430F2012TN(SPW) MSP430F2012TPW@TSSOP14 [(SA026)]  
MSP430F2012TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2012TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2012TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2012TRSA@QFN16 [(SA727)]  
MSP430F2012TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2012TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2012TRSA@QFN16(SPW) [(SA727)]  
MSP430F2013IN  
MSP430F2013IN(ISP) [ISP-HEADER01]  
MSP430F2013IN(SPW ISP) [ISP-HEADER01]  
MSP430F2013IN(SPW) MSP430F2013IPW@TSSOP14 [(SA026)]  
MSP430F2013IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2013IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2013IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2013IRSA@QFN16 [(SA727)]  
MSP430F2013IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2013IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2013IRSA@QFN16(SPW) [(SA727)]  
MSP430F2013TN  
MSP430F2013TN(ISP) [ISP-HEADER01]  
MSP430F2013TN(SPW ISP) [ISP-HEADER01]  
MSP430F2013TN(SPW) MSP430F2013TPW@TSSOP14 [(SA026)]  
MSP430F2013TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2013TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2013TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2013TRSA@QFN16 [(SA727)]  
MSP430F2013TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2013TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2013TRSA@QFN16(SPW) [(SA727)]  
MSP430F2101@QFN24 [(SA710-B006)]  
MSP430F2101@QFN24(ISP) [ISP-HEADER01]  
MSP430F2101@SOIC20 [(SA404)]  
MSP430F2101@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2101@TSSOP20 [(SA643)]  
MSP430F2101@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2101@TVSOP20 [(SA713-B005)]  
MSP430F2101@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2102@QFN32 [(SA686)] MSP430F2102@TSSOP28 [(SA643)]  
MSP430F2111@QFN24 [(SA710-B006)]  
MSP430F2111@QFN24(ISP) [ISP-HEADER01]  
MSP430F2111@SOIC20 [(SA404)]  
MSP430F2111@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2111@TSSOP20 [(SA643)]  
MSP430F2111@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2111@TVSOP20 [(SA713-B005)]  
MSP430F2111@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2112@QFN32 [(SA686)] MSP430F2112@TSSOP28 [(SA643)]  
MSP430F2121@QFN24 [(SA710-B006)]  
MSP430F2121@QFN24(ISP) [ISP-HEADER01]  
MSP430F2121@SOIC20 [(SA404)]  
MSP430F2121@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2121@TSSOP20 [(SA643)]  
MSP430F2121@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2121@TVSOP20 [(SA713-B005)]  
MSP430F2121@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2122@QFN32 [(SA686)] MSP430F2122@TSSOP28 [(SA643)]

MSP430F2131@QFN24 [(SA710-B006)]  
MSP430F2131@QFN24(ISP) [ISP-HEADER01]  
MSP430F2131@SOIC20 [(SA404)]  
MSP430F2131@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2131@TSSOP20 [(SA643)]  
MSP430F2131@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2131@TVSOP20 [(SA713-B005)]  
MSP430F2131@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2132@QFN32 [(SA686)] MSP430F2132@TSSOP28 [(SA643)]  
MSP430F2232IDA@SSOP38 [(SA689)]  
MSP430F2232IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2232IRHA@QFN40 [(SA750)]  
MSP430F2232IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2232TDA@SSOP38 [(SA689)]  
MSP430F2232TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2232TRHA@QFN40 [(SA750)]  
MSP430F2232TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2234IDA@SSOP38 [(SA689)]  
MSP430F2234IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2234IRHA@QFN40 [(SA750)]  
MSP430F2234IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2234TDA@SSOP38 [(SA689)]  
MSP430F2234TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2234TRHA@QFN40 [(SA750)]  
MSP430F2234TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2252IDA@SSOP38 [(SA689)]  
MSP430F2252IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2252IRHA@QFN40 [(SA750)]  
MSP430F2252IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2252TDA@SSOP38 [(SA689)]  
MSP430F2252TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2252TRHA@QFN40 [(SA750)]  
MSP430F2252TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2254IDA@SSOP38 [(SA689)]  
MSP430F2254IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2254IRHA@QFN40 [(SA750)]  
MSP430F2254IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2254TDA@SSOP38 [(SA689)]  
MSP430F2254TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2254TRHA@QFN40 [(SA750)]  
MSP430F2254TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2272IDA@SSOP38 [(SA689)]  
MSP430F2272IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2272IRHA@QFN40 [(SA750)]  
MSP430F2272IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2272TDA@SSOP38 [(SA689)]  
MSP430F2272TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2272TRHA@QFN40 [(SA750)]  
MSP430F2272TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2274IDA@SSOP38 [(SA689)]  
MSP430F2274IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2274IRHA@QFN40 [(SA750)]  
MSP430F2274IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2274TDA@SSOP38 [(SA689)]  
MSP430F2274TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2274TRHA@QFN40 [(SA750)]  
MSP430F2274TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F233@LQFP64 [(PEP+S616)] MSP430F233@QFN64 [(PEP+S702)]  
MSP430F2330IRHA@QFN40 [(SA750)]  
MSP430F2330IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2330TRHA@QFN40 [(SA750)]  
MSP430F2330TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F235@LQFP64 [(PEP+S616)] MSP430F235@QFN64 [(PEP+S702)]  
MSP430F2350IRHA@QFN40 [(SA750)]  
MSP430F2350IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2350TRHA@QFN40 [(SA750)]  
MSP430F2350TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2370IRHA@QFN40 [(SA750)]  
MSP430F2370IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2370TRHA@QFN40 [(SA750)]  
MSP430F2370TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2410@LQFP64 [(PEP+S616)] MSP430F2410@QFN64 [(PEP+S702)]  
MSP430F2416@LQFP64 [(PEP+S616)] MSP430F2416@LQFP80 [(PEP+S640B)]  
MSP430F2417@LQFP64 [(PEP+S616)] MSP430F2417@LQFP80 [(PEP+S640B)]  
MSP430F2418@LQFP64 [(PEP+S616)] MSP430F2418@LQFP80 [(PEP+S640B)]  
MSP430F2419@LQFP64 [(PEP+S616)] MSP430F2419@LQFP80 [(PEP+S640B)]  
MSP430F247@LQFP64 [(PEP+S616)] MSP430F247@QFN64 [(PEP+S702)]  
MSP430F2471@LQFP64 [(PEP+S616)] MSP430F2471@QFN64 [(PEP+S702)]  
MSP430F248@LQFP64 [(PEP+S616)] MSP430F248@QFN64 [(PEP+S702)]  
MSP430F2481@LQFP64 [(PEP+S616)] MSP430F2481@QFN64 [(PEP+S702)]  
MSP430F249@LQFP64 [(PEP+S616)] MSP430F249@QFN64 [(PEP+S702)]

MSP430F2491@LQFP64 [(PEP+S616)]      MSP430F2491@QFN64 [(PEP+S702)]  
MSP430F2616@LQFP64 [(PEP+S616)]      MSP430F2616@LQFP80 [(PEP+S640B)]  
MSP430F2617@LQFP64 [(PEP+S616)]      MSP430F2617@LQFP80 [(PEP+S640B)]  
MSP430F2618@LQFP64 [(PEP+S616)]      MSP430F2618@LQFP80 [(PEP+S640B)]  
MSP430F2619@LQFP64 [(PEP+S616)]      MSP430F2619@LQFP80 [(PEP+S640B)]  
MSP430F412@QFN64 [(PEP+S702)]  
MSP430F412@QFN64(ISP) [ISP-HEADER01]  
MSP430F412@TQFP64 [(PEP+S616)]  
MSP430F412@TQFP64(ISP) [ISP-HEADER01]  
MSP430F413@QFN64 [(PEP+S702)]  
MSP430F413@QFN64(ISP) [ISP-HEADER01]  
MSP430F413@TQFP64 [(PEP+S616)]  
MSP430F413@TQFP64(ISP) [ISP-HEADER01]  
MSP430F415@TQFP64 [(PEP+S616)]  
MSP430F415@TQFP64(\*) [(SA732+B320)]  
MSP430F415@TQFP64(ISP) [ISP-HEADER01]  
MSP430F417@TQFP64 [(PEP+S616)]  
MSP430F417@TQFP64(\*) [(SA732+B320)]  
MSP430F417@TQFP64(ISP) [ISP-HEADER01]  
MSP430F423@TQFP64 [(PEP+S616)]      MSP430F425@TQFP64 [(PEP+S616)]  
MSP430F425@QFN48 [(SA696)]      MSP430F4250@SSOP48 [(SA669)]  
MSP430F4260@QFN48 [(SA696)]      MSP430F4260@SSOP48 [(SA669)]  
MSP430F427@TQFP64 [(PEP+S616)]      MSP430F4270@QFN48 [(SA696)]  
MSP430F4270@SSOP48 [(SA669)]      MSP430F435@TQFP100 [(PEP+S604)]  
MSP430F435@TQFP100(ISP) [ISP-HEADER01]  
MSP430F435@TQFP80 [(PEP+S640B)]  
MSP430F435@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4351@TQFP100 [(PEP+S604)]  
MSP430F4351@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4351@TQFP80 [(PEP+S640B)]  
MSP430F4351@TQFP80(ISP) [ISP-HEADER01]  
MSP430F436@TQFP100 [(PEP+S604)]  
MSP430F436@TQFP100(ISP) [ISP-HEADER01]  
MSP430F436@TQFP80 [(PEP+S640B)]  
MSP430F436@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4361@TQFP100 [(PEP+S604)]  
MSP430F4361@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4361@TQFP80 [(PEP+S640B)]  
MSP430F4361@TQFP80(ISP) [ISP-HEADER01]  
MSP430F437@TQFP100 [(PEP+S604)]  
MSP430F437@TQFP100(ISP) [ISP-HEADER01]  
MSP430F437@TQFP80 [(PEP+S640B)]  
MSP430F437@TQFP80(ISP) [ISP-HEADER01]  
MSP430F4371@TQFP100 [(PEP+S604)]  
MSP430F4371@TQFP100(ISP) [ISP-HEADER01]  
MSP430F4371@TQFP80 [(PEP+S640B)]  
MSP430F4371@TQFP80(ISP) [ISP-HEADER01]  
MSP430F447@TQFP100 [(PEP+S604)]  
MSP430F447@TQFP100(ISP) [ISP-HEADER01]  
MSP430F448@TQFP100 [(PEP+S604)]  
MSP430F448@TQFP100(ISP) [ISP-HEADER01]  
MSP430F449@TQFP100 [(PEP+S604)]  
MSP430F449@TQFP100(ISP) [ISP-HEADER01]  
MSP430FE423@TQFP64 [(PEP+S616)]  
MSP430FE423@TQFP64(\*) [(SA732+B320)]  
MSP430FE423@TQFP64(ISP) [ISP-HEADER01]  
MSP430FE425@TQFP64 [(PEP+S616)]  
MSP430FE425@TQFP64(\*) [(SA732+B320)]  
MSP430FE425@TQFP64(ISP) [ISP-HEADER01]  
MSP430FE427@TQFP64 [(PEP+S616)]  
MSP430FE427@TQFP64(\*) [(SA732+B320)]  
MSP430FE427@TQFP64(ISP) [ISP-HEADER01]  
MSP430FG4250@QFN48 [(SA696)]  
MSP430FG4250@QFN48(ISP) [ISP-HEADER01]  
MSP430FG4260@QFN48 [(SA696)]  
MSP430FG4260@QFN48(ISP) [ISP-HEADER01]  
MSP430FG4270@QFN48 [(SA696)]  
MSP430FG4270@QFN48(ISP) [ISP-HEADER01]  
MSP430FG437@TQFP100 [(PEP+S604)]  
MSP430FG437@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG437@TQFP80 [(PEP+S640B)]  
MSP430FG437@TQFP80(ISP) [ISP-HEADER01]  
MSP430FG438@TQFP100 [(PEP+S604)]  
MSP430FG438@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG438@TQFP80 [(PEP+S640B)]  
MSP430FG438@TQFP80(ISP) [ISP-HEADER01]  
MSP430FG439@TQFP100 [(PEP+S604)]  
MSP430FG439@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG439@TQFP80 [(PEP+S640B)]  
MSP430FG439@TQFP80(ISP) [ISP-HEADER01]  
MSP430FG4616IPZ@TQFP100 [(PEP+S604)]

```

MSP430FG4616IPZR@TQFP100 [(PEP+S604)]
MSP430FG4617IPZ@TQFP100 [(PEP+S604)]
MSP430FG4617IPZR@TQFP100 [(PEP+S604)]
MSP430FG4618IPZ@TQFP100 [(PEP+S604)]
MSP430FG4618IPZR@TQFP100 [(PEP+S604)]
MSP430FG4619IPZ@TQFP100 [(PEP+S604)]
MSP430FG4619IPZR@TQFP100 [(PEP+S604)]
MSP430FW423@TQFP64 [(PEP+S616)]
MSP430FW427@TQFP64 [(PEP+S616)]
MSP430P112@SOIC20 [(SA404)]
PMS430E112@SOIC20 [(SA404)]
MSP430FW425@TQFP64 [(PEP+S616)]
MSP430P112
PMS430E112
    
```

## TMC

### E (E) PROM/FRAM/NVRAM

```

24A01
24A01@TSSOP8 [(SA026)]
24A02@SOIC8 [(SA602A)]
24A04
24A04@TSSOP8 [(SA026)]
24A08@SOIC8 [(SA602A)]
24A16
24A16@TSSOP8 [(SA026)]
93LC46(08bit)@SOIC8 [(SA602A)]
93LC46(16bit)
93LC46(16bit)@TSSOP8 [(SA026)]
93LC56(08bit)@SOIC8 [(SA602A)]
93LC56(16bit)
93LC56(16bit)@TSSOP8 [(SA026)]
93LC57@SOIC8 [(SA602A)]
93LC66(08bit)
93LC66(08bit)@TSSOP8 [(SA026)]
93LC66(16bit)@SOIC8 [(SA602A)]
93LC86(08bit)
93LC86(08bit)@TSSOP8 [(SA026)]
93LC86(16bit)@SOIC8 [(SA602A)]
24A01@SOIC8 [(SA602A)]
24A02
24A02@TSSOP8 [(SA026)]
24A04@SOIC8 [(SA602A)]
24A08
24A08@TSSOP8 [(SA026)]
24A16@SOIC8 [(SA602A)]
93LC46(08bit)
93LC46(08bit)@TSSOP8 [(SA026)]
93LC46(16bit)@SOIC8 [(SA602A)]
93LC56(08bit)
93LC56(08bit)@TSSOP8 [(SA026)]
93LC56(16bit)@SOIC8 [(SA602A)]
93LC57
93LC57@TSSOP8 [(SA026)]
93LC66(08bit)@SOIC8 [(SA602A)]
93LC66(16bit)
93LC66(16bit)@TSSOP8 [(SA026)]
93LC86(08bit)@SOIC8 [(SA602A)]
93LC86(16bit)
93LC86(16bit)@TSSOP8 [(SA026)]
    
```

## TOPRO

### MICROCONTROLLER

```

TP2804H
TP2804H@TQFP44 [(SA245A)]
TP2804L@PLCC44 [(SA244)]
TP2808H
TP2808H@TQFP44 [(SA245A)]
TP2808L@PLCC44 [(SA244)]
TP2851
TP2851@TQFP44 [(SA245A)]
TP2852@PLCC44 [(SA244)]
TP2804H@PLCC44 [(SA244)]
TP2804L
TP2804L@TQFP44 [(SA245A)]
TP2808H@PLCC44 [(SA244)]
TP2808L
TP2808L@TQFP44 [(SA245A)]
TP2851@PLCC44 [(SA244)]
TP2852
TP2852@TQFP44 [(SA245A)]
    
```

## TOSHIBA

### E (E) PROM/FRAM/NVRAM

```

TC541000AF@PLCC32 [(SA015A1T)]
TC541001AF@PLCC32 [(SA015A1T)]
TC54256AF
TC54256AP
TC544000P
TC54512AP
TC571000AD
TC571001AD
TC571024D
TC57256A
TC57256ADI
TC574000D
TC574200D
TC57512AD
TC57H1000AD
TC541000AP
TC541001AP
TC54256AF@SOIC28 [(SA404)]
TC54256AP@SOIC28 [(SA404)]
TC54512AF
TC571000
TC571000D
TC571001D
TC57256
TC57256AD
TC57256D
TC574096D
TC57512
TC578200D
TC57H1001AD
    
```



TC57H256D TC58128AFT@TSOP48 [(SA247-B005)]  
 TC58512FT@TSOP48 [(SA247-B005)]  
 TC58DVG02A1FT00@TSOP48 [(SA247-B005)]  
 TC58DVG02A2FT00@TSOP48 [(SA247-B005)]  
 TC58DVM72A1FT00@TSOP48 [(SA247-B005)]  
 TC58DVM72A1TG00@TSOP48 [(SA247-B005)]  
 TC58DVM82A1FT00@TSOP48 [(SA247-B005)]  
 TC58DVM82A1XBJ1@TFBGA56 [(SA642U-B197-T064F001Y)]  
 TC58DVM92A1FT00@TSOP48 [(SA247-B005)]  
 TC58F400@PSOP44 [(SA638-B006)] TC58F400@TSOP48 [(SA247-B005)]  
 TC58F401@PSOP44 [(SA638-B006)] TC58F401@TSOP48 [(SA247-B005)]  
 TC58FVB004FT@TSOP40 [(SA409T)] TC58FVB008FT@TSOP40 [(SA409T)]  
 TC58FVB016FT@TSOP40 [(SA409T)]  
 TC58FVB160AFT@TSOP48 [(SA247-B005)]  
 TC58FVB160AXB@TFBGA48 [(SA642B-B026A-Y072F001)]  
 TC58FVB160FT@TSOP48 [(SA247-B005)]  
 TC58FVB321FT@TSOP48 [(SA247-B005)]  
 TC58FVB321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
 TC58FVB400F@PSOP44 [(SA638)]  
 TC58FVB400FT@TSOP48 [(SA247-B005)]  
 TC58FVB641FT@TSOP48 [(SA247-B005)]  
 TC58FVB641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
 TC58FVB800F@PSOP44 [(SA638)]  
 TC58FVB800FT@TSOP48 [(SA247-B005)]  
 TC58FVM5B2AFT@TSOP48 [(SA247-B005)]  
 TC58FVM5B2ATG@TSOP48 [(SA247-B005)]  
 TC58FVM5B2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5B2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5B3AFT@TSOP48 [(SA247-B005)]  
 TC58FVM5B3ATG@TSOP48 [(SA247-B005)]  
 TC58FVM5B3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5B3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5T2AFT@TSOP48 [(SA247-B005)]  
 TC58FVM5T2ATG@TSOP48 [(SA247-B005)]  
 TC58FVM5T2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5T2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5T3AFT@TSOP48 [(SA247-B005)]  
 TC58FVM5T3ATG@TSOP48 [(SA247-B005)]  
 TC58FVM5T3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM5T3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
 TC58FVM6B2AFT@TSOP48 [(SA247-B005)]  
 TC58FVM6B2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
 TC58FVM6B5BTG@TSOP48 [(SA247-B005)]  
 TC58FVM6B5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
 TC58FVM6T2AFT@TSOP48 [(SA247-B005)]  
 TC58FVM6T2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
 TC58FVM6T5BTG@TSOP48 [(SA247-B005)]  
 TC58FVM6T5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
 TC58FVM7B2AFT@TSOP56 [(SA628-B045)]  
 TC58FVM7B5BTG@TSOP56 [(SA628-B102)]  
 TC58FVM7B5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]  
 TC58FVM7T2AFT@TSOP56 [(SA628-B045)]  
 TC58FVM7T5BTG@TSOP56 [(SA628-B102)]  
 TC58FVM7T5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]  
 TC58FVT004FT@TSOP40 [(SA409T)] TC58FVT008FT@TSOP40 [(SA409T)]  
 TC58FVT016FT@TSOP40 [(SA409T)]  
 TC58FVT160AFT@TSOP48 [(SA247-B005)]  
 TC58FVT160AXB@TFBGA48 [(SA642B-B026A-Y072F001)]  
 TC58FVT160FT@TSOP48 [(SA247-B005)]  
 TC58FVT321FT@TSOP48 [(SA247-B005)]  
 TC58FVT321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
 TC58FVT400F@PSOP44 [(SA638)]  
 TC58FVT400FT@TSOP48 [(SA247-B005)]  
 TC58FVT641FT@TSOP48 [(SA247-B005)]  
 TC58FVT641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
 TC58FVT800F@PSOP44 [(SA638)]  
 TC58FVT800FT@TSOP48 [(SA247-B005)]  
 TC58FYB160FT@TSOP48 [(SA247-B005)]  
 TC58FYT160FT@TSOP48 [(SA247-B005)]  
 TC58NVG0S3AFT05@TSOP48 [(SA247-B005)]  
 TC58NVG0S3CTA00@TSOP48 [(SA247-B005)]  
 TC58NVG0S3ETA00@TSOP48 [(SA247-B005)]  
 TC58V64BFT@TSOP44 [(SA645-B005)] TC89101(08bit)  
 TC89101(16bit) TC89102(08bit)  
 TC89102(16bit) TC89121  
 TC89121@SOIC8 [(SA602A)] TC89122  
 TC89122@SOIC8 [(SA602A)] TC97101  
 TC9WMA1FK@US8 [(BBBB)] TC9WMA2FK@US8 [(BBBB)]  
 TC9WMB1AFK@US8 [(BBBB)] TC9WMB1AFU@SM8 [(SA666)]  
 TC9WMB1FK@US8 [(BBBB)] TC9WMB2AFK@US8 [(BBBB)]  
 TC9WMB2AFU@SM8 [(SA666)] TC9WMB2FK@US8 [(BBBB)]

TC9WMB4FU@SM8 [(SA666)]	TC9WMB8FU@SM8 [(SA666)]
TC9WMC1FK@US8 [(BBBB)]	TC9WMC1FU@SM8 [(SA666)]
TC9WMC2FK@US8 [(BBBB)]	TC9WMC2FU@SM8 [(SA666)]
TC9WMC4FK@US8 [(BBBB)]	TC9WMC4FU@SM8 [(SA602A)]
TH50VPF5582ADSB@FBGA73 [(SA642E-B032A-T072F001)]	
TH50VPF5583ADSB@FBGA73 [(SA642E-B032A-T072F001)]	
TH50VPF5682CDSB@FBGA73 [(SA642E-B032A-T072F001)]	
TH50VPF5683CDSB@FBGA73 [(SA642E-B032A-T072F001)]	
TH50VPF5782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]	
TH50VPF5783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]	
TH50VPF6782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]	
TH50VPF6783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]	
TH50VSF1480AASB@FBGA65 [(SA642A-B032A-Y096N001)]	
TH50VSF1481AASB@FBGA65 [(SA642A-B032A-Y096N001)]	
TH50VSF2480AASB@FBGA65 [(SA642A-B032A-Y096N001)]	
TH50VSF2481AASB@FBGA65 [(SA642A-B032A-Y096N001)]	
TH50VSF2580AASB@FBGA69 [(SA642A-B032A-Y096F001)]	
TH50VSF2581AASB@FBGA69 [(SA642A-B032A-Y096F001)]	
TH50VSF2582AASB@FBGA69 [(SA642A-B032A-Y096F001)]	
TH50VSF2583AASB@FBGA69 [(SA642A-B032A-Y096F001)]	
TH50VSF2582ADSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF2583ADSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF2583BDSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF2590AASB@FBGA69 [(SA642A-B032A-Y096F001)]	
TH50VSF2682BDSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF2683BDSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF3580AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3581AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3582AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3583AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3582BDSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF3583BDSB@FBGA73 [(SA642A-B032A-Y096F001)]	
TH50VSF3680AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3681AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3682AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3683AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF3682BDSB@FBGA73 [(SA642E-B032A-T072F001)]	
TH50VSF3683BDSB@FBGA73 [(SA642E-B032A-T072F001)]	
TH50VSF4682AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TH50VSF4683AASB@FBGA69 [(SA642A-B032A-Y096N001)]	
TMM24128	TMM24128A
TMM24128AP	TMM24256
TMM24256A	TMM24256AP
TMM24256B	TMM24512
TMM24512A	TMM24512P
TMM2464AP	TMM27128
TMM27128A	TMM27128ADI
TMM27128AP	TMM27256
TMM27256A	TMM27256AD
TMM27256ADI	TMM27256BD
TMM27256BDI	TMM27256D
TMM27256DI	TMM2732
TMM2732A	TMM2732D
TMM27512	TMM27512AD
TMM27512ADI	TMM27512D
TMM27512DI	TMM2764
TMM2764AD	TMM2764ADI
TMM2764AP	TMM2764D
TMM2764DI	
TV00560002ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]	
TV00560002DDGB@FBGA81 [(SA642R-B079A-T096F001N)]	
TV00560002EDGB@FBGA81 [(SA642R-B079A-T096F001N)]	
TV00560003ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]	
TV00569002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]	
TV00569002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]	
TV00569002BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]	
TV00569002BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]	
TV00569003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]	
TV00569003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]	
TV00569003BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]	
TV00569003BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]	
TV00570002AABB@FBGA73 [(SA664A-B096A-W115F001Y)]	
TV00570002ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]	
TV00570002CDGB@FBGA81 [(SA642R-B039A-Y096F001Y)]	
TV00570003AABB@FBGA73 [(SA664A-B096A-W115F001Y)]	
TV00570003ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]	
TV00570003CDGB@FBGA81 [(SA642R-B039A-Y096F001Y)]	
TV00578002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]	
TV00578002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]	
TV00578002CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]	

TV00578002CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00578003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV00578003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00578003CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV00578003CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00579002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV00579002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00579002AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV00579002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00579003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV00579003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00579003AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV00579003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0057A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0057A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0057A002CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0057A002CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0057A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0057A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0057A003CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0057A003CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV00670002ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
 TV00670002CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV00670002CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV00670002CDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
 TV00670003ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
 TV00670003CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV00670003CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV00670003CDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
 TV0067A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0067A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0067A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0067A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0068A02SAAGD(NOR)@FBGA107 [(SA664A-B096A-W115F001Y)]  
 TY00679002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY00679003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY80008000AMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY80008000DMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY80009000AMBF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY8000A010AMGF(HZ)@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY8000A010AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009000AMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009400BMGF(HZ)@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009400BMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009400DMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009800AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY90009800COGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY90009C00AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A000ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000CMHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000EMGF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000GMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A400AMGF(HZ)@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A400AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A800AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800EOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800GOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800HOGG@TFBGA225 [(SA678L-B244-M225F001Y)]  
 TY9000AC00COGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000C010ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000AC00EOGG@TFBGA225 [(SA678L-B294-Y225F001Y)]  
 TYA000B000ALKF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000B400ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000BC10AOGG@FBGA225 [(SA678L-B244-Y225F001Y)]

## DRAM & SRAM

TC518128	TC518128@SOIC32 [(SA630)]
TC518129	TC518129@SOIC32 [(SA630)]
TC51832	TC51832@SOIC28 [(SA630)]
TC518512	TC518512@SOIC32 [(SA630)]
TC551001FL	TC551001FL@SOIC32 [(SA630)]
TC551001PL	TC551001PL@SOIC32 [(SA630)]
TC55257	TC55257@SOIC28 [(SA630)]
TC55257L	TC55257L@SOIC28 [(SA630)]
TC55258	TC55258@SOIC28 [(SA630)]
TC55258L	TC55258L@SOIC28 [(SA630)]
TC55328	TC55328@SOIC28 [(SA630)]
TC5561P	TC5561P@SOJ24 [(SA646)]

TC5562P	TC5562P@SOJ24 [(SA646)]
TC5563APL	TC5563APL@SOIC28 [(SA630)]
TC5564APL	TC5564APL@SOIC28 [(SA630)]
TC5565AFL	TC5565AFL@SOIC28 [(SA630)]
TC5565APL	TC5565APL@SOIC28 [(SA630)]
TC5588	TC5588@SOIC28 [(SA630)]
TC55B88	TC55B88@SOIC28 [(SA630)]
TMM2018	TMM2018@PLCC32 [(SA015A1T)]
TMM2063	TMM2063@SOIC28 [(SA630)]

## MICROCONTROLLER

TMP47P443VDM@SSOP30 [(SA438T)]	TMP47P443VM@SOP28 [(SA404)]
TMP47P443VN@SDIP28 [(SA022A)]	TMP68HC11E1@PLCC52 [(PEP+S415T)]
TMP68HC11E1@PLCC52(*) [(SA647-B5202)]	TMP68HC11E1@QFP52 [(PEP+S673)]
TMP68HC11E1@QFP52 [(PEP+S673)]	TMP68HC11E9@PLCC52 [(SA647-B5202)]
TMP68HC11E9@PLCC52(*) [(SA647-B5202)]	TMP68HC11E9@QFP52 [(PEP+S673)]
TMP68HC711E9@PLCC52(*) [(SA647-B5202)]	TMP86CS44@LQFP44 [(SA245A)]
TMP86CS44@LQFP44 [(SA245A)]	TMP86FH47ADUG@QFP48 [(SA248)]
TMP86FH47AUG@QFP44 [(SA245A)]	TMP86FH92DMG@SSOP30 [(SA626A)]
TMP86FH92IDMG@SSOP30 [(SA626A)]	TMP86P202M@SOIC20 [(SA023A)]
TMP86P202P	TMP86P203M@SOIC20 [(SA023A)]
TMP86P203P	TMP86P807M@SOP28 [(SA438T)]
TMP86P807N@SDIP28 [(SA653)]	TMP86P808DM@SSOP30 [(SA626A)]
TMP86P808N@SDIP30 [(SA653)]	TMP86PH06N@SDIP42 [(SA028+B005)]
TMP86PH06U@QFP44 [(SA245A+B005)]	TMP86PH46N@SDIP42 [(SA028+B005)]
TMP86PH46NG@SDIP42 [(SA028+B005)]	
TMP86PM47U@QFP44 [(SA245A+B005)]	
TMP86PM47UG@QFP44 [(SA245A+B005)]	
TMP86PS44@LQFP44 [(SA245A)]	TMP87P408M@SOIC28 [(SA404)]
TMP87P408N@SDIP28 [(SA022A)]	TMP87P409M@SOIC28 [(SA404)]
TMP87P409N@SDIP28 [(SA022A)]	TMP87P808LM@SOP28 [(SA404)]
TMP87P808LM@SOP28(Toshiba) [(BM11116)]	
TMP87P808LN@SDIP28 [(SA022A)]	
TMP87P808LN@SDIP28(Toshiba) [(BM11122)]	
TMP87P808M@SOP28 [(SA404)]	
TMP87P808M@SOP28(Toshiba) [(BM11116)]	
TMP87P808N@SDIP28 [(SA022A)]	
TMP87P808N@SDIP28(Toshiba) [(BM11122)]	
TMP87P809M@SOIC28 [(SA404)]	TMP87P809N@SDIP28 [(SA022A)]
TMP87P844N@SDIP42 [(SA028)]	
TMP87P844N@SDIP42(Toshiba) [(BM11108)]	
TMP87P844NG@SDIP42 [(SA028)]	
TMP87P844NG@SDIP42(Toshiba) [(BM11108)]	
TMP87PH00DF@QFP64 [(PEP+S621)]	
TMP87PH00DF@QFP64(Toshiba) [(BM1173)]	
TMP87PH00F@QFP64(*) [(TA022-B006)]	
TMP87PH00F@QFP64(Toshiba) [(BM1137)]	
TMP87PH00LF@QFP64 [(PEP+S621)]	
TMP87PH00LF@QFP64(Toshiba) [(BM1173)]	
TMP87PH00N@SDIP64(*) [(S600A-B6402)]	
TMP87PH00N@SDIP64(Toshiba) [(BM1136)]	
TMP87PH20F@QFP80(Toshiba) [(BM1138)]	
TMP87PH40AF@PQFP64(*) [(TA022-B006)]	
TMP87PH40AF@PQFP64(Toshiba) [(BM1137)]	
TMP87PH40AN@SDIP64(*) [(S600A-B6402)]	
TMP87PH40AN@SDIP64(Toshiba) [(BM1136)]	
TMP87PH46N@SDIP42 [(SA028)]	
TMP87PH46N@SDIP42(Toshiba) [(BM1193)]	
TMP87PH47LU@QFP44 [(SA245A)]	
TMP87PH47LU@QFP44(Toshiba) [(BM1194C)]	
TMP87PH47U@QFP44 [(SA245A)]	
TMP87PH47U@QFP44(Toshiba) [(BM1194C)]	
TMP87PM14F@QFP64(Toshiba) [(BM1199)]	
TMP87PM14N@SDIP64(Toshiba) [(BM1198)]	
TMP87PM20F@QFP80(Toshiba) [(BM1138)]	
TMP87PM29U@LQFP64 [(PEP+S616)]	
TMP87PM29U@LQFP64(Toshiba) [(BM11117)]	
TMP87PM34AN@SDIP42(Toshiba) [(BM1183A)]	
TMP87PM36N@SDIP42(Toshiba) [(BM1183A)]	
TMP87PM40AF@PQFP64(*) [(TA022-B006)]	
TMP87PM40AF@PQFP64(Toshiba) [(BM1137)]	
TMP87PM40AN@SDIP64(*) [(S600A-B6402)]	
TMP87PM40AN@SDIP64(Toshiba) [(BM1136)]	
TMP87PM41F@QFP64(*) [(TA022-B006)]	
TMP87PM41F@QFP64(Toshiba) [(BM1137)]	
TMP87PM41N@SDIP64(*) [(S600A-B6402)]	
TMP87PM41N@SDIP64(Toshiba) [(BM1136)]	

TMP87PM41U@LQFP64 [(PEP+S621)]  
TMP87PM41U@LQFP64(Toshiba) [(BM1121)]  
TMP87PM43N@SDIP42 [(SA028)]  
TMP87PM43N@SDIP42(Toshiba) [(BM1163)]  
TMP87PM70F@QFP80 [(PEP+S611A)]  
TMP87PM70F@QFP80(Toshiba) [(BM1150B)]  
TMP87PM74F@QFP80 [(PEP+S611A)]  
TMP87PM74F@QFP80(Toshiba) [(BM11120)]  
TMP87PM75F@QFP100(Toshiba) [(BM11124)]  
TMP87PM78F@QFP100(Toshiba) [(BM1188)]  
TMP87PP21DF@LQFP80 [(PEP+S640B)]  
TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]  
TMP87PP21F@QFP80 [(PEP+S611A)]  
TMP87PP21F@QFP80(Toshiba) [(BM11104)]  
TMP87PP23F@QFP100 [(PEP+S427)]  
TMP87PP23F@QFP100(Toshiba) [(BM1185A)]  
TMP87PP24F@LQFP100 [(PEP+S604)]  
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]  
TMP87PP71F@QFP80 [(PEP+S611A)]  
TMP87PP71F@QFP80(Toshiba) [(BM11107)]  
TMP87PS38F@QFP44 [(SA679)]  
TMP87PS38F@QFP44(Toshiba) [(BM11136)]  
TMP87PS38N@SDIP42 [(SA028)]  
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]  
TMP87PS39F@QFP64(Toshiba) [(BM11138)]  
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]  
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]  
TMP87PS71F@QFP80 [(PEP+S611A)]  
TMP87PS71F@QFP80(Toshiba) [(BM11107)]  
TMP88PH40M@SOIC28 [(SA438T)] TMP88PH40N@SDIP28 [(SA653)]  
TMP91PW12F@LQFP100 [(PEP+S604)] TMP91PW18A@LQFP80 [(PEP+S604)]  
TMP93PW44ADF@PQFP80 [(SA730+B263)]

## TOSHIBA-CUSTOMER

### E(E) PROM/FRAM/NVRAM

TC58DAM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM82A1@FBGA63 [(SA642B-B026A-Y072F001)]  
TC58DVM82A1@TSOP48 [(SA247-B005)]  
TY9000A000EMGF(YH)@BGA149 [(SA664G-B279-Y149F001Y)]

### MICROCONTROLLER

TMP87PM40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PM40AN@SDIP64(\*) [(S600A-B6402)]

## TURBO IC

### E(E) PROM/FRAM/NVRAM

TU24C01 TU24C01@SOIC8 [(SA602A)]  
TU24C02 TU24C02@SOIC8 [(SA602A)]  
TU24C04 TU24C04@SOIC8 [(SA602A)]  
TU24C08 TU24C08@SOIC8 [(SA602A)]  
TU24C128 TU24C128@SOIC8 [(SA602A)]  
TU24C16 TU24C16@SOIC8 [(SA602A)]  
TU24C16@TSSOP8 [(SA026)] TU24C256  
TU24C256@SOIC8 [(SA602A)] TU24C32  
TU24C32@SOIC8 [(SA602A)] TU24C64  
TU24C64@SOIC8 [(SA602A)]

## UBICOM

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)] SX20AC/SS@SSOP20 [(SA626A)]  
SX28AC/DP SX28AC/DP/G  
SX28AC/SS/G@SSOP28 [(SA626A)] SX28AC/SS@SSOP28 [(SA626A)]

SX48BD/G@TQFP48 [(SA248)]

SX48BD@TQFP48 [(SA248)]

## UMC

### E(E) PROM/FRAM/NVRAM

2732

2764

### DRAM & SRAM

UM6116	UM6116@PLCC32 [(SA015A1T)]
UM6116A	UM6116A@PLCC32 [(SA015A1T)]
UM61256	UM61256@SOIC28 [(SA630)]
UM61257	UM61512
UM61512@SOIC32 [(SA630)]	UM6164
UM6164@SOIC28 [(SA630)]	UM6167
UM621024	UM621024@SOIC32 [(SA630)]
UM62256	UM62256@SOIC28 [(SA630)]
UM62256A	UM62256A@SOIC28 [(SA630)]
UM6264	UM6264@SOIC28 [(SA630)]
UM6264A	UM6264A@SOIC28 [(SA630)]

## UTRON

### E(E) PROM/FRAM/NVRAM

UT61256C	UT61256C@SOIC28 [(SA630)]
UT61256C@TSOP28 [(SA430T)]	UT6164C@SOIC28 [(SA630)]
UT6164C@TSOP28 [(SA430T)]	UT61L256C
UT61L256C@SOIC28 [(SA630)]	UT61L256C@TSOP28 [(SA430T)]
UT62256C	UT62256C@SOIC28 [(SA630)]
UT62256C@TSOP28 [(SA430T)]	UT62256CE
UT62256CE@SOIC28 [(SA630)]	UT62256CE@TSOP28 [(SA430T)]
UT62257C	UT62257C@SOIC28 [(SA630)]
UT62257C@TSOP28 [(SA430T)]	UT6264C
UT6264C@SOIC28 [(SA630)]	UT62L256C
UT62L256C@SOIC28 [(SA630)]	UT62L256C@TSOP28 [(SA430T)]
UT62L64C	UT62L64C@SOIC28 [(SA630)]
UT62W256C	UT62W256C@SOIC28 [(SA630)]
UT62W256C@TSOP28 [(SA430T)]	UT62W64C
UT62W64C@SOIC28 [(SA630)]	

## VANTIS

### PLD

M4-128/64@PQFP100 [(PEP+S427)]	M4-128/64@TQFP100 [(PEP+S604)]
M4-128N/64@PLCC84 [(PEP+S416T)]	M4A3-128/64@PQFP100 [(PEP+S427)]
M4A3-128/64@TQFP100 [(PEP+S604)]	
M4A3-128N/64@PLCC84 [(PEP+S416T)]	M4A3-32/32@TQFP44 [(SA245A)]
M4A3-32/32@PLCC44 [(SA244)]	M4A3-64/32@PLCC44 [(SA244)]
M4A3-32/32@TQFP48 [(SA248)]	M4A3-64/32@TQFP48 [(SA248)]
M4A3-64/32@TQFP44 [(SA245A)]	M4A3-96/48@TQFP100 [(PEP+S604)]
M4A3-64/64@TQFP100 [(PEP+S604)]	M4A5-128/64@TQFP100 [(PEP+S604)]
M4A5-128/64@PQFP100 [(PEP+S427)]	
M4A5-128N/64@PLCC84 [(PEP+S416T)]	M4A5-32/32@TQFP44 [(SA245A)]
M4A5-32/32@PLCC44 [(SA244)]	M4A5-64/32@PLCC44 [(SA244)]
M4A5-32/32@TQFP48 [(SA248)]	M4A5-64/32@TQFP48 [(SA248)]
M4A5-64/32@TQFP44 [(SA245A)]	M4LV-128/64@PQFP100 [(PEP+S427)]
M4A5-96/48@TQFP100 [(PEP+S604)]	
M4LV-128/64@TQFP100 [(PEP+S604)]	MACH111@PLCC44 [(SA244)]
M4LV-128N/64@PLCC84 [(PEP+S416T)]	MACH120@PLCC68 [(PEP+S414T)]
MACH110@PLCC44 [(SA244)]	MACH131/1@PLCC84 [(PEP+S416T)]
MACH111@TQFP44 [(SA245A)]	MACH131SP@PQFP100 [(PEP+S427)]
MACH130@PLCC84 [(PEP+S416T)]	MACH210@PLCC44 [(SA244)]
MACH131@PLCC84 [(PEP+S416T)]	MACH210A@PLCC44 [(SA244)]
MACH131SP@TQFP100 [(PEP+S604)]	MACH210AQ@PLCC44 [(SA244)]
MACH210@TQFP44 [(SA245A)]	MACH211@PLCC44 [(SA244)]
MACH210A@TQFP44 [(SA245A)]	
MACH210AQ@TQFP44 [(SA245A)]	

MACH211@TQFP44 [(SA245A)]	MACH211SP@PLCC44 [(SA244)]
MACH211SP@TQFP44 [(SA245A)]	MACH220@PLCC68 [(PEP+S414T)]
MACH221@PLCC68 [(PEP+S414T)]	MACH230@PLCC84 [(PEP+S416T)]
MACH231@PLCC84 [(PEP+S416T)]	MACH231SP@PLCC84 [(PEP+S416T)]
MACH231SP@PQFP100 [(PEP+S427)]	MACH231SP@TQFP100 [(PEP+S604)]
MACH435@PLCC84 [(PEP+S416T)]	MACH436@PLCC84 [(PEP+S416T)]
MACH446@PQFP100 [(PEP+S427)]	MACH446@TQFP100 [(PEP+S604)]
MACHLV210@PLCC44 [(SA244)]	MACHLV436@PLCC84 [(PEP+S416T)]
MACHLV446@PQFP100 [(PEP+S427)]	MACHLV446@TQFP100 [(PEP+S604)]
PAL29M16H	PALCE20RA10
PALCE20RA10@PLCC28 [(SA008A)]	PALCE20RA10@SOIC24 [(SA404)]
PALCE20RA10H	PALCE20RA10H@PLCC28 [(SA008A)]
PALCE20RA10H@SOIC24 [(SA404)]	PALCE20RA10Q
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24 [(SA404)]
PALCE26V12H/4	PALCE26V12H/4@PLCC28 [(SA008A)]
PALCE26V12H/4@SOIC28 [(SA404)]	PALCE26V12H-15
PALCE26V12H-15@PLCC28 [(SA008A)]	PALCE26V12H-15@SOIC28 [(SA404)]
PALCE26V12H-20	PALCE26V12H-20@PLCC28 [(SA008A)]
PALCE26V12H-20@SOIC28 [(SA404)]	PALCE26V12H-25
PALCE26V12H-25@PLCC28 [(SA008A)]	PALCE26V12H-25@SOIC28 [(SA404)]
PALCE29M16H	PALCE29M16H@PLCC28 [(SA008A)]
PALCE29M16H@SOIC24 [(SA404)]	PALCE29MA16H
PALCE29MA16H@PLCC28 [(SA008A)]	PALCE29MA16H@SOIC24 [(SA404)]
PALCE610	PALCE610@PLCC28 [(SA008A)]
PALCE610@SOIC24 [(SA404)]	PALCE610H
PALCE610H@PLCC28 [(SA008A)]	PALCE610H@SOIC24 [(SA404)]
PALCE630H	PALCE630H@PLCC28 [(SA008A)]
PALCE630H@SOIC24 [(SA404)]	

## VERSACHIPS

### MICROCONTROLLER

V87C54	V87C54@PLCC44 [(SA244)]
V87C54@TQFP44 [(SA245A)]	V87C58
V87C58@PLCC44 [(SA244)]	V87C58@TQFP44 [(SA245A)]

## VLSI

### E(E) PROM/FRAM/NVRAM

VT27C128	VT27C256
VT27C512	VT27C64
VT28H64	VT28HC64

### PLD

GAL16V8

## WELTREND

### MICROCONTROLLER

WT61P4K420@SDIP42 [(SA028)]	WT61P4K421@SDIP42 [(SA028)]
WT61P4K422@SDIP42 [(SA028)]	WT61P4L440@PLCC44 [(SA244)]
WT61P4N400	WT61P4N401
WT61P6K420@SDIP42 [(SA028)]	WT61P6L440@PLCC44 [(SA244)]
WT61P6L441@PLCC44 [(SA244)]	WT61P6S@LQFP44 [(SA245A+B258)]
WT61P7@LQFP44 [(SA245)]	WT61P7@PLCC44 [(SA244)]
WT61P7@TQFP48 [(SA248+B250)]	WT61P8@LQFP44 [(SA245A+B258)]
WT61P8S@LQFP44 [(SA245A+B005)]	WT62P1-K42@SDIP42 [(SA028)]
WT62P1-N28(dip28)	WT62P1-N40(dip40)
WT62P1-N42(dip42)	WT62P1-S44@PSOP44 [(SA638)]
WT62P2-K42@SDIP42 [(SA028)]	WT62P2-L44@PLCC44 [(SA244)]
WT62P2-N40(dip40)	WT62P2-N42(dip42)
WT62P2-S44@PSOP44 [(SA638)]	WT65F1@SOIC28 [(SA404)]
WT65F1@TQFP48 [(SA248)]	WT6702F@SOP16 [(SA602)]
WT6702F@SOP20 [(SA404)]	WT6702F@SOP24 [(SA404)]
WT6702F@SSOP20 [(SA674)]	WT6703F@SOP20 [(SA404)]
WT6703F@SOP24 [(SA404)]	WT6703F@SOP28 [(SA404)]

WT6703F@SSOP20 [(SA674)] WT6703F@SSOP24 [(SA674)]  
 WT6703FS161@SSOP16 [(SA602)] WT6703FS163@SSOP16 [(SA602)]

## WHITE ELECTRONIC DESIGNS

### E (E) PROM/FRAM/NVRAM

WE128K8	WE256K8
WE512K8	WF256K8
WF256K8@CLCC32 [(SA015A1T)]	WF256K8@CSOJ32 [(SA661)]
WF512K8	WF512K8@CLCC32 [(SA015A1T)]
WF512K8@CSOJ32 [(SA661)]	WME128K8
WME128K8@CLCC32 [(SA015A1T)]	WME128K8@CSOJ32 [(SA661)]
WMF128K8	WMF128K8@CLCC32 [(SA015A1T)]
WMF128K8@CSOJ32 [(SA661)]	WMF256K8
WMF256K8@CLCC32 [(SA015A1T)]	WMF256K8@CSOJ32 [(SA661)]
WMF512K8	WMF512K8@CLCC32 [(SA015A1T)]
WMF512K8@CSOJ32 [(SA661)]	WMS128K8
WMS128K8@CLCC32 [(SA015A1T)]	WMS128K8@CSOJ32 [(SA661)]
WMS256K8	WMS256K8@CLCC32 [(SA015A1T)]
WMS256K8@CSOJ32 [(SA661)]	WMS512K8
WMS512K8@CLCC32 [(SA015A1T)]	WMS512K8@CSOJ32 [(SA661)]
WSF128K16@PGA66 [(PEP+S667+B6601)]	

## WINBOND

### E (E) PROM/FRAM/NVRAM

W15B020L	W15B020L@SOIC8 [(SA602A)]
W15B020M	W15B020M@SOIC8 [(SA602A)]
W15B040L	W15B040L@SOIC8 [(SA602A)]
W15B040M	W15B040M@SOIC8 [(SA602A)]
W19B160BB@FBGA48 [(SA642G-B026A-T048F001Y)]	
W19B160BB@TSOP48 [(SA247-B005)]	
W19B160BT@FBGA48 [(SA642G-B026A-T048F001Y)]	
W19B160BT@TSOP48 [(SA247-B005)]	
W19B320AB@FBGA48 [(SA642A-B026A-Y096F001Y)]	
W19B320AB@TSOP48 [(SA247-B005)]	
W19B320AT@FBGA48 [(SA642A-B026A-Y096F001Y)]	
W19B320AT@TSOP48 [(SA247-B005)]	
W19B320BB@FBGA48 [(SA642G-B026A-T048F001Y)]	
W19B320BB@TSOP48 [(SA247-B005)]	
W19B320BT@FBGA48 [(SA642G-B026A-T048F001Y)]	
W19B320BT@TSOP48 [(SA247-B005)]	
W19B320SB@FBGA48 [(SA642F-B026A-T064F001)]	
W19B320SB@TSOP48 [(SA247-B005)]	
W19B320ST@FBGA48 [(SA642F-B026A-T064F001)]	
W19B320ST@TSOP48 [(SA247-B005)]	
W19B322MB@FBGA48 [(SA642F-B026A-T064F001)]	
W19B322MB@TSOP48 [(SA247-B005)]	
W19B322MT@FBGA48 [(SA642F-B026A-T064F001)]	
W19B322MT@TSOP48 [(SA247-B005)]	
W19B323MB@FBGA48 [(SA642F-B026A-T064F001)]	
W19B323MB@TSOP48 [(SA247-B005)]	
W19B323MT@FBGA48 [(SA642F-B026A-T064F001)]	
W19B323MT@TSOP48 [(SA247-B005)]	
W19B324MB@FBGA48 [(SA642F-B026A-T064F001)]	
W19B324MB@TSOP48 [(SA247-B005)]	
W19B324MT@FBGA48 [(SA642F-B026A-T064F001)]	
W19B324MT@TSOP48 [(SA247-B005)]	
W19L320SB@FBGA48 [(SA642F-B026A-T064F001)]	
W19L320SB@TSOP48 [(SA247-B005)]	
W19L320ST@FBGA48 [(SA642F-B026A-T064F001)]	
W19L320ST@TSOP48 [(SA247-B005)]	
W25B40(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40(Bottom Boot)@WSON8 [(SA683)]	
W25B40(Top Boot)@SOIC8 [(SA602A)]	
W25B40(Top Boot)@WSON8 [(SA683)]	
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40A(Bottom Boot)@WSON8 [(SA683)]	
W25B40A(Top Boot)@SOIC8 [(SA602A)]	
W25B40A(Top Boot)@WSON8 [(SA683)]	
W25D10	W25D10(SN)@SOIC8 [(SA602A)]
W25D10(SS)@SOIC8 [(SA023A)]	W25D10(ZP)@WSON8 [(SA683)]



W25D20	W25D20(SN)@SOIC8 [(SA602A)]
W25D20(SS)@SOIC8 [(SA023A)]	W25D20(ZP)@WSON8 [(SA683)]
W25D40	W25D40(SN)@SOIC8 [(SA602A)]
W25D40(SS)@SOIC8 [(SA023A)]	W25D40(ZP)@WSON8 [(SA683)]
W25D80	W25D80(SN)@SOIC8 [(SA602A)]
W25D80(SS)@SOIC8 [(SA023A)]	W25D80(ZP)@WSON8 [(SA683)]
W25P10@SOIC8 [(SA602A)]	W25P10@WSON8 [(SA683)]
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16(ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)]	W25P16@SOIC8(ISP) [ISP-HEADER01]
W25P16@WSON8 [(SA683)]	W25P16@WSON8(ISP) [ISP-HEADER01]
W25P20@SOIC8 [(SA602A)]	W25P20@WSON8 [(SA683)]
W25P32@SOIC16 [(SA404)]	
W25P32@SOIC16(ISP) [ISP-HEADER01]	
W25P32@WSON8 [(SA683)]	W25P32@WSON8(ISP) [ISP-HEADER01]
W25P40@SOIC8 [(SA602A)]	W25P40@WSON8 [(SA683)]
W25P64@SOIC16 [(SA404)]	
W25P64@SOIC16(ISP) [ISP-HEADER01]	
W25P64@WSON8 [(SA683)]	W25P64@WSON8(ISP) [ISP-HEADER01]
W25P80@SOIC8 [(SA602A)]	W25P80@WSON8 [(SA683)]
W25Q128BV@SOIC16 [(SA404)]	W25Q128BV@WSON8 [(SA684)]
W25Q16@SOIC16 [(SA404)]	
W25Q16@SOIC16(ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [(SA023A)]	W25Q16@SOIC8(ISP) [ISP-HEADER01]
W25Q16@WSON8 [(SA683)]	W25Q16@WSON8(ISP) [ISP-HEADER01]
W25Q16BV@SOIC16 [(SA404)]	W25Q16BV@SOIC8 [(SA023A)]
W25Q16BV@WSON8 [(SA683)]	W25Q16V@SOIC16 [(SA404)]
W25Q16V@SOIC8 [(SA023A)]	W25Q16V@WSON8 [(SA683)]
W25Q32@SOIC16 [(SA404)]	
W25Q32@SOIC16(ISP) [ISP-HEADER01]	
W25Q32@SOIC8 [(SA023A)]	W25Q32@WSON8 [(SA683)]
W25Q32@WSON8(ISP) [ISP-HEADER01]	W25Q32BV@SOIC16 [(SA404)]
W25Q32BV@SOIC8 [(SA023A)]	W25Q32BV@WSON8 [(SA683)]
W25Q32V@SOIC16 [(SA404)]	W25Q32V@SOIC8 [(SA023A)]
W25Q32V@WSON8 [(SA683)]	W25Q64BV@SOIC16 [(SA404)]
W25Q64BV@SOIC8 [(SA023A)]	W25Q80@SOIC8 [(SA602A)]
W25Q80@WSON8 [(SA683)]	W25Q80BV
W25Q80BV@SOIC16 [(SA602A)]	W25Q80BV@SOIC8[4.0] [(SA602A)]
W25Q80BV@SOIC8[5.4] [(SA605A)]	W25Q80BV@WSON8 [(SA683)]
W25X10	W25X10(SN)@SOIC8 [(SA602A)]
W25X10(SS)@SOIC8 [(SA023A)]	W25X10(ZP)@WSON8 [(SA683)]
W25X10AV	W25X10AV(SN)@SOIC8 [(SA602A)]
W25X10AV(SS)@SOIC8 [(SA023A)]	W25X10AV(ZP)@WSON8 [(SA683)]
W25X10BV	W25X10BV(SN)@SOIC8 [(SA602A)]
W25X10BV(SS)@SOIC8 [(SA023A)]	W25X10BV(ZP)@WSON8 [(SA683)]
W25X10L	W25X10L(SN)@SOIC8 [(SA602A)]
W25X10L(ZP)@WSON8 [(SA683)]	W25X10V
W25X10V(SN)@SOIC8 [(SA602A)]	W25X10V(SS)@SOIC8 [(SA023A)]
W25X10V(ZP)@WSON8 [(SA683)]	W25X16@SOIC16 [(SA404)]
W25X16@SOIC16(ISP) [ISP-HEADER01]	
W25X16@SOIC8 [(SA023A)]	W25X16@SOIC8(ISP) [ISP-HEADER01]
W25X20	W25X20(SN)@SOIC8 [(SA602A)]
W25X20(SS)@SOIC8 [(SA023A)]	W25X20(ZP)@WSON8 [(SA683)]
W25X20AV	W25X20AV(SN)@SOIC8 [(SA602A)]
W25X20AV(SS)@SOIC8 [(SA023A)]	W25X20AV(ZP)@WSON8 [(SA683)]
W25X20BV	W25X20BV(SN)@SOIC8 [(SA602A)]
W25X20BV(SS)@SOIC8 [(SA023A)]	W25X20BV(ZP)@WSON8 [(SA683)]
W25X20L	W25X20L(SN)@SOIC8 [(SA602A)]
W25X20L(ZP)@WSON8 [(SA683)]	W25X20V
W25X20V(SN)@SOIC8 [(SA602A)]	W25X20V(SS)@SOIC8 [(SA023A)]
W25X20V(ZP)@WSON8 [(SA683)]	W25X32@SOIC16 [(SA404)]
W25X32@SOIC16(ISP) [ISP-HEADER01]	
W25X32@SOIC8 [(SA023A)]	W25X32@SOIC8(ISP) [ISP-HEADER01]
W25X40	W25X40(SN)@SOIC8 [(SA602A)]
W25X40(SS)@SOIC8 [(SA023A)]	W25X40(ZP)@WSON8 [(SA683)]
W25X40AV	W25X40AV(SN)@SOIC8 [(SA602A)]
W25X40AV(SS)@SOIC8 [(SA023A)]	W25X40AV(ZP)@WSON8 [(SA683)]
W25X40BV	W25X40BV(SN)@SOIC8 [(SA602A)]
W25X40BV(SS)@SOIC8 [(SA023A)]	W25X40BV(ZP)@WSON8 [(SA683)]
W25X40L	W25X40L(SN)@SOIC8 [(SA602A)]
W25X40L(SS)@SOIC8 [(SA023A)]	W25X40L(ZP)@WSON8 [(SA683)]
W25X40V	W25X40V(SN)@SOIC8 [(SA602A)]
W25X40V(SS)@SOIC8 [(SA023A)]	W25X40V(ZP)@WSON8 [(SA683)]
W25X64@SOIC16 [(SA404)]	
W25X64@SOIC16(ISP) [ISP-HEADER01]	
W25X64@SOIC8 [(SA023A)]	W25X64@SOIC8(ISP) [ISP-HEADER01]
W25X80	W25X80(SN)@SOIC8 [(SA602A)]
W25X80(SS)@SOIC8 [(SA023A)]	W25X80(ZP)@WSON8 [(SA683)]
W25X80AV	W25X80AV(SN)@SOIC8 [(SA602A)]
W25X80AV(SS)@SOIC8 [(SA023A)]	W25X80AV(ZP)@WSON8 [(SA683)]
W25X80L	W25X80L(SS)@SOIC8 [(SA023A)]

W25X80L(ZP)@WSON8 [(SA683)]	W25X80V
W25X80V(SN)@SOIC8 [(SA602A)]	W25X80V(SS)@SOIC8 [(SA023A)]
W25X80V(ZP)@WSON8 [(SA683)]	W27C01
W27C01@PLCC32 [(SA015A1T)]	W27C01@VSOP32 [(SA620)]
W27C010	W27C010@PLCC32 [(SA015A1T)]
W27C010@SOIC32 [(SA438T)]	W27C02
W27C02@PLCC32 [(SA015A1T)]	W27C02@VSOP32 [(SA620)]
W27C020	W27C020@PLCC32 [(SA015A1T)]
W27C020M	W27C020M@PLCC32 [(SA015A1T)]
W27C257	W27C257@PLCC32 [(SA015A1T)]
W27C4096	W27C4096@PLCC44 [(SA244)]
W27C4096@TSOP40 [(SA409T)]	W27C512
W27C512@PLCC32 [(SA015A1T)]	W27C512@TSOP28 [(SA430T)]
W27C520@SOIC20 [(SA404)]	W27C520@TSSOP20 [(SA026)]
W27E01	W27E01@PLCC32 [(SA015A1T)]
W27E01@VSOP32 [(SA620)]	W27E010
W27E010@PLCC32 [(SA015A1T)]	W27E010@SOIC32 [(SA438T)]
W27E02	W27E02@PLCC32 [(SA015A1T)]
W27E02@VSOP32 [(SA620)]	W27E020
W27E020@PLCC32 [(SA015A1T)]	W27E040
W27E040@PLCC32 [(SA015A1T)]	W27E040@SOIC32 [(SA438T)]
W27E257	W27E257@PLCC32 [(SA015A1T)]
W27E4096	W27E4096@PLCC44 [(SA244)]
W27E4096@TSOP40 [(SA409T)]	W27E512
W27E512@PLCC32 [(SA015A1T)]	W27E512@TSOP28 [(SA430T)]
W27E520@SOIC20 [(SA404)]	W27E520@TSSOP20 [(SA026)]
W27L01	W27L01@PLCC32 [(SA015A1T)]
W27L01@VSOP32 [(SA620)]	W27L010
W27L010@PLCC32 [(SA015A1T)]	W27L02
W27L02@PLCC32 [(SA015A1T)]	W27L02@VSOP32 [(SA620)]
W27L520@SOIC20 [(SA404)]	W27L520@TSSOP20 [(SA026)]
W28F321BB@FBGA48 [(SA634A-B005A-Y048F001)]	
W28F321BT@TSOP48 [(SA247-B005)]	
W28F321TB@FBGA48 [(SA634A-B005A-Y048F001)]	
W28F321TT@TSOP48 [(SA247-B005)]	
W28F641BB@FBGA48 [(SA634A-B005A-Y048F001)]	
W28F641BT@TSOP48 [(SA247-B005)]	
W28F641TB@FBGA48 [(SA634A-B005A-Y048F001)]	
W28F641TT@TSOP48 [(SA247-B005)]	W28J160BT@TSOP48 [(SA247-B005)]
W28J160TT@TSOP48 [(SA247-B005)]	
W28J161BB@TFBGA48 [(SA634A-B005A-Y048F001)]	
W28J161TB@TFBGA48 [(SA634A-B005A-Y048F001)]	
W28J320BT@TSOP48 [(SA247-B005)]	W28J320TT@TSOP48 [(SA247-B005)]
W28J321BB@TFBGA48 [(SA634A-B005A-Y048F001)]	
W28J321TB@TFBGA48 [(SA634A-B005A-Y048F001)]	
W28J800BT@TSOP48 [(SA247-B005)]	W28J800TT@TSOP48 [(SA247-B005)]
W28V400BT@TSOP48 [(SA247-B005)]	W28V400TT@TSOP48 [(SA247-B005)]
W29C010	W29C010@PLCC32 [(SA015A1T)]
W29C011A	W29C011A@PLCC32 [(SA015A1T)]
W29C020	W29C020@PLCC32 [(SA015A1T)]
W29C020@SOIC32 [(SA438T)]	W29C020@TSOP32 [(SA410T)]
W29C020C	
W29C020C@PLCC32 [(SA015A1T-B001)]	W29C020C@VSOP32 [(SA620-B005)]
W29C020C@TSOP32 [(SA410T-B003)]	W29C040@PLCC32 [(SA015A1T-B001)]
W29C040	W29C040@VSOP32 [(SA620-B005)]
W29C040@TSOP32 [(SA410T-B003)]	W29C101@PLCC44 [(SA244)]
W29C101	W29C102
W29C101@TSOP40 [(SA409T)]	W29C102@TSOP40 [(SA409T)]
W29C102@PLCC44 [(SA244)]	W29EE010@PLCC32 [(SA015A1T)]
W29EE010	W29EE010@TSOP32 [(SA410T)]
W29EE010@SOIC32 [(SA438T)]	W29EE011@PLCC32 [(SA015A1T)]
W29EE011	W29EE012
W29EE011@SOIC32 [(SA438T)]	W29EE012@SOIC32 [(SA438T)]
W29EE012@PLCC32 [(SA015A1T)]	W29EE512@PLCC32 [(SA015A1T)]
W29EE512	W29EE512@TSOP32 [(SA410T)]
W29EE512@SOIC32 [(SA438T)]	W29F040@PLCC32 [(SA015A1T)]
W29F040	W29F102@PLCC44 [(SA244)]
W29F040@TSOP32 [(SA410T)]	W29L102@PLCC44 [(SA244)]
W29F102@TSOP40 [(SA623)]	W39F010
W29L102@TSOP40 [(SA623)]	
W39F010@PLCC32 [(SA015A1T-B001)]	
W39F010@TSOP32[12.4mm] [(SA620-B005)]	
W39F010@TSOP32[18.4mm] [(SA410T-B003)]	
W39L010@PLCC32 [(SA015A1T-B001)]	W39L010@TSOP32 [(SA620-B005)]
W39L020@PLCC32 [(SA015A1T-B001)]	
W39L020@TSOP32[12.4mm] [(SA620-B005)]	
W39L020@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040@PLCC32 [(SA015A1T-B001)]	
W39L040@TSOP32[12.4mm] [(SA620-B005)]	
W39L040@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040A	W39L040A@PLCC32 [(SA015A1T)]

W39L040A@TSOP32 [(SA410T)]	W39L040A@VSOP32 [(SA620)]
W39L512@PLCC32 [(SA015A1T-B001)]	W39L512@TSOP32 [(SA620-B005)]
W39V040A@PLCC32 [(SA015A1T)]	W39V040A@VSOP32 [(SA620)]
W39V040B(P)@PLCC32 [(SA015A1T)]	W39V040B(Q)@VSOP32 [(SA620)]
W39V040CP@PLCC32 [(SA015A1T)]	W39V040CPZ@PLCC32 [(SA015A1T)]
W39V040CQ@VSOP32 [(SA620)]	W39V040CQZ@VSOP32 [(SA620)]
W39V040FAP@PLCC32 [(SA015A1T)]	W39V040FAQ@VSOP32 [(SA620)]
W39V040FAT@TSOP40 [(SA409T)]	W39V040FB(P)@PLCC32 [(SA015A1T)]
W39V040FB(Q)@VSOP32 [(SA620)]	W39V040FCP@PLCC32 [(SA015A1T)]
W39V040FCPZ@PLCC32 [(SA015A1T)]	W39V040FCQ@VSOP32 [(SA620)]
W39V040FCQZ@VSOP32 [(SA620)]	W39V080A(P)@PLCC32 [(SA015A1T)]
W39V080A(Q)@VSOP32 [(SA620)]	W39V080A(T)@TSOP40 [(SA409T)]
W39V080FA(P)@PLCC32 [(SA015A1T)]	W39V080FA(Q)@VSOP32 [(SA620)]
W39V080FA(T)@TSOP40 [(SA409T)]	W45B012@PLCC32 [(SA015A1T)]
W45B012@SON8 [(SA683)]	W45B512@PLCC32 [(SA015A1T)]
W45B512@SON8 [(SA683)]	W49F002
W49F002@PLCC32 [(SA015A1T-B001)]	W49F002@TSOP32 [(SA410T-B003)]
W49F002B	
W49F002B@PLCC32 [(SA015A1T-B001)]	W49F002N
W49F002B@TSOP32 [(SA410T-B003)]	
W49F002N@PLCC32 [(SA015A1T-B001)]	W49F002U
W49F002N@TSOP32 [(SA410T-B003)]	
W49F002U@PLCC32 [(SA015A1T-B001)]	
W49F002U@TSOP32 [(SA410T-B003)]	W49F020
W49F020@PLCC32 [(SA015A1T)]	W49F020@TSOP32 [(SA410T)]
W49F102@PLCC44 [(SA244)]	W49F102@TSOP40 [(SA623)]
W49F201@PSOP44 [(SA638)]	W49F201@TSOP48 [(SA247-B005)]
W49L102@PLCC44 [(SA244)]	W49L102@TSOP40 [(SA623)]
W49L201@PSOP44 [(SA638)]	W49L201@TSOP48 [(SA247-B005)]
W49L401@PSOP44 [(SA638)]	W49L401@TSOP48 [(SA247-B005)]
W49L401T@PSOP44 [(SA638)]	W49L401T@TSOP48 [(SA247-B005)]
W49V002A@PLCC32 [(SA015A1T)]	W49V002A@VSOP32 [(SA620)]
W49V002FA@PLCC32 [(SA015A1T)]	W49V002FA@VSOP32 [(SA620)]
W49V002FP@PLCC32 [(SA015A1T)]	W49V002FP@VSOP32 [(SA620)]
W49V002P@PLCC32 [(SA015A1T)]	W49V002P@VSOP32 [(SA620)]
W55F05	W55F10A
W55F20	

## MICROCONTROLLER

N79E342AKG	N79E342ASG@SOP16 [(SA404)]
N79E342RAKG	N79E342RASG@SOP16 [(SA404)]
N79E352AEG	N79E352AFG@TQFP44 [(SA245)]
N79E352ALG@TQFP48 [(SA248)]	N79E352APG@PLCC44 [(SA244)]
N79E8213AKG	N79E8213ASG@SOP20 [(SA404)]
N79E8213RAKG	N79E8213RASG@SOP20 [(SA404)]
W77E058	W77E058@PLCC44 [(SA244)]
W77E058@TQFP44 [(SA245A)]	W77E516
W77E516@PLCC44 [(SA244)]	W77E516@TQFP44 [(SA245A)]
W77E532	W77E532@PLCC44 [(SA244)]
W77E532@TQFP44 [(SA245A)]	W77E532A
W77E532A@PLCC44 [(SA244)]	W77E532A@TQFP44 [(SA245A)]
W77E58	W77E58@PLCC44 [(SA244)]
W77E58@TQFP44 [(SA245A)]	W77E58A
W77E58A@PLCC44 [(SA244)]	W77E58A@TQFP44 [(SA245A)]
W77IE58	W77IE58@PLCC44 [(SA244)]
W77IE58@TQFP44 [(SA245A)]	W77L058
W77L058@PLCC44 [(SA244)]	W77L058@TQFP44 [(SA245A)]
W77L516A	W77L516A@PLCC44 [(SA244)]
W77L516A@TQFP44 [(SA245A)]	W77L532A
W77L532A@PLCC44 [(SA244)]	W77L532A@TQFP44 [(SA245A)]
W77LE516	W77LE516@PLCC44 [(SA244)]
W77LE516@TQFP44 [(SA245A)]	W77LE532
W77LE532@PLCC44 [(SA244)]	W77LE532@TQFP44 [(SA245A)]
W77LE58	W77LE58@PLCC44 [(SA244)]
W77LE58@TQFP44 [(SA245A)]	W78E051B
W78E051B@PLCC44 [(SA244)]	W78E051B@TQFP44 [(SA245A)]
W78E051C	W78E051C@PLCC44 [(SA244)]
W78E051C@TQFP44 [(SA245A)]	W78E051DDG
W78E051DFG@TQFP44 [(SA245A)]	
W78E051DLG@TQFP48 [(SA248A-B005)]	W78E052B
W78E051DPG@PLCC44 [(SA244)]	W78E052B@TQFP44 [(SA245A)]
W78E052B@PLCC44 [(SA244)]	W78E052C@PLCC44 [(SA244)]
W78E052C	W78E052DDG
W78E052C@TQFP44 [(SA245A)]	
W78E052DFG@TQFP44 [(SA245A)]	W78E054B
W78E052DLG@TQFP48 [(SA248A-B005)]	W78E054B@TQFP44 [(SA245A)]
W78E052DPG@PLCC44 [(SA244)]	
W78E054B@PLCC44 [(SA244)]	

W78E054C	W78E054C@PLCC44 [(SA244)]
W78E054C@TQFP44 [(SA245A)]	W78E054DDG
W78E054DFG@TQFP44 [(SA245A)]	
W78E054DLG@TQFP48 [(SA248A-B005)]	
W78E054DPG@PLCC44 [(SA244)]	W78E058B
W78E058B@PLCC44 [(SA244)]	W78E058B@TQFP44 [(SA245A)]
W78E058DDG	W78E058DFG@TQFP44 [(SA245A)]
W78E058DLG@TQFP48 [(SA248A-B005)]	
W78E058DPG@PLCC44 [(SA244)]	W78E065
W78E065@PLCC44 [(SA244)]	W78E065@TQFP44 [(SA245A)]
W78E354(dip40)	W78E354(dip48)
W78E354@PLCC68 [(PEP+S414T)]	W78E365
W78E365@PLCC44 [(SA244)]	W78E365@TQFP44 [(SA245A)]
W78E374B	W78E378
W78E378E	W78E378P@PLCC44 [(SA244)]
W78E51	W78E51@PLCC44 [(SA244)]
W78E51@TQFP44 [(SA245A)]	W78E516
W78E516@PLCC44 [(SA244)]	W78E516@TQFP44 [(SA245A)]
W78E516B	W78E516B@PLCC44 [(SA244)]
W78E516B@TQFP44 [(SA245A)]	W78E516DDG
W78E516DFG@TQFP44 [(SA245A)]	
W78E516DLG@TQFP48 [(SA248A-B005)]	
W78E516DPG@PLCC44 [(SA244)]	W78E51B
W78E51B@PLCC44 [(SA244)]	W78E51B@TQFP44 [(SA245A)]
W78E51C	W78E51C@PLCC44 [(SA244)]
W78E51C@TQFP44 [(SA245A)]	W78E52
W78E52@PLCC44 [(SA244)]	W78E52@TQFP44 [(SA245A)]
W78E52B	W78E52B@PLCC44 [(SA244)]
W78E52B@TQFP44 [(SA245A)]	W78E52C
W78E52C@PLCC44 [(SA244)]	W78E52C@TQFP44 [(SA245A)]
W78E54	W78E54@PLCC44 [(SA244)]
W78E54@TQFP44 [(SA245A)]	W78E54B
W78E54B@PLCC44 [(SA244)]	W78E54B@TQFP44 [(SA245A)]
W78E54C	W78E54C@PLCC44 [(SA244)]
W78E54C@TQFP44 [(SA245A)]	W78E58
W78E58@PLCC44 [(SA244)]	W78E58@TQFP44 [(SA245A)]
W78E58B	W78E58B@PLCC44 [(SA244)]
W78E58B@TQFP44 [(SA245A)]	W78E62B
W78E62B@PLCC44 [(SA244)]	W78E62B@TQFP44 [(SA245A)]
W78E65	W78E65@PLCC44 [(SA244)]
W78E65@TQFP44 [(SA245A)]	W78E858
W78E858@PLCC44 [(SA244)]	W78E858@TQFP44 [(SA245A)]
W78ERD2	W78ERD2@PLCC44 [(SA244)]
W78ERD2@TQFP44 [(SA245A)]	W78I051DDG
W78I051DFG@TQFP44 [(SA245A)]	
W78I051DLG@TQFP48 [(SA248A-B005)]	
W78I051DPG@PLCC44 [(SA244)]	W78I052
W78I052@PLCC44 [(SA244)]	W78I052DDG
W78I052DFG@TQFP44 [(SA245A)]	
W78I052DLG@TQFP48 [(SA248A-B005)]	
W78I052DPG@PLCC44 [(SA244)]	W78I054
W78I054@PLCC44 [(SA244)]	W78I054DDG
W78I054DFG@TQFP44 [(SA245A)]	
W78I054DLG@TQFP48 [(SA248A-B005)]	
W78I054DPG@PLCC44 [(SA244)]	W78IE52
W78IE52@PLCC44 [(SA244)]	W78IE54
W78IE54@PLCC44 [(SA244)]	W78IRD2
W78IRD2@PLCC44 [(SA244)]	W78IRD2@TQFP44 [(SA245A)]
W78L051	W78L051@PLCC44 [(SA244)]
W78L051@TQFP44 [(SA245A)]	W78L051C
W78L051C@PLCC44 [(SA244)]	W78L051C@TQFP44 [(SA245A)]
W78L052	W78L052@PLCC44 [(SA244)]
W78L052@TQFP44 [(SA245A)]	W78L052C
W78L052C@PLCC44 [(SA244)]	W78L052C@TQFP44 [(SA245A)]
W78L054	W78L054@PLCC44 [(SA244)]
W78L054@TQFP44 [(SA245A)]	W78L054C
W78L054C@PLCC44 [(SA244)]	W78L054C@TQFP44 [(SA245A)]
W78L058	W78L058@PLCC44 [(SA244)]
W78L058@TQFP44 [(SA245A)]	W78L365
W78L365@PLCC44 [(SA244)]	W78L365@TQFP44 [(SA245A)]
W78L365@TQFP48 [(SA248A-B005)]	W78L516
W78L516@PLCC44 [(SA244)]	W78L516@TQFP44 [(SA245A)]
W78L516A	W78L516A@PLCC44 [(SA244)]
W78L516A@TQFP44 [(SA245A)]	W78L812
W78L812@PLCC44 [(SA244)]	W78L812@TQFP44 [(SA245A)]
W78LE365	W78LE365@PLCC44 [(SA244)]
W78LE365@TQFP44 [(SA245A)]	W78LE365@TQFP48 [(SA248A-B005)]
W78LE51	W78LE51@PLCC44 [(SA244)]
W78LE51@TQFP44 [(SA245A)]	W78LE516
W78LE516@PLCC44 [(SA244)]	W78LE516@TQFP44 [(SA675)]
W78LE51C	W78LE51C@PLCC44 [(SA244)]

W78LE51C@TQFP44 [(SA245A)]	W78LE52
W78LE52@PLCC44 [(SA244)]	W78LE52@TQFP44 [(SA245A)]
W78LE52C	W78LE52C@PLCC44 [(SA244)]
W78LE52C@TQFP44 [(SA245A)]	W78LE54
W78LE54@PLCC44 [(SA244)]	W78LE54@TQFP44 [(SA245A)]
W78LE54C	W78LE54C@PLCC44 [(SA244)]
W78LE54C@TQFP44 [(SA245A)]	W78LE58
W78LE58@PLCC44 [(SA244)]	W78LE58@TQFP44 [(SA245A)]
W78LE812	W78LE812@PLCC44 [(SA244)]
W78LE812@TQFP44 [(SA245A)]	W79E201
W79E201@PLCC44 [(SA244)]	W79E201@TQFP44 [(SA245A)]
W79E2051(dip14)	W79E2051(dip16)
W79E2051(dip20)	W79E2051@SOP20 [(SA404A)]
W79E2051@SSOP14 [(SA626A)]	W79E2051@SSOP16 [(SA626A)]
W79E2051@SSOP20 [(SA626A)]	W79E2051R(dip20)
W79E2051R@SOP20 [(SA404A)]	W79E216AFG@PQFP100 [(PEP+S427)]
W79E216AFG@PQFP100(*) [(SA741-B226)]	
W79E217AFG@PQFP100 [(PEP+S427)]	
W79E217AFG@PQFP100(*) [(SA741-B226)]	
W79E225A@LQFP48 [(SA248)]	W79E225A@PLCC44 [(SA244)]
W79E226A@LQFP48 [(SA248)]	W79E226A@PLCC44 [(SA244)]
W79E227A@LQFP48 [(SA248)]	W79E227A@PLCC44 [(SA244)]
W79E4051(dip14)	W79E4051(dip16)
W79E4051(dip20)	W79E4051@SOP20 [(SA404A)]
W79E4051@SSOP14 [(SA626A)]	W79E4051@SSOP16 [(SA626A)]
W79E4051@SSOP20 [(SA626A)]	W79E4051R(dip20)
W79E4051R@SOP20 [(SA404A)]	W79E532
W79E532@PLCC44 [(SA244)]	W79E532@TQFP44 [(SA245A)]
W79E532A	W79E532A@PLCC44 [(SA244)]
W79E532A@TQFP44 [(SA245A)]	W79E632
W79E632@PLCC44 [(SA244)]	W79E632@TQFP44 [(SA245A)]
W79E633@PLCC44 [(SA244)]	W79E648A@PLCC68 [(PEP+S414T)]
W79E648A@PLCC68(*) [(SA648-B6809)]	
W79E649A@PLCC68 [(PEP+S414T)]	
W79E649A@PLCC68(*) [(SA648-B6809)]	
W79E659A@PQFP100(*) [(SA741-B233)]	
W79E801A	W79E801A@SOIC20 [(SA404)]
W79E802A	W79E802A@SOIC20 [(SA404)]
W79E803A	W79E803A@SOIC20 [(SA404)]
W79E804A	W79E804A@SOIC20 [(SA404)]
W79E821A	W79E821A@SOIC20 [(SA404)]
W79E822A	W79E822A@SOIC20 [(SA404)]
W79E822B	W79E822B@SOIC20 [(SA404)]
W79E823A	W79E823A@SOIC20 [(SA404)]
W79E823B	W79E823B@SOIC20 [(SA404)]
W79E824A	W79E824A@SOIC20 [(SA404)]
W79E825A	W79E825A@SOIC20 [(SA404)]
W79E831A	W79E831A@SOIC28 [(SA404)]
W79E832A	W79E832A@SOIC28 [(SA404)]
W79E833A	W79E833A@SOIC28 [(SA404)]
W79E834A	W79E834A@SOIC28 [(SA404)]
W79L532	W79L532@PLCC44 [(SA244)]
W79L532@TQFP44 [(SA245A)]	W79L632
W79L632@PLCC44 [(SA244)]	W79L632@TQFP44 [(SA245A)]
W79L633@PLCC44 [(SA244)]	W79L648A@PLCC68 [(PEP+S414T)]
W79L648A@PLCC68(*) [(SA648-B6809)]	
W79L649A@PLCC68 [(PEP+S414T)]	
W79L649A@PLCC68(*) [(SA648-B6809)]	
W79L659A@PQFP100(*) [(SA741-B233)]	
W83L950D@TQFP80 [(PEP+S640)]	
W83L950D@TQFP80(*) [(TA060-B006)]	
W83L950G@TQFP80 [(PEP+S640)]	
W83L950G@TQFP80(*) [(TA060-B006)]	
W83L951ADG@LQFP128(*) [(TA056-B006)]	
W83L951D@LQFP128(*) [(TA056-B006)]	
W83L951DF@QFP128(*) [(TA058-B084)]	
W83L951DG@LQFP128(*) [(TA056-B006)]	
W83L951F@QFP128(*) [(TA058-B084)]	
W925EP01@PQFP100 [(PEP+S427)]	
W925EP01@PQFP100(*) [(TA041-B006)]	
W99100DG@TQFP48 [(SA248A-B005)]	

## WISTRON

### E(E) PROM/FRAM/NVRAM

MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]

MX29LV320CBT@TSOP48 [(SA247-B005)]  
 MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CTT@TSOP48 [(SA247-B005)]  
 MX29LV640BBT@TSOP48 [(SA247-B005)]  
 MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
 MX29LV640BT@TSOP48 [(SA247-B005)]  
 MX29LV640BTT@TSOP48 [(SA247-B005)]  
 MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
 MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]  
 MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]  
 MX29LV640TT@TSOP48 [(SA247-B005)]  
 MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]  
 MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]  
 SST25LF016A@SOIC8 [(SA602A)] SST25LF016A@WSON8 [(SA683)]  
 SST25LF016B@SOIC8 [(SA602A)] SST25LF016B@WSON8 [(SA683)]  
 SST25VF016B@SOIC8 [(SA602A)] SST25VF016B@WSON8 [(SA683)]

**MICROCONTROLLER**

CY8C21334@SSOP20 [(SA626A)]  
 CY8C21334@SSOP20(ISP) [ISP-HEADER01]

**WSI****E(E) PROM/FRAM/NVRAM**

WS27C010L	WS27C010L@PLCC32 [(SA015A1T)]
WS27C010L@TSOP32 [(SA410T)]	WS27C010R
WS27C010R@PLCC32 [(SA015A1T)]	WS27C010R@TSOP32 [(SA410T)]
WS27C040L	WS27C040L@PLCC32 [(SA015A1T)]
WS27C040L@TSOP32 [(SA410T)]	WS27C128F
WS27C128F@PLCC32 [(SA015A1T)]	WS27C128L
WS27C128L@PLCC32 [(SA015A1T)]	WS27C210L
WS27C210L@PLCC44 [(SA244)]	WS27C256F
WS27C256F@PLCC32 [(SA015A1T)]	WS27C256L
WS27C256L@PLCC32 [(SA015A1T)]	WS27C512F
WS27C512F@PLCC32 [(SA015A1T)]	WS27C512L
WS27C512L@PLCC32 [(SA015A1T)]	WS27C64
WS27C64@PLCC32 [(SA015A1T)]	WS27C64F
WS27C64F@PLCC32 [(SA015A1T)]	WS27C64L
WS27C64L@PLCC32 [(SA015A1T)]	WS57C128
WS57C128@PLCC32 [(SA015A1T)]	WS57C128F
WS57C128F@PLCC32 [(SA015A1T)]	WS57C128FB
WS57C128FB@PLCC32 [(SA015A1T)]	WS57C191
WS57C191@PLCC28 [(SA008A)]	WS57C191B
WS57C191B@PLCC28 [(SA008A)]	WS57C191C
WS57C191C@PLCC28 [(SA008A)]	WS57C256F
WS57C256F@PLCC32 [(SA015A1T)]	WS57C256FB
WS57C256FB@PLCC32 [(SA015A1T)]	WS57C257
WS57C257@PLCC44 [(SA244)]	WS57C291
WS57C291@PLCC28 [(SA008A)]	WS57C291B
WS57C291B@PLCC28 [(SA008A)]	WS57C291C
WS57C291C@PLCC28 [(SA008A)]	WS57C43
WS57C43@PLCC28 [(SA008A)]	WS57C43B
WS57C43B@PLCC28 [(SA008A)]	WS57C43C
WS57C43C@PLCC28 [(SA008A)]	WS57C45
WS57C45@PLCC28 [(SA008A)]	WS57C49
WS57C49@PLCC28 [(SA008A)]	WS57C49B
WS57C49B@PLCC28 [(SA008A)]	WS57C49C
WS57C49C@PLCC28 [(SA008A)]	WS57C51
WS57C51@PLCC32 [(SA015A1T)]	WS57C51B
WS57C51B@PLCC32 [(SA015A1T)]	WS57C51C
WS57C51C@PLCC32 [(SA015A1T)]	WS57C64F
WS57C64F@PLCC32 [(SA015A1T)]	WS57C71C
WS57C71C@PLCC32 [(SA015A1T)]	WS57LV191C
WS57LV191C@PLCC28 [(SA008A)]	WS57LV291C
WS57LV291C@PLCC28 [(SA008A)]	

**MICROCONTROLLER**

PSD211R@PLCC44 [(SA244)]	PSD211R@TQFP44 [(SA245A)]
PSD301@PLCC44 [(SA244)]	PSD301@TQFP44 [(SA245A)]
PSD301B@PLCC44 [(SA244)]	PSD301C1@PLCC44 [(SA244)]
PSD301L@PLCC44 [(SA244)]	PSD301L@TQFP44 [(SA245A)]

PSD301R@PLCC44 [(SA244)]	PSD301R@TQFP44 [(SA245A)]
PSD301RV@PLCC44 [(SA244)]	PSD301V@PLCC44 [(SA244)]
PSD302@PLCC44 [(SA244)]	PSD302@TQFP44 [(SA245A)]
PSD302B@PLCC44 [(SA244)]	PSD302B@PLCC44(USA) [(SA411A)]
PSD302C1@PLCC44 [(SA244)]	PSD302L@PLCC44 [(SA244)]
PSD302L@TQFP44 [(SA245A)]	PSD302R@PLCC44 [(SA244)]
PSD302R@TQFP44 [(SA245A)]	PSD302RV@PLCC44 [(SA244)]
PSD302V@PLCC44 [(SA244)]	PSD303@PLCC44 [(SA244)]
PSD303@TQFP44 [(SA245A)]	PSD303C1@PLCC44 [(SA244)]
PSD303L@PLCC44 [(SA244)]	PSD303L@TQFP44 [(SA245A)]
PSD303R@PLCC44 [(SA244)]	PSD303R@TQFP44 [(SA245A)]
PSD303RV@PLCC44 [(SA244)]	PSD303V@PLCC44 [(SA244)]
PSD311@PLCC44 [(SA244)]	PSD311@TQFP44 [(SA245A)]
PSD311B@PLCC44 [(SA244)]	PSD311C1@PLCC44 [(SA244)]
PSD311L@PLCC44 [(SA244)]	PSD311L@TQFP44 [(SA245A)]
PSD311R@PLCC44 [(SA244)]	PSD311R@TQFP44 [(SA245A)]
PSD311RV@PLCC44 [(SA244)]	PSD311V@PLCC44 [(SA244)]
PSD312@PLCC44 [(SA244)]	PSD312@TQFP44 [(SA245A)]
PSD312B@PLCC44 [(SA244)]	PSD312C1@PLCC44 [(SA244)]
PSD312L@PLCC44 [(SA244)]	PSD312L@TQFP44 [(SA245A)]
PSD312R@PLCC44 [(SA244)]	PSD312R@TQFP44 [(SA245A)]
PSD312RV@PLCC44 [(SA244)]	PSD312V@PLCC44 [(SA244)]
PSD313@PLCC44 [(SA244)]	PSD313@TQFP44 [(SA245A)]
PSD313-B@PLCC44 [(SA244)]	PSD313-B@TQFP44 [(SA245A)]
PSD313C1@PLCC44 [(SA244)]	PSD313L@PLCC44 [(SA244)]
PSD313L@TQFP44 [(SA245A)]	PSD313R@PLCC44 [(SA244)]
PSD313R@TQFP44 [(SA245A)]	PSD313RV@PLCC44 [(SA244)]
PSD313V@PLCC44 [(SA244)]	PSD813F1@PLCC52 [(PEP+S415T)]
PSD813F1@TQFP52 [(PEP+S662)]	PSD813F1@TQFP52 (*) [(TA071+B006)]
PSD813F1A@PLCC52 [(PEP+S415T)]	PSD813F1V@PLCC52 [(PEP+S415T)]
PSD813F1V@TQFP52 [(PEP+S662)]	PSD813F1V@TQFP52 (*) [(TA071+B006)]
PSD813F1V@TQFP52 (*) [(TA071+B006)]	PSD813F2@PLCC52 [(PEP+S415T)]
PSD813F1VA@PLCC52 [(PEP+S415T)]	PSD813F2@TQFP52 [(PEP+S662)]
PSD813F2@TQFP52 [(PEP+S662)]	PSD813F2@TQFP52 (*) [(TA071+B006)]
PSD813F2@TQFP52 (*) [(TA071+B006)]	PSD813F2A@PLCC52 [(PEP+S415T)]
PSD813F2A@PLCC52 [(PEP+S415T)]	PSD813F2V@PLCC52 [(PEP+S415T)]
PSD813F2V@TQFP52 [(PEP+S662)]	PSD813F2V@TQFP52 (*) [(TA071+B006)]
PSD813F2V@TQFP52 (*) [(TA071+B006)]	PSD813F2VA@PLCC52 [(PEP+S415T)]
PSD813F2VA@PLCC52 [(PEP+S415T)]	PSD813F3@PLCC52 [(PEP+S415T)]
PSD813F3@TQFP52 [(PEP+S662)]	PSD813F3@TQFP52 (*) [(TA071+B006)]
PSD813F3@TQFP52 (*) [(TA071+B006)]	PSD813F3V@PLCC52 [(PEP+S415T)]
PSD813F3V@PLCC52 [(PEP+S415T)]	PSD813F3V@TQFP52 (*) [(TA071+B006)]
PSD813F3V@TQFP52 (*) [(TA071+B006)]	PSD813F4@PLCC52 [(PEP+S415T)]
PSD813F4@PLCC52 [(PEP+S415T)]	PSD813F4@TQFP52 (*) [(TA071+B006)]
PSD813F4@TQFP52 (*) [(TA071+B006)]	PSD813F4V@PLCC52 [(PEP+S415T)]
PSD813F4V@PLCC52 [(PEP+S415T)]	PSD813F4V@TQFP52 (*) [(TA071+B006)]
PSD813F4V@TQFP52 (*) [(TA071+B006)]	PSD813F5@PLCC52 [(PEP+S415T)]
PSD813F5@PLCC52 [(PEP+S415T)]	PSD813F5@TQFP52 (*) [(TA071+B006)]
PSD813F5@TQFP52 (*) [(TA071+B006)]	PSD813F5V@PLCC52 [(PEP+S415T)]
PSD813F5V@PLCC52 [(PEP+S415T)]	PSD813F5V@TQFP52 (*) [(TA071+B006)]
PSD813F5V@TQFP52 (*) [(TA071+B006)]	PSD833F2@PLCC52 [(PEP+S415T)]
PSD833F2@PLCC52 [(PEP+S415T)]	PSD833F2@TQFP52 (*) [(TA071+B006)]
PSD833F2@TQFP52 (*) [(TA071+B006)]	PSD833F2V@PLCC52 [(PEP+S415T)]
PSD833F2V@PLCC52 [(PEP+S415T)]	PSD833F2V@TQFP52 (*) [(TA071+B006)]
PSD833F2V@TQFP52 (*) [(TA071+B006)]	PSD834F2@PLCC52 [(PEP+S415T)]
PSD834F2@PLCC52 [(PEP+S415T)]	PSD834F2@TQFP52 [(PEP+S662)]
PSD834F2@TQFP52 [(PEP+S662)]	PSD834F2V@TQFP52 [(PEP+S662)]
PSD834F2V@TQFP52 [(PEP+S662)]	PSD853F2@PLCC52 [(PEP+S415T)]
PSD853F2@PLCC52 [(PEP+S415T)]	PSD853F2@TQFP52 (*) [(TA071+B006)]
PSD853F2@TQFP52 (*) [(TA071+B006)]	PSD853F2V@PLCC52 [(PEP+S415T)]
PSD853F2V@PLCC52 [(PEP+S415T)]	PSD853F2V@TQFP52 (*) [(TA071+B006)]
PSD853F2V@TQFP52 (*) [(TA071+B006)]	PSD854F2@PLCC52 [(PEP+S415T)]
PSD854F2@PLCC52 [(PEP+S415T)]	PSD854F2@TQFP52 [(PEP+S662)]
PSD854F2@TQFP52 [(PEP+S662)]	PSD854F2V@TQFP52 [(PEP+S662)]
PSD854F2V@TQFP52 [(PEP+S662)]	ZPSD211R@PLCC44 [(SA244)]
ZPSD211R@PLCC44 [(SA244)]	ZPSD211RV@PLCC44 [(SA244)]
ZPSD211RV@PLCC44 [(SA244)]	ZPSD301@PLCC44 [(SA244)]
ZPSD301@PLCC44 [(SA244)]	ZPSD301L@PLCC44 [(SA244)]
ZPSD301L@PLCC44 [(SA244)]	ZPSD301R@PLCC44 [(SA244)]
ZPSD301R@PLCC44 [(SA244)]	ZPSD301RL@PLCC44 [(SA244)]
ZPSD301RL@PLCC44 [(SA244)]	ZPSD301RV@PLCC44 [(SA244)]
ZPSD301RV@PLCC44 [(SA244)]	ZPSD301V@PLCC44 [(SA244)]
ZPSD301V@PLCC44 [(SA244)]	ZPSD302@PLCC44 [(SA244)]
ZPSD302@PLCC44 [(SA244)]	ZPSD302B@PLCC44 [(SA244)]
ZPSD302B@PLCC44 [(SA244)]	ZPSD302B@PLCC44(USA) [(SA411A)]
ZPSD302L@PLCC44 [(SA244)]	ZPSD302L@TQFP44 [(SA245A)]
ZPSD302R@PLCC44 [(SA244)]	ZPSD302R@TQFP44 [(SA245A)]
ZPSD302RL@PLCC44 [(SA244)]	ZPSD302RL@TQFP44 [(SA245A)]
ZPSD302RV@PLCC44 [(SA244)]	ZPSD302RV@TQFP44 [(SA245A)]
ZPSD302V@PLCC44 [(SA244)]	ZPSD302V@TQFP44 [(SA245A)]
ZPSD303@PLCC44 [(SA244)]	ZPSD303@TQFP44 [(SA245A)]
ZPSD303L@PLCC44 [(SA244)]	ZPSD303L@TQFP44 [(SA245A)]

ZPSD303R@PLCC44 [(SA244)]	ZPSD303R@TQFP44 [(SA245A)]
ZPSD303RL@PLCC44 [(SA244)]	ZPSD303RL@TQFP44 [(SA245A)]
ZPSD303RV@PLCC44 [(SA244)]	ZPSD303RV@TQFP44 [(SA245A)]
ZPSD303V@PLCC44 [(SA244)]	ZPSD303V@TQFP44 [(SA245A)]
ZPSD311@PLCC44 [(SA244)]	ZPSD311@TQFP44 [(SA245A)]
ZPSD311L@PLCC44 [(SA244)]	ZPSD311L@TQFP44 [(SA245A)]
ZPSD311R@PLCC44 [(SA244)]	ZPSD311R@TQFP44 [(SA245A)]
ZPSD311RL@PLCC44 [(SA244)]	ZPSD311RL@TQFP44 [(SA245A)]
ZPSD311RV@PLCC44 [(SA244)]	ZPSD311RV@TQFP44 [(SA245A)]
ZPSD311V@PLCC44 [(SA244)]	ZPSD311V@TQFP44 [(SA245A)]
ZPSD312@PLCC44 [(SA244)]	ZPSD312@TQFP44 [(SA245A)]
ZPSD312B@PLCC44 [(SA244)]	ZPSD312L@PLCC44 [(SA244)]
ZPSD312L@TQFP44 [(SA245A)]	ZPSD312R@PLCC44 [(SA244)]
ZPSD312R@TQFP44 [(SA245A)]	ZPSD312RL@PLCC44 [(SA244)]
ZPSD312RL@TQFP44 [(SA245A)]	ZPSD312RV@PLCC44 [(SA244)]
ZPSD312RV@TQFP44 [(SA245A)]	ZPSD312V@PLCC44 [(SA244)]
ZPSD312V@TQFP44 [(SA245A)]	ZPSD313@PLCC44 [(SA244)]
ZPSD313@TQFP44 [(SA245A)]	ZPSD313L@PLCC44 [(SA244)]
ZPSD313L@TQFP44 [(SA245A)]	ZPSD313R@PLCC44 [(SA244)]
ZPSD313R@TQFP44 [(SA245A)]	ZPSD313RL@PLCC44 [(SA244)]
ZPSD313RL@TQFP44 [(SA245A)]	ZPSD313RV@PLCC44 [(SA244)]
ZPSD313RV@TQFP44 [(SA245A)]	ZPSD313V@PLCC44 [(SA244)]
ZPSD313V@TQFP44 [(SA245A)]	ZPSD813F2@PLCC52 [(PEP+S415T)]
ZPSD813F4@PLCC52 [(PEP+S415T)]	

## XELTEK

### E(E) PROM/FRAM/NVRAM

S29GL032NTAI03@TSOP48 [(SA247-B005)]  
 S29GL032NTAI04@TSOP48 [(SA247-B005)]  
 S29GL032NTFI03@TSOP48 [(SA247-B005)]  
 S29GL032NTFI04@TSOP48 [(SA247-B005)]  
 S29GL064NTAI03@TSOP48 [(SA247-B005)]  
 S29GL064NTAI04@TSOP48 [(SA247-B005)]  
 S29GL064NTAI06@TSOP48 [(SA247-B005)]  
 S29GL064NTAI07@TSOP48 [(SA247-B005)]  
 S29GL064NTFI03@TSOP48 [(SA247-B005)]  
 S29GL064NTFI04@TSOP48 [(SA247-B005)]  
 S29GL064NTFI06@TSOP48 [(SA247-B005)]  
 S29GL064NTFI07@TSOP48 [(SA247-B005)]  
 S29GL128N10TAI01@TSOP56 [(SA628-B334)]  
 S29GL128N10TAI02@TSOP56 [(SA628-B334)]  
 S29GL128N10TFI01@TSOP56 [(SA628-B334)]  
 S29GL128N10TFI02@TSOP56 [(SA628-B334)]  
 S29GL128N11TAI01@TSOP56 [(SA628-B334)]  
 S29GL128N11TAI02@TSOP56 [(SA628-B334)]  
 S29GL128N11TAIV1@TSOP56 [(SA628-B334)]  
 S29GL128N11TAIV2@TSOP56 [(SA628-B334)]  
 S29GL128N11TFI01@TSOP56 [(SA628-B334)]  
 S29GL128N11TFI02@TSOP56 [(SA628-B334)]  
 S29GL128N11TFIV1@TSOP56 [(SA628-B334)]  
 S29GL128N11TFIV2@TSOP56 [(SA628-B334)]  
 S29GL128N90TAIR1@TSOP56 [(SA628-B334)]  
 S29GL128N90TAIR2@TSOP56 [(SA628-B334)]  
 S29GL128N90TFIR1@TSOP56 [(SA628-B334)]  
 S29GL128N90TFIR2@TSOP56 [(SA628-B334)]  
 S29GL128PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
 S29GL128PTAI01@TSOP56 [(SA628-B102)]  
 S29GL256PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
 S29GL256PTAI01@TSOP56 [(SA628-B102)]

### MICROCONTROLLER

#####11111111111111111111	#####22222222222222222222
#####33333333333333333333	#####44444444444444444444
#####99999999999999999999	ATMEGA168@TQFP32 [(SA636)]
ATMEGA48@TQFP32 [(SA636)]	ATMEGA88@TQFP32 [(SA636)]
ATMEGA8L(fast)@TQFP32 [(SA636)]	ATMEGA8L@TQFP32 [(SA636)]
MK68F15P	MK68F15S@SOP18 [(SA023A)]
MK68F15X@SSOP20 [(SA674)]	MK68F30K
MK68F30S@SOP28 [(SA404)]	MK68F30X@SSOP28 [(SA626A)]
ST7FLI49MK1B6@SDIP32 [(SA653)]	ST7FLI49MK1T6@TQFP32 [(SA663)]
ST7FLITE49	ST7FLITE49@TQFP32 [(SA663)]



**XICOR****E(E) PROM/FRAM/NVRAM**

X2004	X2004@PLCC32 [(SA015A1T)]
X2004D	X2004D@PLCC32 [(SA015A1T)]
X2004I	X2004I@PLCC32 [(SA015A1T)]
X2210	X2210@SOIC16 [(SA404)]
X2210A	X2210A@SOIC16 [(SA404)]
X2210I	X2210I@SOIC16 [(SA404)]
X2212	X2212@SOIC20 [(SA404)]
X2212A	X2212A@SOIC20 [(SA404)]
X2212I	X2212I@SOIC20 [(SA404)]
X22C10	X22C10@SOIC16 [(SA404)]
X22C10I	X22C10I@SOIC16 [(SA404)]
X22C12	X22C12@SOIC20 [(SA404)]
X22C12I	X22C12I@SOIC20 [(SA404)]
X24012	X24012@SOIC8 [(SA602A)]
X24022	X24022@SOIC8 [(SA602A)]
X24026	X24026@SOIC8 [(SA602A)]
X24042	X24042@SOIC8 [(SA602A)]
X24164	X24164@SOIC8 [(SA602A)]
X24165	X24165@SOIC8 [(SA602A)]
X24325	X24325@SOIC8 [(SA602A)]
X24645	X24645@SOIC8 [(SA602A)]
X24C01	X24C01@MSOP8 [(SA666)]
X24C01@SOIC8 [(SA602A)]	X24C01A
X24C01A@SOIC8 [(SA602A)]	X24C01I
X24C01I@SOIC8 [(SA602A)]	X24C02
X24C02@SOIC8 [(SA602A)]	X24C02I
X24C02I@SOIC8 [(SA602A)]	X24C04
X24C04@SOIC14 [(SA602)]	X24C04@SOIC8 [(SA602A)]
X24C04I	X24C04I@SOIC14 [(SA602)]
X24C04I@SOIC8 [(SA602A)]	X24C08
X24C08@SOIC14 [(SA602)]	X24C08@SOIC8 [(SA602A)]
X24C08I	X24C08I@SOIC14 [(SA602)]
X24C08I@SOIC8 [(SA602A)]	X24C16
X24C16@SOIC14 [(SA602)]	X24C16@SOIC8 [(SA602A)]
X24C16I	X24C16I@SOIC14 [(SA602)]
X24C16I@SOIC8 [(SA602A)]	X24C44
X24C44@SOIC8 [(SA602A)]	X24C44I
X24C44I@SOIC8 [(SA602A)]	X24C45
X24C45@SOIC8 [(SA602A)]	X24C45I
X24C45I@SOIC8 [(SA602A)]	X24F008(3V)
X24F008(3V)@SOIC8 [(SA602A)]	X24F008(3V)@TSSOP14 [(SA602)]
X24F008(5V)	X24F008(5V)@SOIC8 [(SA602A)]
X24F008(5V)@TSSOP14 [(SA602)]	X24F016(3V)
X24F016(3V)@SOIC8 [(SA602A)]	X24F016(3V)@TSSOP14 [(SA602)]
X24F016(5V)	X24F016(5V)@SOIC8 [(SA602A)]
X24F016(5V)@TSSOP14 [(SA602)]	X24F032(3V)
X24F032(3V)@SOIC8 [(SA602A)]	X24F032(3V)@TSSOP14 [(SA602)]
X24F032(5V)	X24F032(5V)@SOIC8 [(SA602A)]
X24F032(5V)@TSSOP14 [(SA602)]	X24F064(3V)
X24F064(3V)@SOIC8 [(SA602A)]	X24F064(3V)@TSSOP20 [(SA404)]
X24F064(5V)	X24F064(5V)@SOIC8 [(SA602A)]
X24F064(5V)@TSSOP20 [(SA404)]	X25020
X25020@SOIC8 [(SA602A)]	X25021
X25021@SOIC8 [(SA602A)]	X25040
X25040@SOIC8 [(SA602A)]	X25041
X25041@SOIC8 [(SA602A)]	X25043
X25043@MSOP8 [(SA666)]	X25043@SOIC8 [(SA602A)]
X25043@TSSOP14 [(SA026)]	X25045
X25045@MSOP8 [(SA666)]	X25045@SOIC8 [(SA602A)]
X25045@TSSOP14 [(SA026)]	X25057@MSOP8 [(SA666)]
X25057@TSSOP8 [(SA026)]	X25080
X25080@SOIC8 [(SA602A)]	X25080@TSSOP14 [(SA026)]
X25097@MSOP8 [(SA666)]	X25097@SOIC8 [(SA602A)]
X25097@TSSOP8 [(SA026)]	X25128
X25128@SOIC16 [(SA602)]	X25138
X25138@SOIC14 [(SA602)]	X25138@SOIC16 [(SA602)]
X25138@SOIC8 [(SA602A)]	X25138@TSSOP8 [(SA026)]
X25160	X25160@SOIC8 [(SA602A)]
X25160@TSSOP14 [(SA026)]	X25163
X25163@SOIC8 [(SA602A)]	X25163@TSSOP14 [(SA026)]
X25164	X25164@SOIC8 [(SA602A)]
X25164@TSSOP14 [(SA026)]	X25165
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14 [(SA026)]
X25166	X25166@SOIC8 [(SA602A)]
X25166@TSSOP14 [(SA026)]	X25168

X25168@SOIC8 [(SA602A)]	X25168@TSSOP14 [(SA026)]
X25169	X25169@SOIC8 [(SA602A)]
X25169@TSSOP14 [(SA026)]	X25256
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20 [(SA026)]
X25320	X25320@SOIC8 [(SA602A)]
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14 [(SA026)]
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14 [(SA026)]
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14 [(SA026)]
X25326@SOIC8 [(SA602A)]	X25328@SOIC8 [(SA602A)]
X25328@TSSOP14 [(SA026)]	X25329@SOIC8 [(SA602A)]
X25329@TSSOP14 [(SA026)]	X25330@SOIC8 [(SA602A)]
X25330@TSSOP14 [(SA026)]	X25401
X25401@SOIC8 [(SA602A)]	X25640
X25640@SOIC14 [(SA602)]	X25642
X25642@SOIC14 [(SA602)]	X25642@SOIC8 [(SA602A)]
X25642@TSSOP20 [(SA026)]	X25643@SOIC14 [(SA602)]
X25644@SOIC14 [(SA602)]	X25645
X25645@SOIC14 [(SA602)]	X25645@SOIC8 [(SA602A)]
X25645@TSSOP20 [(SA026)]	X25648@SOIC14 [(SA602)]
X25649@SOIC14 [(SA602)]	X25650
X25650@SOIC14 [(SA602)]	X25650@SOIC8 [(SA602A)]
X25650@TSSOP20 [(SA026)]	X25C02
X25C02@SOIC8 [(SA602A)]	X25C02@TSSOP8 [(SA026)]
X25F008(3V)	X25F008(3V)@SOIC8 [(SA602A)]
X25F008(3V)@TSSOP14 [(SA602)]	X25F008(3V)@TSSOP20 [(SA404)]
X25F008(5V)	X25F008(5V)@SOIC8 [(SA602A)]
X25F008(5V)@TSSOP14 [(SA602)]	X25F008(5V)@TSSOP20 [(SA404)]
X25F016(3V)	X25F016(3V)@SOIC8 [(SA602A)]
X25F016(3V)@TSSOP14 [(SA602)]	X25F016(3V)@TSSOP20 [(SA404)]
X25F016(5V)	X25F016(5V)@SOIC8 [(SA602A)]
X25F016(5V)@TSSOP14 [(SA602)]	X25F016(5V)@TSSOP20 [(SA404)]
X25F032(3V)	X25F032(3V)@SOIC8 [(SA602A)]
X25F032(3V)@TSSOP14 [(SA602)]	X25F032(3V)@TSSOP20 [(SA404)]
X25F032(5V)	X25F032(5V)@SOIC8 [(SA602A)]
X25F032(5V)@TSSOP14 [(SA602)]	X25F032(5V)@TSSOP20 [(SA404)]
X25F047(3V)	X25F047(3V)@MSOP8 [(SA666)]
X25F047(3V)@SOIC8 [(SA602A)]	X25F047(3V)@TSSOP8 [(SA026)]
X25F047(5V)	X25F047(5V)@MSOP8 [(SA666)]
X25F047(5V)@SOIC8 [(SA602A)]	X25F047(5V)@TSSOP8 [(SA026)]
X25F064(3V)	X25F064(3V)@SOIC8 [(SA602A)]
X25F064(3V)@TSSOP14 [(SA602)]	X25F064(3V)@TSSOP20 [(SA404)]
X25F064(5V)	X25F064(5V)@SOIC8 [(SA602A)]
X25F064(5V)@TSSOP14 [(SA602)]	X25F064(5V)@TSSOP20 [(SA404)]
X25F087(3V)	X25F087(3V)@MSOP8 [(SA666)]
X25F087(3V)@SOIC8 [(SA602A)]	X25F087(3V)@TSSOP8 [(SA026)]
X25F087(5V)	X25F087(5V)@MSOP8 [(SA666)]
X25F087(5V)@SOIC8 [(SA602A)]	X25F087(5V)@TSSOP8 [(SA026)]
X25F128(3V)	X25F128(3V)@SOIC16 [(SA602)]
X25F128(5V)	X25F128(5V)@SOIC16 [(SA602)]
X28010	X28010@PLCC32 [(SA015A1T)]
X28010@TSOP32 [(SA410T)]	X2804A
X2804A(I)	X2804A(MB)
X2816A	X2816A@PLCC32 [(SA015A1T)]
X2816B	X2816B@PLCC32 [(SA015A1T)]
X2816BI	X2816BI@PLCC32 [(SA015A1T)]
X2816BMB	X2816C
X2816C@PLCC32 [(SA015A1T)]	X28256
X28256@PLCC32 [(SA015A1T)]	X28256I
X28256I@PLCC32 [(SA015A1T)]	X2864A
X2864A(I)	X2864A(I)@PLCC32 [(SA015A1T)]
X2864A(M)	X2864A(M)@PLCC32 [(SA015A1T)]
X2864A(MB)	X2864A(MB)@PLCC32 [(SA015A1T)]
X2864A(T)	X2864A(T)@PLCC32 [(SA015A1T)]
X2864A@PLCC32 [(SA015A1T)]	X2864B
X2864B(I)	X2864B(I)@PLCC32 [(SA015A1T)]
X2864B(M)	X2864B(M)@PLCC32 [(SA015A1T)]
X2864B@PLCC32 [(SA015A1T)]	X2864H
X2864H(I)	X2864H(I)@PLCC32 [(SA015A1T)]
X2864H@PLCC32 [(SA015A1T)]	X28C010
X28C010@PLCC32 [(SA015A1T)]	X28C16A
X28C16A@PLCC32 [(SA015A1T)]	X28C16B
X28C16B@PLCC32 [(SA015A1T)]	X28C16C
X28C16C@PLCC32 [(SA015A1T)]	X28C256
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28 [(SA430T)]
X28C512	X28C512@PLCC32 [(SA015A1T)]
X28C513	X28C513@PLCC32 [(SA015A1T)]
X28C64	X28C64@PLCC32 [(SA015A1T)]
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28 [(SA430T)]
X28HC16	X28HC16@PLCC32 [(SA015A1T)]
X28HC16@SOIC24 [(SA404)]	X28HC256
X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28 [(SA430T)]

X28HC64	X28HC64@PLCC32 [(SA015A1T)]
X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28 [(SA430T)]
X28LC512	X28LC512@PLCC32 [(SA015A1T)]
X28LC513	X28LC513@PLCC32 [(SA015A1T)]
X28VC256	X28VC256@PLCC32 [(SA015A1T)]
X28VC256@TSOP28 [(SA430T)]	X40231@SOIC16 [(SA404)]
X40233@SOIC16 [(SA404)]	X40235@SOIC16 [(SA404)]
X40237@SOIC16 [(SA404)]	X40239@SOIC16 [(SA404)]
X40430@SOIC14 [(SA404)]	X40430@TSSOP14 [(SA026)]
X40431@SOIC14 [(SA404)]	X40431@TSSOP14 [(SA026)]
X40434@SOIC14 [(SA404)]	X40434@TSSOP14 [(SA026)]
X40435@SOIC14 [(SA404)]	X40435@TSSOP14 [(SA026)]
X4C105@TSSOP20 [(SA026)]	X5043
X5043@MSOP8 [(SA666)]	X5043@SOIC8 [(SA602A)]
X5043@TSSOP14 [(SA026)]	X5045
X5045@MSOP8 [(SA666)]	X5045@SOIC8 [(SA602A)]
X5045@TSSOP14 [(SA026)]	X5083
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8 [(SA026)]
X5163	X5163@SOIC8 [(SA602A)]
X5163@TSSOP14 [(SA026)]	X51638
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14 [(SA026)]
X5165	X5165@SOIC8 [(SA602A)]
X5165@TSSOP14 [(SA026)]	X5168
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14 [(SA026)]
X5169	X5169@SOIC8 [(SA602A)]
X5169@TSSOP14 [(SA026)]	X5323
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14 [(SA026)]
X5325	X5325@SOIC8 [(SA602A)]
X5325@TSSOP14 [(SA026)]	X5328
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14 [(SA026)]
X5329	X5329@SOIC8 [(SA602A)]
X5329@TSSOP14 [(SA026)]	X5643
X5643@SOIC14 [(SA602)]	X5643@SOIC8 [(SA602A)]
X5643@TSSOP20 [(SA026)]	X5645
X5645@SOIC14 [(SA602)]	X5645@SOIC8 [(SA602A)]
X5645@TSSOP20 [(SA026)]	X5648
X5648@SOIC14 [(SA602)]	X5649
X5649@SOIC14 [(SA602)]	X76F041
X76F041(3)	X76F041(3)@SOIC8 [(SA605)]
X76F041@SOIC8 [(SA605)]	X76F101
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8 [(SA602A)]
X76F400@TSSOP8 [(SA026)]	X84041
X84041@SOIC14 [(SA602)]	X84041@SOIC8 [(SA602A)]
X84047	X84047@TSSOP8 [(SA026)]
X84087	X84087@TSSOP8 [(SA026)]
X84128	X84128@SOIC14 [(SA602)]
X84128@TSSOP28 [(SA643)]	X84128@XBGA8 [(SA683)]
X84129	X84129@SOIC16 [(SA602)]
X84160	X84160@SOIC8 [(SA602A)]
X84160@TSSOP8 [(SA026)]	X84161
X84161@SOIC8 [(SA602A)]	X84161@TSSOP8 [(SA026)]
X84256	X84256@SOIC8 [(SA602A)]
X84256@TSSOP14 [(SA026)]	X84256@XBGA8 [(SA683)]
X84640	X84640@SOIC8 [(SA602A)]
X84640@TSSOP20 [(SA026)]	X84640@XBGA8 [(SA683)]
X84641	X84641@SOIC8 [(SA602A)]
X84641@TSSOP20 [(SA026)]	X84641@XBGA8 [(SA683)]
XD2210	XD2210@SOIC16 [(SA404)]
XM28C010	XM28C020
XM28C040	

## XILINX

### E(E) PROM/FRAM/NVRAM

XC1701	XC1701@PLCC20 [(SA001A)]
XC1701@PLCC44 [(SA244)]	XC1701@SOIC20 [(SA404)]
XC1701L	XC1701L@PLCC20 [(SA001A)]
XC1701L@PLCC44 [(SA244)]	XC1701L@SOIC20 [(SA404)]
XC1702L@PLCC44 [(SA244)]	XC1702L@TQFP44 [(SA245A)]
XC1704L@PLCC44 [(SA244)]	XC1704L@TQFP44 [(SA245A)]
XC17128	XC17128@SOIC8 [(SA602A)]
XC17128D	XC17128D@PLCC20 [(SA001A)]
XC17128D@SOIC8 [(SA602A)]	XC17128D@VOIC8 [(SA602A)]
XC17128E	XC17128E@PLCC20 [(SA001A)]
XC17128E@VOIC8 [(SA602A)]	XC17128EL
XC17128EL@PLCC20 [(SA001A)]	XC17128EL@VOIC8 [(SA602A)]
XC17128L	XC17128L@PLCC20 [(SA001A)]

XC17128L@SOIC8 [(SA602A)]	XC17128L@VOIC8 [(SA602A)]
XC17128X	XC17128X@PLCC20 [(SA001A)]
XC17128X@SOIC8 [(SA602A)]	XC17128X@VOIC8 [(SA602A)]
XC1718D	XC1718D@PLCC20 [(SA001A)]
XC1718D@SOIC8 [(SA602A)]	XC1718D@VOIC8 [(SA602A)]
XC1718L	XC1718L@PLCC20 [(SA001A)]
XC1718L@SOIC8 [(SA602A)]	XC1718L@VOIC8 [(SA602A)]
XC17256D	XC17256D@PLCC20 [(SA001A)]
XC17256D@SOIC8 [(SA602A)]	XC17256D@VOIC8 [(SA602A)]
XC17256E	XC17256E@PLCC20 [(SA001A)]
XC17256E@VOIC8 [(SA602A)]	XC17256EL
XC17256EL@PLCC20 [(SA001A)]	XC17256EL@VOIC8 [(SA602A)]
XC17256L	XC17256L@PLCC20 [(SA001A)]
XC17256L@SOIC8 [(SA602A)]	XC17256L@VOIC8 [(SA602A)]
XC17256X	XC17256X@PLCC20 [(SA001A)]
XC17256X@SOIC8 [(SA602A)]	XC17256X@VOIC8 [(SA602A)]
XC1736	XC1736@SOIC8 [(SA602A)]
XC1736A	XC1736A@SOIC8 [(SA602A)]
XC1736D	XC1736D@PLCC20 [(SA001A)]
XC1736D@SOIC8 [(SA602A)]	XC1736D@VOIC8 [(SA602A)]
XC1736E	XC1736E@PLCC20 [(SA001A)]
XC1736E@SOIC8 [(SA602A)]	XC1736E@VOIC8 [(SA602A)]
XC17512L	XC17512L@PLCC20 [(SA001A)]
XC17512L@PLCC44 [(SA244)]	XC17512L@SOIC20 [(SA404)]
XC1765	XC1765@SOIC8 [(SA602A)]
XC1765D	XC1765D@PLCC20 [(SA001A)]
XC1765D@SOIC8 [(SA602A)]	XC1765D@VOIC8 [(SA602A)]
XC1765E	XC1765E@PLCC20 [(SA001A)]
XC1765E@SOIC8 [(SA602A)]	XC1765E@VOIC8 [(SA602A)]
XC1765EL	XC1765EL@PLCC20 [(SA001A)]
XC1765EL@SOIC8 [(SA602A)]	XC1765EL@VOIC8 [(SA602A)]
XC1765L	XC1765L@PLCC20 [(SA001A)]
XC1765L@SOIC8 [(SA602A)]	XC1765L@VOIC8 [(SA602A)]
XC1765X	XC1765X@PLCC20 [(SA001A)]
XC1765X@SOIC8 [(SA602A)]	XC1765X@VOIC8 [(SA602A)]
XC17S05	XC17S05@SOIC8 [(SA602A)]
XC17S05XL(L)	XC17S05XL(L)@SOIC8 [(SA602A)]
XC17S10	XC17S10@SOIC8 [(SA602A)]
XC17S100A	XC17S100A@SOIC20 [(SA404)]
XC17S100A@SOIC8 [(SA602A)]	XC17S100XL(L)
XC17S100XL(L)@SOIC20 [(SA404)]	XC17S10XL(L)
XC17S10XL(L)@SOIC8 [(SA602A)]	XC17S150A
XC17S150A@SOIC20 [(SA404)]	XC17S150A@SOIC8 [(SA602A)]
XC17S150XL(L)	XC17S150XL(L)@SOIC20 [(SA404)]
XC17S15A	XC17S15A@SOIC20 [(SA404)]
XC17S15A@SOIC8 [(SA602A)]	XC17S20
XC17S20@SOIC8 [(SA602A)]	XC17S200A
XC17S200A@SOIC8 [(SA602A)]	XC17S200A@TQFP44 [(SA245A)]
XC17S20XL(L)	XC17S20XL(L)@SOIC8 [(SA602A)]
XC17S30	XC17S30@SOIC8 [(SA602A)]
XC17S300A@TQFP44 [(SA245A)]	XC17S30A
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8 [(SA602A)]
XC17S30XL(L)	XC17S30XL(L)@SOIC8 [(SA602A)]
XC17S40	XC17S40@SOIC20 [(SA404)]
XC17S40XL(L)	XC17S40XL(L)@SOIC20 [(SA404)]
XC17S50A	XC17S50A@SOIC20 [(SA404)]
XC17S50A@SOIC8 [(SA602A)]	XC17S50XL(L)
XC17S50XL(L)@SOIC20 [(SA404)]	XC17V01@PLCC20 [(SA001A)]
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8 [(SA602A)]
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44 [(SA244)]
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20 [(SA001A)]
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44 [(SA245A)]
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44 [(SA245A)]
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44 [(SA245A)]
XC18V01@PLCC20 [(SA001A)]	XC18V01@SOIC20 [(SA404)]
XC18V01@TQFP44 [(SA245A)]	XC18V02@PLCC44 [(SA244)]
XC18V02@TQFP44 [(SA245A)]	XC18V04@PLCC44 [(SA244)]
XC18V04@TQFP44 [(SA245A)]	XC18V256@PLCC20 [(SA001A)]
XC18V256@SOIC20 [(SA404)]	XC18V256@TQFP44 [(SA245A)]
XC18V512@PLCC20 [(SA001A)]	XC18V512@SOIC20 [(SA404)]
XC18V512@TQFP44 [(SA245A)]	XCF01S(VO)@TSSOP20 [(SA026)]
XCF01S(VOG)@TSSOP20 [(SA026)]	XCF02S(VO)@TSSOP20 [(SA026)]
XCF02S(VOG)@TSSOP20 [(SA026)]	XCF04S(VO)@TSSOP20 [(SA026)]
XCF04S(VOG)@TSSOP20 [(SA026)]	
XCF08P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF08P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	
XCF08P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF08P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	
XCF08P(VO)@TSOP48 [(SA247-B005)]	
XCF08P(VO)@TSOP48(ISP) [ISP-HEADER01]	
XCF08P(VOG)@TSOP48 [(SA247-B005)]	

```
XCF08P(VOG)@TSOP48(ISP) [ISP-HEADER01]
XCF16P(FS)@FBGA48 [(SA642HH-B026A-T072F001Y)]
XCF16P(FS)@FBGA48(ISP) [ISP-HEADER01]
XCF16P(FSG)@FBGA48 [(SA642HH-B026A-T072F001Y)]
XCF16P(FSG)@FBGA48(ISP) [ISP-HEADER01]
XCF16P(VO)@TSOP48 [(SA247-B005)]
XCF16P(VO)@TSOP48(ISP) [ISP-HEADER01]
XCF16P(VOG)@TSOP48 [(SA247-B005)]
XCF16P(VOG)@TSOP48(ISP) [ISP-HEADER01]
XCF32P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]
XCF32P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]
XCF32P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]
XCF32P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]
XCF32P(VO)@TSOP48 [(SA247-B005)]
XCF32P(VO)@TSOP48(ISP) [ISP-HEADER01]
XCF32P(VOG)@TSOP48 [(SA247-B005)]
XCF32P(VOG)@TSOP48(ISP) [ISP-HEADER01]
```

PLD

```
PZ3032C@PLCC44 [(SA244)]
PZ3032N@PLCC44 [(SA244)]
PZ5032C@PLCC44 [(SA244)]
PZ5032N@PLCC44 [(SA244)]
XC2C128@CP132(ISP) [ISP-HEADER01]
XC2C128@FT256(ISP) [ISP-HEADER01]
XC2C128@TQFP100 [(PEP+S604)]
XC2C128@TQFP100(ISP) [ISP-HEADER01]
XC2C128@TQFP144(*) [(SA681+B14418)]
XC2C128@TQFP144(ISP) [ISP-HEADER01]
XC2C256@CP132(ISP) [ISP-HEADER01]
XC2C256@FT256(*) [(SA800+B177)]
XC2C256@FT256(ISP) [ISP-HEADER01]
XC2C256@TQFP100 [(PEP+S604)]
XC2C256@TQFP100(ISP) [ISP-HEADER01]
XC2C256@TQFP144(*) [(SA681+B14418)]
XC2C256@TQFP144(ISP) [ISP-HEADER01]
XC2C256@TQFP208(ISP) [ISP-HEADER01]
XC2C32@PLCC44 [(SA244)]
XC2C32@PLCC44(ISP) [ISP-HEADER01]
XC2C32@QFG32 [(SA686)]
XC2C32@VQFP44 [(SA245A)]
XC2C32@VQFP44(ISP) [ISP-HEADER01]
XC2C32A@PLCC44 [(SA244)]
XC2C32A@PLCC44(ISP) [ISP-HEADER01]
XC2C32A@QFG32 [(SA686)]
XC2C32A@QFG32(ISP) [ISP-HEADER01]
XC2C32A@VQFP44 [(SA245A)]
XC2C32A@VQFP44(ISP) [ISP-HEADER01]
XC2C384@CP204(ISP) [ISP-HEADER01]
XC2C384@FG324(ISP) [ISP-HEADER01]
XC2C384@FT256(*) [(SA800+B177)]
XC2C384@FT256(ISP) [ISP-HEADER01]
XC2C384@TQFP144(*) [(SA681+B14418)]
XC2C384@TQFP144(ISP) [ISP-HEADER01]
XC2C384@TQFP208(ISP) [ISP-HEADER01]
XC2C64@CSP56(*) [(SA699A-B136B-W056F001Y)]
XC2C64@CSP56(ISP) [ISP-HEADER01]
XC2C64@VQFP100 [(PEP+S604)]
XC2C64@VQFP44 [(SA245A)]
XC2C64A@5QFG48I [(SA696)]
XC2C64A@7QFG48I [(SA696)]
XC2C64A@CSP56(*) [(SA699A-B136B-W056F001Y)]
XC2C64A@CSP56(ISP) [ISP-HEADER01]
XC2C64A@PLCC44 [(SA244)]
XC2C64A@VQFP100(*) [(TA063+B006)]
XC2C64A@VQFP44 [(SA245A)]
XC2C64A@5QFG48C [(SA696)]
XC2C64A@7QFG48C [(SA696)]
XC2C64A@CSP56(*) [(SA699A-B136B-W056F001Y)]
XC2C64A@CSP56(ISP) [ISP-HEADER01]
XC2C64A@PLCC44 [(SA244)]
XC2C64A@VQFP100 [(PEP+S604)]
XC7354@PLCC68 [(PEP+S414T)]
XC7372@PLCC84 [(PEP+S416T)]
XC7372@PQFP100 [(PEP+S427)]
XC95108@PQFP100 [(PEP+S427)]
XC95108@PQFP100(*) [(TA082+B084)]
XC95108@PQFP160(*) [(TA081+B084)]
XC95108@TQFP100 [(PEP+S604)]
XC95144@PQFP160(*) [(TA081+B084)]
XC95144@TQFP100 [(PEP+S604)]
XC95144XL@TQFP100(*) [(SA718+B186)]
XC95144XL@TQFP144(*) [(PEP+TA028)]
XC95144XL@TQFP144(**) [(TA028A+B084)]
PZ3032C@TQFP44 [(SA245A)]
PZ3032N@TQFP44 [(SA245A)]
PZ5032C@TQFP44 [(SA245A)]
PZ5032N@TQFP44 [(SA245A)]
XC2C32@QFG32(ISP) [ISP-HEADER01]
XC2C64@PLCC44 [(SA244)]
XC2C64@VQFP100(*) [(TA063+B006)]
XC2C64A@5QFG48C [(SA696)]
XC2C64A@7QFG48C [(SA696)]
XC2C64A@VQFP100 [(PEP+S604)]
XC7354@PLCC44 [(SA244)]
XC7372@PLCC68 [(PEP+S414T)]
XC7372@PLCC84(*) [(SA649+B8408)]
XC95108@PLCC84 [(PEP+S416T)]
XC95144@PQFP100 [(PEP+S427)]
XC95144XL@TQFP100 [(PEP+S604)]
```

```

XC95144XV@TQFP100 [(PEP+S604)]
XC95144XV@TQFP144(*) [(PEP+TA028)]
XC95144XV@TQFP144(**) [(TA028A+B084)]
XC95216@HQFP208(*) [(TA086+B084)]
XC95216@PQFP160(*) [(TA081+B084)]
XC95288XL@TQFP144(*) [(PEP+TA028)]
XC95288XL@TQFP144(**) [(TA028A+B084)]
XC95288XV@FG256(*) [(SA800+B181)]
XC95288XV@TQFP144(*) [(PEP+TA028)]
XC95288XV@TQFP144(**) [(TA028A+B084)]
XC9536@PLCC44 [(SA244)]
XC9536XL@BCSP48 [(SA642QQ+B339)]
XC9536XL@TQFP64 [(PEP+S616)]
XC9536XL@TQFP64(*) [(TA073+B006)]
XC9536XL@VQFP44 [(SA245A)]
XC9536XV@PLCC44 [(SA244)]
XC9572@PLCC44 [(SA244)]
XC9572@PQFP100 [(PEP+S427)]
XC9572@TQFP44 [(SA245A)]
XC9572XL@PLCC44 [(SA244)]
XC9572XL@TQFP44 [(SA245A)]
XC9572XL@TQFP64(*) [(TA073+B006)]
XC9572XV@BCSP48 [(SA642QQ+B339)]
XC9572XV@TQFP100 [(PEP+S604)]
XCR3032A@PLCC44 [(SA244)]
XCR3032C@PLCC44 [(SA244)]
XCR3032N@PLCC44 [(SA244)]
XCR3032XL@CSBGA48 [(SA642QQ+B339)]
XCR3032XL@PLCC44 [(SA244)]
XCR3064XL@CSBGA48 [(SA642QQ+B339)]
XCR3064XL@FPGA56 [(SA699+B155)]
XCR3064XL@TQFP100 [(PEP+S604)]
XCR3128XL@TQFP100 [(PEP+S604)]
XCR3128XL@TQFP144(ISP) [ISP-HEADER01]
XCR3256XL@TQFP144(ISP) [ISP-HEADER01]
XCR3256XL@TQFP208(ISP) [ISP-HEADER01]
XCR5032C@PLCC44 [(SA244)]
XCR5032N@PLCC44 [(SA244)]
XC9536@TQFP44 [(SA245A)]
XC9536XL@PLCC44 [(SA244)]
XC9536XV@BCSP48 [(SA642QQ+B339)]
XC9536XV@TQFP44 [(SA245A)]
XC9572@PLCC84 [(PEP+S416T)]
XC9572@TQFP100 [(PEP+S604)]
XC9572XL@BCSP48 [(SA642QQ+B339)]
XC9572XL@TQFP100 [(PEP+S604)]
XC9572XL@TQFP64 [(PEP+S616)]
XC9572XV@PLCC44 [(SA244)]
XC9572XV@TQFP44 [(SA245A)]
XCR3032A@TQFP44 [(SA245A)]
XCR3032C@TQFP44 [(SA245A)]
XCR3032N@TQFP44 [(SA245A)]
XCR3032XL@TQFP44 [(SA245A)]
XCR3064XL@PLCC44 [(SA244)]
XCR3064XL@TQFP44 [(SA245A)]
XCR5032C@TQFP44 [(SA245A)]
XCR5032N@TQFP44 [(SA245A)]

```

## XILINX-CUSTOMER

### E(E) PROM/FRAM/NVRAM

```

XC17S100A
XC17S100A@SOIC8 [(SA602A)]
XC17S150A@SOIC20 [(SA404)]
XC17S15A
XC17S15A@SOIC8 [(SA602A)]
XC17S200A@SOIC8 [(SA602A)]
XC17S300A@TQFP44 [(SA245A)]
XC17S30A@SOIC20 [(SA404)]
XC17S50A
XC17S50A@SOIC8 [(SA602A)]
XC17V01@SOIC20 [(SA404)]
XC17V02@PLCC20 [(SA001A)]
XC17V02@TQFP44 [(SA245A)]
XC17V04@PLCC44 [(SA244)]
XC17V08@PLCC44 [(SA244)]
XC17V16@PLCC44 [(SA244)]
XC17S100A@SOIC20 [(SA404)]
XC17S150A
XC17S150A@SOIC8 [(SA602A)]
XC17S15A@SOIC20 [(SA404)]
XC17S200A
XC17S200A@TQFP44 [(SA245A)]
XC17S30A
XC17S30A@SOIC8 [(SA602A)]
XC17S50A@SOIC20 [(SA404)]
XC17V01@PLCC20 [(SA001A)]
XC17V01@SOIC8 [(SA602A)]
XC17V02@PLCC44 [(SA244)]
XC17V04@PLCC20 [(SA001A)]
XC17V04@TQFP44 [(SA245A)]
XC17V08@TQFP44 [(SA245A)]
XC17V16@TQFP44 [(SA245A)]

```

## YMC

### E(E) PROM/FRAM/NVRAM

```

Y24LC01
Y24LC01@TSSOP8 [(SA026)]
Y24LC02@SOIC8 [(SA602A)]
Y24LC02A
Y24LC02A@TSSOP8 [(SA026)]
Y24LC04@SOIC8 [(SA602A)]
Y24LC08
Y24LC08@TSSOP8 [(SA026)]
Y24LC16@SOIC8 [(SA602A)]
Y24LC32
Y24LC01@SOIC8 [(SA602A)]
Y24LC02
Y24LC02@TSSOP8 [(SA026)]
Y24LC02A@SOIC8 [(SA602A)]
Y24LC04
Y24LC04@TSSOP8 [(SA026)]
Y24LC08@SOIC8 [(SA602A)]
Y24LC16
Y24LC16@TSSOP8 [(SA026)]
Y24LC32@SOIC8 [(SA602A)]

```

Y24LC32@TSSOP8 [(SA026)]	Y24LC64
Y24LC64@SOIC8 [(SA602A)]	Y24LC64@TSSOP8 [(SA026)]
Y54LC64	Y54LC64@SOIC8 [(SA602A)]
Y54LC64@TSSOP8 [(SA026)]	Y93LC46(08bit)
Y93LC46(08bit)@SOIC8 [(SA602A)]	Y93LC46(08bit)@TSSOP8 [(SA026)]
Y93LC46(16bit)	Y93LC46(16bit)@SOIC8 [(SA602A)]
Y93LC46(16bit)@TSSOP8 [(SA026)]	Y93LC66(08bit)
Y93LC66(08bit)@SOIC8 [(SA602A)]	Y93LC66(08bit)@TSSOP8 [(SA026)]
Y93LC66(16bit)	Y93LC66(16bit)@SOIC8 [(SA602A)]
Y93LC66(16bit)@TSSOP8 [(SA026)]	Y93LC86(08bit)
Y93LC86(08bit)@SOIC8 [(SA602A)]	Y93LC86(08bit)@TSSOP8 [(SA026)]
Y93LC86(16bit)	Y93LC86(16bit)@SOIC8 [(SA602A)]
Y93LC86(16bit)@TSSOP8 [(SA026)]	

## YSS

### E (E) PROM/FRAM/NVRAM

Y25F05@SOP8 [(SA602A)]	Y25F05@VQFN8 [(SA683)]
Y25F10@SOP8 [(SA602A)]	Y25F10@VQFN8 [(SA683)]

## ZHIXIN

### E (E) PROM/FRAM/NVRAM

PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]
PC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]

## ZILOG

### MICROCONTROLLER

Z16F2810AG20AG@LQFP64 [(PEP+S616)]	
Z16F2810AG20EG@LQFP64 [(PEP+S616)]	
Z16F2810AG20SG@LQFP64 [(PEP+S616)]	
Z16F2810FI20AG@QFP80 [(PEP+S611A)]	
Z16F2810FI20EG@QFP80 [(PEP+S611A)]	
Z16F2810FI20SG@QFP80 [(PEP+S611A)]	
Z16F2810VH20AG@PLCC68 [(PEP+S414T)]	
Z16F2810VH20EG@PLCC68 [(PEP+S414T)]	
Z16F2810VH20SG@PLCC68 [(PEP+S414T)]	
Z16F2811AL20AG@LQFP100 [(PEP+S604)]	
Z16F2811AL20EG@LQFP100 [(PEP+S604)]	
Z16F2811AL20SG@LQFP100 [(PEP+S604)]	
Z16F2811FI20AG@QFP80 [(PEP+S611A)]	
Z16F2811FI20EG@QFP80 [(PEP+S611A)]	
Z16F2811FI20SG@QFP80 [(PEP+S611A)]	
Z16F3211AL20AG@LQFP100 [(PEP+S604)]	
Z16F3211AL20EG@LQFP100 [(PEP+S604)]	
Z16F3211AL20SG@LQFP100 [(PEP+S604)]	
Z16F3211FI20AG@QFP80 [(PEP+S611A)]	
Z16F3211FI20EG@QFP80 [(PEP+S611A)]	
Z16F3211FI20SG@QFP80 [(PEP+S611A)]	
Z16F6411AL20AG@LQFP100 [(PEP+S604)]	
Z16F6411AL20EG@LQFP100 [(PEP+S604)]	
Z16F6411AL20SG@LQFP100 [(PEP+S604)]	
Z16F6411FI20AG@QFP80 [(PEP+S611A)]	
Z16F6411FI20EG@QFP80 [(PEP+S611A)]	
Z16F6411FI20SG@QFP80 [(PEP+S611A)]	
Z86733	Z86733@PLCC28 [(SA008A)]
Z86733@SOIC28 [(SA404)]	Z86743
Z86743@PLCC44 [(SA244)]	Z86C0208PEC
Z86C0208PSC	Z86C0208SEC@SOIC18 [(SA404)]
Z86C0208SSC@SOIC18 [(SA404)]	Z86D7308FSC@QFP44 [(SA245A)]
Z86D7308HSC@SSOP48 [(SA669)]	Z86D7308PSC
Z86D7308VSC@PLCC44 [(SA244)]	Z86D8608PSC
Z86D8608SSC@SOIC28 [(SA404)]	Z86D8608SSG@SOIC28 [(SA404)]
Z86D9808PSC	Z86D9808SSC@SOIC28 [(SA404)]
Z86E02	Z86E02@SOIC18 [(SA404)]
Z86E03	Z86E03@SOIC18 [(SA404)]
Z86E04	Z86E04@SOIC18 [(SA404)]

Z86E0412PEC	Z86E0412PEC1903
Z86E0412PSC1866	Z86E0412PSC1903
Z86E0412SEC [(SA404)]	Z86E0412SEC1903 [(SA404)]
Z86E0412SSC1866 [(SA404)]	Z86E0412SSC1903 [(SA404)]
Z86E06	Z86E06@SOIC18 [(SA404)]
Z86E07	Z86E07@SOIC18 [(SA404)]
Z86E08	Z86E08@SOIC18 [(SA404)]
Z86E0812PEC	Z86E0812PEC1903
Z86E0812PSC1866	Z86E0812PSC1903
Z86E0812SEC [(SA404)]	Z86E0812SEC1903 [(SA404)]
Z86E0812SSC1866 [(SA404)]	Z86E0812SSC1903 [(SA404)]
Z86E122	Z86E122@SOIC20 [(SA404)]
Z86E123	Z86E123@SOIC20 [(SA404)]
Z86E124	Z86E124@SOIC20 [(SA404)]
Z86E125	Z86E125@SOIC20 [(SA404)]
Z86E126	Z86E126@SOIC20 [(SA404)]
Z86E132	Z86E132@SOIC28 [(SA404)]
Z86E133	Z86E133@SOIC28 [(SA404)]
Z86E134	Z86E134@SOIC28 [(SA404)]
Z86E135	Z86E135@SOIC28 [(SA404)]
Z86E136	Z86E136@SOIC28 [(SA404)]
Z86E142	Z86E142@TQFP44 [(SA245A)]
Z86E143	Z86E143@TQFP44 [(SA245A)]
Z86E144	Z86E144@TQFP44 [(SA245A)]
Z86E145	Z86E145@TQFP44 [(SA245A)]
Z86E146	Z86E146@TQFP44 [(SA245A)]
Z86E15	Z86E21
Z86E21@PLCC44 [(SA244)]	Z86E21@TQFP44 [(SA245A)]
Z86E2112	Z86E2112@PLCC44 [(SA244)]
Z86E2112@TQFP44 [(SA245A)]	Z86E2116
Z86E2116@PLCC44 [(SA244)]	Z86E2116@TQFP44 [(SA245A)]
Z86E23	Z86E23@PLCC44 [(SA244)]
Z86E23@TQFP44 [(SA245A)]	Z86E2312
Z86E2312@PLCC44 [(SA244)]	Z86E2312@TQFP44 [(SA245A)]
Z86E2316	Z86E2316@PLCC44 [(SA244)]
Z86E2316@TQFP44 [(SA245A)]	Z86E3016PEC
Z86E3016PSC	Z86E3016SEC@SOIC28 [(SA404)]
Z86E3016SSC@SOIC28 [(SA404)]	Z86E3016VEC@PLCC28 [(SA008A)]
Z86E3016VSC@PLCC28 [(SA008A)]	Z86E3016VSG@PLCC28 [(SA008A)]
Z86E3116PEC	Z86E3116PSC
Z86E3116SEC@SOIC28 [(SA404)]	Z86E3116SSC@SOIC28 [(SA404)]
Z86E3116VEC@PLCC28 [(SA008A)]	Z86E3116VSC@PLCC28 [(SA008A)]
Z86E3116VSG@PLCC28 [(SA008A)]	Z86E33
Z86E33@PLCC28 [(SA008A)]	Z86E33@SOIC28 [(SA404)]
Z86E34	Z86E34@PLCC28 [(SA008A)]
Z86E34@SOIC28 [(SA404)]	Z86E4016FEC@TQFP44 [(SA245A)]
Z86E4016FSC@TQFP44 [(SA245A)]	Z86E4016PEC
Z86E4016PSC	Z86E4016VEC@PLCC44 [(SA244)]
Z86E4016VSC@PLCC44 [(SA244)]	Z86E4016VSG@PLCC44 [(SA244)]
Z86E43	Z86E43@PLCC44 [(SA244)]
Z86E43@TQFP44 [(SA245A)]	Z86E44
Z86E44@PLCC44 [(SA244)]	Z86E44@TQFP44 [(SA245A)]
Z86E6116ASG@TQFP44 [(SA245A)]	Z86E6116PSC
Z86E6116VSC@PLCC44 [(SA244)]	Z86E6120ASG@TQFP44 [(SA245A)]
Z86E6120PSC	Z86E6120VSC@PLCC44 [(SA244)]
Z86E61FSC@TQFP44 [(SA245A)]	Z86E61PSC
Z86E61VSC@PLCC44 [(SA244)]	Z86E6316ASG@TQFP44 [(SA245A)]
Z86E6316PSC	Z86E6316VSC@PLCC44 [(SA244)]
Z86E6320ASG@TQFP44 [(SA245A)]	Z86E6320PSC
Z86E6320VSC@PLCC44 [(SA244)]	Z86E63FSC@TQFP44 [(SA245A)]
Z86E63PSC	Z86E63VSC@PLCC44 [(SA244)]
Z86E72	Z86E72@PLCC44 [(SA244)]
Z86E72@TQFP44 [(SA245A)]	Z86E73
Z86E73@PLCC44 [(SA244)]	Z86E73@TQFP44 [(SA245A)]
Z86E83	Z86E83@PLCC28 [(SA008A)]
Z86E83@SOIC28 [(SA404)]	Z86L0208PEC
Z86L0208PSC	Z86L0208SEC@SOIC18 [(SA404)]
Z86L0208SSC@SOIC18 [(SA404)]	Z89371
Z89371@PLCC44 [(SA244)]	Z89371@TQFP44 [(SA245A)]
Z89371B	Z89371B@PLCC44 [(SA244)]
Z89371B@TQFP44 [(SA245A)]	Z8E00010HEC@SSOP20 [(SA626A)]
Z8E00010HSC@SSOP20 [(SA626A)]	Z8E00010PEC
Z8E00010PSC	Z8E00010SEC@SOIC18 [(SA404)]
Z8E00010SSC@SOIC18 [(SA404)]	Z8E00010SSG@SOIC18 [(SA404)]
Z8E00110HEC@SSOP20 [(SA626A)]	Z8E00110HSC@SSOP20 [(SA626A)]
Z8E00110PEC	Z8E00110PSC
Z8E00110SEC@SOIC18 [(SA404)]	Z8E00110SSC@SOIC18 [(SA404)]
Z8E00110SSG@SOIC18 [(SA404)]	Z8F0113HH005EC@SSOP20 [(SA626A)]
Z8F0113HH005EG@SSOP20 [(SA626A)]	Z8F0113HH005SC@SSOP20 [(SA626A)]
Z8F0113HH005SG@SSOP20 [(SA626A)]	Z8F0113HJ005EC@SSOP28 [(SA626A)]
Z8F0113HJ005EG@SSOP28 [(SA626A)]	Z8F0113HJ005SC@SSOP28 [(SA626A)]



Z8F0113HJ005SG@SSOP28 [(SA626A)]	Z8F0113PB005EC
Z8F0113PB005EG	Z8F0113PB005SC
Z8F0113PB005SG	Z8F0113PH005EC
Z8F0113PH005EG	Z8F0113PH005SC
Z8F0113PH005SG	Z8F0113PJ005EC
Z8F0113PJ005EG	Z8F0113PJ005SC
Z8F0113PJ005SG	Z8F0113QB005EC@QFN8 [(SA683)]
Z8F0113QB005EG@QFN8 [(SA683)]	Z8F0113QB005SC@QFN8 [(SA683)]
Z8F0113QB005SG@QFN8 [(SA683)]	Z8F0113SB005EC@SOIC8 [(SA602A)]
Z8F0113SB005EG@SOIC8 [(SA602A)]	Z8F0113SB005SC@SOIC8 [(SA602A)]
Z8F0113SB005SG@SOIC8 [(SA602A)]	Z8F0113SH005EC@SOIC20 [(SA404)]
Z8F0113SH005EG@SOIC20 [(SA404)]	Z8F0113SH005SC@SOIC20 [(SA404)]
Z8F0113SH005SG@SOIC20 [(SA404)]	Z8F0113SJ005EC@SOIC28 [(SA404)]
Z8F0113SJ005EG@SOIC28 [(SA404)]	Z8F0113SJ005SC@SOIC28 [(SA404)]
Z8F0113SJ005SG@SOIC28 [(SA404)]	Z8F011AHH020EC@SSOP20 [(SA626A)]
Z8F011AHH020EG@SSOP20 [(SA626A)]	Z8F011AHH020SC@SSOP20 [(SA626A)]
Z8F011AHH020SG@SSOP20 [(SA626A)]	Z8F011AHJ020EC@SSOP28 [(SA626A)]
Z8F011AHJ020EG@SSOP28 [(SA626A)]	Z8F011AHJ020SC@SSOP28 [(SA626A)]
Z8F011AHJ020SG@SSOP28 [(SA626A)]	Z8F011APB020EC
Z8F011APB020EG	Z8F011APB020SC
Z8F011APB020SG	Z8F011APH020EC
Z8F011APH020EG	Z8F011APH020SC
Z8F011APH020SG	Z8F011APJ020EC
Z8F011APJ020EG	Z8F011APJ020SC
Z8F011APJ020SG	Z8F011AQB020EC@QFN8 [(SA683)]
Z8F011AQB020EG@QFN8 [(SA683)]	Z8F011AQB020SC@QFN8 [(SA683)]
Z8F011AQB020SG@QFN8 [(SA683)]	Z8F011ASB020EC@SOIC8 [(SA602A)]
Z8F011ASB020EG@SOIC8 [(SA602A)]	Z8F011ASB020SC@SOIC8 [(SA602A)]
Z8F011ASB020SG@SOIC8 [(SA602A)]	Z8F011ASH020EC@SOIC20 [(SA404)]
Z8F011ASH020EG@SOIC20 [(SA404)]	Z8F011ASH020SC@SOIC20 [(SA404)]
Z8F011ASH020SG@SOIC20 [(SA404)]	Z8F011ASJ020EC@SOIC28 [(SA404)]
Z8F011ASJ020EG@SOIC28 [(SA404)]	Z8F011ASJ020SC@SOIC28 [(SA404)]
Z8F011ASJ020SG@SOIC28 [(SA404)]	Z8F0123HH005EC@SSOP20 [(SA626A)]
Z8F0123HH005EG@SSOP20 [(SA626A)]	Z8F0123HH005SC@SSOP20 [(SA626A)]
Z8F0123HH005SG@SSOP20 [(SA626A)]	Z8F0123HJ005EC@SSOP28 [(SA626A)]
Z8F0123HJ005EG@SSOP28 [(SA626A)]	Z8F0123HJ005SC@SSOP28 [(SA626A)]
Z8F0123HJ005SG@SSOP28 [(SA626A)]	Z8F0123PB005EC
Z8F0123PB005EG	Z8F0123PB005SC
Z8F0123PB005SG	Z8F0123PH005EC
Z8F0123PH005EG	Z8F0123PH005SC
Z8F0123PH005SG	Z8F0123PJ005EC
Z8F0123PJ005EG	Z8F0123PJ005SC
Z8F0123PJ005SG	Z8F0123QB005EC@QFN8 [(SA683)]
Z8F0123QB005EG@QFN8 [(SA683)]	Z8F0123QB005SC@QFN8 [(SA683)]
Z8F0123QB005SG@QFN8 [(SA683)]	Z8F0123SB005EC@SOIC8 [(SA602A)]
Z8F0123SB005EG@SOIC8 [(SA602A)]	Z8F0123SB005SC@SOIC8 [(SA602A)]
Z8F0123SB005SG@SOIC8 [(SA602A)]	Z8F0123SH005EC@SOIC20 [(SA404)]
Z8F0123SH005EG@SOIC20 [(SA404)]	Z8F0123SH005SC@SOIC20 [(SA404)]
Z8F0123SH005SG@SOIC20 [(SA404)]	Z8F0123SJ005EC@SOIC28 [(SA404)]
Z8F0123SJ005EG@SOIC28 [(SA404)]	Z8F0123SJ005SC@SOIC28 [(SA404)]
Z8F0123SJ005SG@SOIC28 [(SA404)]	Z8F012AHH020EC@SSOP20 [(SA626A)]
Z8F012AHH020EG@SSOP20 [(SA626A)]	Z8F012AHH020SC@SSOP20 [(SA626A)]
Z8F012AHH020SG@SSOP20 [(SA626A)]	Z8F012AHJ020EC@SSOP28 [(SA626A)]
Z8F012AHJ020EG@SSOP28 [(SA626A)]	Z8F012AHJ020SC@SSOP28 [(SA626A)]
Z8F012AHJ020SG@SSOP28 [(SA626A)]	Z8F012APB020EC
Z8F012APB020EG	Z8F012APB020SC
Z8F012APB020SG	Z8F012APH020EC
Z8F012APH020EG	Z8F012APH020SC
Z8F012APH020SG	Z8F012APJ020EC
Z8F012APJ020EG	Z8F012APJ020SC
Z8F012APJ020SG	Z8F012AQB020EC@QFN8 [(SA683)]
Z8F012AQB020EG@QFN8 [(SA683)]	Z8F012AQB020SC@QFN8 [(SA683)]
Z8F012AQB020SG@QFN8 [(SA683)]	Z8F012ASB020EC@SOIC8 [(SA602A)]
Z8F012ASB020EG@SOIC8 [(SA602A)]	Z8F012ASB020SC@SOIC8 [(SA602A)]
Z8F012ASB020SG@SOIC8 [(SA602A)]	Z8F012ASH020EC@SOIC20 [(SA404)]
Z8F012ASH020EG@SOIC20 [(SA404)]	Z8F012ASH020SC@SOIC20 [(SA404)]
Z8F012ASH020SG@SOIC20 [(SA404)]	Z8F012ASJ020EC@SOIC28 [(SA404)]
Z8F012ASJ020EG@SOIC28 [(SA404)]	Z8F012ASJ020SC@SOIC28 [(SA404)]
Z8F012ASJ020SG@SOIC28 [(SA404)]	Z8F0130HH020EG@SSOP20 [(SA626A)]
Z8F0130HH020SG@SSOP20 [(SA626A)]	Z8F0130HJ020EG@SSOP28 [(SA626A)]
Z8F0130HJ020SG@SSOP28 [(SA626A)]	Z8F0130PH020EG
Z8F0130PH020SG	Z8F0130PJ020EG
Z8F0130PJ020SG	Z8F0130QH020EG@QFN20 [(SA759)]
Z8F0130QH020SG@QFN20 [(SA759)]	Z8F0130QJ020EG@QFN28 [(SA697)]
Z8F0130QJ020SG@QFN28 [(SA697)]	Z8F0130SH020EG@SOIC20 [(SA404)]
Z8F0130SH020SG@SOIC20 [(SA404)]	Z8F0130SJ020EG@SOIC28 [(SA404)]
Z8F0130SJ020SG@SOIC28 [(SA404)]	Z8F0131HH020EG@SSOP20 [(SA626A)]
Z8F0131HH020SG@SSOP20 [(SA626A)]	Z8F0131HJ020EG@SSOP28 [(SA626A)]
Z8F0131HJ020SG@SSOP28 [(SA626A)]	Z8F0131PH020EG
Z8F0131PH020SG	Z8F0131PJ020EG
Z8F0131PJ020SG	Z8F0131QH020EG@QFN20 [(SA759)]

Z8F0131QH020SG@QFN20 [(SA759)]	Z8F0131QJ020EG@QFN28 [(SA697)]
Z8F0131QJ020SG@QFN28 [(SA697)]	Z8F0131SH020EG@SOIC20 [(SA404)]
Z8F0131SH020SG@SOIC20 [(SA404)]	Z8F0131SJ020EG@SOIC28 [(SA404)]
Z8F0131SJ020SG@SOIC28 [(SA404)]	Z8F0213HH005EC@SSOP20 [(SA626A)]
Z8F0213HH005EG@SSOP20 [(SA626A)]	Z8F0213HH005SC@SSOP20 [(SA626A)]
Z8F0213HH005SG@SSOP20 [(SA626A)]	Z8F0213HJ005EC@SSOP28 [(SA626A)]
Z8F0213HJ005EG@SSOP28 [(SA626A)]	Z8F0213HJ005SC@SSOP28 [(SA626A)]
Z8F0213HJ005SG@SSOP28 [(SA626A)]	Z8F0213PB005EC
Z8F0213PB005EG	Z8F0213PB005SC
Z8F0213PB005SG	Z8F0213PH005EC
Z8F0213PH005EG	Z8F0213PH005SC
Z8F0213PH005SG	Z8F0213PJ005EC
Z8F0213PJ005EG	Z8F0213PJ005SC
Z8F0213PJ005SG	Z8F0213QB005EC@QFN8 [(SA683)]
Z8F0213QB005EG@QFN8 [(SA683)]	Z8F0213QB005SC@QFN8 [(SA683)]
Z8F0213QB005SG@QFN8 [(SA683)]	Z8F0213SB005EC@SOIC8 [(SA602A)]
Z8F0213SB005EG@SOIC8 [(SA602A)]	Z8F0213SB005SC@SOIC8 [(SA602A)]
Z8F0213SB005SG@SOIC8 [(SA602A)]	Z8F0213SH005EC@SOIC20 [(SA404)]
Z8F0213SH005EG@SOIC20 [(SA404)]	Z8F0213SH005SC@SOIC20 [(SA404)]
Z8F0213SH005SG@SOIC20 [(SA404)]	Z8F0213SJ005EC@SOIC28 [(SA404)]
Z8F0213SJ005EG@SOIC28 [(SA404)]	Z8F0213SJ005SC@SOIC28 [(SA404)]
Z8F0213SJ005SG@SOIC28 [(SA404)]	Z8F021AHH020EC@SSOP20 [(SA626A)]
Z8F021AHH020EG@SSOP20 [(SA626A)]	Z8F021AHH020SC@SSOP20 [(SA626A)]
Z8F021AHH020SG@SSOP20 [(SA626A)]	Z8F021AHJ020EC@SSOP28 [(SA626A)]
Z8F021AHJ020EG@SSOP28 [(SA626A)]	Z8F021AHJ020SC@SSOP28 [(SA626A)]
Z8F021AHJ020SG@SSOP28 [(SA626A)]	Z8F021APB020EC
Z8F021APB020EG	Z8F021APB020SC
Z8F021APB020SG	Z8F021APH020EC
Z8F021APH020EG	Z8F021APH020SC
Z8F021APH020SG	Z8F021APJ020EC
Z8F021APJ020EG	Z8F021APJ020SC
Z8F021APJ020SG	Z8F021AQB020EC@QFN8 [(SA683)]
Z8F021AQB020EG@QFN8 [(SA683)]	Z8F021AQB020SC@QFN8 [(SA683)]
Z8F021AQB020SG@QFN8 [(SA683)]	Z8F021ASB020EC@SOIC8 [(SA602A)]
Z8F021ASB020EG@SOIC8 [(SA602A)]	Z8F021ASB020SC@SOIC8 [(SA602A)]
Z8F021ASB020SG@SOIC8 [(SA602A)]	Z8F021ASH020EC@SOIC20 [(SA404)]
Z8F021ASH020EG@SOIC20 [(SA404)]	Z8F021ASH020SC@SOIC20 [(SA404)]
Z8F021ASH020SG@SOIC20 [(SA404)]	Z8F021ASJ020EC@SOIC28 [(SA404)]
Z8F021ASJ020EG@SOIC28 [(SA404)]	Z8F021ASJ020SC@SOIC28 [(SA404)]
Z8F021ASJ020SG@SOIC28 [(SA404)]	Z8F0223HH005EC@SSOP20 [(SA626A)]
Z8F0223HH005EG@SSOP20 [(SA626A)]	Z8F0223HH005SC@SSOP20 [(SA626A)]
Z8F0223HH005SG@SSOP20 [(SA626A)]	Z8F0223HJ005EC@SSOP28 [(SA626A)]
Z8F0223HJ005EG@SSOP28 [(SA626A)]	Z8F0223HJ005SC@SSOP28 [(SA626A)]
Z8F0223HJ005SG@SSOP28 [(SA626A)]	Z8F0223PB005EC
Z8F0223PB005EG	Z8F0223PB005SC
Z8F0223PB005SG	Z8F0223PH005EC
Z8F0223PH005EG	Z8F0223PH005SC
Z8F0223PH005SG	Z8F0223PJ005EC
Z8F0223PJ005EG	Z8F0223PJ005SC
Z8F0223PJ005SG	Z8F0223QB005EC@QFN8 [(SA683)]
Z8F0223QB005EG@QFN8 [(SA683)]	Z8F0223QB005SC@QFN8 [(SA683)]
Z8F0223QB005SG@QFN8 [(SA683)]	Z8F0223SB005EC@SOIC8 [(SA602A)]
Z8F0223SB005EG@SOIC8 [(SA602A)]	Z8F0223SB005SC@SOIC8 [(SA602A)]
Z8F0223SB005SG@SOIC8 [(SA602A)]	Z8F0223SH005EC@SOIC20 [(SA404)]
Z8F0223SH005EG@SOIC20 [(SA404)]	Z8F0223SH005SC@SOIC20 [(SA404)]
Z8F0223SH005SG@SOIC20 [(SA404)]	Z8F0223SJ005EC@SOIC28 [(SA404)]
Z8F0223SJ005EG@SOIC28 [(SA404)]	Z8F0223SJ005SC@SOIC28 [(SA404)]
Z8F0223SJ005SG@SOIC28 [(SA404)]	Z8F022AHH020EC@SSOP20 [(SA626A)]
Z8F022AHH020EG@SSOP20 [(SA626A)]	Z8F022AHH020SC@SSOP20 [(SA626A)]
Z8F022AHH020SG@SSOP20 [(SA626A)]	Z8F022AHJ020EC@SSOP28 [(SA626A)]
Z8F022AHJ020EG@SSOP28 [(SA626A)]	Z8F022AHJ020SC@SSOP28 [(SA626A)]
Z8F022AHJ020SG@SSOP28 [(SA626A)]	Z8F022APB020EC
Z8F022APB020EG	Z8F022APB020SC
Z8F022APB020SG	Z8F022APH020EC
Z8F022APH020EG	Z8F022APH020SC
Z8F022APH020SG	Z8F022APJ020EC
Z8F022APJ020EG	Z8F022APJ020SC
Z8F022APJ020SG	Z8F022AQB020EC@QFN8 [(SA683)]
Z8F022AQB020EG@QFN8 [(SA683)]	Z8F022AQB020SC@QFN8 [(SA683)]
Z8F022AQB020SG@QFN8 [(SA683)]	Z8F022ASB020EC@SOIC8 [(SA602A)]
Z8F022ASB020EG@SOIC8 [(SA602A)]	Z8F022ASB020SC@SOIC8 [(SA602A)]
Z8F022ASB020SG@SOIC8 [(SA602A)]	Z8F022ASH020EC@SOIC20 [(SA404)]
Z8F022ASH020EG@SOIC20 [(SA404)]	Z8F022ASH020SC@SOIC20 [(SA404)]
Z8F022ASH020SG@SOIC20 [(SA404)]	Z8F022ASJ020EC@SOIC28 [(SA404)]
Z8F022ASJ020EG@SOIC28 [(SA404)]	Z8F022ASJ020SC@SOIC28 [(SA404)]
Z8F022ASJ020SG@SOIC28 [(SA404)]	Z8F0230HH020EG@SSOP20 [(SA626A)]
Z8F0230HH020SG@SSOP20 [(SA626A)]	Z8F0230HJ020EG@SSOP28 [(SA626A)]
Z8F0230HJ020SG@SSOP28 [(SA626A)]	Z8F0230PH020EG
Z8F0230PH020SG	Z8F0230PJ020EG
Z8F0230PJ020SG	Z8F0230QH020EG@QFN20 [(SA759)]
Z8F0230QH020SG@QFN20 [(SA759)]	Z8F0230QJ020EG@QFN28 [(SA697)]

Z8F0230QJ020SG@QFN28 [(SA697)] Z8F0230SH020EG@SOIC20 [(SA404)]  
 Z8F0230SH020SG@SOIC20 [(SA404)] Z8F0230SJ020EG@SOIC28 [(SA404)]  
 Z8F0230SJ020SG@SOIC28 [(SA404)] Z8F0231HH020EG@SSOP20 [(SA626A)]  
 Z8F0231HH020SG@SSOP20 [(SA626A)] Z8F0231HJ020EG@SSOP28 [(SA626A)]  
 Z8F0231HJ020SG@SSOP28 [(SA626A)] Z8F0231PH020EG  
 Z8F0231PH020SG Z8F0231PJ020EG  
 Z8F0231PJ020SG Z8F0231QH020EG@QFN20 [(SA759)]  
 Z8F0231QH020SG@QFN20 [(SA759)] Z8F0231QJ020EG@QFN28 [(SA697)]  
 Z8F0231QJ020SG@QFN28 [(SA697)] Z8F0231SH020EG@SOIC20 [(SA404)]  
 Z8F0231SH020SG@SOIC20 [(SA404)] Z8F0231SJ020EG@SOIC28 [(SA404)]  
 Z8F0231SJ020SG@SOIC28 [(SA404)] Z8F0411HH020EC@SSOP20 [(SA626A)]  
 Z8F0411HH020EG@SSOP20 [(SA626A)] Z8F0411HH020SC@SSOP20 [(SA626A)]  
 Z8F0411HH020SG@SSOP20 [(SA626A)] Z8F0411PH020EC  
 Z8F0411PH020EG Z8F0411PH020SC  
 Z8F0411PH020SG Z8F0412PJ020EC  
 Z8F0412PJ020EG Z8F0412PJ020SC  
 Z8F0412PJ020SG Z8F0412SJ020EC@SOIC28 [(SA404)]  
 Z8F0412SJ020EG@SOIC28 [(SA404)] Z8F0412SJ020SC@SOIC28 [(SA404)]  
 Z8F0412SJ020SG@SOIC28 [(SA404)] Z8F0413HH005EC@SSOP20 [(SA626A)]  
 Z8F0413HH005EG@SSOP20 [(SA626A)] Z8F0413HH005SC@SSOP20 [(SA626A)]  
 Z8F0413HH005SG@SSOP20 [(SA626A)] Z8F0413HJ005EC@SSOP28 [(SA626A)]  
 Z8F0413HJ005EG@SSOP28 [(SA626A)] Z8F0413HJ005SC@SSOP28 [(SA626A)]  
 Z8F0413HJ005SG@SSOP28 [(SA626A)] Z8F0413PB005EC  
 Z8F0413PB005EG Z8F0413PB005SC  
 Z8F0413PB005SG Z8F0413PH005EC  
 Z8F0413PH005EG Z8F0413PH005SC  
 Z8F0413PH005SG Z8F0413PJ005EC  
 Z8F0413PJ005EG Z8F0413PJ005SC  
 Z8F0413PJ005SG Z8F0413QB005EC@QFN8 [(SA683)]  
 Z8F0413QB005EG@QFN8 [(SA683)] Z8F0413QB005SC@QFN8 [(SA683)]  
 Z8F0413QB005SG@QFN8 [(SA683)] Z8F0413SB005EC@SOIC8 [(SA602A)]  
 Z8F0413SB005EG@SOIC8 [(SA602A)] Z8F0413SB005SC@SOIC8 [(SA602A)]  
 Z8F0413SB005SG@SOIC8 [(SA602A)] Z8F0413SH005EC@SOIC20 [(SA404)]  
 Z8F0413SH005EG@SOIC20 [(SA404)] Z8F0413SH005SC@SOIC20 [(SA404)]  
 Z8F0413SH005SG@SOIC20 [(SA404)] Z8F0413SJ005EC@SOIC28 [(SA404)]  
 Z8F0413SJ005EG@SOIC28 [(SA404)] Z8F0413SJ005SC@SOIC28 [(SA404)]  
 Z8F0413SJ005SG@SOIC28 [(SA404)] Z8F041AHH020EC@SSOP20 [(SA626A)]  
 Z8F041AHH020EG@SSOP20 [(SA626A)] Z8F041AHH020SC@SSOP20 [(SA626A)]  
 Z8F041AHH020SG@SSOP20 [(SA626A)] Z8F041AHJ020EC@SSOP28 [(SA626A)]  
 Z8F041AHJ020EG@SSOP28 [(SA626A)] Z8F041AHJ020SC@SSOP28 [(SA626A)]  
 Z8F041AHJ020SG@SSOP28 [(SA626A)] Z8F041APB020EC  
 Z8F041APB020EG Z8F041APB020SC  
 Z8F041APB020SG Z8F041APH020EC  
 Z8F041APH020EG Z8F041APH020SC  
 Z8F041APH020SG Z8F041APJ020EC  
 Z8F041APJ020EG Z8F041APJ020SC  
 Z8F041APJ020SG Z8F041AQB020EC@QFN8 [(SA683)]  
 Z8F041AQB020EG@QFN8 [(SA683)] Z8F041AQB020SC@QFN8 [(SA683)]  
 Z8F041AQB020SG@QFN8 [(SA683)] Z8F041ASB020EC@SOIC8 [(SA602A)]  
 Z8F041ASB020EG@SOIC8 [(SA602A)] Z8F041ASB020SC@SOIC8 [(SA602A)]  
 Z8F041ASB020SG@SOIC8 [(SA602A)] Z8F041ASH020EC@SOIC20 [(SA404)]  
 Z8F041ASH020EG@SOIC20 [(SA404)] Z8F041ASH020SC@SOIC20 [(SA404)]  
 Z8F041ASH020SG@SOIC20 [(SA404)] Z8F041ASJ020EC@SOIC28 [(SA404)]  
 Z8F041ASJ020EG@SOIC28 [(SA404)] Z8F041ASJ020SC@SOIC28 [(SA404)]  
 Z8F041ASJ020SG@SOIC28 [(SA404)] Z8F0421HH020EC@SSOP20 [(SA626A)]  
 Z8F0421HH020EG@SSOP20 [(SA626A)] Z8F0421HH020SC@SSOP20 [(SA626A)]  
 Z8F0421HH020SG@SSOP20 [(SA626A)] Z8F0421PH020EC  
 Z8F0421PH020EG Z8F0421PH020SC  
 Z8F0421PH020SG Z8F0422PJ020EC  
 Z8F0422PJ020EG Z8F0422PJ020SC  
 Z8F0422PJ020SG Z8F0422SJ020EC@SOIC28 [(SA404)]  
 Z8F0422SJ020EG@SOIC28 [(SA404)] Z8F0422SJ020SC@SOIC28 [(SA404)]  
 Z8F0422SJ020SG@SOIC28 [(SA404)] Z8F0423HH005EC@SSOP20 [(SA626A)]  
 Z8F0423HH005EG@SSOP20 [(SA626A)] Z8F0423HH005SC@SSOP20 [(SA626A)]  
 Z8F0423HH005SG@SSOP20 [(SA626A)] Z8F0423HJ005EC@SSOP28 [(SA626A)]  
 Z8F0423HJ005EG@SSOP28 [(SA626A)] Z8F0423HJ005SC@SSOP28 [(SA626A)]  
 Z8F0423HJ005SG@SSOP28 [(SA626A)] Z8F0423PB005EC  
 Z8F0423PB005EG Z8F0423PB005SC  
 Z8F0423PB005SG Z8F0423PH005EC  
 Z8F0423PH005EG Z8F0423PH005SC  
 Z8F0423PH005SG Z8F0423PJ005EC  
 Z8F0423PJ005EG Z8F0423PJ005SC  
 Z8F0423PJ005SG Z8F0423QB005EC@QFN8 [(SA683)]  
 Z8F0423QB005EG@QFN8 [(SA683)] Z8F0423QB005SC@QFN8 [(SA683)]  
 Z8F0423QB005SG@QFN8 [(SA683)] Z8F0423SB005EC@SOIC8 [(SA602A)]  
 Z8F0423SB005EG@SOIC8 [(SA602A)] Z8F0423SB005SC@SOIC8 [(SA602A)]  
 Z8F0423SB005SG@SOIC8 [(SA602A)] Z8F0423SH005EC@SOIC20 [(SA404)]  
 Z8F0423SH005EG@SOIC20 [(SA404)] Z8F0423SH005SC@SOIC20 [(SA404)]  
 Z8F0423SH005SG@SOIC20 [(SA404)] Z8F0423SJ005EC@SOIC28 [(SA404)]  
 Z8F0423SJ005EG@SOIC28 [(SA404)] Z8F0423SJ005SC@SOIC28 [(SA404)]  
 Z8F0423SJ005SG@SOIC28 [(SA404)] Z8F042AHH020EC@SSOP20 [(SA626A)]

Z8F042AHH020EG@SSOP20	[(SA626A)]	Z8F042AHH020SC@SSOP20	[(SA626A)]
Z8F042AHH020SG@SSOP20	[(SA626A)]	Z8F042AHJ020EC@SSOP28	[(SA626A)]
Z8F042AHJ020EG@SSOP28	[(SA626A)]	Z8F042AHJ020SC@SSOP28	[(SA626A)]
Z8F042AHJ020SG@SSOP28	[(SA626A)]	Z8F042APB020EC	
Z8F042APB020EG		Z8F042APB020SC	
Z8F042APB020SG		Z8F042APH020EC	
Z8F042APH020EG		Z8F042APH020SC	
Z8F042APH020SG		Z8F042APJ020EC	
Z8F042APJ020EG		Z8F042APJ020SC	
Z8F042APJ020SG		Z8F042AQB020EC@QFN8	[(SA683)]
Z8F042AQB020EG@QFN8	[(SA683)]	Z8F042AQB020SC@QFN8	[(SA683)]
Z8F042AQB020SG@QFN8	[(SA683)]	Z8F042ASB020EC@SOIC8	[(SA602A)]
Z8F042ASB020EG@SOIC8	[(SA602A)]	Z8F042ASB020SC@SOIC8	[(SA602A)]
Z8F042ASB020SG@SOIC8	[(SA602A)]	Z8F042ASH020EC@SOIC20	[(SA404)]
Z8F042ASH020EG@SOIC20	[(SA404)]	Z8F042ASH020SC@SOIC20	[(SA404)]
Z8F042ASH020SG@SOIC20	[(SA404)]	Z8F042ASJ020EC@SOIC28	[(SA404)]
Z8F042ASJ020EG@SOIC28	[(SA404)]	Z8F042ASJ020SC@SOIC28	[(SA404)]
Z8F042ASJ020SG@SOIC28	[(SA404)]	Z8F0430HH020EG@SSOP20	[(SA626A)]
Z8F0430HH020SG@SSOP20	[(SA626A)]	Z8F0430HJ020EG@SSOP28	[(SA626A)]
Z8F0430HJ020SG@SSOP28	[(SA626A)]	Z8F0430PH020EG	
Z8F0430PH020SG		Z8F0430PJ020EG	
Z8F0430QH020SG@QFN20	[(SA759)]	Z8F0430QH020EG@QFN20	[(SA759)]
Z8F0430QJ020SG@QFN28	[(SA697)]	Z8F0430QJ020EG@QFN28	[(SA697)]
Z8F0430SH020SG@SOIC20	[(SA404)]	Z8F0430SH020EG@SOIC20	[(SA404)]
Z8F0430SJ020SG@SOIC28	[(SA404)]	Z8F0430SJ020EG@SOIC28	[(SA404)]
Z8F0431HH020SG@SSOP20	[(SA626A)]	Z8F0431HH020EG@SSOP20	[(SA626A)]
Z8F0431HJ020SG@SSOP28	[(SA626A)]	Z8F0431HJ020EG@SSOP28	[(SA626A)]
Z8F0431PH020SG		Z8F0431PH020EG	
Z8F0431PJ020SG		Z8F0431PJ020EG	
Z8F0431QH020SG@QFN20	[(SA759)]	Z8F0431QH020EG@QFN20	[(SA759)]
Z8F0431QJ020SG@QFN28	[(SA697)]	Z8F0431QJ020EG@QFN28	[(SA697)]
Z8F0431SH020SG@SOIC20	[(SA404)]	Z8F0431SH020EG@SOIC20	[(SA404)]
Z8F0431SJ020SG@SOIC28	[(SA404)]	Z8F0431SJ020EG@SOIC28	[(SA404)]
Z8F043AHH020SG@SSOP20	[(SA626A)]	Z8F043AHH020EG@SSOP20	[(SA626A)]
Z8F043AHJ020SG@SSOP28	[(SA626A)]	Z8F043AHJ020EG@SSOP28	[(SA626A)]
Z8F043APH020SG		Z8F043APH020EG	
Z8F043APJ020SG		Z8F043APJ020EG	
Z8F043AQH020SG@QFN20	[(SA759)]	Z8F043AQH020EG@QFN20	[(SA759)]
Z8F043AQJ020SG@QFN28	[(SA697)]	Z8F043AQJ020EG@QFN28	[(SA697)]
Z8F043ASH020SG@SOIC20	[(SA404)]	Z8F043ASH020EG@SOIC20	[(SA404)]
Z8F043ASJ020SG@SOIC28	[(SA404)]	Z8F043ASJ020EG@SOIC28	[(SA404)]
Z8F0811HH020EG@SSOP20	[(SA626A)]	Z8F0811HH020EC@SSOP20	[(SA626A)]
Z8F0811HH020SG@SSOP20	[(SA626A)]	Z8F0811HH020SC@SSOP20	[(SA626A)]
Z8F0811PH020EG		Z8F0811PH020EC	
Z8F0811PH020SG		Z8F0811PH020SC	
Z8F0812PJ020EG		Z8F0812PJ020EC	
Z8F0812PJ020SG		Z8F0812PJ020SC	
Z8F0812SJ020EG@SOIC28	[(SA404)]	Z8F0812SJ020EC@SOIC28	[(SA404)]
Z8F0812SJ020SG@SOIC28	[(SA404)]	Z8F0812SJ020SC@SOIC28	[(SA404)]
Z8F0813HH005EG@SSOP20	[(SA626A)]	Z8F0813HH005EC@SSOP20	[(SA626A)]
Z8F0813HH005SG@SSOP20	[(SA626A)]	Z8F0813HH005SC@SSOP20	[(SA626A)]
Z8F0813HJ020EG@SSOP28	[(SA626A)]	Z8F0813HJ020EC@SSOP28	[(SA626A)]
Z8F0813HJ020SG@SSOP28	[(SA626A)]	Z8F0813HJ020SC@SSOP28	[(SA626A)]
Z8F0813PB005EG		Z8F0813PB005EC	
Z8F0813PB005SG		Z8F0813PB005SC	
Z8F0813PH005EG		Z8F0813PH005EC	
Z8F0813PH005SG		Z8F0813PH005SC	
Z8F0813PJ020EG		Z8F0813PJ020EC	
Z8F0813PJ020SG		Z8F0813PJ020SC	
Z8F0813QB005EG@QFN8	[(SA683)]	Z8F0813QB005EC@QFN8	[(SA683)]
Z8F0813QB005SG@QFN8	[(SA683)]	Z8F0813QB005SC@QFN8	[(SA683)]
Z8F0813SB005EG@SOIC8	[(SA602A)]	Z8F0813SB005EC@SOIC8	[(SA602A)]
Z8F0813SB005SG@SOIC8	[(SA602A)]	Z8F0813SB005SC@SOIC8	[(SA602A)]
Z8F0813SH005EG@SOIC20	[(SA404)]	Z8F0813SH005EC@SOIC20	[(SA404)]
Z8F0813SH005SG@SOIC20	[(SA404)]	Z8F0813SH005SC@SOIC20	[(SA404)]
Z8F0813SJ020EG@SOIC28	[(SA404)]	Z8F0813SJ020EC@SOIC28	[(SA404)]
Z8F0813SJ020SG@SOIC28	[(SA404)]	Z8F0813SJ020SC@SOIC28	[(SA404)]
Z8F0813SJ020EG@SOIC28	[(SA404)]	Z8F0813SJ020EC@SOIC28	[(SA404)]
Z8F0813SJ020SG@SOIC28	[(SA404)]	Z8F0813SJ020SC@SOIC28	[(SA404)]
Z8F081AHH005EG@SSOP20	[(SA626A)]	Z8F081AHH005EC@SSOP20	[(SA626A)]
Z8F081AHH005SG@SSOP20	[(SA626A)]	Z8F081AHH005SC@SSOP20	[(SA626A)]
Z8F081AHJ020EG@SSOP28	[(SA626A)]	Z8F081AHJ020EC@SSOP28	[(SA626A)]
Z8F081AHJ020SG@SSOP28	[(SA626A)]	Z8F081AHJ020SC@SSOP28	[(SA626A)]
Z8F081APB020EG		Z8F081APB020EC	
Z8F081APB020SG		Z8F081APB020SC	
Z8F081APH005EG		Z8F081APH005EC	
Z8F081APH005SG		Z8F081APH005SC	
Z8F081APJ020EG		Z8F081APJ020EC	
Z8F081APJ020SG		Z8F081APJ020SC	
Z8F081AQB020EG@QFN8	[(SA683)]	Z8F081AQB020EC@QFN8	[(SA683)]
Z8F081AQB020SG@QFN8	[(SA683)]	Z8F081AQB020SC@QFN8	[(SA683)]
Z8F081ASB020EG@SOIC8	[(SA602A)]	Z8F081ASB020EC@SOIC8	[(SA602A)]
Z8F081ASB020SG@SOIC8	[(SA602A)]	Z8F081ASB020SC@SOIC8	[(SA602A)]

Z8F081ASB020SG@SOIC8 [(SA602A)]	Z8F081ASH005EC@SOIC20 [(SA404)]
Z8F081ASH005EG@SOIC20 [(SA404)]	Z8F081ASH005SC@SOIC20 [(SA404)]
Z8F081ASH005SG@SOIC20 [(SA404)]	Z8F081ASJ020EC@SOIC28 [(SA404)]
Z8F081ASJ020EG@SOIC28 [(SA404)]	Z8F081ASJ020SC@SOIC28 [(SA404)]
Z8F081ASJ020SG@SOIC28 [(SA404)]	Z8F0821HH020EC@SSOP20 [(SA626A)]
Z8F0821HH020EG@SSOP20 [(SA626A)]	Z8F0821HH020SC@SSOP20 [(SA626A)]
Z8F0821HH020SG@SSOP20 [(SA626A)]	Z8F0821PH020EC
Z8F0821PH020EG	Z8F0821PH020SC
Z8F0821PH020SG	Z8F0822PJ020EC
Z8F0822PJ020EG	Z8F0822PJ020SC
Z8F0822PJ020SG	Z8F0822SJ020EC@SOIC28 [(SA404)]
Z8F0822SJ020EG@SOIC28 [(SA404)]	Z8F0822SJ020SC@SOIC28 [(SA404)]
Z8F0822SJ020SG@SOIC28 [(SA404)]	Z8F0823HH005EC@SSOP20 [(SA626A)]
Z8F0823HH005EG@SSOP20 [(SA626A)]	Z8F0823HH005SC@SSOP20 [(SA626A)]
Z8F0823HH005SG@SSOP20 [(SA626A)]	Z8F0823HJ020EC@SSOP28 [(SA626A)]
Z8F0823HJ020EG@SSOP28 [(SA626A)]	Z8F0823HJ020SC@SSOP28 [(SA626A)]
Z8F0823HJ020SG@SSOP28 [(SA626A)]	Z8F0823PB005EC
Z8F0823PB005EG	Z8F0823PB005SC
Z8F0823PB005SG	Z8F0823PH005EC
Z8F0823PH005EG	Z8F0823PH005SC
Z8F0823PH005SG	Z8F0823PJ020EC
Z8F0823PJ020EG	Z8F0823PJ020SC
Z8F0823PJ020SG	Z8F0823QB005EC@QFN8 [(SA683)]
Z8F0823QB005EG@QFN8 [(SA683)]	Z8F0823QB005SC@QFN8 [(SA683)]
Z8F0823QB005SG@QFN8 [(SA683)]	Z8F0823SB005EC@SOIC8 [(SA602A)]
Z8F0823SB005EG@SOIC8 [(SA602A)]	Z8F0823SB005SC@SOIC8 [(SA602A)]
Z8F0823SB005SG@SOIC8 [(SA602A)]	Z8F0823SH005EC@SOIC20 [(SA404)]
Z8F0823SH005EG@SOIC20 [(SA404)]	Z8F0823SH005SC@SOIC20 [(SA404)]
Z8F0823SH005SG@SOIC20 [(SA404)]	Z8F0823SJ020EC@SOIC28 [(SA404)]
Z8F0823SJ020EG@SOIC28 [(SA404)]	Z8F0823SJ020SC@SOIC28 [(SA404)]
Z8F0823SJ020SG@SOIC28 [(SA404)]	Z8F082AHH005EC@SSOP20 [(SA626A)]
Z8F082AHH005EG@SSOP20 [(SA626A)]	Z8F082AHH005SC@SSOP20 [(SA626A)]
Z8F082AHH005SG@SSOP20 [(SA626A)]	Z8F082AHJ020EC@SSOP28 [(SA626A)]
Z8F082AHJ020EG@SSOP28 [(SA626A)]	Z8F082AHJ020SC@SSOP28 [(SA626A)]
Z8F082AHJ020SG@SSOP28 [(SA626A)]	Z8F082APB020EC
Z8F082APB020EG	Z8F082APB020SC
Z8F082APB020SG	Z8F082APH005EC
Z8F082APH005EG	Z8F082APH005SC
Z8F082APH005SG	Z8F082APJ020EC
Z8F082APJ020EG	Z8F082APJ020SC
Z8F082APJ020SG	Z8F082AQB020EC@QFN8 [(SA683)]
Z8F082AQB020EG@QFN8 [(SA683)]	Z8F082AQB020SC@QFN8 [(SA683)]
Z8F082AQB020SG@QFN8 [(SA683)]	Z8F082ASB020EC@SOIC8 [(SA602A)]
Z8F082ASB020EG@SOIC8 [(SA602A)]	Z8F082ASB020SC@SOIC8 [(SA602A)]
Z8F082ASB020SG@SOIC8 [(SA602A)]	Z8F082ASH005EC@SOIC20 [(SA404)]
Z8F082ASH005EG@SOIC20 [(SA404)]	Z8F082ASH005SC@SOIC20 [(SA404)]
Z8F082ASH005SG@SOIC20 [(SA404)]	Z8F082ASJ020EC@SOIC28 [(SA404)]
Z8F082ASJ020EG@SOIC28 [(SA404)]	Z8F082ASJ020SC@SOIC28 [(SA404)]
Z8F082ASJ020SG@SOIC28 [(SA404)]	Z8F0830HH020EG@SSOP20 [(SA626A)]
Z8F0830HH020SG@SSOP20 [(SA626A)]	Z8F0830HJ020EG@SSOP28 [(SA626A)]
Z8F0830HJ020SG@SSOP28 [(SA626A)]	Z8F0830PH020EG
Z8F0830PH020SG	Z8F0830PJ020EG
Z8F0830PJ020SG	Z8F0830QH020EG@QFN20 [(SA759)]
Z8F0830QH020SG@QFN20 [(SA759)]	Z8F0830QJ020EG@QFN28 [(SA697)]
Z8F0830QJ020SG@QFN28 [(SA697)]	Z8F0830SH020EG@SOIC20 [(SA404)]
Z8F0830SH020SG@SOIC20 [(SA404)]	Z8F0830SJ020EG@SOIC28 [(SA404)]
Z8F0830SJ020SG@SOIC28 [(SA404)]	Z8F0831HH020EG@SSOP20 [(SA626A)]
Z8F0831HH020SG@SSOP20 [(SA626A)]	Z8F0831HJ020EG@SSOP28 [(SA626A)]
Z8F0831HJ020SG@SSOP28 [(SA626A)]	Z8F0831PH020EG
Z8F0831PH020SG	Z8F0831PJ020EG
Z8F0831PJ020SG	Z8F0831QH020EG@QFN20 [(SA759)]
Z8F0831QH020SG@QFN20 [(SA759)]	Z8F0831QJ020EG@QFN28 [(SA697)]
Z8F0831QJ020SG@QFN28 [(SA697)]	Z8F0831SH020EG@SOIC20 [(SA404)]
Z8F0831SH020SG@SOIC20 [(SA404)]	Z8F0831SJ020EG@SOIC28 [(SA404)]
Z8F0831SJ020SG@SOIC28 [(SA404)]	Z8F083AHH020EG@SSOP20 [(SA626A)]
Z8F083AHH020SG@SSOP20 [(SA626A)]	Z8F083AHJ020EG@SSOP28 [(SA626A)]
Z8F083AHJ020SG@SSOP28 [(SA626A)]	Z8F083APH020EG
Z8F083APH020SG	Z8F083APJ020EG
Z8F083APJ020SG	Z8F083AQH020EG@QFN20 [(SA759)]
Z8F083AQH020SG@QFN20 [(SA759)]	Z8F083AQJ020EG@QFN28 [(SA697)]
Z8F083AQJ020SG@QFN28 [(SA697)]	Z8F083ASH020EG@SOIC20 [(SA404)]
Z8F083ASH020SG@SOIC20 [(SA404)]	Z8F083ASJ020EG@SOIC28 [(SA404)]
Z8F083ASJ020SG@SOIC28 [(SA404)]	Z8F1232HH020EG@SSOP20 [(SA626A)]
Z8F1232HH020SG@SSOP20 [(SA626A)]	Z8F1232HJ020EG@SSOP28 [(SA626A)]
Z8F1232HJ020SG@SSOP28 [(SA626A)]	Z8F1232PH020EG
Z8F1232PH020SG	Z8F1232PJ020EG
Z8F1232PJ020SG	Z8F1232QH020EG@QFN20 [(SA759)]
Z8F1232QH020SG@QFN20 [(SA759)]	Z8F1232QJ020EG@QFN28 [(SA697)]
Z8F1232QJ020SG@QFN28 [(SA697)]	Z8F1232SH020EG@SOIC20 [(SA404)]
Z8F1232SH020SG@SOIC20 [(SA404)]	Z8F1232SJ020EG@SOIC28 [(SA404)]
Z8F1232SJ020SG@SOIC28 [(SA404)]	Z8F1233HH020EG@SSOP20 [(SA626A)]

Z8F1233HH020SG@SSOP20	[(SA626A)]	Z8F1233HJ020EG@SSOP28	[(SA626A)]
Z8F1233HJ020SG@SSOP28	[(SA626A)]	Z8F1233PH020EG	
Z8F1233PH020SG		Z8F1233PJ020EG	
Z8F1233PJ020SG		Z8F1233QH020EG@QFN20	[(SA759)]
Z8F1233QH020SG@QFN20	[(SA759)]	Z8F1233QJ020EG@QFN28	[(SA697)]
Z8F1233QJ020SG@QFN28	[(SA697)]	Z8F1233SH020EG@SOIC20	[(SA404)]
Z8F1233SH020SG@SOIC20	[(SA404)]	Z8F1233SJ020EG@SOIC28	[(SA404)]
Z8F1233SJ020SG@SOIC28	[(SA404)]	Z8F1601AN020EC@LQFP44	[(SA245A)]
Z8F1601AN020EG@LQFP44	[(SA245A)]	Z8F1601AN020SC@LQFP44	[(SA245A)]
Z8F1601AN020SG@LQFP44	[(SA245A)]	Z8F1601PM020EC	
Z8F1601PM020EG		Z8F1601PM020SC	
Z8F1601PM020SG		Z8F1601VN020EC@PLCC44	[(SA244)]
Z8F1601VN020EG@PLCC44	[(SA244)]	Z8F1601VN020SC@PLCC44	[(SA244)]
Z8F1601VN020SG@PLCC44	[(SA244)]	Z8F1602AN020EC@LQFP44	[(SA245A)]
Z8F1602AN020EG@LQFP44	[(SA245A)]	Z8F1602AN020SC@LQFP44	[(SA245A)]
Z8F1602AN020SG@LQFP44	[(SA245A)]	Z8F1602PM020EC	
Z8F1602PM020EG		Z8F1602PM020SC	
Z8F1602PM020SG		Z8F1602VN020EC@PLCC44	[(SA244)]
Z8F1602VN020EG@PLCC44	[(SA244)]	Z8F1602VN020SC@PLCC44	[(SA244)]
Z8F1602VN020SG@PLCC44	[(SA244)]	Z8F1621AN020AC@LQFP44	[(SA245A)]
Z8F1621AN020AG@LQFP44	[(SA245A)]	Z8F1621AN020EC@LQFP44	[(SA245A)]
Z8F1621AN020EG@LQFP44	[(SA245A)]	Z8F1621AN020SC@LQFP44	[(SA245A)]
Z8F1621AN020SG@LQFP44	[(SA245A)]	Z8F1621PM020AC	
Z8F1621PM020AG		Z8F1621PM020EC	
Z8F1621PM020EG		Z8F1621PM020SC	
Z8F1621PM020SG		Z8F1621VN020AC@PLCC44	[(SA244)]
Z8F1621VN020AG@PLCC44	[(SA244)]	Z8F1621VN020EC@PLCC44	[(SA244)]
Z8F1621VN020EG@PLCC44	[(SA244)]	Z8F1621VN020SC@PLCC44	[(SA244)]
Z8F1621VN020SG@PLCC44	[(SA244)]		
Z8F1622AR020AC@LQFP64	[(PEP+S616)]		
Z8F1622AR020AG@LQFP64	[(PEP+S616)]		
Z8F1622AR020EC@LQFP64	[(PEP+S616)]		
Z8F1622AR020EG@LQFP64	[(PEP+S616)]		
Z8F1622AR020SC@LQFP64	[(PEP+S616)]		
Z8F1622AR020SG@LQFP64	[(PEP+S616)]		
Z8F1622VS020AC@PLCC68	[(PEP+S414T)]		
Z8F1622VS020AG@PLCC68	[(PEP+S414T)]		
Z8F1622VS020EC@PLCC68	[(PEP+S414T)]		
Z8F1622VS020EG@PLCC68	[(PEP+S414T)]		
Z8F1622VS020SC@PLCC68	[(PEP+S414T)]		
Z8F1622VS020SG@PLCC68	[(PEP+S414T)]		
Z8F2421AN020AC@LQFP44	[(SA245A)]	Z8F2421AN020AG@LQFP44	[(SA245A)]
Z8F2421AN020EC@LQFP44	[(SA245A)]	Z8F2421AN020EG@LQFP44	[(SA245A)]
Z8F2421AN020SC@LQFP44	[(SA245A)]	Z8F2421AN020SG@LQFP44	[(SA245A)]
Z8F2421PM020AC		Z8F2421PM020AG	
Z8F2421PM020EC		Z8F2421PM020EG	
Z8F2421PM020SC		Z8F2421PM020SG	
Z8F2421VN020AC@PLCC44	[(SA244)]	Z8F2421VN020AG@PLCC44	[(SA244)]
Z8F2421VN020EC@PLCC44	[(SA244)]	Z8F2421VN020EG@PLCC44	[(SA244)]
Z8F2421VN020SC@PLCC44	[(SA244)]	Z8F2421VN020SG@PLCC44	[(SA244)]
Z8F2422AR020AC@LQFP64	[(PEP+S616)]		
Z8F2422AR020AG@LQFP64	[(PEP+S616)]		
Z8F2422AR020EC@LQFP64	[(PEP+S616)]		
Z8F2422AR020EG@LQFP64	[(PEP+S616)]		
Z8F2422AR020SC@LQFP64	[(PEP+S616)]		
Z8F2422AR020SG@LQFP64	[(PEP+S616)]		
Z8F2422VS020AC@PLCC68	[(PEP+S414T)]		
Z8F2422VS020AG@PLCC68	[(PEP+S414T)]		
Z8F2422VS020EC@PLCC68	[(PEP+S414T)]		
Z8F2422VS020EG@PLCC68	[(PEP+S414T)]		
Z8F2422VS020SC@PLCC68	[(PEP+S414T)]		
Z8F2422VS020SG@PLCC68	[(PEP+S414T)]		
Z8F3221AN020AC@LQFP44	[(SA245A)]	Z8F3221AN020AG@LQFP44	[(SA245A)]
Z8F3221AN020EC@LQFP44	[(SA245A)]	Z8F3221AN020EG@LQFP44	[(SA245A)]
Z8F3221AN020SC@LQFP44	[(SA245A)]	Z8F3221AN020SG@LQFP44	[(SA245A)]
Z8F3221PM020AC		Z8F3221PM020AG	
Z8F3221PM020EC		Z8F3221PM020EG	
Z8F3221PM020SC		Z8F3221PM020SG	
Z8F3221VN020AC@PLCC44	[(SA244)]	Z8F3221VN020AG@PLCC44	[(SA244)]
Z8F3221VN020EC@PLCC44	[(SA244)]	Z8F3221VN020EG@PLCC44	[(SA244)]
Z8F3221VN020SC@PLCC44	[(SA244)]	Z8F3221VN020SG@PLCC44	[(SA244)]
Z8F3222AR020AC@LQFP64	[(PEP+S616)]		
Z8F3222AR020AG@LQFP64	[(PEP+S616)]		
Z8F3222AR020EC@LQFP64	[(PEP+S616)]		
Z8F3222AR020EG@LQFP64	[(PEP+S616)]		
Z8F3222AR020SC@LQFP64	[(PEP+S616)]		
Z8F3222AR020SG@LQFP64	[(PEP+S616)]		
Z8F3222VS020AC@PLCC68	[(PEP+S414T)]		
Z8F3222VS020AG@PLCC68	[(PEP+S414T)]		
Z8F3222VS020EC@PLCC68	[(PEP+S414T)]		
Z8F3222VS020EG@PLCC68	[(PEP+S414T)]		
Z8F3222VS020SC@PLCC68	[(PEP+S414T)]		
Z8F3222VS020SG@PLCC68	[(PEP+S414T)]		

Z8F3222VS020SC@PLCC68 [(PEP+S414T)]	
Z8F3222VS020SG@PLCC68 [(PEP+S414T)]	
Z8F4801AN@TQFP44 [(SA245A)]	Z8F4801PM
Z8F4801VN@PLCC44 [(SA244)]	
Z8F4802AR020SC@LQFP64 [(PEP+S616)]	
Z8F4821AN020AC@LQFP44 [(SA245A)]	Z8F4821AN020AG@LQFP44 [(SA245A)]
Z8F4821AN020EC@LQFP44 [(SA245A)]	Z8F4821AN020EG@LQFP44 [(SA245A)]
Z8F4821AN020EG21@LQFP44 [(SA245A)]	
Z8F4821AN020SC@LQFP44 [(SA245A)]	Z8F4821AN020SG@LQFP44 [(SA245A)]
Z8F4821AN020SG21@LQFP44 [(SA245A)]	
Z8F4821PM020AC	Z8F4821PM020AG
Z8F4821PM020EC	Z8F4821PM020EG
Z8F4821PM020SC	Z8F4821PM020SG
Z8F4821VN020AC@PLCC44 [(SA244)]	Z8F4821VN020AG@PLCC44 [(SA244)]
Z8F4821VN020EC@PLCC44 [(SA244)]	Z8F4821VN020EG@PLCC44 [(SA244)]
Z8F4821VN020SC@PLCC44 [(SA244)]	Z8F4821VN020SG@PLCC44 [(SA244)]
Z8F4822AR020AC@LQFP64 [(PEP+S616)]	
Z8F4822AR020AG@LQFP64 [(PEP+S616)]	
Z8F4822AR020EC@LQFP64 [(PEP+S616)]	
Z8F4822AR020EG@LQFP64 [(PEP+S616)]	
Z8F4822AR020SC@LQFP64 [(PEP+S616)]	
Z8F4822AR020SG@LQFP64 [(PEP+S616)]	
Z8F4822VS020AC@PLCC68 [(PEP+S414T)]	
Z8F4822VS020AG@PLCC68 [(PEP+S414T)]	
Z8F4822VS020EC@PLCC68 [(PEP+S414T)]	
Z8F4822VS020EG@PLCC68 [(PEP+S414T)]	
Z8F4822VS020SC@PLCC68 [(PEP+S414T)]	
Z8F4822VS020SG@PLCC68 [(PEP+S414T)]	
Z8F4823FT020AC@QFP80 [(PEP+S611A)]	
Z8F4823FT020AG@QFP80 [(PEP+S611A)]	
Z8F4823FT020EC@QFP80 [(PEP+S611A)]	
Z8F4823FT020EG@QFP80 [(PEP+S611A)]	
Z8F4823FT020SC@QFP80 [(PEP+S611A)]	
Z8F4823FT020SG@QFP80 [(PEP+S611A)]	
Z8F6401AN@TQFP44 [(SA245A)]	Z8F6401PM
Z8F6401VN@PLCC44 [(SA244)]	
Z8F6402AR020EC@LQFP64 [(PEP+S616)]	
Z8F6402AR020SC@LQFP64 [(PEP+S616)]	
Z8F6402VS020SC@PLCC68 [(PEP+S414T)]	
Z8F6403FT020EC@QFP80 [(PEP+S611A)]	
Z8F6403FT020SC@QFP80 [(PEP+S611A)]	
Z8F6421AN020AC@LQFP44 [(SA245A)]	Z8F6421AN020AG@LQFP44 [(SA245A)]
Z8F6421AN020EC@LQFP44 [(SA245A)]	Z8F6421AN020EG@LQFP44 [(SA245A)]
Z8F6421AN020SC@LQFP44 [(SA245A)]	Z8F6421AN020SG@LQFP44 [(SA245A)]
Z8F6421PM020AC	Z8F6421PM020AG
Z8F6421PM020EC	Z8F6421PM020EG
Z8F6421PM020SC	Z8F6421PM020SG
Z8F6421VN020AC@PLCC44 [(SA244)]	Z8F6421VN020AG@PLCC44 [(SA244)]
Z8F6421VN020EC@PLCC44 [(SA244)]	Z8F6421VN020EG@PLCC44 [(SA244)]
Z8F6421VN020SC@PLCC44 [(SA244)]	Z8F6421VN020SG@PLCC44 [(SA244)]
Z8F6422AR020AC@LQFP64 [(PEP+S616)]	
Z8F6422AR020AG@LQFP64 [(PEP+S616)]	
Z8F6422AR020EC@LQFP64 [(PEP+S616)]	
Z8F6422AR020EG@LQFP64 [(PEP+S616)]	
Z8F6422AR020SC@LQFP64 [(PEP+S616)]	
Z8F6422AR020SG@LQFP64 [(PEP+S616)]	
Z8F6422VS020AC@PLCC68 [(PEP+S414T)]	
Z8F6422VS020AG@PLCC68 [(PEP+S414T)]	
Z8F6422VS020EC@PLCC68 [(PEP+S414T)]	
Z8F6422VS020EG@PLCC68 [(PEP+S414T)]	
Z8F6422VS020SC@PLCC68 [(PEP+S414T)]	
Z8F6422VS020SG@PLCC68 [(PEP+S414T)]	
Z8F6423FT020AC@QFP80 [(PEP+S611A)]	
Z8F6423FT020AG@QFP80 [(PEP+S611A)]	
Z8F6423FT020EC@QFP80 [(PEP+S611A)]	
Z8F6423FT020EG@QFP80 [(PEP+S611A)]	
Z8F6423FT020SC@QFP80 [(PEP+S611A)]	
Z8F6423FT020SG@QFP80 [(PEP+S611A)]	
Z8FMC04100AKEG@QFP32 [(SA663)]	Z8FMC04100AKSG@QFP32 [(SA663)]
Z8FMC04100QKEG@QFN32 [(SA686)]	Z8FMC04100QKSG@QFN32 [(SA686)]
Z8FMC08100AKEG@QFP32 [(SA663)]	Z8FMC08100AKSG@QFP32 [(SA663)]
Z8FMC08100QKEG@QFN32 [(SA686)]	Z8FMC08100QKSG@QFN32 [(SA686)]
Z8FMC16100AKEG@QFP32 [(SA663)]	Z8FMC16100AKSG@QFP32 [(SA663)]
Z8FMC16100QKEG@QFN32 [(SA686)]	Z8FMC16100QKSG@QFN32 [(SA686)]
Z8PE00210HEC@SSOP20 [(SA626A)]	Z8PE00210HSC@SSOP20 [(SA626A)]
Z8PE00210PEC	Z8PE00210PSC
Z8PE00210SEC@SOIC18 [(SA404)]	Z8PE00210SSC@SOIC18 [(SA404)]
Z8PE00210SSG@SOIC18 [(SA404)]	Z8PE00310HEC@SSOP20 [(SA626A)]
Z8PE00310HSC@SSOP20 [(SA626A)]	Z8PE00310PEC
Z8PE00310PSC	Z8PE00310SEC@SOIC18 [(SA404)]
Z8PE00310SSC@SOIC18 [(SA404)]	Z8PE00310SSG@SOIC18 [(SA404)]

ZGP323HAH2004C@SSOP20	[ (SA626A) ]	ZGP323HAH2004G@SSOP20	[ (SA626A) ]
ZGP323HAH2008C@SSOP20	[ (SA626A) ]	ZGP323HAH2008G@SSOP20	[ (SA626A) ]
ZGP323HAH2016C@SSOP20	[ (SA626A) ]	ZGP323HAH2016G@SSOP20	[ (SA626A) ]
ZGP323HAH2032C@SSOP20	[ (SA626A) ]	ZGP323HAH2032G@SSOP20	[ (SA626A) ]
ZGP323HAH2804C@SSOP28	[ (SA626A) ]	ZGP323HAH2804G@SSOP28	[ (SA626A) ]
ZGP323HAH2808C@SSOP28	[ (SA626A) ]	ZGP323HAH2808G@SSOP28	[ (SA626A) ]
ZGP323HAH2816C@SSOP28	[ (SA626A) ]	ZGP323HAH2816G@SSOP28	[ (SA626A) ]
ZGP323HAH2832C@SSOP28	[ (SA626A) ]	ZGP323HAH2832G@SSOP28	[ (SA626A) ]
ZGP323HAH4804C@SSOP48	[ (SA669) ]	ZGP323HAH4804G@SSOP48	[ (SA669) ]
ZGP323HAH4808C@SSOP48	[ (SA669) ]	ZGP323HAH4808G@SSOP48	[ (SA669) ]
ZGP323HAH4816C@SSOP48	[ (SA669) ]	ZGP323HAH4816G@SSOP48	[ (SA669) ]
ZGP323HAH4832C@SSOP48	[ (SA669) ]	ZGP323HAH4832G@SSOP48	[ (SA669) ]
ZGP323HAP2004C		ZGP323HAP2004G	
ZGP323HAP2008C		ZGP323HAP2008G	
ZGP323HAP2016C		ZGP323HAP2016G	
ZGP323HAP2032C		ZGP323HAP2032G	
ZGP323HAP2804C		ZGP323HAP2804G	
ZGP323HAP2808C		ZGP323HAP2808G	
ZGP323HAP2816C		ZGP323HAP2816G	
ZGP323HAP2832C		ZGP323HAP2832G	
ZGP323HAP4004C		ZGP323HAP4004G	
ZGP323HAP4008C		ZGP323HAP4008G	
ZGP323HAP4016C		ZGP323HAP4016G	
ZGP323HAP4032C		ZGP323HAP4032G	
ZGP323HAS2004C@SOIC20	[ (SA404) ]	ZGP323HAS2004G@SOIC20	[ (SA404) ]
ZGP323HAS2008C@SOIC20	[ (SA404) ]	ZGP323HAS2008G@SOIC20	[ (SA404) ]
ZGP323HAS2016C@SOIC20	[ (SA404) ]	ZGP323HAS2016G@SOIC20	[ (SA404) ]
ZGP323HAS2032C@SOIC20	[ (SA404) ]	ZGP323HAS2032G@SOIC20	[ (SA404) ]
ZGP323HAS2804C@SOIC28	[ (SA404) ]	ZGP323HAS2804G@SOIC28	[ (SA404) ]
ZGP323HAS2808C@SOIC28	[ (SA404) ]	ZGP323HAS2808G@SOIC28	[ (SA404) ]
ZGP323HAS2816C@SOIC28	[ (SA404) ]	ZGP323HAS2816G@SOIC28	[ (SA404) ]
ZGP323HAS2832C@SOIC28	[ (SA404) ]	ZGP323HAS2832G@SOIC28	[ (SA404) ]
ZGP323HEH2004C@SSOP20	[ (SA626A) ]	ZGP323HEH2004G@SSOP20	[ (SA626A) ]
ZGP323HEH2008C@SSOP20	[ (SA626A) ]	ZGP323HEH2008G@SSOP20	[ (SA626A) ]
ZGP323HEH2016C@SSOP20	[ (SA626A) ]	ZGP323HEH2016G@SSOP20	[ (SA626A) ]
ZGP323HEH2032C@SSOP20	[ (SA626A) ]	ZGP323HEH2032G@SSOP20	[ (SA626A) ]
ZGP323HEH2804C@SSOP28	[ (SA626A) ]	ZGP323HEH2804G@SSOP28	[ (SA626A) ]
ZGP323HEH2808C@SSOP28	[ (SA626A) ]	ZGP323HEH2808G@SSOP28	[ (SA626A) ]
ZGP323HEH2816C@SSOP28	[ (SA626A) ]	ZGP323HEH2816G@SSOP28	[ (SA626A) ]
ZGP323HEH2832C@SSOP28	[ (SA626A) ]	ZGP323HEH2832G@SSOP28	[ (SA626A) ]
ZGP323HEH4804C@SSOP48	[ (SA669) ]	ZGP323HEH4804G@SSOP48	[ (SA669) ]
ZGP323HEH4808C@SSOP48	[ (SA669) ]	ZGP323HEH4808G@SSOP48	[ (SA669) ]
ZGP323HEH4816C@SSOP48	[ (SA669) ]	ZGP323HEH4816G@SSOP48	[ (SA669) ]
ZGP323HEH4832C@SSOP48	[ (SA669) ]	ZGP323HEH4832G@SSOP48	[ (SA669) ]
ZGP323HEP2004C		ZGP323HEP2004G	
ZGP323HEP2008C		ZGP323HEP2008G	
ZGP323HEP2016C		ZGP323HEP2016G	
ZGP323HEP2032C		ZGP323HEP2032G	
ZGP323HEP2804C		ZGP323HEP2804G	
ZGP323HEP2808C		ZGP323HEP2808G	
ZGP323HEP2816C		ZGP323HEP2816G	
ZGP323HEP2832C		ZGP323HEP2832G	
ZGP323HEP4004C		ZGP323HEP4004G	
ZGP323HEP4008C		ZGP323HEP4008G	
ZGP323HEP4016C		ZGP323HEP4016G	
ZGP323HEP4032C		ZGP323HEP4032G	
ZGP323HES2004C@SOIC20	[ (SA404) ]	ZGP323HES2004G@SOIC20	[ (SA404) ]
ZGP323HES2008C@SOIC20	[ (SA404) ]	ZGP323HES2008G@SOIC20	[ (SA404) ]
ZGP323HES2016C@SOIC20	[ (SA404) ]	ZGP323HES2016G@SOIC20	[ (SA404) ]
ZGP323HES2032C@SOIC20	[ (SA404) ]	ZGP323HES2032G@SOIC20	[ (SA404) ]
ZGP323HES2804C@SOIC28	[ (SA404) ]	ZGP323HES2804G@SOIC28	[ (SA404) ]
ZGP323HES2808C@SOIC28	[ (SA404) ]	ZGP323HES2808G@SOIC28	[ (SA404) ]
ZGP323HES2816C@SOIC28	[ (SA404) ]	ZGP323HES2816G@SOIC28	[ (SA404) ]
ZGP323HES2832C@SOIC28	[ (SA404) ]	ZGP323HES2832G@SOIC28	[ (SA404) ]
ZGP323HSH2004C@SSOP20	[ (SA626A) ]	ZGP323HSH2004G@SSOP20	[ (SA626A) ]
ZGP323HSH2008C@SSOP20	[ (SA626A) ]	ZGP323HSH2008G@SSOP20	[ (SA626A) ]
ZGP323HSH2016C@SSOP20	[ (SA626A) ]	ZGP323HSH2016G@SSOP20	[ (SA626A) ]
ZGP323HSH2032C@SSOP20	[ (SA626A) ]	ZGP323HSH2032G@SSOP20	[ (SA626A) ]
ZGP323HSH2804C@SSOP28	[ (SA626A) ]	ZGP323HSH2804G@SSOP28	[ (SA626A) ]
ZGP323HSH2808C@SSOP28	[ (SA626A) ]	ZGP323HSH2808G@SSOP28	[ (SA626A) ]
ZGP323HSH2816C@SSOP28	[ (SA626A) ]	ZGP323HSH2816G@SSOP28	[ (SA626A) ]
ZGP323HSH2832C@SSOP28	[ (SA626A) ]	ZGP323HSH2832G@SSOP28	[ (SA626A) ]
ZGP323HSH4804C@SSOP48	[ (SA669) ]	ZGP323HSH4804G@SSOP48	[ (SA669) ]
ZGP323HSH4808C@SSOP48	[ (SA669) ]	ZGP323HSH4808G@SSOP48	[ (SA669) ]
ZGP323HSH4816C@SSOP48	[ (SA669) ]	ZGP323HSH4816G@SSOP48	[ (SA669) ]
ZGP323HSH4832C@SSOP48	[ (SA669) ]	ZGP323HSH4832G@SSOP48	[ (SA669) ]
ZGP323HSP2004C		ZGP323HSP2004G	
ZGP323HSP2008C		ZGP323HSP2008G	
ZGP323HSP2016C		ZGP323HSP2016G	
ZGP323HSP2032C		ZGP323HSP2032G	
ZGP323HSP2804C		ZGP323HSP2804G	



ZGP323HSP2808C		ZGP323HSP2808G	
ZGP323HSP2816C		ZGP323HSP2816G	
ZGP323HSP2832C		ZGP323HSP2832G	
ZGP323HSP4004C		ZGP323HSP4004G	
ZGP323HSP4008C		ZGP323HSP4008G	
ZGP323HSP4016C		ZGP323HSP4016G	
ZGP323HSP4032C		ZGP323HSP4032G	
ZGP323HSS2004C@SOIC20	[(SA404)]	ZGP323HSS2004G@SOIC20	[(SA404)]
ZGP323HSS2008C@SOIC20	[(SA404)]	ZGP323HSS2008G@SOIC20	[(SA404)]
ZGP323HSS2016C@SOIC20	[(SA404)]	ZGP323HSS2016G@SOIC20	[(SA404)]
ZGP323HSS2032C@SOIC20	[(SA404)]	ZGP323HSS2032G@SOIC20	[(SA404)]
ZGP323HSS2804C@SOIC28	[(SA404)]	ZGP323HSS2804G@SOIC28	[(SA404)]
ZGP323HSS2808C@SOIC28	[(SA404)]	ZGP323HSS2808G@SOIC28	[(SA404)]
ZGP323HSS2816C@SOIC28	[(SA404)]	ZGP323HSS2816G@SOIC28	[(SA404)]
ZGP323HSS2832C@SOIC28	[(SA404)]	ZGP323HSS2832G@SOIC28	[(SA404)]
ZGP323LAH2004C@SSOP20	[(SA626A)]	ZGP323LAH2004G@SSOP20	[(SA626A)]
ZGP323LAH2008C@SSOP20	[(SA626A)]	ZGP323LAH2008G@SSOP20	[(SA626A)]
ZGP323LAH2016C@SSOP20	[(SA626A)]	ZGP323LAH2016G@SSOP20	[(SA626A)]
ZGP323LAH2032C@SSOP20	[(SA626A)]	ZGP323LAH2032G@SSOP20	[(SA626A)]
ZGP323LAH2804C@SSOP28	[(SA626A)]	ZGP323LAH2804G@SSOP28	[(SA626A)]
ZGP323LAH2808C@SSOP28	[(SA626A)]	ZGP323LAH2808G@SSOP28	[(SA626A)]
ZGP323LAH2816C@SSOP28	[(SA626A)]	ZGP323LAH2816G@SSOP28	[(SA626A)]
ZGP323LAH2832C@SSOP28	[(SA626A)]	ZGP323LAH2832G@SSOP28	[(SA626A)]
ZGP323LAH4804C@SSOP48	[(SA669)]	ZGP323LAH4804G@SSOP48	[(SA669)]
ZGP323LAH4808C@SSOP48	[(SA669)]	ZGP323LAH4808G@SSOP48	[(SA669)]
ZGP323LAH4816C@SSOP48	[(SA669)]	ZGP323LAH4816G@SSOP48	[(SA669)]
ZGP323LAH4832C@SSOP48	[(SA669)]	ZGP323LAH4832G@SSOP48	[(SA669)]
ZGP323LAP2004C		ZGP323LAP2004G	
ZGP323LAP2008C		ZGP323LAP2008G	
ZGP323LAP2016C		ZGP323LAP2016G	
ZGP323LAP2032C		ZGP323LAP2032G	
ZGP323LAP2804C		ZGP323LAP2804G	
ZGP323LAP2808C		ZGP323LAP2808G	
ZGP323LAP2816C		ZGP323LAP2816G	
ZGP323LAP2832C		ZGP323LAP2832G	
ZGP323LAP4004C		ZGP323LAP4004G	
ZGP323LAP4008C		ZGP323LAP4008G	
ZGP323LAP4016C		ZGP323LAP4016G	
ZGP323LAP4032C		ZGP323LAP4032G	
ZGP323LAS2004C@SOIC20	[(SA404)]	ZGP323LAS2004G@SOIC20	[(SA404)]
ZGP323LAS2008C@SOIC20	[(SA404)]	ZGP323LAS2008G@SOIC20	[(SA404)]
ZGP323LAS2016C@SOIC20	[(SA404)]	ZGP323LAS2016G@SOIC20	[(SA404)]
ZGP323LAS2032C@SOIC20	[(SA404)]	ZGP323LAS2032G@SOIC20	[(SA404)]
ZGP323LAS2804C@SOIC28	[(SA404)]	ZGP323LAS2804G@SOIC28	[(SA404)]
ZGP323LAS2808C@SOIC28	[(SA404)]	ZGP323LAS2808G@SOIC28	[(SA404)]
ZGP323LAS2816C@SOIC28	[(SA404)]	ZGP323LAS2816G@SOIC28	[(SA404)]
ZGP323LAS2832C@SOIC28	[(SA404)]	ZGP323LAS2832G@SOIC28	[(SA404)]
ZGP323LEH2004C@SSOP20	[(SA626A)]	ZGP323LEH2004G@SSOP20	[(SA626A)]
ZGP323LEH2008C@SSOP20	[(SA626A)]	ZGP323LEH2008G@SSOP20	[(SA626A)]
ZGP323LEH2016C@SSOP20	[(SA626A)]	ZGP323LEH2016G@SSOP20	[(SA626A)]
ZGP323LEH2032C@SSOP20	[(SA626A)]	ZGP323LEH2032G@SSOP20	[(SA626A)]
ZGP323LEH2804C@SSOP28	[(SA626A)]	ZGP323LEH2804G@SSOP28	[(SA626A)]
ZGP323LEH2808C@SSOP28	[(SA626A)]	ZGP323LEH2808G@SSOP28	[(SA626A)]
ZGP323LEH2816C@SSOP28	[(SA626A)]	ZGP323LEH2816G@SSOP28	[(SA626A)]
ZGP323LEH2832C@SSOP28	[(SA626A)]	ZGP323LEH2832G@SSOP28	[(SA626A)]
ZGP323LEH4804C@SSOP48	[(SA669)]	ZGP323LEH4804G@SSOP48	[(SA669)]
ZGP323LEH4808C@SSOP48	[(SA669)]	ZGP323LEH4808G@SSOP48	[(SA669)]
ZGP323LEH4816C@SSOP48	[(SA669)]	ZGP323LEH4816G@SSOP48	[(SA669)]
ZGP323LEH4832C@SSOP48	[(SA669)]	ZGP323LEH4832G@SSOP48	[(SA669)]
ZGP323LEP2004C		ZGP323LEP2004G	
ZGP323LEP2008C		ZGP323LEP2008G	
ZGP323LEP2016C		ZGP323LEP2016G	
ZGP323LEP2032C		ZGP323LEP2032G	
ZGP323LEP2804C		ZGP323LEP2804G	
ZGP323LEP2808C		ZGP323LEP2808G	
ZGP323LEP2816C		ZGP323LEP2816G	
ZGP323LEP2832C		ZGP323LEP2832G	
ZGP323LEP4004C		ZGP323LEP4004G	
ZGP323LEP4008C		ZGP323LEP4008G	
ZGP323LEP4016C		ZGP323LEP4016G	
ZGP323LEP4032C		ZGP323LEP4032G	
ZGP323LES2004C@SOIC20	[(SA404)]	ZGP323LES2004G@SOIC20	[(SA404)]
ZGP323LES2008C@SOIC20	[(SA404)]	ZGP323LES2008G@SOIC20	[(SA404)]
ZGP323LES2016C@SOIC20	[(SA404)]	ZGP323LES2016G@SOIC20	[(SA404)]
ZGP323LES2032C@SOIC20	[(SA404)]	ZGP323LES2032G@SOIC20	[(SA404)]
ZGP323LES2804C@SOIC28	[(SA404)]	ZGP323LES2804G@SOIC28	[(SA404)]
ZGP323LES2808C@SOIC28	[(SA404)]	ZGP323LES2808G@SOIC28	[(SA404)]
ZGP323LES2816C@SOIC28	[(SA404)]	ZGP323LES2816G@SOIC28	[(SA404)]
ZGP323LES2832C@SOIC28	[(SA404)]	ZGP323LES2832G@SOIC28	[(SA404)]
ZGP323LSH2004C@SSOP20	[(SA626A)]	ZGP323LSH2004G@SSOP20	[(SA626A)]
ZGP323LSH2008C@SSOP20	[(SA626A)]	ZGP323LSH2008G@SSOP20	[(SA626A)]

ZGP323LSH2016C@SSOP20	[ (SA626A) ]	ZGP323LSH2016G@SSOP20	[ (SA626A) ]
ZGP323LSH2032C@SSOP20	[ (SA626A) ]	ZGP323LSH2032G@SSOP20	[ (SA626A) ]
ZGP323LSH2804C@SSOP28	[ (SA626A) ]	ZGP323LSH2804G@SSOP28	[ (SA626A) ]
ZGP323LSH2808C@SSOP28	[ (SA626A) ]	ZGP323LSH2808G@SSOP28	[ (SA626A) ]
ZGP323LSH2816C@SSOP28	[ (SA626A) ]	ZGP323LSH2816G@SSOP28	[ (SA626A) ]
ZGP323LSH2832C@SSOP28	[ (SA626A) ]	ZGP323LSH2832G@SSOP28	[ (SA626A) ]
ZGP323LSH4804C@SSOP48	[ (SA669) ]	ZGP323LSH4804G@SSOP48	[ (SA669) ]
ZGP323LSH4808C@SSOP48	[ (SA669) ]	ZGP323LSH4808G@SSOP48	[ (SA669) ]
ZGP323LSH4816C@SSOP48	[ (SA669) ]	ZGP323LSH4816G@SSOP48	[ (SA669) ]
ZGP323LSH4832C@SSOP48	[ (SA669) ]	ZGP323LSH4832G@SSOP48	[ (SA669) ]
ZGP323LSK2032E		ZGP323LSK2032G	
ZGP323LSK2832E		ZGP323LSK2832G	
ZGP323LSK4032E		ZGP323LSK4032G	
ZGP323LSP2004C		ZGP323LSP2004G	
ZGP323LSP2008C		ZGP323LSP2008G	
ZGP323LSP2016C		ZGP323LSP2016G	
ZGP323LSP2032C		ZGP323LSP2032G	
ZGP323LSP2804C		ZGP323LSP2804G	
ZGP323LSP2808C		ZGP323LSP2808G	
ZGP323LSP2816C		ZGP323LSP2816G	
ZGP323LSP2832C		ZGP323LSP2832G	
ZGP323LSP4004C		ZGP323LSP4004G	
ZGP323LSP4008C		ZGP323LSP4008G	
ZGP323LSP4016C		ZGP323LSP4016G	
ZGP323LSP4032C		ZGP323LSP4032G	
ZGP323LSS2004C@SOIC20	[ (SA404) ]	ZGP323LSS2004G@SOIC20	[ (SA404) ]
ZGP323LSS2008C@SOIC20	[ (SA404) ]	ZGP323LSS2008G@SOIC20	[ (SA404) ]
ZGP323LSS2016C@SOIC20	[ (SA404) ]	ZGP323LSS2016G@SOIC20	[ (SA404) ]
ZGP323LSS2032C@SOIC20	[ (SA404) ]	ZGP323LSS2032G@SOIC20	[ (SA404) ]
ZGP323LSS2804C@SOIC28	[ (SA404) ]	ZGP323LSS2804G@SOIC28	[ (SA404) ]
ZGP323LSS2808C@SOIC28	[ (SA404) ]	ZGP323LSS2808G@SOIC28	[ (SA404) ]
ZGP323LSS2816C@SOIC28	[ (SA404) ]	ZGP323LSS2816G@SOIC28	[ (SA404) ]
ZGP323LSS2832C@SOIC28	[ (SA404) ]	ZGP323LSS2832G@SOIC28	[ (SA404) ]
ZLP12840H2028C@SSOP20	[ (SA626A) ]	ZLP12840H2028G@SSOP20	[ (SA626A) ]
ZLP12840H2032C@SSOP20	[ (SA626A) ]	ZLP12840H2032G@SSOP20	[ (SA626A) ]
ZLP12840H2064C@SSOP20	[ (SA626A) ]	ZLP12840H2064G@SSOP20	[ (SA626A) ]
ZLP12840H2096C@SSOP20	[ (SA626A) ]	ZLP12840H2096G@SSOP20	[ (SA626A) ]
ZLP12840H2828C@SSOP28	[ (SA626A) ]	ZLP12840H2828G@SSOP28	[ (SA626A) ]
ZLP12840H2832C@SSOP28	[ (SA626A) ]	ZLP12840H2832G@SSOP28	[ (SA626A) ]
ZLP12840H2864C@SSOP28	[ (SA626A) ]	ZLP12840H2864G@SSOP28	[ (SA626A) ]
ZLP12840H2896C@SSOP28	[ (SA626A) ]	ZLP12840H2896G@SSOP28	[ (SA626A) ]
ZLP12840P2028C		ZLP12840P2028G	
ZLP12840P2032C		ZLP12840P2032G	
ZLP12840P2064C		ZLP12840P2064G	
ZLP12840P2096C		ZLP12840P2096G	
ZLP12840P2828C		ZLP12840P2828G	
ZLP12840P2832C		ZLP12840P2832G	
ZLP12840P2864C		ZLP12840P2864G	
ZLP12840P2896C		ZLP12840P2896G	
ZLP12840S2028C@SOIC20	[ (SA404) ]	ZLP12840S2028G@SOIC20	[ (SA404) ]
ZLP12840S2032C@SOIC20	[ (SA404) ]	ZLP12840S2032G@SOIC20	[ (SA404) ]
ZLP12840S2064C@SOIC20	[ (SA404) ]	ZLP12840S2064G@SOIC20	[ (SA404) ]
ZLP12840S2096C@SOIC20	[ (SA404) ]	ZLP12840S2096G@SOIC20	[ (SA404) ]
ZLP12840S2828C@SOIC28	[ (SA404) ]	ZLP12840S2828G@SOIC28	[ (SA404) ]
ZLP12840S2832C@SOIC28	[ (SA404) ]	ZLP12840S2832G@SOIC28	[ (SA404) ]
ZLP12840S2864C@SOIC28	[ (SA404) ]	ZLP12840S2864G@SOIC28	[ (SA404) ]
ZLP12840S2896C@SOIC28	[ (SA404) ]	ZLP12840S2896G@SOIC28	[ (SA404) ]
ZLP32300H2004C@SSOP20	[ (SA626A) ]	ZLP32300H2004G@SSOP20	[ (SA626A) ]
ZLP32300H2008C@SSOP20	[ (SA626A) ]	ZLP32300H2008G@SSOP20	[ (SA626A) ]
ZLP32300H2016C@SSOP20	[ (SA626A) ]	ZLP32300H2016G@SSOP20	[ (SA626A) ]
ZLP32300H2032C@SSOP20	[ (SA626A) ]	ZLP32300H2032G@SSOP20	[ (SA626A) ]
ZLP32300H2804C@SSOP28	[ (SA626A) ]	ZLP32300H2804G@SSOP28	[ (SA626A) ]
ZLP32300H2808C@SSOP28	[ (SA626A) ]	ZLP32300H2808G@SSOP28	[ (SA626A) ]
ZLP32300H2816C@SSOP28	[ (SA626A) ]	ZLP32300H2816G@SSOP28	[ (SA626A) ]
ZLP32300H2832C@SSOP28	[ (SA626A) ]	ZLP32300H2832G@SSOP28	[ (SA626A) ]
ZLP32300H4804C@SSOP48	[ (SA669) ]	ZLP32300H4804G@SSOP48	[ (SA669) ]
ZLP32300H4808C@SSOP48	[ (SA669) ]	ZLP32300H4808G@SSOP48	[ (SA669) ]
ZLP32300H4816C@SSOP48	[ (SA669) ]	ZLP32300H4816G@SSOP48	[ (SA669) ]
ZLP32300H4832C@SSOP48	[ (SA669) ]	ZLP32300H4832G@SSOP48	[ (SA669) ]
ZLP32300P2004C		ZLP32300P2004G	
ZLP32300P2008C		ZLP32300P2008G	
ZLP32300P2016C		ZLP32300P2016G	
ZLP32300P2032C		ZLP32300P2032G	
ZLP32300P2804C		ZLP32300P2804G	
ZLP32300P2808C		ZLP32300P2808G	
ZLP32300P2816C		ZLP32300P2816G	
ZLP32300P2832C		ZLP32300P2832G	
ZLP32300P4004C		ZLP32300P4004G	
ZLP32300P4008C		ZLP32300P4008G	
ZLP32300P4016C		ZLP32300P4016G	
ZLP32300P4032C		ZLP32300P4032G	

ZLP32300S2004C@SOIC20 [(SA404)]	ZLP32300S2004G@SOIC20 [(SA404)]
ZLP32300S2008C@SOIC20 [(SA404)]	ZLP32300S2008G@SOIC20 [(SA404)]
ZLP32300S2016C@SOIC20 [(SA404)]	ZLP32300S2016G@SOIC20 [(SA404)]
ZLP32300S2032C@SOIC20 [(SA404)]	ZLP32300S2032G@SOIC20 [(SA404)]
ZLP32300S2804C@SOIC28 [(SA404)]	ZLP32300S2804G@SOIC28 [(SA404)]
ZLP32300S2808C@SOIC28 [(SA404)]	ZLP32300S2808G@SOIC28 [(SA404)]
ZLP32300S2816C@SOIC28 [(SA404)]	ZLP32300S2816G@SOIC28 [(SA404)]
ZLP32300S2832C@SOIC28 [(SA404)]	ZLP32300S2832G@SOIC28 [(SA404)]

## ZMD

### E (E) PROM / FRAM / NVRAM

U62256	U6264
U6264@SOIC28 [(SA630)]	U6264A
U6264A@SOIC28 [(SA630)]	U62H256A@SOIC28 [(SA630)]
U62H256S@SOIC28 [(SA630)]	U62H64SA@SOIC28 [(SA630)]
U630H16	U630H16@SOIC28 [(SA630)]
U630H64	U630H64@SOIC28 [(SA630)]
U631H16	U631H16@SOIC24 [(SA404)]
U631H16@SOIC28 [(SA630)]	U631H256
U631H256@SOIC28 [(SA630)]	U631H64
U631H64@SOIC28 [(SA630)]	U632H16
U632H16@SOIC28 [(SA630)]	U632H64
U632H64@SOIC28 [(SA630)]	U634H256
U634H256@SOIC32 [(SA630)]	U635H16
U635H16@SOIC24 [(SA404)]	U635H256
U635H256@SOIC28 [(SA630)]	U635H64
U635H64@SOIC28 [(SA630)]	U63716
U637256	U63764
U637H256	UL62H256A@SOIC28 [(SA630)]
UL631H256@SOIC28 [(SA630)]	UL631H256@TSOP32 [(SA410T)]
UL634H256@SOIC32 [(SA630)]	UL634H256@TSOP32 [(SA410T)]
UL635H256@SOIC28 [(SA630)]	UL635H256@TSOP32 [(SA410T)]