

Temperature Tester 343

Instruction Manual



Products International, Inc.

515 SW Allen Blvd., Ste. 104
Beaverton, OR USA 97005
520-9197 • Fax: 503-520-1225
info@testproductsintl.com

Products International, Ltd.

42 Bronte Road South, Unit 9
Milton, Ontario L9T5B7
Canada
693-8558 • Fax: 905-693-0888

Products International, Europe Ltd.

House, International Drive, Southgate
Weyley, West Sussex RH10 6AQ
England
3 561212 • Fax: +44 (0) 1293 813465

05 copyright © 2005 Test Products International, Inc.

rd Accessories**Part No.**

	A009
re Probe (2 each)	GK13M
Boot	A303
	A255
manual	

l Accessories**Part No.**

See Catalog

NCE

Warning: The 343 will display battery symbol when the battery needs replacement. Replace battery as follows:
 1. Disconnect and remove all temperature probes from 343.

2. Remove the 4 screws from the back of the 343.

3. Remove the back cover.

4. Remove the old battery and replace it with new battery.

5. Reassemble instrument in reverse order from above.

For 343

1. Use a mild detergent and slightly damp cloth to clean the surfaces of