

# Temperature Tester 340

## Instruction Manual



### **Products International, Inc.**

9615 SW Allen Blvd., Ste. 104  
Beaverton, OR USA 97005  
503-520-9197 • Fax: 503-520-1225  
info@tpi-thevalueleader

---

### **Products International, Ltd.**

342 Bronte Road South, Unit 9  
Milton, Ontario L9T5B7  
Canada  
905-693-8558 • Fax: 905-693-0888

---

### **Products International UK Ltd**

Longley House  
East Park  
Longley, West Sussex RH10 6AP England  
01293 561212 • Fax: 01293 813465

---

28/02 copyright © 2002 Test Products International, Inc.









## Accessories

### Part No.

	A009
Probe	GK11M
(340 only)	A303

## Accessories

### Part No.

K-type w/oven clip	GK12M
Surface	CK13M
Surface, right angle	CK14M
Chisel probe	FK14M
Gas (air) probe	GK17M
Case	A255

## NCE

**Placement:** The 340 will display battery symbol when the battery needs replacement. Replace battery as follows:

1. Disconnect and remove all temperature probes from 340.

2. Remove the 4 screws from the back of the 340.

3. Remove the back cover.

4. Remove the old battery and replace it with new battery.

5. Assemble instrument in reverse order from above.

### For 340

6. Use mild detergent and slightly damp cloth to clean the surfaces of