

Datamate Tooling

DATAMATE

POSITIONER

- Used with hand crimp tool shown opposite.



ORDER CODE

Male & female Crimp	T5747
Power Crimp	Z80-058
Male Jackscrew Crimp	Z80-193

HAND CRIMP TOOL

- Standard circular crimp tool BS5210-3A-300 and MIL specification M22520/2-01.
- Precision tool with ratchet mechanism and 8-indent form.
- Must be used with positioner opposite.
- Instruction sheet available.



ORDER CODE **M22520/2-01**

SEPARATOR TOOL

- Recommended for unplugging latched connectors (tool releases the latches prior to disengagement).
- Can also be used with unlatched and friction lock connectors.
- Suitable for all sizes.



ORDER CODE **T5746**

INSERTION/REMOVAL TOOL

- For inserting crimped socket contacts into the rear of mouldings.
- Instruction sheet available.
- Suitable for all Datamate signal contacts.



ORDER CODE **Z80-280**

www.harwin.com

