








# GENERAL INSTRUCTIONS

INSTRUCTIONS GENERALES  
ALLGEMEINE ANWEISUNGEN  
INSTRUCCIONES GENERALES  
ISTRUZIONI  
ALLMANNA INSTRUKTIONER  
ALGEMENE INSTRUCITIE  
綜合概論



**MHH ENGINEERING Co. Ltd.**

Bramley, Guildford,  
Surrey GU5 0AJ, England

 \*\* (0)1483 892772

 \*\* (0)1483 898555

[WWW.Torqueleader.com](http://WWW.Torqueleader.com)

# DIAL INDICATING TORQUE WRENCHES

CLES DYNAMOMETRIQUES A LECTURE DIRECTE





DREHMOMENTWERKZEUGE MIT ANZEIGESKALA

LLAVES DINAMOMETRICAS CON DIAL INDICADOR

VISARINDIKERANDE MOMENTNYCKLAR

MOMENTSLEUTEL MET WIJZERPLAAT

針 錶 式 扭 力 扳 手



P17020