
Access Floor Workstation Modules (AFWM)





Flush Faceplates



Product Facts

- Include faceplate and mounting hardware
- For 3-gang and 5-gang Access Floor Workstation Modules only
- 2-, 3-, and 4-port faceplates accept inserts for Modular Jack Panels and standard FLEX-MODE Electrical Faceplates

4.3

OUTLETS, FACEPLATES AND ACCESSORIES

The state of the s	F	G	+ H	
#				

Description		Figure	Part Number
2-Port	Accepts two 110Connect, SL Series or MT-RJ Outlet Jacks	Α	569916-X
3-Port	Accepts three 110Connect, SL Series or MT-RJ Outlet Jacks	В	569917-X
4-Port	Accepts four SL Series or MT-RJ Outlet Jacks	С	1116695-X
FLEX-MODE	Accepts one standard FLEX-MODE Module	E	769020-X
Blank	May also be cut or punched for custom mounting	F	557655-X
Power Receptacle Fa	aceplates		
Standard	Accepts one "double D"duplex receptacle or duplex mounting strap	G	769028-X
Decorator	Accepts one decorator-style receptacle or decorator mounting strap	Н	769016-X
Fiber Optic Faceplate	es (for MT-RJ Outlet Jacks see A, B and C above.)		
2-Port ST	Includes two Multimode ST Couplers	l I	557322-X
4-Port ST	Includes four Multimode ST Couplers	J	557474-X
Duplex SC	Accepts one Duplex SC Adapter	K	569646-X
Dual Duplex SC	Accepts two Duplex SC Adapters	L	569648-X
Inserts for Flush Face	eplates (For use with A, B and C above.)		
Blank Insert	(Available in Black -1, or Almond-2)	М	558856-X

X denotes color: -1 = Almond, -2 = Storm Gray, -4 = NEMA Gray, -5 = White

www.ampnetconnect.com