

Push Buttons & Operator Interface - XB4 22 mm Die Cast Chrome Plated Selector Switches

Non-Illuminated Selector Switches ■▲



ZB4BD4



ZB4BJ3

Shape of Head	Type of Operator	Number and Type of Positions	Catalog Number		
	Standard lever, black For colored lever add the following code to end of part number: 01 - white 03 - green 04 - red 05 - yellow 06 - blue (Example: ZB4BD204)	2 - maintained	ZB4BD2		
		2 - momentary from right to left	ZB4BD4		
		3 - maintained	ZB4BD3		
		3 - momentary to center	ZB4BD5		
		3 - momentary from left to center	ZB4BD7		
		3 - momentary from right to center	ZB4BD8		
			Extended lever, black	2 - maintained	ZB4BJ2
				2 - momentary from right to left	ZB4BJ4
3 - maintained	ZB4BJ3				
3 - momentary to center	ZB4BJ5				
3 - momentary from left to center	ZB4BJ7				
3 - momentary from right to center	ZB4BJ8				

Non-Illuminated Key Switches



ZB4BG8

Shape of Head	Type of Operator	Number and Type of Positions	Catalog Number ●
	Key (No. 455)	2 - maintained	ZB4BG2
			ZB4BG4
		2 - momentary from right to left	ZB4BG6
			3 - maintained
		ZB4BG3	
		ZB4BG5	
		ZB4BG9	
		ZB4BG09	
		3 - momentary from left to center	ZB4BG1
		3 - momentary to center	ZB4BG7
		3 - momentary from right to center	ZB4BG8
ZB4BG08			

The symbol indicates key withdrawal position(s).

- For actuation of outside contacts only.
- ▲ See selector switch sequence charts on page 56.
- Other key numbers:
 - key No. 421E: add the suffix 12 to the reference.
 - key No. 458A: add the suffix 10 to the reference.
 - key No. 520E: add the suffix 14 to the reference.
 - key No. 3131A: add the suffix 20 to the reference.

Example:

The catalog number for a head with key No. 421E for a 2 position maintained, lockable selector switch, with key withdrawal from the left-hand position, becomes: ZB4BG212.