

Selector Switches (Continued)

60° Throw Non-illuminated Lever and Knob Operated Selector Switches

Note: Will accept a maximum of 2 contact blocks (4 circuits) with supplied 3-way mounting adapter. Optional 5-way adapter will accept a maximum of 5 contact blocks (10 circuits). See Page 47-77.

Table 47-65. 60° Throw Non-illuminated Lever and Knob Operated Selector Switches — UL (NEMA) Type 3, 3R, 4, 4X, 12, 13

			Operating Mode M = Maintained S = Momentary			Cam Code	E22 Series — Plastic Operators				EM22 Series — Metal Operators	
Left 	Center 	Right 	Black Bezel		Chrome Bezel		Chrome Bezel					
			Catalog Number ①	Price U.S. \$	Catalog Number ①		Price U.S. \$	Catalog Number ①	Price U.S. \$	Catalog Number ①	Price U.S. \$	
			2-Position — 60° Throw — Black Lever									
—	M	M	2	<u>E22VBF61</u>		<u>E22VF61</u>		<u>EM22VF61</u>				
M	—	M	2	<u>E22VB561</u>		<u>E22V561</u>		<u>EM22V561</u>				
—	M	S	2	<u>E22VBE61</u>		<u>E22VE61</u>		<u>EM22VE61</u>				
M	—	S	2	<u>E22VB661</u>		<u>E22V661</u>		<u>EM22V661</u>				
			2-Position — 60° Throw — Black Knob									
—	M	M	2	<u>E22XBF61</u>		<u>E22XF61</u>		<u>EM22XF61</u>				
M	—	M	2	<u>E22XB561</u>		<u>E22X561</u>		<u>EM22X561</u>				
—	M	S	2	<u>E22XBE61</u>		<u>E22XE61</u>		<u>EM22XE61</u>				
M	—	S	2	<u>E22XB661</u>		<u>E22X661</u>		<u>EM22X661</u>				
			3-Position — 60° Throw — Black Lever									
M	M	M	1	<u>E22VBG61</u>		<u>E22VG61</u>		<u>EM22VG61</u>				
M	M	M	2	<u>E22VBH61</u>		<u>E22VH61</u>		<u>EM22VH61</u>				
S	M	M	1	<u>E22VBJ61</u>		<u>E22VJ61</u>		<u>EM22VJ61</u>				
S	M	M	2	<u>E22VBK61</u>		<u>E22VK61</u>		<u>EM22VK61</u>				
S	M	S	1	<u>E22VBL61</u>		<u>E22VL61</u>		<u>EM22VL61</u>				
S	M	S	2	<u>E22VBM61</u>		<u>E22VM61</u>		<u>EM22VM61</u>				
M	M	S	1	<u>E22VBN61</u>		<u>E22VN61</u>		<u>EM22VN61</u>				
M	M	S	2	<u>E22VP61</u>		<u>E22VP61</u>		<u>EM22VP61</u>				
			3-Position — 60° Throw — Black Knob									
M	M	M	1	<u>E22XBG61</u>		<u>E22XG61</u>		<u>EM22XG61</u>				
M	M	M	2	<u>E22XBH61</u>		<u>E22XH61</u>		<u>EM22XH61</u>				
S	M	M	1	<u>E22XBJ61</u>		<u>E22XJ61</u>		<u>EM22XJ61</u>				
S	M	M	2	<u>E22XBK61</u>		<u>E22XK61</u>		<u>EM22XK61</u>				
S	M	S	1	<u>E22XBL61</u>		<u>E22XL61</u>		<u>EM22XL61</u>				
S	M	S	2	<u>E22XBM61</u>		<u>E22XM61</u>		<u>EM22XM61</u>				
M	M	S	1	<u>E22XBN61</u>		<u>E22XN61</u>		<u>EM22XN61</u>				
M	M	S	2	<u>E22XP61</u>		<u>E22XP61</u>		<u>EM22XP61</u>				

① Listed selector switches are supplied as standard with Black levers or knobs. To select an alternate color, change the last digit (underlined) in the listed Catalog Number using Code Number from following table. Example: E22VE62 — Two-Position Selector Switch with Red Lever.

Color	Code	Color	Code	Color	Code	Color	Code	Color	Code	Color	Code	Color	Code	Color	Code
Black	1	Red	2	Green	3	Yellow	4	White	5	Blue	6	Gray	7	Orange	8

Note: For Rear of Panel Extensions, see Table 47-128 on Page 47-94.

Ordering Example — A complete Non-illuminated Selector Switch consists of the following:

