

**Accessories**



**Auxiliary Contacts**

**Table B-6. Front Mount Auxiliary Contacts for Use with XTRM Mini Control Relays**

Conventional thermal current, I <sub>th</sub> Open (A)	Rated Operational Current AC-15 I <sub>e</sub> (A)			Contact Configuration	Contact Sequence	Package Qty.	Screw Terminals	Spring Cage Terminals	Price <sup>①</sup>
	220V 230V 240V	380V 400V 415V	500V				catalogue Number	catalogue Number	
10	4	2	1.5	2NC		5	XTMCXFA02	—	
10	4	2	1.5	1NO-1NC		5	XTMCXFA11	XTMCXFAC11	
10	4	2	1.5	2NO		5	XTMCXFA20	—	
10	4	2	1.5	1NO <sub>E</sub> -1NC <sub>L</sub>		5	XTMCXFAL11 <sup>②</sup>	—	
10	4	2	1.5	4NC		5	XTMCXFA04	XTMCXFAC04	
10	4	2	1.5	1NO-3NC		5	XTMCXFA13	XTMCXFAC13	
10	4	2	1.5	2NO-2NC		5	XTMCXFA22	XTMCXFAC22	
10	4	2	1.5	3NO-1NC		5	XTMCXFA31	XTMCXFAC31	
10	4	2	1.5	4NO		5	XTMCXFA40	XTMCXFAC40	
10	4	2	1.5	1NO-1NC 1NO <sub>E</sub> -1NC <sub>L</sub>		5	XTMCXFAL22 <sup>②</sup>	XTMCXFCLC22 <sup>②</sup>	

① Orders must be placed in multiples of package quantity listed.

② 1 early-make contact (NO<sub>E</sub>), 1 late-break contact (NC<sub>L</sub>).

**B**