

Features

- 18 mm swivel mount uses a ball-and-socket joint to simplify sensor alignment
- May be used with any sensor having an 18 mm mounting thread, including Banner MINI-BEAM[®], Q25, T18, and S18 series sensors (S18 sensor shown here)
- Plastic parts are thermoplastic polyester; mounting hardware is stainless steel

Mounting

- Thread the swivel ball onto sensor and lock against either the sensor housing (e.g., Q25) or the jam nut provided with the sensor.
- Loosely mount the bracket and sensor assembly in position.
- Align the sensor and lock the swivel ball by tightening the two mounting screws.

