

 **Full Product Info**
ON THIS PAGE:

- | | |
|---|--------------------------------------|
| Product Overview | Components |
| Connection to Target System | System Configuration |


[Top](#)[Top](#)**Components**

This set package consists of two product packages shown below. These product packages are also available alone respectively. For details, refer to the information page of each product.

- [R0E521000CPE00](#) compact emulator (Includes development software tools.)



- [R0E5212BACFK00](#) converter board for PLQP0064KB-A* (Comes with connecting accessories.)
*Previous code : 64P6Q-A (64-pin 0.5mm-pitch LQFP)

[Top](#)**Connection to Target System****(1) Debugging**

●: No.1 pin

*: These products are included with the R0E5212BACFK00 package.

For more detailed connection information, refer to the followings:

- Refer to the User's Manual.
 1. Click the **"Documentation"** button in the left menu of this page.
 2. Click "R0E521000CPE00 User's Manual".
- Refer to the connection flow with option products (accessories).
 1. Click the **"Options"** button in the left menu.
 2. Choose "M16C Family", "R8C/Tiny Series" followed by a type of the group you would like to use, and click "Display results".

[Top](#)**System Configuration****PC Interfaces**

- USB interface (USB1.1, Full-Speed)
* Connectable to PC with a USB 2.0 port.

Operating Environment

- IBM PC/AT compatibles (Windows XP, Windows 2000)