

● Part Numbering

SAW Filters for RF/Local and IF · SAW Trap

(Part Number)

SA	F	EB	942M	FL0	F	00	R14
①	②	③	④	⑤	⑥	⑦	⑧

① Product ID

Product ID	
SA	SAW

② Function

Code	Function
F	Single Filter
W	Dual Filter
E	Trap

③ Structure/Size

Code	Structure/Size
EB	Package Type

④ Nominal Center Frequency

Expressed by four-digit alphanumerics. The unit is hertz (Hz). If the unit is "MHz", it is expressed by three figures plus "M". If the unit is "GHz", a decimal point is expressed by capital letter "G".

⑤ Character Design

Code	Character Design
FL0	A serial number expresses the design version.

⑥ Board

Code	Board
F	Expresses the substrate being used.

⑦ Individual Specification

Code	Individual Specification
00	—

⑧ Packaging

Code	Packaging
R00	10000 pcs./ø330mm Reel
R02	2000 pcs./ø330mm Reel
R04	4000 pcs./ø330mm Reel
R05	5000 pcs./ø330mm Reel
R11	1000 pcs./ø180mm Reel
R12	2000 pcs./ø180mm Reel
R14	4000 pcs./ø180mm Reel