



Products Applications Development Tools FAQ/Support Buy/Samples Technology

Products > Microcontrollers >

Microcontroller Development Environment

The following page content corresponds to the products formerly marketed by NEC Electronics


























[Download Software Tools](#) | [Hardware Tools Information](#)
[Go to archive tools](#)




























Currently Available Tools

[Login or create account >](#) | [Software tool download policy](#)






[Technical Details](#) [Documentation](#) [Marketing Documents](#)

To purchase a tool, please use our [online order center](#) or contact your nearest [sales representative](#).

Download Software Tools 					
	Tool Name	Version / Size	Lineup	Tool Type	Remarks
			All	All	
	Applilet for 78K0S/Kx1+	v1.70 / 12 MB	78K0S	Reference Driver Generator	
	Applilet for V850ES/Fx2	v151 / 12.2MB	V850	Reference Driver Generator	
	Applilet for V850ES/Hx2	v1.70 / 12MB	V850	Reference Driver Generator	
	Applilet for V850ES/Jx2	v1.71 / 11.7MB	V850	Reference Driver Generator	
	Applilet for V850ES/Kx2	v1.70 / 11.8MB	V850	Reference Driver Generator	
	Applilet for V850ES/Sx2	v1.51 / 13.0 MB	V850	Reference Driver Generator	
	Applilet2 for 78K0/Fx2	v2.30 / 7.58MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0/Kx2	v2.30 / 7.8MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0/Kx2 MCUs	v2.41 / 7.78 MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0/Lx2	v2.30 / 8.4MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0/Lx2 MCUs	v2.41 / 8.39 MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0/Lx3	v2.41 / 8.52MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0/Lx3 MCUs	v2.41 / 8.52 MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0R/Kx3	v2.31 / 7.81MB	78K0R	Reference Driver Generator	
	Applilet2 for 78K0R/Kx3 MCUs	v2.41 / 7.84 MB	78K0R	Reference Driver Generator	
	Applilet2 for 78K0R/Kx3 MCUs	v2.41 / 7.58 MB	78K0	Reference Driver Generator	
	Applilet2 for 78K0S/Kx1+ MCUs	v2.41 / 7.49 MB	78K0S	Reference Driver Generator	
	Applilet2 for V850ES/Fx3	v2.31 / 9.77 MB	V850	Reference Driver Generator	
	Applilet2 for V850ES/Fx3 MCUs	v2.41 / 9.10 MB	V850	Reference Driver Generator	
	Applilet2 for V850ES/Jx3	v2.30 / 8.74 MB	V850	Reference Driver Generator	Also supports Jx3-L
	Applilet2 for V850ES/Jx3 MCUs	v2.41 / 8.51 MB	V850	Reference Driver Generator	
	Applilet2 for V850ES/Sx3	v2.30 / 9.36 MB	V850	Reference Driver Generator	
	Applilet2 for V850ES/Sx3 MCUs	v2.41 / 8.73 MB	V850	Reference Driver Generator	
	AZ850	v3.10 / 5MB	V850	Performance Analyzer	

	CA78K0	w4.01 / 96.1 MB	78K0	Compiler-Assembler	Evaluation version is 32 KB code size restricted
	CA78K0	v4.0 / 106 MB	78K0	Compiler-Assembler	
	CA78K0R	w2.11 / 114 MB	78K0R	Compiler-Assembler	Evaluation version is 64 KB code size restricted
	CA78K0R	v2.11 / 95.7 MB	78K0R	Compiler-Assembler	
	CA78K0S	w2.01 / 73.4 MB	78K0S	Compiler-Assembler	Evaluation version is 32 KB code size restricted
	CA78K0S	v2.00 / 110 MB	78K0S	Compiler-Assembler	
	CA850	w3.10 / 11.8MB	V850	Compiler-Assembler	Evaluation version is 128KB code size restricted and requires PM+.
	CA850	v3.42 / 99.7 MB	V850	Compiler-Assembler	This is an update to version v3.x. Please use your product ID to unlock it.
	CubeSuite	v1.40 / 669 MB	78K0 78K0R V850	Integrated Development Environment (IDE)	Eval version is code size restricted: 78K0 = 32K, 78K0R = 64K, V850 = 128K - includes all update patches Purchase upgrade for 78K > Purchase upgrade for V850 >
	DemoKit-KA1	v1.0 / 275KB	78K0S	Sample Code	Included with DemoKit-KA1.
	DemoKit-LG2	v1.0 / 89KB	78K0	Sample Code	Included with DemoKit-LG2.
	Device Files		78K0 78K0R 78K0S 78K4 V850	Device File	
	ID78K0-LCE	v2.52a / 6.37MB	78K0	Debugger	
	ID78K0-LCE	v2.52a / 6.37MB	78K0	Debugger	Debugger for 78K0 low-cost emulator (LCE)
	ID78K0-NS	v3.00 / 6.37MB	78K0	Debugger	Debugger for 78K0 NS-type emulator
	ID78K0-QB		78K0	Debugger	Debugger for IECUBE, MINICUBE, MINCUBE2.
	ID78K0-QB-MON	v1.00 / 5.25MB	78K0	Debugger	
	ID78K0R-QB		78K0R	Debugger	Debugger for IECUBE, MINICUBE, MINCUBE2, DemoKit-KG3.
	ID78K0S-LCE	v2.52a / 6.32 MB	78K0S	Debugger	Debugger for 78K0S low-cost emulator (LCE).
	ID78K0S-QB		78K0S	Debugger	Debugger for IECUBE, MINICUBE, MINCUBE2.
	ID850	v3.10 / 15.6MB	V850	Debugger	Debugger for V850 NS-Type emulator.
	ID850-QB		V850	Debugger	Debugger for IECUBE, MINICUBE, MINCUBE2, NWC.
	ID850-QB debugger	v3.60 / 132 MB	V850	Debugger	Debugger application for use with V850 devices
	ID850NW	v3.10 / 15.4MB	V850	Debugger	Debugger for MC and Midas emulators.
	LCE-USB-IF	v1.0 / 31.8KB	78K0 78K0S V850	USB driver	USB driver for LCE
	LDG	v1.20 / 9.43MB	V850	Link Directive Generator	
	MINI2_78K0KF2	v1.0 / 55.8KB	78K0	Sample Code	Included with MINICUBE2 package. Generated base on Applet and 78K0/KF2 demo-board.

	MINI2_78K0SKB1+	v1.0 / 43.6KB	78K0S	Sample Code	Included with MINICUBE2 package. Generated base on Applilet.
	MINI2_V850ESHG2	v1.0 / 72.6KB	V850	Sample Code	Included with MINICUBE2 package. Generated base on Applilet and QB-V850ESHG2-TB.
	MINI2_V850ESJG2	v1.0 / 71.7KB	V850	Sample Code	Included with MINICUBE2 package. Generated base on Applilet and QB-V850ESJG2-TB.
	MINI2_V850ESKG2	v1.0 / 60.3KB	V850	Sample Code	Included with MINICUBE2 package. Generated base on Applilet and QB-V850ESKG2-TB.
	MST_78K0	v1.0 / 8.37MB	78K0	M-Station	Includes FPMST, MSTTERM, and ID78K0-MON
	MST_78K0S	v1.0 / 9.37MB	78K0S	M-Station	Includes FPMST, MSTTERM, and ID78K0S-MON
	MST_Driver	v1.6 / 47.4KB	78K0 78K0S V850	M-Station	USB driver for M-Station
	Parameter Files		78K0 78K0R 78K0S V850	Programmer Parameter Files	Supports PG-FP4, PG-FP5-EA, QB-MINICUBE2 and PG-FPLx
	PG-FP4-EA Firmware	v2.20 / 1.68 MB	78K0 78K0R 78K0S V850	Programmer GUI	Flash programming GUI for PG-FP4-EA
	PG-FP4-EA Firmware	v1.39 / 156 KB	78K0 78K0R 78K0S V850	Programmer Firmware	Firmware updates for PG-FP4-EA
	PG-FP4 Driver	v1.51 / 15.4KB	78K0 78K0R 78K0S V850	Programmer Driver	
	PG-FP4 Firmware		78K0 78K0R 78K0S 78K4 V850	Programmer Firmware	
	PG-FP4 GUI		78K0R 78K0S V850	Programmer GUI	
	PG-FP5-EA FPGA	v2.0 / 184 KB	78K0 78K0R 78K0S V850	Programmer Firmware	FPGA updates for PG-FP5-EA
	PG-FP5-EA GUI		78K0 78K0R 78K0S V850	Programmer GUI	This is GUI for PG-FP5-EA Flash programmer
	PG-FP5-EA GUI	v2.03 / 26.2 MB	78K0 78K0R 78K0S V850	Programmer GUI	Flash programming GUI for PG-FP5-EA
	PG-FPL		78K0 V850	Programmer GUI	For C26 process.
	PG-FPL GUI	v1.50 / 8.85 MB	78K0 78K0R 78K0S V850	Programmer GUI	Programmer for C26 process
	PG-FPL2		78K0S	Programmer GUI for 78K0S/Kx1+	
	PG-FPL3		78K0	Programmer GUI for 78K0/Kx2	
	PM+ (Multi)	v6.30 / 17.7MB	78K0 78K0R V850	PM+ (IDE)	
	QB-Programmer GUI	/ 32.3 MB	78K0 78K0R 78K0S V850	Programmer GUI	Flash programming GUI for MINICUBE2
	SK78K0S	v3.00 / 10.1MB	78K0S	Stack Estimation	
	SM+ for 78K0/Kx2	w1.01 / 16MB	78K0	System Simulator for 78K0/Kx2	Evaluation version is 32KB code size restricted
	SM+ for 78K0S/Kx1+	w1.01 / 19.5 MB	78K0S	System Simulator for 78K0S/Kx1+	Evaluation version is 32KB code size restricted.
	SM+ for V850ES/Hx2	w2.00 / 19 MB	V850	System Simulator for V850ES/Hx2	Evaluation version is 64 KB code size restricted.
	SM+ for V850ES/Sx2	v2.00 / 19.5MB	V850	System Simulator for V850ES/Sx2	
	SM850	v3.00 / 19.9MB	V850	System Simulator	Multi Install Version


















 FULL VERSION	SM850+	v2.00 / 36.1MB	V850	System Simulator	
 FULL VERSION	SP850	v4.30 / 281MB	V850	Software Package	
 FREE	STK850	v2.11 / 7.93MB	V850	Stack Estimation	
 FULL VERSION	TW850	v2.10 / 12.4MB	V850	Performance profiling/analyzing and tuning tool	
 FREE	V850ES Core Behavior Check Tools	v1.0 / 4.8 MB	V850	Special Tool	Check execution behavior of mul or mulu instructions on V850ES core


Hardware Tools Information 
--

Fatal error: Maximum execution time of 60 seconds exceeded in **D:\Program Files\Apache Software Foundation\Apache2.2\htdocs\micro\development\tools.html** on line **1274**











	Tool Name	Tool Type	Lineup	Sub-lineup
		All	All	All
	AF-EV850-FJ3	Evaluation Board	V850	V850ES/FE3 , V850ES/FF3 , V850ES/FG3 , V850ES/FJ3 , V850ES/FK3
	AF-EV850-SJ3	Evaluation Board	V850	V850ES/SG3 , V850ES/SJ3
	CEB-V850/SA1	Evaluation Board	V850	V850/SA1 , V850/SB1
	CEB-V850/SB1	Evaluation Board	V850	V850/SB1
	CEB-V850E/MA3	Evaluation Board	V850	V850E/MA3
	CSICE121A1312NO2	Target Connector / Conversion Adapter	V850	V850/SA1
	CSPACK121A1312NO2	Target Connector / Conversion Adapter	V850	V850/SA1
	CSSOCKET73A0909N01	Target Connector / Conversion Adapter	78K0	UPD78002xA , UPD78003xA
	 DemoKit-KA1	Evaluation Board	78K0S	78K0S/KA1+ , 78K0S/KB1+ , 78K0S/KY1+
	 DemoKit-KG3	Evaluation Board	78K0R	78K0R/KE3 , 78K0R/KF3 , 78K0R/KG3 , 78K0R/KH3 , 78K0R/KJ3
	 DemoKit-LF3	Evaluation Board	78K0	78K0/LC3 , 78K0/LD3 , 78K0/LE3 , 78K0/LF3
	 DemoKit-LG2	Evaluation Board	78K0	78K0/LE2 , 78K0/LF2 , 78K0/LG2
	DM-78K0R-KE3L	Starter Kits	78K0R	78K0R/KE3-L
	EV-K0-HCD	Starter Kits	78K0	UPD78F8025
	 EV0338	Evaluation Board	78K0	UPD78033x
	FA-100GC-UEU-B	Programming Adapter	V850	78K0/LG2 , 78K0/LG3-M , 78K0R/FG3 , 78K0R/KG3 , 78K0R/KG3-C , 78K0R/KG3-L , 78K0R/LG3 , UPD78035x , V850/SA1 , V850/SB1 , V850/SB2 , V850E/DG3 , V850E/IA2 , V850E/IG3 , V850ES/FG3 , V850ES/FG3-L , V850ES/HG3 , V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG1 , V850ES/SG3
	FA-100GF-3BA-A	Programming Adapter	V850	V850/SB1 , V850/SB2 , V850/SF1 , V850E/IA2 , V850E/IA4
	FA-100GF-GAS-B	Programming Adapter	V850	78K0R/KG3 , 78K0R/KG3-L , V850E/IG3 , V850ES/JG3-L
	FA-121F1-EA6-A	Programming Adapter	V850	V850/SA1
	FA-144GJ-GAE-B	Programming Adapter	V850	78K0R/KH3 , 78K0R/KJ3 , V850/SC3 , V850E/DJ3 , V850E/IA1 , V850E/SJ3-H , V850ES/FJ3 , V850ES/HJ3 , V850ES/JJ3 , V850ES/JJ3-E , V850ES/SJ3
	FA-161F1-EN4-A	Programming Adapter	V850	V850E/MA3
	FA-16GR-JJG-B	Programming Adapter	78K0S	78K0/FY2-L , 78K0/IY2 , 78K0S/KU1+ , 78K0S/KY1+
	FA-176GM-GAR-B	Programming Adapter	V850	V850E/SK3-H , V850ES/FK3
	FA-208GD-50-WML-A	Programming Adapter	V850	V850E/DL3
	FA-20MC-5A4-B	Programming Adapter	78K0	78K0/FA2-L , 78K0/IA2 , 78K0S/KA1+ , UPD78086x
	FA-30MC-5A4-A	Programming Adapter	78K0	78K0S/KB1+ , UPD78907x , UPD78908x , UPD78F073x
	FA-30MC-CAB-B	Programming Adapter	78K0	78K0/FB2-L , 78K0/IB2 , 78K0/KB1+ , 78K0/KB2 , 78K0/KB2-A , 78K0/KB2-L , 78K0R/FB3 , 78K0R/IB3 , 78K0S/KB1+ , UPD78F071x , UPD78F073x
	FA-44GC-UEU-A	Programming Adapter	78K0	78K0/FC2

	FA-48GC-UEU-A	Programming Adapter	78K0	78K0/FC2
	FA-52GB-8ET-A	Programming Adapter	78K0	78K0/KD2
	FA-56K8-9B4-B	Programming Adapter	78K0R	UPD78F8043 , UPD78F8058
	FA-64GB-8EU-A	Programming Adapter	V850	78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/LE2 , 78K0R/KE3 , UPD78003xA , UPD78988x , V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L , V850ES/HE2 , V850ES/KE1+ , V850ES/KE2
	FA-64GC-8BS-A	Programming Adapter	V850	78K0/KE1+ , 78K0/KE2 , UPD78003xA , UPD78098x , UPD78930x , UPD78931x , V850ES/IE2 , V850ES/IK1
	FA-64GK-9ET-A	Programming Adapter	V850	78K0/KE1+ , 78K0/KE2 , 78K0/LE2 , 78K0R/KE3 , UPD78003xA , UPD78930x , UPD78931x , UPD78F071x , V850ES/KE1+
	FA-64GK-UEU-A	Programming Adapter	78K0	78K0/FE2
	FA-70F3385GM-GAR-RX	Programming Adapter	V850	V850ES/FK3
	FA-70F3701GB-8EU-RX	Programming Adapter	V850	V850ES/FE2 , V850ES/FE3-L , V850ES/HE2
	FA-70F3704GK-9EU-RX	Programming Adapter	V850	V850ES/FF2 , V850ES/FF3-L , V850ES/HF2
	FA-70F3707GC-8EA-RX	Programming Adapter	V850	V850ES/FG2 , V850ES/FG3-L , V850ES/HG2
	FA-70F3712GJ-UEN-RX	Programming Adapter	V850	V850ES/FJ2 , V850ES/HJ2
	FA-70F3714GC-8BS-RX	Programming Adapter	V850	V850ES/IE2 , V850ES/IK1
	FA-70F3717GF-JBT-RX	Programming Adapter	V850	V850ES/JG2 , V850ES/SG2
	FA-70F3719GC-8EA-RX	Programming Adapter	V850	V850ES/JG2 , V850ES/JG3-L , V850ES/SG2 , V850ES/SG2-H
	FA-70F3724GJ-UEN-RX	Programming Adapter	V850	V850ES/JJ2 , V850ES/SJ2 , V850ES/SJ2-H
	FA-70F3726GB-8EU-RX	Programming Adapter	V850	V850ES/KE1+ , V850ES/KE2
	FA-70F3729GC-8BT-RX	Programming Adapter	V850	V850ES/KF2
	FA-70F3732GC-8EA-RX	Programming Adapter	V850	V850ES/KG1 , V850ES/KG2
	FA-70F3732GF-JBT-RX	Programming Adapter	V850	V850ES/KG2
	FA-70F3734GJ-UEN-RX	Programming Adapter	V850	V850ES/KJ2
	FA-70F3736GC-GAD-RX	Programming Adapter	V850	V850ES/JF3-L
	FA-73F1-CN3-A	Programming Adapter	78K0	UPD78003xA
	FA-78F0138HDGK-8A8-MX	Programming Adapter	78K0	78K0/KE1+
	FA-78F0363GB-UEU-RX	Programming Adapter	78K0	78K0/LE2
	FA-78F0363GK-UET-RX	Programming Adapter	78K0	78K0/LE2
	FA-78F0376GC-UBT-RX	Programming Adapter	78K0	78K0/LF2
	FA-78F0376GK-8EU-RX	Programming Adapter	78K0	78K0/LF2
	FA-78F0386GC-UBT-RX	Programming Adapter	78K0	78K0/LF2
	FA-78F0386GK-8EU-RX	Programming Adapter	78K0	78K0/LF2
	FA-78F0397GC-8EA-RX	Programming Adapter	78K0	78K0/LG2
	FA-78F0433GB-GAG-RX	Programming Adapter	78K0	78K0/LD3
	FA-78F0465GB-GAH-RX	Programming Adapter	78K0	78K0/LE3
	FA-78F0465GK-GAJ-RX	Programming Adapter	78K0	78K0/LE3
	FA-78F0495GC-GAD-RX	Programming Adapter	78K0	78K0/LF3
	FA-78F0495GK-GAK-RX	Programming Adapter	78K0	78K0/LF3
	FA-78F0515GA-8EU-MX	Programming Adapter	78K0	78K0/KC2
	FA-78F0527GB-UET-MX	Programming Adapter	78K0	78K0/KD2
	FA-78F0537GB-UEU-MX	Programming Adapter	78K0	78K0/KE2
	FA-78F0537GC-UBS-MX	Programming Adapter	78K0	78K0/KE2
	FA-78F0537GK-UET-MX	Programming Adapter	78K0	78K0/KE2
	FA-78F0547GC-UBT-MX	Programming Adapter	78K0	78K0/KF2
	FA-78F0547GK-8EU-MX	Programming Adapter	78K0	78K0/KF2
	FA-78F0557MA-FAA-RX	Programming Adapter	78K0	78K0/FY2-L , 78K0/IY2 , 78K0/KY2-L

	FA-78F0567MC-CAA-RX	Programming Adapter	78K0	78K0/FA2-L , 78K0/FB2-L , 78K0/IA2 , 78K0/KA2-L
	FA-78F0731MC-5A4-MX	Programming Adapter	78K0	UPD78F073x
	FA-78F0883GB-GAF-RX	Programming Adapter	78K0	78K0/FC2
	FA-78F0886GA-GAM-RX	Programming Adapter	78K0	78K0/FC2
	FA-78F0890GB-GAH-RX	Programming Adapter	78K0	78K0/FE2
	FA-78F0890GK-GAJ-RX	Programming Adapter	78K0	78K0/FE2 , 78K0/FF2
	FA-78F0893GC-GAD-RX	Programming Adapter	78K0	78K0/FF2
	FA-78F0893GK-GAK-RX	Programming Adapter	78K0	78K0/FF2
	FA-78F1146GA-HAB-RX	Programming Adapter	78K0R	78K0R/KE3
	FA-78F1146GB-GAH-RX	Programming Adapter	78K0R	78K0R/KE3
	FA-78F1146GK-GAJ-RX	Programming Adapter	78K0R	78K0R/KE3
	FA-78F1156GC-GAD-RX	Programming Adapter	78K0R	78K0R/KF3
	FA-78F1156GK-GAK-RX	Programming Adapter	78K0R	78K0R/KF3
	FA-78F1166GC-UEU-MX	Programming Adapter	78K0R	78K0R/KG3
	FA-78F1168GC-UEU-RX	Programming Adapter	78K0R	78K0R/KG3
	FA-78F1168GF-GAS-RX	Programming Adapter	78K0R	78K0R/KG3
	FA-78F1849GC-UEU-RX	Programming Adapter	78K0R	78K0R/KG3-C
	FA-78F9202MA-CAC-RX	Programming Adapter	78K0S	78K0S/KU1+
	FA-78F9212GR-JJG-MX	Programming Adapter	78K0S	78K0S/KY1+
	FA-78F9212GR-JJG-RX	Programming Adapter	78K0S	78K0S/KY1+
	FA-78F9222MC-5A4-MX	Programming Adapter	78K0S	78K0S/KA1+
	FA-78F9222MC-5A4-RX	Programming Adapter	78K0S	78K0S/KA1+
	FA-78F9234MC-5A4-MX	Programming Adapter	78K0S	78K0S/KB1+
	FA-78F9234MC-5A4-RX	Programming Adapter	78K0S	78K0S/KB1+
	FA-80GC-8BT-A	Programming Adapter	V850	78K0/KF1+ , 78K0/KF2 , 78K0/LF2 , 78K0R/KF3 , V850E/IA3 , V850ES/KF2
	FA-80GK-9EU-A	Programming Adapter	V850	78K0/KF1+ , 78K0/KF2 , 78K0/LF2 , V850ES/FF2 , V850ES/FF3 , V850ES/FF3-L , V850ES/HF2
	FA-80GK-UEU-A	Programming Adapter	78K0	78K0/FF2
	HQPACK044SA	Target Connector / Conversion Adapter	78K0S	UPD78902x , UPD78904x , UPD78980x , UPD78985xA
	HQPACK052SB	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78932x , UPD78946x , UPD78987x
	HQPACK064SA	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78007x , UPD78098x , UPD78930x , UPD78931x
	HQPACK064SB140	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78007x , UPD78930x , UPD78931x , UPD78942x , UPD78943x , UPD78944x , UPD78945x
	HQPACK064SD	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78988x
	HQPACK080SB	Target Connector / Conversion Adapter	78K0S	UPD78005x , UPD78006x , UPD78023x , UPD78070xA , UPD78940xA , UPD78941xA , UPD789479 , UPD78948x
	HQPACK080SD	Target Connector / Conversion Adapter	78K0	UPD78005x
	HQPACK100RB	Target Connector / Conversion Adapter	V850	UPD78030x , V850/SB1 , V850/SB2 , V850/SF1 , V850E/IA2
	HQPACK100SD	Target Connector / Conversion Adapter	V850	UPD78030x , UPD78034x , UPD78035x , UPD78983x , V850/SA1 , V850/SB1 , V850/SF1 , V850E/IA2
	HQPACK120SE	Target Connector / Conversion Adapter	78K0	UPD78031x , UPD78032x , UPD78033x
	HQPACK144SD	Target Connector / Conversion Adapter	V850	UPD78983x , V850/SC1 , V850/SC3 , V850E/IA1
	HSPACK30BK	Target Connector / Conversion Adapter	78K0S	UPD78905x , UPD78907x , UPD78908x , UPD78910xA , UPD78985xA


	IE-70000-CD-IF-A	Host Interface Tool	V850	UPD78002xA , UPD78003xA , UPD78003xAS , UPD78005x , UPD78007x , UPD78023x , UPD78030x , UPD78031x , UPD78032x , UPD78033x , UPD78034x , UPD78035x , UPD78086x , UPD78098x , UPD78902x , UPD78905x , UPD78906x , UPD78907x , UPD78908x , UPD78910xA , UPD78916x , UPD78917x , UPD78930x , UPD78931x , UPD78932x , UPD78940xA , UPD78941xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78946x , UPD789479 , UPD78948x , UPD78980x , UPD78983x , UPD78985xA , UPD78987x , UPD78988x , V850/SA1 , V850/SB1 , V850/SB2 , V850/SC1 , V850/SC2 , V850/SC3 , V850/SF1 , V850E/IA1 , V850E/IA2 , V850ES/SJ2
	IE-70000-MC-PS-B	Power Supply	V850	UPD78002xA , UPD78003xA , UPD78003xAS , UPD78035x , UPD78902x , UPD78904x , UPD78905x , UPD78906x , UPD78907x , UPD78908x , UPD78910xA , UPD78916x , UPD78917x , UPD78930x , UPD78931x , UPD78932x , UPD78940xA , UPD78941xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78946x , UPD789479 , UPD78948x , UPD78980x , UPD78983x , UPD78985xA , UPD78987x , UPD78988x , V850/SA1 , V850/SB1 , V850/SB2 , V850/SC1 , V850/SC2 , V850/SC3 , V850/SF1 , V850E/IA1 , V850E/IA2
	IE-70000-PC-IF-C	Host Interface Tool	V850	V850/SA1 , V850/SB1 , V850/SC3 , V850/SF1
	IE-70000-PCI-IF-A	Host Interface Tool	V850	UPD78002xA , UPD78002xAS , UPD78003xA , UPD78003xAS , UPD78005x , UPD78006x , UPD78007x , UPD78023x , UPD78030x , UPD78031x , UPD78032x , UPD78033x , UPD78034x , UPD78035x , UPD78070xA , UPD78086x , UPD78098x , UPD78902x , UPD78904x , UPD78905x , UPD78906x , UPD78907x , UPD78908x , UPD78910xA , UPD78916x , UPD78917x , UPD78930x , UPD78931x , UPD78932x , UPD78940xA , UPD78941xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78946x , UPD789479 , UPD78948x , UPD78980x , UPD78983x , UPD78985xA , UPD78987x , UPD78988x , V850/SA1 , V850/SB1 , V850/SB2 , V850/SC1 , V850/SC2 , V850/SC3 , V850/SF1 , V850E/IA1 , V850E/IA2
	IE-703002-MC	In Circuit Emulator	V850	V850/SA1 , V850/SB1 , V850/SB2 , V850/SC1 , V850/SC2 , V850/SC3 , V850/SF1
	IE-703017-MC-EM1	Emulation Board	V850	V850/SA1
	IE-703037-MC-EM1	Emulation Board	V850	V850/SB1 , V850/SB2
	IE-703079-MC-EM1	Emulation Board	V850	V850/SF1
	IE-703089-MC-EM1	Emulation Board	V850	V850/SC1 , V850/SC2 , V850/SC3
	IE-703102-MC	In Circuit Emulator	V850	V850E/IA1
	IE-703102-MC-EM1-A	Emulation Board	V850	V850E/IA1
	IE-703114-MC-EM1	Emulation Board	V850	V850E/IA2
	IE-703116-MC-EM1	Emulation Board	V850	V850E/IA1
	IE-780034-NS-EM1	Emulation Board	78K0	UPD78002xA , UPD78002xAS , UPD78003xA , UPD78003xAS
	IE-780066-NS-EM4	Emulation Board	78K0	UPD78006x
	IE-780078-NS-EM1	Emulation Board	78K0	UPD78007x
	IE-780233-NS-EM4	Emulation Board	78K0	UPD78023x
	IE-780308-NS-EM1	Emulation Board	78K0	UPD78005x , UPD78030x
	IE-780338-NS-EM1	Emulation Board	78K0	UPD78031x , UPD78032x , UPD78033x
	IE-780354-NS-EM1	Emulation Board	78K0	UPD78034x , UPD78035x
	IE-780701-NS-EM1	Emulation Board	78K0	UPD78070xA
	IE-780862-NS-EM1	Emulation Board	78K0	UPD78086x
	IE-780988-NS-EM4	Emulation Board	78K0	UPD78098x
	IE-789026-NS-EM1	Emulation Board	78K0S	UPD78902x
	IE-789046-NS-EM1	Emulation Board	78K0S	UPD78904x , UPD78907x
	IE-789088-NS-EM1	Emulation Board	78K0S	UPD78908x
	IE-789136-NS-EM1	Emulation Board	78K0S	UPD78910xA
	IE-789177-NS-EM1	Emulation Board	78K0S	UPD78916x , UPD78917x
	IE-789306-NS-EM1	Emulation Board	78K0S	UPD78930x , UPD78931x
	IE-789418-NS-EM1	Emulation Board	78K0S	UPD78940xA , UPD78941xA
	IE-789436-NS-EM1	Emulation Board	78K0S	UPD78942x , UPD78943x
	IE-789456-NS-EM1	Emulation Board	78K0S	UPD78944x , UPD78945x
	IE-789468-NS-EM1	Emulation Board	78K0S	UPD78932x , UPD78946x
	IE-789488-NS-EM1	Emulation Board	78K0S	UPD789479 , UPD78948x

	IE-789801-NS-EM1	Emulation Board	78K0S	UPD78980x
	IE-789831-NS-EM1	Emulation Board	78K0S	UPD78983x
	IE-789835-NS-EM1	Emulation Board	78K0S	UPD78983x
	IE-789850-NS-EM1	Emulation Board	78K0S	UPD78985xA
	IE-789852-NS-EM1	Emulation Board	78K0S	UPD78985xA
	IE-789860-NS-EM1	Emulation Board	78K0S	UPD78905x , UPD78906x
	IE-789871-NS-EM1	Emulation Board	78K0S	UPD78987x
	IE-789882-NS-EM1	Emulation Board	78K0S	UPD78988x
	IE-78K0-NS	In Circuit Emulator	78K0	UPD78002xA , UPD78003xA , UPD78003xAS , UPD78035x , UPD78098x
	IE-78K0-NS-A	In Circuit Emulator	78K0	UPD78002xA , UPD78002xAS , UPD78003xA , UPD78003xAS , UPD78005x , UPD78006x , UPD78007x , UPD78023x , UPD78030x , UPD78031x , UPD78032x , UPD78033x , UPD78034x , UPD78035x , UPD78070xAAY , UPD78086x , UPD78098x
	IE-78K0-NS-P01	Emulation Board	78K0	UPD78006x , UPD78023x , UPD78098x
	IE-78K0-NS-P04	Emulation Board	78K0	UPD78098x
	IE-78K0S-NS	In Circuit Emulator	78K0S	UPD78098x , UPD78916x , UPD78917x
	IE-78K0S-NS-A	In Circuit Emulator	78K0S	UPD78902x , UPD78904x , UPD78905x , UPD78906x , UPD78907x , UPD78908x , UPD78910xA , UPD78916x , UPD78917x , UPD78930x , UPD78931x , UPD78932x , UPD78940xA , UPD78941xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78946x , UPD78947x , UPD78948x , UPD78980x , UPD78983x , UPD78985xA , UPD78987x , UPD78988x
	IE-V850E-MC	In Circuit Emulator	V850	V850E/IA1 , V850E/IA2
	IE-V850E1-CD-NW	On Chip Debugging Emulator	V850	V850E/MA3 , V850ES/SG2 , V850ES/SJ2
	IE-V850ES-G1	In Circuit Emulator	V850	V850ES/SJ2
	LCE-780034-EM	Emulation Board	78K0	UPD78002xA , UPD78003xA
	LCE-780308-EM	Emulation Board	78K0	UPD78030x
	LCE-780338-EM	Emulation Board	78K0	UPD78033x
	LCE-789316-EM	Emulation Board	78K0S	UPD78930x , UPD78931x
	LCE-78K0	In Circuit Emulator	78K0	UPD78002xA , UPD78003xA , UPD78030x , UPD78033x
	LCE-78K0S	In Circuit Emulator	78K0S	UPD78930x , UPD78931x
	LCE-USB-IF	Host Interface Tool	78K0S	UPD78002xA , UPD78003xA , UPD78005x , UPD78030x , UPD78033x , UPD78930x , UPD78931x
	LSPACK73A0909N01	Target Connector / Conversion Adapter	78K0	UPD78002xA , UPD78003xA
	M-78F0148H	Evaluation Board	78K0	78K0/KD1+ , 78K0/KE1+ , 78K0/KF1+
	M-78F0354	Evaluation Board	78K0	UPD78035x
	M-78F0537	Evaluation Board	78K0	78K0/KD2 , 78K0/KE2 , 78K0/KF2
	M-Station	Evaluation Board	78K0	78K0/KD1+ , 78K0/KD2 , 78K0/KE1+ , 78K0/KE2 , 78K0/KF1+ , 78K0/KF2 , UPD78033x , UPD78035x
	NEX-100SD/RB	Target Connector / Conversion Adapter	V850	V850/SB1 , V850/SB2
	NEXB-100SD/RB	Target Connector / Conversion Adapter	V850	V850/SB1 , V850/SB2
	NEXB-2R100SD/RB	Target Connector / Conversion Adapter	V850	V850/SB1 , V850/SF1 , V850E/IA2
	NP-100GC	Emulation Probe	78K0S	UPD78030x , UPD78034x , UPD78035x , UPD78983x
	NP-100GF	Emulation Probe	78K0	UPD78030x
	NP-100GF-TQ	Emulation Probe	78K0	UPD78030x
	NP-20GS	Emulation Probe	78K0S	UPD78906x
	NP-30MC	Emulation Probe	78K0S	UPD78905x , UPD78907x , UPD78908x , UPD78910xA , UPD78985xA
	NP-44GB-TQ	Emulation Probe	78K0S	UPD78902x , UPD78904x , UPD78916x , UPD78917x , UPD78980x , UPD78985xA
	NP-64CW	Emulation Probe	78K0	UPD78098x
	NP-64GB-TQ	Emulation Probe	78K0S	UPD78002xA , UPD78003xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78988x

	NP-64GC	Emulation Probe	78K0	UPD78003xA
	NP-64GC-TQ	Emulation Probe	78K0S	UPD78002xA , UPD78003xA , UPD78007x , UPD78098x , UPD78930x , UPD78931x
	NP-64GK	Emulation Probe	78K0S	UPD78002xA , UPD78003xA , UPD78007x , UPD78930x , UPD78931x , UPD78942x , UPD78943x , UPD78944x , UPD78945x
	NP-73F1-CN3	Emulation Probe	78K0	UPD78002xA , UPD78003xA
	NP-80GC-TQ	Emulation Probe	78K0S	UPD78005x , UPD78006x , UPD78023x , UPD78070xAAY , UPD78940xA , UPD78941xA , UPD789479 , UPD78948x
	NP-80GK	Emulation Probe	78K0S	UPD78005x , UPD78940xA , UPD78941xA , UPD789479 , UPD78948x
	NP-CON20MC	Emulation Probe	78K0S	UPD78905x
	NP-H100GC-TQ	Emulation Probe	78K0S	UPD78030x , UPD78034x , UPD78035x , UPD78983x
	NP-H100GF-TQ	Emulation Probe	78K0	UPD78030x
	NP-H44GB-TQ	Emulation Probe	78K0S	UPD78902x , UPD78916x , UPD78917x , UPD78980x
	NP-H52GB-TQ	Emulation Probe	78K0S	UPD78002xAS , UPD78003xAS , UPD78932x , UPD78946x , UPD78987x
	NP-H64GB-TQ	Emulation Probe	78K0S	UPD78002xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78988x
	NP-H64GC-TQ	Emulation Probe	78K0S	UPD78002xA , UPD78007x , UPD78098x , UPD78930x , UPD78931x
	NP-H64GK-TQ	Emulation Probe	78K0S	UPD78002xA , UPD78007x , UPD78931x , UPD78942x , UPD78943x , UPD78944x
	NP-H80GC-TQ	Emulation Probe	78K0S	UPD78005x , UPD78006x , UPD78023x , UPD78940xA , UPD78941xA , UPD789479
	NP-H80GK-TQ	Emulation Probe	78K0S	UPD78005x , UPD78940xA , UPD78941xA , UPD78945x
	NQPACK044SA	Target Connector / Conversion Adapter	78K0S	UPD78902x , UPD78904x , UPD78980x , UPD78985xA
	NQPACK052SB	Target Connector / Conversion Adapter	78K0S	UPD78002xAS , UPD78003xAS , UPD78932x , UPD78946x , UPD78987x
	NQPACK064SA	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78007x , UPD78098x , UPD78930x , UPD78931x
	NQPACK064SB	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78007x , UPD78930x , UPD78931x , UPD78942x , UPD78943x , UPD78944x , UPD78945x
	NQPACK064SD	Target Connector / Conversion Adapter	78K0S	UPD78002xA , UPD78003xA , UPD78942x , UPD78943x , UPD78944x , UPD78945x , UPD78988x
	NQPACK080SB	Target Connector / Conversion Adapter	78K0S	UPD78005x , UPD78006x , UPD78023x , UPD78070xAAY , UPD78940xA , UPD78941xA , UPD789479 , UPD78948x
	NQPACK100RB	Target Connector / Conversion Adapter	V850	UPD78030x , V850/SB1 , V850/SB2 , V850/SF1 , V850E/IA2
	NQPACK100SD	Target Connector / Conversion Adapter	V850	UPD78030x , UPD78034x , UPD78035x , UPD78983x , V850/SA1 , V850/SB1 , V850/SF1 , V850E/IA2
	NQPACK120SE	Target Connector / Conversion Adapter	78K0	UPD78031x , UPD78032x , UPD78033x
	NQPACK144SD	Target Connector / Conversion Adapter	V850	UPD78983x , V850/SC1 , V850/SC3 , V850E/IA1
	NSPACK20BK	Target Connector / Conversion Adapter	78K0S	UPD78086x , UPD78905x
	NSPACK30BK	Target Connector / Conversion Adapter	78K0S	UPD78907x , UPD78908x , UPD78910xA , UPD78985xA
	PG-FP5-EA	Flash Memory Programmer	V850	78K0/DE2 , 78K0/DF2 , 78K0/FA2-L , 78K0/FB2-L , 78K0/KA2-L , 78K0/KB2 , 78K0/KB2-L , 78K0/KC2-C , 78K0/KC2-L , 78K0/KE2-C , 78K0/KY2-L , 78K0/LC3 , 78K0/LD3 , 78K0/LE3 , 78K0/LE3-M , 78K0/LF3 , 78K0/LG3-M , 78K0R/FB3 , 78K0R/FC3 , 78K0R/FE3 , 78K0R/FF3 , 78K0R/FG3 , 78K0R/LF3 , 78K0R/LG3 , 78K0R/LH3 , 78K0S/KA1+ , 78K0S/KB1+ , 78K0S/KU1+ , 78K0S/KY1+ , UPD78F071x , UPD78F073x , UPD78F8025 , V850ES/FE3 , V850ES/FE3-L , V850ES/FF3 , V850ES/FF3-L , V850ES/FG3 , V850ES/FG3-L , V850ES/FJ3 , V850ES/FK3 , V850ES/JH3-E , V850ES/JJ3-E
	QB-100-CA-01S	Check Pin Adapter	V850	V850E/IA4 , V850E/IG3 , V850E/RG3 , V850ES/FG2 , V850ES/FG3 , V850ES/FG3-L , V850ES/HG2 , V850ES/HG3 , V850ES/JG2 , V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG1 , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H , V850ES/SG3
	QB-100-SA-01S	Space Adapter	V850	V850E/IA4 , V850E/IG3 , V850ES/FG2 , V850ES/FG3 , V850ES/FG3-L , V850ES/HG2 , V850ES/HG3 , V850ES/JG2 , V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG1 , V850ES/SG2 , V850ES/SG2-H , V850ES/SG3 , V850E/IG3 , V850E/RG3 , V850ES/FG2 , V850ES/JG2 , V850ES/JG3-H , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H , V850ES/SG3 , V850ES/SJ3

🔗	QB-100FA-NQ-01T	Target Connector / Conversion Adapter	RL78	RL78/G13
🔗	QB-100FA-YQ-01T	Target Connector / Conversion Adapter	RL78	RL78/G13
🔗	QB-100FB-NQ-01T	Target Connector / Conversion Adapter	RL78	RL78/G13
🔗	QB-100FB-YQ-01T	Target Connector / Conversion Adapter	RL78	RL78/G13
🔗	QB-100GC-EA-01S	Exchange Adapter	V850	V850ES/FG2 , V850ES/FG3 , V850ES/FG3-L , V850ES/HG2 , V850ES/HG3 , V850ES/JG2 , V850ES/JG3-L(USB) , V850ES/KG1 , V850ES/KG2 , V850ES/SG2 , V850ES/SG3 , V850E/RG3 , V850ES/FG2 , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/KG1 , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H
🔗	QB-100GC-EA-01T	Exchange Adapter	V850	78K0R/KG3 , V850ES/JG3-L(USB) , V850ES/KG2
🔗	QB-100GC-EA-02S	Exchange Adapter	V850	V850E/IA4 , V850E/IG3
🔗	QB-100GC-EA-03T	Exchange Adapter	78K0	78K0/LG2
🔗	QB-100GC-EA-04T	Exchange Adapter	V850	V850E/DG3
🔗	QB-100GC-EA-05S	Exchange Adapter	V850	V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-U
🔗	QB-100GC-EA-07T	Exchange Adapter	78K0R	78K0R/KG3-C , 78K0R/KG3-L
🔗	QB-100GC-EA-08T	Exchange Adapter	78K0R	78K0R/LG3
🔗	QB-100GC-EA-09T	Exchange Adapter	78K0R	78K0R/FG3
🔗	QB-100GC-HQ-01T	Mount Adapter	V850	78K0/LG2 , 78K0/LG3-M , 78K0R/FG3 , 78K0R/KG3 , 78K0R/KG3-C , 78K0R/KG3-L , 78K0R/LG3 , V850E/DG3 , V850E/IA4 , V850E/IG3 , V850ES/FG2 , V850ES/FG3 , V850ES/FG3-L , V850ES/HG2 , V850ES/HG3 , V850ES/JG2 , V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG1 , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H , V850ES/SG3
🔗	QB-100GC-MA-01S	Mount Adapter	V850	V850E/IG3 , V850E/RG3 , V850ES/FG2 , V850ES/JG2 , V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG1 , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H
🔗	QB-100GC-NQ-01T	Target Connector / Conversion Adapter	V850	78K0/LG2 , 78K0/LG3-M , 78K0R/FG3 , 78K0R/KG3 , 78K0R/KG3-C , 78K0R/KG3-L , 78K0R/LG3 , 78K0R/LG3-M , V850E/DG3 , V850ES/JG3-L(USB) , V850ES/KG2
🔗	QB-100GC-TC-01S	Target Connector / Conversion Adapter	V850	V850E/IG3 , V850ES/FG2 , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H
🔗	QB-100GC-YQ-01T	Target Connector / Conversion Adapter	V850	78K0/LG2 , 78K0/LG3-M , 78K0R/FG3 , 78K0R/KG3 , 78K0R/KG3-C , 78K0R/KG3-L , 78K0R/LG3 , V850E/DG3 , V850ES/JG3-H , V850ES/JG3-U , V850ES/KG2
🔗	QB-100GC-YS-01T	Space Adapter	V850	78K0/LG2 , 78K0/LG3-M , 78K0R/FG3 , 78K0R/KG3 , 78K0R/KG3-C , 78K0R/KG3-L , 78K0R/LG3 , V850E/IA4 , V850E/IG3 , V850ES/FG2 , V850ES/FG3 , V850ES/FG3-L , V850ES/HG2 , V850ES/HG3 , V850ES/JG2 , V850ES/JG3 , V850ES/JG3-H , V850ES/JG3-L , V850ES/JG3-L(USB) , V850ES/JG3-U , V850ES/KG1 , V850ES/KG2 , V850ES/SG2 , V850ES/SG2-H , V850ES/SG3
🔗	QB-100GF-EA-01S	Exchange Adapter	V850	V850ES/JG2 , V850ES/JG3-L , V850ES/SG2 , V850ES/KG2 , V850ES/SG2
🔗	QB-100GF-EA-02S	Exchange Adapter	V850	V850E/IA4
🔗	QB-100GF-EA-04T	Exchange Adapter	78K0R	78K0R/KG3
🔗	QB-100GF-EA-05T	Exchange Adapter	78K0R	78K0R/KG3-L
🔗	QB-100GF-HQ-01T	Mount Adapter	V850	V850E/IA4 , V850ES/JG2 , V850ES/JG3-L , V850ES/KG2 , V850ES/SG2
🔗	QB-100GF-HQ-02T	Mount Adapter	V850	V850E/IA4
🔗	QB-100GF-HQ-03T	Mount Adapter	V850	78K0R/KG3 , 78K0R/KG3-L , V850E/IG3
🔗	QB-100GF-MA-01S	Mount Adapter	V850	V850ES/JG3-L , V850ES/KG2 , V850ES/SG2 , V850ES/JG2 , V850ES/KG2 , V850ES/SG2
🔗	QB-100GF-MA-02S	Mount Adapter	V850	V850E/IA4
🔗	QB-100GF-MA-03S	Mount Adapter	V850	V850E/IG3
🔗	QB-100GF-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0R/KG3 , 78K0R/KG3-L
🔗	QB-100GF-TC-01S	Target Connector / Conversion Adapter	V850	V850E/IA4 , V850E/IG3 , V850ES/JG2 , V850ES/JG3-L , V850ES/KG2 , V850ES/SG2
🔗	QB-100GF-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0R/KG3 , 78K0R/KG3-L
🔗	QB-100GF-YS-01T	Space Adapter	V850	78K0R/KG3 , 78K0R/KG3-L , V850E/IA4 , V850E/IG3 , V850ES/JG2 , V850ES/JG3-L , V850ES/KG2 , V850ES/SG2

	QB-10MA-EA-01T	Exchange Adapter	78K0S	78K0S/KU1+
	QB-10MA-NQ-01T	Target Connector / Conversion Adapter	78K0S	78K0S/KU1+
	QB-128FB-NQ-01T	Target Connector / Conversion Adapter	RL78	RL78/G13
	QB-128FB-YQ-01T	Target Connector / Conversion Adapter	RL78	RL78/G13
	QB-128GF-EA-01S	Exchange Adapter	V850	V850ES/JH3-H, V850ES/JH3-U
	QB-128GF-EA-01T	Exchange Adapter	78K0R	78K0R/LH3
	QB-128GF-EA-02S	Exchange Adapter	V850	V850ES/JH3-E
	QB-128GF-HQ-01T	Mount Adapter	V850	78K0R/KH3, 78K0R/LH3, V850ES/JH3-E, V850ES/JH3-H, V850ES/JH3-U
	QB-128GF-NQ-01T	Target Connector / Conversion Adapter	RL78	78K0R/LH3, RL78/G13
	QB-128GF-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/JH3-E, V850ES/JH3-H, V850ES/JH3-U
	QB-128GF-YS-01T	Space Adapter	V850	78K0R/KH3, 78K0R/LH3, V850ES/JH3-E, V850ES/JH3-H, V850ES/JH3-U
	QB-144-CA-01	Check Pin Adapter	V850	78K0/DE2, 78K0/DF2, 78K0/FA2-L, 78K0/FB2-L, 78K0/FC2, 78K0/FE2, 78K0/FF2, 78K0/FY2-L, 78K0/IA2, 78K0/IB2, 78K0/IY2, 78K0/KA2-L, 78K0/KB2, 78K0/KB2-A, 78K0/KB2-L, 78K0/KC2, 78K0/KC2-A, 78K0/KC2-C, 78K0/KC2-L, 78K0/KD1+, 78K0/KD2, 78K0/KE1+, 78K0/KE2, 78K0/KE2-C, 78K0/KF1+, 78K0/KF2, 78K0/KY2-L, 78K0/LC3, 78K0/LD3, 78K0/LE2, 78K0/LE3, 78K0/LE3-M, 78K0/LF2, 78K0/LF3, 78K0/LG2, 78K0/LG3-M, 78K0R/FB3, 78K0R/FC3, 78K0R/FE3, 78K0R/FF3, 78K0R/FG3, 78K0R/IB3, 78K0R/IC3, 78K0R/ID3, 78K0R/IE3, 78K0R/KC3-L, 78K0R/KC3-L(USB), 78K0R/KD3-L, 78K0R/KE3, 78K0R/KE3-L, 78K0R/KE3-L(USB), 78K0R/KF3, 78K0R/KF3-C, 78K0R/KF3-L, 78K0R/KG3, 78K0R/KG3-C, 78K0R/KG3-L, 78K0R/KH3, 78K0R/KJ3, 78K0R/LF3, 78K0R/LG3, 78K0R/LG3-M, 78K0R/LH3, 78K0S/KA1+, 78K0S/KB1+, 78K0S/KU1+, 78K0S/KY1+, RL78/G12, RL78/G13, UPD78F071x, UPD78F073x, UPD78F8025, UPD78F8043, V850E/IA3, V850E/IA4, V850E/IF3, V850E/IG3, V850E/SJ3-H, V850ES/FE2, V850ES/FE3, V850ES/FE3-L, V850ES/FF3, V850ES/FG2, V850ES/FG3, V850ES/FG3-L, V850ES/FJ2, V850ES/FJ3, V850ES/HE2, V850ES/HE3, V850ES/HF2, V850ES/HF3, V850ES/HG2, V850ES/HG3, V850ES/HJ2, V850ES/HJ3, V850ES/IK1, V850ES/JC3-H, V850ES/JC3-L, V850ES/JE3-E, V850ES/JE3-H, V850ES/JE3-L, V850ES/JF3-E, V850ES/JF3-L, V850ES/JG2, V850ES/JG3, V850ES/JG3-E, V850ES/JG3-H, V850ES/JG3-L, V850ES/JG3-L(USB), V850ES/JG3-U, V850ES/JH3-E, V850ES/JH3-H, V850ES/JH3-U, V850ES/JJ2, V850ES/JJ3, V850ES/JJ3-E, V850ES/KE2, V850ES/KF2, V850ES/KG1, V850ES/KG2, V850ES/KJ2, V850ES/SG2, V850ES/SG2-H, V850ES/SJ2, V850ES/SJ2-H, V850ES/SJ3
	QB-144-CA-01S	Check Pin Adapter	V850	V850E/MA3, V850E/RG3, V850E/SJ3-H, V850ES/FJ2, V850ES/FJ3, V850ES/HJ2, V850ES/HJ3, V850ES/IE2, V850ES/JG3-L(USB), V850ES/JJ2, V850ES/JJ3, V850ES/JJ3-E, V850ES/KJ2, V850ES/SG3, V850ES/SJ2, V850ES/SJ2-H, V850ES/SJ3
	QB-144-EP-01S	Emulation Probe	V850	V850ES/JG3-L(USB)
	QB-144-EP-02S	Emulation Probe	V850	78K0/LE2, 78K0/LF2, 78K0/LG2, 78K0R/FG3, 78K0R/KE3, 78K0R/KF3, 78K0R/KF3-C, 78K0R/KF3-L, 78K0R/KG3, 78K0R/KG3-C, 78K0R/KG3-L, 78K0R/KH3, 78K0R/KJ3, 78K0R/LF3, 78K0R/LG3, 78K0R/LG3-M, 78K0R/LH3, RL78/G12, RL78/G13, UPD78F8043, V850E/IA3, V850E/IA4, V850E/IF3, V850E/IG3, V850E/MA3, V850E/SJ3-H, V850ES/FE2, V850ES/FE3, V850ES/FE3-L, V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/FG2, V850ES/FG3, V850ES/FG3-L, V850ES/FJ2, V850ES/FJ3, V850ES/FK3, V850ES/HE2, V850ES/HE3, V850ES/HF2, V850ES/HF3, V850ES/HG2, V850ES/HG3, V850ES/HJ2, V850ES/HJ3, V850ES/IE2, V850ES/IK1, V850ES/JC3-H, V850ES/JC3-L, V850ES/JE3-E, V850ES/JE3-H, V850ES/JE3-L, V850ES/JF3-E, V850ES/JF3-L, V850ES/JG2, V850ES/JG3, V850ES/JG3-E, V850ES/JG3-H, V850ES/JG3-L, V850ES/JG3-L(USB), V850ES/JG3-U, V850ES/JH3-E, V850ES/JH3-H, V850ES/JH3-U, V850ES/JJ2, V850ES/JJ3, V850ES/JJ3-E, V850ES/KE1+, V850ES/KE2, V850ES/KF2, V850ES/KG1, V850ES/KG2, V850ES/KJ2, V850ES/SG2, V850ES/SG2-H, V850ES/SG3, V850ES/SJ2, V850ES/SJ2-H, V850ES/SJ3
	QB-144-SA-01S	Space Adapter	V850	V850E/MA3, V850E/SJ3-H, V850ES/FF3-L, V850ES/FJ3, V850ES/HJ2, V850ES/HJ3, V850ES/JH3-E, V850ES/JH3-H, V850ES/JH3-U, V850ES/JJ2, V850ES/JJ3, V850ES/JJ3-E, V850ES/SJ2, V850ES/SJ2-H, V850ES/SJ3, V850E/SJ3-H, V850ES/FJ2, V850ES/HJ2, V850ES/JH3-H, V850ES/JH3-U, V850ES/JJ2, V850ES/JJ3, V850ES/KJ2, V850ES/SJ2, V850ES/SJ2-H
	QB-144GC-YS-01T	Space Adapter	V850	V850E/DG3
	QB-144GJ-EA-01S	Exchange Adapter	V850	V850E/SJ3-H, V850ES/JJ2, V850ES/JJ3, V850ES/JJ3-E, V850ES/SJ2, V850ES/SJ2-H, V850ES/SJ3
	QB-144GJ-EA-01T	Exchange Adapter	V850	V850E/SJ3-H

	QB-144GJ-EA-02S	Exchange Adapter	V850	V850E/MA3
	QB-144GJ-EA-03S	Exchange Adapter	V850	V850ES/FJ3 , V850ES/HJ2 , V850ES/HJ3
	QB-144GJ-EA-04T	Exchange Adapter	V850	V850E/DJ3
	QB-144GJ-EA-05T	Exchange Adapter	78K0R	78K0R/KH3 , 78K0R/KJ3
	QB-144GJ-HQ-01T	Mount Adapter	V850	78K0R/KH3 , 78K0R/KJ3 , V850E/DJ3 , V850E/SJ3-H , V850ES/FJ2 , V850ES/FJ3 , V850ES/HJ2 , V850ES/HJ3 , V850ES/JJ2 , V850ES/JJ3 , V850ES/JJ3-E , V850ES/KJ2 , V850ES/SJ2 , V850ES/SJ2-H
	QB-144GJ-MA-01S	Mount Adapter	V850	V850E/MA3 , V850E/SJ3-H , V850ES/FJ3 , V850ES/HJ2 , V850ES/HJ3 , V850ES/JJ2 , V850ES/JJ3 , V850ES/JJ3-E , V850ES/KJ2 , V850ES/SJ2 , V850ES/SJ2-H , V850ES/SJ3
	QB-144GJ-NQ-01S	Target Connector / Conversion Adapter	V850	V850E/SJ3-H
	QB-144GJ-NQ-01T	Target Connector / Conversion Adapter	V850	78K0R/KH3 , 78K0R/KJ3 , V850E/DJ3 , V850E/SJ3-H
	QB-144GJ-TC-01S	Target Connector / Conversion Adapter	V850	V850E/MA3 , V850E/SJ3-H , V850ES/FJ3 , V850ES/HJ2 , V850ES/HJ3 , V850ES/JJ2 , V850ES/JJ3 , V850ES/JJ3-E , V850ES/SJ2 , V850ES/SJ2-H , V850ES/SJ3
	QB-144GJ-YQ-01T	Target Connector / Conversion Adapter	V850	78K0R/KH3 , 78K0R/KJ3 , V850E/DJ3 , V850ES/JJ3-E
	QB-144GJ-YS-01T	Space Adapter	V850	78K0R/KH3 , 78K0R/KJ3 , V850E/DJ3 , V850E/SJ3-H , V850ES/FJ2 , V850ES/FJ3 , V850ES/HJ2 , V850ES/HJ3 , V850ES/JJ2 , V850ES/JJ3 , V850ES/JJ3-E , V850ES/KJ2 , V850ES/SJ2 , V850ES/SJ2-H
	QB-16GR-EA-01T	Exchange Adapter	78K0S	78K0S/KY1+
	QB-16GR-EA-02T	Exchange Adapter	78K0S	78K0/FY2-L , 78K0S/KY1+
	QB-16GR-NQ-01T	Target Connector / Conversion Adapter	78K0S	78K0/FY2-L , 78K0/IY2 , 78K0/KY2-L , 78K0S/KY1+
	QB-176-CA-01S	Check Pin Adapter	V850	V850E/SK3-H , V850ES/FK3
	QB-176-SA-01S	Space Adapter	V850	V850E/SK3-H , V850ES/FK3
	QB-176GM-EA-01S	Exchange Adapter	V850	V850ES/FK3
	QB-176GM-EA-02S	Exchange Adapter	V850	V850E/SK3-H
	QB-176GM-EA-02T	Exchange Adapter	V850	V850E/SK3-H
	QB-176GM-HQ-01T	Mount Adapter	V850	V850E/SK3-H
	QB-176GM-MA-01S	Mount Adapter	V850	V850E/SK3-H , V850ES/FK3
	QB-176GM-NQ-01T	Target Connector / Conversion Adapter	V850	V850E/SK3-H
	QB-176GM-TC-01S	Target Connector / Conversion Adapter	V850	V850E/SK3-H , V850ES/FK3
	QB-176GM-YS-01T	Space Adapter	V850	V850E/SK3-H
	QB-208GD-HQ-01T	Mount Adapter	V850	V850E/DL3
	QB-208GD-NQ-01T	Target Connector / Conversion Adapter	V850	V850E/DL3
	QB-208GD-YQ-01T	Target Connector / Conversion Adapter	V850	V850E/DL3
	QB-208GD-YS-01T	Space Adapter	V850	V850E/DL3
	QB-20MC-EA-01T	Exchange Adapter	78K0S	78K0S/KA1+
	QB-20MC-NQ-01T	Target Connector / Conversion Adapter	78K0S	78K0/FA2-L , 78K0/IA2 , 78K0/KA2-L , 78K0S/KA1+
	QB-30MC-EA-01T	Exchange Adapter	78K0	UPD78F073x
	QB-30MC-EA-02T	Exchange Adapter	78K0	78K0/KB2 , 78K0/KB2-A
	QB-30MC-EA-03T	Exchange Adapter	78K0	UPD78F071x
	QB-30MC-EA-04T	Exchange Adapter	78K0S	78K0S/KB1+
	QB-30MC-EA-05T	Exchange Adapter	78K0R	78K0R/IB3
	QB-30MC-EA-06T	Exchange Adapter	78K0R	78K0R/FB3
	QB-30MC-HQ-01T	Mount Adapter	78K0	78K0/FB2-L , 78K0/IB2 , 78K0/KB1+ , 78K0/KB2 , 78K0/KB2-A , 78K0/KB2-L , 78K0R/FB3 , 78K0R/IB3 , UPD78F071x , UPD78F073x
	QB-30MC-NQ-01T	Target Connector / Conversion Adapter	78K0	78K0/FB2-L , 78K0/IB2 , 78K0/KB2 , 78K0/KB2-A , 78K0/KB2-L , 78K0R/FB3 , 78K0R/IB3 , UPD78F071x , UPD78F073x

	QB-30MC-NQ-02T	Target Connector / Conversion Adapter	78K0S	78K0S/KB1+
	QB-30MC-YQ-01T	Target Connector / Conversion Adapter	78K0	78K0/FB2-L , 78K0/IB2 , 78K0/KB2 , 78K0/KB2-A , 78K0/KB2-L , 78K0R/FB3 , 78K0R/IB3 , UPD78F071x , UPD78F073x
	QB-30MC-YS-01T	Space Adapter	78K0	78K0/FB2-L , 78K0/IB2 , 78K0/KB1+ , 78K0/KB2 , 78K0/KB2-A , 78K0/KB2-L , 78K0R/FB3 , 78K0R/IB3 , UPD78F071x , UPD78F073x
	QB-36FC-EA-01T	Exchange Adapter	78K0	78K0/KB2
	QB-36FC-NQ-01T	Target Connector / Conversion Adapter	78K0	78K0/KB2
	QB-38MC-EA-01T	Exchange Adapter	78K0	78K0/KC2
	QB-38MC-EA-03T	Exchange Adapter	78K0R	78K0R/IC3
	QB-38MC-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/KC2 , 78K0R/IC3
	QB-40K8-EA-02S	Exchange Adapter	V850	V850ES/JC3-L
	QB-40K8-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/JC3-L
	QB-44GA-HQ-01T	Mount Adapter	78K0	78K0/KC2-L
	QB-44GA-YS-01T	Space Adapter	78K0	78K0/KC2 , 78K0/KC2-L
	QB-44GB-EA-02T	Exchange Adapter	78K0	78K0/FC2
	QB-44GB-EA-03T	Exchange Adapter	78K0	78K0/KC2
	QB-44GB-EA-04T	Exchange Adapter	78K0R	78K0R/IC3 , 78K0R/KC3-L
	QB-44GB-HQ-01T	Mount Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-L , 78K0R/IC3 , 78K0R/KC3-L
	QB-44GB-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-L , 78K0R/IC3 , 78K0R/KC3-L
	QB-44GB-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-L , 78K0R/IC3 , 78K0R/KC3-L
	QB-44GB-YS-01T	Space Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-L , 78K0R/IC3 , 78K0R/KC3-L
	QB-48-EP-01T	Emulation Probe	78K0S	78K0S/KB1+
	QB-48GA-EA-01T	Exchange Adapter	78K0	78K0/FC2
	QB-48GA-EA-02S	Exchange Adapter	V850	V850ES/JC3-L
	QB-48GA-EA-02T	Exchange Adapter	78K0	78K0/KC2 , 78K0/KC2-C
	QB-48GA-EA-03T	Exchange Adapter	78K0	78K0/LC3
	QB-48GA-EA-04T	Exchange Adapter	78K0R	78K0R/IC3 , 78K0R/KC3-L
	QB-48GA-EA-05T	Exchange Adapter	78K0R	78K0R/FC3 , 78K0R/KC3-L(USB)
	QB-48GA-HQ-01T	Mount Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-A , 78K0/KC2-C , 78K0/KC2-L , 78K0/LC3 , 78K0R/FC3 , 78K0R/IC3 , 78K0R/KC3-L , 78K0R/KC3-L(USB)
	QB-48GA-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-A , 78K0/KC2-C , 78K0/KC2-L , 78K0/LC3 , 78K0R/FC3 , 78K0R/IC3 , 78K0R/KC3-L , 78K0R/KC3-L(USB)
	QB-48GA-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/JC3-L
	QB-48GA-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-A , 78K0/KC2-C , 78K0/KC2-L , 78K0/LC3 , 78K0R/FC3 , 78K0R/IC3 , 78K0R/KC3-L , 78K0R/KC3-L(USB)
	QB-48GA-YS-01T	Space Adapter	78K0R	78K0/FC2 , 78K0/KC2 , 78K0/KC2-A , 78K0/KC2-C , 78K0/KC2-L , 78K0/LC3 , 78K0R/FC3 , 78K0R/IC3 , 78K0R/KC3-L , 78K0R/KC3-L(USB)
	QB-48K8-EA-01T	Exchange Adapter	78K0R	78K0R/FC3
	QB-48K8-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0R/FC3
	QB-50-EP-01T	Emulation Probe	78K0S	78K0S/KA1+ , 78K0S/KB1+ , 78K0S/KU1+ , 78K0S/KY1+
	QB-52GB-EA-02T	Exchange Adapter	78K0	78K0/KD2
	QB-52GB-EA-03T	Exchange Adapter	78K0	78K0/LD3
	QB-52GB-EA-04T	Exchange Adapter	78K0R	78K0R/ID3 , 78K0R/KD3-L
	QB-52GB-HQ-01T	Mount Adapter	78K0R	78K0/KD1+ , 78K0/KD2 , 78K0/LD3 , 78K0R/ID3 , 78K0R/KD3-L
	QB-52GB-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/KD1+ , 78K0/KD2 , 78K0/LD3 , 78K0R/ID3 , 78K0R/KD3-L
	QB-52GB-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/KD2 , 78K0/LD3 , 78K0R/ID3 , 78K0R/KD3-L
	QB-52GB-YS-01T	Space Adapter	78K0R	78K0/KD1+ , 78K0/KD2 , 78K0/LD3 , 78K0R/ID3 , 78K0R/KD3-L

	QB-56K8-NQ-01T	Target Connector / Conversion Adapter	78K0R	UPD78F8043
	QB-64-CA-01S	Check Pin Adapter	V850	V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L , V850ES/HE2 , V850ES/HE3 , V850ES/IE2 , V850ES/IK1 , V850ES/KE1+ , V850ES/KE2
	QB-64-EA-01S	Exchange Adapter	V850	V850ES/HE2 , V850ES/HE3 , V850ES/KE1+ , V850ES/KE2
	QB-64-SA-01S	Space Adapter	V850	V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L , V850ES/HE2 , V850ES/HE3 , V850ES/IE2 , V850ES/IK1 , V850ES/KE1+ , V850ES/FE3 , V850ES/FE3-L , V850ES/HE2 , V850ES/IK1 , V850ES/KE2
	QB-64F1-EA-02S	Exchange Adapter	V850	V850ES/JE3-L
	QB-64F1-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/JE3-L
	QB-64FC-EA-01T	Exchange Adapter	78K0R	78K0/KE2 , 78K0R/KE3-L(USB)
	QB-64FC-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/KE2 , 78K0R/KE3-L(USB)
	QB-64GA-EA-01T	Exchange Adapter	78K0R	78K0/KE2 , 78K0R/KE3-L
	QB-64GA-HQ-01T	Mount Adapter	78K0R	78K0/KE2 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB)
	QB-64GA-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/KE2 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB)
	QB-64GA-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/KE2 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB)
	QB-64GA-YS-01T	Space Adapter	78K0R	78K0/KE2 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB)
	QB-64GB-EA-01S	Exchange Adapter	V850	V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L
	QB-64GB-EA-03S	Exchange Adapter	V850	V850ES/JE3-L
	QB-64GB-EA-03T	Exchange Adapter	78K0	78K0/FE2
	QB-64GB-EA-04T	Exchange Adapter	78K0R	78K0/KE2 , 78K0/KE2-C , 78K0R/IE3 , 78K0R/KE3-L
	QB-64GB-EA-07T	Exchange Adapter	78K0	78K0/LE2
	QB-64GB-EA-08T	Exchange Adapter	78K0R	78K0R/KE3
	QB-64GB-EA-09T	Exchange Adapter	78K0R	78K0/LE3 , 78K0R/FE3
	QB-64GB-EA-10T	Exchange Adapter	78K0	78K0/DE2
	QB-64GB-HQ-01T	Mount Adapter	V850	78K0/DE2 , 78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/KE2-C , 78K0/LE2 , 78K0/LE3 , 78K0/LE3-M , 78K0R/FE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB) , V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L , V850ES/HE2 , V850ES/HE3 , V850ES/KE1+ , V850ES/KE2
	QB-64GB-MA-01S	Mount Adapter	V850	V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L , V850ES/HE3 , V850ES/KE1+ , V850ES/FE3-L , V850ES/HE2 , V850ES/KE2
	QB-64GB-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/DE2 , 78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/KE2-C , 78K0/LE2 , 78K0/LE3 , 78K0/LE3-M , 78K0R/FE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB)
	QB-64GB-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/FE2 , V850ES/FE3 , V850ES/FE3-L , V850ES/HE2 , V850ES/HE3 , V850ES/IK1 , V850ES/JE3-L , V850ES/KE1+ , V850ES/KE2
	QB-64GB-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/DE2 , 78K0/FE2 , 78K0/KE2 , 78K0/KE2-C , 78K0/LE2 , 78K0/LE3 , 78K0/LE3-M , 78K0R/FE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , 78K0R/KE3-L(USB)
	QB-64GB-YS-01T	Space Adapter	V850	78K0/DE2 , 78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/KE2-C , 78K0/LE2 , 78K0/LE3 , 78K0/LE3-M , 78K0R/FE3 , 78K0R/IE3 , 78K0R/KE3 , V850ES/KE2
	QB-64GC-EA-01S	Exchange Adapter	V850	V850ES/IE2 , V850ES/IK1
	QB-64GC-EA-03T	Exchange Adapter	78K0	78K0/KE2
	QB-64GC-HQ-01T	Mount Adapter	V850	78K0/KE1+ , 78K0/KE2 , 78K0/KE2-C , V850ES/IK1
	QB-64GC-HQ-02T	Mount Adapter	78K0	78K0/KE2
	QB-64GC-MA-01S	Mount Adapter	V850	V850ES/IE2 , V850ES/IK1
	QB-64GC-NQ-01T	Target Connector / Conversion Adapter	78K0	78K0/KE1+ , 78K0/KE2
	QB-64GC-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/IE2 , V850ES/IK1
	QB-64GC-YQ-01T	Target Connector / Conversion Adapter	78K0	78K0/KE2
	QB-64GC-YS-01T	Space Adapter	V850	78K0/KE1+ , 78K0/KE2 , V850ES/IK1
	QB-64GK-EA-01T	Exchange Adapter	78K0	UPD78F071x
	QB-64GK-EA-03T	Exchange Adapter	78K0	78K0/FE2 , UPD78F071x

	QB-64GK-EA-04T	Exchange Adapter	78K0	78K0/KE2 , 78K0R/IE3 , 78K0R/KE3-L , UPD78F8025
	QB-64GK-EA-05T	Exchange Adapter	78K0	78K0/LE2
	QB-64GK-EA-06T	Exchange Adapter	78K0R	78K0R/KE3
	QB-64GK-EA-07T	Exchange Adapter	78K0	78K0/LE3
	QB-64GK-HQ-01T	Mount Adapter	V850	78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/LE2 , 78K0/LE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , UPD78F071x , UPD78F8025 , V850ES/KE1+
	QB-64GK-HQ-02T	Mount Adapter	78K0	78K0/KE1+ , 78K0/KE2
	QB-64GK-MA-01S	Mount Adapter	V850	V850ES/KE1+
	QB-64GK-NQ-01T	Target Connector / Conversion Adapter	78K0	78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/LE2 , 78K0/LE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , UPD78F071x , UPD78F8025
	QB-64GK-TC-01S	Target Connector / Conversion Adapter	V850	V850ES/KE1+
	QB-64GK-YQ-01T	Target Connector / Conversion Adapter	78K0	78K0/FE2 , 78K0/KE2 , 78K0/LE2 , 78K0/LE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , UPD78F071x , UPD78F8025
	QB-64GK-YS-01T	Space Adapter	78K0	78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/LE2 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , UPD78F071x , UPD78F8025 , V850ES/KE1+ , 78K0/FE2 , 78K0/KE1+ , 78K0/KE2 , 78K0/LE2 , 78K0/LE3 , 78K0R/IE3 , 78K0R/KE3 , 78K0R/KE3-L , UPD78F071x
	QB-780714-T30MC	In Circuit Emulator	78K0	UPD78F071x
	QB-780714-T64GK	In Circuit Emulator	78K0	UPD78F071x
	QB-78F0730-TB	MCU Test Board	78K0	UPD78F073x
	QB-78F8024-EA-01T	Exchange Adapter	78K0	UPD78F8025
	QB-78F8043-EA-01T	Exchange Adapter	78K0R	UPD78F8043
	QB-78K0FX2-T44GB	In Circuit Emulator	78K0	78K0/FC2
	QB-78K0FX2-T48GA	In Circuit Emulator	78K0	78K0/FC2
	QB-78K0FX2-T64GB	In Circuit Emulator	78K0	78K0/FE2
	QB-78K0FX2-T64GK	In Circuit Emulator	78K0	78K0/FE2
	QB-78K0FX2-T80GC	In Circuit Emulator	78K0	78K0/FF2
	QB-78K0FX2-T80GK	In Circuit Emulator	78K0	78K0/FF2
	QB-78K0IB2-TB	MCU Test Board	78K0	78K0/IA2 , 78K0/IB2 , 78K0/IY2
	QB-78K0KA2L-EA-01T	Exchange Adapter	78K0	78K0/KA2-L
	QB-78K0KB2L-EA-01T	Exchange Adapter	78K0	78K0/KB2-L
	QB-78K0KC2L-EA-01T	Exchange Adapter	78K0	78K0/KC2-L
	QB-78K0KC2L-EA-02T	Exchange Adapter	78K0	78K0/KC2-L
	QB-78K0KC2L-TB	MCU Test Board	78K0	78K0/KA2-L , 78K0/KB2-L , 78K0/KC2-L , 78K0/KY2-L
	QB-78K0KF2-TB	MCU Test Board	78K0	78K0/KB2 , 78K0/KB2-L , 78K0/KC2 , 78K0/KC2-L , 78K0/KD2 , 78K0/KE2 , 78K0/KF2
	QB-78K0KX2-T30MC	In Circuit Emulator	78K0	78K0/KB2 , 78K0/KB2-L
	QB-78K0KX2-T36FC	In Circuit Emulator	78K0	78K0/KB2
	QB-78K0KX2-T38MC	In Circuit Emulator	78K0	78K0/KC2
	QB-78K0KX2-T44GB	In Circuit Emulator	78K0	78K0/KC2
	QB-78K0KX2-T48GA	In Circuit Emulator	78K0	78K0/KC2
	QB-78K0KX2-T52GB	In Circuit Emulator	78K0	78K0/KD2
	QB-78K0KX2-T64FC	In Circuit Emulator	78K0	78K0/KE2
	QB-78K0KX2-T64GA	In Circuit Emulator	78K0	78K0/KE2 , 78K0/KE2 , UPD78F8025
	QB-78K0KX2-T64GB	In Circuit Emulator	78K0	78K0/KE2 , 78K0/LE2
	QB-78K0KX2-T64GC	In Circuit Emulator	78K0	78K0/KE2
	QB-78K0KX2-T64GK	In Circuit Emulator	78K0	78K0/KE2 , 78K0/LE2
	QB-78K0KX2-T80GC	In Circuit Emulator	78K0	78K0/KF2
	QB-78K0KX2-T80GK	In Circuit Emulator	78K0	78K0/KF2
	QB-78K0KY2L-EA-01T	Exchange Adapter	78K0	78K0/KY2-L
	QB-78K0LF3-TB	MCU Test Board	78K0	78K0/LC3 , 78K0/LD3 , 78K0/LE3 , 78K0/LF3

	QB-78K0LX2-T100GC	In Circuit Emulator	78K0	78K0/LG2
	QB-78K0LX2-T64GB	In Circuit Emulator	78K0	78K0/LE2
	QB-78K0LX2-T64GK	In Circuit Emulator	78K0	78K0/LE2
	QB-78K0LX2-T80GC04	In Circuit Emulator	78K0	78K0/LF2
	QB-78K0LX2-T80GC05	In Circuit Emulator	78K0	78K0/LF2
	QB-78K0LX2-T80GK04	In Circuit Emulator	78K0	78K0/LF2
	QB-78K0LX2-T80GK05	In Circuit Emulator	78K0	78K0/LF2
	QB-78K0LX3-T48GA	In Circuit Emulator	78K0	78K0/LC3
	QB-78K0LX3-T52GB	In Circuit Emulator	78K0	78K0/LD3
	QB-78K0LX3-T64GB	In Circuit Emulator	78K0	78K0/LE3
	QB-78K0LX3-T64GK	In Circuit Emulator	78K0	78K0/LE3
	QB-78K0LX3-T80GC	In Circuit Emulator	78K0	78K0/LF3
	QB-78K0LX3-T80GK	In Circuit Emulator	78K0	78K0/LF3
	QB-78K0RFG3-TB	MCU Test Board	78K0R	78K0R/FB3 , 78K0R/FC3 , 78K0R/FE3 , 78K0R/FF3 , 78K0R/FG3
	QB-78K0RIE3-TB	MCU Test Board	78K0R	78K0R/IB3 , 78K0R/IC3 , 78K0R/ID3 , 78K0R/IE3
	QB-78K0RIX3-T30MC	In Circuit Emulator	78K0R	78K0R/IB3
	QB-78K0RIX3-T38MC	In Circuit Emulator	78K0R	78K0R/IC3
	QB-78K0RIX3-T44GB	In Circuit Emulator	78K0R	78K0R/IC3 , 78K0R/KC3-L
	QB-78K0RIX3-T48GA	In Circuit Emulator	78K0R	78K0R/IC3 , 78K0R/KC3-L
	QB-78K0RIX3-T52GB	In Circuit Emulator	78K0R	78K0R/ID3 , 78K0R/KD3-L
	QB-78K0RIX3-T64GB	In Circuit Emulator	78K0R	78K0R/IE3 , 78K0R/KE3-L
	QB-78K0RIX3-T64GK	In Circuit Emulator	78K0R	78K0R/IE3 , 78K0R/KE3-L
	QB-78K0RKE3L-TB	MCU Test Board	78K0R	78K0R/KC3-L , 78K0R/KD3-L , 78K0R/KE3-L
	QB-78K0RKG3-TB	MCU Test Board	78K0R	78K0R/KE3 , 78K0R/KF3 , 78K0R/KG3 , 78K0R/KH3 , 78K0R/KJ3
	QB-78K0RKG3C-TB	MCU Test Board	78K0R	78K0R/KF3-C , 78K0R/KG3-C
	QB-78K0RKG3L-TB	MCU Test Board	78K0R	78K0R/KF3-L , 78K0R/KG3-L
	QB-78K0RKX3-T100GC	In Circuit Emulator	78K0R	78K0R/KG3
	QB-78K0RKX3-T100GF	In Circuit Emulator	78K0R	78K0R/KG3
	QB-78K0RKX3-T128GF	In Circuit Emulator	78K0R	78K0R/KH3
	QB-78K0RKX3-T144GJ	In Circuit Emulator	78K0R	78K0R/KJ3
	QB-78K0RKX3-T64GB	In Circuit Emulator	78K0R	78K0R/KE3
	QB-78K0RKX3-T64GK	In Circuit Emulator	78K0R	78K0R/KE3
	QB-78K0RKX3-T80GC	In Circuit Emulator	78K0R	78K0R/KF3
	QB-78K0RKX3-T80GK	In Circuit Emulator	78K0R	78K0R/KF3
	QB-78K0RKX3C-T100GC	In Circuit Emulator	78K0R	78K0R/KG3-C , 78K0R/KG3-L
	QB-78K0RKX3C-T100GF	In Circuit Emulator	78K0R	78K0R/KG3-L
	QB-78K0RKX3C-T80GC	In Circuit Emulator	78K0R	78K0R/KF3-L
	QB-78K0RKX3C-T80GK	In Circuit Emulator	78K0R	78K0R/KF3-C , 78K0R/KF3-L
	QB-78K0RKX3C-ZZZ	In Circuit Emulator	78K0R	78K0R/KE3-L , UPD78F8043
	QB-78K0RLH3-TB	MCU Test Board	78K0R	78K0R/LF3 , 78K0R/LG3 , 78K0R/LH3
	QB-78K0RLX3-T100GC	In Circuit Emulator	78K0R	78K0R/LG3
	QB-78K0RLX3-T80GC	In Circuit Emulator	78K0R	78K0R/LF3
	QB-78K0RLX3-T80GK	In Circuit Emulator	78K0R	78K0R/LF3
	QB-78K0RLX3-ZZZ	In Circuit Emulator	78K0R	78K0R/LF3 , 78K0R/LG3 , 78K0R/LG3-M , 78K0R/LH3
	QB-78K0SKB1-TB	MCU Test Board	78K0S	78K0S/KA1+ , 78K0S/KB1+ , 78K0S/KU1+ , 78K0S/KY1+
	QB-78K0SKU1-TB	MCU Test Board	78K0S	78K0S/KU1+
	QB-78K0SKX1-T10MA	In Circuit Emulator	78K0S	78K0S/KU1+

	QB-78K0SKX1-T16GR	In Circuit Emulator	78K0S	78K0S/KY1+
	QB-78K0SKX1-T20MC	In Circuit Emulator	78K0S	78K0S/KA1+
	QB-78K0SKX1-T30MC	In Circuit Emulator	78K0S	78K0S/KB1+
	QB-78K0SKX1-ZZZ	In Circuit Emulator	78K0S	78K0S/KA1+, 78K0S/KB1+, 78K0S/KY1+
	QB-78K0SKY1-TB	MCU Test Board	78K0S	78K0S/KY1+
	QB-78K0SKY1W-TB	MCU Test Board	78K0S	78K0S/KY1+
	QB-80-CA-01S	Check Pin Adapter	V850	V850E/IA3, V850E/IF3, V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/HF2, V850ES/HF3, V850ES/JF3-L, V850ES/KF2
	QB-80-EP-01T	Emulation Probe	78K0	78K0/DE2, 78K0/DF2, 78K0/FA2-L, 78K0/FB2-L, 78K0/FC2, 78K0/FE2, 78K0/FF2, 78K0/FY2-L, 78K0/IA2, 78K0/IB2, 78K0/IY2, 78K0/KA2-L, 78K0/KB1+, 78K0/KB2, 78K0/KB2-A, 78K0/KB2-L, 78K0/KC2, 78K0/KC2-A, 78K0/KC2-C, 78K0/KC2-L, 78K0/KD2, 78K0/KE2, 78K0/KE2-C, 78K0/KF1+, 78K0/KF2, 78K0/KY2-L, 78K0/LC3, 78K0/LD3, 78K0/LE3, 78K0/LE3-M, 78K0/LF3, 78K0/LG3-M, 78K0R/FB3, 78K0R/FC3, 78K0R/FE3, 78K0R/FF3, 78K0R/IB3, 78K0R/IC3, 78K0R/ID3, 78K0R/IE3, 78K0R/KC3-L, 78K0R/KC3-L(USB), 78K0R/KD3-L, 78K0R/KE3-L, 78K0R/KE3-L(USB), UPD78F071x, UPD78F073x, UPD78F8025
	QB-80-SA-01S	Space Adapter	V850	V850E/IA3, V850E/IF3, V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/HF2, V850ES/HF3, V850ES/JF3-L, V850ES/FF3, V850ES/HF2, V850ES/KF2
	QB-80GC-EA-01T	Exchange Adapter	78K0	78K0/FF2, 78K0/KF2, 78K0/LF3
	QB-80GC-EA-02S	Exchange Adapter	V850	V850ES/JF3-L, V850ES/KF2
	QB-80GC-EA-03S	Exchange Adapter	V850	V850E/IF3
	QB-80GC-EA-04T	Exchange Adapter	78K0	78K0/LF2
	QB-80GC-EA-05T	Exchange Adapter	78K0	78K0/LF2
	QB-80GC-EA-06T	Exchange Adapter	78K0R	78K0R/KF3
	QB-80GC-EA-09T	Exchange Adapter	78K0R	78K0R/LF3
	QB-80GC-EA-10T	Exchange Adapter	78K0R	78K0R/KF3-L
	QB-80GC-HQ-01T	Mount Adapter	78K0	78K0/DF2, 78K0/FF2, 78K0/KF2, 78K0/LF3
	QB-80GC-MA-01S	Mount Adapter	V850	V850E/IA3, V850E/IF3, V850ES/JF3-L, V850E/IF3, V850ES/KF2
	QB-80GC-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/FF2, 78K0/KF1+, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/KF3, 78K0R/KF3-L, 78K0R/LF3
	QB-80GC-TC-01S	Target Connector / Conversion Adapter	V850	V850E/IF3, V850ES/JF3-L, V850ES/KF2
	QB-80GC-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/FF2, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/KF3, 78K0R/KF3-L, 78K0R/LF3
	QB-80GC-YS-01T	Space Adapter	V850	78K0/DF2, 78K0/FF2, 78K0/KF1+, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/KF3, 78K0R/KF3-L, 78K0R/LF3, V850E/IA3, V850ES/JF3-L, V850ES/KF2, 78K0/FF2, 78K0/KF1+, 78K0/KF2, 78K0/LF2, 78K0/LF3, V850E/IF3, V850ES/KF2
	QB-80GK-EA-01S	Exchange Adapter	78K0R	78K0R/LF3
	QB-80GK-EA-01T	Exchange Adapter	78K0R	78K0/DF2, 78K0/FF2, 78K0/KF2, 78K0/LF3, 78K0R/LF3
	QB-80GK-EA-02S	Exchange Adapter	V850	V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/HF2, V850ES/HF3, V850ES/JF3-L
	QB-80GK-EA-04T	Exchange Adapter	78K0	78K0/LF2
	QB-80GK-EA-05T	Exchange Adapter	78K0	78K0/LF2
	QB-80GK-EA-06T	Exchange Adapter	78K0R	78K0R/KF3
	QB-80GK-EA-08T	Exchange Adapter	78K0R	78K0R/LF3
	QB-80GK-EA-09T	Exchange Adapter	78K0R	78K0R/KF3-C, 78K0R/KF3-L
	QB-80GK-EA-10T	Exchange Adapter	78K0R	78K0R/FF3
	QB-80GK-HQ-01T	Mount Adapter	V850	78K0/DF2, 78K0/FF2, 78K0/KF1+, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/FF3, 78K0R/KF3, 78K0R/KF3-C, 78K0R/KF3-L, 78K0R/LF3, V850ES/JF3-L, V850ES/HF2, V850ES/HF3, V850ES/JF3-L
	QB-80GK-MA-01S	Mount Adapter	V850	V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/HF2, V850ES/HF3, V850ES/JF3-L, 78K0R/LF3, V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/HF2
	QB-80GK-NQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/DF2, 78K0/FF2, 78K0/KF1+, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/FF3, 78K0R/KF3, 78K0R/KF3-C, 78K0R/KF3-L, 78K0R/LF3
	QB-80GK-TC-01S	Target Connector / Conversion Adapter	V850	78K0R/LF3, V850ES/FF2, V850ES/FF3, V850ES/FF3-L, V850ES/HF2, V850ES/HF3, V850ES/JF3-L

	QB-80GK-YQ-01T	Target Connector / Conversion Adapter	78K0R	78K0/DF2, 78K0/FF2, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/FF3, 78K0R/KF3, 78K0R/KF3-C, 78K0R/KF3-L, 78K0R/LF3
	QB-80GK-YS-01T	Space Adapter	V850	78K0/DF2, 78K0/FF2, 78K0/KF1+, 78K0/KF2, 78K0/LF2, 78K0/LF3, 78K0R/FF3, 78K0R/KF3, 78K0R/KF3-C, V850ES/FF3, V850ES/HF2
	QB-COMMON-PW-EA	Power Supply	78K0R	78K0R/LF3, 78K0R/LG3, 78K0R/LH3
	QB-MINI2-EA	On Chip Debugging Emulator	V850	78K0/DE2, 78K0/DF2, 78K0/FA2-L, 78K0/FB2-L, 78K0/FY2-L, 78K0/KA2-L, 78K0/KB2-L, 78K0/KC2-C, 78K0/KE2-C, 78K0/KY2-L, 78K0/LE3-M, 78K0/LG3-M, 78K0R/FB3, 78K0R/FC3, 78K0R/FE3, 78K0R/FF3, 78K0R/FG3, 78K0R/LF3, 78K0R/LG3, 78K0R/LH3, 78K0S/KA1+, 78K0S/KB1+, 78K0S/KU1+, 78K0S/KY1+, UPD78F071x, UPD78F073x, UPD78F8025, V850ES/FE3, V850ES/FE3-L, V850ES/FF3, V850ES/FF3-L, V850ES/FG3, V850ES/FG3-L, V850ES/FJ3, V850ES/FK3, V850ES/JH3-E, V850ES/JJ3-E, V850ES/SG3, V850ES/SJ3
	QB-V850EIA4-S100GC	In Circuit Emulator	V850	V850E/IA4
	QB-V850EIA4-S100GF	In Circuit Emulator	V850	V850E/IA4
	QB-V850EIA4-S64GC	In Circuit Emulator	V850	V850ES/IK1
	QB-V850EIA4-S80GC	In Circuit Emulator	V850	V850E/IA3
	QB-V850EIA4-T100GF	In Circuit Emulator	V850	V850E/IA4
	QB-V850EIA4-T64GC	In Circuit Emulator	V850	V850ES/IK1
	QB-V850EIA4-T80GC	In Circuit Emulator	V850	V850E/IA3
	QB-V850EIG3-TB	MCU Test Board	V850	V850E/IF3, V850E/IG3
 	QB-V850ESFX2-S100GC	In Circuit Emulator	V850	V850ES/FG2, V850ES/HG2
 	QB-V850ESFX2-S144GJ	In Circuit Emulator	V850	V850ES/FJ2, V850ES/HJ2
 	QB-V850ESFX2-S64GB	In Circuit Emulator	V850	V850ES/FE2, V850ES/FE3, V850ES/HE2
 	QB-V850ESFX2-S80GK	In Circuit Emulator	V850	V850ES/FF2, V850ES/HF2
 	QB-V850ESFX2-T100GC	In Circuit Emulator	V850	V850ES/FG2, V850ES/HG2
 	QB-V850ESFX2-T144GJ	In Circuit Emulator	V850	V850ES/FJ2, V850ES/HJ2
 	QB-V850ESFX2-T64GB	In Circuit Emulator	V850	V850ES/FE2, V850ES/FE3, V850ES/HE2
 	QB-V850ESFX2-T80GK	In Circuit Emulator	V850	V850ES/FF2, V850ES/FF3-L, V850ES/HF2
 	QB-V850ESFX3-S100GC	In Circuit Emulator	V850	V850ES/FG3, V850ES/FG3-L, V850ES/HG3
 	QB-V850ESFX3-S144GJ	In Circuit Emulator	V850	V850ES/FJ3, V850ES/HJ3
 	QB-V850ESFX3-S64GB	In Circuit Emulator	V850	V850ES/FE3-L, V850ES/HE3
 	QB-V850ESFX3-S80GK	In Circuit Emulator	V850	V850ES/FF3, V850ES/FF3-L, V850ES/HF3
 	QB-V850ESFX3-T100GC	In Circuit Emulator	V850	V850ES/FG3, V850ES/FG3-L, V850ES/HG3
 	QB-V850ESFX3-T144GJ	In Circuit Emulator	V850	V850ES/FJ3, V850ES/HJ3
 	QB-V850ESFX3-T176GM	In Circuit Emulator	V850	V850ES/FK3
 	QB-V850ESFX3-T64GB	In Circuit Emulator	V850	V850ES/FE3, V850ES/FE3-L, V850ES/HE3
 	QB-V850ESFX3-T80GK	In Circuit Emulator	V850	V850ES/FF3, V850ES/FF3-L, V850ES/HF3
 	QB-V850ESHG2-TB	MCU Test Board	V850	V850ES/HE2, V850ES/HF2, V850ES/HG2, V850ES/HJ2
 	QB-V850ESHG3-TB	MCU Test Board	V850	V850ES/HE3, V850ES/HF3, V850ES/HG3, V850ES/HJ3
 	QB-V850ESIE2-TB	MCU Test Board	V850	V850ES/IE2
 	QB-V850ESIX2-S64GC	In Circuit Emulator	V850	V850ES/IE2
 	QB-V850ESIX2-T64GC	In Circuit Emulator	V850	V850ES/IE2
 	QB-V850ESJG2-TB	MCU Test Board	V850	V850ES/JG2, V850ES/JJ2
 	QB-V850ESJG3L-TB	MCU Test Board	V850	V850ES/JF3-L, V850ES/JG3-L
 	QB-V850ESJG3U-TB	MCU Test Board	V850	V850ES/JC3-H, V850ES/JE3-H, V850ES/JG3-H, V850ES/JG3-U, V850ES/JH3-H, V850ES/JH3-U
 	QB-V850ESJJ3-TB	MCU Test Board	V850	V850ES/JG3, V850ES/JJ3
 	QB-V850ESJX3E-S128GF	In Circuit Emulator	V850	V850ES/JH3-E

