
TOSHIBA

8 Bit Microcontroller TLCS-870/C Series

TMP86FH92DMG

TOSHIBA CORPORATION



TMP86FH92DMG



Precaution for Using the Emulation Chip / Difference among Products

- (1) Precaution for Using the Emulation Chip (Development Tool)
 - Precaution for debugging the voltage detection circuit

The functions of the voltage detection circuit vary between the TMP86FH92DMG and the emulation chip TMP86C993XB. Therefore, please ensure that the final verification of software operation related to the voltage detection circuit is conducted with the TMP86FH92DMG.

For details, refer to the chapter on the voltage detection circuit.

· Precaution for debugging the power-on reset circuit

The power-on reset circuit cannot be emulated with the TMP86C993XB. Therefore, when using the development tool for debugging, ensure that operation is performed within the operating voltage range of the TMP86FH92DMG. For the operating voltage range, refer to the chapter on electrical characteristics.

Precaution for debugging the Flash control register

Although the TMP86FH92DMG contains the Flash control register (FLSCR) at 0FFFH in the DBR area, the TMP86C993XB do not contain the FLSCR register. Therefore, when using the development tool for debugging, a program that accesses the FLSCR register cannot function properly (executes differently as in the case of TMP86FH92DMG).

(2) Difference among Products

• Differences in Functions

Producrs	TMP86FH92DMG	TMP86FH93NG	
CPUCORE	TLCS-870/C		
ROM	16K bytes		
	· · · · · · · · · · · · · · · · · · ·	ASH)	
RAM		bytes	
Interrrupt	22 interrupts (Exte	ernal:5 Internal:17)	
I/O	24 pins	26 pins	
Port 0	8pins(Large current ou C-MOS output/with Progra	ntput/sink open-drain or mmable Pull-up resistance)	
D. 14	5 pins	7pins	
Port 1	(sink-opendrain or C-MOS output/wi	th Programmable Pull-up resistance)	
Port 2	3 pins (P20 is addition progr	ammable Pull-up resistance)	
Port 3	8 p	oins	
Watchdog Timer	1 cha	annel	
Timer/counter	16 bit: 1 channel 8 bit: 2 channels		
UART	2 channels (1 channel is shared with I ² C bus)	2 channels	
Serial bus interface (I ² C bus)	1 channel (shared with UART) SDA(P13) and SCL(P14) are fixed	1 channel SDA(P13) and SCL(P14) or SDA(P15) and SCL(P16) are selectable	
SEI	1 cha	annel	
10 bit ADconverter	6 cha	innels	
Key-on wake-up	4 channels		
Clock Oscillation circuit	2 circuits (single / dual clo	ock modes are selectable)	
Low power consumption operating	9 modes (STOP/SLOW1/SLOW2/IDLE0/IDLE1/IDLE2/SLEEP0/SLEEP1/SLEEP2)		
otehr functions	Power on reset circuit Low voltage detector circuit		
Operating voltage(VDD)	4.0V to 5.5V (at 16MHz / 32.768KHz) 2.7V to 5.5V (at 8MHz / 32.768KHz)		
Package	30pin (SSOP30-P-56-0.65) 32pin (SDIP32-P-400-1.78)		

· Difference in Electrical Characteristics

		TMP86FH92DMG TMP86FH93NG		
Operating condition	Read/Fetch	3.0V to 5.5V (-40 to 85°C) 2.7V to 3.0V (-20 to 85°C)		
(MCU mode)	Erase/ Program	4.5V to 5.5V (-10 to 40°C)		
Operating cond (Serial PROM r		4.5V to 5.5V	(-10 to 40°C)	

Revision History

Date	Revision		
2007/4/19	1	First Release	
2007/5/17	2	Contents Revised	
2007/6/26	3	Contents Revised	
2008/1/31	4	Contents Revised	
2008/2/27	5	Contents Revised	
2008/9/26	6	Contents Revised	
2009/8/24	7	Contents Revised	

Table of Contents

Precaution for Using the Emulation Chip / Difference among Products		
TMP86FH92DMG		
1.1 Features	1	
1.2 Pin Assignment	3	
1.3 Block Diagram		
1.4 Pin Names and Functions		
2. Operational Description		
2.1 CPU Core Functions	7	
2.1.1 Memory Address Map		
2.1.2 Program Memory (Flash)		
2.1.3 Data Memory (RAM)		
2.2 System Clock Controller 2.2.1 Clock Generator		
2.2.1 Clock Generator		
2.2.2.1 Configuration of timing generator		
2.2.2.2 Machine cycle		
2.2.3 Operation Mode Control Circuit	11	
2.2.3.2 Dual-clock mode		
2.2.3.3 STOP mode		
2.2.3.4 Operating Mode Transition 2.2.4 Operating Mode Control	16	
2.2.4.1 STOP mode		
2.2.4.2 IDLE1/2 mode and SLEEP1/2 mode		
2.2.4.3 IDLE0 and SLEEP0 modes (IDLE0, SLEEP0) 2.2.4.4 SLOW mode		
2.3 Reset Circuit	30	
2.3.1 External Reset Input		
2.3.2 Address trap reset		
2.3.3 Watchdog timer reset		
2.3.4 System clock reset		
2.3.5 Power-on Reset		
2.3.7 Trimming data reset		
2.4 Internal Reset Detection Flags		
D. Testerment Control Circuit		
3. Interrupt Control Circuit		
3.1 Interrupt latches (IL21 to IL2)		
3.2 Interrupt enable register (EIR)		
3.2.1 Interrupt master enable flag (IMF)		
3.3 Interrupt Sequence	38	

39
42
42
42
43
43
44
47
49
52
54
56
58
61
61
61
63
64
66
66
66
67 67
68
68
69
71
72
72
74

	8.2.5 Watchdog Timer Reset	75
	8.3 Address Trap	76
	8.3.1 Selection of Address Trap in Internal RAM (ATAS)	76
	8.3.2 Selection of Operation at Address Trap (ATOUT)	
	8.3.3 Address Trap Interrupt (INTATRAP)	
	8.3.4 Address Trap Reset	//
<u> </u>	Time Base Timer (TBT)	
	9.1 Time Base Timer	70
	9.1 Time Base Timer 9.1.1 Configuration	
	9.1.2 Control	
	9.1.3 Function	80
	9.2 Divider Output (DVO)	81
	9.2.1 Configuration	
	9.2.2 Control	81
10.	16-Bit Timer/Counter 1 (TC1)	
	10.1 Configuration	83
	10.2 Timer/Counter Control.	
	10.3 Function	
	10.3.1 Timer mode	
	10.3.3 Event Counter Mode	
	10.3.4 Window Mode	
	10.3.5 Pulse Width Measurement Mode	
	10.3.6 Programmable Pulse Generate (PPG) Output Mode	93
11.	8-Bit TimerCounter (TC3, TC4)	
	11.1 Configuration	99
	11.2 TimerCounter Control	100
	11.3 Function	
	11.3.1 8-Bit Timer Mode (TC3 and 4)	
	11.3.2 8-Bit Event Counter Mode (TC3, 4)	106
	11.3.3 8-Bit Programmable Divider Output (PDO) Mode (TC3, 4)	
	11.3.4 8-Bit Pulse Width Modulation (PWM) Output Mode (TC3, 4)	
	11.3.5 16-Bit Timer Mode (TC3 and 4)	
	11.3.7 16-Bit Pulse Width Modulation (PWM) Output Mode (TC3 and 4)	
	11.3.8 16-Bit Programmable Pulse Generate (PPG) Output Mode (TC3 and 4)	
	11.3.9 Warm-Up Counter Mode	117
	11.3.9.1 Low-Frequency Warm-up Counter Mode (NORMAL1 → NORMAL2 → SLOW2 → SLOW1)	
	11.3.9.2 High-Frequency Warm-Up Counter Mode	
	$(SLOW1 \rightarrow SLOW2 \rightarrow NORMAL2 \rightarrow NORMAL1)$	
12.	Asynchronous Serial interface (UART1)	
	12.1 Configuration	110
	12.2 Control	
	12.3 Transfer Data Format	
	12.4 Transfer Rate	124

	12.5	Data Sampling Method	124
	12.6	STOP Bit Length	125
	12.7	Parity	
	12.8	Transmit/Receive Operation	
	12.8	•	
	12.8	· · · · · · · · · · · · · · · · · · ·	
	12.9	Status Flag	
	12.9	, and the second se	
	12.9 12.9		
	12.9		
	12.9	1 2	
	12.9	.6 Transmit End Flag	128
13.	Asy	nchronous Serial interface (UART2)	
	13.1	Configuration	129
	13.2	Control	130
	13.3	Transfer Data Format	133
	13.4	Transfer Rate	
	13.5	Data Sampling Method	
	13.6	STOP Bit Length	
	13.7	Parity	
	13.8	Transmit/Receive Operation	
	13.8	•	
	13.8		
	13.9	Status Flag	136
	13.9	•	
	13.9 13.9	č	
	13.9		
	13.9	1 2	
	13.9		138
14.	Seri	al Expansion Interface (SEI)	
	14.1	Features	139
	14.2	SEI Registers	
	14.2	.1 SEI Control Register (SECR)	140
	14.2		141
	14.2	.3 SEI Data Register (SEDR)	141
	14.3	SEI Operation	
	14.3		
	14.3 14.4	· · · · · · · · · · · · · · · · · · ·	
	14.4 14.4	SEI Pin Functions 1 SCLK pin	
	14.4	±	
	14.4	.3 SS pin	143
	14.5	SEI Transfer Formats	
	14.5	(8)	
	14.5 14.6		
		Functional Description	
	14.7	Interrupt Generation	
	14.8	SEI System Errors	147

14.8.1 Write collision error	147
14.8.3 Mode fault error	
15. Serial Bus Interface(I ² C Bus) VerD (SBI)	
15.1 Configuration	149
15.2 Control	149
15.3 Software Reset	
15.4 The Data Format in the I2C Bus Mode	
15.5 I2C Bus Control	
15.5.1 Acknowledgement mode specification	153
15.5.1.2 Non-acknowledgment mode (ACK = "0")	
15.5.2 Number of transfer bits	
15.5.3.1 Clock source	
15.5.3.2 Clock synchronization 15.5.4 Slave address and address recognition mode specification	155
15.5.5 Master/slave selection	155
15.5.6 Transmitter/receiver selection	
15.5.8 Interrupt service request and cancel	
15.5.9 Setting of I2C bus mode	
15.5.10 Arbitration lost detection monitor	
15.5.12 GENERAL CALL detection monitor	159
15.5.13 Last received bit monitor	
15.6.1 Device initialization	
15.6.2 Start condition and slave address generation	159
15.6.3 1-word data transfer	160
15.6.3.2 When the MST is "0" (Slave mode)	
15.6.4 Stop condition generation	
16. 10-bit AD Converter (ADC)	
16.1 Configuration	
16.2 Register configuration	
16.3 Function	
16.3.1 Software Start Mode	
16.3.3 Register Setting	170
16.4 STOP/SLOW Modes during AD Conversion	171
16.5 Analog Input Voltage and AD Conversion Result	172
16.6 Precautions about AD Converter	
16.6.1 Analog input pin voltage range	
16.6.3 Noise Countermeasure	
17. Key-on Wakeup (KWU)	
17.1 Configuration	175

	17.2 Control	176
18.	Flash Memory	
	18.1 Flash Memory Control	178
	18.1.1 Flash Memory Command Sequence Execution Control (FLSCR <flsmd>)</flsmd>	
	18.1.2 Flash Memory Standby Control (FLSSTB <fstb>)</fstb>	
	18.2 Command Sequence	
	18.2.1 Byte Program	
	18.2.3 Chip Erase (All Erase)	181
	18.2.4 Product ID Entry	
	18.2.5 Product ID Exit	
	18.3 Toggle Bit (D6)	
	18.4 Access to the Flash Memory Area.	
	18.4.1 Flash Memory Control in the Serial PROM Mode	183
	18.4.2 Flash Memory Control in the MCU mode	185
19.	Serial PROM Mode	
	19.1 Outline	187
	19.2 Memory Mapping	187
	19.3 Serial PROM Mode Setting.	
	19.3.1 Serial PROM Mode Control Pins	
	19.3.2 Pin Function	
	19.3.4 Activating the Serial PROM Mode	190
	19.4 Interface Specifications for UART	
	19.5 Operation Command	
	19.6 Operation Mode	
	19.6.1 Flash Memory Erasing Mode (Operating command: F0H)	
	19.6.3 RAM Loader Mode (Operation Command: 60H)	
	19.6.4 Flash Memory SUM Output Mode (Operation Command: 90H)	201
	19.6.5 Product ID Code Output Mode (Operation Command: C0H)	
	19.6.7 Flash Memory security program Setting Mode (Operation Command: FAH)	
	19.7 Error Code	
	19.8 Checksum (SUM)	
	19.8.1 Calculation Method	
	19.9 Intel Hex Format (Binary).	
	19.10 Passwords	
	19.10.1 Password String	
	19.10.2 Handling of Password Error	
	19.10.3 Password Management during Program Development	
	19.12 Flash Memory Status Code	
	19.13 Specifying the Erasure Area	
	19.15 Flowchart	
	19.16 UART Timing.	
	1/•10 U/MXI IIIIII	ں 1 کے ۔۔۔۔۔۔۔ کے ا

20.	Input/Output Circuitry	
	20.1 Control Pins	
21.	Electrical Characteristics	
	21.1 Absolute Maximum Ratings	221
	21.2 Operating Conditions	
	21.2.1 MCU mode (Flash Programming or erasing)	
	21.2.2 MCU mode (Except Flash Programming or erasing)	
	21.2.3 Serial PROM mode	
	21.3 DC Characteristics	
	21.4 AD Conversion Characteristics	
	21.5 Power-on reset circuit Characteristics	226
	21.6 Voltage detection circuit characteristics	227
	21.7 AC Characteristics	228
	21.8 Flash Characteristics.	
	21.8.1 Write/Erase Characteristics.	
	21.9 Oscillating Conditions	229
	21.10 Handling Precaution	

CMOS 8-Bit Microcontroller

TMP86FH92DMG

Product No.	ROM (FLASH)	RAM	Package	Emulation Chip
TMP86FH92DMG	16384 bytes	512 bytes	SSOP30-P-56-0.65	TMP86C993XB

1.1 Features

- 1. 8-bit single chip microcomputer TLCS-870/C series
 - Instruction execution time:

0.25 µs (at 16 MHz)

122 μs (at 32.768 kHz)

- 132 types & 731 basic instructions
- 2. 22interrupt sources (External: 5 Internal: 17)
- 3. Input / Output ports (24 pins)

Large current output: 8pins (Typ. 20mA), LED direct drive

- 4. Power-on reset circuit
- 5. Voltage detection circuit
- 6. Watchdog Timer
- 7. Prescaler
 - Time base timer
 - Divider output function
- 8. 16-bit timer counter: 1 ch
 - Timer, External trigger, Window, Pulse width measurement,

Event counter, Programmable pulse generate (PPG) modes

- 9. 8-bit timer counter: 2 ch
 - Timer, Event counter, Programmable divider output (PDO),

Pulse width modulation (PWM) output,

Programmable pulse generation (PPG),

16bit mode (8bit timer 2ch combination) modes

- 10. 8-bit UART: 2 ch
- 11. 8bit Serial Expansion Interface (SEI): 1 channel

(MSB/LSB selectable and max. 4Mbps at 16MHz)

- 12. Serial Bus Interface(I²C Bus): 1ch
- 13. 10-bit successive approximation type AD converter
 - Analog input: 6 ch
- 14. Key-on wakeup: 4 channels
- 15. Clock operation

Single clock mode

Dual clock mode

16. Low power consumption operation

This product uses the Super Flash® technology under the licence of Silicon Storage Technology, Inc. Super Flash® is registered trademark of Silicon Storage Technology, Inc.

1.1 Features TMP86FH92DMG

STOP mode: Oscillation stops. (Battery/Capacitor back-up.)

SLOW1 mode: Low power consumption operation using low-frequency clock.(High-frequency clock stop.)

SLOW2 mode: Low power consumption operation using low-frequency clock.(High-frequency clock oscillate.)

IDLE0 mode: CPU stops, and only the Time-Based-Timer(TBT) on peripherals operate using high frequency clock. Release by falling edge of the source clock which is set by TBTCR<TBTCK>.

IDLE1 mode: CPU stops and peripherals operate using high frequency clock. Release by interruputs(CPU restarts).

IDLE2 mode: CPU stops and peripherals operate using high and low frequency clock. Release by interruputs. (CPU restarts).

SLEEP0 mode: CPU stops, and only the Time-Based-Timer(TBT) on peripherals operate using low frequency clock. Release by falling edge of the source clock which is set by TBTCR<TBTCK>.

SLEEP1 mode: CPU stops, and peripherals operate using low frequency clock. Release by interruput.(CPU restarts).

SLEEP2 mode: CPU stops and peripherals operate using high and low frequency clock. Release by interruput.

17. Wide operation voltage:

4.0 V to 5.5 V at 16MHz /32.768 kHz 2.7 V to 5.5 V at 8 MHz /32.768 kHz

TOSHIBA TMP86FH92DMG

1.2 Pin Assignment




Figure 1-1 Pin Assignment

1.3 Block Diagram TMP86FH92DMG

1.3 Block Diagram




Figure 1-2 Block Diagram

1.4 Pin Names and Functions

The TMP86FH92DMG has MCU mode, parallel PROM mode, and serial PROM mode. Table 1-1 shows the pin functions in MCU mode. The serial PROM mode is explained later in a separate chapter.

Table 1-1 Pin Names and Functions(1/2)

Pin Name	Pin Number	Input/Output	Functions
P07 TC1 INT4	19	10 1	PORT07 TC1 input External interrupt 4 input
P06 INT3 PPG	18	10 1 0	PORT06 External interrupt 3 input PPG output
P05 SS	15	IO I	PORT05 SEI master/slave select input
P04 MISO	14	IO IO	PORT04 SEI master input, slave output
P03 MOSI	13	IO IO	PORT03 SEI master input, slave output
P02 SCLK	12	IO IO	PORT02 SEI serial clock input/output pin
P01 RXD1 BOOT	11	10 1	PORT01 UART data input 1 Serial PROM mode control input
P00 TXD1	10	IO O	PORT00 UART data output 1
P14 SCL TXD2	17	10 10 0	PORT14 I2C bus clock UART data output 2
P13 SDA RXD2	16	10 10	PORT13 I2C bus data UART data input 2
P12 DVO	22	IO O	PORT12 Divider Output
P11 INT1	21	IO I	PORT11 External interrupt 1 input
P10 INTO	20	IO I	PORT10 External interrupt 0 input
P22 XTOUT	7	IO O	PORT22 Resonator connecting pins(32.768kHz) for inputting external clock
P21 XTIN	6	IO 1	PORT21 Resonator connecting pins(32.768kHz) for inputting external clock
P20 STOP INT5	9	10 1	PORT20 STOP mode release signal input External interrupt 5 input

1.4 Pin Names and Functions TMP86FH92DMG

Table 1-1 Pin Names and Functions(2/2)

Pin Name	Pin Number	Input/Output	Functions
P37 AIN5 STOP5	30	10 1 1	PORT37 Analog Input5 STOP5
P36 AIN4 STOP4	29	IO I	PORT36 Analog Input4 STOP4
P35 AIN3 STOP3	28	IO I	PORT35 Analog Input3 STOP3
P34 AIN2 STOP2	27	10 1	PORT34 Analog Input2 STOP2
P33 AIN1	26	IO I	PORT33 Analog Input1
P32 AIN0	25	IO I	PORT32 Analog Input0
P31 TC4 PDO4/PWM4/PPG4	24	10 1 0	PORT31 TC4 input PDO4/PWM4/PPG4 output
P30 TC3 PDO3/PWM3	23	10 1 0	PORT30 TC3 input PDO3/PWM3 output
XIN	2	1	Resonator connecting pins for high-frequency clock
XOUT	3	0	Resonator connecting pins for high-frequency clock
RESET	8	1	Reset signal
TEST	4	1	Test pin for out-going test. Normally, be fixed to low.
VDD	5	1	+5V
VSS	1	1	0(GND)

TOSHIBA TMP86FH92DMG

2. Operational Description

2.1 CPU Core Functions

The CPU core consists of a CPU, a system clock controller, and an interrupt controller.

This section provides a description of the CPU core, the program memory, the data memory, and the reset circuit.

2.1.1 Memory Address Map

The TMP86FH92DMG memory is composed Flash, RAM, DBR(Data buffer register) and SFR(Special function register). They are all mapped in 64-Kbyte address space. Figure 2-1 shows the TMP86FH92DMG memory address map.




Figure 2-1 Memory Address Map

2.1.2 Program Memory (Flash)

The TMP86FH92DMG has a 16384 bytes (Address C000H to FFFFH) of program memory (Flash).

2.1.3 Data Memory (RAM)

The TMP86FH92DMG has 512bytes (Address 0040H to 023FH) of internal RAM. The first 192 bytes (0040H to 00FFH) of the internal RAM are located in the direct area; instructions with shorten operations are available against such an area.

The data memory contents become unstable when the power supply is turned on; therefore, the data memory should be initialized by an initialization routine.

Example: Clears RAM to "00H". (TMP86FH92DMG)

	LD	HL, 0040H	; Start address setup
	LD	A, H	; Initial value (00H) setup
	LD	BC, 01FFH	
SRAMCLR:	LD	(HL), A	
	INC	HL	
	DEC	BC	
	JRS	F, SRAMCLR	

2.2 System Clock Controller

The system clock controller consists of a clock generator, a timing generator, and a standby controller.




Figure 2-2 System Clock Control

2.2.1 Clock Generator

The clock generator generates the basic clock which provides the system clocks supplied to the CPU core and peripheral hardware. It contains two oscillation circuits: One for the high-frequency clock and one for the low-frequency clock. Power consumption can be reduced by switching of the standby controller to low-power operation based on the low-frequency clock.

The high-frequency (fc) clock and low-frequency (fs) clock can easily be obtained by connecting a resonator between the XIN/XOUT and XTIN/XTOUT pins respectively. Clock input from an external oscillator is also possible. In this case, external clock is applied to XIN/XTIN pin with XOUT/XTOUT pin not connected.




Figure 2-3 Examples of Resonator Connection

Note: The function to monitor the basic clock directly at external is not provided for hardware, however, with disabling all interrupts and watchdog timers, the oscillation frequency can be adjusted by monitoring the pulse which the fixed frequency is outputted to the port by the program.

The system to require the adjustment of the oscillation frequency should create the program for the adjustment in advance.

2.2.2 Timing Generator

The timing generator generates the various system clocks supplied to the CPU core and peripheral hardware from the basic clock (fc or fs). The timing generator provides the following functions.

- 1. Generation of main system clock
- 2. Generation of divider output (\overline{DVO}) pulses
- 3. Generation of source clocks for time base timer
- 4. Generation of source clocks for watchdog timer
- 5. Generation of internal source clocks for timer/counters
- 6. Generation of warm-up clocks for releasing STOP mode

2.2.2.1 Configuration of timing generator

The timing generator consists of a 2-stage prescaler, a 21-stage divider, a main system clock generator, and machine cycle counters.

An input clock to the 7th stage of the divider depends on the operating mode, SYSCR2<SYSCK> and TBTCR<DV7CK>, that is shown in Figure 2-4. As reset and STOP mode started/canceled, the prescaler and the divider are cleared to "0".





Figure 2-4 Configuration of Timing Generator

Timing Generator Control Register



Note 1: In single clock mode, do not set DV7CK to "1".

Note 2: Do not set "1" on DV7CK while the low-frequency clock is not operated stably.

Note 3: fc: High-frequency clock [Hz], fs: Low-frequency clock [Hz], *: Don't care

Note 4: In SLOW1/2 and SLEEP1/2 modes, the DV7CK setting is ineffective, and fs is input to the 7th stage of the divider.

Note 5: When STOP mode is entered from NORMAL1/2 mode, the DV7CK setting is ineffective during the warm-up period after release of STOP mode, and the 6th stage of the divider is input to the 7th stage during this period.

2.2.2.2 Machine cycle

Instruction execution and peripheral hardware operation are synchronized with the main system clock.

The minimum instruction execution unit is called an "machine cycle". There are a total of 10 different types of instructions for the TLCS-870/C Series: Ranging from 1-cycle instructions which require one machine cycle for execution to 10-cycle instructions which require 10 machine cycles for execution. A machine cycle consists of 4 states (S0 to S3), and each state consists of one main system clock.




Figure 2-5 Machine Cycle

2.2.3 Operation Mode Control Circuit

The operation mode control circuit starts and stops the oscillation circuits for the high-frequency and low-frequency clocks, and switches the main system clock. There are three operating modes: Single clock mode, dual clock mode and STOP mode. These modes are controlled by the system control registers (SYSCR1 and SYSCR2). Figure 2-6 shows the operating mode transition diagram.

2.2.3.1 Single-clock mode

Only The oscillation circuit for the high-frequency clock is used, and P21 (XTIN) and P22 (XTOUT) pins are used as input/output ports. The main-system clock is obtained from the high-frequency clock. In the single-clock mode, the machine cycle time is 4/fc [s].

(1) NORMAL1 mode

In this mode, both the CPU core and on-chip peripherals operate using the high-frequency clock. The TMP86FH92DMG is placed in this mode after reset.

2.2 System Clock Controller

(2) IDLE1 mode

In this mode, the internal oscillation circuit remains active. The CPU and the watchdog timer are halted; however on-chip peripherals remain active (Operate using the high-frequency clock).

IDLE1 mode is started by SYSCR2<IDLE> = "1", and IDLE1 mode is released to NORMAL1 mode by an interrupt request from the on-chip peripherals or external interrupt inputs. When the IMF (Interrupt master enable flag) is "1" (Interrupt enable), the execution will resume with the acceptance of the interrupt, and the operation will return to normal after the interrupt service is completed. When the IMF is "0" (Interrupt disable), the execution will resume with the instruction which follows the IDLE1 mode start instruction.

(3) IDLE0 mode

In this mode, all the circuit, except oscillator and the timer-base-timer, stops operation.

This mode is enabled by SYSCR2<TGHALT> = "1".

When IDLE0 mode starts, the CPU stops and the timing generator stops feeding the clock to the peripheral circuits other than TBT. Then, upon detecting the falling edge of the source clock selected with TBTCR<TBTCK>, the timing generator starts feeding the clock to all peripheral circuits.

When returned from IDLE0 mode, the CPU restarts operating, entering NORMAL1 mode back again. IDLE0 mode is entered and returned regardless of how TBTCR<TBTEN> is set. When IMF = "1", EF7 (TBT interrupt individual enable flag) = "1", and TBTCR<TBTEN> = "1", interrupt processing is performed. When IDLE0 mode is entered while TBTCR<TBTEN> = "1", the INTTBT interrupt latch is set after returning to NORMAL1 mode.

2.2.3.2 Dual-clock mode

Both the high-frequency and low-frequency oscillation circuits are used in this mode. P21 (XTIN) and P22 (XTOUT) pins cannot be used as input/output ports. The main system clock is obtained from the high-frequency clock in NORMAL2 and IDLE2 modes, and is obtained from the low-frequency clock in SLOW and SLEEP modes. The machine cycle time is 4/fc [s] in the NORMAL2 and IDLE2 modes, and 4/fs [s] (122 µs at fs = 32.768 kHz) in the SLOW and SLEEP modes.

The TLCS-870/C is placed in the single-clock mode during reset. To use the dual-clock mode, the low-frequency oscillator should be turned on at the start of a program.

(1) NORMAL2 mode

In this mode, the CPU core operates with the high-frequency clock. On-chip peripherals operate using the high-frequency clock and/or low-frequency clock.

(2) SLOW2 mode

In this mode, the CPU core operates with the low-frequency clock, while both the high-frequency clock and the low-frequency clock are operated. As the SYSCR2<SYSCK> becomes "1", the hardware changes into SLOW2 mode. As the SYSCR2<SYSCK> becomes "0", the hardware changes into NOR-MAL2 mode. As the SYSCR2<XEN> becomes "0", the hardware changes into SLOW1 mode. Do not clear SYSCR2<XTEN> to "0" during SLOW2 mode.

(3) SLOW1 mode

This mode can be used to reduce power-consumption by turning off oscillation of the high-frequency clock. The CPU core and on-chip peripherals operate using the low-frequency clock.

Switching back and forth between SLOW1 and SLOW2 modes are performed by SYSCR2<XEN>. In SLOW1 and SLEEP modes, the input clock to the 1st stage of the divider is stopped; output from the 1st to 6th stages is also stopped.

(4) IDLE2 mode

In this mode, the internal oscillation circuit remain active. The CPU and the watchdog timer are halted; however, on-chip peripherals remain active (Operate using the high-frequency clock and/or the low-frequency clock). Starting and releasing of IDLE2 mode are the same as for IDLE1 mode, except that operation returns to NORMAL2 mode.

(5) SLEEP1 mode

In this mode, the internal oscillation circuit of the low-frequency clock remains active. The CPU, the watchdog timer, and the internal oscillation circuit of the high-frequency clock are halted; however, on-chip peripherals remain active (Operate using the low-frequency clock). Starting and releasing of SLEEP mode are the same as for IDLE1 mode, except that operation returns to SLOW1 mode. In SLOW1 and SLEEP1 modes, the input clock to the 1st stage of the divider is stopped; output from the 1st to 6th stages is also stopped.

(6) SLEEP2 mode

The SLEEP2 mode is the idle mode corresponding to the SLOW2 mode. The status under the SLEEP2 mode is same as that under the SLEEP1 mode, except for the oscillation circuit of the high-frequency clock.

(7) SLEEP0 mode

In this mode, all the circuit, except oscillator and the timer-base-timer, stops operation. This mode is enabled by setting "1" on bit SYSCR2<TGHALT>.

When SLEEP0 mode starts, the CPU stops and the timing generator stops feeding the clock to the peripheral circuits other than TBT. Then, upon detecting the falling edge of the source clock selected with TBTCR<TBTCK>, the timing generator starts feeding the clock to all peripheral circuits.


When returned from SLEEP0 mode, the CPU restarts operating, entering SLOW1 mode back again. SLEEP0 mode is entered and returned regardless of how TBTCR<TBTEN> is set. When IMF = "1", EF7 (TBT interrupt individual enable flag) = "1", and TBTCR<TBTEN> = "1", interrupt processing is performed. When SLEEP0 mode is entered while TBTCR<TBTEN> = "1", the INTTBT interrupt latch is set after returning to SLOW1 mode.

2.2.3.3 STOP mode

In this mode, the internal oscillation circuit is turned off, causing all system operations to be halted. The internal status immediately prior to the halt is held with a lowest power consumption during STOP mode.

STOP mode is started by the system control register 1 (SYSCR1), and STOP mode is released by a inputting (Either level-sensitive or edge-sensitive can be programmable selected) to the $\overline{\text{STOP}}$ pin. After the warm-up period is completed, the execution resumes with the instruction which follows the STOP mode start instruction.

2.2.3.4 Operating Mode Transition



Note 1: NORMAL1 and NORMAL2 modes are generically called NORMAL; SLOW1 and SLOW2 are called SLOW; IDLE0, IDLE1 and IDLE2 are called IDLE; SLEEP0, SLEEP1 and SLEEP2 are called SLEEP.

Note 2: The mode is released by falling edge of TBTCR<TBTCK> setting.

Figure 2-6 Operating Mode Transition Diagram

Table 2-1 Operating Mode and Conditions

		Osci	llator				AD	Power-on Rest	Other	Marilia
Operat	ting Mode	High Frequency	Low Frequency	CPU Core	WDT	ТВТ	Converter	Voltage Detect Reset	Peripherals	Machine Cycle Time
	RESET			Reset	Reset	Reset	Reset		Reset	
	NORMAL1	Oscillation		Operate	Operate		Operate		Operate	4/fo [o]
Single clock	IDLE1	Oscillation	Stop			Operate	Operate	Operate	Operate	4/fc [s]
	IDLE0			Halt	Halt		Halt		Halt	
	STOP	Stop				Halt	Hait			-
	NORMAL2			Operate with High-freq.	Operate with High or Low- freq.		Operate			4/fs [s]
	IDLE2	Oscillation		Halt	Halt					
	SLOW2		Oscillation	Operate with Low-freq.	Operate with Low-freq.	Operate			Operate	
Dual clock	SLEEP2		Oscillation	Halt	Halt	Operate		Operate		
	SLOW1			Operate with Low-freq.	Operate with Low-freq.		Halt			4/fs [s]
	SLEEP1	Stop								
	SLEEP0	, "		Halt	Halt				Halt	
	STOP		Stop			Halt	Halt		пак	-

TMP86FH92DMG

2.2.4 Operating Mode Control

System Control Register 1

SYSCR1	7	6	5	4	3	2	_ 1	0	
(0038H)	STOP	RELM	RETM	OUTEN	W	UT			(Initial value: 0000 00**)

STOP	STOP mode start	CPU core and peripherals remain active CPU core and peripherals are halted (Start STOP mode)					
RELM	Release method for STOP mode	ı	0: Edge-sensitive release 1: Level-sensitive release				
RETM	Operating mode after STOP mode	0: Return to NORMAL1/2 mode 1: Return to SLOW1 mode					
OUTEN	Port output during STOP mode	0: High impedance 1: Output kept					
			Return to NORMAL mode	Return to SLOW mode			
WUT	Warm-up time at releasing STOP mode	00 01 10	3 x 2 ¹⁶ /fc 2 ¹⁶ /fc 3 x 2 ¹⁴ /fc	3 x 2 ¹³ /fs 2 ¹³ /fs 3 x 2 ⁶ /fs	R/W		
			2 ¹⁴ /fc	2 ⁶ /fs			

- Note 1: Always set RETM to "0" when transiting from NORMAL mode to STOP mode. Always set RETM to "1" when transiting from SLOW mode to STOP mode.
- Note 2: When STOP mode is released with RESET pin input, a return is made to NORMAL1 regardless of the RETM contents.
- Note 3: fc: High-frequency clock [Hz], fs: Low-frequency clock [Hz], *; Don't care
- Note 4: Bits 0 and 1 in SYSCR1 are read as undefined data when a read instruction is executed.
- Note 5: As the hardware becomes STOP mode under OUTEN = "0", input value is fixed to "0"; therefore it may cause external interrupt request on account of falling edge.
- Note 6: When the key-on wakeup is used, RELM should be set to "1".
- Note 7: In case of setting as STOP mode is released by a rising edge of STOP pin input, the release setting by STOP5 to STOP2 on STOPCR register is prohibited.
- Note 8: Port P20 is used as STOP pin. Therefore, when stop mode is started, OUTEN does not affect to P20, and P20 becomes High-Z mode.
- Note 9: The warming-up time should be set correctly for using oscillator.

System Control Register 2

SYSCR2	7	6	5	4	3	2	1	0	
(0039H)	XEN	XTEN	SYSCK	IDLE		TGHALT			(Initial value: 1000 *0**)

XEN	High-frequency oscillator control	0: Turn off oscillation 1: Turn on oscillation		
XTEN	Low-frequency oscillator control	0: Turn off oscillation 1: Turn on oscillation		
SYSCK	Main system clock select (Write)/ main system clock monitor (Read)	0: High-frequency clock (NORMAL1/NORMAL2/IDLE1/IDLE2) 1: Low-frequency clock (SLOW1/SLOW2/SLEEP1/SLEEP2)		
IDLE	CPU and watchdog timer control (IDLE1/2 and SLEEP1/2 modes)	0: CPU and watchdog timer remain active 1: CPU and watchdog timer are stopped (Start IDLE1/2 and SLEEP1/2 modes)		
TGHALT	TG control (IDLE0 and SLEEP0 modes)	0: Feeding clock to all peripherals from TG 1: Stop feeding clock to peripherals except TBT from TG. (Start IDLE0 and SLEEP0 modes)	R/W	

- Note 1: A reset is applied if both XEN and XTEN are cleared to "0", XEN is cleared to "0" when SYSCK = "0", or XTEN is cleared to "0" when SYSCK = "1".
- Note 2: *: Don't care, TG: Timing generator.
- Note 3: Bits 3, 1 and 0 in SYSCR2 are always read as undefined value.

- Note 4: Do not set IDLE and TGHALT to "1" simultaneously.
- Note 5: Because returning from IDLE0/SLEEP0 to NORMAL1/SLOW1 is executed by the asynchronous internal clock, the period of IDLE0/SLEEP0 mode might be shorter than the period setting by TBTCR<TBTCK>.
- Note 6: When IDLE1/2 or SLEEP1/2 mode is released, IDLE is automatically cleared to "0".
- Note 7: When IDLE0 or SLEEP0 mode is released, TGHALT is automatically cleared to "0".
- Note 8: Before setting TGHALT to "1", be sure to stop peripherals. If peripherals are not stopped, the interrupt latch of peripherals may be set after IDLE0 or SLEEP0 mode is released.

2.2.4.1 STOP mode

STOP mode is controlled by the system control register 1, the $\overline{\text{STOP}}$ pin input and key-on wakeup input (STOP5 to STOP2) which are controlled by the STOP mode release control register (STOPCR).

The STOP pin is also used both as a port P20 and an INT5 (external interrupt input 5) pin. STOP mode is started by setting SYSCR1<STOP> to "1". During STOP mode, the following status is maintained.

- 1. Oscillations are turned off, and all internal operations are halted.
- 2. The data memory, registers, the program status word and port output latches are all held in the status in effect before STOP mode was entered.
- 3. The prescaler and the divider of the timing generator are cleared to "0".
- 4. The program counter holds the address 2 ahead of the instruction (e.g., [SET (SYSCR1).7]) which started STOP mode.

STOP mode includes a level-sensitive mode and an edge-sensitive mode, either of which can be selected with the SYSCR1<RELM>. Do not use any key-on wakeup input (STOP5 to STOP2) for releasing STOP mode in edge-sensitive mode.

- Note 1: The STOP mode can be released by either the STOP or key-on wakeup pins (STOP5 to STOP2). However, because the STOP pin is different from the key-on wakeup and can not inhibit the release input, the STOP pin must be used for releasing STOP mode.
- Note 2: During STOP period (from start of STOP mode to end of warm up), due to changes in the external interrupt pin signal, interrupt latches may be set to "1" and interrupts may be accepted immediately after STOP mode is released. Before starting STOP mode, therefore, disable interrupts. Also, before enabling interrupts after STOP mode is released, clear unnecessary interrupt latches.

(1) Level-sensitive release mode (RELM = "1")

In this mode, STOP mode is released by setting the STOP pin high or detecting high or low edge input for the STOP5 to STOP2 pins which are enabled by STOPCR. This mode is used for capacitor backup when the main power supply is cut off and long term battery backup.

Even if an instruction for starting STOP mode is executed while STOP pin input is high, STOP mode does not start but instead the warm-up sequence starts immediately. Thus, to start STOP mode in the level-sensitive release mode, it is necessary for the program to first confirm that the STOP pin input is low and the STOP5 to STOP2 inputs are high. The following two methods can be used for confirmation.

- 1. Testing a port.
- 2. Using an external interrupt input INT5 (INT5 is a falling edge-sensitive input).


Example 1: Starting STOP mode from NORMAL mode by testing a port P20.

	LD	(SYSCR1), 01010000B	; Sets up the level-sensitive release mode
SSTOPH:	TEST	(P2PRD). 0	; Wait until the $\overline{\rm STOP}$ pin input goes low level
	JRS	F, SSTOPH	
	DI		; IMF ← 0
	SET	(SYSCR1). 7	; Starts STOP mode

2. Operational Description

2.2 System Clock Controller TMP86FH92DMG

Example 2: Starting STOP mode from NORMAL mode with an INT5 interrupt.



Confirm by program that the

STOP mode.

STOP pin input is low and start

Figure 2-7 Level-sensitive Release Mode

Note 1: Even if the \$\overline{STOP}\$ pin input is low or the STOP5 to STOP2 pin inputs are high after warm-up start, the STOP mode is not restarted.

STOP mode is released by the hardware.

Always released if the STOP

pin input is high.

Note 2: In this case of changing to the level-sensitive mode from the edge-sensitive mode, the release mode is not switched until a rising edge of the \$\overline{STOP}\$ pin input is detected.

(2) Edge-sensitive release mode (RELM = "0")

In this mode, STOP mode is released by a rising edge of the \overline{STOP} pin input. This is used in applications where a relatively short program is executed repeatedly at periodic intervals. This periodic signal (for example, a clock from a low-power consumption oscillator) is input to the \overline{STOP} pin. In the edge-sensitive release mode, STOP mode is started even when the \overline{STOP} pin input is high level. Do not use any STOP5 to STOP2 pin inputs for releasing STOP mode in edge-sensitive release mode.

Example: Starting STOP mode from NORMAL mode

DI ; IMF \leftarrow 0 LD (SYSCR1), 10010000B ; Starts after specified to the edge-sensitive release mode




Figure 2-8 Edge-sensitive Release Mode

STOP mode is released by the following sequence.

- In the dual-clock mode, when returning to NORMAL2, both the high-frequency and low-frequency clock oscillators are turned on; when returning to SLOW1 mode, only the low-frequency clock oscillator is turned on. In the single-clock mode, only the high-frequency clock oscillator is turned on.
- 2. A warm-up period is inserted to allow oscillation time to stabilize. During warm up, all internal operations remain halted. Four different warm-up times can be selected with the SYSCR1<WUT> in accordance with the resonator characteristics.
- 3. When the warm-up time has elapsed, normal operation resumes with the instruction following the STOP mode start instruction.
- Note 1: When the STOP mode is released, the start is made after the prescaler and the divider of the timing generator are cleared to "0".
- Note 2: STOP mode can also be released by inputting low level on the RESET pin, which immediately performs the normal reset operation.
- Note 3: When STOP mode is released with a low hold voltage, the following cautions must be observed.

 The power supply voltage must be at the operating voltage level before releasing STOP mode.

 The RESET pin input must also be "H" level, rising together with the power supply voltage. In this case, if an external time constant circuit has been connected, the RESET pin input voltage will increase at a slower pace than the power supply voltage. At this time, there is a danger that a reset may occur if input voltage level of the RESET pin drops below the non-inverting high-level input voltage (Hysteresis input).

Table 2-2 Warm-up Time Example (at fc = 16.0 MHz, fs = 32.768 kHz)

\A/LIT	Warm-up Time [ms]				
WUT	Return to NORMAL Mode	Return to SLOW Mode			
00	12.288	750			
01	4.096	250			
10	3.072	5.85			
11	1.024	1.95			

Note 1: The warm-up time is obtained by dividing the basic clock by the divider. Therefore, the warm-up time may include a certain amount of error if there is any fluctuation of the oscillation frequency when STOP mode is released. Thus, the warm-up time must be considered as an approximate value.




Figure 2-9 STOP Mode Start/Release

2.2.4.2 IDLE1/2 mode and SLEEP1/2 mode

IDLE1/2 and SLEEP1/2 modes are controlled by the system control register 2 (SYSCR2) and maskable interrupts. The following status is maintained during these modes.

- 1. Operation of the CPU and watchdog timer (WDT) is halted. On-chip peripherals continue to operate.
- 2. The data memory, CPU registers, program status word and port output latches are all held in the status in effect before these modes were entered.
- 3. The program counter holds the address 2 ahead of the instruction which starts these modes.




Figure 2-10 IDLE1/2 and SLEEP1/2 Modes

TMP86FH92DMG

• Start the IDLE1/2 and SLEEP1/2 modes

After IMF is set to "0", set the individual interrupt enable flag (EF) which releases IDLE1/2 and SLEEP1/2 modes. To start IDLE1/2 and SLEEP1/2 modes, set SYSCR2<IDLE> to "1".

• Release the IDLE1/2 and SLEEP1/2 modes

IDLE1/2 and SLEEP1/2 modes include a normal release mode and an interrupt release mode. These modes are selected by interrupt master enable flag (IMF). After releasing IDLE1/2 and SLEEP1/2 modes, the SYSCR2<IDLE> is automatically cleared to "0" and the operation mode is returned to the mode preceding IDLE1/2 and SLEEP1/2 modes.

IDLE1/2 and SLEEP1/2 modes can also be released by inputting low level on the \overline{RESET} pin. After releasing reset, the operation mode is started from NORMAL1 mode.

(1) Normal release mode (IMF = "0")

IDLE1/2 and SLEEP1/2 modes are released by any interrupt source enabled by the individual interrupt enable flag (EF). After the interrupt is generated, the program operation is resumed from the instruction following the IDLE1/2 and SLEEP1/2 modes start instruction. Normally, the interrupt latches (IL) of the interrupt source used for releasing must be cleared to "0" by load instructions.

(2) Interrupt release mode (IMF = "1")

IDLE1/2 and SLEEP1/2 modes are released by any interrupt source enabled with the individual interrupt enable flag (EF) and the interrupt processing is started. After the interrupt is processed, the program operation is resumed from the instruction following the instruction, which starts IDLE1/2 and SLEEP1/2 modes.

Note: When a watchdog timer interrupts is generated immediately before IDLE1/2 and SLEEP1/2 modes are started, the watchdog timer interrupt will be processed but IDLE1/2 and SLEEP1/2 modes will not be started.




Figure 2-11 IDLE1/2 and SLEEP1/2 Modes Start/Release

2.2.4.3 IDLE0 and SLEEP0 modes (IDLE0, SLEEP0)

IDLE0 and SLEEP0 modes are controlled by the system control register 2 (SYSCR2) and the time base timer control register (TBTCR). The following status is maintained during IDLE0 and SLEEP0 modes.

- 1. Timing generator stops feeding clock to peripherals except TBT.
- 2. The data memory, CPU registers, program status word and port output latches are all held in the status in effect before IDLE0 and SLEEP0 modes were entered.
- 3. The program counter holds the address 2 ahead of the instruction which starts IDLE0 and SLEEP0 modes.

Note: Before starting IDLE0 or SLEEP0 mode, be sure to stop (Disable) peripherals.




Figure 2-12 IDLE0 and SLEEP0 Modes

• Start the IDLE0 and SLEEP0 mode s

Stop (Disable) peripherals such as a timer counter.

To start IDLE0 and SLEEP0 mode s, set SYSCR2<TGHALT> to "1".

Release the IDLE0 and SLEEP0 mode s

IDLE0 and SLEEP0 mode s include a normal release mode and an interrupt release mode.

These modes are selected by interrupt master flag (IMF), the individual interrupt enable flag of TBT and TBTCR<TBTEN>.

After releasing IDLE0 and SLEEP0 mode s, the SYSCR2<TGHALT> is automatically cleared to "0" and the operation mode is returned to the mode preceding IDLE0 and SLEEP0 mode s. Before starting the IDLE0 or SLEEP0 mode, when the TBTCR<TBTEN> is set to "1", INTTBT interrupt latch is set to "1".

IDLE0 and SLEEP0 mode s can also be released by inputting low level on the \overline{RESET} pin. After releasing reset, the operation mode is started from NORMAL1 mode.

Note: IDLE0 and SLEEP0 mode s start/release without reference to TBTCR<TBTEN> setting.

(1) Normal release mode (IMF • EF7 • TBTCR<TBTEN> = "0")

IDLE0 and SLEEP0 mode s are released by the source clock falling edge, which is setting by the TBTCR<TBTCK>. After the falling edge is detected, the program operation is resumed from the instruction following the IDLE0 and SLEEP0 mode s start instruction. Before starting the IDLE0 or SLEEP0 mode, when the TBTCR<TBTEN> is set to "1", INTTBT interrupt latch is set to "1".

(2) Interrupt release mode (IMF • EF7 • TBTCR<TBTEN> = "1")

IDLE0 and SLEEP0 mode s are released by the source clock falling edge, which is setting by the TBTCR<TBTCK> and INTTBT interrupt processing is started.

- Note 1: Because returning from IDLE0, SLEEP0 to NORMAL1, SLOW1 is executed by the asynchronous internal clock, the period of IDLE0, SLEEP0 mode might be the shorter than the period setting by TBTCR<TBTCK>.
- Note 2: When a watchdog timer interrupt is generated immediately before IDLE0/SLEEP0 mode is started, the watchdog timer interrupt will be processed but IDLE0/SLEEP0 mode will not be started.




Figure 2-13 IDLE0 and SLEEP0 Modes Start/Release

2.2.4.4 SLOW mode

SLOW mode is controlled by the system control register 2 (SYSCR2).

The following is the methods to switch the mode with the warm-up counter.

(1) Switching from NORMAL2 mode to SLOW1 mode

First, set SYSCR2<SYSCK> to switch the main system clock to the low-frequency clock for SLOW2 mode. Next, clear SYSCR2<XEN> to turn off high-frequency oscillation.

Note: The high-frequency clock can be continued oscillation in order to return to NORMAL2 mode from SLOW mode quickly. Always turn off oscillation of high-frequency clock when switching from SLOW mode to stop mode.

When the low-frequency clock oscillation is unstable, wait until oscillation stabilizes before performing the above operations. The timer/counter (TC4,TC3) can conveniently be used to confirm that low-frequency clock oscillation has stabilized.

Example 1 :Switching from NORMAL2 mode to SLOW1 mode.

SET	(SYSCR2). 5	; SYSCR2 <sysck> ← 1</sysck>
		; (Switches the main system clock to the low-frequency clock for SLOW2)
CLR	(SYSCR2). 7	; SYSCR2 <xen> ← 0</xen>
		; (Turns off high-frequency oscillation)

Example 2 :Switching to the SLOW1 mode after low-frequency clock has stabilized.

	SET	(SYSCR2). 6	; SYSCR2 <xten> ← 1</xten>
	LD	(TC3CR), 43H	; Sets mode for TC4, 3 (16-bit mode, fs for source)
	LD	(TC4CR), 05H	; Sets warming-up counter mode
	LDW	(TTREG3), 8000H	; Sets warm-up time (Depend on oscillator accompanied)
	DI		; IMF ← 0
	SET	(EIRH). 7	; Enables INTTC4
	EI		; IMF ← 1
	SET	(TC4CR). 3	; Starts TC4, 3
	:		
PINTTC4:	CLR	(TC4CR). 3	; Stops TC4, 3
	SET	(SYSCR2). 5	; SYSCR2 <sysck> ← 1</sysck>
			; (Switches the main system clock to the low-frequency clock)
	CLR	(SYSCR2). 7	; SYSCR2 <xen> \leftarrow 0</xen>
			; (Turns off high-frequency oscillation)
	RETI		
	:		
VINTTC4:	DW	PINTTC4	; INTTC4 vector table

Operational Description


2.2 System Clock Controller TMP86FH92DMG

(2) Switching from SLOW1 mode to NORMAL2 mode

First, set SYSCR2<XEN> to turn on the high-frequency oscillation. When time for stabilization (Warm up) has been taken by the timer/counter (TC4,TC3), clear SYSCR2<SYSCK> to switch the main system clock to the high-frequency clock.

SLOW mode can also be released by inputting low level on the \overline{RESET} pin. After releasing reset, the operation mode is started from NORMAL1 mode.

Note: After SYSCR2<SYSCK> is cleared to 0, instructions are executed continuously by the low-frequency clock during synchronization period for high-frequency and low-frequency clocks.



Example :Switching from the SLOW1 mode to the NORMAL2 mode (fc = 16 MHz, warm-up time is 4.0 ms).

	SET	(SYSCR2). 7	; SYSCR2 <xen> ← 1 (Starts high-frequency oscillation)</xen>
	LD	(TC3CR), 63H	; Sets mode for TC4, 3 (16-bit mode, fc for source)
	LD	(TC4CR), 05H	; Sets warming-up counter mode
	LD	(TTREG4), 0F8H	; Sets warm-up time
	DI		; IMF ← 0
	SET	(EIRH). 7	; Enables INTTC4
	EI		; IMF ← 1
	SET	(TC4CR). 3	; Starts TC4, 3
	:		
PINTTC4:	CLR	(TC4CR). 3	; Stops TC4, 3
	CLR	(SYSCR2). 5	; SYSCR2 <sysck> ← 0</sysck>
			; (Switches the main system clock to the high-frequency clock)
	RETI		
	:		
VINTTC4:	DW	PINTTC4	; INTTC4 vector table




Figure 2-14 Switching between the NORMAL2 and SLOW Modes

2.3 Reset Circuit TMP86FH92DMG

2.3 Reset Circuit

The TMP86FH92DMG has types of reset generation procedures: An external reset input, an address trap reset, a watchdog timer reset and a system clock reset, voltage detect reset 1,voltage detection 2,power on reset, trimming data reset. Of these reset, the address trap reset, the watchdog timer and the system clock reset, voltage detect reset 1,voltage detection 2 are a malfunction reset. When the malfunction reset request is detected, reset occurs during the maximum 24/fc[s].

The power-on reset signal and trimming data reset signal are input to the power-on warming-up reset circuit, which causes the device to enter a reset state. After the power-on warming-up time (tPOWUP) has elapsed, the reset is released. For details, refer to the section on the power-on reset circuit.

Table 2-3 shows on-chip hardware initialization by reset action.

Table 2-3 On-chip hardware Initialization by Reset Action

On-chip Hardware		Initial Value	On-chip Hardware	Initial Value	
Program counter	(PC)	(FFFEH)			
Stack pointer	(SP)	Not initialized	Prescaler and divider of timing generator	0	
General-purpose registers (W, A, B, C, D, E, H, L, IX, IY)		Not initialized	Watchdog timer	Enable	
Jump status flag	(JF)	Not initialized	voltage detection circuit	Disable	
Zero flag	(ZF)	Not initialized			
Carry flag	(CF)	Not initialized			
Half carry flag	(HF)	Not initialized	Output latches of I/O ports	Refer to I/O port circuitry	
Sign flag	(SF)	Not initialized			
Overflow flag	(VF)	Not initialized			
Interrupt master enable flag	(IMF)	0	Control or sinters	Refer to each of control	
Interrupt individual enable flags	(EF)	0	Control registers	register	
Interrupt latches	(IL)	0	RAM	Not initialized	

2.3.1 External Reset Input

The RESET pin contains a Schmitt trigger (Hysteresis) with an internal pull-up resistor.

When the \overline{RESET} pin is held at "L" level for at least 3 machine cycles (12/fc [s]) with the power supply voltage within the operating voltage range and oscillation stable, a reset is applied and the internal state is initialized.

When the \overline{RESET} pin input goes high, the reset operation is released and the program execution starts at the vector address stored at addresses FFFEH to FFFFH.





Figure 2-15 Reset Circuit

2.3.2 Address trap reset

If the CPU should start looping for some cause such as noise and an attempt be made to fetch an instruction from the on-chip RAM (when WDTCR1<ATAS> is set to "1"), DBR or SFR area, address trap reset will be generated. The reset time is maximum 24/fc[s] (1.5µs at 16.0 MHz).

Note: The operating mode under address trapped is alternative of reset or interrupt. The address trap area is alternative.



Note 1: Address "a" is on-chip RAM (WDTCR1<ATAS> = "1") space, DBR or SFR area.

Note 2: During reset release, reset vector "r" is read out, and an instruction at address "r" is fetched and decoded.

Figure 2-16 Address Trap Reset

2.3.3 Watchdog timer reset

Refer to Section "Watchdog Timer".

2.3.4 System clock reset

If the condition as follows is detected, the system clock reset occurs automatically to prevent dead lock of the CPU. (The oscillation is continued without stopping.)

- In case of clearing SYSCR2<XEN> and SYSCR2<XTEN> simultaneously to "0".
- In case of clearing SYSCR2<XEN> to "0", when the SYSCR2<SYSCK> is "0".
- In case of clearing SYSCR2<XEN>to "1"when the SYSCR2<XTEN> is "0".

The reset time is maximum 24/fc[s] (1.5 µs at 16.0 MHz).

2.3 Reset Circuit TMP86FH92DMG

2.3.5 Power-on Reset

A power-on reset is generated internally when the supply voltage (VDD) is turned on.

Refer to Section "Power on reset".

2.3.6 Voltage detection reset

A voltage detection reset is generated internally when the supply voltage (VDD) falls below the predefined threshold voltage.

Refer to Section "Voltage detection circuit".

2.3.7 Trimming data reset

Trimming data bits are provided for adjusting the ladder resistor used to generate the reference voltages for the power-on reset signal and voltage detecting signal. These bits are read from the flash memory and latched internally during the power-on warming up period (tPOWUP). The trimming data reset is generated if the trimming data is corrupted due to noise or other causes. A supply voltage reset is generated internally when the supply voltage (VDD) falls below the predefined threshold voltage.

TMP86FH92DMG

2.4 Internal Reset Detection Flags

After an internal reset is released, the cause of this internal reset can be identified by reading the internal reset detection flag register (IRSCR). IRSCR<SYSRSF> corresponds to system clock reset, IRSCR<ADTRF> to address trap reset, IRSCR<WDTF> to watchdog timer reset, and IRSCR<CLKSF> to clock stop detection reset. Each of these bits is set to "1" when the corresponding reset is generated.

To clear IRSCR<SYSRSF, ADTRF, WDTF, CLKSF> to "0", write "1" in IRSCR<FCLR> or set the RESET pin (external reset) to "L" level

Internal Reset Detection Flag Register

IRSTSR	7	6	5	4	3	2	1	0	
(0019H)	RFCLR	-	TRMRF L	.VD2RF	LVD1RF	SYSRF	WDTF	ADTRF	(Initial value: 0*00 0000)

RFCLR	Reset flag of initialized	O: Initial state 1: Internal request reset flag to "0"	write
TRMRF	Trimming data reset de- tection flag	0: Initial state 1:Triming data reset detection flag	only
LVD2RF	Voltage detection2 reset flag	O: Initial state 1: Voltage detection2 reset detected	
LVD1RF	Voltage detection1 reset flag	O: Initial state 1: Voltage detection1 reset detected	
SYSRF	System clock reset de- tection flag	0: Initial state 1: System clock reset detected	Read only
WDTF	Watchdog timer reset flag	0: Initial state 1: Watch dog reset detected	
ADTRF	Address latch reset detection flag	O: Initial state 1: Address trap reset detected	

2.4 Internal Reset Detection Flags

TMP86FH92DMG

3. Interrupt Control Circuit

The TMP86FH92DMG has a total of 22 interrupt sources excluding reset. Interrupts can be nested with priorities. Four of the internal interrupt sources are non-maskable while the rest are maskable.

Interrupt sources are provided with interrupt latches (IL), which hold interrupt requests, and independent vectors. The interrupt latch is set to "1" by the generation of its interrupt request which requests the CPU to accept its interrupts. Interrupts are enabled or disabled by software using the interrupt master enable flag (IMF) and interrupt enable flag (EF). If more than one interrupts are generated simultaneously, interrupts are accepted in order which is dominated by hardware. However, there are no prioritized interrupt factors among non-maskable interrupts.

	Interrupt Factors	Enable Condition	Interrupt Latch	Vector Ad- dress	Priority
Internal/External	(Reset)	Non-maskable	-	FFFE	1
Internal	INTSWI (Software interrupt)	Non-maskable	-	FFFC	2
Internal	INTUNDEF (Executed the undefined instruction interrupt)	Non-maskable	-	FFFC	2
Internal	INTATRAP (Address trap interrupt)	Non-maskable	IL2	FFFA	3
Internal	INTWDT (Watchdog timer interrupt)	Non-maskable	IL3	FFF8	4
Internal	INTVLTD	IMF • EF4 = 1	IL4	FFF6	5
External	ĪNT0	IMF • EF5 = 1, INT0EN =1	IL5	FFF4	6
External	INT1	IMF • EF6 = 1	IL6	FFF2	7
Internal	INTTBT	IMF • EF7 = 1	IL7	FFF0	8
Internal	INTSBI	IMF • EF8 = 1	IL8	FFEE	9
Internal	INTRXD1	IMF • EF9 = 1	IL9	FFEC	10
Internal	INTTXD1	IMF • EF10 = 1	IL10	FFEA	11
Internal	INTTC1	IMF • EF11 = 1	IL11	FFE8	12
Internal	INTRXD2	IMF • EF12 = 1	IL12	FFE6	13
Internal	INTTXD2	IMF • EF13 = 1	IL13	FFE4	14
Internal	INTTC3	IMF • EF14 = 1	IL14	FFE2	15
Internal	INTTC4	IMF • EF15 = 1	IL15	FFE0	16
External	INT3	IMF • EF16 = 1	IL16	FFBE	17
Internal	INTADC	IMF • EF17 = 1	IL17	FFBC	18
Internal	INTSEI0	IMF • EF18 = 1	IL18	FFBA	19
Internal	INTSEI1	IMF • EF19 = 1	IL19	FFB8	20
External	INT4	IMF • EF20 = 1	IL20	FFB6	21
External	ĪNT5	IMF • EF21 = 1	IL21	FFB4	22
-	Reserved	IMF • EF22 = 1	IL22	FFB2	23
-	Reserved	IMF • EF23 = 1	IL23	FFB0	24

Note 1: To use the address trap interrupt (INTATRAP), clear WDTCR1<ATOUT> to "0" (It is set for the "reset request" after reset is cancelled). For details, see "Address Trap".

Note 2: To use the watchdog timer interrupt (INTWDT), clear WDTCR1<WDTOUT> to "0" (It is set for the "Reset request" after reset is released). For details, see "Watchdog Timer".

3.1 Interrupt latches (IL21 to IL2)

An interrupt latch is provided for each interrupt source, except for a software interrupt and an executed the undefined instruction interrupt. When interrupt request is generated, the latch is set to "1", and the CPU is requested to accept the interrupt if its interrupt is enabled. The interrupt latch is cleared to "0" immediately after accepting interrupt. All interrupt latches are initialized to "0" during reset.

The interrupt latches are located on address 003CH, 003DH, and 003EH in SFR area. Each latch can be cleared to "0" individually by instruction. However, IL2 and IL3 should not be cleared to "0" by software. For clearing the interrupt latch, load instruction should be used and then IL2 and IL3 should be set to "1". If the read-modify-write instructions such as bit manipulation or operation instructions are used, interrupt request would be cleared inadequately if interrupt is requested while such instructions are executed.

Interrupt latches are not set to "1" by an instruction.

Since interrupt latches can be read, the status for interrupt requests can be monitored by software.

Note: In main program, before manipulating the interrupt enable flag (EF) or the interrupt latch (IL), be sure to clear IMF to "0" (Disable interrupt by DI instruction). Then set IMF newly again as required after operating on the EF or IL (Enable interrupt by EI instruction)

In interrupt service routine, because the IMF becomes "0" automatically, clearing IMF need not execute normally on interrupt service routine. However, if using multiple interrupt on interrupt service routine, manipulating EF or IL should be executed before setting IMF="1".

Example 1 :Clears interrupt latches

DI ; IMF← 0

LDW (ILL), 11101000001111111B ; IL12, IL10 to IL6← 0

EI ; IMF ← 1

Example 2 :Reads interrupt latches

LD WA, (ILL) ; $W \leftarrow ILH$, $A \leftarrow ILL$

Example 3: Tests interrupt latches

TEST (ILL). 7 ; if IL7 = 1 then jump

JR F, SSET

3.2 Interrupt enable register (EIR)

The interrupt enable register (EIR) enables and disables the acceptance of interrupts, except for the non-maskable interrupts (Software interrupt, undefined instruction interrupt, address trap interrupt and watchdog interrupt). Non-maskable interrupt is accepted regardless of the contents of the EIR.

The EIR consists of an interrupt master enable flag (IMF) and the individual interrupt enable flags (EF). These registers are located on address 003AH, 003BH, and 0032H in SFR area, and they can be read and written by an instructions (Including read-modify-write instructions such as bit manipulation or operation instructions).

3.2.1 Interrupt master enable flag (IMF)

The interrupt enable register (IMF) enables and disables the acceptance of the whole maskable interrupt. While IMF = "0", all maskable interrupts are not accepted regardless of the status on each individual interrupt enable flag (EF). By setting IMF to "1", the interrupt becomes acceptable if the individuals are enabled. When an interrupt is accepted, IMF is cleared to "0" after the latest status on IMF is stacked. Thus the maskable interrupts which follow are disabled. By executing return interrupt instruction [RETI/RETN], the stacked data, which was the status before interrupt acceptance, is loaded on IMF again.

TMP86FH92DMG

The IMF is located on bit0 in EIRL (Address: 003AH in SFR), and can be read and written by an instruction. The IMF is normally set and cleared by [EI] and [DI] instruction respectively. During reset, the IMF is initialized to "0".

3.2.2 Individual interrupt enable flags (EF21 to EF4)

Each of these flags enables and disables the acceptance of its maskable interrupt. Setting the corresponding bit of an individual interrupt enable flag to "1" enables acceptance of its interrupt, and setting the bit to "0" disables acceptance. During reset, all the individual interrupt enable flags (EF21 to EF4) are initialized to "0" and all maskable interrupts are not accepted until they are set to "1".

Note: In main program, before manipulating the interrupt enable flag (EF) or the interrupt latch (IL), be sure to clear IMF to "0" (Disable interrupt by DI instruction). Then set IMF newly again as required after operating on the EF or IL (Enable interrupt by EI instruction)


In interrupt service routine, because the IMF becomes "0" automatically, clearing IMF need not execute normally on interrupt service routine. However, if using multiple interrupt on interrupt service routine, manipulating EF or IL should be executed before setting IMF="1".

Example 1: Enables interrupts individually and sets IMF

```
DI ; IMF \leftarrow 0 
 LDW (EIRL), 1110100010100000B ; EF15 to EF13, EF11, EF7, EF5 \leftarrow 1 
 : Note: IMF should not be set. 
 : 
 EI ; IMF \leftarrow 1
```

Example 2: C compiler description example

Interrupt Latches



Note 1: To clear any one of bits IL7 to IL4, be sure to write "1" into IL2 and IL3.


Interrupt Sequence TMP86FH92DMG

Note 2: In main program, before manipulating the interrupt enable flag (EF) or the interrupt latch (IL), be sure to clear IMF to "0" (Disable interrupt by DI instruction). Then set IMF newly again as required after operating on the EF or IL (Enable interrupt by EI instruction)

In interrupt service routine, because the IMF becomes "0" automatically, clearing IMF need not execute normally on interrupt service routine. However, if using multiple interrupt on interrupt service routine, manipulating EF or IL should be executed before setting IMF="1".

Note 3: Do not clear IL with read-modify-write instructions such as bit operations.

Interrupt Enable Registers



Note 1: *: Don't care

Note 2: Do not set IMF and the interrupt enable flag (EF15 to EF4) to "1" at the same time.

Note 3: In main program, before manipulating the interrupt enable flag (EF) or the interrupt latch (IL), be sure to clear IMF to "0" (Disable interrupt by DI instruction). Then set IMF newly again as required after operating on the EF or IL (Enable interrupt by EI instruction)

In interrupt service routine, because the IMF becomes "0" automatically, clearing IMF need not execute normally on interrupt service routine. However, if using multiple interrupt on interrupt service routine, manipulating EF or IL should be executed before setting IMF="1".


3.3 Interrupt Sequence

An interrupt request, which raised interrupt latch, is held, until interrupt is accepted or interrupt latch is cleared to "0" by resetting or an instruction. Interrupt acceptance sequence requires 8 machine cycles (2 µs @16 MHz) after the completion of the current instruction. The interrupt service task terminates upon execution of an interrupt return instruction [RETI] (for maskable interrupts) or [RETN] (for non-maskable interrupts). Figure 3-1 shows the timing chart of interrupt acceptance processing.

3.3.1 Interrupt acceptance processing is packaged as follows.

- a. The interrupt master enable flag (IMF) is cleared to "0" in order to disable the acceptance of any following interrupt.
- b. The interrupt latch (IL) for the interrupt source accepted is cleared to "0".
- c. The contents of the program counter (PC) and the program status word, including the interrupt master enable flag (IMF), are saved (Pushed) on the stack in sequence of PSW + IMF, PCH, PCL. Meanwhile, the stack pointer (SP) is decremented by 3.
- d. The entry address (Interrupt vector) of the corresponding interrupt service program, loaded on the vector table, is transferred to the program counter.
- e. The instruction stored at the entry address of the interrupt service program is executed.

Note: When the contents of PSW are saved on the stack, the contents of IMF are also saved.



Note 1: a: Return address, b: Entry address, c: Address which RETI instruction is stored

Note 2: On condition that interrupt is enabled, it takes 38/fc [s] or 38/fs [s] at maximum (If the interrupt latch is set at the first machine cycle on 10 cycle instruction) to start interrupt acceptance processing since its interrupt latch is set.

Figure 3-1 Timing Chart of Interrupt Acceptance/Return Interrupt Instruction

Example: Correspondence between vector table address for INTTBT and the entry address of the interrupt service program



Figure 3-2 Vector Table Address and Entry Address

A maskable interrupt is not accepted until the IMF is set to "1" even if the maskable interrupt higher than the level of current servicing interrupt is requested.

In order to utilize nested interrupt service, the IMF is set to "1" in the interrupt service program. In this case, acceptable interrupt sources are selectively enabled by the individual interrupt enable flags.

To avoid overloaded nesting, clear the individual interrupt enable flag whose interrupt is currently serviced, before setting IMF to "1". As for non-maskable interrupt, keep interrupt service shorten compared with length between interrupt requests; otherwise the status cannot be recovered as non-maskable interrupt would simply nested.

3.3.2 Saving/restoring general-purpose registers

During interrupt acceptance processing, the program counter (PC) and the program status word (PSW, includes IMF) are automatically saved on the stack, but the accumulator and others are not. These registers are saved by software if necessary. When multiple interrupt services are nested, it is also necessary to avoid using the same data memory area for saving registers. The following methods are used to save/restore the general-purpose registers.

3. Interrupt Control Circuit

3 Interrupt Sequence TMP86FH92DMG

3.3.2.1 Using PUSH and POP instructions

If only a specific register is saved or interrupts of the same source are nested, general-purpose registers can be saved/restored using the PUSH/POP instructions.

Example :Save/store register using PUSH and POP instructions





Figure 3-3 Saving/Restoring General-purpose Registers under PUSH and POP instructions

3.3.2.2 Using data transfer instructions

To save only a specific register without nested interrupts, data transfer instructions are available.

Example :Save/store register using data transfer instructions

PINTxx:	LD	(GSAVA), A	; Save A register
	(interrupt p	processing)	
	LD	A, (GSAVA)	; Restore A register
	RETI		; RETURN



Saving/Restoring general-purpose registers using PUSH/POP data transfer instruction

Figure 3-4 Saving/Restoring General-purpose Registers under Interrupt Processing

3.4 Software Interrupt (INTSW)

3.3.3 Interrupt return

Interrupt return instructions [RETI]/[RETN] perform as follows.

[RETI]/[RETN] Interrupt Return

- 1. Program counter (PC) and program status word (PSW, includes IMF) are restored from the stack.
- 2. Stack pointer (SP) is incremented by 3.

As for address trap interrupt (INTATRAP), it is required to alter stacked data for program counter (PC) to restarting address, during interrupt service program.

Note: If [RETN] is executed with the above data unaltered, the program returns to the address trap area and INTATRAP occurs again. When interrupt acceptance processing has completed, stacked data for PCL and PCH are located on address (SP + 1) and (SP + 2) respectively.

Example 1 :Returning from address trap interrupt (INTATRAP) service program

PINTxx: POP WA ; Recover SP by 2

LD WA, Return Address

PUSH WA ; Alter stacked data

(interrupt processing)

RETN ; RETURN

Example 2: Restarting without returning interrupt

(In this case, PSW (Includes IMF) before interrupt acceptance is discarded.)

PINTxx: INC SP ; Recover SP by 3

INC SP ;

(interrupt processing)

LD EIRL, data ; Set IMF to "1" or clear it to "0"

JP Restart Address ; Jump into restarting address

Interrupt requests are sampled during the final cycle of the instruction being executed. Thus, the next interrupt can be accepted immediately after the interrupt return instruction is executed.

- Note 1: It is recommended that stack pointer be return to rate before INTATRAP (Increment 3 times), if return interrupt instruction [RETN] is not utilized during interrupt service program under INTATRAP (such as Example 2).
- Note 2: When the interrupt processing time is longer than the interrupt request generation time, the interrupt service task is performed but not the main task.

3.4 Software Interrupt (INTSW)

Executing the SWI instruction generates a software interrupt and immediately starts interrupt processing (INTSW is highest prioritized interrupt).

Use the SWI instruction only for detection of the address error or for debugging.

3.4.1 Address error detection

FFH is read if for some cause such as noise the CPU attempts to fetch an instruction from a non-existent memory address during single chip mode. Code FFH is the SWI instruction, so a software interrupt is generated

and an address error is detected. The address error detection range can be further expanded by writing FFH to unused areas of the program memory. Address trap reset is generated in case that an instruction is fetched from RAM, DBR or SFR areas.

3.4.2 Debugging

Debugging efficiency can be increased by placing the SWI instruction at the software break point setting address.

3.5 Undefined Instruction Interrupt (INTUNDEF)

Taking code which is not defined as authorized instruction for instruction causes INTUNDEF. INTUNDEF is generated when the CPU fetches such a code and tries to execute it. INTUNDEF is accepted even if non-maskable interrupt is in process. Contemporary process is broken and INTUNDEF interrupt process starts, soon after it is requested.

Note: The undefined instruction interrupt (INTUNDEF) forces CPU to jump into vector address, as software interrupt (SWI) does.

3.6 Address Trap Interrupt (INTATRAP)

Fetching instruction from unauthorized area for instructions (Address trapped area) causes reset output or address trap interrupt (INTATRAP). INTATRAP is accepted even if non-maskable interrupt is in process. Contemporary process is broken and INTATRAP interrupt process starts, soon after it is requested.

Note: The operating mode under address trapped, whether to be reset output or interrupt processing, is selected on watchdog timer control register (WDTCR).

3.7 External Interrupts

The TMP86FH92DMG has 5 external interrupt inputs. These inputs are equipped with digital noise reject circuits (Pulse inputs of less than a certain time are eliminated as noise).

Edge selection is also possible with INT1,INT3,INT4. The INT0/P10 pin can be configured as either an external interrupt input pin or an input/output port, and is configured as an input port during reset.

Edge selection, noise reject control and $\overline{\text{INT0}}/\text{P10}$ pin function selection are performed by the external interrupt control register (EINTCR).

Source	Pin	Enable Conditions	Release Edge (level)	Digital Noise Reject
INTO	ĪNT0	IMF × EF5 × INT0EN=1	Falling edge	Pulses of less than 2/fc [s] are eliminated as noise. Pulses of 7/fc [s] or more are considered to be signals. In the SLOW or the SLEEP mode, pulses of less than 1/fs [s] are eliminated as noise. Pulses of 3.5/fs [s] or more are considered to be signals.
INT1	INT1	IMF × EF6 = 1	Falling edge or Rising edge	Pulses of less than 15/fc or 63/fc [s] are eliminated as noise. Pulses of 49/fc or 193/fc [s] or more are considered to be signals. In the SLOW or the SLEEP mode, pulses of less than 1/fs [s] are eliminated as noise. Pulses of 3.5/fs [s] or more are considered to be signals.
INT3	INT3	IMF × EF16 = 1	Falling edge Rising edge Falling and Rising edge or H level	Pulses of less than 7/fc [s] are eliminated as noise. Pulses of 25/fc [s] or more are considered to be signals. In the SLOW or the SLEEP mode, pulses of less than 1/fs [s] are eliminated as noise. Pulses of 3.5/fs [s] or more are considered to be signals.
INT4	INT4	IMF × EF20 = 1	Falling edge Rising edge Falling and Rising edge or H level	Pulses of less than 7/fc [s] are eliminated as noise. Pulses of 25/fc [s] or more are considered to be signals. In the SLOW or the SLEEP mode, pulses of less than 1/fs [s] are eliminated as noise. Pulses of 3.5/fs [s] or more are considered to be signals.
INT5	ĪNT5	IMF × EF21 = 1	Falling edge	Pulses of less than 2/fc [s] are eliminated as noise. Pulses of 7/fc [s] or more are considered to be signals. In the SLOW or the SLEEP mode, pulses of less than 1/fs [s] are eliminated as noise. Pulses of 3.5/fs [s] or more are considered to be signals.

- Note 1: In NORMAL1/2 or IDLE1/2 mode, if a signal with no noise is input on an external interrupt pin, it takes a maximum of "signal establishment time + 6/fs[s]" from the input signal's edge to set the interrupt latch.
- Note 2: When INT0EN = "0", IL5 is not set even if a falling edge is detected on the $\overline{\text{INT0}}$ pin input.
- Note 3: When a pin with more than one function is used as an output and a change occurs in data or input/output status, an interrupt request signal is generated in a pseudo manner. In this case, it is necessary to perform appropriate processing such as disabling the interrupt enable flag.

External Interrupt Control Register

EINTCR	7	6	5	4	3	2	1	0	
(0037H)	INT1NC	INT0EN	INT	BES	INT4	1ES	INT1ES		(Initial value: 0000 000*)

INT1NC	Noise reject time select	O: Pulses of less than 63/fc [s] are eliminated as noise 1: Pulses of less than 15/fc [s] are eliminated as noise	R/W
INT0EN	P10/INT0 pin configuration	0: P10 input/output port 1: INTO pin (Port P10 should be set to an input mode)	R/W
INT4 ES	INT4 edge select	00: Rising edge 01: Falling edge 10: Rising edge and Falling edge 11: "H" level	R/W
INT3 ES	INT3 edge select	00: Rising edge 01: Falling edge 10: Rising edge and Falling edge 11: "H" level	R/W
INT1 ES	INT1 edge select	0: Rising edge 1: Falling edge	R/W

- Note 1: fc: High-frequency clock [Hz], *: Don't care
- Note 2: When the system clock frequency is switched between high and low or when the external interrupt control register (EINTCR) is overwritten, the noise canceller may not operate normally. It is recommended that external interrupts are disabled using the interrupt enable register (EIR).
- Note 3: The maximum time from modifying INT1NC until a noise reject time is changed is 26/fc.
- Note 4: In case RESET pin is released while the state of INT4 pin keeps "H" level, the external interrupt 4 request is not generated even if the INT4 edge select is specified as "H" level. The rising edge is needed after RESET pin is released.

3. Interrupt Control Circuit

3.7 External Interrupts TMP86FH92DMG

TOSHIBA TMP86FH92DMG

4. Special Function Register (SFR)

The TMP86FH92DMG adopts the memory mapped I/O system, and all peripheral control and data transfers are performed through the special function register (SFR) or the data buffer register (DBR). The SFR is mapped on address 0000H to 003FH, DBR is mapped on address 0F80H to 0FFFH.

This chapter shows the arrangement of the special function register (SFR) and data buffer register (DBR) for TMP86FH92DMG.

4.1 SFR

Address	Read Write				
0000H	POI	DR			
0001H	P1I	DR			
0002H	P2I	DR			
0003H	P3I	DR			
0004H	P0PU	JCR			
0005H	P1Pl	JCR			
0006Н	P2PI	JCR			
0007H	Rese	rved			
0008H	P3C	CR1			
0009H	P10L	ITCR			
000AH	P3C	CR2			
000BH	P0OL	ITCR			
000CH	P0PRD	-			
000DH	P2PRD	-			
000EH	ADC	CR1			
000FH	ADCCR2				
0010H	TC1DRAL				
0011H	TC1D	RAH			
0012H	TC1DRBL				
0013H	TC1DRBH				
0014H	TC1CR				
0015H	SBISRA	SBICRA			
0016H	SBIE	DBR			
0017H	-	I2CAR			
0018H	SBISRB	SBICRB			
0019H	IRS ⁻	rsr			
001AH	TC3	CR			
001BH	TC4	CR			
001CH	TTREG3				
001DH	TTR	EG4			
001EH	PWREG3				
001FH	PWREG4				
0020H	ADCDR2 -				
0021H	ADCDR1	-			
0022H	UART2SR	UART2CR1			
0023H	-	UART2CR2			
0024H	RD2BUF	TD2BUF			
0025H	UART1SR	UART1CR1			

4.1 SFR TMP86FH92DMG

Address	Read	Write			
0026H	-	UART1CR2			
0027H	RD1BUF	TD1BUF			
0028H	SESR	-			
0029H	SE	DR			
002AH	SE	CR			
002BH	VDC	CR1			
002CH	VDC	CR2			
002DH	P1PRD	-			
002EH	Rese	erved			
002FH	Rese	erved			
0030H	Rese	erved			
0031H	-	STOPCR			
0032H	EIRE				
0033H	Reserved				
0034H	-	WDTCR1			
0035H	-	WDTCR2			
0036H	TBTCR				
0037H	EINTCR				
0038H	SYSCR1				
0039H	SYSCR2				
003AH	EIRL				
003BH	EIRH				
003CH	ILL				
003DH	IL	H			
003EH	IL	E			
003FH	PS	SW SW			

Note 1: Do not access reserved areas by the program.

Note 2: -; Cannot be accessed.

Note 3: Write-only registers and interrupt latches cannot use the read-modify-write instructions (Bit manipulation instructions such as SET, CLR, etc. and logical operation instructions such as AND, OR, etc.).

4.2 DBR

Addross	Pond	Write		
Address	Read	Write		
0F80H	Rese			
::	: D			
0F9FH	Rese	rved		
Λ	2			
Address	Read	Write		
0FA0H	Rese	rved		
::	:	:		
0FBFH	Rese	rved		
Address	Read	Write		
0FC0H	Rese	rved		
::	:	:		
0FDFH	Rese	rved		
	-			
Address	Read	Write		
0FE0H	Rese	rved		
0FE1H	Rese	rved		
0FE2H	Rese	rved		
0FE3H	Rese	rved		
0FE4H	Rese	rved		
0FE5H	Rese	rved		
0FE6H	Rese	rved		
0FE7H	Rese	rved		
0FE8H	Rese	rved		
0FE9H	-	FLSSTB		
0FEAH	SP	CR		
0FEBH	Rese			
0FECH	Rese			
0FEDH	Rese			
0FEEH	Rese			
0FEFH	Rese			
0FF0H	Rese			
0FF1H	Rese			
0FF2H	Reserved Reserved			
0FF3H				
0FF4H 0FF5H	Reserved			
0FF6H	Reserved			
0FF7H	Reserved			
0FF8H	Reserved			
0FF9H	Reserved			
0FFAH	Reserved Reserved			
0FFBH	Rese			
0FFCH	Rese			
0FFDH	Rese			
OFFEH				
VFFERI	Reserved			

- 4. Special Function Register (SFR)
- 4.2 DBR TMP86FH92DMG

Address	Read	Write
0FFFH	FLS	SCR

- Note 1: Do not access reserved areas by the program.
- Note 2: -; Cannot be accessed.
- Note 3: Write-only registers and interrupt latches cannot use the read-modify-write instructions (Bit manipulation instructions such as SET, CLR, etc. and logical operation instructions such as AND, OR, etc.).

5. I/O Ports


The TMP86FH92DMG have 4 parallel input/output ports as follows.

	Primary Function	Secondary Functions
Port P0	8-bit I/O port	External interrupt input, Timer/Counter input/output, UART input/output, Serial expansion interface input/output and serial PROM mode control input.
Port P1	5-bit I/O port	External interrupt input, divider output, UART input/output and serial bus interface input/output
Port P2	3-bit I/O port	External interrupt input, STOP mode release signal input and low frequency resonator connection
Port P3	8-bit I/O port	Analog input, STOP mode release signal input and Timer/Counter input/output

Each output port contains a latch, which holds the output data. All input ports do not have latches, so the external input data should be externally held until the input data is read from outside or reading should be performed several timer before processing. Figure 5-1 shows input/output timing examples.

External data is read from an I/O port in the S1 state of the read cycle during execution of the read instruction. This timing cannot be recognized from outside, so that transient input such as chattering must be processed by the program.

Output data changes in the S2 state of the write cycle during execution of the instruction which writes to an I/O port.



Note: The positions of the read and write cycles may vary, depending on the instruction.

Figure 5-1 Input/Output Timing (Example)

5.1 P0 (P07 to P00) Port (High Current)

The P0 port is an 8-bit input/output port shared with external interrupt input, serial expansion interface input/output, UART1 input/output, timer counter input/output and serial PROM mode control input. When using this port as serial expansion interface output or UART1 output, set the output latch to 1. When using this port as a port output, the output latch data (P0DR) is output to the P0 port.

When reset, the output latch (P0DR) and the push-pull control register (P0OUTCR) are initialized to 1 and 0, respectively.

The P0 port allows its output circuit to be selected between N-channel open-drain output or push-pull output by the P0OUTCR register.

The P0 port has programmable internal Pull-up resistance to be controlled by P0PUCR registers.

When using this port as a port input, external interrupt input, serial expansion interface input, UART1 input and timer counter input, set the P0OUTCR register's corresponding bit to 0 after setting the P0DR to 1. The P0 port has independent data input registers. To inspect the output latch status, read the P0DR register. To inspect the pin status, read the P0PRD register.

In the serial PROM mode, P01 pin used as a BOOT/RXD1 pin, P00 pin used as a TXD1 pin. For details, see "Serial PROM Mode Setting".




Figure 5-2 P0 Port

P0DR	7	6	5	4	3	2	1	0		
(0000H)	P07	P06	P05	P04	P03	P02	P01	P00		
(000011) R/W	TC1	INT3	SS	MISO	MOSI	SCLK	RxD1	TxD1	(Initial value: 1111 1111)	
	INT4	PPG					воот			
P0OUTCR	7	6	5	4	3	2	1	0		
(000BH)									(Initial value: 0000 0000)	
R/W							ļ	Į.	1	
					0: Not	open-drair	output			
	P0OUTC		ort input/outp ified bitwise			h-pull outpu				R/W
ļ		1		-						<u> </u>
	7	6	5	4	3	2	1	0		
P0PUCR	•		Г			1	1		//pitial value, 0000 0000\	
(0004H) R/W									(Initial value: 0000 0000)	
1000										
ı										
	P0PUC		ort pull-up re		.	Pull-up resi				R/W
		trol (s	pecified bity	vise)	1: Pul	-up resistar	nce			
P0PRD	7	6	5	4	3	2	1	0	_	
(000CH)	P07	P06	P05	P04	P03	P02	P01	P00		
Read only			•			•			-	

5.2 P1 (P14 to P10) Port TMP86FH92DMG

5.2 P1 (P14 to P10) Port

The P1 port is a 5-bit input/output port shared with external interrupt input, divider output, UART2 input/output and serial bus interface input/output. When using this port as divider output, UART2 output and serial bus interface output, set the output latch to 1. When using this port as a port output, the output latch data(P1DR) is output to the P1 port.

When reset, the output latch (P1DR) and the push-pull control register(P1OUTCR) are initialized to 1 and 0,respectively.

The P1 allows its output circuit to be selected between N-channel open-drain or push-pull output by the P1OUTCR register.

The P1 port has programmable internal pull-up resistance to be controlled by P1PUCR.

When using this port as a port input, external interrupt input, UART2 input and serial bus interface input, set the P1OUTCR register's corresponding bit to 0 after setting the P1DR to 1.

The P1 port has independent data input registers. To inspect the output latch status, read the P1DR register. To inspect the pin status, read the P1PRD register.




Figure 5-3 P1 Port

1	O	5	4	3	2	ı	U		
			P14 TXD2 SCL	P13 RXD2 SDA	P12 DVO	P11 INT1	P10 INT0	(Initial value: ***1 1111)	
7	6	5	4	3	2	1	0	(Initial value: ***0 0000)	
P1OUTC				- 1	-	-			R/W
7	6	5	4	3	2	1	0	(Initial value: ***0 0000)	
		oort pull up r	raciatanaa a	ontrol	0: No Pull-un	resistance			
P1PUC					-				R/W
7	6	5	4	3	2	1	0	1	
			D1/	P13	D12	D11	D10		
	7 P10UTC 7	7 6 P10UTCR P1pc (special special spec	7 6 5 P1OUTCR P1port input/outp (specified bitwise) 7 6 5 P1PUCR P1 port pull-up r (specified bitwise)	P10UTCR P1port input/output control (specified bitwise) P1PUCR P1 port pull-up resistance c (specified bitwise)	P14 P13 TXD2 RXD2 SCL SDA 7 6 5 4 3 P10UTCR P1port input/output control (specified bitwise) 7 6 5 4 3 P1PUCR P1 port pull-up resistance control (specified bitwise) 7 6 5 4 3	P14	P14	P14 P13 RXD2 DVO INT1 P10 INT0	P14

Note: P13 and P14 can be used as the input/output for either UART2 or I²C bus control signals. Therefore, UART2 and serial bus interface cannot be used at the same time. These functions can be enabled and disabled in their respective function registers. UART2 and I²C bus cannot be enabled at the same time.

5.3 P2 (P22 to P20) Port TMP86FH92DMG

5.3 P2 (P22 to P20) Port

The P2 port is a 3-bit input/output port shared with external interrupt input, STOP mode release signal input, and low-frequency resonator connecting pin. When using this port as a port input or function pin, set the output latch to 1. The output latch is initialized to 1 when reset. When operating in dual-clock mode, connect a low-frequency resonator (32.768 kHz) to the P21 (XTIN) and P22 (XTOUT) pins. When operating in single-clock mode, the P21 and P22 pins can be used as ordinary input/output ports. We recommend using the P20 pin for external interrupt input or STOP mode release signal input or as a port input. (When used as a port output, the interrupt latch is set by a falling edge.)

The P2 port has independent data input registers. To inspect the output latch status, read the P2DR register. To inspect the pin status, read the P2PRD register. When the P2DR or P2PRD read instruction is executed for the P2 port, the values read from bits 7 to 3 are indeterminate.

The P20 port has programmable internal Pull-up resistance to be controlled by P2PUCR.




Figure 5-4 P2 Port

P2DR	7	6	5	4	3	2	1	0	_	
(0002H) R/W						P22 XTOUT	P21 XTIN	P20 INT5	(Initial value: **** *111)	
IVW								STOP		
P2PUCR	7	6	5	4	3	2	1	0		
(0006H)] (Initial value: **** ***0)	
R/W										
		P2 pc	ort pull-up re	sistance con	_ 0: No	Pull-up resis	stance			
	P2PUCR		specified bity		- 1	II-up resistan				R/W
	_							•		
P2PRD	7	6	5	4	3	2	1	0	1	
(000DH)						P22	P21	P20		
Read only							·		-	

Note: The P20 pin is shared with the $\overline{\text{STOP}}$ pin, so that when in STOP mode, its output goes to a High-Z state regardless of the OUTEN status.

5.4 P3 (P37 to P30) Port TMP86FH92DMG

5.4 P3 (P37 to P30) Port

The P3 port is an 8-bit input/output port that can be specified for input or output bitwise, and is shared with analog input and key-on wakeup input (KWI).

The P3 port input/output control registers P3CR1 and P3CR2 are used to specify the function of each pin. After reset, the P3CR1 and P3CR2 are initialized to 0 and 1, respectively, so the P3 port is configured for input mode. The P3 port output latches are initialized to 0.

To use each pin as a port output, set the corresponding bit in the P3CR1 to 1.

To use each pin as a port input, set the corresponding bit in the P3CR1 to 0 and then set the corresponding bit in the P3CR2 to 1.

To use each pin as a key-on wakeup input, set the corresponding bit in the P3CR1 to 0 and then set the corresponding bit in the STOPCR to 1.

To use each pin as an analog input, set the corresponding bit in the P3CR1 to 0 and then set the corresponding bit in the P3CR2 to 0.

When P3CR1=1, reading the P3DR returns the values of the respective output latches.


Any pins of the P3 port which are not used for analog input can be used as input/output ports. During AD conversion, however, avoid executing output instructions on these pins to ensure the accuracy of conversion. Also note that, during AD conversion, rapidly changing signals should not be input on any pins near analog input pins.


Table 5-1 Setting of register according to each function value

Europhia a	Set value						
Function	P3DR	P3CR1	P3CR2	STOPCR			
Port input	-	0	1	-			
Key-on wakeup input	-	0	-	1			
Analog input	-	0	0	-			
Port 0 output	0	1	-	-			
Port 1 output	1	1	-	-			


Table 5-2 Setting of register according to each function value

Cond	lition	Deading value of D2DD	
P3CR1	P3CR2	Reading value of P3DR	
0	0	0	
0	1	State of terminal	
4	0	Contanto of autout lately	
1	1	Contents of output latch	





b) Equivalent circuit of P32, P33



c) Equivalent circuit of P34 to P37

Note 1) STOP = bit 7 of SYSCR1 Note 2) SAIN = AD input select signal Note 3) STOPk = bit 7 to bit 4 of STOPCR

Figure 5-5 P3 Port

	7	6	5	4	3	2	1	0	_	
P3DR (0003H) R/W	P37 AIN5 STOP5	P36 AIN4 STOP4	P35 AIN3 STOP3	P34 AIN2 STOP2	P33 AIN1	P32 AIN0	P31 TC4 PDO4 PWM4 PPG4	P30 TC3 PDO3 PWM3	(Initial value: 0000 0000)	
P3CR1	7	6	5	4	3	2	1	0	_	
(H8000)									(Initial value: 0000 0000)	
	P3CR1		ols P3 port ified bitwise	input/output)	t or key on wake up input)	R/W				
P3CR2 (000AH)	7					(Initial value: 1111 11**)				
	P3CR2 Controls P3 port input (specified bitwise)					alog input t Input				R/W

- Note 1: The port placed in input mode reads the pin input state. Therefore, when the input and output modes are used together, the output latch contents for the port in input mode might be changed by executing a bit manipulation instruction.
- Note 2: As for the analog input pin because of penetration electric current measure, please be sure to clear the bit to which P3CR2 corresponds in "0".
- Note 3: Do not set the output mode (P3CR1="1") for the pin used as an analog input, due to avoid external short-circuits.
- Note 4: Pins not used for analog input can be used as I/O ports. During AD conversion, output instructions should not be executed to keep a precision. In addition, a variable signal should not be input to a port adjacent to the analog input during AD conversion.

TOSHIBA TMP86FH92DMG

6. Power-on reset circuit

6.1 Power-on reset circuit

The power-on reset circuit generates a reset when the TMP86FH92DMG is powered on. It also generates a power-on reset signal if the supply voltage drops below the threshold voltage of the power-on reset circuit.

Note: The power-on reset circuit cannot be emulated with the TMP86C993XB (Emulation Chip). Therefore, when using the development tool for debugging, ensure that operation is performed within the operating voltage range of the TMP86FH92DMG. For the operating voltage range, refer to the chapter on electrical characteristics.

6.1.1 Configuration

The power-on reset circuit is comprised of a reference voltage generator and a comparator.

The comparator compares the supply voltage divided by a resistor ladder with the reference voltage generated by the reference voltage generator.




Figure 6-1 Power-on reset circuit


6.1.2 function

When the TMP86FH92DMG is powered on, the power-on reset circuit generates a power-on reset signal while the supply voltage is below the power-on reset release voltage. The power-on reset signal is released when the supply voltage rises above the power-on reset release voltage.

When the TMP86FH92DMG is shut off, the power-on reset circuit generates a power-on reset signal when the supply voltage drops below the power-on reset threshold voltage. While the power-on reset signal is generated, the warm-up counter circuit, CPU and peripheral circuits are reset.

Upon release of the power-on reset signal, the warm-up counter circuit starts operating. After the warm-up time has elapsed, the CPU and peripheral circuits are released from the reset state.

After the supply voltage reaches the power-on reset release voltage level, it must be raised to the operating range before the power-on warm-up time expires. If the supply voltage is not in the operating range at the completion of the power-on warm-up time, the TMP86FH92DMG cannot operate properly.



- Note 1: The power-on reset circuit may not operate properly depending on transitions in supply voltage (VDD). When designing your application system, careful consideration must be given to ensure proper operation of the power-on reset circuit by referring to the device's electrical characteristics.
- Note 2: The input clock to the warm-up counter is derived from the oscillation circuit. Because the oscillation frequency is unstable until the oscillation circuit stabilizes, the warm-up time includes error.
- Note 3: The supply voltage must be raised to satisfy the condition t_{VDD} < t_{PWUP} .

Figure 6-2 Operation of the power on reset circuit

TOSHIBA TMP86FH92DMG

Voltage detection circuit (VLTD)

The voltage detecting circuit monitors the supply voltage level and generates an interrupt or reset upon detection of a low-voltage condition.

Note: The voltage detecting circuit may not operate properly depending on transitions in supply voltage (VDD). When designing your application system, careful consideration must be given to ensure proper operation of the voltage detecting circuit by referring to the device's electrical characteristics.

7.1 Configuration

The voltage detecting circuit is comprised of a reference voltage generator, two detection voltage select circuits, two comparators and control registers.

The supply voltage (VDD) is divided by the ladder resistor and input to the detection voltage select circuit. The detection voltage select circuit selects a voltage according to the specified detection voltage (VDxLVL) (x = 1 or 2), and the comparator compares it with the reference voltage. When the comparator detects the selected voltage, a voltage detection reset signal or an INTVLTD interrupt request signal can be generated.

Whether to generate a voltage detection reset signal or an INTVLTD interrupt request signal can be programmed by software. In the former case, a voltage detection reset signal is generated when the supply voltage (VDD) becomes lower than the detection voltage (VDxLVL). In the latter case, an INTVLTD interrupt request signal is generated when the supply voltage (VDD) falls to the detection voltage level.

Note: Since the comparators used for voltage detection do not have a hysteresis structure, INTVLTD interrupt request signals may be generated frequently if the supply voltage (VDD) is close to the detection voltage (VDxLVL). INTVLTD interrupt request signals may be generated not only when the supply voltage falls to the detection voltage but also when it rises to the detection voltage.




Figure 7-1 Voltage detection circuit diagram

7.2 Control TMP86FH92DMG

7.2 Control

The voltage detection circuit is controlled by the Voltage Detection Control Register 1 (VDCR1) and Voltage Detection Control Register 2 (VDCR2).

The functions of the VDCR1 and VDCR2 vary between the TMP86FH92DMG and the emulation chip TMP86C993XB. For details, refer to the register descriptions below.

The TMP86C993XB does not allow an interrupt or a reset to be generated by voltage detection. Instead, the VD1S and VD2S bits are provided in the VDCR2 to support the emulation of voltage detection operation. Setting VDCR2<VDxS> to 0 while VDCR2<VDxEN> is set to 1 generates an interrupt or a reset depending on the VDCR2<VDxMOD> setting (x = 1, 2). In debugging the voltage detection circuit with the TMP86C993XB (development tool), this function can be used to emulate interrupt/reset generation by inserting a write instruction to the VDCR2 in a software program.

Please ensure that the final verification of software operation is conducted with the TMP86FH92DMG.

Voltage detection control register1

VDCR1	7	6	5	4	3	2	1	0	_
(002BH)	VD2F	VD2SF	VD2I	LVL	VD1F	1F VD1SF VD1LVL		LVL	(Initial value: 0010 0000)

			TMP86FH92DMG		TMP86C993XB		
			Read		Read		
VD2F	Voltage detection 2 flag (Latches the state when VDD < VD2LVL)	0: 1:	VDD ≥ VD2LVL VDD < VD2LVL	0: 1:	- Writing a 0 to VDCR2 <vd2s> sets this bit to 1.</vd2s>	R/W	
	(Note 2)		Write		Write		
		0: 1:			l		
VD2SF	Voltage detection 2 status flag (Indicates the relation between VDD and VD2LVL when read.)	0: 1:	VDD ≥ VD2LVL VDD < VD2LVL	This ately 0 is vother	Read Only		
VD2LVL	Voltage detection 2 level select (Note 3)	00: Reserved 01: 2.9 to 3.3V 10: Reserved 11: Reserved			This bit has no meaning as voltage detection is performed based on the VDCR2 <vd2s> setting.</vd2s>		
		Read			Read		
VD1F	Voltage detection 1 flag (Latches the state when VDD < VD1LVL.)		VDD ≥ VD1LVL VDD < VD1LVL	0: 1:	· -		
	(Note 2)	Write					
		0: 1:	Clearing the flag - (Note 4)	0: 1:	Clear the flag - (Note 4)		
VD1SF	Voltage detection 1 status flag (Indicates the relation between VDD and VD1LVL when read.)	0: 1:	VDD ≥ VD1LVL VDD < VD1LVL	ately 0 is v	This bit is only read as 1 immeditely (for 3 machine cycles) after a is written to VDCR2 <vd1s>. At ther times, it is always read as 0.</vd1s>		
VD1LVL	Voltage detection 1 level select	00: 01: 10: 11:	4.0 to 4.7V Reserved Reserved 2.9 to 3.3V	This determine the \	R/W		

Note 1: The VDCR1 is initialized by a power-on reset or an external reset input.

Note 2: If VDCR1<VD2F> or VDCR1<VD1F> is cleared by software simultaneously as it is set by detection of a low-voltage condition, the setting operation overrides the clearing operation so that the bit is set to 1.

Note 3: To enable voltage detection 2 operation by setting VDCR2<VD2EN> to 1, VDCR1<VD2LVL> must be set to 01.

Note 4: Each flag cannot be set to 1 by writing a 1 to it.

Voltage detection control register 2

VDCR2	7	6	5	4	3	2	1	0	
(002CH)		VD2S	VD1S		VD2MOD	VD2EN	VD1MOD	VD1EN	(Initial value: **** 0000)

			TMP86FH92DMG		TMP86C993XB	
VD2S	Voltage detection 2 set	No fu	unction	0: 1:	Generate a reset or an interrupt by VD2	Write Only
VD1S	Voltage detection 1 set	No fu	unction	0: 1:	Generate a reset or an interrupt by VD1	Write Only
VD2MOD	Voltage detection 2 operation mode select	0: 1:				R/W
VD2EN	Voltage detection 2 operation enable/disable	0: 1:	Voltage detection 2 disable Voltage detection 2 enable			R/W
VD1MOD	Voltage detection 1 operation mode select	0: 1:	INTVLTD interrupt Voltage detection 1 reset sign	nal oc	currence	R/W
VD1EN	Voltage detection 1 operation enable/disable	0: 1:	Voltage detection 1 disable Voltage detection 1 enable			R/W

Note 1: The VDCR2 is only initialized by a power-on reset or an external reset input.

Note 2: In the TMP86FH92DMG, the VD2S and VD1S bits are not available. Setting a value to these bits has no effect.

7.3 Function

The voltage detecting circuit allows two detection voltage levels (VDxLVL, x = 1, 2) to be specified. For each detection voltage, whether to enable or disable voltage detect operation and the action to be taken when the supply voltage (VDD) falls to or below the detection voltage (VDxLVL) can be programmed by software.

7.3.1 Enabling/Disabling Voltage Detection Operation

Setting the VDCR2<VDxEN> bit to 1 enables voltage detect operation and clearing this bit to 0 disables it. Immediately after release of a power-on reset, VDCR2<VDxEN>, is cleared to 0.

Note: Setting VDCR2<VDxEN> to 1 while the supply voltage is below the detection voltage (VDD<VDxLVL) immediately causes an INTVLTD interrupt or a voltage detect x reset signal to be generated.

7.3.2 Selecting the Voltage Detect Operating Mode

When VDCR2<VDxMOD> is set to "0", the voltage detection operation mode is set to generate INTVLTD interrupt request signals. When VDCR2<VDxMOD> is set to "1", the operation mode is set to generate voltage detection reset signals.

When the operation mode is set to generate INTVLTD interrupt signals (VDCR2<VDxMOD>="0") When VDCR2<VDxEN>="1", an INTVLTD interrupt request signal is generated when the supply voltage (VDD) falls to the detection voltage (VDxLVL).




Figure 7-2 Voltage Detection Interrupt Request

Note: Since the comparators used for voltage detection do not have a hysteresis structure, INTVLTD interrupt request signals may be generated frequently when the supply voltage (VDD) is close to the detection voltage (VDxLVL). INTVLTD interrupt request signals may be generated not only when the supply voltage falls to the detection voltage but also when it rises to the detection voltage.

When the operation mode is set to generate voltage detection reset signals (VDCR2<VDxMOD>="1")

When VDCR2<VDxEN>="1", a voltage detection reset signal is generated when the supply voltage (VDD) becomes lower than the detection voltage (VDxLVL).

VDCR1 and VDCR2 are initialized by a power-on reset or an external reset input only. A voltage detection reset signal is generated continuously as long as the supply voltage (VDD) is lower than the detection voltage (VDxLVL).




Figure 7-3 Voltage Detection Reset Signal

7.3.3 Detection voltage level section

The detection voltage level is selected by programming the VDCR1<VDxLVL> bits.

7.3.4 Voltage detection flag and voltage detection status flag

The voltage detect flag (VDCR1<VDxF>) and voltage detect status flag (VDCR1<VDxSF>) indicate the relation between the supply voltage (VDD) and the detection voltage (VDxLVL), i.e, whether VDD is above or equal to VDxLVL or VDD is below VDxLVL.

When VDCR2<VDxEN>=1, a drop of the supply voltage (VDD) below the detection voltage (VDxLVL) causes the VDCR1<VDxF> flag to be set. This flag remains set until it is cleared by software. VDCR1<VDxF> is not cleared to 0 when the supply voltage (VDD) becomes equal to or higher than the detection voltage (VDxLVL).

Once VDCR1<VDxF> has been set to 1, this state is retained even if VDCR2<VDxEN> is cleared to 0. VDCR1<VDxF> can only be cleared by writing a 0.

When VDCR2<VDxEN>=1, a drop of the supply voltage (VDD) below the detection voltage (VDxLVL) also causes the VDCR1<VDxSF> flag to be set to 1. When VDD rises above VDxLVL, the VDCR1<VDxSF> flag is cleared to 0.

Unlike the VDCR1<VDxF> flag, the VDCR1<VDxSF> flag does not remain set and changes its state according to the relation between VDD and VDxLVL.

Note: Depending on the voltage detect timing, the voltage detect status flag (VDCR1<VDxSF>) may be set one machine cycle before the voltage detect flag (VDCR1<VDxF>) is set.




Figure 7-4 Change of voltage detection flag and voltage detection status flag

7.4 Setting of register TMP86FH92DMG

7.4 Setting of register

7.4.1 Setting Procedure for Generate an interrupt

The following shows the setting procedure for generating an INTVLTD interrupt upon detection of a low-voltage condition.

- 1. Clear the INTVLTD interrupt enable flag <EF4> to 0.
- 2. Select the detection voltage by programming the VDCR1<VDxLVL>(x=1, 2) bits.
- 3. Clear the VDCR2<VDxMOD> bit to 0 to generate an INTVLTD interrupt upon detection of a low-voltage condition.
- 4. Set the VDCR2<VDxEN> bit to 1 to enable voltage detect operation.
- 5. Wait for 5 µs until the voltage detecting circuit stabilizes.
- 6. Ensure that the VDCR1<VDxSF> is 0.
- 7. Clear VDCR1<VDxF> to 0.
- 8. Clear the INTVLTD interrupt latch <IL4> to 0 and set the interrupt enable flag <EF4> to 1 to enable interrupts.

Note: When the supply voltage (VDD) is close to the detection voltage (VDxLVL), voltage detection request signals may be generated frequently. If this may pose any problem, execute appropriate wait processing depending on fluctuations in the system power supply and clear the interrupt latch before returning from the INTVLTD interrupt service routine.

To disable the voltage detection circuit while it is enabled with the voltage detection interrupt request, make the following setting:

- 1. Clear the INTVLTD interrupt enable flag <EF4> to 0.
- 2. Clear VDCR2<VDxEN> to 0 to disable the voltage detection operation.

Note: If the voltage detection circuit is disabled without clearing interrupt enable flag, unexpected interrupt request may occur.

7.4.2 Setting procedure to generate a reset

The following shows the setting procedure for generating a voltage detect x reset signal upon detection of a low-voltage condition.

- 1. Clear the INTVLTD interrupt enable flag <EF4> to 0.
- 2. Select the detection voltage by programming the VDCR1<VDxLVL> (x=1, 2) bits.
- 3. Clear the VDCR2<VDxMOD> bit to 0 to generate an INTVLTD interrupt upon detection of a low-voltage condition.
- 4. Set the VDCR2<VDxEN> bit to 1 to enable voltage detect operation.
- 5. Wait for 5 μs until the voltage detecting circuit stabilizes.
- 6. Ensure that the VDCR1<VDxSF> bit is 0.
- 7. Clear VDCR1<VDxF> to 0.
- 8. Set the VDCR2<VDxMOD> bit to 1 to generate a voltage detect x reset signal upon detection of a low-voltage condition.
- Note 1: The VDCR1 and VDCR2 are only initialized by a power-on reset or an external reset input. Therefore, at the time when a low-voltage detect reset is released, if the supply voltage (VDD) is found to be below the detection voltage (VDxLVL) before VDCR2<VDxEN> is cleared to 0, a voltage detect reset will immediately be generated
- Note 2: The voltage detect reset signal remains asserted while the supply voltage (VDD) is below the detection voltage (LDxLVL).

To disable the voltage detection circuit while it is enabled with the voltage detection reset, make the following setting:

- 1. Clear the INTVLTD interrupt enable flag <EF4> to 0.
- 2. Clear VDCR2<VDxMOD> to 0 to set the operation mode to generate voltage detection interrupt request signals.
- 3. Clear VDCR2<VDxEN> to 0 to disable the voltage detection operation.

Note: If the voltage detection circuit is disabled without clearing interrupt enable flag, unexpected interrupt request may occur.

7. Voltage detection circuit (VLTD)	
7.4 Setting of register	TMP86FH92DMG

TOSHIBA TMP86FH92DMG

8. Watchdog Timer (WDT)

The watchdog timer is a fail-safe system to detect rapidly the CPU malfunctions such as endless loops due to spurious noises or the deadlock conditions, and return the CPU to a system recovery routine.

The watchdog timer signal for detecting malfunctions can be programmed only once as "reset request" or "interrupt request". Upon the reset release, this signal is initialized to "reset request".

When the watchdog timer is not used to detect malfunctions, it can be used as the timer to provide a periodic interrupt.

Note: Care must be taken in system design since the watchdog timer functions are not be operated completely due to effect of disturbing noise.

8.1 Watchdog Timer Configuration




Figure 8-1 Watchdog Timer Configuration

TMP86FH92DMG

8.2 Watchdog Timer Control

The watchdog timer is controlled by the watchdog timer control registers (WDTCR1 and WDTCR2). The watchdog timer is automatically enabled after the reset release.

8.2.1 Malfunction Detection Methods Using the Watchdog Timer

The CPU malfunction is detected, as shown below.


- 1. Set the detection time, select the output, and clear the binary counter.
- 2. Clear the binary counter repeatedly within the specified detection time.

If the CPU malfunctions such as endless loops or the deadlock conditions occur for some reason, the watchdog timer output is activated by the binary-counter overflow unless the binary counters are cleared. When WDTCR1<WDTOUT> is set to "1" at this time, the reset request is generated and then internal hardware is initialized. When WDTCR1<WDTOUT> is set to "0", a watchdog timer interrupt (INTWDT) is generated.

The watchdog timer temporarily stops counting in the STOP mode including the warm-up or IDLE/SLEEP mode, and automatically restarts (continues counting) when the STOP/IDLE/SLEEP mode is inactivated.

Note: The watchdog timer consists of an internal divider and a two-stage binary counter. When the clear code 4EH is written, only the binary counter is cleared, but not the internal divider. The minimum binary-counter overflow time, that depends on the timing at which the clear code (4EH) is written to the WDTCR2 register, may be 3/4 of the time set in WDTCR1<WDTT>. Therefore, write the clear code using a cycle shorter than 3/4 of the time set to WDTCR1<WDTT>.

Example :Setting the watchdog timer detection time to 2²¹/fc [s], and resetting the CPU malfunction detection



Watchdog Timer Control Register 1

WDTCR1	7	6	5	4	3	2	1	0	
(0034H)			(ATAS)	(ATOUT)	WDTEN	WD	TT	WDTOUT	(Initial value: **11 1001)

WDTEN	Watchdog timer enable/disable		D: Disable (Writing the disable code to WDTCR2 is required.) 1: Enable					
			NORMAL	1/2 mode	SLOW1/2			
			DV7CK = 0	DV7CK = 1	mode			
WDTT	Watchdog timer detection time [s]	00	2 ²⁵ /fc	2 ¹⁷ /fs	2 ¹⁷ /fs	Write only		
WDII		01	2 ²³ /fc	2 ¹⁵ /fs	2 ¹⁵ fs			
		10	2 ²¹ fc	2 ¹³ /fs	2 ¹³ fs			
		11	2 ¹⁹ /fc	2 ¹¹ /fs	2 ¹¹ /fs			
WDTOUT	Watchdog timer output select	0: Interrupt request						
WBTOOT	waterides times output select	1: Rese	t request			only		

- Note 1: After clearing WDTOUT to "0", the program cannot set it to "1".
- Note 2: fc: High-frequency clock [Hz], fs: Low-frequency clock [Hz], *: Don't care
- Note 3: WDTCR1 is a write-only register and must not be used with any of read-modify-write instructions. If WDTCR1 is read, a don't care is read.
- Note 4: To activate the STOP mode, disable the watchdog timer or clear the counter immediately before entering the STOP mode.

 After clearing the counter, clear the counter again immediately after the STOP mode is inactivated.
- Note 5: To clear WDTEN, set the register in accordance with the procedures shown in "8.2.3 Watchdog Timer Disable".

Watchdog Timer Control Register 2

WDTCR2

(0035H)							(Initial value: **** ****)				
ı											
				4EH: Clear the watchdog timer binary counter (Clear code)							
	WDTCR2 Write B1H: Disable the watchdog timer (Disable code)					,	Write only				
		Watchdog timer c	ontrol code	D2H: Enable assigning address trap area							
					Others: Invalid						

- Note 1: The disable code is valid only when WDTCR1<WDTEN> = 0.
- Note 2: *: Don't care
- Note 3: The binary counter of the watchdog timer must not be cleared by the interrupt task.
- Note 4: Write the clear code 4EH using a cycle shorter than 3/4 of the time set in WDTCR1<WDTT>.

8.2.2 Watchdog Timer Enable

Setting WDTCR1<WDTEN> to "1" enables the watchdog timer. Since WDTCR1<WDTEN> is initialized to "1" during reset, the watchdog timer is enabled automatically after the reset release.

8.2 Watchdog Timer Control

8.2.3 Watchdog Timer Disable

To disable the watchdog timer, set the register in accordance with the following procedures. Setting the register in other procedures causes a malfunction of the micro controller.

- 1. Set the interrupt master flag (IMF) to "0".
- 2. Set WDTCR2 to the clear code (4EH).
- 3. Set WDTCR1<WDTEN> to "0".
- 4. Set WDTCR2 to the disable code (B1H).

Note: While the watchdog timer is disabled, the binary counters of the watchdog timer are cleared.

Example :Disabling the watchdog timer

DI : IMF \leftarrow 0

LD (WDTCR2), 04EH : Clears the binary counter

LDW (WDTCR1), 0B101H : WDTEN ← 0, WDTCR2 ← Disable code

Table 8-1 Watchdog Timer Detection Time (Example: fc = 16.0 MHz, fs = 32.768 kHz)

	Watchdog Timer Detection Time[s]							
WDTT	NORMAL	SLOW						
	DV7CK = 0	DV7CK = 1	mode					
00	2.097	4	4					
01	524.288 m	1	1					
10	131.072 m	250 m	250 m					
11	32.768 m	62.5 m	62.5 m					

8.2.4 Watchdog Timer Interrupt (INTWDT)

When WDTCR1<WDTOUT> is cleared to "0", a watchdog timer interrupt request (INTWDT) is generated by the binary-counter overflow.

A watchdog timer interrupt is the non-maskable interrupt which can be accepted regardless of the interrupt master flag (IMF).

When a watchdog timer interrupt is generated while the other interrupt including a watchdog timer interrupt is already accepted, the new watchdog timer interrupt is processed immediately and the previous interrupt is held pending. Therefore, if watchdog timer interrupts are generated continuously without execution of the RETN instruction, too many levels of nesting may cause a malfunction of the microcontroller.

To generate a watchdog timer interrupt, set the stack pointer before setting WDTCR1<WDTOUT>.

Example :Setting watchdog timer interrupt

LD SP, 023FH : Sets the stack pointer LD (WDTCR1), 00001000B : WDTOUT \leftarrow 0

8.2.5 Watchdog Timer Reset

When a binary-counter overflow occurs while WDTCR1<WDTOUT> is set to "1", a watchdog timer reset request is generated. When a watchdog timer reset request is generated, the internal hardware is reset. The reset time is maximum 24/fc [s] (1.5 μ s @ fc = 16.0 MHz).

Note: When a watchdog timer reset is generated in the SLOW1 mode, the reset time is maximum 24/fc (high-frequency clock) since the high-frequency clock oscillator is restarted. However, when crystals have inaccuracies upon start of the high-frequency clock oscillator, the reset time should be considered as an approximate value because it has slight errors.





Figure 8-2 Watchdog Timer Interrupt

8.3 Address Trap TMP86FH92DMG

8.3 Address Trap


The Watchdog Timer Control Register 1 and 2 share the addresses with the control registers to generate address traps.

Watchdog Timer Control Register 1



ATAS	Select address trap generation in the internal RAM area	0: Generate no address trap 1: Generate address traps (After setting ATAS to "1", writing the control code D2H to WDTCR2 is required)	Write
ATOUT	Select operation at address trap	0: Interrupt request 1: Reset request	Offig

Watchdog Timer Control Register 2



8.3.1 Selection of Address Trap in Internal RAM (ATAS)

WDTCR1<ATAS> specifies whether or not to generate address traps in the internal RAM area. To execute an instruction in the internal RAM area, clear WDTCR1<ATAS> to "0". To enable the WDTCR1<ATAS> setting, set WDTCR1<ATAS> and then write D2H to WDTCR2.

Executing an instruction in the SFR or DBR area generates an address trap unconditionally regardless of the setting in WDTCR1<ATAS>.

8.3.2 Selection of Operation at Address Trap (ATOUT)

When an address trap is generated, either the interrupt request or the reset request can be selected by WDTCR1<ATOUT>.

8.3.3 Address Trap Interrupt (INTATRAP)

While WDTCR1<ATOUT> is "0", if the CPU should start looping for some cause such as noise and an attempt be made to fetch an instruction from the on-chip RAM (while WDTCR1<ATAS> is "1"), DBR or the SFR area, address trap interrupt (INTATRAP) will be generated.

An address trap interrupt is a non-maskable interrupt which can be accepted regardless of the interrupt master flag (IMF).

When an address trap interrupt is generated while the other interrupt including an address trap interrupt is already accepted, the new address trap is processed immediately and the previous interrupt is held pending. Therefore, if address trap interrupts are generated continuously without execution of the RETN instruction, too many levels of nesting may cause a malfunction of the microcontroller.

To generate address trap interrupts, set the stack pointer beforehand.

TMP86FH92DMG

8.3.4 Address Trap Reset

While WDTCR1<ATOUT> is "1", if the CPU should start looping for some cause such as noise and an attempt be made to fetch an instruction from the on-chip RAM (while WDTCR1<ATAS> is "1"), DBR or the SFR area, address trap reset will be generated.

When an address trap reset request is generated, the internal hardware is reset. The reset time is maximum 24/ fc [s] (1.5 μ s @ fc = 16.0 MHz).

Note: When an address trap reset is generated in the SLOW1 mode, the reset time is maximum 24/fc (high-frequency clock) since the high-frequency clock oscillator is restarted. However, when crystals have inaccuracies upon start of the high-frequency clock oscillator, the reset time should be considered as an approximate value because it has slight errors.

8. Watchdog Timer (WDT)

8.3 Address Trap TMP86FH92DMG

TOSHIBA TMP86FH92DMG

9. Time Base Timer (TBT)

The time base timer generates time base for key scanning, dynamic displaying, etc. It also provides a time base timer interrupt (INTTBT).

9.1 Time Base Timer

9.1.1 Configuration




Figure 9-1 Time Base Timer configuration

9.1.2 Control

Time Base Timer is controlled by Time Base Timer control register (TBTCR).

Time Base Timer Control Register

	7	6	5	4	3	2	1	0	
TBTCR (0036H)	(DVOEN)	(DVC	OCK)	(DV7CK)	TBTEN		твтск		(Initial Value: 0000 0000)

TBTEN	Time Base Timer enable / disable	0: Disab					
			NORMAL1/2,	IDLE1/2 Mode	SLOW1/2		
			DV7CK = 0	DV7CK = 1	SLEEP1/2 Mode		
		000	fc/2 ²³	fs/2 ¹⁵	fs/2 ¹⁵		
		001	fc/2 ²¹	fs/2 ¹³	fs/2 ¹³		
TBTCK	Time Base Timer interrupt	010	fc/2 ¹⁶	fs/2 ⁸	-	R/W	
	Frequency select : [Hz]	011	fc/2 ¹⁴	fs/2 ⁶	-		
		100	fc/2 ¹³	fs/2 ⁵	-	7	
		101	fc/2 ¹²	fs/2 ⁴	-		
		110	fc/2 ¹¹	fs/2 ³	-		
		111	fc/2 ⁹	fs/2	-		

Note 1: fc; High-frequency clock [Hz], fs; Low-frequency clock [Hz], *; Don't care

Note 2: The interrupt frequency (TBTCK) must be selected with the time base timer disabled (TBTEN = "0"). (The interrupt frequency must not be changed with the disable from the enable state.) Both frequency selection and enabling can be performed simultaneously.

Example :Set the time base timer frequency to fc/2¹⁶ [Hz] and enable an INTTBT interrupt.

LD (TBTCR),00000010B ; TBTCK \leftarrow LD (TBTCR),00001010B ; TBTEN \leftarrow DI ; IMF \leftarrow SET (EIRL).7

Table 9-1 Time Base Timer Interrupt Frequency (Example: fc = 16.0 MHz, fs = 32.768 kHz)

TRICK	Time Base Timer Interrupt Frequency [Hz]						
TBTCK	NORMAL1/2, IDLE1/2 Mode	NORMAL1/2, IDLE1/2 Mode	SLOW1/2, SLEEP1/2 Mode				
	DV7CK = 0	DV7CK = 1					
000	1.91	1	1				
001	7.63	4	4				
010	244.14	128	-				
011	976.56	512	-				
100	1953.13	1024	-				
101	3906.25	2048	-				
110	7812.5	4096	-				
111	31250	16384	-				

9.1.3 Function

An INTTBT (Time Base Timer Interrupt) is generated on the first falling edge of source clock (The divider output of the timing generator which is selected by TBTCK.) after time base timer has been enabled.

The divider is not cleared by the program; therefore, only the first interrupt may be generated ahead of the set interrupt period (Figure 9-2).




Figure 9-2 Time Base Timer Interrupt

TMP86FH92DMG

9.2 Divider Output (DVO)

Approximately 50% duty pulse can be output using the divider output circuit, which is useful for piezoelectric buzzer drive. Divider output is from \overline{DVO} pin.

9.2.1 Configuration




Figure 9-3 Divider Output

9.2.2 Control

The Divider Output is controlled by the Time Base Timer Control Register.

Time Base Timer Control Register

	7	6	5	4	3	2	1	0	
TBTCR (0036H)	DVOEN	DVC	OCK	(DV7CK)	(TBTEN)		(TBTCK)		(Initial value: 0000 0000)

DVOEN	Divider output enable / disable	0: Disab				R/W
			NORMAL1/2,	IDLE1/2 Mode	SLOW1/2	
			DV7CK = 1	SLEEP1/2		
			DV7CK = 0	DV/CK = 1	Mode	
DVOCK	Divider Output (DVO)	00	fc/2 ¹³	fs/2 ⁵	fs/2 ⁵	R/W
	frequency selection: [Hz]	01	fc/2 ¹²	fs/2⁴	fs/2 ⁴	
		10	fc/2 ¹¹	fs/2³	fs/2 ³	
		11	fc/2 ¹⁰	fs/2²	fs/2²	

Note: Selection of divider output frequency (DVOCK) must be made while divider output is disabled (DVOEN="0"). Also, in other words, when changing the state of the divider output frequency from enabled (DVOEN="1") to disable(DVOEN="0"), do not change the setting of the divider output frequency.

9. Time Base Timer (TBT)

Example :1.95 kHz pulse output (fc = 16.0 MHz)

Setting port

LD (TBTCR) , 00000000B ; DVOCK \leftarrow "00" LD (TBTCR) , 10000000B ; DVOEN \leftarrow "1"


Table 9-2 Divider Output Frequency (Example: fc = 16.0 MHz, fs = 32.768 kHz)

	Divider Output Frequency [Hz]						
DVOCK	NORMAL1/2,	SLOW1/2, SLEEP1/2					
	DV7CK = 0	DV7CK = 1	Mode				
00	1.953 k	1.024 k	1.024 k				
01	3.906 k	2.048 k	2.048 k				
10	7.813 k	4.096 k	4.096 k				
11	15.625 k	8.192 k	8.192 k				

TOSHIBA TMP86FH92DMG

10. 16-Bit Timer/Counter 1 (TC1)

10.1 Configuration



Note: Function I/O may not operate depending on I/O port setting. For more details, see the chapter "I/O Port".

Figure 10-1 TimerCounter 1 (TC1)

10.2 Timer/Counter Control TMP86FH92DMG

10.2 Timer/Counter Control

The TimerCounter 1 is controlled by the TimerCounter 1 control register (TC1CR) and two 16-bit timer registers (TC1DRA and TC1DRB).

Timer Register

_	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TC1DRA	TC1DRAH (0011H)									TC1DRAL (0010H)						
(0011H, 0010H)		(Initial value: 1111 1111 1111 1111)						Read/Write								
TC1DRB TC1DRBH (0013H)						l)		TC1DRBL (0012H)								
(0013H, 0012H)	(Initial value: 1111 1111 1111)							Read/Write (Write enabled only in the PPG output mode)						le)		

TimerCounter 1 Control Register

	7	6	5	4	3	2	1	0	
TC1CR (0014H)	TFF1	ACAP1 MCAP1 METT1 MPPG1	TC	1S	TC	1CK	тс	C1M	Read/Write (Initial value: 0000 0000)

TFF1	Timer F/F1 control	0: Cle	ar		1: Set					R/W	
ACAP1	Auto capture control	0 : Au	to-capture disable		1 : Auto-	-capture e	nable				
MCAP1	Pulse width measurement mode control	0 :Doi	uble edge capture		1 : Single edge capture						
METT1	External trigger timer mode control	0 : Tri	gger start		1 : Trigg	er start an	d stop			R/W	
MPPG1	PPG output control	0 : Co	ontinuous pulse generation		1 : One-	shot					
				Timer	Extrig- ger	Event	Win- dow	Pulse	PPG		
		00: St	op and counter clear	0	0	0	0	0	0		
		01: C	ommand start	0	-	-	-	-	0		
TC1S	TC1 start control	(Ex-tri	sing edge start igger/Pulse/PPG) g edge count (Event) ve logic count (Window)	-	0	0	0	0	0	R/W	
		(Ex-tri	alling edge start igger/Pulse/PPG) g edge count (Event) tive logic count (Window)	-	0	0	0	0	0		
			NORMAL1/2	IDLE1/2	mode				SLOW,		
		DV7CK = 0			DV70	CK = 1	Divider	SLEEP mode			
TC1CK	TC1 source clock select	00	fc/2 ¹¹		fs	/2³		DV9	fs/2 ³	R/W	
TOTOK	[Hz]	01	fc/2 ⁷		fc	/2 ⁷		DV5	-	R/VV	
		10	fc/2 ³		fc	/2 ³		DV1	-		
		11	Exte	rnal clock	(TC1 pin	input)		•	•		
		00: Ti	mer/external trigger timer/event count	er mode							
TC1M	TC1 operating mode se-	_	findow mode							R/W	
	lect		ulse width measurement mode PG (Programmable pulse generate) o							'	

Note 1: fc: High-frequency clock [Hz], fs: Low-frequency clock [Hz]

Note 2: The timer register consists of two shift registers. A value set in the timer register becomes valid at the rising edge of the first source clock pulse that occurs after the upper byte (TC1DRAH and TC1DRBH) is written. Therefore, write the lower byte and the upper byte in this order (it is recommended to write the register with a 16-bit access instruction). Writing only the lower byte (TC1DRAL and TC1DRBL) does not enable the setting of the timer register.

- Note 3: To set the mode, source clock, PPG output control and timer F/F control, write to TC1CR during TC1S=00. Set the timer F/F1 control until the first timer start after setting the PPG mode.
- Note 4: Auto-capture can be used only in the timer, event counter, and window modes.
- Note 5: To set the timer registers, the following relationship must be satisfied.

 TC1DRA > TC1DRB > 1 (PPG output mode), TC1DRA > 1 (other modes)
- Note 6: Set TFF1 to "0" in the mode except PPG output mode.
- Note 7: Set TC1DRB after setting TC1M to the PPG output mode.
- Note 8: When the STOP mode is entered, the start control (TC1S) is cleared to "00" automatically, and the timer stops. After the STOP mode is exited, set the TC1S to use the timer counter again.
- Note 9: Use the auto-capture function in the operative condition of TC1. A captured value may not be fixed if it's read after the execution of the timer stop or auto-capture disable. Read the capture value in a capture enabled condition.
- Note 10: Since the up-counter value is captured into TC1DRB by the source clock of up-counter after setting TC1CR<ACAP1> to "1". Therefore, to read the captured value, wait at least one cycle of the internal source clock before reading TC1DRB for the first time.

10.3 Function

TimerCounter 1 has six types of operating modes: timer, external trigger timer, event counter, window, pulse width measurement, programmable pulse generator output modes.

10.3.1 Timer mode

In the timer mode, the up-counter counts up using the internal clock. When a match between the up-counter and the timer register 1A (TC1DRA) value is detected, an INTTC1 interrupt is generated and the up-counter is cleared. After being cleared, the up-counter restarts counting. Setting TC1CR<ACAP1> to "1" captures the up-counter value into the timer register 1B (TC1DRB) with the auto-capture function. Use the auto-capture function in the operative condition of TC1. A captured value may not be fixed if it's read after the execution of the timer stop or auto-capture disable. Read the capture value in a capture enabled condition. Since the up-counter value is captured into TC1DRB by the source clock of up-counter after setting TC1CR<ACAP1> to "1". Therefore, to read the captured value, wait at least one cycle of the internal source clock before reading TC1DRB for the first time.

Table 10-1 Internal Source Clock for TimerCounter 1 (Example: fc = 16 MHz, fs = 32.768 kHz)

T0401/		NORMAL1/2, IDLE1/2 mode							
TC1CK	DV7C	CK = 0	DV7C	SLOW, SLEEP mode					
	Resolution [µs]	Maximum Time Setting [s]	Resolution [µs]	Maximum Time Setting [s]	Resolution [µs]	Maximum Time Setting [s]			
00	128	8.39	244.14	16.0	244.14	16.0			
01	8.0	0.524	8.0	0.524	-	-			
10	0.5	32.77 m	0.5	32.77 m	-	-			

Example 1 :Setting the timer mode with source clock $fc/2^{11}$ [Hz] and generating an interrupt 1 second later (fc = 16 MHz, TBTCR < DV7CK > = "0")

LDW (TC1DRA), 1E84H ; Sets the timer register (1 s \div 2¹¹/fc = 1E84H) DI ; IMF= "0" SET (EIRH). 3 ; Enables INTTC1 ΕI ; IMF= "1" LD (TC1CR), 00000000B ; Selects the source clock and mode LD (TC1CR), 00010000B : Starts TC1

Example 2: Auto-capture

LD (TC1CR), 01010000B ; ACAP1 ← 1
: :
LD WA, (TC1DRB) ; Reads the capture value

Note: Since the up-counter value is captured into TC1DRB by the source clock of up-counter after setting TC1CR<ACAP1> to "1". Therefore, to read the captured value, wait at least one cycle of the internal source clock before reading TC1DRB for the first time.




Figure 10-2 Timer Mode Timing Chart

10.3.2 External Trigger Timer Mode

In the external trigger timer mode, the up-counter starts counting by the input pulse triggering of the TC1 pin, and counts up at the edge of the internal clock. For the trigger edge used to start counting, either the rising or falling edge is defined in TC1CR<TC1S>.

• When TC1CR<METT1> is set to "1" (trigger start and stop)

When a match between the up-counter and the TC1DRA value is detected after the timer starts, the up-counter is cleared and halted and an INTTC1 interrupt request is generated.

If the edge opposite to trigger edge is detected before detecting a match between the up-counter and the TC1DRA, the up-counter is cleared and halted without generating an interrupt request. Therefore, this mode can be used to detect exceeding the specified pulse by interrupt.

After being halted, the up-counter restarts counting when the trigger edge is detected.

• When TC1CR<METT1> is set to "0" (trigger start)

When a match between the up-counter and the TC1DRA value is detected after the timer starts, the up-counter is cleared and halted and an INTTC1 interrupt request is generated.

The edge opposite to the trigger edge has no effect in count up. The trigger edge for the next counting is ignored if detecting it before detecting a match between the up-counter and the TC1DRA.

Since the TC1 pin input has the noise rejection, pulses of 4/fc [s] or less are rejected as noise. A pulse width of 12/fc [s] or more is required to ensure edge detection. The rejection circuit is turned off in the SLOW1/2 or SLEEP1/2 mode, but a pulse width of one machine cycle or more is required.

Example 1 :Generating an interrupt 1 ms after the rising edge of the input pulse to the TC1 pin (fc = 16 MHz)

```
LDW
               (TC1DRA), 007DH
                                          ; 1ms ÷ 27/fc = 7DH
DI
                                          ; IMF= "0"
SET
               (EIRH). 3
                                          ; Enables INTTC1 interrupt
                                          : IMF= "1"
ΕI
LD
               (TC1CR), 00000100B
                                           ; Selects the source clock and mode
LD
               (TC1CR), 00100100B
                                          ; Starts TC1 external trigger, METT1= 0
```

Example 2 :Generating an interrupt when the low-level pulse with 4 ms or more width is input to the TC1 pin (fc = 16 MHz)

LDW	(TC1DRA), 01F4H	; 4 ms \div 2 ⁷ /fc = 1F4H
DI		; IMF= "0"
SET	(EIRH). 3	; Enables INTTC1 interrupt
El		; IMF= "1"
LD	(TC1CR), 00000100B	; Selects the source clock and mode
LD	(TC1CR), 01110100B	; Starts TC1 external trigger, METT1= 1




Figure 10-3 External Trigger Timer Mode Timing Chart

10.3.3 Event Counter Mode

In the event counter mode, the up-counter counts up at the edge of the input pulse to the TC1 pin. Either the rising or falling edge of the input pulse is selected as the count up edge in TC1CR<TC1S>.

When a match between the up-counter and the TC1DRA value is detected, an INTTC1 interrupt is generated and the up-counter is cleared. After being cleared, the up-counter restarts counting at each edge of the input pulse to the TC1 pin. Since a match between the up-counter and the value set to TC1DRA is detected at the edge opposite to the selected edge, an INTTC1 interrupt request is generated after a match of the value at the edge opposite to the selected edge.

Two or more machine cycles are required for the low-or high-level pulse input to the TC1 pin.

Setting TC1CR<ACAP1> to "1" captures the up-counter value into TC1DRB with the auto capture function. Use the auto-capture function in the operative condition of TC1. A captured value may not be fixed if it's read after the execution of the timer stop or auto-capture disable. Read the capture value in a capture enabled condition. Since the up-counter value is captured into TC1DRB by the source clock of up-counter after setting TC1CR<ACAP1> to "1". Therefore, to read the captured value, wait at least one cycle of the internal source clock before reading TC1DRB for the first time.




Figure 10-4 Event Counter Mode Timing Chart

Table 10-2 Input Pulse Width to TC1 Pin

	Minimum Pulse Width [s]					
	NORMAL1/2, IDLE1/2 Mode	SLOW1/2, SLEEP1/2 Mode				
High-going	2 ³ /fc	2³/fs				
Low-going	2 ³ /fc	2³/fs				

10.3.4 Window Mode

In the window mode, the up-counter counts up at the rising edge of the pulse that is logical ANDed product of the input pulse to the TC1 pin (window pulse) and the internal source clock. Either the positive logic (count up during high-going pulse) or negative logic (count up during low-going pulse) can be selected.

When a match between the up-counter and the TC1DRA value is detected, an INTTC1 interrupt is generated and the up-counter is cleared.

Define the window pulse to the frequency which is sufficiently lower than the internal source clock programmed with TC1CR<TC1CK>.




Figure 10-5 Window Mode Timing Chart

10.3.5 Pulse Width Measurement Mode

In the pulse width measurement mode, the up-counter starts counting by the input pulse triggering of the TC1 pin, and counts up at the edge of the internal clock. Either the rising or falling edge of the internal clock is selected as the trigger edge in TC1CR<TC1S>. Either the single- or double-edge capture is selected as the trigger edge in TC1CR<MCAP1>.

• When TC1CR<MCAP1> is set to "1" (single-edge capture)

Either high- or low-level input pulse width can be measured. To measure the high-level input pulse width, set the rising edge to TC1CR<TC1S>. To measure the low-level input pulse width, set the falling edge to TC1CR<TC1S>.

When detecting the edge opposite to the trigger edge used to start counting after the timer starts, the up-counter captures the up-counter value into TC1DRB and generates an INTTC1 interrupt request. The up-counter is cleared at this time, and then restarts counting when detecting the trigger edge used to start counting.

• When TC1CR<MCAP1> is set to "0" (double-edge capture)

The cycle starting with either the high- or low-going input pulse can be measured. To measure the cycle starting with the high-going pulse, set the rising edge to TC1CR<TC1S>. To measure the cycle starting with the low-going pulse, set the falling edge to TC1CR<TC1S>.


When detecting the edge opposite to the trigger edge used to start counting after the timer starts, the up-counter captures the up-counter value into TC1DRB and generates an INTTC1 interrupt request. The up-counter continues counting up, and captures the up-counter value into TC1DRB and generates an INTTC1 interrupt request when detecting the trigger edge used to start counting. The up-counter is cleared at this time, and then continues counting.

- Note 1: The captured value must be read from TC1DRB until the next trigger edge is detected. If not read, the captured value becomes a don't care. It is recommended to use a 16-bit access instruction to read the captured value from TC1DRB.
- Note 2: For the single-edge capture, the counter after capturing the value stops at "1" until detecting the next edge.

 Therefore, the second captured value is "1" larger than the captured value immediately after counting starts.
- Note 3: The first captured value after the timer starts may be read incorrectively, therefore, ignore the first period captured values.

Example :Duty measurement (resolution fc/2⁷ [Hz])

	CLR	(INTTC1SW). 0	; INTTC1 service switch initial setting Address set to convert INTTC1SW at each INTTC1
	LD	(TC1CR), 00000110B	; Sets the TC1 mode and source clock
	DI		; IMF= "0"
	SET	(EIRH). 3	; Enables INTTC1
	EI		; IMF= "1"
	LD	(TC1CR), 00100110B	; Starts TC1 with an external trigger at MCAP1 = 0
	:		
PINTTC1:	CPL	(INTTC1SW). 0	; INTTC1 interrupt, inverts and tests INTTC1 service switch
	JRS	F, SINTTC1	
	LD	A, (TC1DRBL)	; Reads TC1DRB (High-level pulse width)
	LD	W,(TC1DRBH)	
	LD	(HPULSE), WA	; Stores high-level pulse width in RAM
	RETI		
SINTTC1:	LD	A, (TC1DRBL)	; Reads TC1DRB (Cycle)
	LD	W,(TC1DRBH)	
	LD	(WIDTH), WA	; Stores cycle in RAM
	:		
	RETI		; Duty calculation
	:		
VINTTC1:	DW	PINTTC1	; INTTC1 Interrupt vector






Figure 10-6 Pulse Width Measurement Mode

10.3.6 Programmable Pulse Generate (PPG) Output Mode

In the programmable pulse generation (PPG) mode, an arbitrary duty pulse is generated by counting performed in the internal clock. To start the timer, TC1CR<TC1S> specifies either the edge of the input pulse to the TC1 pin or the command start. TC1CR<MPPG1> specifies whether a duty pulse is produced continuously or not (one-shot pulse).

• When TC1CR<MPPG1> is set to "0" (Continuous pulse generation)

When a match between the up-counter and the TC1DRB value is detected after the timer starts, the level of the \overline{PPG} pin is inverted and an INTTC1 interrupt request is generated. The up-counter continues counting. When a match between the up-counter and the TC1DRA value is detected, the level of the \overline{PPG} pin is inverted and an INTTC1 interrupt request is generated. The up-counter is cleared at this time, and then continues counting and pulse generation.

When TC1S is cleared to "00" during PPG output, the \overline{PPG} pin retains the level immediately before the counter stops.

• When TC1CR<MPPG1> is set to "1" (One-shot pulse generation)

When a match between the up-counter and the TC1DRB value is detected after the timer starts, the level of the \overline{PPG} pin is inverted and an INTTC1 interrupt request is generated. The up-counter continues counting. When a match between the up-counter and the TC1DRA value is detected, the level of the \overline{PPG} pin is inverted and an INTTC1 interrupt request is generated. TC1CR<TC1S> is cleared to "00" automatically at this time, and the timer stops. The pulse generated by PPG retains the same level as that when the timer stops.

Since the output level of the \overline{PPG} pin can be set with TC1CR<TFF1> when the timer starts, a positive or negative pulse can be generated. Since the inverted level of the timer F/F1 output level is output to the \overline{PPG} pin, specify TC1CR<TFF1> to "0" to set the high level to the \overline{PPG} pin, and "1" to set the low level to the \overline{PPG} pin. Upon reset, the timer F/F1 is initialized to "0".

- Note 1: To change TC1DRA or TC1DRB during a run of the timer, set a value sufficiently larger than the count value of the counter. Setting a value smaller than the count value of the counter during a run of the timer may generate a pulse different from that specified.
- Note 2: Do not change TC1CR<TFF1> during a run of the timer. TC1CR<TFF1> can be set correctly only at initialization (after reset). When the timer stops during PPG, TC1CR<TFF1> can not be set correctly from this point onward if the PPG output has the level which is inverted of the level when the timer starts. (Setting TC1CR<TFF1> specifies the timer F/F1 to the level inverted of the programmed value.) Therefore, the timer F/F1 needs to be initialized to ensure an arbitrary level of the PPG output. To initialize the timer F/F1, change TC1CR<TC1M> to the timer mode (it is not required to start the timer mode), and then set the PPG mode. Set TC1CR<TFF1> at this time.
- Note 3: In the PPG mode, the following relationship must be satisfied. TC1DRA > TC1DRB
- Note 4: Set TC1DRB after changing the mode of TC1M to the PPG mode.

Example :Generating a pulse which is high-going for 800 μ s and low-going for 200 μ s (fc = 16 MHz)

Setting port LD (TC1CR), 10000111B ; Sets the PPG mode, selects the source clock LDW (TC1DRA), 007DH ; Sets the cycle (1 ms \div 2 7 /fc μ s = 007DH) LDW (TC1DRB), 0019H ; Sets the low-level pulse width (200 μ s \div 2 7 /fc = 0019H) LD (TC1CR), 10010111B ; Starts the timer

Example : After stopping PPG, setting the PPG pin to a high-level to restart PPG (fc = 16 MHz)

	Setting port	
LD	(TC1CR), 10000111B	; Sets the PPG mode, selects the source clock
LDW	(TC1DRA), 007DH	; Sets the cycle (1 ms \div 2 7 /fc μ s = 007DH)
LDW	(TC1DRB), 0019H	; Sets the low-level pulse width (200 $\mu s \div 2^7/fc$ = 0019H)
LD	(TC1CR), 10010111B	; Starts the timer
:	:	
LD	(TC1CR), 10000111B	; Stops the timer
LD	(TC1CR), 10000100B	; Sets the timer mode
LD	(TC1CR), 00000111B	; Sets the PPG mode, TFF1 = 0
LD	(TC1CR), 00010111B	; Starts the timer




Figure 10-7 PPG Output




Figure 10-8 PPG Mode Timing Chart

10.	16-Bit Timer/Counter 1 (TC1)	

TOSHIBA TMP86FH92DMG

11. 8-Bit TimerCounter (TC3, TC4)

11.1 Configuration




Figure 11-1 8-Bit TimerCounter 3, 4

11.2 TimerCounter Control TMP86FH92DMG

11.2 TimerCounter Control

The TimerCounter 3 is controlled by the TimerCounter 3 control register (TC3CR) and two 8-bit timer registers (TTREG3, PWREG3).

TimerCounter 3 Timer Register

TTREG3	7	6	5	4	3	2	1	0	
(001CH) R/W									(Initial value: 1111 1111)
IV VV									I
PWREG3	7	6	5	4	3	2	1	0	
(001EH) R/W									(Initial value: 1111 1111)

Note 1: Do not change the timer register (TTREG3) setting while the timer is running.

Note 2: Do not change the timer register (PWREG3) setting in the operating mode except the 8-bit and 16-bit PWM modes while the timer is running.

TimerCounter 3 Control Register

TC3CR	7	6	5	4	3	2	1	0	_
(001AH)	TFF3		тсзск		TC3S		ТС3М		(Initial value: 0000 0000)

TFF3	Time F/F3 control (Note 2,3)	0: Clear 1: Set				R/W			
			NORMAL1/2, DV7CK = 0	IDLE1/2 mode DV7CK = 1	SLOW1/2 SLEEP1/2 mode				
		000	fc/2 ¹¹	fs/2 ³	fs/2³				
TC3CK Operating clock selection [Hz] (Note 2,3,6)		001	fc/2 ⁷	fc/2 ⁷	-				
	010	fc/2 ⁵	fc/2 ⁵	-	R/W				
	(Note 2,3,6)	011	fc/2 ³	fc/2 ³	-				
		100	fs	fs	fs				
		101	fc/2	fc/2	-				
		110	fc (Note 8)	fc (Note 8)	fc (Note 8)				
		111	TC3 pin input						
TC3S	TC3 start control (Note 3)		on stop and counter cl	ear		R/W			
ТСЗМ	TC3M operating mode select (Note 2,3,7)	001: 8-bit pro 010: 8-bit pul 011: 16-bit m (Each m	000: 8-bit timer/event counter mode 001: 8-bit programmable divider output (PDO) mode 010: 8-bit pulse width modulation (PWM) output mode 011: 16-bit mode (Note 4,5) (Each mode is selectable with TC4M.)						

Note 1: fc: High-frequency clock [Hz] fs: Low-frequency clock[Hz]

Note 2: Do not change the TC3M, TC3CK and TFF3 settings while the timer is running.

Note 3: To stop the timer operation (TC3S= $1 \rightarrow 0$), do not change the TC3M, TC3CK and TFF3 settings. To start the timer operation (TC3S= $0 \rightarrow 1$), TC3M, TC3CK and TFF3 can be programmed.

Note 4: To use the TimerCounter in the 16-bit mode, set the operating mode by programming TC4CR<TC4M>, where TC3M must be fixed to 011.

Note 5: To use the TimerCounter in the 16-bit mode, select the source clock by programming TC3CK. Set the timer start control and timer F/F control by programming TC4CR<TC4S> and TC4CR<TFF4>, respectively.

Note 6: The operating clock settings are limited depending on the timer operating mode. For the detailed descriptions, see Table 11-1 and Table 11-2.

Note 7: The timer register settings are limited depending on the timer operating mode. For the detailed descriptions, see Table 11-3.

TMP86FH92DMG

Note 8: The clock "fc" can be selected as the source clock only in 8/16 bit PWM mode and in warming-up counter mode in SLOW or SLEEP mode.

11.2 TimerCounter Control TMP86FH92DMG

The TimerCounter 4 is controlled by the TimerCounter 4 control register (TC4CR) and two 8-bit timer registers (TTREG4 and PWREG4).

TimerCounter 4 Timer Register

TTREG4	7	6	5	4	3	2	1	0	
(001DH)									(Initial value: 1111 1111)
R/W									(IIIIIIai value. 1111 1111)
PWREG4	7	6	5	4	3	2	1	0	
(001FH)									(
R/W									(Initial value: 1111 1111)

Note 1: Do not change the timer register (TTREG4) setting while the timer is running.

Note 2: Do not change the timer register (PWREG4) setting in the operating mode except the 8-bit and 16-bit PWM modes while the timer is running.

TimerCounter 4 Control Register

TC4CR	7	6	5	4	3	2	1	0	_
(001BH)	TFF4		TC4CK		TC4S		TC4M		(Initial value: 0000 0000)

TFF4	Timer F/F4 control (Note 2,3)	0: Clear 1: Set				R/W			
			NORMAL1/2,	IDLE1/2 mode	SLOW1/2				
			DV7CK = 0	DV7CK = 1	SLEEP1/2 mode				
		000	fc/2 ¹¹	fs/2 ³	fs/2 ³				
		001	fc/2 ⁷	fc/2 ⁷	-				
TC4CK	TC4CK Operating clock selection [Hz]	010	fc/2 ⁵	fc/2 ⁵	-	R/W			
(Note 2,3,7)	011	fc/2 ³	fc/2 ³	-					
		100	fs	fs	fs				
		101	fc/2	fc/2	-				
		110	fc (Note 9)	fc (Note 9)	-				
		111		TC4 pin input		1			
TC4S	TC4 start control (Note 3)	0: Operation	on stop and counter cl	ear		R/W			
TC4M	TC4M operating mode select (Note 2,3,8)	001: 8-bit pro 010: 8-bit pul 011: Reserve 100: 16-bit tii 101: Warm-u	000: 8-bit timer/event counter mode 001: 8-bit programmable divider output (PDO) mode 010: 8-bit pulse width modulation (PWM) output mode 011: Reserved 100: 16-bit timer/event counter mode 101: Warm-up counter mode 110: 16-bit pulse width modulation (PWM) output mode						

Note 1: fc: High-frequency clock [Hz] fs: Low-frequency clock [Hz]

Note 2: Do not change the TC4M, TC4CK and TFF4 settings while the timer is running.

Note 3: To stop the timer operation (TC4S= 1 \rightarrow 0), do not change the TC4M, TC4CK and TFF4 settings. To start the timer operation (TC4S= 0 \rightarrow 1), TC4M, TC4CK and TFF4 can be programmed.

Note 4: When TC4M= 1** (upper byte in the 16-bit mode), the source clock becomes the TC3 overflow signal regardless of the TC4CK setting.

Note 5: To use the TimerCounter in the 16-bit mode, select the operating mode by programming TC4M, where TC3CR<TC3M> must be set to 011.

Note 6: To the TimerCounter in the 16-bit mode, select the source clock by programming TC3CR<TC3CK>. Set the timer start control and timer F/F control by programming TC4S and TFF4, respectively.

Note 7: The operating clock settings are limited depending on the timer operating mode. For the detailed descriptions, see Table 11-1 and Table 11-2.

Note 8: The timer register settings are limited depending on the timer operating mode. For the detailed descriptions, see Table

Note 9: The clock "fc" can be selected as the source clock only in 8 bit PWM mode.

Table 11-1 Operating Mode and Selectable Source Clock (NORMAL1/2 and IDLE1/2 Modes)

Operating mode	fc/2 ¹¹ or fs/2 ³	fc/2 ⁷	fc/2 ⁵	fc/2³	fs	fc/2	fc	TC3 pin input	TC4 pin input
8-bit timer	0	0	0	0	-	-	-	-	-
8-bit event counter	-	-	-	-	-	-	-	0	0
8-bit PDO	0	0	0	0	-	-	-	-	-
8-bit PWM	0	0	0	0	0	0	0	-	-
16-bit timer	0	0	0	0	-	-	-	-	-
16-bit event counter	-	-	-	-	-	-	-	0	-
Warm-up counter	-	-	-	-	0	-	-	-	-
16-bit PWM	0	0	0	0	0	0	0	0	-
16-bit PPG	0	0	0	0	-	-	-	0	-

Note 1: For 16-bit operations (16-bit timer/event counter, warm-up counter, 16-bit PWM and 16-bit PPG), set its source clock on lower bit (TC3CK).

Note 2: O: Available source clock

Table 11-2 Operating Mode and Selectable Source Clock (SLOW1/2 and SLEEP1/2 Modes)

Operating mode	fc/2 ¹¹ or fs/2 ³	fc/2 ⁷	fc/2 ⁵	fc/2³	fs	fc/2	fc	TC3 pin input	TC4 pin input
8-bit timer	0	-	-	-	-	-	-	-	-
8-bit event counter	-	-	-	-	-	-	-	0	0
8-bit PDO	0	-	-	-	-	-	-	-	-
8-bit PWM	0	-	-	-	0	-	-	-	-
16-bit timer	0	-	-	-	-	-	-	-	-
16-bit event counter	-	-	-	-	-	-	-	0	-
Warm-up counter	-	-	-	-	-	-	0	-	-
16-bit PWM	0	-	-	-	0	-	-	0	-
16-bit PPG	0	-	-	-	-	-	-	0	-

Note 1: For 16-bit operations (16-bit timer/event counter, warm-up counter, 16-bit PWM and 16-bit PPG), set its source clock on lower bit (TC3CK).
Note 2: O : Available source clock

11.2 TimerCounter Control TMP86FH92DMG

Table 11-3 Constraints on Register Values Being Compared

Operating mode	Register Value
8-bit timer/event counter	1≤ (TTREGn) ≤255
8-bit PDO	1≤ (TTREGn) ≤255
8-bit PWM	2≤ (PWREGn) ≤254
16-bit timer/event counter	1≤ (TTREG4, 3) ≤65535
Warm-up counter	256≤ (TTREG4, 3) ≤65535
16-bit PWM	2≤ (PWREG4, 3) ≤65534
16-bit PPG	1≤ (PWREG4, 3) < (TTREG4, 3) ≤65535 and (PWREG4, 3) + 1 < (TTREG4, 3)

Note:n = 3 to 4

TMP86FH92DMG

11.3 Function

The TimerCounter 3 and 4 have the 8-bit timer, 8-bit event counter, 8-bit programmable divider output (PDO), 8-bit pulse width modulation (PWM) output modes. The TimerCounter 3 and 4 (TC3, 4) are cascadable to form a 16-bit timer. The 16-bit timer has the operating modes such as the 16-bit timer, 16-bit event counter, warm-up counter, 16-bit pulse width modulation (PWM) output and 16-bit programmable pulse generation (PPG) modes.

11.3.1 8-Bit Timer Mode (TC3 and 4)

In the timer mode, the up-counter counts up using the internal clock. When a match between the up-counter and the timer register j (TTREGj) value is detected, an INTTCj interrupt is generated and the up-counter is cleared. After being cleared, the up-counter restarts counting.

Note 1: In the timer mode, fix TCjCR<TFFj> to 0. If not fixed, the PDOj, PWMj and PPGj pins may output pulses.

Note 2: In the timer mode, do not change the TTREGj setting while the timer is running. Since TTREGj is not in the shift register configuration in the timer mode, the new value programmed in TTREGj is in effect immediately after the programming. Therefore, if TTREGj is changed while the timer is running, an expected operation may not be obtained.

Note 3: j = 3, 4

Table 11-4 Source Clock for Timer Counter 3, 4 (Internal Clock)

	Source Clock (Note)		Reso	lution	Maximum Setting Time		
NORMAL1/2,	NORMAL1/2, IDLE1/2 mode					fs = 32.768 kHz	
DV7CK = 0	DV7CK = 1	SLEEP1/2 fc = 16 MHz mode		fs = 32.768 kHz	fc = 16 MHz		
fc/2 ¹¹ [Hz]	fs/23 [Hz]	fs/2³ [Hz]	128 µs	244.14 µs	32.6 ms	62.3 ms	
fc/2 ⁷	fc/2 ⁷	-	8 µs	-	2.0 ms	-	
fc/2 ⁵	fc/2 ⁵	-	2 μs	-	510 μs	-	
fc/2 ³	fc/2 ³	-	500 ns	-	127.5 µs	-	

Note: In the timer mode, do not select a source clock other than those shown above.

Example :Setting the timer mode with source clock $fc/2^7$ Hz and generating an interrupt 80 μ s later (TimerCounter4, fc = 16.0 MHz)

LD (TTREG4), 0AH ; Sets the timer register (80 μ s ÷ 2 7 /fc = 0AH).

DI

SET (EIRH). 7 ; Enables INTTC4 interrupt.

ΕI

LD (TC4CR), 00010000B ; Sets the operating clock to $fc/2^7$, and 8-bit timer mode.

LD (TC4CR), 00011000B ; Starts TC4.




Figure 11-2 8-Bit Timer Mode Timing Chart (TC4)

11.3.2 8-Bit Event Counter Mode (TC3, 4)

In the 8-bit event counter mode, the up-counter counts up at the falling edge of the input pulse to the TCj pin. When a match between the up-counter and the TTREGj value is detected, an INTTCj interrupt is generated and the up-counter is cleared. After being cleared, the up-counter restarts counting at the falling edge of the input pulse to the TCj pin. Two machine cycles are required for the low- or high-level pulse input to the TCj pin. Therefore, a maximum frequency to be supplied is fc/2⁴ Hz in the NORMAL1/2 or IDLE1/2 mode, and fs/2⁴ Hz in the SLOW1/2 or SLEEP1/2 mode.

Note 1: In the event counter mode, fix TCjCR<TFFj> to 0. If not fixed, the PDOj, PWMj and PPGj pins may output nulses

Note 2: In the event counter mode, do not change the TTREGj setting while the timer is running. Since TTREGj is not in the shift register configuration in the event counter mode, the new value programmed in TTREGj is in effect immediately after the programming. Therefore, if TTREGj is changed while the timer is running, an expected operation may not be obtained.

Note 3: j = 3, 4




Figure 11-3 8-Bit Event Counter Mode Timing Chart (TC4)

11.3.3 8-Bit Programmable Divider Output (PDO) Mode (TC3, 4)

This mode is used to generate a pulse with a 50% duty cycle from the \overline{PDOj} pin.

In the PDO mode, the up-counter counts up using the internal \underline{clock} . When a match between the up-counter and the TTREGj value is detected, the logic level output from the \overline{PDOj} pin is switched to the opposite state and the up-counter is cleared. The INTTCj interrupt request is generated at the time. The logic state opposite to the timer F/Fj logic level is output from the \overline{PDOj} pin. An arbitrary value can be set to the timer F/Fj by TCjCR<TFFj>. Upon reset, the timer F/Fj value is initialized to 0.

To use the programmable divider output, set the output latch of the I/O port to 1.

TMP86FH92DMG

Example :Generating 1024 Hz pulse using TC4 (fc = 16.0 MHz)

Setting port

LD (TTREG4), 3DH ; $1/1024 \div 2^{7}/\text{fc} \div 2 = 3DH$

LD (TC4CR), 00010001B ; Sets the operating clock to fc/2⁷, and 8-bit PDO mode.

LD (TC4CR), 00011001B ; Starts TC4.

Note 1: In the programmable divider output mode, do not change the TTREGj setting while the timer is running. Since TTREGj is not in the shift register configuration in the programmable divider output mode, the new value programmed in TTREGj is in effect immediately after programming. Therefore, if TTREGj is changed while the timer is running, an expected operation may not be obtained.

Note 2: When the timer is stopped during PDO output, the PDOj pin holds the output status when the timer is stopped. To change the output status, program TCjCR<TFFj> after the timer is stopped. Do not change the TCjCR<TFFj> setting upon stopping of the timer.

Example: Fixing the PDOj pin to the high level when the TimerCounter is stopped

CLR (TCjCR).3; Stops the timer.

CLR (TCjCR).7; Sets the PDOj pin to the high level.

Note 3: j = 3, 4




Figure 11-4 8-Bit PDO Mode Timing Chart (TC4)

11.3.4 8-Bit Pulse Width Modulation (PWM) Output Mode (TC3, 4)

This mode is used to generate a pulse-width modulated (PWM) signals with up to 8 bits of resolution. The upcounter counts up using the internal clock.

When a match between the up-counter and the PWREGj value is detected, the logic level output from the timer F/Fj is switched to the opposite state. The counter continues counting. The logic level output from the timer F/Fj is switched to the opposite state again by the up-counter overflow, and the counter is cleared. The INTTCj interrupt request is generated at this time.

Since the initial value can be set to the timer F/Fj by TCjCR<TFFj>, positive and negative pulses can be generated. Upon reset, the timer F/Fj is cleared to 0.

(The logic level output from the PWMj pin is the opposite to the timer F/Fj logic level.)

Since PWREGj in the PWM mode is serially connected to the shift register, the value set to PWREGj can be changed while the timer is running. The value set to PWREGj during a run of the timer is shifted by the INTTCj interrupt request and loaded into PWREGj. While the timer is stopped, the value is shifted immediately after the programming of PWREGj. If executing the read instruction to PWREGj during PWM output, the value in the shift register is read, but not the value set in PWREGj. Therefore, after writing to PWREGj, the reading data of PWREGj is previous value until INTTCj is generated.

For the pin used for PWM output, the output latch of the I/O port must be set to 1.

- Note 1: In the PWM mode, program the timer register PWREGj immediately after the INTTCj interrupt request is generated (normally in the INTTCj interrupt service routine.) If the programming of PWREGj and the interrupt request occur at the same time, an unstable value is shifted, that may result in generation of the pulse different from the programmed value until the next INTTCj interrupt request is generated.
- Note 2: When the timer is stopped during PWM output, the PWMj pin holds the output status when the timer is stopped. To change the output status, program TCjCR<TFFj> after the timer is stopped. Do not change the TCjCR<TFFj> upon stopping of the timer.

Example: Fixing the PWMj pin to the high level when the TimerCounter is stopped

CLR (TCjCR).3; Stops the timer.

CLR (TCjCR).7; Sets the PWMj pin to the high level.

Note 3: To enter the STOP mode during PWM output, stop the timer and then enter the STOP mode. If the STOP mode is entered without stopping the timer when fc, fc/2 or fs is selected as the source clock, a pulse is output from the PWMj pin during the warm-up period time after exiting the STOP mode.

Note 4: j = 3, 4

Table 11-5 PWM Output Mode

Source Clock			Reso	lution	Repeated Cycle		
NORMAL1/2,	IDLE1/2 mode	SLOW1/2,					
DV7CK = 0	DV7CK = 1	SLEEP1/2 fc = 16 MHz f		fs = 32.768 kHz	fc = 16 MHz	fs = 32.768 kHz	
fc/2 ¹¹ [Hz]	fs/23 [Hz]	fs/23 [Hz]	128 µs	244.14 µs	32.8 ms	62.5 ms	
fc/2 ⁷	fc/2 ⁷	-	8 µs	-	2.05 ms	-	
fc/2 ⁵	fc/2 ⁵	-	2 μs	-	512 µs	-	
fc/2³	fc/2 ³	-	500 ns	-	128 µs	-	
fs	fs	fs	30.5 µs	30.5 µs	7.81 ms	7.81 ms	
fc/2	fc/2	-	125 ns	-	32 µs	-	
fc	fc	-	62.5 ns	-	16 µs	-	




Figure 11-5 8-Bit PWM Mode Timing Chart (TC4)

11.3.5 16-Bit Timer Mode (TC3 and 4)

In the timer mode, the up-counter counts up using the internal clock. The TimerCounter 3 and 4 are cascadable to form a 16-bit timer.

When a match between the up-counter and the timer register (TTREG3, TTREG4) value is detected after the timer is started by setting TC4CR<TC4S> to 1, an INTTC4 interrupt is generated and the up-counter is cleared. After being cleared, the up-counter continues counting. Program the lower byte and upper byte in this order in the timer register. (Programming only the upper or lower byte should not be attempted.)

Note 1: In the timer mode, fix TCjCR<TFFj> to 0. If not fixed, the PDOj, PWMj, and PPGj pins may output a pulse.

Note 2: In the timer mode, do not change the TTREGj setting while the timer is running. Since TTREGj is not in the shift register configuration in the timer mode, the new value programmed in TTREGj is in effect immediately after programming of TTREGj. Therefore, if TTREGj is changed while the timer is running, an expected operation may not be obtained.

Note 3: i = 3, 4

Table 11-6 Source Clock for 16-Bit Timer Mode

Source Clock			Reso	lution	Maximum Setting Time		
NORMAL1/2,	NORMAL1/2, IDLE1/2 mode						
DV7CK = 0	DV7CK = 1	SLEEP1/2 fc = 16 MHz mode		fs = 32.768 kHz	fc = 16 MHz	fs = 32.768 kHz	
fc/2 ¹¹	fs/2 ³	fs/2 ³	128 µs	244.14 µs	8.39 s	16 s	
fc/2 ⁷	fc/2 ⁷	-	8 µs	-	524.3 ms	-	
fc/2 ⁵	fc/2 ⁵	-	2 μs	-	131.1 ms	-	
fc/2 ³	fc/2 ³	-	500 ns	-	32.8 ms	-	

Example :Setting the timer mode with source clock $fc/2^7$ [Hz], and generating an interrupt 300 ms later (fc = 16.0 MHz)

LDW (TTREG3), 927CH ; Sets the timer register (300 ms \div 2⁷/fc = 927CH). DI SET (EIRH). 7 ; Enables INTTC4 interrupt. ΕI LD (TC3CR), 13H ; Sets the operating clock to fc/27, and 16-bit timer mode : (lower byte). LD (TC4CR), 04H ; Sets the 16-bit timer mode (upper byte). ΙD (TC4CR), 0CH : Starts the timer.




Figure 11-6 16-Bit Timer Mode Timing Chart (TC3 and TC4)

11.3.6 16-Bit Event Counter Mode (TC3 and 4)

In the event counter mode, the up-counter counts up at the falling edge to the TC3 pin. The TimerCounter 3 and 4 are cascadable to form a 16-bit event counter.

When a match between the up-counter and the timer register (TTREG3, TTREG4) value is detected after the timer is started by setting TC4CR<TC4S> to 1, an INTTC4 interrupt is generated and the up-counter is cleared.

After being cleared, the up-counter restarts counting at the falling edge of the input pulse to the TC3 pin. Two machine cycles are required for the low- or high-level pulse input to the TC3 pin.

Therefore, a maximum frequency to be supplied is fc/2⁴ Hz in the NORMAL1/2 or IDLE1/2 mode, and fs/2⁴ in the SLOW1/2 or SLEEP1/2 mode. Program the lower byte (TTREG3), and upper byte (TTREG4) in this order in the timer register. (Programming only the upper or lower byte should not be attempted.)

Note 1: In the event counter mode, fix TCjCR<TFFj> to 0. If not fixed, the PDOj, PWMj and PPGj pins may output pulses.

Note 2: In the event counter mode, do not change the TTREGj setting while the timer is running. Since TTREGj is not in the shift register configuration in the event counter mode, the new value programmed in TTREGj is in effect immediately after the programming. Therefore, if TTREGj is changed while the timer is running, an expected operation may not be obtained.

Note 3: j = 3, 4

11.3.7 16-Bit Pulse Width Modulation (PWM) Output Mode (TC3 and 4)

This mode is used to generate a pulse-width modulated (PWM) signals with up to 16 bits of resolution. The TimerCounter 3 and 4 are cascadable to form the 16-bit PWM signal generator.

The counter counts up using the internal clock or external clock.

When a match between the up-counter and the timer register (PWREG3, PWREG4) value is detected, the logic level output from the timer F/F4 is switched to the opposite state. The counter continues counting. The logic level output from the timer F/F4 is switched to the opposite state again by the counter overflow, and the counter is cleared. The INTTC4 interrupt is generated at this time.

Two machine cycles are required for the high- or low-level pulse input to the TC3 pin. Therefore, a maximum frequency to be supplied is fc/2⁴ Hz in the NORMAL1/2 or IDLE1/2 mode, and fs/2⁴ to in the SLOW1/2 or SLEEP1/2 mode.

Since the initial value can be set to the timer F/F4 by TC4CR<TFF4>, positive and negative pulses can be generated. Upon reset, the timer F/F4 is cleared to 0.

(The logic level output from the PWM4 pin is the opposite to the timer F/F4 logic level.)

Since PWREG4 and 3 in the PWM mode are serially connected to the shift register, the values set to PWREG4 and 3 can be changed while the timer is running. The values set to PWREG4 and 3 during a run of the timer are shifted by the INTTCj interrupt request and loaded into PWREG4 and 3. While the timer is stopped, the values are shifted immediately after the programming of PWREG4 and 3. Set the lower byte (PWREG3) and upper byte (PWREG4) in this order to program PWREG4 and 3. (Programming only the lower or upper byte of the register should not be attempted.)

If executing the read instruction to PWREG4 and 3 during PWM output, the values set in the shift register is read, but not the values set in PWREG4 and 3. Therefore, after writing to the PWREG4 and 3, reading data of PWREG4 and 3 is previous value until INTTC4 is generated.

For the pin used for PWM output, the output latch of the I/O port must be set to 1.

- Note 1: In the PWM mode, program the timer register PWREG4 and 3 immediately after the INTTC4 interrupt request is generated (normally in the INTTC4 interrupt service routine.) If the programming of PWREGj and the interrupt request occur at the same time, an unstable value is shifted, that may result in generation of pulse different from the programmed value until the next INTTC4 interrupt request is generated.
- Note 2: When the timer is stopped during PWM output, the PWM4 pin holds the output status when the timer is stopped. To change the output status, program TC4CR<TFF4> after the timer is stopped. Do not program TC4CR<TFF4> upon stopping of the timer.

Example: Fixing the PWM4 pin to the high level when the TimerCounter is stopped

CLR (TC4CR).3; Stops the timer.

CLR (TC4CR).7; Sets the PWM4 pin to the high level.

Note 3: To enter the STOP mode, stop the timer and then enter the STOP mode. If the STOP mode is entered without stopping of the timer when fc, fc/2 or fs is selected as the source clock, a pulse is output from the PWM4 pin during the warm-up period time after exiting the STOP mode.

Table 11-7 16-Bit PWM Output Mode

	Source Clock			lution	Repeated Cycle		
NORMAL1/2,	IDLE1/2 mode	SLOW1/2,					
DV7CK = 0	DV7CK = 1	SLEEP1/2 mode	fc = 16 MHz	fs = 32.768 kHz	fc = 16 MHz	fs = 32.768 kHz	
fc/2 ¹¹	fs/2³ [Hz]	fs/23 [Hz]	128 µs	244.14 µs	8.39 s	16 s	
fc/2 ⁷	fc/2 ⁷	-	8 µs	-	524.3 ms	-	
fc/2 ⁵	fc/2 ⁵	-	2 μs	-	131.1 ms	-	
fc/2 ³	fc/2 ³	-	500 ns	-	32.8 ms	-	
fs	fs	fs	30.5 μs	30.5 μs	2 s	2 s	
fc/2	fc/2	-	125 ns	-	8.2 ms	-	
fc	fc	-	62.5 ns	-	4.1 ms	-	

Example: Generating a pulse with 1-ms high-level width and a period of 32.768 ms (fc = 16.0 MHz)

		Setting ports	
LD	W	(PWREG3), 07D0H	; Sets the pulse width.
LD)	(TC3CR), 33H	; Sets the operating clock to fc/ 2^{3} , and 16-bit PWM output mod
			; (lower byte).
LD)	(TC4CR), 056H	; Sets TFF4 to the initial value 0, and 16-bit PWM signal
			; generation mode (upper byte).
LD)	(TC4CR), 05EH	; Starts the timer.




Figure 11-7 16-Bit PWM Mode Timing Chart (TC3 and TC4)

11.3.8 16-Bit Programmable Pulse Generate (PPG) Output Mode (TC3 and 4)

This mode is used to generate pulses with up to 16-bits of resolution. The timer counter 3 and 4 are cascadable to enter the 16-bit PPG mode.

The counter counts up using the internal clock or external clock. When a match between the up-counter and the timer register (PWREG3, PWREG4) value is detected, the logic level output from the timer F/F4 is switched to the opposite state. The counter continues counting. The logic level output from the timer F/F4 is switched to the opposite state again when a match between the up-counter and the timer register (TTREG3, TTREG4) value is detected, and the counter is cleared. The INTTC4 interrupt is generated at this time.

Two machine cycles are required for the high- or low-level pulse input to the TC3 pin. Therefore, a maximum frequency to be supplied is fc/2⁴ Hz in the NORMAL1/2 or IDLE1/2 mode, and fs/2⁴ to in the SLOW1/2 or SLEEP1/2 mode.

Since the initial value can be set to the timer F/F4 by TC4CR<TFF4>, positive and negative pulses can be generated. Upon reset, the timer F/F4 is cleared to 0.

(The logic level output from the $\overline{PPG4}$ pin is the opposite to the timer F/F4.)

Set the lower byte and upper byte in this order to program the timer register. (TTREG3 → TTREG4, PWREG3 → PWREG4) (Programming only the upper or lower byte should not be attempted.)

For PPG output, set the output latch of the I/O port to 1.

Example :Generating a pulse with 1-ms high-level width and a period of 16.385 ms (fc = 16.0 MHz)

```
Setting ports
IDW
         (PWREG3), 07D0H
                                        ; Sets the pulse width.
LDW
         (TTREG3), 8002H
                                        ; Sets the cycle period
LD
         (TC3CR), 33H
                                        ; Sets the operating clock to fc/23, and16-bit PPG mode
                                        : (lower byte).
ΙD
         (TC4CR), 057H
                                        : Sets TFF4 to the initial value 0, and 16-bit
                                        ; PPG mode (upper byte).
LD
         (TC4CR), 05FH
                                        ; Starts the timer.
```

Note 1: In the PPG mode, do not change the PWREGi and TTREGi settings while the timer is running. Since PWREGi and TTREGi are not in the shift register configuration in the PPG mode, the new values programmed in PWREGi and TTREGi are in effect immediately after programming PWREGi and TTREGi. Therefore, if PWREGi and TTREGi are changed while the timer is running, an expected operation may not be obtained.

Note 2: When the timer is stopped during PPG output, the PPG4 pin holds the output status when the timer is stopped. To change the output status, program TC4CR<TFF4> after the timer is stopped. Do not change TC4CR<TFF4> upon stopping of the timer.

Example: Fixing the PPG4 pin to the high level when the TimerCounter is stopped

CLR (TC4CR).3; Stops the timer

CLR (TC4CR).7; Sets the PPG4 pin to the high level

Note 3: i = 3, 4




Figure 11-8 16-Bit PPG Mode Timing Chart (TC3 and TC4)

11.3.9 Warm-Up Counter Mode

In this mode, the warm-up period time is obtained to assure oscillation stability when the system clocking is switched between the high-frequency and low-frequency. The timer counter 3 and 4 are cascadable to form a 16-bit TimerCounter. The warm-up counter mode has two types of mode; switching from the high-frequency to low-frequency, and vice-versa.

- Note 1: In the warm-up counter mode, fix TCiCR<TFFi> to 0. If not fixed, the PDOi, PWMi and PPGi pins may output pulses.
- Note 2: In the warm-up counter mode, only upper 8 bits of the timer register TTREG4 and 3 are used for match detection and lower 8 bits are not used.

Note 3: i = 3, 4

11.3.9.1 Low-Frequency Warm-up Counter Mode (NORMAL1 → NORMAL2 → SLOW2 → SLOW1)

In this mode, the warm-up period time from a stop of the low-frequency clock fs to oscillation stability is obtained. Before starting the timer, set SYSCR2<XTEN> to 1 to oscillate the low-frequency clock. When a match between the up-counter and the timer register (TTREG4, 3) value is detected after the timer is started by setting TC4CR<TC4S> to 1, the counter is cleared by generating the INTTC4 interrupt request. After stopping the timer in the INTTC4 interrupt service routine, set SYSCR2<SYSCK> to 1 to switch the system clock from the high-frequency to low-frequency, and then clear of SYSCR2<XEN> to 0 to stop the high-frequency clock.

Table 11-8 Setting Time of Low-Frequency Warm-Up Counter Mode (fs = 32.768 kHz)

Minimum Time Setting	Maximum Time Setting
(TTREG4, 3 = 0100H)	(TTREG4, 3 = FF00H)
7.81 ms	1.99 s

Example : After checking low-frequency clock oscillation stability with TC4 and 3, switching to the SLOW1 mode

```
SET
                               (SYSCR2).6
                                                       ; SYSCR2<XTEN> ← 1
                 LD
                               (TC3CR), 43H
                                                       ; Sets TFF3=0, source clock fs, and 16-bit mode.
                 LD
                               (TC4CR), 05H
                                                       ; Sets TFF4=0, and warm-up counter mode
                 LDW
                               (TTREG3), 8000H
                                                       : Sets the warm-up time.
                                                       ; (The warm-up time depends on the oscillator characteristic.)
                 DI
                                                       : IMF ← 0
                 SET
                               (EIRH). 7
                                                       ; Enables the INTTC4.
                 FΙ
                                                       : IMF ← 1
                 SET
                               (TC4CR).3
                                                       ; Starts TC4 and 3.
PINTTC4:
                 CLR
                               (TC4CR).3
                                                       ; Stops TC4 and 3.
                               (SYSCR2).5
                                                       ; SYSCR2<SYSCK> ← 1
                 SET
                                                       ; (Switches the system clock to the low-frequency clock.)
                 CLR
                               (SYSCR2).7
                                                       ; SYSCR2<XEN> \leftarrow 0 (Stops the high-frequency clock.)
                 RET
                               PINTTC4
VINTTC4:
                 DW
                                                       : INTTC4 vector table
```

11.3.9.2 High-Frequency Warm-Up Counter Mode (SLOW1 → SLOW2 → NORMAL2 → NORMAL1)

In this mode, the warm-up period time from a stop of the high-frequency clock fc to the oscillation stability is obtained. Before starting the timer, set SYSCR2<XEN> to 1 to oscillate the high-frequency clock. When a match between the up-counter and the timer register (TTREG4, 3) value is detected after the timer is started by setting TC4CR<TC4S> to 1, the counter is cleared by generating the INTTC4 interrupt request. After stopping the timer in the INTTC4 interrupt service routine, clear SYSCR2<SYSCK> to 0 to switch the system clock from the low-frequency to high-frequency, and then SYSCR2<XTEN> to 0 to stop the low-frequency clock.

Table 11-9 Setting Time in High-Frequency Warm-Up Counter Mode

Minimum time Setting	Maximum time Setting
(TTREG4, 3 = 0100H)	(TTREG4, 3 = FF00H)
16 µs	4.08 ms

Example : After checking high-frequency clock oscillation stability with TC4 and 3, switching to the NORMAL1 mode

SET (SYSCR2).7 ; SYSCR2<XEN> ← 1 LD (TC3CR), 63H ; Sets TFF3=0, source clock fc, and 16-bit mode. LD (TC4CR), 05H ; Sets TFF4=0, and warm-up counter mode. LDW (TTREG3), 0F800H ; Sets the warm-up time. ; (The warm-up time depends on the oscillator characteristic.) DΙ : IMF ← 0 SET (EIRH). 7 ; Enables the INTTC4. ; IMF ← 1 ΕI SET (TC4CR).3 ; Starts the TC4 and 3. PINTTC4: CLR (TC4CR).3 ; Stops the TC4 and 3. CLR (SYSCR2).5 ; SYSCR2<SYSCK> \leftarrow 0 ; (Switches the system clock to the high-frequency clock.) (SYSCR2).6 ; SYSCR2<XTEN> ← 0 CLR ; (Stops the low-frequency clock.) RFTI VINTTC4: DW PINTTC4 ; INTTC4 vector table

TOSHIBA TMP86FH92DMG

12. Asynchronous Serial interface (UART1)

12.1 Configuration




Figure 12-1 UART1 (Asynchronous Serial Interface)

12.2 Control TMP86FH92DMG

12.2 Control

UART1 is controlled by the UART1 Control Registers (UART1CR1, UART1CR2). The operating status can be monitored using the UART status register (UART1SR).

UART1 Control Register1

UART1CR1	7	6	5	4	3	2	1	0	
(0025H)	TXE	RXE	STBT	EVEN	PE		BRG		(Initial value: 0000 0000)

TXE	Transfer operation	0:		
		1:	Enable	
RXE	Receive operation	0:	Disable	
100	Treceive operation	1:	Enable	
STBT	Transmit stop bit length	0:	1 bit]
3161	Transmit stop bit length	1:	2 bits	
EVEN	Even-numbered parity	0:	Odd-numbered parity	
EVEN	Even-numbered parity	1:	Even-numbered parity	
PE	Parity addition	0:	No parity	Write
FL	Fairty addition	1:	Parity	only
		000:	fc/13 [Hz]	
		001:	fc/26	
		010:	fc/52	
BRG	Transmit clock select	011:	fc/104	
BRG	Transmit clock select	100:	fc/208	
		101:	fc/416	
		110:	TC3 (Input INTTC3)	
		111:	fc/96	

Note 1: When operations are disabled by setting TXE and RXE bit to "0", the setting becomes valid when data transmit or receive complete. When the transmit data is stored in the transmit data buffer, the data are not transmitted. Even if data transmit is enabled, until new data are written to the transmit data buffer, the current data are not transmitted.

Note 2: The transmit clock and the parity are common to transmit and receive.

Note 3: UART1CR1<RXE> and UART1CR1<TXE> should be set to "0" before UART1CR1<BRG> is changed.

UART1 Control Register2

UART1CR2	7	6	5	4	3	2	1	0	
(0026H)						RXI	ONC	STOPBR	(Initial value: **** *000)

RXDNC	Selection of RXD input noise rejection time	01: 10:	No noise rejection (Hysteresis input) Rejects pulses shorter than 31/fc [s] as noise Rejects pulses shorter than 63/fc [s] as noise Rejects pulses shorter than 127/fc [s] as noise	Write only
STOPBR	Receive stop bit length		1 bit 2 bits	

Note: Settings of RXDNC are limited depending on the transfer clock specified by BRG. The combination "O" is available but please do not select the combination "-". The transfer clock is calculated by the following equation: Transfer clock [Hz] = Timer/counter source clock [Hz] ÷ TTREG3 set value

		RXDNC setting						
BRG setting	Transfer clock [Hz]	00 (No noise rejection)	01 (Reject pulses shorter than 31/fc[s] as noise)	10 (Reject pulses shorter than 63/fc[s] as noise)	11 (Reject pulses shorter than 127/fc[s] as noise)			
000	fc/13	0	0	0	-			
110	fc/8	0	-	-	-			
(When the transfer clock gen-	fc/16	0	0	-	-			
erated by INTTC3 is the same as the right side column)	fc/32	0	0	0	-			
The setting except the above		0	0	0	0			

UART1 Status Register

UART1SR	7	6	5	4	3	2	1	0	
(0025H)	PERR	FERR	OERR	RBFL	TEND	TBEP			(Initial value: 0000 11**)

PERR	Parity error flag	O: No parity error Parity error	
FERR	Framing error flag	O: No framing error T: Framing error	
OERR	Overrun error flag	O: No overrun error Overrun error	Read
RBFL	Receive data buffer full flag	Receive data buffer empty Receive data buffer full	only
TEND	Transmit end flag	O: On transmitting Transmit end	
TBEP	Transmit data buffer empty flag	Transmit data buffer full (Transmit data writing is finished) Transmit data buffer empty	

Note: When an INTTXD is generated, TBEP flag is set to "1" automatically.

UART1 Receive Data Buffer

RD1BUF	7	6	5	4	3	2	1	0	Read only
(0027H)									(Initial value: 0000 0000)

12. Asynchronous Serial interface (UART1)

12.2 Control TMP86FH92DMG

UART1 Transmit Data Buffer

TD1BUF	7	6	5	4	3	2	1	0	Write only
(0027H)									(Initial value: 0000 0000)

12.3 Transfer Data Format

In UART1, an one-bit start bit (Low level), stop bit (Bit length selectable at high level, by UART1CR1<STBT>), and parity (Select parity in UART1CR1<PE>; even- or odd-numbered parity by UART1CR1<EVEN>) are added to the transfer data. The transfer data formats are shown as follows.




Figure 12-2 Transfer Data Format




Figure 12-3 Caution on Changing Transfer Data Format

Note: In order to switch the transfer data format, perform transmit operations in the above Figure 12-3 sequence except for the initial setting.

2.4 Transfer Rate TMP86FH92DMG

12.4 Transfer Rate

The baud rate of UART1 is set of UART1CR1<BRG>. The example of the baud rate are shown as follows.

Table 12-1 Transfer Rate (Example)

DDC.	Source Clock								
BRG	16 MHz	8 MHz	4 MHz						
000	76800 [baud]	38400 [baud]	19200 [baud]						
001	38400	19200	9600						
010	19200	9600	4800						
011	9600	4800	2400						
100	4800	2400	1200						
101	2400	1200	600						

When TC3 is used as the UART1 transfer rate (when UART1CR1<BRG> = "110"), the transfer clock and transfer rate are determined as follows:

Transfer clock [Hz] = TC3 source clock [Hz] / TTREG3 setting value

Transfer Rate [baud] = Transfer clock [Hz] / 16

12.5 Data Sampling Method

The UART1 receiver keeps sampling input using the clock selected by UART1CR1<BRG> until a start bit is detected in RXD1 pin input. RT clock starts detecting "L" level of the RXD1 pin. Once a start bit is detected, the start bit, data bits, stop bit(s), and parity bit are sampled at three times of RT7, RT8, and RT9 during one receiver clock interval (RT clock). (RT0 is the position where the bit supposedly starts.) Bit is determined according to majority rule (The data are the same twice or more out of three samplings).




Figure 12-4 Data Sampling Method

TMP86FH92DMG

12.6 STOP Bit Length

Select a transmit stop bit length (1 bit or 2 bits) by UART1CR1<STBT>.

12.7 Parity

Set parity / no parity by UART1CR1<PE> and set parity type (Odd- or Even-numbered) by UART1CR1<EVEN>.

12.8 Transmit/Receive Operation

12.8.1 Data Transmit Operation

Set UART1CR1<TXE> to "1". Read UART1SR to check UART1SR<TBEP> = "1", then write data in TD1BUF (Transmit data buffer). Writing data in TD1BUF zero-clears UART1SR<TBEP>, transfers the data to the transmit shift register and the data are sequentially output from the TXD1 pin. The data output include a one-bit start bit, stop bits whose number is specified in UART1CR1<STBT> and a parity bit if parity addition is specified. Select the data transfer baud rate using UART1CR1<BRG>. When data transmit starts, transmit buffer empty flag UART1SR<TBEP> is set to "1" and an INTTXD1 interrupt is generated.

While UART1CR1<TXE> = "0" and from when "1" is written to UART1CR1<TXE> to when send data are written to TD1BUF, the TXD1 pin is fixed at high level. When transmitting data, first read UART1SR, then write data in TD1BUF. Otherwise, UART1SR<TBEP> is not zero-cleared and transmit does not start.

12.8.2 Data Receive Operation

Set UART1CR1<RXE> to "1". When data are received via the RXD1 pin, the receive data are transferred to RD1BUF (Receive data buffer). At this time, the data transmitted includes a start bit and stop bit(s) and a parity bit if parity addition is specified. When stop bit(s) are received, data only are extracted and transferred to RD1BUF (Receive data buffer). Then the receive buffer full flag UART1SR<RBFL> is set and an INTRXD1 interrupt is generated. Select the data transfer baud rate using UART1CR1<BRG>.

If an overrun error (OERR) occurs when data are received, the data are not transferred to RD1BUF (Receive data buffer) but discarded; data in the RD1BUF are not affected.

Note: When a receive operation is disabled by setting UART1CR1<RXE> bit to "0", the setting becomes valid when data receive is completed. However, if a framing error occurs in data receive, the receive-disabling setting may not become valid. If a framing error occurs, be sure to perform a re-receive operation.

12.9 Status Flag TMP86FH92DMG

12.9 Status Flag

12.9.1 Parity Error

When parity determined using the receive data bits differs from the received parity bit, the parity error flag UART1SR<PERR> is set to "1". The UART1SR<PERR> is cleared to "0" when the RD1BUF is read after reading the UART1SR.




Figure 12-5 Generation of Parity Error

12.9.2 Framing Error

When "0" is sampled as the stop bit in the receive data, framing error flag UART1SR<FERR> is set to "1". The UART1SR<FERR> is cleared to "0" when the RD1BUF is read after reading the UART1SR.




Figure 12-6 Generation of Framing Error

12.9.3 Overrun Error

When all bits in the next data are received while unread data are still in RD1BUF, overrun error flag UART1SR<OERR> is set to "1". In this case, the receive data is discarded; data in RD1BUF are not affected. The UART1SR<OERR> is cleared to "0" when the RD1BUF is read after reading the UART1SR.




Figure 12-7 Generation of Overrun Error

Note: Receive operations are disabled until the overrun error flag UART1SR<OERR> is cleared.

12.9.4 Receive Data Buffer Full

Loading the received data in RD1BUF sets receive data buffer full flag UART1SR<RBFL> to "1". The UART1SR<RBFL> is cleared to "0" when the RD1BUF is read after reading the UART1SR.




Figure 12-8 Generation of Receive Data Buffer Full

Note: If the overrun error flag UART1SR<OERR> is set during the period between reading the UART1SR and reading the RD1BUF, it cannot be cleared by only reading the RD1BUF. Therefore, after reading the RD1BUF, read the UART1SR again to check whether or not the overrun error flag which should have been cleared still remains set.

12.9.5 Transmit Data Buffer Empty

When no data is in the transmit buffer TD1BUF, that is, when data in TD1BUF are transferred to the transmit shift register and data transmit starts, transmit data buffer empty flag UART1SR<TBEP> is set to "1". The UART1SR<TBEP> is cleared to "0" when the TD1BUF is written after reading the UART1SR.

12.9 Status Flag TMP86FH92DMG




Figure 12-9 Generation of Transmit Data Buffer Empty

12.9.6 Transmit End Flag

When data are transmitted and no data is in TD1BUF (UART1SR<TBEP> = "1"), transmit end flag UART1SR<TEND> is set to "1". The UART1SR<TEND> is cleared to "0" when the data transmit is started after writing the TD1BUF.




Figure 12-10 Generation of Transmit End Flag and Transmit Data Buffer Empty

TOSHIBA TMP86FH92DMG

13. Asynchronous Serial interface (UART2)

13.1 Configuration




Figure 13-1 UART2 (Asynchronous Serial Interface)

13.2 Control TMP86FH92DMG

13.2 Control

UART2 is controlled by the UART2 Control Registers (UART2CR1, UART2CR2). The operating status can be monitored using the UART status register (UART2SR).

UART2 Control Register1

UART2CR1	7	6	5	4	3	2	1	0	
(0022H)	TXE	RXE	STBT	EVEN	PE		BRG		(Initial value: 0000 0000)

TXE	Transfer operation	0:		
		1:	Enable	
RXE	Receive operation	0:	Disable	
100	Treceive operation	1:	Enable	
STBT	Transmit stop bit length	0:	1 bit	
3161	Transmit stop bit length	1:	2 bits	
EVEN	Even-numbered parity	0:	Odd-numbered parity	
EVEN	Even-numbered parity	1:	Even-numbered parity	
PE	Parity addition	0:	No parity	Write
""	Fairty addition	1:	Parity	only
		000:	fc/13 [Hz]	
		001:	fc/26	
		010:	fc/52	
BRG	Transmit clock select	011:	fc/104	
BRG		100:	fc/208	
		101:	fc/416	
		110:	TC3 (Input INTTC3)	
		111:	fc/96	

Note 1: When operations are disabled by setting TXE and RXE bit to "0", the setting becomes valid when data transmit or receive complete. When the transmit data is stored in the transmit data buffer, the data are not transmitted. Even if data transmit is enabled, until new data are written to the transmit data buffer, the current data are not transmitted.

Note 2: The transmit clock and the parity are common to transmit and receive.

Note 3: UART2CR1<RXE> and UART2CR1<TXE> should be set to "0" before UART2CR1<BRG> is changed.

UART2 Control Register2

UART2CR2	7	6	5	4	3	2	1	0	
(0023H)						RXI	DNC	STOPBR	(Initial value: **** *000)

RXDNC	Selection of RXD input noise rejection time	01: 10:	No noise rejection (Hysteresis input) Rejects pulses shorter than 31/fc [s] as noise Rejects pulses shorter than 63/fc [s] as noise Rejects pulses shorter than 127/fc [s] as noise	Write only
STOPBR	Receive stop bit length	· ·	1 bit 2 bits	

Note: Settings of RXDNC are limited depending on the transfer clock specified by BRG. The combination "O" is available but please do not select the combination "-". The transfer clock is calculated by the following equation: Transfer clock [Hz] = Timer/counter source clock [Hz] ÷ TTREG3 set value

		RXDNC setting							
BRG setting	Transfer clock [Hz]	00 (No noise rejection)	01 (Reject pulses shorter than 31/fc[s] as noise)	10 (Reject pulses shorter than 63/fc[s] as noise)	11 (Reject pulses shorter than 127/fc[s] as noise)				
000	fc/13	0	0	0	-				
110	fc/8	0	-	-	-				
(When the transfer clock gen-	fc/16	0	0	-	-				
erated by INTTC3 is the same as the right side column)	fc/32	0	0	0	-				
The setting except the	above	0	0	0	0				

UART2 Status Register

UART2SR	7	6	5	4	3	2	1	0	
(0022H)	PERR	FERR	OERR	RBFL	TEND	TBEP			(Initial value: 0000 11**)

PERR	Parity error flag	0: No parity error 1: Parity error	
FERR	Framing error flag	O: No framing error T: Framing error	
OERR	Overrun error flag	0: No overrun error 1: Overrun error	Read
RBFL	Receive data buffer full flag	O: Receive data buffer empty 1: Receive data buffer full	only
TEND	Transmit end flag	On transmitting Transmit end	
TBEP	Transmit data buffer empty flag	O: Transmit data buffer full (Transmit data writing is finished) 1: Transmit data buffer empty	

Note: When an INTTXD is generated, TBEP flag is set to "1" automatically.

UART2 Receive Data Buffer

RD2BUF	7	6	5	4	3	2	1	0	Read only
(0024H)									(Initial value: 0000 0000)

13. Asynchronous Serial interface (UART2)

13.2 Control TMP86FH92DMG

UART2 Transmit Data Buffer

TD2BUF	7	6	5	4	3	2	1	0	Write only
(0024H)									(Initial value: 0000 0000)

13.3 Transfer Data Format

In UART2, an one-bit start bit (Low level), stop bit (Bit length selectable at high level, by UART2CR1<STBT>), and parity (Select parity in UART2CR1<PE>; even- or odd-numbered parity by UART2CR1<EVEN>) are added to the transfer data. The transfer data formats are shown as follows.




Figure 13-2 Transfer Data Format




Figure 13-3 Caution on Changing Transfer Data Format

Note: In order to switch the transfer data format, perform transmit operations in the above Figure 13-3 sequence except for the initial setting.

13.4 Transfer Rate TMP86FH92DMG

13.4 Transfer Rate

The baud rate of UART2 is set of UART2CR1<BRG>. The example of the baud rate are shown as follows.

Table 13-1 Transfer Rate (Example)

DDC	Source Clock							
BRG	16 MHz	8 MHz	4 MHz					
000	76800 [baud]	38400 [baud]	19200 [baud]					
001	38400	19200	9600					
010	19200	9600	4800					
011	9600	4800	2400					
100	4800	2400	1200					
101	2400	1200	600					

When TC3 is used as the UART2 transfer rate (when UART2CR1<BRG> = "110"), the transfer clock and transfer rate are determined as follows:

Transfer clock [Hz] = TC3 source clock [Hz] / TTREG3 setting value

Transfer Rate [baud] = Transfer clock [Hz] / 16

13.5 Data Sampling Method

The UART2 receiver keeps sampling input using the clock selected by UART2CR1<BRG> until a start bit is detected in RXD2 pin input. RT clock starts detecting "L" level of the RXD2 pin. Once a start bit is detected, the start bit, data bits, stop bit(s), and parity bit are sampled at three times of RT7, RT8, and RT9 during one receiver clock interval (RT clock). (RT0 is the position where the bit supposedly starts.) Bit is determined according to majority rule (The data are the same twice or more out of three samplings).




Figure 13-4 Data Sampling Method

TMP86FH92DMG

13.6 STOP Bit Length

Select a transmit stop bit length (1 bit or 2 bits) by UART2CR1<STBT>.

13.7 Parity

Set parity / no parity by UART2CR1<PE> and set parity type (Odd- or Even-numbered) by UART2CR1<EVEN>.

13.8 Transmit/Receive Operation

13.8.1 Data Transmit Operation

Set UART2CR1<TXE> to "1". Read UART2SR to check UART2SR<TBEP> = "1", then write data in TD2BUF (Transmit data buffer). Writing data in TD2BUF zero-clears UART2SR<TBEP>, transfers the data to the transmit shift register and the data are sequentially output from the TXD2 pin. The data output include a one-bit start bit, stop bits whose number is specified in UART2CR1<STBT> and a parity bit if parity addition is specified. Select the data transfer baud rate using UART2CR1<BRG>. When data transmit starts, transmit buffer empty flag UART2SR<TBEP> is set to "1" and an INTTXD2 interrupt is generated.

While UART2CR1<TXE> = "0" and from when "1" is written to UART2CR1<TXE> to when send data are written to TD2BUF, the TXD2 pin is fixed at high level. When transmitting data, first read UART2SR, then write data in TD2BUF. Otherwise, UART2SR<TBEP> is not zero-cleared and transmit does not start.

13.8.2 Data Receive Operation

Set UART2CR1<RXE> to "1". When data are received via the RXD2 pin, the receive data are transferred to RD2BUF (Receive data buffer). At this time, the data transmitted includes a start bit and stop bit(s) and a parity bit if parity addition is specified. When stop bit(s) are received, data only are extracted and transferred to RD2BUF (Receive data buffer). Then the receive buffer full flag UART2SR<RBFL> is set and an INTRXD2 interrupt is generated. Select the data transfer baud rate using UART2CR1<BRG>.

If an overrun error (OERR) occurs when data are received, the data are not transferred to RD2BUF (Receive data buffer) but discarded; data in the RD2BUF are not affected.

Note: When a receive operation is disabled by setting UART2CR1<RXE> bit to "0", the setting becomes valid when data receive is completed. However, if a framing error occurs in data receive, the receive-disabling setting may not become valid. If a framing error occurs, be sure to perform a re-receive operation.

13.9 Status Flag TMP86FH92DMG

13.9 Status Flag

13.9.1 Parity Error

When parity determined using the receive data bits differs from the received parity bit, the parity error flag UART2SR<PERR> is set to "1". The UART2SR<PERR> is cleared to "0" when the RD2BUF is read after reading the UART2SR.




Figure 13-5 Generation of Parity Error

13.9.2 Framing Error

When "0" is sampled as the stop bit in the receive data, framing error flag UART2SR<FERR> is set to "1". The UART2SR<FERR> is cleared to "0" when the RD2BUF is read after reading the UART2SR.




Figure 13-6 Generation of Framing Error

13.9.3 Overrun Error

When all bits in the next data are received while unread data are still in RD2BUF, overrun error flag UART2SR<OERR> is set to "1". In this case, the receive data is discarded; data in RD2BUF are not affected. The UART2SR<OERR> is cleared to "0" when the RD2BUF is read after reading the UART2SR.




Figure 13-7 Generation of Overrun Error

Note: Receive operations are disabled until the overrun error flag UART2SR<OERR> is cleared.

13.9.4 Receive Data Buffer Full

Loading the received data in RD2BUF sets receive data buffer full flag UART2SR<RBFL> to "1". The UART2SR<RBFL> is cleared to "0" when the RD2BUF is read after reading the UART2SR.




Figure 13-8 Generation of Receive Data Buffer Full

Note: If the overrun error flag UART2SR<OERR> is set during the period between reading the UART2SR and reading the RD2BUF, it cannot be cleared by only reading the RD2BUF. Therefore, after reading the RD2BUF, read the UART2SR again to check whether or not the overrun error flag which should have been cleared still remains set.

13.9.5 Transmit Data Buffer Empty

When no data is in the transmit buffer TD2BUF, that is, when data in TD2BUF are transferred to the transmit shift register and data transmit starts, transmit data buffer empty flag UART2SR<TBEP> is set to "1". The UART2SR<TBEP> is cleared to "0" when the TD2BUF is written after reading the UART2SR.

13.9 Status Flag TMP86FH92DMG




Figure 13-9 Generation of Transmit Data Buffer Empty

13.9.6 Transmit End Flag

When data are transmitted and no data is in TD2BUF (UART2SR<TBEP> = "1"), transmit end flag UART2SR<TEND> is set to "1". The UART2SR<TEND> is cleared to "0" when the data transmit is started after writing the TD2BUF.




Figure 13-10 Generation of Transmit End Flag and Transmit Data Buffer Empty

TOSHIBA TMP86FH92DMG

14. Serial Expansion Interface (SEI)

SEI is one of the serial interfaces incorporated in the TMP86FH92DMG. It allows connection to peripheral devices via full-duplex synchronous communication protocols. The TMP86FH92DMG contain one channel of SEI.

SEI is connected with an external device through SCLK, MOSI, MISO and the terminal \overline{SS} . SCLK, MOSI, MISO, and \overline{SS} pins respectively are shared with P02, P03, P04 and P05. When using these ports as SCLK, MOSI, MISO, or \overline{SS} pins, set the each Port Output Latch to "1".

14.1 Features

- The master outputs the shift clock for only a data transfer period.
- · The clock polarity and phase are programmable.
- The data is 8 bits long.
- · MSB or LSB-first can be selected.
- The programmable data and clock timing of SEI can be connected to almost all synchronous serial peripheral devices. Refer to ""14.5 SEI Transfer Formats".
- The transfer rate can be selected from the following four (master only):
 - 4 Mbps, 2 Mbps, 1 Mbps, or 250 kbps (when operating at 16 MHz)
- The error detection circuit supports the following functions:
 - 1. Write collision detection: When the shift register is accessed for write during transfer
 - 2. Overflow detection: When new data is received while the transfer-finished flag is set (slave only)
 - 3. Mode fault error input: When the <u>SEI</u> device is set as the master, driver output is disabled immediately upon input of a low level on the \overline{SS} pin (in open-drain output mode only). Overflow detection: When new data is received while the transfer-finished flag is set (slave only)




Figure 14-1 SEI (Serial Extended Interface)

14.2 SEI Registers TMP86FH92DMG

14.2 SEI Registers

The SEI interface has the SEI Control Register (SECR), SEI Status Register (SESR), and SEI Data Register (SEDR) which are used to set up the SEI system and enable/disable SEI operation.

14.2.1 SEI Control Register (SECR)

	7	6	5	4	3	2	1	0	
SECR	MODE	SEE	BOS	MSTR	CPOL	СРНА	SE	R	(Initial value: 0000 0100)
(002AH)									_

Read-modify-write instruction are prohibited.

		Enables mode fault detection Disables mode fault detection					
MODE	Mode fault detection (Note1)	It is available in Master mode only.					
		· · · · · · · · · · · · · · · · · · ·					
		(Note: Make sure to set <mode> bit to "1" for disabling Mode fault detection</mode>					
055	OFI an aretical (Nata 2)	0: Disables SEI operation					
SEE	SEI operation (Note2)	1: Enables SEI operation					
DOG	Dit and a calcution	0: Transmitted beginning with the MSB (bit 7) of SEDR register					
BOS	Bit order selection	1: Transmitted beginning with the LSB (bit 0) of SEDR register					
MSTR	Made coloction (Note2)	0: Sets SEI for slave					
MSTR	Mode selection (Note3)	1: Sets SEI for master					
CPOL	Clock polarity	0: Selects active-"H" clock. SCLK remains "L" when IDLE.					
CFOL	Clock polarity	1: Selects active-"L" clock. SCLK remains "H" when IDLE.					
CPHA	Clock phase	Selects clock phase. For details, refer to Section "SEI Transfer Formats".					
		00: Divide-by-4					
SER	Selects SEI transfer rate	01: Divide-by-8					
JER	Sciects SLI transfer fate	10: Divide-by-16					
		11: Divide-by-64					

Note 1: If mode fault detection is enabled, an interrupt is generated when the MODF flag (SESR<MODF>) is set.

Note 2: SEI operation can only be disabled after transfer is completed. Before the SEI can be used, the each Port Control Register and Output Latch Control must be set for the SEI function (In case P0 port, P0OUTCR and P0DR).

When using the SEI as the master, set the SECR<SEE> bit to "1" (to enable SEI operation) and then place transmit data in the SEDR register. This initiates transmission/reception.

Note 3: Master/slave settings must be made before enabling SEI operation (This means that the SECR<MSTR> bit must first be set before setting the SECR<SEE> bit to "1").

14.2.1.1 Transfer rate

(1) Master mode (Transfer rate = fc/Internal clock divide ratio (unit: bps))

The table below shows the relationship between settings of the SER bit and transfer bit rates when the SEI is operating as the master.

Table 14-1 SEI Transfer Rate

SER	Internal Clock Divide Ratio of SEI	Transfer Rate when fc = 16 MHz
00	4	4 Mbps
01	8	2 Mbps
10	16	1 Mbps
11	64	250 kbps

TMP86FH92DMG

(2) Slave mode

When the SEI is operating as a slave, the serial clock is input from the master and the setting of the SER bit has no effect. The maximum transfer rate is fc/4.

Note: Take note of the following relationship between the serial clock speed and fc on the master side:

15.625 kbps < Transfer rate < fc/4 bps

Example) 15.625 kbps < Transfer rate < 4 Mbps (fc = 16 MHz at V_{DD} = 4.5 to 5.5 V)

15.625 kbps < Transfer rate < 2 Mbps (fc = 8 MHz at V_{DD} = 2.7 to 5.5 V)

14.2.2 SEI Status Register (SESR)

	7	6	5	4	3	2	1	0	
SESR	SEF	WCOL	SOVF	MODF					(Initial value: 0000 ****)
(0028H)									

SEF	Transfer-finished flag (Note1)	0: Transfer in progress 1: Transfer completed	
WCOL	Write collision error flag (Note2)	O: No write collision error occurred 1: Write collision error occurred	Budge
SOVF	Overflow error flag (slave) (Note3)	0: No overflow occurred 1: Overflow occurred	Read only
MODF	Mode fault flow error flag (master) (Note4)	0: No mode fault occurred 1: Mode fault occurred	

- Note 1: The SEF flag is automatically set at completion of transfer. The SEF flag thus set is automatically cleared by reading the SESR register and accessing the SEDR register.
- Note 2: The WCOL flag is automatically set by a write to the SEDR register while transfer is in progress. Writing to the SEDR register during transfer has no effect. The WCOL flag thus set is automatically cleared by reading the SESR register and accessing the SEDR register. No interrupts are generated for reasons that the WCOL flag is set.
- Note 3: During master mode:

This bit does not function; its data when read is "0".

During slave mode:

The SOVF flag is automatically set when the device finishes reading the next data while the SEF flag is set. The SOVF flag thus set is automatically cleared by reading the SESR register and accessing the SEDR register. The SOVF flag also is cleared by a switchover to master mode. No interrupts are generated for reasons that the SOVF flag is set.

Note 4: Master mode:

The MODF flag is set when the SS pin is driven low. At this time, the SEI performs the following operations:

- 1. Disables the SEI pin driver and sets the SCLK and MOSI pins as inputs in the high-impedance state.
- 2. Clears the SECR<MSTR> bit.
- 3. Forcefully clears the SECR<SEE> bit to disable the SEI system.
- 4. The MODF flag thus set is automatically cleared by a read of the SESR register and a write to the SECR register. Slave mode:

This bit does not function; its data when read is 0.

14.2.3 SEI Data Register (SEDR)

The SEI Data Register (SEDR) is used to send and receive data. When the SEI is set for master, data transfer is initiated by writing to this SEDR register. If the master device needs to write to the SEDR register after transfer began, always check to see by means of an interrupt or by polling that the SEF flag (SESR<SEF>) is set, before writing to the SEDR register.

	7	6	5	4	3	2	1	0	_
SEDR	SED7	SED6	SED5	SED4	SED3	SED2	SED1	SED0	R/W (Initial value: 0000 0000)

(0029H)

4.3 SEI Operation TMP86FH92DMG

14.3 SEI Operation

During a SEI transfer, data transmission (serial shift-out) and reception (serial shift-in) are performed simultaneously. The serial clock synchronizes the timing at which information on the two serial data lines are shifted or sampled. Slave device can be selected individually using the slave select pin (\overline{SS}) pin). For unselected slave devices, data on the SEI bus cannot be taken in.

When operating as the master devices, the \overline{SS} pin can be used to indicate multiple-master bus connection.

14.3.1 Controlling SEI clock polarity and phase

The SEI clock allows its phase and polarity to be selected in software from four combinations available by using two bits, CPHA and CPOL (SECR<CPHL,CPOL>).

The clock polarity is set by CPOL to select between active-high or active-low (The transfer format is unaffected).

The clock phase is set by CPHA. The master device and the slave devices to communicate with must have the same clock phase and polarity.

If multiple slave devices with different transfer formats exist on the same bus, the format can be changed to that of the slave device to which to transfer.

Table 14-2 Clock Phase and Polarity

СРНА	SEI control register (SECR 002AH) bit 2
CPOL	SEI control register (SECR 002AH) bit 3

14.3.2 SEI data and clock timing

The programmable data and clock timing of SEI allows connection to almost all synchronous serial peripheral devices. Refer to Section ""14.5 SEI Transfer Formats "".

14.4 SEI Pin Functions

The TMP86FH92DMG have four input/output pins associated with SEI transfer. The functionality of each pin depends on the SEI device's mode (master or slave). The SCLK pin, MOSI pin and MISO pin of all SEI devices are connected with the same name pin to each other.

14.4.1 SCLK pin

The SCLK pin functions as an output pin when SEI is set for master, or as an input pin when SEI is set for slave

When SEI is set for master, serial clock is output from the SCLK pin to external devices. After the master starts transfer, eight serial clock pulses are output from the SCLK pin only during transfer.

When SEI is set for slave, the SCLK pin functions as an input pin.

During data transfer between master and slave, device operation is synchronized by the serial clock output from the master.

When the \overline{SS} pin of the slave device is "H", data is not taken in regardless of whether the serial clock is available.

For both master and slave devices, data is shifted in and out at a rising or falling edge of the serial clock, and is sampled at the opposite edge where the data is stable. The active edge is determined by SEI transfer protocols.

Note: Noise in a slave device's SCLK input may cause the device to operate erratically.

14.4.2 MISO/MOSI pins

The MISO and MOSI pins are used for serial data transmission/reception. The status of each pin during master and slave are shown in the table below.

Table 14-3 MISO/MOSI Pin Status

	MISO	MOSI
Master	Input	Output
Slave	Output	Input

Also, the SCLK, MOSI, and MISO pins can be set for open-drain by the each pin's input/output control register (In case P0 Port, Input/output Control Register is P0OUTCR).

The MISO pin of a slave device becomes an output when the SECR<SEE> bit is set to 1 (SEI operation enabled). To set the MISO pin of an inactive slave device to a high-impedance state, clear the SECR<SEE> bit to 0.

14.4.3 SS pin

The \overline{SS} pin function differently when the SEI is the master and when it is a slave.

- When the SEI is a slave, this pin is used to enable the SEI transmission/reception. When the slave's \overline{SS} pin is high, the slave device ignores the serial clock from the master. Nor does it receive data from the MISO pin. When the slave's \overline{SS} pin is L, the SEI operates as slave.
- When the SEI is the master, the \overline{SS} pin is used for SEI error input. When the \overline{SS} pin of the master device goes low, output is immediately disabled on the SCLK and MOSI pins if these pins are configured as open-drain outputs. This causes the SESR<MODF> flag of the master device to be set. This state is called a mode fault. The mode fault function is provided to prevent damage caused by a collision between drivers that may occur, for example, when another device on the same bus becomes the master.

14.5 SEI Transfer Formats TMP86FH92DMG

14.5 SEI Transfer Formats

The transfer formats are set using CPHA and CPOL (SECR<CPHA,CPOL>). CPHA allows transfer protocols to be selected between two.

14.5.1 CPHA (SECR register bit 2) = 0 format

Figure 14-2 shows a transfer format when CPHA = 0.




Figure 14-2 Transfer Format When CPHA = 0

Table 14-4 Transfer Format Details when CPHA = 0

	SCLK Level when not Communicating (IDLE)	Data Shift	Data Sampling
CPOL = 0	"L" level	Falling edge of transfer clock	Rising edge of transfer clock
CPOL = 1	"H" level	Rising edge of transfer clock	Falling edge of transfer clock

- In master mode, transfer is initiated by writing new data to the SEDR register. At this time, the new data changes state on the MOSI pin a half clock period before the shift clock starts pulsing. Use BOS (SECR<BOS>) to select whether the data should be shifted out beginning with the MSB or LSB. The SEF flag (SESR<SEF>) is set after the last shift cycle.
- In slave mode, writing data to the SEDR register is inhibited when the \overline{SS} pin is "L". A write during this period causes collision of writes, so that the WCOL flag (SESR<WCOL>) is set. Therefore, when writing data to the SEDR (SEI Data Register) after the SEF flag is set upon completion of transfer, make sure the \overline{SS} pin goes "H" again before writing the next data to the SEDR register.

Note: In slave mode, be careful not to write data while the SEF flag is set and the $\overline{\text{SS}}$ pin remains "L".

14.5.2 CPHA = 1 format

Figure 14-3 shows a transfer format when CPHA = 1.




Figure 14-3 Transfer Format When CPHA = 1

Table 14-5 Transfer Format Details when CPHA = 1

	SCLK Level when Not Communicating (IDLE)	Data Shift	Data Sampling
CPOL=0	"L" level	Rising edge of transfer clock	Falling edge of transfer clock
CPOL=1	"H" level	Falling edge of transfer clock	Rising edge of transfer clock

- In master mode, transfer is initiated by writing new data to the SEDR register. The new data changes state on the MOSI pin at the first edge of the shift clock. Use BOS (SECR<BOS>) to select whether the data should be shifted out beginning with the MSB or LSB.
- In slave mode, unlike in the case of CPHA = 0 format, data can be written to the SEDR (SEI Data Register) regardless of whether the \overline{SS} pin is "L" or "H". In both master and slave modes, the SEF flag (SESR<SEF>) is set after the last shift cycle. Writing data to the SEDR register while data transfer is in progress causes collision of writes. Therefore, wait until the SEF flag is set before writing new data to the SEDR register.

4.6 Functional Description TMP86FH92DMG

14.6 Functional Description

Figure 14-4 shows how the SEI master and slave are connected.

When the master device sends data from its MOSI pin to a slave device's MOSI pin, the slave device returns data from its MISO pin to the master device's MISO pin. This means that data are exchanged between master and slave via full-duplex communication, with data output and input operations synchronized by the same clock signal. After end of transfer, the transmit byte in 8 bit shift register is replaced with the receive byte.




Figure 14-4 Master and Slave Connection in SEI

Figure 14-5 shows an example of how an SEI system can be configured. The general-purpose pins used for SEI transfer can be programmed to be open-drain outputs. This feature enables these pins to be connected with multiple devices. (We recommend using these pins in open-drain output mode.)




Figure 14-5 Example of SEI System Configuration (1 Master, 2 Slaves)

In this example, all the SCLK pins are interconnected, and all the MOSI and MISO pins are interconnected. One SEI device is set as the master and all the other SEI devices on the SEI bus are set as slaves. The master device sends data from its SCLK and MOSI pins to the SCLK and MOSI pins of a slave device.

The slave device selected by the master sends data from its MISO pin to the MISO pin of the master device.

14.7 Interrupt Generation

The TMP86FH92DMG is provided with the SEI interrupt channels 0 and 1 (INTSEI0 and INTSEI1) for processing SEI interrupts.

INTSEI0 generates an interrupt pulse when the SESR<MODF> flag is set. INTSEI1 generates an interrupt pulse when the SESR<SEF> flag is set.

Table 14-6 SEI Interrupt

SEI interrupt channe0 (INTSEI0)	Generates an interrupt pulse when the MODF flag is setl
SEI interrupt channel 1 (INTSEI1)	Generates an interrupt pulse when the SEF flag is setl

14.8 SEI System Errors

The SEI can detect the following three types of system errors:

- Mode fault error: A mode fault error occurs if the SS pin of the master device is driven low.
- Write collision error: A write collision error occurs if data is written to the SEDR register while a transfer is in progress.
- Overflow error: An overflow error occurs if new data is received in a slave device before the previous data is read."

14.8.1 Write collision error

A write collision error occurs if an attempt is made to write to the SEDR register while data is being transferred. Because the SEDR register is not configured as dual-buffers for sending data, a write to the SEDR register directly results in writing to the SEI shift register. Therefore, writing to the SEDR register while a transfer is in progress causes a write collision error.

In no case is data transfer stopped in the middle, so that the write data which caused a write collision error will not be written to the shift register. Because slaves cannot control the timing at which the master starts a transfer, write collision errors normally occur on slave devices. The master has the right to perform a transfer at any time, and thus write collision errors do not normally occur on the master side. However, both master and slave SEI devices are capable of detecting write collision errors.

A write collision error tends to occur on a slave device when the master shifts out data at a speed faster than that at which the slave processes the transferred data. More specifically, a write collision error occurs if the slave transfers a new value to the SEDR register when the master has already started a shift cycle for the next byte.

14.8.2 Overflow error

The transfer bit rate on the SEI bus is determined by the master. At higher bit rates, a slave device may not be able to keep up with transfer from the master. This occurs when the master shifts out data faster than can be processed by the slave. The SEI module uses the SESR<SOVF> flag to detect an overflow error.

The SOVF flag is set if the following conditions are both met:

- · When the SEI module is set as a slave
- · When the previous data byte remains to be read after a new data byte has been received

When the SOVF flag is set, the SEDR register is overwritten with a new data byte.

Note: Please carefully examine the communication processing routine and communication rate when designing your application system.

4.9 Bus Driver Protection TMP86FH92DMG

14.8.3 Mode fault error

When the SEI device is set as the master, a mode fault error occurs if the \overline{SS} pin is driven low. When a mode fault error occurs, the SEI immediately performs the following operations: The SOVF flag is set if the following conditions are both met:

- Clears the SECR<MSTR> bit to 0 to set the SEI device as a slave.
- Clears the SECR<SEE> bit to 0 to disable SEI operation.
- Sets the SESR<MODF> flag to 1 to generate an INTSEI0 interrupt pulse.
- Sets the SCLK and MOSI pins to output 1. (These pins become high-impedance in open-drain output mode, or high level in CMOS output mode.)

The SESR<MODF> flag thus set is automatically cleared by a read of the SESR register and a write to the SECR register. Once the SESR<MODF> flag is cleared, the mode setting can be made again.

When open-drain output mode is selected, this mode fault error function can be used to prevent the collision between the SCLK pin and MOSI pin drivers if two or more devices on the same bus are set as the master at the same time. (It is not possible to prevent the collision of the MISO pins if the SS pins of two or more slave devices on the same bus are simultaneously driven low.)

14.9 Bus Driver Protection

- One method to protect the device against latch-up due to collision of the bus drivers is the use of an open-drain option. This means changing the SEI pins' CMOS outputs to the open-drain type, which is accomplished by setting the SCLK, MOSI, and MISO pins for open-drain individually by using the each Port Input/output Control Register. In this case, these pins must be provided with pull-up resistors external to the chip.
- When using the SEI pins as CMOS outputs, we recommend connecting them to the bus via resistors in order to protect the device against collision of drivers. However, be sure to select the appropriate resistance value which will not affect actual device operation (Example: 1Ω to several $k\Omega$).

15. Serial Bus Interface(I²C Bus) Ver.-D (SBI)

The TMP86FH92DMG has a serial bus interface which employs an I²C bus.

The serial interface is connected to an external devices through SDA and SCL.

The serial bus interface pins are also used as the port. When used as serial bus interface pins, set the output latches of these pins to "1". When not used as serial bus interface pins, the port is used as a normal I/O port.

- Note 1: The serial bus interface can be used only in NORMAL1/2 and IDLE1/2 mode. It can not be used in IDLE0, SLOW1/2 and SLEEP0/1/2 mode.
- Note 2: The serial bus interface can be used only in the Standard mode of I²C. The fast mode and the high-speed mode can not be used.
- Note 3: Please refer to the I/O port section about the detail of setting port.

15.1 Configuration




Figure 15-1 Serial Bus Interface (SBI)

15.2 Control

The following registers are used for control the serial bus interface and monitor the operation status.

- · Serial bus interface control register A (SBICRA)
- · Serial bus interface control register B (SBICRB)
- Serial bus interface data buffer register (SBIDBR)
- I²C bus address register (I2CAR)
- Serial bus interface status register A (SBISRA)
- · Serial bus interface status register B (SBISRB)

15.3 Software Reset

A serial bus interface circuit has a software reset function, when a serial bus interface circuit is locked by an external noise, etc.

To reset the serial bus interface circuit, write "10", "01" into the SWRST (Bit1, 0 in SBICRB).

And a status of software reset can be read from SWRMON (Bit0 in SBISRA).

15.4 The Data Format in the I²C Bus Mode

The data format of the I²C bus is shown below.




Figure 15-2 Data Format in of I²C Bus

TMP86FH92DMG

15.5 I2C Bus Control

The following registers are used to control the serial bus interface and monitor the operation status of the I²C bus.

Serial Bus Interface Control Register A

SBICRA	7	6	5	4	3	2	1	0	_
(0015H)		ВС		ACK			SCK		(Initial value: 0000 *000)

			ACŁ	<=0	ACI	< = 1	
		ВС	Number of Clock	Bits	Number of Clock	Bits	
		000:	8	8	9	8	
		001:	1	1	2	1	
ВС	Number of transferred bits	010:	2	2	3	2	Write only
		011:	3	3	4	3	Offig
		100:	4	4	5	4	
		101:	5	5	6	5	
		110:	6	6	7	6	
		111:	7	7	8	7	
	Acknowledgement mode	ACK	Master mode		Slave		
ACK		0:	Not generate a clock pulse for an acknowledgement.		Not count a cloc	R/W	
	specification	1:	Generate a clock pulse for an acknowledgement.		Count a clock po		
		SCK	n	At fc = 16 MHz	At fc = 8 MHz	At fc = 4 MHz	
		000:	4	Reserved	Reserved	100.0 kHz	
		001:	5	Reserved	Reserved	55.6 kHz	
	Serial clock (fscl) selection	010:	6	Reserved	58.8 kHz	29.4 kHz	
SCK	(Output on SCL pin)	011:	7	60.6 kHz	30.3 kHz	15.2 kHz	Write only
	[fscl = $1/(2^{n+1}/fc + 8/fc)$]	100:	8	30.8 kHz	15.4 kHz	7.7 kHz	Offig
		101:	9	15.5 kHz	7.8 kHz	3.9 kHz	
		110:	10	7.8 kHz	3.9 kHz	1.9 kHz	
		111:		Rese	erved		

Note 1: fc: High-frequency clock [Hz], *: Don't care

Note 2: SBICRA cannot be used with any of read-modify-write instructions such as bit manipulation, etc.

Note 3: Do not set SCK as the frequency that is over 100 kHz.

Serial Bus Interface Data Buffer Register

SBIDBR	7	6	5	4 3	2	1	0	
(0016H)								(Initial value: **** ****) R/W

Note 1: For writing transmitted data, start from the MSB (Bit7).

Note 2: The data which was written into SBIDBR can not be read, since a write data buffer and a read buffer are independent in SBIDBR. Therefore, SBIDBR cannot be used with any of read-modify-write instructions such as bit manipulation, etc.

Note 3: *: Don't care

15. Serial Bus Interface(I

15.5 I²C Bus Control TMP86FH92DMG

I²C bus Address Register

I2CAR	7	6	5	4	3	2	1	0	_
(0017H)					(Initial value: 0000 0000)				
	SA6	SA5	SA4	SA3	SA2	SA1	SA0	ALS	

SA	Slave address selection		
41.0	Address recognition mode spec-	0: Slave address recognition	Write only
ALS	ification	1: Non slave address recognition	

Note 1: I2CAR is write-only register, which cannot be used with any of read-modify-write instruction such as bit manipulation, etc.

Note 2: Do not set I2CAR to "00H" to avoid the incorrect response of acknowledgment in slave mode. (If "00H" is set to I2CAR as the Slave Address and a START Byte "01H" in I2C bus standard is received, the device detects slave address match.)

Serial Bus Interface Control Register B

SBICRB	7	6	5	4	3	2	1	0	
(0018H)	MST	TRX	BB	PIN	SB	BIM	SWRST1	SWRST0	(Initial value: 0001 0000)

			1
MST	Master/slave selection	0: Slave	
IVIST	iviaster/slave selection	1: Master	
TRX	Transmitter/reasiver extention	0: Receiver	
IRX	Transmitter/receiver selection	1: Transmitter	
BB	Start/stan generation	0: Generate a stop condition when MST, TRX and PIN are "1"	
ВВ	Start/stop generation	1: Generate a start condition when MST, TRX and PIN are "1"	
PIN	Canaal interment agreeing request	0: - (Can not clear this bit by a software)	Write
PIN	Cancel interrupt service request	Cancel interrupt service request	only
		00: Port mode (Serial bus interface output disable)	
SBIM	Serial bus interface operating	01: Reserved	
SBIIVI	mode selection	10: I ² C bus mode	
		11: Reserved	
SWRST1	Software reset start bit	Software reset starts by first writing "10" and next writing "01"	
SWRST0	Sultware reset start bit	Software reset starts by first writing TO and next writing OT	

Note 1: Switch a mode to port after confirming that the bus is free.

Note 2: Switch a mode to I²C bus mode after confining that the port is high level.

Note 3: SBICRB has write-only register and must not be used with any of read-modify-write instructions such as bit manipulation, etc.

Note 4: When the SWRST (Bit1, 0 in SBICRB) is written to "10", "01" in I²C bus mode, software reset is occurred. In this case, the SBICRA, I2CAR, SBISRA and SBISRB registers are initialized and the bits of SBICRB except the SBIM (Bit3, 2 in SBICRB) are also initialized.

Serial Bus Interface Status Register A

SBISRA	7	6	5	4	3 2	1	0	
(0015H)							SWRMON	(Initial value: **** ***1)

SWRMON	SWRMON Software reset monitor	0: During software reset	Read
SWRIVION	Software reset monitor	1: - (Initial value)	only

Serial Bus Interface Status Register B

SBISRB	7	6	5	4	3	2	1	0	_
(0018H)	MST	TRX	BB	PIN	AL	AAS	AD0	LRB	(Initial value: 0001 0000)

			_
MST	Master/slave selection status	0: Slave	
IVIST	monitor	1: Master	
TRX	Transmitter/receiver selection	0: Receiver	
IRA	status monitor	1: Transmitter	
BB	Bus status monitor	0: Bus free	
ВВ	Bus status monitor	1: Bus busy	
DIN	Interrupt service requests status	0: Requesting interrupt service	
PIN	monitor	1: Releasing interrupt service request	Read
AL	Arbitration lost detection monitor	0: -	only
AL	Arbitration lost detection monitor	1: Arbitration lost detected	
440	Slave address match detection	0: -	
AAS	monitor	1: Detect slave address match or "GENERAL CALL"	
400	"GENERAL CALL" detection	0: -	
AD0	monitor	1: Detect "GENERAL CALL"	
LDD		0: Last receive bit is "0"	
LRB	Last received bit monitor	1: Last receive bit is "1"	

15.5.1 Acknowledgement mode specification

15.5.1.1 Acknowledgment mode (ACK = "1")

To set the device as an acknowledgment mode, the ACK (Bit4 in SBICRA) should be set to "1". When a serial bus interface circuit is a master mode, an additional clock pulse is generated for an acknowledge signal. In a slave mode, a clock is counted for the acknowledge signal.

In the master transmitter mode, the SDA pin is released in order to receive an acknowledge signal from the receiver during additional clock pulse cycle. In the master receiver mode, the SDA pin is set to low level generation an acknowledge signal during additional clock pulse cycle.

In a slave mode, when a received slave address matches to a slave address which is set to the I2CAR or when a "GENERAL CALL" is received, the SDA pin is set to low level generating an acknowledge signal. After the matching of slave address or the detection of "GENERAL CALL", in the transmitter, the SDA pin is released in order to receive an acknowledge signal from the receiver during additional clock pulse cycle. In a receiver, the SDA pin is set to low level generation an acknowledge signal during additional clock pulse cycle after the matching of slave address or the detection of "GENERAL CALL"

The Table 15-1 shows the SCL and SDA pins status in acknowledgment mode.

Table 15-1 SCL and SDA Pins Status in Acknowledgement Mode

Mode	Pin Transmitter			Receiver		
		SCL	An additional clock pulse is generated.			
Master	SDA		SDA Released in order to receive an acknowledge signal. Set to low level generation acknowledge signal.			Set to low level generating an acknowledge signal
	SCL		A clock is counted for the acknowledge signal.			
Slave	004	When slave address matches or a general call is detected	-	Set to low level generating an acknowledge signal.		
	SDA	After matching of slave address or general call	Released in order to receive an acknowledge signal.	Set to low level generating an acknowledge signal.		

15. Serial Bus Interface(I

15.5 I²C Bus Control TMP86FH92DMG

15.5.1.2 Non-acknowledgment mode (ACK = "0")

To set the device as a non-acknowledgement mode, the ACK (Bit4 in SBICRA) should be cleared to "0".

In the master mode, a clock pulse for an acknowledge signal is not generated.

In the slave mode, a clock for a acknowledge signal is not counted.

15.5.2 Number of transfer bits

The BC (Bits7 to 5 in SBICRA) is used to select a number of bits for next transmitting and receiving data.

Since the BC is cleared to "000" by a start condition, a slave address and direction bit transmissions are always executed in 8 bits. Other than these, the BC retains a specified value.


15.5.3 Serial clock


15.5.3.1 Clock source

The SCK (Bits2 to 0 in SBICRA) is used to select a maximum transfer frequency output from the SCL pin in the master mode.

Four or more machine cycles are required for both high and low levels of pulse width in the external clock which is input from SCL pin.

Note: Since the serial bus interface can not be used as the fast mode and the high-speed mode, do not set SCK as the frequency that is over 100 kHz.





tSCKL, tSCKH > 4 tcyc

Note 1: fc = High-frequency clock

Note 2: tcyc = 4/fc (in NORMAL mode, IDLE mode)

Figure 15-3 Clock Source

15.5.3.2 Clock synchronization

In the I²C bus, in order to drive a bus with a wired AND, a master device which pulls down a clock pulse to low will, in the first place, invalidate a clock pulse of another master device which generates a high-level clock pulse.

The serial bus interface circuit has a clock synchronization function. This function ensures normal transfer even if there are two or more masters on the same bus.

The example explains clock synchronization procedures when two masters simultaneously exist on a bus.




Figure 15-4 Clock Synchronization

As Master 1 pulls down the SCL pin to the low level at point "a", the SCL line of the bus becomes the low level. After detecting this situation, Master 2 resets counting a clock pulse in the high level and sets the SCL pin to the low level.

Master 1 finishes counting a clock pulse in the low level at point "b" and sets the SCL pin to the high level. Since Master 2 holds the SCL line of the bus at the low level, Master 1 waits for counting a clock pulse in the high level. After Master 2 sets a clock pulse to the high level at point "c" and detects the SCL line of the bus at the high level, Master 1 starts counting a clock pulse in the high level. Then, the master, which has finished the counting a clock pulse in the high level, pulls down the SCL pin to the low level.

The clock pulse on the bus is determined by the master device with the shortest high-level period and the master device with the longest low-level period from among those master devices connected to the bus.

15.5.4 Slave address and address recognition mode specification

When the serial bus interface circuit is used with an addressing format to recognize the slave address, clear the ALS (Bit0 in I2CAR) to "0", and set the SA (Bits7 to 1 in I2CAR) to the slave address.

When the serial bus interface circuit is used with a free data format not to recognize the slave address, set the ALS to "1". With a free data format, the slave address and the direction bit are not recognized, and they are processed as data from immediately after start condition.

15.5.5 Master/slave selection

To set a master device, the MST (Bit7 in SBICRB) should be set to "1". To set a slave device, the MST should be cleared to "0".

When a stop condition on the bus or an arbitration lost is detected, the MST is cleared to "0" by the hardware.

15.5.6 Transmitter/receiver selection

To set the device as a transmitter, the TRX (Bit6 in SBICRB) should be set to "1". To set the device as a receiver, the TRX should be cleared to "0". When data with an addressing format is transferred in the slave mode, the TRX is set to "1" by a hardware if the direction bit (R/\overline{W}) sent from the master device is "1", and is cleared

15.5 I²C Bus Control TMP86FH92DMG

to "0" by a hardware if the bit is "0". In the master mode, after an acknowledge signal is returned from the slave device, the TRX is cleared to "0" by a hardware if a transmitted direction bit is "1", and is set to "1" by a hardware if it is "0". When an acknowledge signal is not returned, the current condition is maintained.

When a stop condition on the bus or an arbitration lost is detected, the TRX is cleared to "0" by the hardware. "Table 15-2 TRX changing conditions in each mode" shows TRX changing conditions in each mode and TRX value after changing

Mode	Direction Bit	Conditions	TRX after Changing
Slave	"0"	A received slave address is the	"0"
Mode	"1"	same value set to I2CAR	"1"
Master	"0"	101/11	"1"
Mode	"1"	ACK signal is returned	"0"

Table 15-2 TRX changing conditions in each mode

When a serial bus interface circuit operates in the free data format, a slave address and a direction bit are not recognized. They are handled as data just after generating a start condition. The TRX is not changed by a hardware.

15.5.7 Start/stop condition generation

When the BB (Bit5 in SBISRB) is "0", a slave address and a direction bit which are set to the SBIDBR are output on a bus after generating a start condition by writing "1" to the MST, TRX, BB and PIN. It is necessary to set ACK to "1" beforehand.




Figure 15-5 Start Condition Generation and Slave Address Generation

When the BB is "1", sequence of generating a stop condition is started by writing "1" to the MST, TRX and PIN, and "0" to the BB. Do not modify the contents of MST, TRX, BB and PIN until a stop condition is generated on a bus.

When a stop condition is generated and the SCL line on a bus is pulled-down to low level by another device, a stop condition is generated after releasing the SCL line.




Figure 15-6 Stop Condition Generation

The bus condition can be indicated by reading the contents of the BB (Bit5 in SBISRB). The BB is set to "1" when a start condition on a bus is detected (Bus Busy State) and is cleared to "0" when a stop condition is detected (Bus Free State).

15.5.8 Interrupt service request and cancel

When a serial bus interface circuit is in the master mode and transferring a number of clocks set by the BC and the ACK is complete, a serial bus interface interrupt request (INTSBI) is generated.

In the slave mode, the conditions of generating INTSBI interrupt request are follows:

- At the end of acknowledge signal when the received slave address matches to the value set by the I2CAR
- · At the end of acknowledge signal when a "GENERAL CALL" is received
- At the end of transferring or receiving after matching of slave address or receiving of "GENERAL CALL"

When a serial bus interface interrupt request occurs, the PIN (Bit4 in SBISRB) is cleared to "0". During the time that the PIN is "0", the SCL pin is pulled-down to low level.

Either writing data to SBIDBR or reading data from the SBIDBR sets the PIN to "1".

The time from the PIN being set to "1" until the SCL pin is released takes t_{LOW}.

Although the PIN (Bit4 in SBICRB) can be set to "1" by the software, the PIN can not be cleared to "0" by the software.

Note: When the arbitration lost occurs, if the slave address sent from the other master devices is not match, the INTSBI interrupt request is generated. But the PIN is not cleared.

15.5.9 Setting of I²C bus mode

The SBIM (Bit3 and 2 in SBICRB) is used to set I²C bus mode.

Set the SBIM to "10" in order to set I²C bus mode. Before setting of I²C bus mode, confirm serial bus interface pins in a high level, and then, write "10" to SBIM. And switch a port mode after confirming that a bus is free.

15.5.10 Arbitration lost detection monitor

Since more than one master device can exist simultaneously on a bus, a bus arbitration procedure is implemented in order to guarantee the contents of transferred data.

Data on the SDA line is used for bus arbitration of the I²C bus.

The following shows an example of a bus arbitration procedure when two master devices exist simultaneously on a bus. Master 1 and Master 2 output the same data until point "a". After that, when Master 1 outputs "1" and Master 2 outputs "0", since the SDA line of a bus is wired AND, the SDA line is pulled-down to the low level by Master 2. When the SCL line of a bus is pulled-up at point "b", the slave device reads data on the SDA line, that is data in Master 2. Data transmitted from Master 1 becomes invalid. The state in Master 1 is called "arbitration lost". A master device which loses arbitration releases the SDA pin and the SCL pin in order not to effect data transmitted from other masters with arbitration. When more than one master sends the same data at the first word, arbitration occurs continuously after the second word.

15.5 I²C Bus Control TMP86FH92DMG




Figure 15-7 Arbitration Lost

The serial bus interface circuit compares levels of a SDA line of a bus with its SDA pin at the rising edge of the SCL line. If the levels are unmatched, arbitration is lost and the AL (Bit3 in SBISRB) is set to "1".

When the AL is set to "1", the MST and TRX are cleared to "0" and the mode is switched to a slave receiver mode. Thus, the serial bus interface circuit stops output of clock pulses during data transfer after the AL is set to "1".

The AL is cleared to "0" by writing data to the SBIDBR, reading data from the SBIDBR or writing data to the SBICRB.




Figure 15-8 Example of when a Serial Bus Interface Circuit is a Master B

15.5.11 Slave address match detection monitor

In the slave mode, the AAS (Bit2 in SBISRB) is set to "1" when the received data is "GENERAL CALL" or the received data matches the slave address setting by I2CAR with an address recognition mode (ALS = 0).

When a serial bus interface circuit operates in the free data format (ALS = 1), the AAS is set to "1" after receiving the first 1-word of data.

The AAS is cleared to "0" by writing data to the SBIDBR or reading data from the SBIDBR.

15.5.12 GENERAL CALL detection monitor

The AD0 (Bit1 in SBISRB) is set to "1" when all 8-bit received data is "0" immediately after a start condition in a slave mode. The AD0 is cleared to "0" when a start or stop condition is detected on a bus.

15.5.13 Last received bit monitor

The SDA line value stored at the rising edge of the SCL line is set to the LRB (Bit0 in SBISRB). In the acknowledge mode, immediately after an INTSBI interrupt request is generated, an acknowledge signal is read by reading the contents of the LRB.

15.6 Data Transfer of I²C Bus

15.6.1 Device initialization

For initialization of device, set the ACK in SBICRA to "1" and the BC to "000". Specify the data length to 8 bits to count clocks for an acknowledge signal. Set a transfer frequency to the SCK in SBICRA.

Next, set the slave address to the SA in I2CAR and clear the ALS to "0" to set an addressing format.

After confirming that the serial bus interface pin is high level, for specifying the default setting to a slave receiver mode, clear "0" to the MST, TRX and BB in SBICRB, set "1" to the PIN, "10" to the SBIM, and "00" to bits SWRST1 and SWRST0.

Note: The initialization of a serial bus interface circuit must be complete within the time from all devices which are connected to a bus have initialized to and device does not generate a start condition. If not, the data can not be received correctly because the other device starts transferring before an end of the initialization of a serial bus interface circuit.

15.6.2 Start condition and slave address generation

Confirm a bus free status (BB = 0).

Set the ACK to "1" and specify a slave address and a direction bit to be transmitted to the SBIDBR.

By writing "1" to the MST, TRX, BB and PIN, the start condition is generated on a bus and then, the slave address and the direction bit which are set to the SBIDBR are output. The time from generating the START condition until the falling SCL pin takes t_{LOW}.

An INTSBI interrupt request occurs at the 9th falling edge of a SCL clock cycle, and the PIN is cleared to "0". The SCL pin is pulled-down to the low level while the PIN is "0". When an interrupt request occurs, the TRX changes by the hardware according to the direction bit only when an acknowledge signal is returned from the slave device.

- Note 1: Do not write a slave address to be output to the SBIDBR while data is transferred. If data is written to the SBIDBR, data to been outputting may be destroyed.
- Note 2: The bus free must be confirmed by software within 98.0 µs (The shortest transmitting time according to the I²C bus standard) after setting of the slave address to be output. Only when the bus free is confirmed, set "1" to the MST, TRX, BB, and PIN to generate the start conditions. If the writing of slave address and setting of MST, TRX, BB and PIN doesn't finish within 98.0 µs, the other masters may start the transferring and the slave address data written in SBIDBR may be broken.




Figure 15-9 Start Condition Generation and Slave Address Transfer

15.6.3 1-word data transfer

Check the MST by the INTSBI interrupt process after an 1-word data transfer is completed, and determine whether the mode is a master or slave.

15.6.3.1 When the MST is "1" (Master mode)

Check the TRX and determine whether the mode is a transmitter or receiver.

(1) When the TRX is "1" (Transmitter mode)

Test the LRB. When the LRB is "1", a receiver does not request data. Implement the process to generate a stop condition (Described later) and terminate data transfer.

When the LRB is "0", the receiver requests next data. When the next transmitted data is other than 8 bits, set the BC, set the ACK to "1", and write the transmitted data to the SBIDBR. After writing the data, the PIN becomes "1", a serial clock pulse is generated for transferring a next 1 word of data from the SCL pin, and then the 1 word of data is transmitted. After the data is transmitted, and an INTSBI interrupt request occurs. The PIN become "0" and the SCL pin is set to low level. If the data to be transferred is more than one word in length, repeat the procedure from the LRB test above.




Figure 15-10 Example of when BC = "000", ACK = "1"

(2) When the TRX is "0" (Receiver mode)

When the next transmitted data is other than of 8 bits, set the BC again. Set the ACK to "1" and read the received data from the SBIDBR (Reading data is undefined immediately after a slave address is sent). After the data is read, the PIN becomes "1". A serial bus interface circuit outputs a serial clock pulse to the SCL pin to transfer next 1-word of data and sets the SDA pin to "0" at the acknowledge signal timing.

An INTSBI interrupt request occurs and the PIN becomes "0". Then a serial bus interface circuit outputs a clock pulse for 1-word of data transfer and the acknowledge signal each time that received data is read from the SBIDBR.




Figure 15-11 Example of when BC = "000", ACK = "1"

To make the transmitter terminate transmit, clear the ACK to "0" before reading data which is 1-word before the last data to be received. A serial bus interface circuit does not generate a clock pulse for the acknowledge signal by clearing ACK. In the interrupt routine of end of transmission, when the BC is set to "001" and read the data, PIN is set to "1" and generates a clock pulse for a 1-bit data transfer. In this case, since the master device is a receiver, the SDA line on a bus keeps the high-level. The transmitter receives the high-level signal as an ACK signal. The receiver indicates to the transmitter that data transfer is complete.

After 1-bit data is received and an interrupt request has occurred, generate the stop condition to terminate data transfer.




Figure 15-12 Termination of Data Transfer in Master Receiver Mode

15.6.3.2 When the MST is "0" (Slave mode)

In the slave mode, a serial bus interface circuit operates either in normal slave mode or in slave mode after losing arbitration.

In the slave mode, the conditions of generating INTSBI interrupt request are follows:

- At the end of acknowledge signal when the received slave address matches to the value set by the I2CAR
- At the end of acknowledge signal when a "GENERAL CALL" is received
- At the end of transferring or receiving after matching of slave address or receiving of "GENERAL CALL"

15.6 Data Transfer of I²C Bus TMP86FH92DMG

A serial bus interface circuit changes to a slave mode if arbitration is lost in the master mode. And an INTSBI interrupt request occurs when word data transfer terminates after losing arbitration. The behavior of INTSBI interrupt request and PIN after losing arbitration are shown in Table 15-3.

Table 15-3 The Behavior of INTSBI interrupt request and PIN after Losing Arbitration

	When the Arbitration Lost Occurs during Transmission of Slave Address as a Master	When the Arbitration Lost Occurs during Transmission of Data as a Master Transmit Mode
INTSBI in- terrupt re- quest	INTSBI interrupt request is genera	ted at the termination of word data.
PIN	When the slave address matches the value set by I2CAR, the PIN is cleared to "0" by generating of INTSBI interrupt request. When the slave address doesn't match the value set by I2CAR, the PIN keeps "1".	PIN keeps "1" (PIN is not cleared to "0").

When an INTSBI interrupt request occurs, the PIN (bit 4 in the SBICRB) is reset, and the SCL pin is set to low level. Either reading or writing from or to the SBIDBR or setting the PIN to "1" releases the SCL pin after taking t_{LOW}.

Check the AL (Bit3 in the SBISRB), the TRX (Bit6 in the SBISRB), the AAS (Bit2 in the SBISRB), and the AD0 (Bit1 in the SBISRB) and implements processes according to conditions listed in "Table 15-4 Operation in the Slave Mode".

Table 15-4 Operation in the Slave Mode

TRX	AL	AAS	AD0	Conditions	Process
	1	1	0	A serial bus interface circuit loses arbitration when transmitting a slave address. And receives a slave address of which the value of the direction bit sent from another master is "1".	Set the number of bits in 1 word to the BC
1		1	0	In the slave receiver mode, a serial bus in- terface circuit receives a slave address of which the value of the direction bit sent from the master is "1".	and write transmitted data to the SBIDBR.
	0	0	0	In the slave transmitter mode, 1-word data is transmitted.	Test the LRB. If the LRB is set to "1", set the PIN to "1" since the receiver does not request next data. Then, clear the TRX to "0" to release the bus. If the LRB is set to "0", set the number of bits in 1 word to the BC and write transmitted data to the SBIDBR since the receiver requests next data.
	1	1	1/0	A serial bus interface circuit loses arbitration when transmitting a slave address. And receives a slave address of which the value of the direction bit sent from another master is "0" or receives a "GENERAL CALL".	Read the SBIDBR for setting the PIN to "1" (Reading dummy data) or write "1" to the PIN.
0		0	0	A serial bus interface circuit loses arbitration when transmitting a slave address or data. And terminates transferring word data.	A serial bus interface circuit is changed to slave mode. To clear AL to "0", read the SBIDBR or write the data to SBIDBR.
	0	1	1/0	In the slave receiver mode, a serial bus interface circuit receives a slave address of which the value of the direction bit sent from the master is "0" or receives "GENERAL CALL".	Read the SBIDBR for setting the PIN to "1" (Reading dummy data) or write "1" to the PIN.
		0	1/0	In the slave receiver mode, a serial bus interface circuit terminates receiving of 1-word data.	Set the number of bits in 1-word to the BC and read received data from the SBIDBR.

Note: In the slave mode, if the slave address set in I2CAR is "00H", a START Byte "01H" in I2C bus standard is received, the device detects slave address match and the TRX is set to "1".

15.6.4 Stop condition generation

When the BB is "1", a sequence of generating a stop condition is started by setting "1" to the MST, TRX and PIN, and clear "0" to the BB. Do not modify the contents of the MST, TRX, BB, PIN until a stop condition is generated on a bus.

When a SCL line on a bus is pulled-down by other devices, a serial bus interface circuit generates a stop condition after they release a SCL line.

The time from the releasing SCL line until the generating the STOP condition takes t_{LOW}.




Figure 15-13 Stop Condition Generation

15.6.5 Restart

Restart is used to change the direction of data transfer between a master device and a slave device during transferring data. The following explains how to restart a serial bus interface circuit.

Clear "0" to the MST, TRX and BB and set "1" to the PIN. The SDA pin retains the high-level and the SCL pin is released. Since a stop condition is not generated on a bus, a bus is assumed to be in a busy state from other devices. Test the BB until it becomes "0" to check that the SCL pin of a serial bus interface circuit is released. Test the LRB until it becomes "1" to check that the SCL line on a bus is not pulled-down to the low level by other devices. After confirming that a bus stays in a free state, generate a start condition with procedure "15.6.2 Start condition and slave address generation".

In order to meet setup time when restarting, take at least $4.7 \mu s$ of waiting time by software from the time of restarting to confirm that a bus is free until the time to generate a start condition.

Note: When the master is in the receiver mode, it is necessary to stop the data transmission from the slave device before the STOP condition is generated. To stop the transmission, the master device make the slave device receiving a negative acknowledge. Therefore, the LRB is "1" before generating the Restart and it can not be confirmed that SCL line is not pulled-down by other devices. Please confirm the SCL line state by reading the port.




Figure 15-14 Timing Diagram when Restarting

TOSHIBA TMP86FH92DMG


16. 10-bit AD Converter (ADC)

The TMP86FH92DMG have a 10-bit successive approximation type AD converter.

16.1 Configuration

The circuit configuration of the 10-bit AD converter is shown in Figure 16-1.

It consists of control register ADCCR1 and ADCCR2, converted value register ADCDR1 and ADCDR2, a DA converter, a sample-hold circuit, a comparator, and a successive comparison circuit.



Note: Before using AD converter, set appropriate value to I/O port register combining a analog input port. For details, see the section on "I/O ports".

Figure 16-1 10-bit AD Converter

16.2 Register configuration

TMP86FH92DMG

16.2 Register configuration

The AD converter consists of the following four registers:

1. AD converter control register 1 (ADCCR1)

This register selects the analog channels and operation mode (Software start or repeat) in which to perform AD conversion and controls the AD converter as it starts operating.

2. AD converter control register 2 (ADCCR2)

This register selects the AD conversion time and controls the connection of the DA converter (Ladder resistor network).

3. AD converted value register 1 (ADCDR1)

This register used to store the digital value after being converted by the AD converter.

4. AD converted value register 2 (ADCDR2)

This register monitors the operating status of the AD converter.


AD Converter Control Register 1

ADCCR1	7	6	5	4	3	2	1	0	
(000EH)	ADRS	AM	D	AINDS		SA	IN		(Initial value: 0001 0000)

ADRS	AD conversion start	0:	-	
		1:	AD conversion start	
AMD AD operating mode		00:	AD operation disable	
	AD energting mode	01:	Software start mode	
AIVID	AD operating mode	10:	Reserved	
		11:	Repeat mode	
AINIDO	A color for the last	0:	Analog input enable	
AINDS	Analog input control	1:	Analog input disable	
		0000:	AIN0	
		0001:	AIN1	
		0010:	AIN2	
		0011:	AIN3	R/W
		0100:	AIN4	
		0101:	AIN5	
		0110:	Reserved	
SAIN	Analog input channel select	0111:	Reserved	
SAIN	Analog input charmer select	1000:	Reserved	
		1001:	Reserved	
		1010:	Reserved	
		1011:	Reserved	
		1100:	Reserved	
		1101:	Reserved	
		1110:	Reserved	
		1111:	Reserved	

- Note 1: Select analog input channel during AD converter stops (ADCDR2<ADBF> = "0").
- Note 2: When the analog input channel is all use disabling, the ADCCR1<AINDS> should be set to "1".
- Note 3: During conversion, Do not perform port output instruction to maintain a precision for all of the pins because analog input port use as general input port. And for port near to analog input, Do not input intense signaling of change.
- Note 4: The ADCCR1<ADRS> is automatically cleared to "0" after starting conversion.
- Note 5: Do not set ADCCR1<ADRS> newly again during AD conversion. Before setting ADCCR1<ADRS> newly again, check ADCDR2<EOCF> to see that the conversion is completed or wait until the interrupt signal (INTADC) is generated (e.g., interrupt handling routine).
- Note 6: After STOP or SLOW/SLEEP mode are started, AD converter control register1 (ADCCR1) is all initialized and no data can be written in this register. Therefore, to use AD converter again, set the ADCCR1 newly after returning to NORMAL1 or NORMAL2 mode.

AD Converter Control Register 2



IREFON	DA converter (Ladder resistor) connection control	0: 1:	Connected only during AD conversion Always connected	
ACK	AD conversion time select (Refer to the following table about the conversion time)	001: 010: 011:	78/fc 156/fc 312/fc	R/W

Note 1: Always set bit0 in ADCCR2 to "0" and set bit4 in ADCCR2 to "1".

Note 2: When a read instruction for ADCCR2, bit6 to 7 in ADCCR2 read in as undefined data.

Note 3: After STOP or SLOW/SLEEP mode are started, AD converter control register2 (ADCCR2) is all initialized and no data can be written in this register. Therefore, to use AD converter again, set the ADCCR2 newly after returning to NORMAL1 or NORMAL2 mode.

Table 16-1 ACK setting and Conversion time

Condition ACK	Conversion time	16 MHz	8 MHz	4 MHz	2 MHz	10 MHz	5 MHz	2.5 MHz	
000	39/fc	-	-	-	19.5 µs	-	-	15.6 µs	
001		Reserved							
010	78/fc	-	-	19.5 µs	39.0 µs	-	15.6 µs	31.2 µs	
011	156/fc	-	19.5 µs	39.0 µs	78.0 µs	15.6 µs	31.2 µs	62.4 µs	
100	312/fc	19.5 µs	39.0 µs	78.0 µs	156.0 µs	31.2 µs	62.4 µs	124.8 µs	
101	624/fc	39.0 µs	78.0 µs	156.0 µs	-	62.4 µs	124.8 µs	-	
110	1248/fc	78.0 µs	156.0 µs	-	-	124.8 µs	-	-	
111	Reserved								

Note 1: Setting for "-" in the above table are inhibited. fc: High Frequency oscillation clock [Hz]

Note 2: Set conversion time setting should be kept more than the following time by Power supply voltage(VDD) .

VDD = 4.5 to 5.5 V
 VDD = 2.7 to 5.5 V
 31.2 μs and more

AD Converted value Register 1

5 0 6 4 3 2 1 ADCDR1 (0021H)AD09 AD08 AD07 AD06 AD05 AD04 AD03 AD02 (Initial value: 0000 0000) 16. 10-bit AD Converter (ADC)

16.2 Register configuration TMP86FH92DMG

AD Converted value Register 2

ADCDR2	7	6	5	4	3	2	1	0	
(0020H)	AD01	AD00	EOCF	ADBF					(Initial value: 0000 ****)

EOCF	AD conversion end flag	0: 1:	Before or during conversion Conversion completed	Read
ADBF	AD conversion BUSY flag	0: 1:	During stop of AD conversion During AD conversion	only

Note 1: The ADCDR2<EOCF> is cleared to "0" when reading the ADCDR1. Therefore, the AD conversion result should be read to ADCDR2 more first than ADCDR1.

Note 2: The ADCDR2<ADBF> is set to "1" when AD conversion starts, and cleared to "0" when AD conversion finished. It also is cleared upon entering STOP mode or SLOW mode.

Note 3: If a read instruction is executed for ADCDR2, read data of bit3 to bit0 are unstable.

16.3 Function

16.3.1 Software Start Mode

After setting ADCCR1<AMD> to "01" (software start mode), set ADCCR1<ADRS> to "1". AD conversion of the voltage at the analog input pin specified by ADCCR1<SAIN> is thereby started.

After completion of the AD conversion, the conversion result is stored in AD converted value registers (ADCDR1, ADCDR2) and at the same time ADCDR2<EOCF> is set to 1, the AD conversion finished interrupt (INTADC) is generated.

ADRS is automatically cleared after AD conversion has started. Do not set ADCCR1<ADRS> newly again (Restart) during AD conversion. Before setting ADRS newly again, check ADCDR2<EOCF> to see that the conversion is completed or wait until the interrupt signal (INTADC) is generated (e.g., interrupt handling routine).




Figure 16-2 Software Start Mode

16.3.2 Repeat Mode

AD conversion of the voltage at the analog input pin specified by ADCCR1<SAIN> is performed repeatedly. In this mode, AD conversion is started by setting ADCCR1<ADRS> to "1" after setting ADCCR1<AMD> to "11" (Repeat mode).

After completion of the AD conversion, the conversion result is stored in AD converted value registers (ADCDR1, ADCDR2) and at the same time ADCDR2<EOCF> is set to 1, the AD conversion finished interrupt (INTADC) is generated.

In repeat mode, each time one AD conversion is completed, the next AD conversion is started. To stop AD conversion, set ADCCR1<AMD> to "00" (Disable mode) by writing 0s. The AD convert operation is stopped immediately. The converted value at this time is not stored in the AD converted value register.

16.3 Function TMP86FH92DMG




Figure 16-3 Repeat Mode

16.3.3 Register Setting

- 1. Set up the AD converter control register 1 (ADCCR1) as follows:
 - Choose the channel to AD convert using AD input channel select (SAIN).
 - Specify analog input enable for analog input control (AINDS).
 - Specify AMD for the AD converter control operation mode (software or repeat mode).
- 2. Set up the AD converter control register 2 (ADCCR2) as follows:
 - Set the AD conversion time using AD conversion time (ACK). For details on how to set the conversion time, refer to Figure 16-1 and AD converter control register 2.
 - · Choose IREFON for DA converter control.
- 3. After setting up (1) and (2) above, set AD conversion start (ADRS) of AD converter control register 1 (ADCCR1) to "1". If software start mode has been selected, AD conversion starts immediately.
- 4. After an elapse of the specified AD conversion time, the AD converted value is stored in AD converted value register 1 (ADCDR1) and the AD conversion finished flag (EOCF) of AD converted value register 2 (ADCDR2) is set to "1", upon which time AD conversion interrupt INTADC is generated.
- 5. EOCF is cleared to "0" by a read of the conversion result. However, if reconverted before a register read, although EOCF is cleared the previous conversion result is retained until the next conversion is completed.

TMP86FH92DMG

Example :After selecting the conversion time 19.5 µs at 16 MHz and the analog input channel AIN3 pin, perform AD conversion once. After checking EOCF, read the converted value, store the lower 2 bits in address 0009EH and store the upper 8 bits in address 0009FH in RAM. The operation mode is software start mode.

	: (port setting)	:	;Set port register appropriately before setting AD converter registers.
	:	:	(Refer to section I/O port in details)
	LD	(ADCCR1), 00100011B	; Select AIN3
	LD	(ADCCR2), 11011000B	; Select conversion time (312/fc) and operation mode $$
	SET	(ADCCR1).7	; ADRS = 1(AD conversion start)
SLOOP:	TEST	(ADCDR2) . 5	; EOCF= 1 ?
	JRS	T, SLOOP	
	LD	A , (ADCDR2)	; Read result data
	LD	(9EH) , A	
	LD	A , (ADCDR1)	; Read result data
	LD	(9FH), A	

16.4 STOP/SLOW Modes during AD Conversion

When standby mode (STOP or SLOW mode) is entered forcibly during AD conversion, the AD convert operation is suspended and the AD converter is initialized (ADCCR1 and ADCCR2 are initialized to initial value). Also, the conversion result is indeterminate. (Conversion results up to the previous operation are cleared, so be sure to read the conversion results before entering standby mode (STOP or SLOW mode).) When restored from standby mode (STOP or SLOW mode), AD conversion is not automatically restarted, so it is necessary to restart AD conversion. Note that since the analog reference voltage is automatically disconnected, there is no possibility of current flowing into the analog reference voltage.

Analog Input Voltage and AD Conversion Result 16.5

The analog input voltage is corresponded to the 10-bit digital value converted by the AD as shown in Figure 16-4.




Figure 16-4 Analog Input Voltage and AD Conversion Result (Typ.)

TOSHIBA TMP86FH92DMG

16.6 Precautions about AD Converter

16.6.1 Analog input pin voltage range

Make sure the analog input pins (AIN0 to AIN5) are used at voltages within VDD to VSS. If any voltage outside this range is applied to one of the analog input pins, the converted value on that pin becomes uncertain. The other analog input pins also are affected by that.

16.6.2 Analog input shared pins

The analog input pins (AIN0 to AIN5) are shared with input/output ports. When using any of the analog inputs to execute AD conversion, do not execute input/output instructions for all other ports. This is necessary to prevent the accuracy of AD conversion from degrading. Not only these analog input shared pins, some other pins may also be affected by noise arising from input/output to and from adjacent pins.

16.6.3 Noise Countermeasure

The internal equivalent circuit of the analog input pins is shown in Figure 16-5. The higher the output impedance of the analog input source, more easily they are susceptible to noise. Therefore, make sure the output impedance of the signal source in your design is $5 \text{ k}\Omega$ or less. Toshiba also recommends attaching a capacitor external to the chip.




Figure 16-5 Analog Input Equivalent Circuit and Example of Input Pin Processing

10-bit AD Converter (ADC)	
` ,	
	10-bit AD Converter (ADC)

16.6 Precautions about AD Converter

TMP86FH92DMG

TOSHIBA TMP86FH92DMG

17. Key-on Wakeup (KWU)

TMP86FH92DMG have four pins P34 to P37, in addition to the P20 (INT5/STOP) pin, that can be used to exit STOP mode.

When using these P34 to P37 pin's input to exit STOP mode, pay attention to the logic of P20 pin. In details, refer to the following section"17.2 Control".

17.1 Configuration





Figure 17-1 Key-on Wakeup Circuit

Example of STOP mode release operation

STOP mode release operation(P34 to 37)



^{*:} The time required for wakeup from releasing STOP mode includes the warming-up time. For details, refer to section "Control of Operation Modes".

Figure 17-2 Example of STOP Mode Release Operation

17.2 Control TMP86FH92DMG

17.2 Control

The P34 to P37 (STOP2 to STOP5) pins can individually be disabled/enabled using Key-on Wakeup Control Register (STOPCR). When these pins are used as a release input of STOP mode, beforehand they set to key-on wakeup by each register of P3 Port. For details, refer to section "I/O Ports".

STOP mode can be entered by setting up the System Control Register (SYSCR1), and can be released by detecting the active edge (rising or falling edge) on any STOP2 to STOP5 pins which are available for STOP mode release.

Note: When using Key-on Wakeup function, select level mode (set SYSCR1<RELM> to "1") for selection of STOP mode release method.

Although P20 pin is shared with $\overline{\text{INT5}}$ and $\overline{\text{STOP}}$ pin input, use mainly $\overline{\text{STOP}}$ pin to release STOP mode. This is because Key-on Wakeup function is comprised of $\overline{\text{STOP}}$ pin and STOP2 to STOP5 pins as shown in the configuration diagram.

- Note 1: When STOP mode release by an edge on STOP pin, follow one of the two methods described below.
 - (1) Disable all of STOP2 to STOP5 pin inputs.
 - (2) Fix STOP2 to 5 pin inputs high or low level.
- Note 2: When using key-on wakeup (STOP2 to 5 pins) to exit STOP mode, make sure \$\overline{STOP}\$ pin is held low and \$\overline{STOP}\$ to 5 pin inputs are held high or low level, because \$\overline{STOP}\$ mode release signal is created by OR circuit the \$\overline{STOP}\$ pin input and the \$\overline{STOP2}\$ to 5 pin input together.

Key-on Wakeup STOP Mode Control Register

STOPCR	7	6	5	4	3	2	1	0	
(0031H)	STOP5	STOP4	STOP3	STOP2					(Initial value : 0000 ****)

STOP2	STOP mode release by P34 (STOP2)		Disable	
310F2	STOP IIIOUE TELEBASE BY F34 (STOP2)	1:	Enable	
STOP3 STOP mode release by P35 (STOP3)	CTOD made release by D25 (CTOD2)	0:	Disable	
	STOP mode release by P35 (STOP3)	1:	Enable	Write
STOP4	OTOD words welsoes by D2C (OTODA)	0:	Disable	only
S10P4	STOP mode release by P36 (STOP4)	1:	Enable	
OTODE	0700	0:	Disable	
STOP5	STOP mode release by P37 (STOP5)		Enable	

<example mode="" of="" release="" stop=""> The device is released from STOP mode in the following condition.</example>							
P20(STOP) P3x							
STOP mode release using P3x (STOP2 to 5)	Level detection mode: Low Edge detection mode: Disable	Edge detection Rising or falling edge					
STOP mode release using P20 (STOP)	Level detection mode: High Edge detection mode: Rising edge	STOPCR: inhibited					

Note: Assertion of the STOP mode release signal is not recognized within three instruction cycles after executing the STOP instruction.

TOSHIBA TMP86FH92DMG

18. Flash Memory

TMP86FH92DMG has 16384byte flash memory (address: C000H to FFFFH). The write and erase operations to the flash memory are controlled in the following three types of mode.

- MCU mode

The flash memory is accessed by the CPU control in the MCU mode. This mode is used for software bug correction and firmware change after shipment of the device since the write operation to the flash memory is available by retaining the application behavior.

- Serial PROM mode

The flash memory is accessed by the CPU control in the serial PROM mode. Use of the serial interface (UART) enables the flash memory to be controlled by the small number of pins. TMP86FH92DMG in the serial PROM mode supports on-board programming which enables users to program flash memory after the microcontroller is mounted on a user board.

- Parallel PROM mode

The parallel PROM mode allows the flash memory to be accessed as a stand-alone flash memory by the program writer provided by the third party. High-speed access to the flash memory is available by controlling address and data signals directly. For the support of the program writer, please ask Toshiba sales representative

In the MCU and serial PROM modes, the flash memory control register (FLSCR) is used for flash memory control. This chapter describes how to access the flash memory using the flash memory control register (FLSCR) in the MCU and serial PROM modes.


Note 1: The 'Read Protect' described by data sheet of old edition was changed into 'Security Program'.

3.1 Flash Memory Control TMP86FH92DMG

18.1 Flash Memory Control


The flash memory is controlled via the flash memory control register (FLSCR) and flash memory standby control resister (FLSSTB).

Flash Memory Control Register



- Note 1: The command sequence of the flash memory can be executed only when FLSMD="0011B". In other cases, any attempts to execute the command sequence are ineffective.
- Note 2: FLSMD must be set to either "1100B" or "0011B".
- Note 3: Bits 3 through 0 in FLSCR are always read as don't care.
- Note 4: Always set bit3 in FLSCR to "1".

Flash Memory Standby Control Register



- Note 1: When FSTB is set to 1, do not execute the read/write instruction to the flash memory because there is a possibility that the expected data is not read or the program is not operated correctly. If executing the read/write instruction, FSTB is initialized to 0 automatically.
- Note 2: If an interrupt is issued when FSTB is set to 1, FSTB is initialized to 0 automatically and then the vector area of the flash memory is read.
- Note 3: If the IDLE0/1/2, SLEEP0/1/2 or STOP mode is activated when FSTB is set to 1, FSTB is initialized to 0 automatically. In the IDLE0/1/2, SLEEP0/1/2 or STOP mode, the standby function operates regardless of FSTB setting.

18.1.1 Flash Memory Command Sequence Execution Control (FLSCR<FLSMD>)

The flash memory can be protected from inadvertent write due to program error or microcontroller misoperation. This write protection feature is realized by disabling flash memory command sequence execution via the flash memory control register (write protect). To enable command sequence execution, set FLSCR<FLSMD> to "0011B". To disable command sequence execution, set FLSCR<FLSMD> to "1100B". After reset, FLSCR<FLSMD> is initialized to "1100B" to disable command sequence execution. Normally, FLSCR<FLSMD> should be set to "1100B" except when the flash memory needs to be written or erased.

18.1.2 Flash Memory Standby Control (FLSSTB<FSTB>)

Low power consumption is enabled by cutting off the steady-state current of the flash memory. In the IDLE0/1/2, SLEEP0/1/2 or STOP mode, the steady-state current of the flash memory is cut off automatically.

When the program is executed in the RAM area (without accessing the flash memory) in the NORMAL 1/2 or SLOW1/2 mode, the current can be cut off by the control of the register. To cut off the steady-state current of the flash memory, set FLSSTB<FSTB> to "1" by the control program in the RAM area. The procedures for controlling the FLSSTB register are explained below.

(Steps1 and 2 are controlled by the program in the flash memory, and steps 3 through 8 are controlled by the write control program executed in the RAM area.)

- 1. Transfer the control program of the FLSSTB register to the RAM area.
- 2. Jump to the RAM area.
- 3. Disable (DI) the interrupt master enable flag (IMF = "0").
- 4. Set FLSSTB<FSTB> to "1".
- 5. Execute the user program.
- 6. Repeat step 5 until the return request to the flash memory is detected.
- 7. Set FLSSTB<FSTB> to "0".
- 8. Jump to the flash memory area.
- Note 1: The standby function is not operated by setting FLSSTB<FSTB> with the program in the flash memory. You must set FLSSTB<FSTB> by the program in the RAM area.
- Note 2: To use the standby function by setting FLSSTB<FSTB> to "1" with the program in the RAM area, FLSSTB<FSTB> must be set to "0" by the program in the RAM area before returning the program control to the flash memory. If the program control is returned to the flash memory with FLSSTB<FSTB> set to "1", the program may malfunction and run out of control.

nce TMP86FH92DMG

18.2 Command Sequence

The command sequence in the MCU and the serial PROM modes consists of six commands (JEDEC compatible), as shown in Table 18-1. Addresses specified in the command sequence are recognized with the lower 12 bits (excluding BA, SA, and FF7FH used for security program). The upper 4 bits are used to specify the flash memory area,

Table 18-1 Command Sequence

	0	1st Bus W	rite Cycle	2nd Bus W	/rite Cycle	3rd Bus W	/rite Cycle	4th Bus W	/rite Cycle	5th Bus W	/rite Cycle	6th Bus W	/rite Cycle
	Command Sequence	Address	Data	Address	Data	Address	Data	Address	Data	Address	Data	Address	Data
1	Byte program	555H	AAH	АААН	55H	555H	A0H	BA (Note 1)	Data (Note 1)	-	-	-	-
2	Sector Erase (4-kbyte Erase)	555H	AAH	AAAH	55H	555H	80H	555H	AAH	AAAH	55H	SA (Note 2)	30H
3	Chip Erase (All Erase)	555H	AAH	AAAH	55H	555H	80H	555H	AAH	АААН	55H	555H	10H
4	Product ID Entry	555H	AAH	AAAH	55H	555H	90H	-	-	-	-	-	-
Ę	Product ID Exit	XXH	F0H	-	-	-	-	-	-	-	-	-	-
5	Product ID Exit	555H	AAH	AAAH	55H	555H	F0H	-	-	-	-	-	-
6	Security Program	555H	AAH	AAAH	55H	555H	A5H	FF7FH	00H	-	-	-	-

Note 1: Set the address and data to be written.

Note 2: The area to be erased is specified with the upper 4 bits of the address.

18.2.1 Byte Program

This command writes the flash memory for each byte unit. The addresses and data to be written are specified in the 4th bus write cycle. Each byte can be programmed in a maximum of $40~\mu s$. The next command sequence cannot be executed until the write operation is completed. To check the completion of the write operation, perform read operations repeatedly until the same data is read twice from the same address in the flash memory. During the write operation, any consecutive attempts to read from the same address is reversed bit 6 of the data (toggling between 0 and 1).

Note: To rewrite data to Flash memory addresses at which data (including FFH) is already written, make sure to erase the existing data by "sector erase" or "chip erase" before rewriting data.

18.2.2 Sector Erase (4-kbyte Erase)

This command erases the flash memory in units of 4 kbytes. The flash memory area to be erased is specified by the upper 4 bits of the 6th bus write cycle address. For example, to erase 4 kbytes from F000H to FFFFH, specify one of the addresses in F000H-FFFFH as the 6th bus write cycle. The sector erase command is effective only in the MCU and serial PROM modes, and it cannot be used in the parallel PROM mode.

A maximum of 30 ms is required to erase 4 kbytes. The next command sequence cannot be executed until the erase operation is completed. To check the completion of the erase operation, perform read operations repeatedly for data polling until the same data is read twice from the same address in the flash memory. During the erase operation, any consecutive attempts to read from the same address is reversed bit 6 of the data (toggling between 0 and 1).

18.2.3 Chip Erase (All Erase)

This command erases the entire flash memory in approximately 30 ms. The next command sequence cannot be executed until the erase operation is completed. To check the completion of the erase operation, perform read operations repeatedly for data polling until the same data is read twice from the same address in the flash memory. During the erase operation, any consecutive attempts to read from the same address is reversed bit 6 of the data (toggling between 0 and 1). After the chip is erased, all bytes contain FFH.

18.2.4 Product ID Entry

This command activates the Product ID mode. In the Product ID mode, the vendor ID, the flash ID, and the security program status can be read from the flash memory.

Table 18-2 Values To Be Read in the Product ID Mode

Address	Meaning	Read Value
F000H	Vendor ID	98H
F001H	Flash macro ID	41H
		0EH: 60 kbytes
		0BH: 48 kbytes
	Flash size	07H: 32 kbytes
F002H		05H: 24 kbytes
		03H: 16 kbytes
		01H: 8 kbytes
		00H: 4 kbytes
FF7FH	Socurity program status	FFH: Security program disabled
FF/FM	Security program status	Other than FFH: Security program enabled

Note: The value at address F002H (flash size) depends on the size of flash memory incorporated in each product. For example, if the product has 60-kbyte flash memory, "0EH" is read from address F002H.

18.2.5 Product ID Exit

This command is used to exit the Product ID mode.

18.2.6 Security Program

This command enables the read protection setting in the flash memory. When the security program is enabled, the flash memory cannot be read in the parallel PROM mode. In the serial PROM mode, the flash write and RAM loader commands cannot be executed.

To disable the security program setting, it is necessary to execute the chip erase command sequence. Whether or not the security program is enabled can be checked by reading FF7FH in the Product ID mode. For details, see Table 18-2.

It takes a maximum of 40 µs to set security program in the flash memory. The next command sequence cannot be executed until this operation is completed. To check the completion of the security program operation, perform read operations repeatedly for data polling until the same data is read twice from the same address in the flash memory. During the security program operation, any attempts to read from the same address is reversed bit 6 of the data (toggling between 0 and 1).

18. Flash Memory

18.3 Toggle Bit (D6) TMP86FH92DMG

18.3 Toggle Bit (D6)

After the byte program, chip erase, and security program command sequence is executed, any consecutive attempts to read from the same address is reversed bit 6 (D6) of the data (toggling between 0 and 1) until the operation is completed. Therefore, this toggle bit provides a software mechanism to check the completion of each operation. Usually perform read operations repeatedly for data polling until the same data is read twice from the same address in the flash memory. After the byte program, chip erase, or security program command sequence is executed, the initial read of the toggle bit always produces a "1".

18.4 Access to the Flash Memory Area

When the write, erase and security program are set in the flash memory, read and fetch operations cannot be performed in the entire flash memory area. Therefore, to perform these operations in the entire flash memory area, access to the flash memory area by the control program in the BOOTROM or RAM area. (The flash memory program cannot write to the flash memory.) The serial PROM or MCU mode is used to run the control program in the BOOTROM or RAM area.

- Note 1: The flash memory can be written or read for each byte unit. Erase operations can be performed either in the entire area or in units of 4 kbytes, whereas read operations can be performed by an one transfer instruction. However, the command sequence method is adopted for write and erase operations, requiring several-byte transfer instructions for each operation.
- Note 2: To rewrite data to Flash memory addresses at which data (including FFH) is already written, make sure to erase the existing data by "sector erase" or "chip erase" before rewriting data.

18.4.1 Flash Memory Control in the Serial PROM Mode

The serial PROM mode is used to access to the flash memory by the control program provided in the BOOT-ROM area. Since almost of all operations relating to access to the flash memory can be controlled simply by the communication data of the serial interface (UART), these functions are transparent to the user. For the details of the serial PROM mode, see "Serial PROM Mode."

To access to the flash memory by using peripheral functions in the serial PROM mode, run the RAM loader command to execute the control program in the RAM area. The procedures to execute the control program in the RAM area is shown in "18.4.1.1 How to write to the flash memory by executing the control program in the RAM area (in the RAM loader mode within the serial PROM mode)".

18.4.1.1 How to write to the flash memory by executing the control program in the RAM area (in the RAM loader mode within the serial PROM mode)

(Steps 1 and 2 are controlled by the BOOTROM, and steps 3 through 9 are controlled by the control program executed in the RAM area.)

- 1. Transfer the write control program to the RAM area in the RAM loader mode.
- 2. Jump to the RAM area.
- 3. Disable (DI) the interrupt master enable flag (IMF←"0").
- 4. Set FLSCR<FLSMD> to "0011B" (to enable command sequence execution).
- 5. Execute the erase command sequence.
- 6. Read the same flash memory address twice.

(Repeat step 6 until the same data is read by two consecutive reads operations.)

- 7. Execute the write command sequence.
- 8. Read the same flash memory address twice.

(Repeat step 8 until the same data is read by two consecutive reads operations.)

- 9. Set FLSCR<FLSMD> to "1100B" (to disable command sequence execution).
- Note 1: Before writing to the flash memory in the RAM area, disable interrupts by setting the interrupt master enable flag (IMF) to "0". Usually disable interrupts by executing the DI instruction at the head of the write control program in the RAM area.
- Note 2: Since the watchdog timer is disabled by the BOOTROM in the RAM loader mode, it is not required to disable the watchdog timer by the RAM loader program.

Example : After chip erasure, the program in the RAM area writes data 3FH to address F000H.

	DI		: Disable interrupts (IMF←"0")
	LD	(FLSCR),00111000B	: Enable command sequence execution.
	LD	IX,0F555H	
	LD	IY,0FAAAH	
	LD	HL,0F000H	
; #### Flash Mem	ory Chip erase I	Process ####	
	LD	(IX),0AAH	: 1st bus write cycle
	LD	(IY),55H	: 2nd bus write cycle
	LD	(IX),80H	: 3rd bus write cycle
	LD	(IX),0AAH	: 4th bus write cycle
	LD	(IY),55H	: 5th bus write cycle
	LD	(IX),10H	: 6th bus write cycle
sLOOP1:	LD	W,(HL)	
	CMP	W,(HL)	
	JR	NZ,sLOOP1	: Loop until the same value is read.
; #### Flash Mem	ory Write Proces	ss ####	
	LD	(IX),0AAH	: 1st bus write cycle
	LD	(IY),55H	: 2nd bus write cycle
	LD	(IX),0A0H	: 3rd bus write cycle
	LD	(HL),3FH	: 4th bus write cycle, (F000H)=3FH
sLOOP2:	LD	W,(HL)	
	CMP	W,(HL)	
	JR	NZ,sLOOP2	: Loop until the same value is read.
	LD	(FLSCR),11001000B	: Disable command sequence execution.
sLOOP3:	JP	sLOOP3	

18.4.2 Flash Memory Control in the MCU mode

In the MCU mode, write operations are performed by executing the control program in the RAM area. Before execution of the control program, copy the control program into the RAM area or obtain it from the external using the communication pin. The procedures to execute the control program in the RAM area in the MCU mode are described below.

18.4.2.1 How to write to the flash memory by executing a user write control program in the RAM area (in the MCU mode)

(Steps 1 and 2 are controlled by the program in the flash memory, and steps 3 through 11 are controlled by the control program in the RAM area.)

- 1. Transfer the write control program to the RAM area.
- 2. Jump to the RAM area.
- 3. Disable (DI) the interrupt master enable flag (IMF←"0").
- 4. Disable the watchdog timer, if it is used.
- 5. Set FLSCR<FLSMD> to "0011B" (to enable command sequence execution).
- 6. Execute the erase command sequence.
- 7. Read the same flash memory address twice.

(Repeat step 7 until the same data is read by two consecutive read operations.)

- 8. Execute the write command sequence.
- 9. Read the same flash memory address twice.

(Repeat step 9 until the same data is read by two consecutive read operations.)

- 10. Set FLSCR<FLSMD> to "1100B" (to disable command sequence execution).
- 11. Jump to the flash memory area.
- Note 1: Before writing to the flash memory in the RAM area, disable interrupts by setting the interrupt master enable flag (IMF) to "0". Usually disable interrupts by executing the DI instruction at the head of the write control program in the RAM area.
- Note 2: When writing to the flash memory, do not intentionally use non-maskable interrupts (the watchdog timer must be disabled if it is used). If a non-maskable interrupt occurs while the flash memory is being written, unexpected data is read from the flash memory (interrupt vector), resulting in malfunction of the microcontroller.

18.4 Access to the Flash Memory Area

Example :After sector erasure (E000H-EFFFH), the program in the RAM area writes data 3FH to address E000H.

	DI		: Disable interrupts (IMF←"0")
	LD	(WDTCR2),4EH	: Clear the WDT binary counter.
	LDW	(WDTCR1),0B101H	: Disable the WDT.
	LD	(FLSCR),00111000B	: Enable command sequence execution.
	LD	IX,0F555H	
	LD	IY,0FAAAH	
	LD	HL,0E000H	
; #### Flash Men	nory Sector Eras	se Process ####	
	LD	(IX),0AAH	: 1st bus write cycle
	LD	(IY),55H	: 2nd bus write cycle
	LD	(IX),80H	: 3rd bus write cycle
	LD	(IX),0AAH	: 4th bus write cycle
	LD	(IY),55H	: 5th bus write cycle
	LD	(HL),30H	: 6th bus write cycle
sLOOP1:	LD	W,(HL)	
	CMP	W,(HL)	
	JR	NZ,sLOOP1	: Loop until the same value is read.
; #### Flash Men	nory Write Proce	ess ####	
	LD	(IX),0AAH	: 1st bus write cycle
	LD	(IY),55H	: 2nd bus write cycle
	LD	(IX),0A0H	: 3rd bus write cycle
	LD	(HL),3FH	: 4th bus write cycle, (E000H)=3FH
sLOOP2:	LD	W,(HL)	
	CMP	W,(HL)	
	JR	NZ,sLOOP2	: Loop until the same value is read.
	LD	(FLSCR),11001000B	: Disable command sequence execution
	JP	XXXXH	: Jump to the flash memory area.

Example: This write control program reads data from address F000H and stores it to 98H in the RAM area.

LD A,(0F000H) : Read data from address F000H. LD (98H),A : Store data to address 98H.

TOSHIBA TMP86FH92DMG

19. Serial PROM Mode

19.1 Outline

The TMP86FH92DMG has a 2048 byte BOOTROM (Mask ROM) for programming to flash memory. The BOOTROM is available in the serial PROM mode, and controlled by TEST, BOOT and RESET pins. Communication is performed via UART. The serial PROM mode has seven types of operating mode: Flash memory writing, RAM loader, Flash memory SUM output, Product ID code output, Flash memory status output, Flash memory erasing and Flash memory security program setting. Memory address mapping in the serial PROM mode differs from that in the MCU mode. Figure 19-1 shows memory address mapping in the serial PROM mode.

Table 19-1 Operating Range in the Serial PROM Mode

Parameter	Min	Max	Unit
Power supply	4.5	5.5	V
High frequency (Note)	2	16	MHz

Note: Though included in above operating range, some of high frequencies are not supported in the serial PROM mode. For details, refer to "Table 19-5".

19.2 Memory Mapping

The Figure 19-1 shows memory mapping in the Serial PROM mode and MCU mode.

In the serial PROM mode, the BOOTROM (Mask ROM) is mapped in addresses from 7800H to 7FFFH.




Figure 19-1 Memory Address Maps

19.3 Serial PROM Mode Setting

19.3 Serial PROM Mode Setting

19.3.1 Serial PROM Mode Control Pins

To execute on-board programming, activate the serial PROM mode. Table 19-2 shows pin setting to activate the serial PROM mode.

Table 19-2 Serial PROM Mode Setting

Pin	Setting
TEST pin	High
BOOT/RXD1 pin	High
RESET pin	

Note: The BOOT pin is shared with the UART communication pin (RXD1 pin) in the serial PROM mode. This pin is used as UART communication pin after activating serial PROM mode

19.3.2 Pin Function

In the serial PROM mode, TXD1 (P00) and RXD1 (P01) are used as a serial interface pin.

Table 19-3 Pin Function in the Serial PROM Mode

Pin Name (Serial PROM Mode)	Input/ Output	Function	Pin Name (MCU Mode)			
TXD1	Output	Serial data output		P00		
BOOT/RXD1	Input/In- put	Serial PROM mode control/Serial data input	(Note 1)	P01		
RESET	Input	Serial PROM mode control	1	RESET		
TEST	Input	Fixed to high	TEST			
VDD	Power supply	4.5 to 5.5 V				
VSS	Power supply	0 V				
I/O ports except P00, P01	I/O	These ports are in the high-impedance state in the serial PROM mode. The input level is fixed to the port inputs with a hardware feature to prevent overlap current. (The port inputs are invalid.) To make the port inputs valid, set the pin of the SPCR register to "1" by the RAM loader control program.				
XIN	Input	Colf assillate with an assillator		(Note 2)		
XOUT	Output	Self-oscillate with an oscillator.		(Note 2)		

Note 1: During on-board programming with other parts mounted on a user board, be careful no to affect these communication control pins.

Note 2: Operating range of high frequency in serial PROM mode is 2 MHz to 16 MHz.




Figure 19-2 Serial PROM Mode Pin Setting

Note 1: For connection of other pins, refer to "Table 19-3 Pin Function in the Serial PROM Mode".

19.3.3 Example Connection for On-Board Writing

Figure 19-3 shows an example connection to perform on-board wring.




Figure 19-3 Example Connection for On-Board Writing

- Note 1: When other parts on the application board effect the UART communication in the serial PROM mode, isolate these pins by a jumper or switch.
- Note 2: When the reset control circuit on the application board effects activation of the serial PROM mode, isolate the pin by a jumper or switch.
- Note 3: For connection of other pins, refer to "Table 19-3 Pin Function in the Serial PROM Mode".

19.3.4 Activating the Serial PROM Mode

The following is a procedure to activate the serial PROM mode. "Figure 19-4 Serial PROM Mode Timing" shows a serial PROM mode timing.

- 1. Supply power to the VDD pin.
- 2. Set the \overline{RESET} pin to low.
- 3. Set the TEST pin and BOOT/RXD1 pins to high.
- 4. Wait until the power supply and clock oscillation stabilize.
- 5. Set the \overline{RESET} pin to high.
- 6. Input the matching data (5AH) to the BOOT/RXD1 pin after setup sequence. For details of the setup timing, refer to "19.16 UART Timing".




Figure 19-4 Serial PROM Mode Timing

19.4 Interface Specifications for UART

The following shows the UART communication format used in the serial PROM mode.

To perform on-board programming, the communication format of the write controller must also be set in the same manner.

The default baud rate is 9600 bps regardless of operating frequency of the microcontroller. The baud rate can be modified by transmitting the baud rate modification data shown in Table 19-4 to TMP86FH92DMG. The Table 19-5 shows an operating frequency and baud rate. The frequencies which are not described in Table 19-5 can not be used

- Baud rate (Default): 9600 bps

Data length: 8 bitsParity addition: None

- Stop bit: 1 bit

Table 19-4 Baud Rate Modification Data

Baud rate modification data	04H	05H	06H	07H	0AH	18H	28H
Baud rate (bps)	76800	62500	57600	38400	31250	19200	9600

Table 19-5 Operating Frequency and Baud Rate in the Serial PROM Mode

	Reference	Baud Rate (bps)	768	300	625	500	576	300	384	400	312	250	192	200	96	00
(Note 3)	Baud Rate	Modification Da- ta	04	ŀН	05	iН	06	SH	07	7H	0,4	λH	18H		28H	
(Note 3)	Ref. Frequency (MHz)	Rating (MHz)	Baud rate (bps)	(%)	(bps)	(%)										
1	2	1.91 to 2.10	-	-	-	-	-	-	-	-	-	-	-		9615	+0.16
	4	3.82 to 4.19	-	-	-	-	-	-	-	-	31250	0.00	19231	+0.16	9615	+0.16
2	4.19	3.82 to 4.19	-	-	-	-	-	-	-	-	32734	+4.75	20144	+4.92	10072	+4.92
2	4.9152	4.70 to 5.16	-	-	-	-	-	-	38400	0.00	-	-	19200	0.00	9600	0.00
3	5	4.70 to 5.16	-	-	-	-	-	-	39063	+1.73	-	-	19531	+1.73	9766	+1.73
4	6	5.87 to 6.45	-	-	-	-	-	-	-	-	-	-	-	-	9375	-2.34
4	6.144	5.87 to 6.45	1	ı	1	1	-	ı	ı	-	-	-	-	-	9600	0.00
5	7.3728	7.05 to 7.74	1	1		1	57600	0.00	-	-	-	-	19200	0.00	9600	0.00
6	8	7.64 to 8.39	1	1	62500	0.00	-	1	38462	+0.16	31250	0.00	19231	+0.16	9615	+0.16
7	9.8304	9.40 to 10.32	76800	0.00	-	1	-	1	38400	0.00	-	-	19200	0.00	9600	0.00
,	10	9.40 to 10.32	78125	+1.73	-	1	-	1	39063	+1.73	-	-	19531	+1.73	9766	+1.73
	12	11.75 to 12.90	-	1	-	-	57692	+0.16	-	-	31250	0.00	18750	-2.34	9375	-2.34
8	12.288	11.75 to 12.90	-	1	-	-	59077	+2.56	-	-	32000	+2.40	19200	0.00	9600	0.00
	12.5	11.75 to 12.90	-	-	60096	-3.85	60096	+4.33	-	-	30048	-3.85	19531	+1.73	9766	+1.73
9	14.7456	14.10 to 15.48	-	-	-	-	57600	0.00	38400	0.00	-	-	19200	0.00	9600	0.00
10	16	15.27 to 16.77	76923	+0.16	62500	0.00	-	-	38462	+0.16	31250	0.00	19231	+0.16	9615	+0.16

Note 1: "Ref. Frequency" and "Rating" show frequencies available in the serial PROM mode. Though the frequency is supported in the serial PROM mode, the serial PROM mode may not be activated correctly due to the frequency difference in the external controller (such as personal computer) and oscillator, and load capacitance of communication pins.

Note 2: It is recommended that the total frequency difference is within ±3% so that auto detection is performed correctly by the reference frequency.

Note 3: The external controller must transmit the matching data (5AH) repeatedly till the auto detection of baud rate is performed. This number indicates the number of times the matching data is transmitted for each frequency.

TMP86FH92DMG

19.5 Operation Command

The eight commands shown in Table 19-6 are used in the serial PROM mode. After reset release, the TMP86FH92DMG waits for the matching data (5AH).

Table 19-6 Operation Command in the Serial PROM Mode

Command Data	Operating Mode	Description
5AH	Setup	Matching data. Execute this command after releasing the reset.
F0H	Flash memory erasing	Erases the flash memory area (address C000H to FFFFH).
30H	Flash memory writing	Writes to the flash memory area (address C000H to FFFFH).
60H	RAM loader	Writes to the specified RAM area (address 0050H to 023FH).
90H	Flash memory SUM output	Outputs the 2-byte checksum upper byte and lower byte in this order for the entire area of the flash memory (address C000H to FFFFH).
C0H	Product ID code output	Outputs the product ID code (13-byte data).
СЗН	Flash memory status output	Outputs the status code (7-byte data) such as the security program condition.
FAH	Flash memory security program setting	Enables the security program.

19.6 Operation Mode

The serial PROM mode has seven types of modes, that are (1) Flash memory erasing, (2) Flash memory writing, (3) RAM loader, (4) Flash memory SUM output, (5) Product ID code output, (6) Flash memory status output and (7) Flash memory security program setting modes. Description of each mode is shown below.

1. Flash memory erasing mode

The flash memory is erased by the chip erase (erasing an entire flash area) or sector erase (erasing sectors in 4-kbyte units). The erased area is filled with FFH. When the security program is enabled, the sector erase in the flash erasing mode can not be performed. To disable the security program, perform the chip erase. Before erasing the flash memory, TMP86FH92DMG checks the passwords except a blank product. If the password is not matched, the flash memory erasing mode is not activated.

2. Flash memory writing mode

Data is written to the specified flash memory address for each byte unit. The external controller must transmit the write data in the Intel Hex format (Binary). If no error is encountered till the end record, TMP86FH92DMG calculates the checksum for the entire flash memory area (C000H to FFFFH), and returns the obtained result to the external controller. When the security program is enabled, the flash memory writing mode is not activated. In this case, perform the chip erase command beforehand in the flash memory erasing mode. Before activating the flash memory writing mode, TMP86FH92DMG checks the password except a blank product. If the password is not matched, flash memory writing mode is not activated.

3. RAM loader mode

The RAM loader transfers the data in Intel Hex format sent from the external controller to the internal RAM. When the transfer is completed normally, the RAM loader calculates the checksum. After transmitting the results, the RAM loader jumps to the RAM address specified with the first data record in order to execute the user program. When the security program is enabled, the RAM loader mode is not activated. In this case, perform the chip erase beforehand in the flash memory erasing mode. Before activating the RAM loader mode, TMP86FH92DMG checks the password except a blank product. If the password is not matched, flash RAM loader mode is not activated.

4. Flash memory SUM output mode

The checksum is calculated for the entire flash memory area (C000H to FFFFH), and the result is returned to the external controller. Since the BOOTROM does not support the operation command to read the flash memory, use this checksum to identify programs when managing revisions of application programs.

5. Product ID code output

The code used to identify the product is output. The code to be output consists of 13-byte data, which includes the information indicating the area of the ROM incorporated in the product. The external controller reads this code, and recognizes the product to write.

(In the case of TMP86FH92DMG, the addresses from C000H to FFFFH become the ROM area.)

6. Flash memory status output mode

The status of the area from FFE0H to FFFFH, and the security program condition are output as 7-byte code. The external controller reads this code to recognize the flash memory status.

7. Flash memory security program setting mode

This mode disables reading the flash memory data in parallel PROM mode. In the serial PROM mode, the flash memory writing and RAM loader modes are disabled. To disable the flash memory security program, perform the chip erase in the flash memory erasing mode.

19.6.1 Flash Memory Erasing Mode (Operating command: F0H)

Table 19-7 shows the flash memory erasing mode.

Table 19-7 Flash Memory Erasing Mode

	Transfer Byte	Transfer Data from the External Controller to TMP86FH92DMG	Baud Rate	Transfer Data from TMP86FH92DMG to the External Controller
	1st byte 2nd byte	Matching data (5AH)	9600 bps 9600 bps	- (Automatic baud rate adjustment) OK: Echo back data (5AH) Error: No data transmitted
	3rd byte 4th byte	Baud rate change data (Table 19-4)	9600 bps 9600 bps	- OK: Echo back data Error: A1H × 3, A3H × 3, 62H × 3 (Note 1)
	5th byte 6th byte	Operation command data (F0H)	Modified baud rate Modified baud rate	- OK: Echo back data (F0H) Error: A1H × 3, A3H × 3, 63H × 3 (Note 1)
	7th byte 8th byte	Password count storage address bit 15 to 08 (Note 4, 5)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	9th byte 10th byte	Password count storage address bit 07 to 00 (Note 4, 5)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
BOOT ROM	11th byte 12th byte	Password comparison start address bit 15 to 08 (Note 4, 5)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	13th byte 14th byte	Password comparison start address bit 07 to 00 (Note 4, 5)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	15th byte	Password string (Note 4, 5)	Modified baud rate	-
	m'th byte	-	Modified baud rate	OK: Nothing transmitted Error: Nothing transmitted
	n'th - 2 byte	Erase area specification (Note 2)	Modified baud rate	-
	n'th - 1 byte	-	Modified baud rate	OK: Checksum (Upper byte) (Note 3) Error: Nothing transmitted
	n'th byte	-	Modified baud rate	OK: Checksum (Lower byte) (Note 3) Error: Nothing transmitted
	n'th + 1 byte	(Wait for the next operation command data)	Modified baud rate	-

- Note 1: " $xxH \times 3$ " indicates that the device enters the halt condition after transmitting 3 bytes of xxh.
- Note 2: Refer to "19.13 Specifying the Erasure Area".
- Note 3: Refer to "19.8 Checksum (SUM)".
- Note 4: Refer to "19.10 Passwords".
- Note 5: Do not transmit the password string for a blank product.
- Note 6: When a password error occurs, TMP86FH92DMG stops UART communication and enters the halt mode. Therefore, when a password error occurs, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.
- Note 7: If an error occurs during transfer of a password address or a password string, TMP86FH92DMG stops UART communication and enters the halt condition. Therefore, when a password error occurs, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.

Description of the flash memory erasing mode

- 1. The 1st through 4th bytes of the transmitted and received data contain the same data as in the flash memory writing mode.
- 2. The 5th byte of the received data contains the command data in the flash memory erasing mode (F0H).
- 3. When the 5th byte of the received data contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position of the received data (in this case, F0H). If the 5th byte of the received data does not contain the operation command data, the device enters the halt condition after sending 3 bytes of the operation command error code (63H).
- 4. The 7th thorough m'th bytes of the transmitted and received data contain the same data as in the flash memory writing mode. In the case of a blank product, do not transmit a password string. (Do not transmit a dummy password string.)
- 5. The n'th 2 byte contains the erasure area specification data. The upper 4 bits and lower 4 bits specify the start address and end address of the erasure area, respectively. For the detailed description, see "19.13 Specifying the Erasure Area".
- 6. The n'th 1 byte and n'th byte contain the upper and lower bytes of the checksum, respectively. For how to calculate the checksum, refer to "19.8 Checksum (SUM)". Checksum is calculated unless a receiving error or Intel Hex format error occurs. After sending the end record, the external controller judges whether the transmission is completed correctly by receiving the checksum sent by the device.
- 7. After sending the checksum, the device waits for the next operation command data.

19.6.2 Flash Memory Writing Mode (Operation command: 30H)

Table 19-8 shows flash memory writing mode process.

Table 19-8 Flash Memory Writing Mode Process

	Transfer Byte	Transfer Data from External Controller to TMP86FH92DMG	Baud Rate	Transfer Data from TMP86FH92DMG to External Controller
	1st byte 2nd byte	Matching data (5Ah)	9600 bps 9600 bps	- (Automatic baud rate adjustment) OK: Echo back data (5AH) Error: Nothing transmitted
	3rd byte 4th byte	Baud rate modification data (See Table 19-4)	9600 bps 9600 bps	- OK: Echo back data Error: A1H × 3, A3H × 3, 62H × 3 (Note 1)
	5th byte 6th byte	Operation command data (30H)	Modified baud rate Modified baud rate	- OK: Echo back data (30H) Error: A1H × 3, A3H × 3, 63H × 3 (Note 1)
	7th byte 8th byte	Password count storage address bit 15 to 08 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	9th byte 10th byte	Password count storage address bit 07 to 00 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
BOOT ROM	11th byte 12th byte	Password comparison start address bit 15 to 08 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	13th byte 14th byte	Password comparison start address bit 07 to 00 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	15th byte	Password string (Note 5)	Modified baud rate	-
	m'th byte	-		OK: Nothing transmitted Error: Nothing transmitted
	m'th + 1 byte : n'th - 2 byte	Intel Hex format (binary) (Note 2)	Modified baud rate	-
	n'th - 1 byte	-	Modified baud rate	OK: SUM (Upper byte) (Note 3) Error: Nothing transmitted
	n'th byte	-	Modified baud rate	OK: SUM (Lower byte) (Note 3) Error: Nothing transmitted
	n'th + 1 byte	(Wait state for the next operation command data)	Modified baud rate	-

- Note 1: "xxH × 3" indicates that the device enters the halt condition after sending 3 bytes of xxH. For details, refer to "19.7 Error Code".
- Note 2: Refer to "19.9 Intel Hex Format (Binary)".
- Note 3: Refer to "19.8 Checksum (SUM)".
- Note 4: Refer to "19.10 Passwords".
- Note 5: If addresses from FFE0H to FFFFH are filled with "FFH", the passwords are not compared because the device is considered as a blank product. Transmitting a password string is not required. Even in the case of a blank product, it is required to specify the password count storage address and the password comparison start address. Transmit these data from the external controller. If a password error occurs due to incorrect password count storage address or password comparison start address, TMP86FH92DMG stops UART communication and enters the halt condition. Therefore, when a password error occurs, initialize TMP86FH92DMG by the RESET pin and reactivate the serial ROM mode.
- Note 6: If the security program is enabled or a password error occurs, TMP86FH92DMG stops UART communication and enters the halt condition. In this case, initialize TMP86FH92DMG by the RESET pin and reactivate the serial ROM mode.

- Note 7: If an error occurs during the reception of a password address or a password string, TMP86FH92DMG stops UART communication and enters the halt condition. In this case, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.
- Note 8: Do not write only the address from FFE0H to FFFFH when all flash memory data is the same. If only these area are written, the subsequent operation can not be executed due to password error.
- Note 9: To rewrite data to Flash memory addresses at which data (including FFH) is already written, make sure to erase the existing data by "sector erase" or "chip erase" before rewriting data.

Description of the flash memory writing mode

- 1. The 1st byte of the received data contains the matching data. When the serial PROM mode is activated, TMP86FH92DMG (hereafter called device), waits to receive the matching data (5AH). Upon reception of the matching data, the device automatically adjusts the UART's initial baud rate to 9600 bps.
- 2. When receiving the matching data (5AH), the device transmits an echo back data (5AH) as the second byte data to the external controller. If the device can not recognize the matching data, it does not transmit the echo back data and waits for the matching data again with automatic baud rate adjustment. Therefore, the external controller should transmit the matching data repeatedly till the device transmits an echo back data. The transmission repetition count varies depending on the frequency of device. For details, refer to Table 19-5.
- 3. The 3rd byte of the received data contains the baud rate modification data. The five types of baud rate modification data shown in Table 19-4 are available. Even if baud rate is not modified, the external controller should transmit the initial baud rate data (28H: 9600 bps).
- 4. Only when the 3rd byte of the received data contains the baud rate modification data corresponding to the device's operating frequency, the device echoes back data the value which is the same data in the 4th byte position of the received data. After the echo back data is transmitted, baud rate modification becomes effective. If the 3rd byte of the received data does not contain the baud rate modification data, the device enters the halts condition after sending 3 bytes of baud rate modification error code (62H).
- 5. The 5th byte of the received data contains the command data (30H) to write the flash memory.
- 6. When the 5th byte of the received data contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position of the received data (in this case, 30H). If the 5th byte of the received data does not contain the operation command data, the device enters the halt condition after sending 3 bytes of the operation command error code (63H).
- 7. The 7th byte contains the data for 15 to 8 bits of the password count storage address. When the data received with the 7th byte has no receiving error, the device does not send any data. If a receiving error or password error occurs, the device does not send any data and enters the halt condition.
- 8. The 9th byte contains the data for 7 to 0 bits of the password count storage address. When the data received with the 9th byte has no receiving error, the device does not send any data. If a receiving error or password error occurs, the device does not send any data and enters the halt condition.
- 9. The 11th byte contains the data for 15 to 8 bits of the password comparison start address. When the data received with the 11th byte has no receiving error, the device does not send any data. If a receiving error or password error occurs, the device does not send any data and enters the halt condition.
- 10. The 13th byte contains the data for 7 to 0 bits of the password comparison start address. When the data received with the 13th byte has no receiving error, the device does not send any data. If a receiving error or password error occurs, the device does not send any data and enters the halt condition.
- 11. The 15th through m'th bytes contain the password data. The number of passwords becomes the data (N) stored in the password count storage address. The external password data is compared with N-byte data from the address specified by the password comparison start address. The external controller should send N-byte password data to the device. If the passwords do not match, the device enters the halt condition without returning an error code to the external controller. If the addresses from FFE0H to FFFFH are filled with "FFH", the passwords are not compared because the device is considered as a blank product.
- 12. The m'th + 1 through n'th 2 bytes of the received data contain the binary data in the Intel Hex format. No received data is echoed back to the external controller. After receiving the start mark (3AH for ":") in the Intel Hex format, the device starts data record reception. Therefore, the received data except 3AH is ignored until the start mark is received. After receiving the start mark, the device receives the data record, that consists of data length, address, record type, write data and checksum. Since the device

19.6 Operation Mode TMP86FH92DMG

starts checksum calculation after receiving an end record, the external controller should wait for the checksum after sending the end record. If a receiving error or Intel Hex format error occurs, the device enters the halts condition without returning an error code to the external controller.

- 13. The n'th 1 and n'th bytes contain the checksum upper and lower bytes. For details on how to calculate the SUM, refer to "19.8 Checksum (SUM)". The checksum is calculated only when the end record is detected and no receiving error or Intel Hex format error occurs. After sending the end record, the external controller judges whether the transmission is completed correctly by receiving the checksum sent by the device.
- 14. After transmitting the checksum, the device waits for the next operation command data.

19.6.3 RAM Loader Mode (Operation Command: 60H)

Table 19-9 shows RAM loader mode process.

Table 19-9 RAM Loader Mode Process

	Transfer Bytes	Transfer Data from External Controller to TMP86FH92DMG	Baud Rate	Transfer Data from TMP86FH92DMG to External Controller
	1st byte 2nd byte	Matching data (5AH)	9600 bps 9600 bps	- (Automatic baud rate adjustment) OK: Echo back data (5AH) Error: Nothing transmitted
	3rd byte	Baud rate modification data (See Table 19-4)	9600 bps	-
	4th byte	-	9600 bps	OK: Echo back data Error: A1H × 3, A3H × 3, 62H × 3 (Note 1)
	5th byte 6th byte	Operation command data (60H)	Modified baud rate Modified baud rate	- OK: Echo back data (60H) Error: A1H × 3, A3H × 3, 63H × 3 (Note 1)
	7th byte 8th byte	Password count storage address bit 15 to 08 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	9th byte 10th byte	Password count storage address bit 07 to 00 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
BOOT ROM	11th byte 12th byte	Password comparison start address bit 15 to 08 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	13th byte 14th byte	Password comparison start address bit 07 to 00 (Note 4)	Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	15th byte	Password string (Note 5)	Modified baud rate	-
	m'th byte	-		OK: Nothing transmitted Error: Nothing transmitted
	m'th + 1 byte :	Intel Hex format (Binary) (Note 2)	Modified baud rate	-
	n'th - 2 byte		Modified baud rate	-
	n'th - 1 byte	-	Modified baud rate	OK: SUM (Upper byte) (Note 3) Error: Nothing transmitted
	n'th byte	-	Modified baud rate	OK: SUM (Lower byte) (Note 3) Error: Nothing transmitted
RAM	-	The program jumps to the start address	of RAM in which the first transfe	erred data is written.

- Note 1: "xxH × 3" indicates that the device enters the halt condition after sending 3 bytes of xxH. For details, refer to "19.7 Error Code".
- Note 2: Refer to "19.9 Intel Hex Format (Binary)".
- Note 3: Refer to "19.8 Checksum (SUM)".
- Note 4: Refer to "19.10 Passwords".
- Note 5: If addresses from FFE0H to FFFFH are filled with "FFH", the passwords are not compared because the device is considered as a blank product. Transmitting a password string is not required. Even in the case of a blank product, it is required to specify the password count storage address and the password comparison start address. Transmit these data from the external controller. If a password error occurs due to incorrect password count storage address or password comparison start address, TMP86FH92DMG stops UART communication and enters the halt condition. Therefore, when a password error occurs, initialize TMP86FH92DMG by the RESET pin and reactivate the serial ROM mode.
- Note 6: After transmitting a password string, the external controller must not transmit only an end record. If receiving an end record after a password string, the device may not operate correctly.
- Note 7: If the security program is enabled or a password error occurs, TMP86FH92DMG stops UART communication and enters the halt condition. In this case, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.

S Operation Mode TMP86FH92DMG

Note 8: If an error occurs during the reception of a password address or a password string, TMP86FH92DMG stops UART communication and enters the halt condition. In this case, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.

Note 9: To rewrite data to Flash memory addresses at which data (including FFH) is already written, make sure to erase the existing data by "sector erase" or "chip erase" before rewriting data.

Description of RAM loader mode

- 1. The 1st through 4th bytes of the transmitted and received data contains the same data as in the flash memory writing mode.
- 2. In the 5th byte of the received data contains the RAM loader command data (60H).
- 3. When the 5th byte of the received data contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position (in this case, 60H). If the 5th byte does not contain the operation command data, the device enters the halt condition after sending 3 bytes of operation command error code (63H).
- 4. The 7th through m'th bytes of the transmitted and received data contain the same data as in the flash memory writing mode.
- 5. The m'th + 1 through n'th 2 bytes of the received data contain the binary data in the Intel Hex format. No received data is echoed back to the external controller. After receiving the start mark (3AH for ":") in the Intel Hex format, the device starts data record reception. Therefore, the received data except 3AH is ignored until the start mark is received. After receiving the start mark, the device receives the data record, that consists of data length, address, record type, write data and checksum. The writing data of the data record is written into RAM specified by address. Since the device starts checksum calculation after receiving an end record, the external controller should wait for the checksum after sending the end record. If a receiving error or Intel Hex format error occurs, the device enters the halts condition without returning an error code to the external controller.
- 6. The n'th 1 and n'th bytes contain the checksum upper and lower bytes. For details on how to calculate the SUM, refer to "19.8 Checksum (SUM)". The checksum is calculated only when the end record is detected and no receiving error or Intel Hex format error occurs. After sending the end record, the external controller judges whether the transmission is completed correctly by receiving the checksum sent by the device.
- 7. After transmitting the checksum to the external controller, the boot program jumps to the RAM address that is specified by the first received data record.

19.6.4 Flash Memory SUM Output Mode (Operation Command: 90H)

Table 19-10 shows flash memory SUM output mode process.

Table 19-10 Flash Memory SUM Output Process

	Transfer Bytes	Transfer Data from External Control- ler to TMP86FH92DMG	Baud Rate	Transfer Data from TMP86FH92DMG to External Controller
	1st byte 2nd byte	Matching data (5AH)	9600 bps 9600 bps	- (Automatic baud rate adjustment) OK: Echo back data (5AH) Error: Nothing transmitted
	3rd byte	Baud rate modification data (See Table 19-4)	9600 bps	-
	4th byte	-	9600 bps	OK: Echo back data Error: A1H × 3, A3H × 3, 62H × 3 (Note 1)
BOOT ROM	5th byte 6th byte	Operation command data (90H)	Modified baud rate Modified baud rate	- OK: Echo back data (90H) Error: A1H × 3, A3H × 3, 63H × 3 (Note 1)
	7th byte	-	Modified baud rate	OK: SUM (Upper byte) (Note 2) Error: Nothing transmitted
	8th byte	-	Modified baud rate	OK: SUM (Lower byte) (Note 2) Error: Nothing transmitted
	9th byte	(Wait for the next operation command data)	Modified baud rate	-

Note 1: "xxH × 3" indicates that the device enters the halt condition after sending 3 bytes of xxH. For details, refer to "19.7 Error Code".

Note 2: Refer to "19.8 Checksum (SUM)".

Description of the flash memory SUM output mode

- 1. The 1st through 4th bytes of the transmitted and received data contains the same data as in the flash memory writing mode.
- 2. The 5th byte of the received data contains the command data in the flash memory SUM output mode (90H).
- 3. When the 5th byte of the received data contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position of the received data (in this case, 90H). If the 5th byte of the received data does not contain the operation command data, the device enters the halt condition after transmitting 3 bytes of operation command error code (63H).
- 4. The 7th and the 8th bytes contain the upper and lower bits of the checksum, respectively. For how to calculate the checksum, refer to "19.8 Checksum (SUM)".
- 5. After sending the checksum, the device waits for the next operation command data.

TMP86FH92DMG

19.6.5 Product ID Code Output Mode (Operation Command: C0H)

Table 19-11 shows product ID code output mode process.

Table 19-11 Product ID Code Output Process

	Transfer Bytes	Transfer Data from External Controller to TMP86FH92DMG	Baud Rate	Transfe	r Data from TMP86FH92DMG to External Controller
	1st byte 2nd byte	Matching data (5AH)	9600 bps 9600 bps	OK: Ech	atic baud rate adjustment) o back data (5AH) othing transmitted
	3rd byte	Baud rate modification data (See Table 19-4)	9600 bps	-	
	4th byte	-	9600 bps	1	o back data H × 3, A3H × 3, 62H × 3 (Note 1)
	5th byte	Operation command data (C0H)	Modified baud rate	-	
	6th byte	-	Modified baud rate		o back data (C0H) H × 3, A3H × 3, 63H × 3 (Note 1)
	7th byte		Modified baud rate	3AH	Start mark
	8th byte		Modified baud rate	0AH	The number of transfer data (from 9th to 18th bytes)
	9th byte		Modified baud rate	02H	Length of address (2 bytes)
	10th byte		Modified baud rate	1DH	Reserved data
BOOT	11th byte		Modified baud rate	00H	Reserved data
ROM	12th byte		Modified baud rate	00H	Reserved data
	13th byte		Modified baud rate	00H	Reserved data
	14th byte		Modified baud rate	01H	ROM block count (1 block)
	15th byte		Modified baud rate	СОН	First address of ROM (Upper byte)
	16th byte		Modified baud rate	00H	First address of ROM (Lower byte)
	17th byte		Modified baud rate	FFH	End address of ROM (Upper byte)
	18th byte		Modified baud rate	FFH	End address of ROM (Lower byte)
	19th byte		Modified baud rate	22H	Checksum of transferred data (9th through 18th byte)
	20th byte	(Wait for the next operation command data)	Modified baud rate	-	

Note: " $xxH \times 3$ " indicates that the device enters the halt condition after sending 3 bytes of xxH. For details, refer to "19.7 Error Code".

Description of Product ID code output mode

- 1. The 1st through 4th bytes of the transmitted and received data contain the same data as in the flash memory writing mode.
- 2. The 5th byte of the received data contains the product ID code output mode command data (C0H).
- 3. When the 5th byte contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position of the received data (in this case, C0H). If the 5th byte data does not contain the operation command data, the device enters the halt condition after sending 3 bytes of operation command error code (63H).
- 4. The 9th through 19th bytes contain the product ID code. For details, refer to "19.11 Product ID Code".
- 5. After sending the checksum, the device waits for the next operation command data.

19.6.6 Flash Memory Status Output Mode (Operation Command: C3H)

Table 19-12 shows Flash memory status output mode process.

Table 19-12 Flash Memory Status Output Mode Process

	Transfer Bytes	Transfer Data from External Controller to TMP86FH92DMG	Baud Rate	Transfe	er Data from TMP86FH92DMG to Ex- ternal Controller		
	1st byte 2nd byte	Matching data (5AH)	9600 bps 9600 bps	OK: Ech	- (Automatic baud rate adjustment) OK: Echo back data (5AH) Error: Nothing transmitted		
	3rd byte	Baud rate modification data (See Table 19-4)	9600 bps	-			
	4th byte	-	9600 bps		no back data 1H × 3, A3H × 3, 62H × 3 (Note 1)		
	5th byte 6th byte	Operation command data (C3H)	Modified baud rate Modified baud rate	1	no back data (C3H) 1H × 3, A3H × 3, 63H × 3 (Note 1)		
	7th byte		Modified baud rate	3AH	Start mark		
	8th byte		Modified baud rate	04H	Byte count (from 9th to 12th byte)		
BOOT ROM	9th byte		Modified baud rate	00H to 03H	Status code 1		
	10th byte		Modified baud rate	00H	Reserved data		
	11th byte		Modified baud rate	00H	Reserved data		
	12th byte		Modified baud rate	00H	Reserved data		
	13th byte		Modified baud rate	Checksum 2's complement for the sum through 12th bytes 9th byte Checksum 00H: 00H 01H: FFH 02H: FEH 03H: FDH			
	14th byte	(Wait for the next operation command data)	Modified baud rate	-			

Note 1: "xxH × 3" indicates that the device enters the halt condition after sending 3 bytes of xxH. For details, refer to "19.7 Error Code".

Note 2: For the details on status code 1, refer to "19.12 Flash Memory Status Code".

Description of Flash memory status output mode

- 1. The 1st through 4th bytes of the transmitted and received data contain the same data as in the Flash memory writing mode.
- 2. The 5th byte of the received data contains the flash memory status output mode command data (C3H).
- 3. When the 5th byte contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position of the received data (in this case, C3H). If the 5th byte does not contain the operation command data, the device enters the halt condition after sending 3 bytes of operation command error code (63H).
- 4. The 9th through 13th bytes contain the status code. For details on the status code, refer to "19.12 Flash Memory Status Code".
- 5. After sending the status code, the device waits for the next operation command data.

TMP86FH92DMG

19.6.7 Flash Memory security program Setting Mode (Operation Command: FAH)

Table 19-13 shows Flash memory security program setting mode process.

Table 19-13 Flash Memory security program Setting Mode Process

	Transfer Bytes	Transfer Data from External Control- ler to TMP86FH92DMG	Baud Rate	Transfer Data from TMP86FH92DMG to External Controller
	1st byte 2nd byte	Matching data (5AH) -	9600 bps 9600 bps	- (Automatic baud rate adjustment) OK: Echo back data (5AH) Error: Nothing transmitted
	3rd byte 4th byte	Baud rate modification data (See Table 19-4)	9600 bps 9600 bps	- OK: Echo back data
	2710		2000 200	Error: A1H × 3, A3H × 3, 62H × 3 (Note 1)
	5th byte 6th byte	Operation command data (FAH)	Modified baud rate Modified baud rate	- OK: Echo back data (FAH) Error: A1H × 3, A3H × 3, 63H × 3 (Note 1)
	7th byte 8th byte	Password count storage address 15 to 08 (Note 2)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
BOOT ROM	9th byte 10th byte	Password count storage address 07 to 00 (Note 2)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	11th byte 12th byte	Password comparison start address 15 to 08 (Note 2)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	13th byte 14th byte	Password comparison start address 07 to 00 (Note 2)	Modified baud rate Modified baud rate	- OK: Nothing transmitted Error: Nothing transmitted
	15th byte	Password string (Note 2)	Modified baud rate	-
	: m'th byte	-	Modified baud rate	OK: Nothing transmitted Error: Nothing transmitted
	n'th byte	-	Modified baud rate	OK: FBH (Note 3) Error: Nothing transmitted
	n'+1th byte	(Wait for the next operation command data)	Modified baud rate	-

- Note 1: "xxH × 3" indicates that the device enters the halt condition after sending 3 bytes of xxH. For details, refer to "19.7 Error Code".
- Note 2: Refer to "19.10 Passwords".
- Note 3: If the security program is enabled for a blank product or a password error occurs for a non-blank product, TMP86FH92DMG stops UART communication and enters the halt mode. In this case, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.
- Note 4: If an error occurs during reception of a password address or a password string, TMP86FH92DMG stops UART communication and enters the halt mode. In this case, initialize TMP86FH92DMG by the RESET pin and reactivate the serial PROM mode.

Description of the Flash memory security program setting mode

- 1. The 1st through 4th bytes of the transmitted and received data contain the same data as in the Flash memory writing mode.
- 2. The 5th byte of the received data contains the command data in the flash memory status output mode (FAH).

- 3. When the 5th byte of the received data contains the operation command data shown in Table 19-6, the device echoes back the value which is the same data in the 6th byte position of the received data (in this case, FAH). If the 5th byte does not contain the operation command data, the device enters the halt condition after transmitting 3 bytes of operation command error code (63H).
- 4. The 7th through m'th bytes of the transmitted and received data contain the same data as in the flash memory writing mode.
- 5. The n'th byte contains the status to be transmitted to the external controller in the case of the successful security program.

19.7 Error Code TMP86FH92DMG

19.7 Error Code

When detecting an error, the device transmits the error code to the external controller, as shown in Table 19-14.

Table 19-14 Error Code

Transmit Data	Meaning of Error Data
62H, 62H, 62H	Baud rate modification error.
63H, 63H, 63H	Operation command error.
A1H, A1H, A1H	Framing error in the received data.
A3H, A3H, A3H	Overrun error in the received data.

Note: If a password error occurs, TMP86FH92DMG does not transmit an error code.


19.8 Checksum (SUM)

19.8.1 Calculation Method

The checksum (SUM) is calculated with the sum of all bytes, and the obtained result is returned as a word.

The data is read for each byte unit and the calculated result is returned as a word.

Example:



The checksum which is transmitted by executing the flash memory write command, RAM loader command, or flash memory SUM output command is calculated in the manner, as shown above.

19.8.2 Calculation data

The data used to calculate the checksum is listed in Table 19-15.

Table 19-15 Checksum Calculation Data

Operating Mode	Calculation Data	Description		
Flash memory writing mode		Even when a part of the flash memory is written, the checksum		
Flash memory SUM output mode	Data in the entire area of the flash memory	of the entire flash memory area (C000H to FFFH) is calculated. The data length, address, record type and checksum in Intel Hex format are not included in the checksum.		
RAM loader mode	RAM data written in the first received RAM address through the last received RAM address	The length of data, address, record type and checksum in Intel Hex format are not included in the checksum.		
Product ID Code output mode	9th through 18th bytes of the transferred data	For details, refer to "19.11 Product ID Code".		
Flash Memory Status Output mode	9th through 12th bytes of the transferred data	For details, refer to "19.12 Flash Memory Status Code"		
Flash Memory Erasing mode	All data in the erased area of the flash memory (the whole or part of the flash memory)	When the sector erase is executed, only the erased area is used to calculate the checksum. In the case of the chip erase, an entire area of the flash memory is used.		

19.9 Intel Hex Format (Binary)

- 1. After receiving the checksum of a data record, the device waits for the start mark (3AH ":") of the next data record. After receiving the checksum of a data record, the device ignores the data except 3AH transmitted by the external controller.
- 2. After transmitting the checksum of end record, the external controller must transmit nothing, and wait for the 2-byte receive data (upper and lower bytes of the checksum).
- 3. If a receiving error or Intel Hex format error occurs, the device enters the halt condition without returning an error code to the external controller. The Intel Hex format error occurs in the following case:

When the record type is not 00H, 01H, or 02H

When a checksum error occurs

When the data length of an extended record (record type = 02H) is not 02H

When the device receives the data record after receiving an extended record (record type = 02H) with extended address of 1000H or larger.

When the data length of the end record (record type = 01H) is not 00H

19.10 Passwords

The consecutive eight or more-byte data in the flash memory area can be specified to the password. TMP86FH92DMG compares the data string specified to the password with the password string transmitted from the external controller. The area in which passwords can be specified is located at addresses C000H to FF9FH. The area from FFA0H to FFFFH can not be specified as the passwords area.

If addresses from FFE0H through FFFFH are filled with "FFH", the passwords are not compared because the product is considered as a blank product. Even in this case, the password count storage addresses and password comparison start address must be specified. Table 19-16 shows the password setting in the blank product and non-blank product.

Table 19-16 Password Setting in the Blank Product and Non-Blank Product

Password	Blank Product (Note 1)	Non-Blank Product
PNSA (Password count storage address)	C000H ≤ PNSA ≤ FF9FH	C000H ≤ PNSA ≤ FF9FH
PCSA (Password comparison start address)	C000H ≤ PCSA ≤ FF9FH	C000H ≤ PCSA ≤ FFA0 - N
N (Password count)	*	8 ≤ N
Password string setting	Not required (Note 5)	Required (Note 2)

- Note 1: When addresses from FFE0H through FFFFH are filled with "FFH", the product is recognized as a blank product.
- Note 2: The data including the same consecutive data (three or more bytes) can not be used as a password. (This causes a password error data. TMP86FH92DMG transmits no data and enters the halt condition.)
- Note 3: *: Don't care.
- Note 4: When the above condition is not met, a password error occurs. If a password error occurs, the device enters the halt condition without returning the error code.
- Note 5: In the flash memory writing mode or RAM loader mode, the blank product receives the Intel Hex format data immediately after receiving PCSA without receiving password strings. In this case, the subsequent processing is performed correctly because the blank product ignores the data except the start mark (3AH ":") as the Intel Hex format data, even if the external controller transmits the dummy password string. However, if the dummy password string contains "3AH", it is detected as the start mark erroneously. The microcontroller enters the halt mode. If this causes the problem, do not transmit the dummy password strings.
- Note 6: In the flash memory erasing mode, the external controller must not transmit the password string for the blank product.




Figure 19-5 Password Comparison

19.10.1 Password String

The password string transmitted from the external controller is compared with the specified data in the flash memory. When the password string is not matched to the data in the flash memory, the device enters the halt condition due to the password error.

19.10.2 Handling of Password Error

If a password error occurs, the device enters the halt condition. In this case, reset the device to reactivate the serial PROM mode.

19.10.3 Password Management during Program Development

If a program is modified many times in the development stage, confusion may arise as to the password. Therefore, it is recommended to use a fixed password in the program development stage.

Example :Specify PNSA to F000H, and the password string to 8 bytes from address F001H (PCSA becomes F001H.)

Password Section code abs = 0F000H

DB 08H : PNSA definition

DB "CODE1234" : Password string definition

19.11 Product ID Code

The product ID code is the 13-byte data containing the start address and the end address of ROM. Table 19-17 shows the product ID code format.

Table 19-17 Product ID Code Format

Data	Description	In the Case of TMP86FH92DMG
1st	Start Mark (3AH)	зан
2nd	The number of transfer data (10 bytes from 3rd to 12th byte)	0AH
3rd	Address length (2 bytes)	02H
4th	Reserved data	1DH
5th	Reserved data	00H
6th	Reserved data	00H
7th	Reserved data	00H
8th	ROM block count	01H
9th	The first address of ROM (Upper byte)	C0H
10th	The first address of ROM (Lower byte)	00H
11th	The end address of ROM (Upper byte)	FFH
12th	The end address of ROM (Lower byte)	FFH
13th	Checksum of the transferred data (2's compliment for the sum of 3rd through 12th bytes)	22H

19.12 Flash Memory Status Code

The flash memory status code is the 7-byte data including the security program status and the status of the data from FFE0H to FFFFH. Table 19-18 shows the flash memory status code.

Table 19-18 Flash Memory Status Code

Data	Description	In the Case of TMP86FH92DMG		
1st	Start mark	3.4	АН	
2nd	Transferred data count (3rd through 6th byte)	04	ŧН	
3rd	Status code	00H to 03H (See figure below)		
4th	Reserved data	Reserved data 00H		
5th	Reserved data	00H		
6th	Reserved data	00)H	
7th	Checksum of the transferred data (2's compliment for the sum of 3rd through 6th data)	3rd byte 00H 01H 02H 03H	checksum 00H FFH FEH FDH	

Status Code 1



RPENA	Flash memory security program status 0:		Security program is disabled. Security program is enabled.
BLANK	The status from FFE0H to FFFFH.	0: 1:	All data is FFH in the area from FFE0H to FFFFH. The value except FFH is included in the area from FFE0H to FFFFH.

Some operation commands are limited by the flash memory status code 1. If the security program is enabled, flash memory writing mode command and RAM loader mode command can not be executed. Erase all flash memory before executing these command.

RPENA	BLANK	Flash Memory	RAM Loader	Flash memory SUM	Product ID Code	Flash Memory Status Output		Memory g Mode	Security pro- gram Setting	
INI LIVA	DEANK	Writing Mode	Mode	Output Mode	Output Mode	Mode Mode	Chip Erase	Sector Erase	Mode	
0	0	0	0	0	0	0	()	×	
0	1	Pass	Pass	0	0	0	Pa	ass	Pass	
1	0	×	×	0	0	0	0	×	×	
1	1	×	×	0	0	0	Pass	×	Pass	

Note: O: The command can be executed.

Pass: The command can be executed with a password.

×: The command can not be executed.

(After echoing the command back to the external controller, TMP86FH92DMG stops UART communication and enters the halt condition.)

19.13 Specifying the Erasure Area

In the flash memory erasing mode, the erasure area of the flash memory is specified by n-2 byte data.

The start address of an erasure area is specified by ERASTA, and the end address is specified by ERAEND.

If ERASTA is equal to or smaller than ERAEND, the sector erase (erasure in 4 kbyte units) is executed. Executing the sector erase while the security program is enabled results in an infinite loop.

If ERASTA is larger than ERAEND, the chip erase (erasure of an entire flash memory area) is executed and the security program is disabled. Therefore, execute the chip erase (not sector erase) to disable the security program.

Erasure Area Specification Data (n-2 byte data)

7	6	5	4	3	2	1	0
	ERA	STA			ERA	END	

		0000:	from 0000H
	The start address of the	0001:	from 1000H
		0010:	from 2000H
		0011:	from 3000H
		0100:	from 4000H
		0101:	from 5000H
		0110:	from 6000H
ERASTA		0111:	from 7000H
ERASTA		1000:	from 8000H
		1001:	from 9000H
		1010:	from A000H
		1011:	from B000H
		1100:	from C000H
		1101:	from D000H
		1110:	from E000H
		1111:	from F000H
		0000:	to 0FFFH
		0001:	to 1FFFH
		0010:	to 2FFFH
		0011:	to 3FFFH
		0100:	to 4FFFH
		0101:	to 5FFFH
		0110:	to 6FFFH
ERAEND	The end address of the	0111:	to 7FFFH
ERAEND	erasure area	1000:	to 8FFFH
		1001:	to 9FFFH
		1010:	to AFFFH
		1011:	to BFFFH
		1100:	to CFFFH
		1101:	to DFFFH
		1110:	to EFFFH
		1111:	to FFFFH
·	·		


Note: When the sector erase is executed for the area containing no flash cell, TMP86FH92DMG stops the UART communication and enters the halt condition.

19.14 Port Input Control Register

In the serial PROM mode, the input level is fixed to the all ports except P00 and P01 ports with a hardware feature to prevent overlap current to unused ports. (All port inputs and peripheral function inputs shared with the ports become invalid.) Therefore, to access to the flash memory in the RAM loader mode without UART communication, port inputs must be valid. To make port inputs valid, set the pin of the port input control register (SPCR) to "1".

The SPCR register is not operated in the MCU mode.


Port Input Control Register



Note 1: The SPCR register can be read or written only in the serial PROM mode. When the write instruction is executed to the SPCR register in the MCU mode, the port input control can not be performed. When the read instruction is executed for the SPCR register in the MCU mode, read data of bit7 to 1 are unstable.

Note 2: All I/O ports except P00 and P01 ports are controlled by the SPCR register.

19.15 Flowchart




19.16 UART Timing

Table 19-19 UART Timing-1 (VDD = 4.5 to 5.5 V, fc = 2 to 16 MHz, Topr = -10 to 40°C)

Descriptor	O. made al	Clash Francisco (fa)	Minimum Required Time		
Parameter	Symbol	Clock Frequency (fc)	At fc = 2 MHz	At fc = 16 MHz	
Time from matching data reception to the echo back	CMeb1	Approx. 930	465 µs	58.1 µs	
Time from baud rate modification data reception to the echo back	CMeb2	Approx. 980	490 μs	61.3 µs	
Time from operation command reception to the echo back	CMeb3	Approx. 800	400 μs	50 µs	
Checksum calculation time	CKsm	Approx. 7864500	3.93 s	491.5 µs	
Erasure time of an entire flash memory	CEall	-	30 ms	30 ms	
Erasure time for a sector of a flash memory (in 4-kbyte units)	CEsec	-	15 ms	15 ms	

Table 19-20 UART Timing-2 (VDD = 4.5 to 5.5 V, fc = 2 to 16 MHz, Topr = -10 to 40°C)

Description	0	Obel Francis (fa)	Minimum Required Time		
Parameter	Symbol	Clock Frequency (fc)	At fc = 2 MHz	At fc = 16 MHz	
Time from the reset release to the acceptance of start bit of RXD pin	RXsup	2100	1.05 ms	131.3 ms	
Matching data transmission interval	CMtr1	28500	14.2 ms	1.78 ms	
Time from the echo back of matching data to the acceptance of baud rate modification data	CMtr2	380	190 µs	23.8 µs	
Time from the echo back of baud rate modification data to the acceptance of an operation command	CMtr3	650	325 µs	40.6 µs	
Time from the echo back of operation command to the acceptance of password count storage addresses (Upper byte)	CMtr4	800	400 μs	50 µs	



19. Serial PROM Mode19.16 UART Timing

16 UART Timing TMP86FH92DMG

TOSHIBA TMP86FH92DMG

20. Input/Output Circuitry

20.1 Control Pins


The input/output circuitries of the TMP86FH92DMG control pins are shown delow.

Control Pin	I/O	Input/Output Circuitry	Remarks
XIN XOUT	Input Output	Osc.enable VDD Rf VDD Rf XIN XOUT	Resonator connecting pins $R_f = 1.5 \ M\Omega \ (typ.)$ $R_O = 0.5 \ k\Omega \ (typ.)$
XTIN XTOUT	Input Output	Osc.enable XTEN VDD Rf Ro VDD XTIN XTOUT	Resonator connecting R_f = 8 $M\Omega$ (typ.) R_O = 200 $k\Omega$ (typ.)
RESET	Input	Reset input Address trap reset Watchdog timer reset System clock reset Voltage detection1 reset Voltage detection2 reset Triming data reset Power on reset	Hysteresis input Pull-up resistor $R_{IN} = 220 \text{ k}\Omega \text{ (typ.)}$ $R = 100 \Omega \text{ (typ.)}$
TEST	Input	- R - D	R = 100 Ω (typ.)

Note: The Test pins of TMP86FH92DMG does not have a pull-down resistor and diode(D1). Fix the TEST pin at Low level in MCU mode.

20.2 Input/Output Ports

Control Pin	I/O	Input/Output Circuitry	Remarks
P0	I/O	Initial "High-Z" Programmable pull-up resistor Pull-up control Pch control Data output Input from output latch High-Z control Pin input	Sink open drain output or Push-Pull output Hysteresis input High current output (Nch) (Programmable port option) $R = 100 \ \Omega \ (typ.)$ $R_{IN} = 100 \ K\Omega \ (typ.)$
P1	1/0	Initial "High-Z" Programmable pulli-up resistor Pull-up control Data output Disable Pin input	Sink open drain output or Push-Pull output Hysteresis input Programmable port option R = 100Ω (typ.) R_{IN} = $100 K\Omega$ (typ.)
P2	I/O	Initial "High-Z" Programmable pull-up resistor Pull-up control Data output Input from output latch Pin input Data output Pin input Pin input Pin input Pin input	Sink open drain output or Hysteresis input Programmable port option R = 100Ω (typ.) R_{IN} = $100 K\Omega$ (typ.)



20.	Input/Output Circuitry
20.2	Input/Output Ports

TMP86FH92DMG

TOSHIBA TMP86FH92DMG

21. Electrical Characteristics

21.1 Absolute Maximum Ratings

The absolute maximum ratings are rated values which must not be exceeded during operation, even for an instant. Any one of the ratings must not be exceeded. If any absolute maximum rating is exceeded, a device may break down or its performance may be degraded, causing it to catch fire or explode resulting in injury to the user. Thus, when designing products which include this device, ensure that no absolute maximum rating value will ever be exceeded.

(VSS = 0 V)

Parameter	Symbol	Pins	Ratings	Unit
Supply voltage	V _{DD}		-0.3 to 6.0	٧
Input voltage	V _{IN}		-0.3 to V _{DD} + 0.3	٧
Output voltage	V _{OUT1}		-0.3 to V _{DD} + 0.3	٧
	I _{OUT1}	P0, P1, P3 ports	-1.8	
Output current (Per 1 pin)	I _{OUT2}	P1, P2, P3 ports	3.2	
	I _{OUT3}	P0 ports	30	4
	Σ I _{OUT1}	P0, P1, P3 ports	-30	mA
Output current (Total)	Σ I _{OUT2}	P1, P2, P3 ports	60	
	Σ I _{OUT3}	P0 ports	80	
Power dissipation [Topr = 85 °C]	P _D		200	mW
Soldering temperature (time)	Tsld		260 (10 s)	
Storage temperature	Tstg		-55 to 125	°C
Operating temperature	Topr		-40 to 85	

21.2 Operating Conditions

The Operating Conditions show the conditions under which the device be used in order for it to operate normally while maintaining its quality. If the device is used outside the range of Operating Conditions (power supply voltage, operating temperature range, or AC/DC rated values), it may operate erratically. Therefore, when designing your application equipment, always make sure its intended working conditions will not exceed the range of Operating Conditions.

21.2.1 MCU mode (Flash Programming or erasing)

(Vcc	= 0 V	Tonr	= -10 to	40°C)
IVSS '	– u v,	I UDI	10 10	+0 0

Parameter	Symbol	Pins	Ratings	Min.	Max	Unit
Supply voltage	V_{DD}		NORMAL1, 2 modes	4.5	5.5	
	V _{IH1}	Except hysteresis input	V >45V	V _{DD} × 0.70	.,	v
Input high level V _{IH2}	V _{IH2}	Hysteresis input	V _{DD} ≥ 4.5 V	V _{DD} × 0.75	V _{DD}	
Lea the dead	V _{IL1}	Except hysteresis input	V >45V		V _{DD} × 0.30	
Input low level	V _{IL2}	Hysteresis input	V _{DD} ≥ 4.5 V	0	V _{DD} × 0.25	
Clock frequency	fc	XIN, XOUT		1.0	16.0	MHz

21.2.2 MCU mode (Except Flash Programming or erasing)

 $(V_{SS} = 0 \text{ V}, \text{Topr} = -40 \text{ to } 85^{\circ}\text{C})$

Parameter	Symbol	Pins	F	Ratings	Min	Max	Unit
			fc = 16 MHz	NORMAL1, 2 modes IDLE0, 1, 2 modes	4.0		
Supply voltage			fc = 8 MHz	NORMAL1, 2 modes IDLE0, 1, 2 modes		5.5	
(Condition 1)			fs = 32.768 KHz	SLOW1, 2 modes SLEEP0, 1, 2 modes	3.0		
	V _{DD}		STOP mode				V
Supply voltage			fc = 8 MHz	NORMAL1, 2 modes IDLE0, 1, 2 modes			
(Condition 2) (Note)			fs = 32.768 KHz	SLOW1, 2 modes SLEEP0, 1, 2 modes	2.7	3.0	
			STOP mode				
	V _{IH1}	Except hysteresis input	— V _{DD} ≥ 4.0V		V _{DD} × 0.70		
Input high level	V _{IH2}	Hysteresis input			V_{DD}	V	
	V _{IH3}		V _{DD} < 4.0V		V _{DD} × 0.90		
	V _{IL1}	Except hysteresis input	V >4.0V			V _{DD} × 0.30	
Input low level	V _{IL2}	Hysteresis input	- V _{DD} ≥ 4.0V		0	V _{DD} × 0.25	V
	V _{IL3}		V _{DD} < 4.0V			V _{DD} × 0.10	
	fc	VINI VOLIT	V _{DD} = 2.7 to 5.5V		1.0	8.0	MUL
Clock frequency	IC IC	XIN, XOUT	V _{DD} = 4.0 to 5.5V		1.0	16.0	MHz
	fs	XTIN, XTOUT	V _{DD} = 2.7 to 5.5V		30.0	34.0	kHz

Note: When the supply voltage VDD is less than 3.0V, the operating temperature Topr must be in a range of -20°C to 85°C

21.2.3 Serial PROM mode

(V_{SS} = 0 V, Topr = -10 to 40 °C)

Parameter	Symbol	Pins	Condition	Condition Min		Unit
Supply voltage	V _{DD}		NORMAL1, 2 modes	4.5	5.5	
land think walters	V _{IH1}	Except hysteresis input	V >45V	V _{DD} × 0.70	V	
Input high voltage —	V _{IH2}	Hysteresis input	· V _{DD} ≥ 4.5 V	V _{DD} × 0.75	V _{DD}	V
land the control to a control t	V _{IL1}	Except hysteresis input	V >45V	0	V _{DD} × 0.30	
Input low voltage	V _{IL2}	Hysteresis input	V _{DD} ≥ 4.5 V	0	V _{DD} × 0.25	
Clock frequency	fc	XIN, XOUT		2.0	16.0	MHz

TMP86FH92DMG

21.3 DC Characteristics

 $(V_{SS} = 0 \text{ V}, \text{Topr} = -40 \text{ to } 85 ^{\circ}\text{C})$

Parameter	Symbol	Pins	Cor	ndition	Min	Тур.	Max	Unit
Hysteresis voltage	V_{HS}	Hysteresis input	V _{DD} = 5.0V		-	0.9	-	V
	I _{IN1}	TEST	\ - 5 5 \ \ \ \ - 1					
Input current	I _{IN2}	Sink open drain, tri - state port	$V_{DD} = 5.5 \text{ V}, V_{IN} = 9$	5.5 V/U V	-	-	±2	μA
	I _{IN3}	RESET	V _{DD} = 5.5 V, V _{IN} = 9	5.5 V				
	R _{IN1}	RESET pull - up	V _{DD} = 5.5 V, V _{IN} = 0	0 V	100	200	450	kΩ
Input resistance	R _{IN2}	PORT pull - up	V _{DD} = 5.5 V, V _{IN} = 0	0 V	50	100	200	kΩ
Output leakage current	I _{LO0}	P0,P1,P2,P3	V _{DD} = 5.5 V, V _{OUT} :	= 5.3 V/0.2 V	-	-	±2	μA
Output high voltage	V _{OH}	P0,P1,P2,P3	V _{DD} = 4.5 V, I _{OH} = -	-0.7 mA	4.1	-	-	
Output low voltage	V _{OL}	Except P0	V _{DD} = 4.5 V, I _{OL} = 1	1.6 mA	-	-	0.4	V
Output low current	I _{OL}	High current port (P0 Port)	V _{DD} = 4.5 V, V _{OL} =	1.0 V	-	20	-	mA
Supply current in			V _{DD} = 5.5 V	When a program operates on flash memory (Note4,5)	-	12.5	20	
NORMAL1, 2 modes			$V_{IN} = 5.3 \text{ V}/0.2 \text{ V}$ fc = 16 MHz	When a program operates on RAM	-	7.5	14	mA
Supply current in			fs = 32.768 kHz		_	5.5	9	
IDLE 0, 1, 2 modes						0.0		
				When a program operates on flash memory (Note4,5)	-	22	65	
Supply current in SLOW1 mode	I _{DD}		V _{DD} = 3.0 V	When a program operates on RAM (FLSSTB <fstb>= 0)</fstb>	-	21	30	
			V _{IN} = 2.8 V/0.2 V fs = 32.768 kHz	When a program operates on RAM (FLSSTB <fstb>= 1)</fstb>	1	16	25	μA
Supply current in SLEEP1 mode					-	14	22	
Supply current in SLEEP0 mode					-	12	20	
Supply current in STOP mode			V _{DD} = 5.5 V V _{IN} = 5.3 V/0.2 V		-	10	20	
Peak current of inter-			V _{DD} = 5.5 V		-	10	-	
mittent operation (Note4,5)	I _{DDP-P}		V _{DD} = 3.0 V		-	2	-	mA

- Note 1: Typical values show those at Topr = 25 °C and V_{DD} = 5 V.
- Note 2: Input current (I_{IN3}): The current through pull-up or pull-down resistor is not included.
- Note 3: The supply currents of SLOW2 and SLEEP2 modes are equivalent to those of IDLE0, IDLE1 and IDLE2 modes.
- Note 4: When a program is executing in the flash memory or when data is being read from the flash memory, the flash memory operates in an intermittent manner, causing peak currents in the operation current, as shown in Figure 21-1.

 In this case, the supply current I_{DD} (in NORMAL1, NORMAL2 and SLOW1 modes) is defined as the sum of the average peak current and MCU current.
- Note 5: When designing the power supply, make sure that peak currents can be supplied. In SLOW1 mode, the difference between the peak current and the average current becomes large.




Figure 21-1 Intermittent Operation of Flash Memory

21.4 AD Conversion Characteristics


21.4 AD Conversion Characteristics

 $(Topr = -40 \text{ to } 85^{\circ}C)$

Parameter	Symbol	Condition	Min	Тур.	Max	Unit
Analog input voltage	V _{AIN}		V _{SS}	-	V _{DD}	V
Non linearity error			-	-	±6	
Zero point error		V _{DD} = 3.0V/5.0 V	-	-	±6	LOD
Full scale error		V _{SS} = 0.0 V	-	-	±6	LSB
Total error			-	-	±6	

- Note 1: The total error includes all errors except a quantization error, and is defined as a maximum deviation from the ideal conversion line.
- Note 2: Conversion time is different in recommended value by power supply voltage.
- Note 3: The voltage to be input on the AIN input pin must not exceed the range between V_{DD} and V_{SS}. If a voltage outside this range is input, conversion values will become unstable and conversion values of other channels will also be affected.
- Note 4: When the supply voltage VDD is less than 3.0V, the operating temperature Topr must be in a range of −20°C to 85°C.

21.5 Power-on reset circuit Characteristics



Note: The power-on reset circuit may not operate properly depending on transitions in supply voltage (VDD). When designing your application system, careful consideration must be given to ensure proper operation of the power-on reset circuit by referring to the device's electrical characteristics.


Figure 21-2 Operation of the Power-on reset circuit

 $(V_{SS} = 0 \text{ V}, \text{Topr} = -40 \text{ to } 85 ^{\circ}\text{C})$

Symbol	Parameter	Min	Тур.	Max	Unit
V _{PROFF}	Power-on reset release voltage (Note1)	2.2	2.4	2.6	V
V _{PRON}	Power-on reset threshold voltage (Note1)	2.0	2.2	2.3	V
t _{PROFF}	Power-on reset release response time	-	0.01	0.1	
t _{PRON}	Power-on reset generation response time	-	0.01	0.1	
t _{PRW}	Power-on reset minimum pulse width	1.0	-	-	ms
t _{PWUP}	Power-on warm-up time	9.0	15.0	48.0	
t _{VDD}	Power-on reset	-	-	5	

- Note 1: Because the power-on reset releasing voltage and the power-on reset detecting voltage change relative to one another, the detected voltage will never become inverted.
- Note 2: The input clock to the warm-up counter is derived from the oscillation circuit. Because the oscillation frequency is unstable until the oscillation circuit stabilizes, the warm-up time includes error.
- Note 3: The supply voltage must be raised to satisfy the condition $t_{VDD} < t_{PWUP}$.

21.6 Voltage detection circuit characteristics



Note: The voltage detection circuit may not operate properly depending on transitions in supply voltage (VDD). When designing your application system, careful consideration must be given to ensure proper operation of the voltage detection circuit by referring to the device's electrical characteristics.

Figure 21-3 Operation timing of Voltage detection circuit

(V_{SS} = 0 V, Topr = -40 to 85 $^{\circ}$ C)

Symbol	Parameter	Min	Тур.	Max	Unit
t _{VLTOFF}	Voltage detection release response time	-	0.01	0.1	
t _{VLTON}	Voltage detection response time	-	0.01	0.1	ms
t _{VLTPW}	Voltage detection minimum pulse width	1.0	-	-	

21.7 AC Characteristics TMP86FH92DMG

21.7 AC Characteristics

 $(V_{SS} = 0 \text{ V}, 4.0 \text{ V} \le V_{DD} \le 5.5 \text{ V}, \text{Topr} = -40 \text{ to } 85^{\circ}\text{C})$

Parameter Symbol		Condition	Min	Тур.	Max	Unit
		NORMAL1, 2 modes	0.05	-	4	μs
Markey and Con-		IDLE0, 1, 2 modes	0.25			
Machine cycle time	tcy	SLOW1, 2 modes	447.0	-	133.3	
		SLEEP0, 1, 2 modes	117.6			
High-level clock pulse width	t _{WCH}	For external clock operation (XIN input)		04.05		
Low-level clock pulse width	t _{WCL}	fc = 16 MHz	-	31.25	-	ns
High-level clock pulse width	t _{WSH}	For external clock operation (XTIN input)	-	15.26	-	
Low-level clock pulse width	t _{WSL}	fs = 32.768 kHz				μs

(V_{SS} = 0 V, 3.0 V \leq V_{DD} \leq 5.5 V, Topr = -40 to 85°C)

Parameter Symbol Condition		Min	Тур.	Max	Unit	
		NORMAL1, 2 modes		-	4	· µs
Market and the Care	tcy	IDLE0, 1, 2 modes	0.5			
Machine cycle time		SLOW1, 2 modes	447.0	-	133.3	
		SLEEP0, 1, 2 modes	117.6			
High-level clock pulse width	twch	For external clock operation (XIN input)		00.5		
Low-level clock pulse width	t _{WCL}	fc = 8 MHz	-	62.5	-	ns
High-level clock pulse width	t _{WSH}	For external clock operation (XTIN input)		45.00		
Low-level clock pulse width	t _{WSL}	fs = 32.768 kHz	-	15.26	-	μs

 $(V_{SS} = 0 \text{ V}, 2.7 \text{ V} \le V_{DD} < 3.0 \text{ V}, \text{Topr} = -20 \text{ to } 85^{\circ}\text{C})$

	1	<u> </u>	1			
Parameter	Symbol	Condition	Min	Тур.	Max	Unit
		NORMAL1, 2 modes	0.5	-	4	μs
Madelan and Care	tcy	IDLE0, 1, 2 modes				
Machine cycle time		SLOW1, 2 modes	117.6	-	133.3	
		SLEEP0, 1, 2 modes				
High-level clock pulse width	t _{WCH}	For external clock operation (XIN input)		CO F		
Low-level clock pulse width t _{WCL}		fc = 8 MHz	-	62.5	-	ns
High-level clock pulse width	t _{WSH}	For external clock operation (XTIN input)				
Low-level clock pulse width	t _{WSL}	fs = 32.768 kHz	-	15.26	-	μs

21.8 Flash Characteristics

21.8.1 Write/Erase Characteristics


 $(V_{SS} = 0 V)$

Parameter	Condition	Min	Тур.	Max.	Unit
Number of guaranteed writes to flash memory	V _{SS} = 0 V, Topr = -10 to 40°C	-	-	100	Times

Note: To rewrite data to Flash memory addresses at which data is already written, make sure to erase the existing data before rewriting data.

TMP86FH92DMG

21.9 Oscillating Conditions



- Note 1: To ensure stable oscillation, the resonator position, load capacitance, etc. must be appropriate. Because these factors are greatly affected by board patterns, please be sure to evaluate operation on the board on which the device will actually be mounted.
- Note 2: The product numbers and specifications of the resonators by Murata Manufacturing Co., Ltd. are subject to change. For up-to-date information, please refer to the following URL: http://www.murata.com

21.10 Handling Precaution

- The solderability test conditions are shown below.
 - 1. When using the Sn-37Pb solder bath

Solder bath temperature = 230° C

Dipping time = 5 seconds

Number of times = once

R-type flux used

2. When using the Sn-3.0Ag-0.5Cu solder bath

Solder bath temperature = 245° C

Dipping time = 5 seconds

Number of times = once

R-type flux used

The pass criteron of the above test is as follows: Solderability rate until forming $\geq 95\%$


- When using the device (oscillator) in places exposed to high electric fields such as cathode-ray tubes, we recommend electrically shielding the package in order to maintain normal operating condition.


TOSHIBA TMP86FH92DMG


22. Package Dimensions

SSOP30-P-56-0.65 Rev 02

Unit: mm







22.	Dookogo	Dimonoione
∠∠ .	rackaue	Dimensions

TMP86FH92DMG

RESTRICTIONS ON PRODUCT USE

- Toshiba Corporation, and its subsidiaries and affiliates (collectively "TOSHIBA"), reserve the right to make changes to the information in this document, and related hardware, software and systems (collectively "Product") without notice.
- This document and any information herein may not be reproduced without prior written permission from TOSHIBA. Even with TOSHIBA's written permission, reproduction is permissible only if reproduction is without alteration/omission.
- Though TOSHIBA works continually to improve Product's quality and reliability, Product can malfunction or fail. Customers are responsible for complying with safety standards and for providing adequate designs and safeguards for their hardware, software and systems which minimize risk and avoid situations in which a malfunction or failure of Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption. Before customers use the Product, create designs including the Product, or incorporate the Product into their own applications, customers must also refer to and comply with (a) the latest versions of all relevant TOSHIBA information, including without limitation, this document, the specifications, the data sheets and application notes for Product and the precautions and conditions set forth in the "TOSHIBA Semiconductor Reliability Handbook" and (b) the instructions for the application that Product will be used with or for. Customers are solely responsible for all aspects of their own product design or applications, including but not limited to (a) determining the appropriateness of the use of this Product in such design or applications; (b) evaluating and determining the applicability of any information contained in this document, or in charts, diagrams, programs, algorithms, sample application circuits, or any other referenced documents; and (c) validating all operating parameters for such designs and applications. TOSHIBA ASSUMES NO LIABILITY FOR CUSTOMERS' PRODUCT DESIGN OR APPLICATIONS.
- Product is intended for use in general electronics applications (e.g., computers, personal equipment, office equipment, measuring equipment, industrial robots and home electronics appliances) or for specific applications as expressly stated in this document. Product is neither intended nor warranted for use in equipment or systems that require extraordinarily high levels of quality and/or reliability and/or a malfunction or failure of which may cause loss of human life, bodily injury, serious property damage or serious public impact ("Unintended Use"). Unintended Use includes, without limitation, equipment used in nuclear facilities, equipment used in the aerospace industry, medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, devices related to electric power, and equipment used in finance-related fields. Do not use Product for Unintended Use unless specifically permitted in this document.
- · Do not disassemble, analyze, reverse-engineer, alter, modify, translate or copy Product, whether in whole or in part.
- Product shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable laws or regulations.
- The information contained herein is presented only as guidance for Product use. No responsibility is assumed by TOSHIBA for any infringement of patents or any other intellectual property rights of third parties that may result from the use of Product. No license to any intellectual property right is granted by this document, whether express or implied, by estoppel or otherwise.
- ABSENT A WRITTEN SIGNED AGREEMENT, EXCEPT AS PROVIDED IN THE RELEVANT TERMS AND CONDITIONS OF SALE
 FOR PRODUCT, AND TO THE MAXIMUM EXTENT ALLOWABLE BY LAW, TOSHIBA (1) ASSUMES NO LIABILITY
 WHATSOEVER, INCLUDING WITHOUT LIMITATION, INDIRECT, CONSEQUENTIAL, SPECIAL, OR INCIDENTAL DAMAGES OR
 LOSS, INCLUDING WITHOUT LIMITATION, LOSS OF PROFITS, LOSS OF OPPORTUNITIES, BUSINESS INTERRUPTION AND
 LOSS OF DATA, AND (2) DISCLAIMS ANY AND ALL EXPRESS OR IMPLIED WARRANTIES AND CONDITIONS RELATED TO
 SALE, USE OF PRODUCT, OR INFORMATION, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS
 FOR A PARTICULAR PURPOSE, ACCURACY OF INFORMATION, OR NONINFRINGEMENT.
- Do not use or otherwise make available Product or related software or technology for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). Product and related software and technology may be controlled under the Japanese Foreign Exchange and Foreign Trade Law and the U.S. Export Administration Regulations. Export and re-export of Product or related software or technology are strictly prohibited except in compliance with all applicable export laws and regulations.
- Please contact your TOSHIBA sales representative for details as to environmental matters such as the RoHS compatibility of Product.
 Please use Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. TOSHIBA assumes no liability for damages or losses occurring as a result of noncompliance with applicable laws and regulations.