


4-CH H BRIDGE MOTOR DRIVER

—TOP VIEW—

**INPUT**

CH1, CH2 : CAPACITOR FOR CHARGE PUMP
 EN1 - EN4 : ENABLE CONTROL
 IN1 - IN4 : SENSE OF ROTATION CONTROL
 VM1 - VM3 : POWER FOR MOTOR

OUTPUT

C1L, C2L : CAPACITOR FOR CHARGE PUMP
 VG : CHARGE PUMP

INPUT/OUTPUT

A1 - A4, B1 - B4 : MOTOR

OTHER

LGND : LOGIC GROUND
 PGND1 - PGND2 : POWER GROUND

