

To measure temperature with the 315 follow these simple instructions:

Select either the Fahrenheit or Celsius mode:

- With the unit "oFF" press and continue to hold the ON/OFF button. The LCD will alternate between F and C.
- Release the ON/OFF button when desired measurement mode appears on the LCD.

Remove the protective sheath from the stem.

Press the ON/OFF button.

Insert stem into area or object to be tested. At least 1/2 inch of the stem must be inserted.

WARNING: The stem is a sharp and pointed object which can be dangerous.

The Data Hold Function is used by pressing the D-H button when taking a measurement. The measurement will flash on the LCD when Data Hold is activated. To return to normal operation, press and release the D-H button a second time.

Press the ON/OFF button to end operation or the unit will automatically power off after approx. 35 minutes.

Specifications:

Temperature Range-58 to 300 F/-50 to 150 C
Resolution.....0.1 Degrees
Accuracy +/- 2 F, +/- 1C
Sampling Time1.5 Seconds
Battery.....(LR44) A044



Test Products International, Inc.

9615 SW Allen Blvd.
Beaverton, OR 97005-4814 USA
Ph: 503-520-9197 Fax: 503-520-1225

The Value Leader
www.tpi-thevalueleader.com



Made in Korea