## **NPN Silicon Photodarlington OP300SL Series**



### Features:

- Narrow receiving angle
- · Variety of sensitivity ranges
- Enhanced temperature range
- PCBoard mounting
- Mechanically and spectrally matched to OP123 and OP223 LEDs



### **Description:**

Each device in this series is a NPN silicon photodarlington in a hermetically sealed pill package with a narrow receiving angle that provides excellent on-axis coupling. Photodarlingtons are normally used in applications with low light signal levels, where more current gain is needed than phototransistors can provide.

Components in the OP300 series are mechanically and spectrally matched to the OP123 and OP223 series.

Please refer to Application Bulletins 208 and 210 for additional design information and reliability (degradation) data, and to Application Bulletin 202 for pill-type soldering to PCBoard.

### Applications:

- Non-contact reflective object sensor
- Assembly line automation Machine automation
- Machine safety · End of travel sensor
- Door sensor

Ordering Information								
Part Number	Sensor	Light Current I <sub>C(ON)</sub> (mA) Min / Max	Input Power E <sub>E</sub> (mW/cm <sup>2</sup> )	Viewing Angle				
OP300SL		0.8 / NA						
OP301SL		0.8 / 2.4	1.0 with 2870°K or 0.4 with	35°				
OP302SL	Darlington	1.8 / 5.4						
OP303SL	Danington	3.6 / 12.0						
OP304SL	]	7.0 / 21.0	890nm					
OP305SL		14.0 / NA						



OPTEK reserves the right to make changes at any time in order to improve design and to supply the best product possible

OPTEK Technology Inc. - 1645 Wallace Drive, Carrollton, Texas 75006 Phone: (972) 323-2200 or (800) 341-4747 FAX: (972) 323-2396 sensors@optekinc.com www.optekinc.com

RoHS



#### Absolute Maximum Ratings (T<sub>A</sub>=25°C unless otherwise noted)

Collector-Emitter Voltage	15.0 V
Emitter-Collector Voltage	5.0 V
Storage Temperature Range	-65° C to +150° C
Operating Temperature Range	-65° C to +125° C
Soldering Temperature (5 seconds with soldering iron)	260° C <sup>(1)(2)</sup>
Power Dissipation	50 mW <sup>(3)</sup>
Continuous Collector Current	50 mA

#### Electrical Characteristics (T<sub>A</sub> = 25° C unless otherwise noted)

SYMBOL	PARAMETER	MIN	ТҮР	MAX	UNITS	TEST CONDITIONS
I <sub>C(ON)</sub> <sup>(4)</sup>	On-State Collector Current OP300SL OP301SL OP302SL OP303SL OP304SL OP305SL	0.8 0.8 1.8 3.6 7.0 14.0		2.4 5.4 12.0 21.0	mA	$V_{CE}$ = 5.0 V, E <sub>E</sub> = 1.0 or 0.4 mW/cm <sup>2(5)</sup>
I <sub>CEO</sub>	Collector-Dark Current	-	-	1.0	μA	$V_{CE} = 10 V, E_{E} = 0$
V <sub>(BR)CEO</sub>	Collector-Emitter Breakdown Voltage	15.0	-	-	V	I <sub>C</sub> = 100 μA
V <sub>(BR)ECO</sub>	Emitter-Collector Breakdown Voltage	5.0	-	-	V	I <sub>E</sub> = 100 μA
V <sub>CE(SAT)</sub> <sup>(4)</sup>	Collector-Emitter Saturation Voltage OP300SL, OP301SL OP302SL through OP305SL	-	-	1.1 1.1	V	$I_{c}$ = 0.4 mA, E <sub>E</sub> = 1.0 or 0.4 mW/cm <sup>2(5)</sup> $I_{c}$ = 1.0 mA, E <sub>E</sub> = 1.0 or 0.4 mW/cm <sup>2(5)</sup>

Notes:

(1) Refer to Application Bulleting 202, which discusses proper techniques for soldering pill-type devices to PCBoards.

(2) No clean or low solids. RMA flux is recommended. Duration can be extended to 10 seconds maximum when flow soldering.
(3) Derate linearly 0.5 mW/° C above 25° C.

(4) Junction temperature maintained at 25° C.

(5) Light source is an unfiltered tungsten bulb operating at CT =  $2870^{\circ}$  K at  $E_{E} = 1.0$  mW/cm<sup>2</sup> or 890nm at  $E_{E} = 0.4$  mW/cm<sup>2</sup>.

OPTEK reserves the right to make changes at any time in order to improve design and to supply the best product possible.

# NPN Silicon Photodarlington OP300SL Series





OPTEK reserves the right to make changes at any time in order to improve design and to supply the best product possible.

## NPN Silicon Photodarlington OP300SL Series





Switching time Circuit



The light source is a pulsed LED with a rise time of less than 500 nS. The LED output is adjusted for  $I_C$  = 0.8 mA.

OPTEK reserves the right to make changes at any time in order to improve design and to supply the best product possible.