

CORCOM Product Guide

corcom

Voltage Selecting and Fused Connector with Optional RFI Power Line Filter for General Purpose Applications for UL544 Health Care Equipment

J Series




CSA Certified





Voltage Selection Unfiltered and Filtered Models



Open cover door and rotate fuse-pull lever to left. Select operating voltage by orienting voltage selection card, desired voltage on top left side. Push card firmly into module slot. Rotate fuse-pull lever back into normal position and re-insert fuse into holders. Use caution in selecting correct fuse value.

Unfiltered Models			
	Available Volta	ge Selection	
Part Number	Positi	ons	
6VJ1	4		
6VJ1-2	2		
Unfiltered Models			
	Available Voltage		
Part Number	Selection	RFI Filter	

Part Number	Selection RFI Filter		
	Positions	Туре	
6VJ4	4	General Purpose ¹	
6J4-2	2	General Purpose ¹	
6HJ4-4	4	Medical ²	
6HJ4-2	2	Medical ²	

Note 1: General purpose filter for susceptibility applications

Note 2: Medical line filter for very low leakage UL544 health care requirements

J Series

The most widely accepted of all the power entry modules, the J series combines an IEC connector, 2-voltage, or 4voltage selection, and a North American fuseholder. It features a compact snap-in design and a unique voltage selector card.

J4 Models - This general purpose filter provides susceptibility protection from line-to-ground noise on the power line and acts as a high frequency "clean-up" filter for more complex emissions applications.

HJ4 Models - This medical filter provides susceptibility protection without the leakage current associated with line-to-ground capacitors. Designed to allow equipment to meet UL544 medical specifications for patient care and non-patient care equipment, the HJ filter has a maximum leakage current of 2μ A at 120 VAC 60 Hz. See Appendix C for more information on medical applications and UL standards.

Equipment rating labels and mounting clips for thicker panel widths are available as accessories.

For more information on UL544 specifications, see Appendix C.

Note: When using the models with an IEC connector, remember that the leakage current of the companion line cord, GA400, is more significant than that of the filter which may disqualify this line cord from use in patient care applications.

114

Catalog 1654001 Revised 04-06 Dimensions are in inches and millimeters unless otherwise specified. Values in italics are metric equivalents. Dimensions are shown for reference purposes only. Specifications subject to change. USA Cust. Svc.: 1-800-468-2023 CORCOM Prods: 1-847-680-7400 Germany: 49-89-6089-0 www.corcom.com www.tycoelectronics.com



Electronics

CORCOM Product Guide

Note 3

120V

100V

220V

240V

corcom


6VJ

Voltage Selecting and Fused Connector with Optional RFI Power Line Filter for General Purpose Applications for UL544 Health Care Equipment (Continued)

J Series

Electrical Schematics

Filtered 6J4 & 6J4-2



Specifications

		Models	Models	Models
@250 VAC	50 Hz:	500 µA	5 μΑ	5 μΑ
Hipot rating (on	e minute):			
line-to-grou	und	2250	2250	1550
line-to-line		1450	1450	1450
Operating freque	ency:		5	0/60 Hz
Operating voltage	jes:			
6VJ1, 6J4,	6HJ4-4:	100, 12	20, 220, 2	40 VAC
6J1-2, 6J4	-2, 6HJ4-2:		115, 2	30 VAC
Rated current:				6A
Rated current:Fuse (not included):Integral fuseholde side,accepts .25" x 1.25				
Terminals:	Connector b suitable fo	lock termin or soldering		apping,

6J4


6EHJ4

Minimum insertion loss in dB:

Line-to-ground in 50 ohm circuit

Current	Frequency-MHz						
Rating	.15	.5	1	5	10	20	30
J4 Models							
6A	9	20	25	41	45	45	48
HJ4 Models							
6A	9	11	15	19	13	12	10

Filtered 6HJ4-4 & 6HJ4-2



Note 1: Jumper required if only SPST power switch is used.

Note 2: Jumpers required if no input filtering is used.

Note 3: Use only 120V and 240V positions for 2-volt selection units.

Catalog 1654001 Revised 04-06 Dimensions are in inches and millimeters unless otherwise specified. Values in italics are metric equivalents. Dimensions are shown for reference purposes only. Specifications subject to change. USA Cust. Svc.: 1-800-468-2023 CORCOM Prods: 1-847-680-7400 Germany: 49-89-6089-0 115




CORCOM Product Guide


corcom

Electronics

J Series

Case Styles Unfiltered Models






~	D :	
1.360	Dimor	ncinnc
Case	Dimer	1310113


Voltage Selecting and Fused Connector with Optional RFI Power Line Filter for

General Purpose Applications for UL544 Health Care Equipment (Continued)

Part No.	Α	В	С	D
i art ito.	(max)	(max)	(max)	(max)
Unfiltered	2.68	1.52	1.17	1.23
6VJ1/6VJ1-2	68.1	38.6	29.7	31.2
Filtered	2.75	1.87	1.17	1.58
6J4/6J4-2	69.9	47.5	29.7	40.1
6HJ4-4/6HJ4-2	2.75	1.87	1.17	1.58
01104 4/01104 2	69.9	47.5	29.7	40.1


Filtered Models





Recommended Panel Cutout

Unfiltered and Filtered Models



*±.003 Note 4:

Fuse cover door shown in open condition.

Note 5: Standard units mount in panel thickness of .060 - .090" Special mounting clips sold separately for panel thickness of .105-.125". See Accessories List on next page.

116

Catalog 1654001 Revised 04-06

Downloaded from Elcodis.com electronic components distributor

Dimensions are in inches and millimeters unless otherwise specified. Values in italics are metric equivalents. Dimensions are shown for reference purposes only. Specifications subject to change. USA Cust. Svc.: 1-800-468-2023 CORCOM Prods: 1-847-680-7400 Germany: 49-89-6089-0 www.corcom.com www.tycoelectronics.com **CORCOM Product Guide**

corcom


Electronics

Voltage Selecting and Fused Connector with Optional RFI Power Line Filter for General Purpose Applications for UL544 Health Care Equipment (Continued)

J Series

Equipment Rating Labels Unfiltered and Filtered Models

Self-adhesive labels, as shown below, are available in multiples of 40. Specify part number.



Part Number	A VA Max.	B Fuse 100/120 (115)	C Fuse 220/240 (230)
JA410	25	250 mA	125 mA
JA411	50	500 mA	250 mA
JA412	100	1A	500 mA
JA413	200	2A	1A
JA414	250	2.5A	1.25A
JA415	300	ЗA	1.5A
JA416	400	4 A	2A
JA417	500	5A	2.5A
JA418	600	6A	ЗA
JA419	Assortment		

Labels - 40 of one part number

Labels - 5 each of 8 part numbers for 4-volt

Accessories Unfiltered and Filtered Models

Line Cord No. GA400: (7 1/2 foot, 3-conductor line cord to mate with J series)

JA302, 2 Voltage Selector Card (comes standard with 6VJ1-2, 6J4-2, 6HJ4-2)

JA304, 4 Voltage Selector Card (comes standard with 6VJ1, 6J4, 6HJ4-4)

JA403, Mounting Clips for .105-.125" Panel

JA500, Voltage Selector Card Extractor Tool

Dimensions are in inches and millimeters unless otherwise specified. Values in italics are metric equivalents. Dimensions are shown for reference purposes only. Specifications subject to change. 117

Power Entry Modules