


Si APD

S5343 to S5345, S9073 to S9075

Short wavelength type APD



Features

- High sensitivity and low noise in UV to visible range

Applications

- Low-light-level measurement
- Analytical equipment

■ General ratings / Absolute maximum ratings

| Type No. | Dimensional outline/ Window material *1 | Package | Effective active | | Absolute maximum ratings | |
|----------|--|---------|-------------------|----------------------------|---|---|
| | | | area size (mm) | area (mm ²) | Operating temperature T _{opr} (°C) | Storage temperature T _{stg} (°C) |
| S9073 | ①/U | TO-18 | φ0.2 | 0.03 | -20 to +60 | -55 to +100 |
| S9074 | | | φ0.5 | 0.19 | | |
| S5343 | | | φ1.0 | 0.78 | | |
| S9075 | ②/U | TO-5 | φ1.5 | 1.77 | | |
| S5344 | | | φ3.0 | 7.0 | | |
| S5345 | | | φ5.0 | 19.6 | | |

■ Electrical and optical characteristics (Typ. T_a=25 °C, unless otherwise noted)


| Type No. | Spectral response range λ (nm) | Peak *3 sensitivity wavelength λ _p (nm) | Photo sensitivity S M=1 λ=620 nm (A/W) | Quantum efficiency QE M=1 λ=620 nm (%) | Breakdown voltage V _{BR} I _D =100 μA | | Temp. coefficient of V _{BR} (V/°C) | Dark *3 current I _D | | Cut-off *3 frequency f _c R _L =50 Ω (MHz) | Terminal *3 capacitance C _t (pF) | Excess *3 noise figure x λ=650 nm | Gain M λ=650 nm | | |
|----------|--------------------------------------|--|---|---|---|----------|--|--------------------------------|-----------|--|--|--------------------------------------|--------------------|-----|-----|
| | | | | | Typ. (V) | Max. (V) | | Typ. (nA) | Max. (nA) | | | | | | |
| S9073 | 200 to 1000 | 620 | 0.42 | 80 | 150 | 200 | 0.14 | 0.2 | 5 | 900 | 3 | 0.28 | 50 | | |
| S9074 | | | | | | | | | | | | | | 400 | 7 |
| S5343 | | | | | | | | | | | | | | 250 | 15 |
| S9075 | | | | | | | | | | | | | | 100 | 30 |
| S5344 | | | | | | | | | | | | | | 25 | 120 |
| S5345 | | | | | | | | | | | | | | 8 | 320 |

*1: U: UV glass

*2: Area in which a typical gain can be obtained.


*3: Values measured at a gain listed in the characteristics table.

■ Spectral response




KAPDB0010ED

■ Quantum efficiency vs. wavelength




KAPDB0023EB

■ Dark current vs. reverse voltage




KAPDB0009ED

■ Gain vs. reverse voltage




KAPDB0011EC

■ Terminal capacitance vs. reverse voltage






■ Excess noise figure vs. gain



Dimensional outlines (unit: mm)




① S9073, S9074, S5343



The glass window may extend a maximum of 0.1 mm beyond the upper surface of the cap.

KAPDA0014EA




② S9075, S5344



The glass window may extend a maximum of 0.2 mm beyond the upper surface of the cap.

KAPDA0015EA

③ S5345



The glass window may extend a maximum of 0.2 mm beyond the upper surface of the cap.

KAPDA0016EB

HAMAMATSU

Information furnished by HAMAMATSU is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein. ©2004 Hamamatsu Photonics K.K.

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Hamamatsu City, 435-8558 Japan, Telephone: (81) 053-434-3311, Fax: (81) 053-434-5184, <http://www.hamamatsu.com>

U.S.A.: Hamamatsu Corporation, 360 Foothill Road, P.O.Box 6910, Bridgewater, N.J. 08807-0910, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218

France: Hamamatsu Photonics France S.A.R.L.: 8, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 10

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Telephone: (44) 1707-294888, Fax: (44) 1707-325777

North Europe: Hamamatsu Photonics Norden AB: Smidesvägen 12, SE-171 41 Solna, Sweden, Telephone: (46) 8-509-031-00, Fax: (46) 8-509-031-01

Italy: Hamamatsu Photonics Italia S.R.L.: Strada della Moia, 1/E, 20020 Arese, (Milano), Italy, Telephone: (39) 02-935-81-733, Fax: (39) 02-935-81-741