

Data Sheet, DS 2, December 2001



ABM Premium  
ATM Buffer Manager  
PXF 4336 Version 1.1

Wired  
Communications



Never stop thinking.

**Edition 2001-12-17**

**Published by Infineon Technologies AG,  
St.-Martin-Strasse 53,  
D-81541 München, Germany**

**© Infineon Technologies AG 2001.  
All Rights Reserved.**

**Attention please!**

The information herein is given to describe certain components and shall not be considered as warranted characteristics.

Terms of delivery and rights to technical change reserved.

We hereby disclaim any and all warranties, including but not limited to warranties of non-infringement, regarding circuits, descriptions and charts stated herein.

Infineon Technologies is an approved CECC manufacturer.

**Information**

For further information on technology, delivery terms and conditions and prices please contact your nearest Infineon Technologies Office in Germany or our Infineon Technologies Representatives worldwide (see address list).

**Warnings**

Due to technical requirements components may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies Office.

Infineon Technologies Components may only be used in life-support devices or systems with the express written approval of Infineon Technologies, if a failure of such components can reasonably be expected to cause the failure of that life-support device or system, or to affect the safety or effectiveness of that device or system. Life support devices or systems are intended to be implanted in the human body, or to support and/or maintain and sustain and/or protect human life. If they fail, it is reasonable to assume that the health of the user or other persons may be endangered.

Data Sheet, DS 2, December 2001

# ABM Premium ATM Buffer Manager PXF 4336 Version 1.1

Wired  
Communications



Never stop thinking.

---

**ABM-P Data Sheet****Revision History:**      **2001-12-17**      **DS 2**

Previous Version:      DS 1.5, 2001-07-12

Page	Subjects (major changes since last revision)
	Reworked from preliminary to first finalized status

For questions on technology, delivery and prices please contact the Infineon Technologies Offices in Germany or the Infineon Technologies Companies and Representatives worldwide: see our webpage at <http://www.infineon.com>

## Disclaimer:

This data sheet describes a product under development by Infineon Technologies AG ('Infineon'). Infineon reserves the right to change features and characteristics of the product or to discontinue this product without notice. None of the information contained in this document constitutes an express or implied assurance of availability or functionality. Please contact Infineon for the latest information on the product.

<b>Table of Contents</b>		<b>Page</b>
<b>1</b>	<b>Overview</b> .....	21
1.1	Features .....	22
1.1.1	Queueing Functions .....	23
1.1.2	Scheduling Functions .....	23
1.1.3	Interfaces .....	23
1.1.4	Supervision Functions .....	24
1.1.5	Technology .....	24
1.2	Logic Symbol .....	25
1.3	Typical Applications .....	26
<b>2</b>	<b>Pin Descriptions</b> .....	27
2.1	Pin Diagram .....	27
2.2	Pin Diagram with Functional Groupings .....	28
2.3	Pin Definitions and Functions .....	29
2.3.1	Common System Clock Supply (6 pins) .....	29
2.3.2	UTOPIA Receive Interface Upstream (Master/Slave) (32 pins) .....	30
2.3.3	UTOPIA Transmit Interface Downstream (Master/Slave) (32 pins) .....	32
2.3.4	UTOPIA Receive Interface Downstream (Master/Slave) (32 pins) .....	33
2.3.5	UTOPIA Transmit Interface Upstream (Master/Slave) (32 pins) .....	35
2.3.6	Microprocessor Interface (32 pins) .....	36
2.3.7	Cell Storage RAM Upstream (50 pins) .....	38
2.3.8	Cell Storage RAM Downstream (50 pins) .....	40
2.3.9	Common Up- and Downstream Cell Pointer RAM (42 pins) .....	42
2.3.10	JTAG Boundary Scan (5 pins) .....	43
2.3.11	SPI Interface (5 pins) .....	44
2.3.12	QCI Interface (3 pins) .....	44
2.3.13	Production Test (2 pin) .....	44
2.3.14	Supply (74 VSS, 32 VDD33 and 14 VDD18 pins) .....	44
2.3.15	Unconnected (13 pins) .....	45
<b>3</b>	<b>Functional Description</b> .....	46
3.1	Block Diagrams .....	46
3.1.1	Throughput and Speedup .....	48
3.2	Functional Block Description .....	49
3.2.1	Cell Handler (Upstream/Downstream) .....	49
3.2.2	Buffer Manager and Queue Scheduler (Overview) .....	49
3.2.3	Enhanced Rate Control Unit Overview .....	49
3.2.4	AAL5 Assistant .....	50
3.2.5	Internal Address Reduction Unit .....	50
3.2.6	Queue Congestion Indication Unit .....	55
3.2.7	Clocking System .....	55
3.2.7.1	Clocking System Overview .....	56
3.2.7.2	DPLL Programming .....	56

<b>Table of Contents</b>		<b>Page</b>
3.2.7.3	Programming Example .....	57
3.2.7.4	Initialization Phase .....	58
3.2.8	Reset System .....	59
3.3	System Integration .....	60
3.3.1	LCI Translation in Mini-Switch Configurations .....	62
3.4	Buffer Manager and Queue Scheduler Details .....	64
3.4.1	Buffer Manager .....	65
3.4.1.1	Functional Overview .....	65
3.4.1.2	Logical Buffer Views .....	66
3.4.1.3	Threshold Classification .....	68
3.4.1.4	Counter Classification .....	69
3.4.1.5	Threshold and Occupancy Counter Overview .....	70
3.4.1.6	Discard Mechanisms and Buffer Reservation .....	72
3.4.1.7	Cell Acceptance Algorithm .....	76
3.4.1.8	SB Congestion Indication Mechanism .....	79
3.4.1.9	Statistical Counters .....	80
3.4.2	Queue Scheduler .....	81
3.4.2.1	Functional Overview .....	81
3.4.2.2	Scheduler Block .....	82
3.4.2.3	Quality of Service Support .....	84
3.4.2.4	Traffic Shaping .....	86
3.4.2.5	VC-Merge and Dummy Queue .....	91
3.4.3	Scheduler Block Usage .....	93
3.4.4	Scheduler Block Scheduler (SBS) .....	94
3.4.5	Supervision Functions .....	95
3.4.5.1	Cell Header Protection .....	95
3.4.5.2	Cell Queue Supervision .....	95
3.5	Available Bit Rate Support .....	96
3.5.1	ABR Service Description .....	96
3.5.1.1	Example Network Configuration .....	98
3.5.1.2	ABR Parameters .....	99
3.5.1.3	Source Behavior Overview .....	102
3.5.1.4	ABR Mechanisms .....	105
3.5.1.5	EFCI Marking .....	106
3.5.1.6	Relative Rate Marking .....	106
3.5.1.7	Explicit Rate Marking .....	106
3.5.1.8	Reactive Switch Control .....	107
3.5.1.9	VS/VD Behavior .....	108
3.5.2	ERC Unit Functional Overview .....	110
3.5.2.1	Processor .....	111
3.5.2.2	Message Interface .....	111
3.5.2.3	ERC Mailbox .....	113

<b>Table of Contents</b>		<b>Page</b>
3.5.2.4	AVT (Context RAM) .....	114
3.5.2.5	Scan Unit .....	114
3.6	Internal Tables .....	116
3.6.1	Table Overview .....	116
3.6.2	LCI: Local Connection Identifier Table .....	117
3.6.3	QCT: Queue Configuration Table .....	117
3.6.4	QPT: Queue Parameter Table .....	117
3.6.5	TCT: Traffic Class Table .....	117
3.6.6	SBOC: Scheduler Block Occupancy Table .....	117
3.6.7	SCT: Scheduler Configuration Table .....	118
3.6.8	MGT: Merge Group Table .....	118
3.6.9	AVT: ABR/VBR Configuration Table .....	118
3.6.9.1	AVT Context RAM Organization and Addressing .....	118
3.6.9.2	AVT Context RAM Section for ABR-VS/VD Support .....	120
3.6.9.3	AVT Context RAM Section for ABR-ER Support .....	124
3.6.9.4	AVT Context RAM Section for VBR Shaping Support .....	126
3.6.9.5	Common AVT CONFIG Field .....	128
3.6.10	ERC Message Interface .....	129
3.6.10.1	RM_Cell FIFO Organization (IOP/FW View) .....	129
3.6.10.2	Emit FIFO Organization (IOP/FW View) .....	130
3.6.11	QCIT: Congestion Indication Table .....	131
<b>4</b>	<b>Operational Description</b> .....	<b>132</b>
4.1	Basic Device Initialization .....	132
4.2	Basic Traffic Management Initialization .....	132
4.2.1	Setup of Queues .....	137
4.2.2	Programming Queue Scheduler Rates and Granularities .....	138
4.2.2.1	Scheduler Block Scheduler .....	138
4.2.2.2	Programming the Scheduler Block Rates .....	138
4.2.2.3	Programming the Common Real-Time Bypass .....	141
4.2.2.4	Programming the SDRAM Refresh Empty Cell Cycles .....	141
4.2.2.5	Programming the PCR Limiter .....	141
4.2.2.6	Programming the Leaky Bucket Shaper .....	144
4.2.2.7	Guaranteed Cell Rates and WFQ Weight Factors .....	146
4.2.3	ABM-P Configuration Example .....	147
4.2.4	Normal Operation .....	148
4.2.5	Bandwidth Reservation .....	149
4.2.5.1	Bandwidth Reservation Example .....	149
4.2.6	Buffer Reservation .....	150
4.2.7	Support of Standard ATM Service Categories .....	151
4.2.7.1	CBR Connections .....	151
4.2.7.2	rt-VBR Connections .....	151
4.2.7.3	nrt-VBR Connections .....	151

<b>Table of Contents</b>		<b>Page</b>
4.2.7.4	ABR Connections .....	151
4.2.7.5	UBR+ Connections .....	152
4.2.7.6	GFR Connections .....	152
4.2.7.7	UBR Connections .....	152
4.2.7.8	Generic Service Classes .....	153
4.2.8	Configuration of ABR Mechanisms .....	153
4.2.8.1	EFCI Marking .....	153
4.2.8.2	Relative Rate Marking .....	153
4.2.8.3	Explicit Rate Marking .....	153
4.2.8.4	VS/VD .....	153
4.2.9	Enhanced Rate Control Unit Initialization .....	153
4.2.9.1	Firmware Parameter Configuration .....	154
4.2.9.2	ERC Operation Modes Overview .....	155
4.3	Connection Teardown Example .....	156
4.4	AAL5 Packet Insertion/Extraction .....	156
4.4.1	AAL5 Packet Insertion .....	156
4.4.2	AAL5 Packet Extraction .....	156
4.5	Exception Handling .....	158
<b>5</b>	<b>Interface Description .....</b>	<b>159</b>
5.1	UTOPIA L2 Interfaces (PHY side) .....	159
5.1.1	URXU: UTOPIA Receive Upstream (PHY side) .....	159
5.1.2	UTXD: UTOPIA Transmit Downstream (PHY side) .....	160
5.1.3	UTOPIA Port/Address Mapping (PHY side) .....	162
5.1.4	Functional UTOPIA Timing (PHY side) .....	163
5.1.5	UTOPIA Master Mode Polling Scheme (PHY side) .....	164
5.1.6	UTOPIA Cell Format (PHY side) .....	165
5.1.6.1	UTOPIA Level 2 Standard Cell Formats .....	165
5.1.6.2	LCI Mapping Mode: VPI Mode .....	166
5.1.6.3	LCI Mapping Mode: VCI Mode .....	166
5.1.6.4	LCI Mapping Mode: Infineon Mode .....	167
5.1.6.5	LCI Mapping Mode: Address Reduction Mode .....	167
5.2	UTOPIA L2 Interface (Backplane side) .....	169
5.2.1	URXD: UTOPIA Receive Downstream (Backplane side) .....	169
5.2.2	UTXU: UTOPIA Transmit Upstream (Backplane side) .....	169
5.2.3	UTOPIA Port/Address Mapping (Backplane side) .....	169
5.2.4	Functional UTOPIA Timing (Backplane side) .....	169
5.2.5	UTOPIA Master Mode Polling Scheme (Backplane side) .....	169
5.2.6	UTOPIA Cell Format (Backplane side) .....	170
5.3	MPI: Microprocessor Interface .....	170
5.3.1	Intel Style Write Access .....	170
5.3.2	Intel Style Read Access .....	171
5.3.3	Motorola Style Write Access .....	171



<b>Table of Contents</b>		<b>Page</b>
5.3.4	Motorola Style Read Access .....	172
5.3.5	Interrupt Signals .....	172
5.4	External RAM Interfaces .....	173
5.4.1	RAM Configurations .....	173
5.5	SPI: Serial Peripheral Interface .....	177
5.5.1	SPI Read Sequence .....	177
5.6	QCI: Queue Congestion Indication Interface .....	177
5.7	Test Interface .....	179
5.8	Clock and Reset Interface .....	179
5.8.1	Clocking .....	179
5.8.2	Reset .....	179
<b>6</b>	<b>Memory Structure .....</b>	<b>180</b>
<b>7</b>	<b>Register Description .....</b>	<b>181</b>
7.1	Overview of the ABM-P Register Set .....	181
7.2	Detailed Register Descriptions .....	194
7.2.1	Cell Flow Test Registers .....	194
7.2.2	SDRAM Configuration Registers .....	195
7.2.3	Cell Insertion/Extraction and AAL5 Control Registers .....	196
7.2.4	Buffer Occupation Counter Registers .....	212
7.2.5	Buffer Threshold and Occupation Capture Registers .....	214
7.2.6	Configuration Register .....	219
7.2.7	Backpressure Control Registers .....	220
7.2.8	QCI Control Registers .....	229
7.2.9	DBA Control Registers .....	231
7.2.10	LCI Table Transfer Registers .....	237
7.2.11	Traffic Class Table Transfer Registers .....	241
7.2.12	Queue Configuration Table Transfer Registers .....	258
7.2.13	Scheduler Block Occupancy Table Transfer Registers .....	270
7.2.14	Merge Group Table Transfer Registers .....	277
7.2.15	Mask Registers .....	282
7.2.16	Queue Congestion Indication Table .....	286
7.2.17	Rate Shaper CDV Registers .....	288
7.2.18	Queue Parameter Table Mask Registers .....	289
7.2.19	Scheduler Configuration Register .....	295
7.2.20	Queue Parameter Table Transfer Registers .....	296
7.2.21	Scheduler Block Configuration Table Transfer/Mask Registers SDRAM Refresh Registers UTOPIA Port Select of Common Real Time Queue Registers	306
7.2.22	Scheduler Block Enable Registers .....	319
7.2.23	Common Real Time Queue Rate Registers .....	327
7.2.24	AVT Table Registers .....	329

<b>Table of Contents</b>		<b>Page</b>
7.2.25	PLL Control Registers . . . . .	341
7.2.26	ERC Register Access Control . . . . .	346
7.2.27	External RAM Test Registers . . . . .	349
7.2.28	ABM-P Version Code Registers . . . . .	354
7.2.29	Interrupt Status/Mask Registers . . . . .	356
7.2.30	RAM Select Registers . . . . .	368
7.2.31	Global ABM-P Status and Mode Registers . . . . .	372
7.2.32	UTOPIA Configuration Registers . . . . .	379
7.2.33	Test Registers/Special Mode Registers . . . . .	397
<b>8</b>	<b>Electrical Characteristics . . . . .</b>	<b>398</b>
8.1	Absolute Maximum Ratings . . . . .	398
8.2	Operating Range . . . . .	398
8.3	DC Characteristics . . . . .	399
8.4	AC Characteristics . . . . .	401
8.4.1	Microprocessor Interface Timing Intel Mode . . . . .	403
8.4.1.1	Microprocessor Write Cycle Timing (Intel) . . . . .	403
8.4.1.2	Microprocessor Read Cycle Timing (Intel) . . . . .	404
8.4.2	Microprocessor Interface Timing Motorola Mode . . . . .	405
8.4.2.1	Microprocessor Write Cycle Timing (Motorola) . . . . .	405
8.4.2.2	Microprocessor Read Cycle Timing (Motorola) . . . . .	406
8.4.3	UTOPIA Interface . . . . .	408
8.4.4	CPR SSRAM Interface . . . . .	413
8.4.5	CSR SDRAM Interface(s) . . . . .	414
8.4.6	Reset Timing . . . . .	415
8.4.7	Boundary-Scan Test Interface . . . . .	416
8.4.8	SPI Interface . . . . .	417
8.4.9	Queue Congestion Interface (QCI) . . . . .	418
8.5	Capacitances . . . . .	419
8.6	Package Characteristics . . . . .	419
<b>9</b>	<b>Test Mode . . . . .</b>	<b>420</b>
<b>10</b>	<b>Package Outlines . . . . .</b>	<b>422</b>
<b>11</b>	<b>Glossary . . . . .</b>	<b>423</b>

<b>List of Figures</b>	<b>Page</b>
Figure 1-1 Logic Symbol . . . . .	25
Figure 1-2 General System Integration . . . . .	26
Figure 2-1 Pin Configuration (Bottom View) . . . . .	27
Figure 2-2 Pin Configuration (Bottom View) . . . . .	28
Figure 3-1 Sub-System Integration Diagram . . . . .	46
Figure 3-2 Functional Block Diagram . . . . .	47
Figure 3-3 Logical Block Diagram (One Direction) . . . . .	48
Figure 3-5 LCI Building Patterns . . . . .	52
Figure 3-6 LCI Building Patterns (VPI only) . . . . .	54
Figure 3-7 Clocking System Overview . . . . .	56
Figure 3-8 DPLL Structure . . . . .	57
Figure 3-9 Reset System Overview . . . . .	59
Figure 3-10 ABM-P in Bi-directional Mode . . . . .	60
Figure 3-11 ABM-P in Uni-directional Mode Using both Cores . . . . .	61
Figure 3-12 ABM-P in Uni-directional Mode Using one Core . . . . .	62
Figure 3-13 Connection Identifiers in Mini-Switch Configuration . . . . .	63
Figure 3-14 Cell Acceptance and Scheduling . . . . .	64
Figure 3-15 Buffer Manager Tables . . . . .	65
Figure 3-16 Queue Assignment to Traffic Classes and Scheduler Blocks . . . . .	67
Figure 3-18 Buffer Management with per Queue Minimum Buffer Reservation . . . . .	75
Figure 3-19 Buffer Threshold with Hysteresis . . . . .	76
Figure 3-21 Functional Structure of the Hierarchical Queue Scheduler . . . . .	81
Figure 3-22 Scheduler Block Structure . . . . .	82
Figure 3-23 Behavior of Different Scheduler Types . . . . .	83
Figure 3-25 Scheduler Behavior Example . . . . .	85
Figure 3-26 Shaping and Policing at Network Boundaries . . . . .	86
Figure 3-27 Ideal ABM-P Shaper Output . . . . .	88
Figure 3-28 Ideal and Real ABM-P Shaper Output . . . . .	88
Figure 3-31 VC Merge Scheduling . . . . .	91
Figure 3-32 Scheduler Block Usage at Switch Output . . . . .	93
Figure 3-33 Scheduler Block Usage at Switch Input . . . . .	94
Figure 3-34 User and RM Cell Flows of an ABR Connection . . . . .	96
Figure 3-35 Source Behavior of an Explicit Rate controlled ABR Connection . . . . .	97
Figure 3-36 Example Network Configuration . . . . .	98
Figure 3-38 ACR calculation at BRM Cell Receive . . . . .	102
Figure 3-39 ACR calculation at FRM Cell Send . . . . .	103
Figure 3-41 RM and User Cell Sequence: General Case . . . . .	104
Figure 3-42 RM and User Cell Sequence: Worst Case . . . . .	104
Figure 3-44 ABR Mechanisms . . . . .	105
Figure 3-45 Reactive Switch Control Example . . . . .	107
Figure 3-46 Distribution of VS/VD Function in a Switch . . . . .	109
Figure 3-47 ERC Unit . . . . .	110

<b>List of Figures</b>	<b>Page</b>
Figure 3-48 Message Interface between ERC Unit and ABM-P Core.....	111
Figure 3-49 SCAN Timer Generation .....	114
Figure 3-51 Table Access Overview .....	116
Figure 3-52 AVT Context RAM Addressing Scheme .....	119
Figure 4-1 Parameters for Connection Setup (bit field width indicated) .....	133
Figure 4-7 ABM-P Application Example: DSLAM .....	147
Figure 4-9 Example of Threshold Configuration .....	150
Figure 4-12 AAL5 Extraction: End of packet, Trailer and Status Byte.....	157
Figure 5-1 UTOPIA Receive Upstream Master Mode .....	159
Figure 5-2 UTOPIA Receive Upstream Slave Mode .....	159
Figure 5-3 UTOPIA Transmit Downstream Master Mode .....	161
Figure 5-4 UTOPIA Transmit Downstream Slave Mode .....	161
Figure 5-5 Intel Style Write Access .....	170
Figure 5-6 Intel Style Read Access .....	171
Figure 5-7 Motorola Style Write Access .....	171
Figure 5-8 Motorola Style Read Access .....	172
Figure 5-9 SPI Read Sequence .....	177
Figure 5-10 QCI Interface .....	178
Figure 7-1 Table Access Overview .....	182
Figure 8-1 Input/Output Waveform for AC Measurements .....	401
Figure 8-2 Microprocessor Interface Write Cycle Timing (Intel) .....	403
Figure 8-3 Microprocessor Interface Read Cycle Timing (Intel) .....	404
Figure 8-4 Microprocessor Interface Write Cycle Timing (Motorola).....	405
Figure 8-5 Microprocessor Interface Read Cycle Timing (Motorola).....	406
Figure 8-6 Setup and Hold Time Definition (Single- and Multi-PHY).....	408
Figure 8-7 Tristate Timing (Multi-PHY, Multiple Devices Only).....	408
Figure 8-8 SSRAM Interface Generic Timing Diagram .....	413
Figure 8-9 Generic SDRAM Interface Timing Diagram .....	414
Figure 8-10 Reset Timing .....	415
Figure 8-11 Boundary-Scan Test Interface Timing Diagram.....	416
Figure 8-12 SPI Interface Timing Diagram .....	417
Figure 8-13 QCI Interface Timing Diagram .....	418
Figure 9-1 Block Diagram of Test Access Port and Boundary Scan Unit .....	420

<b>List of Tables</b>	<b>Page</b>
Table 2-1	Ball Definitions and Functions . . . . . 29
Table 3-4	Maximum ABM-P Throughput and Speedup . . . . . 48
Table 3-17	Threshold and Occupancy Counter Table . . . . . 70
Table 3-20	Statistical Counters . . . . . 80
Table 3-24	Guaranteed Rates for each ATM Service Category . . . . . 84
Table 3-29	Summary of VBR Shaping Parameters . . . . . 89
Table 3-30	VBR Conformance Definitions . . . . . 89
Table 3-37	ABR Parameters . . . . . 99
Table 3-40	In-rate and Out-of-rate Cells . . . . . 103
Table 3-43	ABR Mechanisms Supported in the ABM-P . . . . . 105
Table 3-50	Timer Values for Clock Generation . . . . . 115
Table 3-53	AVT Context Table: ABR-VS/VD (Table Layout) . . . . . 120
Table 3-54	AVT Context Table: ABR-VS/VD Parameter Description . . . . . 121
Table 3-55	AVT Context Table: ABR-ER (Table Layout) . . . . . 124
Table 3-56	AVT Context Table: ABR-ER Parameter Description . . . . . 125
Table 3-57	AVT Context Table: VBR Shaping (Table Layout) . . . . . 126
Table 3-58	AVT Context Table: VBR Shaping Parameter Description . . . . . 126
Table 3-59	Config(6:0) Bit Map . . . . . 128
Table 3-60	RM Cell FIFO Entry (16 bit IOP View) . . . . . 129
Table 3-61	Emit FIFO Entry for Emit Events . . . . . 130
Table 3-62	Emit FIFO Entry for Time-out Events in VS/VD Mode . . . . . 130
Table 3-63	Emit FIFO Entry for Time-out Events in ER Mode . . . . . 130
Table 4-2	Scheduler Block Rate Limits . . . . . 139
Table 4-3	SB Rate Calculation Examples for SYSCLK = 51.84 MHz . . . . . 140
Table 4-4	Minimum Shaper Rates as a Function of TstepC and SYSCLK . . . . . 143
Table 4-5	Shaper Accuracy as a Function of desired PCR and TstepC . . . . . 144
Table 4-6	Maximum BT as a Function of TstepC and SYSCLK . . . . . 145
Table 4-8	Number of Possible Connections per PHY . . . . . 150
Table 4-10	Firmware Parameters . . . . . 154
Table 4-11	Operation Modes per Connection . . . . . 155
Table 4-13	AAL5 Status Byte . . . . . 157
Table 5-1	Port/Address Mapping . . . . . 162
Table 5-2	Port Polling Sequence . . . . . 164
Table 5-3	Standardized UTOPIA Level 2 Cell Format (16-bit) . . . . . 165
Table 5-4	Standardized UTOPIA Level 2 Cell Format (16-bit): OAM Cells . . . . . 165
Table 5-5	Standardized UTOPIA Level 2 Cell Format (16-bit) . . . . . 166
Table 5-6	Standardized UTOPIA Level 2 Cell Format (16-bit) . . . . . 166
Table 5-7	Standardized UTOPIA Level 2 Cell Format (16-bit) . . . . . 167
Table 5-8	Standardized UTOPIA Level 2 Cell Format (16-bit) . . . . . 167
Table 5-9	External RAM Sizes . . . . . 173
Table 5-10	SSRAM Configuration Examples . . . . . 174
Table 5-11	SDRAM Configuration Examples . . . . . 175

<b>List of Tables</b>	<b>Page</b>
Table 5-12	SSRAM and SDRAM Type Examples . . . . . 176
Table 5-13	Serial SPI Bus EEPROM Type Example . . . . . 177
Table 7-1	Color Convention for Internal Table Field Illustration . . . . . 183
Table 7-2	ABM-P Registers Overview . . . . . 183
Table 7-3	External RAM Sizes . . . . . 215
Table 7-5	WAR Register Mapping for DTC Table access . . . . . 235
Table 7-4	Registers DTC Upstream/Downstream Table Access . . . . . 235
Table 7-7	WAR Register Mapping for LCI Table Access . . . . . 237
Table 7-6	Registers for LCI Table Access . . . . . 237
Table 7-8	Registers for TCT Table Access . . . . . 241
Table 7-9	WAR Register Mapping for TCT Table Access . . . . . 242
Table 7-10	Registers for Queue Configuration Table Access . . . . . 258
Table 7-11	WAR Register Mapping for LCI Table Access . . . . . 259
Table 7-12	Registers for SBOC Table Access . . . . . 270
Table 7-13	WAR Register Mapping for SBOC Table Access . . . . . 271
Table 7-14	Registers for MGT Table Access . . . . . 277
Table 7-15	WAR Register Mapping for MGT Table Access . . . . . 278
Table 7-17	WAR Register Mapping for DTC Table access . . . . . 286
Table 7-16	Registers QCIT Table Access . . . . . 286
Table 7-18	Registers for QPT1 Upstream Table Access . . . . . 296
Table 7-19	Registers for QPT1 Downstream Table Access . . . . . 296
Table 7-20	WAR Register Mapping for QPT Table Access . . . . . 297
Table 7-21	Registers for QPT2 Upstream Table Access . . . . . 300
Table 7-22	Registers for QPT2 Downstream Table Access . . . . . 300
Table 7-23	WAR Register Mapping for QPT Table Access . . . . . 301
Table 7-24	Registers SCTI Upstream Table Access . . . . . 306
Table 7-25	Registers SCTI Downstream Table Access . . . . . 307
Table 7-26	Registers SCTF Upstream Table Access . . . . . 316
Table 7-27	Registers SCTF Downstream Table Access . . . . . 316
Table 7-28	WAR Register Mapping for SCTFU/SCTFD Table access . . . . . 317
Table 7-29	Registers for AVT Table Access . . . . . 329
Table 7-30	WAR Register Mapping for AVT Table Access . . . . . 330
Table 7-31	Extended RAM Address Range for Test Access . . . . . 351
Table 8-1	Absolute Maximum Ratings . . . . . 398
Table 8-2	Operating Range . . . . . 398
Table 8-3	DC Characteristics . . . . . 399
Table 8-4	Clock Frequencies . . . . . 402
Table 8-5	Microprocessor Interface Write Cycle Timing (Intel) . . . . . 403
Table 8-6	Microprocessor Interface Read Cycle Timing (Intel) . . . . . 404
Table 8-7	Microprocessor Interface Write Cycle Timing (Motorola) . . . . . 405
Table 8-8	Microprocessor Interface Read Cycle Timing (Motorola) . . . . . 406
Table 8-9	Transmit Timing (16-Bit Data Bus, 50 MHz Cell Mode, Single PHY) . 409

<b>List of Tables</b>	<b>Page</b>
Table 8-10 Receive Timing (16-Bit Data Bus, 50 MHz Cell Mode, Single PHY) .	409
Table 8-11 Transmit Timing (16-Bit Data Bus, 50 MHz Cell Mode, Multi-PHY) . .	410
Table 8-12 Receive Timing (16-Bit Data Bus, 50 MHz Cell Mode, Multi-PHY) . .	411
Table 8-13 SSRAM Interface AC Timing Characteristics . . . . .	413
Table 8-14 SDRAM Interface AC Timing Characteristics . . . . .	414
Table 8-15 Reset Timing . . . . .	415
Table 8-16 Boundary-Scan Test Interface AC Timing Characteristics . . . . .	416
Table 8-17 SPI Interface AC Timing Characteristics . . . . .	417
Table 8-18 QCI Interface AC Timing Characteristics . . . . .	418
Table 8-20 Thermal Package Characteristics . . . . .	419
Table 8-19 Capacitances . . . . .	419

<b>List of Registers</b>		<b>Page</b>
Register 1	UCFTST/DCFTST .....	194
Register 2	URCFG/DRCFG .....	195
Register 3	UA5TXHD0/DA5TXHD0 .....	196
Register 4	UA5TXHD1/DA5TXHD1 .....	198
Register 5	UA5TXDAT0/DA5TXDAT0 .....	200
Register 6	UA5TXDAT1/DA5TXDAT1 .....	201
Register 7	UA5TXTR/DA5TXTR .....	202
Register 8	UA5XCMD/DA5XCMD .....	203
Register 9	UA5RXHD0/DA5RXHD0 .....	204
Register 10	UA5RXHD1/DA5RXHD1 .....	206
Register 11	UA5RXDAT0/DA5RXDAT0 .....	208
Register 12	UA5RXDAT1/DA5RXDAT1 .....	209
Register 13	UA5SARS/DA5SARS .....	210
Register 14	UBufferOcc/DBufferOcc .....	212
Register 15	UBufferOccNg/DBufferOccNg .....	213
Register 16	UBufMax/DBufMax .....	214
Register 17	UMAC/DMAC .....	216
Register 18	UMIC/DMIC .....	217
Register 19	CLP1DIS .....	218
Register 20	CONFIG .....	219
Register 21	UUBPTH0 .....	220
Register 22	UUBPTH1 .....	221
Register 23	UUBPTH2 .....	222
Register 24	UUBPTH3 .....	223
Register 25	UBPEI .....	224
Register 26	DUBPTH0 .....	225
Register 27	DUBPTH1 .....	226
Register 28	DUBPTH2 .....	227
Register 29	DUBPTH3 .....	228
Register 30	DQCIC .....	229
Register 31	DSBT1 .....	231
Register 32	DSBT2 .....	232
Register 33	DSBT3 .....	233
Register 34	DSBT4 .....	234
Register 35	DTCT .....	236
Register 36	LCI0 .....	238
Register 37	LCI1 .....	239
Register 38	LCI2 .....	240
Register 39	TCT0 .....	244
Register 40	TCT1 .....	247
Register 41	TCT2 .....	250
Register 42	TCT3 .....	253
Register 43	QCT0 .....	260
Register 44	QCT1 .....	261
Register 45	QCT2 .....	264
Register 46	QCT3 .....	266
Register 47	QCT4 .....	267
Register 48	QCT5 .....	268
Register 49	QCT6 .....	269
Register 50	SBOC0 .....	272
Register 51	SBOC1 .....	273



<b>List of Registers</b>		<b>Page</b>
Register 52	SBOC2 .....	274
Register 53	SBOC3 .....	275
Register 54	SBOC4 .....	276
Register 55	MGT0 .....	279
Register 56	MGT1 .....	280
Register 57	MGT2 .....	281
Register 58	MASK0/MASK1 .....	282
Register 59	MASK2/MASK3 .....	283
Register 60	MASK4/MASK5 .....	284
Register 61	MASK6 .....	285
Register 62	QCIT .....	287
Register 63	UCDV/DCDV .....	288
Register 64	UQPTM0/DQPTM0 .....	289
Register 65	UQPTM1/DQPTM1 .....	290
Register 66	UQPTM2/DQPTM2 .....	291
Register 67	UQPTM3/DQPTM3 .....	292
Register 68	UQPTM4/DQPTM4 .....	293
Register 69	UQPTM5/DQPTM5 .....	294
Register 70	USCONF/DSCONF .....	295
Register 71	UQPT1T0/DQPT1T0 .....	298
Register 72	UQPT1T1/DQPT1T1 .....	299
Register 73	UQPT2T0/DQPT2T0 .....	302
Register 74	UQPT2T1/DQPT2T1 .....	303
Register 75	UQPT2T2/DQPT2T2 .....	304
Register 76	UQPT2T3/DQPT2T3 .....	305
Register 77	USADR/DSADR .....	308
Register 78	USCTI/DSCTI .....	309
Register 79	UECRI/DECRI .....	312
Register 80	UECRF/DECRF .....	313
Register 81	UCRTQ/DCRTQ .....	314
Register 82	USCTFM/DSCTFM .....	315
Register 83	USCTFT/DSCTFT .....	318
Register 84	USCEN0/DSCEN0 .....	319
Register 85	USCEN1/DSCEN1 .....	320
Register 86	USCEN2/DSCEN2 .....	321
Register 87	USCEN3/DSCEN3 .....	322
Register 88	USCEN4/DSCEN4 .....	323
Register 89	USCEN5/DSCEN5 .....	324
Register 90	USCEN6/DSCEN6 .....	325
Register 91	USCEN7/DSCEN7 .....	326
Register 92	UCRTRI/DCRTRI .....	327
Register 93	UCRTRF/DCRTRF .....	328
Register 94	ERCT0 .....	331
Register 95	ERCT1 .....	332
Register 96	ERCM0 .....	333
Register 97	ERCM1 .....	334
Register 98	ERCMB0 .....	335
Register 99	ERCMB1 .....	336
Register 100	ERCMB2 .....	337
Register 101	ERCCONF0 .....	338
Register 102	ERCCONF1 .....	340

<b>List of Registers</b>	<b>Page</b>
Register 103 PLL1CONF .....	341
Register 104 PLL2CONF .....	343
Register 105 PLLTST .....	345
Register 106 ERCRAC .....	346
Register 107 ERCRAM .....	348
Register 108 EXTRAMD0 .....	349
Register 109 EXTRAMD1 .....	350
Register 110 EXTRAMA0 .....	351
Register 111 EXTRAMA1 .....	352
Register 112 EXTRAMC .....	353
Register 113 VERL .....	354
Register 114 VERH .....	355
Register 115 ISRU .....	356
Register 116 ISRD .....	359
Register 117 ISRC .....	362
Register 118 IMRU .....	363
Register 119 IMRD .....	364
Register 120 IMRC .....	365
Register 121 ISRDBA .....	366
Register 122 IMRDBA .....	367
Register 123 MAR .....	368
Register 124 WAR .....	370
Register 125 USTATUS .....	372
Register 126 MODE1 .....	373
Register 127 MODE2 .....	377
Register 128 UTRXCFG .....	379
Register 129 UUTRXP0 .....	381
Register 130 UUTRXP1 .....	382
Register 131 UUTRXP2 .....	383
Register 132 DUTRXP0 .....	384
Register 133 DUTRXP1 .....	385
Register 134 DUTRXP2 .....	386
Register 135 UUTTXCFG .....	387
Register 136 DUTTXCFG .....	389
Register 137 UUTTXP0 .....	391
Register 138 UUTTXP1 .....	392
Register 139 UUTTXP2 .....	393
Register 140 DUTTXP0 .....	394
Register 141 DUTTXP1 .....	395
Register 142 DUTTXP2 .....	396
Register 143 TEST .....	397

## Preface

The purpose of this Data Sheet is to provide comprehensive information about the ABM-P device regarding system-level integration, hardware/board design, and software driver aspects.

### Organization of this Document

This Data Sheet is divided into 13 chapters and two appendices. It is organized as follows:

- **Chapter 1, Overview**  
Gives a general description of the product and its family, lists the key features, and presents some typical applications.
- **Chapter 2, Pin Descriptions**  
Lists pin locations with associated signals, categorizes signals according to function, and describes the signals.
- **Chapter 3, Functional Description**  
Gives descriptions of major functional blocks, configuration tables, and global device functions.
- **Chapter 4, Operational Description**  
Describes basic initialization and operation procedures.
- **Chapter 5, Interface Description**  
Gives a functional description of all interfaces.
- **Chapter 6, Memory Structure**
- **Chapter 7, Register Description**  
Lists all registers and tables with functional description.
- **Chapter 8, Electrical Characteristics**  
Provides detailed information about electrical characteristics and interface timings.
- **Chapter 9, Test Mode**
- **Chapter 10, Package Outlines**
- **Chapter 11, Glossary**

#### **Related Documentation**

- [1] ITU-T Recommendation I.371, Traffic Control and Congestion Control in B-ISDN, 2nd Release, March 1996.
- [2] ATMF, Traffic Management Specification 4.1, March 1999.
- [3] ATMF, UTOPIA Level 1 Specification Version 2.01, March 1994.
- [4] ATMF, UTOPIA Level 2 Specification Version 1, June 1995.

#### **Your Comments**

We welcome your comments on this document. We are continuously trying improving our documentation. Please send your remarks and suggestions by e-mail to [sc.docu\\_comments@infineon.com](mailto:sc.docu_comments@infineon.com)

Please provide in the subject of your e-mail:

device name (ABM-P), device part number (PXF 4336), device version (Version 1.1),

and in the body of your e-mail:

document type (Data Sheet), issue date (2001-12-17) and document revision number (DS 2).



## **1 Overview**

The ABM-P PXF 4336 Version 1.1 is Infineon's new generation ATM Buffer Manager device. It addresses the performance needs of new multi-service platforms with combined ATM cell and packet-handling applications. The ABM-P manages ATM traffic flowing through multi-service platforms in which voice, video, and data traffic converge. The optimizes the interworking of ATM and higher-layer traffic-management and flow-control schemes. The Enhanced Rate Control (ERC) feature provides maximum link utilization by rate-adaptive schemes such as ABR-ER, ABR-VS/VD, and ABR-RSC. Optional "leaky bucket" shaping per queue provides full VBR support. The ABM-P is useful in applications where extensive ATM traffic management capabilities are required. This includes either distributed or centralized system architectures that cover enterprise and Central Office switches, DSLAMs, and ATM line cards for routers and switches.




**ATM Buffer Manager  
ABM-P**

**ABM-P  
PXF 4336 V1.1**

**1.1 Features**

- ATM Traffic Management processing support up to STM-4/OC-12 equivalent bandwidth
- Throughput at UTOPIA Interface up to 687 Mbit/s transmit, 795 Mbit/s receive
- Speed-up factor relative to STM-4/OC12: 1.32
- Uni-directional mode with combined resources of both directions (optional)
- 256K cells buffer per direction (configurable in guaranteed and shared buffer)
- Up to 16384 connections arbitrarily assignable to queues for sharing connections and saving resources
- Up to 8192 queues per direction, individually assignable to schedulers and to traffic classes
- Up to 128 Scheduler Blocks (SB) per direction with programmable service rates, individually assignable to UTOPIA ports
- The ABM-P is cascadable to provide up to 512 schedulers, 32K queues, and 1M cell memories per direction
- Up to 16 traffic classes with individually-selectable thresholds for highest service differentiation
- Up to 48 ports per UTOPIA Interface
- Standards-compliant support for the following ATM Forum service categories: CBR, rt-VBR, nrt-VBR, GFR, ABR (EFCI, CI/NI relative marking, ER, VS/VD, RSC), UBR, UBR+
- Generic PHB (Per Hop Behavior) characteristics are configurable (PHB traffic class is not standardized)
- Configurable cell-address translation modes



Type	Package
ABM-P PXF 4336 V1.1	BGA-456

### 1.1.1 Queueing Functions

- Per-VC queueing for up to 8192 connections per direction for optimal connection isolation
- Optional queue sharing
- Guaranteed per-queue minimum buffer reservation
- Cell acceptance based on programmable threshold sets with hysteresis evaluation
- Threshold sets for individual queues, traffic classes, schedulers, and global buffer for optimized buffer sharing
- Per VC Packet Discard, including Early Packet Discard (EPD) & Partial Packet Discard (PPD) thresholds for Guaranteed Frame Rate (GFR) support
- Cell Loss Priority (CLP) aware selective discard thresholds
- EFICI and CI/NI support thresholds
- UTOPIA input port backpressure thresholds without head-of-line-blocking
- Per queue and scheduler block congestion indication/avoidance thresholds

### 1.1.2 Scheduling Functions

- Multistage scheduling units with
  - Work conservative Weighted Round Robin (WRR) scheduling stage for 128 Scheduler Blocks
  - Each Scheduler Block comprising of
    - a Weighted Fair Queueing (WFQ) scheduler with 16320 programmable weight factors for each queue, providing rate guarantees and fairness in bandwidth allocation
    - a high priority Round Robin (RR) scheduler for real-time traffic
    - a low priority RR scheduler for best effort traffic
- Additional common real-time bypass queue for each direction, for cascading multiple ABM-Ps
- Selectable Peak Cell Rate (PCR) shaping for each queue with minimum 2.62 Kbps and maximum 343 Mbit/s at 52 MHz clock (65472 programmable rates)
- Selectable Variable Bit Rate (VBR.1.2.3) leaky bucket shaping for up to 2046 queues
- VC merge function for up to 128 merge groups (arbitrary queues per merge group) for Multi Protocol Label Switching (MPLS) applications
- Support for Dynamic Bandwidth Allocation with SB occupancy threshold monitoring
- SB scheduler overbooking possibility

### 1.1.3 Interfaces

- Two external SDRAM Interfaces for cell storage, one for upstream and one for downstream direction (up to 256 K cell buffer per direction)
- One common cell pointer SSRAM Interface
- Multiport UTOPIA Level 2 Interface in up- and downstream direction conforming to the specifications of the ATM Forum [4]

- 4-cell FIFO buffer at UTOPIA receive interfaces for clock synchronization (head-of-line blocking-free)
- 64-cell buffer logical queuing for up to 48 PHYs at UTOPIA transmit interfaces (head-of-line blocking-free)
- 16-bit Microprocessor Interface, configurable as Intel or Motorola type (with AAL5 packet insertion/extraction support)
- Queue Congestion Indication Interface
- JTAG Boundary Scan Interface
- SPI Interface for EPROM (optionally, required for ABR ER and ABR VS/VD support)

#### **1.1.4 Supervision Functions**


- Internal pointer supervision
- Cell-header protection function

#### **1.1.5 Technology**

- Supply voltages 1.8 V (core) and 3.3 V (I/Os)
- Ball Grid Array BGA-456 package (Plastic BGA (35 mm)<sup>2</sup>)
- Temperature range -40°C to 85°C
- Power dissipation 2.0 W (typical)



**1.2 Logic Symbol**




**Figure 1-1 Logic Symbol**

### 1.3 Typical Applications

The ABM-P device is designed for traffic management on line cards and trunk cards such as are used in:


- ATM Switches
- DSLAMs, DLCs
- Multi-Service Access Switches
- 3G Wireless Infrastructure



**Figure 1-2 General System Integration**



**2.2 Pin Diagram with Functional Groupings**



**Figure 2-2 Pin Configuration (Bottom View)**

## 2.3 Pin Definitions and Functions

**Table 2-1** lists and explains all pins/balls organized into functional groups. **Table 2-1** uses the following naming conventions:

<b>Ball No.</b>	Ball Number with respect to package outline (see <a href="#">Figure 2-1</a> )
<b>Symbol</b>	Signal Name
<b>Type</b>	Type of pin/ball:
	I Input pin
	I <sub>PD</sub> Input pin (Internal Pull-Down Transistor)
	I <sup>PU</sup> Input pin (Internal Pull-Up Transistor)
	O Output pin (Push/Pull)
	O (oD) Output pin (Open Drain)
	O (tri) Output pin (TriState)
<b>Function</b>	Functional pin/ball description

Note: The ABM-P signal pins are not 5 V I/O tolerant. For further details refer to “[DC Characteristics](#)” on [Page 399](#).

**Table 2-1 Ball Definitions and Functions**

Ball No.	Symbol	Type	Function
----------	--------	------	----------

### 2.3.1 Common System Clock Supply (6 pins)

P24	SYCLK	I	System Clock This clock signal feeds DPLL1 and DPLL2 and the internal ABM-P Core Clock, depending on signal SYCLKSEL.
N24	SYCLKSEL	I <sub>PD</sub>	Internal ABM-P Core Clock Source Select: 'H': Internal Core Clock is supplied by signal SYCLK 'L': Internal Core Clock is supplied by DPLL1
M25	ERCCLK	I	Alternative ERC Clock Supply It is recommended to connect this signal to V <sub>SS</sub> if not used.

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
M26	ERCCLKSEL	I <sub>PD</sub>	Internal Alternative ERC Clock Source Select: 'H': ERC unit alternative clock is supplied by signal 'ERCCLK'. 'L': ERC unit alternative clock is supplied by DPLL2.
L24	ERCFREQSEL	I <sub>PD</sub>	Internal ERC Clock Source Select: 'H': Asynchronous ERC Operation ERC unit clock is supplied by signal 'ERCCLK' or DPLL2. 'L': Synchronous ERC Operation ERC unit clock is supplied by internal core clock (signal 'SYSCLK' or DPLL1).
D21	RAMCLK	O	Reference clock for external RAM (CSRU, CSRD and CPR)

**2.3.2 UTOPIA Receive Interface Upstream (Master/Slave) (32 pins)**

G4, G3, G2, G1, F4, F3, F2, F1, E4, E3, E2, E1, D2, D1, C2, C1	15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	URXDATU(15:0)	I	UTOPIA Receive Data Bus Upstream (from PHY)
A1	URXPRTYU		I <sub>PD</sub>	UTOPIA Receive Odd Parity of URXDATU(15:0) (PHY side)

**Table 2-1 Ball Definitions and Functions (cont'd)**

<b>Ball No.</b>	<b>Symbol</b>	<b>Type</b>	<b>Function</b>
A5, C4, B4, A4, B3	4, 3, 2, 1, 0 URXADRU(4:0)	I/O <sub>PD</sub>	UTOPIA Receive Address Bus (PHY side) Master Mode: output Slave Mode: input
A3, B2, A2, C3	3, 2, 1, 0 URXENBU(3:0)	I/O <sup>PU</sup>	UTOPIA Receive Enable Bus (PHY side) Master Mode: output Slave Mode: input
B6, A6, D5, C5	3, 2, 1, 0 URXCLAVU(3:0)	I/O <sub>PD</sub>	UTOPIA Receive CLAV Bus (PHY side) Master Mode: input Slave Mode: output
D4	URXSOCU	I <sub>PD</sub>	UTOPIA Receive Start of Cell signal (PHY side)
B1	URXCLKU	I	UTOPIA Receive Clock signal (PHY side)

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
----------	--------	------	----------

**2.3.3 UTOPIA Transmit Interface Downstream (Master/Slave) (32 pins)**

W1, Y4, Y3, Y2, Y1, AA4, AA3, AA2, AB4, AB3, AB2, AB1, AC3, AC2, AC1, AD2	15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	UTXDATD(15:0)	O	UTOPIA Transmit Data Bus Downstream (to PHY)
AE2	UTXPRTYD		O <sub>PD</sub>	UTOPIA Transmit Odd Parity of UTXDATD(15:0) (PHY side)
AE3, AF4, AE4, AD4, AF5	4, 3, 2, 1, 0	UTXADDR(4:0)	I/O <sub>PD</sub>	UTOPIA Transmit Address Bus (PHY side) Master Mode: output Slave Mode: input
AD5, AC5, AF6, AE6	3, 2, 1, 0	UTXENBD(3:0)	I/O <sup>PU</sup>	UTOPIA Transmit Enable Bus (PHY side) Master Mode: output Slave Mode: input



**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
AC4, AF1, AF2, AF3	3, 2, 1, 0  UTXCLAVD(3:0)	I/O <sub>PD</sub>	UTOPIA Transmit CLAV Bus (PHY side) Master Mode: input Slave Mode: output
AD3	UTXSOC	O <sub>PD</sub>	UTOPIA Transmit Start of Cell signal (PHY side)
AE1	UTXCLKD	I	UTOPIA Transmit Clock signal (PHY side)

**2.3.4 UTOPIA Receive Interface Downstream (Master/Slave) (32 pins)**

AD24, AF26, AE26, AD26, AD25, AC26, AC25, AC24, AB26, AB25, AB24, AB23, AA26, AA25, AA23, Y26	15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0  URXDATD(15:0)	I	UTOPIA Receive Data Bus Downstream (from Backplane)
AF24	URXPRTYD	I <sub>PD</sub>	UTOPIA Receive Odd Parity of URXDATD(15:0) (Backplane side)

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
AE21, AF21, AC22, AD22, AE22	4, 3, 2, 1, 0 URXADDR(4:0)	I/O <sub>PD</sub>	UTOPIA Receive Address Bus (Backplane side) Master Mode: output Slave Mode: input
AE20, AF20, AC21, AD21	3, 2, 1, 0 URXENBD(3:0)	I/O <sup>PU</sup>	UTOPIA Receive Enable Bus (Backplane side) Master Mode: output Slave Mode: input
AF22, AD23, AE23, AF23	3, 2, 1, 0 URXCLAVD(3:0)	I/O <sub>PD</sub>	UTOPIA Receive CLAV Bus (Backplane side) Master Mode: input Slave Mode: output
AF25	URXSOCD	I <sub>PD</sub>	UTOPIA Receive Start of Cell signal (Backplane side)
AE25	URXCLKD	I	UTOPIA Receive Clock signal (Backplane side)

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
J26, H23, H24, H25, H26, G23, G24, G25, G26, F23, F24, F25, F26, E23, E24, E25	15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	UTXDATU(15:0)	O UTOPIA Transmit Data Bus Upstream (to Backplane)
D24	UTXPRTYU	O <sub>PD</sub>	UTOPIA Transmit Odd Parity of UTXDATU(15:0) (Backplane side)
D23, A26, A25, A24, B24	4, 3, 2, 1, 0	UTXADRU(4:0)	I/O <sub>PD</sub> UTOPIA Transmit Address Bus (Backplane side) Master Mode: output Slave Mode: input
A23, B23, C23, A22	3, 2, 1, 0	UTXENBU(3:0)	I/O <sup>PU</sup> UTOPIA Transmit Enable Bus (Backplane side) Master Mode: output Slave Mode: input

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
C25, C26, B26, B25	3, 2, 1, 0 UTXCLAVU(3:0)	I/O <sub>PD</sub>	UTOPIA Transmit CLAV Bus (Backplane side) Master Mode: input Slave Mode: output
D25	UTXSOCU	O <sub>PD</sub>	UTOPIA Transmit Start of Cell signal (Backplane side)
E26	UTXCLKU	I	UTOPIA Transmit Clock signal (Backplane side)

**2.3.6 Microprocessor Interface (32 pins)**

N25	$\overline{\text{RESET}}$	I	ABM-P Reset
Y25, Y24, Y23, W26, W25, W24, W23, V25, V24, V23, U26, U25, U24, U23, T23, T26	15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0 MPDAT(15:0)	I/O	Microprocessor Data Bus

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function	
T25, T24, R26, R25, R24, P23, P26, P25	7, 6, 5, 4, 3, 2, 1, 0	MPADR(7:0)	I	Microprocessor Address Bus
K24	$\overline{\text{MPWR}}$			
K23	$\overline{\text{MPRD}}$	I	$\overline{\text{RD}}$ when MPMOD=0 (Intel Mode) DS when MPMOD=1 (Motorola Mode).	
J24	$\overline{\text{MPCS}}$	I	Chip Select from Microprocessor.	
J23	$\overline{\text{MPINT}}$	O(oD)	Interrupt Request to Microprocessor. Open drain, needs external pull-up resistor. Inter- rupt pins of several devices can be wired-or together.	
K26	$\overline{\text{MPINTD}}$	O(oD)	Interrupt Request DBA to Microprocessor. Open drain, needs external pull-up resistor. Inter- rupt pins of several devices can be wired-or together. This interrupt signal is exclusively for DBA related events and thus associated to <b>Register 121</b> <b>"ISRDBA" on Page 366.</b>	
K25	MPRDY	O(tri)	Ready Output to Microprocessor for read and write accesses.	
J25	MPMODE	I <sub>PD</sub>	Intel/Motorola select: 'L' Intel type processor 'H' Motorola type processor	

**Table 2-1 Ball Definitions and Functions (cont'd)**

<b>Ball No.</b>	<b>Symbol</b>	<b>Type</b>	<b>Function</b>
-----------------	---------------	-------------	-----------------

**2.3.7 Cell Storage RAM Upstream (50 pins)**

C19, D19, A18, B18, D18, A17, B17, C17, D17, D16, A16, B16, C16, A15, B15, D15, C15, D14, A14, B14, C14, C13, B13, A13, D13, D12, C12, B12, C11, B11, A11, D11	31, 30, 29, 28, 27, 26, 25, 24, 23, 22, 21, 20, 19, 18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	CSRDATU(31:0)	I/O	Data Bus to Cell Storage RAM Upstream
D10	CSRBAU0	O		Cell Storage RAM Bank Address 0 Upstream

**Table 2-1 Ball Definitions and Functions (cont'd)**

<b>Ball No.</b>	<b>Symbol</b>	<b>Type</b>	<b>Function</b>
C10	CSRBAU1	O	Cell Storage RAM Bank Address 1 Upstream
B10, A10, D9, C9, B9, A9, D8, C8, B8, A8, D7, C7	11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	O	Address Bus of Cell Storage RAM Upstream
	CSRADRU(11:0)		
B7	$\overline{\text{CSRCSU}}$	O	Cell Storage RAM Upstream Chip Select
A7	$\overline{\text{CSRRASU}}$	O	Cell Storage RAM Upstream Row Address Strobe
D6	$\overline{\text{CSRCASU}}$	O	Cell Storage RAM Upstream Column Address Strobe
C6	$\overline{\text{CSRWEU}}$	O	Cell Storage RAM Upstream Write Enable

**Table 2-1 Ball Definitions and Functions (cont'd)**

<b>Ball No.</b>	<b>Symbol</b>	<b>Type</b>	<b>Function</b>
-----------------	---------------	-------------	-----------------

**2.3.8 Cell Storage RAM Downstream (50 pins)**

AD6, AC6, AF7, AE7, AD7, AC7, AF8, AD8, AC8, AF9, AE9, AD9, AC9, AF10, AD10, AC10, AC11, AF11, AE11, AD11, AF12, AC12, AD12, AC13, AF13, AE13, AD13, AD14, AF14, AC14, AC15, AD15	31, 30, 29, 28, 27, 26, 25, 24, 23, 22, 21, 20, 19, 18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	CSRDATD(31:0)	I/O	Data Bus to Cell Storage RAM Downstream
AE15	CSRBAD0	O		Cell Storage RAM Bank Address 0 Downstream



**Table 2-1 Ball Definitions and Functions (cont'd)**

<b>Ball No.</b>	<b>Symbol</b>	<b>Type</b>	<b>Function</b>
AF15	CSRBAD1	O	Cell Storage RAM Bank Address 1 Downstream
AD16, AE16, AF16, AC16, AC17, AD17, AE17, AF17, AC18, AD18, AE18, AC19	11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	O	Address Bus of Cell Storage RAM Downstream
	CSRARD(11:0)		
AD19	$\overline{\text{CSRCSD}}$	O	Cell Storage RAM Downstream Chip Select
AE19	$\overline{\text{CSRRASD}}$	O	Cell Storage RAM Downstream Row Address Strobe
AF19	$\overline{\text{CSRCASD}}$	O	Cell Storage RAM Downstream Column Address Strobe
AC20	$\overline{\text{CSRWED}}$	O	Cell Storage RAM Downstream Write Enable

**Table 2-1 Ball Definitions and Functions (cont'd)**

<b>Ball No.</b>	<b>Symbol</b>	<b>Type</b>	<b>Function</b>
-----------------	---------------	-------------	-----------------

**2.3.9 Common Up- and Downstream Cell Pointer RAM (42 pins)**

P2, P1, P4, R4, R3, R2, R1, T3, T2, T1, T4, U4, U3, U2, U1, V4, V3, V1, W4, W3	19, 18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	CPRDAT(19:0)	I/O	Data Bus to Cell Pointer RAM
---	---	--------------	-----	------------------------------

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
J1, J2, J3, J4, K1, K2, K3, K4, L1, L2, L3, M1, M2, M3, M4, N4, N1, N2, N3	18, 17, 16, 15, 14, 13, 12, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, 1, 0	O	Address Bus of Cell Pointer RAM
	CPRADR(18:0)		
H4	$\overline{\text{CPRADSC}}$	O	Cell Pointer RAM Chip Select
H3	$\overline{\text{CPRGW}}$	O	Cell Pointer RAM Write Enable
H2	$\overline{\text{CPROE}}$	O	Cell Pointer RAM Output Enable

**2.3.10 JTAG Boundary Scan (5 pins)**

A21	TDI	I <sup>PU</sup>	Test Data Input.
D22	TCK	I <sup>PU</sup>	Test Clock.
C22	TMS	I <sup>PU</sup>	Test Mode Select.
B21	$\overline{\text{TRST}}$	I <sup>PU</sup>	Test Data Reset
B22	TDO	O	Test Data Output In normal operation, must not be connected.

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
----------	--------	------	----------

**2.3.11 SPI Interface (5 pins)**

B20	SPICS	O	SPI Chip Select
C20	SPICLK	O	SPI Clock
D20	SPISO	O	SPI Serial Out
A19	SPISI	I <sub>PD</sub>	SPI Serial In
B19	IOPRAMSEL	I <sub>PD</sub>	IOP Code RAM Select Must be connected to 'L'.

**2.3.12 QCI Interface (3 pins)**

L26	QCITXDAT	O	QCI Transmit Data
L25	QCITXCLK	I	QCI Clock
L23	QCITXFRAME	I	QCI Transmit Frame Sync

**2.3.13 Production Test (2 pin)**

A20	TSTERCCLK	I <sub>PD</sub>	For device test only, do not connect. Must not be connected in normal operation.
C21	EXTFREEZ	I <sub>PD</sub>	For device test only, do not connect. Must not be connected in normal operation.

**2.3.14 Supply (74 VSS, 32 VDD33 and 14 VDD18 pins)**

**Table 2-1 Ball Definitions and Functions (cont'd)**

Ball No.	Symbol	Type	Function
E5, E6, E9, E10, E13, E14, E17, E18, E21, E22, F5, F22, J5, J22, K5, K22, L11, L12, L13, L14, L15, L16, M11, M12, M13, M14, M15, M16, N5, N11, N12, N13, N14, N15, N16, N22, P5, P11, P12, P13, P14, P15, P16, P22, R11, R12, R13, R14, R15, R16, T11, T12, T13, T14, T15, T16, U5, U22, V5, V22, AA5, AA22, AB5, AB6, AB9, AB10, AB13, AB14, AB17, AB18, AB21, AB22			VSS, Chip GND Supply (All pins should be connected to the same level)
E7, E8, E11, E12, E15, E16, E19, E20, G5, G22, H5, H22, L5, L22, M5, M22, R5, R22, T5, T22, W5, W22, Y5, Y22, AB7, AB8, AB11, AB12, AB15, AB16, AB19, AB20			VDD33, Chip 3.3 V Supply (All pins should be connected to the same level)
B5, A12, C18, D26, R23, AA24, AD20, AE12, AE5, W2, P3, H1			VDD18, Chip 1.8 V Supply (All pins should be connected to the same level)
N23, M24			VSS PLL, Chip GND Supply (All pins should be connected to the same level)
N26, M23			VDD18 PLL, Chip 1.8 V Supply (All pins should be connected to the same level)

**2.3.15 Unconnected (13 pins)**

D3, L4, V2, AA1, AD1, AE8, AE10, AE14, AF18, AE24, AC23, V26, C24	Unconnected pins. It is recommended to leave these pins unconnected on the board to guarantee board compatibility to future device versions.
---	---

Note: Total signal pins: 323; total power supply pins: 120.

### 3 Functional Description

#### 3.1 Block Diagrams

Figure 3-1 shows a typical sub-system integration scenario using the ABM-P. The memory configurations are examples and depend on the ABM-P operation modes and required queuing resources.





Figure 3-1 Sub-System Integration Diagram

Figure 3-2 shows a functional block diagram of the ABM-P. The function blocks are referenced and described in more detail in subsequent chapters.




**Figure 3-2 Functional Block Diagram**

**Figure 3-3** shows a logical illustration of the ATM Buffer Manager (ABM-P) core for one direction.

Cells are assigned to queues in the Buffer Manager unit. The cell acceptance algorithm verifies that no thresholds are exceeded that are provided for queues, schedulers, traffic classes, as well as for the global buffer. Once accepted, a cell cannot be lost, but will be emitted at the respective UTOPIA Interface after some time (exception: queue has been disabled while cells are stored). Alternatively, cells can be received from the Microprocessor Interface via the AAL5 unit. In case of ABR connections, Resource Management (RM) cells are handled within the Enhanced Rate Control (ERC) unit. The demultiplexer forwards the cells to the respective queue associated with a scheduler which sorts them for transmission according to the programmed configuration. As part of the scheduling function, an optional Peak Rate Limiter and a Leaky-Bucket shaper are provided for the shaping of individual queues (connections).

The Queue Scheduler and the Buffer Manager are the key units for QoS provisioning in the ABM-P. The behavior of both units is described in subsequent chapters. The output multiplexer recombines the cell streams of all schedulers. Emitted cells are either forwarded to the UTOPIA Transmit Interface or to the AAL5 unit for extraction.



**Figure 3-3 Logical Block Diagram (One Direction)**

### 3.1.1 Throughput and Speedup

At a given clock frequency, applied to the ABM-P UTOPIA interfaces and the ABM-P core, the core is the limiting factor for throughput because it needs 32 clock cycles per cell as opposed to UTOPIA, which needs only 27+2. The available speedup in the ABM-P relative to STM-4/OC12 transmission rates is shown in [Table 3-4](#).

**Table 3-4 Maximum ABM-P Throughput and Speedup**

<b>Clock Frequency</b>	<b>ABM-P core Throughput [Mbit/s] (53 Byte Cells)</b>	<b>Speedup relative to STM-4/OC12 (599.04 Mbit/s)</b>
<b>51.84</b>	686.88	1.146
<b>60</b>	795	1.327



## 3.2 Functional Block Description

### 3.2.1 Cell Handler (Upstream/Downstream)

The Cell Handler (CH) units are responsible for the physical data flow of storing and retrieving cells to/from the respective Cell Storage RAM or insertion and extraction of Resource Management (RM) cells. Updates to the cell header section or to the cell contents in case of OAM-RM cells are also performed by the Cell Handler units.

### 3.2.2 Buffer Manager and Queue Scheduler (Overview)

The Buffer Manager (BM) unit is the central function of the ABM-P device and handles the logical data flows for upstream and downstream direction. It utilizes the Queue Scheduler to coordinate cell emission and a common Cell Pointer RAM (SSRAM) to administrate cell storage.

Any cell entering the CH unit is reported to the BM unit running the cell acceptance algorithm. In a first step a cell is classified and associated to the logical resource entities connection, queue, traffic class and scheduler. As an exception Resource Management (RM) cells are extracted and forwarded to the ERC unit for further processing. Once all associated resources are determined, the BM runs the cell acceptance algorithm based on the current parameter sets. As a result of all threshold evaluations the cell is either discarded or accepted and related counters are updated accordingly. Non-empty queues are reported to the Queue Scheduler (QS) unit to be scheduled by the associated calendar. In return the QS unit reports queues to the Buffer Manager that are due for cell transmission in the current cell slot. Upon a cell emit request for a specific queue the BM either requests the Cell Handler to retrieve and transmit the next cell or to insert an RM cell as prepared by the ERC unit.

Since the BM and QS units are the central functions of the ABM-P device they are described in more detail in chapter [“Buffer Manager and Queue Scheduler Details” on Page 64](#).

### 3.2.3 Enhanced Rate Control Unit Overview

The Enhanced Rate Control (ERC) unit interfaces to the BM and the CH units for RM cell insertion and extraction. It controls the following functions on a per connection basis:

- ABR-VS/VD: Processing of RM cells, related state machines and rate adjustment
- ABR-ER: Rate calculation and RM cell processing (and adjustment in case of RSC)

The ERC unit is described in more detail in section [“ERC Unit Functional Overview” on Page 110](#).

### 3.2.4 AAL5 Assistant

The AAL5 Assistant unit allows insertion and extraction of AAL5 segmented packets from and towards the Microprocessor Interface. Supported by the corresponding software driver, the unit implements an “in-line” SAR function, i.e. one packet is processed at any time by an SAR function. However, upstream and downstream flow as well as extraction and insertion are independent functions that may be operationally interleaved.

For extraction, a Scheduler Block must be associated to the AAL5 Assistant unit and each queue assigned to this scheduler block must be assigned to a VC-merge group to guarantee that complete packets are forwarded to the AAL5 Assistant unit. The scheduler block rates can be adjusted according to the microprocessor interface bandwidth or the intended CPU load. However, the CPU may extract the payload chunks at a lower rate which will result in internal scheduler block backpressure. No data loss will occur in that case. The CPU reads consecutive bytes from the cell’s payload chunks that can be re-assembled immediately in the host memory while the AAL5 Assistant unit checks the AAL5 trailer. The section **“AAL5 Packet Extraction” on Page 156** provides programming details.

Refer to **“Scheduler Configuration Table Integer Transfer Registers” on Page 306** for the assignment of scheduler blocks to the AAL5 Assistant and the programming of their rates.

For insertion, the CPU prepares the ATM cell header for the following packet and writes packet payload chunks to the AAL5 Assistant unit which will generate the cells and the AAL5 trailer for automatic completion of the last cell of the packet. Internally, the cells are forwarded to either the downstream or upstream Cell Handler and processed in the same way as cells received by an UTOPIA receive interface.

The section **“AAL5 Packet Insertion” on Page 156** provides the details.

### 3.2.5 Internal Address Reduction Unit

The ABM-P requires an internal 16-bit Local Connection Identifier (LCI) to address its resources. Two basic cell addressing schemes are supported to extract/generate an LCI from the cell header:

- LCI Mapping Modes  
An external device generates an LCI and maps it into the ATM cell header. Three different mapping modes are supported by the ABM-P.  
The LCI mapping modes are described as part of the UTOPIA interface description in chapters **“UTOPIA L2 Interfaces (PHY side)” on Page 159** and **“UTOPIA L2 Interface (Backplane side)” on Page 169**.
- Internal Address Reduction Mode  
The ABM-P generates its own internal LCI as a programmable combination of the cell

**Functional Description**

header fields VPI, VCI and the Port Number (PN). The port number is taken either from the UTOPIA port number or the UDF1 cell header byte.

**Internal Address Reduction**

Two parameters in **Register 127 "MODE2" on Page 377** determine the building function of the internal LCI value:

- PNUM(2:0)  
Determines the number of bits taken from the port number field.
- MNUM(3:0)  
Determines the VCI and VPI ranges depending on the cell header VPI value.

Two translation functions are effective, depending on the cell header VPI(11:0) value compared to the configured parameter MNUM.

In the first case

$$\text{VPI}(11,0) < 2^x - 1 \quad ; \quad \text{with} \quad \left\{ \begin{array}{ll} x = 16 - \text{MNUM} & \text{for } \text{MNUM} > 0 \\ x = 0 & \text{for } \text{MNUM} = 0 \end{array} \right\}$$

the LCI is built by {VPI, VCI, PN} values whereas the VCI range is given by (MNUM - PNUM) bits and the VPI range is given by (16 - MNUM) bits.

Note: Programming MNUM(3:0) = 0 is interpreted as decimal 16.

The following tables provide the possible LCI building patterns for all allowed PNUM and MNUM configurations. The resulting LCI is internally treated in the same way as in the LCI cell header mapping modes, i.e. the two MSBs are checked against the quarter segment configuration that allows for cascading of up to four ABM-P devices.

Note: VPI and VCI cell header field positions that are not mapped into the LCI are checked against '0'. A mismatch is treated as 'invalid LCI' and the cell is discarded.

Functional Description

PNUM	MNUM	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
0	8	VPI(7:0)						VCI(7:0)										
0	9	VPI(6:0)						VCI(8:0)										
0	10	VPI(5:0)						VCI(9:0)										
0	11	VPI(4:0)						VCI(10:0)										
0	12	VPI(3:0)						VCI(11:0)										
1	9	VPI(6:0)						VCI(7:0)										PN
1	10	VPI(5:0)						VCI(8:0)										PN
1	11	VPI(4:0)						VCI(9:0)										PN
1	12	VPI(3:0)						VCI(10:0)										PN
1	13	VPI(2:0)						VCI(11:0)										PN
1	14	VPI(1:0)						VCI(12:0)										PN
1	15	VPI						VCI(13:0)										PN
1	16							VCI(14:0)										PN
2	9	VPI(6:0)						VCI(6:0)										PN(1:0)
2	10	VPI(5:0)						VCI(7:0)										PN(1:0)
2	11	VPI(4:0)						VCI(8:0)										PN(1:0)
2	12	VPI(3:0)						VCI(9:0)										PN(1:0)
2	13	VPI(2:0)						VCI(10:0)										PN(1:0)
2	14	VPI(1:0)						VCI(11:0)										PN(1:0)
2	15	VPI						VCI(12:0)										PN(1:0)
2	16							VCI(13:0)										PN(1:0)
3	10	VPI(5:0)						VCI(6:0)										PN(2:0)
3	11	VPI(4:0)						VCI(7:0)										PN(2:0)
3	12	VPI(3:0)						VCI(8:0)										PN(2:0)
3	13	VPI(2:0)						VCI(9:0)										PN(2:0)
3	14	VPI(1:0)						VCI(10:0)										PN(2:0)
3	15	VPI						VCI(11:0)										PN(2:0)
3	16							VCI(12:0)										PN(2:0)
4	10	VPI(5:0)						VCI(5:0)										PN(3:0)
4	11	VPI(4:0)						VCI(6:0)										PN(3:0)
4	12	VPI(3:0)						VCI(7:0)										PN(3:0)
4	13	VPI(2:0)						VCI(8:0)										PN(3:0)
4	14	VPI(1:0)						VCI(9:0)										PN(3:0)
4	15	VPI						VCI(10:0)										PN(3:0)
4	16							VCI(11:0)										PN(3:0)
5	11	VPI(4:0)						VCI(5:0)										PN(4:0)
5	12	VPI(3:0)						VCI(6:0)										PN(4:0)
5	13	VPI(2:0)						VCI(7:0)										PN(4:0)
5	14	VPI(1:0)						VCI(8:0)										PN(4:0)
5	15	VPI						VCI(9:0)										PN(4:0)
5	16							VCI(10:0)										PN(4:0)
6	12	VPI(3:0)						VCI(5:0)										PN(5:0)
6	13	VPI(2:0)						VCI(6:0)										PN(5:0)
6	14	VPI(1:0)						VCI(7:0)										PN(5:0)
6	15	VPI						VCI(8:0)										PN(5:0)
6	16							VCI(9:0)										PN(5:0)
7	13	VPI(2:0)						VCI(5:0)										PN(6:0)
7	14	VPI(1:0)						VCI(6:0)										PN(6:0)
7	15	VPI						VCI(7:0)										PN(6:0)
7	16							VCI(8:0)										PN(6:0)

Figure 3-5 LCI Building Patterns

In the second case

$$\text{VPI}(11,0) \geq 2^x - 1 ; \text{ with } \left\{ \begin{array}{ll} x = 16 - \text{MNUM} & \text{for } \text{MNUM} > 0 \\ x = 0 & \text{for } \text{MNUM} = 0 \end{array} \right\}$$

the LCI is built by {VPI, PN} values only whereas the VPI range is given by MNUM bits.

Note: Programming MNUM(3:0) = 0 is interpreted as decimal 16.

The following tables provide the possible LCI building patterns for all PNUM and MNUM configurations. The resulting LCI is internally treated in the same way as in the LCI cell header mapping modes, i.e. the two MSBs are checked against the quarter segment configuration that allows for cascading of up to four ABM-P devices.

Note: VPI cell header field positions that are not mapped into the LCI are checked against '0'. A mismatch is treated as 'invalid LCI' and the cell is discarded.

Note: When QS check is enabled (for cascaded ABM-Ps), the transparent VPCs are handled by the ABM-P with QS=11b. See [Register 127 "MODE2" on Page 377](#).

Functional Description

PNUM	MNUM	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	8	1	1	1	1	1	1	1	1								VPI(7:0)
0	9	1	1	1	1	1	1	1	1								VPI(8:0)
0	10	1	1	1	1	1	1	1									VPI(9:0)
0	11	1	1	1	1	1	1										VPI(10:0)
0	12	1	1	1	1												VPI(11:0)
1	9	1	1	1	1	1	1	1									VPI(7:0) PN
1	10	1	1	1	1	1	1										VPI(8:0) PN
1	11	1	1	1	1	1											VPI(9:0) PN
1	12	1	1	1	1												VPI(10:0) PN
1	13	1	1	1													VPI(11:0) PN
1	14	1	1														VPI(12:0) PN
1	15	1															VPI(13:0) PN
1	16																VPI(14:0) PN
2	9	1	1	1	1	1	1	1									VPI(6:0) PN(1:0)
2	10	1	1	1	1	1	1										VPI(7:0) PN(1:0)
2	11	1	1	1	1	1											VPI(8:0) PN(1:0)
2	12	1	1	1	1												VPI(9:0) PN(1:0)
2	13	1	1	1													VPI(10:0) PN(1:0)
2	14	1	1														VPI(11:0) PN(1:0)
2	15	1															VPI(12:0) PN(1:0)
2	16																VPI(13:0) PN(1:0)
3	10	1	1	1	1	1	1										VPI(6:0) PN(2:0)
3	11	1	1	1	1	1											VPI(7:0) PN(2:0)
3	12	1	1	1	1												VPI(8:0) PN(2:0)
3	13	1	1	1													VPI(9:0) PN(2:0)
3	14	1	1														VPI(10:0) PN(2:0)
3	15	1															VPI(11:0) PN(2:0)
3	16																VPI(12:0) PN(2:0)
4	10	1	1	1	1	1	1										VPI(5:0) PN(3:0)
4	11	1	1	1	1	1											VPI(6:0) PN(3:0)
4	12	1	1	1	1												VPI(7:0) PN(3:0)
4	13	1	1	1													VPI(8:0) PN(3:0)
4	14	1	1														VPI(9:0) PN(3:0)
4	15	1															VPI(10:0) PN(3:0)
4	16																VPI(11:0) PN(3:0)
5	11	1	1	1	1	1											VPI(5:0) PN(4:0)
5	12	1	1	1	1												VPI(6:0) PN(4:0)
5	13	1	1	1													VPI(7:0) PN(4:0)
5	14	1	1														VPI(8:0) PN(4:0)
5	15	1															VPI(9:0) PN(4:0)
5	16																VPI(10:0) PN(4:0)
6	12	1	1	1	1												VPI(5:0) PN(5:0)
6	13	1	1	1													VPI(6:0) PN(5:0)
6	14	1	1														VPI(7:0) PN(5:0)
6	15	1															VPI(8:0) PN(5:0)
6	16																VPI(9:0) PN(5:0)
7	13	1	1	1													VPI(5:0) PN(6:0)
7	14	1	1														VPI(6:0) PN(6:0)
7	15	1															VPI(7:0) PN(6:0)
7	16																VPI(8:0) PN(6:0)

Figure 3-6 LCI Building Patterns (VPI only)

### 3.2.6 Queue Congestion Indication Unit

Some system implementations are based on in-system flow control mechanisms that require congestion indication information from the downstream queues on a per queue basis (i.e. typically per connection). As an example, a traffic management optimized IP over ATM implementation requires a control link between the ATM traffic management and the packet scheduling unit.

Queue status information (e.g. the queue length) can generally be obtained by reading the Queue Configuration Table (QCT). For a large number of queues (e.g. 8k) and typical time constraints of control loop mechanisms, a software based queue monitoring is not feasible.

The Queue Congestion Indication interface (QCI) is a serial interface providing a bit-pattern with queue-specific threshold exceed information. Each bit represents the queue number corresponding to the bit position. A '1' means congestion, i.e. the queue-specific threshold is currently exceeded. The bit-pattern is generated with minimum HDLC framing and can be limited to 1024, 2048, 4096 or 8192 bits payload, depending on the number of queues that need to be monitored.

Global configuration of the QCI unit is performed in register **"DQCIC" on Page 229**. The queue specific thresholds are programmed in table QCIT via transfer register **"QCIT" on Page 287**.

### 3.2.7 Clocking System

The clocking system of the ABM-P distinguishes the core clock, the ERC clock, and the UTOPIA Interfaces whereas each UTOPIA Interface and direction (transmit/receive) is clocked independently, as shown in **Figure 3-7**.

The ERC clock can be derived internally from either the SYSCLK signal or the internal core clock. Programmable DPPLLs allow for a wide range of external clocks to derive the required core clocks.

In addition to the major clock domains, the serial QCI Interface is also clocked independently.

### 3.2.7.1 Clocking System Overview





Figure 3-7 Clocking System Overview

### 3.2.7.2 DPLL Programming

DPLL1 and DPLL2 are identical function blocks with identical programming interfaces. The DPLL features two factors programmed by parameters **m** and **n** in register “PLL1CONF” on Page 341 and “PLL2CONF” on Page 343 respectively:



$$f_1 = f_{in} / (m + 1) \quad ; \quad f_2 = f_{in} \times \frac{n + 1}{m + 1}$$



**Figure 3-8 DPLL Structure**

The division factor determined by  $m$  must be chosen such that intermediate frequency  $f_1$  is in the range 2..15 MHz based on the input frequency at signal 'SYSCLK'.

The multiplication factor determined by  $n$  must be chosen such that intermediate frequency  $f_2$  is equal or twice the final value in case of DPLL2 and twice or four times the final value in case of DPLL1.

Finally, the division by the two factors ( $f_1, f_2$ ) may be enabled in case of DPLL2 and one or two divisions by the two factors ( $f_1, f_2$ ) may be enabled in case of DPLL1 to achieve the final clock frequency.

When choosing the factors  $m$  and  $n$ , two conditions must be met:

- $n=1..24$ :  $f_1$  must be in a range of 5..15 MHz  
 $n=25..63$ :  $f_1$  must be in a range of 2..6 MHz
- $f_2$  must be in a range of 100 to 200 MHz

### 3.2.7.3 Programming Example

The following numbers are assumed for this example:

- ABM-P internal core clock: 52 MHz
- ABM-P ERC clock: 60 MHz
- Clock supply: 52 MHz at signal SYSCLK

**Functional Description**

In this example, signal SYSCLKSEL must be connected to  $V_{SS}$  to connect the internal core clock to the DPPLL1 output. Signal ERCCLKSEL must be connected to  $V_{SS}$  to connect the alternative ERC clock to the DPPLL2 output. Signal ERCFREQSEL must be connected to  $V_{DD}$  to connect the internal ERC core clock to the alternative ERC clock (which is DPPLL2 output in this example). (Please refer to [Figure 3-7](#))

**DPPLL1 Programming**

A reasonable value for parameter M1 in register “[PLL1CONF](#)” on [Page 341](#) is  $M1 = 12$  which results in

$$f_1 = 52 \text{ MHz} / (12 + 1) = 4 \text{ MHz.}$$

Now a possible value for parameter N1 is  $N1 = 25$  which results in

$$f_2 = 4 \text{ MHz} * (25 + 1) = 104 \text{ MHz.}$$

To achieve the 52 MHz core clock division factor 1 shall be enabled.

Thus, for this example the value  $3B19_H$  must be programmed to register PLL1CONF.

The conditions given above are met because  $f_1=4$  MHz is in the range of 2..6 MHz ( $n=25$ ) and  $f_2=104$  MHz is between 100 and 200 MHz.

Note: Multiple combinations of parameters are possible to achieve a 52 MHz clock in this example.

**DPPLL2 Programming**

A reasonable value for parameter M2 in register “[PLL2CONF](#)” on [Page 343](#) is  $M2 = 12$  which results in

$$f_1 = 52 \text{ MHz} / (12 + 1) = 4 \text{ MHz.}$$

Now a possible value for parameter N2 is  $N2 = 29$  which results in

$$f_2 = 4 \text{ MHz} * (29 + 1) = 120 \text{ MHz.}$$

The division factor shall be enabled to maintain the 60 MHz clock frequency.

Thus for this example the value  $3B1D_H$  must be programmed to register PLL2CONF.

The conditions given above are met because  $f_1=4$  MHz is in the range of 2..6 MHz ( $n=29$ ) and  $f_2=120$  MHz is between 100 and 200 MHz.

Note: Multiple combinations of parameters are possible to achieve a 60 MHz clock in this example.


**3.2.7.4 Initialization Phase**

After power-on reset, both DPPLLs are in bypass mode which means that signal ‘SYSCLK’ is directly feeding the internal core clock and internal ERC core clock. After basic configuration of at least the DPPLL configuration registers, the bypass can be disabled which will make a glitch-free adjustment of the internal clocks to the selected frequency.

### 3.2.8 Reset System

The ABM-P provides three different reset sources, as shown in [Figure 3-9](#). The hardware signal  $\overline{\text{RESET}}$  affects the entire device. The self-clearing software reset bit 'SWRES' in register "MODE1" on [Page 373](#) also affects the entire device. The software reset bit 'ERC SWRES' in register "MODE1" on [Page 373](#) affects only the ERC unit. This bit is not self-clearing and allows the entire ERC unit to be kept in reset state while the rest of the device is working.

Hardware reset as well as software reset bit 'SWRES' completely initialize the device into power-on reset state.




**Figure 3-9 Reset System Overview**

Note: Initialization of external and internal RAM must be started by software via command bits 'INITRAM' and 'INITSDRAM' in register "MODE1" on [Page 373](#) following the device reset.

### 3.3 System Integration

The ABM-P has two operational modes: Bi-directional mode and Uni-directional mode. The directional terminology for the modes refers to the usage of the ABM-P cores, not to the connections. The connections are bi-directional in all cases. In Bi-directional mode, one ABM-P core is used exclusively for the cells of a connection in the upstream direction and the other core exclusively handles cells of the same connection in the downstream direction. In Uni-directional mode, only one core always will be used to handle the cells of a connection both in up- and downstream direction. The two basic applications for these modes are the switch port line card application and the mini-switch, respectively.

On a typical switch port line card, both the upstream and downstream cell flow pass through the same ABM-P device. One ABM-P core is used for each direction as shown in [Figure 3-10](#).




**Figure 3-10 ABM-P in Bi-directional Mode**

The ABM-P assumes that all connections are set up bi-directionally with the same Local Connection Identifier (LCI) in both directions. In the Infineon ATM chip set environment, the LCI is provided by the PXB 4350 E ALP and contains VPI, VCI, and PHY information. If the ABM-P is not used with the ALP, it can extract the LCI from VPI or VCI fields or generate the LCI by using the internal Address Reduction Circuit (ARC).

In a mini-switch application, the total throughput at 51.84 MHz is 687 Mbit/s. Only the UTOPIA Receive and Transmit interfaces at the PHY-side are active. Both ABM-P cores are selected from the multiplexer options shown in [Figure 3-11](#). Each cell is forwarded to both ABM-P cores and the LCI table entry for the connection determines which of the


**Functional Description**

two cores accepts the cell. The other core ignores it. Thus, each cell is stored and queued in one of the two cores. The cell streams of both cores are multiplexed together at the output. In normal operation, the schedulers are programmed such that the sum of all output rates does not exceed the maximum rate supported by the UTOPIA transmit interface. However, bandwidth overbooking of the interface is also possible, resulting in backpressure towards the respective ABM-P core.



**Figure 3-11 ABM-P in Uni-directional Mode Using both Cores**

If the resources of one core are sufficient, the downstream core can be deactivated (see [Figure 3-12](#)). This reduces power consumption and allows omission of the external downstream SDRAM. It also permits the SSRAM to be smaller (see below).




**Figure 3-12 ABM-P in Uni-directional Mode Using one Core**

### 3.3.1 LCI Translation in Mini-Switch Configurations

In Uni-directional applications, the ABM-P can be programmed to make a minimum header translation. This is necessary in a Mini-Switch configuration as both the forward and backward direction of a connection traverse the devices in the same direction. The OAM functions in the Infineon ALP (PXB 4350) or AOP (PXB 4340) devices need the same LCI for forward and backward direction of a connection.

This is clarified by the example shown in [Figure 3-13](#) in which a connection is set up from PHY<sub>1</sub> to PHY<sub>2</sub>. VPI/VCI<sub>1</sub> is the identifier on the transmission line where PHY<sub>1</sub> is connected. The terminal sends ATM cells with this identifier and expects cells in the backward direction from PHY<sub>2</sub> with the same identifier. The ALP in the upstream direction translates VPI/VCI<sub>1</sub> into LCI<sub>1</sub>, the unique local identifier for this connection in the upstream direction. Similarly, for the backward connection from PHY<sub>2</sub> to PHY<sub>1</sub>, the ALP receives ATM cells from PHY<sub>2</sub> with the identifier VPI/VCI<sub>2</sub> and translates them into LCI<sub>2</sub>.



**Figure 3-13 Connection Identifiers in Mini-Switch Configuration**

For minimum complexity, the header translation of the ABM-P is done by inverting the Least Significant Bit (LSB) of the LCI. This measure divides the available LCI range into two parts: odd LCI values for forward connections and even LCI values for backward connections (or vice-versa). That is, it reduces the available number of connection identifiers to 8192, because two LCI values are used per connection.

This is not a restriction in the case of arbitrary address reduction modes as, for example, when the ALP chip is used with the CAME chip (PXB 4360), as ATM connections are always set up bi-directionally with the same VPI/VCI in both directions of a link.

Refer to [Register 126 "MODE1" on Page 373](#) for the configuration of the bi-directional and uni-directional mode, the enabling of the LCI toggling, as well as the deactivation of the downstream core.

Note: In case of fixed address reduction, as, for example, when using the ALP with the built-in Address Reduction Circuit (ARC), the usable LCI range may be seriously restricted, depending on the PHY configuration.

### 3.4 Buffer Manager and Queue Scheduler Details

This section provides more detailed information about buffering (cell acceptance) and scheduling (cell emission) functions.





Figure 3-14 Cell Acceptance and Scheduling



### 3.4.1 Buffer Manager

#### 3.4.1.1 Functional Overview

The basic function of the Buffer Manager (BM) is to decide whether an arriving cell is granted access to the shared buffer or is discarded. This is done by running the Cell Acceptance Algorithm (CAA) (see [Chapter 3.4.1.7](#)). The buffer manager tables accessed by the CAA are summarized in [Figure 3-15](#).



**Figure 3-15 Buffer Manager Tables**

More generally, the buffer manager allocates the buffer resources needed to fulfill the specific service guarantees of individual connections.

In a first step when receiving a cell, the Local Connection Identifier (LCI) that was previously assigned by the Header Translation (see [Figure 3-13](#)), is mapped to a corresponding Queue Identifier (QID). The QID represents the logical queue in which the cell will be stored upon acceptance and serves as an index for subsequent table lookups. In particular, the Scheduler Block and the Traffic Class of the received cell is identified with the Scheduler Block Identifier (SBID) and the Traffic Class Identifier (TCID) respectively.

With any incoming cell, the Cell Acceptance Algorithm (CAA) can access the current buffer status information containing counters, thresholds and flags. Based on this data, the cell is either discarded or accepted. The respective counters are updated appropriately.

**Functional Description**

Under normal operation conditions, once a cell is accepted by the CAA, it will be emitted at a time. The only reason for cell discard after cell acceptance is queue disabling. The cell itself is stored in the external cell store RAM. The logical queue is a linked list of pointers to the cell store RAM providing a FIFO ordering.

**3.4.1.2 Logical Buffer Views**

The ABM-P Cell Buffer is structured by the Buffer Manager into the following major logical views:

- Global Buffer,
- Logical Queues,
- Scheduler Blocks,
- Traffic Classes.

Each view is characterized by attributes, state variables (e.g. occupancy counters), and programmable thresholds.

**3.4.1.2.1 Global Buffer**

A total amount of 262,140 cells can be stored per direction in the global cell buffer. Depending on the particular threshold configuration, global buffer space can be exclusively reserved or shared among different logical queues, scheduler blocks or traffic classes and the individual connections assigned to them.

**3.4.1.2.2 Logical Queues**

The concept of logical queues is implemented to provide isolation between connections or groups of connections sharing the global buffer. Strict per VC queueing is achieved by exclusively assigning connections to logical queues. However, it is also possible to assign more than one connection to a particular logical queue.

A total of 8192 logical queues is provided per direction, with QIDs ranging from 0 to 8191. QID 0 is reserved for the common real-time (CRT) bypass queue. It may be used for real-time traffic in case of an unstructured ABM-P output, as e.g. in input buffered switches and also for cascading multiple ABM-Ps. The common real-time bypass is programmed as a rate limited queue. [Section 3.4.2.1](#) provides scheduling related details.

**3.4.1.2.3 Scheduler Blocks**

From a buffer manager perspective, Scheduler Blocks (SB) can be conceived as a grouping of logical queues sharing the bandwidth provided by the configured SB rate. Each logical queue, except the common real-time (CRT) bypass (QID=0), is unambiguously assigned to a scheduler block.

A total of 128 Scheduler Blocks is provided per direction.

**Functional Description**


Scheduler Blocks are usually assigned to ports, logical channels, or limited terminated VPCs, providing the necessary rate adaptation. [Section 3.4.3](#) provides the details. SB occupancy thresholds are provided for buffer protection in case of SB overload.

**3.4.1.2.4 Traffic Classes**

The concept of traffic classes is introduced to provide a logical grouping of queues with common properties, defined by a set of parameters. Each logical queue is unambiguously assigned to a traffic class and inherits the thresholds and flags defined therein.

The Buffer Manager supports up to 16 distinct parameter sets for traffic classes in the Traffic Class Table (TCT). Each parameter set includes thresholds and flags as listed in [Chapter 3.4.1.3](#).

[Figure 3-16](#) shows the independent assignment connections to queues and of queues to traffic classes and schedulers.



**Figure 3-16 Queue Assignment to Traffic Classes and Scheduler Blocks**

Traffic classes are the principal buffer management concept for Quality of Service (QoS) differentiation. They are not pre-defined or fixed to the standard ATM service categories. This allows for configuration of generic or new services (e.g. DiffServ Per Hop Behaviors (PHB) as defined by the IETF). Along with the queue scheduler concept of scheduler blocks (see [Section 3.4.2.2](#)), a wide range of QoS objectives can be met.

### 3.4.1.3 Threshold Classification

The different threshold types are listed in [Table 3-17](#). In this section, each classification includes a short description.

#### 3.4.1.3.1 Discard Thresholds

Discard thresholds are used by the Cell Acceptance Algorithm (see [Chapter 3.4.1.7](#)). The CAA is invoked every time a cell arrives and calculates a truth value from individual discard conditions.

A discard condition is an expression involving thresholds, counters, flags, parameters, and state variables that renders a truth value as result. Several basic discard conditions can be combined to implement more advanced discard mechanisms (see [Chapter 3.4.1.6](#)).

#### Basic Discard Conditions

The simplest discard condition is the comparison of an occupancy counter with a threshold. A common classification of discard conditions includes:

- **Maximum**  
A discard condition is classified as Maximum Fill if it is independent of the CLP transparency flag or if the CLP transparency flag is set to 1.
- **CLP1**  
A discard condition is classified as CLP1 if it is dependent on the setting of the CLP transparency flag to 0.
- **Packet**  
A discard condition refers to a packet if it is dependent on the setting of EPDen = 1 or PPDen = 1.

A particular threshold can participate in several discard conditions. In the ABM-P, it is quite common to use a threshold in both maximum fill and packet discard conditions. Refer to [Table 3-17](#).

#### Discard Control Parameters

Besides the simple comparison of a threshold value to a counter, several flags and variables are combined to provide more complex discard conditions.

- **CLP1DIS**  
CLP1 thresholds are only enabled if the number of CLP1 cells in the SB, counted by SBOccLP is greater or equal to CLP1DIS. To enable CLP1 thresholds unconditionally, this threshold must be set to 0 in [Register 19 "CLP1DIS" on Page 218](#).
- **MinBG**  
This queue-specific threshold disables discard when the QueueLength counter is lower than MinBG. The description of the minimum buffer guarantee in [Section 3.4.1.6.4](#) provides the details.

- DH  
Delta Hysteresis is a traffic class specific factor applied to all maximum thresholds. The description of the hysteresis mechanism in [Section 3.4.1.6.5](#) provides the details.

### 3.4.1.3.2 Congestion Indication Thresholds

Congestion indication thresholds are provided to support external flow control algorithms.

- ABR Congestion Indication  
Some thresholds are used to indicate congestion to ABR connections (ABRen='1') on a global buffer, scheduler and queue basis. By exceeding one or a combination of these thresholds EFCI bits of user cells and NI and CI bits of RM cells are set appropriately. NI is set in a slightly congested situation. NI and CI are set in a heavy congested situation. [Chapter 3.5.1](#) provides the details on the ABR support.
- SB Congestion Indication  
If the scheduler low and high priority buffer occupation exceeds the respective thresholds the corresponding threshold crossing indication bits for these scheduler blocks are set to '1'. The indication is used for the support of dynamic bandwidth allocation (DBA) protocols. [Chapter 3.4.1.8](#) provides the details on DBA support.
- Queue Congestion Indication  
These per queue thresholds generate a queue specific congestion indication that is provided to the QCI interface and translated into a serial bit pattern to be processed by external devices (downstream only).

### 3.4.1.3.3 Backpressure Thresholds

- UTOPIA Backpressure Thresholds  
These thresholds (four in upstream and four in downstream direction) are global thresholds with respect to the cell buffer fill level and result in backpressure of specific port groups of the respective UTOPIA receive interface.

### 3.4.1.4 Counter Classification

The ABM-P Buffer Manager contains the following counter types

- Occupancy Counters  
These counters reflect the current buffer state and are basic elements in discard, congestion indication and backpressure mechanisms.
- Statistics Counters  
These counters are used for measurements and statistics. Refer also to [Chapter 3.4.1.9](#).

**Functional Description**
**3.4.1.5 Threshold and Occupancy Counter Overview**

**Table 3-17** summarizes thresholds and occupancy counters used by the Cell Acceptance Algorithm. The thresholds are grouped by logical buffer view. For each arriving cell, all conditions in this table are checked. Several thresholds may be exceeded at the same time. Therefore, the table is not a truth table.

**Table 3-17 Threshold and Occupancy Counter Table**

Logical Buffer View	Location	Threshold	Related Occupancy Counter	Threshold Type	Granularity	TCT3 Control Flags					LCI Table		Affected Cells
						ABRen	EPDen	PPDen	GFRen	DH	CLPT	CRT Queue	
Global Buffer	Reg 16	BufMax	BufferOcc	Maximum	4	x	x	x	x	n	x	x	x
				PPD	4	x	x	1	x	n	x	x	0/1
	TCT0	BufMaxNg	BufferOccNg	Maximum	1024	x	x	x	x	y	x	x	0/1
				PPD <sup>1)</sup>	1024	x	x	1	x	n	x	x	0/1
	TCT0	BufEPDNg	BufferOccNg	EPD	1024	x	1	x	0	n	x	x	0/1
				GFR	1024	x	1	x	1	n	x	x	0/1
	TCT1	BufCiCLP1	BufferOccNg	CLP1	1024	0	0	x	x	n	0	x	1
				PPD	1024	0	0	1	x	n	0	x	1
				EPD	1024	0	1	x	x	n	0	x	1
				ABR Ci	1024	1	x	x	x	n	x	x	1/0
	Reg 21	UBTH0	BufferOccNg	UTOPIA backpressure	4	x	x	x	x	n	x	x	x
	Reg 22	UBTH1			4	x	x	x	x	n	x	x	x
	Reg 23	UBTH2			4	x	x	x	x	n	x	x	x
	Reg 24	UBTH3			4	x	x	x	x	n	x	x	x

**Functional Description**
**Table 3-17 Threshold and Occupancy Counter Table (cont'd)**

Logical Buffer View	Location	Threshold	Related Occupancy Counter	Threshold Type	Granularity	TCT3 Control Flags						LCI Table	CRT Queue	Affected Cells
						ABRen	EPDen	PPDen	GFRen	DH	CLPT			
						CLP								
Scheduler Block	TCT3	SBMax	SBOccNg	Maximum	1024	x	0	x	x	y	0	0	0/1	
				PPD	1024	x	0	1	x	n	x	0	0/1	
				EPD	1024	x	1	x	0	n	x	0	0/1	
				GFR	1024	x	1	x	1	n	x	0	0/1	
	TCT2	SBCiCLP1	SBOccNg	CLP1	64	0	0	x	x	n	0	0	1	
				PPD	64	0	0	1	x	n	x	0	1	
				EPD	64	0	1	x	x	n	x	0	1	
				ABR CI	64	1	x	x	x	n	x	0	0/1	
	Reg 19	CLP1DIS	SBOccLP	Control	64	x	x	x	x	n	x	0	1	
	Reg 31	DSBT1	SBOccLP, SBOccHP, SBOccLPd	SB CI	16	x	x	x	x	n	x	0	0 for HP, 1 for LP	
	Reg 32	DSBT2			16	x	x	x	x	n	x	0		
	Reg 33	DSBT3			16	x	x	x	x	n	x	0		
	Reg 34	DSBT4			16	x	x	x	x	n	x	0		
Traffic Class	TCT3	TrafClassMax	TrafClassOccNg	Maximum	1024	x	0	x	x	y	x	x	0/1	
				PPD	1024	x	0	1	x	n	x	x	0/1	
				EPD	1024	x	1	x	0	n	x	x	0/1	
				GFR	1024	x	1	x	1	n	x	x	0/1	
Queue	Fixed	QueueLimit (16383)	QueueLength	Maximum	1	x	x	x	x	n	x	x	0/1	
				PPD	1	x	x	1	x	n	x	x	0/1	
	TCT1	QueueMax	QueueLength	Maximum	64	x	0	x	x	y	x	x	0/1	
				PPD	64	x	0	1	x	n	x	x	0/1	
				EPD	64	x	1	x	x	n	x	x	0/1	
				GFR	64	x	1	x	1	n	x	x	0/1	
	TCT0	QueueCiCLP1	QueueLength	CLP1	4	0	0	x	x	n	0	x	1	
				PPD	4	0	0	1	x	n	x	x	1	
				EPD	4	0	1	x	x	n	1	x	1	
				ABR CI	4	1	x	x	x	n	x	x	0/1	
QCT2	MinBG	QueueLength	Control	1.8	x	x	x	x	n	x	x	0/1		

<sup>1)</sup> Not a true PPD threshold because the last cell of the packet is also discarded when BufMaxNg is exceeded.

**Functional Description**

Note: The flags in columns “TCT3 enabling flags” indicate the traffic class settings required to make the threshold effective during cell acceptance algorithm for a cell (connection) determined to belong to that traffic class. An ‘x’ means don’t care, i.e. the flag has no effect on the threshold. The same applies to flag “CLPT” which is a connection specific setting in the LCI table. The column “affected cells” indicates whether the threshold affects CLP0, CLP1 or all cells.

Note: The thresholds and counters shown above are available in both the upstream and the downstream ABM-P core. In case of registers, the variable name is prefixed with U for upstream and D for downstream in the register tables of [Chapter 7](#).

**3.4.1.6 Discard Mechanisms and Buffer Reservation**

Each arriving cell is classified by determination of its QID, SBID, and TCID.

The discard mechanisms available in the ABM-P Buffer Manager are based on occupancy counters and the programmable thresholds described in [Chapter 3.4.1.3](#) and [Chapter 3.4.1.4](#).

**3.4.1.6.1 Maximum Fill Discard**

A maximum fill discard occurs if the cell counter exceeds the related maximum fill threshold at cell arrival.

The following maximum fill thresholds are available:

BufMax, and QueueLimit are determined by physical limits.

BufMaxNg, SBMax, TrafClassMax, QueueMax are configured per traffic class.

**3.4.1.6.2 Selective CLP1 Discard**

Selective discard is based on the CLP marking found in the arriving cells and is enabled by the CLP transparency flag (CLPT) stored per connection in the LCI table.

In cell discard mode, the mechanism triggers tail drop for CLP=1 cells only. In this mode, the mechanism is used to limit the buffer space provided for the non-guaranteed part of VBR.2/3 traffic.

In packet discard mode, the mechanism triggers EPD for CLP=1 frames only. According to the GFR conformance definition, a CLP1 frame is assumed when the first cell of the frame is a CLP1 cell. In this mode, the mechanism is used mainly for the GFR service.

The following discard thresholds are available to control selective CLP1 discard:

BufCiCLP1, SBCiCLP1, QueueCiCLP1.

Note: There is no selective CLP1 discard threshold available for the traffic class view.



### 3.4.1.6.3 Packet Discard

Packet discard mechanisms rely on the AAL5 End Of Packet (EOP) indication in the PTI field of the cell header. The ABM-P implements two packet discard mechanisms:

- Early Packet Discard (EPD)
- Partial Packet Discard (PPD).

Packet discard can be enabled individually per traffic class by setting the flags EPD<sub>en</sub> and PPD<sub>en</sub> in the TCT respectively. The dynamic status of an ongoing packet discard is stored per connection in the fields LastCellOfPacket, DiscardPacket and DiscardRestOfPacket in the LCI table.

Both mechanisms are provided to avoid or reduce the volume in the transmission of corrupted packets and therefore improve utilization of buffer and bandwidth resources.

#### Early Packet Discard (EPD)

The Early Packet Discard (EPD) mechanism drops all cells of a packet if it decides to drop the first cell of that packet. In packet discard mode, if at cell arrival the related cell counter exceeds this threshold, and the flag LastCellOfPacket is enabled in the LCI table, indicating that the arriving cell is the first cell of a packet, then the cell is discarded and the flag DiscardPacket is enabled in the LCI table. All subsequently arriving cells of the packet are discarded without taking into consideration the cell counter.

EPD may only be applied to non real-time connections. The mechanism is enabled by the software configurable flag EPD<sub>en</sub>, specified per traffic class in the TCT.

The Buffer Manager attempts not to corrupt a packet, once it has accepted the first cell. This means that for EPD<sub>en</sub>=1, the maximum thresholds TrafClassMax, SBMax and QueueMax are disabled for the rest of the packet. Only the thresholds BufMax, BufMaxNg and QueueLimit can corrupt an accepted packet.

#### Partial Packet Discard (PPD)

Under the rare circumstances described at the end of the previous section, it may happen that a cell is discarded from within a packet although the EPD algorithm has accepted it. In this case it is meaningful to discard also all following cells of the packet. However, the last cell of a partially discarded packet should be buffered if possible, since the reassemble mechanism at the receiver is triggered by the last cells of user data packets. This mechanism is referred to as Partial Packet Discard (PPD).

In packet discard mode, if at cell arrival the related cell counter exceeds this threshold, and the exceeding cell is not an end of packet or an OAM cell, then the cell is discarded and the flag DiscardRestOfPacket is enabled in the LCI table. All subsequently arriving cells of the packet, excluding the last cell of the packet, are discarded without taking into consideration the cell counter.

**Functional Description**

PPD may only be applied to non real-time connections. The mechanism is enabled by the software configurable flag PPDen, specified per traffic class in the TCT.

Note: EPD/PPD functionality is offered by the ABM-P on a per VC basis. Hence, these functions can be supported also for connections sharing a queue.

Note: Cell discarding due to EPD and PPD does not apply to non-user cells, e.g. an OAM cell within a packet is not discarded.

**GFR Packet Discard**

The EPD mechanism in combination with the flag GFRen is used to support the GFR service. GFR packet discard works only in conjunction with EPDen = 1 and discards only a well defined subset of the packets normally eligible for EPD.

In particular, when EPDen = 1 and GFRen = 1, a packet is discarded only if:


[(BufEPDNg or SBMax or TrafClassMax) and QueueMax] or any of the EPD CLP1 thresholds is exceeded.

GFRen and PPDen are independent. GFRen has no influence on PPD and PPDen has no influence on GFR.

GFRen has no influence on the discard of CLP=1 frames. Therefore there is no difference between EPD and GFR packet discard regarding CLP=1 frames.

**3.4.1.6.4 Minimum Buffer Reservation**

A minimum buffer reservation is provided on a per queue basis by setting parameter MinBG. As long as the queue length has not reached this value, an incoming cell can be stored without further checks, except the queue threshold checks. When the MinBG limit is exceeded, the Cell Acceptance Algorithm checks if buffer space is available in the non guaranteed buffer space.



**Figure 3-18 Buffer Management with per Queue Minimum Buffer Reservation**

For all traffic classes, the threshold BufMaxNg must be adjusted appropriately, such that, if LQ is the set of logical queues allocated so far, then:

$$\text{BufMax} - \text{BufMaxNg} \geq \sum_{\forall i \in \text{LQ}} \text{MinBG}_i$$

Although the ABM-P in principle has the knowledge of all programmed guaranteed minimum queue sizes, it does not perform the summation for complexity reasons.

Refer to [Register 45 "QCT2" on Page 264](#) for the programming of minimum buffer reservation thresholds. If the condition in the formula above is not fulfilled, then error condition BCFGE occurs and is signalled in [Register 115 "ISRU" on Page 356](#) or [Register 116 "ISRD" on Page 359](#) respectively.

### 3.4.1.6.5 Hysteresis for Maximum Thresholds

Hysteresis is an optional feature for the maximum thresholds BufMaxNg, SBMax, TrafClassMax, and QueueMax in cell discard mode. Hysteresis means that cell discard starts when any of the maximum thresholds mentioned above (referred to as TH for convenience) is exceeded and continues until the level falls below a threshold TL that is considerably lower than TH.

A hysteresis control parameter  $\text{DH}_i$  is provided per traffic class  $i$ . It is used to calculate the low threshold  $\text{TL}_i$  from a given high threshold  $\text{TH}_i$  according to:

Functional Description

$TL_i = TH_i - (TH_i \gg [DH_i + 1])$ , with  $DH_i$  ranging from 1 to 7.

$DH_i=0$  disables the feature. “DH” on Page 253 provides the programming details.

An example for the hysteresis mechanism is shown in Figure 3-19 below.

When TH is exceeded, a connection specific discard flag is set which is cleared again when the buffer fill falls below TL. This flag is used by the cell acceptance algorithm to differentiate between accept state and discard state.




Figure 3-19 Buffer Threshold with Hysteresis

Hysteresis is not used with packet discard and CLP1 discard thresholds.

Hysteresis avoids oscillation effects when the buffer fill is just stable at a certain value and this value just coincides with a certain threshold. A stable buffer fill occurs when input and output flow of the buffer are equal. However, due to cell clumping effects the fill value will vary with a cell jitter in the range 10..100 cells. The hysteresis threshold difference should be larger than the jitter.

### 3.4.1.7 Cell Acceptance Algorithm

The following pseudo-code provides the cell acceptance algorithm of the ABM-P based on the parameter set listed in Chapter 3.4.1.3.

#### 3.4.1.7.1 Discard Conditions

```
/***** Basic Max/EPD conditions *****/
```

**Functional Description**

```

ExceedMaxBuffer = (BufferOcc = BufMax)
ExceedMaxGlobal = (BufferOccNg >= BufMaxNg)
ExceedEpdGlobal = (BufferOccNg >= BufEPDNg)
ExceedMaxSB = (SBOccNg >= SBMax) AND (QID != 0)
ExceedMaxTrafClass = (TrafClassOccNg >= TrafClassMax)
ExceedMaxQueueLimit = (QueueLength = QueueLimit)
ExceedMaxQueue = (QueueLength >= QueueMax)

/**** Basic CLP1 conditions *****/
ActiveCLP1 = (CLP=1) AND (CLPT = FALSE) AND (ABRen = FALSE)

ExceedCLP1Global = (BufferOccNg >= BufCiCLP1) AND ActiveCLP1
ExceedCLP1SB = (SBOccNg >= SBCiCLP1) AND (QID != 0) AND ActiveCLP1
ExceedCLP1Queue = (QueueLength >= QueueCiCLP1) AND ActiveCLP1

/**** Basic reservation conditions *****/
ExceedMinBG = (QueueLength >= MinBG)
ExceedCLP1DIS = (SBOccLP >= CLP1DIS) OR (QID = 0)

/**** Derived conditions *****/
ExceedMaxNg = ExceedMinBG AND { [
                (EPDen = FALSE) AND (
                ExceedMaxTrafClass OR ExceedMaxSB OR ExceedMaxQueue
                )
            ] OR ExceedMaxGlobal }

ExceedEpd = ExceedMinBG AND [
            ExceedEpdGlobal OR ExceedMaxTrafClass OR ExceedMaxSB
            ]

ExceedEpdCLP1 = ExceedCLP1DIS AND { [
                ExceedMinBG AND (ExceedCLP1Global OR ExceedCLP1SB)
            ]
            OR ExceedCLP1Queue }

ExceedCLP1 = ExceedEpdCLP1 AND (EPDen = FALSE)

```

**3.4.1.7.2 EPD Algorithm**

Based on the variables set by the EPD support parts of the threshold exceed algorithm and queue specific variables, the EPD algorithm decides upon the acceptance of a packet.

```

IF      LastCellOfPacket AND UserToUserCell
THEN   IF      [(ExceedEpd OR ExceedMaxQueue) AND (GFRen = FALSE)] OR
            (ExceedEpd AND ExceedMaxQueue) OR

```

```

                ExceedEpdCLP1
            THEN DiscardPacket = TRUE
            ELSE DiscardPacket = FALSE
ELSE Do nothing

IF EPDen AND UserToUserCell AND DiscardPacket
THEN CellAcceptedByEPD = FALSE
ELSE CellAcceptedByEPD = TRUE

LastCellOfPacket = UserToUserCell AND EndOfPacket

```

### 3.4.1.7.3 PPD Algorithm

If the PPD algorithm is applied, the last cell of a corrupted packet should be accepted.

```

IF PPDen AND UserToUserCell AND EndOfPacket
THEN DiscardRestOfPacket = FALSE

IF PPDen AND UserToUserCell AND DiscardRestOfPacket
THEN CellAcceptedByPPD = FALSE
ELSE CellAcceptedByPPD = TRUE

```

### 3.4.1.7.4 Hysteresis Algorithm

For any threshold TH:  $\Delta(\text{TH}) = \text{TH} - \text{TH}/2^{**}[\text{DH} + 1]$  with DH in 1..7

```

FillBelowHyst = (ExceedMinBG = FALSE) OR (DH = 0) OR [
                (BufferOccNg < Delta(BufMaxNg)) AND
                ((SBOccNg < Delta(SBMax)) OR (QID = 0)) AND
                (TrafClassOccNg < Delta(TrafClassMax)) AND
                (QueueLength >= Delta(QueueMax)) ]

```

```

IF UserToUserCell AND (PPDen = FALSE) AND FillBelowHyst
THEN DiscardRestOfPacket = FALSE

IF UserToUserCell AND (PPDen = FALSE) AND DiscardRestOfPacket
THEN CellAcceptedByHyst = FALSE
ELSE CellAcceptedByHyst = TRUE

```

### 3.4.1.7.5 Overall Cell Acceptance Algorithm

The overall decision whether an arriving cell is buffered is based on the results of the previous algorithms. The arriving cell can only be accepted if all algorithms would accept the cell and if buffer space is available. To obtain the overall decision whether a correctly received cell is finally buffered the following algorithm applies:

```

IF      (ExceedMaxBuffer = FALSE) AND
        (ExceedMaxQueueLimit = FALSE) AND
        (ExceedMaxNg = FALSE) AND
        (ExceedCLP1 = FALSE) AND
        (CellAcceptedByEPD = TRUE) AND
        (CellAcceptedByPPD = TRUE) AND
        (CellAcceptedByHyst = TRUE)
THEN    BufferIncomingCell
ELSE    DiscardIncomingCell
        IF  PPDen AND UserToUserCell AND (EndOfPacket = FALSE)
        THEN DiscardRestOfPacket = TRUE
        IF  PPDen = FALSE AND UserToUserCell AND ExceedMaxNg
        THEN DiscardRestOfPacket = TRUE

```

#### 3.4.1.7.6 ABR Congestion Indication Support

```

ExceedCiGlobal = (BufferOccNg >= BufCiCLP1)
ExceedCiSB = [(SBOccNg >= SBCiCLP1) AND (QID != 0)]
ExceedCiQueue = (QueueLength >= QueueCiCLP1)

```

See [Figure 4-9](#) for an example of threshold configuration.

#### 3.4.1.8 SB Congestion Indication Mechanism

The SB congestion indication mechanism is provided to support external flow control based on Dynamic Bandwidth Allocation (DBA) algorithms. These algorithms allocate bandwidth in aggregates often referred to as pipes. Several pipes are assumed to compete for bandwidth on a shared resource bottleneck. The demand for bandwidth of each individual pipe is monitored and a corresponding share of the resource is dynamically allocated to the pipe. Several variants of this algorithm have been reported, supporting fairness and QoS requirements across the bottleneck. Examples of DBA applications are

- Internal flow control across switching fabrics in an input/output buffered switch
- Point-to-multipoint traffic aggregation, e.g. in an ATM Passive Optical Network (APON) scenario

In the context of the ABM-P, a pipe is implemented by a scheduler block. Remember that the SB rate can be changed flexibly, on the fly. In order to monitor the congestion in an SB, a set of four congestion indication thresholds have been defined per SB. The crossing of these thresholds is indicated in a bitmap which can be accessed externally.

**Functional Description**

Refer to “[Upstream/Downstream DBA Scheduler Block Threshold Register 1](#)” on [Page 231](#) for the configuration of the thresholds and “[DTC Transfer Register](#)” on [Page 236](#) for the indication of threshold crossing status.

**3.4.1.9 Statistical Counters**

In addition to the occupancy counters, which may also be used for statistical purposes, the ABM-P device provides several dedicated counters for statistics purposes. These are summarized in [Table 3-20](#):

**Table 3-20 Statistical Counters**

BM view	Location	Name	Width	Comment
Buffer	<a href="#">Reg 17</a>	<a href="#">UMAC/DMAC</a>	16	Maximum buffer occupancy value since last readout
	<a href="#">Reg 18</a>	<a href="#">UMIC/DMIC</a>	16	Minimum buffer occupancy value since last readout
Traffic Class	<a href="#">TCT2</a> <a href="#">TCT3</a>	<a href="#">AcceptedCells/ Packets</a>	32	Total transmitted cells or packets, selectable by flag <a href="#">SCNT</a>
	<a href="#">TCT0</a>	<a href="#">LostPackets/CLP1Cells</a>	16	EPD discards or CLP1 discards
	<a href="#">TCT2</a> <a href="#">TCT3</a>	<a href="#">LostCellsTotal</a>	32	Total cell discards
	<a href="#">TCT1</a>	<a href="#">LostCellsBuffer</a>	4	Global buffer overflow cell discards
	<a href="#">TCT1</a>	<a href="#">LostCellsSB</a>	4	Scheduler block overflow discards
SB	<a href="#">SBOC0</a> <a href="#">SBOC1</a>	<a href="#">SBOccLPd</a>	18	Scheduler block CLP1 cell discards




### 3.4.2 Queue Scheduler

#### 3.4.2.1 Functional Overview

The basic function of the hierarchical Queue Scheduler (QS) is to properly allocate cell transmission slots to scheduler blocks and within those to queues, enabling them to send buffered cells. Thereby, the QS allocates the bandwidth resources needed to fulfill the specific service guarantees of individual connections.

Internally, the QS functions are implemented by two basic building blocks: 128 identical scheduler blocks (SB) and a subsequent round robin scheduler (SBS) as depicted in [Figure 3-21](#). In addition to these, a prioritized empty cell generator queue (for SDRAM refresh) and a Common Real-Time (CRT) queue which also has priority over the SBS, are provided. These two queues are assumed to be rate limited. [Section 4.2.2.4](#) and [Section 4.2.2.3](#) respectively provide the details on the programming of these queues.



**Figure 3-21 Functional Structure of the Hierarchical Queue Scheduler**

In summary, the Queue Scheduler calculates a QID for each cell emission opportunity.

### 3.4.2.2 Scheduler Block

Each Scheduler Block (SB) is a cascade of two scheduling levels, a combination of Weighted Fair Queueing (WFQ) and Round Robin (RR) schedulers in the first stage, followed by a priority scheduler in the second stage as shown in [Figure 3-22](#). An arbitrary number of queues from a maximum of 8191 can be assigned to each scheduler input at stage 1. (Queue 0 is reserved for the common real-time bypass).




Figure 3-22 Scheduler Block Structure

Scheduler Blocks are the principal queue scheduler concept for QoS differentiation. Together with the buffer manager concept of traffic classes, various QoS objectives can be met.

#### 3.4.2.2.1 Priority Scheduler

The priority scheduler implemented in the scheduler block of the ABM-P has three priority levels. As long as there are buffered cells destined to pass at priority 1, only these cells are served. Otherwise, buffered cells destined to pass at priority 2 are served. Only when there are neither priority 1 nor priority 2 cells buffered, then cells from priority 3 are allowed to pass. As a result the available bandwidth for priority 1 traffic is the total output bandwidth. The available bandwidth for priority 2 and priority 3 traffic is the leftover bandwidth from the next higher priority level respectively.

[Chapter 4.2.2.7](#) provides the details on the mapping of queues to the 3 priority levels.

### 3.4.2.2.2 Round Robin Scheduler

The round robin scheduler keeps all of its input queues, which have cells to send in a FIFO structured list. The queue at the head of the list is allowed to send one cell and is then rescheduled at the end of the list. Thereby, the available bandwidth is divided equally among those queues which have cells to send.

### 3.4.2.2.3 Weighted Fair Queueing Scheduler

Rate guarantees for non real-time connections are achieved with the WFQ scheduler. The WFQ scheduler has an arbitrary number of input queues with a weight factor assigned to each of them. The absolute values of the weights are irrelevant, only the relative values count. See [Chapter 4.2.2.7](#) for a discussion on appropriate selection of weight factors.

The WFQ scheduler has the following important properties:

- It is work conserving, i.e. the available bandwidth is always used completely as long as any of the attached queues has cells to send.
- It provides a fair distribution of the available bandwidth in proportion to the assigned weights under any load condition.
- It guarantees minimum rates to queues as long as the sum of the configured minimum rates fits into the available bandwidth.

The properties above make the WFQ scheduler particularly useful for bursty connections with start/stop behavior. The WFQ scheduler automatically deals with the varying load situations and always distributes the bandwidth according to the weight factors.




Figure 3-23 Behavior of Different Scheduler Types

**Functional Description**

For a given arrival rate [Figure 3-23](#) shows the repartition of the output rate. The priority scheduler simply cuts off the low priority traffic assumed in the white bar. The RR scheduler iteratively divides the output rate into equal shares among the active inputs. The WFQ scheduler divides the output rate in proportion to the assigned weights assumed to be proportional to the respective arrival rates.

**3.4.2.3 Quality of Service Support**

In the context of ATM service categories, it is useful to introduce the concept of guaranteed rate. This is the rate which the network must guarantee to the user in order to fulfill the QoS demands.


**Table 3-24 Guaranteed Rates for each ATM Service Category**

ATM Service Category	Guaranteed Rate	Comment
CBR	PCR	
rt-VBR	SCR...PCR	Guaranteed rate is calculated with “effective bandwidth formulas” assuming small buffers and taking into account statistical multiplexing gain.
nrt-VBR	SCR	
ABR	MCR	
GFR	MCR	Guaranteed rate is delivered in complete uncorrupted AAL5 frames.
UBR+	MCR	
UBR	none	Guaranteed rate is always > 0 with queue connected to the WFQ scheduler, can be 0 for arbitrary long times in low priority RR scheduler.

Mapping of connections to stage 1 schedulers depends on the ATM service category of the connection (also shown in [Figure 3-22](#)) as follows:

- Priority 1 RR: real-time connections (CBR, rt-VBR).
- Priority 2 WFQ: non real-time connections with guaranteed rate (nrt-VBR, ABR, GFR, UBR+)
- Priority 3 RR: best effort connections UBR

An example of a scheduler with one priority 1 real-time queue (Queue 1) and nine priority 2 non-real-time queues (Queue 2 through Queue 10) is shown in [Figure 3-25](#). Queue 1 is shared by a number of connections with different bit rates.



**Figure 3-25 Scheduler Behavior Example**

The three columns in [Figure 3-25](#) describe different conditions: The left column shows the scheduler load as seen from Connection Acceptance Control (CAC). New connections are accepted as long as their guaranteed rates fit the spare bandwidth of the scheduler. The center column shows the case in which all Queues 2..10 are filled; that is, all non-real-time connections are sending data. The total non-real-time bandwidth, including the spare bandwidth, is then distributed to the 9 queues according to their weight. In this case, two weight factors are defined. Queue 6 has weight of 1, others have weight of 10. The right column shows the case of only three queues (6, 7 and 9) filled; all other connections are not sending data at this time. Again, the available bandwidth is fairly distributed among the queues, still conserving the 1:10 ratio defined by their weights.


Notice that bandwidth of the real-time connections is not affected by bandwidth re-adjustments; but, remains constant over time under the assumption that real-time connections are constantly sending data. If, however, a real-time connection should not use its bandwidth, the bandwidth would be used immediately by the non-real-time connections. The behavior of the WFQ scheduler shown in [Figure 3-25](#) for non-real-time connections has advantages for both the network operator and for the end user:

- The available bandwidth is always used completely, resulting in optimum usage of transmission resources.
- A user paying for a higher guaranteed rate also obtains higher throughput under all load conditions.

### 3.4.2.4 Traffic Shaping

Traffic shaping is a mechanism that alters the characteristics of a cell stream in order to make better use of network resources or to enforce conformance to the negotiated traffic contract at an interface. Conformance is defined operationally in terms of a Generic Cell Rate Algorithm GCRA(T,tau) which specifies the upper limits, in terms of a given tolerance tau, for cells arriving in excess with respect to a given reference cell rate (1/T). The ITU-T Recommendation I.371 [ 1 ] or the ATM Forum TM Specification 4.1 [ 2 ] provide the details.

A situation that is particularly prone to produce non-conforming traffic is congestion in a network. **Figure 3-26** shows the need for shapers at the output of a congested network for nrt-VBR traffic. An nrt-VBR cell stream originally shaped to conformance by the terminal (1) traverses Network A, which exhibits burst level congestion. At the output of Network A the cell stream is accumulated into a single large burst, which by far exceeds even the Peak Cell Rate (PCR) of the original connection (2). It is no longer conforming to the traffic contract and therefore would not pass through the subsequent policer. Hence, at the output of Network A, an SCR shaper is enabled, which regenerates a conforming cell stream to match a given burst tolerance BT (3). This cell stream is accepted by the policer and traverses Network B which exhibits cell level congestion only. As a result PCR and SCR vary slightly due to the cell clumping effect (4). This Cell Delay Variation (CDV) is reduced to match a given tolerance (CDVT) by the PCR shaper at the output of Network B (5).



**Figure 3-26 Shaping and Policing at Network Boundaries**

Note that the outcome of Network B has a very different shape when compared to the input to Network A and to the outcome of Network A. Nevertheless, due to the shapers implied, the traffic is conforming on both the User-Network interface (UNI) and the subsequent Network-Network Interfaces (NNI).

**Functional Description**

The ABM-P contains two basic shaping mechanisms, which can be activated per logical queue: PCR limitation and leaky bucket shaping. In particular it is possible to enable both mechanisms simultaneously on the same logical queue, a necessary feature to implement true VBR shaping as explained below.

**3.4.2.4.1 PCR Limitation**

For all logical queues a rate limitation can be enabled, which controls the peak cell rate (PCR) from this queue. In other words, cells from a PCR limited queue are always spaced by at least  $TP=1/PCR$  seconds. Cell clumping within the network is thereby eliminated. Traffic passing through a PCR limiter is conforming to any PCR traffic contract, since the tolerance of the PCR limiter is zero.

**3.4.2.4.2 Leaky Bucket Shaping**

A leaky bucket shaper controls a given sustainable cell rate (SCR) within the limits of a given Burst Tolerance (BT).

The Burst Tolerance and the SCR determine the Maximum Burst Size (MBS) (in cells) that may be transmitted at an arbitrary PCR according to the following formula (refer to [ 2 ]):


$$MBS = \left[ 1 + \frac{BT}{\frac{1}{SCR} - \frac{1}{PCR}} \right] \quad [\text{cells}] \quad (1)$$

Vice versa, when the MBS is received (via signalling), the corresponding BT can be calculated according to the following formula:

$$BT = (MBS - 1) \cdot \left( \frac{1}{SCR} - \frac{1}{PCR} \right) \quad [\text{s}] \quad (2)$$

In the ABM-P leaky bucket shaping can be enabled for up to 2048 PCR limited logical queues. In addition to the parameter  $TP = 1/PCR$ , the cell spacing for  $TS = 1/SCR$  and the burst tolerance  $\tau_S = BT$  must be specified.

**Figure 3-27** shows the outcome of the ABM-P leaky bucket shaper under ideal conditions when loaded with a burst.




**Figure 3-27 Ideal ABM-P Shaper Output**

The implementation of the combined shaper guarantees sending the MBS as fast as possible without exceeding the PCR.

If several cell streams are shaped simultaneously, it may happen that cells from different shapers would have to be sent out at the same cell slot. If N cell streams are shaped, in rare cases, a cell may have to wait up to N-1 cell cycles for transmission. This temporary loss of rate is compensated for by slightly stretching the burst in time.

The additional CDV introduced to the PCR by this effect is monitored. With parameter CDVMax an upper limit on the CDV than can occur without notice is programmed. If this value is exceeded, an interrupt is generated. [“UCDV/DCDV” on Page 288](#) provides the details.

The difference between ideal and real shaper output is shown in [Figure 3-28](#)



**Figure 3-28 Ideal and Real ABM-P Shaper Output**



**Functional Description**

**Table 3-29** summarizes the parameters needed for combined PCR and SCR shaping.

**Table 3-29 Summary of VBR Shaping Parameters**

Parameter	Derived from	Stored in Table/ Register	Range	Min. Value	Max Value
<b>TP</b>	1/PCR	AVT:TP	16 bit	*)	65471
<b>TS</b>	1/SCR	AVT:TS	16 bit	*)	65471
<b>tauS</b>	MBS or BT	AVT:tauS	16 bit	0	64511
<b>VBR2.3</b>		AVT:Config	1 bit	0	1
<b>CDVMax</b>		UCDV/DCDV	8 bit	16 cell cycles	255 x 16 cell cycles

\*) Refer to **Table 4.2.2.5f** for an explanation of shaper parameter ranges and granularities.

### 3.4.2.4.3 Shaping for VBR conformance

The standards define three conformance definitions for rt-VBR and nrt-VBR, referred to as VBR.1, VBR.2 and VBR.3. **Table 3-30** explains the differences between the three VBR conformance definitions in terms of the relevant cell stream: index 0+1 denotes both CLP=0 and CLP=1 cells while index 0 denotes CLP=0 cells only.

**Table 3-30 VBR Conformance Definitions**

	PCR Conformance	SCR Conformance
<b>VBR.1</b>	GCRA( $PCR_{0+1}$ , $CDVT_{PCR}$ )	GCRA( $SCR_{0+1}$ , BT)
<b>VBR.2</b>	GCRA( $PCR_{0+1}$ , $CDVT_{PCR}$ )	GCRA( $SCR_0$ , BT)
<b>VBR.3</b>	GCRA( $PCR_{0+1}$ , $CDVT_{PCR}$ )	GCRA( $SCR_0$ , BT), non conforming CLP=0 cells may be tagged (CLP set to 1)

Hence, from a shaping perspective, there is no difference between VBR.2 and VBR.3.

As a consequence, the leaky bucket shaper in the ABM-P is configurable on a per queue basis to shape either the CLP=0+1 cell stream (config parameter VBR2,3 = 0) or alternatively the CLP=0 cell stream only (config parameter VBR2,3 = 1). The PCR limiter always shapes the CLP=0+1 cell stream.

By enabling a Leaky Bucket Shaper with the parameters TP=1/PCR, TS=1/SCR, tau = BT and VBR2,3 = (0|1), the ABM-P can be used to produce conforming VBR traffic.

---

**Functional Description**

Note that the PCR limiter does not make use of the tolerance  $CDVT_{PCR}$  where transmission at higher rates than PCR would be possible. However,  $CDVT_{PCR}$  is primarily intended to allow cell clumping and other networks artifacts, not to allow a higher rate. As mentioned earlier, this more rigid shaping does not violate PCR conformance.

**3.4.2.4.4 Shaping for CBR conformance**

In cases where simple PCR limitation is not sufficient for service categories that define a PCR conformance only, such as CBR, it is possible to use the leaky bucket shaper with parameters  $TS=1/PCR$  and  $\tau=CDVT_{PCR}$ . The parameter TP can be set to any suitable value to reflect higher allowed rates than PCR.


### 3.4.2.5 VC-Merge and Dummy Queue

Any queue can be configured (mutually exclusive) to participate in a VC-merge group or as a 'dummy queue'. A detailed description of enabling/disabling those special queue functions is provided in the description of ["Queue Configuration Table Transfer Registers QCT0..6"](#) on Page 258.

#### 3.4.2.5.1 VC-Merge

Several logical queues carrying AAL5 packets may be grouped together into one of a maximum of 128 merge groups. Functionally, a Packet Round-Robin (PRR) scheduler stage is inserted between the queues of the merge group and the first scheduling stage of the scheduler block. Whenever a **complete** packet is queued in a QID of a merge group, this QID is enabled to the PRR. The PRR schedules a QID to the SB until all cells of the current packet are transmitted. Then it switches to the next enabled QID.

Hence, viewed from the Scheduler Block, a merge group appears like a single queue with the additional benefit that the output VC maintains AAL5 packet boundaries. See [Figure 3-31](#).



**Figure 3-31 VC Merge Scheduling**

Any queue can be configured to be member of one of the 128 merge groups in the QCT by setting 'RSall' = 0 in [Register 44 "QCT1"](#) on Page 261 and then setting 'MGconf/DQsch' = 1 and 'MGID' to the desired merge group identifier in [Register 45 "QCT2"](#) on Page 264.

If the queue is the first queue of the merge group, then its QID must be written into field 'Head\_Pointer' in [Register 57 "MGT2"](#) on Page 281.

Assigning a queue to a VC-merge group already enables the packet boundary aware scheduling of all queues within the same group.

**Functional Description**

Optionally, the ATM cell header may be overwritten with a new value programmed in the MGT by setting 'LCIOen' = 1 and 'LCI' to the desired value in [Register 57 "MGT2" on Page 281](#).

A queue is released from its VC-merge group by setting 'QIDvalid' = 0 in [Register 44 "QCT1" on Page 261](#).

It is recommended to set the parameters of the individual queues in a merge group to equal values, reflecting the desired properties of the outgoing merged VC. In particular, the user must make sure that all queues of a merge group are assigned to the same SB.

Also, for the optional shaping of a merged VC, the shaping parameters TP, TS, tauS and Config must be specified for each of the logical queues of the merge group and should all be equal to the intended shaping parameters of the outgoing merged VC.

The VC-merge shaping mechanism works round robin on a per queue basis with the changing of the QID going on transparently behind the scene. Hence, viewed from the outgoing VC, there is no difference between a single queue VBR shaping and a merge queue VBR shaping. In particular, no cell slot is lost on the transition between queues.

#### 3.4.2.5.2 Dummy Queue

A 'dummy queue' (in contrast to a normal queue) is always scheduled by the queue scheduler according to its associated rates and parameters, even though it does not contain stored cells. Scheduling a dummy queue results in an 'empty cell cycle' (no cell is emitted during this cycle).

Storing cells into a dummy queue is possible, but not recommended, since the cells are never emitted.

Dummy queues can be used for bandwidth reservation e.g. for subsequent multicast operation or any other cell insert/multiplier process.


A queue can be configured as a 'dummy queue' by setting 'DQac = 1' and 'RSall' = 1 in [Register 44 "QCT1" on Page 261](#). This may only be done if 'MGconf/DQsch' = 0 in [Register 45 "QCT2" on Page 264](#) and the queue is empty (QueueLength = 0).

### 3.4.3 Scheduler Block Usage

The ABM-P allows arbitrary assignment of connections to queues and of queues to scheduler blocks. A scheduler block can be assigned to any UTOPIA PHY. Usage of a scheduler differs in switch input (upstream) or output (downstream). For the Mini-Switch application the upstream case does not exist.

At a switch output, the scheduler blocks provide constant cell streams to fill the payloads of the PHYs. Either the entire cell stream of a PHY is provided or it is disassembled into several VPCs as shown in [Figure 3-32](#). A VPC may contain both real-time and data connections. This is the case for a VPC which connects two corporate networks (virtual private networks), for example. The scheduler block concept has the advantage that data traffic is automatically adjusted after setup or teardown of a real-time connection. The output rate of a scheduler block in both applications is usually constant.

The scheduler blocks always react to UTOPIA backpressure or can be controlled completely by backpressure instead of shaping. All scheduler blocks whose physical outputs are asserting backpressure hold on serving. Scheduler blocks serving time slots which are lost due to temporary backpressure are maintained and served later, if possible. Therefore, the rate with some CDV will be maintained. The maximum number of stored time slots which can be configured is equal to the maximum burst possible for that port or path.




**Figure 3-32 Scheduler Block Usage at Switch Output**

At a switch input, each scheduler block is assigned to a switch output ([Figure 3-33](#)). A switch with  $n$  ports needs  $n^2$  scheduler blocks. The output rate of each scheduler block

**Functional Description**

is re-adjusted continuously to obtain maximum switch throughput without overloading the switch port output rate. This principle is called Preemptive Congestion Control, that is, congestion due to overload is avoided.



**Figure 3-33 Scheduler Block Usage at Switch Input**

There are three options for scheduler block rate adjustment:

- After each connection setup or trade-in (static bandwidth allocation).
- Dynamic bandwidth allocation using input scheduler buffer fill information to assign scheduler rates dynamically.
- Backpressure controlled.

### 3.4.4 Scheduler Block Scheduler (SBS)

The SBS performs a weighted round robin scheduling among the active SBs. As long as the sum of the configured SB rates is below the service rate of the SBS, each SB receives bandwidth up to the configured rate, depending on the load in the SB.

The SBS is said to be overbooked if the sum of the configured SB rates is above the service rate of the SBS. In this case, the SBS behaves like an RR scheduler for the overbooked SBs, which all receive an equal amount of bandwidth.

The SBS supports up to 128 Scheduler Blocks per direction. In addition to this, a common real-time bypass queue (with fixed QID = 0) is supported.

### 3.4.5 Supervision Functions

#### 3.4.5.1 Cell Header Protection

To guarantee that the cell header is not corrupted by the external SDRAM, it is protected by an 8-bit interleaved parity octet. It extends over the 5-octet standard header including the UDF1 octet. The BIP-8 octet is calculated for all incoming cells and stored at the place of the UDF2 octet. When a cell is read out, the BIP-8 is calculated again and is compared with the stored BIP-8. In case of a mismatch, an 'BIP8ER' (**Register 115: ISRU, Register 116: ISRD**) interrupt is generated and the cell is discarded or not, depending on the configuration. cell header protection by BIP-8 can be disabled to achieve UDF2 transparency.

#### 3.4.5.2 Cell Queue Supervision

The queueing of cells in the ABM-P is implemented mostly by pointers. To detect pointer errors, the number of the queue in which the cell is stored is appended to the cell in the external cell storage SDRAM. When the cell is read out later, the selected queue number is compared to the QID stored with the cell. In case of a mismatch, a 'BUFFER4' (**Register 115: ISRU, Register 116: ISRD**) interrupt is generated. See also "[Upstream/Downstream Cell Flow Test Registers](#)" on [Page 194](#).

### 3.5 Available Bit Rate Support


The support of the Available Bit Rate (ABR) service category is implemented in the Enhanced Rate Control (ERC) unit of the ABM-P.

#### 3.5.1 ABR Service Description

Available Bit Rate (ABR) is the only ATM service category with dynamic adaptation of the transmission rate according to the currently available bandwidth. It uses an ATM layer control loop carrying special Resource Management (RM) cells to convey congestion and/or bandwidth information along a connection's path through the network. The RM cells are inserted in regular intervals by the source of a connection - usually the terminal. At the destination of the connection, the receiving terminal loops the RM cells back to the source. All the switches/bottlenecks on the way may update specific fields of the RM cells. Based on this information, the source reacts by adapting its transmission rate in a predefined and standardized way.

Refer to the ATM Forum Traffic Management Specification V4.1 [ 2 ] for a complete operational description of the ABR source, destination and switch behavior.

**Figure 3-34** provides an overview of the cell flows in a bi-directional ABR connection with FRM denoting **forward** RM cells and BRM denoting **backward** RM cell flows. Note that both sides A and B of the ABR connection have both source and destination behavior.



**Figure 3-34 User and RM Cell Flows of an ABR Connection**

To summarize:


- **Source** behavior defines the rules for allowed cell rate (ACR) calculation and multiplexing of user cells, FRM cells and BRM cells.
- **Destination** behavior defines the rules for FRM cell turnaround.
- **Switch** behavior defines the rules for BRM cell update.



Functional Description

Source and destination behavior normally occur in terminals only, but there is an option to implement Virtual Source (VS) and Virtual Destination (VD) behavior in a switch, as described in more detail in [Section 3.5.1.9](#).

An example of rate variation over time of an ABR connection is shown in [Figure 3-35](#).



**Figure 3-35 Source Behavior of an Explicit Rate controlled ABR Connection**

Refer to [Section 3.5.1.2](#) for an explanation of ACR, ICR and ADF.

The instantaneous rate at which the source emits user cells must never exceed ACR, but may stay below it. Some special situations are identified in [Figure 3-35](#) with numbers in circles. These are explained as follows:

1. The sending rate remains below ACR. The reason for this could be that the connection source has less than ACR data to send.
2. Same as 1 with the sending rate dropping below MCR.
3. The sender stops transmitting data. After some time the ACR is reduced to MCR.
4. After the time-out defined by ADF the connection is allowed to start with ICR, i.e. ACR is set to ICR.

Normally RM cells are sent **in-rate** (within the limits of ACR). However, under well defined conditions, RM cells may be sent **out-of-rate** (in excess of ACR). [Section 3.5.1.3](#) provides the details.

### 3.5.1.1 Example Network Configuration

Usually, the rate of an ABR connection is determined by the smallest bottleneck in the network leaving unused bandwidth in some of the links. This bandwidth can be used in turn by other ABR connections, leading to a very efficient overall usage of network resources.

In the example of [Figure 3-36](#), five connections with different source and destination points are traversing four switches.

Assume the following scenario:

Connections 1 to 4 are active ABR connections and connection 5 is a high priority CBR connection which is initially inactive. The four ABR connections ramp up until the bandwidth of the common bottleneck in Switch 2 is used up.

At an instant in time, CBR connection 5 becomes active and as a result, ABR connection 4 experiences severe congestion at the common bottleneck in Switch 4. While connection 4 reduces its sending rate, the bandwidth it had previously used becomes available along its path. In particular, at the bottleneck in Switch 2 bandwidth becomes available which is claimed by the other ABR connections.




Figure 3-36 Example Network Configuration

### 3.5.1.2 ABR Parameters

**Table 3-37** identifies the numerous parameters used to describe ABR service.

**Table 3-37 ABR Parameters**

Parameter	ABM-P Location	Default	Description
PCR [cells/sec]	AVT-VS/VD <a href="#">Table 3-53</a>	configure	Peak Cell Rate The cell rate that may never be exceeded by the source. After negotiation in the network, the PCR is constant for each connection and may be supervised by policing.
MCR [cells/sec]	AVT-VS/VD <a href="#">Table 3-53</a> AVT-ER <a href="#">Table 3-54</a>	configure	Minimum Cell Rate The cell rate that the source may send at any time.
ICR [cells/sec]	AVT-VS/VD <a href="#">Table 3-53</a> TPi	configure	Initial Cell Rate The cell rate at which the source may send at start time and after a long inactive time, defined by the global constant ADTF (ACR Decrease Time Factor). To configure, see <a href="#">Section 3.5.1.9</a>
TBE [cells]		configure in connection handler SW	Transient Buffer Exposure The number of cells the source may send without receiving BRM cell feedback. Must be adapted to match the buffer space allocated to the VC in the first downstream switch. Used in ICR and CRM calculation, see formula in <a href="#">Section 3.5.1.9</a>
FRTT [sec]		configure in connection handler SW	Fixed Round Trip Time The estimated delay on a full round trip, from sending FRM until receiving BRM, including propagation and queueing delays. Used in ICR and CRM calculation, see formula in <a href="#">Section 3.5.1.9</a>
RIF	AVT-VS/VD <a href="#">Table 3-53</a>	1/32768	Rate Increase Factor Used in the ACR calculation for the relative rate marking mechanism. see <a href="#">Section 3.5.1.3.1</a>

**Functional Description**
**Table 3-37 ABR Parameters (cont'd)**

Parameter	ABM-P Location	Default	Description
RDF	AVT-VS/VD <a href="#">Table 3-53</a>	1	Rate Decrease Factor Used in the ACR calculation for the relative rate marking mechanism. See <a href="#">Section 3.5.1.3.1</a>
Nrm [cells]	ERC Firmware via Mailbox	32	Maximum number of cells (user and BRM) between two in-rate FRM cells. Configured globally in firmware (via mailbox)
Trm [ms]	Register <a href="#">ERCCONF1</a>	100	After Trm the next FRM cell is generated if at least two in-rate cells (user or BRM) have been sent. Range x Granularity: (0..15) x 10 ms Configured in global register <a href="#">ERCCONF1</a>
ADTF [ms]	AVT-VS/VD <a href="#">Table 3-53</a>	500	ACR Decrease Time Factor Time-out of a connection; if no user cells are received for this time the connection is considered inactive and has to restart with ICR.
Mrm [cells]	ERC Firmware Constant	2	Controls the bandwidth allocation between RM cells and user cells. Minimum 2 user cells must be transmitted between two consecutive FRM cells.
TCR [cells/s]	ERC Calculated	10	Tagged cell rate Limits insertion rate of out-of-rate FRM cells. Parameter unused, TCR triggered by Trm time-out (ToT)
CDF	ERC Firmware via Mailbox	1/16	Cutoff Decrease Factor Controls the decrease in ACR as a result of CRM (see below) Range 1/64 .. 1

**Functional Description**

**Table 3-37 ABR Parameters (cont'd)**

<b>Parameter</b>	<b>ABM-P Location</b>	<b>Default</b>	<b>Description</b>
CRM [cells]	AVT-VS/VD <a href="#">Table 3-53</a>	32	Missing RM cell count Range x Granularity: (0..63) x 16 cells
ACR	ERC Calculated in Firmware	MCR	Allowed Cell Rate Is computed by the source according to the rules 1, 2, 5, 6, 8 and 9 of section 5.10.4, Source Behavior, of ATM Forum TM4.1 [ 2 ]. The ACR is bounded upwards by the PCR and downwards by the MCR. The ACR is included in the forward RM cells (FRM) emitted by the ABR source in the field CCR (current cell rate).

### 3.5.1.3 Source Behavior Overview

#### 3.5.1.3.1 ACR Calculation


The standardized source behavior defines several conditions under which the ACR must be recalculated.

##### BRM Cell Receive

The BRM cells received by the ABR source carry the following congestion related information:

- CI Congestion Indication Bit is set in highly congested nodes
- NI No Increase Bit is set in moderately congested nodes
- ER Explicit Rate is calculated by nodes

Based on this information, the source performs the ACR calculation according to the algorithm shown in [Figure 3-38](#):



**Figure 3-38 ACR calculation at BRM Cell Receive**

##### FRM Cell Send

Before sending an FRM cell, the ABR source performs the algorithm in [Figure 3-39](#):




Figure 3-39 ACR calculation at FRM Cell Send

### 3.5.1.3.2 User Cell and RM Cell Multiplexing

The parameters  $N_{rm}$  and  $M_{rm}$ , together with source rule #3 of the ATMF TM 4.1 specification [ 2 ], lead to the sequence of user and RM cells shown in [Figure 3-41](#). This figure also explains the definition of in-rate and out-of-rate cells given in [Table 3-40](#):

Table 3-40 In-rate and Out-of-rate Cells

Cell type	User cells	FRM cells	BRM cells	CLP	Within ACR
In-rate	yes	yes	yes	0	yes
Out-of-rate	not allowed	yes	yes	1	no

When the current cell inter arrival time  $T$  is very small compared to  $T_{rm}$ , the cell sequence will be:

- One in-rate FRM cell
- Optionally, one in-rate BRM cell (if there is one to be turned around)
- 30 user cells (31 in case there is no BRM cell to be turned around)

Functional Description

and the  $T_{rm}$  time-out will never happen. If, however, only a few cell slots fit into the  $T_{rm}$  interval, the time-out event will occur before 30 user cells have been transmitted.




Figure 3-41 RM and User Cell Sequence: General Case

The worst case that only one user cell is transmitted in each FRM cell cycle is shown in Figure 3-42, where the cell sequence is

- One in-rate FRM cell
- One in-rate BRM cell (if there is one to be turned around)
- 1 user cell




Figure 3-42 RM and User Cell Sequence: Worst Case

Note: Out-of-rate RM cells are not supported by first firmware version.




### 3.5.1.4 ABR Mechanisms

ABR Mechanisms are classified depending on the way congestion information is conveyed to the ABR source and the way switches make use of the information contained in the RM cells passing through. [Table 3-43](#) shows this classification with complexity increasing from top to bottom.

**Table 3-43 ABR Mechanisms Supported in the ABM-P**

ABR Mechanism	Description	ABM	ABM-P
EFCI marking	Setting the PT bits in the user cell header to “congestion experienced”	yes	yes
Relative Rate Marking	Setting CI and/or NI bits of forward or backward RM cells to 1 (binary feedback)	yes	yes
Explicit Rate Marking	Updating the ER field of forward or backward RM cells	no	yes
Reactive Switch Control	Explicit rate marking and additional reduction of the forward transmission rate in switches to the ER in received BRM cells	no	yes
VS/VD control	Segmentation of the ABR control loop in a switch by building a virtual source (VS) and virtual destination (VD)	no	yes

The implementation of the ABR mechanisms is mainly left to the manufacturer. It is implicitly stated that the switch should update the RM cells in such a way that no cell losses occur. The ABM-P supports all switch mechanisms mentioned above. The ABR control loop with the different ABR mechanisms is shown below for one direction.



**Figure 3-44 ABR Mechanisms**

### 3.5.1.5 EFCI Marking

The EFCI bit is carried in user data cells and supposed to be set in congested nodes. At the ABR destination the EFCI state is maintained in a status bit.

When the EFCI status bit is set and the destination turns around an RM cell, it sets CI=1 before sending the BRM and resets its EFCI status bit.

EFCI marking is a cheap way to enable ABR, because the node doesn't need to update BRM cells, however the control response is slow.

The ABM-P supports EFCI marking by setting the EFCI bit in outgoing data cells. The value of the EFCI bit is calculated by the Cell Acceptance Algorithm (see [Section 3.4.1.7](#)) as follows:

Outgoing EFCI = 1 if and only if incoming EFCI = 1 or threshold QueueCiCLP1 has been exceeded and either the last arrived cell has been discarded or one of the buffer management thresholds BufCiCLP1 or SBCiCLP1 has also been exceeded.

Since the ABM-P chip provides more advanced mechanisms, it is not recommended to rely solely on EFCI marking for ABR.

### 3.5.1.6 Relative Rate Marking

The Relative Rate Marking mechanism uses two bits in the RM cell to convey information about congested nodes: Congestion Indication (CI) and No Increase (NI).

The ABM-P supports Relative Rate Marking by calculating local values of CI and NI in the Cell Acceptance Algorithm (see [Section 3.4.1.7](#)) and setting the outgoing CI and NI as follows:

Outgoing CI = 1 if and only if incoming CI = 1 or threshold QueueCiCLP1 has been exceeded and either the last arrived cell has been discarded or one of the buffer management thresholds BufCiCLP1 or SBCiCLP1 has also been exceeded.

Outgoing NI = 1 if and only if incoming NI = 1 or threshold QueueCiCLP1 has been exceeded or either the last arrived cell has been discarded or one of the buffer management thresholds BufCiCLP1 or SBCiCLP1 has been exceeded.

### 3.5.1.7 Explicit Rate Marking

The Explicit Rate Marking mechanism uses the Explicit Rate (ER) field in the RM cells to convey an estimate for the appropriate source rate. By default, the BRM cells are used. Updating of FRM cells instead is optional.

The ABM-P supports Explicit Rate Marking by calculating a local ER in the ERC unit (see [Section 3.5.2](#)) depending on a measurement of the current emitted cell rate (CCR) and the current logical queue length of the ABR connection and updating the outgoing ER field of BRM cells as: outgoing ER = min(incoming ER, local ER). The updating is only enabled when the TCT parameter ABRen is set to 1.

**Functional Description**

The algorithm is designed to control the queue length around a given operating point, which can be chosen with parameter QL0 (see [Table 3-55](#)) to be one of 256, 512, 1024, 2048 cells.

**3.5.1.8 Reactive Switch Control**


Reactive Switch Control (RSC) is an extension to the Explicit Rate Marking mechanism. A switch with RSC behavior enabled is intended to adjust connection specific rates to not exceed the current explicit rate value from the incoming BRM cells (see [Figure 3-45](#)).

The ABM-P supports RSC by extracting the ER from incoming BRM cells in the ERC unit (see [Section 3.5.2](#)) and dynamically adjusting the PCR limiter of the corresponding logical queue to the value of the ER.

**Example:**

Imagine that a connection crosses 2 bottlenecks called ABM-P (a) and ABM-P (b). At a certain moment ABM-P (a) serves the connection with 10 Mbit/s, ABM-P (b) with 5 Mbit/s. Hence, ABM-P (b) will have to store the difference of 5 Mbit/s incoming cells. In such a situation the BRM cells flowing backwards from ABM-P (b) towards ABM-P (a) will carry the ER=5 Mbit/s. The ABM-P (a) has calculated an ER=10 Mbit/s and hence will not modify the ER field of the backward RM cells. Depending on the loop length (round trip time until BRM cells arrive at the source and source reduces the emit rate), ABM-P (b) is likely to overflow with cells for this connection. To shorten the control loop, Reactive Switch Control (RSC) immediately updates the emit rate of ABM-P (a) to the lower ER value extracted from the BRM cells.

Symmetric, but de-coupled control loops are foreseen by the standard to control both source-destination flows. For simplification, only one flow is shown in this example.



**Figure 3-45 Reactive Switch Control Example**

### 3.5.1.9 VS/VD Behavior

The VS/VD behavior is very similar to the terminal source and destination behavior.

**VS/VD source behavior** performs two different tasks:

- Calculation of the ACR and appropriate adjustment of the sending rate.
- Multiplexing of user cells, FRM cells and BRM cells.

Calculation of ACR is done by using the CI/NI and ER conveyed in the BRM cells and taking into consideration some further constraints:

- ACR must stay between MCR and PCR.
- In the absence of received BRM cells the source assumes heavy congestion in the network and reduces ACR by a factor.
- After time-outs, the ACR is reduced to ICR.

According to the standards, after connection setup, the ICR must be adapted as follows:


$$ICR = \max\left(MCR, \min\left(ICR_{Setup}, \frac{TBE}{FRTT}\right)\right) \quad (3)$$

In the ABM-P, the ACR is programmed to the peak rate limiter of a queue. Then the rule is fulfilled that the actual sending rate shall never be higher than ACR. If the queue is served at a lower rate than ACR - due to resource contention - the unused bandwidth will be consumed by the network ("use-it-or-lose-it" principle). Using the WFQ scheduler and assigning an appropriate weight assures that ACR is not falling below MCR.

Multiplexing user cells and FRM cells occurs under control of the ERC unit according to the behavior defined in the standards.

**VS/VD destination behavior** is basically to convert the received FRM cells into BRM cells. The CI/NI and ER fields of the outgoing BRM cells are updated to reflect the congestion situation of the VD side buffers. The received BRM cells are evaluated and the ACR is conveyed to the companion virtual source.

In a switch, the VS/VD function is distributed, as shown in [Figure 3-46](#).



**Figure 3-46 Distribution of VS/VD Function in a Switch**

**VS/VD Options**

Destination Behavior (ATM Forum TM 4.1 spec. rule 3 options): If FRM cells are received and turned into BRM cells, while older BRM cells are still waiting for transmission, the contents overwrite option is supported. The new BRM cell is scheduled in place of the old BRM cell for in-rate transmission. The old BRM cell is lost.

### 3.5.2 ERC Unit Functional Overview

Figure 3-47 provides an overview of the ERC unit of the ABM-P:




Figure 3-47 ERC Unit

The central function blocks of the ERC sub-system are the processor running the ABR state machines and the AVT context table storing all connection specific parameters. The SCAN unit next to the AVT table enforces all time-out related parameters by generating time-out notifications. During initialization, the Code RAM is loaded via the SPI Interface from an external serial EEPROM device. This firmware is needed for ABR ER and ABR VS/VD. Communication with the ABM-P core (RM cell insert/extract, queue information, rate update messages, cell emit events) is handled by the message interface. The ERC sub-system shares the Microprocessor Interface with the ABM-P core. Communication with an external microprocessor (e.g. extended Context RAM access) is performed via a mailbox while access to the main context table AVT is done directly by the microprocessor through dedicated transfer registers.

### 3.5.2.1 Processor


The ABM-P includes a general purpose RISC processor on-chip, called IOP. The IOP is responsible for ABR explicit rate calculation and the implementation of VS/VD behavior.

The basic parameters for the ABM-P IOP are:

- 24 bit instruction width
- Program/Code RAM Interface (24 bit data, 13 bit address bus)
- Data RAM Interface (16 bit, 16 bit address bus) shared by context RAM, extended context RAM and variable RAM (upper Cache RAM page)
- 16 Ports mapped into register file
- 4 tasks with 16 registers each
- 4 interrupt inputs managed by a separate interrupt controller

### 3.5.2.2 Message Interface

For communication between the ERC unit and the ABM-P core, a Message Interface is implemented. It is designed to support both ABR and VBR (Rate Shaping) related calculations in the IOP. Since standard VBR shaping is performed entirely in hardware, the VBR related messages are currently unused and are not supported.



**Figure 3-48 Message Interface between ERC Unit and ABM-P Core**

Towards the ERC unit, the messages sent by the ABM-P core are buffered in two FIFO queues: the RM FIFO and the Emit FIFO.

### 3.5.2.2.1 RM\_Cell\_received

For each incoming RM cell (FRM and BRM), a message is generated containing the QID, the cell header and the first 24 octets of the RM cell payload. The message is stored in the RM FIFO. The structure of this message is shown in [Section 3.6.10.1](#).

After reading a message from the RM FIFO, the IOP handles the following cases:

- In ABR-VS/VD mode, the FRM cells are stored and updates of the destination turnaround function are performed. An RM\_Cell\_Insert message is generated in response. For the BRM cells, the CI/NI and ER fields are evaluated to calculate the ACR.
- In ABR-ER mode, the CI/NI and ER fields are evaluated to calculate the ACR.

### 3.5.2.2.2 Emit

For each cell emission event from an ABR queue, the ABM-P core generates an Emit message with the QID, the current queue length Qlen and the current time Tnow as parameters. The message is stored in the Emit FIFO. The structure of this message is shown in [Section 3.6.10.2](#).

After reading a message from the Emit FIFO, the IOP handles the following cases:

- In ABR-VS/VD mode RM\_Cell\_insert messages and/or Rate\_update messages are generated.
- In ABR-ER and RSC mode Rate\_update messages are generated.

In addition to cell emission events, the Emit FIFO also contains time-out events generated and forwarded by the Scan Unit (see [Section 3.5.2.5](#))

### 3.5.2.2.3 Rate\_Update\_ABR

In Reactive Switch Control mode (see [Section 3.5.1.8](#)), the ERC unit sends the current rate shaping parameter TP (RateFactor) of the PCR Limiter to the ABM-P core. The delivered value is immediately stored and used by the next schedule event on the respective queue.

In ABR-VS/VD mode, the virtual source receives the current rate shaping parameter TP (Rate Factor) of the PCR Limiter from the ERC unit.

### 3.5.2.2.4 RM\_Cell\_Insert

In case of VS/VD, this message is sent by the ERC unit to inform the ABM-P core that an in-rate RM cell needs to be inserted instead of the planned user cell. The RM cell itself is generated within the ABM-P core. All variable values of the RM cell are delivered by the ERC unit, all other fields have fixed values. The user cell (at least one) inside the queue is scheduled next. But, it can happen that an RM cell is inserted before.



### 3.5.2.2.5 RM\_Cell\_Update

In case of ABR-ER mode, this message is sent to inform the ABM-P core about the results of the last ER calculation. If the emitted cell is an RM cell, the fields CI, NI, and ER (if necessary) are updated. All other parameters are ignored.

### 3.5.2.3 ERC Mailbox

The ERC mailbox is used by an external micro-controller to communicate with the IOP through the Microprocessor Interface. The micro-controller writes command messages to the control and data registers which are evaluated by the IOP firmware. One control bit initiates an interrupt to the IOP.

The usage of command and data fields is firmware implementation specific. A handshake protocol is implemented in firmware to exchange information.

Note: The hardware does not determine the usage and interpretation of commands. These are determined by firmware and must be known to the device driver software.

#### Command List

The ERC mailbox is used, for instance, at system setup or setup of queues in order to initialize appropriate variables of the IOP. The available commands use the following parameters:

ConnTableWrite:	Command=0x1
ConnTableRead:	Command=0x2
ABMWriteRegister:	Command=0x3
ABMReadRegister:	Command=0x4
ExtdRAMWrite:	Command=0x5
ExtdRAMRead:	Command=0x6
InitIOP:	Command=0x7
CacheVarWrite:	Command=0x8
CacheVarRead:	Command=0x9
WriteIOPRegister:	Command=0xA
ReadIOPRegister:	Command=0xB

Commands are transferred via [Register "ERC MailBox Register 0" on Page 335](#). In case of read or write operations Register [ERCMB1](#) transfers the address to the IOP while [ERCMB2](#) transfers the data word.

Note: For ERC unit configuration, only the commands InitIOP, CacheVarWrite and CacheVarRead are relevant.

### 3.5.2.4 AVT (Context RAM)

Chapter 3.6.9 provides the details.

### 3.5.2.5 Scan Unit

The basic function of the Scan Unit is to periodically refresh outdated variables and detect idle connections.

The Scan Unit generates the (relative) cell clock **Tnow** needed by the VBR shaping mechanism and two (absolute) 1.25 ms and 10 ms clocks referred to as **ms125count** and **ms10count**, needed by the ABR-ER and ABR-VS/VD mechanisms.

The Scan Unit accesses the complete AVT Context RAM periodically every 1.25ms. In a first step dword0 containing the Config(6:0) bits is read. These bits are interpreted and then in a second step the respective dwords are read which contain the time information. In case of time-outs the information is modified and written back.




Figure 3-49 SCAN Timer Generation

The 40...60 MHz SYSCLK is divided by 32 to obtain a cell clock CellClk.

The **Tnow** counter with 24-bit width increments by  $2^{**}TStepC$  every CellClk. The value of this counter is made available as relative time reference to other blocks. Parameter TStepC is set in [Register 70 "USCONF/DSCONF" on Page 295](#).

The absolute time bases are provided by dividing the CellClk first by 256 and then by a programmable divider of 7 bit (1...127).

Timer **ms125count** is derived from bit 4 of the programmable divider.

Timer **ms10count** is derived by from bit 7 of the programmable divider.

**Functional Description**

The divider is programmed with the parameter SCANP found in register “**ERCCONF0**” on [Page 338](#) depending on the SYSCLK value:

**Table 3-50 Timer Values for Clock Generation**

Frequency [MHz]	SCANP	period of ms10count [s]	delta [%]
40	49	0.010035	0.35
51.84	63	0.009956	0.44
60	73	0.009967	0.33

Default value is SCANP=63, for the frequency of 51.84 MHz, which is easy to obtain as 1/3 of 155.52 MHz, the SDH/Sonet frequency.

The following scan is performed:

- For VBR
  - Scan over all VBR QID
  - Refresh TETvalid=Config[0], STvalid=Config[1] and TeV
- For ABR
  - Scan over all ABR QID
  - If VS/VD: Refresh ToT, ToA
  - If ER: Refresh

The Scan Unit can be disabled with flag SCAND found in register “**ERCCONF0**” on [Page 338](#).

### 3.6 Internal Tables

#### 3.6.1 Table Overview

The ABM-P provides a set of internal tables for configuration and runtime parameters. **Figure 3-51** gives an overview of all (user accessible) tables and related control/transfer/mask registers:




Figure 3-51 Table Access Overview

---

**Functional Description**

The tables are accessed by the microcontroller via control registers, data transfer registers and mask registers. While the control registers **“MAR” on Page 368** and **“WAR” on Page 370** are common to all tables (except SCTI tables), sets of mask registers are dedicated or shared among some tables. Data transfer registers are always dedicated to the specific table.

**3.6.2 LCI: Local Connection Identifier Table**

The basic function of the LCI table is assigning the connection (identified by the LCI) to one out of 8192 queues per direction. Single connections can be assigned to a dedicated queue (per VC queueing) or multiple connections might be assigned to the same queue. **“LCI Table Transfer Registers” on Page 237** provides the details.

**3.6.3 QCT: Queue Configuration Table**

The basic function of the QCT table is to determine queue specific parameters and to assign the queue to dedicated resources (Traffic Class, Scheduler Block, Merge Group). **“Queue Configuration Table Transfer Registers” on Page 258** provides the details.

**3.6.4 QPT: Queue Parameter Table**

The function of the QPT table is to configure the weight factor (in case a queue is assigned to the WFQ scheduler) and the peak cell rate value (in case the peak cell rate shaper is enabled).

**“Queue Parameter Table Transfer Registers” on Page 296** provides the details.

**3.6.5 TCT: Traffic Class Table**

The function of the TCT table is to configure the buffer management behavior of up to 16 traffic classes.

**“Traffic Class Table Transfer Registers” on Page 241** provides the details.

**3.6.6 SBOC: Scheduler Block Occupancy Table**

The function of the SBOC table (for 2\*128 scheduler blocks) is to maintain the buffer filling levels associated with the dedicated scheduler and to control the scheduler specific DBA threshold indications.

**“Scheduler Block Occupancy Table Transfer Registers” on Page 270** provides the details.

### 3.6.7 SCT: Scheduler Configuration Table

The function of the SCT table (for  $2^*128$  scheduler blocks) is to determine the integer part (SCTI) and fractional part (SCTF) of the scheduler block output rates as well as the UTOPIA port number the scheduler is assigned to.

“[Scheduler Configuration Table Integer Transfer Registers](#)” on [Page 306](#) and “[Scheduler Configuration Table Fractional Transfer Registers](#)” on [Page 316](#) provide the details.

### 3.6.8 MGT: Merge Group Table

The function of the MGT table (for 128 merge groups per direction) is to enable and specify the cell header overwrite function for the merge group output streams.

“[Merge Group Table Transfer Registers](#)” on [Page 277](#) provides the details.

### 3.6.9 AVT: ABR/VBR Configuration Table

The AVT table is the main context RAM of the ERC and VBR shaping sub-system.

#### 3.6.9.1 AVT Context RAM Organization and Addressing

The AVT Context RAM addressing scheme imposes some restrictions to the choice of QID numbers for support of VBR shaping or ABR (ER, VS/VD) operation. The table is organized into 2 K sections of 4 double words (32-bit) each whereas each section corresponds to the respective QID number.

Support of VBR shaping requires one section per connection, i.e. up to  $2k-1$  connections assigned to QID numbers (1, ..., 2047) can be supported for VBR shaping.


Support of ABR functionality requires two sections per connection, i.e. up to  $1K-1$  connections can be supported with full ABR functionality.

The following restrictions apply:

Only even QID numbers can be used for ABR operation. Selecting ABR for QID  $2n$  ( $n = 1..1023$ ) also occupies section  $2n+1$  of the AVT table. Therefore, VBR operation is prohibited for QID  $2n+1$ .

QID 0 is reserved for the common real-time queue.

**Functional Description**



**Figure 3-52 AVT Context RAM Addressing Scheme**

The parameter utilization of each section depends on the mode selected for the particular queue (QID) in the Config field of the section. The mode specific parameter sets are described in subsequent chapters.

### 3.6.9.2 AVT Context RAM Section for ABR-VS/VD Support

In ABR-VS/VD mode, one connection entry requires two AVT Context RAM sections with a total of 8 double words (of 32-bit width each). Since the AVT table is accessed from the external micro controller via a 16-bit transfer register, the ABR-VS/VD connection context appears as a 16-bit organized table with 16 entries as shown:

**Table 3-53 AVT Context Table: ABR-VS/VD (Table Layout)**

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
0	Config(6:0)							Flags(3:0)			F0	Clb	Nib	EFCld	EFCldu		
1	TPI(15:0)																
2	VCI/LCI(11:0)											PTI		C			
3	VPI/LCI(11:0)											VCI/LCI(15:12)					
4	MCRf*(15:0)																
5	UDF1(7:0)							UDF2(7:0)									
6	CCRf*(15:0)																
7	PCRf*(15:0)																
8	0	0	0	0	0	0	0	Clt	Nlt	reserved							
9	ERt*(15:0)																
10	CRM(5:0)						CRMcnt(9:0)										
11	TPf(15:0)																
12	ERb*(15:0)																
13	RDF(3:0)				RIF(3:0)				reserved								
14	FinRateCount(5:0)							LastInRateSent(9:0)									
15	LastFRMSent(3:0)			ToT	ToA	ADTF(9:0)											

Note: \* = value represented in exponent-mantissa format as described in ATM Forum TM Specification 4.1 [ 2 ].



**Table 3-54 AVT Context Table: ABR-VS/VD Parameter Description**

Parameter	Initial Value	Comment
Config(6:0)	configure	see <a href="#">Section 3.6.9.5</a> for mapping
TPi(15:0)	configure	Time Parameter corresponding to the Initial Cell Rate (ICR); constant connection parameter; if the SCAN detects the ADTF time-out it writes the TPi value to the TPf field, i.e. it switches to ICR.
VCI/LCI(15:0)	configure	cell header template: VCI/LCI of the ABR connection (depends on LCI mapping)
VPI/LCI(11:0)	configure	cell header template: VPI/LCI of the ABR connection (depends on LCI mapping)
PTI(2:0)	configure	cell header template: value ignored by HW, optionally in FW: if <b>not</b> 110 then discard RM cell fragment
C	configure	cell header template: CLP bit (=0)
MCRf*	configure	Lower bound for VS ACR calculation
PCRf*	configure	Upper bound for VS ACR calculation
RDF(3:0)	configure	Rate Decrease Factor for VS ACR calculation (given as right shift)
RIF(3:0)	configure	Rate Increase Factor for VS ACR calculation (given as right shift)
ADTF(9:0)	configure	ACR Decrease Time Factor (optional ABR negotiation parameter, default 500 ms) for time-out detection in SCAN
Flags(3:0)	0	reserved for internal use by IOP
F0	0	reserved for internal use by ABM-P core
EFCId	0	EFCI stored for downstream user cell
EFCIu	0	EFCI stored for upstream user cell
UDF1(7:0)	0	cell header template: UDF1 field (may contain part of LCI, depends on LCI mapping)
UDF2(7:0)	0	cell header template: UDF2 field
CIb/NIb	0	CI/NI extracted from received BRM cells; used together with ERb to calculate ACRf

**Functional Description**
**Table 3-54 AVT Context Table: ABR-VS/VD Parameter Description (cont'd)**

Parameter	Initial Value	Comment
CCRf*(15:0)	0	Current Cell Rate field in generated FRM cells; set equal to ACRf* according to TM4.1
ERb*(15:0)	PCRf	Explicit Rate extracted from received BRM cells; used together with Clb/Nlb to calculate ACRf
ERt*(15:0)	PCRf	Explicit Rate extracted from received FRM cells; latest value is stored for transparent forwarding in generated BRM cells
Cl/Nl	0	Latest Cl/Nl values extracted from received FRM cells; stored for transparent loop back to the remote destination in generated BRM cells
InRateCount(5:0)	0	Count all (user and RM cells) InRate events - Check against Nrm (>=2, default 32), Nrm is FW constant in Cache
LastFRMSent(3:0)	0	Count 10ms Cnt events - Check against Trm (default 100ms => 10d), Trm is global register value
LastInRateSent(9:0)	0	Count 10ms Cnt events - Check against ADTF
CRM(5:0)	32	Max. number of RM cells in the loop, granularity 16: 16, 32, 48, 64, ...1024; constant connection parameter
CRMcnt(9:0)	0	Current number of RM cells in the loop
TPf(15:0)	TPi	Time Parameter corresponding to the Allowed Cell Rate (ACR), resulted from ACR calculation for up- or downstream PCR limiter; only one of them may be enabled using the configuration bit 3 (ABR_FWD_Enable)

Note: The cell header template is used for generating new BRM cells. It is overwritten by each incoming FRM cell. It is necessary to initialize these fields because BRM cells might be generated before the first FRM cell comes in.

---

**Functional Description**

The following parameters are supported as global values common to all ABR connections (“[Firmware Parameter Configuration](#)” on [Page 154](#) provides the details):

- Trm** To be set in register “[ERCCONF1](#)” on [Page 340](#)  
Granularity 100 ms, value:  $100 \text{ ms} \cdot 2^{(-\text{Trm})}$ , range:  $(2^{(-7)} \dots 2^0) \cdot 100 \text{ ms}$
- Nrm** Provided to ERC unit via mailbox  
(CacheVarWrite: Command=0x8, see [Section 3.5.2.3](#)).
- CDF** Provided to ERC unit via mailbox  
(CacheVarWrite:Command=0x8, see [Section 3.5.2.3](#)).

### 3.6.9.3 AVT Context RAM Section for ABR-ER Support

In ABR-ER mode, one connection entry requires two AVT Context RAM sections with a total of 8 double words. Since the AVT table is accessed from the external micro controller via a 16-bit transfer register, the ABR-ER connection context appears as a 16-bit organized table with 16 entries as shown in [Table 3-55](#).

Assuming that each bi-directional ABR connection has two sides, A and B, and the upstream core is handling traffic from A->B and the downstream core is handling traffic from B->A; then, parameters with suffix **b** denote direction A->B, and parameters with suffix **f** denote direction B->A.

**Table 3-55 AVT Context Table: ABR-ER (Table Layout)**

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	Config(6:0)							unused			C1f	N1f	C1b	N1b	EFC1d	EFC1u
1	Qlenb(13:0)														QL0b(1:0)	
2	MCRb*(15:0)															
3	SumdTb(15:0)															
4	SumdTb(20:16)					Vb	Cntb(4:0)				Tlastb(20:16)					
5	Tlastb(15:0)															
6	TPb(15:0)															
7	ERf*(15:0)															
8	0	0	0	0	0	0	0	unused								
9	Qlenf(13:0)														QL0f(1:0)	
10	MCRf*(15:0)															
11	SumdTf(15:0)															
12	SumdTf(20:16)					Vf	Cntf(4:0)				Tlastf(20:16)					
13	Tlastf(15:0)															
14	TPf(15:0)															
15	ERb*(15:0)															

Note: \* = value represented in exponent-mantissa format as described in ATM Forum TM Specification 4.1 [ 2 ].

**Table 3-56 AVT Context Table: ABR-ER Parameter Description**

Parameter	Initial Value	Comment
Config(6:0)	configure	See <a href="#">Section 3.6.9.5</a> for mapping
QL0(1:0)	configure	Ideal Queue Length (selects one out of four possible operating points: 00 = 256, 01=512, 10=1024, 11=2048)
MCR	configure	Lower bound for ER calculation
CI/NI	0/0	If Config[3] = 1 CI/NI extracted from received FRM cells; If Config[3] = 0 CI/NI extracted from received BRM cells; unused
EFClu	0	EFCI stored from upstream user cell; unused
EFCld	0	EFCI stored from downstream user cell; unused
Qlen(13:0)	0	Stores current queue length received via Emit FIFO, used internally for ER calculation; unused
SumdT(20:0)	0	Cumulated time interval for CCR measurement
V	0	Tlast valid indication
Cnt(4:0)	0	Counter used in CCR measurement
Tlast(20:0)	don't care	Timestamp of last emit event, used in conjunction with Tnow to measure inter departure time of cells for the ABR connection
TP(15:0)	TPmin	If RSC, Time Parameter TP is derived from the incoming ER values to adjust the PCR limiter; only one of them may be enabled using the configuration bit 3 ( <b>ABR-FWD enable;</b> )
ER(15:0)	FFFFh	If Config[3] = 1 ER extracted from received FRM cells; If Config[3] = 0 ER extracted from received BRM cells; used for RSC

### 3.6.9.4 AVT Context RAM Section for VBR Shaping Support

In VBR shaping mode, one connection entry requires one AVT Context RAM section with a total of four double words. Since the AVT table is accessed from the external micro controller via a 16-bit transfer register, the VBR connection context appears as a 16-bit organized table with 8 entries as shown in [Table 3-57](#):

**Table 3-57 AVT Context Table: VBR Shaping (Table Layout)**

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	Config(6:0)								TET(23:16)							
1	TET(15:0)															
2a	ST1(12:0)												ST0(12:10)			
3a	ST0(9:0)								STf(5:0)							
2b	unused												VDT(18:16)			
3b	VDT(15:0)															
4	unused		TeV		Temit(12:0)											
5	tauS(15:0)															
6	TS(15:0)															
7	TP(15:0)															

Note: Entry 2/3 is used for 2 purposes:

- a) Internal Relog–Relog/Reschedule: two possible ST values for low and high priority cells
- b) Relog/Reschedule–Emit: VDT of next cell

**Table 3-58 AVT Context Table: VBR Shaping Parameter Description**

Parameter	Initial Value	Comment
Config(6:0)	configure	See <a href="#">Section 3.6.9.5</a> for mapping
tauS(15:0)	configure	Delay tolerance parameter tau for SCR extension (15:10) and integer (9:0) part
TP(15:0)	configure	Rate parameter for peak rate limiter integer (15:6) and fractional (5:0) part
TS(15:0)	configure	Rate parameter for SCR-Leaky Bucket integer (15:6) and fractional (5:0) part
TET(23:0)	don't care	Theoretical Emit Time for SCR
VDT(18:0)	don't care	Virtual departure time of cell extension (18:16), integer (15:6) and fractional (5:0) part

**Functional Description**

**Table 3-58 AVT Context Table: VBR Shaping Parameter Description (cont'd)**

<b>Parameter</b>	<b>Initial Value</b>	<b>Comment</b>
ST0(12:0)	don't care	Scheduled departure Time for CLP=0 cell extension (12:10) and integer (9:0) part
ST1(12:0)	don't care	Scheduled departure Time for CLP=1 cell extension (12:10) and integer (9:0) part
STf(5:0)	don't care	Scheduled departure Time common fractional part for CLP=0 and CLP=1
TeV	0	Temit valid
Temit(12:0)	don't care	Real Emit Time

### 3.6.9.5 Common AVT CONFIG Field

The first word (WORD0) of each entry defines the entry type (inactive, ABR, VBR) with its respective submodes. The mapping of the 7 configuration bits Config(6:0) is summarized in [Table 3-59](#).

**Table 3-59 Config(6:0) Bit Map**

Config field bit	absolute WORD bit	Function		
Bit 6	Bit 15	ERC enable	if '1' then ERC functions enabled	
Bit 5	Bit 14	ABR enable	'1': ABR Mode	'0': VBR Mode
Bit 4	Bit 13	ABR-VS/VD enable; Core select	'1': VS/VD Mode  '0': ER Mode	'0': upstream core  1': downstream core
Bit 3	Bit 12	ABR-FWD enable; VBR mode	ER: '1': BRM cell update '0': FRM cell update VS/VD: '1': downstream rate ctrl. '0': upstream rate ctrl.	'0': VBR1 '1': VBR2 and VBR3
Bit 2	Bit 11	ABR-BIDIR enable	'1': Bi-directional mode enabled '0': Uni-directional mode enabled	CLP (used internally, default don't care)
Bit 1	Bit 10	ABR-RSC enable	'1': Reactive Switch Control enabled	STvalid (used internally, def. 0)
Bit 0	Bit 9	unused	unused	TETvalid (used internally, def. 0)

Note: For both ABR-ER and ABR-VS/VD, the configuration bit field Config(6:0) in WORD8 is ignored and may be set to 0.

Note: Uni-directional mode is not supported in first firmware version.



### 3.6.10 ERC Message Interface

#### 3.6.10.1 RM\_Cell FIFO Organization (IOP/FW View)

The ABM-P core extracts the first 7 dwords of every incoming RM Cell, prepends the QID of the respective connection and forwards the resulting RM Cell dataset to the RM FIFO. The IOP always sees the first entry of the RM FIFO, i.e. the longest waiting RM cell.

The format of the RM FIFO entries is shown in [Table 3-60](#):

**Table 3-60 RM Cell FIFO Entry (16 bit IOP View)**

w\b	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
1	0	0	0	0	0	QID(10:0)										
2	VPI(11:0)											VCI(15:12)				
3	VCI(11:0)											PTI		C		
4	UDF1(7:0)							UDF2(7:0)								
5	ID(7:0)							DIR	BN	CI	NI	RA	reserved			
6	ER(15:0)															
7	CCR(15:0)															
8	MCR(15:0)															
9	QueueLength(31:16) (not supported)															
10	QueueLength(15:0) (not supported)															
11	SequenceNumber(31:16) (not supported)															
12	SequenceNumber(15:0) (not supported)															
13	don't care															
14	unused															
15	unused															

Note: Using the 4-bit SubAddress, the IOP can directly access any of the 16 words.

Remarks on RM FIFO fields:

Words 2 - 15 are copied literally from the RM cell. Shaded regions are not used.

ID(7:0) Protocol Identifier (should be 1 for ABR)  
value forwarded but not evaluated by HW, optionally in FW: if *not* 1 then discard RM cell fragment.

Functional Description

**3.6.10.2 Emit FIFO Organization (IOP/FW View)**

This FIFO stores Emit and time-out events from both cores. Each event is stored in 3 successive 16-bit words. The mapping of the parameters in the 3 words depends on the event type:

**Table 3-61 Emit FIFO Entry for Emit Events**

wb	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	Tnow(19:16)				Core	QID(10:0)										
1	0	0	Qlen(13:0)													
2	Tnow(15:0)															

- Core Indicates upstream(0) or downstream (1) emit event
- QID(10:0) 2k-1 QID (range 1 to 2047), only 1k-1 (even numbers) used for ABR; QID 0 is reserved for CRT bypass
- Tnow(19:0) Cell emit time for rate calculation in ER algorithm. Tnow counts cell cycles. The granularity Tnow is defined by the global parameter TstepC, located in [Register 70 "USCONF/DSCONF" on Page 295](#) and calculated as follows:  
Granularity of Tnow = 2 \*\* TstepC
- Qlen Queue length from Buffer Manager for ER algorithm

**Table 3-62 Emit FIFO Entry for Time-out Events in VS/VD Mode**

wb	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	Core	QID(10:0)										
1	ToT	ToA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

- Core Indicates upstream(0) or downstream (1) rate control
- QID(10:0) 2k-1 QID (range 1 to 2047), only 1k-1 (even numbers) used for ABR; QID 0 is reserved for CRT bypass
- ToT 1 if time-out event Trm (set by SCAN)
- ToA 1 if time-out event ADTF (set by SCAN)

**Table 3-63 Emit FIFO Entry for Time-out Events in ER Mode**

wb	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	Core	QID(10:0)										
1	ToF	ToB	0	0	0	0	0	0	0	0	0	0	0	0	0	0
2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

---

**Functional Description**

Core	Indicates upstream(0) or downstream (1) time-out event
QID(10:0)	2k-1 QID (range 1 to 2047), only 1k-1 (even numbers) used for ABR; QID 0 is reserved for CRT bypass
ToF	1 if time-out in forward direction
ToB	1 if time-out in backward direction

**3.6.11 QCIT: Congestion Indication Table**

The function of the QCIT table (for 8192 downstream queues) is to determine the per queue threshold that triggers the queue congestion indication toward the QCI interface. [“Queue Congestion Indication Table Transfer Register” on Page 286](#) provides the details.

## 4 Operational Description

### 4.1 Basic Device Initialization

The following actions are recommended to be performed after reset to prepare the ABM-P chip for operation:

#### Basic settings

- Configure clocking system (DPLLs)
- Check register reset values
- Initialize SDRAM
- Reset internal tables (RAM)

#### ABM-P diagnostic possibilities

- Check all internal RAM and register values
- Check external RAM

#### Data path setting and initial queueing and scheduling initialization

- Set MODE1 and MODE2 registers  
(Uni-directional Mode or Bi-directional Mode)
- Configure UTOPIA Interfaces: modes, number of PHYs
- Set global thresholds
- Initialize traffic class tables
- Set interrupt mask registers
- Programming of Scheduler output rates
- Programming of Empty Cell Rate generator
- Programming of Common Real Time Queue rate
- Assignment of Scheduler Blocks to PHYs at switch egress side
- Assignment of Scheduler Blocks to switch outputs at ingress side
- Initialization of IOP variables

Refer to the detailed register descriptions in [Chapter 7](#) for a complete picture of the necessary initializations.

### 4.2 Basic Traffic Management Initialization


To set up a connection, the complete table structure must be established:

LCI → QID → SBID and

LCI → QID → TCID

**Operational Description**

(see **Figure 4-1**). Additionally, bandwidth and buffer space reservations must be performed (see below). Depending on the traffic class, special functions must be enabled; for example: ABR feedback enable or EPD/PPD for UBR.



**Figure 4-1 Parameters for Connection Setup (bit field width indicated)**

**Operational Description**

Figure 4-1 refers to the following parameters:

<b>ABM-P Transfer Register</b>	<b>Parameter</b>	<b>Description</b>	<b>See page</b>
<b>LCI0</b>	CLPT	If set, the CLP bit of the cells is ignored. (not to be set for GFR; optional for ABR and UBR)	7-238
	ABMcore	Selects upstream or downstream ABM-P Core in the Uni-directional Mode	7-238
<b>LCI1</b>	DnQID	Points to the queue assigned to this connection in the downstream direction	7-239
	Dnflags	PPD(0), EPD(1), EOP(2)	7-239
<b>LCI2</b>	UpQID	Points to the queue assigned to this connection in the upstream direction	7-240
	Upflags	PPD(0), EPD(1), EOP(2)	7-240
<b>QCT0</b>	QueueLength	Status value (Read only)	7-261
<b>QCT1</b>	SBID	Selects the Scheduler Block	7-261
	QIDvalid	Enables queue; if cleared, cells directed to this queue are discarded and interrupt QID-INV (see 7-356f.) occurs	7-261
	TCID	Selects the Traffic Class	7-261
	ABRdir	Selects the ABM-P Core in which RM cell update is made for ABR connections	7-261
	VS/VDen	Enables ABR-VS/VD (ERC unit) functions for this queue	7-261
	RSall	Enables the dummy queue function	7-261
	DQac	Status bit	7-261

**Operational Description**

<b>ABM-P Transfer Register</b>	<b>Parameter</b>	<b>Description</b>	<b>See page</b>
<b>QCT2</b>	MinBG	Minimum buffer guaranteed per queue	7-264
	MGID	Selects the VC-Merge Group the queue is assigned to	7-264
	MGconf/DQsch	Command bit to enable merge group assignment or dummy queue status indication	7-264
<b>SBOC0</b>	DBAThCross	DBA threshold crossing indication	7-272
<b>TCT0</b>	BufMax	Defines maximum number of non-guaranteed cells allowed in the entire buffer for this traffic class	7-244
	BufEPD	Defines threshold for EPD/maximum <sup>1)</sup> for this traffic class for the entire buffer	7-244
	QueueCiCLP1	Combined threshold for each queue for CI indication (ABR) and CLP=1 cell discard in case of CLPT=0	7-244
<b>TCT1</b>	QueueMax	Defines threshold for each queue for this traffic class	7-247
	BufCiCLP	This 8-bit value determines a global cell filling level threshold with a granularity of 1024 cells that triggers early packet discard (EPD) for CLP=1 tagged frames used by GFR traffic class service (low watermark)	7-247
<b>TCT2</b>	SBCiCLP	This threshold determines a maximum number of low priority cells allowed to be stored per scheduler block with a granularity of 64 cells	7-250

**Operational Description**

<b>ABM-P Transfer Register</b>	<b>Parameter</b>	<b>Description</b>	<b>See page</b>
<b>TCT3</b>	DH	Selects the hysteresis value for threshold evaluation	7-253
	ABRen	If set, binary ABR marking by ABM-P core is enabled	7-253
	ABRVp	(ABR service category) relating to the VP or to the individual VC, respectively; If set, congestion is indicated via VP RM cells (F4 flow)	7-253
	EPDen	If set, EPD is enabled	7-253
	PPDen	If set, PPD is enabled	7-253
	SCNT	Selects whether accepted packets or cells are counted	7-253
	CntLPDBA	Selects whether low and high priority cells are counted separately for DBA thresholds	7-253
	GFRen	This bit enables a modified EPD threshold evaluation for GFR traffic	7-253
	CLPTransDBA	Specifies whether the CLP bit of cells belonging to this connection is evaluated or not for DBA threshold checks and counters.	7-253
	TrafClassMax	Defines maximum number of cells for this traffic class	7-253
	SBMax	Defines threshold for the number of cells of this traffic class allowed in the associated Scheduler	7-253
QPT1	flags	Initialization value	7-298



**Operational Description**

<b>ABM-P Transfer Register</b>	<b>Parameter</b>	<b>Description</b>	<b>See page</b>
QPT2	RateFactor	Select value of peak rate limiter	7-302
	WFQFactor	Weight of scheduler input in 16,320 steps	7-303
SCTI	IntRate	Integer part of incremental value for Scheduler output rate	7-309
	Init	Initialization value for SB counter	
	UTOPIAPort	Specify UTOPIA port for this scheduler	7-309
SCTF	FracRate	Fractional part of incremental value for Scheduler output rate	7-318

<sup>\*)</sup> mixed threshold: EPD if enabled; otherwise, maximum threshold

#### 4.2.1 Setup of Queues

Before assigning a connection to a new queue, it should be verified to be empty, as some cells could remain from the previous connection. A queue is emptied by setting it 'invalid' while maintaining the scheduling parameters. An invalid queue will not except further cells; cells will be scheduled and de-queued, but not transmitted to the UTOPIA Interface. The queue length can be monitored by the external microprocessor.

## 4.2.2 Programming Queue Scheduler Rates and Granularities

### 4.2.2.1 Scheduler Block Scheduler

The aggregate theoretical **peak cell rate** of the SBS is calculated as follows:

$$PCR_{SBS} = \frac{SYSCLK}{32} \quad [\text{cells/s}] \quad (4)$$

SYSCLK designates the core clock frequency. Each cell cycle needs 32 clock cycles. With the core SYSCLK = 51.84 [MHz] we have  $PCR_{SBS} = 1620000$  [cells/s].

This corresponds to 686,8 [Mbit/s] for 53 byte cells

Note: Due to the need to perform internal SDRAM refresh cycles, the  $PCR_{SBS}$  contains empty cells. A discussion on the empty cell rate  $PCR_{empty}$ , which restricts the maximum scheduler block rate is contained in [Section 4.2.2.4](#).

### 4.2.2.2 Programming the Scheduler Block Rates

For the **peak cell rate** of an SB we can have  $PCR_{SB} = PCR_{SBS} - PCR_{empty}$ .

In the following, let LC denote the logical channel assigned to an SB. Recall that a logical channel can subsume the whole output port or an reasonable subdivision.

Let  $CCR_{SB}$  denote the **configured cell rate** of an SB (i.e. the desired output cell rate).

$CCR_{SB(LC)} = PCR_{LC}$  must be chosen to match the peak cell rates of the LC as close as possible. Both permanent overload, leading to UTOPIA backpressure, and permanent underload, leading to poor channel utilization, should be avoided.

Overall, the following holds

$$\sum_{LC} CCR_{SB(LC)} \leq PCR_{UTOPIA} \quad (5)$$

Note: For short periods of time  $PCR_{SB}$  as defined above can occur internally, independent of the particular  $CCR_{SB}$

### Deriving Internal Parameters from a Given $CCR_{SB}$

Internally the scheduler block output cell rate  $CCR_{SB}$  is represented by two parameters:

$T_{SB(i)}[13:0]$ , the 14 bit integer division factor

$T_{SB(f)}[7:0]$ , the 8 bit fractional division factor

These parameters are dimensionless and thus only indirectly represent the output rate. The following formulas show how to derive the two parameters assuming a given desired output rate  $CCR_{SB}$ :

**Operational Description**

First, a dimensionless floating point number  $T_{SB}$  is calculated from  $CCR_{SB}$  as follows:

$$T_{SB} = \frac{SYSCLK}{32 \times CCR_{SB}} \quad (6)$$

with  $T_{SB}$  constrained internally to

$$T_{SB} \leq 2^{14} - \frac{1}{2^8} \quad (7)$$

Therefore  $T_{SBmax} = 16383,99609$ .

Given a particular  $T_{SB}$ , the internal parameters for the SB rate can be calculated:

The integer division factor is calculated as:

$$T_{SB(i)} = \lfloor T_{SB} \rfloor \quad (8)$$

The fractional division factor is calculated as:

$$T_{SB(f)} = \min(\lceil \langle T_{SB} - \lfloor T_{SB} \rfloor \rceil \times 2^8, 255) \quad (9)$$

with  $\lfloor X \rfloor$  designating the integer part of X and  $\lceil X \rceil$  designating the next integer greater or equal to X.

The integer and fractional division factor defined above are referred to as **IntRate** and **FracRate** in the register description. Refer to **“USCTI/DSCTI” on Page 309** and **“USCTFT/DSCTFT” on Page 318**.

The **minimum cell rate** possible in an SB is configured with  $T_{SBmax}$  according to:

$$MCR_{SB} = \frac{SYSCLK}{32 \times T_{SBmax}} \quad (10)$$

The following **Table 4-2** shows the rate limits for the SB as a function of the system clock SYSCLK.

**Table 4-2 Scheduler Block Rate Limits**

<b>SYSCLK [MHz]</b>	<b>Cell cycle [ns]</b>	<b>PCR<sub>SB</sub> [cells/s]</b>	<b>MCR<sub>SB</sub> [cells/s]</b>	<b>MBR<sub>SB</sub> [bit/s] (53)</b>
51.84	617	1556000	98.8769	41924
60	533	1811000	114.4409	48523

In **Table 4-3**, the numerical values of the integer and fractional divisors are shown for different desired  $CCR_{SB}$ . Due to the limited resolution of the internal rate representation,

Operational Description

the delivered  $CCR_{SB}$  measured at the scheduler output does not always match exactly the desired  $CCR_{SB}$ . The delivered  $CCR_{SB}$  is calculated by:

$$CCR_{SB} = \frac{SYSCLK}{32 \times \left( T_{SB(i)} + \frac{T_{SB(f)}}{256} \right)} \quad (11)$$

**Table 4-3 SB Rate Calculation Examples for SYSCLK = 51.84 MHz**

Desired $CCR_{SB}$ [cells/s]	$T_{SB}$	$T_{SB(i)}$	$T_{SB(f)}$	Delivered $CCR_{SB}$ [cells/s]
4830	335.4037	335	104	4829.963
353108	4.5878	4	151	352953.191
1412429	1.1469	1	38	1410612.245

The deviation of the delivered CCR from the desired CCR is always less than 1 ‰ and improves towards lower CCR.

**Scheduler Block Burst Limitation**

Per scheduler block cell bursts can occur due to previously unused cell cycles. Each SB has an event generator that determines when this SB should be served based on the programmed SB rates. Because several SB may share one UTOPIA interface, it can happen that events cannot be served immediately due to active cell transfers of previous events. Such 'unused cell cycles' are counted and can be used for later cell bursts allowing a near 100% SB rate utilization. Cell bursts due to this mechanism are not rate limited.

The maximum burst size (MBS) generated due to previously counted 'unused cell cycles', is controlled by bit field MaxBurstS(3:0) in the range 0..15 cells (a minimum value of at least 1 is recommended). MaxBurst is programmed in registers "[UECRI/DECRI](#)" on Page 312.

Per SB MBS dimensioning depends on the burst tolerance (BT) of subsequent devices (buffer capacity and backpressure capability).

For example, if PHY(s) connected to the ABM-P do not support backpressure and provide a 3-cell transmit buffer, a value in the range 1..3 is recommended to avoid PHY buffer overflows resulting in cell losses (e.g. typical for ADSL PHYs connected to the ABM-P).

If a PHY is connected that supports port specific backpressure to prevent its transmit buffers from overflowing or provides sufficient buffering, the maximum value of 15 can be programmed, guaranteeing a near 100% scheduler rate utilization.

#### 4.2.2.3 Programming the Common Real-Time Bypass

The Common Real-Time bypass (CRT) is denoted by the reserved logical queue identifier QID = 0. The rate assigned to the CRT bypass is programmed in the same way as the SB rates. The parameters **CRTIntRate** and **CRTFracRate** are described in registers “**UCRTRI/DCRTRI**” on Page 327 and “**UCRTRF/DCRTRF**” on Page 328.

#### 4.2.2.4 Programming the SDRAM Refresh Empty Cell Cycles

The programming of the rate for the internal SDRAM refresh generator is done by calculating the integer and fractional parts of the dimensionless value  $T_{\text{empty}}$  according to the SB formulas (Equation (8) and Equation (9)).

$T_{\text{empty}}$  is constrained by the need to allow a minimum number of empty cell cycles for the internal SDRAM refresh generator according to:

$$T_{\text{empty}} \leq \frac{\text{SYSCLK} \times \text{RefreshPeriod}}{32 \times \text{RefreshCycles}} \quad (12)$$

Given values of RefreshPeriod = 64ms, RefreshCycles = 4096 then

at SYSCLK = 51.84 MHz,  $T_{\text{empty}} = 25.3125$ ,  $T_{\text{empty}(i)} = 25$ ,  $T_{\text{empty}(f)} = 80$

at SYSCLK = 60 MHz,  $T_{\text{empty}} = 29.2968$ ,  $T_{\text{empty}(i)} = 29$ ,  $T_{\text{empty}(f)} = 76$

This renders  $\text{PCR}_{\text{empty}} = 64000$  [cells/s] in both cases.

In case additional bandwidth needs to be reserved (e.g. for multicast operation in subsequent devices), a second maximum condition for parameter  $T_{\text{emptyMC}}$  can be derived depending on the empty cell rate required for multicast bandwidth reservation.

The cell rate for the empty cell cycles  $\text{PCR}_{\text{empty}}$  is programmed by setting  $T_{\text{empty}(i)}$  and  $T_{\text{empty}(f)}$ , referred to as **ECIntRate** and **ECFracRate** in the corresponding registers “**UECRI/DECRI**” on Page 312 and “**UECRF/DECRF**” on Page 313.

#### 4.2.2.5 Programming the PCR Limiter

For each logical queue, an optional peak rate shaper can be programmed.

Each cell passing the PCR limiter needs at least 2 cell cycles to emit. This limits the maximum PCR that can be shaped to:

$$\text{PCR}_{\text{Rmax}} = \frac{\text{SYSCLK}}{32} \times \frac{1}{2} \quad [\text{cells/s}] \quad (13)$$

The resolution of the PCR limiter is determined by the global parameter  $T_{\text{stepC}}$ , common for all shapers in an ABM-P core.

Operational Description

TstepC is configured per direction by the field TstepC[2:0] described in “[USCONF/DSCONF](#)” on [Page 295](#). Internally the shaper use a derived value Tstep with the following interpretation:

$$Tstep = 2^{TstepC - 8} \quad (14)$$

This renders Tstep in the range 1/2 ... 1/256.

Smaller values for TstepC and in consequence Tstep imply lower shaping rates.

Given a particular TP, the resulting PCR shaping rate is calculated as follows:

$$PCR_{RS} = \frac{SYSCLK}{32} \times Tstep \times \frac{64}{TP} \quad (15)$$

Vice versa, for a given PCR, the corresponding TP value is calculated as:

$$TP = \left\lceil \frac{SYSCLK}{32} \times Tstep \times \frac{64}{PCR_{RS}} \right\rceil \quad (16)$$

The value of parameter TP is constrained internally to:

$$TP \leq 2^{16} - 2^6 \quad (17)$$

Therefore,  $TP_{max} = 65472$ .

Though possible to specify, very low values of TP do not make much sense, because the shaper is limited by  $PCR_{RSmax}$  in any case (see [Equation \(13\)](#)). Together with [Equation \(15\)](#) this leads to the following constraint on TP:

$$TP \geq \max(1, Tstep \times 128) \quad (18)$$

The following special case must be considered:

TP = 0 disables the shaper, connecting the queue directly to the level 1 schedulers (RR / WFQ).

**Operational Description**

**Table 4-4** shows minimum PCR shaper rates for all the possible values of TstepC calculated at a SYSCLK of 51.84 MHz and 60 MHz with TPmax and [Equation \(15\)](#).

**Table 4-4 Minimum Shaper Rates as a Function of TstepC and SYSCLK**

TstepC	1/Tstep	SYSCLK = 51.84 [MHz]		SYSCLK = 60 [MHz]	
		PCR <sub>RSmin</sub> [cells/s]	PBR <sub>RSmin</sub> [bit/s]	PCR <sub>RSmin</sub> [cells/s]	PBR <sub>RSmin</sub> [bit/s]
0	256	6.185	2622	7.160	3036
1	128	12.371	5245	14.320	6072
2	64	24.743	10491	28.639	12143
3	32	49.487	20982	57.278	24286
4	16	98.975	41965	114.555	48572
5	8	197.950	83930	229.110	97143
6	4	395.900	167861	458.219	194285
7	2	791.800	335723	916.437	388569

The accuracy of the shaping rate is defined as:

$$\text{acc}_{\text{PCR}} = \frac{\text{PCR}_{\text{in}} - \text{PCR}_{\text{out}}}{\text{PCR}_{\text{out}}} \quad (19)$$

with PCR<sub>in</sub> denoting the desired PCR and PCR<sub>out</sub> denoting the delivered PCR, which is always less than PCR<sub>in</sub>.

PCR<sub>out</sub> is calculated by first deriving TP from PCR<sub>in</sub> in [Equation \(16\)](#) and then substituting TP in [Equation \(15\)](#).

The accuracy improves towards lower shaping rates and higher values of TstepC.

Note: The improvement is not monotonic and depends on the rounding error made at the calculation of TP. However, from the formulas given above, it can be deduced that the accuracy is always better than:

$$\text{acc}_{\text{PCR}} \leq \frac{\text{PCR}_{\text{in}}}{2 \times \text{SYSCLK} \times \text{Tstep}} \quad (20)$$

Operational Description

**Table 4-5** shows the accuracy of the shaping rate at some characteristic rates for three selected values of TstepC.

**Table 4-5 Shaper Accuracy as a Function of desired PCR and TstepC**

desired PCR	acc <sub>PCR</sub> at SYSCLK = 51.84 [MHz]		
	TstepC = 0	TstepC = 4	TstepC = 7
32	0.000059	not possible	not possible
64	0.000138	not possible	not possible
170	0.000271	0.000009	not possible
4830	0.001774	0.000286	0.000007
101957	0.006934	0.006934	0.001081
353108	0.425621	0.034140	0.001288

Regarding the inevitable jitter (CDV) produced by the rate shaper due to its limited accuracy, it improves towards higher shaping rates and higher values of TstepC.

The value of parameter TP derived above is programmed into the field **RateFactor** in register **“UQPT2T0/DQPT2T0”** on [Page 302](#).

Note: A value of 0 in field RateFactor disables both the PCR limiter and the leaky bucket shaper. Values other than 0 in field RateFactor are ignored for queues with an additional leaky bucket shaper enabled. The parameter TP defined there overrides. See [Section 4.2.2.6](#).

#### 4.2.2.6 Programming the Leaky Bucket Shaper

Regarding the Leaky Bucket Shaper, the formulas given previously in [Section 4.2.2.5](#) apply accordingly when substituting SCR for PCR and TS for TP.

In addition, given MBS, the parameter tauS is calculated as:

$$\text{tauS} = (\text{MBS} - 1) \times \left( \frac{\text{TS} - \text{TP}}{64} \right) \quad (21)$$

with tauS constrained internally to:

$$\text{tauS} \leq 2^{16} - 2^{10} \quad (22)$$

Therefore, tauS<sub>max</sub> = 64512.



**Operational Description**

Given a particular  $\tau_S$ , the burst tolerance BT and the corresponding MBS produced by the leaky bucket shaper is calculated as:

$$BT = \frac{\tau_S}{T_{step}} \times \frac{32}{SYSCLK} \quad [\text{sec}] \quad (23)$$

and

$$MBS = \left\lceil 1 + \frac{\tau_S \times 64}{TS - TP} \right\rceil \quad [\text{cells}] \quad (24)$$

The maximum BT has been derived from  $\tau_{S_{max}}$  and is shown in [Table 4-6](#) for different values of  $T_{stepC}$  and  $SYSCLK$ .

**Table 4-6 Maximum BT as a Function of  $T_{stepC}$  and  $SYSCLK$**

<b><math>T_{stepC}</math></b>	<b><math>1/T_{step}</math></b>	<b>BT [s]</b>	
		<b><math>SYSCLK = 51.84</math> [MHz]</b>	<b><math>SYSCLK = 60</math> [MHz]</b>
0	256	10.192	8.807
1	128	5.097	4.403
2	64	2.548	2.201
3	32	1.274	1.100
4	16	0.637	0.550
5	8	0.318	0.275
6	4	0.159	0.137
7	2	0.079	0.068

Refer to [“AVT Context Table: VBR Shaping \(Table Layout\)” on Page 126](#) for a detailed description and layout of the parameter fields.

#### 4.2.2.7 Guaranteed Cell Rates and WFQ Weight Factors

The total WFQ scheduler rate is calculated as follows:

$$GCR_{WFQ} = CCR_{SB} - ECR_{RT(SB)} \quad (25)$$

with  $CCR_{SB}$  being the configured SB rate as defined in [Section 4.2.2.2](#) and  $ECR_{RT(SB)}$  being the effective cell rate of the high priority RR scheduler in the SB.

$GCR_{WFQ}$  is distributed to the queues in proportion to the queue's relative weight factor  $1/T_{WFQ}$ .

The guaranteed cell rate for connection  $i$  is calculated according to:

$$GCR_i = \frac{GCR_{WFQ}}{T_{WFQ(i)} \times \sum_{\forall k \in \text{Active Queues}} 1/T_{WFQ(k)}} \quad (26)$$

with  $T_{WFQ}$  constrained internally to:

$$T_{WFQ} \leq 2^{14} - 2^6 \quad (27)$$

Therefore,  $T_{WFQmax} = 16320$ .

The minimum guaranteed cell rate at a given  $GCR_{WFQ}$  is therefore:

$$GCR_{min} = \frac{GCR_{WFQ}}{T_{WFQmax}} \quad (28)$$

Assuming a fixed given  $GCR_{min}$ , then for any given  $GCR \geq GCR_{min}$  the corresponding  $T_{WFQ}$  can be calculated as:

$$T_{WFQ} = \left\lceil \frac{GCR_{min} \times T_{WFQmax}}{GCR} \right\rceil \quad (29)$$

The integer function in equation above selects the next smaller value of the integer  $T_{WFQ}$ , that is to say, the weight factor is higher than required and, thus, the queue is served slightly faster in order to guarantee the rate.

Two special cases must be considered:

$T_{WFQ} = 0$  is used to assign the queue to the high priority round robin scheduler.

$T_{WFQ} = 16383$  is used to assign the queue to the low priority round robin scheduler.

$T_{WFQ}$  is referred to as parameter **WFQFactor** in the register description "[UQPT2T1/DQPT2T1](#)" on [Page 303](#).


### 4.2.3 ABM-P Configuration Example

In this section, a popular mini-switch scenario (Figure 4-7) is used to describe the most important points for the software configuration of the ABM-P. Among other things, the following fixed assignments can be made in software by the user:

- Assignment of Schedulers to PHYs and programming of Scheduler output rates
- Definition of the necessary traffic classes
- Assignment of the queues to the traffic classes
- Assignment of the queues (QIDs) to the Schedulers (SBIDs)

#### Assignment of Schedulers and Programming Output Rates

The ABM-P has 256 Schedulers (128 in the upstream direction and 128 in the downstream direction). In this example each xDSL device is assigned to a separate Scheduler (this guarantees each xDSL device a 2-Mbit/s data throughput without bandwidth restrictions caused by the other xDSL devices); then, 255 xDSL devices can be connected. The 256th Scheduler will be occupied by the E3 uplink to the public network. The assignment of the Schedulers to the PHYs is totally independent and even such a strong asymmetrical structure as in (Figure 4-7) can be supported. The output rates of the Schedulers must be programmed in such a way that the total sum does not exceed 622 Mbit/s (payload rate). From the example, the following result is derived:  $255 \times 2 \text{ Mbit/s} + 1 \times 34 \text{ Mbit/s} = 544 \text{ Mbit/s} \leq 622 \text{ Mbit/s}$ .



**Figure 4-7 ABM-P Application Example: DSLAM**

### Definition of Necessary Traffic Classes

The ABM-P allows up to 16 traffic classes to be defined by Traffic Class Table RAM entry via the registers TCT0 to TCT3 (see [Page 244f](#)). In this example, there are 3 traffic classes:

- CBR (real-time) = traffic class 1
- GFR (non-real-time) = traffic class 2
- UBR (non-real-time) = traffic class 3

### Assignment of the Queues to the Traffic Classes

Each queue must relate to a defined traffic class according to the Queue Configuration Table RAM entry via the TCID(3:0) bits of the QCT table.

### Assignment of the Queues (QIDs) to the Scheduler Blocks (SBIDs)

Every Scheduler Block (SB) possesses a certain number of queues depending on the assignment by the user of the SBID(5:0) bits of register “QCT1” on [Page 261](#). In the example, every ADSL device has four data connections so that four queues per SB are necessary. Each SB of the ABM-P has one real-time queue and an arbitrary number of non-real-time queues. For SB 0..254, indicate that the first queue belongs to Traffic Class 1, the 2nd and 3rd Queue to Traffic Class 2, and the 4th Queue to Traffic Class 3. There are 1020 (1..1020) queues altogether for SB 0..254. The 256th SB must be able to serve the 255 xDSL devices (255 SBs and appropriate queues). Thus, SB 255 has  $255 \times 2 = 510$  non-real-time queues as every SB from 0..254 possesses two GFR non-real-time queues (GFR has a guaranteed minimum rate; thus, each GFR queue needs a per VC queueing). The 255 UBR queues of SBs 0..254 need only one UBR queue at the 256th SB as UBR has no guaranteed minimum rate. As every SB has only one real-time queue, the 255 real-time queues from SBs 0..254 flow into the one real-time queue of SB 255. Therefore, SB 256 needs the assignment of  $510 \text{ (GFR)} + 1 \text{ (UBR)} + 1 \text{ (CBR)} = 512$  queues.

## 4.2.4 Normal Operation

In normal operation, no microprocessor interaction is necessary as the ABM-P chip does all queueing and scheduling automatically. For maintenance purposes, periodically the microprocessor could read out the counters for buffer overflow events. Some overflow events may also be programmed as interrupts.

The only instance of permanent microprocessor interaction is operation of the dynamic bandwidth allocation protocol. In this case, the microprocessor must permanently check the fill thresholds of the upstream SBs and adjust their output rates accordingly.

In case of static bandwidth allocation, all rate adjustments are made only at connection setup or teardown.

#### 4.2.5 Bandwidth Reservation

Due to the WFQ Scheduler concept of the ABM-P, the Connection Acceptance Check (CAC) is very simple:

- Check if the Guaranteed Rate of the connection fits within the spare bandwidth of the Scheduler.

For the definition of the Guaranteed Rate, see [Table 3-24](#). Mathematically, the CAC can be reduced to the following formulas:

For all connections make sure that no overbooking of the configured scheduler output rate  $CCR_{out}$  occurs, i.e.:

$$\sum_i GCR_i = CCR_{out} \quad (30)$$

For real-time connections, (CBR, rt-VBR) [Equation \(30\)](#) is the only condition required.

For non-real-time connections or connections using the WFQ scheduler, additional conditions must be fulfilled.

VBR, ABR and UBR+ connections must be setup in per VC queueing configurations, that is, an empty queue must be found for the connection. The Guaranteed Rate determines the weight of the queue.

##### 4.2.5.1 Bandwidth Reservation Example

As an example, an access network multiplexer is assumed with ADSL lines and an E3 uplink. CBR and UBR+ connections are supported. A minimum Guaranteed Rate of  $GR_{min} = 19.2$  Kbps is selected. This allows GR up to 314.57 Mbit/s with increasing granularity for higher values.

This behavior is well suited to the Guaranteed Rates which are minimum or sustainable rates. The values for MCR and SCR will be well below 10 Mbit/s for public networks. In high speed LANs with high MCR and SCR values, a higher minimum rate could be selected.

Additionally, it is assumed that three types of line interfaces (PHY) exist in the system: 34 Mbit/s for the uplink, ADSL rates of 8 Mbit/s downstream, and 0.6 Mbit/s upstream. For each PHY, a maximum possible weight factor  $1/n$  exists:  $n_{max} = 9$ ,  $n_{max} = 39$ , and  $n_{max} = 524$ , respectively.

Two types of non-real-time connection are defined with Guaranteed Rates of 100 kbit/s and 20 Kbps with the weight factors  $1/n$ ,  $n_{100} = 3146$  and  $n_{20} = 15730$ , respectively. The 100 Kbps connections would be used for the downstream direction, and the 20 Kbps connections for the upstream direction. [Table 4-8](#) provides the maximum number of connections possible on each PHY.

**Table 4-8 Number of Possible Connections per PHY**


PHY	GR = 100 Kbps	GR = 20 Kbps
34 Mbit/s	349	1747
8 Mbit/s	80	403
0.6 Mbit/s	6	30

For example, if the maximum number of connections for each Subscriber is fixed (such as 5 data connections), the queues can be pre-configured for each Subscriber so that only the LCI assignment must be changed when a connection is setup or released.

#### 4.2.6 Buffer Reservation

In addition to the bandwidth reservation, buffer space must be assigned by the appropriate setting of discard thresholds.

**Figure 4-9** shows an example of threshold configurations for four traffic classes (real-time, nrt-VBR, GFR, UBR).



**Figure 4-9 Example of Threshold Configuration**

#### 4.2.7 Support of Standard ATM Service Categories

The following sections provide some insight into how the ABM-P supports connections belonging to the well known ATM Forum service categories.

##### 4.2.7.1 CBR Connections

These connections should use the real-time bypass of the respective scheduler block. However, if two priority levels for real-time connections must be offered, a slightly lower real-time performance can be achieved by using the WFQ scheduler with maximum weight. In this case, the bandwidth must fit into the WFQ scheduler (conditions **(1)** and **(2)** in [“Bandwidth Reservation” on Page 149](#)).

##### 4.2.7.2 rt-VBR Connections

These connections can be treated like CBR connections with a guaranteed cell rate less than or equal to the Peak Cell Rate (PCR). Depending on the behavior of the sources, a statistical benefit could be obtained by reserving less than PCR.

As an example, assume 1000 connections with compressed voice are multiplexed on a link. PCR is 32 Kbps, but on average only 16 Kbps. SCR is 8 Kbps. Hence, instead of reserving 32 Mbit/s for the ensemble of connections, only 16 Mbit/s must be reserved. The large number of connections guarantees that the mean sum rate of 16 Mbit/s is exceeded only with a negligible probability.

##### 4.2.7.3 nrt-VBR Connections

For these connections, the three parameters PCR, SCR, and MBS are given. One queue is reserved for each nrt-VBR connection with SCR programmed as the weight of the respective Scheduler queue. The maximum queue size is set to MBS plus approximately 100 cells for cell level bursts. If the buffer space reserved for nrt-VBR connections is set to the sum of all MBS, it is guaranteed that no cell is lost. However, with a large number of nrt-VBR connections, the total reserved buffer can be smaller with a negligible number of cell losses.

For the PCR, no adjustment is necessary as the rates of the queues of a Scheduler always adjust automatically to the maximum possible values.

As an option for network endpoints, for both rt-VBR and nrt-VBR the PCR and SCR may be shaped by the PCR limiter and SCR leaky bucket shaper as described in [Chapter 3.4.2.4](#). This is useful at network boundaries (UNI/NNI) to provide conforming traffic to the subsequent policer.

##### 4.2.7.4 ABR Connections

It is recommended that ABR connections be configured with per VC queueing and with the peak rate limiter for the queue enabled. Further on, ABR logical queues are always

**Operational Description**

assigned to the WFQ scheduler of the ABM-P. The weight factor of the logical queue is derived from the MCR according to the formulas given in [Chapter 4.2.2.7](#).

The ABM-P in turn guarantees the MCR when per VC queueing is used and the appropriate weight factor is set for the queue. By assigning ABR connections to the WFQ scheduler, fair allocation of available bandwidth in proportion to the MCR is achieved. Connection Acceptance Control (CAC) must assure that no bandwidth overbooking occurs.

In the ABR VS/VD implementation of the ABM-P, BRM cells are inserted within the ACR for the turn-around of RM cells. Out-of-rate RM cell insertion is supported with the dummy cell mechanism.

A backward direction connection must be setup. In Bi-directional Mode, the same queue ID must be chosen in order to make the ABR functions work properly.

Binary ABR marking functions can be performed by programming an appropriate traffic class in the buffer manager. For ABR explicit rate or VS/VD functions, the ERC unit must be programmed accordingly for the same QID.

In Uni-directional Mode, the queue ID value with the toggled LSB must be setup for the backward direction. EFCI marking in forward data cells or CI/NI marking in backward RM cells can be enabled per traffic class.

Note: Also the LCI is toggled in the Uni-directional Mode (see [“LCI Translation in Mini-Switch Configurations” on Page 62](#)).

**4.2.7.5 UBR+ Connections**

UBR+ connections are UBR connections with MCR. They must be setup in individual queues with the weight factor guaranteeing the MCR.

To enhance the overall throughput, the EPD/PPD function is enabled.

**4.2.7.6 GFR Connections**

GFR Connections are setup like UBR+ connections with a Guaranteed Rate in individual queues, with the weight factor guaranteeing the rate for the high-priority packets. The threshold for the discard for low-priority packets must be set accordingly.

**4.2.7.7 UBR Connections**

As described in [“Bandwidth Reservation” on Page 149](#), one queue per Scheduler is reserved for UBR connections with the smallest weight assigned. All UBR connections share this queue. EPD/PPD can be enabled as the relevant parameters are stored per connection (LCI table).



#### 4.2.7.8 Generic Service Classes

Besides the standard ATM Forum service categories, other generic service classes can be flexibly supported by the ABM-P.

Quality of service differentiation in terms of absolute and relative guarantees can be achieved for any traffic stream that is segmentable into the ABM-P cell format.

#### 4.2.8 Configuration of ABR Mechanisms

Initialization of the AVT Context RAM entry is required for each ABR connection QID, to initial values as indicated in the respective tables.

##### 4.2.8.1 EFCI Marking

Enabled per traffic class together with Relative Rate Marking by setting  $ABRen=1$ . No connection specific action required.

EFCI Marking must be globally enabled in the [MODE1](#) register before.

##### 4.2.8.2 Relative Rate Marking

Enabled per traffic class together with EFCI Marking by setting  $ABRen=1$ . No connection specific action required.

Relative Rate Marking must be globally enabled in the [MODE1](#) register before.

##### 4.2.8.3 Explicit Rate Marking

Initialization of the AVT Context RAM according to [Table 3-56 "AVT Context Table: ABR-ER Parameter Description" on Page 125](#)

##### 4.2.8.4 VS/VD

Initialization of the AVT Context RAM according to [Table 3-54 "AVT Context Table: ABR-VS/VD Parameter Description" on Page 121](#)

#### 4.2.9 Enhanced Rate Control Unit Initialization

After reset, the ERC unit automatically starts loading the firmware necessary for ABR-ER and ABR-VS/VD from the external serial EEPROM via the SPI interface.

In either case, firmware download completion is indicated by status bit 'FWDF' (bit 15) in register "[ERCCONF0](#)" on [Page 338](#) that can be polled by the external microprocessor. At this time, the ERC will start to run the firmware initialization and self-test routines. Completion of firmware initialization will be reported to the external microprocessor by a message via the ERC microprocessor mailbox ([ERCMB0=4000<sub>H</sub>](#), [ERCMB1=6A6A<sub>H</sub>](#), [ERCMB2=6A6A<sub>H</sub>](#)).

**Operational Description**

After generating this message, the firmware is fully operative and in its “idle loop”. The external microprocessor may:

- Configure global parameters for ABR connections
- Set up connections,
- Modify/monitor connection parameters,
- Teardown connections.

**4.2.9.1 Firmware Parameter Configuration**

For ABR ER and ABR VS/VD operation, some global parameters need to be defined in the Cache RAM of the IOP. These parameters can be read and written via the ERC mailbox registers (see “[ERC Mailbox](#)” on [Page 113](#)) using the commands CacheVarWrite and CacheVarRead. Refer to “[ABR Parameters](#)” on [Page 99](#) for detailed information on ABR parameters.

The parameters Trm, TstepUp, and TstepDn can automatically be copied from the ABM-P registers by the firmware using the InitIOP command. This operation should always be performed after setting the corresponding ABM-P registers and the firmware parameters.

**Table 4-10 Firmware Parameters**

<b>Name</b>	<b>Addr</b>	<b>Default</b>	<b>Comment</b>
Version	02 <sub>H</sub>	0012 <sub>H</sub>	Major (bits 7:4) and minor (bits 3:0) firmware version
Trm	03 <sub>H</sub>	000A <sub>H</sub>	Upper time bound for FRM cells, automatically copied from register <a href="#">ERCCONF1</a> by firmware (default 10 for 100 ms)
Mrm	04 <sub>H</sub>	0002 <sub>H</sub>	Mrm (2 cells fixed)
Nrm	05 <sub>H</sub>	0020 <sub>H</sub>	Number of user cells per FRM cell (default 32)
CDF	07 <sub>H</sub>	0004 <sub>H</sub>	Cutoff Decrease Factor, given in $CDF=1/(2 \exp n)$
QLmax	0A <sub>H</sub>	3F00 <sub>H</sub>	Maximum Queue Length (0..16383 cells). ABR VS/VD only: If Qlength exceeds QLmax CI and NI are set in RM cells, if Qlength falls below QLmax CI is reset.
QLdelta	0B <sub>H</sub>	0200 <sub>H</sub>	Queue Length Delta (0..QLmax). ABR VS/VD only: If Qlength falls below QLmax-Qconst NI is reset in RM cells.
SysClkLo	0C <sub>H</sub>	8700 <sub>H</sub>	ABM-P core clock low word (default 60 MHz)
SysClkHi	0D	0393 <sub>H</sub>	ABM-P core clock high word (default 60 MHz)
TstepUp	12 <sub>H</sub>	0004 <sub>H</sub>	Time Base for Rate Shaper upstream, automatically copied from register <a href="#">USCONF/DSCONF</a> by firmware.

**Operational Description**

TstepDn	13 <sub>H</sub>	0004 <sub>H</sub>	Time Base for Rate Shaper downstream, automatically copied from register <a href="#">USCONF/DSCONF</a> by firmware.
DummyQ	14 <sub>H</sub>	0000 <sub>H</sub>	Dummy Queue for Out-of-Rate RM cell insertion (VS/VD) (0 - disabled)

**4.2.9.2 ERC Operation Modes Overview**

**Table 4-11 Operation Modes per Connection**

Enhanced Rate Control (ERC) Enabled						VBR Mode	ERC off
ABR Mode							
ABR Switch Mode (ER)				ABR VS/VD Mode		Bi-directional Mode	Mini-Switch Mode: i) upstream core only ii) both cores
Forward RM cell Update		Backward RM cell Update		Mini-Switch Mode ABR i) upstream core only ii) both cores			
RSC on	RSC off	RSC on	RSC off	RSC on	RSC off		

Note: Uni-directional mode is not supported by first firmware version.

### 4.3 Connection Teardown Example

#### Teardown of Queues

Disabling a queue via the queue-disable bit does not clear the cells in the queue, but:

- The acceptance of the queue for new cells is disabled
- The queue is still served, but the cells are discarded internally

Normally, at the time a queue is cleared, there will be no more cells in the queue. This can be checked by reading the queue length. In case of a highly filled queue which is served slowly, the time to empty the queue could be long. To deplete the queue more quickly, its weight can be increased temporarily. However, because the discarded cells produce idle times on the UTOPIA output, the chosen weight factor should not be too high.

### 4.4 AAL5 Packet Insertion/Extraction

Refer to [Chapter 3.2.4](#) for a more general description.


#### 4.4.1 AAL5 Packet Insertion

First, the header octets are assembled from the VPI, VCI and/or LCI and written to the corresponding registers [UA5TXHD0/DA5TXHD0](#) and [UA5TXHD1/DA5TXHD1](#). The CPCS-UU and CPI are also provided to register [UA5TXTR/DA5TXTR](#). The packet payload length is written to [UA5XCMD/DA5XCMD](#) together with the AAL5EN flag. Four octets of payload are written to the two data registers [UA5XDAT0/DA5XDAT0](#) and [UA5XDAT1/DA5XDAT1](#). The Status register [UA5SARS/DA5SARS](#) should be read afterwards to check the current state of the assembly unit. The assembly of the cells is done without interaction of the microprocessor.

#### 4.4.2 AAL5 Packet Extraction

If an AAL5 interrupt indicates that an AAL5 packets has arrived first the cell header should be read. Before each access to the data registers the status register [UA5SARS/DA5SARS](#) should be read to get the current status of the extraction unit.

As long as the AAL5 status register does not indicate End of Packet (PE), the payload can be received from the data registers [UA5RXDAT0/DA5RXDAT0](#) and [UA5RXDAT1/DA5RXDAT1](#). This data registers should always be read together. If the PE flag is set the next read accesses to the both data registers will return the last payload octets. After this access the Status register still contains the PE flag but additionally a length information of the packet stored in the OV flags. Again the data registers are read to get the trailer of the packet (CPCS-UU and CPI) and the Status Byte. Depending on the packet length there are four possibilities for the mapping of these octets to the two data registers, indicated by the OV flags. The four cases are depicted in [Figure 4-12](#).



**Figure 4-12 AAL5 Extraction: End of packet, Trailer and Status Byte**

The Status Byte returns some information about the received packet:

Bit	7	6	5	4	3	2	1	0
	unused	END	ICHN	CLP	CGST	UUE	CPIE	

**Table 4-13 AAL5 Status Byte**

Flag	Description
END	Error bit. Set if a cell with a different header is received before the end of a packet. Should not occur if VC merge is used, but the user might have a programming error.
ICHN	Invalid channel number. Indicates a change of the cell header before end of packet.
CLP	CLP=1 in at least one cell of the packet
CGST	Congestion occurred, i.e. PT(1)=1 in at least one cell of the packet
UUE	CPCS-UU value is not 0; no other action
CPIE	CPI value is not 0; no other action

Note: If a packet is extracted too slowly, an MUXOV interrupt might occur. To avoid this, either mask the MUXOV interrupt during extraction or reduce the output rate of the scheduler.

#### **4.5 Exception Handling**

The ABM-P provides a set interrupts classified as:

- Fatal
- Notification
- Normal

##### **Fatal interrupts**

It is recommended to reset the device upon occurrence of a 'fatal interrupt' which is generated by the ABM-P detecting internal consistency violations.

##### **Notifications/Normal interrupts**

- Control interrupts for activation/de-activation of VC-merge groups
- Control interrupts for activation/de-activation of 'dummy' queues
- Control interrupts for DBA threshold crossing information

## 5 Interface Description

### 5.1 UTOPIA L2 Interfaces (PHY side)

The UTOPIA Interface to the PHY is ATMF UTOPIA Level 2 and Level 1 compliant. The interface can be configured in Master or Slave Mode. Internal UTOPIA FIFOs guarantee Head-of-Line blocking-free operation in both modes. Each interface direction (receive and transmit) is independently clocked. The PHY side and backplane side UTOPIA Interfaces are identical with minor exceptions as described in the subsequent chapters.

#### 5.1.1 URXU: UTOPIA Receive Upstream (PHY side)

The UTOPIA Receive Interface supports up to 48 PHY addresses that can be individually enabled. In Master Mode and Slave Mode, 48 PHYs are supported in four groups (4\*12 scheme).

Note: In Slave Mode, the interface responds to all enabled port addresses.




Figure 5-1 UTOPIA Receive Upstream Master Mode




Figure 5-2 UTOPIA Receive Upstream Slave Mode

**Head of Line Blocking Avoidance**

The internal Cell Handler Unit accepts any cell from the common UTOPIA receive FIFO to either accept the cell or discard the cell depending on threshold decisions. Thus, no HOL blocking can occur. Optionally, internal thresholds can be enabled to generate backpressure to UTOPIA port groups in a fixed scheme:

- Threshold 0 effects ports {0, 4, 8, 12, 16, 20, 24, 28, 32, 36, 40, 44}
- Threshold 1 effects ports {1, 5, 9, 13, 17, 21, 25, 29, 33, 37, 41, 45}
- Threshold 2 effects ports {2, 6, 10, 14, 18, 22, 26, 30, 34, 38, 42, 46}
- Threshold 3 effects ports {3, 7, 11, 15, 19, 23, 27, 31, 35, 39, 43, 47}

In case of pending backpressure, a specific port reacts in the same way as being disabled:

- Master Mode:  
A backpressured (or disabled) port is deleted from the polling scheme.
- Slave Mode:  
A backpressured (or disabled) port does not generate a cell available signal indication.

Note: The internal backpressure does only effect the polling/response scheme. The UTOPIA receive FIFO is served in any case to avoid HOL blocking.

**5.1.2 UTXD: UTOPIA Transmit Downstream (PHY side)**

The UTOPIA transmit interface supports up to 48 PHY addresses that can be individually enabled.

In Master Mode, 48 PHYs are supported in four groups (4\*12 scheme).


In Slave configuration, two polling modes are supported:

- Up to 48 Ports in 4 groups (4\*12 scheme)
- Up to 31 Ports in 1 group (1\*31 scheme)


Note: In Slave Mode, the interface responds to all enabled port addresses in either scheme.

A cell buffer pool of 64 cells is provided for UTOPIA port specific queues. The number of enabled ports determines the queue length that can be configured. At least one cell buffer per queue is provided.





**Figure 5-3 UTOPIA Transmit Downstream Master Mode**



**Figure 5-4 UTOPIA Transmit Downstream Slave Mode**

**Head of Line Blocking Avoidance**

The internal Cell Handler Unit forwards cells to UTOPIA port-specific queues. In case of a filled queue, queue-specific backpressure is signalled to all schedulers that are associated to that queue/port prohibiting further cell emits. Thus no HOL blocking can occur.

### 5.1.3 UTOPIA Port/Address Mapping (PHY side)

**Table 5-1** describes the mapping of UTOPIA addresses and groups to port numbers.

**Table 5-1 Port/Address Mapping**

Port Number	Group 0	Group 1	Group 2	Group 3	
Address	Slave Mode 1*31	Slave Mode 4*12 and Master Modes			
30	30	-	-	-	-
...	...	...	...	...	...
12	12	-	-	-	-
11	11	11	23	35	47
10	10	10	22	34	46
9	9	9	21	33	45
8	8	8	20	32	44
7	7	7	19	31	43
6	6	6	18	30	42
5	5	5	17	29	41
4	4	4	16	28	40
3	3	3	15	27	39
2	2	2	14	26	38
1	1	1	13	25	37
0	0	0	12	24	36

**5.1.4 Functional UTOPIA Timing (PHY side)**

The functional timing is compatible to ATMF UTOPIA Level 2 standard [4] and ATMF UTOPIA Level 1 standard [3] respectively.

**Remark 1**

The ABM-P UTOPIA Interfaces in Master Mode always introduce at least 1 idle clock between transmission or reception of subsequent ATM cells.

**Remark 2**

The ABM-P UTOPIA Interfaces in **Level 1 Slave Mode** do not support constant active enable signals  $\overline{UTXENBi}/\overline{URXENBi}$  ( $i = \{D(\text{Downstream}); U(\text{Upstream})\}$ ).  
The enable signals must be deasserted with each cell cycle.

### 5.1.5 UTOPIA Master Mode Polling Scheme (PHY side)

The polling scheme is based on a port priority list. A serviced port is automatically moved to the end of the priority list. The priority list port sequence is based on incrementing addresses; for a given address, the port numbers are in increasing order:

**Table 5-2 Port Polling Sequence**

Address	0				1				2				3				4
Sequence	0	12	24	36	1	13	<b>25</b>	37	2	14	26	38	3	15	27	39	4
Priority	decreasing priority ->					min Prio.		max Prio.	decreasing priority ->								

#### Example

Assume Port 25 (printed bold in example pattern) is at the top of the priority list and gets serviced. Now, the list top pointer is moved to the next entry which is Port 37 (i.e. Port 25 becomes the end of the list).

Note: Disabled or internally backpressured ports are deleted from the priority list.  
Polling operation of Receive and Transmit interfaces is independent of each other.

### 5.1.6 UTOPIA Cell Format (PHY side)

The following sections describe the cell format expected by the ABM-P, depending on the selected mapping mode. Transmitted cells have the same format.

The ABM-P may modify user-cell field 'EFCI' and the LCI field (VC-Merge function), depending on the configuration. In OAM cells, bits 'CI' and 'NI' as well as Function Specific fields may be modified. For internal use, also field UDF2 may be modified. The CRC10 field gets recalculated accordingly.

#### 5.1.6.1 UTOPIA Level 2 Standard Cell Formats

**Table 5-3 Standardized UTOPIA Level 2 Cell Format (16-bit)**

bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	VPI(11:0)											VCI(15:12)				
1	VCI(11:0)											PT(2:0)		CLP		
2	UDF1							UDF2								
3	Payload Octet 1							Payload Octet 2								
4	Payload Octet 3							Payload Octet 4								
...	:							:								
26	Payload Octet 47							Payload Octet 48								

Note: All Fields According to Standards, Unused Octets Shaded

**Table 5-4 Standardized UTOPIA Level 2 Cell Format (16-bit): OAM Cells**

bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	VPI(11:0)											VCI(15:12)				
1	VCI(11:0)											PT(2:0)		CLP		
2	UDF1							UDF2								
3	OAM Type(3:0)			Function Type(3:0)				Function Specific Octet 1								
4	Function Specific Octet 2							Function Specific Octet 3								
...	:							:								
25	Function Specific Octet 44							Function Specific Octet 45								
26	Reserved							CRC10								

Note: All fields according to standards, unused octets are shaded.

### 5.1.6.2 LCI Mapping Mode: VPI Mode

In Mapping Mode 'VPI', the ABM-P expects a 12-bit local connection identifier in the location of the VPI field. Mapping Mode 'VPI' is configured via bit field LCIMOD(1:0)='00' in Register "MODE1" on Page 373.

**Table 5-5 Standardized UTOPIA Level 2 Cell Format (16-bit)**

bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	LCI(11:0)											VCI(15:12)				
1	VCI(11:0)											PT(2:0)		CLP		
2	UDF1							UDF2								
3	Payload Octet 1							Payload Octet 2								
4	Payload Octet 3							Payload Octet 4								
...	:							:								
26	Payload Octet 47							Payload Octet 48								

### 5.1.6.3 LCI Mapping Mode: VCI Mode

In Mapping Mode 'VCI', the ABM-P expects a 16-bit local connection identifier in the location of the VCI field. Mapping mode 'VCI' is configured via bit field LCIMOD(1:0)='01' in Register "MODE1" on Page 373.

**Table 5-6 Standardized UTOPIA Level 2 Cell Format (16-bit)**

bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	VPI(11:0)											LCI(15:12)				
1	LCI(11:0)											PT(2:0)		CLP		
2	UDF1							UDF2								
3	Payload Octet 1							Payload Octet 2								
4	Payload Octet 3							Payload Octet 4								
...	:							:								
26	Payload Octet 47							Payload Octet 48								

Since the ABM-P supports 16 K connections, the MSB bits 15 and 14 of the LCI must match the selected quarter segment. Otherwise, the cells are automatically forwarded to the global real time bypass queue (Queue 0) and may be handled by a subsequent ABM-P device.

#### 5.1.6.4 LCI Mapping Mode: Infineon Mode

In Mapping Mode 'Infineon', the ABM-P expects a 16-bit local connection identifier in the location of the VPI field and the UDF1 byte as shown below. Mapping Mode 'Infineon' is configured via bit field LCIMOD(1:0)='10' in Register **"MODE1"** on [Page 373](#).

**Table 5-7 Standardized UTOPIA Level 2 Cell Format (16-bit)**

bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	LCI(11:0)											VCI(15:12)				
1	VCI(11:0)											PT(2:0)		CLP		
2	LCI(13:12)		transparent				LCI(15:14)		UDF2							
3	Payload Octet 1						Payload Octet 2									
4	Payload Octet 3						Payload Octet 4									
...	:						:									
26	Payload Octet 47						Payload Octet 48									

Since the ABM-P supports 16 K connections, the MSB bits 15 and 14 of the LCI must match the selected quarter segment. Otherwise the cells are automatically forwarded to the global real time bypass queue (Queue 0) and may be handled by a subsequent ABM-P device.

#### 5.1.6.5 LCI Mapping Mode: Address Reduction Mode

In Mapping Mode 'Address Reduction', the ABM-P generates a 16-bit local connection identifier based on the marked bit fields. Mapping Mode 'Address Reduction' is configured via bit field LCIMOD(1:0)='11' in Register **"MODE1"** on [Page 373](#).

**Table 5-8 Standardized UTOPIA Level 2 Cell Format (16-bit)**

bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	VPI(11:0)											VCI(15:12)				
1	VCI(11:0)											PT(2:0)		CLP		
2	transp.		optional PNUT(5:0)				UDF2									
3	Payload Octet 1						Payload Octet 2									
4	Payload Octet 3						Payload Octet 4									
...	:						:									
26	Payload Octet 47						Payload Octet 48									



---

**Interface Description**

To generate an Local Connection Identifier (LCI), programmable parts of the fields VCI and VPI optionally supplemented by the UTOPIA port number can be used as basis. The UTOPIA port number is internally provided either by side-band signals (no modifications to ATM cell) or mapped into either the UDF2 field of the cells. In this case, the respective UDF2 field is not transparent.

Address Reduction Mode is described in [Chapter 3.2.5](#).



## 5.2 UTOPIA L2 Interface (Backplane side)

### 5.2.1 URXD: UTOPIA Receive Downstream (Backplane side)

The UTOPIA Receive Downstream Interface is identical to the UTOPIA Receive Upstream Interface as described in [Chapter 5.1.1](#).

#### Standard Exceeding UTOPIA Feature

To support system architectures that require a bandwidth overprovisioning from the backplane, the URXD can be operated up to 60 MHz which corresponds to a data rate of 795 Mbit/s received from the backplane. This provides an overprovisioning factor of 1.32 to OC12 data rate on the line side as described in [Chapter 3.1.1](#).

### 5.2.2 UTXU: UTOPIA Transmit Upstream (Backplane side)

The UTOPIA Transmit Upstream Interface is identical to the UTOPIA Transmit Downstream Interface as described in [Chapter 5.1.2](#).

### 5.2.3 UTOPIA Port/Address Mapping (Backplane side)

The UTOPIA Port/Address mapping (Backplane side) is identical to the UTOPIA Port/Address Mapping as described in [Chapter 5.1.3](#).

### 5.2.4 Functional UTOPIA Timing (Backplane side)

The functional timing is compatible to ATMF UTOPIA Level 2 standard [4] and ATMF UTOPIA Level 1 standard [3] respectively.

#### Remark 1

The ABM-P UTOPIA Interfaces in master mode always introduce at least 1 idle clock between transmission or reception of subsequent ATM cells.

#### Remark 2

The ABM-P UTOPIA Interfaces in **Level 1 Slave Mode** do not support constant active enable signals  $\overline{UTXENBi}/\overline{URXENBi}$  ( $i = \{D(\text{Downstream}); U(\text{Upstream})\}$ ).

The enable signals must be deasserted with each cell cycle.

### 5.2.5 UTOPIA Master Mode Polling Scheme (Backplane side)

The UTOPIA Polling scheme (Backplane side) is identical to the UTOPIA Polling scheme as described in [Chapter 5.1.5](#).


### 5.2.6 UTOPIA Cell Format (Backplane side)

The UTOPIA Polling scheme (Backplane side) is identical to the UTOPIA Polling scheme as described in [Chapter 5.1.6](#).

### 5.3 MPI: Microprocessor Interface


The ABM-P Microprocessor Interface is a generic asynchronous 16-bit slave-only interface that supports Intel and Motorola style control signals. The interface is 'ready' signal controlled.

#### 5.3.1 Intel Style Write Access




**Figure 5-5 Intel Style Write Access**

### 5.3.2 Intel Style Read Access




**Figure 5-6 Intel Style Read Access**

### 5.3.3 Motorola Style Write Access



**Figure 5-7 Motorola Style Write Access**

### 5.3.4 Motorola Style Read Access



**Figure 5-8 Motorola Style Read Access**

### 5.3.5 Interrupt Signals

The ABM-P asserts its interrupt signals  $\overline{\text{MPINT}}$  and  $\overline{\text{MPINTD}}$  if non-masked interrupt events are pending in the respective interrupt status registers. Interrupt signals are deasserted in case all events are cleared by writing '1' to pending interrupt bits (e.g. write  $0\text{xFFFF}_H$  to the respective Interrupt Status Register). This allows edge sensitive interrupt implementations.

Interrupt signals are of type 'Open Drain' to allow wired-or implementations sharing one interrupt signal with other devices.

## 5.4 External RAM Interfaces

### 5.4.1 RAM Configurations

The ABM-P device uses synchronous dynamic RAM (SDRAM) for the storage of ATM cells and synchronous static RAM (SSRAM) for the storage of cell pointers. Two SDRAM Interfaces and one SSRAM Interface are provided. Each of the two SDRAM Interfaces is associated with one of the ABM Cores. The SSRAM Interface is shared by both ABM-P Cores. All RAM Interfaces are operated with the system clock provided by the ABM-P:

**Table 5-9 External RAM Sizes**

<b>Cell Pointer SSRAM</b>	<b>Min. Required Up- stream Cell SDRAM</b>	<b>Min. Required Down- stream Cell SDRAM</b>	<b>UBMTH</b>	<b>Up- stream Buffer</b>	<b>DBMTH</b>	<b>Down- stream Buffer</b>
e.g. 512 k x 32 bit	128 Mb e.g. 2*(4Mb*16)	128 Mb e.g. 2*(4Mb*16)	3FFFF <sub>H</sub>	256K cells	3FFFF <sub>H</sub>	256K cells
e.g. 256 k x 32 bit	64 Mb e.g. 1*(2Mb*32)	64 Mb e.g. 1*(2Mb*32)	1FFFF <sub>H</sub>	128K cells	1FFFF <sub>H</sub>	128Kk cells
e.g. 128 k x 32 bit	32 Mb	32 Mb	0FFFF <sub>H</sub>	64K cells	0FFFF <sub>H</sub>	64K cells
e.g. 256 k x 32 bit	128 Mb e.g. 2*(4Mb*16)	none	3FFFF <sub>H</sub>	256K cells	0000 <sub>H</sub>	0
e.g. 128 k x 32 bit	64 Mb e.g. 1*(2Mb*32)	none	1FFFF <sub>H</sub>	128K cells	0000 <sub>H</sub>	0
e.g. 64 k x 32 bit	32 Mb	none	0FFFF <sub>H</sub>	64K cells	0000 <sub>H</sub>	0

Note: The upstream cell storage RAM must always be connected.

**Interface Description**

The minimum required width of the cell pointer SSRAM is in the range 16..20 bits depending on the selected Cell Storage Size and additional feature configurations:

**Table 5-10 SSRAM Configuration Examples**

Cell Storage RAM cell capacity (each)	Enabled Features	Stored Address Pointer Width	Feature Bits	Min. SSRAM Width
256K	VBR.2/3 + EOP marking	18	2	20
	EOP marking	18	1	19
	none	18	0	18
128K	VBR.2/3 + EOP marking	17	2	19
	EOP marking	17	1	18
	none	17	0	17
64K	VBR.2/3 + EOP marking	16	2	18
	EOP marking	16	1	17
	none	16	0	16

Note: VBR.2/3 represents VBR shaping function 2 and 3 requiring one additional bit storage in the CPR for the CLP bit.

EOP marking represents one additional bit storage in the CPR for End-of-Packet indication required by EPD/PPD and VC-Merge operation.

**Table 5-11** gives an example of supported SDRAM configuration:

**Table 5-11 SDRAM Configuration Examples**

Type	Configuration per Direction
512k * 32 (4 bank) (64Mb Type)	1 SDRAM: 8-bit column address 10-bit row address 2-bit bank select  Note: This Configuration supports only 128k cells storage per direction.
1Mb * 16 (4 bank) (64Mb Types)	2 SDRAM: 8-bit column address 12-bit row address 2-bit bank select  Note: This Configuration supports 256k cells storage per direction.
2Mb * 16 (4 bank) (128Mb Types)	2 SDRAM: 9-bit column address 12-bit row address 2-bit bank select  Note: This Configuration supports 256k cells storage per direction. (50% memory remains unused)
4Mb * 16 (4 bank) (256Mb Types)	2 SDRAM: 9-bit column address 12-bit row address (13) 2-bit bank select  Note: This Configuration supports 256k cells storage per direction. (75% memory remains unused; one of the 13 memory address bits remains unused)

Note: Both CSR Interfaces support 8-bit and 9-bit column address width SDRAM types (see register **"MODE2"** on Page 377).

**Table 5-12** gives an example of supported SSRAM configurations:

Table 5-12 SSRAM and SDRAM Type Examples

Type		Configuration
<b>SSRAM</b>		
1	Micron MT58V512V32F (flow through)	512k * 32
<b>SDRAM</b>		
1	Infineon HYB39S64160BT	4 banks * 1M * 16
2	Infineon HYB39S256160BT	4 banks * 4M * 16



## 5.5 SPI: Serial Peripheral Interface

Support of ABR-ER and ABR-VS/VD requires firmware that is provided by an external EEPROM. Via the SPI interface the ERC subsystem firmware can be loaded into the internal code RAM during start-up of the device. The SPI Interface supports EEPROMs with an 8-bit address space. After a system reset, the ABM-P starts reading out the memory contents. Every time four bytes are read out of the EEPROM (starting with byte address 00<sub>h</sub>), the ABM-P writes the read information into the code RAM.


Table 5-13 gives an example of supported EEPROMs:

**Table 5-13 Serial SPI Bus EEPROM Type Example**

Type	Configuration
1	STMicroelectronics M95256

### 5.5.1 SPI Read Sequence

The ABM-P selects an external EEPROM by pulling  $\overline{\text{SPICS}}$  low. The 8-bit read sequence is transmitted followed by the 8-bit address. After the read instruction and address is sent, the data stored in the memory at the selected address is shifted in on the SPISI pin. The read operation is terminated by setting  $\overline{\text{SPICS}}$  high (see Figure 5-9).



**Figure 5-9 SPI Read Sequence**

## 5.6 QCI: Queue Congestion Indication Interface


The Queue Congestion Indication Interface provides threshold crossing information of up to 8k queues of the downstream core. Dedicated queue specific thresholds are internally supervised using a hysteresis. The threshold exceed information is stored in a bit pattern that is accessible via the QCI Interface in a basic HDLC framing.

The QCI Interface supports two modes:

**Interface Description**

- **Periodic Frame Mode:**  
The pattern is periodically transmitted with an HDLC framing. The transmit clock is provided externally.
- **Single Step Frame Mode:**  
A single pattern is transmitted with an HDLC framing if the 'QCITXFRAME' signal is asserted. The transmit clock is provided externally.

The bit-stuffing function is optional. The HDLC frame is transmitted-octet synchronous starting with the 'QCITXFRAME' signal. The 'QCITXFRAME' signal may not be asserted for more than 3 clock cycles. The minimum distance between two frames has to be payload-length + 16 + 1 or even more if bitstuffing is used.



**Figure 5-10 QCI Interface**

The bit-pattern length can be limited to 1k, 2k, 4k or 8k (maximum number of downstream queues). The first data bit of the pattern always represents the threshold status of queue 0, the second bit represents queue 1 respectively (increasing order).

The CRC16 is not calculated but set fixed to 55AA<sub>H</sub>.

Global configuration of the QCI unit is performed in register **“DQCIC” on Page 229**. The queue specific thresholds are programmed in table QCIT via transfer register **“QCIT” on Page 287**.

## 5.7 Test Interface

The boundary scan functionality is implemented according to IEEE 1149.1, using a 5-pin test access port.

## 5.8 Clock and Reset Interface

### 5.8.1 Clocking

The ABM-P supports different clock domains and clock generation configurations. **“Clocking System” on Page 55** provides the details.

### 5.8.2 Reset

The Reset signal can be asserted anytime asynchronously to the system clock. After detecting an active reset, the ABM-P starts internal initialization processes and resets all registers to their reset value. Chapter **“Reset System” on Page 59** provides the details.

Note: Internal and external RAM initialization must be initiated by software via register **“MODE1” on Page 373**.

## **6 Memory Structure**

The ABM-P is a slave device in relation to the microcontroller bus and provides a set of 256 16-bit wide registers. Internal tables are accessed via dedicated transfer registers (see [Figure 7-1](#)). Typically, the register structure is mapped into the memory address space of the local controller.

## 7 Register Description

This chapter provides both an overview of the ATM Buffer Manager ABM-P Register Set and detailed register descriptions and Table Access descriptions.

### 7.1 Overview of the ABM-P Register Set

Control and operation of the ABM-P chip can be done by directly configuring Status Registers or, to a large extent, by programming the internal tables. Access to these tables is not direct, but occurs via Transfer Registers and Transfer Commands. Any transfer must be prepared by writing appropriate values to the Transfer Registers. Bit positions named 'don't Write' must be masked by writing **1** to the corresponding bit positions in the Mask Register. This avoids overwriting these table bit positions with the Transfer Register contents, which may cause fatal malfunction. The specific table position which should be modified with the Transfer Register contents is selected via Register WAR. Transfer is started by writing the table address to Register MAR and also setting the 'Start' bit. The ABM-P device will reset the 'Start' bit after transfer completion.

The ABM-P contains the following internal tables for configuration:

- LCI Table (LCI)
- Traffic Class Table (TCT)
- Queue Configuration Table (QCT)
- Queue Parameter Table 1 (QPT1)
- Queue Parameter Table 2 (QPT2)
- Scheduler Block Occupancy Table (SBOC)
- Scheduler Block Rate Tables (consisting of 4 tables):
  - SCTI Upstream
  - SCTI Downstream
  - SCTF Upstream
  - SCTF Downstream
- Merge Group Table (MGT)
- ABR/VBR Table (AVT)
- Queue Congestion Indication Table (QCIT)

**Figure 7-1** gives an overview of all (user accessible) tables and related control/transfer/mask registers:

Register Description




Figure 7-1 Table Access Overview

The Status Registers and Transfer Registers are described below in [Table 7-2](#). Offset addresses are 16-bit word addresses. In order to prevent malfunctions and to guarantee upwards compatibility to future versions of the device, performing Write accesses to 'Reserved Register' addresses is not recommended.

**Register Description**

Internal table entries contain bit fields for internal device operation only. [Table 7-1](#) identifies the color conventions used for the various types of fields described in this register chapter:

**Table 7-1 Color Convention for Internal Table Field Illustration**

Color	Meaning
	Grey shaded fields are 'unused'. Reading these fields will return '0'.
	Green shaded fields require attention by CPU. They can be written or read by CPU; usage depends on the respective field description. Typically green fields must be written for initialization and configuration or read for status query.
	Blue shaded fields require/allow <b>READ</b> attention by CPU. Typically blue fields provide counter or status information. The CPU <b>MUST NOT</b> write to blue fields.
	Red shaded fields are for device internal use only and require <b>NO</b> attention by CPU. The CPU <b>MUST NOT</b> write to red fields.

**Table 7-2 ABM-P Registers Overview**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
<b>Cell Flow Test Registers</b>					
01/11	UCFTST/ DCFTST	Upstream/Downstream Cell Flow Test Registers	0000	R/W	194
<b>SDRAM Configuration Registers</b>					
02/12	URCFG/ DRCFG	Upstream/Downstream SDRAM Configuration Registers	0033	R/W	195
03/13	-	Reserved Register	0000	R	-
04/14	-	Reserved Register	0000	R	-
<b>Cell Insertion/Extraction and AAL5 Control Registers</b>					
05/15	UA5TXHD0/ DA5TXHD0	Upstream/Downstream AAL5 Transmit Header 0 Registers	0000	R/W	196
06/16	UA5TXHD1/ DA5TXHD1	Upstream/Downstream AAL5 Transmit Header 1 Registers	0000	R/W	198
07/17	UA5TXDAT0/ DA5TXDAT0	Upstream/Downstream AAL5 Transmit Data 0 Registers	0000	R/W	200

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
08/18	UA5TXDAT1/ DA5TXDAT1	Upstream/Downstream AAL5 Transmit Data 1 Registers	0000	R/W	201
09/19	UA5TXTR/ DA5TXTR	Upstream/Downstream AAL5 Transmit Trailer Registers	0000	R/W	202
0A/1A	UA5TXCMD/ DA5TXCMD	Upstream/Downstream AAL5 Transmit Command Registers	0000	R/W	203
0B/1B	UA5RXHD0/ DA5RXHD0	Upstream/Downstream AAL5 Receive Header 0 Registers	0000	R/W	204
0C/1C	UA5RXHD1/ DA5RXHD1	Upstream/Downstream AAL5 Receive Header 1 Registers	0000	R/W	206
0D/1D	UA5RXDAT0/ DA5RXDAT0	Upstream/Downstream AAL5 Receive Data 0 Registers	0000	R/W	208
0E/1E	UA5RXDAT1/ DA5RXDAT1	Upstream/Downstream AAL5 Receive Data 1 Registers	0000	R/W	209
0F/1F	UA5SARS/ DA5SARS	Upstream/Downstream AAL5 SAR Status Registers	0000	R/W	210
<b>Buffer Occupation Counter Registers</b>					
20	UBufferOcc	Upstream/Downstream Buffer Occupation Registers	0000	R	212
21	DBufferOcc		0000	R	212
22	UBufferOccNg	Up-/Downstream Non-Guaranteed Buffer Occupation Registers	0000	R	213
23	DBufferOccNg		0000	R	213
<b>Buffer Threshold and Occupation Capture Registers</b>					
24	UBufMax	Upstream/Downstream Buffer Maximum Threshold Registers	0000	R/W	214
25	DBufMax		0000	R/W	214
26	UMAC	Upstream/Downstream Maximum Occupation Capture Registers	0000	R	216
27	DMAC		0000	R	216
28	UMIC	Upstream/Downstream Minimum Occupation Capture Registers	FFFF	R	217
29	DMIC		FFFF	R	217
2A	CLP1DIS	CLP1 Discard Global Threshold Registers	0000	R/W	218



**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
<b>Configuration Register</b>					
2B	CONFIG	Configuration Register	0000	R/W	219
<b>Backpressure Control Registers</b>					
2C	UUBPTH0	Upstream UTOPIA Backpressure Threshold Register 0	FFFF	R/W	220
2D	UUBPTH1	Upstream UTOPIA Backpressure Threshold Register 1	FFFF	R/W	221
2E	UUBPTH2	Upstream UTOPIA Backpressure Threshold Register 2	FFFF	R/W	222
2F	UUBPTH3	Upstream UTOPIA Backpressure Threshold Register 3	FFFF	R/W	223
30	UBPEI	UTOPIA Backpressure Exceed Indication Register	0000	R/W	224
31	DUBPTH0	Downstream UTOPIA Backpressure Threshold Register 0	FFFF	R/W	225
32	DUBPTH1	Downstream UTOPIA Backpressure Threshold Register 1	FFFF	R/W	226
33	DUBPTH2	Downstream UTOPIA Backpressure Threshold Register 2	FFFF	R/W	227
34	DUBPTH3	Downstream UTOPIA Backpressure Threshold Register 3	FFFF	R/W	228
<b>QCI Control Registers</b>					
35	DQCIC	Downstream Queue Congestion Indication Control Register	0080	R/W	229
<b>DBA Control Registers</b>					
36	DSBT1	Upstream/Downstream DBA Scheduler Block Threshold Register 1	0000	R/W	231
37	DSBT2	Upstream/Downstream DBA Scheduler Block Threshold Register 2	0000	R/W	232
38	DSBT3	Upstream/Downstream DBA Scheduler Block Threshold Register 3	0000	R/W	233

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
39	DSBT4	Upstream/Downstream DBA Scheduler Block Threshold Register 4	0000	R/W	234
3A	DBACTC	DTC Transfer Register	0000	R	236
<b>LCI Table Transfer Registers</b>					
3B	LCI0	LCI Transfer Register 0	0000	R/W	238
3C	LCI1	LCI Transfer Register 1	0000	R/W	239
3D	LCI2	LCI Transfer Register 2	0000	R/W	240
<b>Traffic Class Table Transfer Registers</b>					
3E	TCT0	TCT Transfer Register 0	0000	R/W	244
3F	TCT1	TCT Transfer Register 1	0000	R/W	247
40	TCT2	TCT Transfer Register 2	0000	R/W	250
41	TCT3	TCT Transfer Register 3	0000	R/W	253
<b>Queue Configuration Table Transfer Registers</b>					
42	QCT0	Queue Configuration Transfer Register 0	0000	R/W	260
43	QCT1	Queue Configuration Transfer Register 1	0000	R/W	261
44	QCT2	Queue Configuration Transfer Register 2	0000	R/W	264
45	QCT3	Queue Configuration Transfer Register 3	0000	R/W	266
46	QCT4	Queue Configuration Transfer Register 4	0000	R/W	267
47	QCT5	Queue Configuration Transfer Register 5	0000	R/W	268
48	QCT6	Queue Configuration Transfer Register 6	0000	R/W	269
<b>Scheduler Block Occupancy Table Transfer Registers</b>					
49	SBOC0	SBOC Transfer Register 0	0000	R/W	272
4A	SBOC1	SBOC Transfer Register 1	0000	R/W	273
4B	SBOC2	SBOC Transfer Register 2	0000	R/W	274
4C	SBOC3	SBOC Transfer Register 3	0000	R/W	275
4D	SBOC4	SBOC Transfer Register 4	0000	R/W	276
<b>Merge Group Table Transfer Registers</b>					
4E	MGT0	MGT Transfer Register 0	0000	R/W	279
4F	MGT1	MGT Transfer Register 1	0000	R/W	280

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
50	MGT2	<a href="#">MGT Transfer Register 2</a>	0000	R/W	<a href="#">281</a>
51	-	Reserved Register	0000	R/W	-
52	-	Reserved Register	0000	R/W	-
53	-	Reserved Register	0000	R/W	-
54	-	Reserved Register	0000	R/W	-
<b>Mask Registers</b>					
for Read/Write transfer access control of LCI-, Traffic Class-, Queue Configuration-, Scheduler Block Occupancy and Merge Group Tables					
55/56	MASK0/ MASK1	<a href="#">Table Access Mask Registers 0/1</a>	0000	R/W	<a href="#">282</a>
57/58	MASK2/ MASK3	<a href="#">Table Access Mask Registers 2/3</a>	0000	R/W	<a href="#">283</a>
59/5A	MASK4/ MASK5	<a href="#">Table Access Mask Registers 4/5</a>	0000	R/W	<a href="#">284</a>
5B	MASK6	<a href="#">Table Access Mask Registers 6</a>	0000	R/W	<a href="#">285</a>
<b>Queue Congestion Indication Table</b>					
5C	QCIT	<a href="#">QCIT Transfer Register</a>	0000	R/W	<a href="#">287</a>
5D	-	Reserved Register	0000	R/W	-
5E	-	Reserved Register	0000	R/W	-
5F	-	Reserved Register	0000	R/W	-
<b>Rate Shaper CDV Registers</b>					
60/80	-	Reserved Register	0000	R	-
61/81	-	Reserved Register	0000	R	-
62/82	UCDV/ DCDV	<a href="#">Upstream/Downstream Rate Shaper CDV Registers</a>	0000	R/W	<a href="#">288</a>
63/83	-	Reserved Register	0000	R	-
64/84	-	Reserved Register	0000	R	-

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
<b>Queue Parameter Table Mask Registers</b>					
65/85	UQPTM0/ DQPTM0	Upstream/Downstream Queue Parameter Table Mask Registers 0	0000	R/W	289
66/86	UQPTM1/ DQPTM1	Upstream/Downstream Queue Parameter Table Mask Registers 1	0000	R/W	290
67/87	UQPTM2/ DQPTM2	Upstream/Downstream Queue Parameter Table Mask Registers 2	0000	R/W	291
68/88	UQPTM3/ DQPTM3	Upstream/Downstream Queue Parameter Table Mask Registers 3	0000	R/W	292
69/89	UQPTM4/ DQPTM4	Upstream/Downstream Queue Parameter Table Mask Registers 4	0000	R/W	293
6A/8A	UQPTM5/ DQPTM5	Upstream/Downstream Queue Parameter Table Mask Registers 5	0000	R/W	294
<b>Scheduler Configuration Register</b>					
6B/8B	USCONF/ DSCONF	Upstream/Downstream Scheduler Configuration Registers	0000	R/W	295
6C/8C	-	Reserved Register	0000	R	-
6D/8D	-	Reserved Register	0000	R	-
6E/8E	-	Reserved Register	0000	R	-
6F/8F	-	Reserved Register	0000	R	-
<b>Queue Parameter Table Transfer Registers</b>					
70/90	UQPT1T0/ DQPT1T0	Upstream/Downstream QPT1 Table Transfer Register 0	0000	R/W	298
71/91	UQPT1T1/ DQPT1T1	Upstream/Downstream QPT1 Table Transfer Register 1	0000	R/W	299
72/92	UQPT2T0/ DQPT2T0	Upstream/Downstream QPT2 Table Transfer Register 0	0000	R/W	302
73/93	UQPT2T1/ DQPT2T1	Upstream/Downstream QPT2 Table Transfer Register 1	0000	R/W	303
74/94	UQPT2T2/ DQPT2T2	Upstream/Downstream QPT2 Table Transfer Register 2	0000	R/W	304

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
75/95	UQPT2T3/ DQPT2T3	<a href="#">Upstream/Downstream QPT2 Table Transfer Register 3</a>	0000	R/W	<a href="#">305</a>
76/96	-	Reserved Register	0000	R/W	-
77/97	-	Reserved Register	0000	R/W	-
78/98	-	Reserved Register	0000	R/W	-
79/99	-	Reserved Register	0000	R/W	-
7A/9A	-	Reserved Register	0000	R/W	-
7B/9B	-	Reserved Register	0000	R/W	-
7C/9C	-	Reserved Register	0000	R/W	-
7D/9D	-	Reserved Register	0000	R/W	-
7E/9E	-	Reserved Register	0000	R/W	-
7F/9F	-	Reserved Register	0000	R/W	-
<b>Scheduler Block Configuration Table Transfer/Mask Registers SDRAM Refresh Registers UTOPIA Port Select of Common Real Time Queue Registers</b>					
A0/B8	USADR/ DSADR	<a href="#">Upstream/Downstream SCTI Address Registers</a>	0000	R/W	<a href="#">308</a>
A1/B9	USCTI/ DSCTI	<a href="#">Upstream/Downstream SCTI Transfer Registers</a>	0000	R/W	<a href="#">309</a>
A2/BA	UECRI/ DECRI	<a href="#">Upstream/Downstream Empty Cycle Rate Integer Part Registers</a>	0000	R/W	<a href="#">312</a>
A3/BB	UECRF/ DECRF	<a href="#">Upstream/Downstream Empty Cycle Rate Fractional Part Registers</a>	0000	R/W	<a href="#">313</a>
A4/BC	UCRTQ/ DCRTQ	<a href="#">Upstream/Downstream Common Real Time Queue UTOPIA Port Select Registers</a>	0000	R/W	<a href="#">314</a>
A5/BD	USCTFM/ DSCTFM	<a href="#">Upstream/Downstream SCTF Mask Registers</a>	0000	R/W	<a href="#">315</a>
A6/BE	USCTFT/ DSCTFT	<a href="#">Upstream/Downstream SCTF Transfer Registers</a>	0000	R/W	<a href="#">318</a>
A7/BF	-	Reserved Register	0000	R	-

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
<b>Scheduler Block Enable Registers</b>					
A8/C0	USCEN0/ DSCEN0	Upstream/Downstream Scheduler Block Enable 0 Registers	0000	R/W	319
A9/C1	USCEN1/ DSCEN1	Upstream/Downstream Scheduler Block Enable 1 Registers	0000	R/W	320
AA/C2	USCEN2/ DSCEN2	Upstream/Downstream Scheduler Block Enable 2 Registers	0000	R/W	321
AB/C3	USCEN3/ DSCEN3	Upstream/Downstream Scheduler Block Enable 3 Registers	0000	R/W	322
AC/C4	USCEN4/ DSCEN4	Upstream/Downstream Scheduler Block Enable 4 Registers	0000	R/W	323
AD/C5	USCEN5/ DSCEN5	Upstream/Downstream Scheduler Block Enable 5 Registers	0000	R/W	324
AE/C6	USCEN6/ DSCEN6	Upstream/Downstream Scheduler Block Enable 6 Registers	0000	R/W	325
AF/C7	USCEN7/ DSCEN7	Upstream/Downstream Scheduler Block Enable 7 Registers	0000	R/W	326
<b>Common Real Time Queue Rate Registers</b>					
B0/C8	UCRTRI/ DCRTRI	Upstream/Downstream CRT Rate Integer Registers	0000	R/W	327
B1/C9	UCRTRF/ DCRTRF	Upstream/Downstream CRT Rate Fractional Registers	0000	R/W	328
B2	-	Reserved Register	0000	R	-
B3	-	Reserved Register	0000	R	-
B4	-	Reserved Register	0000	R	-
B5	-	Reserved Register	0000	R	-
B6	-	Reserved Register	0000	R	-
B7	-	Reserved Register	0000	R	-
<b>AVT Table Registers</b>					
CA	ERCT0	AVT Table Transfer Register 0	0000	R/W	331
CB	ERCT1	AVT Table Transfer Register 1	0000	R/W	332

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
CC	ERCM0	<a href="#">AVT Table Access Mask Register 0</a>	0000	R/W	<a href="#">333</a>
CD	ERCM1	<a href="#">AVT Table Access Mask Register 1</a>	0000	R/W	<a href="#">334</a>
CE	-	Reserved Register	0000	R	-
CF	-	Reserved Register	0000	R	-
D0	-	Reserved Register	0000	R	-
D1	-	Reserved Register	0000	R	-
D2	ERCMB0	<a href="#">ERC MailBox Register 0</a>	0000	R/W	<a href="#">335</a>
D3	ERCMB1	<a href="#">ERC MailBox Register 1</a>	0000	R/W	<a href="#">336</a>
D4	ERCMB2	<a href="#">ERC MailBox Register 2</a>	0000	R/W	<a href="#">337</a>
D5	ERCCONF0	<a href="#">ERC Configuration Register 0</a>	0000	R/W	<a href="#">338</a>
D6	ERCCONF1	<a href="#">ERC Configuration Register 1</a>	0000	R/W	<a href="#">340</a>
<b>PLL Control Registers</b>					
D7	PLL1CONF	<a href="#">PLL1 Configuration Register</a>	0000	R/W	<a href="#">341</a>
D8	PLL2CONF	<a href="#">PLL2 Configuration Register</a>	0000	R/W	<a href="#">343</a>
D9	PLLST	<a href="#">PLL Test Register</a>	0000	R/W	<a href="#">345</a>
<b>ERC Register Access Control</b>					
DA	ERCAC	<a href="#">ERC Register Access Control Register</a>	0000	R/W	<a href="#">346</a>
DB	ERCAM	<a href="#">ERC Register Access Mask Register</a>	0000	R/W	<a href="#">348</a>
<b>External RAM Test Registers</b>					
DC	EXTRAMD0	<a href="#">External RAM Test Data Register 0</a>	0000	R/W	<a href="#">349</a>
DD	EXTRAMD1	<a href="#">External RAM Test Data Register 1</a>	0000	R/W	<a href="#">350</a>
DE	EXTRAMA0	<a href="#">External RAM Test Address Register Low</a>	0000	R/W	<a href="#">351</a>
DF	EXTRAMA1	<a href="#">External RAM Test Address Register High</a>	0000	R/W	<a href="#">352</a>
E0	EXTRAMC	<a href="#">External RAM Test Command Register</a>	0000	R/W	<a href="#">353</a>
<b>ABM-P Version Code Registers</b>					
E1	VERL	<a href="#">Version Number Low Register</a>	F083	R	<a href="#">354</a>
E2	VERH	<a href="#">Version Number High Register</a>	1007	R	<a href="#">355</a>

**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
<b>Interrupt Status/Mask Registers</b>					
E3	ISRU	Interrupt Status Register Upstream	0000	R/W	356
E4	ISRD	Interrupt Status Register Downstream	0000	R/W	359
E5	ISRC	Interrupt Status Register Common	0000	R/W	362
E6	IMRU	Interrupt Mask Register Upstream	0000	R/W	363
E7	IMRD	Interrupt Mask Register Downstream	0000	R/W	364
E8	IMRC	Interrupt Mask Register Common	0000	R/W	365
E9	ISRDBA	Interrupt Status Register DBA	0000	R/W	366
EA	IMRDBA	Interrupt Mask Register DBA	0000	R/W	367
<b>RAM Select Registers</b>					
EB	MAR	Memory Address Register	0000	R/W	368
EC	WAR	Word Address Register	0000	R/W	370
<b>Global ABM-P Status and Mode Registers</b>					
ED	USTATUS	ABM-P UTOPIA Status Register	0000	R/W	372
EE	MODE1	ABM-P Mode 1 Register	0000	R/W	373
EF	MODE2	ABM-P Mode 2 Register	0000	R/W	377
<b>UTOPIA Configuration Registers</b>					
F0	UTRXCFCG	Upstream/Downstream UTOPIA Receive Configuration Register	0001	R/W	379
F1	UUTRXP0	Upstream UTOPIA Receive Port Register 0	0000	R/W	381
F2	UUTRXP1	Upstream UTOPIA Receive Port Register 1	0000	R/W	382
F3	UUTRXP2	Upstream UTOPIA Receive Port Register 2	0000	R/W	383
F4	DUTRXP0	Downstream UTOPIA Receive Port Register 0	0000	R/W	384
F5	DUTRXP1	Downstream UTOPIA Receive Port Register 1	0000	R/W	385



**Register Description**
**Table 7-2 ABM-P Registers Overview (cont'd)**

Addr (hex)	Register	Description	Reset value (hex)	μP	See page
F6	DUTRXP2	Downstream UTOPIA Receive Port Register 2	0000	R/W	386
F7	UUTTXCFG	Upstream UTOPIA Transmit Configuration Register	0000	R/W	387
F8	DUTTXCFG	Downstream UTOPIA Transmit Configuration Register	0001	R/W	389
F9	UUTTXP0	Upstream UTOPIA Transmit Port Register 0	0000	R/W	391
FA	UUTTXP1	Upstream UTOPIA Transmit Port Register 1	0000	R/W	392
FB	UUTTXP2	Upstream UTOPIA Transmit Port Register 2	0000	R/W	393
FC	DUTTXP0	Downstream UTOPIA Transmit Port Register 0	0000	R/W	394
FD	DUTTXD1	Downstream UTOPIA Transmit Port Register 1	0000	R/W	395
FE	DUTTXD2	Downstream UTOPIA Transmit Port Register 2	0000	R/W	396
<b>Test Registers/Special Mode Registers</b>					
FF	TEST	TEST Register	0000	R/W	397

## 7.2 Detailed Register Descriptions

### 7.2.1 Cell Flow Test Registers

#### Register 1 UCFTST/DCFTST Upstream/Downstream Cell Flow Test Registers

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UCFTST 01<sub>H</sub> DCFTST 11<sub>H</sub>**

Typical Usage: Written by CPU to test internal integrity functions during special system test scenarios

Bit	15	14	13	12	11	10	9	8
	Unused(15:8)							
Bit	7	6	5	4	3	2	1	0
	Unused(7:2)						TSTBIP	TSTQID

#### TSTBIP Test BIP-8 Supervision

- |   |  |
|---|--|
| 0 | <b>Normal Operation:</b><br>BIP-8 for cell protection is generated normally. No 'BIP8ER' interrupt should occur indicating a cell storage failure.   |
| 1 | <b>Test Mode:</b><br>Least Significant Bit (LSB) of BIP-8 is inverted to test BIP-8 checking function. A 'BIP8ER' ( <b>Register 115: ISRU</b> , <b>Register 116: ISRD</b> ) interrupt is generated whenever a cell is Read out of the Cell Buffer RAM. |

#### TSTQID Test Queue ID Supervision (see "[Cell Queue Supervision](#)" on Page 95)

- |   |   |
|---|---|
| 0 | <b>Normal Operation:</b><br>A correct QID is generated. No 'BUFFER4' interrupt should occur indicating an internal queue pointer failure. |
|---|---|

**Register Description**

**1 Test Mode:**  
The LSB of the QID is inverted to test the QID checking function. A 'BUFFER4' (**Register 115: ISRU**, **Register 116: ISRD**) interrupt is generated whenever a cell is Read out from the Cell Buffer RAM.

*Note: The respective QID value is stored with each cell when written to the appropriate queue in the cell storage RAM. The ABM-P checks the stored QID value against the supposed QID when a cell is read back from the cell storage RAM.*

**7.2.2 SDRAM Configuration Registers**

**Register 2 URCFG/DRCFG  
Upstream/Downstream SDRAM Configuration Registers**

CPU Accessibility: **Read/Write**  
Reset Value: **0033<sub>H</sub>**  
Offset Address: **URCFG 02<sub>H</sub> DRCFG 12<sub>H</sub>**  
Typical Usage: (Reserved)

Bit	15	14	13	12	11	10	9	8
	Reserved(15:8)							
Bit	7	6	5	4	3	2	1	0
	Reserved(7:0)							

*Note: These registers are for internal use only. Do not to Write a value different from the Reset Value 0033<sub>H</sub> to Registers URCFG/DRCFG.*



Register Description

*Note: If LCI mapping mode '10' is chosen LCI(13:12) cannot be specified, i.e. AAL5 cell insertion is limited to the LCI range 0..4095.*


**VCI(15:12)**  
or  
**LCI(15:12)**  
or  
**VCI(15:12)**

The meaning of this bit field depends on the selected LCI mapping mode in **Register 126: MODE1**:  
MODE1->LCIMOD(1:0):

'00'	VCI transparent mode: VCI(15:12)
'01'	VCI Address translated mode: LCI(15:12)
'10'	VCI transparent mode: VCI(15:12)
'11'	VCI transparent mode: VCI(15:12)

**Register 4 UA5TXHD1/DA5TXHD1**  
**Upstream/Downstream AAL5Transmit Header 1 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5TXHD1 06<sub>H</sub>**      **DA5TXHD1 16<sub>H</sub>**  
 Typical Usage:      Written by CPU



Second 16-bit word of an ATM cell.  
 The ABM-P does not interpret these bit fields, but copies them into ATM cells that are inserted during AAL5 packet segmentation process. Inserted cells are forwarded to the ABM-P like any cell received by the respective UTOPIA Interface. Thus the bit field usage must comply to the selected LCI mapping mode in the particular application.

**VCI(11:0)**      The meaning of this bit field depends on the selected LCI mapping mode  
**or**  
**LCI(11:0)**      **MODE1->LCIMOD(1:0):**  
                   '00'      VCI transparent mode: VCI(11:0)  
                   '01'      VCI Address translated mode: LCI(11:0)  
                   '10'      VCI transparent mode: VCI(11:0)  
                   '11'      VCI transparent mode: VCI(11:0)

**PT(2:0)**      **Payload Type Field in ATM cell Header**

---

**Register Description**

PT(0) is automatically handled by the ABM-P (End of Packet indication set to '1' in last cell of any AAL5 segmented packet).

PT(1) ('Congestion Experienced') may be overwritten by CPU anytime during segmentation process and will be inserted in the following AAL5 cell generated.


This field must be initialized to all 0s.

**CLP      Cell Loss Priority Bit in ATM cell Header**

The CLP bit is copied transparently and may be overwritten (changed) by CPU anytime during segmentation process (new value will be inserted in the following AAL5 cell generated).

**Register 5 UA5TXDAT0/DA5TXDAT0**  
**Upstream/Downstream AAL5Transmit Data 0 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5TXDAT 07<sub>H</sub>      DA5TXDAT0 17<sub>H</sub>**  
**0**  
 Typical Usage: **Written by CPU**



Cell Transmit Data Transfer Register


**Octet(4n)(7:0)      Payload data Octet (4n)**  
**Octet(4n+1)(7:0)      Payload data Octet (4n+1)**

The payload data octets of a cell to be inserted in either upstream or downstream direction are written by consecutive write accesses to registers **UTXDAT0/DTXDAT0** and **UTXDAT1/DTXDAT1** in alternating manner until end of packet:  
 cycle n=0: Octet 0 and 1: write to **UTXDAT0/DTXDAT0**  
 cycle n=0: Octet 2 and 3: write to **UTXDAT1/DTXDAT1**  
 cycle n=1: Octet 4 and 5: write to **UTXDAT0/DTXDAT0**  
 cycle n=1: Octet 6 and 7: write to **UTXDAT1/DTXDAT1**  
 ...



**Register 6 UA5TXDAT1/DA5TXDAT1**  
**Upstream/Downstream AAL5 Transmit Data 1 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5TXDAT1 08<sub>H</sub>**      **DA5TXDAT1 18<sub>H</sub>**  
 Typical Usage: **Written by CPU**



Cell Transmit Data Transfer Register

**Octet(4n+2)(7:0) Payload data Octet (4n+2)**

**Octet(4n+3)(7:0) Payload data Octet (4n+3)**

The payload data octets of a cell to be inserted in either upstream or downstream direction are written by consecutive write accesses to registers **UTXDAT0/DTXDAT0** and **UTXDAT1/DTXDAT1** in alternating manner until end of packet:

cycle n=0: Octet 0 and 1: write to **UTXDAT0/DTXDAT0**

cycle n=0: Octet 2 and 3: write to **UTXDAT1/DTXDAT1**

cycle n=1: Octet 4 and 5: write to **UTXDAT0/DTXDAT0**

cycle n=1: Octet 6 and 7: write to **UTXDAT1/DTXDAT1**

...


**Register 7 UA5TXTR/DA5TXTR**  
**Upstream/Downstream AAL5 Transmit Trailer Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UA5TXTR 09<sub>H</sub>**                      **DA5TXTR 19<sub>H</sub>**

Typical Usage:        Written by CPU




**CPCS-UU(7:0)        Common Part Convergence Sublayer User to User Indication**  
The CPCS-UU bit field is copied transparently into the CPCS-PDU trailer in the last cell of an AAL5 segmented packet.

**CPI(7:0)             Common Part Indication**  
The CPI bit field is copied transparently into the CPCS-PDU trailer in the last cell of an AAL5 segmented packet.

**Register 8 UA5TXCMD/DA5TXCMD**  
**Upstream/Downstream AAL5 Transmit Command Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5TXCMD 0A<sub>H</sub> DA5TXCMD 1A<sub>H</sub>**  
 Typical Usage: Written by CPU (write only, read always returns 0000)



**AAL5EN AAL5 Segmentation Enable**

This bit enables AAL5 segmentation process accompanied by the payload length octet counter PLENGTH:

- '0' AAL5 segmentation is disabled. Payload data octets written to the cell transmit data registers are ignored.  
*Note: Setting AAL5EN='0' during an active packet segmentation process leads to an abort of the packet, i.e. the current cell is inserted with PT(0)='1' (End of Packet indication) and CPCS-SDU Length field of the trailer set to 0. To abort it is recommended to write all 0 to the register: AAL5EN | PLENGTH(14:0) = 0000<sub>H</sub>*
- '1' AAL5 segmentation is enabled. Payload data octets written to the cell transmit data registers are processed and the CPCS-PDU trailer is automatically appended in the last cell controlled by the payload length octet counter.

**PLENGTH(14:0) Payload Length Octet Counter**

This bit field represents the number of PDU payload octets for the current packet and is equal to the CPCS-SDU length field which is automatically inserted in the PDU trailer (last cell of the packet). The ABM-P uses this counter value to control the AAL5 segmentation process.

*Note: The maximum supported CPCS-SDU length is 32767 octets.*

**Register 9 UA5RXHD0/DA5RXHD0  
Upstream/Downstream AAL5 Receive Header 0 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5RXHD0 0B<sub>H</sub>**                      **DA5RXHD0 1B<sub>H</sub>**  
 Typical Usage: Read by CPU

Bit	15	14	13	12	11	10	9	8
	LCI(11:4), VPI(11:4) or GFC(3:0)   VPI(7:4), LCI(11:4), VPI(11:4) or GFC(3:0)   VPI(7:4),							
Bit	7	6	5	4	3	2	1	0
	LCI(3:0), VPI(3:0), LCI(3:0), VPI(3:0)				VCI(15:12), LCI(15:12), VCI(15:12), VCI(15:12)			


Header octets one and two of first ATM cell of packet.  
 The ABM-P SAR unit does not interpret these bit fields, but copies them from ATM cells that are extracted during AAL5 packet reassembly process. Extracted cells are forwarded from the ABM-P like any cell to be transmitted by the respective UTOPIA Interface. Thus, the bit field usage depends on the selected LCI mapping mode in the particular application. From scheduler point of view the reassembly unit is addressed as UTOPIA port number 30<sub>H</sub>.

**Register Description**

<p><b>VPI(11:0)</b> or <b>GFC(3:0)  </b> <b>VPI(7:0)</b> or <b>LCI(11:0)</b></p>	<p>The meaning of this bit field depends on the selected LCI mapping mode in <b>Register 126: MODE1</b>: MODE1-&gt;LCIMOD(1:0):</p> <p>'00' VPI Address translated mode: LCI(11:0) '01' VPI transparent mode:  <ul style="list-style-type: none"> <li>• NNI cell format: 12 bit VPI field</li> <li>• UNI cell format: 4 bit GFC field and 8 bit VPI field</li> </ul> </p> <p>'10' VPI Address translated mode: LCI(11:0) '11' VPI transparent mode:  <ul style="list-style-type: none"> <li>• NNI cell format: 12 bit VPI field</li> <li>• UNI cell format: 4 bit GFC field and 8 bit VPI field</li> </ul> </p> <p><i>Note: If LCI mapping mode '10' is chosen LCI(13:12) are not given to the user.</i></p>
<p><b>VCI(15:12)</b> or <b>LCI(15:12)</b> or <b>VCI(15:12)</b></p>	<p>The meaning of this bit field depends on the selected LCI mapping mode in <b>Register 126: MODE1</b>: MODE1-&gt;LCIMOD(1:0):</p> <p>'00' VCI transparent mode: VCI(15:12) '01' VCI Address translated mode: LCI(15:12) '10' VCI transparent mode: VCI(15:12) '11' VCI transparent mode: VCI(15:12)</p>

**Register 10 UA5RXHD1/DA5RXHD1**  
**Upstream/Downstream AAL5 Receive Header 1 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5RXHD1 0C<sub>H</sub>**      **DA5RXHD1 1C<sub>H</sub>**  
 Typical Usage: Read by CPU



Header octets three and four of first ATM cell of AAL5 packet.  
 The ABM-P SAR unit does not interpret these bit fields, but copies them from ATM cells that are extracted during AAL5 packet reassembly process. Extracted cells are forwarded from the ABM-P like any cell to be transmitted by the respective UTOPIA Interface. Thus, the bit field usage depends on the selected LCI mapping mode in the particular application. From scheduler point of view the reassembly unit is addressed as UTOPIA port number 30<sub>H</sub>.

**VCI(11:0)**      The meaning of this bit field depends on the selected LCI mapping mode in **Register 126: MODE1**:  
**or**                      **LCI(11:0)**      MODE1->LCIMOD(1:0):

'00'	VCI transparent mode: VCI(11:0)
'01'	VCI Address translated mode: LCI(11:0)
'10'	VCI transparent mode: VCI(11:0)
'11'	VCI transparent mode: VCI(11:0)


---

**Register Description**

<b>PT(2:0)</b>	<b>Payload Type Field in ATM cell Header</b> PT(0) is automatically handled by the ABM-P (End of Packet detection). <i>Note: OAM or RM cells detected with PT(2)='1' are discarded by the reassembly unit and ignored for the packet reassembly process. Thus packet reassembly is not disturbed by inserted OAM cells.</i>
<b>CLP</b>	<b>Cell Loss Priority Bit in ATM cell Header</b> The CLP bit is copied transparently from the ATM cell.

**Register 11 UA5RXDAT0/DA5RXDAT0**  
**Upstream/Downstream AAL5 Receive Data 0 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5RXDAT0 0D<sub>H</sub>**      **DA5RXDAT0 1D<sub>H</sub>**  
 Typical Usage: Read by CPU



Cell Receive Data Transfer Register

**Octet(4n)(7:0)**      **Payload data Octet (4n)**  
**Octet(4n+1)(7:0)**      **Payload data Octet (4n+1)**

The payload data octets of a cell extracted from either upstream or downstream direction are read by consecutive read accesses to registers **URXDAT0/DRXDAT0** and **URXDAT1/DRXDAT1** in alternating manner until end of packet:

cycle n=0: Octet 0 and 1: read from **URXDAT0/DRXDAT0**

cycle n=0: Octet 2 and 3: read from **URXDAT1/DRXDAT1**

cycle n=1: Octet 4 and 5: read from **URXDAT0/DRXDAT0**

cycle n=1: Octet 6 and 7: read from **URXDAT1/DRXDAT1**


...

After EOP is found, CPCS-UU, CPI and Status is read.



**Register 12 UA5RXDAT1/DA5RXDAT1**  
**Upstream/Downstream AAL5 Receive Data 1 Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UA5RXDAT1 0E<sub>H</sub>**      **DA5RXDAT1 1E<sub>H</sub>**  
 Typical Usage: Read by CPU



Cell Receive Data Transfer Register

**Octet(4n)(7:0) Payload data Octet (4n)**  
**Octet(4n+1)(7:0) Payload data Octet (4n+1)**

The payload data octets of a cell extracted from either upstream or downstream direction are read by consecutive read accesses to registers **URXDAT0/DRXDAT0** and **URXDAT1/DRXDAT1** in alternating manner until end of packet:

cycle n=0: Octet 0 and 1: read from **URXDAT0/DRXDAT0**

cycle n=0: Octet 2 and 3: read from **URXDAT1/DRXDAT1**

cycle n=1: Octet 4 and 5: read from **URXDAT0/DRXDAT0**

cycle n=1: Octet 6 and 7: read from **URXDAT1/DRXDAT1**

...

After EOP is found, CPCS-UU, CPI and Status is read.

**Register 13 UA5SARS/DA5SARS**  
**Upstream/Downstream AAL5 SAR Status Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0080<sub>H</sub>**  
 Offset Address: **UA5SARS 0F<sub>H</sub> DA5SARS 1F<sub>H</sub>**  
 Typical Usage: Read and written by CPU

Bit	15	14	13	12	11	10	9	8
	PE	CRC ERR	ILEN	MFLE	RAB	OV(1:0)		RXS
Bit	7	6	5	4	3	2	1	0
	WAIT	SP	SAB	SE	unused(3:0)			

- PE Packet End**  
 A '1' indicates that with the preceding read to register **UA5RXDAT0/DA5RXDAT0** or **UA5RXDAT1/DA5RXDAT1**, the last two bytes of the current packet have been read.
- CRCERR CRC Error**  
 A '1' indicates that the CRC32 of the current packet is erroneous.
- ILEN Illegal Length**  
 A '1' indicates that the length of the current packet is erroneous, i.e the number of octets does not match the length field in the AAL5 trailer or exceeds the maximum supported packet length of 65536 octets.
- MFLE Maximum Frame Length Exceeded**  
 A '1' indicates that the length of the current packet exceeds the maximum supported packet length of 65536 octets.
- RAB Receive Abort**  
 A '1' indicates that the length field of the current packet is 0, indicating an aborted or corrupted packet.
- OV(1:0) Octets Valid**  
 This bit field indicates the number of valid octets in registers **UA5RXDAT0** and **UA5RXDAT1** or **DA5RXDAT0** and **DA5RXDAT1** respectively.

**Register Description**


<b>RXS</b>	<p><b>Receive Packet Start</b></p> <p>A '1' indicates that the first octets of a new packet are available in registers <b>UA5RXDAT0</b> and <b>UA5RXDAT1</b> or <b>DA5RXDAT0</b> and <b>DA5RXDAT1</b> respectively.</p>
<b>WAIT</b>	<p><b>Wait</b></p> <p>A '1' indicates that no valid octets are available in registers <b>UA5RXDAT0</b> and <b>UA5RXDAT1</b> or <b>DA5RXDAT0</b> and <b>DA5RXDAT1</b> respectively. Read access to any read register while WAIT is asserted results into an error interrupt.</p>
<b>SP</b>	<p><b>Segmentation Pending</b></p> <p>A '1' indicates that a cell is ready to be transmitted towards the ABM-P core. A cell is ready either when 48 octets have been written to <b>UA5TXDAT0</b> and <b>UA5TXDAT1</b> or <b>DA5TXDAT0</b> and <b>DA5TXDAT1</b> respectively or when the last cell is being built.</p> <p>Bit 'SP' is set when the 48-byte transmit buffer is full and it is reset as soon as at least 4-octet space is available for new octets. The microprocessor has to poll this bit before writing the next 48-octet bunch or beginning a new packet. If the microprocessor attempts to write to <b>UA5TXDAT0</b> and <b>UA5TXDAT1</b> or <b>DA5TXDAT0</b> and <b>DA5TXDAT1</b> respectively while 'SP' is set, an interrupt is generated and the write access is delayed by the READY signal.</p>
<b>SAB</b>	<p><b>Segmentation Abort</b></p> <p>A '1' indicates that the transmission of a packet has been aborted because the enable bit EN was reset by the microprocessor before the transmission was completed. The AAL5 unit automatically closed the packet with an abort sequence in the last cell (length field set to 0).</p> <p><i>Note: Status bit 'SE' is not set in this case.</i></p>
<b>SE</b>	<p><b>Segmentation Ended</b></p> <p>A '1' indicates that the transmission of a packet has been completed successfully.</p>

*Note: Status bits SP, SAB, SE are used for transmit, the others for receive.*

## 7.2.4 Buffer Occupation Counter Registers

### Register 14 UBufferOcc/DBufferOcc Upstream/Downstream Buffer Occupation Registers

CPU Accessibility: **Read only**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UBufferOcc 20<sub>H</sub>**                      **DBufferOcc 21<sub>H</sub>**  
 Typical Usage: Read by CPU



**UBufferOcc(17:2) Upstream Buffer Occupation Counter**

**DBufferOcc(17:2) Downstream Buffer Occupation Counter**

These bit fields represent the most significant 16 bits of the internal 18-bit wide counters reflecting the number of cells currently stored in the upstream/downstream cell storage RAM.

The CPU determines the buffer fill level with a granularity of 4 by reading register UBufferOcc/DBufferOcc and left shifting the value by 2:

$fill\_level(17:0) := (xBufferOcc(17:2) \ll 2)$

**Register 15 UBufferOccNg/DBufferOccNg**


**Up-/Downstream Non-Guaranteed Buffer Occupation Registers**

CPU Accessibility: **Read only**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UBufferOccNg 22<sub>H</sub>                      DBufferOccNg 23<sub>H</sub>**

Typical Usage: Read by CPU



**UBufferOccNg(17:2) Upstream Non-Guaranteed Buffer Occupation Counter**

**DBufferOccNg(17:2) Downstream Non-Guaranteed Buffer Occupation Counter**

These bit fields represent the most significant 16 bits of the internal 18-bit wide counters reflecting the number of **non-guaranteed** cells currently stored in the upstream/downstream cell storage RAM.

The CPU determines the number of cells with a granularity of 4 by reading register UBufferOccNg/DBufferOccNg and left shifting the value by 2:

$$\text{fill\_level}(17:0) = (\text{xBufferOccNg}(17:2) \ll 2)$$

“Non-Guaranteed” cell count refers to cells, that are accepted (stored) because of shared buffer availability although the guaranteed minimum per queue buffer size is already occupied by the specific queue.

The sum of all per queue guaranteed buffer sizes virtually divides the global buffer space into a “guaranteed” part and a “non-guaranteed” (shared) part.

*Note: This counter function has been modified from ABM v1.1 since minimum per queue buffer reservation was introduced in ABM-P v1.1.*

*In ABM v1.1 these counters represented the number stored “non-real-time” cells belonging to traffic classes with the real-time indication bit ‘RTind’ cleared in the traffic class table.*

## 7.2.5 Buffer Threshold and Occupation Capture Registers

### Register 16 UBufMax/DBufMax


#### Upstream/Downstream Buffer Maximum Threshold Registers

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UBufMax 24<sub>H</sub> DBufMax 25<sub>H</sub>**

Typical Usage: Written by CPU



**UBufMax(17:2) Upstream Buffer Maximum Threshold**

**DBufMax(17:2) Downstream Buffer Maximum Threshold**

These bit fields determine a maximum limit for the total upstream and downstream buffer size with a granularity of 4 cells. The values depend on:

- The size of the external cell pointer RAM,
- Whether the downstream cell storage RAM is connected.

See [Table 7-3](#) for recommended values.

The CPU programs the maximum number of cells with a granularity of 4 by right shifting the value by 2:

$xBufMax(17:2) = (maximum\_cells(17:0) \gg 2)$

[Table 7-3](#) provides typical values and related RAM sizes:

**Table 7-3 External RAM Sizes**

<b>Cell Pointer SSRAM</b>	<b>Min. Required Upstream Cell SDRAM</b>	<b>Min. Required Downstream Cell SDRAM</b>	<b>UBufMax</b>	<b>Up- stream Buffer</b>	<b>DBufMax</b>	<b>Down- stream Buffer</b>
e.g. 512 k x 32 bit	128 Mb e.g. 2*(4Mb*16)	128 Mb e.g. 2*(4Mb*16)	3FFFF <sub>H</sub>	256k cells	3FFFF <sub>H</sub>	256k cells
e.g. 256 k x 32 bit	64 Mb e.g. 1*(2Mb*32)	64 Mb e.g. 1*(2Mb*32)	1FFFF <sub>H</sub>	128k cells	1FFFF <sub>H</sub>	128k cells
e.g. 128 k x 32 bit	32 Mb	32 Mb	0FFFF <sub>H</sub>	64k cells	0FFFF <sub>H</sub>	64k cells
e.g. 256 k x 32 bit	128 Mb e.g. 2*(4Mb*16)	none	3FFFF <sub>H</sub>	256k cells	00000 <sub>H</sub>	0
e.g. 128 k x 32 bit	64 Mb e.g. 1*(2Mb*32)	none	1FFFF <sub>H</sub>	128k cells	00000 <sub>H</sub>	0
e.g. 64 k x 32 bit	32 Mb	none	0FFFF <sub>H</sub>	64k cells	00000 <sub>H</sub>	0

*Note: The upstream cell storage RAM must always be connected.*

*Note: The size of the cell storage RAMs need not to be specified. Its minimum size is determined by the setting of UBufMax/DbufMax.*

**Register 17 UMAC/DMAC**


**Upstream/Downstream Maximum Occupation Capture Registers**

CPU Accessibility: **Read only, self-clearing on Read**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UMAC 26<sub>H</sub> DMAC 27<sub>H</sub>**

Typical Usage: Read by CPU



**UMAC(17:2) Upstream Maximum Occupation Capture Counter**

**DMAC(17:2) Downstream Maximum Occupation Capture Counter**

These bit fields represent the most significant 16 bits of the internal 18-bit wide counters reflecting the absolute maximum number of cells stored in the respective external cell buffer since the last Read access (peak cell filling level within measurement interval).

The CPU determines the maximum number of cells with a granularity of 4 by reading register UMAC/DMAC and left shifting the value by 2:


$$\text{max\_level}(17:0) := (\text{xMAC}(17:2) \ll 2)$$

The counter value is automatically cleared to 0000<sub>H</sub> after Read.



**Register 18 UMIC/DMIC**  
**Upstream/Downstream Minimum Occupation Capture Registers**

CPU Accessibility: **Read only, self-clearing on Read**  
 Reset Value: **FFFF<sub>H</sub>**  
 (modified by chip logic immediately after reset)  
 Offset Address: **UMIC 28<sub>H</sub> DMIC 29<sub>H</sub>**  
 Typical Usage: Read by CPU



**UMIC(17:2) Upstream Minimum Occupation Capture Counter**  
**DMIC(17:2) Downstream Minimum Occupation Capture Counter**

These bit fields represent the most significant 16 bits of the internal 18-bit wide counters reflecting the absolute minimum number of cells stored in the respective external cell buffer since the last Read access (minimum cell filling level within measurement interval).

The CPU determines the minimum number of cells with a granularity of 4 by reading register UMIC/DMIC and left shifting the value by 2:


$$\text{min\_level}(17:0) := (\text{xMIC}(17:2) \ll 2)$$

The counter value is automatically cleared to 0000<sub>H</sub> after Read.

*Note: The reset value is modified by chip logic immediately after reset or clearing read and thus shall not be included in register reset value test programs.*

**Register 19 CLP1DIS**  
**CLP1 Discard Global Threshold Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **CLP1DIS 2A<sub>H</sub>**  
 Typical Usage: Written by CPU



**UCLP1DIS(13:6) Upstream CLP1 Discard Threshold value**  
**DCLP1DIS(13:6) Downstream CLP1 Discard Threshold value**

These 8-bit values determine a global 14-bit threshold value (granularity of 64 cells) that enables discard of low-priority (CLP='1') cells.

The threshold values are compared with the per scheduler low priority cell counter SBOccLP (Scheduler Block Low Priority Occupancy) (see **Internal Table 5: Scheduler Block Occupancy Table Transfer Registers SBOC0..SBOC4**) and enables all CLP1 related discard thresholds, i.e.:

- TCT1.BufCiCLP1(7:0) (**Register 40: TCT1**)
- TCT2.SBCiCLP1(7:0) (**Register 41: TCT2**)
- TCT0.QueueCiCLP1(11:0) (**Register 39: TCT0**)

As a second condition, CLP1 related discard thresholds are only effective, if the specific queue that is asked to accept the cell is associated to a traffic class that has EPD function disabled (EPDen='0', see **“Traffic Class Table Transfer Registers TCT0, TCT1, TCT2, TCT3” on Page 241**).

The CPU programs the threshold with a granularity of 64 cells by right shifting the value by 6:  
 $xCLP1DIS(13:6) = (threshold\_value(13:0) \gg 6)$

## 7.2.6 Configuration Register

### Register 20 CONFIG Configuration Register

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **2B<sub>H</sub>**  
 Typical Usage: Written by CPU

Bit	15	14	13	12	11	10	9	8	
	Unused(13:6)								
Bit	7	6	5	4	3	2	1	0	
	Unused(5:0)						Reserved1	ABRTQ	

**Reserved1**      **this bit is for internal use only** and must be set to 0 during normal operation.

**ABRTQ**      **ABR Toggle Queue ID:**  
 This global bit controls treatment of RM cells for uni-directional (miniswitch) mode.

0	Normal Operation (set for bi-directional mode).
1	RM cells with toggled LCI and QID are modified.

*Note: The following conditions must apply for proper CI/NI operation:*  
*In Bi-directional Mode, the same LCI and the same queue identifier QID must be used for the ABR connection in forward and backward directions; for example, in forward direction LCI=2 and QID=7, in backward direction LCI=2 and QID=7.*  
*In Uni-directional Mode, LCI and QID must have the LSB inverted; for example, in forward direction LCI=3 and QID=7, in backward direction LCI=2 and QID=6.*  
*The LCI inversion (toggle) is activated by setting the LCI toggle bit in the **MODE1** register to 1.*  
*(LCI toggling and Queue toggling are not necessary for proper operation of ABM-P but of preceding devices that expect the same LCI for forward and backward direction of one connection (e.g. AOP PXB4340 and ALP PXB4350).)*

## 7.2.7 Backpressure Control Registers

### Register 21 UUBPTH0


#### Upstream UTOPIA Backpressure Threshold Register 0

CPU Accessibility: **Read/Write**

Reset Value: **FFFF<sub>H</sub>**

Offset Address: **UUBPTH0 2C<sub>H</sub>**

Typical Usage: **Written by CPU**



#### UUBPTH0(17:2) Upstream UTOPIA Backpressure Threshold 0


This bit field determines the backpressure threshold for the Upstream UTOPIA Receive Interface Group 0 (see [Chapter 5.1.1](#)) with a granularity of 4 cells.

The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:

$UUBPTH0(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

**Register 22 UUBPTH1**  
**Upstream UTOPIA Backpressure Threshold Register 1**


CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **UUBPTH1 2D<sub>H</sub>**  
 Typical Usage: **Written by CPU**



**UUBPTH1(17:2) Upstream UTOPIA Backpressure Threshold 1**  
 This bit field determines the backpressure threshold for the Upstream UTOPIA Receive Interface Group 1 (see [Chapter 5.1.1](#)) with a granularity of 4 cells.  
 The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  
 $UUBPTH1(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

**Register 23 UUBPTH2**  
**Upstream UTOPIA Backpressure Threshold Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **UUBPTH2 2E<sub>H</sub>**  
 Typical Usage: **Written by CPU**




**UUBPTH2(17:2) Upstream UTOPIA Backpressure Threshold 2**  
 This bit field determines the backpressure threshold for the Upstream UTOPIA Receive Interface Group 2 (see [Chapter 5.1.1](#)) with a granularity of 4 cells.  
 The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  

$$\text{UUBPTH2}(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$$

**Register 24 UUBPTH3**  
**Upstream UTOPIA Backpressure Threshold Register 3**


CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **UUBPTH3 2E<sub>H</sub>**  
 Typical Usage: **Written by CPU**



**UUBPTH3(17:2) Upstream UTOPIA Backpressure Threshold 3**  
 This bit field determines the backpressure threshold for the Upstream UTOPIA Receive Interface Group 3 (see [Chapter 5.1.1](#)) with a granularity of 4 cells.  
 The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  
 $UUBPTH3(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

**Register 25 UBPEI**  
**UTOPIA Backpressure Exceed Indication Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UBPEI 30<sub>H</sub>**  
 Typical Usage: Read by CPU



**DUBPEI(3:0)**      **Downstream UTOPIA Backpressure Exceed Indication (3:0)**  
**UUBPEI(3:0)**      **Upstream UTOPIA Backpressure Exceed Indication (3:0)**


These bits indicate the respective UTOPIA backpressure threshold status.

Bit i (i = 0..3) active indicates, that the backpressure threshold for group i is exceeded (bit = 'H') and the UTOPIA Receive Interface backpressures the respective UTOPIA ports.



**Register 26 DUBPTH0**  
**Downstream UTOPIA Backpressure Threshold Register 0**


CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **DUBPTH0 31<sub>H</sub>**  
 Typical Usage: **Written by CPU**



**DUBPTH0(17:2) Downstream UTOPIA Backpressure Threshold 0**  
 This bit field determines the backpressure threshold for the Downstream UTOPIA Receive Interface Group 0 (see [Chapter 5.2.1](#)) with a granularity of 4 cells. The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  
 $DUBPTH0(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

**Register 27 DUBPTH1**  
**Downstream UTOPIA Backpressure Threshold Register 1**


CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **DUBPTH1 32<sub>H</sub>**  
 Typical Usage: **Written by CPU**



**DUBPTH1(17:2) Downstream UTOPIA Backpressure Threshold 1**  
 This bit field determines the backpressure threshold for the Downstream UTOPIA Receive Interface Group 1 (see [Chapter 5.2.1](#)) with a granularity of 4 cells.  
 The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  
 $DUBPTH1(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

**Register 28 DUBPTH2**  
**Downstream UTOPIA Backpressure Threshold Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **DUBPTH2 33<sub>H</sub>**  
 Typical Usage: **Written by CPU**




**DUBPTH2(17:2) Downstream UTOPIA Backpressure Threshold 2**  
 This bit field determines the backpressure threshold for the Downstream UTOPIA Receive Interface Group 2 (see [Chapter 5.2.1](#)) with a granularity of 4 cells. The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  
 $DUBPTH2(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

**Register 29 DUBPTH3**

**Downstream UTOPIA Backpressure Threshold Register 3**

CPU Accessibility: **Read/Write**  
 Reset Value: **FFFF<sub>H</sub>**  
 Offset Address: **DUBPTH3 34<sub>H</sub>**  
 Typical Usage: **Written by CPU**



**DUBPTH3(17:2) Downstream UTOPIA Backpressure Threshold 3**


This bit field determines the backpressure threshold for the Downstream UTOPIA Receive Interface Group 3 (see [Chapter 5.2.1](#)) with a granularity of 4 cells. The CPU programs the threshold with a granularity of 4 by right shifting the value by 2:  
 $DUBPTH3(17:2) = (\text{maximum\_cells}(17:0) \gg 2)$

## 7.2.8 QCI Control Registers

### Register 30 DQCIC

#### Downstream Queue Congestion Indication Control Register

CPU Accessibility: **Read/Write**  
 Reset Value: **0080<sub>H</sub>**  
 Offset Address: **DQCIC 35<sub>H</sub>**  
 Typical Usage: Written by CPU



#### FSEN

##### Frame Sync Enable

This bit enables frame sync operation controlled by signal 'QCITXFRAME'.

- 0 Frame Sync Operation disabled. Input signal 'QCITXFRAME' is ignored.
- 1 Frame Sync Operation enabled. An active high edge at input signal 'QCITXFRAME' starts transmission of a new pattern.

#### BSEN

##### Bit-Stuffing Enable

This bit enables HDLC bit-stuffing within the transmission pattern.

- 0 Bit-stuffing disabled.
- 1 Bit-stuffing enabled.

#### BPLEN(1:0)

##### Bit-Pattern Length

This bit field determines the bit pattern payload length depending on the number of queues that need to be monitored.

- 00 1k bits (queues 0..1023 are monitored)
- 01 2k bits (queues 0..2047 are monitored)

**Register Description**

10	4k bits (queues 0..4095 are monitored)
11	8k bits (queues 0..8191 are monitored)

**QCIHYS(3:0)**

**Queue Congestion Indication Hysteresis**

This bit field determines the hysteresis that is applied to the Queue Congestion Indication threshold evaluation. The queue specific threshold is programmed in table [QCIT](#).

The hysteresis determines a lower threshold  $TH_{hys}$  with

$$TH_{hysi} = Threshold_i - \Delta_i$$

The  $\Delta_i$  value is determined by bit field DH(2:0) and  $Threshold_i$  with:

$$\Delta_i = Threshold_i \gg [QCIHYS(3:0)]$$

The following table shows the operation and resulting example  $TH_{hysi}$  values for the example of a threshold programmed to 1024 cells:

QCIHYS (2:0):	$\Delta_i =$	Example:
0d	0 (hysteresis disabled)	$TH_{hysi} = 1024$
1d	$Threshold_i \gg 1$	$TH_{hysi} = 512$
2d	$Threshold_i \gg 2$	$TH_{hysi} = 768$
4d	$Threshold_i \gg 4$	$TH_{hysi} = 960$
8d	$Threshold_i \gg 8$	$TH_{hysi} = 1020$
10d	$Threshold_i \gg 10$	hysteresis ineffective)

## 7.2.9 DBA Control Registers

### Register 31 DSBT1


#### Upstream/Downstream DBA Scheduler Block Threshold Register 1

CPU Accessibility: **Read/Write**

Reset Value: **FFFF<sub>H</sub>**

Offset Address: **DSBT1 36<sub>H</sub>**

Typical Usage: Written and Read by CPU during initialization



#### DSBT1HP(11:4) DBA Scheduler Block Threshold 1 High Priority

This bit field represents the most significant 8 bits of the internal 12-bit wide **High** Priority DBA Threshold 1. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOccHP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

$DSBT1HP(11:4) = (\text{threshold\_value} \gg 4)$

#### DSBT1LP(11:4) DBA Scheduler Block Threshold 1 Low Priority

This bit field represents the most significant 8 bits of the internal 12-bit wide **Low** Priority DBA Threshold 1. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOccLP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

$DSBT1LP(11:4) = (\text{threshold\_value} \gg 4)$

**Register 32 DSBT2**


**Upstream/Downstream DBA Scheduler Block Threshold Register 2**

CPU Accessibility: **Read/Write**

Reset Value: **FFFF<sub>H</sub>**

Offset Address: **DSBT2 37<sub>H</sub>**

Typical Usage: Written and Read by CPU during initialization



**DSBT2HP(11:4) DBA Scheduler Block Threshold 2 High Priority**

This bit field represents the most significant 8 bits of the internal 12-bit wide **High** Priority DBA Threshold 2. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOcHP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

$DSBT2HP(11:4) = (\text{threshold\_value} \gg 4)$

**DSBT2LP(11:4) DBA Scheduler Block Threshold 2 Low Priority**

This bit field represents the most significant 8 bits of the internal 12-bit wide **Low** Priority DBA Threshold 2. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOcLP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

$DSBT2LP(11:4) = (\text{threshold\_value} \gg 4)$



**Register 33 DSBT3**


**Upstream/Downstream DBA Scheduler Block Threshold Register 3**

CPU Accessibility: **Read/Write**

Reset Value: **FFFF<sub>H</sub>**

Offset Address: **DSBT3 38<sub>H</sub>**

Typical Usage: Written and Read by CPU during initialization



**DSBT3HP(11:4) DBA Scheduler Block Threshold 3 High Priority**

This bit field represents the most significant 8 bits of the internal 12-bit wide **High** Priority DBA Threshold 3. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOcHP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

DSBT3HP(11:4) := (threshold\_value >> 4)

**DSBT3LP(11:4) DBA Scheduler Block Threshold 3 Low Priority**

This bit field represents the most significant 8 bits of the internal 12-bit wide **Low** Priority DBA Threshold 3. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOcLP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

DSBT3LP(11:4) := (threshold\_value >> 4)

**Register 34 DSBT4**


**Upstream/Downstream DBA Scheduler Block Threshold Register 4**

CPU Accessibility: **Read/Write**

Reset Value: **FFFF<sub>H</sub>**

Offset Address: **DSBT4 39<sub>H</sub>**

Typical Usage: Written and Read by CPU during initialization



**DSBT4HP(11:4) DBA Scheduler Block Threshold 4 High Priority**

This bit field represents the most significant 8 bits of the internal 12-bit wide **High** Priority DBA Threshold 4. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOcHP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:

$DSBT4HP(11:4) = (\text{threshold\_value} \gg 4)$

**DSBT4LP(11:4) DBA Scheduler Block Threshold 4 Low Priority**

This bit field represents the most significant 8 bits of the internal 12-bit wide **Low** Priority DBA Threshold 4. The threshold value is global, but individually evaluated against all scheduler block specific fill level counter (upstream and downstream) of the same priority class (SBOcLP).

The threshold range is (0..4095) with a granularity of 16 cells.

The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 4:


$DSBT4LP(11:4) = (\text{threshold\_value} \gg 4)$

Register Description

**Internal Table 1: DBA Threshold Crossing Table Transfer Register**


The DBA Threshold Crossing Table (DTCT) Transfer Register is used to access the internal Upstream/Downstream DBA Threshold Crossing Table containing 2\*8 entries of 16 bits each. [Table 7-4](#) summarize the registers.

**Table 7-4 Registers DTC Upstream/Downstream Table Access**



DTCT is the transfer register (read only) for a 16-bit DTC Table entry. The Read process is controlled by the [MAR](#) (Memory Address Register). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the DTC Table, bit field MAR(4:0) must be set to 05<sub>H</sub>. Bit 5 of MAR starts the transfer and is automatically cleared after execution.

**Table 7-5 WAR Register Mapping for DTC Table access**




**Core** Selects the core (upstream/downstream) for access of the DBA Threshold Crossing Indication entries:

- 0 Upstream Core
- 1 Downstream Core

**EntrySel(3:0)** Selects one of the 8 DBA Threshold Crossing Indication Entries.

**Register 35 DTCT**  
**DTC Transfer Register**

CPU Accessibility: **Read**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **DTCT 3A<sub>H</sub>**  
 Typical Usage: Read by CPU



**DTCSBE(15:0) DBA Threshold Crossing Scheduler Block Event**  
 Each bit indicates that a DBA Threshold Crossing Event has occurred in a specific Scheduler Block (SB). The Threshold Crossing type must then be read from the respective SBOC table entry (see **Register 50: SBOC0**).  
 The Scheduler Block *j* is determined from the bit-position *N* in bit field DTCSBE(15:8) and the Entry number (Register WAR bit field 'EntrySel(3:0)' and bit 'Core'):

Core='0' Upstream Events:  

$$j_{SBU_p} = \text{EntrySel}(3:0) * 16 + N$$

Core='1' Downstream Events:  

$$j_{SBD_n} = \text{EntrySel}(3:0) * 16 + N$$

*Note: The DTCSBE(15:0) entries are automatically cleared on read. Any new event (bit set by ABM-P) generates an interrupt in register ISRDBA (see Register 121: ISRDBA).*

## 7.2.10 LCI Table Transfer Registers

### Internal Table 2: LCI Table Transfer Registers LCI0, LCI1, LCI2

These registers are used to access the internal Local Connection Identifier (LCI) table containing 16384 entries (one entry serves for upstream and downstream direction). [Table 7-6](#) shows an overview of the registers involved.

**Table 7-6 Registers for LCI Table Access**

47							0	
LCI RAM entry							RAM select:	
15	0	15	0	15	0	15	0	
LCI2		LCI1		LCI0		MAR=00 <sub>H</sub>		
							LCI select:	
15	0	15	0	15	0	15	0	
MASK2		MASK1		MASK0		WAR (0..16383 <sub>D</sub> )		

LCI0, LCI1 and LCI2 are the transfer registers for one 48-bit LCI table entry. The LCI value representing the table entry which needs to be read or written must be written to the Word Address Register (**WAR**). The dedicated LCI table entry is read into the LCI0/LCI1/LCI2 Registers or modified by the LCI0/LCI1/LCI2 Register values with a write mechanism. The associated Mask Registers MASK0 to MASK2 allow a bit-wise masking for Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated LCI0/LCI1/LCI2 register bit will be overwritten by the respective LCI table entry bit value. In case of Write operation, the dedicated LCI0/LCI1/LCI2 register bit will modify the respective LCI table entry bit value.

The Read or Write process is controlled by the Memory Address Register (**MAR**). The 5 LSBs (= Bit 4..0) of the MAR select the memory/table that will be accessed; to select the LCI table bit field MAR(4:0) must be set to 0. Bit 5 of the MAR starts the transfer and is automatically cleared after execution.


**Table 7-7 WAR Register Mapping for LCI Table Access**

Bit	15	14	13	12	11	10	9	8
	Unused(2:0)		LCISel(13:8)					
Bit	7	6	5	4	3	2	1	0
	LCISel(7:0)							

**LCISel(13:0)** Selects an LCI entry within the range (0..16383).

**Register 36 LC10**  
**LCI Transfer Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **LC10            3B<sub>H</sub>**  
 Typical Usage:    Written and Read by CPU to maintain the LCI table



**CLPT**                    **CLP Transparent:**  
 Specifies whether the CLP bit of cells belonging to this connection is evaluated or not in threshold checks. Valid for both upstream and downstream cores. Does not affect SBOC counters.


0	CLP bit is evaluated.
1	CLP bit is not evaluated; all cells are treated as high priority cells assuming CLP=0.

**ABMcore**                **ABM-P Core Selection:**  
 This bit is valid in Uni-directional Mode only and specifies the core responsible for cells of this LCI.

0	Scheduler Blocks 0..127 are selected (core 0).
1	Scheduler Blocks 128..255 are selected (core 1).

**Register 37 LCI1**  
**LCI Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **LCI1 3C<sub>H</sub>**  
 Typical Usage: Written and Read by CPU to maintain the LCI table



**DnQID(12:0)**      **Downstream Queue Identifier.**  
 Specifies the queue (0..8191) in which the cells of the connection are stored.


**Dnflag 2**      **Last cell of packet flag for downstream direction;**  
 This bit is autonomously used by the EPD function of the ABM-P. Initialize to 1 at connection setup. Do not Write during normal operation.

**Dnflag 1**      **Discard packet flag in downstream direction;**  
 This bit is autonomously used by the EPD function of the ABM-P. Initialize to 0 at connection setup. Do not Write during normal operation.

**Dnflag 0**      **Discard rest of packet flag in downstream direction;**  
 This bit is autonomously used by the EPD function of the ABM-P. Initialize to 0 at connection setup. Do not Write during normal operation.

**Register 38 LCI2**  
**LCI Transfer Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **LCI1 3D<sub>H</sub>**  
 Typical Usage: Written and Read by CPU to maintain the LCI table



**UpQID(12:0)**      **Upstream Queue Identifier.**  
 Specifies the queue (0..8191) in which the cells of the connection are stored.

**Upflag 2**      **Last cell of packet flag for upstream direction;**  
 This bit is autonomously used by the EPD function of the ABM-P. Initialize to 1 at connection setup. Do not Write during normal operation.

**Upflag 1**      **Discard packet flag in upstream direction;**  
 This bit is autonomously used by the EPD function of the ABM-P. Initialize to 0 at connection setup. Do not Write during normal operation.

**Upflag 0**      **Discard rest of packet flag in upstream direction;**  
 This bit is autonomously used by the EPD function of the ABM-P. Initialize to 0 at connection setup. Do not Write during normal operation.




### 7.2.11 Traffic Class Table Transfer Registers

#### Internal Table 3: Traffic Class Table Transfer Registers TCT0, TCT1, TCT2, TCT3

The Traffic Class Table Transfer Registers are used to access the internal Traffic Class Table (TCT) containing 2\*16 entries of 4\*64 bits each (16 traffic classes per ABM-P core, 4 words of 64 bits per entry). [Table 7-8](#) shows an overview of the registers involved.

**Table 7-8 Registers for TCT Table Access**



TCT0, TCT1, TCT2 and TCT3 are the transfer registers used to access the 4\*64 bit TCT table entries.

Core selection, traffic class number, and 64-bit word selection of the table entry which needs to be read or written must be programmed to the Word Address Register (WAR). The dedicated TCT table entry 64-bit word is read into the TCT3/TCT2/TCT1/TCT0 registers or modified by the TCT3/TCT2/TCT1/TCT0 register values with a write mechanism. The associated Mask Registers MASK<sub>i</sub> (i=3..0) allow a bit-wise masking for Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated TCT<sub>i</sub> (i=3..0) register bit will be overwritten by the respective TCT table entry bit value. In case of Write operation, the dedicated TCT<sub>i</sub> (i=3..0) register bit will modify the respective TCT table entry bit value.

The Read or Write process is controlled by the Memory Address Register (MAR). The 5 LSBs (= Bit 4..0) of the MAR select the memory/table that will be accessed; to select the TCT table bit field MAR(4:0) must be set to 1. Bit 5 of MAR starts the transfer and is automatically cleared after execution.

**Table 7-9 WAR Register Mapping for TCT Table Access**

Bit	15	14	13	12	11	10	9	8
	Unused(7:0)							
Bit	7	6	5	4	3	2	1	0
	Unused	CoreSel	TCID(3:0)				word64Sel(1:0)	

**CoreSel**                   **Selects the ABM-P core for TCT table access:**  
 0                   Upstream core selected (Core 0)  
 1                   Downstream core selected (Core 1)

**TCID(3:0)**               **Selects The Traffic Class** for the TCT table access in the range (0..15).

**word64Sel(1:0)**       **Selects The 64-Bit Word** of the 256-bit TCT table entry for access:  
 00                   Bit field (63..0) of traffic class entry is selected.  
 01                   Bit field (127..64) of traffic class entry is selected.  
 10                   Bit field (191..128) of traffic class entry is selected.  
 11                   Bit field (255..192) of traffic class entry is selected.

The meaning of registers TCTi (i=3..0) depends on the word selection bit field 'word64Sel(1:0)' in the WAR, because 256-bit TCT entries are mapped to 64 bits of registers TCTi (i=3..0) by this selection:

**Register Description**

WAR modulo 4

	63		56	55		48	47		40	39		32		
3	LostCellsTotal(31:0) <sup>1)</sup>													
2	AcceptedCells/Packets(31:0) <sup>1)</sup>													
1	TrafClassMax(7:0)				SBMax(7:0)				unused(3:0)		SBCiCLP1(11:0)			
0	DH (2:0)	2 8	2 7	2 6	2 5	2 4	2 3	2 2	2 1	2 0	unused(3:0)		unused(15:0)	

TCT3(15:0)	TCT2(15:0)
------------	------------

<sup>1)</sup> All 5 statistical counters stop at their maximum value. Counters must be set to 0 after read.

WAR modulo 4

	31		24	23		16	15		8	7		0
3	unused(7:0)			LostCell sBuffer (3:0) <sup>1)</sup>	LostCell sSB(3:0) <sup>1)</sup>	LostPackets/CLP1Cells(15:0) <sup>1)</sup>						
2	unused(13:0)					TrafClassOccNg(17:0)						
1	unused(7:0)			QueueMax(7:0)			unused(3:0)		QueueCiCLP1(11:0)			
0	unused(7:0)			BufCiCLP1(7:0)			BufMaxNg(7:0)		BufEPDNg(7:0)			

TCT1(15:0)	TCT0(15:0)
------------	------------


<sup>1)</sup> All 5 statistical counters stop at their maximum value. Counters must be set to 0 after read.

*Note:* - grey fields are 'unused', it is recommended to mask them for write access  
 - green fields must be configured (written) by the CPU  
 - blue fields are statistical counter values optionally read by CPU

**Register 39 TCT0**  
**TCT Transfer Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **TCT0 3E<sub>H</sub>**  
 Typical Usage: Written and Read by CPU to maintain the TCT table;  
 the meaning of register TCT0 depends on the bit field  
 'Word64Sel' in [WAR](#);

Register WAR.Word64Sel(1:0) ='00':




**BufMaxNg(7:0)** **Maximum Buffer Fill Threshold for a non-real-time traffic class configuration** (register TCT1, DwordSel=00).  
 The first cell exceeding this threshold is discarded and if also PPD is enabled for this traffic class (register TCT1, DwordSel=00, PPDen=1) PPD is applied on a per connection (LCI) basis.  
 The threshold is defined with a granularity of 1024 cells:  
 Threshold = BufMaxNg(7:0) \* 1024 Cells

**BufEPDNg(7:0)** **EPD threshold for a non-real-time traffic class configuration** (register TCT1, DwordSel='00').  
 If the buffer fill exceeds this threshold and EPD is enabled for this traffic class (register TCT1, DwordSel=00, EPDen=1) EPD is applied on a per connection (LCI) basis.  
 The threshold is defined with a granularity of 1024 cells:  
 Threshold = BufEPDNg(7:0) \* 1024Cells

**Register Description**

Register WAR.Word64Sel(1:0) = '01':




**QueueCiCLP1 (11:0)** **Combined Queue Threshold of this Traffic Class** for the following cases:

- a) if ABRen=1 for the traffic class  
⇒ ABR Congestion Indication CI/NI/EFCl is triggered
- b) if CLPT=0 (CLP transparent bit is not true) and EPDen=0  
⇒ CLP1 queue threshold for CLP=1 cells (cells with CLP=1 are discarded)
- c) if CLPT=0 and EPDen=1  
⇒ EPD GFR queue threshold. If that threshold and additionally BufNrtEPD (of the respective traffic class) is exceeded then EPD is triggered.

The threshold is defined with a granularity of 4:  
Threshold = QueueCiCLP1(7:0) \* 4 Cells


Register WAR.Word64Sel(1:0) = '10':



**TrafClassOccNg (15:0)** **Current Buffer Occupation** in number of cells for this traffic class. Do not Write in normal operation.

**Register Description**

Register WAR.Word64Sel(1:0) = '11':




**LostPackets/CLP1Cells (15:0)**      **Count of Lost Packets due to EPD Overflow** for this traffic class or count of lost CLP=1 cells due to CLP threshold overflow. Automatically reset after Read access.

**Register 40 TCT1**  
**TCT Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **TCT1 3F<sub>H</sub>**  
 Typical Usage: Written and Read by CPU to maintain the TCT table;  
 the meaning of register TCT1 depends on the bit field  
 'Word64Sel' in [WAR](#);

Register WAR.Word64Sel(1:0) ='00':



**BufCiCLP1 (17:10)**      **Buffer EPD CLP1 Threshold**

This 8-bit value determines a global cell filling level threshold with a granularity of 1024 cells that triggers early packet discard (EPD) for CLP=1 tagged frames used by GFR traffic class service (low watermark).

The threshold values are compared with the non guaranteed Buffer Occupancy counters UBufferOccNg, DBufferOccNg respectively.


The CPU programs the threshold with a granularity of 1024 cells by right shifting the value by 10:

$$\text{BufCiCLP1}(17:10) = (\text{threshold\_value}(17:0) \gg 10)$$

*Note: In ABM v1.1 this threshold was determined by registers UEC and DEC.*

**Register Description**

Register WAR.Word64Sel(1:0) = '01':



**QueueMax (7:0)** This 8-bit value determines the maximum queue length with a granularity of 64 cells. The CPU programs the maximum queue length with a granularity of 64 cells by right shifting the value by 6:

$$\text{QueueMax}(7:0) := \text{queuelength} \gg 6$$

The maximum length of any queue is limited to  $(255 \cdot 64) = 16320$  cells.

Register WAR.Word64Sel(1:0) = '10':




**TrafClassOccNg (17:16) MSBs of Current Buffer Occupation Counter**  
TrafClassOccNg(17:0) counts the number of cells stored for this traffic class.  
Do not Write in normal operation.



**Register Description**

Register WAR.Word64Sel(1:0) = '11':




**LostCellsBuffer (3:0)**      **Count of Lost Cells due to Buffer Overflow** for this traffic class.  
Automatically reset after Read access.

**LostCellsSB (3:0)**      **Count of Lost Cells due to Scheduler Block Overflow** for this traffic class.  
Automatically reset after Read access.


**Register 41 TCT2**  
**TCT Transfer Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **TCT2 40<sub>H</sub>**  
 Typical Usage: Not used by CPU;  
 the meaning of register TCT2 depends on the bit field  
 'Word64Sel' in [WAR](#);

Register WAR.Word64Sel(1:0) = '00':



Register WAR.Word64Sel(1:0) = '01':



**Register Description**


**SBCiCLP1(11:0) Scheduler Block Ci/CLP1 Threshold**

This threshold determines a maximum number of low priority cells allowed to be stored per scheduler block with a granularity of 64 cells.

The CPU programs the threshold with a granularity of 64 cells by right shifting the value by 6:

SBCiCLP1(11:0):= threshold >> 6

Register WAR.Word64Sel(1:0) = '10':



**AcceptedCells/  
Packets  
(15:0)**

**Count of Accepted Cells or AAL5 Units** within this traffic class, depending on flag **SCNT** in **TCT3**.

If **SCNT** = 0:

This counter is incremented when a user data cell with AAL\_ indication=1 is accepted (Packet end indication in AAL5: PTI= xx1).


If **SCNT** = 1 all accepted cells are counted

Do not Write in normal operation.

Must be reset after Read access.

**Register Description**

Register WAR.Word64Sel(1:0) = '11':



**LostCellsTotal (15:0)**    Count of all lost cells for this traffic class.  
Do not Write in normal operation.  
Must be reset after Read access.

**Register 42 TCT3**  
**TCT Transfer Register 3**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **TCT3 41<sub>H</sub>**  
 Typical Usage: Written and Read by CPU to maintain the TCT table;  
 the meaning of register TCT3 depends on the bit field  
 'Word64Sel' in [WAR](#);

Register WAR.Word64Sel(1:0) = '00':

Bit	15	14	13	12	11	10	9	8
	DH(2:0)			unused	ABRen	ABRVp	EPDen	PPDen
Bit	7	6	5	4	3	2	1	0
	SCNT	CntLP DBA	GFRen	CLPtran s DBA	unused(3:0)			

**DH  
(2:0)**

**DeltaHysteresis** for threshold evaluations with hysteresis applied:

This value is per traffic class, but is evaluated individually for each effected threshold TH relative to the threshold size. The hysteresis determines a lower threshold TL with  
 $TL_i = TH_i - \Delta_i$

The  $\Delta_i$  value is determined by bit field DH(2:0) and  $TH_i$  with:  
 $\Delta_i = TH_i \gg [DH(2:0) + 1]$

The following table shows the operation and resulting  $TL_i$  values for the example of a threshold programmed to 256 cells:

DH(2:0):	$\Delta_i =$	Example:
0d	0 (hysteresis disabled)	$TL_i = 256$
1d	$TH_i \gg 2$	$TL_i = 192$
2d	$TH_i \gg 3$	$TL_i = 224$

**Register Description**

3d	TH <sub>i</sub> >>4	TL <sub>i</sub> = 240
4d	TH <sub>i</sub> >>5	TL <sub>i</sub> = 248
5d	TH <sub>i</sub> >>6	TL <sub>i</sub> = 252
6d	TH <sub>i</sub> >>7	TL <sub>i</sub> = 254
7d	TH <sub>i</sub> >>8 (hysteresis ineffective)	TL <sub>i</sub> = 256

**ABRen**

**Congestion indication**

This bit enables congestion indication marking in user cells (EFCI marking) within every ABR connection (LCI) that belongs to this traffic class:

- 0 Congestion indication disabled.
- 1 Congestion indication enabled.

*Note: This ABR function is a buffer manager function and not related to the Enhanced Rate Control (ERC) unit.*

**ABRvp**

**Indication for update of RM cells** (ABR service category) relating to the VP or to the individual VC, respectively:

- 0 Congestion is indicated via VC RM cells (F5 flow). VC RM cells are identified with PTI=110 and VCI <> 6.
- 1 Congestion is indicated via VP RM cells (F4 flow). VP RM cells are identified with VCI=6 (regardless of the value of the PTI field)

*Note: According to the standards, VP RM cells MUST have VCI=6 and PTI=110. If cells with PTI=110 and VCI <> 6 are contained in the cell stream they are ignored. This is the correct behavior for an ABR VC within an ABR VP.*

**EPDen**

**EPD for the individual traffic class.** EPD is used for every connection (LCI) within that traffic class (see [Chapter 3.4.1.6.3](#)):

- 0 EPD is disabled.
- 1 EPD is enabled.

**PPDen**

**PPD for the individual traffic class.** PPD is used for every connection (LCI) within that traffic class (see [Chapter 3.4.1.6.3](#)):


- 0 PPD is disabled

Register Description

	1	PPD is enabled
<b>SCNT</b>	<b>Counter Function Select</b>	
	This bit selects the function of counter 'AcceptedCells/Packets(31:0)':	
	0	Accepted Packets are counted
	1	Accepted Cells are counted
<b>CntLPDBA</b>	<b>Count all Low Priority (DBA):</b>	
	This bit enforces that all cells of that traffic class are counted as low priority cells for <b>DBA threshold</b> counters, regardless of the CLP bit value.	
	0	CLP bit is evaluated and determines whether the cell is counted by the High Priority (HP) or Low Priority (LP) counters.
	1	CLP bit is not evaluated; all cells are treated as low priority and are counted by the Low Priority counter (LP).
<b>GFRen</b>	<b>GFR Enable:</b>	
	This bit enables a modified EPD threshold evaluation for GFR traffic (see <a href="#">Chapter 3.4.1.6.3</a> ).	
	0	Modified EPD threshold evaluation for GFR disabled
	1	Modified EPD threshold evaluation for GFR enabled
<b>CLPtransDBA</b>	<b>CLP Transparent (DBA):</b>	
	Specifies whether the CLP bit of cells belonging to this connection is evaluated or not for <b>DBA threshold</b> checks and counters.	
	0	CLP bit is evaluated.
	1	CLP bit is not evaluated; all cells are treated as high priority cells assuming CLP=0.

**Register Description**

Register WAR.Word64Sel(1:0) = '01':




**TrafClassMax (7:0)**      **Maximum Traffic Class Fill Threshold** (determines the maximum number of cells in all queues associated with this traffic class). The threshold is defined with a granularity of 1024:  
Threshold = TrafClassMax(7:0) \* 1024 Cells

**SBMax(7:0)**      **Combined Threshold of the Maximum Number of Buffered Cells** in the Scheduler Block; that is, all cells which are in the traffic classes (= cells in the corresponding queues) of the Scheduler Block for the following cases:

- a) If EPDen=0 and ABRen=0  
    ⇒ Maximum Scheduler Block fill threshold for CLP='0/1' cells
- b) If EPDen=1 and ABRen=0  
    ⇒ EPD Scheduler Block threshold
- c) If ABRen=1  
    ⇒ CI Scheduler Block threshold for ABR connections  
    (Set CI-Bit (Congestion Indication) in the RM cells)

The threshold is defined with a granularity of 1024:  
Threshold = SBMax(7:0) \* 1024 Cells

Register WAR.Word64Sel(1:0) = '10':






**Register Description**

**AcceptedCells/  
Packets  
(31:16)**      **Count of Accepted Cells or AAL5 Units** within this traffic class, depending on flag **SCNT** in **TCT3**.  
 If **SCNT** = 0:  
 This counter is incremented when a user data cell with AAL\_ indication=1 is accepted (Packet end indication in AAL5: PTI= xx1).  
 If **SCNT** = 1 all accepted cells are counted  
 Do not Write in normal operation.  
 Must be reset after Read access.

Register WAR.Word64Sel(1:0) = '11':




**LostCellsTotal  
(31:16)**      Count of all lost cells for this traffic class.  
 Do not Write in normal operation.  
 Must be reset after Read access.

## 7.2.12 Queue Configuration Table Transfer Registers

### Internal Table 4: Queue Configuration Table Transfer Registers QCT0..6

Queue Configuration Table Transfer Registers are used to access the internal Queue Configuration Table (QCT) containing 2\*8192 entries. The lower 8K entries control the upstream core queues and the upper 8K entries control the downstream core queues. [Table 7-10](#) shows an overview of the registers involved. Some fields are not used for entry 0 (common real time bypass)

**Table 7-10 Registers for Queue Configuration Table Access**



QCT0...QCT6 are the transfer registers for one 112 bit QCT table entry. The core selection and queue number representing the table entry which needs to be read or written must be written to the Word Address Register (WAR). The dedicated QCT table entry is read into the QCT0..QCT6 registers or modified by the QCT0..QCT6 register values with a write mechanism. The associated Mask Registers MASK0..MASK6 allow a bit-wise Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated QCT0..QCT6 register bit will be overwritten by the respective QCT table entry bit value. In case of Write operation, the dedicated QCT0..QCT6 register bit will modify the respective QCT table entry bit value.

*Note: It is recommended not to Write to bit fields (111:64) and (15:0) of the QCT table entries; i.e. registers MASK0, MASK6, MASK5, MASK4 and MASK3 should always be programmed with FFFF<sub>H</sub>.*

The 13 LSBs (= Bit 12..0) of the WAR register select the queue-specific entry that will be accessed and bit 'CoreSel' the ABM-P core.

The Read or Write process is controlled by the Memory Address Register (MAR). The 5 LSBs (= Bit 4..0) of the MAR select the memory/table that will be accessed; to select the QCT table, bit field MAR(4:0) must be set to 2. Bit 5 of MAR starts the transfer and is automatically cleared after execution.

**Register Description**

**Table 7-11 WAR Register Mapping for LCI Table Access**


Bit	15	14	13	12	11	10	9	8
	unused(1:0)		CoreSel	QSel(12:8)				
Bit	7	6	5	4	3	2	1	0
	QSel(7:0)							

**CoreSel**           **Selects an ABM-P Core:**  
 0           Upstream core selected  
 1           Downstream core selected

**QSel(12:0)**       **Selects a Queue Entry** within the range (0..8191).

**Register 43 QCT0**  
**Queue Configuration Transfer Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT0 42<sub>H</sub>**  
 Typical Usage: Read by CPU



**QueueLength (13:0)** Represents the **Current Number of Cells Stored in this Queue.**  
Do not Write in normal operation.

**Register 44 QCT1**  
**Queue Configuration Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT1 43<sub>H</sub>**  
 Typical Usage: Written and Read by CPU to maintain the LCI table

Bit	15	14	13	12	11	10	9	8
	DQac	RSall	VS/VD en	ABR dir	TCID(3:0)			
Bit	7	6	5	4	3	2	1	0
	QIDvalid	SBID(6:0)						

**DQac**                    **Dummy Queue Action**  
 This bit is a command bit that must always be set when a dummy queue is activated or deactivated.  
*Note: Read access to this command bit will always return '0'.*

**RSall**                    **ReSchedule Always**  
 This bit determines the queue scheduling process:  
 '0'                    The queue is only scheduled/re-scheduled with its specific rate while the queue is not empty (normal operation).

Register Description

- '1' The queue is always scheduled/re-scheduled with its specific rate independent of the queue filling level. Scheduling an empty queue results in an 'empty cell cycle' (no cell is emitted during this cycle). A so called 'dummy queue' is used either for generating empty cell cycles or by the ERC unit for generating out-of-rate RM cells.
- Note: 'RSall' can be set with connection setup (together with QIDvalid='1') or anytime while the queue is enabled.*
- After setting bit 'RSall', the ABM-P will automatically set bit 'MGconf/DQsch' to acknowledge the first dummy schedule event.*
- The 'RSall' information is internally conveyed to the scheduler. This process is acknowledged by an interrupt (Bit 'UDQRD/DDQRD' in Register 117: ISRC). It is recommended not to select any other table or table entry while waiting for this acknowledge.*
- Note: 'RSall' can be reset anytime while the queue is enabled. In response to resetting 'RSall' the ABM-P will generate an interrupt (Bit 'UDQRD/DDQRD' in Register 117: ISRC) and reset bit 'MGconf/DQsch' in this table.*
- Note: To activate or deactivate a dummy queue, command bit 'DQac' must be set in conjunction with setting or resetting bit 'RSall'.*

VS/VDen

VS/VD Enable

This bit enables ABR VS/VD operation for the queue (in conjunction with appropriate settings of the ERC unit):


- '0' The queue is not configured for ABR VS/VD operation.
- '1' The queue is configured for ABR VS/VD operation in conjunction with proper settings of the ERC unit. This bit enables control information exchange between the Buffer Manager and the ERC unit as well as enables ABR OAM cell handling.

Register Description

<b>QIDvalid</b>	<b>Queue Enable:</b>
	<p>0 Queue disabled. An attempt to store a cell to a disabled queue leads to discard of the cell and a <b>QIDINV</b> interrupt is generated. If a filled queue gets disabled, cells may still be in the queue. In this case the disabled queue is still scheduled, and cells are logically emitted from the queue but will not be transmitted. Actual filling of the queue can be obtained via QueueLength(13:0) parameter in the QCT entry. <i>Note: To disable an active VC-merge group, bit 'QIDvalid' must be reset. Deactivating the queue by setting QIDvalid='0' automatically starts an internal process to delete the queue from the VC-merge group. In response to resetting 'QIDvalid' the ABM-P will generate an interrupt (Bit 'UQVCMGD/DQVCMGD' in Register 117: ISRC) and reset bit 'MGconf/DQsch' in this table.</i></p> <p>1 Queue enabled. Cells are allowed to enter the queue.</p>
<b>TCID(3:0)</b>	<b>Traffic Class Number (0..15)</b> Assigns the queue to one of the 16 traffic classes defined in the traffic class table TCT for this core.
<b>SBID(6:0)</b>	<b>Scheduler Block Number (0..127)</b> Assigns the queue to one of the 128 schedulers of this core.
<b>ABRdir</b>	<b>ABR CI/NI update</b> of backward RM cells: <p>0 RM cells of the same core are updated.</p> <p>1 RM cells of the opposite core are updated.</p> <p><i>Note: ABR Congestion Indication is done in RM cells of the backward ABR connection. In Bi-directional Mode, these cells are handled by the opposite core (therefore ABRdir must be 1 for each ABR QID). In Mini-switch Mode, these cells can be handled from the same or opposite core depending on configuration. (If only one core will be used, ABRdir must be 0 for each ABR QID.)</i></p>

**Register 45 QCT2**  
**Queue Configuration Transfer Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT2 44<sub>H</sub>**  
 Typical Usage: Written by CPU to configure VC-Merge operation



**MGconf/DQsch Merge Group Configured/  
Dummy Queue Scheduled**

The meaning of this flag depends on bit '**RSall**':

**RSall**='0'

The queue is not configured as a 'dummy queue' and may be configured as a VC-merge group member:

MGconf

- 0 The queue is neither a dummy queue, nor member of a VC-merge group.
- 1 The queue is member of a VC-merge group. The VC-merge group is determined by bit field 'MGID(6:0)'.  
*Note: To disable an active VC-merge group, bit 'QIDvalid' must be reset. Deactivating the queue by setting QIDvalid='0' automatically starts an internal process to delete the queue from the VC-merge group. In response to resetting 'QIDvalid' the ABM-P will generate an interrupt (Bit 'UQVCMGD/DQVCMGD' in Register 117: ISRC) and reset bit 'MGconf/DQsch' in this table.*

**RSall**='1'

The queue is configured as a 'dummy queue':

DQsch



Register Description

- 0 The queue is activated as a 'dummy queue', but no first dummy schedule event has occurred.
  - 1 The queue is activated as a 'dummy queue' and at least one first dummy schedule event has occurred.
- Note: 'RSall' can be reset anytime while the queue is enabled. In response to resetting 'RSall' the ABM-P will generate an interrupt (Bit 'UDQRD/DDQRD' in Register 117: ISRC) and reset bit 'MGconf/DQsch' in this table.*

**MGID(6:0)**      **Merge Group Number (0..127)**  
Assigns the queue to one of 128 merge groups of this core.

**MinBG(7:0)**      **Minimum Buffer Guarantee**  
This bit field determines a minimum buffer reservation for this particular queue. The sum of all minimum buffer reservations virtually divides the total buffer into a 'Guaranteed' part and a shared 'Non-Guaranteed' part.  
The minimum buffer reservation offers to granularities depending on MSB of MinBG(7):

- MinBG(7) Granularity of 1 cell for short queues (e.g. real-time queues):  
:= 0      The minimum reserved buffer in number of cells is  $reserved\_buffer = MinBG(6:0) = \{0, 1, 2, \dots, 127\}$
- MinBG(7) Granularity of 8 cells for long queues (e.g. non-real-time queues):  
:= 1      The minimum reserved buffer in number of cells is  $reserved\_buffer = MinBG(6:0) \ll 3 = \{0, 8, 16, \dots, 1016\}$

**Register 46 QCT3**  
**Queue Configuration Transfer Register 3**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT3 45<sub>H</sub>**  
 Typical Usage: Not used by CPU

Bit	15	14	13	12	11	10	9	8
	unused(11:4)							
Bit	7	6	5	4	3	2	1	0
	unused(3:0)				EOP	CI	NI	EFCI

- EOP**      **EOP-Flag:**  
Do not Write during normal operation.
- CI**        **CI-Flag:**  
Whenever a cell is accepted the respective queue threshold values are checked. In case a CI condition is detected, this condition is stored in flag2 for further recognition by resource monitoring operation (ABR).  
It is recommended to set this bit to 0 during queue setup.  
Do not Write during normal operation.
- NI**        **NI-Flag:**  
Whenever a cell is accepted the respective queue threshold values are checked. In case a NI condition is detected, this condition is stored in flag1 for further recognition by resource monitoring operation (ABR).  
It is recommended to set this bit to 0 during queue setup.  
Do not Write during normal operation.
- EFCI**      **EFCI-Flag:**  
Whenever a cell is accepted the respective queue threshold values are checked. In case a EFCI condition is detected, this condition is stored in flag0 for further recognition by resource monitoring operation (ABR).  
It is recommended to set this bit to 0 during queue setup.  
Do not Write during normal operation.

**Register 47 QCT4**  
**Queue Configuration Transfer Register 4**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT4 46<sub>H</sub>**  
 Typical Usage: Not used by CPU



**Reserved(15:0)** Do not Write in normal operation.

**Register 48 QCT5**  
**Queue Configuration Transfer Register 5**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT5 47<sub>H</sub>**  
 Typical Usage: Not used by CPU



**reserved(15:0)** Do not Write in normal operation.

**Register 49 QCT6**  
**Queue Configuration Transfer Register 6**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCT6 48<sub>H</sub>**  
 Typical Usage: Not used by CPU



**reserved(15:0)** Do not Write in normal operation.

### 7.2.13 Scheduler Block Occupancy Table Transfer Registers

**Internal Table 5:**

**Scheduler Block Occupancy Table Transfer Registers SBOC0..SBOC4**

The Scheduler Block Occupancy Table Transfer Registers are used to access the internal Scheduler Block Occupancy Table (SBOC) containing 2\*128 entries of 80 bit each. [Table 7-12](#) shows an overview of the registers involved.

*Note: The SBOC table information is typically not required by the CPU. The SBOC maintains global counters that are internally used for threshold evaluation. In case of DBA operation, the SBOC0 transfer register provides information about threshold crossing events that are evaluated by CPU for the DBA algorithm. For statistical purposes, reading the SBOC entries provides a snap shot of the respective scheduler occupation situation distinguished by priorities and also the current number of discarded low priority cells.*

**Table 7-12 Registers for SBOC Table Access**

79											0		
SBOC RAM entry											RAM Select:		
15	0	15	0	15	0	15	0	15	0	15	0	15	0
SBOC4	SBOC3	SBOC2	SBOC1	SBOC0							MAR=03 <sub>H</sub>		
											Entry select:		
15	0	15	0	15	0	15	0	15	0	15	0	15	0
MASK4	MASK3	MASK2	MASK1	MASK0							WAR (0..255 <sub>D</sub> )		

SBOC0..SBOC4 are the transfer registers for one 80-bit SBOC table entry. The Scheduler Block number representing the table entry which needs to be read or written must be written to the Word Address Register (WAR). The dedicated SBOC table entry is read into the SBOC0..SBOC4 Registers or modified by the SBOC0..SBOC4 register values with a write mechanism. The associated Mask Registers MASK0..MASK4 allow a bit-wise Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated SBOC0..SBOC4 register bit will be overwritten by the respective SBOC table entry bit value. In case of Write operation, the dedicated SBOC0..SBOC4 register bit will modify the respective SBOC table entry bit value.

The Read or Write process is controlled by the Memory Address Register (MAR). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the SBOC table, bit field MAR(4:0) must be set to 3. Bit 5 of MAR starts the transfer and is automatically cleared after execution.

**Register Description**

**Table 7-13 WAR Register Mapping for SBOC Table Access**

Bit	15	14	13	12	11	10	9	8
	Unused(7:0)							
Bit	7	6	5	4	3	2	1	0
	CoreSel	SchedSel(6:0)						

**CoreSel**      **Selects an ABM-P core:**

0	Upstream core selected
1	Downstream core selected

**SchedSel(6:0)**      **Selects one of the 128 core-specific Scheduler Blocks.**

**Register 50 SBOC0**  
**SBOC Transfer Register 0**

CPU Accessibility: **Read only**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **SBOC0 49<sub>H</sub>**  
 Typical Usage: Read by CPU


Bit	15	14	13	12	11	10	9	8
	SBOccNg(1:0)		SBOccHP(1:0)		SBOccLP(1:0)		SBOccLPd(1:0)	
Bit	7	6	5	4	3	2	1	0
	DBATHCROSS(7:0)							

**DBATHCROSS (7:0)**     **DBA Threshold Crossing Indication**  
 DBATHCROSS(3:0) correspond to the four thresholds for low priority cells, DBATHCROSS(7:4) to the four thresholds for high priority cells.  
 A '1' indicates that the dedicated threshold was reached. The flags are reset if both SBOccLP and SBOccHP are equal 0.



**Register 51 SBOC1**  
**SBOC Transfer Register 1**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **SBOC1 4A<sub>H</sub>**  
 Typical Usage: Read by CPU (for debug purposes or statistics)



**SBOccLPd (17:2)**      **Scheduler Block Occupancy Counter Low Priority Discarded Cells**  
 The Counter is reset if both SBOccLP and SBOccHP are equal 0.  
*Note: The LSBs SBOccLPd(1:0) are mapped to transfer register SBOC0.*

**Register 52 SBOC2**  
**SBOC Transfer Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **SBOC1 4B<sub>H</sub>**  
 Typical Usage: Read by CPU (for debug purposes or statistics)




**SBOccLP(17:2) Scheduler Block Occupancy Counter Low Priority**

*Note: The LSBs SBOccLP(1:0) are mapped to transfer register SBOC0.*

**Register 53 SBOC3**  
**SBOC Transfer Register 3**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **SBOC3 4C<sub>H</sub>**  
 Typical Usage: Read by CPU (for debug purposes or statistics)



**SBOccHP(17:2) Scheduler Block Occupancy Counter High Priority**  
*Note: The LSBs SBOccHP(1:0) are mapped to transfer register SBOC0.*

**Register 54 SBOC4**  
**SBOC Transfer Register 4**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **SBOC4 4D<sub>H</sub>**  
 Typical Usage: Read by CPU (for debug purposes or statistics)



**SBOccNg(17:2) Scheduler Block Occupancy Counter Non Guaranteed**  
*Note: The LSBs SBOccNg(1:0) are mapped to transfer register SBOC0.*

### 7.2.14 Merge Group Table Transfer Registers

#### Internal Table 6: Merge Group Table Transfer Registers MGT0..MGT2

The Merge Group Table Transfer Registers are used to access the internal Merge Group Table (MGT) containing 2\*128 entries of 48 bit each. [Table 7-12](#) shows an overview of the registers involved.

**Table 7-14 Registers for MGT Table Access**

47							0
MGT RAM entry							RAM Select:
15	0	15	0	15	0	15	0
MGT2		MGT1		MGT0		MAR=07 <sub>H</sub>	
							Entry select:
15	0	15	0	15	0	15	0
MASK2		MASK1		MASK0		WAR (0..255 <sub>D</sub> )	

MGT0..MGT2 are the transfer registers for one 48-bit MGT table entry. The Scheduler Block number representing the table entry which needs to be read or written must be written to the Word Address Register ([WAR](#)). The dedicated MGT table entry is read into the MGT0..MGT2 Registers or modified by the MGT0..MGT2 register values with a write mechanism. The associated Mask Registers MASK0..MASK2 allow a bit-wise Write operation (0 - unmasked, 1 - masked). In case of read operation, the dedicated MGT0..MGT2 register bit will be overwritten by the respective MGT table entry bit value. In case of Write operation, the dedicated MGT0..MGT2 register bit will modify the respective MGT table entry bit value.

The Read or Write process is controlled by the Memory Address Register ([MAR](#)). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the MGT table, bit field MAR(4:0) must be set to 6. Bit 5 of MAR starts the transfer and is automatically cleared after execution.

**Register Description**


**Table 7-15 WAR Register Mapping for MGT Table Access**

Bit	15	14	13	12	11	10	9	8
	Unused(7:0)							
Bit	7	6	5	4	3	2	1	0
	CoreSel	GroupSel(6:0)						

- CoreSel**      **Selects an ABM-P core:**
- 0      Upstream core selected
  - 1      Downstream core selected
- GroupSel(6:0)**      **Selects one of the 128 Merge Groups.**

**Register 55 MGT0  
MGT Transfer Register 0**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **MGT0 4E<sub>H</sub>**  
 Typical Usage: Not used by CPU



**Reserved(15:0)**

**Register 56 MGT1  
MGT Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **MGT1 4F<sub>H</sub>**  
 Typical Usage: Not used by CPU



**Reserved(15:13)**

**Head\_Pointer(12:0)** When setting up a merge group, this pointer must be set to point to any of the queues contained in the merge group.




**Register 57 MGT2**  
**MGT Transfer Register 2**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **MGT2 50<sub>H</sub>**

Typical Usage: Written by CPU to maintain the MGT table



**LClOen**

**LCl Overwrite Enable:**

This bit enables the LCl overwrite function for cells/packets emitted by the VC-Merge Group.

0 Disable LCl overwrite

1 Enable LCl overwrite

**LCl(13:0)**

**LCl**

In case LCl overwrite function is enabled, this value overwrites the original LCl of any cell emitted by this VC-Merge Group.


The cell field that is overwritten depends on the selected LCl mapping mode.

### 7.2.15 Mask Registers

#### Register 58 MASK0/MASK1

##### Table Access Mask Registers 0/1

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **MASK0 55<sub>H</sub> MASK1 56<sub>H</sub>**  
 Typical Usage: Written by CPU to control internal table Read/Write access



**MASK0(15:0) Mask Register 0**


**MASK1(15:0) Mask Register 1**

Mask Registers 0..6 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (LCI0..LCI2, TCT0..TCT3, QCT0..6, SBOC0..SBOC4, MGT0..MGT2):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

**Register 59 MASK2/MASK3**  
**Table Access Mask Registers 2/3**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **MASK2 57<sub>H</sub> MASK3 58<sub>H</sub>**  
 Typical Usage: Written by CPU to control internal table Read/Write access




**MASK2(15:0) Mask Register 2**  
**MASK3(15:0) Mask Register 3**

Mask Registers 0..6 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (LCI0..LCI2, TCT0..TCT3, QCT0..6, SBOC0..SBOC4, MGT0..MGT2):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

**Register 60 MASK4/MASK5**  
**Table Access Mask Registers 4/5**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **MASK4 59<sub>H</sub> MASK5 5A<sub>H</sub>**  
 Typical Usage: Written by CPU to control internal table Read/Write access



**MASK4(15:0) Mask Register 4**

**MASK5(15:0) Mask Register 5**

Mask Registers 0..6 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (LCI0..LCI2, TCT0..TCT3, QCT0..6, SBOC0..SBOC4, MGT0..MGT2):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

**Register 61 MASK6**


**Table Access Mask Registers 6**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **MASK6 5B<sub>H</sub>**

Typical Usage: Written by CPU to control internal table Read/Write access



**MASK6(15:0) Mask Register 6**

Mask Registers 0..6 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (LCI0..LCI2, TCT0..TCT3, QCT0..6, SBOC0..SBOC4, MGT0..MGT2):


- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

### 7.2.16 Queue Congestion Indication Table

#### Internal Table 7: Queue Congestion Indication Table Transfer Register


The Queue Congestion Indication Table (QCIT) Transfer Register is used to access the internal Downstream Queue Congestion Indication Table containing 8192 entries of 16 bit each. [Table 7-4](#) summarize the registers.

**Table 7-16 Registers QCIT Table Access**



QCIT is the transfer register for a 16-bit QCIT Table entry. Table access is controlled by the **MAR** (Memory Address Register). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the QCIT Table, bit field MAR(4:0) must be set to 08<sub>H</sub>. Bit 5 of MAR starts the transfer and is automatically cleared after execution.


**Table 7-17 WAR Register Mapping for DTC Table access**



**EntrySel(12:0)** Selects one of the 8192 Queue Congestion Indication Table entries.

**Register 62 QCIT**  
**QCIT Transfer Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **QCIT 5C<sub>H</sub>**  
 Typical Usage: Written by CPU



**QCITH(11:0) Queue Congestion Indication Threshold**  
 This threshold determines the number of cells stored in the dedicated queue to set the associated congestion indication bit in the bit pattern of the QCI Interface. The threshold value is programmed with a granularity of 4 cells.  
 The CPU programs the threshold with a granularity of 4 cells by right shifting the value by 2:


$$QCITH(11:0) = \text{threshold} \gg 2$$

*Note: Reset of the congestion indication is performed with a hysteresis. The hysteresis value is common to all congestion indication thresholds, but evaluated queue threshold specific. Register 30: DQCIC provides the details.*

### 7.2.17 Rate Shaper CDV Registers

#### Register 63 UCDV/DCDV Upstream/Downstream Rate Shaper CDV Registers

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UCDV 62<sub>H</sub> DCDV 82<sub>H</sub>**  
 Typical Usage: Written by CPU



**CDVMax(8:0)** Maximal Cell Delay Variation (without notice)  
 This bit field determines a maximum CDV value for peak rate limited queues that can be introduced without notice.  
 The CDVMax is measured in multiples of 16-cell cycles.  
 If this maximum CDV is exceeded, a CDVOV (see registers [ISRU/ISR](#)[D](#)) interrupt is generated to indicate an unexpected CDV value. This can occur if multiple peak rate limited queues are scheduled to emit a cell in the same Scheduler time slot.  
 No cells are discarded due to this event.



### 7.2.18 Queue Parameter Table Mask Registers

#### Register 64 UQPTM0/DQPTM0

##### Upstream/Downstream Queue Parameter Table Mask Registers 0

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UQPTM0 65<sub>H</sub> DQPTM0 85<sub>H</sub>**

Typical Usage: Written by CPU to control internal table Read/Write access

Bit	15	14	13	12	11	10	9	8
	xQPTM0(15:8)							
Bit	7	6	5	4	3	2	1	0
	xQPTM0(7:0)							

**UQPTM0(15:0) Upstream QPT Mask Register 0**

**DQPTM0(15:0) Downstream QPT Mask Register 0**

UQPTM0/DQPTM0 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (UQPT1T0/UQPT2T0, DQPT1T0/DQPT2T0):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write. Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write. Does not affect Read access.

**Register 65 UQPTM1/DQPTM1**  
**Upstream/Downstream Queue Parameter Table Mask Registers 1**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UQPTM1 66<sub>H</sub> DQPTM1 86<sub>H</sub>**

Typical Usage: Written by CPU to control internal table Read/Write access

Bit	15	14	13	12	11	10	9	8
	xQPTM1(15:8)							
Bit	7	6	5	4	3	2	1	0
	xQPTM1(7:0)							

**UQPTM1(15:0) Upstream QPT Mask Register 1**

**DQPTM1(15:0) Downstream QPT Mask Register 1**

UQPTM1/DQPTM1 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (UQPT1T1/UQPT2T1, DQPT1T1/DQPT2T1):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

**Register 66 UQPTM2/DQPTM2**  
**Upstream/Downstream Queue Parameter Table Mask Registers 2**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UQPTM2 67<sub>H</sub> DQPTM2 87<sub>H</sub>**

Typical Usage: Written by CPU to control internal table Read/Write access

Bit	15	14	13	12	11	10	9	8
	xQPTM2(15:8)							
Bit	7	6	5	4	3	2	1	0
	xQPTM2(7:0)							

**UQPTM2(15:0) Upstream QPT Mask Register 2**


**DQPTM2(15:0) Downstream QPT Mask Register 2**

UQPTM2/DQPTM2 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (UQPT2T2, DQPT2T2):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write. Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write. Does not affect Read access.

**Register 67 UQPTM3/DQPTM3**  
**Upstream/Downstream Queue Parameter Table Mask Registers 3**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPTM3 68<sub>H</sub> DQPTM3 88<sub>H</sub>**  
 Typical Usage: Written by CPU to control internal table Read/Write access




**UQPTM3(15:0) Upstream QPT Mask Register 3**  
**DQPTM3(15:0) Downstream QPT Mask Register 3**

UQPTM3/DQPTM3 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (UQPT2T3, DQPT2T3):

- 0 The dedicated bit of the transfer register overwrites the table entry during Write. Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write. Does not affect Read access.

**Register 68 UQPTM4/DQPTM4**  
**Upstream/Downstream Queue Parameter Table Mask Registers 4**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPTM4 69<sub>H</sub> DQPTM4 89<sub>H</sub>**  
 Typical Usage: Not used for user-accessible tables.




**UQPTM4(15:0) Upstream QPT Mask Register 4**  
**DQPTM4(15:0) Downstream QPT Mask Register 4**

UQPTM4/DQPTM4 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers:

- 0 The dedicated bit of the transfer register overwrites the table entry during Write. Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write. Does not affect Read access.

**Register 69 UQPTM5/DQPTM5**  
**Upstream/Downstream Queue Parameter Table Mask Registers 5**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPTM5 6A<sub>H</sub> DQPTM5 8A<sub>H</sub>**  
 Typical Usage: Not used for user-accessible tables.



**UQPTM5(15:0) Upstream QPT Mask Register 5**  
**DQPTM5(15:0) Downstream QPT Mask Register 5**

UQPTM5/DQPTM5 control the Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers:

- 0 The dedicated bit of the transfer register overwrites the table entry during Write. Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write. Does not affect Read access.

### 7.2.19 Scheduler Configuration Register

#### Register 70 USCONF/DSCONF


##### Upstream/Downstream Scheduler Configuration Registers

CPU Accessibility: **Read/Write**

Reset Value: **0004<sub>H</sub>**

Offset Address: **USCONF 6B<sub>H</sub> DSCONF 8B<sub>H</sub>**

Typical Usage: Written by CPU during global initialization



#### TstepC(2:0) Time Base for the Rate Shaper

Refer to [Section 4.2.2.5 "Programming the PCR Limiter"](#) on [Page 141](#)


## 7.2.20 Queue Parameter Table Transfer Registers

### Internal Table 8: Queue Parameter Table 1 Transfer Registers


Queue Parameter Table Transfer Registers are used to access the internal Upstream and Downstream Queue Parameter Table 1 (QPT1) containing 8192 entries each. In both [Table 7-18](#) and [Table 7-19](#) provide an overview of the registers involved. Each QPT1 entry consists of 32 bits.

*Note: The QPT1 table information is not used by the CPU beside during queue initialization.*

**Table 7-18 Registers for QPT1 Upstream Table Access**



**Table 7-19 Registers for QPT1 Downstream Table Access**



UQPT1T0 and UQPT1T1 are the transfer registers for the 32-bit entry of the upstream QPT1 table. DQPT1T0 and DQPT1T1 are the transfer registers for the 32-bit entry of the downstream QPT1 table. Access to high and low word are both controlled by mask registers UQPTM0/UQPTM1 and DQPTM0/DQPTM1 respectively. The Mask registers are shared for access to both tables QPT1 and QPT2, whereas, the transfer registers are unique for each table.



**Register Description**

The queue number representing the table entry which needs to be read or written must be written to the Word Address Register (**WAR**). The dedicated QPT1 table entry is read into the xQPT1T0/xQPT1T1 transfer registers (x=U,D) or modified by the xQPT1T0/xQPT1T1 transfer register values with a write mechanism. The associated mask registers xQPTM0 and xQPTM1 allow a bit-wise Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated xQPT1T0/xQPT1T1 register bit will be overwritten by the respective QPT1 table entry bit value. In case of Write operation, the dedicated xQPT1T0/xQPT1T1 register bit will modify the respective QPT1 table entry bit value.

The Read or Write process is controlled by the Memory Address Register (**MAR**). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the QPT table bit field MAR(4:0) must be set to:

10<sub>H</sub> for QPT1 upstream table,

18<sub>H</sub> for QPT1 downstream table.

Bit 5 of MAR starts the transfer and is cleared automatically after execution.


**Table 7-20 WAR Register Mapping for QPT Table Access**

Bit	15	14	13	12	11	10	9	8
	Unused(2:0)			QueueSel(12:8)				
Bit	7	6	5	4	3	2	1	0
	QueueSel(7:0)							

**QueueSel(12:0)** Selects one of the 8192 queue parameter table entries.

**Register 71 UQPT1T0/DQPT1T0**  
**Upstream/Downstream QPT1 Table Transfer Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPT1T0 70<sub>H</sub> DQPT1T0 90<sub>H</sub>**  
 Typical Usage: Written by CPU during queue initialization



**Reserved(13:0)** These bits are used by the device logic. Do not Write to this field as that could lead to complete malfunctioning of the ABM-P which can be corrected by chip reset only.

**flags(1:0)** These bits must be written to 0 when initializing the queue. Do not Write during normal operation.

**Register 72 UQPT1T1/DQPT1T1**  
**Upstream/Downstream QPT1 Table Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPT1T1 71<sub>H</sub> DQPT1T0 91<sub>H</sub>**  
 Typical Usage: Not used by CPU

Bit	15	14	13	12	11	10	9	8
	Reserved(15:8)							
Bit	7	6	5	4	3	2	1	0
	Reserved(7:0)							

**Reserved(15:0)** These bits are used by the device logic. Do not Write to this field as that could lead to complete malfunctioning of the ABM-P which can be corrected by chip reset only.

**Internal Table 9: Queue Parameter Table 2 Transfer Registers**

Queue Parameter Table Transfer Registers are used to access the internal Upstream and Downstream Queue Parameter Table 2 (QPT2) containing 8192 entries each. In both [Table 7-21](#) and [Table 7-22](#) provide an overview of the registers involved. Each QPT2 entry consists of 64 bits.

**Table 7-21 Registers for QPT2 Upstream Table Access**

63				0					
QPT2 RAM entry (Upstream)								RAM Select:	
15	0	15	0	15	0	15	0	15	0
UQPT2T3		UQPT2T2		UQPT2T1		UQPT2T0		MAR=11 <sub>H</sub>	
								Entry Select:	
15	0	15	0	15	0	15	0	15	0
UQPTM3		UQPTM2		UQPTM1		UQPTM0		WAR (0..8191 <sub>D</sub> )	

**Table 7-22 Registers for QPT2 Downstream Table Access**

63				0					
QPT2 RAM entry (Downstream)								RAM Select:	
15	0	15	0	15	0	15	0	15	0
DQPT2T3		DQPT2T2		DQPT2T1		DQPT2T0		MAR=19 <sub>H</sub>	
								Entry Select:	
15	0	15	0	15	0	15	0	15	0
DQPTM3		DQPTM2		DQPTM1		DQPTM0		WAR (0..8191 <sub>D</sub> )	

UQPT2T0..UQPT2T3 are the transfer registers for the 64-bit entry of the upstream QPT2 table. DQPT2T0..DQPT2T3 are the transfer registers for the 64-bit entry of the downstream QPT2 table. Access to the RAM entry is controlled by mask registers UQPTM0..UQPTM3 and DQPTM0..DQPTM3, respectively. The Mask registers are shared for access to both tables QPT1 and QPT2 whereas the transfer registers are unique for each table.

The queue number representing the table entry which needs to be read or written must be written to the Word Address Register (WAR). The dedicated QPT2 table entry is read into the xQPT2T0..xQPT2T3 transfer registers (x=U,D) or modified by the xQPT2T0..xQPT2T3 transfer register values with a write mechanism. The associated mask registers xQPTM0..xQPTM3 allow a bit-wise Write operation (0 - unmasked, 1 -

**Register Description**

masked). In case of Read operation, the dedicated xQPT2T0..xQPT2T3 register bit will be overwritten by the respective QPT1 table entry bit value. In case of Write operation, the dedicated xQPT2T0..xQPT2T3 register bit will modify the respective QPT1 table entry bit value.

The Read or Write process is controlled by the Memory Address Register (MAR). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the QPT table bit field MAR(4:0) must be set to:

11<sub>H</sub> for QPT2 upstream table,

19<sub>H</sub> for QPT2 downstream table.

Bit 5 of MAR starts the transfer and is cleared automatically after execution.


**Table 7-23 WAR Register Mapping for QPT Table Access**

Bit	15	14	13	12	11	10	9	8
	Unused(2:0)			QueueSel(12:8)				
Bit	7	6	5	4	3	2	1	0
	QueueSel(7:0)							

**QueueSel(12:0)** Selects one of the 8192 queue parameter table entries.

**Register 73 UQPT2T0/DQPT2T0**  
**Upstream/Downstream QPT2 Table Transfer Register 0**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPT2T0 72<sub>H</sub>**      **DQPT2T0 92<sub>H</sub>**  
 Typical Usage:      Written by CPU during queue initialization



**RateFactor(15:0)** Controls the Peak Cell Rate of the queue. It is identical to the Rate factor TP described in [Section 4.2.2.5 “Programming the PCR Limiter” on Page 141](#). The value 0 disables the PCR limiter, that is, the cells from this queue bypass the shaper circuit. For VBR shaping, this parameter is not used (overridden by the parameter TP of the AVT table). However, it must be set unequal to 0 to enable VBR shaping.

**Register 74 UQPT2T1/DQPT2T1**  
**Upstream/Downstream QPT2 Table Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPT2T1 73<sub>H</sub> DQPT2T1 93<sub>H</sub>**  
 Typical Usage: Written by CPU during queue initialization




**WFQFactor (13:0)** Determines the weight factor  $T_{WFQ}$  of the queue at the WFQ scheduler input to which it is connected. Refer to [Section 4.2.2.7 “Guaranteed Cell Rates and WFQ Weight Factors” on Page 146](#).  
 The value WFQ Factor = 0 connects the queue to the high priority Round Robin Scheduler.  
 The value WFQFactor = 16383 (all ones) connects the queue to the low priority Round Robin Scheduler.

Modifying the WFQFactor during operation:

- If one of the Round Robin Schedulers (WFQFactor=0 or WFQFactor=16383) is used the WFQFactor must not be changed
- If the WFQ Scheduler (WFQFactor=1..16320) is used the WFQ-Factor may be varied in a range 1 to 16320.

**Register 75 UQPT2T2/DQPT2T2**  
**Upstream/Downstream QPT2 Table Transfer Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPT2T2 74<sub>H</sub>**      **DQPT2T2 94<sub>H</sub>**  
 Typical Usage: Not used by CPU



**Reserved(15:0)** These bits are used by the device logic. Do not Write to this field as that could lead to complete malfunctioning of the ABM-P, which can be corrected by chip reset only.



**Register 76 UQPT2T3/DQPT2T3**  
**Upstream/Downstream QPT2 Table Transfer Register 3**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UQPT2T3 75<sub>H</sub>**      **DQPT2T3 95<sub>H</sub>**  
 Typical Usage: Not used by CPU

Bit	15	14	13	12	11	10	9	8
	Reserved(15:8)							
Bit	7	6	5	4	3	2	1	0
	Reserved(7:0)							

**Reserved(15:0)** These bits are used by the device logic. Do not Write to this field as that could lead to complete malfunctioning of the ABM-P, which can be corrected by chip reset only.

**7.2.21 Scheduler Block Configuration Table Transfer/Mask Registers  
SDRAM Refresh Registers  
UTOPIA Port Select of Common Real Time Queue Registers**


**Internal Table 10: Scheduler Configuration Table Integer Transfer Registers**

The Scheduler Configuration Table Integer Transfer Registers are used to access the internal Upstream/Downstream Scheduler Configuration Tables Integer Part (SCTI) containing 128 entries each.


These tables are not addressed by the MAR and WAR registers, but are addressed via dedicated address registers (USADR/DSADR) and data registers (USCTI/DSCTI).

[Table 7-24](#) and [Table 7-25](#) show an overview of the registers involved.

**Table 7-24 Registers SCTI Upstream Table Access**



**Table 7-25 Registers SCTI Downstream Table Access**



USCTI and DSCTI are the transfer registers for the 32-bit SCTI upstream/downstream table entries. The upstream and downstream Schedulers use different tables (internal RAM) addressed via dedicated registers, USADR/DSADR. The address registers select the scheduler-specific entry as well as the high or low word of a 32-bit entry to be accessed. Further, there is no command bit, but transfers are triggered via Write access of the address registers and the data registers:

- To initiate a Read access, the Scheduler Block number must be written to the address register USADR (upstream) or to the address register DSADR (downstream). One system clock cycle later, the data can be Read from the respective transfer register USCTI or DSCTI.
- To initiate a Write access, it is sufficient to Write the desired Scheduler Block number to the address registers, USADR and DSADR, and then Write the desired data to the respective transfer register, USCTI or DSCTI, respectively. The transfer to the integer table is executed one system clock cycle after the Write access to USCTI or DSCTI. Thus, consecutive Write cycles may be executed by the microprocessor.

The SCTI table entries are either read or written. Thus, no additional mask registers are provided for bit-wise control of table entry accesses.


**Register 77 USADR/DSADR**  
**Upstream/Downstream SCTI Address Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USADR A0<sub>H</sub> DSADR B8<sub>H</sub>**

Typical Usage: Written and Read by CPU to maintain the SCTI tables



**WSEL**                   SCTI table entry **Word Select**

1                   Selects the high word (bit 31..16) for next access via register SCTIU/SCTID

0                   Selects the low word (bit 15..0) for next access via register SCTIU/SCTID


**SchedNo(6:0)**       **Scheduler Block Number**

Selects one of the 128 core-specific Scheduler Blocks for next access via register USCTI/DSCTI.

**Register 78 USCTI/DSCTI**  
**Upstream/Downstream SCTI Transfer Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **USCTI A1<sub>H</sub> DSCTI B9<sub>H</sub>**  
 Typical Usage: Written by CPU to maintain the SCTI tables

Register SADRx.WSel = 0:



**IntRate(13:0) Integer Rate**  
 This value determines the integer part of the Scheduler Block output rate.

*Note: Recommendation for changing the UTOPIA port number or scheduler rate during operation:*

*Disable specific scheduler by read-modify-write operation to corresponding bit in registers [USCEN0/DSCEN0... USCEN7/DSCEN7](#).*

*Modify scheduler specific UTOPIA port number and rates via [Table 10 "Scheduler Configuration Table Integer Transfer Registers" on Page 306](#), registers [USCTI/DSCTI](#) and [Table 11 "Scheduler Configuration Table Fractional Transfer Registers" on Page 316](#), registers [USCTFT/DSCTFT](#).*


*Enable specific scheduler by read-modify-write operation to corresponding bit in registers [USCEN0/DSCEN0... USCEN7/DSCEN7](#).*

*Note: Read access to bit field IntRate(13:0) is not supported and will return undefined values.*

Refer to [Section 4.2.2.2 "Programming the Scheduler Block Rates" on Page 138](#) for the calculation of IntRate and FracRate

**Register Description**

Register SADRx.WSel = 1:



**Init(9:0)**

**Initialization Value**

It is recommended to Write this bit field to all 0s during Scheduler Block configuration/initialization (the note below provides the details).

**UTOPIAPort(5:0) UTOPIA Port Number**

Specifies one of the 48 UTOPIA ports to which the Scheduler Block is assigned to. Only values in the range 0..47<sub>D</sub> are valid (0..3 for UTOPIA level 1). The UTOPIA port number value can be changed during operation (see note below). UTOPIA Port 48<sub>D</sub> is used to select the AAL5 reassembly unit.

**The UTOPIA port number can be modified during operation; (port) switch-over is e.g. used for ATM protection switching.** The following Notes explain switch-over and rate adaptation during operation:

*Note: This SCTI table entry should be programmed during Scheduler Block configuration/initialization. However the UTOPIA port number value can be modified during operation (e.g. for port switching). In this case the Init(9:0) value can be reset to 0. This bit field contains a 4-bit counter incrementing the number of unused scheduler cell cycles. Unused cell cycles occur whenever a scheduled event cannot be served, because a previously generated event is still in service (active cell transfer at UTOPIA Interface). This counter value is used (and decremented accordingly) to determine the allowed cell burst size for following scheduler events. Such bursts are treated as 'one event' to allow a near 100% scheduler rate utilization. The maximum burst size is programmed in registers [UECRI/DECRI](#) on page 7-312.*

*Thus, overwriting bit field Init(9:0) with 0 during operation may invalidate some stored cell cycles, only if maximum burst size is programmed >1 for this port.*

*Only saved scheduler cell cycles can get lost; in no way can stored cells be lost or discarded by these operations.*

*To minimize even this small impact, value Init(9:0) can be read and written back with the new UTOPIA port number.*

*Note: Recommendation for changing the UTOPIA port number or scheduler rate during operation:*

*Disable specific scheduler by read-modify-write operation to corresponding bit in registers [USCEN0/DSCEN0... USCEN7/DSCEN7](#).*

*Modify scheduler specific UTOPIA port number and rates via [Table 10 "Scheduler Configuration Table Integer Transfer Registers" on Page 306](#), registers [USCTI/DSCTI](#) and [Table 11 "Scheduler Configuration Table Fractional Transfer Registers" on Page 316](#), registers [USCTFT/DSCTFT](#).*

*Enable specific scheduler by read-modify-write operation to corresponding bit in registers [USCEN0/DSCEN0... USCEN7/DSCEN7](#).*

**Register 79 UECRI/DECRI**

**Upstream/Downstream Empty Cycle Rate Integer Part Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UECRI A2<sub>H</sub> DECRI BA<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration

Bit	15	14	13	12	11	10	9	8
	MaxBurstS(3:0)				Unused(1:0)		ECIntRate(9:8)	
Bit	7	6	5	4	3	2	1	0
	ECIntRate(7:0)							

**MaxBurstS(3:0) Maximum Burst size for a Scheduler Block**  
Refer to [Section 4.2.2.2 “Programming the Scheduler Block Rates” on Page 138](#)

**ECIntRate(9:0) Integer part of Empty Cycle Rate**  
The empty cycles are required by internal logic to perform the refresh cycles of the SDRAMs.  
Minimum value is 10<sub>H</sub> and should be programmed during configuration.

Refer to [Section 4.2.2.4 “Programming the SDRAM Refresh Empty Cell Cycles” on Page 141](#) for the calculation of ECIntRate and ECFracRate



**Register 80 UECRF/DECRF**


**Upstream/Downstream Empty Cycle Rate Fractional Part Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UECRF A3<sub>H</sub>      DECRF BB<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**ECFracRate(7:0) Fractional part of Empty Cycle Rate**


The empty cycles are required by internal logic to perform the refresh cycles of the SDRAMs.

Recommended value is 00<sub>H</sub> and should be programmed during configuration.

Refer to [Section 4.2.2.4 “Programming the SDRAM Refresh Empty Cell Cycles”](#) on [Page 141](#) for the calculation of ECIntRate and ECFracRate

**Register 81 UCRTQ/DCRTQ**  
**Upstream/Downstream Common Real Time Queue UTOPIA Port**  
**Select Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UCRTQ A4<sub>H</sub> DCRTQ BC<sub>H</sub>**  
 Typical Usage: Written by CPU for global Scheduler configuration



**CrtqUTOPIA(5:0)** Common Real Time Queue UTOPIA Port Number.  
 Specifies one of the 48 UTOPIA ports to which the common real time queue is assigned. Only values in the range 0..47<sub>D</sub> are valid.


**Register 82 USCTFM/DSCTFM**  
**Upstream/Downstream SCTF Mask Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCTFM      A5<sub>H</sub>                  DSCTFM      BD<sub>H</sub>**

Typical Usage:      Written by CPU to control internal table Read/Write access



**USCTFM(15:0)      Upstream SCTF Mask Register**

**DSCTFM(15:0)      Downstream SCTF Mask Register**

USCTFM and DSCTFM control the Read or Write access from the respective transfer registers to the internal tables on a per-bit selection basis. The mask registers correspond to the respective transfer registers (USCTFT, DSCTFT):

- 0      The dedicated bit of the transfer register is *not* overwritten by the corresponding table entry bit during Read, but overwrites the table entry bit during the Write. This is a Write access to the internal table entry.
- 1      The dedicated bit of the transfer register is overwritten by the corresponding table entry bit during Read and is written back to the table entry bit during Write. This is a Read access to the internal table entry.

**Internal Table 11: Scheduler Configuration Table Fractional Transfer Registers**

The Scheduler Configuration Table Fractional Transfer Registers are used to access the internal Upstream/Downstream Scheduler Configuration Tables Fractional Part (SCTF) containing 128 entries each. [Table 7-26](#) and [Table 7-27](#) summarize the registers.

**Table 7-26 Registers SCTF Upstream Table Access**

15	0		
SCTF RAM Entry (Upstream)		RAM Select:	
15	0		15
USCTFT			MAR=17 <sub>H</sub>
		Entry Select:	
15	0		15
USCTFM			WAR (0..127 <sub>D</sub> )

**Table 7-27 Registers SCTF Downstream Table Access**

15	0		
SCTF RAM Entry (Downstream)		RAM Select:	
15	0		15
DSCTFT			MAR=1F <sub>H</sub>
		Entry Select:	
15	0		15
DSCTFM			WAR (0..127 <sub>D</sub> )

SCTFU and SCTFD are transfer registers for one 16-bit SCTF upstream/downstream table entry. The upstream and downstream Scheduler Blocks use different tables (internal RAM) addressed via the [MAR](#). The Scheduler Block number representing the table entry which needs to be read or written must be written to the [WAR](#) (Word Address Register). The dedicated SCTFU/D table entry is read into the SCTFU/D registers or modified by the SCTFU/D register value with a write mechanism. The associated mask registers, SMSKU and SMSKD, allow a bit-wise Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated SCTFU/D register bit will be overwritten by the respective SCTFU/D table entry bit value. In case of Write operation, the dedicated SCTFU/D register bit will modify the value of the respective SCTFU/D table entry bit.

**Register Description**

The Read or Write process is controlled by the **MAR** (Memory Address Register). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the SCTF Upstream table, bit field MAR(4:0) must be set to 17<sub>H</sub> and 1F<sub>H</sub> for the SCTF Downstream table respectively. Bit 5 of MAR starts the transfer and is automatically cleared after execution.

**Table 7-28 WAR Register Mapping for SCTFU/SCTFD Table access**

Bit	15	14	13	12	11	10	9	8
	Unused(9:2)							
Bit	7	6	5	4	3	2	1	0
	unused	SchedSel(6:0)						

**SchedSel(6:0)** Selects one of the 128 core specific Scheduler Blocks.


**Register 83 USCTFT/DSCTFT**  
**Upstream/Downstream SCTF Transfer Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCTFT A6<sub>H</sub> DSCTFT BE<sub>H</sub>**

Typical Usage: Written and Read by CPU to maintain the SCTF tables



**Init(7:0) Scheduler Block Initialization Value**  
This bit field must be written to 00<sub>H</sub> at the time of Scheduler configuration/initialization and should not be written during normal operation.

**FracRate(7:0) Fractional Rate**  
This value determines the fractional part of the Scheduler Block output rate. Refer to [Section 4.2.2.2 “Programming the Scheduler Block Rates” on Page 138](#) for the calculation of FracRate

*Note: Recommendation for changing the UTOPIA port number or scheduler rate during operation:*

*Disable specific scheduler by read-modify-write operation to corresponding bit in registers [USCEN0/DSCEN0... USCEN7/DSCEN7](#).*

*Modify scheduler specific UTOPIA port number and rates via [Table 10 “Scheduler Configuration Table Integer Transfer Registers” on Page 306](#), registers [USCTI/DSCTI](#) and [Table 11 “Scheduler Configuration Table Fractional Transfer Registers” on Page 316](#), registers [USCTFT/DSCTFT](#).*

*Enable specific scheduler by read-modify-write operation to corresponding bit in registers [USCEN0/DSCEN0... USCEN7/DSCEN7](#).*

## 7.2.22 Scheduler Block Enable Registers

### Register 84 USCEN0/DSCEN0


#### Upstream/Downstream Scheduler Block Enable 0 Registers

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN0 A8<sub>H</sub> DSCEN0 C0<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



#### **SchedEn(15:0) Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (15..0):

- |   |                          |
|---|--------------------------|
| 1 | Scheduler Block enabled  |
| 0 | Scheduler Block disabled |

**Register 85 USCEN1/DSCEN1**


**Upstream/Downstream Scheduler Block Enable 1 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN0 A9<sub>H</sub> DSCEN0 C1<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**SchedEn(31:16) Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (31..16):

- 1 Scheduler Block enabled
- 0 Scheduler Block disabled




**Register 86 USCEN2/DSCEN2**  
**Upstream/Downstream Scheduler Block Enable 2 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN2 AA<sub>H</sub> DSCEN2 C2<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**SchedEn(47:32) Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (47..32):

- 1 Scheduler Block enabled
- 0 Scheduler Block disabled

**Register 87 USCEN3/DSCEN3**


**Upstream/Downstream Scheduler Block Enable 3 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN3 AB<sub>H</sub> DSCEN3 C3<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**SchedEn(63:48) Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (63..48):

- 1 Scheduler Block enabled
- 0 Scheduler Block disabled


**Register 88 USCEN4/DSCEN4**  
**Upstream/Downstream Scheduler Block Enable 4 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN4 AC<sub>H</sub> DSCEN4 C4<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**SchedEn(79:64) Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (79..64):

- 1 Scheduler Block enabled
- 0 Scheduler Block disabled


**Register 89 USCEN5/DSCEN5**  
**Upstream/Downstream Scheduler Block Enable 5 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN5 AD<sub>H</sub> DSCEN5 C5<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**SchedEn(95:80) Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (95..80):

- 1 Scheduler Block enabled
- 0 Scheduler Block disabled


**Register 90 USCEN6/DSCEN6**  
**Upstream/Downstream Scheduler Block Enable 6 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN6 AE<sub>H</sub> DSCEN6 C6<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



**SchedEn  
(111:96)**

**Scheduler Block Enable**

Each bit position enables/disables the respective Scheduler Block (111..96):

- 1 Scheduler Block enabled
- 0 Scheduler Block disabled


**Register 91 USCEN7/DSCEN7**  
**Upstream/Downstream Scheduler Block Enable 7 Registers**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **USCEN7 AF<sub>H</sub> DSCEN7 C7<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration



<b>SchedEn (127:112)</b>	<b>Scheduler Block Enable</b> Each bit position enables/disables the respective Scheduler Block (127..112):
	1 Scheduler Block enabled
	0 Scheduler Block disabled

### 7.2.23 Common Real Time Queue Rate Registers

#### Register 92 UCRTRI/DCRTRI


##### Upstream/Downstream CRT Rate Integer Registers

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UCRTRI B0<sub>H</sub> DCRTRI C8<sub>H</sub>**

Typical Usage: Written by CPU for global Scheduler configuration




#### CRTIntRate(9:0) Integer part of CRT Queue Rate

Refer to [Section 4.2.2.3 “Programming the Common Real-Time Bypass”](#) on [Page 141](#) for the calculation of CRTIntRate and CRTFracRate

**Register 93 UCRTRF/DCRTRF**  
**Upstream/Downstream CRT Rate Fractional Registers**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UCRTRF B1<sub>H</sub> DCRTRF C9<sub>H</sub>**  
 Typical Usage: Written and Read by CPU



**Init(7:0) Scheduler Initialization Value**  
 This bit field must be written to 00<sub>H</sub> at the time of Scheduler configuration/initialization and should not be written during normal operation.

**CRTFracRate (7:0) CRT Fractional Rate**  
 This value determines the fractional part of the CRT Queue output rate. Refer to [Section 4.2.2.3 "Programming the Common Real-Time Bypass" on Page 141](#) for the calculation of CRTIntRate and CRTFracRate



## 7.2.24 AVT Table Registers


### Internal Table 12: ABR/VBR Table Transfer Registers

ABR/VBR Context Table Transfer Registers are used to access the ABR/VBR Context Table (AVT).

Refer to [Chapter 3.6.9.1](#) for the RAM organization of this table.

[Table 7-29](#) provides an overview of the registers involved. Each AVT word consists of 32 bits.

**Table 7-29 Registers for AVT Table Access**



ERCT0 and ERCT1 are the transfer registers for one 32-bit word of the AVT table. Access to words are controlled by mask registers ERCM0/ERCM1.

The context entry number and the corresponding word number representing the table word which needs to be read or written must be written to the Word Address Register (WAR). The dedicated AVT table word is read into the ERCT0/ERCT1 transfer registers or modified by the ERCT0/ERCT1 transfer register values with a write mechanism. The associated mask registers ERCM0 and ERCM1 allow a bit-wise Write operation (0 - unmasked, 1 - masked). In case of Read operation, the dedicated ERCT0/ERCT1 register bit will be overwritten by the respective AVT table entry bit value. In case of Write operation, the dedicated ERCT0/ERCT1 register bit will modify the respective AVT table entry bit value.

The Read or Write process is controlled by the Memory Address Register (MAR). The 5 LSBs (= Bit 4..0) of the MAR register select the memory/table that will be accessed; to select the AVT table bit field MAR(4:0) must be set to 08<sub>H</sub>.

**Register Description**

Bit 5 of MAR starts the transfer and is cleared automatically after execution.

**Table 7-30 WAR Register Mapping for AVT Table Access**


Bit	15	14	13	12	11	10	9	8
	Unused(2:0)			EntrySel(9:5)				
Bit	7	6	5	4	3	2	1	0
	EntrySel(4:0)				WordSel(2:0)			

**EntrySel(9:0)** Selects one of the 1024 AVT table context entries.

**WordSel(2:0)** Selects one of the 8 DWORDS per AVT table context entries.

**Register 94 ERCT0**  
**AVT Table Transfer Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCT0 CA<sub>H</sub>**  
 Typical Usage: Written and Read by CPU




**Word0(15:0)** The meaning of the 'Word0' depends on:

- The selected context entry word (WordSel(2:0))
- The mode of this particular context entry

For detailed description of the context entry fields refer to **“AVT Context RAM Organization and Addressing” on Page 118 f.**

**Register 95 ERCT1**  
**AVT Table Transfer Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCT1      CB<sub>H</sub>**  
 Typical Usage:      Written and Read by CPU




**Word1(31:16)**      The meaning of the 'Word1' depends on

- The selected context entry word (WordSel(2:0))
- The mode of this particular context entry

For detailed description of the context entry fields refer to **“AVT Context RAM Organization and Addressing” on Page 118 f.**

**Register 96 ERCM0**  
**AVT Table Access Mask Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCM0 CC<sub>H</sub>**  
 Typical Usage: Written by CPU to control internal table Read/Write access




**ERCM0(15:0) ERC Mask Register 0**

ERC Mask Registers 0..1 control the Write access from transfer registers ERCT0 and ERCT1 to the internal AVT table on a per-bit selection basis. The mask register bit positions correspond to the respective transfer registers ERCT0 and ERCT1:

- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

**Register 97 ERCM1**  
**AVT Table Access Mask Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCM0 CD<sub>H</sub>**  
 Typical Usage: Written by CPU to control internal table Read/Write access



**ERCM1(31:16) ERC Mask Register 1**

ERC Mask Registers 0..1 control the Write access from transfer registers ERCT0 and ERCT1 to the internal AVT table on a per-bit selection basis. The mask register bit positions correspond to the respective transfer registers ERCT0 and ERCT1:

- 0 The dedicated bit of the transfer register overwrites the table entry during Write.  
Does not affect Read access.
- 1 The dedicated bit of the transfer register does *not* overwrite the table entry during Write.  
Does not affect Read access.

**Register 98 ERCMB0**  
**ERC MailBox Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCMB0 D2<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	INT	ACK	Command(13:8)					
Bit	7	6	5	4	3	2	1	0
	Command(7:0)							

**INT** Interrupt request for the ERC unit. Set together with a Command ID to start the request.  
 In case of write access the address and the data word must be written to the corresponding registers [ERCMB1](#) and [ERCMB2](#) before.  
 In case of read access the address has to be written only. The data word can be read from [ERCMB2](#) if the ACK flag has been set.


**ACK** Acknowledge Flag  
 0 Operation has not been finished yet  
 1 Indicates that the operation has been finished

**Command(13:0)** Command ID of the operation. Refer to [Section 3.5.2.3 “ERC Mailbox” on Page 113](#).

*Note: The register is set to 4000<sub>H</sub> immediately after firmware initialization if the external EEPROM is connected.*

**Register 99 ERCMB1**  
**ERC MailBox Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCMB1 D3<sub>H</sub>**  
 Typical Usage: Written and Read by CPU




**Address(15:0)** Address corresponding to a read or write command

*Note: The register is set to 6A6A<sub>H</sub> immediately after firmware initialization if the external EEPROM is connected.*



**Register 100 ERCMB2**  
**ERC MailBox Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCMB2 D4<sub>H</sub>**  
 Typical Usage: Written and Read by CPU



**Data(15:0)** Data to be written to the ERC unit or data that was read from the ERC unit.

*Note: The register is set to 6A6A<sub>H</sub> immediately after firmware initialization if the external EEPROM is connected.*

**Register 101 ERCCONF0**  
**ERC Configuration Register 0**

CPU Accessibility: **Read/Write**  
 Reset Value: **0061<sub>H</sub>**  
 Offset Address: **ERCCONF0 D5<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	FWDF	unused(3:0)				QIDFR	QIDFE	SCAND
Bit	7	6	5	4	3	2	1	0
	unused	SCANP(6:0)						

**FWDF Firmware Download Finished**

0 not ready  
 1 ready

*Note: "Ready" does not indicate that the firmware download was successful but that the download process has finished. Check the Mailbox registers [ERCMB0](#), [ERCMB1](#) and [ERCMB2](#) instead.*

**QIDFR QID Filter RM FIFO**

By default only RM cells of ABR connections that are set up in the AVT Context RAM are forwarded to the RM FIFO.

0 QID Filter for RM FIFO enabled  
 1 QID Filter for RM FIFO disabled (Bypass)

**QIDFE QID Filter EMIT FIFO**

By default only cells of ABR connections that are set up in the AVT Context RAM are forwarded to the RM FIFO.

0 QID Filter for EMIT FIFO enabled  
 1 QID Filter for EMIT FIFO disabled (Bypass)




---

Register Description

<b>SCAND</b>	<b>SCAN Disable</b>
	0      SCAN enabled
	1      SCAN disabled
<b>SCANP(6:0)</b>	<b>SCAN Period</b>
	Refer to <b>“Scan Unit” on Page 114</b> for a description

**Register 102 ERCCONF1**  
**ERC Configuration Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **000A<sub>H</sub>**  
 Offset Address: **ERCCONF1 D6<sub>H</sub>**  
 Typical Usage: Written and Read by CPU



**TRM(3:0)**      **ABR TRM Parameter**  
 Global for all connections.  
 The bit field TRM(3:0) determines a 10 ms counter:  
 Tout:= TRM(3:0) \* 10ms  
 The default (reset) value is **000A<sub>H</sub>** which equals 100 ms.

## 7.2.25 PLL Control Registers

### Register 103 PLL1CONF

#### PLL1 Configuration Register

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **PLL1CONF D7<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	Locked1	Div2En1	Div1En1	BYPAS S1	PU1	RES1	M1(3:2)	
Bit	7	6	5	4	3	2	1	0
	M1(1:0)		N1(5:0)					

DPLL1 generates a clock that is an alternative clock source for the ABM-P. The DPLL1 is fed by clock input signal 'SYSCLK'. Signal 'SYSCLKSEL' determines the clock source of the ABM-P. [Section 3.2.7 "Clocking System" on Page 55](#) provides the details.

**Locked1**      **DPLL1 Locked**  
 (read only)  
 1      DPLL1 is locked based on the current parameter setting.  
 0      DPLL1 is in transient status.

**Div2En1**      **Division Factor 2 Enable for DPLL1**  
 This bit enables one of the additional divide by 2 factors subsequent to the DPLL1 output.  
 0      Division Factor 2 disabled.  
 1      Division Factor 2 enabled.

**Div1En1**      **Division Factor 1 Enable for DPLL1**  
 This bit enables one of the additional divide by 2 factors subsequent to the DPLL1 output.

Register Description

	0	Division Factor 1 disabled.
	1	Division Factor 1 enabled.
<b>BYPASS1</b>		<b>DPLL1 Bypass</b> Switching between bypass and non-bypass mode is glitch-free with respect to the internal clock output. The DPLL1 is bypassed after power-on reset and can be switched to non-bypass mode by software during device configuration.
	0	DPLL1 is internally bypassed, i.e. DPLL1 clock input connected to DPLL1 clock output
	1	DPLL1 is not bypassed, i.e. DPLL1 clock output is generated by DPLL1 depending on its parameter configuration
<b>PU1</b>		<b>Power Up DPLL1</b>
	0	DPLL1 is in power-down mode. (The analog part of DPLL1 is switched-off for power saving.)
	1	DPLL1 is in power on (operational) mode.
<b>RES1</b>		<b>Reset DPLL1</b>
	0	DPLL1 is in operational mode.
	1	DPLL1 is in reset mode. <i>Note: The result of reset mode is identical to bypass mode, but switching between reset and non-reset status is not glitch-free with respect to the internal clock output.</i>
<b>M1(3:0)</b>		<b>M1 Parameter of DPLL1</b> This parameter determines the first stage division factor of DPLL1. The effective division factor is (M1 + 1) in the range 1..16.
<b>N1(5:0)</b>		<b>N1 Parameter of DPLL1</b> This parameter determines the second stage multiplication factor of DPLL1. The effective multiplication factor is (N1 + 1) in the range 1..64.

**Register 104 PLL2CONF  
PLL2 Configuration Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **PLL2CONF D8<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	Locked2	unused	Dev1En 2	BYPAS S2	PU2	RES2	M2(3:2)	
Bit	7	6	5	4	3	2	1	0
	M2(1:0)		N2(5:0)					

DPLL2 generates a clock that is an alternative clock source for the ERC unit. The DPLL2 is fed by clock input signal 'SYSCLK'. Signal 'IOPCLKSEL' determines the clock source of the ERC unit. [Section 3.2.7 "Clocking System" on Page 55](#) provides the details.

<b>Locked2</b>	<b>DPLL2 Locked</b> (read only)
1	DPLL2 is locked based on the current parameter setting.
0	DPLL2 is in transient status.

<b>Div1En2</b>	<b>Division Factor 1 Enable for DPLL2</b>
	This bit enables the additional divide by 2 factor subsequent to the DPLL2 output.
0	Division Factor 1 disabled.
1	Division Factor 1 enabled.

<b>BYPASS2</b>	<p><b>DPLL2 Bypass</b></p> <p>Switching between bypass and non-bypass mode is glitch-free with respect to the internal clock output. The DPLL2 is bypassed after power-on reset and can be switched to non-bypass mode by software during device configuration.</p> <p>0 DPLL2 is internally bypassed, i.e. DPLL2 clock input connected to DPLL2 clock output</p> <p>1 DPLL2 is not bypassed, i.e. DPLL2 clock output is generated by DPLL2 depending on its parameter configuration</p>
<b>PU2</b>	<p><b>Power Up DPLL2</b></p> <p>0 DPLL2 is in power-down mode. (The analog part of DPLL2 is switched-off for power saving.)</p> <p>1 DPLL2 is in power on (operational) mode.</p>
<b>RES2</b>	<p><b>Reset DPLL2</b></p> <p>0 DPLL2 is in operational mode.</p> <p>1 DPLL2 is in reset mode.</p> <p><i>Note: The result of Reset Mode is identical to bypass mode, but switching between reset and non-reset status is not glitch-free with respect to the internal clock output.</i></p>
<b>M2(3:0)</b>	<p><b>M2 Parameter of DPLL2</b></p> <p>This parameter determines the first stage division factor of DPLL2. The effective division factor is (M2 + 1) in the range 1..16.</p>
<b>N2(5:0)</b>	<p><b>N2 Parameter of DPLL2</b></p> <p>This parameter determines the second stage multiplication factor of DPLL2. The effective multiplication factor is (N2 + 1) in the range 1..64.</p>



**Register 105 PLLTST  
PLL Test Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **PLLTST D9<sub>H</sub>**  
 Typical Usage: **Written and Read by CPU**

Bit	15	14	13	12	11	10	9	8
	Reserved(15:8)							
Bit	7	6	5	4	3	2	1	0
	Reserved(7:0)							

## 7.2.26 ERC Register Access Control

### Register 106 ERCRAC

#### ERC Register Access Control Register

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **ERCRAC DA<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	unused(8:1)							
Bit	7	6	5	4	3	2	1	0
	unused(0)	ERC ACF	IUPAC	ERC RTAC	IERC RAC	UP RTAC	ERC RD	ERC WR

**ERCWR** ERC Write Access  
Do not write during normal operation.

**ERCRD** ERC Read Access  
Do not write during normal operation.

**UPRTAC** uP RAM Transfer Access  
Do not write during normal operation.

**IERCRAC** Inhibit ERC Register Access  
 0 Allow the ERC unit the access to ABM-P registers.  
 1 Inhibit the ERC unit to access ABM-P registers.  
*Note: It is recommended to lock the IOP access as short as possible.*

**ERCRTAC** ERC RAM Transfer Access



---

**Register Description**

Do not write during normal operation.

**IUPRAC**      Inhibit UP Register Access  
Do not write during normal operation.

**ERCACF**      ERC Access Free  
Do not write during normal operation.

**Register 107 ERCRAM**


**ERC Register Access Mask Register**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **ERCRAM DB<sub>H</sub>**

Typical Usage: Written and Read by CPU



**MASK(15:0)** The ERCRAM Mask Register controls the Write access to the register [ERCRAC](#).


- 0 The dedicated bit of the [ERCRAC](#) register is overwritten during Write access
- 1 The dedicated bit of the [ERCRAC](#) register is not overwritten during Write access.

In order not to overwrite reserved flags it is recommended to set the ERCRAM Mask Register to FFF7<sub>H</sub>.

## 7.2.27 External RAM Test Registers

### Register 108 EXTRAMD0 External RAM Test Data Register 0

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **EXTRAMD0 DC<sub>H</sub>**  
 Typical Usage: Written and Read by CPU




**Data(31:16)** Upper part of data to be read from or to be written to the external RAM

*Note: Only the lower 20 bits of each Cell Pointer RAM entry can be accessed. Read access to the upper bits will always return 0.*

**Register 109 EXTRAMD1**  
**External RAM Test Data Register 1**


CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **EXTRAMD1 DD<sub>H</sub>**  
 Typical Usage: Written and Read by CPU



**Data(15:0)** Lower part of data to be read from or to be written to the external RAM

**Register 110 EXTRAMA0**  
**External RAM Test Address Register Low**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **EXTRAMA0 DE<sub>H</sub>**  
 Typical Usage: Written and Read by CPU




**Address(15:0)** Lower bits of the Address  
 The Address field selects an entry within the external RAM, selected by the [EXTRAMC](#) register.  
 The range depends on the size of the selected external RAM (see [Table 7-31](#)).

**Table 7-31 Extended RAM Address Range for Test Access**

RAM Type	Size	Address Range
SSRAM	64 k x 32 bit	0 .. 65536
SSRAM	128 k x 32 bit	0 .. 131072
SSRAM	256 k x 32 bit	0 .. 262144
SSRAM	512 k x 32 bit	0 .. 524288
SDRAM	32 Mbit per core	0 .. 1048576
SDRAM	64 Mbit per core	0 .. 2097152
SDRAM	128 Mbit per core	0 .. 4194304

**Register 111 EXTRAMA1**  
**External RAM Test Address Register High**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **EXTRAMA0 DF<sub>H</sub>**  
 Typical Usage: Written and Read by CPU




**Address(19:16)** Upper bits of the Address  
 The Address field selects an entry within the external RAM, selected by the [EXTRAMC](#) register.  
 The range depends on the size of the selected external RAM (see [Table 7-31](#)).



**Register 112 EXTRAMC**  
**External RAM Test Command Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **EXTRAMA0 E0<sub>H</sub>**  
 Typical Usage: Written and Read by CPU



Setting a command bit starts the Read or Write procedure from/to the selected external RAM. The corresponding bit is automatically cleared after completion of the Read/Write procedure.

The address to be read or to be written is provided in registers [EXTRAMA0](#) and [EXTRAMA1](#). The 32-bit wide data is transferred via registers [EXTRAMD0](#) and [EXTRAMD1](#).

*Note: Access to external RAM is only allowed before first cell flow.*



- CSRDW** Cell Storage RAM downstream write
- CSRDR** Cell Storage RAM downstream read
- CSR UW** Cell Storage RAM upstream write
- CSRUR** Cell Storage RAM upstream read
- CPRW** Cell Pointer RAM write
- CPRR** Cell Pointer RAM read

**7.2.28 ABM-P Version Code Registers**

**Register 113 VERL**

**Version Number Low Register**

CPU Accessibility: **Read**  
 Reset Value: **F083<sub>H</sub>**  
 Offset Address: **VERL E1<sub>H</sub>**  
 Typical Usage: Read by CPU to determine device version number



**VERL(15..0) F083<sub>H</sub>**

**Register 114 VERH**


**Version Number High Register**

CPU Accessibility: **Read**

Reset Value: **1007<sub>H</sub>**

Offset Address: **VERH           E2<sub>H</sub>**

Typical Usage:    Read by CPU to determine device version number



**VERH(15..0)      1007<sub>H</sub>**

## 7.2.29 Interrupt Status/Mask Registers

### Register 115 ISRU

#### Interrupt Status Register Upstream

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **ISRU E3<sub>H</sub>**

Typical Usage: Read by CPU to evaluate interrupt events related to the upstream core. Interrupt indications must be cleared by writing a 1 to the respective bit locations; writing a 0 has no effect;

Bit	15	14	13	12	11	10	9	8
	Unused	BCFGE	QIDINV	BUFFER 1	LCI INVAL	PARITY ER	SOCER	BUFFER 2
Bit	7	6	5	4	3	2	1	0
	BUFFER 3	CDVOV	MUXOV	AAL5 COL	RMCER	BIP8ER	BUFFER 4	VPRM ER

**BCFGE** Buffer Configuration Error upstream

**QIDINV** This interrupt is generated if the ABM-P tries to write a cell into a disabled queue. The cell is discarded in this case. (Typically occurs on queue configuration errors.)

**BUFFER1** Unexpected buffer error number 1. Should never occur in normal operation. Immediate reset of the chip recommended.

**LCIINVAL** Error when performing the internal address reduction  
The cell is discarded.

**PARITYER** Parity error at UTOPIA Receive Upstream (PHY) Interface detected.

**Register Description**

<b>SOCER</b>	Start of Cell Error at UTOPIA Receive Upstream (PHY) Interface detected.
<b>BUFER2</b>	Unexpected Buffer Error number 2. Should never occur in normal operation. Immediate reset of the chip is recommended.
<b>BUFER3</b>	Unexpected Buffer Error number 3. Should never occur in normal operation. Immediate reset of the chip is recommended.
<b>CDVOV</b>	The maximum upstream CDV value for shaped connections given in CDVU register has been exceeded. This interrupt is a notification only; that is, no cells are discarded due to this event.
<b>MUXOV</b>	Indicates that a Scheduler Block lost a serving time slot. (Can indicate a static backpressure on one port). The 'MUXOV' interrupt is generated when the number of lost serving time slots exceeds the number specified in bit field MaxBurstS(3:0) (see register <a href="#">UECRI/DECRI</a> ). No further action is required upon this interrupt.
<b>AAL5COL</b>	Indicates that an interrupt event occurred in the upstream AAL5 unit. The interrupt reason must be read from the AAL5 status register " <a href="#">UA5SARS/DA5SARS</a> " on <a href="#">Page 210</a> (upstream).
<b>RM CER</b>	RM Cell received with corrupted CRC-10.
<b>BIP8ER</b>	BIP-8 error detected when reading a cell from the upstream external SDRAM. BIP-8 protects the cell header of each cell. The cell is discarded. One single sporadic event can be ignored. Hardware should be taken out of service when the error rate exceeds $10^{-10}$ .

---

**Register Description**

**BUFFER4** Unexpected Buffer Error number 4. Should never occur in normal operation. Immediate reset of the chip recommended.  
For consistency check the ABM-P stores the queue ID with each cell written to the respective queue within the cell storage RAM. When reading a cell from the cell storage RAM, the queue ID is compared to the stored queue ID.  
A queue ID mismatch would indicate a global buffering/pointer problem.

**VPRMER** VP RM Cell received erroneously when traffic class is configured for VCs using bit ABRvp in Register [TCT3](#)  
(see **Register 42: TCT3**).

*Note: Several mechanisms are implemented in the ABM-P to check for consistency of pointer operation and internal/external memory control. The interrupt events **BUFFER1..BUFFER4** indicate errors detected by these mechanisms. It is recommended that these interrupts be classified as "fatal device errors."*

**Register 116 ISRD**

**Interrupt Status Register Downstream**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **ISRD            E4<sub>H</sub>**

Typical Usage: Read by CPU to evaluate interrupt events related to the downstream core. Interrupt indications must be cleared by writing a 1 to the respective bit locations; writing a 0 has no effect;

Bit	15	14	13	12	11	10	9	8
	Unused	BCFGE	QIDINV	BUFER 1	LCI INVAL	PARITY ER	SOCER	BUFER 2
Bit	7	6	5	4	3	2	1	0
	BUFER 3	CDVOV	MUXOV	AAL5 COL	RM CER	BIP8ER	BUFER 4	VCRM ER

**BCFGE**            Buffer Configuration Error downstream

**QIDINV**            This interrupt is generated if the ABM-P tries to Write a cell into a disabled queue. The cell is discarded.  
(Typically occurs on queue configuration errors.)

**BUFER1**            Unexpected Buffer Error number 1. Should never occur in normal operation. Immediate reset of the chip is recommended.

**LCIINVAL**            Error when performing the internal address reduction  
The cell is discarded.

**PARITYER**            Parity Error at UTOPIA Receive Downstream (PHY) Interface detected.

**SOCER**            Start of Cell Error at UTOPIA Receive Downstream (PHY) Interface detected.

**Register Description**

<b>BUFER2</b>	Unexpected Buffer Error number 2. Should never occur in normal operation. Immediate reset of the chip is recommended.
<b>BUFER3</b>	Unexpected Buffer Error number 3. Should never occur in normal operation. Immediate reset of the chip recommended.
<b>CDVOV</b>	The maximum downstream CDV value for shaped connections given in CDVU register has been exceeded. This interrupt is a notification only; that is, no cells are discarded due to this event.
<b>MUXOV</b>	Indicates that a Scheduler Block lost a serving time slot. (Can indicate a static backpressure on one port). The 'MUXOV' interrupt is generated when the number of lost serving time slots exceeds the number specified in bit field MaxBurstS(3:0) (see register <a href="#">UECRI/DECRI</a> ). No further action is required upon this interrupt.
<b>AAL5COL</b>	Indicates that an interrupt event occurred in the downstream AAL5 unit. The interrupt reason must be read from the AAL5 status register " <a href="#">UA5SARS/DA5SARS</a> " on <a href="#">Page 210</a> (downstream).
<b>RM CER</b>	RM cell received with corrupted CRC-10.
<b>BIP8ER</b>	BIP-8 error detected when reading a cell from the downstream external SDRAM. BIP-8 protects the cell header of each cell. The cell is discarded. One single sporadic event can be ignored. Hardware should be taken out of service when the error rate exceeds $10^{-10}$ .



---

**Register Description**

<b>BUFER4</b>	Unexpected Buffer Error number 4. Should never occur in normal operation. Immediate reset of the chip is recommended. For consistency check the ABM-P stores the queue ID with each cell written to the respective queue within the cell storage RAM. When reading a cell from the cell storage RAM, the queue ID is compared to the stored queue ID. A queue ID mismatch would indicate a global buffering/pointer problem.
<b>VPRMER</b>	VP RM Cell received erroneously, when traffic class is configured for VCs using bit ABRvp in Register <a href="#">TCT3</a> (see <b>Register 42: TCT3</b> ).

*Note: Several mechanisms are implemented in the ABM-P to check for consistency of pointer operation and internal/external memory control. The interrupt events BUFER1..BUFER4 indicate errors detected by these mechanisms.  
It is recommended that these interrupts be classified as "fatal device errors."*

**Register 117 ISRC**

**Interrupt Status Register Common**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **ISRC E5<sub>H</sub>**

Typical Usage: Read by CPU to evaluate interrupt events related to both cores. Interrupt indications must be cleared by writing a 1 to the respective bit locations; writing a 0 has no effect;

Bit	15	14	13	12	11	10	9	8
	Unused(10:3)							
Bit	7	6	5	4	3	2	1	0
	Unused(2:0)			RAMER	DDQRD	UDQRD	DQ VCMGD	UQ VCMGD

**RAMER** Configuration of common Cell Pointer RAM has been changed after cells have been received (see Register [MODE1](#), bit field CPR).

**DDQRD** **Downstream Dummy Queue Relogged/Deactivated**  
This interrupt confirms the dummy queue operation being activated and deactivated. (see Register [44: QCT1](#))

**UDQRD** **Upstream Dummy Queue Relogged/Deactivated**  
This interrupt confirms the dummy queue operation being activated and deactivated. (see Register [44: QCT1](#))

**DQVCMGD** **Downstream Queue VC-Merge Group Deactivated**  
This interrupt confirms the VC-Merge group being deactivated.

**UQVCMGD** **Upstream Queue VC-Merge Group Deactivated**  
This interrupt confirms the VC-Merge group being deactivated.

**Register 118 IMRU**


**Interrupt Mask Register Upstream**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **IMRU E6<sub>H</sub>**

Typical Usage: Written by CPU to control interrupt signal effective events



**IMRU(15:0)**

**Interrupt Mask Upstream**

Each bit controls whether the corresponding interrupt indication in register ISRU (same bit location) activates the interrupt signal:

- 1      Interrupt indication masked.  
The interrupt signal is not activated upon this event.
- 0      Interrupt indication unmasked.  
The interrupt signal is activated upon this event.

**Register 119 IMRD**


**Interrupt Mask Register Downstream**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **IMRD E7<sub>H</sub>**

Typical Usage: Written by CPU to control interrupt signal effective events



**IMRD(15:0)**

**Interrupt Mask Downstream**

Each bit controls whether the corresponding interrupt indication in register ISRD (same bit location) activates the interrupt signal:

- 1      Interrupt indication masked.  
         The interrupt signal is not activated upon this event.
- 0      Interrupt indication unmasked.  
         The interrupt signal is activated upon this event.

**Register 120 IMRC**


**Interrupt Mask Register Common**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **IMRC E8<sub>H</sub>**

Typical Usage: Written by CPU to control interrupt signal effective events



**IMRC(15:0)**

**Interrupt Mask Common**

Each bit controls whether the corresponding interrupt indication in register ISRC (same bit location) activates the interrupt signal:

- 1      Interrupt indication masked.  
         The interrupt signal is not activated upon this event.
- 0      Interrupt indication unmasked.  
         The interrupt signal is activated upon this event.

**Register 121 ISRDBA**


**Interrupt Status Register DBA**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **ISRDBA E9<sub>H</sub>**


Typical Usage: Read by CPU to evaluate interrupt events related to both cores. Reset by read.



**DBATC(15:0)** Each bit position indicates that a DBA Threshold Crossing Event occurred in the respective entry *i* of the DBA Threshold Crossing Table (see Register [DTCT](#)).

**Register 122 IMRDBA**  
**Interrupt Mask Register DBA**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **IMRDBA EA<sub>H</sub>**  
 Typical Usage: Written by CPU to control interrupt signal effective events



**IMRDBA(15:0) Interrupt Mask DBA**  
 Each bit controls whether the corresponding interrupt indication in register ISRDBA (same bit location) activates the interrupt signal:

1	Interrupt indication masked. The interrupt signal is not activated upon this event.
0	Interrupt indication unmasked. The interrupt signal is activated upon this event.

### 7.2.30 RAM Select Registers

#### Register 123 MAR

##### Memory Address Register

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **MAR** **EB<sub>H</sub>**

Typical Usage: Written by CPU to address internal RAM/tables for Read or Write operation via transfer registers

Bit	15	14	13	12	11	10	9	8
	Unused(9:2)							
Bit	7	6	5	4	3	2	1	0
	Unused	Start_W	Start_R	MAR(4:0)				

**Start\_W** This command bit starts the Write procedure to the internal RAM/table addressed by bit field MAR(4:0). The specific data transfer and mask registers must be prepared appropriately in advance. This bit is automatically cleared after completion of the Write procedure.

**Start\_R** Simplifies Read access without need to touch the mask registers

#### MAR(4:0)

##### Memory Address

This bit field selects one of the internal RAM/tables for Read or Write operation:

00000	LCI: LCI Table RAM (see page <a href="#">237</a> )
00001	TCT: Traffic Class Table (see page <a href="#">241</a> )
00010	QCT: Queue Configuration Table (see page <a href="#">258</a> )
00011	SBOC: Scheduler Block Occupation Table (see page <a href="#">270</a> )
00101	DTC: DBA Threshold Crossing Table (see page <a href="#">235</a> )
00111	MGT: Merge Group Table (see page <a href="#">277</a> )
01000	QCI: Queue Congestion Indication Table (see page <a href="#">286</a> )



**Register Description**

01010	AVT: ABR/VBR Table (see page <a href="#">329</a> )
10000	QPT1 Upstream: Queue Parameter Table 1 Up (see page <a href="#">296</a> )
10001	QPT2 Upstream: Queue Parameter Table 2 Up (see page <a href="#">300</a> )
11000	QPT1 Downstream: Queue Parameter Table 1 Dn (see page <a href="#">296</a> )
11001	QPT2 Downstream: Queue Parameter Table 2 Dn (see page <a href="#">300</a> )
10111	SCTF Upstream: Scheduler Configuration Table Fractional Part (see page <a href="#">306</a> )
11111	SCTF Downstream: Scheduler Configuration Table Fractional Part (see page <a href="#">316</a> )

*Note: The SCTI Table (Scheduler Configuration Table Integer Part) is addressed via dedicated address registers and thus not listed in bit field MAR(4:0) (see page [308](#)).*

*Note: MAR(4:0) values not listed above are invalid and reserved. It is recommended to not use invalid/reserved values.*

**Register 124 WAR**


**Word Address Register**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **WAR EC<sub>H</sub>**

Typical Usage: Written by CPU to address entries of internal RAM/tables for Read or Write operation via transfer registers.



**WAR(15:0)**

**Word Address**

This bit field selects an entry within the internal RAM/table selected by the [MAR](#) register.

In general, it can address up to 64K entries.

The current range of supported values depends on the size and organization of the selected RAM/table.

Thus, the specific WAR register meaning is listed in the overview part of each internal RAM/table description:

- LCI      LCI Table RAM (see page [237](#))
- TCT      Traffic Class Table (see page [241](#))
- QCT      Queue Configuration Table (see page [270](#))
- SBOC    Scheduler Block Occupation Table (see page [270](#))
- QPTHU   QPT High Word Upstream:  
Queue Parameter Table (see page [296f.](#))
- QPTHD   QPT High Word Downstream:  
Queue Parameter Table (see page [296f.](#))
- QPTLU   QPT Low Word Upstream:  
Queue Parameter Table(see page [296](#))
- QPTLD   QPT Low Word Downstream:  
Queue Parameter Table (see page [296](#))

---

**Register Description**

SCTFU SCTF Upstream:  
Scheduler Configuration Table Fractional Part  
(see page [316](#))

SCTFD SCTF Downstream:  
Scheduler Configuration Table Fractional Part  
(see page [316](#))


*Note: The SCTI Table (Scheduler Configuration Table Integer Part) is addressed via dedicated address registers and, thus, is not listed in the MAR and WAR registers (see page [306](#)).*

### 7.2.31 Global ABM-P Status and Mode Registers

#### Register 125 USTATUS

##### ABM-P UTOPIA Status Register

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **USTATUS ED<sub>H</sub>**  
 Typical Usage: Read by CPU



**DUTFL(6:0) Downstream UTOPIA Receive Buffer Fill Level**  
 This bit field indicates the current number of cells stored in the UTOPIA receive buffers (0..64 cells).

**UUTFL(6:0) Upstream UTOPIA Receive Buffer Fill Level**  
 This bit field indicates the current number of cells stored in the UTOPIA receive buffer (0..64 cells).

**Register 126 MODE1**

**ABM-P Mode 1 Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **MODE1 EE<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	SWRES	ERC SWRES	CPR(1:0)		VC MERGE	INIT RAM	INIT SDRAM	CORE
Bit	7	6	5	4	3	2	1	0
	WGS	BIN	EFCI	BIP8	CRC10	LCItog	LCIMOD(1:0)	

**SWRES**      **Software Reset** (clears automatically after four cycles).  
 This bit is automatically cleared after execution.  
 'SWRES' controls reset of all ABM-P units excluding the ERC unit.

1	Starts internal reset procedure
(0)	self-clearing

**ERCSWRES**      **ERC Software Reset** (not self-clearing).  
 'ERCSWRES' controls reset of the ERC unit.

1	Starts internal reset procedure and keeps the ERC unit in reset state.
0	Releases the ERC unit from reset state to operational state.

**CPR(1:0)**      **Cell Pointer Ram Size configuration**  
 (see also [Table 7-3 "External RAM Sizes" on Page 215](#))

00	256k pointer entries per direction (corresponds to 256k cells in each cell storage RAM)
01	128k pointer entries per direction (corresponds to 128k cells in each cell storage RAM)

**Register Description**

- 10        64k pointer entries per direction  
            (corresponds to 64k cells in each cell storage RAM)
- 11        reserved

*Note: The Cell Pointer RAM Size should be programmed during initialization and should not be changed during operation.*

**VCMerge**

**VC Merge Enable**

This bit enables VC-Merge operation on a global basis. It determines the usage (required width) of the Cell Pointer RAM, since VC-Merge operation requires one additional flag 'EOP Mark' in the CPR.

(see also [Table 5-10 "SSRAM Configuration Examples" on Page 174](#))

- 0        VC-Merge operation disabled.
- 1        VC-Merge operation enabled.

**INITRAM**

**Init RAM**

Start of Initialization of the internal RAM.  
This bit is automatically cleared after execution.

- 1        Starts internal RAM initialization procedure.

*Note: The internal RAM initialization process can be activated only once after hardware reset.*

- (0)     self-clearing

**INITSDRAM**

**Init SDRAM**

Initialization and configuration of the external SDRAM. This bit must be set to 1 after reset (initial pause of at least 200  $\mu$ s is necessary) and is automatically cleared by the ABM-P after configuration of the SDRAM has been executed.

- 1        Starts SDRAM initialization procedure

- (0)     self-clearing

**Register Description**

<b>CORE</b>	<p><b>Downstream Core Disable</b> This bit disables the downstream ABM-P Core, which is necessary in some MiniSwitch configurations (Uni-Directional Mode using one core). It is recommended to set CORE = 0 in Bi-directional operation modes.</p> <p>1      Downstream ABM-P core disabled 0      Downstream ABM-P core enabled</p>
<b>WGS</b>	<p><b>Work Group Switch Mode</b> Selects MiniSwitch (Uni-directional) Mode if set to 1.</p> <p>1      MiniSwitch (Uni-directional) operation mode selected: upstream transmit UTOPIA Interface is disabled; downstream receive UTOPIA Interface is disabled. 0      Normal (Bi-directional) operation mode</p>
<b>BIN</b>	<p>Indicate the usage of the CI/NI mechanism for ABR connections:</p> <p>1      Enables CI/NI feedback 0      CI/NI feedback disabled</p>
<b>EFCI</b>	<p>Indicate the usage of the EFCI mechanism for ABR connections:</p> <p>1      Enables EFCI feedback 0      EFCI feedback disabled</p>
<b>BIP8</b>	<p>Disables discard of cells with BIP-8 header error.</p> <p>1      BIP-8 errored cells are not discarded 0      BIP-8 errored cells are discarded</p>
<b>CRC10</b>	<p>Disables discard of RM cells with defect CRC10.</p> <p>1      CRC10 errored RM cells are not discarded 0      CRC10 errored RM cells are discarded</p>
<b>LCItog</b>	<p>Enables toggling of the LCI(0) bit in outgoing cells in MiniSwitch (uni-directional) mode.</p>

**Register Description**

- 1 LCI bit 0 is toggled in outgoing cells in case of MiniSwitch operation mode selected
- 0 LCI bit 0 remains unchanged

*Note: Does not affect the cell header if Internal Address Reduction is used.*

- LCIMOD(1:0)** Specifies the expected mapping of Local Connection Identifier (LCI) field to cell header:
- 00 LCI(13, 12) = '00', LCI(11:0) mapped to VPI(11:0) field
  - 01 LCI(15:0) mapped to VCI(15:0) field;
  - 10 LCI(15:14) mapped to UDF1(1:0) field;  
LCI(13:12) mapped to UDF1(7:6) field;  
LCI(11:0) mapped to VPI(11:0) field
  - 11 Internal Address reduction mode;  
The LCI is derived from programmable parts of the VPI, VCI and PN bit fields. The derived LCI is used by the ABM-P, but not written to the cell.



**Register 127 MODE2**

**ABM-P Mode 2 Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0800<sub>H</sub>**  
 Offset Address: **MODE EF<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	SD CAW	SDRR	unused	ERCPD	TUTS	DQSC	QS(1:0)	
Bit	7	6	5	4	3	2	1	0
	PNSRC	MNUM(3:0)			PNUM(2:0)			

<b>SDCAW</b>	<b>SDRAM Column Address Width</b>
	0      8 bit
	1      9 bit
<b>SDRR</b>	<b>SDRAM Refresh Rate</b>
	0      Default Refresh Rate (4096 cycles/s)
	1      Double Refresh Rate (8192 cycles/s)
<b>ERCPD</b>	<b>ERC Power Down</b>
	0      ERC active
	1      ERC in power-down mode
<b>TUTS</b>	<b>Tristate all UTOPIA Signals</b>
	0      Normal mode
	1      UTOPIA Signals in Tristate mode
<b>DQSC</b>	<b>Disable Quarter Segment Check</b>
	0      Normal mode

**Register Description**

	1	Quarter Segment Check disabled
<b>QS(1:0)</b>		<p><b>Quarter Segment</b></p> <p>If Quarter Segment Check is enabled, the ABM-P processes only cells matching the LCI segment:  <math>LCI(15:14) = QS(1:0)</math>            All other cells are forwarded depending on the value found in entry 0 of the LCT table. Default: send to the Common Real-Time Queue to be processed by a subsequent ABM-P (cascading).</p>
<b>PNSRC</b>		<p><b>Port Number Source</b></p> <p>This bit determines which Port Number field is used for internal Address Reduction Mode:</p> <p>0          PN field is taken from the UTOPIA Port number, that accepted the cell.</p> <p>1          PN field is taken from the UDF1(5:0) field of the cell</p>
<b>MNUM(3:0)</b>		<p><b>M Parameter</b></p> <p>This bit field determines the ranges of VPI and VCI cell header fields mapped into the LCI in internal Address Reduction mode.  <a href="#">Chapter 3.2.5</a> provides the details.</p>
<b>PNUM(2:0)</b>		<p><b>P Parameter</b></p> <p>This bit field determines the number of port number bits mapped into the LCI in internal Address Reduction mode.  <a href="#">Chapter 3.2.5</a> provides the details.</p>

### 7.2.32 UTOPIA Configuration Registers

#### Register 128 UTRXCFG

##### Upstream/Downstream UTOPIA Receive Configuration Register

CPU Accessibility: **Read/Write**  
 Reset Value: **0001<sub>H</sub>**  
 Offset Address: **UTRXCFG F0<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	DURD	DURUT	DURPD	DURPE	DURCFG(1:0)		DURBU S	DURM
Bit	7	6	5	4	3	2	1	0
	UURD	UURUT	UURPD	UURPE	UURCFG(1:0)		UURBU S	UURM

**DURD**                      **Downstream UTOPIA Receive Discard**  
**UURD**                      **Upstream UTOPIA Receive Discard**

0            Normal operation  
 1            Discard all cells without notification

**DURUT**                      **Downstream UTOPIA Receive UDF2 Transparent**  
**UURUT**                      **Upstream UTOPIA Receive UDF2 Transparent**

0            PN mapped to UDF2 (for internal processing)  
 1            UDF2 transparent (BIP8 checksum not usable)

**DURPD**                      **Downstream UTOPIA Receive Parity Error discard**  
**UURPD**                      **Upstream UTOPIA Receive Parity Error discard**

0            No discarding of cells with Parity Error

**Register Description**

	1	Discarding of cells with Parity Error
<b>DURPE</b>	<b>Downstream UTOPIA Receive Parity Check Enable</b>	
<b>UURPE</b>	<b>Upstream UTOPIA Receive Parity Check Enable</b>	
	0	Parity check disabled
	1	Parity check enabled
<b>DURCFG(1:0)</b>	<b>Downstream UTOPIA Receive Port Configuration</b>	
<b>UURCFG(1:0)</b>	<b>Upstream UTOPIA Receive Port Configuration</b>	
	00	4 x 12 ports
	01	4 x 12 ports
	10	4 x 12 ports
	11	Level 1 Mode (4 x 1 port)
<b>DURBUS</b>	<b>Downstream UTOPIA Receive Bus Width</b>	
<b>UURBUS</b>	<b>Upstream UTOPIA Receive Bus Width</b>	
	0	8-bit bus width
	1	16-bit bus width
<b>DURM</b>	<b>Downstream UTOPIA Receive Mode</b>	
<b>UURM</b>	<b>Upstream UTOPIA Receive Mode</b>	
	0	Slave Mode
	1	Master Mode

**Register 129 UUTRXP0**


**Upstream UTOPIA Receive Port Register 0**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UUTRXP0 F1<sub>H</sub>**

Typical Usage: Written and Read by CPU



**UUTRXPEnable (15:0) Upstream UTOPIA Receive Port Enable**  
 Each bit enables or disables the respective UTOPIA port (15..0):  
 bit = 0 Port disabled.  
 bit = 1 Port enabled.

**Register 130 UUTRXP1**


**Upstream UTOPIA Receive Port Register 1**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UUTRXP1 F2<sub>H</sub>**

Typical Usage: Written and Read by CPU



**UUTRXPEnable (31:16) Upstream UTOPIA Receive Port Enable**  
 Each bit enables or disables the respective UTOPIA port (31..16):  
 bit = 0 Port disabled.  
 bit = 1 Port enabled.

**Register 131 UUTRXP2**


**Upstream UTOPIA Receive Port Register 2**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UUTRXP2 F3<sub>H</sub>**

Typical Usage: Written and Read by CPU



**UUTRXPEnable (47:32) Upstream UTOPIA Receive Port Enable**  
 Each bit enables or disables the respective UTOPIA port (47..32):  
 bit = 0 Port disabled.  
 bit = 1 Port enabled.

**Register 132 DUTRXP0**


**Downstream UTOPIA Receive Port Register 0**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **DUTRXP0 F4<sub>H</sub>**

Typical Usage: Written and Read by CPU



**DUTRXPEnable (15:0) Downstream UTOPIA Receive Port Enable**

Each bit enables or disables the respective UTOPIA port (15..0):

bit = 0 Port disabled.

bit = 1 Port enabled.



**Register 133 DUTRXP1**


**Downstream UTOPIA Receive Port Register 1**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **DUTRXP1 F5<sub>H</sub>**

Typical Usage: Written and Read by CPU



**DUTRXPEnable Downstream UTOPIA Receive Port Enable**

**(31:16)** Each bit enables or disables the respective UTOPIA port (31..16):

bit = 0 Port disabled.

bit = 1 Port enabled.

**Register 134 DUTRXP2**


**Downstream UTOPIA Receive Port Register 2**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **DUTRXP2 F6<sub>H</sub>**

Typical Usage: Written and Read by CPU



**DUTRXPEnable Downstream UTOPIA Receive Port Enable**

**(47:32)**

Each bit enables or disables the respective UTOPIA port (47..32):

bit = 0 Port disabled.

bit = 1 Port enabled.

**Register 135 UUTXCFG**  
**Upstream UTOPIA Transmit Configuration Register**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UUTXCFG F7<sub>H</sub>**  
 Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	unused(2:0)			UUTES	UUTUT	UUTCFG(1:0)		UUTBUS
Bit	7	6	5	4	3	2	1	0
	UUTQL(6:0)							UUTM

**UUTM**                    **Upstream UTOPIA Transmit Mode**

0	Slave Mode
1	Master Mode

**UUTQL(6:0)**           **Upstream UTOPIA Transmit Queue Length**  
[Chapter 5.2.2](#) provides the details.  
 64 cells maximum

**UURBUS**                **Upstream UTOPIA Transmit Bus Width**

0	8-bit bus width
1	16-bit bus width

**UUTCFG(1:0)**           **Upstream UTOPIA Transmit Port Configuration**

00	4 x 12 ports
01	4 x 12 ports
10	4 x 12 ports

Register Description

11 Level 1 Mode (4 x 1 port)

**UUTUT Upstream UTOPIA Transmit UDF2 Transparent**

0 Port number is mapped to UDF2

1 UDF2 not modified at transmit Interface (UDF2 transparency if set together with [UTRXCFG.UURUT](#))

**UUTES Upstream UTOPIA Transmit Extended Slave**

0 1x4 or 4x12

1 1x31 together with UUTM="0" (slave)

**Register 136 DUTTXCFG**

**Downstream UTOPIA Transmit Configuration Register**

CPU Accessibility: **Read/Write**

Reset Value: **0001<sub>H</sub>**

Offset Address: **DUTTXCFG F8<sub>H</sub>**

Typical Usage: Written and Read by CPU

Bit	15	14	13	12	11	10	9	8
	unused(2:0)			DUTES	DUTUT	DUTCFG(1:0)		DUTBUS
Bit	7	6	5	4	3	2	1	0
	DUTQL(6:0)							DUTM

**DUTM Downstream UTOPIA Transmit Mode**

- 0 Slave Mode
- 1 Master Mode

**DUTQL(6:0) Downstream UTOPIA Transmit Queue Length**  
Chapter 5.1.2 provides the details.  
64 cells maximum

**DURBUS Downstream UTOPIA Transmit Bus Width**

- 0 8-bit bus width
- 1 16-bit bus width

**DUTCFG(1:0) Downstream UTOPIA Transmit Port Configuration**

- 00 4 x 12 ports
- 01 4 x 12 ports
- 10 4 x 12 ports

---

**Register Description**

11      Level 1 Mode (4 x 1 port)

**DUTUT      Downstream UTOPIA Transmit UDF2 Transparent**

0      Port number is mapped to UDF2

1      UDF2 not modified at transmit Interface (UDF2 transparency if set together with [UTRXCFG.DURUT](#))

**DUTES      Downstream UTOPIA Transmit Extended Slave**

0      1x4 or 4x12

1      1x31 together with UUTM="0" (slave)

**Register 137 UUTXP0**


**Upstream UTOPIA Transmit Port Register 0**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **UUTXP0 F9<sub>H</sub>**

Typical Usage: Written and Read by CPU



**UUTXPEnable (15:0) Upstream UTOPIA Transmit Port Enable**

Each bit enables or disables the respective UTOPIA port (15..0):

bit = 0 Port disabled.


bit = 1 Port enabled.

*Note: If transmit port is disabled, cells assigned to this port are discarded without notification*

**Register 138 UUTXP1**

**Upstream UTOPIA Transmit Port Register 1**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UUTXP1 FA<sub>H</sub>**  
 Typical Usage: Written and Read by CPU




**UUTXPEnable (31:16) Upstream UTOPIA Transmit Port Enable**  
 Each bit enables or disables the respective UTOPIA port (31..16):  
 bit = 0 Port disabled.  
 bit = 1 Port enabled.  
*Note: If transmit port is disabled, cells assigned to this port are discarded without notification*



**Register 139 UUTXP2**

**Upstream UTOPIA Transmit Port Register 2**

CPU Accessibility: **Read/Write**  
 Reset Value: **0000<sub>H</sub>**  
 Offset Address: **UUTXP2 FB<sub>H</sub>**  
 Typical Usage: Written and Read by CPU



**UUTXPEnable (47:32) Upstream UTOPIA Transmit Port Enable**  
 Each bit enables or disables the respective UTOPIA port (47..32):  
 bit = 0 Port disabled.  
 bit = 1 Port enabled.  
*Note: If transmit port is disabled, cells assigned to this port are discarded without notification*

**Register 140 DUTTXP0**


**Downstream UTOPIA Transmit Port Register 0**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **DUTTXP0 FC<sub>H</sub>**

Typical Usage: Written and Read by CPU



**DUTTXPEnable (15:0) Downstream UTOPIA Transmit Port Enable**

Each bit enables or disables the respective UTOPIA port (15..0):

bit = 0 Port disabled.

bit = 1 Port enabled.

*Note: If transmit port is disabled, cells assigned to this port are discarded without notification*

**Register 141 DUTTXP1**


**Downstream UTOPIA Transmit Port Register 1**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **DUTTXP1 FD<sub>H</sub>**

Typical Usage: Written and Read by CPU



**DUTTXPEnable Downstream UTOPIA Transmit Port Enable**

**(31:16)**

Each bit enables or disables the respective UTOPIA port (31..16):

bit = 0 Port disabled.

bit = 1 Port enabled.

*Note: If transmit port is disabled, cells assigned to this port are discarded without notification*

**Register 142 DUTTXP2**


**Downstream UTOPIA Transmit Port Register 2**

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **DUTTXP2 FE<sub>H</sub>**

Typical Usage: Written and Read by CPU



**DUTTXPEnable Downstream UTOPIA Transmit Port Enable**

**(47:32)**

Each bit enables or disables the respective UTOPIA port (47..32):

bit = 0 Port disabled.

bit = 1 Port enabled.

*Note: If transmit port is disabled, cells assigned to this port are discarded without notification*

### 7.2.33 Test Registers/Special Mode Registers

#### Register 143 TEST

##### TEST Register

CPU Accessibility: **Read/Write**

Reset Value: **0000<sub>H</sub>**

Offset Address: **TEST FF<sub>H</sub>**

Typical Usage: Written and Read by CPU for device test purposes

Bit	15	14	13	12	11	10	9	8
	Unused(5:0)						Reserved(7:6)	
Bit	7	6	5	4	3	2	1	0
	CLKdelay(1:0)		Reserved(5:0)					

**CLKDelay(1:0)** This bit field adjusts the delay of RAMCLK output with respect to SYSClk input. [“SPI: Serial Peripheral Interface” on Page 177](#) provides the details.

00	Delay 0
01	Delay 2
10	Delay 4
11	Delay 6

## 8 Electrical Characteristics

### 8.1 Absolute Maximum Ratings

**Table 8-1 Absolute Maximum Ratings**

Parameter	Symbol	Limit Values	Unit
Ambient temperature under biasPXF	$T_A$	-40 to 85	°C
Storage temperature	$T_{stg}$	-40 to 125	°C
IC supply voltage with respect to ground	$V_{DD}$	-0.3 to 3.6	V
Voltage on any pin with respect to ground	$V_S$	-0.4 to $V_{DD} + 0.4$	V
ESD robustness <sup>1)</sup> HBM: 1.5 kΩ, 100 pF	$V_{ESD,HBM}$	2000	V

<sup>1)</sup> According to MIL-Std 883D, method 3015.7 and ESD Association Standard EOS/ESD-5.1-1993.  
The RF Pins 20, 21, 26, 29, 32, 33, 34 and 35 are not protected against voltage stress > 300 V (versus  $V_S$  or GND). The high frequency performance prohibits the use of adequate protective structures.

**Note: Stresses above those listed here may cause permanent damage to the device. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.**

### 8.2 Operating Range

**Table 8-2 Operating Range**

Parameter	Symbol	Limit Values		Unit	Test Condition
		min.	max.		
Ambient temperature under bias	$T_A$	-40	85	°C	
Junction temperature	$T_J$		125	°C	
Supply voltage 3.3V	$V_{DD33}$	3.0	3.6	V	
Supply voltage 1.8V	$V_{DD18}$	1.62	1.98	V	
Ground	$V_{SS}$	0	0	V	
Power dissipation	$P$		2.5	W	

Note: In the operating range, the functions given in the circuit description are fulfilled.

**8.3 DC Characteristics**
**Table 8-3 DC Characteristics**

Parameter	Symbol	Limit Values			Unit	Notes
		min.	typ.	max		
Input low voltage	$V_{IL}$	-0.4		0.8	V	
Input high voltage	$V_{IH}$	2.0		$V_{DD} + 0.3$	V	LVTTTL (3.3 V)
Output low voltage	$V_{OL}$		0.2	0.4	V	$I_{OL} = 5 \text{ mA}$
Output high voltage	$V_{OH}$	2.4		$V_{DD}$	V	$I_{OH} = -5 \text{ mA}$ all pins except TDO (TDO: $I_{OH} = -3 \text{ mA}$ )
Average power supply current	$I_{CC}$ (AV)		330		mA	$V_{DD33} = 3.3 \text{ V}$ , $V_{DD18} = 1.8 \text{ V}$ , $T_A = 25 \text{ }^\circ\text{C}$ , SYSCLK = 52 MHz; URXCLKU = UTXCLKU = URXCLKD = UTXCLKD = 52 MHz;
Average power down supply current	$I_{CCPD}$ (AV)			10	mA	$V_{DD} = 3.3 \text{ V}$ , $T_A = 25 \text{ }^\circ\text{C}$ , no output loads, no clocks
Average power dissipation	$P$ (AV)		1	1.3	W	$V_{DD33} = 3.3 \text{ V}$ , $V_{DD18} = 1.8 \text{ V}$ , $T_A = 25 \text{ }^\circ\text{C}$ , SYSCLK = 52 MHz; URXCLKU = UTXCLKU = URXCLKD = UTXCLKD = 52 MHz;

**Electrical Characteristics**
**Table 8-3 DC Characteristics (cont'd)**

Parameter	Symbol	Limit Values			Unit	Notes
		min.	typ.	max		
Input current	$I_{IIN}$	-1		1	$\mu\text{A}$	$V_{IN} = V_{DD33}$ or $V_{SS}$
		4		8	$\mu\text{A}$	$V_{IN} = V_{DD33}$ for Inputs with internal Pull-Down resistor
		-4		-8	$\mu\text{A}$	$V_{IN} = V_{SS}$ for Inputs with internal Pull-Up resistor
Input leakage current	$I_{IL}$			1	$\mu\text{A}$	$V_{DD33} = 3.3\text{ V}$ , $V_{DD18} = 1.8\text{ V}$ , $GND = 0\text{ V}$ ; all other pins are floating
Output leakage current	$I_{OZ}$			1	$\mu\text{A}$	$V_{DD33} = 3.3\text{ V}$ , $V_{DD18} = 1.8\text{ V}$ , $GND = 0\text{ V}$ ; $V_{OUT} = 0\text{ V}$




#### 8.4 AC Characteristics

$T_A = -40$  to  $85$  °C,  $V_{DD33} = 3.3$  V  $\pm$  10%,  $V_{DD18} = 1.8$  V  $\pm$  10%,  $V_{SS} = 0$  V

All inputs are driven to  $V_{IH} = 2.4$  V for a logical 1  
and to  $V_{IL} = 0.4$  V for a logical 0

All outputs are measured at  $V_H = 2.0$  V for a logical 1  
and at  $V_L = 0.8$  V for a logical 0

The AC testing input/output waveforms are shown in [Figure 8-1](#).




**Figure 8-1** Input/Output Waveform for AC Measurements


**Electrical Characteristics**
**Table 8-4 Clock Frequencies**

Parameter	Symbol	Limit Values		Unit
		min.	max.	
Core clock (internal) <sup>1)</sup>	$f_{\text{int.coreclock}}$	25	60	MHz
ERC core clock (internal) <sup>1)</sup>		25	60	MHz
External core clock source	SYSCLK	25	60	MHz
UTOPIA clocks at PHY-side	UTRXCLKU	$f_{\text{int.coreclock}}/2$	MIN { $f_{\text{int. coreclock}}$ , 60 MHz}	MHz
	UTTXCLKD	$f_{\text{int.coreclock}}/2$	MIN { $f_{\text{int. coreclock}}$ , 52 MHz}	MHz
UTOPIA clock at Backplane-side	UTRXCLKD	$f_{\text{int.coreclock}}/2$	MIN { $f_{\text{int. coreclock}}$ , 60 MHz}	MHz
	UTTXCLKU	$f_{\text{int.coreclock}}/2$	MIN { $f_{\text{int. coreclock}}$ , 52 MHz}	MHz
SPI Interface clock	SPICLK	derived internally		
QCI Interface clock	QCITXCLK	>0	MIN { $f_{\text{int. core clock}}$ , 60 MHz}	MHz
Clock for external RAM	RAMCLK	$f_{\text{int.coreclock}}$	$f_{\text{int.coreclock}}$	

<sup>1)</sup> For frequencies > 52 MHz, the following restrictions apply:  
 $V_{\text{DD18}} = 1.8 \text{ V} \pm 5\%$  and  $T_{\text{A}} = 0$  to  $70 \text{ }^{\circ}\text{C}$

**8.4.1 Microprocessor Interface Timing Intel Mode**
**8.4.1.1 Microprocessor Write Cycle Timing (Intel)**

**Figure 8-2 Microprocessor Interface Write Cycle Timing (Intel)**
**Table 8-5 Microprocessor Interface Write Cycle Timing (Intel)**

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
1	MPADR setup time before MPCS low	0			ns
2	MPCS setup time before MPWR low	0			ns
3	MPRDY low delay after MPWR low	0		20	ns
4	MPDAT setup time before MPWR high	5			ns
5	Pulse width MPRDY low	4 SYSCLK cycles		5 SYSCLK cycles	
6	MPRDY high to MPWR high	5			ns
7	MPDAT hold time after MPWR high	5			ns
8	MPCS hold time after MPWR high	5			ns
9	MPADR hold time after MPWR high	5			ns
10	MPCS low to MPRDY low impedance	0			ns
11	MPCS high to MPRDY high impedance			15	ns

**8.4.1.2 Microprocessor Read Cycle Timing (Intel)**

**Figure 8-3 Microprocessor Interface Read Cycle Timing (Intel)**
**Table 8-6 Microprocessor Interface Read Cycle Timing (Intel)**

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
20	MPADR setup time before $\overline{\text{MPCS}}$ low	0			ns
21	$\overline{\text{MPCS}}$ setup time before $\overline{\text{MPRD}}$ low	0			ns
22	MPRDY low delay after $\overline{\text{MPRD}}$ low	0		20	ns
23	Pulse width MPRDY low	4 SYSCLK cycles		5 SYSCLK cycles	
24	MPDAT valid before MPRDY high	5			ns
25	MPRDY high to $\overline{\text{MPRD}}$ high	5			ns
26	MPDAT hold time after $\overline{\text{MPRD}}$ high	2			ns
27	$\overline{\text{MPCS}}$ hold time after $\overline{\text{MPRD}}$ high	5			ns
28	MPADR hold time after $\overline{\text{MPRD}}$ high	5			ns
29	$\overline{\text{MPRD}}$ low to MPDAT low impedance	0		15	ns
30	$\overline{\text{MPRD}}$ high to MPDAT high impedance	0		17	ns
31	$\overline{\text{MPCS}}$ low to MPRDY low impedance	0			ns
32	$\overline{\text{MPCS}}$ high to MPRDY high impedance			15	ns

## 8.4.2 Microprocessor Interface Timing Motorola Mode

### 8.4.2.1 Microprocessor Write Cycle Timing (Motorola)





Figure 8-4 Microprocessor Interface Write Cycle Timing (Motorola)

Table 8-7 Microprocessor Interface Write Cycle Timing (Motorola)

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
40	MPADR setup time before $\overline{\text{MPCS}}$ low	0			ns
41	$\overline{\text{MPCS}}$ setup time before $\overline{\text{DS}}$ low	0			ns
42	RDY low delay after $\overline{\text{DS}}$ low	0		20	ns
43	MPDAT setup time before $\overline{\text{DS}}$ high	5			ns
44	Pulse width RDY low	4 SYSCLK cycles		5 SYSCLK cycles	
45	RDY high to $\overline{\text{DS}}$ high	5			ns
46	MPDAT hold time after $\overline{\text{DS}}$ high	5			ns
47	$\overline{\text{MPCS}}$ hold time after $\overline{\text{DS}}$ high	5			ns
48	MPADR hold time after $\overline{\text{DS}}$ high	5			ns
51	$\overline{\text{R/W}}$ setup time before $\overline{\text{DS}}$ low	10			ns
52	$\overline{\text{R/W}}$ hold time after $\overline{\text{DS}}$ high	0			ns

**Table 8-7 Microprocessor Interface Write Cycle Timing (Motorola) (cont'd)**

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
53	MPCS low to RDY low impedance	0			ns
54	MPCS high to RDY high impedance			15	ns

**8.4.2.2 Microprocessor Read Cycle Timing (Motorola)**

**Figure 8-5 Microprocessor Interface Read Cycle Timing (Motorola)**
**Table 8-8 Microprocessor Interface Read Cycle Timing (Motorola)**

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
60	MPADR setup time before MPCS low	0			ns
61	MPCS setup time before DS low	0			ns
62	RDY low delay after DS low	0		20	ns
63	Pulse width RDY low	4 SYSCLK cycles		5 SYSCLK cycles	
64	MPDAT valid before RDY high	5			ns
65	RDY high to DS high	5			ns

**Electrical Characteristics**
**Table 8-8 Microprocessor Interface Read Cycle Timing (Motorola) (cont'd)**


No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
66	MPDAT hold time after $\overline{DS}$ high	2			ns
67	$\overline{MPCS}$ hold time after $\overline{DS}$ high	5			ns
68	MPADR hold time after $\overline{DS}$ high	5			ns
69	$\overline{DS}$ low to MPDAT low impedance	0		15	ns
70	$\overline{DS}$ high to MPDAT high impedance	0		17	ns
71	$R/\overline{W}$ setup time before $\overline{DS}$ low	10			ns
72	$R/\overline{W}$ hold time after $\overline{DS}$ high	0			ns
73	$\overline{MPCS}$ low to RDY low impedance	0			ns
74	$\overline{MPCS}$ high to RDY high impedance			15	ns

### 8.4.3 UTOPIA Interface

The AC characteristics of the UTOPIA Interface fulfill the standard of [3] and [4]. Setup and hold times of the 50 MHz UTOPIA Specification are valid. According to the UTOPIA Specification, the AC characteristics are based on the timing specification for the receiver side of a signal. The setup and the hold times are defined with regards to a positive clock edge, see [Figure 8-6](#).


Taking into account the actual clock frequency (up to the maximum frequency), the corresponding (min. and max.) transmit side “clock to output” propagation delay specifications can be derived. The timing references (tT5 to tT12) are according to the data found in [Table 8-9](#) through [Table 8-12](#).

Note: The UTOPIA Receive Interface backplane-side is optimized for operation up to 60 MHz UTOPIA clock frequency to achieve a speed-up factor of 1.25 in bandwidth accepted from the backplane (respective values provided in brackets).



**Figure 8-6 Setup and Hold Time Definition (Single- and Multi-PHY)**

[Figure 8-7](#) shows the tristate timing for the multi-PHY application (multiple PHY devices, multiple output signals are multiplexed together).



**Figure 8-7 Tristate Timing (Multi-PHY, Multiple Devices Only)**



**Electrical Characteristics**

In the following tables, A⇒P (column DIR, Direction) defines a signal from the ATM Layer (transmitter, driver) to the PHY Layer (receiver), A⇐P defines a signal from the PHY Layer (transmitter, driver) to the ATM Layer (receiver).

Both UTOPIA Interfaces (PHY-side and Backplane-side) can be configured in either Slave or Master Mode. If configured in Master Mode, the interface is considered to be the ATM Layer device (A) and if configured in Slave Mode, the interface is considered to be the PHY Layer device (P) respectively.

All timings also apply to UTOPIA Level 1 8-bit data bus operation.

**Table 8-9 Transmit Timing (16-Bit Data Bus, 50 MHz Cell Mode, Single PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit		
				Min	Max			
80	UTXCLKD, UTXCLKU	A>P	TxCk frequency (nominal)	0	52	MHz		
81			TxCk duty cycle	40	60	%		
82			TxCk peak-to-peak jitter	-	5	%		
83			TxCk rise/fall time	-	2	ns		
84	UTXDATD, UTXDATU, UTXPRTYD, UTXPRTYU, UTXSOCU, UTXSOCU, UTXENBD, UTXENBU	A>P	Input setup to TxClk	4	-	ns		
85			Input hold from TxClk	1	-	ns		
86			UTXCLAVD, UTXCLAVU	A<P	Input setup to TxClk	4	-	ns
87					Input hold from TxClk	1	-	ns

**Table 8-10 Receive Timing (16-Bit Data Bus, 50 MHz Cell Mode, Single PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit
				Min	Max	
80	URXCLKD, URXCLKU	A>P	RxCk frequency (nominal)			
			URXCLKD:	0	60	
			URXCLKU:	0	52	
81			RxCk duty cycle	40	60	%
82			RxCk peak-to-peak jitter	-	5	%
83			RxCk rise/fall time	-	2	ns

**Electrical Characteristics**
**Table 8-10 Receive Timing (16-Bit Data Bus, 50 MHz Cell Mode, Single PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit
				Min	Max	
84	URXENBD,	A>P	Input setup to RxClk	4	-	ns
85	URXENBU		Input hold from RxClk	1	-	ns
86	URXDATD,	A<P	Input setup to RxClk	4	-	ns
87	URXDATU, URXPRTYD, URXPRTYU, URXSOCU, URXSOCV, URXCLAVD, URXCLAVU		Input hold from RxClk	1	-	ns

**Table 8-11 Transmit Timing (16-Bit Data Bus, 50 MHz Cell Mode, Multi-PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit
				Min	Max	
80	UTXCLKD,	A>P	TxCk frequency (nominal)	0	52	MHz
81	UTXCLKU		TxCk duty cycle	40	60	%
82			TxCk peak-to-peak jitter	-	5	%
83			TxCk rise/fall time	-	2	ns
84	UTXDATD,	A>P	Input setup to TxClk	4	-	ns
85	UTXDATU, UTXPRTYD, UTXPRTYU, UTXSOCU, UTXSOCV, UTXENBD, UTXENBU, UTXADRDR, UTXADRUR		Input hold from TxClk	1	-	ns

**Electrical Characteristics**
**Table 8-11 Transmit Timing (16-Bit Data Bus, 50 MHz Cell Mode, Multi-PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit
				Min	Max	
86	UTXCLAVD, UTXCLAVU	A<P	Input setup to TxClk	4	-	ns
87			Input hold from TxClk	1	-	ns
88			Signal going low impedance to TxCLK	4	-	ns
89			Signal going high impedance to TxCLK	0	-	ns
90			Signal going low impedance from TxCLK	1	-	ns
91			Signal going high impedance from TxCLK	1	-	ns

**Table 8-12 Receive Timing (16-Bit Data Bus, 50 MHz Cell Mode, Multi-PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit
				Min	Max	
80	URXCLKD, URXCLKU	A>P	RxClk frequency (nominal)			MHz
			URXCLKD:	0	60	
			URXCLKU:	0	52	
81			RxClk duty cycle	40	60	%
82			RxClk peak-to-peak jitter	-	5	%
83	RxClk rise/fall time	-	2	ns		
84	URXENBD, URXENBU, URXADRD, URXADRU	A>P	Input setup to RxClk	4	-	ns
85			Input hold from RxClk	1	-	ns

**Electrical Characteristics**


**Table 8-12 Receive Timing (16-Bit Data Bus, 50 MHz Cell Mode, Multi-PHY)**

No.	Signal Name	DIR	Description	Limit Values		Unit
				Min	Max	
86	URXDATD,	A<P	Input setup to RxClk	4	-	ns
87	URXDATU,		Input hold from RxClk	1	-	ns
88	URXPRTYD,		Signal going low impedance to RxCLK	4	-	ns
	URXPRTYU,		Signal going high impedance to RxCLK	0	-	ns
89	URXSOCU,		Signal going low impedance from RxCLK	1	-	ns
90	URXCLAVD,		Signal going high impedance from RxCLK	1	-	ns
91	URXCLAVU					

Note: The setup and hold times for receive Interfaces deviate for non-standard 60 MHz operation. Timings are provided on request.

#### 8.4.4 CPR SSRAM Interface

Timing of the Synchronous Static RAM Interfaces is simplified as all signals are referenced to the rising edge of RAMCLK. In **Figure 8-8**, it can be seen that all signals output by the ABM-P have identical delay times with reference to the clock. When reading from the RAM, the ABM-P samples the data within a window at the rising clock edge.




**Figure 8-8 SSRAM Interface Generic Timing Diagram**

**Table 8-13 SSRAM Interface AC Timing Characteristics**

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
100	$T_{RAMCLK}$ : Period RAMCLK	16.7			ns
100A	$F_{RAMCLK}$ : Frequency RAMCLK			60	MHz
101	Setup time $\overline{CPRADSC}$ , $\overline{CPRADR(18:0)}$ , $\overline{CPRGW}$ , $\overline{CPROE}$ before RAMCLK rising	2.5			ns
102	Hold time $\overline{CPRADSC}$ , $\overline{CPRADR(18:0)}$ , $\overline{CPRGW}$ , $\overline{CPROE}$ after RAMCLK rising	1.5			ns
103	Delay CPRDAT Output after RAMCLK rising	2.5		11	ns
104	Setup time CPRDAT Input before CLK rising (Read cycles)	2.5			ns
105	Hold time CPRDAT Input after CLK rising (Read cycles)	1.5			ns

### 8.4.5 CSR SDRAM Interface(s)

Timing of the Synchronous Dynamic RAM (SDRAM) Interface is simplified as all signals are referenced to the rising edge of RAMCLK. In **Figure 8-9**, it can be seen that all signals output by the ABM-P have identical delay times with reference to the clock. When reading from RAM, the ABM-P samples the data within a window at the rising clock edge.



**Figure 8-9** Generic SDRAM Interface Timing Diagram

**Table 8-14** SDRAM Interface AC Timing Characteristics

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
110	$T_{RAMCLK}$ : Period RAMCLK	16.7			ns
110A	$F_{RAMCLK}$ : Frequency RAMCLK			60	MHz
111	Setup time $\overline{CSRADRI}(13:0)$ , $\overline{CSRCSI}$ , $\overline{CSRRASI}$ , $\overline{CSRCASI}$ , $\overline{CSRWEI}$ , CSRBAI0, CSRBAI1 before RAMCLK rising	2.5			ns
112	Hold time $\overline{CSRADRI}(13:0)$ , $\overline{CSRCSI}$ , $\overline{CSRRASI}$ , $\overline{CSRCASI}$ , $\overline{CSRWEI}$ , CSRBAI0, CSRBAI1 after RAMCLK rising	1.5			ns
113	Delay CSRDATi Output after RAMCLK rising	3		6.5	ns
114	Setup time CSRDATi Input before RAMCLK rising (Read cycles)	2.5			ns
115	Hold time CSRDATi Input after RAMCLK rising (Read cycles)	1.5			ns

### 8.4.6 Reset Timing




Figure 8-10 Reset Timing

Table 8-15 Reset Timing

No.	Parameter	Limit Values		Unit
		min.	max.	
150	RESET pulse width	120		ns
151	Number of SYSCLK cycles during RESET active	2		SYSCLK cycles

Note:  $\overline{\text{RESET}}$  may be asynchronous to CLK when asserted or deasserted.  $\overline{\text{RESET}}$  may be asserted during power-up or asserted after power-up. Nevertheless, deassertion must be at a clean, bounce-free edge.

### 8.4.7 Boundary-Scan Test Interface




Figure 8-11 Boundary-Scan Test Interface Timing Diagram

Table 8-16 Boundary-Scan Test Interface AC Timing Characteristics

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
160	$T_{TCK}$ : Period TCK	100			ns
160A	$F_{TCK}$ : Frequency TCK			10	MHz
161	TCK high time	40			ns
162	TCK low time	40			ns
163	Setup time TMS before TCK rising	10			ns
164	Hold time TMS after TCK rising	10			ns
165	Setup time TDI before TCK rising	10			ns
166	Hold time TDI after TCK rising	10			ns
167	Delay TCK falling to TDO valid			30	ns
167A	Delay TCK falling to TDO high impedance			30	ns
168	Pulse width $\overline{TRST}$ low	200			ns



### 8.4.8 SPI Interface




Figure 8-12 SPI Interface Timing Diagram

Table 8-17 SPI Interface AC Timing Characteristics

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
200	$\overline{\text{SPICS}}$ low to SPICLK delay	500			ns
201	SPICLK to $\overline{\text{SPICS}}$ delay	500			ns
202	SPICLK high time	500			ns
203	SPICLK low time	500			ns
204	$\overline{\text{SPICS}}$ low to SPISO delay			100	ns
205	SPICLK to SPISO delay			100	ns
206	SPISI to SPICLK setup time	100			ns
207	SPISI to SPICLK hold time	100			ns

### 8.4.9 Queue Congestion Interface (QCI)




Figure 8-13 QCI Interface Timing Diagram

Table 8-18 QCI Interface AC Timing Characteristics

No.	Parameter	Limit Values			Unit
		Min	Typ	Max	
250	$T_{QCICLK}$ : Period QCICLK	15.15			ns
250A	$F_{QCICLK}$ : Frequency QCICLK			60	MHz
251	QCICLK low time	7			ns
252	QCICLK high time	7			ns
253	Setup time QCITXFRAME before QCICLK rising	4			ns
254	Hold time QCITXFRAME after QCICLK rising	4			ns
255	Setup time QCITXDAT before QCICLK rising	4			ns
256	Hold time QCITXDAT after QCICLK rising	3			ns

**8.5 Capacitances**
**Table 8-19 Capacitances**


Parameter	Symbol	Limit Values		Unit
		min.	max.	
Input Capacitance	$C_{IN}$	2.5	5	pF
Output Capacitance	$C_{OUT}$	2	5	pF
Load Capacitance at: UTOPIA Outputs	$C_{FO1}$		40	pF
MPDAT(15:0), MPRDY	$C_{FO2}$		50	pF
other outputs	$C_{FO3}$		20	pF

**8.6 Package Characteristics**
**Table 8-20 Thermal Package Characteristics**

Parameter		Symbol	Value	Unit
Thermal Package Resistance Junction to Ambient				
Airflow	Ambient Temperature			
No airflow	$T_A=25^\circ\text{C}$	$R_{JA(0,25)}$	21,1	$^\circ\text{C/W}$
Airflow 200 lfm = 1 m/s	$T_A=25^\circ\text{C}$	$R_{JA(0,25)}$	17,7	$^\circ\text{C/W}$
Airflow 500 lfm = 2.5 m/s	$T_A=25^\circ\text{C}$	$R_{JA(0,25)}$	16,3	$^\circ\text{C/W}$

## 9 Test Mode

A Test Access Port (TAP) is implemented in the ABM-P. The essential part of the TAP is a finite state machine (16 states) controlling the different operational modes of the boundary scan. Both the TAP controller and boundary scan meet the requirements given by the JTAG standard: IEEE 1149.1. **Figure 9-1** gives an overview about the TAP controller.



**Figure 9-1 Block Diagram of Test Access Port and Boundary Scan Unit**

If no boundary scan operation is planned,  $\overline{\text{TRST}}$  must be connected with  $V_{\text{SS}}$ . TMS and TDI do not need to be connected since pull-up transistors ensure high input levels in this case. Nevertheless, it is good practice to set the unused inputs to defined levels.

In this case, if the JTAG is not used:  
 TMS = TCK = '1' is recommended.

Test handling (boundary scan operation) is performed via the pins TCK (Test Clock), TMS (Test Mode Select), TDI (Test Data Input), and TDO (Test Data Output) when the TAP controller is not in its reset state; i.e.,  $\overline{\text{TRST}}$  is connected to  $V_{\text{DD3}}$  or it remains unconnected due to its internal pull up. Test data at TDI are loaded with a clock signal connected to TCK. '1' or '0' on TMS causes a transition from one controller state to another; constant '1' on TMS leads to normal operation of the chip.

An Input pin (I) uses one boundary scan cell (data in); an Output pin (O) uses two cells (data out, enable); and an I/O-pin (I/O) uses three cells (data in, data out, enable). Note that most functional output and input pins of the ABM-P are tested as I/O pins in boundary scan, thus using three cells. The boundary scan unit of the ABM-P contains a

total of  $n = 572$  scan cells. The desired test mode is selected by serially loading a 4-bit instruction code into the instruction register via TDI (LSB first).

**EXTEST** is used to examine the interconnection of the devices on the board. In this test mode, at first all input pins capture the current level on the corresponding external interconnection line, whereas all output pins are held at constant values ('0' or '1'). Then, the contents of the boundary scan are shifted to TDO. At the same time the next scan vector is loaded from TDI. Subsequently all output pins are updated according to the new boundary scan contents and all input pins again capture the current external level afterwards, and so on.

**INTEST** supports internal testing of the chip; i.e., the output pins capture the current level on the corresponding internal line whereas all input pins are held on constant values ('0' or '1'). The resulting boundary scan vector is shifted to TDO. The next test vector is serially loaded via TDI. Then, all input pins are updated for the following test cycle.

**SAMPLE/PRELOAD** is a test mode which provides a snapshot of pin levels during normal operation.

**IDCODE:** A 32-bit identification register is serially read out via TDO. It contains the version number (4 bits), the device code (16 bits) and the manufacturer code (11 bits). The LSB is fixed to '1'.

#### **Standard Mode**

The ID code field is set to:

Version : 1<sub>H</sub>  
Part Number : 07F0<sub>H</sub>  
Manufacturer : 083<sub>H</sub> (including LSB, which is fixed to '1')

#### **Alternate Mode**

The ID code field is set to

Version : 1<sub>H</sub>  
Part Number : 07F0<sub>H</sub>  
Manufacturer : 083<sub>H</sub> (including LSB, which is fixed to '1')


Note: Since in test logic reset state the code '0011' is automatically loaded into the instruction register, the ID code can easily be read out in shift DR state.

**BYPASS:** A bit entering TDI is shifted to TDO after one TCK clock cycle.

**CLAMP** allows the state of signals driven from component pins to be determined from the boundary-scan register while the bypass register is selected as the serial path between TDI and TDO. Signals driven from the ABM-P will not change while the CLAMP instruction is selected.

**HIGHZ** places all of the system outputs in an inactive drive state.

## 10 Package Outlines



### Sorts of Packing

Package outlines for tubes, trays etc. are contained in our Data Book "Package Information".

SMD = Surface Mounted Device


Dimensions in mm

## 11 Glossary

AAL	<b>ATM Adaptation Layer</b>
ABM	<b>ATM Buffer Manager</b> device, PXB 4330E
ABM-P	<b>ATM Buffer Manager</b> device, PXF 4336
ABR	<b>Available Bit Rate</b>
ALP	<b>ATM Layer Processor</b> device, PXB 4350 E
AOP	<b>ATM OAM Processor</b> device, PXB 4340 E
ATM	<b>Asynchronous Transfer Mode</b>
BIST	<b>Built-In Self Test</b>
CAC	<b>Connection Acceptance Control</b>
CAME	<b>Content Addressable Memory Element</b> device, PXB 4360 E
CBR	<b>Constant Bit Rate</b>
CDV	<b>Cell Delay Variation</b>
CI/NI	<b>Congestion Indication/No Increase</b> (ABR connections: 2 Bits of a RM cell)
CLP	<b>Cell Loss Priority</b> of standardized ATM cell
CRC	<b>Cyclic Redundancy Check</b>
DBA	<b>Dynamic Bandwidth Allocation</b>
DSLAM	<b>Digital Subscriber Line Access Multiplexer</b>
dword	double word (32 bits)
EFCI	<b>Explicit Forward Congestion Indication</b> (ABR connections: Header-Bit of a data cell)
EPD	<b>Early Packet Discard</b>
ER	<b>Explicit Rate</b> (ABR)
FIFO	<b>First-In-First-Out</b> buffer
GFR	<b>Guaranteed Frame Rate</b>
I/O	<b>Input/Output</b>
ITU-T	<b>International Telecommunications Union—Telecommunications</b> standardization sector
LCI	<b>Local Connection Identifier</b>
LIC	<b>Line Interface Card</b> or <b>Line Interface Circuit</b>
LIFO	<b>Last-In-First-Out</b> buffer

LSB	<b>Least Significant Bit</b>
MBS	<b>Maximum Burst Size</b>
MCR	<b>Minimum Cell Rate</b>
MSB	<b>Most Significant Bit</b>
OAM	<b>Operation And Maintenance</b>
PCR	<b>Peak Cell Rate</b>
PHY	<b>PHYSical Line Port</b>
PPD	<b>Partial Packet Discard</b>
PTI	<b>Payload Type Indication</b> field of standardized ATM cell
QID	<b>Queue IDentifier</b>
QoS	<b>Quality of Service</b>
RAM	<b>Random Access Memory</b>
RM	<b>Resource Management Cell</b> (ABR connections)
RSC	<b>Reactive Switch Control</b> (ABR)
SCR	<b>Sustainable Cell Rate</b>
SDRAM	<b>Synchronous Dynamic Random Access Memory</b>
SID	<b>Scheduler IDentifier</b>
SSRAM	<b>Synchronous Static Random Access Memory</b>
TM	<b>Traffic Management</b>
UBR	<b>Unspecified Bit Rate</b>
UTOPIA	<b>Universal Test and OPeration Interface for ATM</b>
VBR-nrt	<b>Variable Bit Rate - non real time</b>
VBR-rt	<b>Variable Bit Rate - real time</b>
VC-	<b>Virtual Channel specific</b>
VCC	<b>Virtual Channel Connection</b>
VCI	<b>Virtual Channel Identifier</b> of standardized ATM cell
VP-	<b>Virtual Path specific</b>
VPC	<b>Virtual Path Connection</b>
VPI	<b>Virtual Path Identifier</b> of standardized ATM cell
VS/VD	<b>Virtual Source / Virtual Destination</b> (ABR)
WFQ	<b>Weighted Fair Queueing</b>
word	16 bits





## Infineon goes for Business Excellence

“Business excellence means intelligent approaches and clearly defined processes, which are both constantly under review and ultimately lead to good operating results.

Better operating results and business excellence mean less idleness and wastefulness for all of us, more professional success, more accurate information, a better overview and, thereby, less frustration and more satisfaction.”

Dr. Ulrich Schumacher



<http://www.infineon.com>

Published by Infineon Technologies AG