

TEMPERATURE COMPENSATED REAL TIME CLOCK REFERENCE DESIGN KIT USER'S GUIDE

1. Kit Contents

- Temperature Compensated RTC Evaluation Board
- AC to DC Power Adapter
- Straight DB9 serial cable (male-female)
- Straight DB25 parallel cable (male-male)
- Quick-start Guide
- Reference Design Kit CD-ROM containing the following items:
 - Temperature Compensated Real Time Clock Reference Design Programmer's Guide (AN293) and associated software (AN293SW.zip).
 - Keil Software 8051 Development Tools (evaluation assembler, 2 kB limited compiler, and linker).

2. Requirements

The Temperature Compensated Real Time Clock Reference Design Kit is a completely independent evaluation platform with preloaded firmware. The following are the only requirements to evaluate this reference design without any modifications to the firmware.

PC with the following features:

- Operating system: Windows 2000/XP/Server2003
- One available serial port
- One available parallel port (required to evaluate the optional SMBus/I²C interface)

Although the instructions in this user's guide are written for a PC running the Windows OS, PCs with other operating systems can also be used to evaluate this design as long as a serial port and a terminal program are available.

In order to modify, rebuild, and download code into the C8051F300 MCU on this evaluation board, the following additional items are required but not included in this kit:

- USB Debug Adapter and USB cable, or Serial Adapter and RS-232 serial cable
- Full version of Keil Software C51 assembler, compiler, and linker

The C8051F300DK Development Kit includes the USB Debug Adapter and USB cable along with a C8051F300-TB Target Board.

Note: A full version of the Keil tool chain is required in order to modify and recompile the code provided with this reference design because the code size is greater than the evaluation tool chain's code size limits. Alternatively, the source code can be ported to work with other 8051 tool chains that are supported by the Silicon Labs IDE. For a list of currently supported tool chains, please refer to the following MCU Knowledge Base Article: <u>http://portal.knowledgebase.net/article=173563&p=4120</u>

3. Kit Overview

The Temperature Compensated Real Time Clock (TC-RTC) Reference Design Kit includes an evaluation board that utilizes a Silicon Laboratories C8051F300 Mixed Signal Microcontroller. This kit offers the following features:

- Low-cost Temperature Compensated Real Time Clock and Calendar
- 56-byte General Purpose Non-Volatile RAM
- **RS-232 Serial Interface**
- Optional SMBus/I²C Interface
- Full source code for the TC-RTC firmware is included

The board is pictured in Figure 1, with the major components labeled. The MCU on the board is preloaded with the TC-RTC firmware with UART interface, and the included CD-ROM contains the firmware source code. More information about this reference design can be found in "AN293: Temperature Compensated Real Time Clock Reference Design Programmer's Guide." The following sections demonstrate the features of this reference design.




Figure 1. Temperature Compensated RTC Evaluation Board



2

4. TC-RTC Evaluation Board

The functions of the major components on the TC-RTC Evaluation Board that are labeled in Figure 1 are listed below. The board schematic and bill of materials are shown in Sections 7 and 8, respectively.

- C8051F300 MCU (U3)—Microcontroller with firmware to perform the TC-RTC function.
- 32.768 kHz Crystal (Y1)—This low-cost watch crystal is used for time keeping.
- DB9 connector (J5)—This is for the serial RS-232 connection.
- DB25 connector (J6)—This is for the optional parallel connection with SMBus interface.

In addition to these, a RS-232 transceiver and a buffer are used for the serial and SMBus interfaces, respectively.

5. TC-RTC Firmware

The clock accuracy of a time-keeping system based on a resonating quartz crystal is primarily affected by the variation of crystal frequency with respect to temperature. Figure 2 shows a plot of the variation of crystal frequency versus temperature. From the parabolic curve, it can be seen that the RTC will *lose* time if the temperature is increased or decreased from the room temperature value (25 °C). The RTC will never have a positive error caused by temperature variations (i.e., *gain* time) because the maximum frequency is at room temperature.




Figure 2. Crystal Frequency Variation Due to Temperature

The TC-RTC firmware running on the C8051F300 MCU eliminates this time loss because of temperature variations. It uses the on-chip ADC and temperature sensor to measure the temperature every minute and compensate for the lost time at the end of the day by adding the accumulated error to the RTC's reported time. This is explained in more detail in "AN293: Temperature Compensated Real Time Clock Reference Design Programmer's Guide".

The time maintained by the TC-RTC can be accessed via two interfaces—a RS-232 serial interface via a DB9 connector and an SMBus interface via a DB25 connector. The preloaded firmware is built to work with the RS-232 serial interface. Also included in the AN293SW.zip package is a pre-built OMF file, which enables the SMBus interface to the RTC when loaded into the device. The AN293SW.zip package contains the full source code as well.



6. TC-RTC Demonstration

The following step-by-step demonstration explains the various features and capabilities of this reference design. There are two interfaces available for the RTC—UART and SMBus, which are demonstrated in sections 6.1 and 6.2, respectively.

6.1. UART Interface Demonstration

The TC-RTC Evaluation Board comes preloaded with firmware that enables the UART interface. The following sections show how to set up and use this interface.

6.1.1. PC Software Setup

On the PC, set up HyperTerminal to use the COM port at 9600 baud, 8-N-1, and no flow control. Detailed instructions to set this up are shown below.

- 1. Launch HyperTerminal from your Start Menu: Start Menu→Programs→Accessories→Communications→ HyperTerminal.
- 2. Type any name for the new connection, and click OK.
- 3. In the "Connect using:" drop-down list, Choose "COM1", or if you have multiple COM ports, choose the one you want to use.
- 4. Set up the COM1 Properties dialog as shown in Figure 3, and click OK.
- 5. Select "File→Properties→Settings→ASCII Setup". Check the box marked "Echo typed characters locally", and click OK. See Figure 4.

COM1 Properties	? 🔀
Port Settings	
<u>B</u> its per second:	9600
<u>D</u> ata bits:	8
<u>P</u> arity:	None
<u>S</u> top bits:	1
<u>F</u> low control:	None
	<u>R</u> estore Defaults
	K Cancel Apply

Figure 3. HyperTerminal Settings



4

Connect To Settings	
Function, arrow, and ctrl keys act as Terminal keys Windows keys	
Backspace key sends O Ctrl+H O Del O Ctrl+H, Space, Ctrl+H	ASCII Setup ?
Emulation: Auto detect	 Send line ends with line feeds Echo typed characters locally Line delay: 0 milliseconds.
Telnet terminal ID: ANSI Backscroll buffer lines: 500	Character delay: 0 milliseconds.
Play sound when connecting or disconnecting Input Translation ASCII Setup	ASCII Receiving Append line feeds to incoming line ends Force incoming data to 7-bit ASCII Wrap lines that exceed terminal width
ОК	Cane OK Cancel

Figure 4. HyperTerminal ASCII Setup

6.1.2. Hardware Setup

- 1. Connect the provided DB9 serial cable between the PC's serial port and the TC-RTC evaluation board connector J5.
- 2. Apply power to the evaluation board using the provided dc power adapter.

6.1.3. Interacting with the TC-RTC

- 1. After the board is powered on for the first time, the board firmware will perform a temperature sensor/ADC offset calibration. For valid calibration, a soak period is required before the calibration is done. Wait for 15 seconds for calibration to complete. At the end of calibration, the green LED on the board will start blinking at a 1 Hz rate.
- 2. HyperTerminal should now be displaying initial date, time and temperature information from the board. You can program the current date and time data into the board. This data should be trans-coded to the format expected by the device firmware. Refer to "Appendix B—TC-RTC: Implementation Details" on page 12 for the data format. Note that the AM/PM information is encoded in the same byte as the hour. Here are some examples:

06:31:09 PM, Thursday, May 04, 2006→09 31 66 04 04 05 06

11:05:39 AM, Saturday, December, 08, 1979→39 05 51 06 08 12 79

- 3. Type the "s" command to *toggle off* the auto-display mode that displays the time once every second. Note that commands should be only in lower case.
- 4. Type the following "w" command (*write*) to program the device with a new time and date. See "Appendix A—TC-RTC: Supported Commands" on page 11 for command formats.

w000709316604040506

- 5. Type the "r" command (*read*) to get the current time and date information from the device. r0007
- 6. Type the "s" command to toggle on the auto-display mode.



Rev. 0.1

C-RTC Demo - HyperTerminal	
Eile Edit View Call Iransfer Help	
O0:00:01 Saturday, 01.01.2000 Temperature:27.99 deg C 00:00:02 Saturday, 01.01.2000 Temperature:27.99 deg C 00:00:03 Saturday, 01.01.2000 Temperature:27.99 deg C sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw000709316604040506r0007 22 31 66 04 04 05 06 sw00070931660440506r0007 22 31 66 04 04 05 06 sw00070931660440506r0007 22 31 66 04 104 05 06 sw00070931660440506r0007 104 05 2006 Temperature:27.99 sw00070931660440506r0007 22 30 60 Temperature:27.99 sw006:31:36 PM T	
	>
Connected 0:02:04 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print echo	

Figure 5. Interacting with the TC-RTC—HyperTerminal Session

An index of all supported commands is available in "Appendix A—TC-RTC: Supported Commands" on page 11. Detailed information about this reference design is contained in "AN293: Temperature Compensated Real Time Clock Reference Design Programmer's Guide".

6.2. SMBus Interface Demonstration

The TC-RTC Evaluation Board can be loaded with firmware that can enable an SMBus/I²C interface. This is described in the following sections.

6.2.1. Firmware Download

The TC-RTC Evaluation Board comes preloaded with firmware that enables the UART interface. In order to enable the SMBus interface, alternate firmware has to be loaded on the device. The steps in this section will guide you through downloading the TC-RTC firmware with SMBus interface to the TC-RTC evaluation board.

 Install the Silicon Laboratories IDE from the Reference Design Kit CD. Launch the IDE by choosing "Start Menu→All Programs→Silicon Laboratories→Silicon Laboratories IDE". If you need more information about installing and using the IDE, please refer to the C8051F300DK Development Kit User's Guide, which is available on this web page:

http://www.silabs.com/tgwWebApp/public/web_content/products/Microcontrollers/en/C8051F300DK.htm

2. Depending on which type of debug adapter you have, set up the hardware as shown in one of the two diagrams below (Figure 4, Figure 5). Consult the C8051F300DK User's Guide if you need detailed instructions.






Figure 6. Hardware Setup using a Serial Adapter




Figure 7. Hardware Setup using a USB Debug Adapter

- 3. Before connecting to the target device, several connection options may need to be set. Open the "Connection Options" window by selecting "Options→Connection Options..." in the IDE menu. First, select the adapter that you are using in the "Serial Adapter" section. Next, the correct "Debug Interface" must be selected. C8051F30x family devices use the Silicon Labs 2-wire (C2) debug interface. Once these selections are made, click the OK button to close the window.
- 4. Click the "Connect" button in the toolbar or select "Debug→Connect" from the menu to connect to the device. You will see the text "Target: C8051F300" in the status bar of the IDE if the connection was successful.
- Choose the "Project→Download Object File..." option. This shows a "Download" dialog. Click the "Browse" button and select the TC-RTC firmware pre-linked OMF file from this path: C:\Silabs\MCU\TemperatureCompensated RTC RD\Firmware\TEMPCOMPRTC RD SMBUS.OMF
- 6. Click the "Download" button to download this firmware to the 'F300 device. You will see the text "Download successful" in the Build window if the firmware was downloaded successfully.
- 7. Disconnect the dc power adapter and the ribbon cable from the target board.

6.2.2. Hardware Setup

- 1. Connect the DB25 parallel cable provided with the kit between the PC's parallel port (printer port) and the 25-pin connector on the TC-RTC Evaluation board (J6).
- 2. Apply power to the board by connecting the dc power adapter.



6.2.3. Interacting with the Windows SMBus Test Software

The TC-RTC Evaluation Board with the SMBus firmware enables an SMBus/I²C interface to the RTC. In order to test this interface, PC software is provided that emulates an SMBus master via the PC's parallel port.

- 1. The PC Software is installed as part of the TC-RTC RD installation from the Reference Design Kit CD. Launch this by selecting the following: Start Menu→All Programs→Silicon Laboratories→TC-RTC SMBus Test.
- 2. Make sure that the green LED is blinking on the board, and then click the "Refresh All" button. This updates all the values shown.
- 3. Modify any value(s) that you would like to modify, and click the corresponding "Write", "Write NVRAM", or "Write Selected" button. This will write the value(s) to the board.
- 4. Clicking the "Read" button will read the current values from the board.
- 5. Check the "Auto-refresh Time/Date" check box to automatically update values every second. Note that when this is checked, the other read/write buttons are disabled.

🔯 TC RTC SMBUS Test											
<u>File</u> <u>H</u> elp											
Time (hh:mm:ss) 08 : 16 : 19 PM -	-	Refresh All						-	Write NVRAM		
✓ 12-Hours format		✓ Display all memory Write Selected									
Read Write		00		02			05				
	00	19	16	68	05	08	12	06	00	h	
Date (dd/MM/yyyy)	08	FF	FF	FF	FF	FF	FF	FF	FF	<u> </u>	
08 / 12 / 2006	10	FF	FF	FF	FF	FF	FF	FF	FF	<u> </u>	
Read Write	18 20	FF	FF FF	FF FF	FF FF	FF FF	FF FF	FF FF	FF FF	999999999	
	28	FF	FF	FF	FF	FF	FF		FF	999999999 999999999	
Auto-refresh Time/Date	30	FF	FF	FF	FF	FF	FF	FF	FF	999999999	
Enabled	38			FF	FF	FF	FF	FF	FF	99999999	
Every: 1 🚖 second(s)	Registers										
		-			7					0	
		SI	ECO	NDS			0 1		0 0		
		м	INL	ITES	; [0		0 1	0	1 1		
			HO	URS	i 0	1	1 0	1	0 0	0	
Temperature 25.93				DA		0	0 0	0	1 0) 1	
Accumulative			D	ATE		0	0 0	1	0 0	0 0	
345			MO	NTH	1 0	0	0 1	0	0 1	0	
S mS uS			Y	EAR	1	0	0 0	0	1 1	0	
		C	DNT	ROL	. 0	0	0 0	0	0 0	0 0	


Figure 8. TC-RTC SMBus Interface Test Software

This PC software is provided solely for test and demonstration purposes. In a real application, the 'F300 device with the TC-RTC firmware is meant to be connected to other microcontrollers that have an SMBus interface. Refer to "AN293: Temperature Compensated Real Time Clock Reference Design Programmer's Guide" for more details on the SMBus interface implementation.



8

7. Schematic



SILICON LABORATORIES Downloaded from <u>Elcodis.com</u> electronic components distributor

TEMPCOMPRTC-RD

8. Bill of Materials

ltem	Qty	Reference	Value	Туре	Manufacturer	P/N	Footprint	
1	13	C1,C2,C4,C6,C10 C12,C13,C14,C15 C16,C17,C18,C19	0u1F	X7R	AVX			
2	2	C11,C20	1u0F	X7R	AVX	0805YC105MAT2A	0805	
3	1	C3	1000uF/16V	Electrolit	SANYO	16MV1000FA	CAPMV-FA_10_125	
4	1	C7	33uT/25V	Tantalum	Vishay	293D336X9025D2T	Case-D	
5	1	C5	2u2F	X7R		0805YC225MAT2A	0805	
6	2	C8,C9	18pF	NPO	AVX	0805YA180MAT2A	0805	
7	1	D1	B140		Diodes Inc.	B140	SMA	
8	1	D2	Red		Kingbright	L-7104EC	LED_3mm	
9	1	D3	Green 2mA		Kingbright	L-934LGD	LED_3mm	
10	1	J1	HEADER 6X2		Weitronics	144-11-012-10-10	HED6x2	
11	1	J2	HEADER 2		Weitronics	143-11-002-10-10	HED2	
12	1	J3	HEADER4X2		Weitronics	144-11-008-10-10	HED4x2	
13	1	J4	Box 10pin		Molex	87256-1011	BOX5x2	
14	1	J5	DB9 Female RA	D-Type	Kycon	K22-E9S-NJ	d_type_9P	
15	1	J6	DB25Female RA	D-Type	Kycon	K22-E25S-NJ	d_type_25P	
16	1	P1	PHONEJACK		Kycon	RTC Commp	CONPWR	
17	2	R2,R23	2R		AVX	CR-21-200J-T	0805	
18	2	R4,R5	100R		AVX	CR-21-101J-T	0805	
19	1	R3	470R		AVX	CR-21-471J-T	0805	
20	3	R10,R14,R15	1K		AVX	CR-21-102J-T	0805	
21	1	R16	100K		AVX	CR-21-105J-T	0805	
22	6	R8,R9,R11,R12,R 21,R22	10K		AVX	CR-21-104J-T	0805	
23	1	R13	10M		AVX	CR-21-107J-T	0805	
24	1	R17	750R		AVX	CR-21-751J-T	0805	
25	1	R18	4K75		AVX	CR-21-4751J-T	0805	
26	2	R19,R20	33R		YAGEO	RC2512-330	2512	
27	2	SW1,SW2	PUSHBUTTON		Bourns	SDTX-610	PB-TC0112	
28	6	TP31,TP33,TP36, TP37,TP41,TP53	Test point	SMT	Keystone	5015	SMT-TP	
29	1	U1	L4931CD33		STG	L4931CD33	SO-8	
30	1	U3	C8051F300		Silicon Labs	C8051F300	QFN-11	
31	1	U4	74LCX07		National	LM339	SO-14	
32	1	U5	MAX3224		Maxim	MAX3224E	SSOP-20	
33	1	Y1	32.768 kHz		Gollege	SM26F-A	GWX-38	



APPENDIX A-TC-RTC: SUPPORTED COMMANDS

TC-RTC Firmware with UART Interface

The TC-RTC firmware with UART interface supports a set of commands to read/write date and time. The supported commands along with explanations are listed below:

- s Toggles auto-display mode that displays time once every second.
- w xx yy data Write yy bytes starting at address xx.

Notes:

- **1.** The commands are case-sensitive. Only lower-case letters are accepted.
- 2. The addresses should be in decimal format (e.g., address 0x1F is entered as 31).
- 3. See "Appendix B—TC-RTC: Implementation Details" for information on how the RTC register data is formatted.

Write Command Examples

- Date/Time: 11:05:39 AM, Saturday, December, 08, 1979→39 05 51 06 08 12 79 w000739055106081279
- Time: 21: 48: 22→22 48 21 w0003224821
- Day: Tuesday→02 w030102
- NVRAM data write: 01 02 03 starting at address 0x1F (31)→31 01 02 03 w3103010203

Read Command Examples

- Date/Time: r0007
- NVRAM (all 56 bytes): r0856
- NVRAM (4 bytes starting at address 26): r2604

TC-RTC Firmware with SMBus Interface

The TC-RTC firmware with the SMBus interface implements a SMBus Slave device with a Slave Address of 0xD0. The device operates in one of two modes: Slave Receiver Mode or Slave Transmitter Mode. In Slave Receiver Mode, it receives address and data from the Master and writes it to the RTC or NVRAM registers. In Slave Transmitter Mode, it sends data from the RTC or NVRAM registers to the Master. Refer to "AN293: Temperature Compensated Real Time Clock Reference Design Programmer's Guide" for more details on the SMBus interface implementation.



TEMPCOMPRTC-RD

APPENDIX B—TC-RTC: IMPLEMENTATION DETAILS

UART Communication Parameters

- Baud rate: 9600 bps
- Data format: 8 data bits, 1 stop bit, no parity
- Flow control: None

RTC and NVRAM Registers—Data Format

Address	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Range			
00H	СН		Seconds									
01H	0		Minutes									
02H	0	12 / 24	Hours									
03H	0	0	0	0	0	Da	y of W	eek	1-7			
04H	0	0	0 Date									
05H	0	0	0 0 Month									
06H			Year									
07H												
08H												
3FH												

Figure 10. RTC and NVRAM Registers—Data Format

Notes:

- 1. The contents of the time and calendar registers are in binary coded decimal (BCD) format.
- 2. The Clock Halt (CH) bit, when set to zero, will disable the RTC.
- 3. The 12/24 bit selects 12-hour mode if set to one.
- 4. In 12-hour mode, the AM/PM bit selects "PM" if set to one. In 24-hour mode, this bit is the second 10-hour bit (20-23 hours).



NOTES:

Contact Information

Silicon Laboratories Inc.

4635 Boston Lane Austin, TX 78735 Email: MCUinfo@silabs.com Internet: www.silabs.com

The information in this document is believed to be accurate in all respects at the time of publication but is subject to change without notice. Silicon Laboratories assumes no responsibility for errors and omissions, and disclaims responsibility for any consequences resulting from the use of information included herein. Additionally, Silicon Laboratories assumes no responsibility for the functioning of undescribed features or parameters. Silicon Laboratories reserves the right to make changes without further notice. Silicon Laboratories makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Silicon Laboratories assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Silicon Laboratories products are not designed, intended, or authorized for use in applications intended to support or sustain life, or for any other application in which the failure of the Silicon Laboratories product could create a situation where personal injury or death may occur. Should Buyer purchase or use Silicon Laboratories products for any such unintended or unauthorized application, Buyer shall indemnify and hold Silicon Laboratories harmless against all claims and damages.

Silicon Laboratories and Silicon Labs are trademarks of Silicon Laboratories Inc.

Other products or brandnames mentioned herein are trademarks or registered trademarks of their respective holders.

