



PE Platform Setup

PROPELLER EDUCATION KIT LAB SERIES


Introduction

The Propeller Education (PE) Kit Platform and Propeller Plug USB to serial converter/programming tool are shown in Figure 1. The PE Platform is an array of breadboards with a Propeller™ microcontroller in the center along with support circuits that make it a convenient and reusable project platform. The support circuits include:

- 5.0 V and 3.3 V voltage regulators
- EEPROM for non-volatile program storage
- 5 MHz external crystal oscillator for precise clock signal
- Reset button for manual program restarts
- LED power indicator
- 9 V battery-to-breadboard connector
- 4-pin Propeller Plug header for program downloads and bidirectional communication with the PC.

In this lab, you will assemble the PE Platform and run a test program to verify that the platform is correctly wired and fully functional. If there is a wiring error, you will also perform the troubleshooting steps necessary to find and correct the error.

Figure 1: PE Kit Platform



Prerequisites

These labs assume prior microcontroller experience. Although this first lab provides wiring diagrams, future labs will not. As a minimum, you should have experience building circuits from schematics as well as experience with some form of computer or microcontroller programming language.



Resources for Beginners: For introductions to building circuits, microcontroller programming, and much more “prior microcontroller experience”, try either the BASIC Stamp Activity Kit or BASIC Stamp Discovery kit. Both kits have everything you’ll need to get started, including a BASIC Stamp 2 microcontroller, project board, the introductory level *What’s a Microcontroller?* text and parts for every activity. The *What’s a Microcontroller?* text is also available for free PDF download from www.parallax.com, and both kits are available for purchase from the web site as well as from a variety of electronics retailers and distributors. To find a retailer or distributor near you, check the Distributors list under the Company category at the Parallax web site.

Procedure Overview

The goal of this lab is to prepare the PE Platform for use with future labs by following these steps:

- Taking an inventory of equipment and parts
- Installing the Propeller Tool (v1.0 or newer) software
- Assembling the PE Platform
- Testing power and programming connections
- Testing the crystal oscillator and the programming connections to EEPROM.
- Testing I/O pins as both inputs and outputs
- Troubleshooting if necessary

Since the PE Platform will be the microcontroller system at the heart of the forthcoming lessons and labs, all its circuits should be tested. This will help rule out potential wiring errors, which can easily slip by unnoticed as you build the PE Platform circuits.

Equipment and Parts

You will need the following to complete this lab:

- Computer with Microsoft Windows 2000 or XP, and an available USB port
- PE Platform Parts listed in Table 1

The following equipment is optional, but extremely useful:

- Needle-nose pliers and wire cutter/stripper
- Voltmeter
- Digital storage oscilloscope
- Antistatic mat and bracelet



ESD Precautions : Electrostatic discharge (ESD) can damage the integrated circuits (ICs) in this kit. If you have an antistatic bracelet and mat, use them. If you don’t, handling the gray bag and black foam before handling the ICs will greatly reduce the possibility of a static zap that could damage the components. Another strategy to reduce the risk is to handle ICs by their black plastic cases and avoid touching their metal pins.

| Table 1: Parts List – PE Platform | | |
|--|-----------------|---|
| Part Number | Quantity | Description |
| 130-32305 | 1 | Propeller DIP Plus Kit (See Table 2 for this kit's parts list.) |
| 32201 | 1 | Propeller Plug USB/Serial converter + USB cable |
| 700-00077 | 3 | Breadboards, Prototyping (30 rows x 12 columns) |
| 700-00081 | 4 | Breadboards, Power Rail (26 rows x 2 columns) |

| Table 2: Parts List - Propeller DIP Plus Kit (130-32305) (Parts and quantities subject to change without notice) | | |
|--|-----------------|--|
| Part Number | Quantity | Description |
| 571-32305 | 1 | 9 V battery clip |
| 201-01085 | 2 | Capacitor, Electrolytic, 6.3 V, 1000 μ F |
| 201-04740 | 1 | Capacitor, Electrolytic, 25 V, 0.47 μ F |
| 150-01011 | 1 | Resistor, CF, 5%, 1/4 watt, 100 Ω |
| 150-01030 | 1 | Resistor, CF, 5%, 1/4 watt, 10 k Ω |
| 251-05000 | 1 | Crystal 5.000 MHz, 20 pF, HC-49/ μ s |
| 350-00001 | 1 | LED Green T1 3/4 |
| 400-00002 | 1 | Pushbutton - normally open |
| 451-00302 | 1 | 2-pin m/m header |
| 451-00406 | 1 | Extended right angle m/m 4 pin header with 0.1 spacing |
| 601-00513 | 1 | 3.3 V regulator, TO92 package |
| 601-00506 | 1 | 5.0 V regulator, TO92 package |
| 602-00032 | 1 | 32 kB EEPROM, DIP-8 |
| 800-00016 | 6 | Bags of 10 Jumper Wires |
| P8X32A-D40 | 1 | Propeller Chip P8X32A - 40 pin DIP |
| 120-00003 | 1 | Propeller DIP pin map sticker |

- ✓ Take an inventory of the components in the Propeller DIP Plus Kit. If anything is missing, replacement parts can be obtained from www.parallax.com using the part numbers shown.

Software and Driver Installation

The Propeller Tool software is available for download from the Parallax web site. One of its default installation features is the USB drivers for the Propeller Plug communication and programming tool. When you install the software, it will also install the USB drivers your PC will need to communicate with the Propeller Plug by default.

- ✓ Download Setup-Propeller-Propeller-Tool-v1.0.exe (or newer) from www.parallax.com.
- ✓ Run the setup program to install the Propeller Tool software and FTDI USB drivers for PC to Propeller Plug communication.
- ✓ Connect the Propeller Plug to your PC with the USB cable, keeping an eye on its parts side. If the connection works, you should see a brief flicker from both the blue and red communication monitor LEDs on the Propeller Plug. Your computer may also play a tone or display a message indicating that your driver is installed and ready to use. No apparent connection? Go to Troubleshooting entry (1) on page 11.

Propeller Platform Assembly

Figure 2 shows a schematic of the PE platform, and Figure 3 shows a recommended wiring diagram. Notice that the board in the wiring diagram is tight-wired, with all the wires cut to length to be flush with the breadboard surface. This will make it easier to identify and remove loose-wired project circuits without having to worry about potentially removing a part or wire that's integral to the PE Platform.



Recommended reading: *Propeller Manual v1.0* pages 13 - 17.

- ✓ Do not plug in the battery, Propeller Plug, or Propeller chip until instructed to do so.
- ✓ Connect the interlocking breadboards together as shown in Figure 3, making sure the numbers and letters are oriented the same way as in the figure.
- ✓ Build the circuit in Figure 2, using Figure 3 as a placement guide. (Remember to leave out the battery, Propeller Plug, and Propeller chip for now).

Figure 2: Schematic – Propeller DIP Plus Kit






Figure 3: Wiring Diagram – Propeller DIP Plus Kit



See it in color: This file is available in color as a free pdf download from the Propeller Education Kit (32305) product page at www.parallax.com.

Connection Testing

It's important to eliminate all wiring mistakes before connecting power to the PE Platform. By double-checking your wiring and running a few simple tests, you can in many cases catch a mistake that might otherwise have caused your system not to work or even damage your components. To start, let's look at the design of these breadboards since they are integral to all of the circuits.

Wiring

Each socket on each 12-column × 26-row prototyping breadboard has a letter for the column and a number for the row. For example, the 9 V battery's positive terminal wire plugs into the center breadboard's (L, 1) (column L, row 1) and its negative terminal plugs into (L, 2). The 2 × 26 power rails' rows line up with the numbers on the prototyping breadboards. Red and black lines indicate the column designation in the power rails. For example, the coordinates of the LED's anode is (RED, 10) and the coordinates of the top-left capacitor's negative terminal is (BLACK, 1).

The red and black lines on the power rails also indicate continuity for power distribution. Unlike the prototyping breadboards, which are grouped into 6-socket-wide rows each with a metal bracket underneath, the power rails have only three metal brackets. A single metal bracket connects the entire column of sockets adjacent to the black line. This typically serves as a common ground, and each negative rail is connected to the battery's negative terminal on the PE Platform.



Vss and GND; Vdd and 3.3V: The Propeller chip's GND pin is referred to as Vss in the Propeller Manual; Vdd is +3.3 V.

The column adjacent to the red lines has two separate metal brackets underneath instead of just one. The upper twelve sockets next to the red line are grouped together, but are not connected to the lower twelve, and the break in the red line next indicates the break in continuity. The breadboard is designed this way to accommodate two separate voltage supplies on the same power rail. This feature is not used now, so all the positive power rails are shorted together with jumper wires. In later labs, you may end up removing one or more jumpers for dual supply applications.

- ✓ Make a printout of Figure 3, and verify each connection by drawing over it with a highlighter pen after you have checked your wiring against the diagram, matching the coordinates of each socket against the coordinates shown in the figure.
- ✓ Verify that the LM2940 5 V regulator output capacitor's negative terminal is connected to (BLACK, 1) and that the LM2937 3 V regulator's output capacitor's negative terminal is plugged into (K, 6) or (K, 7)



WARNING: Reverse voltage across the electrolytic capacitors can cause them to rupture or in some cases explode. The electrolytic capacitor's negative terminals (denoted by a stripe with negative signs) should always be connected a lower voltage than their positive terminals. The electrolytic capacitors' negative terminals should be connected to the PE Platform's negative power rail. This power rail is connected directly to the battery supply's negative terminal.

- ✓ Verify that the Power LED's anode terminal is connected to (RED, 10).

Power Supply

- ✓ Connect the battery to the battery holder as shown in Figure 3. The power LED should glow brightly. If it does not, unplug it immediately and go to Troubleshooting entry (2) on page 11.
- ✓ If you have a voltmeter, make sure to test the voltage difference between the four red/black vertical power rails. Each should measure 3.3 V. If the voltage is incorrect, go to Troubleshooting entry (3) on page 11.
- ✓ If you have an oscilloscope, examine the total power supply noise. With a 9 V battery input, it should fall in the 50 mV neighborhood. (Example settings: 10 mV x 10 ms / division, AC coupled, Auto Store enabled to capture and hold transients for several minutes.) What happens to the total noise if you place the 0.47 μ F capacitor across the power rails?
- ✓ **Disconnect the battery from the clip!**



The 0.47 μ F capacitor should be placed across the 9 V power input if you are using a 6-9 VDC supply that plugs into the wall.

Socket the Propeller Chip

- ✓ Identify the orientation of the chip's and sticker's reference notches against Figure 3.
- ✓ Affix the pinout sticker to the Propeller chip, making sure that the reference notch on the sticker is oriented the same way as the reference notch on the chip.
- ✓ Disconnect both the battery and the Propeller Plug.
- ✓ Plug the Propeller chip into the breadboard, verifying its orientation as shown in Figure 3.
- ✓ Plug in the battery and verify that the LED power light glows brightly, as in your earlier battery test. If it does not, disconnect the battery immediately, and go to Troubleshooting entry (4) on page 11.

Programming Connection

- ✓ Disconnect the battery, and plug in the Propeller Plug onto the 4-pin header as shown in Figure 3, with the label side down. The power LED on the breadboard should glow dimly. If it does not, go to Troubleshooting entry (5) on page 11.

System Testing

The PE Platform is a microcontroller system very similar to the ones you'll find in common products and specialized equipment. The subcircuits and complete designs of many such products are prototyped, tested, modified and refined using pluggable breadboards before they are mass-produced as one or more printed circuit boards and housed in metal or plastic cases.

The PE Platform itself has a number of subcircuits, including the Propeller chip itself, voltage regulators, oscillator, EEPROM, power indicator, reset button and programming connections. All these subsystems need to be tested to make sure that the PE Platform will perform correctly through the upcoming labs. For these tests, a couple of simple circuits will be built on the PE Platform, and a test program will be downloaded to and executed by the Propeller chip. By modifying both the test circuit and test program, you will be able to verify all the PE Platform's subsystems.

Test the Programming Connection

The first test uses the Propeller Tool software's Identify Hardware feature. The battery should be connected, and the Propeller Plug should be connected to the 4-pin header and your PC via the USB cable.

- ✓ Open the Propeller Tool, then from the *Run* menu select *Identify Hardware...* (or Press F7.)

An information window will appear with one of two messages:

- "Propeller Chip version 1 found on COM..."
- "No Propeller Chip found on any COM port. Scanned COM..."

When this feature is used, the Propeller Tool searches the available COM ports for a serial connection to a Propeller chip. If the "Propeller...found..." message appears, it verifies three things: (1) The USB virtual com port (VCP) driver is properly installed, (2) the Propeller Plug is functioning and connected to the PC's USB port, and (3) the PE Platform's 4-pin Propeller Plug port is correctly wired to the Propeller Chip. On the other hand, if the "No Propeller...found..." message appears, there is a problem somewhere in the communication stream. In that case, Troubleshooting entry (6) on page 11.

Test Circuit Parts List

For the next test circuits, you will need the following parts from the PE Project Parts bag:

- (1) LED - Red, green or yellow
- (1) Resistor - 100 Ω
- (1) Resistor - 10 k Ω
- (1) Pushbutton
- (4) Jumper wires

Build the Test Circuit

The circuit shown in Figure 4 and Figure 5 will provide a means of testing the Propeller chip's I/O pins as both inputs and outputs. If any of the checklist instructions do not work, go to Troubleshooting entry (7) on page 12.

- ✓ Build the circuit shown in Figure 4 and Figure 5.
- ✓ Connect the 9 V battery
- ✓ Disconnect the LED wire from (L, 14) in Figure 5, and plug it into (RED, 13) on the power rail between the center and left prototyping breadboards. The LED should light. If it doesn't double check your wiring, and especially check if the LED is plugged in backwards.
- ✓ Disconnect the wire from (RED, 13), and plug it into (RED, 12) on the leftmost power rail. The LED should glow again.
- ✓ Disconnect the LED wire from (RED, 12) and reconnect it to the Propeller chip's P3 I/O pin. For this, you've got a choice of (L, 4), (K, 4), or (I, 4).

Figure 4: Test Circuit Schematic





Figure 5: Test Circuit Wiring Diagram



Test Program – PushbuttonLedTest.spin

This program will test the PE Platform's EEPROM and external oscillator circuits as well as the I/O pins as outputs, and you will modify it to test the I/O pins as inputs. For a new, factory-tested Propeller chip the I/O pin testing may seem unnecessary, however, if this platform was used by a student during the previous semester, or you purchased the kit used, it will be especially important. In any case, subsystem and I/O pin testing before building experimental circuits is a good engineering habit.

As written, PushbuttonLedTest.spin flashes an LED connected to any I/O pin on the Propeller chip's left side (P0 to P15), at a rate of 10 Hz if the pushbutton connected to P18 is not pressed, or at 4 Hz if it is pressed. The fact that the LED blinks confirms the oscillator is working properly, since the program causes the Propeller chip to use it for a clock signal. Next, the lead that connects P3 to the LED circuit can be connected to P0, then P1, etc, through P15, and it should blink at 10 Hz at each probe point, or 2 Hz if the button is pressed. This will test the output function of those pins.



How PushbuttonLedTest.spin works will be explained in later labs.

When the Propeller Tool's *Identify Hardware...* feature works, it indicates that the transmit, receive and reset wiring is all correct. If you have confirmed this, you will be able to download programs to the Propeller chip's RAM using the *Run* → *Compile Current* → *Load RAM* feature (F10). However, we will use PushbuttonLedTest.spin to test whether the EEPROM was correctly wired by using the Propeller Tool's *Load EEPROM* feature (F11).

```
Propeller Tool - PushbuttonLedTest.v1.0
File Edit Run Help
PushbuttonLedTest.v1.0
Full Source Condensed Summary Documentation
File: PushbuttonLedTest.spin
Test program for the Propeller Education Lab "PE Platform Setup"

CON
  _clkmode      = xtall + pll16x      ' Feedback and PLL multiplier
  _xinfreq      = 5_000_000          ' External oscillator = 5 MHz

  LEDS_START    = 0                  ' Start of I/O pin group for on/off signals
  LEDS_END      = 15                 ' End of I/O pin group for on/off signals
  PUSHBUTTON    = 18                 ' Pushbutton Input Pin

PUB ButtonBlinkSpeed                  ' Main method
  ' Sends on/off (3.3 V / 0 V) signals at approximately 2 Hz.

  dira[LEDS_START..LEDS_END]~~~      ' Set entire pin group to output

  repeat                               ' Endless loop
    ! outa[LEDS_START..LEDS_END]      ' Change the state of pin group

    if ina[PUSHBUTTON] == 1            ' If pushbutton pressed
      waitcnt(clkfreq / 4 + cnt)       ' Wait 1/4 second -> 2 Hz
    else
      waitcnt(clkfreq / 20 + cnt)      ' If pushbutton not pressed
                                        ' Wait 1/20 second -> 10 Hz

7:74 Insert
```



You can download `PushbuttonLedTest.spin` from the Propeller Education Kit product page at www.parallax.com. Then, simply drag and drop it onto the Propeller Tool's Edit Pane to open it.

- ✓ Open `PushbuttonLedTest.spin` into the Propeller Tool, or type it in. If you type, be careful to indent each line exactly as shown.
- ✓ Click the Propeller Tool's *Run* menu and select *Compile Current* → *Load EEPROM* (F11).

The Propeller Communication window will appear briefly and display the progress. If it closes after the “Verifying EEPROM” message, then the download was successful. If instead an error window opens that reads “EEPROM programming error...”, refer to Troubleshooting entry (8) on page 12.

- ✓ Verify that the LED flashes on/off rapidly, at 10 Hz.
- ✓ Press and hold the pushbutton down, and verify that the LED flashes slower, at only 4 Hz.
- ✓ If everything worked as anticipated, go on to I/O Pin Tests below. If it did not work, go to Troubleshooting entry (9) on page 12.

I/O Pin Tests

If you are inheriting this platform from a student who has already taken the class you are starting, it is especially important to take some time now to confirm all the I/O pins are functioning correctly, both as outputs and inputs. We will use the LED circuit to test each of the I/O pins' output function on the Propeller's left side (P0 to P15). Since they all send the same signal as P3, each one should make the LED circuit blink. After that, the pushbutton can be iteratively rewired to different I/O pins on the right. `PushbuttonLedTest.spin` has to be modified and downloaded to the propeller to test each wiring change. Once the left side has been tested as outputs and the right as inputs, the circuits can be swapped so that the left side can be tested as inputs and the right side as outputs. If any of these tests indicate that an I/O pin is faulty, refer to Troubleshooting entry (10) on page 12.

- ✓ Use the wire connecting P3 to probe P0 through P15. Each I/O pin should cause the LED circuit to blink the same way it does when it's connected to P3.
- ✓ Unplug the pushbutton wire at P18, and plug it into P16.
- ✓ Change the CON directive `PUSHBUTTON` from 18 to 16.
- ✓ Run the modified program and verify that a pushbutton connected to P16 still controls the LED frequency.
- ✓ Repeat this procedure for P17, P19, P20, and so on, up through P27. Using F10 to download to RAM instead of EEPROM will make this go faster.
- ✓ Disconnect the battery, and remove the pushbutton and LED test circuits from the board.
- ✓ Reconnect the battery and Propeller plug.
- ✓ Change the CON directives `LEDs_START` and `LEDs_END` from 0 and 15 to 16 and 27.
- ✓ Change the `PUSHBUTTON` directive from 18 to 13.
- ✓ Download the modified program.
- ✓ Disconnect the battery, then rebuild the test circuits on opposite sides of the board from what's shown in Figure 5. The pushbutton should be connected to P13, and the LED should be used to probe I/O pins from P16 to P27.
- ✓ Reconnect the battery. The LED frequency should again be controlled by the pushbutton.
- ✓ Repeat the output tests for P16 to P27 and the input tests for P0 to P15.
- ✓ Also use the LED to probe the positive supply rails on the right side of the board.

An Empty Program for the Next Circuit

Whenever you change a prototype circuit, it's a good idea to load a program that doesn't do anything to the I/O pins into the propeller. This reduces the risk of the Propeller chip inadvertently sending a high signal to a circuit that is sending a low signal, or visa versa. In either case, if no resistor is in series, it could result in a damaged Propeller chip, or a damaged circuit, or both. Loading an "empty" program now in anticipation of building new circuits in the future will help protect your Propeller chip. Ending your experiments this way is a good habit.

- ✓ Enter and run this program:

```
'' File: DoNothing.spin
PUB main                               ' Empty main method
```

Troubleshooting

Here are a list of symptoms and possible causes.

- (1) If there is no apparent communication when you plug the Propeller Plug into the PC's USB port, follow the USB link on the Parallax home page. It will take you to the Installing USB Drivers Page. If the steps on that page don't fix the problem, follow the Troubleshooting link at the bottom of that web page.
- (2) If the PE Platform's power LED did not light when the battery was connected:
 - a. The LED may be plugged in backwards. Check to make sure the cathode is connected to the resistor and the anode is connected to the 3.3 V supply rail. In other words, the pin coming out by the flat spot at the base of the LED's round plastic housing should be plugged into (L, 10), and the other pin should be connected to (RED, 10).
 - b. The battery leads may be plugged into the breadboard backwards. The battery's + terminal should connect to (L, 1) and the - terminal should connect to (L, 2).
 - c. There could be a wiring mistake causing a short circuit from one of the supply voltages to ground. If you don't have a multimeter, start visually checking your wiring again. With a multimeter, you can check the resistance between the battery's negative terminal, and the 3 V power rail. Repeat for 5 V regulated output (G, 3) and for the battery inputs (G, 1). If any of these shows less than 1 Ω , that supply voltage has been shorted to ground.
- (3) If the voltage across the power rails is not 3.3 V, the most common culprits are faulty wiring and a faulty meter. If your meter is a lesser-quality model or has been subject to heavy use by other students, check it against a known voltage before trusting its measurements. Assuming the voltmeter's measurements are correct, check wiring, part placement, and part orientation.
- (4) If the Power LED does not light when you plug the battery in after socketing the Propeller chip, check for wiring errors to its pins. If a wire terminates at a row that is shared with a Propeller chip I/O pin, it's a prime suspect.
- (5) If the Power LED does not glow faintly when you connect the Propeller Plug to the 4-pin header, double-check the wiring of the header. The header should be placed in (A, 1) through (A, 4). The TX pin of the Propeller Plug, (A, 2) must be connected to P31 of the Propeller chip, which is accomplished with the jumper wire connecting (C, 2) and (C, 11).
- (6) Common causes of the "No Propeller Chip found..." message are:
 - a. Battery disconnected. Connect the battery.
 - b. Propeller Plug plugged in upside down. The parts side of the Propeller plug should be facing up, and the logo side with the socket labels should be facing the breadboard.
 - c. Propeller Plug not plugged in to USB port.

- d. Propeller chip not fully socketed. The underside of the Propeller chip should be flush with the top of the breadboard. If not, make sure all the pins are lined up with the breadboard holes, then press down firmly on the Propeller chip.
 - e. FTDI USB drivers not installed. See entry (1) in this section.
 - f. Supply voltages – if you didn't check the voltages with a voltmeter, it's time to get one and do that. If the supply voltages are incorrect, see entry (3).
 - g. Propeller chip plugged in upside down. Check the top of the propeller chip, under where the semicircle is on the sticker. Is the chip's reference notch there? The reference notch should be on the end of the chip that is closest to the EEPROM and voltage regulators, in the neighborhood of row 11, not row 30.
- (7) If the LED does not light up when you plug the jumper wire into (RED, 13), the polarity on the LED may be backward. Check to make sure the LED's cathode is connected to a socket on the power rail next to the black line. If the LED did not light up when probing the power rail on the left, check the jumper that connects the red column between the left and center breadboards to the red column on the far left power rail.
 - (8) If you get an "EEPROM programming error..." message when you use the Propeller Tool's Load EEPROM feature, check the various EEPROM connections. Also verify that Pin 1 of the EEPROM, denoted by a dot on the case, is inserted into (G, 6), that is, make sure it is not inserted upside down. Also, verify that all the pins on the left side of the chip are tied to GND.
 - (9) If you hand entered the program, download it from the Propeller Education Kit page instead. Open it with the Propeller Tool software, and use F11 to download it to EEPROM. This will eliminate the possibility of a clerical error during program entry. If the LED does not start flashing, check the oscillator connections (XO and XI). If the LED circuit turns on and stays on with no blinking, there may be an issue with the power supply. If you have not already done so, try entry (3) in this section.
 - (10) If the LED or pushbutton tests indicate a bad I/O pin, take a close look at the pin and verify that it did not bend under the chip instead of inserting into the socket. Propeller microcontrollers are 100% factory tested before shipment and it is not typical that the chip is defective; please contact Parallax Tech Support if you have a potentially defective part. Also, replacement Propeller DIP chips can be purchased individually from Parallax if you do happen to damage yours. If you wish to return your product because of a manufacturer's defect or because it does not meet your needs, please see the Warranty Policy at www.parallax.com for details.

Tech Support Resources

Parallax Inc. offers several avenues through which to gain free technical support services:

- Email: support@parallax.com
- Fax: (916) 624-8006
- Telephone: Toll free in the U.S: (888) 99-STAMP; or (916) 624-8333, between the hours of 7:00 am and 5:00 pm Pacific time.
- Forums: <http://forums.parallax.com/forums/>. Here you will find an active forum dedicated to the Propeller chip, frequented by both Parallax customers and employees.