

# DEMO9S08LG32

---

Demonstration Board for Freescale MC9S08LG32  
Microcontroller

## USER GUIDE



Web Site: [www.axman.com](http://www.axman.com)

Support: [support@axman.com](mailto:support@axman.com)

# CONTENTS

<b>CAUTIONARY NOTES</b> .....	<b>5</b>
<b>TERMINOLOGY</b> .....	<b>5</b>
<b>FEATURES</b> .....	<b>6</b>
<b>REFERENCES</b> .....	<b>7</b>
<b>MEMORY MAP</b> .....	<b>7</b>
<b>SOFTWARE DEVELOPMENT</b> .....	<b>7</b>
<b>DEVELOPMENT SUPPORT</b> .....	<b>8</b>
INTEGRATED BDM .....	8
<i>USB-BDM OPTION HEADERS</i> .....	8
BDM_PORT HEADER .....	8
<b>POWER</b> .....	<b>9</b>
POWER SELECT .....	9
<i>PWR_SEL</i> .....	9
<i>VX_EN</i> .....	10
<b>RESET SWITCH</b> .....	<b>11</b>
<b>LOW VOLTAGE RESET</b> .....	<b>11</b>
<b>TIMING</b> .....	<b>11</b>
<b>COMMUNICATIONS</b> .....	<b>11</b>
USB SERIAL LINK .....	11
RS-232 .....	12
<i>COM CONNECTOR</i> .....	12
<i>COM_SEL</i> .....	12
<b>LCD</b> .....	<b>13</b>
CONTRAST .....	13
<b>USER I/O</b> .....	<b>14</b>
BUZZER .....	14
POTENTIOMETER .....	15
USER LED'S .....	15
PUSHBUTTON SWITCHES .....	16
<b>MCU I/O PORT</b> .....	<b>17</b>
<b>LCD ENABLE OPTION HEADER</b> .....	<b>18</b>
<b>APPENDIX A</b> .....	<b>20</b>
SCHEMATIC .....	20
<b>APPENDIX B</b> .....	<b>22</b>
BILL OF MATERIAL .....	22



# FIGURES

Figure 1: Memory Map.....7  
 Figure 2: JP1 Option Header .....8  
 Figure 3: BDM\_PORT Header .....9  
 Figure 4: V\_SEL Option Header .....9  
 Figure 5: VX\_EN Option Header .....10  
 Figure 6: COM Connections .....12  
 Figure 7: COM1 Connector.....12  
 Figure 8: COM\_SEL Option.....13  
 Figure 9: VLL3\_SEL Option Header .....14  
 Figure 10: BUZ Option Header .....14  
 Figure 11: ADC Option Header.....15  
 Figure 12: User1 Option Header.....15  
 Figure 13: User2 Option Header.....16  
 Figure 14: MCU I/O PORT – J1 .....17  
 Figure 15: LCD Enable Option Header – JP1 .....19

# REVISION

Date	Rev	Comments
November 21, 2008	A	Initial Release
December 02, 2008	B	Updated DEMO9S08LG32 connector pins, features, MCU I/O port, and demonstration board diagram.
February 24, 2009	C	Minor updates to format and corrections to content. Added Notes and Caution boxes

## CAUTIONARY NOTES

- 1) Electrostatic Discharge (ESD) prevention measures should be used when handling this product. ESD damage is not a warranty repair item.
- 2) Axiom Manufacturing does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey any license under patent rights or the rights of others.
- 3) EMC Information on the DEMO9S08LG32 board:
  - a) This product as shipped from the factory with associated power supplies and cables, has been verified to meet with requirements of CE and the FCC as a CLASS A product.
  - b) This product is designed and intended for use as a development platform for hardware or software in an educational or professional laboratory.
  - c) In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate prevention measures.
  - d) Attaching additional wiring to this product or modifying the products operation from the factory default as shipped may effect its performance and cause interference with nearby electronic equipment. If such interference is detected, suitable mitigating measures should be taken.

## TERMINOLOGY

This development module utilizes option select jumpers to configure default board operation. Terminology for application of the option jumpers is as follows:

Jumper – a plastic shunt that connects 2 terminals electrically

Jumper on, in, or installed = jumper is a plastic shunt that fits across 2 pins and the shunt is installed so that the 2 pins are connected with the shunt.

Jumper off, out, or idle = jumper or shunt is installed so that only 1 pin holds the shunt, no 2 pins are connected, or jumper is removed. It is recommended that the jumpers be placed idle by installing on 1 pin so they will not be lost.


Cut-Trace – a circuit trace connection between component pads. The circuit trace may be cut using a knife to break the default connection. To reconnect the circuit, simply install a suitably sized 0-ohm resistor or attach a wire across the pads.

Signal names followed by an asterisk (\*) denote active-low signals.

# FEATURES

The DEMO9S08LG32 is a demonstration board for the MC9S08LG32 microcontroller. Application development is quick and easy with the integrated USB-BDM, sample software tools, and examples. An optional BDM\_PORT port is also provided to allow use of a BDM\_PORT cable. One, 80-pin connector provides access to all IO signals on the target MCU.

- MC9S08LG32, 80 LQFP
  - 32K Bytes Flash
  - 2K Bytes RAM
  - Internal Oscillator
- On-Board 4x40 Custom LCD Glass
- Integrated P&E USB-BDM
- BDM\_PORT header for BDM cable support
- MCU\_PORT pin header for access to MCU IO signals
- On-board +5V regulator
- Optional Power from USB-BDM or MCU\_PORT connector
- Power Input Selection Jumpers
  - Power input from USB-BDM
  - Power input from on-board regulator
  - Power input from Connector J1
  - Optional Power output through Connector J1
- User Components Provided
  - 10 Push Switches; 8 User, 1 Reset, 1 IRQ
  - 12 LED Indicators; 8 User, VDD, IRQ, USB, and reset
  - 5K ohm POT w /LP Filter for ADC input
  - LCD Glass Contrast POT
  - 2.3kHz Piezo Buzzer
- User Option Jumpers to disconnect Peripherals
- User Option Jumpers to disconnect LCD Signals
- Connectors
  - 80-pin MCU I/O Pin Header
  - 2.0mm Barrel Connector
  - BDM\_PORT Connector for External BDM Cable
  - USB Connector
  - DB9 Connector (not installed)



**Specifications:**  
Board Size 5.5" x 4.5"

**NOTE:**  
Manual LCD contrast control requires +12V power input at VIN barrel connector.

## REFERENCES

Reference documents are provided on the Axiom Support web site Acrobat Reader format. These documents may be accessed at [www.axman.com/support](http://www.axman.com/support).

DEMO9S08LG32_UG.pdf	DEMO9S08LG32 User Guide (this document)
DEMO9S08LG32_SCH_A.pdf	DEMO9S08LG32 Schematic Rev. A
DEMO9S08LG32_Silk_A.pdf	DEMO9S08LG32 Top Silk, Rev A
AppsDemo.s19	CodeWarrior LCD Demo Program Object Code

## MEMORY MAP

The table below shows the default memory map for the MC9S08LG32 immediately out of reset. Refer to the MC9S08LG32 Data Sheet (DS) for further information.

**Figure 1: Memory Map**

\$0000 - \$005F	Direct Page Registers
\$0060 - \$081F	RAM 1980 Bytes
\$0820 - \$085C	LCD Registers
\$0860 - \$17FF	Unimplemented
\$1800 - \$187A	High Page Registers
\$187B - \$7FFF	Unimplemented
\$8000 - \$BFFF	FLASH A
\$C000 - \$FFFF	FLASH B

## SOFTWARE DEVELOPMENT

Software development requires the use of a compiler or an assembler supporting the HCS08 instruction set and a host PC operating a debug interface. CodeWarrior Development Studio for Microcontrollers is supplied with this board for application development and debug. Refer to the supporting CodeWarrior documentation for details on use and capabilities.

# DEVELOPMENT SUPPORT

Application development and debug for the target MC9S08LG32 is supported through the background debug mode (BDM) interface. The BDM interface consists of an integrated USB-Multilink BDM and a 6-pin interface header (BDM\_PORT). The BDM\_PORT header allows connecting a HCS12/HCS08 BDM cable.

## Integrated BDM


The DEMO9S08LG32 board features an integrated USB-Multilink BDM from P&E Microcomputer Systems. The integrated USB-Multilink BDM supports application development and debugging via background debug mode. All necessary signals are provided by the integrated USB-Multilink BDM. A USB, type B, connector provides connection from the target board to the host PC.

The integrated USB-Multilink BDM provides power and ground to the target board eliminating the need to power the board externally. Power from the USB-Multilink BDM is derived from the USB bus; therefore, total current consumption for the target board, and connected circuitry, **must not exceed 500mA**. This current limit describes the current supplied by the USB cable to the BDM circuit, the target board, and any connected circuitry. Excessive current drain will violate the USB specification causing the bus to disconnect. Damage to the host PC USB hub or the target board may result.

### *USB-BDM OPTION Headers*

Option header JP2 connects two timer channels to the USB-BDM to facilitate the Signal Analyzer functionality. Installing an option jumper shunt enables the selected timer channel to the BDM circuitry.

**Figure 2: JP1 Option Header**



## BDM\_PORT Header

A compatible HCS12 BDM cable may also attach to the 6-pin BDM interface header (BDM\_PORT). Figure 3 below shows the pin-out for the BDM\_PORT header.



**Figure 3: BDM\_PORT Header**

BKGD	1	2	GND
	3	4	RESET*
	5	6	VDD

Refer to MC9S08LG32 Reference Manual for complete details

## POWER

The DEMO9S08LG32 uses several methods to apply power to the board. An option header allows selection between the various power inputs. For application development and debug, the board may be powered from the USB BDM. The 2.0mm, center-positive, barrel connector (VIN) supports stand-alone operation and higher power requirements. Power may also be applied to connector J1 or the board may be configured to supply power from connector J1 to external circuitry.

**CAUTION:**  
Damage to the board may result if voltages greater than +5.5V are applied at the connector J1 input.





## POWER SELECT

Power may be applied to the board through the integrated USB-Multilink BDM circuitry, a 2.0mm barrel connector, or through connector J1. Power selection is achieved using 2 selection headers: the PWE\_SEL option header and the VX\_EN option header.

### *PWR\_SEL*

The PWR\_SEL option header allows the user to select power input either from either an external power source connected to the VIN connector or from the integrated USB-BDM. Figure 4 below details the PWR\_SEL header connections.

**Figure 4: V\_SEL Option Header**

	VR1	VB	
PWR_SEL			Enable power to board from external power supply
PWR_SEL			Enable power to board from Integrated USB-BDM

**CAUTION:**

Total power from the USB-BDM is limited to **500 mA**. Exceeding this limit violates the USB specification and will cause the USB bus to disconnect. Damage to the target board and the host PC may result.

Power from the integrated BDM is drawn from the USB bus and is limited to **500 mA**. This current limit accounts for the total current supplied over the USB cable to the BDM circuit, the target board, and any connected circuitry. Current drain in excess of 500 mA will violate the USB specification and will cause the USB bus to disconnect. This will cause the board to exhibit power cycling where the board appears to turn-on then off continually. Damage to the host PC or the target board may also result.

Power input to the VIN barrel connector should not exceed +12V. LCD contrast is connected directly to the VIN power input.

**CAUTION:**


Voltage input exceeding +12V applied to VIN may damage the target board

*VX\_EN*

The VX\_EN option header is a 2-pin jumper that connects or disconnects input J1-1 directly to the target board voltage rail. J1-3 connects directly to the target board ground plane. Use of this feature requires a regulated input power source. This power input is decoupled to minimize noise but is not regulated or protected. Care should be exercised when using this feature; no protection is applied on this input and damage to the target board may result if excessive voltage is applied. Also, do not attempt to power the target board through this connector while also applying power through the USB-Multilink BDM or the PWR connector; damage to the board may result.

Power may also be sourced to off-board circuitry through the J1 connector. The current supplied from the USB bus or the on-board regulator limits current available to external circuitry. Excessive current drain may damage the target board, the host PC USB hub, or the on-board regulator. The figure below details the VX\_EN header connections.

**Figure 5: VX\_EN Option Header**



### **CAUTION:**

Do not exceed available current from USB-BDM or on-board regulator when sourcing power through connector J1 to external circuitry.

## **RESET SWITCH**

The RESET switch applies an asynchronous RESET to the MCU. The RESET switch is connected directly to the RESET\* input on the MCU. Pressing the RESET switch applies a low voltage level to the RESET\* input. A pull-up bias resistor allows normal MCU operation. Shunt capacitance ensures an adequate input pulse width.

## **LOW VOLTAGE RESET**

The MC9S08LG32 utilizes an internal Low Voltage Detect (LVD) circuit. The LVD holds the MCU in reset until applied voltage reaches an appropriate level. The LVD also protect against under-voltage conditions. Consult the MC9S08LG32 reference manual for details LVD operation.

## **TIMING**

The DEMO9S08LG32 internal timing source is active from RESET by default. An external 32 kHz XTAL oscillator, configured for low-power operation, is also provided. Refer to the MC9S08LG32 Reference Manual for details on configuring the selected timing source.

## **COMMUNICATIONS**

The DEMO9S08LG32 supports serial communications through the integrated USB-BDM and an on-board, low-voltage, RS-232 transceiver. The COM\_SEL header selects the serial path applied. The 9-pin, D-Sub, connector at COM1 is not installed in default configurations.

## **USB SERIAL LINK**

The integrated USB-BDM provides a serial link from the target MCU to the host PC through the host application. Refer to the P&E Multilink documentation for further details.

## RS-232

An RS-232 translator provides RS-232 to TTL/CMOS logic level translation on the COM connector. The COM connector is a 9-pin Dsub, right-angle connector. A ferrite bead on shield ground provides conducted immunity protection. Communication signals TXD1 and RXD1 are routed from the transceiver to the MCU. Hardware flow control signals RTS and CTS are available on the logic side of the transceiver. These signals are routed to vias located near the transceiver. RTS has been biased properly to support 2-wire RS-232 communications.


**Figure 6: COM Connections**

MCU Port	COM Signal	I/O PORT CONNECTOR
PTI1/TMRCLK/TX2	TXD	J1-5
PTI0/RX2	RXD	J1-7

### COM Connector

A standard 9-pin Dsub connector provides external connections for the SCI0 port. The Dsub shell is connected to board ground through a ferrite bead. The ferrite bead provides noise isolation on the RS-232 connection. The figure below details the DB9 connector.

**Figure 7: COM1 Connector**



Female DB9 connector that interfaces to the MCU internal SCI0 serial port via the RS232 transceiver. Flow control is provided at test points on the board.



**Pins 1, 4, and 6 are connected together.**

**NOTE:** The COM1 connector is not installed in default configurations.

### COM\_SEL

The COM\_SEL option header connects the MCU SCI port to either the SCI PHY or the USB-BDM connection. Figure 8 below shows the option jumper configuration for the COM\_SEL option header.

**Figure 8: COM\_SEL Option**



**NOTE:** The silkscreen marking for the COM\_SEL header is incorrect on Rev A boards. The RXD position enables COM through the DB9 connector while the TXD position enables COM through the integrated USB-BDM.

## LCD

The DEMO9S08LG32 provides a 4 x 40 custom LCD glass connected directly to the target MCU. Refer to the MC9S08LG32 Reference Manual for details on use and configuration.



A row of option jumpers located below the LCD module allows each LCD signal to be disconnected from the associated LCD input. This allows multiplexed signal functionality to be used without affecting the LCD module.

The LCD Enable Option Header allows the user to disable any LCD signal to the LCD. This allows any signal to be used for a multiplexed function with out affecting the LCD. Figure 15, at the end of this document, shows the relation between target MCU signals and LCD glass pins through the JP1 option header. Installing a shunt at any position enables the LCD signal to the LCD. Removing a shunt at any position disconnects the LCD signal from the LCD.

## Contrast

LCD contrast control is controlled by the VLL3\_SEL option header. This option header applies either fixed or variable LCD contrast. Variable contrast control requires the target board be powered from an external +12V power supply connected to VIN.

**Figure 9: VLL3\_SEL Option Header**



**NOTE:** Silkscreen on VLL3\_SEL is incorrect. The RV1 selection actually connects to the CONTRAST POT and not the RV1 POT.

**NOTE:** Use of variable Contrast Control requires that +12V input be applied at VIN connector.

**NOTE:** VLL3\_SEL must be set to FIX if target board is powered from integrated USB-BDM.

**CAUTION**  
Voltage input at VIN greater than +12V may damage the target board.


## USER I/O

User I/O includes 2 potentiometer, 8 push button switches, and 8 green LEDs, and 1 piezo buzzer for user I/O. The User1, User2, and Buz option header blocks enable or disable each User I/O function individually.

## Buzzer

The DEMO9S08LG32 target board provides an externally modulated piezo-buzzer for audible applications. A push-pull drive circuit allows the target MCU to easily drive the buzzer at a center frequency of 2300 Hz. Figure 10 below shows the USER enable position and associated signal for the buzzer.

**Figure 10: BUZ Option Header**






## Potentiometer

The DEMO9S08LG32 target board provides a 5K ohm potentiometer (POT) to simulate analog input. The POT is decoupled to minimize noise during adjustment. The POT is selectively assignable to ADC6 or ADC7 by the ADC option header.

The ADC option header also controls POT configuration. The POT may be configured as a variable pull-down resistance or may be connected to VDDA as a variable voltage input.

Figure 11 below shows the ADC option header selections.

**Figure 11: ADC Option Header**

ADC	Signal	ON	OFF
 PTH0	PTH0/KBI5/ADC6	Enabled	Disabled
 PTH1	PTH1/KBI6/ADC7	Enabled	Disabled
 VDDA	VDDA	Enabled	Disabled









### CAUTION

While using pushbuttons KBI5 or KBI6 in end-user applications, the option jumper at PTH0 and, or, PTH1 should be removed. Pressing pushbutton KBI5 with option jumper installed at PTH0; or, pressing pushbutton KBI6 with option jumper installed at PTH1 will cause a target board POR.

## User LED's

The DEMO9S08LG32 target board provides 8, green, LEDs for output indication. Each LED is configured for active-low operation. A series, current-limit resistor prevents excessive diode current. Figure 12 below shows the USER1 enable position and associated signal for each LED.

**Figure 12: User1 Option Header**

	USER2	Signal	ON	OFF
T1C0	 1	PTH5/TPM1CH0	Enabled	Disabled
T1C1	 2	PTH4/TPM1CH1	Enabled	Disabled
T2C0	 3	PTI5/TMP2CH0	Enabled	Disabled
T2C1	 4	PTI4/TPM2CH1	Enabled	Disabled
T2C2	 5	PTI3/TPM2CH2	Enabled	Disabled
T2C3	 6	PTF5/TMP2CH3	Enabled	Disabled
T2C4	 7	PTF4/TPM2CH4	Enabled	Disabled
T2C5	 8	PTF3/TPM2CH5	Enabled	Disabled

**CAUTION**

While using pushbuttons KBI5 or KBI6 in end-user applications, the option jumper at PTH0 and, or, PTH1 should be removed. Pressing pushbutton KBI5 with option jumper installed at PTH0; or, pressing pushbutton KBI6 with option jumper installed at PTH1 will cause a target board POR.

## Pushbutton Switches

The DEMO9S08LG32 provides 8 push-button switches for user input. Each push-button switch is configured for active-low operation. No bias is applied to these push-button inputs. Use of target MCU internal pull-ups is required for proper operation. Figure 13 below shows the USER2 enable position and associated signal for each user switch.

**Figure 13: User2 Option Header**

USER1	Signal	ON	OFF
• • KBI1	PTH6/KBI1	Enabled	Disabled
• • KBI2	PTH7/KBI2	Enabled	Disabled
• • KBI3	PTH4/KBI3	Enabled	Disabled
• • KBI4	PTF0/KBI4	Enabled	Disabled
• • KBI5	PTH0/KBI5	Enabled	Disabled
• • KBI6	PTH1/KBI6	Enabled	Disabled
• • KBI7	PTH2/KBI7	Enabled	Disabled
• • KBI8	PTH3/KBI8	Enabled	Disabled



# MCU I/O PORT

The MCU I/O PORT connector provides access to the MC9S08LG32 I/O signals. Figure 14 below show the pin-out for the MCU I/O connector.

**Figure 14: MCU I/O PORT – J1**

VDD	<b>1</b>	<b>2</b>	PTF2/SPSCK/TPM1CH1/IRQ/ADC14
VSS	<b>3</b>	<b>4</b>	PTC6/RESET*
PTI1/TMRCLK/TX2	<b>5</b>	<b>6</b>	PTC5/BKGD/MS
PTI0/RX2	<b>7</b>	<b>8</b>	PTA7/TCLK/ADC5/LCD28
PTH5/TX1/KBI4/TPM1CH0/ADC11	<b>9</b>	<b>10</b>	PTH2/KBI7/ADC8
PTH4/RX1/KBI3/TPM1CH1/ADC10	<b>11</b>	<b>12</b>	PTA6/KBI8/TPM2CH1/ADC4/LCD27
PTH7/KBI2/TPM2CH4	<b>13</b>	<b>14</b>	PTA5/KBI7/TPM2CH0/ADC3/LCD26
PTH6/TPM2CH5/KBI1/ADC15	<b>15</b>	<b>16</b>	PTA4/KBI6/RX2/ADC2/LCD25
PTI3/TPM2CH2/MOSI	<b>17</b>	<b>18</b>	PTA3/KBI5/TX2/ADC1/LCD24
PTI2/TPM2CH3/MISO	<b>19</b>	<b>20</b>	PTA0/LCD21
PTI4/TPM2CH1/SDA/SPSCK	<b>21</b>	<b>22</b>	PTH0/KBI5/ADC6
PTI5/TPM2CH0/SCL/SS*	<b>23</b>	<b>24</b>	PTH1/KBI6/ADC7
PTF6/XTAL	<b>25</b>	<b>26</b>	PTA1/SCL/LCD22
PTF7/EXTAL	<b>27</b>	<b>28</b>	PTA2/SDA/ADC0/LC23
PTD0/LCD0	<b>29</b>	<b>30</b>	PTH3/KBI8/ADC9
PTD1/LCD1	<b>31</b>	<b>32</b>	PTF3/SS*/KBI1/TPM2CH5
PTD2/LCD2	<b>33</b>	<b>34</b>	PTF5/MOSI/KBI3/TPM2CH3
PTD3/LCD3	<b>35</b>	<b>36</b>	PTF4/MISO/KBI2/TPM2CH4
PTD4/LCD4	<b>37</b>	<b>38</b>	PTF1_out/RX1/TPM1CH0/ADC13
PTD5/LCD5	<b>39</b>	<b>40</b>	PTF0/TX1/KBI4/TPM2CH2/ADC12
PTD6/LCD6	<b>41</b>	<b>42</b>	PTG0/LCD33
PTD7/LCD7	<b>43</b>	<b>44</b>	PTG1/LCD34
PTE0/LCD8	<b>45</b>	<b>46</b>	PTG2/LCD35
PTE1/LCD9	<b>47</b>	<b>48</b>	PTG3/LCD36
PTE2/LCD10	<b>49</b>	<b>50</b>	PTG4/LCD41
PTE3/LCD11	<b>51</b>	<b>52</b>	PTG5/LCD42
PTB3/LCD32	<b>53</b>	<b>54</b>	PTG6/LCD43
PTB2/LCD31	<b>55</b>	<b>56</b>	PTG7/LCD44
PTB6/LCD39	<b>57</b>	<b>58</b>	PTB7/LCD40
PTB4/LCD37	<b>59</b>	<b>60</b>	PTB5/LCD38
PTE4/LCD12	<b>61</b>	<b>62</b>	PTB1/LCD30
PTE5/LCD13	<b>63</b>	<b>64</b>	PTB0/LCD29
PTE6/LCD14	<b>65</b>	<b>66</b>	PTC0/LCD16
PTE7/LCD15	<b>67</b>	<b>68</b>	PTC1/LCD17
PTC4/LCD20	<b>69</b>	<b>70</b>	PTC2/LCD18
PTC3/LCD19	<b>71</b>	<b>72</b>	VCAP1
VDDA/VREFH	<b>73</b>	<b>74</b>	VCAP2
VSSA/VREFL	<b>75</b>	<b>76</b>	VLL1
VLL3	<b>77</b>	<b>78</b>	VLL2
VSS	<b>79</b>	<b>80</b>	VSS

## LCD ENABLE OPTION HEADER

The LCD Enable Option Header allows the user to disable any LCD signal to the LCD. This allows any signal to be used for a multiplexed function without affecting the LCD. Figure 15 below shows the relation between target MCU signals and LCD glass pins through the JP1 option header. Installing a shunt at any position enables the LCD signal to the LCD. Removing a shunt at any position disconnects the LCD signal from the LCD.





**Figure 15: LCD Enable Option Header – JP1**

MCU Pin #	MCU Signal	LCD Signal	JP1 Pos #	JP1 Pin		LCD Pin
14	PTB0/LCD29	LCD29	2	1	2	44
13	PTB1/LCD30	LCD30	4	3	4	43
12	PTB4/LCD37	LCD37	6	5	6	42
11	PTB5/LCD38	LCD38	8	7	8	41
10	PTB6/LCD39	LCD39	10	9	10	40
9	PTB7/LCD40	LCD40	12	11	12	39
8	PTB2/LCD31	LCD31	14	13	14	38
7	PTB3/LCD32	LCD32	16	15	16	37
16	PTD0/LCD0	LCD00	18	17	18	1
15	PTD1/LCD1	LCD01	20	19	20	2
6	PTD2/LCD2	LCD02	22	21	22	3
5	PTD3/LCD3	LCD03	24	23	24	4
4	PTD4/LCD4	LCD04	26	25	26	5
3	PTD5/LCD5	LCD05	28	27	28	6
2	PTD6/LCD6	LCD06	30	29	30	7
1	PTD7/LCD7	LCD07	32	31	32	8
80	PTE0/LCD8	LCD08	34	33	34	9
79	PTE1/LCD9	LCD09	36	35	36	10
78	PTE2/LCD10	LCD10	38	37	38	11
77	PTE3/LCD11	LCD11	40	39	40	12
76	PTE4/LCD12	LCD12	42	41	42	13
75	PTE5/LCD13	LCD13	44	43	44	14
74	PTG0/LCD33	LCD33	46	45	46	15
73	PTG1/LCD34	LCD34	48	47	48	16
72	PTG4/LCD41	LCD41	50	49	50	17
71	PTG5/LCD42	LCD42	52	51	52	18
70	PTG6/LCD43	LCD43	54	53	54	19
66	PTE6/LCD14	LCD14	56	55	56	20
65	PTE7/LCD15	LCD15	58	57	58	21
64	PTC0/LCD16	LCD16	60	59	60	22
63	PTC1/LCD17	LCD17	62	61	62	36
62	PTC2/LCD18	LCD18	64	63	64	35
61	PTC3/LCD19	LCD19	66	65	66	34
60	PTC4/LCD20	LCD20	68	67	68	33
59	PTA0/LCD21	LCD21	70	69	70	32
58	PTG2/LCD35	LCD35	72	71	72	31
57	PTG3/LCD36	LCD36	74	73	74	30
56	PTA1 /LCD22	LCD22	76	75	76	29
55	PTA2 /LCD23	LCD23	78	77	78	28
54	PTA3 /LCD24	LCD24	80	79	80	27
53	PTA4 /LCD25	LCD25	82	81	82	26
52	PTA5 /LCD26	LCD26	84	83	84	25
51	PTA6 /LCD27	LCD27	86	85	86	24
50	PTA7 /LCD28	LCD28	88	87	88	23

# APPENDIX A

## SCHEMATIC






APPROVALS		DATE	TITLE
DRAWN	GLG	072208	DEM09S08LG32
CHECKED	DSR	071487	AXM-0469
FINISH			

SIZE	DWG. NO.	REV
B	DOC-0469-030	A

SCALE	SHEET 2 OF 2
	2



## APPENDIX B

### Bill of Material

Item	Qty	Title	Detail	Reference(m)	Vendor	Vendor P/N	Mfr	Mfr P/N
1	1	Buzzer-Thru	Mag,2.3Khz,5V	Bz1	Digi-Key	102-1155-ND	CUI Inc	CEM-1206S
2	1	Cap-Cer-Smt(R)	(0603) .01uF,50V	C307	Emtek	MA0603XR103K500	Meritek	MA0603XR103K500
3	21	Cap-Cer-Smt(R)	(0603) .1uF,16V	C2-C4,C13-C22,C26,C300-C304,C308,C311	Emtek	MA0603XR104K160	Meritek	MA0603XR104K160
4	1	Cap-Cer-Smt(R)	(0805) .1uF,50V	C1	Emtek	MA0805XR104K500	Meritek	MA0805XR104K500
5	4	Cap-Cer-Smt(R)	(0603) 22pF,50V, npo/cog,5%	C11,C12,C305,C306	Emtek	MA0603CG220J500	Meritek	MA0603CG220J500
6	1	Cap-Cer-Smt(R)	(0805) .47uF,16V	C25	Mouser	80-C0805C474J4R	Kemet	C0805C474J4RACTU
7	4	Cap-Cer-Thru(R)	(C315) .1uF,50V,20%,.1 SP	C5,C6,C9,C10	Digi-Key	399-4151-ND	Kemet	C315C104M5U5TA
8	1	Cap-Elec-Smt(R)	(SMD) 100uF,16V,6x5	C309	Emtek	16CAE101S	Surge	16CAE101S
9	4	Cap-Tant-Smt(R)	(SMA) 10uF,10V	C7,C8,C23,C24	FAI	293D106X9016B2TE3	Vishay	293D106X9016B2TE3
10	2	Cap-Tant-Smt(R)	(SMA) 4.7uF,10V	C310,C312	Avnet	TAJA475K010R	Avx	TAJA475K010R
17	1	Conn-Barl-Thru(R)	Plug 2mm Barrel,RA	Vin	Emtek	SCD-014	Vimex	SCD-014-PB
19	4	Conn-Pin Hdr-Thru(R)	1x2 Header	Agnd,Buz,Mcu_En,Vx_En	Emtek	PH1-2S-G-F1	Keltron	PH1-2S-G-F1
20	2	Conn-Pin Hdr-Thru(R)	1x3 Header	Pwr_Sel,VII3_Sel	Emtek	PH1-3S-G-F1	Keltron	PH1-3S-G-F1
21	1	Conn-Pin Hdr-Thru(R)	2x2 Header	Jp3	Emtek	PH2-4S-G-F1	Keltron	PH2-4S-G-F1
22	3	Conn-Pin Hdr-Thru(R)	2x3 Header	Adc,Bdm_Port, Com_Sel	Emtek	PH2-6S-G-F1	Keltron	PH2-6S-G-F1
23	1	Conn-Pin Hdr-Thru(R)	2x4 Header	JP2C	Emtek	PH2-8S-G-F1	Keltron	PH2-8S-G-F1
24	4	Conn-Pin Hdr-Thru(R)	2x40 Header	J1A,J1B,Jp1A,Jp2B	Emtek	PH2-80S-G-F1	Keltron	PH2-80S-G-F1
25	2	Conn-Pin Hdr-Thru(R)	2x8 Header	User1,User2	Emtek	PH2-16S-G-F1	Keltron	PH2-16S-G-F1



Web Site: [www.axman.com](http://www.axman.com)

Support: [support@axman.com](mailto:support@axman.com)

26	1	Conn-USB-Thru(R)	USB-B,RA	J300	Emtek	USB-B-HR-DNN		
67	1	Crystal-Cyindr-Thru(R)	(3X8) 32.768KHz,3.3V	Y1	FAI	AB38T-32.768KHZ	Abrakon	AB38T-32.768KHZ
66	1	Crystal-Smt(R)	(HC49S) 12.0MHz,18PF	X300	FAI	FOXSDLF/120-20/TR	Fox	FOXSDLF/120-20/TR
14	1	Dio-Zener-Smt	(Sot23) MMBZ5232B	D1	Mouser	512-MMBZ5232B	Fairchild	MMBZ5232B
13	1	Display-Custom-Thru(R)	LCD Glass, Freescale, GDM121F w/GD3980 Disp	Ds1	S-Tek, Inc	GDM121F_GD3980	S-Tek	
72	4	HDW-Rubber Bump(R)	0.375"x0.15" (W x H), Hemi,Clear	Feet	Mouser	517-SJ-5306CL	3M	SJ-5306 CLEAR
71	72	HDW-Shunt(R)	.10 Shunt	Shunts	E-Call	0146-230-020	E-Call	0146-230-020
15	2	HDW-Test Pt-Thru(R)	PC Mnt,Black,Compact Loop,Glass Bead	Gnd1,Gnd2	Mouser	151-203-RC	Kobiconn	151-203-RC
16	2	HDW-Test Pt-Thru(R)	PC Mnt,Red,Compact Loop,Glass Bead	Vdd1,Vdd2	Mouser	151-207-RC	Kobiconn	151-207-RC
60	3	IC-Buffer-Smt(R)	(Ssop8) 74LVC2G125, Dual,3-St	U303,U308,U310	Avnet	SN74LVC2G125DCTR	TI	SN74LVC2G125DCTR
61	1	IC-Buffer-Smt(R)	(Ssop8) 74LVC2G126, Dual,3-St	U309	Arrow	SN74LVC2G126DCTR	TI	SN74LVC2G126DCTR
63	1	IC-Comprtr-Smt(R)	(Sot23-5) LMV7219M5,R-R	U302	Avnet	LMV7219M5/NOPB	Nat Semi	LMV7219M5/NOPB
30	1	IC-Lvl Det5V-Smt(R)	(Soic8) MC34164D,Reset	U305	FAI	MC34164D-5R2-LF	On Semi	MC34164D-5R2G
58	1	IC-Microp-Smt(R)	(Lqfp80) MC9S08LG32	U1	Freescale	Supplied	Freescale	PC9S08LG32VLF
59	1	IC-RS232-Smt(R)	(Soic16) ICL3232,Dual Xcvr,3.3V,ESD	U2	FAI	MAX3232ECSA-LF	Sipex	SP3232EBCN-L
62	2	IC-Switch-Smt(R)	(Ssop8) SN74LVC2G66DCT, Analog,Bilateral, Dual	U300,U301	Mouser	595-SN74LVC2G66DCTR	TI	SN74LVC2G66DCTR
28	2	Ind-FB-Smt(R)	(1206) 26 Ohms,Ferrite,EMI,1.5A	L300,L301	Digi-Key	240-2403-1-ND	Steward	MI1206K260R-10
29	1	Ind-FB-Smt(R)	(0805) 330 Ohms@100M,1.5A	Fb1	Mouser	81-BLM21P331SG	Murata	BLM21PG331SN1D
27	1	Ind-Smt(R)	(1210) 10uH,Choke	L1	FAI	NL1210-100JTR-LF	Tdk	NLV32T-100J-PF

11	9	LED-Smt(R)	(1206) Green	D300,T1C0,T1C1,T2C0,T2C1,T2C2,T2C3,T2C4,T2C5	Emtek	150YG	Micro Elec	150YG
12	3	LED-Smt(R)	(1206) Red	Irqlcd,Rstled,Vdd	Emtek	150SR	Micro Elec	150SR
69	1	Misc-Not Installed		Rxd,Tp1,Txd,VII1-VII3	Axiom	DNI-MISC		
70	1	Part-Not Installed		Com1,I2C_Pu,R333,SU1,U3	Axiom	DNI-PART		
68	1	Pcb(R)	Rev A DEMO9S08LG3 2, 5.5x4.5,4 Lyr,Pnl=2x1	Pcb	BBG	PCB-AXM0469A		
64	1	Prog'd IC-Microp-Smt(R)	(Tqfp100) MC9S12UF32PU ,MCUSLK	U306	P&E	UF32E_MCUSLK (Supplied)	Freescale	MC9S12UF32PUE
34	2	Res-Carb-Smt(R)	(0603) 100 Ohm,5%	R4,R6	Emtek	CR16-101J	Meritek	CR16-101J
35	3	Res-Carb-Smt(R)	(0603) 1K Ohm,5%	R319,R322,R324	Emtek	CR16-102J	Meritek	CR16-102J
36	1	Res-Carb-Smt(R)	(0805) 1K Ohm,5%	R15	Emtek	CR10-102J	Meritek	CR10-102J
37	1	Res-Carb-Smt(R)	(1210) 1K Ohm, 5%	R13	Digi-Key	P1.0KVCT-ND	Panasonic	ERJ-14YJ102U
38	14	Res-Carb-Smt(R)	(0603) 10K Ohm,5%	R1,R5,R7,R9-R11,R300- R303,R306,R307,R313,R314	Emtek	CR16-103J	Meritek	CR16-103J
39	3	Res-Carb-Smt(R)	(0603) 100K Ohm,5%	R304,R305,R331	Emtek	CR16-104J	Meritek	CR16-104J
40	2	Res-Carb-Smt(R)	(0603) 1M Ohm,5%	R3,R316	Emtek	CR16-105J	Meritek	CR16-105J
41	1	Res-Carb-Smt(R)	(0603) 1.1K Ohm ,5%	R321	Emtek	CR16-112J	Meritek	CR16-112J
42	1	Res-Carb-Smt(R)	(0603) 1.5K Ohm,5%	R308	Emtek	CR16-152J-TR	Meritek	CR16-152J
43	1	Res-Carb-Smt(R)	(0805) 22K Ohm,5%	R14	Emtek	CR10-223J	Meritek	CR10-223J
44	6	Res-Carb-Smt(R)	(0603) 3.3K Ohm,5%	R315,R317,R318,R320,R330 ,R332	Emtek	CR16-332J-TR	Meritek	CR16-332J
45	2	Res-Carb-Smt(R)	(0805) 47 Ohm,5%	R326,R327	Emtek	CR10-470J	Meritek	CR10-470J
46	2	Res-Carb-Smt(R)	(0603) 470 Ohm,5%	R2,R12	Emtek	CR16-471J	Meritek	CR16-471J
47	4	Res-Carb-Smt(R)	(0603) 4.7K Ohm,5%	R323,R325,R328,R329	Emtek	CR16-472J	Meritek	CR16-472J



48	2	Res-Carb-Smt(R)	(0603) 510 Ohm,5%	R309,R312	Emttek	CR16-511J	Meritek	CR16-511J
49	1	Res-Carb-Smt(R)	(0603) 680 Ohm,5%	R8	Emttek	CR16-681J	Meritek	CR16-681J
50	2	Res-MF-Smt(R)	(0805) 33 Ohm,1%	R310,R311	Emttek	CR10-0330F	Meritek	CR10-0330F
51	2	Res-Netw-Smt(R)	(0603x4) 680 Ohm,8P4R,Iso	Rn1,Rn2	Digi-Key	Y4681CT-ND	Panasonic	EXB-V8V681JV
53	2	Res-Pot-Thru(R)	(CE9M) 5K Ohm,Thumb Wheel,Offset pins	Contrast,Rv1	Emttek	CE9MH2.5 5K WT	Vimex	CE9MH2.5 5K WT
54	10	Sw-PB-Thru(R)	Tact Sw,6mm Sq	Irq,KBI1-KBI8,Reset	Emttek	EG1827	E-Switch	EG1827
31	1	Trans-Mosfet-Smt(R)	(Sot23) IRLML6402CT, P-Ch, 20V,3.7A	U307	Digi-Key	IRLML6402PBFCT-ND	Int Rectifier	IRLML6402TRPBF
32	1	Trans-NPN-Smt(R)	(Sot23) MMBT3904, 40V,350mW	Q1	Emttek	MMBT3904	Taitron	MMBT3904
33	1	Trans-PNP-Smt(R)	(Sot23) MMBT3906, 40V,350mW	Q2	Emttek	MMBT3906	Taitron	MMBT3906
65	1	VReg-5V-Smt(R)	(To263) LM2940,1A,Ldo	Vr1	FAI	LM2940CS-5.0/NOPB	Nat Semi	LM2940CS-5.0/NOPB