

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

Renesas Starter Kit for H8S/2215R

User's Manual

RENEASAS SINGLE-CHIP MICROCOMPUTER
H8S FAMILY

Table of Contents

| | |
|--|----|
| Chapter 1. Preface | 3 |
| Chapter 2. Purpose | 4 |
| Chapter 3. Power Supply | 5 |
| 3.1. Requirements | 5 |
| 3.2. Power – Up Behaviour | 5 |
| Chapter 4. Board Layout | 6 |
| 4.1. Component Layout | 6 |
| 4.2. Board Dimensions | 7 |
| Chapter 5. Block Diagram | 8 |
| Chapter 6. User Circuitry | 9 |
| 6.1. Switches | 9 |
| 6.2. LEDs | 9 |
| 6.3. Potentiometer | 9 |
| 6.4. Serial port | 9 |
| 6.5. LCD Module | 10 |
| 6.6. Option Links | 11 |
| 6.7. Oscillator Sources | 15 |
| 6.8. Reset Circuit | 16 |
| 6.9. USB Port | 16 |
| Chapter 7. Modes | 17 |
| 7.1.1. Boot mode | 17 |
| 7.1.2. User Mode | 17 |
| Chapter 8. Programming Methods | 18 |
| Chapter 9. Headers | 19 |
| 9.1. Microcontroller Headers | 19 |
| 9.2. Application Headers | 23 |
| Chapter 10. Code Development | 26 |
| 10.1. Overview | 26 |
| 10.2. Compiler Restrictions | 26 |
| 10.3. Breakpoint Support | 26 |
| 10.4. Memory Map | 27 |
| Chapter 11. Component Placement | 28 |
| Chapter 12. Additional Information | 29 |

Chapter 1. Preface

Cautions

This document may be, wholly or partially, subject to change without notice.

All rights reserved. No one is permitted to reproduce or duplicate, in any form, a part or this entire document without the written permission of Renesas Technology Europe Limited.

Trademarks

All brand or product names used in this manual are trademarks or registered trademarks of their respective companies or organisations.

Copyright

© Renesas Technology Europe Ltd. 2008. All rights reserved.

© Renesas Technology Corporation. 2008. All rights reserved.

© Renesas Solutions Corporation. 2008. All rights reserved.

Website: <http://www.renesas.com/>

Glossary

| | | | |
|-----|-----------------------------|------|------------------------------------|
| ADC | Analog to Digital Converter | USB | Universal Serial Bus |
| CPU | Central Processing Unit | DAC | Digital to Analog Converter |
| DMA | Direct Memory Access | E10A | E10A for Starter Kits debug module |
| FDT | Flash Development Tool | RSK | Renesas Starter Kit |
| LED | Light Emitting Diode | LCD | Liquid Crystal Display |

Chapter 2. Purpose

This RSK is an evaluation tool for Renesas microcontrollers.

Features include:

- Renesas Microcontroller Programming.
- User Code Debugging.
- User Circuitry such as switches, LEDs and potentiometer(s).
- Sample Application.
- Sample peripheral device initialisation code.

The CPU board contains all the circuitry required for microcontroller operation.

This manual describes the technical details of the RSK hardware. The Quick Start Guide and Tutorial Manual provide details of the software installation and debugging environment.

Chapter 3. Power Supply

3.1. Requirements

This CPU board operates from a 5V power supply.

A diode provides reverse polarity protection only if a current limiting power supply is used.

The CPU board is supplied with an E10A debugger. This product is NOT able to power the CPU board.

When the CPU board is connected to another system, that system should supply power to the CPU board.

All CPU boards have a centre positive supply connector using a 2.0mm barrel power jack and are supplied with a suitable universal power supply. The user should select the correct mains connector for their country of use.

Warning

The CPU board is neither under not over voltage protected. Always use a centre positive supply for this board.

3.2. Power – Up Behaviour

When the RSK is purchased the CPU board has the 'Release' or stand alone code from the example tutorial code pre-programmed into the Renesas microcontroller. On powering up the board the user LEDs will start to flash. Pressing switch 2 will cause the LEDs to flash at a rate controlled by the potentiometer.

Chapter 4. Board Layout

4.1. Component Layout

The following diagram shows top layer component layout of the board.




Figure 4.1: Board Layout

4.2. Board Dimensions

The following diagram gives the board dimensions and connector positions. All through hole connectors are on a common 0.1" grid for easy interfacing.




Figure 4.2 : Board Dimensions

Chapter 5. Block Diagram

Figure 5.1 shows the CPU board components and their connectivity.




Figure 5.1: Block Diagram

Figure 5.2 shows the connections to the RSK.




Figure 5.2 : RSK Connctions

Chapter 6. User Circuitry

6.1. Switches

There are four switches located on the CPU board. The function of each switch and its connection are shown in Table 6-1.

| Switch | Function | Microcontroller |
|-----------|--|----------------------------------|
| RES | When pressed; the CPU board microcontroller is reset. | RESn |
| SW1/BOOT* | Connects to an IRQ input for user controls. | IRQ0n, Pin 39 (Port 1, pin 4) |
| SW2* | Connects to an IRQ line for user controls. | IRQ2n, Pin 87 (Port F, pin 0) |
| SW3* | Connects to the ADC trigger/ IRQ3 input via option 0R link R105. | IRQ3n, Pin 83 (Port F, pin 3) |

Table 6-1: Switch Functions

*Refer to schematic for detailed connectivity information.

6.2. LEDs

There are six LEDs on the CPU board. The green 'POWER' LED lights when the board is powered. The orange BOOT LED indicates the device is in BOOT mode when lit. The four user LEDs are connected to an IO port and will light when their corresponding port pin is set low.

Table 6-2, below, shows the LED pin references and their corresponding microcontroller port pin connections.

| LED Reference (As shown on silkscreen) | Microcontroller Port Pin function | Microcontroller Pin Number | Polarity |
|--|-----------------------------------|----------------------------|------------|
| LED0 | Port F1 | 86 | Active Low |
| LED1 | Port F2 | 85 | Active Low |
| LED2* | Port A0 | 30 via R133 | Active Low |
| LED3 | Port G0 | 101 | Active Low |

Table 6-2: LED Port

*Refer to schematic for detailed connectivity information.

6.3. Potentiometer

A single turn potentiometer is connected to AN0 of the microcontroller via R42. This may be used to vary the input analog voltage value to this pin between AVCC and Ground.

6.4. Serial port

The microcontroller programming serial port (SCI2) is connected to the 'E8' connector by default. SCI0 is connected to the 9-way D-type connector labelled J8 via a RS232 transceiver.

| Programming via | SCI 2 | SCI 0 | Fit | Remove |
|-----------------|-------|--------------|------------------|------------------|
| E8a | E8a | RS232 | R6, R7, R28, R29 | R37, R38 |
| Serial | RS232 | Disconnected | R37, R38 | R6, R7, R28, R29 |

Table 6-3 - Serial Option Links

The board is designed to accept a straight through RS232 cable. A secondary microcontroller serial port is available and connected to the application headers. Please refer to the schematic diagram for more details on the available connections.

6.5. LCD Module

A LCD module can be fitted to the LCD connector. Any module that conforms to the pin connections and has a KS0066u compatible controller can be used with the tutorial code. The LCD module uses a 4bit interface to reduce the pin allocation. No contrast control is provided; this must be set on the display module.

Table 6-4 shows the pin allocation and signal names used on this connector.

The module supplied with the CPU board only supports 5V operation.

| LCD | | | | | |
|-----|---------------------------|------------|-----|------------------|------------|
| Pin | Circuit Net Name | Device Pin | Pin | Circuit Net Name | Device Pin |
| 1 | Ground | - | 2 | 5V Only | - |
| 3 | No Connection | - | 4 | D0_DLCDRS | 111 |
| 5 | R/W (Wired to Write only) | - | 6 | D1_DLCDE | 113 |
| 7 | No Connection | - | 8 | No connection | - |
| 9 | No Connection | - | 10 | No connection | - |
| 11 | D4_DLCDD4 | 117 | 12 | D5_DLCDD5 | 118 |
| 13 | D6_DLCDD6 | 119 | 14 | D7_DLCDD7 | 120 |

Table 6-4 LCD Module Connections

6.6. Option Links

Table 6-5 below describes the function of the option links associated with serial configuration. The default configuration is indicated by BOLD text.

| Option Link Settings | | | | |
|----------------------|---------------------------|---|---|---------------|
| Reference | Function | Fitted | Alternative (Removed) | Related To |
| R6 | Serial Port Configuration | Connects programming port (Rx) to E8 connector. | Disconnects programming port (Rx) from E8 connector. | R7, R37, R38 |
| R7 | Serial Port Configuration | Connects programming port (Tx) to E8 connector. | Disconnects programming port (Tx) from E8 connector. | R6, R37, R38 |
| R19 | RS232 Serial | Disables RS232 Serial Transceiver | Enables RS232 Serial Transceiver | |
| R28 | Serial Port Configuration | Connects serial port RXD0 to SERIAL D-type connector. | Disconnects serial port RXD0 from SERIAL D-type connector. | R29 |
| R29 | Serial Port Configuration | Connects serial port TXD0 to SERIAL D-type connector. | Disconnects serial port TXD0 from SERIAL D-type connector. | R28 |
| R30 | Serial Port Configuration | Routes RS232 serial port Rx to application connector (JA6) | Disconnects RS232 serial port Rx from application connector (JA6) | R31 |
| R31 | Serial Port Configuration | Routes RS232 serial port Tx to application connector (JA6) | Disconnects RS232 serial port Tx from application connector (JA6) | R30 |
| R32 | Serial Port Configuration | Connects serial port 1(Tx) to SERIAL D-type (J8). | Disconnects serial port 1 (Tx) from SERIAL D-type. | R16, R26, R33 |
| R33 | Serial Port Configuration | Connects serial port 1 (Rx) to D-type (J8). | Disconnects serial port 1 (Rx) from SERIAL D-type. | R16, R26, R32 |
| R37 | Serial Port Configuration | Connects programming port (Rx) to external connectors (not E8). | Disconnects programming port (Rx) to external connectors (not E8). | R6, R7, R38 |
| R38 | Serial Port Configuration | Connects programming port (Tx) to external connectors (not E8). | Disconnects programming port (Tx) to external connectors (not E8). | R6, R7, R37 |

Table 6-5: Serial configuration links

Table 6-6 below describes the function of the option links associated with Power configuration. The default configuration is indicated by BOLD text.

| Option Link Settings | | | | |
|----------------------|------------------------------|--|--|------------------------|
| Reference | Function | Fitted | Alternative (Removed) | Related To |
| R4 | Power Source | Board can be powered from PWR connector | Disable external power connector | R14, R21, R82 |
| R14 | Power Source | Board is powered from VBUS | Board is powered by another source | R4, R21, R82 |
| R17 | Power Source | Connects external 3.3V power source to Board_VCC | Disconnects external 3.3V power source from Board_VCC | R41 |
| R21 | Power Source | Board can be powered from E8a | Disable E8a power source | R4, R14, R82 |
| R23 | Microcontroller Power Supply | Supply power to Microcontroller | Fit Low ohm resistor to measure current. | |
| R41 | Power Source | Connects regulated 3.3V voltage source to Board_VCC | Disconnects regulated 3.3V voltage source from Board_VCC | R41 |
| R76 | LCD Power Source | LCD powered from External 5V source PWR. | LCD Powered from a different source. | R79, R81 |
| R78 | CON 5V connection | CON 5V connected to External power source PWR. | CON 5V connected to a different place. | R80, R82 |
| R79 | LCD Power Source | LCD powered from VBUS 5V source. | LCD powered from a different source. | R76, R81 |
| R80 | CON 5V connection | CON 5V connected to VBUS 5V source | CON 5V connected to a different place. | R78, R82 |
| R81 | LCD Power Source | LCD powered from Microprocessor 5V Source. | LCD powered from a different source. | R76, R79 |
| R82 | CON 5V connection | CON 5V connected to Microprocessor 5V Source | CON 5V connected to a different place. | R4, R14, R21, R78, R80 |

Table 6-6: Power configuration links

Table 6-7 below describes the function of the option links associated with Analog configuration. The default configuration is indicated by BOLD text.

| Option Link Settings | | | | |
|----------------------|--------------------------|---|--|------------|
| Reference | Function | Fitted | Alternative (Removed) | Related To |
| R34 | Analog Input | AN0 channel connected to JA1 | AN0 channel disconnected from JA1 | R42 |
| R42 | Analog Input | AN0 channel connected to POT | AN0 channel disconnected from POT | R34 |
| R43 | Voltage Reference Source | Voltage Reference set to AVcc signal | Voltage Reference taken from external connector (JA1-7). | R99 |
| R85 | Analog Voltage Source | Analog Voltage Source from external connector. | Analog voltage source from Board_Vcc. | R86, R131 |
| R86 | Analog Voltage Source | Links analog ground to digital ground. | Isolates analog ground from digital ground. | R85,R131 |
| R99 | Voltage Reference Source | Voltage Reference set to AVcc signal | Voltage Reference taken from external connector (J4). | R43 |
| R131 | Analog Voltage Source | Analog voltage source from on board Vcc. | Analog Voltage Source from external connector. | R85,R86 |

Table 6-7: Analog configuration links

Table 6-8 below describes the function of the option links associated with Pin function configuration. The default configuration is indicated by **BOLD** text.

| Option Link Settings | | | | |
|----------------------|---------------------|---------------------------------------|--------------------------------------|------------|
| Reference | Function | Fitted | Alternative (Removed) | Related To |
| R47 | Pin function select | PIN 28 connected to A14 on JA3 | PIN 28 disconnected from A14 | R48 |
| R48 | Pin function select | PIN 28 connected to IO6 on JA1 | PIN 28 disconnected from IO6 | R47 |
| R49 | Pin function select | PIN 83 connected to LWRn on JA3 | PIN 83 disconnected from JA3 | R105 |
| R50 | Pin function select | PIN 31 connected to PTTX | PIN 31 disconnected from PTTX | R61 |
| R51 | Pin function select | PIN 20 connected to IO0 on JA1 | PIN 20 disconnected from IO0 | R52 |
| R52 | Pin function select | PIN 20 connected to A8 on JA3 | PIN 20 disconnected from A8 | R51 |
| R53 | Pin function select | PIN 21 connected to IO1 on JA1 | PIN 21 disconnected from IO1 | R54 |
| R54 | Pin function select | PIN 21 connected to A9 on JA3 | PIN 21 disconnected from A9 | R53 |
| R55 | Pin function select | PIN 23 connected to IO2 on JA1 | PIN 23 disconnected from IO2 | R56 |
| R56 | Pin function select | PIN 23 connected to A10 on JA3 | PIN 23 disconnected from A10 | R55 |
| R57 | Pin function select | PIN 25 connected to IO3 on JA1 | PIN 25 disconnected from IO3 | R58 |
| R58 | Pin function select | PIN 25 connected to A11 on JA3 | PIN 25 disconnected from A11 | R57 |
| R59 | Pin function select | PIN 27 connected to A13 on JA3 | PIN 27 disconnected from A13 | R60 |
| R60 | Pin function select | PIN 27 connected to IO5 on JA1 | PIN 27 disconnected from IO5 | R59 |
| R61 | Pin function select | PIN 31 connected to A17 on JA3 | PIN 31 disconnected from A17 | R50 |
| R62 | Pin function select | PIN 26 connected to A12 on JA3 | PIN 26 disconnected from A12 | R63 |
| R63 | Pin function select | PIN 26 connected to IO4 on JA1 | PIN 26 disconnected from IO4 | R62 |
| R64 | Pin function select | PIN 29 connected to A15 on JA3 | PIN 29 disconnected from A15 | R65 |
| R65 | Pin function select | PIN 29 connected to IO7 on JA1 | PIN 29 disconnected from IO7 | R64 |
| R66 | Pin function select | PIN 32 connected to PTRX | PIN 32 disconnected from PTRX | R67 |
| R67 | Pin function select | PIN 32 connected to A18 on JA3 | PIN 32 disconnected from A18 | R66 |
| R68 | Pin function select | PIN 33 connected to SCK2 | PIN 33 disconnected from SCK2 | R69 |
| R69 | Pin function select | PIN 33 connected to A19 on JA3 | PIN 33 disconnected from A19 | R68 |
| R70 | Pin function select | PIN 36 connected to Un on JA2 | PIN 36 disconnected from Un | R71 |
| R71 | Pin function select | PIN 36 connected to A21 on JA3 | PIN 36 disconnected from A21 | R70 |
| R72 | Pin function select | PIN 35 connected to Up on JA2 | PIN 35 disconnected from Up | R73 |
| R73 | Pin function select | PIN 35 connected to A20 on JA3 | PIN 35 disconnected from A20 | R72 |
| R74 | Pin function select | PIN 37 connected to Vp on JA2 | PIN 37 disconnected from Vp | R75 |
| R75 | Pin function select | PIN 37 connected to A22 on JA3 | PIN 37 disconnected from A22 | R74 |
| R91 | Pin function select | PIN 45 connected to DA0 on JA1 | PIN 45 disconnected from DA0 | R113 |
| R93 | Pin function select | PIN 44 connected to DA1 on JA1 | PIN 44 disconnected from DA1 | R111 |
| R105 | Pin function select | PIN 83 connected to SW3 | PIN 83 disconnected from SW3 | R49 |
| R111 | Pin function select | PIN 44 connected to AN15 on JA5 | PIN 44 disconnected from AN15 | R93 |

| Option Link Settings | | | | |
|----------------------|---------------------|---------------------------------|--------------------------------------|------------|
| Reference | Function | Fitted | Alternative (Removed) | Related To |
| R113 | Pin function select | PIN 45 connected to AN14 on JA5 | PIN 45 disconnected from AN14 | R91 |
| R133 | Pin function select | PIN 30 connected to LED2 | PIN 30 disconnected from LED2 | R130 |
| R130 | Pin function select | PIN 30 connected to A16 on JA3 | PIN 30 disconnected from A16 | R133 |

Table 6-8: Pin function configuration links

Table 6-9 below describes the function of the option links associated with Clock configuration. The default configuration is indicated by BOLD text.

| Option Link Settings | | | | |
|----------------------|---------------------------------|--|---|---------------|
| Reference | Function | Fitted | Alternative (Removed) | Related To |
| R107 | Main OscillatorCrystal | Parallel resistor for crystal | Not fitted | |
| R109 | 48MHz USB Crystal Oscillator | Parallel resistor for crystal | Not fitted | |
| R110 | Main Oscillator Source | Connects on board clock to MCU | External Clock Source | R112,R121 |
| R112 | Main Oscillator Source | Connects external clock to MCU | Disconnects external clock connection to MCU | R110,R121 |
| R114 | 48MHz USB Crystal Oscillator | Connected to Ring Connector | Disconnected from Ring Connector | R117, R118 |
| R117 | 48MHz USB Crystal Oscillator | Force clock Input low. USB uses main oscillator | USB Uses 48MHz Oscillator | R114,R118 |
| R118 | 48MHz USB Crystal Oscillator | Connected to Ring Connector | Disconnected from Ring Connector | R114,R117 |
| R121 | Main Oscillator Source | Connects external clock to MCU | Disconnects external clock connection to MCU | R110,R112 |
| R129 | Crystal Selection | Fit if 16MHz Crystal Fitted | 24MHz Crystal Fitted | R132 |
| R132 | Crystal Selection | Fit if 24MHz Crystal Fitted | 16MHz Crystal Fitted | R129 |

Table 6-9: Clock configuration links

6.7. Oscillator Sources

A crystal oscillator is fitted on the CPU board and used to supply the main clock input to the Renesas microcontroller. Another crystal oscillator is provided to drive the USB clock. Table 6-10 details the oscillators that are fitted and alternative footprints provided on this CPU board:

| Component | | |
|--------------|------------|-------------------------|
| Crystal (X1) | Not Fitted | 48MHz (HC49/4H package) |
| Crystal (X2) | Fitted | 24MHz (HC49/4H package) |

Table 6-10: Oscillators / Resonators

Warning: When replacing the default oscillator with that of another frequency, the debugging monitor will not function unless the following are corrected:

- FDT programming kernels supplied are rebuilt for the new frequency

The user is responsible for code written to support operating speeds other than the default.

6.8. Reset Circuit

The CPU Board includes a simple latch circuit that links the mode selection and reset circuit. This provides an easy method for swapping the device between Boot Mode, User Boot Mode and User mode. This circuit is not required on customer's boards as it is intended for providing easy evaluation of the operating modes of the device on the RSK. Please refer to the Hardware Manual for more information on the requirements of the reset circuit.

The reset circuit operates by latching the state of the boot switch on pressing the reset button. This control is subsequently used to modify the mode pin states as required.

The mode pins should change state only while the reset signal is active to avoid possible device damage.

The reset is held in the active state for a fixed period by a pair of resistors and a capacitor. Please check the reset requirements carefully to ensure the reset circuit on the user's board meets all the reset timing requirements.

6.9. USB Port

This RSK has a Full-speed (12 Mbps) USB port compliant to USB 2.0 specification. It is available as **USB** port on the RSK. This port allows Boot mode programming using **USB Direct** connection and FDT. For more details please refer to *H8S/2215 Group Hardware Manual*.

Chapter 7. Modes

The CPU board can be configured in User mode and Boot mode. User mode may be used to run and debug user code, while Boot mode may only be used to program the Renesas microcontroller with program code via the USB interface. Further details of programming the flash are available in the H8S/2215 Group hardware manual.

Note: Please note that, jumper 'J13' needs to be fitted in order to use the E10A debugger.

The CPU board provides the capability of changing between User and Boot / User Boot modes using a simple latch circuit. This is only to provide a simple mode control on this board when the E10A debugger is not in use.

To manually enter boot mode, press and hold the SW1/BOOT. The mode pins are held in their boot states while reset is pressed and released. Release the boot button. The BOOT LED will be illuminated to indicate that the microcontroller is in boot mode.

More information on the operating modes can be found in the device hardware manual.

7.1.1. Boot mode

The boot mode settings for this CPU board are shown in Table 7-1 below:

| MD2 | MD1 | MD0 | LSI State after Reset End |
|-----|-----|-----|------------------------------|
| 1 | 0 | 1 | Boot Mode |

Table 7-1: Mode pin settings

7.1.2. User Mode

The H8S/2215R supports four user modes. The memory map in all of these modes is 16Mbyte in size. The default user mode for CPU board supporting H8S2215R is mode 7.

| MD2 | MD1 | MD0 | LSI State after Reset End |
|-----|-----|-----|------------------------------|
| 1 | 1 | 1 | User Mode |

Table 7-2: Mode pin settings

Chapter 8. Programming Methods

The board is intended for use with HEW and the supplied E10A debugger. This board can also be programmed using the H8S/2215 on-chip USB port. Refer to *H8S/2215 Group Hardware Manual* for details of programming the microcontroller without using E10A debugger.

Note: Please note that, jumper 'J13' needs to be fitted in order to use the E10A debugger.

Chapter 9.Headers

9.1. Microcontroller Headers

Table 9-1 to Table 9-4 show the microcontroller pin headers and their corresponding microcontroller connections. The header pins connect directly to the microcontroller pin unless otherwise stated.

| J1 | | | | | |
|-----|------------------|------------|-----|------------------|------------|
| Pin | Circuit Net Name | Device Pin | Pin | Circuit Net Name | Device Pin |
| 1 | EMLEn | 1 | 2 | D8 | 2 |
| 3 | D9 | 3 | 4 | D10 | 4 |
| 5 | D11 | 5 | 6 | D12 | 6 |
| 7 | D13 | 7 | 8 | D14 | 8 |
| 9 | D15 | 9 | 10 | Board_VCC | 10 |
| 11 | A0 | 11 | 12 | GROUND | 12 |
| 13 | A1 | 13 | 14 | A2 | 14 |
| 15 | A3 | 15 | 16 | A4 | 16 |
| 17 | A5 | 17 | 18 | A6 | 18 |
| 19 | A7 | 19 | 20 | A8_IO0 | 20 |
| 21 | A9_IO1 | 21 | 22 | No connection | 22 |
| 23 | A10_IO2 | 23 | 24 | No connection | 24 |
| 25 | A11_IO3 | 25 | 26 | A12_IO4 | 26 |
| 27 | A13_IO5 | 27 | 28 | A14_IO6 | 28 |
| 29 | A15_IO7 | 29 | 30 | A16_LED2 | 30 |

Table 9-1: J1

| J2 | | | | | |
|-----|----------------------|------------|-----|----------------------|------------|
| Pin | Circuit Net Name | Device Pin | Pin | Circuit Net Name | Device Pin |
| 1 | A17_PTTX | 31 | 2 | A18_PTRX | 32 |
| 3 | A19_SCK2 | 33 | 4 | No connection | 34 |
| 5 | A20_Up | 35 | 6 | A21_Un | 36 |
| 7 | A22_Vp | 37 | 8 | Vn | 38 |
| 9 | IRQ0n | 39 | 10 | Wp | 40 |
| 11 | Wn | 41 | 12 | TRIGb | 42 |
| 13 | CON_AVSS | 43 | 14 | AN15_DA1 | 44 |
| 15 | AN14_DAO | 45 | 16 | AN3 | 46 |
| 17 | AN2 | 47 | 18 | AN1 | 48 |
| 19 | AN0_ADPOT | 49 | 20 | CON_VREF | 50 |
| 21 | CON_AVCC | 51 | 22 | No connection | 52 |
| 23 | USPND | 53 | 24 | No connection | 54 |
| 25 | VBUS_DET | 55 | 26 | UBPMn | 56 |
| 27 | Board_VCC (DRVCC) | 57 | 28 | No connection (USD-) | 58 |
| 29 | No connection (USD+) | 59 | 30 | GROUND (DRVSS) | 60 |

Table 9-2: J2

| J3 | | | | | |
|-----|------------------------|------------|-----|------------------|------------|
| Pin | Circuit Net Name | Device Pin | Pin | Circuit Net Name | Device Pin |
| 1 | GROUND | 61 | 2 | GROUND (DRVSS) | 62 |
| 3 | No connection (PLLCAP) | 63 | 4 | CON_PLLVCC | 64 |
| 5 | CON_XTAL48 | 65 | 6 | CON_EXTAL48 | 66 |
| 7 | MD0 | 67 | 8 | MD1 | 68 |
| 9 | FWE | 69 | 10 | NMI | 70 |
| 11 | STBYn | 71 | 12 | RESn | 72 |
| 13 | GROUND | 73 | 14 | CON_XTAL | 74 |
| 15 | Board_VCC | 75 | 16 | CON_EXTAL | 76 |
| 17 | MD2 | 77 | 18 | PHI | 78 |
| 19 | ASn | 79 | 20 | RDn | 80 |
| 21 | HWRn | 81 | 22 | No connection | 82 |
| 23 | LWRn_ADTRG_IRQ3n | 83 | 24 | No connection | 84 |
| 25 | LED1 | 85 | 26 | LED0 | 86 |
| 27 | IRQ2n | 87 | 28 | TxD0 | 88 |
| 29 | TxD0 | 89 | 30 | SCK0 | 90 |

Table 9-3: J3

| J4 | | | | | |
|-----|------------------|------------|-----|------------------|------------|
| Pin | Circuit Net Name | Device Pin | Pin | Circuit Net Name | Device Pin |
| 1 | TxD1 | 91 | 2 | RxD1 | 92 |
| 3 | SCK1 | 93 | 4 | PUD+ | 94 |
| 5 | No connection | 95 | 6 | TRISTn | 96 |
| 7 | TMR1 | 97 | 8 | TMR0 | 98 |
| 9 | UD | 99 | 10 | TRIGa | 100 |
| 11 | LED3 | 101 | 12 | IRQ7n | 102 |
| 13 | CS2n | 103 | 14 | CS1n | 104 |
| 15 | CS0n | 105 | 16 | TDO | 106 |
| 17 | TCK | 107 | 18 | TMS | 108 |
| 19 | TRISTn | 109 | 20 | TDI | 110 |
| 21 | D0_DLCDRS | 111 | 22 | No connection | 112 |
| 23 | D1_DLCDE | 113 | 24 | No connection | 114 |
| 25 | D2 | 115 | 26 | D3 | 116 |
| 27 | D4_DLCDD4 | 117 | 28 | D5_DLCDD5 | 118 |
| 29 | D6_DLCDD6 | 119 | 30 | D7_DLCDD7 | 120 |

Table 9-4: J4

9.2. Application Headers

Table 9-5 and Table 9-9 below show the standard application header connections.

| JA1 | | | | | | | | | |
|-----|------------------------|-------|--------------------------|---------------|-----|--------------------------|--|--------------------------|---------------|
| Pin | Generic Header Name | | CPU board Signal Name | Device Pin | Pin | Generic Header Name | | CPU board Signal Name | Device Pin |
| 1 | Regulated Supply (5V) | | --- | --- | 2 | Regulated Supply 1 (Gnd) | | --- | --- |
| 3 | Regulated Supply (3V3) | | --- | --- | 4 | Regulated Supply 2 (Gnd) | | --- | --- |
| 5 | Analog Supply | | AVcc* | 51 | 6 | Analog Supply | | AVss | 43 |
| 7 | Analog Reference | | AVref* | 50 | 8 | ADTRG | | ADTRG_IRQ3n* | 83 |
| 9 | AD0 | | AN0* | 49 | 10 | AD1 | | AN1 | 48 |
| 11 | AD2 | | AN2 | 47 | 12 | AD3 | | AN3 | 46 |
| 13 | DAC0 | | DAC0* | 45 | 14 | DAC1 | | DA1* | 44 |
| 15 | IOPort | | IO0* | 20 | 16 | IOPort | | IO1* | 21 |
| 17 | IOPort | | IO2* | 23 | 18 | IOPort | | IO3* | 25 |
| 19 | IOPort | | IO4* | 26 | 20 | IOPort | | IO5* | 27 |
| 21 | IOPort | | IO6* | 28 | 22 | IOPort | | IO7* | 29 |
| 23 | Open drain | IRQ3n | ADTRG_IRQ3n* | 83 | 24 | IIC_EX | | --- | --- |
| 25 | IIC_SDA | | --- | --- | 26 | IIC_SCL | | --- | --- |

Table 9-5: JA1 Standard Generic Header

| JA2 | | | | | | | | | |
|-----|---------------------|-----|--------------------------|---------------|-----|------------------------|--|--------------------------|---------------|
| Pin | Generic Header Name | | CPU board Signal Name | Device Pin | Pin | Generic Header Name | | CPU board Signal Name | Device Pin |
| 1 | Open drain | | RESn | 72 | 2 | External Clock Input | | CON_EXTAL* | 76 |
| 3 | Open drain | | NMI | 70 | 4 | Regulated Supply (Vss) | | --- | --- |
| 5 | Open drain output | | --- | --- | 6 | Serial Port | | TxD0* | 88 |
| 7 | Open drain | WUP | IRQ0 | 39 | 8 | Serial Port | | RxD0* | 89 |
| 9 | Open drain | | IRQ2 | 87 | 10 | Serial Port | | SCK0* | 90 |
| 11 | Up/down | | UD | 99 | 12 | Serial Port Handshake | | --- | --- |
| 13 | Motor control | | Up* | 35 | 14 | Motor control | | Un* | 36 |
| 15 | Motor control | | Vp* | 37 | 16 | Motor control | | Vn | 38 |
| 17 | Motor control | | Wp* | 40 | 18 | Motor control | | Wn | 41 |
| 19 | Output | | TMR0 | 98 | 20 | Output | | TMR1 | 97 |
| 21 | Input | | TRIGa | 100 | 22 | Input | | TRIGb | 42 |
| 23 | Open drain | | ADTRG_IRQ3n* | 83 | 24 | Tristate Control | | TRISTn | 96 |
| 25 | Reserved | | --- | --- | 26 | Reserved | | --- | --- |

Table 9-6: JA2 Standard Generic Header

| JA3 | | | | | | | |
|-----|---------------------|--------------------------|---------------|-----|-----------------------|--------------------------|---------------|
| Pin | Generic Header Name | CPU board Signal Name | Device Pin | Pin | Generic Header Name | CPU board Signal Name | Device Pin |
| 1 | Address Bus | A0 | 11 | 2 | Address Bus | A1 | 13 |
| 3 | Address Bus | A2 | 14 | 4 | Address Bus | A3 | 15 |
| 5 | Address Bus | A4 | 16 | 6 | Address Bus | A5 | 17 |
| 7 | Address Bus | A6 | 18 | 8 | Address Bus | A7 | 19 |
| 9 | Address Bus | A8* | 20 | 10 | Address Bus | A9* | 21 |
| 11 | Address Bus | A10* | 23 | 12 | Address Bus | A11* | 25 |
| 13 | Address Bus | A12* | 26 | 14 | Address Bus | A13* | 27 |
| 15 | Address Bus | A14* | 28 | 16 | Address Bus | A15* | 29 |
| 17 | Data Bus | D0_DLCDRS | 111 | 18 | Data Bus | D1_DLCADE | 113 |
| 19 | Data Bus | D2 | 115 | 20 | Data Bus | D3 | 116 |
| 21 | Data Bus | D4_DLCD4 | 117 | 22 | Data Bus | D5_DLCD5 | 118 |
| 23 | Data Bus | D6_DLCD6 | 119 | 24 | Data Bus | D7_DLCD7 | 120 |
| 25 | Read/Write Control | RDn | 80 | 26 | Read/Write Control | LWRn* | 83 |
| 27 | Memory Select | CS0n | 105 | 28 | Memory Select | CS1n | 104 |
| 29 | Data Bus | D8 | 2 | 30 | Data Bus | D9 | 3 |
| 31 | Data Bus | D10 | 4 | 32 | Data Bus | D11 | 5 |
| 33 | Data Bus | D12 | 6 | 34 | Data Bus | D13 | 7 |
| 35 | Data Bus | D14 | 8 | 36 | Data Bus | D15 | 9 |
| 37 | Address Bus | A16* | 30 | 38 | Address Bus | A17* | 31 |
| 39 | Address Bus | A18* | 32 | 40 | Address Bus | A19* | 33 |
| 41 | Address Bus | A20* | 35 | 42 | Address Bus | A21* | 36 |
| 43 | Address Bus | A22* | 37 | 44 | External Device Clock | PHI | 78 |
| 45 | Memory Select | CS2n | 103 | 46 | Bus Control | ASn | 79 |
| 47 | Data Bus Strobe | HWRn | 81 | 48 | Data Bus Strobe | LWRn* | 83 |
| 49 | Reserved | | | 50 | Reserved | | |

Table 9-7: JA3 Expansion bus Header

| JA5 | | | | | | | |
|-----|---------------------|--------------------------|---------------|-----|---------------------|--------------------------|---------------|
| Pin | Generic Header Name | CPU board Signal Name | Device Pin | Pin | Generic Header Name | CPU board Signal Name | Device Pin |
| 1 | AD4 | AN14* | 45 | 2 | AD5 | AN15* | 44 |
| 3 | AD6 | --- | --- | 4 | AD7 | --- | --- |
| 5 | CAN1TX | --- | --- | 6 | CAN1RX | --- | --- |
| 7 | CAN2TX | --- | --- | 8 | CAN2RX | --- | --- |
| 9 | AD8 | --- | --- | 10 | AD9 | --- | --- |
| 11 | AD10 | --- | --- | 12 | AD11 | --- | --- |
| 13 | TIOC0A | --- | --- | 14 | TIOC0B | --- | --- |
| 15 | TIOC0C | --- | --- | 16 | M2_TRISTn | --- | --- |
| 17 | TCLKC | --- | --- | 18 | TCLKD | --- | --- |
| 19 | M2_Up | --- | --- | 20 | M2_Un | --- | --- |
| 21 | M2_Vp | --- | --- | 22 | M2_Vn | --- | --- |
| 23 | M2_Wp | --- | --- | 24 | M2_Wn | --- | --- |

Table 9-8: JA5 Optional Generic Header

| JA6 | | | | | | | | | |
|-----|---------------------|-------------|-----------------------------|---------------|-----|----------------------|-------------|-----------------------------|---------------|
| Pin | Generic Header Name | | CPU board Signal Name | Device Pin | Pin | Generic Header Name | | CPU board Signal Name | Device Pin |
| 1 | DMA | | --- | --- | 2 | DMA | | --- | --- |
| 3 | DMA | | --- | --- | 4 | Standby (Open drain) | | STBYn | 71 |
| 5 | Host Serial | | RS232TX* | --- | 6 | Host Serial | | RS232RX* | --- |
| 7 | Serial Port | | RxD1 | 92 | 8 | Serial Port | | TxD1 | 91 |
| 9 | Serial Port | Synchronous | PTTX* | 31 | 10 | Serial Port | | SCK1 | 93 |
| 11 | Serial Port | Synchronous | SCK2* | 33 | 12 | Serial Port | Synchronous | PTRX* | 32 |
| 13 | Reserved | | | | 14 | Reserved | | | |
| 15 | Reserved | | | | 16 | Reserved | | | |
| 17 | Reserved | | | | 18 | Reserved | | | |
| 19 | Reserved | | | | 20 | Reserved | | | |
| 21 | Reserved | | | | 22 | Reserved | | | |
| 23 | Reserved | | | | 24 | Reserved | | | |
| 25 | Reserved | | | | 26 | Reserved | | | |

Table 9-9: JA6 Optional Generic Header

* Marked pins are affected by option links (see 6.6).

Chapter 10. Code Development

10.1. Overview

Note: For all code debugging using Renesas software tools, the CPU board must either be connected to a PC serial port via a serial cable or a PC USB port via an E10A. An E10A is supplied with the RSK product.

Due to the continuous process of improvements undertaken by Renesas the user is recommended to review the information provided on the Renesas website at www.renesas.com to check for the latest updates to the Compiler and Debugger manuals.

10.2. Compiler Restrictions

The compiler supplied with this RSK is fully functional for a period of 60 days from first use. After the first 60 days of use have expired, the compiler will default to a maximum of 64k code and data. To use the compiler with programs greater than this size you will need to purchase the full tools from your distributor.

Warning: The protection software for the compiler will detect changes to the system clock. Changes to the system clock back in time may cause the trial period to expire prematurely.

10.3. Breakpoint Support

This RSK is supplied with E10A emulator which supports breakpoints in ROM. For more details on breakpoints & E10A functions please refer to 'H8S, H8SX Family E10A-USB Emulator User's Manual'.

10.4. Memory Map

The memory map shown in this section visually describes the locations of the each memory areas when operating the RSK in the default mode (Mode 7).




Figure 10-1: Memory Map

Chapter 11. Component Placement




Figure 11-1: Component Placement

Chapter 12. Additional Information

For details on how to use High-performance Embedded Workshop (HEW), refer to the HEW manual available on the CD or installed in the Manual Navigator.

For information about the H8S/2215R series microcontrollers please refer to the *H8S/2215 Group Hardware Manual*

For information about the H8S/2215R assembly language, please refer to the *H8S Series Programming Manual*

For information about the E10A Emulator, please refer to the *H8S, H8SX Family E10A-USB Emulator User's Manual*

Further information available for this product can be found on the Renesas website at:

http://www.renesas.com/renesas_starter_kits

General information on Renesas Microcontrollers can be found on the following website.

Global: <http://www.renesas.com/>

Renesas Starter Kit for H8S/2215R

User's Manual

Publication Date Rev.1.00 17.Jan.2008

Published by: Renesas Technology Europe Ltd.

Dukes Meadow, Millboard Road, Bourne End Buckinghamshire

SL8 5FH, United Kingdom

©2008 Renesas Technology Europe and Renesas Solutions Corp., All Rights Reserved.

Renesas Starter Kit for H8S/2215R User's Manual



Renesas Electronics Corporation

1753, Shimonumabe, Nakahara-ku, Kawasaki-shi, Kanagawa 211-8668 Japan

REG10J0112-0100