ToolStick-F411DC



TOOLSTICK C8051F411 DAUGHTER CARD USER'S GUIDE

1. Handling Recommendations

To enable development, the ToolStick Base Adapter and daughter cards are distributed without any protective plastics. To prevent damage to the devices and/or the host PC, please take into consideration the following recommendations when using the ToolStick:

- Never connect or disconnect a daughter card to or from the ToolStick Base Adapter while the Base Adapter is connected to a PC.
- Always connect and disconnect the ToolStick Base Adapter from the PC by holding the edges of the boards.



Figure 1. Proper Method of Holding the ToolStick

• Avoid directly touching any of the other components.



Figure 2. Improper Method of Holding the ToolStick

 Manipulate mechanical devices on the daughter cards, such as potentiometers, with care to prevent the Base Adapter or daughter card from accidentally dislodging from their sockets.

2. Contents

The ToolStick-F411DC kit contains the following items:

■ ToolStick C8051F411 Daughter Card

The ToolStick Starter Kit includes the following items:

- ToolStick Base Adapter
- ToolStick C8051F411 Daughter Card
- 3-foot USB extension cable

A ToolStick daughter card requires a ToolStick Base Adapter to communicate with the PC. ToolStick Base Adapters can be purchased separately at www.silabs.com/toolstick.

3. ToolStick Overview

The purpose of the ToolStick is to provide a development and demonstration platform for Silicon Laboratories microcontrollers and to demonstrate the Silicon Laboratories software tools, including the Integrated Development Environment (IDE).

The ToolStick development platform consists of two components: the ToolStick Base Adapter and a daughter card. The ToolStick Base Adapter provides a USB debug interface and data communications path between a Windows PC and a target microcontroller.

The target microcontroller and application circuitry are located on the daughter card. Some daughter cards, such as the C8051F411 Daughter Card, are used as general-purpose development platforms for the target microcontrollers and some are used to demonstrate a specific feature or application.

The C8051F411 Daughter Card includes a pair of LEDs, a potentiometer, a resistor across the C8051F411's current DAC output pin, a switch connected to a GPIO, and a small prototyping area which provides access to all of the pins of the device. This prototyping area can be used to connect additional hardware to the microcontroller and use the daughter card as a development platform.

Figure 3 shows the ToolStick C8051F411 Daughter Card and identifies the various components.





2

4. Getting Started

The necessary software to download, debug and communicate with the target microcontroller must be downloaded from www.silabs.com/toolstick. The following software is necessary to build a project, download code to, and communicate with the target microcontroller:

- Silicon Laboratories Integrated Development Environment (IDE)
- Keil Demonstration Tools
- ToolStick Terminal application

The Keil Demo Toolset includes a compiler, assembler, and linker. See "5.2.2. Keil Demonstration C51 C Compiler" for more details about the demo tools. ToolStick Terminal communicates with the target microcontroller's UART through the ToolStick Base Adapter. It can also read/write the two GPIO pins available on the ToolStick Base Adapter.

Other useful software that is provided on the Silicon Labs Downloads (www.silabs.com/mcudownloads) website includes:

- Configuration Wizard 2
- Keil uVision2 and uVision3 Drivers

All of the above software is described in more detail in Section "5. Software Overview".

To simplify the download process, the necessary software described above is provided in two download packages. The IDE Download package includes the Silicon Labs IDE and the Keil Demo Toolset. The ToolStick Download package includes example code, documentation (including user's guides and data sheets), and the ToolStick Terminal application. The Configuration Wizard 2, and Keil uVision Drivers are available as separate downloads. After downloading and installing these two packages, see the following sections for information regarding the software and running one of the demo applications.

5. Software Overview

5.1. Silicon Laboratories IDE

The Silicon Laboratories IDE integrates a source-code editor, source-level debugger, and an in-system Flash programmer. See Section "6. ToolStick C8051F411 Daughter Card Features Demo" for detailed information on how to use the IDE. The Keil Demonstration Toolset includes a compiler, linker, and assembler and easily integrates into the IDE. The use of third-party compilers and assemblers is also supported.

5.1.1. IDE System Requirements

The Silicon Laboratories IDE requirements:

- Pentium-class host PC running Microsoft Windows 2000 or newer.
- One available USB port.
- 64 MB RAM and 40 MB free HD space recommended.

5.1.2. 3rd Party Toolsets

The Silicon Laboratories IDE has native support for many 8051 compilers. The full list of natively supported tools is:

- Keil
- IAR
- Raisonance
- Tasking
- Hi-Tech
- SDCC

Please note that the demo applications for the C8051F411 Daughter Card are written for the Keil toolset.



5.2. Keil Demonstration Toolset

5.2.1. Keil Assembler and Linker

The assembler and linker that are part of the Keil Demonstration Toolset are the same versions that are found in the full Keil Toolset. Once the tools have been installed, the assembler and linker reference manual can be found in the "SiLabs\MCU\IDEfiles\C51\hlp" default directory (A51.pdf).

5.2.2. Keil Demonstration C51 C Compiler

The demonstration version of the C51 compiler is the same as the full version except code size is limited to 2 kB and the floating point library is not included. The C51 compiler reference manual can be found under the **Help** menu in the IDE or in the *"SiLabs\MCU\hlp"* directory (C51.pdf).

5.3. Configuration Wizard 2

The Configuration Wizard 2 is a code generation tool for all of the Silicon Laboratories devices. Code is generated through the use of dialog boxes for each of the device's peripherals.



Figure 4. Configuration Wizard 2 Utility

The Configuration Wizard 2 utility helps accelerate development by automatically generating initialization source code to configure and enable the on-chip resources needed by most design projects. In just a few steps, the wizard creates complete startup code for a specific Silicon Laboratories MCU. The program is configurable to provide the output in C or assembly.

For more information, please refer to the Configuration Wizard 2 documentation. The documentation and software available from the Downloads webpage (www.silabs.com/mcudownloads).



4

5.4. Keil uVision2 and uVision3 Silicon Laboratories Drivers

As an alternative to the Silicon Laboratories IDE, the uVision debug driver allows the Keil uVision2 and uVision3 IDEs to communicate with Silicon Laboratories on-chip debug logic. In-system Flash memory programming integrated into the driver allows for rapidly updating target code. The uVision2 and uVision3 IDEs can be used to start and stop program execution, set breakpoints, check variables, inspect and modify memory contents, and single-step through programs running on the actual target hardware.

For more information, please refer to the uVision driver documentation. The documentation and software are available from the Downloads webpage (www.silabs.com/mcudownloads).

5.5. ToolStick Terminal

The ToolStick Terminal program provides the standard terminal interface to the target microcontroller's UART. However, instead of requiring the usual RS-232 and COM port connection, ToolStick Terminal uses the USB interface of the ToolStick Base Adapter to provide the same functionality.

In addition to the standard terminal functions (send file, receive file, change baud rate), two GPIO pins on the target microcontroller can be controlled using the Terminal for either RTS/CTS handshaking or software-configurable purposes (see the demo software for an example).

See Section 6.8 for more information on using ToolStick Terminal. The software is available on the ToolStick webpage (www.silabs.com/toolstick).



6. ToolStick C8051F411 Daughter Card Features Demo

The ToolStick kit includes a few simple code examples. The example described in this section is titled **F411DC_FeaturesDemo**. The purpose of this example is to guide a new user through the features and capabilities of the IDE and demonstrate the microcontroller's on-chip debug capabilities. The **F411DC_FeaturesDemo** example code uses the potentiometer on the daughter card to vary the blinking rate of the LED. Also, pressing the switch, labeled S1, on the daughter card will toggle the MCU's clock source between the MCU's internal oscillator and the external 32 kHz crystal. The first part of this demo shows how to use the IDE to connect and download the firmware, view and modify registers, use watch windows, use breakpoints, and single step through code. The second part of the demo shows how to use ToolStick Terminal to receive UART data from the daughter card and how to use the GPIO pins.

6.1. Hardware Setup

Connect the ToolStick hardware to the PC using the steps below while taking note of the recommendations in Section 1:

- 1. Connect the ToolStick Base Adapter to the ToolStick C8051F411 Daughter Card.
- 2. If available, connect the USB extension cable to the ToolStick Base Adapter.
- 3. Connect the ToolStick to a USB port on a PC.

See Figure 5 below for an example hardware setup using the C8051F411 ToolStick Daughter Card.



Figure 5. Hardware Setup Example



6.2. Connecting to the Device and Downloading Firmware

This section describes how to open the IDE, open and build a project, connect to a device and download the firmware.

- 1. Open the Silicon Laboratories IDE from the Start \rightarrow Programs \rightarrow Silicon Laboratories menu.
- 2. In the IDE, go to **Project** \rightarrow **Open Project**.
- 3. Browse to the default location, C:\SiLabs\MCU\ToolStick\F411DC\Firmware\.
- 4. Select F411DC_FeaturesDemo.wsp and click OK.
- 5. In the IDE, select $Project \rightarrow Rebuild Project$.
- 6. Go to **Options** \rightarrow **Connection Options**.
- 7. Select "USB Debug Adapter" for the Serial Adapter and "C2" for the Debug Interface, and then click "OK".
- 8. Go to **Debug** \rightarrow **Connect**.
- 9. Download the code using the download button on the menu bar or use alt-D.

Once these steps are completed, the firmware is built into an object file (step 5) and downloaded to the device (step 9). The device is now ready to begin executing code. If all of these steps were followed successfully, the "Go" option is enabled in the Debug menu. A green circle icon in the IDE toolbar also indicates that the device is ready to run. If one of the steps leads to an error, make sure that the ToolStick is properly inserted in a USB port and start again with step 6.

6.3. Running and Stopping Code Execution

Once the IDE is connected to the device and the firmware is loaded, the IDE can start and stop the code execution. The following steps can be performed using the buttons on the toolbar or using the options in the Debug menu.

To start code execution, click the green "Go" button on the toolbar or use the Debug → Go menu option. The green LED on the daughter card will start to flash. The debug commands in the IDE (single-step, multiple-step, set breakpoint, and others) are disabled when the device is running. While the firmware is running, the potentiometer on the daughter card can be turned to alter the blinking speed of the LED.



To stop code execution, click the red "Stop" button on the toolbar or use the Debug → Stop menu option. The device will halt code execution and all of the registers and pins on the device will hold their state.



All debug windows and watch windows are refreshed when the device is stopped. If any of the values in these windows have changed since the last time the device was halted, the new value is shown in red text instead of black text.



6.4. Viewing and Modifying Registers

All registers on the device can be viewed and modified when the device is in a halted state. The registers are grouped together according to which peripheral or part of hardware they belong. As an example, this guide shows how to open the ADC0 Debug Window and disable the ADC0 directly from the IDE.

 Open the ADC0 Debug Window from the View → Debug Windows → SFR's → ADC0 menu option. The ADC0 Debug Window appears on the right-hand side of the IDE. In this window, the ADC0CN register is shown. This register is used to enable and configure the on-chip ADC. When the firmware is running, the ADC0CN register reads as 0x82 indicating that the ADC is running.



2. In the debug window, change the value of **ADC0CN** from 0x82 to 0x02. This value turns off the ADC on the target microcontroller.

			- - x
AMXON	=	11	
AMXOP	=	0E	
ADCOCN	=	02	
ADCOCF	=	FO	
ADCOL	=	00	
ADCOH	=	00	
ADCOGTL	=	FF	
ADCOGTH	=	FF	
ADCOLTL	=	00	
ADCOLTH	=	00	

3. To write this new value to the device, select **Refresh** from the Debug Menu or click the **Refresh** button in the toolbar.



- 4. Click "Go" to resume running the device with the new ADC0CN value.
- 5. Turn the potentiometer on the daughter card and notice that it has no effect on the blinking rate of the LED.
- 6. Re-enable the ADC by writing 0x82 to the ADC0CN and clicking the Refresh button.

Changing the values of registers does not require recompiling the code and redownloading the firmware. At any time, the device can be halted and the values of the registers can be changed. After selecting "Go", the firmware will continue execution using the new values. This capability greatly speeds up the debugging process. See the data sheet for the C8051F30x device family for the definitions and usage for all registers.

The debug windows for other sets of registers are found in the View \rightarrow Debug Windows \rightarrow SFR's menu.



8

6.5. Enabling and Using Watch Windows

The Debug Windows in the View menu are used to view and modify hardware registers. To view and modify variables in code, the IDE provides Watch Windows. Just as with register debug windows, variables in the watch windows are updated each time the device is halted. This section of the User's Guide explains how to add a variable to the watch window and modify the variable. In the F300_FeatureDemo example code, the variable **Num_LED_Flashes** is a counter that stores the number of times the LED blinks.

- 1. If the device is running, stop execution using the "**Stop**" button or use the **Debug** \rightarrow **Stop** menu option.
- 2. In the File View on the left-hand side of the IDE, double-click on F300DC_FeaturesDemo.c to open the source file.
- 3. Scroll to the **ADC0_ISR** function (line 283) and right-click on the variable "**Num_LED_Flashes**". In the context menu that appears, select "**Add Num_LED_Flashes to Watch**" and then choose "**Default**." On the right-hand portion of the IDE, the watch window appears and the variable is added. The current value of the variable is shown to the right of the name.

	// // if {	Toggle the ADC interr (ADC_Blink	state of the LED every <adc_9 upt _Counter++ >= (ADC_SAMPLE_RATE</adc_9 	SAMPLE_RATE/Blink_Rate> S/Blink_Rate))
		LED = !LED Num_LED_F1	;	
		ADC_Blink_	Add Num_LED_Flashes to Watch	Detailed Type 🔹 🕨
}	}		🖑 Insert/Remove Breakpoint	Default
els: {	e		🗾 Enable/Disable Breakpoint	
:	if	(ADC_resul	*{} Run to Cursor	max reading indicates VDD
	ł	percentage PWM Duty C	Undo Redo	(VDD - 1 LSB)
ė	} els /	se	苏 Cut	
	ι	percentage	Copy	256;
		percentage PWM_Duty_C	🗟 Paste	ADC_COUNTS; .lt * (long)100) /
	}	(long)A	Select All	

- 4. Start and stop the device a few times. See that the value of the Num_LED_Flashes is incremented each time the LED blinks.
- When the device is halted, click on the value field in the watch window and change the value to 0. Then click the Refresh button or select Debug → Refresh to write the new value to the device.

	x
Name	Value
Num_LED_Flashes	0
11	

6. Start and stop the device a few times to watch the variable increment starting at 0.

Changing the values of variables does not require recompiling the code and redownloading the firmware. At any time, the device can be halted and the values of the variables can be changed. The firmware will continue execution using the new values.



6.6. Setting and Running to Breakpoints

The Silicon Laboratories microcontroller devices support up to four hardware breakpoints. A breakpoint is associated with a specific line of code. When the processor reaches a hardware breakpoint, the code execution stops, and the IDE refreshes all debug and watch windows. The on-chip debug hardware allows for breakpoints to be placed on any line of executable code, including code in Interrupt Service Routines. This section provides steps to set a breakpoint on the line of source code that increments the **Num_LED_Flashes** variable.

- 1. If the device is running, stop execution using the "**Stop**" button or use the **Debug** \rightarrow **Stop** menu option.
- Scroll to the Timer3_ISR function (line 351) and right-click on the variable "Num_LED_Flashes". In the context
 menu that appears, select "Insert/Remove Breakpoint." On the left side of the line in the editor window, a red
 circle is added to indicate a breakpoint is placed on the source line.

//		
void TIMER3_IS	<pre>GR (void) interrupt 14 '0x80;</pre>	// Cle
LED = LED;		
Num_LED_F1	Add Num_LED_Flashes to Watch	•
// //_Initializa	Insert/Remove Breakpoint Finable/Disable Breakpoint Finable/Disable/Disable Breakpoint Finable/Disable/Disable Breakpoint Finable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Disable/Dis	i i i
OSCILLATOR	Undo	—t
// // Return Valu // Parameters	Redo X Cut	_
// This funct: // oscillator	Copy	리
void OSCILLAT	Select All	-

- 3. Click the "**Go**" button or select the **Debug** \rightarrow **Go** menu option.
- 4. After a short time, the IDE will show that the device is halted. A blue line will be placed in the editor window to indicate where the code execution has stopped.

11-		
vo	id TIMER3_ISR (void) interrupt 1	4
1	TARBEN &= ~UxBU;	
	LED = !LED;	
<mark>۰</mark> ۲	Nun_LED_Flashes++;	

5. **Start** and **stop** the processor a few more times. Notice that the LED blinks once for every time the processor is started and the **Num_LED_Flashes** variable also increments by one.



6.7. Single-Stepping Through Firmware

The IDE supports the ability to single-step through firmware one assembly instruction at a time. The IDE reads the Flash from the device, converts the instructions to assembly and displays them in a disassembly window. The following steps show how to open the disassembly window and single step through firmware.

- 1. If there is already not a breakpoint set on line of code that increments the **Num_LED_Flashes** variable, set the breakpoint using the steps described in Section 6.6.
- 2. Start the processor using the "Go" button and wait till it stops on the breakpoint.
- Select View → Debug Windows → Disassembly. The disassembly window will appear on the right-hand side of the IDE, if it is not already open.
- 4. To execute one assembly instruction at a time, click the "Step" button on the toolbar or select the Debug → Step menu option. The highlighted line in the disassembly window indicates the next instruction to be executed. The blue line marker in the editor window will stay on the same .C source line until all of the assembly instructions are completed.

📆 🐺 🖓 😗 🖉 🗶 🖉 🦉 0Đ 🎬 🎬 🚟 🏐 🛀 65 😂 🖽 Address if (PVN_Duty_Cycle != PVM_Duty_C update = 1; 0D3D E4 CLR A 0D3E FA 0D3F F9 MON R2, A MOV R1, A PWM_Duty_Cycle_Old = PWM_Duty_Cyc 0D40 F8 MOV RO,A Set new PCA0 Module0 PVM duty MOV A.11H 0D41 E5 11 PCA0CPH0 = (char) percentage; 0D43 24 01 ADD A,#01H 0D45 F5 0D47 EA MOV 11H, A 11 MOV A, R2 35 10 A,10H 0D48 ADDC MOV 10H, A MOV A, R1 0D4A F5 10 0D4C E9 0D4D ADDC A, OFH 35 0FTIMER3 ISR 0D4F F5 OF MOV OFH A 0D51 E8 MOV A, RO This ISR is triggered upon a Timer3 the state of the LED and keeps track 0D52 ADDC A, OEH 35 OE MOV OEH, A 0D54 F5 0E POP 02H 0D56 D0 02 0D58 D0 01 POP 01H 0D5A D0 00 POP 00H 0D5C D0 D0 POP DOH void TIMER3_ISR (void) interrupt 14 FOP EOH OD5E D0 E0 TMR3CN &= ~0x80; 32 0D60 RETI 0D61 4C ORL A, R4 LED = !LED; 0D62 45 44 ORL A,44H 0D64 20 42 6C JB 28.2H,6CH 0D67 69 XRL A,R1 Num_LED_Flashes++; 0D68 6E XRL A.R6

The disassembly window has three columns. The left column is the address of the instruction in Flash. The middle column is the instruction in hex. The right column is the disassembled instruction. The Disassembly debug window and the capability to single-step through firmware allows a developer to see exactly what instructions are executed and their output.



ToolStick-F411DC

6.8. Using ToolStick Terminal

This section describes how to use ToolStick Terminal to communicate with UART from the PC to the daughter card through the ToolStick Base Adapter.

- 1. If the Silicon Laboratories IDE is open, close the IDE. The IDE and the ToolStick Terminal cannot communicate with the daughter card simultaneously.
- 2. Open ToolStick Terminal from the Start \rightarrow Programs \rightarrow Silicon Laboratories menu.

Connect Con	rminal ToolStick Help				
Transfer Data: Data Format Capture Data to File Receive File: Feceive_data.bt Send Data Receive Data: Capture Receive Data to File: Capture Receive	Connection TS00000834	Current Pn State GPI00 GPI01 C2 Reset	Pin State Configuration Do Not Set GPI00 Do Not Set GPI01 Do Not Set C2 Reset	+ + +	Set Selected Pin States
Send Data Capture Receive Data to File Receive Data:	Fransfer Data:		C Hex Format	Capture D Receive receive_	Data to File File: data.bxt
Receive Data:	Devise Data		Send Data	Capture	e Receive Data to File
	Receive Data:				

- 3. Go to the **ToolStick** \rightarrow **Settings** menu.
- 4. Under "Pin Settings", change GPIO0 / RTS to "GPIO Output Push Pull" and click "OK." The rest of the default settings are correct for the C8051F411 Features Demo.
- 5. In the top, left-hand corner of the Terminal application, available devices are shown in the drop-down Connection menu. Click "Connect" to connect to the device. In the "Receive Data" window, text indicating the blink rate of the LED will appear.
- 6. Turn the potentiometer on the daughter card and see that the blink rate is updated on the daughter card and the new blink rate is printed to the Terminal.

In addition to the standard two UART pins (TX and RX), there are two GPIO/UART handshaking pins on the ToolStick Base Adapter that are connected to two port pins on the target microcontroller. ToolStick Terminal is used to configure and read/write these pins. For the **F411DC_FeaturesDemo**, one of these GPIO pins is connected to an external interrupt pin on the C8051F411. The following steps describe how to change the level of one of the GPIO pins and trigger an interrupt on the target microcontroller. The interrupt forces the firmware to switch modes and send a pulse-width modulated (PWM) signal to the LED instead of blinking the LED using an on-chip Timer.

- 1. In ToolStick Terminal, under Pin State Configuration, select "Set GPIO0 Logic Low" and click on "Set Selected Pin States." This changes the level of the GPIO0 pin from Logic High to Logic Low and triggers a levelsensitive interrupt on the microcontroller.
- 2. In the Receive window, see that the printed text has changed to indicate the LED PWM duty cycle.
- 3. Turn the potentiometer on the daughter card to change the brightness of the LED on the daughter card.
- 4. Change the GPIO0 pin state back to **Logic High** and notice that the firmware switches back to blinking the LED.

The firmware on the C8051F411 target microcontroller does not need to be customized to use the UART and communicate with ToolStick Terminal. The firmware on the microcontroller should write to the UART as it would in any standard application and all of the translation is handled by the ToolStick Base Adapter.



7. Using the C8051F411 Daughter Card as a Development Platform

The prototyping area on the ToolStick C8051F411 daughter card makes it easy to interface to external hardware. All of the digital I/O pins are available so it possible to create a complete system.

7.1. C8051F411 Pin Connections

It is important to note that if external hardware is being added, some of the existing components on the board can interfere with the signaling. The following is a list of port pins on the C8051F411 that are connected to other components:

- P0.2, P0.3 These pins are connected directly to the ToolStick Base Adapter's GPIO pins. By default, these GPIO pins on the Base Adapter are high-impedance pins so they will not affect any signaling. Configuring these pins on the Base Adapter to output pin or handshaking pins could affect signaling.
- P0.4, P0.5 These pins are connected directly to the ToolStick Base Adapter for UART communication.
- P1.4 This pin is connected to the "S1" switch. The switch can be removed to disconnect them from the pin.
- P1.6 This pin is connected to the output of the potentiometer. R5 (a 0 Ω resistor) can be removed to disconnect the potentiometer from the pin.
- P2.1 This pin is connected to the cathode of the green LED on the daughter card. The LED or the R2 resistor can be removed to disconnect the LED from the pin.

See the daughter card schematic in Section 9 for more information.

7.2. C2 Pin Sharing

On the C8051F411, the debug pins, C2CK, and C2D, are shared with the pins /RST and P2.7 respectively. The daughter card includes the resistors necessary to enable pin sharing which allow the /RST and P2.7 pins to be used normally while simultaneously debugging the device. See Application Note "AN124: Pin Sharing Techniques for the C2 Interface" at www.silabs.com for more information regarding pin sharing.

8. Information Locations

Example source code is installed by default in the C:\SiLabs\MCU\ToolStick\F411DC\Firmware directory during the ToolStick installation.

Documentation for the ToolStick kit, including this User's Guide, can be found by default in the C:\SiLabs\MCU\ToolStick\Documentation and the C:\SiLabs\MCU\ToolStick\F411DC\Documentation directories.

The installer for the ToolStick software is available at www.silabs.com/toolstick.



ToolStick-F411DC

9. C8051F411 Daughter Card Schematic





NOTES:

CONTACT INFORMATION

Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 Tel: 1+(512) 416-8500 Fax: 1+(512) 416-9669 Toll Free: 1+(877) 444-3032

Email: MCUinfo@silabs.com Internet: www.silabs.com

The information in this document is believed to be accurate in all respects at the time of publication but is subject to change without notice. Silicon Laboratories assumes no responsibility for errors and omissions, and disclaims responsibility for any consequences resulting from the use of information included herein. Additionally, Silicon Laboratories assumes no responsibility for the functioning of undescribed features or parameters. Silicon Laboratories reserves the right to make changes without further notice. Silicon Laboratories makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Silicon Laboratories assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Silicon Laboratories products are not designed, intended, or authorized for use in applications intended to support or sustain life, or for any other application in which the failure of the Silicon Laboratories product could create a situation where personal injury or death may occur. Should Buyer purchase or use Silicon Laboratories products for any such unintended or unauthorized application, Buyer shall indemnify and hold Silicon Laboratories harmless against all claims and damages.

Silicon Laboratories and Silicon Labs are trademarks of Silicon Laboratories Inc.

Other products or brandnames mentioned herein are trademarks or registered trademarks of their respective holders.

