

To our customers,

---

## Old Company Name in Catalogs and Other Documents

---

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1<sup>st</sup>, 2010  
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

# User's Manual

# IE-789177-NS-EM1

## Emulation Board

---

### Target Devices

**$\mu$ PD789167 Subseries**

**$\mu$ PD789167Y Subseries**

**$\mu$ PD789177 Subseries**

**$\mu$ PD789177Y Subseries**

[MEMO]

**Windows is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.**

**PC/AT is a trademark of International Business Machines Corporation.**

- **The information in this document is current as of January, 2002. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC's data sheets or data books, etc., for the most up-to-date specifications of NEC semiconductor products. Not all products and/or types are available in every country. Please check with an NEC sales representative for availability and additional information.**

- No part of this document may be copied or reproduced in any form or by any means without prior written consent of NEC. NEC assumes no responsibility for any errors that may appear in this document.

- NEC does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC semiconductor products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC or others.

- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of customer's equipment shall be done under the full responsibility of customer. NEC assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.

- While NEC endeavours to enhance the quality, reliability and safety of NEC semiconductor products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC semiconductor products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment, and anti-failure features.

- NEC semiconductor products are classified into the following three quality grades:

"Standard", "Special" and "Specific". The "Specific" quality grade applies only to semiconductor products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of a semiconductor product depend on its quality grade, as indicated below. Customers must check the quality grade of each semiconductor product before using it in a particular application.

"Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots

"Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support)

"Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC semiconductor products is "Standard" unless otherwise expressly specified in NEC's data sheets or data books, etc. If customers wish to use NEC semiconductor products in applications not intended by NEC, they must contact an NEC sales representative in advance to determine NEC's willingness to support a given application.

(Note)

(1) "NEC" as used in this statement means NEC Corporation and also includes its majority-owned subsidiaries.

(2) "NEC semiconductor products" means any semiconductor product developed or manufactured by or for NEC (as defined above).

M8E 00.4

# Regional Information

Some information contained in this document may vary from country to country. Before using any NEC product in your application, please contact the NEC office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

## **NEC Electronics Inc. (U.S.)**

Santa Clara, California  
Tel: 408-588-6000  
800-366-9782  
Fax: 408-588-6130  
800-729-9288

## **NEC do Brasil S.A.**

Electron Devices Division  
Guarulhos-SP, Brasil  
Tel: 11-6462-6810  
Fax: 11-6462-6829

## **NEC Electronics (Europe) GmbH**

Duesseldorf, Germany  
Tel: 0211-65 03 01  
Fax: 0211-65 03 327

### **• Sucursal en España**

Madrid, Spain  
Tel: 091-504 27 87  
Fax: 091-504 28 60

### **• Succursale Française**

Vélizy-Villacoublay, France  
Tel: 01-30-67 58 00  
Fax: 01-30-67 58 99

### **• Filiale Italiana**

Milano, Italy  
Tel: 02-66 75 41  
Fax: 02-66 75 42 99

### **• Branch The Netherlands**

Eindhoven, The Netherlands  
Tel: 040-244 58 45  
Fax: 040-244 45 80

### **• Branch Sweden**

Taeby, Sweden  
Tel: 08-63 80 820  
Fax: 08-63 80 388

### **• United Kingdom Branch**

Milton Keynes, UK  
Tel: 01908-691-133  
Fax: 01908-670-290

## **NEC Electronics Hong Kong Ltd.**

Hong Kong  
Tel: 2886-9318  
Fax: 2886-9022/9044

## **NEC Electronics Hong Kong Ltd.**

Seoul Branch  
Seoul, Korea  
Tel: 02-528-0303  
Fax: 02-528-4411

## **NEC Electronics Shanghai, Ltd.**

Shanghai, P.R. China  
Tel: 021-6841-1138  
Fax: 021-6841-1137

## **NEC Electronics Taiwan Ltd.**

Taipei, Taiwan  
Tel: 02-2719-2377  
Fax: 02-2719-5951

## **NEC Electronics Singapore Pte. Ltd.**

Novena Square, Singapore  
Tel: 253-8311  
Fax: 250-3583

## Major Revisions in This Edition

Page	Description
Throughout	<ul style="list-style-type: none"> <li>• Addition of description of IE-78K0S-NS-A as supported in-circuit emulator</li> <li>• Addition of NP-H44GB-TQ as supported emulation probe</li> </ul>
pp. 12, 13	<p><b>Figure 1-1 System Configuration</b></p> <ul style="list-style-type: none"> <li>• Modification of supply medium of debugger ID78K0S-NS to CD-ROM</li> <li>• Modification of <b>Notes 1 to 3</b></li> </ul>
p. 15	Modification of part of <b>Table 1-1 Basic Specifications</b>
pp. 20 to 22	<p><b>3.2.1 Overview of clock settings</b></p> <ul style="list-style-type: none"> <li>• Modification of “internal clock” to “clock oscillator”</li> <li>• <b>Figure 3-2 External Circuits Used as System Clock Oscillator</b> Addition of V<sub>SS</sub> pin to the figure of <b>(a) Clock oscillator</b></li> <li>• <b>Figure 3-3 When Using Clock That Is Already Mounted on Emulation Board</b> and <b>Figure 3-4 When Using User-Mounted Clock</b> Modification of “resonator” in target system to “clock oscillator or external clock”</li> <li>• Modification of “clock generator” to “external clock” in <b>Figure 3-5 When Using an External Clock</b></li> </ul>
p. 34 in previous revision	Deletion of <b>3.4 Low-Voltage Emulation Setting</b>
p. 33	Addition of <b>3.4 Power Supply Voltage Setting of Target Interface</b>
p. 35	<p><b>3.6 Switch and Jumper Settings</b></p> <ul style="list-style-type: none"> <li>• Addition of <b>(2) Switch and jumper settings on the IE-78K0S-NS-A</b></li> </ul>
p. 42	Addition of <b>APPENDIX B CAUTIONS ON DESIGNING TARGET SYSTEM</b>

The mark ★ shows major revised points.

## INTRODUCTION

### Product Overview

The IE-789177-NS-EM1 is designed to be used with the IE-78K0S-NS or IE-78K0S-NS-A to debug the following target devices that belong to the 78K/0S Series of 8-bit single-chip microcontrollers.

- $\mu$ PD789167 Subseries:  $\mu$ PD789166, 789167
- $\mu$ PD789177 Subseries:  $\mu$ PD789176, 789177, 78F9177, 78F9177A
- $\mu$ PD789167Y Subseries:  $\mu$ PD789166Y, 789167Y
- $\mu$ PD789177Y Subseries:  $\mu$ PD789176Y, 789177Y, 78F9177Y, 78F9177AY

### Target Readers

This manual is intended for engineers who will use the IE-789177-NS-EM1 with the IE-78K0S-NS or IE-78K0S-NS-A to perform system debugging.

Engineers who use this manual are expected to be thoroughly familiar with the target device's functions and use methods and to be knowledgeable about debugging.

### Organization

When using the IE-789177-NS-EM1, refer to not only this manual (supplied with the IE-789177-NS-EM1) but also the manual that is supplied with the IE-78K0S-NS or IE-78K0S-NS-A.

IE-78K0S-NS User's Manual
------------------------------

- Basic specifications
- System configuration
- External interface functions

IE-78K0S-NS-A User's Manual
--------------------------------

- Basic specifications
- System configuration
- External interface functions

IE-789177-NS-EM1 User's Manual
-----------------------------------

- General
- Part names
- Installation
- Differences between target devices and target interface circuits

### Purpose

This manual's purpose is to explain various debugging functions that can be performed when using the IE-789177-NS-EM1.



## Terminology

The meanings of certain terms used in this manual are listed below.

Term	Meaning
Emulation device	This is a general term that refers to the device in the emulator that is used to emulate the target device. It includes the emulation CPU.
Emulation CPU	This is the CPU block in the emulator that is used to execute user-generated programs.
Target device	This is the device to be emulated (a real chip).
Target system	This includes the target program and the hardware provided by the user. When defined narrowly, it includes only the hardware.
IE system	This refers to the combination of the IE-78K0S-NS or IE-78K0S-NS-A and the IE-789177-NS-EM1.

## Conventions

Data significance: Higher digits on the left and lower digits on the right

**Note:** Footnote for item marked with **Note** in the text

**Caution:** Information requiring particular attention

**Remark:** Supplementary information

## Related Documents

The related documents (user's manuals) indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

Document Name	Document Number
IE-78K0S-NS	U13549E
IE-78K0S-NS-A	U15207E
IE-789177-NS-EM1	U14621E
ID78K0-NS, ID78K0S-NS Integrated Debugger Ver. 2.20 or Later Operation (Windows™ Based)	U14910E
μPD789167, 789177, 789167Y, 789177Y Subseries	U14186E

**Caution** The documents listed above are subject to change without notice. Be sure to use the latest documents when designing.

# CONTENTS

<b>CHAPTER 1 GENERAL</b> .....	<b>11</b>
<b>1.1 System Configuration</b> .....	<b>12</b>
<b>1.2 Hardware Configuration</b> .....	<b>14</b>
<b>1.3 Basic Specifications</b> .....	<b>15</b>
<b>CHAPTER 2 PART NAMES</b> .....	<b>16</b>
<b>2.1 Parts of Main Unit</b> .....	<b>17</b>
<b>CHAPTER 3 INSTALLATION</b> .....	<b>18</b>
<b>3.1 Connection</b> .....	<b>19</b>
<b>3.2 Clock Settings</b> .....	<b>20</b>
3.2.1 Overview of clock settings.....	20
3.2.2 Main system clock settings.....	22
3.2.3 Subsystem clock settings.....	27
<b>3.3 Mask Option Settings</b> .....	<b>32</b>
★ <b>3.4 Power Supply Voltage Setting of Target Interface</b> .....	<b>33</b>
<b>3.5 External Trigger</b> .....	<b>34</b>
<b>3.6 Switch and Jumper Settings</b> .....	<b>35</b>
<b>CHAPTER 4 DIFFERENCES BETWEEN TARGET DEVICES AND TARGET INTERFACE CIRCUITS</b> ..	<b>36</b>
<b>APPENDIX A. EMULATION PROBE PIN ASSIGNMENT TABLE</b> .....	<b>40</b>
★ <b>APPENDIX B. CAUTIONS ON DESIGNING TARGET SYSTEM</b> .....	<b>42</b>

## LIST OF FIGURES

Figure No.	Title	Page
1-1	System Configuration .....	12
1-2	Basic Hardware Configuration .....	14
2-1	IE-789177-NS-EM1 Part Names.....	17
3-1	Connection of Emulation Probe .....	19
3-2	External Circuits Used as System Clock Oscillator .....	20
3-3	When Using Clock That Is Already Mounted on Emulation Board.....	21
3-4	When Using User-Mounted Clock .....	21
3-5	When Using an External Clock .....	22
3-6	Connections on Parts Board (When Using Main System Clock or User-Mounted Clock) .....	23
3-7	Crystal Oscillator (When Using Main System Clock or User-Mounted Clock) .....	25
3-8	Pin Alignment of Crystal Oscillator and Socket .....	25
3-9	Connections on Parts Board (When Using Subsystem Clock or User-Mounted Clock) .....	28
3-10	Crystal Oscillator (When Using Subsystem Clock or User-Mounted Clock) .....	30
3-11	Pin Alignment of Crystal Oscillator and Socket .....	30
3-12	Mask Option Setting .....	32
3-13	Connection of TP1 and Power Supply Voltage of Target System .....	33
3-14	External Trigger Input Position .....	34
4-1	Equivalent Circuit 1 of Emulator .....	38
4-2	Equivalent Circuit 2 of Emulator .....	39
B-1	Distance Between In-Circuit Emulator and Conversion Socket (NP-44GB, NP-44GB-TQ).....	42
B-2	Connction Condition of Target System (NP-H44GB-TQ).....	43
B-3	Distance Between In-Circuit Emulator and Conversion Socket (NP-48GA) .....	44
B-4	Connection Condition of Target System (NP-48GA) .....	45

## LIST OF TABLES

Table No.	Title	Page
1-1	Basic Specifications .....	15
3-1	Main System Clock Settings .....	22
3-2	Subsystem Clock Settings .....	27
3-3	SW1 Switch Setting .....	32
3-4	Switch and Jumper Settings on IE-78K0S-NS .....	35
3-5	Switch and Jumper Settings on IE-78K0S-NS-A .....	35
3-6	Initialize Settings of Switch and Jumper on IE-789177-NS-EM1 .....	35
A-1	NP-44GB, NP-44GB-TQ, NP-H44GB-TQ Pin Assignments.....	40
A-2	NP-48GA Pin Assignments .....	41

## CHAPTER 1 GENERAL

The IE-789177-NS-EM1 is a development tool for efficient debugging of hardware or software when using one of the following target devices that belong to the 78K/0S Series of 8-bit single-chip microcontrollers.

This chapter describes the IE-789177-NS-EM1's system configuration and basic specifications.


- Target devices
  - $\mu$ PD789167 Subseries
  - $\mu$ PD789177 Subseries
  - $\mu$ PD789167Y Subseries
  - $\mu$ PD789177Y Subseries

## 1.1 System Configuration

Figure 1-1 illustrates the IE-789177-NS-EM1's system configuration.

★

**Figure 1-1. System Configuration**



**Notes 1.** The device file is as follows.

$\mu$ SxxxxDF789178:  $\mu$ PD789167, 789167Y, 789177, 789177Y Subseries  
Device files can be downloaded from the NEC Electron Devices Web site  
(URL: <http://www.ic.nec.co.jp/micro>).

**2.** The emulation probe is as follows.

NP-44GB: 44-pin plastic QFP (GB-8ES type)

NP-44GB-TQ: 44-pin plastic QFP (GB-8ES type)

NP-H44GB-TQ: Long type for 44-pin plastic QFP (GB-8ES type)

NP-48GA: 48-pin plastic TQFP (GA-9EU type)

The NP-44GB, NP-44GB-TQ, NP-H44GB-TQ, and NP-48GA are products of Naito Densei Machida Mfg. Co., Ltd.

For further information, contact Naito Densei Machida Mfg. Co., Ltd. (+81-45-475-4191)

**3.** The conversion socket/conversion adapter are as follows.

EV-9200G-44: 44-pin plastic LQFP (GB-8ES type)

TGB-044SAP: 44-pin plastic LQFP (GB-8ES type)

TGA-048SDP: 48-pin plastic TQFP (GA-9EU type)

The TGB-044SAP and TGA-048SDP are products of TOKYO ELETECH CORPORATION.

For further information, contact Daimaru Kogyo Co., Ltd.


Tokyo Electronics Department (+81-3-3820-7112)

Osaka Electronics Department (+81-6-6244-6672)

## 1.2 Hardware Configuration

Figure 1-2 shows the IE-789177-NS-EM1's position in the basic hardware configuration.

**Figure 1-2. Basic Hardware Configuration**





### 1.3 Basic Specifications

The IE-789177-NS-EM1's basic specifications are listed in Table 1-1.

★

**Table 1-1. Basic Specifications**

Parameter	Description
Target device	$\mu$ PD789167, 789177, 789167Y, 789177Y Subseries
System clock	10.0 MHz
Main clock supply	External: Input via an emulation probe from the target system Internal: Mounted on emulation board (5.0 MHz), or mounted on the board by the user
Subsystem clock supply	Internal: Mounted on emulation board (32.768 kHz), or mounted on the board by the user
Target interface voltage	$V_{DD} = 1.8$ to $5.5$ V (same as target device) Operates on internal power supply (5 V) when target system not connected

## CHAPTER 2 PART NAMES

This chapter introduces the parts of the IE-789177-NS-EM1 main unit.


The packing box contains the emulation board (IE-789177-NS-EM1), packing list, user's manual, and guarantee card.

If there are any missing or damaged items, please contact an NEC sales representative.

Fill out and return the guarantee card that comes with the main unit.

2.1 Parts of Main Unit

Figure 2-1. IE-789177-NS-EM1 Part Names



## CHAPTER 3 INSTALLATION

This chapter describes methods for connecting the IE-789177-NS-EM1 to the IE-78K0S-NS or IE-78K0S-NS-A, emulation probe, etc. Mode setting methods are also described.

**Caution** Connecting or removing components to or from the target system, or making switch or other setting changes must be carried out after the power supply to both the IE system and the target system has been switched OFF.

### 3.1 Connection

#### (1) Connection with IE-78K0S-NS or IE-78K0S-NS-A main unit

See the **IE-78K0S-NS User's Manual (U13549E)** for a description of how to connect the IE-789177-NS-EM1 to the IE-78K0S-NS<sup>Note</sup>.

**Note** See the **IE-78K0S-NS-A User's Manual (U15207E)** when using the IE-78K0S-NS-A.

#### (2) Connection with emulation probe

See the **IE-78K0S-NS User's Manual (U13549E)** for a description of how to connect an emulation probe to the IE-789177-NS-EM1<sup>Note</sup>.


On this board, connect the emulation probe to CN1.

**Note** See the **IE-78K0S-NS-A User's Manual (U15207E)** when using the IE-78K0S-NS-A.

**Caution** Incorrect connection may damage the IE system.

**Be sure to read the emulation probe's user's manual for a detailed description of the connection method.**

**Figure 3-1. Connection of Emulation Probe**



## 3.2 Clock Settings

### 3.2.1 Overview of clock settings

The main system and subsystem clocks to be used during debugging can be selected from (1) to (3) below.

- (1) Clock that is already mounted on emulation board
- (2) Clock that is mounted by user
- (3) Pulse input from target system


★ If the target system includes a clock oscillator, select either “(1) Clock that is already mounted on emulation board” or “(2) Clock that is mounted by user”. For the clock oscillator, a resonator is connected to the target device and the target device’s internal oscillator is used. An example of the external circuit is shown in part (a) of Figure 3-2. During emulation, the oscillator that is mounted on the target system is not used. Instead, the clock that is mounted on the emulation board installed in the IE-78K0S-NS or IE-78K0S-NS-A is used.

If the target system includes an external clock, select “(3) Pulse input from target system”.

For the external clock, a clock signal is supplied from outside the target device and the target device’s internal oscillator is not used. An example of the external circuit is shown in part (b) of Figure 3-2.

**Caution** The IE system will be hung-up if the main system clock is not supplied normally. Moreover, be sure to input a rectangular wave as the clock from the target. There is no need to supply a clock to the X2 pin.

**Figure 3-2. External Circuits Used as System Clock Oscillator**




**(1) Clock that is already mounted on emulation board**

A crystal oscillator is already mounted on the emulation board. Its frequency is 5.0 MHz.

★

**Figure 3-3. When Using Clock That Is Already Mounted on Emulation Board**




**Remark** The clock that is supplied by the IE-789177-NS-EM1's oscillator (encircled in the figure) is used.

**(2) Clock that is mounted by user**

The user is able to mount any clock supported by the set specifications on the IE-789177-NS-EM1. Either attach the parts board on which the resonator to be used is mounted or an oscillator to the IE-789177-NS-EM1. This method is useful when using a different frequency from that of the premounted clock.

★

**Figure 3-4. When Using User-Mounted Clock**




**Remark** The clock that is supplied by the parts board on which the IE-789177-NS-EM1's resonator is mounted (encircled in the figure) or by the oscillator is used.

**(3) Pulse input from target system**

An external clock connected to the target system can be used via an emulation probe.

★ **Figure 3-5. When Using an External Clock**



**Remark** The clock supplied by the target system’s external clock (encircled in the figure) is used.

**3.2.2 Main system clock settings**

**Table 3-1. Main System Clock Settings**

Frequency of Main System Clock		IE-789177-NS-EM1	
		Parts Board (X1 UMCLK)	CPU Clock Source Selection (ID)
When using clock that is already mounted on emulation board	5.0 MHz	Oscillator used	Internal
When using clock mounted by user	Other than 5.0 MHz	Oscillator assembled by user	
When inputting pulse from target system			Oscillator not used

**Caution** When inputting pulse from the target system, open the configuration dialog box when starting the integrated debugger (ID78K0S-NS) and select “External” in the area (Clock) for selecting the CPU’s clock source (this selects the user’s clock).

**Remark** The IE-789177-NS-EM1’s factory settings are those listed above under “when using clock that is already mounted on emulation board”.

**(1) When using clock that is already mounted on emulation board**

When the IE-789177-NS-EM1 is shipped, a 5.0 MHz crystal oscillator is already mounted in the IE-789177-NS-EM1’s X1 UMCLK socket. When using the factory-set mode settings, there is no need to make any other hardware settings.

When starting the integrated debugger (ID78K0S-NS), open the configuration dialog box and select “Internal” in the area (Clock) for selecting the CPU’s clock source (this selects the emulator’s internal clock).



**(2) When using clock mounted by user**

The settings described under either (a) or (b) are required, depending on the type of clock to be used. When starting the integrated debugger (ID78K0S-NS), open the configuration dialog box and select "Internal" in the area (Clock) for selecting the CPU's clock source (this selects the emulator's internal clock).

**(a) When using a ceramic resonator or crystal resonator**


- Items to be prepared
  - Parts board
  - Ceramic resonator or crystal resonator
  - Resistor Rx
- Capacitor CA
- Capacitor CB
- Solder kit

<Steps>

- <1> Solder the target ceramic resonator or crystal resonator, resistor Rx, capacitor CA, and capacitor CB (all with suitable oscillation frequency) onto the parts board (as shown below).


**Figure 3-6. Connections on Parts Board (When Using Main System Clock or User-Mounted Clock)**

Parts board (X1 UMCLK)



Pin No.	Connection
2-13	Capacitor CA
3-12	Capacitor CB
4-11	Ceramic resonator or crystal resonator
5-10	Resistor Rx
8-9	Short


Circuit diagram



**Remark** The sections enclosed in broken lines indicate parts that are attached to the parts board.

- <2> Prepare the IE-789177-NS-EM1.
- <3> Remove the crystal oscillator that is mounted in the IE-789177-NS-EM1's socket (X1 UMCLK).
- <4> Connect the prepared parts board to the socket (X1 UMCLK) from which the crystal oscillator was removed. Check the pin 1 mark to make sure the board is mounted in the correct direction.
- <5> Make sure that the parts board mounted in the socket (X1 UMCLK) on the emulation board is wired as shown in Figure 3-6 above.
- <6> Install the IE-789177-NS-EM1 in the IE-78K0S-NS or IE-78K0S-NS-A.

The above steps configure the following circuit and enable supply of the clock from the mounted resonator to the emulation device.




**Remark** The sections enclosed in broken lines indicate parts that are attached to the parts board.

**(b) When using a crystal oscillator**

- Items to be prepared
  - Crystal oscillator (see pinouts shown in Figure 3-7)


**Figure 3-7. Crystal Oscillator (When Using Main System Clock or User-Mounted Clock)**



<Steps>


- <1> Prepare the IE-789177-NS-EM1.
- <2> Remove the crystal oscillator that is mounted in the IE-789177-NS-EM1's socket (X1 UMCLK).
- <3> Connect the prepared crystal oscillator to the socket (X1 UMCLK) from which the crystal oscillator was removed. Insert the crystal oscillator pin into the socket aligning the pins as shown in the figure below.

**Figure 3-8. Pin Alignment of Crystal Oscillator and Socket**



- <4> Install the IE-789177-NS-EM1 in the IE-78K0S-NS or IE-78K0S-NS-A.

The above steps configure the following circuit and enable supply of the clock from the mounted resonator to the emulation device.



**(3) When inputting pulse from target system**

No hardware settings are required for this situation.

When starting the integrated debugger (ID78K0S-NS), open the configuration dialog box and select “External” in the area (Clock) for selecting the CPU’s clock source (this selects the user’s clock).

## 3.2.3 Subsystem clock settings

Table 3-2. Subsystem Clock Settings

Frequency of Subsystem Clock		IE-789177-NS-EM1	
		Parts board (XT1 USCLK)	JP1
When using clock that is already mounted on emulation board	32.768 kHz	6 and 8 shorted	Short 2 and 3
When using clock mounted by user	Other than 32.768 kHz	Oscillator assembled by user	
When inputting pulse from target system		Not used	Short 1 and 2

**Caution** Jumper JP1, which is used to select the board's clock or an external clock, should be set only after turning off the power of IE-78K0S-NS or IE-78K0S-NS-A.

**Remark** When the IE-789177-NS-EM1 is shipped, the settings for "when using clock that is already mounted on emulation board" are preset.

**(1) When using clock that is already mounted on emulation board**

When the IE-789177-NS-EM1 is shipped, a 32.768 kHz crystal resonator (XTC1) and a parts board (XT1 USCLK) on which pins 6 and 8 are shorted are already mounted on the IE-789177-NS-EM1. Short pins 2 and 3 on the IE-789177-NS-EM1's jumper (JP1). There is no need to make any other settings via the integrated debugger (ID78K0S-NS).

**(2) When using the clock mounted by user**

The settings described under either (a) or (b) are required, depending on the type of clock to be used. Short pins 2 and 3 on the IE-789177-NS-EM1's jumper (JP1).

There is no need to make any other settings via the integrated debugger (ID78K0S-NS).

**(a) When using a ceramic resonator or crystal resonator**


- Items to be prepared
  - Parts board
  - Ceramic resonator or crystal resonator
  - Resistor Rx
  - Capacitor CA
  - Capacitor CB
  - Solder kit

## &lt;Steps&gt;

- <1> Solder the target ceramic resonator or crystal resonator, resistor Rx, capacitor CA, and capacitor CB (all with suitable oscillation frequency) onto the parts board (as shown in the following diagram).


Figure 3-9. Connections on Parts Board (When Using Subsystem Clock or User-Mounted Clock)

Parts board (XT1 USCLK)



Pin No.	Connection
2-13	Capacitor CA
3-12	Capacitor CB
4-11	Ceramic resonator or crystal resonator
5-10	Resistor Rx
8-9	Short


Circuit diagram



**Remark** The sections enclosed in broken lines indicate parts that are attached to the parts board.

- <2> Prepare the IE-789177-NS-EM1.
- <3> Remove the parts board that is mounted in the IE-789177-NS-EM1's socket (XT1 USCLK).
- <4> Connect the prepared parts board to the socket (XT1 USCLK) from which the parts board was removed.  
Check the pin 1 mark to make sure the board is mounted in the correct direction.
- <5> Install the IE-789177-NS-EM1 in the IE-78K0S-NS or IE-78K0S-NS-A.

The above steps configure the following circuit and enable supply of the clock from the mounted resonator to the emulation device.




**Remark** The section enclosed in broken lines indicates parts that are attached to the parts board.

**(b) When using a crystal oscillator**

- Items to be prepared
  - Crystal oscillator (see pinouts shown in Figure 3-10)


**Figure 3-10. Crystal Oscillator (When Using Subsystem Clock or User-Mounted Clock)**



<Steps>

- <1> Prepare the IE-789177-NS-EM1.
- <2> Remove the parts board that is mounted in the IE-789177-NS-EM1's socket (XT1 USCLK).
- <3> Connect the prepared crystal oscillator to the socket (XT1 USCLK) from which the parts board was removed. Insert the crystal oscillator into the socket aligning the pins as shown below.


**Figure 3-11. Pin Alignment of Crystal Oscillator and Socket**



- <4> Install the IE-789177-NS-EM1 in the IE-78K0S-NS or IE-78K0S-NS-A.



The above steps configure the following circuit and enable supply of the clock from the mounted oscillator to the emulation device.



**(3) When inputting pulse from target system**

Short pins 1 and 2 on the IE-789177-NS-EM1's jumper (JP1). There is no need to make any settings via the integrated debugger (ID78K0S-NS).

### 3.3 Mask Option Settings


By setting the DIP switch (SW1) in the IE-789177-NS-EM1, a 33 kΩ pull-up resistor can be connected to P50 to P53 by a mask option.

**Table 3-3. SW1 Switch Setting**

	SW1			
	1	2	3	4
Destination pin	P50	P51	P52	P53

When the DIP switch is ON, the corresponding pin is pulled-up by the target V<sub>DD</sub> pin. When it is OFF, the corresponding pull-up resistor is disconnected. Set the DIP switch to OFF for ports that do not exist.

**Figure 3-12. Mask Option Setting**



### ★ 3.4 Power Supply Voltage Setting of Target Interface


In the IE system, emulation is possible with a voltage of the same level as the power supply voltage of the target system.

When the target system is not connected, the IE system automatically operates with the emulator's internal power supply (5 V). When debugging with a voltage that is the same level as that of the target system, supply the same voltage as that of the target system to the TP1 terminal pin of the IE-789177-NS-EM1 (the same applies when the voltage is 5 V). Set the target voltage to between 1.8 and 5.0 V.

Maximum current consumption of TP1

1.8 to 5.0 V: Approximately 100 mA

**Figure 3-13. Connection of TP1 and Power Supply Voltage of Target System**



**Caution** Connect TP1 on the board and the power supply voltage of the target system after turning off the power of the IE-78K0S-NS or IE-78K0S-NS-A.

**Remark** The V<sub>DD</sub> pin of the target system is only used for controlling LED1 (TV<sub>CC</sub>), which monitors whether the power supply of the target system is connected in IE-789177-NS-EM1.

### 3.5 External Trigger

To set up an external trigger, connect it to the IE-789177-NS-EM1's check pins EXTOUT and EXTIN as shown below.

For the pin characteristics, see the **IE-78K0S-NS User's Manual (U13549E)** or **IE-78K0S-NS-A User's Manual (U15207E)**. For the use methods, see the **ID78K0-NS, ID78K0S-NS Integrated Debugger Ver. 2.20 or Later Operation (Windows Based) User's Manual (U14910E)**.

#### (1) EXTOUT


Output a low level from the EXTOUT pin on the IE-789177-NS-EM1 for 1.3  $\mu$ s upon the occurrence of a break event.

**Caution** Connect a pull-up resistor on the target system since this is an open-drain output.

#### (2) EXTIN

An event signal can be input from the EXTIN pin on the IE-789177-NS-EM1. Input a high-level pulse signal for 2 CPU operation clocks or more.

**Figure 3-14. External Trigger Input Position**



### 3.6 Switch and Jumper Settings

**(1) Switch and jumper settings on the IE-78K0S-NS**

When using the IE-789177-NS-EM1, set the switches and jumpers on the IE-78K0S-NS as shown in Table 3-4. For details of these switch and jumper settings, refer to the **IE-78K0S-NS User's Manual (U13549E)**.

**Table 3-4. Switch and Jumper Settings on IE-78K0S-NS**

	SW1	SW3	SW4	JP1	JP4
Setting	OFF	All switches ON	All switches ON	2 and 3 shorted	1 and 2 shorted

**Caution** Incorrect settings may damage the IE-789177-NS-EM1.

★ **(2) Switch and jumper settings on the IE-78K0S-NS-A**

When using the IE-789177-NS-EM1, set the switches and jumpers on the IE-78K0S-NS-A as shown in Table 3-5. For details of these switch and jumper settings, refer to the **IE-78K0S-NS-A User's Manual (U15207E)**.

**Table 3-5. Switch and Jumper Settings on IE-78K0S-NS-A**

	SW1	JP1	JP3
Setting	OFF	1 and 2 shorted	Shorted

**Caution** Incorrect settings may damage the IE-78K0S-NS-A.

**(3) Initial settings of switch and jumper on the IE-789177-NS-EM1**

The initial settings of switch and jumper on the IE-789177-NS-EM1 are shown in Table 3-6.

**Table 3-6. Initialize Settings of Switch and Jumper on IE-789177-NS-EM1**

	SW1	JP1
Setting	All switches OFF	2 and 3 shorted

For details, refer to **3.2 Clock Settings** or **3.3 Mask Option Settings**.

## CHAPTER 4 DIFFERENCES BETWEEN TARGET DEVICES AND TARGET INTERFACE CIRCUITS

This chapter describes the differences between the target device's signal lines and the signal lines of the IE-789177-NS-EM1's target interface circuit.

Although the target device is a CMOS circuit, the IE-789177-NS-EM1's target interface circuit consists of emulators such as an emulation CPU, TTL, and CMOS-IC.

When the IE system is connected with the target system for debugging, the IE system performs emulation so as to operate as the actual target device would operate in the target system.

However, some minor differences exist since the operations are performed via the IE system's emulation.

- (1) Signals directly input/output to/from the evaluation chip and peripheral evaluation chip
- (2) Signals input from the target system via a gate
- (3) Analog signals
- (4) Other signals

The IE system's circuit is used as follows for signals listed in (1) to (4) above.

### (1) Signals directly input/output to/from the evaluation chip and peripheral evaluation chip

The following signals perform the same operations as in the  $\mu$ PD789167, 789177 Subseries. However, a 1 M $\Omega$  pull-down resistor and 100  $\Omega$  resistor are inserted in series.

- Signals related to port 0
- Signals related to port 1
- Signals related to port 2
- Signals related to port 3
- Signals related to port 5

### (2) Signals input from the target system via a gate

Since the following signals are input via a gate, their timing shows a delay compared to the  $\mu$ PD789167, 789177 Subseries.

- $\overline{\text{RESET}}$  signal
- X1, XT1 signals

**(3) Analog signals**

Because the following signals input/output analog-related signals, special processing is not performed in the IE-789177-NS-EM1.

- AV<sub>DD</sub> pin
- AV<sub>REF</sub> pin
- Signals related to port 6

**(4) Other signals**

- V<sub>DD</sub>, V<sub>DD1</sub> pins

When the target system is not connected, the internal power supply voltage (5 V) of the IE-789177-NS-EM1 is supplied to the emulation CPU. When the target system is connected, power is supplied from the voltage supply pin (TP1). The V<sub>DD0</sub>, V<sub>DD1</sub> pins of the target system are only used to control the LED1 in the IE-789177-NS-EM1 that monitors the input of the target system's power supply (TV<sub>CC</sub>).

- V<sub>SS0</sub>, V<sub>SS1</sub>, AV<sub>SS</sub> pins

The V<sub>SS0</sub>, V<sub>SS1</sub>, and AV<sub>SS</sub> pins are connected to GND in the IE-789177-NS-EM1.


- TEST/V<sub>PP</sub> pin

The TEST/V<sub>PP</sub> pin is not used in the IE-789177-NS-EM1.

- X2, XT2 pins

The X2, XT2 pins are not used in the IE-789177-NS-EM1.

Figure 4-1. Equivalent Circuit 1 of Emulator







## APPENDIX A. EMULATION PROBE PIN ASSIGNMENT TABLE

**Table A-1. NP-44GB, NP-44GB-TQ, NP-H44GB-TQ Pin Assignments**

Emulation Probe	CN1 Pin No.	Emulation Probe	CN1 Pin No.
1	104	23	18
2	103	24	17
3	100	25	22
4	99	26	21
5	94	27	28
6	93	28	27
7	30	29	92
8	29	30	91
9	24	31	98
10	23	32	97
11	20	33	102
12	47	34	73
13	48	35	72
14	51	36	69
15	52	37	70
16	57	38	63
17	58	39	64
18	59	40	61
19	60	41	62
20	55	42	65
21	56	43	66
22	49	44	71

- Remarks**
1. NP-44GB, NP-44GB-TQ, and NP-H44GB-TQ are products of Naito Densai Machida Mfg. Co., Ltd.
  2. The numbers in the “Emulation probe” column indicate the corresponding pin number on the emulation probe tip.

**Table A-2. NP-48GA Pin Assignments**


Emulation Probe	CN1 Pin No.	Emulation Probe	CN1 Pin No.
1	104	25	18
2	103	26	17
3	100	27	22
4	99	28	21
5	94	29	28
6	93	30	27
7	30	31	101
8	29	32	92
9	24	33	91
10	23	34	98
11	20	35	97
12	19	36	102
13	47	37	73
14	48	38	72
15	51	39	69
16	52	40	70
17	57	41	63
18	58	42	64
19	50	43	61
20	59	44	74
21	60	45	62
22	55	46	65
23	56	47	66
24	49	48	71

- Remarks**
1. NP-48GA is a product of Naito Densetsu Machida Mfg. Co., Ltd.
  2. The numbers in the “Emulation probe” column indicate the corresponding pin number on the emulation probe tip.

## APPENDIX B. CAUTIONS ON DESIGNING TARGET SYSTEM

The following shows the conditions when connecting the emulation probe to the conversion connector or conversion socket. Follow the configuration below and consider the shape of parts to be mounted on the target system when designing a system.


**Figure B-1. Distance Between In-Circuit Emulator and Conversion Socket (NP-44GB, NP-44GB-TQ)**



**Note** Distance when NP-44GB and NP-44GB-TQ are used. When NP-H44GB-TQ is used, the distance is 370 mm.


**Remarks** 1. NP-44GB, NP-44GB-TQ, and NP-H44GB-TQ are products of Naito Densai Machida Mfg. Co., Ltd.  
2. TGB-044SAP is a product of TOKYO ELETECH CORPORATION.

Figure B-2. Connection Condition of Target System (NP-H44GB-TQ)




- Remarks**
1. NP-H44GB-TQ are products of Naito Densetsu Machida Mfg. Co., Ltd.
  2. TGB-044SAP is a product of TOKYO ELETECH CORPORATION.

**Figure B-3. Distance Between In-Circuit Emulator and Conversion Socket (NP-48GA)**



- Remarks**
1. NP-48GA is a product of Naito Densai Machida Mfg. Co., Ltd.
  2. TGA-048SDP is a product of TOKYO ELETECH CORPORATION.

Figure B-4. Connection Condition of Target System (NP-48GA)



- Remarks**
1. NP-48GA is a product of Naito Densai Machida Mfg. Co., Ltd.
  2. TGA-048SDP is a product of TOKYO ELETECH CORPORATION.

[MEMO]



## Facsimile Message

Although NEC has taken all possible steps to ensure that the documentation supplied to our customers is complete, bug free and up-to-date, we readily accept that errors may occur. Despite all the care and precautions we've taken, you may encounter problems in the documentation. Please complete this form whenever you'd like to report errors or suggest improvements to us.

From:

Name

Company

Tel.

FAX

Address

*Thank you for your kind support.*

<b>North America</b> NEC Electronics Inc. Corporate Communications Dept. Fax: +1-800-729-9288 +1-408-588-6130	<b>Hong Kong, Philippines, Oceania</b> NEC Electronics Hong Kong Ltd. Fax: +852-2886-9022/9044	<b>Taiwan</b> NEC Electronics Taiwan Ltd. Fax: +886-2-2719-5951
<b>Europe</b> NEC Electronics (Europe) GmbH Market Communication Dept. Fax: +49-211-6503-274	<b>Korea</b> NEC Electronics Hong Kong Ltd. Seoul Branch Fax: +82-2-528-4411	<b>Asian Nations except Philippines</b> NEC Electronics Singapore Pte. Ltd. Fax: +65-250-3583
<b>South America</b> NEC do Brasil S.A. Fax: +55-11-6462-6829	<b>P.R. China</b> NEC Electronics Shanghai, Ltd. Fax: +86-21-6841-1137	<b>Japan</b> NEC Semiconductor Technical Hotline Fax: +81- 44-435-9608

I would like to report the following error/make the following suggestion:

Document title: \_\_\_\_\_

Document number: \_\_\_\_\_ Page number: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

If possible, please fax the referenced page or drawing.

Document Rating	Excellent	Good	Acceptable	Poor
Clarity	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Technical Accuracy	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>