

## POWER MANAGEMENT CONTROLLER

### Features

- Enables use of smaller power supplies for up to 48-port PoE systems with Si3452 PSE interface ICs
- Can operate with or without a host
- Configuration save
- Pin-selectable SPI or UART interface
- Pin-selectable UART data rate
- Fully-compliant with IEEE 802.3 clause 33 for PoE including the 802.3at amendment for higher power (30 W, category 2 ports)
- Supports classification-based and LLDP power negotiation
- Supports individual port priority and port configuration
- Supports Power supply status from up to 3 power supplies
- 24 pin Quad flat pack package (4x4 mm)
  - 4x4 mm PCB footprint; RoHS complaint
- Extended operation range (-40 to +85 °C)

### Applications

- Power over Ethernet Endpoint switches and Midspans for IEEE Std 802.3af and 802.3at
- Supports high-power PDs, such as:
  - Pan/Tilt/Zoom security cameras
  - 802.11n WAPs
  - Multi-band, multi-radio WAPs
- Security and RFID systems
- Industrial automation systems
- Networked audio
- IP Phone Systems and iPBXs
- Metropolitan area networked WAPs, cameras, and sensors
- WiMAX, ASN/BTS, and CPE/ODU systems

### Description


The Si3452 is capable of delivering over 30 W per port, which means that, in a 24- or 48-port system, a very large power supply would have to be used to avoid overload. Typically, not all ports are used at full power; so, a smaller power supply in the range of 5 W per port can be used along with the Si3482 power management controller.

The Si3482 is a power manager intended for use with the Si3452/3 Power over Ethernet (PoE) controllers for power management of up to 48 ports with three power sources.


Use of the Si3482 power manager greatly simplifies system implementation of power management. The Si3482 power management controller is programmed via a SPI or UART interface to set the power supply capacity, the port power configuration (Category 1: 15.4 W, or high-power category 2: 30 W) ports, the port priority, the detection timing (Alternative A or Alternative B), and the fault recovery protocol. Once programmed, the configuration data can be saved, and the Si3482 can work without host intervention. If desired, port and overall status information is available and continuously updated.

The Si3482 uses the real-time overload and current monitoring capability of the Si3452 to manage provided power among up to 48 ports. Power management is selectable between grant-based or consumption-based in order to supply power to the greatest number of ports.

In high-reliability systems, multiple power supplies are often connected to provide redundancy, which further increases the power supply requirements. The Si3482 can manage up to three power supplies automatically enabling or disabling ports in priority order when required.



## Functional Block Diagram



---

**TABLE OF CONTENTS**


---

| <b><u>Section</u></b>                       | <b><u>Page</u></b> |
|---|--------------------|
| <b>1. Electrical Specifications</b> .....   | <b>4</b>           |
| <b>2. Functional Description</b> .....      | <b>6</b>           |
| 2.1. Host Interface .....                   | 7                  |
| 2.2. Hardware Only Mode .....               | 7                  |
| <b>3. Serial Packet Protocol</b> .....      | <b>9</b>           |
| 3.1. Packet Format .....                    | 10                 |
| 3.2. SPP Error Handling .....               | 15                 |
| <b>4. Power Manager API</b> .....           | <b>16</b>          |
| 4.1. Management .....                       | 16                 |
| 4.2. System Status .....                    | 17                 |
| 4.3. Port Status .....                      | 18                 |
| 4.4. System Control .....                   | 22                 |
| 4.5. Port Control .....                     | 22                 |
| 4.6. System Configuration .....             | 23                 |
| 4.7. Port Configuration .....               | 26                 |
| 4.8. Power Supply Status .....              | 28                 |
| 4.9. Events .....                           | 29                 |
| 4.10. Return Codes .....                    | 30                 |
| <b>5. Pin Descriptions</b> .....            | <b>31</b>          |
| <b>6. Package Outline: 24-Pin QFN</b> ..... | <b>33</b>          |
| <b>7. PCB Land Pattern</b> .....            | <b>34</b>          |
| <b>8. Solder/Paste Recommendation</b> ..... | <b>35</b>          |
| <b>9. Top Marking Diagram</b> .....         | <b>36</b>          |
| <b>10. Ordering Guide</b> .....             | <b>37</b>          |
| <b>Contact Information</b> .....            | <b>38</b>          |

## 1. Electrical Specifications

**Table 1. Recommended Operating Conditions**

| Description                 | Symbol   | Test Conditions     | Min | Typ | Max | Units |
|-----------------------------|----------|---------------------|-----|-----|-----|-------|
| Operating Temperature Range | $T_A$    | No airflow          | -40 | —   | 85  | °C    |
| $V_{DD}$ Supply Voltage     | $V_{DD}$ | All operating modes | 2.7 | —   | 3.6 | V     |

**Table 2. Absolute Maximum Ratings**

| Parameter                               | Conditions       | Min  | Typ | Max | Units |
|---|------------------|------|-----|-----|-------|
| Ambient Temperature under Bias          |                  | -55  | —   | 125 | °C    |
| Storage Temperature                     |                  | -65  | —   | 150 | °C    |
| Voltage on any I/O with Respect to GND  | $V_{DD} > 2.2$ V | -0.3 | —   | 5.8 | V     |
| Voltage on $V_{DD}$ with Respect to GND |                  | -0.3 | —   | 4.2 | V     |

**Note:** Stresses above those listed under “Absolute Maximum Ratings” may cause permanent damage to the device. This is a stress rating only and functional operation of the devices at those or any other conditions above those indicated in the operation listings of this specification is not implied. Exposure to maximum rating conditions for extended periods may affect device reliability.

**Table 3. Electrical Characteristics**

| Description                            | Symbol   | Test Conditions  | Min | Typ | Max            | Units |
|--|----------|--|-----|-----|----------------|-------|
| Input High                             | $V_{IH}$ | Input pins:<br>RST, SCK, MOSI, NSS,<br>RX, PSn, BAUDn,<br>SLCTIN, SCL, SDA | 2.0 | —   | —              | V     |
| Input Low                              | $V_{IL}$ |  | —   | —   | 0.8            | V     |
| Input Leakage Current                  | $I_{IL}$ |  | —   | —   | ±1             | uA    |
| Output Low<br>(MOSI, TX, SCL, and SDA) | $V_{OL}$ | $I_{OL} = 8.5$ mA  | —   | —   | 0.6            | V     |
| Output High<br>(MOSI, TX)              | $V_{OH}$ | $I_{OH} = -3$ mA   | —   | —   | $V_{DD} - 0.7$ | V     |
| $V_{DD}$ Current                       | $I_{DD}$ | $V_{DD} = 3.0$ V*<br>$V_{DD} = 3.6$ V*                                     | —   | —   | 8.6<br>12.1    | mA    |

**\*Note:**  $V_{DD} = 2.7$  to  $3.6$  V,  $-40$  to  $85$  °C unless otherwise noted.

Table 4. Timing Requirements

| Description                                   | Test Conditions   | Min | Max | Units |
|---|---|-----|-----|-------|
| <b>SPI Timing Requirements (See Figure 1)</b> |   |     |     |       |
| $T_{SE}$                                      | NSS Falling to First SCK Edge                             | 84  | —   | ns    |
| $T_{SD}$                                      | Last SCK Edge to NSS Rising                               | 84  | —   | ns    |
| $T_{SEZ}$                                     | NSS Falling to MISO Valid                                 | —   | 168 | ns    |
| $T_{SDZ}$                                     | NSS Rising to MISO High Z                                 | —   | 168 | ns    |
| $T_{CKH}$                                     | SCK High Time   | 210 | —   | ns    |
| $T_{CKL}$                                     | SCK Low Time  | 210 | —   | ns    |
| $T_{SIS}$                                     | MOSI Valid to SCK Sample Edge                             | 84  | —   | ns    |
| $T_{SIH}$                                     | SCK Sample Edge to MOSI Change                            | 84  | —   | ns    |
| $T_{SCH}$                                     | SCK Shift Edge to MISO Change                             | —   | 168 | ns    |
| $F_{MAX}$                                     | Maximum SPI Clock Speed                                   | —   | 1   | MHz   |
| <b>UART Requirements (See Figure 2)</b>       |   |     |     |       |
| $\Delta FTx$                                  | Deviation of Tx Transmit Speed from Pin-programmed Value. | -3  | +3  | %     |
| $\Delta FRx$                                  | Deviation of Rx receive Speed from Pin-programmed Value.  | -4  | +4  | %     |




Figure 1. SPI Timing Diagram




Figure 2. UART Timing Diagram

## 2. Functional Description

The Si3482 Power Management Controller is the central controller in a Silicon Labs Power over Ethernet (PoE) system. In a PoE system, power is provided by one or more power supplies and is consumed by one or more powered devices (PDs). The Si3482 decides which of the PDs can have power and monitors the amount of power consumed by each.

A host microcontroller unit (MCU) can configure the Si3482 and can query the status of the PDs and the power supplies. The Si3482 stores its configuration in internal flash memory. A host MCU uses a Universal Asynchronous Receiver Transmitter (UART) or a Serial Peripheral Interface (SPI) to communicate with the Si3482. Pins on the Si3482 select which host interface to use and which baud rate to use for the UART interface.

Power supplies may be inserted into bays. The Si3482 supports a system with up to three bays. Power supplies may be inserted or removed from the bays at any time. Each bay provides a signal to the Si3482 that indicates if a power supply is present in the bay. The outputs of the power supplies are ganged together to provide a single power source for the system.

The Si3482 manages a collection of Si3452 Port Controllers. The Si3482 supports a system with up to 12 Si3452s. Each Si3452 has four ports; so, a system may have up to 48 ports. The Si3452 performs low-level port functions, such as detecting and classifying PDs. The Si3482 has a global view of the system and manages power across all ports.

PDs are connected to ports on the Si3452s. PDs may be connected or disconnected from the ports at any time. When a PD is connected to a port, then the PD requests power from the port. The Si3482 determines the amount of power requested from the classification of the PD. If there is enough power remaining, the Si3482 grants the request; otherwise, the Si3482 denies the request.

The host may configure an optional power limit for each port. A power limit restricts the amount of power that the Si3482 grants to a port. If a power request is greater than the power limit, the Si3482 does not fully grant the request, but only grants the amount of the power limit.

The Si3482 supports Link Layer Discovery Protocol (LLDP) agents in the host. An LLDP agent can call a routine in the Si3482 to dynamically adjust the amount of power granted to a PD during the course of a connection.

Several PDs may be connected to a PoE system. The Si3482 may have granted different amounts of power to each PD, and each PD may be consuming different amounts of power. If a PD consumes more power than it is granted (port overload), the Si3482 turns off the PD.

There are two approaches that the Si3482 can take when granting requests for power. The granting policy can be grant-based or it can be consumption-based.






Figure 3. Powered Devices Example



**Figure 4. Grant Based Power Management**



**Figure 5. Consumption-Based Power Management**

If the granting policy is grant based, then the power remaining for new grants is the total ungranted power. The power remaining is the total power provided minus the total power granted.

The problem with this approach is that much of the provided power is unused because PDs often do not consume all of their granted power.

If the granting policy is consumption-based, then the power remaining for new grants is the total unconsumed power. The power remaining is the total power provided minus the total power consumed (excluding the reserved power). This approach uses more of the provided power, but there is a possibility that the system may consume more power than the power provided (system overload).

To avoid system overloads caused by momentary surges in power consumption, the host can specify that a certain amount of power be held in reserve. The Si3482 does not use the reserved power when granting new requests.

Most power supplies can tolerate a limited amount of overload for a short duration. The host specifies the overload limit of the power supplies to the Si3482. If a system overload is less than the overload limit, the Si3482 turns off ports, one at a time in priority order, until the system is no longer overloaded. If a system overload is greater than the overload limit (severe overload), the Si3482 immediately turns off all low-priority ports. If the system is still overloaded, the Si3482 turns off additional ports, one at a time in priority order, until the system is no longer overloaded. A severe overload is usually caused by removing a power supply.

## 2.1. Host Interface

The Si3482 has a UART interface and an SPI interface for communicating with the host MCU, but only one interface is used at a time. The PSLCT (protocol select) pin selects which interface is used.

### 2.1.1. UART Interface

If the PSLCT pin is tied high, then the Si3482 uses the UART interface to communicate with the host MCU. The Si3482 uses the TX and RX pins to send and receive serial data. The BAUD0, BAUD1, and BAUD2 pins select the baud rate for the UART interface.

**Table 5. Baud Rates**

| BAUD2 | BAUD1 | BAUD0 | Baud Rate (bps) |
|-------|-------|-------|-----------------|
| H     | L     | L     | 19200           |
| H     | L     | H     | 38400           |
| H     | H     | L     | 57600           |
| H     | H     | H     | 115200          |

The UART interface uses eight data bits, no parity, and one stop bit.

### 2.1.2. SPI Interface

If the PSLCT pin is tied low, then the Si3482 uses the SPI interface to communicate with the host MCU. The Si3482 is an SPI slave device. Therefore, it receives data on the MOSI pin and sends data on the MISO pin. The host MCU drives the NSS and SCK pins.

The SPI interface uses an active-high clock (CKPOL = 0). The clock line is low in the idle state, and the leading edge of the clock goes from low to high. The SPI interface samples the data on the leading edge of the clock (CKPHA = 0). The SPI interface transfers the most-significant bit first, and the maximum bit rate is 1 Mbps

## 2.2. Hardware Only Mode

The host interface (SPI or UART) and the UART baud rate are pin-configured. The Si3482 reads the pin configuration at power up, and it cannot be changed after power up. The hardware designer only needs to decide which interface to use and, if UART is selected, which BAUD rate to use.

In general, the host interface must be electrically isolated from the host MCU using an appropriate electrical isolator for either SPI or UART signals as well as power supply status signals as needed.

The Si3482 backs up its configuration to internal flash memory. Once the Si3482 is configured, it is possible to disconnect the host interface and use the Si3482 without a host MCU.

To configure the Si3482 when a host MCU is not required or for initial system debug, the USB adapter and Power Manager GUI supplied with the Si3482 evaluation system, "SMARTPSE24-KIT", can be adapted to set the device configuration as desired.



### 3. Serial Packet Protocol

The Si3482 contains the Power Manager component and the interface to the Power Manager is a collection of routines known as the Power Manager application programming interface (API).

The Power Manager API is described later in this manual. The host MCU contains a User Interface component, which calls the routines in the Power Manager API to get status information and configure and control the Power Manager.

The Serial packet protocol (SPP) is a remote procedure call (RPC) mechanism that allows a User Interface component to call routines in the Power Manager, even though the User Interface component and the Power Manager are on different MCUs. The Serial Packet Protocol is implemented by a Serial Packet Client in the host MCU and the Serial Packet Server in the Si3482.

A Serial Packet Client is a collection of stub routines with the same names and parameters as the routines in the Power Manager API. A User Interface component calls a stub routine, and the stub routine uses the host interface to send a packet to the Serial Packet Server. The Serial Packet Client receives a packet back and then returns to the User Interface component.

The Serial Packet Server receives a packet from a Serial Packet Client and then calls the specified routine in the Power Manager. When the Power Manager routine returns, the Serial Packet Server sends a packet back to the Serial Packet Client.

Silicon Labs provides a Serial Packet Client Software Development Kit (SDK) that implements SPP and is portable to any MCU. The customer only needs to write some small support routines, which map SDK routines to RTOS routines.





Figure 6. Serial Packet Protocol

## 3.1. Packet Format

A packet is a sequence of fields sent together as a unit. Figure 7 shows the SPP packet format.



**Figure 7. Packet Format**


Each field is a single byte except for the Data field. The Data field may be from zero to 255 bytes.

### 3.1.1. Start Field

The Start field marks the beginning of a packet and always contains the Start-of-Packet (SOP) character (0xAC). If data is lost on the host interface, the Serial Packet Server and the Serial Packet Client use the Start field to resynchronize. A “receive packet” routine starts by receiving and discarding bytes until the SOP character is found.

### 3.1.2. Checksum Field

The Checksum field is used to verify that the packet was not corrupted during transmission. The sender of a packet calculates the checksum and writes it into the Checksum field. The receiver of a packet verifies that the checksum is correct. The Checksum field should contain the value such that all the bytes in the packet, except for the Start field, add up to zero.



**Figure 8. Packet Checksum**

To calculate the checksum, the sender uses an 8-bit variable to sum up the bytes of the Routine field through the end of the Data field. The sender adds one to the one's complement of this sum and stores the result in the Checksum field.

$$\text{Checksum} = (\sim\text{Sum}) + 1$$

To verify the checksum, the receiver uses an 8-bit variable to sum up the bytes of the Routine field through the Checksum field. The sum should be zero.

### 3.1.3. Routine Field

The Routine field identifies a routine in the Power Manager API.

The client uses the Routine field to specify which routine to call. The client should verify that the Routine field in a received packet matches the Routine field in the sent packet.

**Table 6. Routine Field**

| Routine                 | Symbol                    | Value |
|-------------------------|---------------------------|-------|
| GetSystemStatus()       | RTN_GETSYSTEMSTATUS       | 1     |
| GetSystemInfo()         | RTN_GETSYSTEMINFO         | 2     |
| GetTotalPowerConsumed() | RTN_GETTOTALPOWERCONSUMED | 3     |
| GetTotalPowerGranted()  | RTN_GETTOTALPOWERGRANTED  | 4     |
| GetTotalPowerProvided() | RTN_GETTOTALPOWERPROVIDED | 5     |
| GetPortCount()          | RTN_GETPORTCOUNT          | 6     |
| GetPortStatus()         | RTN_GETPORTSTATUS         | 7     |
| GetPortInfo()           | RTN_GETPORTINFO           | 8     |

Table 6. Routine Field (Continued)

| Routine                  | Symbol                     | Value |
|--------------------------|----------------------------|-------|
| GetPortPriorityStatus()  | RTN_GETPORTPRIORITYSTATUS  | 9     |
| GetPortPowerConsumed()   | RTN_GETPORTPOWERCONSUMED   | 10    |
| GetPortPowerGranted()    | RTN_GETPORTPOWERGRANTED    | 11    |
| GetPortPowerRequested()  | RTN_GETPORTPOWERREQUESTED  | 12    |
| GetPortPowerAvailable()  | RTN_GETPORTPOWERAVAILABLE  | 13    |
| ResetSystem()            | RTN_RESETSYSTEM            | 14    |
| RestoreFactoryDefaults() | RTN_RESTOREFACTORYDEFAULTS | 15    |
| SetPortControl()         | RTN_SETPORTCONTROL         | 16    |
| AdjustPortPower()        | RTN_ADJUSTPORTPOWER        | 17    |
| SetPowerProvided()       | RTN_SETPOWERPROVIDED       | 18    |
| GetPowerProvided()       | RTN_GETPOWERPROVIDED       | 19    |
| SetReservedPower()       | RTN_SETRESERVEDPOWER       | 20    |
| GetReservedPower()       | RTN_GETRESERVEDPOWER       | 21    |
| SetOverloadLimit()       | RTN_SETOVERLOADLIMIT       | 22    |
| GetOverloadLimit()       | RTN_GETOVERLOADLIMIT       | 23    |
| SetGrantingPolicy()      | RTN_SETGRANTINGPOLICY      | 24    |
| GetGrantingPolicy()      | RTN_GETGRANTINGPOLICY      | 25    |
| SetRetryPolicy()         | RTN_SETRETRYPOLICY         | 26    |
| GetRetryPolicy()         | RTN_GETRETRYPOLICY         | 27    |
| SetPowerLocation()       | RTN_SETPOWERLOCATION       | 28    |
| GetPowerLocation()       | RTN_GETPOWERLOCATION       | 29    |
| SetPortEnable()          | RTN_SETPORTENABLE          | 30    |
| GetPortEnable()          | RTN_GETPORTENABLE          | 31    |
| SetPortCapability()      | RTN_SETPORTCAPABILITY      | 32    |
| GetPortCapability()      | RTN_GETPORTCAPABILITY      | 33    |
| SetPortPriority()        | RTN_SETPORTPRIORITY        | 34    |
| GetPortPriority()        | RTN_GETPORTPRIORITY        | 35    |
| SetPortPowerLimit()      | RTN_SETPORTPOWERLIMIT      | 36    |
| GetPortPowerLimit()      | RTN_GETPORTPOWERLIMIT      | 37    |
| SetPowerSupplyStatus()   | RTN_SETPOWERSUPPLYSTATUS   | 38    |
| GetPowerSupplyStatus()   | RTN_GETPOWERSUPPLYSTATUS   | 39    |
| GetEvents()              | RTN_GETEVENTS              | 40    |

### 3.1.4. Data Length Field

The DataLength field specifies the number of bytes in the Data field. The number of bytes may be from zero to 255.

### 3.1.5. Data Field


The Data field is used to pass data to and from the Si3482. The Data field may contain four different types of data:

- Parameters
- System Information
- Port Information
- Events

The Data field has a different format for each type of data. In almost all packets (sent and received), the Data field has the Parameters format. The only exceptions are the packets that are received back after calling the GetSystemInfo(), GetPortInfo(), and GetEvents() routines. The Data fields for these packets are in the System Information format, Port Information format, and Events format.

#### 3.1.5.1. Parameters Format

The Parameters format of the Data field is used to pass parameters to Power Manager routines. In most cases, the Parameters format is also used to return data from the routines.



**Figure 9. Parameters Format**

The Parameters format has an 8-bit Parm8 field followed by a 32-bit Parm32 field (see Table 7). Depending on the routine being called, Parm8, Parm32, or both fields are used. Sometimes, neither field is used. However, both fields are always sent and received. The DataLength field contains five.

**Table 7. Use of Parameters**

| Routine                 | Parameters in Sent Packet |         | Parameters in Received Packet  |                |
|-------------------------|---------------------------|---------|--------------------------------|----------------|
|                         | Parm8                     | Parm32* | Parm8                          | Parm32*        |
| GetSystemStatus()       |                           |         | SystemStatus                   |                |
| GetSystemInfo()         |                           |         | Uses System Information Format |                |
| GetTotalPowerConsumed() |                           |         |                                | PowerConsumed  |
| GetTotalPowerGranted()  |                           |         |                                | PowerGranted   |
| GetTotalPowerProvided() |                           |         |                                | PowerProvided  |
| GetPortCount()          |                           |         | PortCount                      |                |
| GetPortStatus()         | Port                      |         | PortStatus                     |                |
| GetPortInfo()           | Port                      |         | Uses Port Information Format   |                |
| GetPortPriorityStatus() | Port                      |         | PortPriorityStatus             |                |
| GetPortPowerConsumed()  | Port                      |         |                                | PowerConsumed  |
| GetPortPowerGranted()   | Port                      |         |                                | PowerGranted   |
| GetPortPowerRequested() | Port                      |         |                                | PowerRequested |

**\*Note:** The Parm32 field is big endian; therefore, the most significant byte is first.


Table 7. Use of Parameters (Continued)

| Routine                  | Parameters in Sent Packet |               | Parameters in Received Packet |                |
|--------------------------|---------------------------|---------------|-------------------------------|----------------|
|                          | Parm8                     | Parm32*       | Parm8                         | Parm32*        |
| GetPortPowerAvailable()  | Port                      |               |                               | PowerAvailable |
| ResetSystem()            |                           |               | Result                        |                |
| RestoreFactoryDefaults() |                           |               |                               |                |
| SetPortControl()         | Port                      | Control       | Result                        |                |
| AdjustPortPower()        | Port                      | PortPower     | Result                        |                |
| SetPowerProvided()       | PowerSupply               | PowerProvided | Result                        |                |
| GetPowerProvided()       | PowerSupply               |               |                               | PowerProvided  |
| SetReservedPower()       | ReservedPower             |               | Result                        |                |
| GetReservedPower()       |                           |               | ReservedPower                 |                |
| SetOverloadLimit()       | OverloadLimit             |               | Result                        |                |
| GetOverloadLimit()       |                           |               | OverloadLimit                 |                |
| SetGrantingPolicy()      | GrantingPolicy            |               | Result                        |                |
| GetGrantingPolicy()      |                           |               | GrantingPolicy                |                |
| SetRetryPolicy()         | RetryPolicy               |               | Result                        |                |
| GetRetryPolicy()         |                           |               | RetryPolicy                   |                |
| SetPowerLocation()       | PowerLocation             |               | Result                        |                |
| GetPowerLocation()       |                           |               | PowerLocation                 |                |
| SetPortEnable()          | Port                      | Enable        | Result                        |                |
| GetPortEnable()          | Port                      |               | Enable                        |                |
| SetPortCapability()      | Port                      | Capability    | Result                        |                |
| GetPortCapability()      | Port                      |               | Capability                    |                |
| SetPortPriority()        | Port                      | Priority      | Result                        |                |
| GetPortPriority()        | Port                      |               | Priority                      |                |
| SetPortPowerLimit()      | Port                      | PowerLimit    | Result                        |                |
| GetPortPowerLimit()      | Port                      |               |                               | PowerLimit     |
| SetPowerSupplyStatus()   | PowerSupply               | Status        | Result                        |                |
| GetPowerSupplyStatus()   | PowerSupply               |               | Status                        |                |
| GetEvents()              |                           |               | Uses Events Format            |                |

\*Note: The Parm32 field is big endian; therefore, the most significant byte is first.

### 3.1.5.2. System Information Format

The System Information format of the Data field is used to return system information to the client. System information is returned after calling the GetSystemInfo() routine.




**Figure 10. System Information Format**

The System Information format has a PowerManagerVersion field followed by a PlatformSupportVersion field. Both of these fields are eight bytes long and contain a version string that is a zero-terminated ASCII string. A version string may be from one to seven characters long. The Routine field contains RTN\_GETSYSTEMINFO, and the DataLength field contains 16.

### 3.1.5.3. Port Information Format

The Port Information format of the Data field is used to return port information to the client. Port information is returned after calling the GetPortInfo() routine.



**Figure 11. Port Information Format**

In C, the Port Information format is:

```
typedef struct
{
    INT8    Result;
    UINT8   Detection;
    UINT8   Classification;
    UINT16  Current;
    UINT16  PowerSupplyVoltage;
    char    SiliconVersion[2];
    char    FirmwareVersion[8];
} DATA_PORTINFO;
```


The Port Information format is a sequence of fields as shown above. For more information, read the description of the `GetPortInfo()` routine in the Power Manager API Section. The Routine field contains `RTN_GETPORTINFO`, and the `DataLength` field contains 17.

The Result field contains the return code from the `GetPortInfo()` routine, and, if Result is not `SUCCESS (0)`, the remaining fields should be ignored.

The Current and `PowerSupplyVoltage` fields are big endian. Therefore, the most significant byte comes first.

#### 3.1.5.4. Events Format

The Events format of the Data field is used to return events to the client. Events are returned after calling the `GetEvents()` routine.



**Figure 12. Events Format**

In the Si3482, the Serial Packet Server internally receives events from the Power Manager and stores them in a circular event queue. If the event queue becomes full, newer events overwrite older events.

If a client wishes to receive events, it should periodically get the events from the Serial Packet Server. The client gets the events by sending a packet with the Routine field set to `RTN_GETEVENTS`. The Serial Packet Server returns all the events from the event queue in a single packet with the Data field in the Events format.

The Data field does not have a fixed length. The length of the Data field depends on the number of events that are returned. An event is three bytes long; so, the number of events in the Data field is `DataLength` divided by three. If there are no events to return, then `DataLength` is zero, and the Data field is empty. The maximum number of events that can be returned is 85.

## 3.2. SPP Error Handling

There are many reasons why a client may not receive back a packet. Perhaps the Si3482 is not running or perhaps the serial data was corrupted or lost during transmission (in either direction). In any case, it is not prudent for a Serial Packet Client to call a serial receive routine that blocks forever until data is received. If the serial receive routine does not have a timeout option, the client should not call the receive routine unless it knows that received data is available. If a client does not receive a packet within one second of sending a packet, then the client should assume that there has been a communications error. The client should resend the original packet or simply give up (but do not wait forever to receive a packet).

When the Serial Packet Server receives a packet, it validates the packet. If the checksum is bad or the Routine field is invalid, the Serial Packet Server ignores the packet and does not send back a packet in response. After one second, the client should realize that a packet has not been received and should resend the original packet.

The Si3482 checks the configuration every 30 seconds to see if it has changed. If the configuration has changed, the Si3482 backs up the configuration to internal flash memory. While the Si3482 is writing to flash memory, it cannot send or receive packets on the host interface. If a host MCU sends a packet to the Si3482 while it is backing up the configuration, the packet is lost. If a host MCU does not receive a packet back within one second, the host MCU should resend the original packet.

## 4. Power Manager API

User Interface components call the routines in the Power Manager API to get status information and configure and control the Power Manager. The Power Manager API has routines for:

- Management
- System Status
- Port Status
- System Control
- Port Control
- System Configuration
- Port Configuration
- Power Supply Status
- Events

### 4.1. Management

The Management routines allow a User Interface component to:

- Initialize the Serial Packet Client
- Close the Serial Packet Client

#### 4.1.1. InitPowerManager

Initialize the Serial Packet Client.

**Prototype:**           INT8 InitPowerManager ( EVENT\_HANDLER EventHandler )

**Parameters:**        EventHandler    A pointer to an event handler routine.

**Return Value:**      Zero (for success) or an error code.

This is the first call that a User Interface component makes to the Serial Packet Client. The Serial Packet Client does everything that is required to bring itself to an operational state and is ready to execute all other Power Manager API routines.

If a User Interface component would like to receive events, it should pass the address of an event handler to this routine. If a User Interface component does not want to receive events, it should pass a null address to this routine.

An event handler is located in a User Interface component and has the following prototype:

**Prototype:**         void EventHandler ( EVENT \*Event )

**Parameters:**       Event            A pointer to an EVENT structure, where event information is provided.

**Return Value:**      None

An EVENT structure has the following layout:

```
typedef struct
{
    UINT8  Type;
    INT8   Parm1;
    UINT8  Parm2;
} EVENT;
```



Table 8 lists the event type values.

**Table 8. Event Types**

| Event Type   | Value | Symbol             | Parm1               | Parm2               |
|--------------|-------|--------------------|---------------------|---------------------|
| System       | 1     | SYSTEM_EVENT       | System Status       | (not used)          |
| Port         | 2     | PORT_EVENT         | Port Status         | Port Number         |
| Power Supply | 4     | POWER_SUPPLY_EVENT | Power Supply Status | Power Supply Number |
| Error        | 8     | ERROR_EVENT        | Error Code          | (error specific)    |
| Information  | 16    | INFO_EVENT         | Information Code    | (not used)          |

See the `GetSystemStatus()`, `GetPortStatus()`, and `GetPowerSupplyStatus()` routines for a listing of the status values. See the end of this section for a listing of error codes and information codes.

The Serial Packet Client calls the event handler whenever there is a change in system status, port status, or power supply status. The event handler is also called when an error occurs, such as port overload. If the first parameter (Parm1) is negative, this means there is an error.

#### 4.1.2. ClosePowerManager

Shut down the Serial Packet Client.

**Prototype:** `void ClosePowerManager ( void )`

**Parameters:** None

**Return Value:** None

This function shuts down the Serial Packet Client and frees all allocated resources.

## 4.2. System Status

The System Status routines allow a User Interface component to get the following information:

- System Status
- System Info
- Total Power Consumed
- Total Power Granted
- Total Power Provided

#### 4.2.1. GetSystemStatus

Get the status of the system.

**Prototype:** `INT8 GetSystemStatus( void )`

**Parameters:** None

**Return Value:** System status value.

Table 9 lists the system status values. The system status is the overall status of the system. A negative system status value is an error that is not specific to a particular port.

**Table 9. System Status**

| Status                | Value | Symbol                   |
|-----------------------|-------|--------------------------|
| OK                    | 0     | STATUS_SYSTEM_OK         |
| Initialization Failed | -1    | STATUS_SYSTEM_INIT_FAIL  |
| Under Voltage         | -2    | STATUS_SYSTEM_UNDER_VOLT |
| Over Temperature      | -3    | STATUS_SYSTEM_OVER_TEMP  |
| Communications Lost   | -4    | STATUS_SYSTEM_COMM_LOST  |

## 4.2.2. GetSystemInfo

Get information about the system.

**Prototype:** void GetSystemInfo ( SYSINFO \*SystemInfo )

**Parameters:** SystemInfo A pointer to a SYSINFO structure, where the system information is returned.

**Return Value:** None

A SYSINFO structure has the following layout:

```
typedef struct
{
    char *PowerManagerVersion;
    char *PlatformSupportVersion;
} SYSINFO;
```

The SYSINFO structure contains the version of the Power Manager and the version of the Platform Support component as zero-terminated strings.

## 4.2.3. GetTotalPowerConsumed

Get the power consumed by all PDs.

**Prototype:** INT32 GetTotalPowerConsumed ( void )

**Parameters:** None

**Return Value:** Total power consumed in milliwatts.

## 4.2.4. GetTotalPowerGranted

Get the power granted to all PDs.

**Prototype:** INT32 GetTotalPowerGranted ( void )

**Parameters:** None

**Return Value:** Total power granted in milliwatts.

## 4.2.5. GetTotalPowerProvided

Get the power provided by all power supplies.

**Prototype:** INT32 GetTotalPowerProvided ( void )

**Parameters:** None

**Return Value:** Total power provided in milliwatts.

## 4.3. Port Status

The Port Status routines allow a User Interface component to get the following:

- Port Count
- Port Status
- Port Info
- Port Priority Status
- Port Power Consumed
- Port Power Granted
- Port Power Requested
- Port Power Available

### 4.3.1. GetPortCount

Get the number of ports in the system.

**Prototype:** UINT8 GetPortCount ( void )

**Parameters:** None

**Return Value:** Number of ports in the system.

When the Power Manager starts up, it discovers the number of ports in the system by searching for port controllers.

### 4.3.2. GetPortStatus

Get the status of a port.

**Prototype:** INT8 GetPortStatus ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Port status value or an error code.

Table 10 lists the Port status values.

**Table 10. Port Status Values**

| Status      | Value | Symbol                  | Description   |
|-------------|-------|-------------------------|---|
| Disabled    | 0     | STATUS_PORT_DISABLED    | The port is off because it is not allowed to turn on.                                   |
| Powered On  | 1     | STATUS_PORT_POWERED_ON  | A PD is connected and receiving power.  |
| Powered Off | 2     | STATUS_PORT_POWERED_OFF | The port is off because a PD is not connected.  |
| Denied      | 3     | STATUS_PORT_DENIED      | The port is off because there is not enough power remaining to grant the power request. |
| Blocked     | 4     | STATUS_PORT_BLOCKED     | The port is off because of a port overload.   |
| Forced On   | 5     | STATUS_PORT_FORCED_ON   | The user forced the port on.  |
| Forced Off  | 6     | STATUS_PORT_FORCED_OFF  | The user forced the port off.   |

If a port is blocked, then the PD consumed more power than it was granted (port overload), and the retry policy is “retry after reconnect”. To remove the block, the user must physically disconnect the PD from the port. Another way to remove the block is to disable and then reenble the port.

### 4.3.3. GetPortInfo

Get low-level port information.

**Prototype:** INT8 GetPortInfo ( UINT8 Port, PORTINFO \*PortInfo )

**Parameters:** Port The port number (1–48)

PortInfo A pointer to a PORTINFO structure, where the port information is returned.

**Return Value:** Zero (for success) or an error code

A PORTINFO structure has the following layout:

```
typedef struct
{
    UINT8    Detection;
    UINT8    Classification;
    UINT16   Current;           /* in mA */
    UINT16   PowerSupplyVoltage; /* in mV */
    char     *SiliconVersion;
    char     *FirmwareVersion;
} PORTINFO;
```

Table 11 lists Detection values.

**Table 11. Detection Values**

| Detection | Value | Symbol         |
|-----------|-------|----------------|
| Unknown   | 0     | DETECT_UNKNOWN |
| Short     | 1     | DETECT_SHORT   |
| Low       | 3     | DETECT_LOW     |
| Good      | 4     | DETECT_GOOD    |
| High      | 5     | DETECT_HIGH    |
| Open      | 6     | DETECT_OPEN    |

Table 12 lists Classification values.

**Table 12. Classification Values**

| Classification    | Value | Symbol             |
|-------------------|-------|--------------------|
| Unknown           | 0     | CLASS_UNKNOWN      |
| Class 1           | 1     | CLASS_1            |
| Class 2           | 2     | CLASS_2            |
| Class 3           | 3     | CLASS_3            |
| Class 4           | 4     | CLASS_4            |
| Fingers Not Equal | 5     | CLASS_UNEQ_FINGERS |
| Class 0           | 6     | CLASS_0            |
| Overload          | 7     | CLASS_OVERLOAD     |

#### 4.3.4. GetPortPriorityStatus

Get the priority status of a port.

**Prototype:** INT8 GetPortPriorityStatus ( UINT8 Port )

**Parameters:** Port            The port number (1–48)

**Return Value:** Port priority status value or an error code.

Table 13 lists the Port Priority Status values.

**Table 13. Port Priority Status Values**

| Port Priority Status | Value | Symbol            |
|----------------------|-------|-------------------|
| Low                  | 0     | PRIORITY_LOW      |
| High                 | 1     | PRIORITY_HIGH     |
| Forced               | 2     | PRIORITY_FORCED   |
| Critical             | 3     | PRIORITY_CRITICAL |

The priority status of a port is the currently-active priority and may be different than the configured priority of the port. If a port is forced on or off and the configured priority is low or high, the priority status is elevated to the forced priority. If a forced port is returned to automatic control, the Power Manager returns the priority status to the configured priority.

#### 4.3.5. GetPortPowerConsumed

Get the power that a PD is currently using.

**Prototype:** INT32 GetPortPowerConsumed ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Port power consumed in milliwatts or an error code.

#### 4.3.6. GetPortPowerGranted

Get the power that is allocated to a PD.

**Prototype:** INT32 GetPortPowerGranted ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Port power granted in milliwatts or an error code.

#### 4.3.7. GetPortPowerRequested

Get the power that a PD says it needs.

**Prototype:** INT32 GetPortPowerRequested ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Port power requested in milliwatts or an error code.

#### 4.3.8. GetPortPowerAvailable

Get the maximum request that would be successfully granted.

**Prototype:** INT32 GetPortPowerAvailable ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Port power available in milliwatts or an error code.

An LLDP agent calls this routine to ask the question, “What is the maximum power that you would give me if I asked for it?”

If a port has a power limit, then the power limit is returned. If a port does not have a power limit and the port can supply high power, then maximum power (40 W) is returned; otherwise, low power (15.4 W) is returned.

## 4.4. System Control

The System Control routines allow a User Interface component to

- Reset the System
- Restore Factory Defaults

### 4.4.1. ResetSystem

Reset the system.

**Prototype:** INT8 ResetSystem ( void )

**Parameters:** None

**Return Value:** Zero (for success) or an error code.

### 4.4.2. RestoreFactoryDefaults

Restore the configuration to factory default values.

**Prototype:** void RestoreFactoryDefaults ( void )

**Parameters:** None

**Return Value:** None

The Power Manager also resets the system after setting the configuration to default values.

## 4.5. Port Control

The Port Control routines allow a User Interface component to

- Set Port Control
- Adjust Port Power

### 4.5.1. SetPortControl

Set how the port is turned on and off.

**Prototype:** INT8 SetPortControl ( UINT8 Port, UINT8 Control )

**Parameters:** Port The port number (1–48)  
Control How the port is turned on and off.

**Return Value:** Zero (for success) or an error code.

Table 14 lists Port Control values.

**Table 14. Port Control Values**

| Control   | Value | Symbol              |
|-----------|-------|---------------------|
| Automatic | 0     | PORT_CTRL_AUTOMATIC |
| Force On  | 1     | PORT_CTRL_FORCE_ON  |
| Force Off | 2     | PORT_CTRL_FORCE_OFF |

If the port control is automatic, the Power Manager automatically turns the port on and off when a PD is connected and disconnected from the port.

If the port control is forced on, the port's priority is boosted to the forced priority level. This usually results in the port turning on. However, a forced port cannot cause a critical priority port to turn off in order to turn on the forced port. If a forced port is granted power, the Power Manager turns on a forced port even if no PD is detected.

If the port control is forced off, the port is unconditionally turned off and held off. A forced-off port is considered to be temporarily off, while a disabled port is considered to be permanently off.

### 4.5.2. AdjustPortPower

Adjust the power granted to a PD.

**Prototype:** INT8 AdjustPortPower ( UINT8 Port, INT32 Power )

**Parameters:** Port The port number (1–48)  
Power Requested port power in milliwatts.

**Return Value:** Zero (for success) or an error code.

An LLDP agent calls this routine to reallocate the power granted to a PD. The agent can request more power than is currently granted or it can request less power than is currently granted. This routine allows an LLDP agent to dynamically change the amount of power granted to a PD during the course of a connection. A port must be on before its power can be adjusted.

## 4.6. System Configuration

The System Configuration routines allow a User Interface component to set and get

- Power Provided
- Reserved Power
- Overload Limit
- Granting Policy
- Retry Policy
- Power Location

### 4.6.1. SetPowerProvided

Set the amount of power that is output from a power supply.

**Prototype:** INT8 SetPowerProvided ( UINT8 PowerSupply, INT32 Power )

**Parameters:** PowerSupply The power supply number (1–3)  
Power Power provided by the power supply in milliwatts.

**Return Value:** Zero (for success) or an error code.

### 4.6.2. GetPowerProvided

Get the amount of power that is output from a power supply.

**Prototype:** INT32 GetPowerProvided ( UINT8 PowerSupply )

**Parameters:** PowerSupply The power supply number (1–3)

**Return Value:** Power provided by the power supply in milliwatts or an error code.

### 4.6.3. SetReservedPower

Set the percentage of power that is reserved from granting.

**Prototype:** INT8 SetReservedPower ( INT8 Reserved )

**Parameters:** Reserved Reserved power as a percentage of the total power provided.

**Return Value:** Zero (for success) or an error code.

If the granting policy is consumption-based, the Power Manager holds this amount of power in reserve. The Power Manager does not use the reserved power to grant new requests. This creates a power buffer that reduces the likelihood of system overloads caused by momentary surges in consumption.

### 4.6.4. GetReservedPower

Get the percentage of power that is reserved from granting.

**Prototype:** INT8 GetReservedPower ( void )

**Parameters:** None

**Return Value:** Reserved power as a percentage of the total power provided or an error code.

## 4.6.5. SetOverloadLimit

Set the maximum system overload that the power supplies can tolerate.

**Prototype:** INT8 SetOverloadLimit ( INT8 Limit )

**Parameters:** Limit Overload limit as a percentage of the total power provided.

**Return Value:** Zero (for success) or an error code.

The overload limit is the maximum system overload that the power supplies can tolerate. It is expressed as a percentage of the total power provided. If a system overload is less than the overload limit, the ports are turned off one at a time. If a system overload is greater than the overload limit (severe overload), all of the low-priority ports are immediately turned off.

## 4.6.6. GetOverloadLimit

Get the maximum system overload that the power supplies can tolerate.

**Prototype:** INT8 GetOverloadLimit ( void )

**Parameters:** None

**Return Value:** Overload limit as a percentage of the total power provided or an error code.

## 4.6.7. SetGrantingPolicy

Set the granting policy.

**Prototype:** INT8 SetGrantingPolicy ( INT8 GrantingPolicy )

**Parameters:** GrantingPolicy How requests for power are granted.

**Return Value:** Zero (for success) or an error code.

Table 15 lists the Granting Policy values.

**Table 15. Granting Policy Values**

| Granting Policy   | Value | Symbol                         |
|-------------------|-------|--------------------------------|
| Grant-based       | 0     | GRANT_POLICY_GRANT_BASED       |
| Consumption-based | 1     | GRANT_POLICY_CONSUMPTION_BASED |

The granting policy is used by the Power Manager when deciding if a request for power should be granted. If the granting policy is grant based, the remaining power is considered to be the total ungranted power. If the granting policy is consumption-based, the remaining power is considered to be the total unconsumed power (excluding the reserved power). If the remaining power is greater than or equal to the requested power, then the Power Manager grants the request.

Grant based:  $PowerRemaining = TotalPowerProvided - TotalPowerGranted$

Consumption based:  $PowerRemaining = TotalPowerProvided - TotalPowerConsumed - ReservedPower$

## 4.6.8. GetGrantingPolicy

Get the granting policy.

**Prototype:** INT8 GetGrantingPolicy ( void )

**Parameters:** None

**Return Value:** The granting policy value.



#### 4.6.9. SetRetryPolicy

Set the retry policy.

**Prototype:** INT8 SetRetryPolicy ( INT8 RetryPolicy )

**Parameters:** RetryPolicy When to retry after a port overload.

**Return Value:** Zero (for success) or an error code.

Table 16 lists the Retry policy values.

**Table 16. Retry Policy Values**

| Retry Policy | Value | Symbol                |
|--------------|-------|-----------------------|
| Immediate    | 0     | RETRY_IMMEDIATELY     |
| Reconnect    | 1     | RETRY_AFTER_RECONNECT |
| Reenable     | 2     | RETRY_AFTER_REENABLE  |

The retry policy specifies when the Power Manager tries again to power a port that is turned off because of a port overload. A port overload is when the power consumed by a PD is greater than the power granted to that PD. If the retry policy is “immediate”, the Power Manager tries to turn the port back on immediately.

If the retry policy is “reconnect”, the Power Manager waits until the PD is disconnected and then reconnected before it tries again to power the port. The Power Manager must detect an open circuit on the port before retrying.

If the retry policy is “reenable”, the Power Manager disables the port when a port overload occurs. The user must reenables the port before the Power Manager tries to power the port again.

#### 4.6.10. GetRetryPolicy

Get the retry policy.

**Prototype:** INT8 GetRetryPolicy ( void )

**Parameters:** None

**Return Value:** The retry policy value.

#### 4.6.11. SetPowerLocation

Set the location of the power source.

**Prototype:** INT8 SetPowerLocation ( INT8 Location )

**Parameters:** Location Where the power source is located.

**Return Value:** Zero (for success) or an error code.

Table 17 lists the Location values.

**Table 17. Power Location Values**

| Location | Value | Symbol            |
|----------|-------|-------------------|
| Endpoint | 0     | LOCATION_ENDPOINT |
| Midspan  | 1     | LOCATION_MIDSPAN  |

If the power source is within an Ethernet switch, the location is an “endpoint”. If the power source is inserted between an Ethernet switch and a PD, the location is a “midspan”. The Power Manager uses different back-off timings for different locations. The Power Manager assumes that an endpoint device uses the Alternative A pinout and that a midspan device uses the Alternative B pinout.

## 4.6.12. GetPowerLocation

Get the location of the power source.

**Prototype:** INT8 GetPowerLocation ( void )

**Parameters:** None

**Return Value:** The location value.

## 4.7. Port Configuration

The Port Configuration routines allow a User Interface component to set and get:

- Port Enable
- Port Capability
- Port Priority
- Port Power Limit

### 4.7.1. SetPortEnable

Set if a port is allowed to turn on.

**Prototype:** INT8 SetPortEnable ( UINT8 Port, INT8 Enable )

**Parameters:** Port The port number (1–48)  
Enable Specifies if the port is allowed to power on.

**Return Value:** Zero (for success) or an error code

If `Enable` is zero, the port is disabled and is not allowed to power on. If `Enable` is one, the port is enabled and is allowed to power on.

### 4.7.2. GetPortEnable

Get if a port is allowed to turn on.

**Prototype:** INT8 GetPortEnable ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Zero for disabled, one for enabled, or an error code

### 4.7.3. SetPortCapability

Set if a port can supply high power.

**Prototype:** INT8 SetPortCapability ( UINT8 Port, INT8 Capability )

**Parameters:** Port The port number (1–48)  
Capability Specifies if the port can supply high power.

**Return Value:** Zero (for success) or an error code

Table 18 lists the Port Capability values.

**Table 18. Port Capability Values**

| Capability | Value | Symbol                |
|------------|-------|-----------------------|
| Low Power  | 0     | CAPABILITY_LOW_POWER  |
| High Power | 1     | CAPABILITY_HIGH_POWER |

If the port hardware is designed to supply high power (PoE+), set `Capability` to one. Otherwise, set `Capability` to zero.

A port's capability cannot be changed while the port is on. This is a limitation of the Si3452 port controller.

#### 4.7.4. GetPortCapability

Get if a port can supply high power.

**Prototype:** INT8 GetPortCapability ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Capability value or an error code

#### 4.7.5. SetPortPriority

Set the priority of a port.

**Prototype:** INT8 SetPortPriority ( UINT8 Port, INT8 Priority )

**Parameters:** Port The port number (1–48)  
Priority How important it is for the port to be powered.

**Return Value:** Zero (for success) or an error code

Table 19 lists the Port priority values.

**Table 19. Port Priority Values**

| Port Priority | Value | Symbol            |
|---------------|-------|-------------------|
| Low           | 0     | PRIORITY_LOW      |
| High          | 1     | PRIORITY_HIGH     |
| Critical      | 3     | PRIORITY_CRITICAL |

The priority of a port indicates how important it is that the port receives power. If there is not enough power provided for all ports that want power, then the low priority ports are the first ports to be denied. Critical priority ports are the last ports to be denied.

If a port is forced on, then the port's priority is elevated to the forced priority level. Forced priority is between high priority and critical priority and cannot be directly set by the user. When a port is forced on, it may cause a high priority port to be turned off, but it can never cause a critical priority port to be turned off.

If a severe overload occurs, all of the low priority ports are immediately powered off.

#### 4.7.6. GetPortPriority

Get the priority of a port.

**Prototype:** INT8 GetPortPriority ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Priority value or an error code

#### 4.7.7. SetPortPowerLimit

Set the power limit of a port.

**Prototype:** INT8 SetPortPowerLimit ( UINT8 Port, INT32 Limit )

**Parameters:** Port The port number (1–48)  
Limit Maximum power that may be granted in milliwatts.

**Return Value:** Zero (for success) or an error code.

A power limit restricts the amount of power that may be granted to a port. If a port's power limit is zero, the Power Manager grants the power requested without restriction. If a port's power limit is greater than zero, the Power Manager grants the lesser of the power limit or the power requested. If a power request is greater than the power limit, the Power Manager grants less power than requested.

## 4.7.8. GetPortPowerLimit

Get the power limit of a port.

**Prototype:** INT32 GetPortPowerLimit ( UINT8 Port )

**Parameters:** Port The port number (1–48)

**Return Value:** Power limit in milliwatts or an error code

## 4.8. Power Supply Status

The Power Supply Status routines allow a User Interface component to get:

### ■ Power Supply Status

#### 4.8.1. SetPowerSupplyStatus

Set the status of a power supply.

**Prototype:** INT8 SetPowerSupplyStatus (UINT8 PowerSupply, INT8 Status)

**Parameters:** PowerSupply The power supply number (1–3)  
Status Power supply status

**Return Value:** Zero (for success) or an error code.

In platforms that do not have signals to indicate the presence of power supplies, this routine allows a User Interface component to simulate the insertion and removal of power supplies. However, the Si3482 does have power supply signals (PS1, PS2, and PS3). If a User Interface component calls this routine, the Power Manager does nothing and returns SUCCESS.

#### 4.8.2. GetPowerSupplyStatus

Get the status of a power supply.

**Prototype:** INT8 GetPowerSupplyStatus (UINT8 PowerSupply )

**Parameters:** PowerSupply The power supply number (1–3)

**Return Value:** The status of the power supply.

Table 20 lists the Power supply status values.


**Table 20. Power Supply Status**

| Power Supply Status | Value | Symbol                       |
|---------------------|-------|------------------------------|
| Removed             | 0     | STATUS_POWER_SUPPLY_REMOVED  |
| Inserted            | 1     | STATUS_POWER_SUPPLY_INSERTED |

A User Interface component calls this function to determine whether a power supply is present in a bay. If the voltage on the specified power supply pin (PS1, PS2, or PS3) is high, this routine returns STATUS\_POWER\_SUPPLY\_INSERTED; otherwise, this routine returns STATUS\_POWER\_SUPPLY\_REMOVED.

## 4.9. Events

An event is an unsolicited notification from the Power Manager that a status has changed. The Power Manager calls the event handler in the Serial Packet Server whenever there is a change in system status, port status, or power supply status. The Serial Packet Server stores the events in an event queue.



**Figure 13. Events Architecture**

If a User Interface component wishes to receive events, it provides the address of an event handler when it calls `InitPowerManager()`. The Serial Packet Client spawns an event task. The event task remotely calls the `GetEvents()` routine in the Serial Packet Server every 200 ms to retrieve the events from the event queue. For each event that is retrieved, the Serial Packet Client calls the event handler in the User Interface component.

### 4.9.1. GetEvents

Get the events from the event queue.

**Prototype:** `void GetEvents ( EVENT *Event )`

**Parameters:** `Event` Pointer to returned events.

**Return Value:** None.

This routine exists in the Serial Packet Server and is called by a Serial Packet Client to get events from the event queue. This routine sends back a packet with the Data field in the Events format. This routine may return from zero to 85 events.

## 4.10. Return Codes

The routines of the Power Manager API return codes to indicate the success or failure of an operation. These codes are also used in Parm1 of error events and information events.

### 4.10.1. Success Code

A zero code indicates success.

**Table 21. Success Code**

| Success | Value | Symbol  |
|---------|-------|---------|
| Success | 0     | SUCCESS |

### 4.10.2. Error Codes

A negative code indicates an error.

**Table 22. Error Codes**

| Error                          | Value | Symbol                  |
|--------------------------------|-------|-------------------------|
| Port number is invalid         | -1    | ERROR_PORT_INVALID      |
| Power supply number is invalid | -2    | ERROR_PWR_SUPLY_INVALID |
| Parameter is invalid           | -3    | ERROR_PARAMETER_INVALID |
| Cannot create resource         | -4    | ERROR_RESOURCE_CREATE   |
| Resource is invalid            | -5    | ERROR_RESOURCE_INVALID  |
| Cannot configure resource      | -6    | ERROR_RESOURCE_CONFIG   |
| Cannot read from resource      | -7    | ERROR_RESOURCE_READ     |
| Cannot write to resource       | -8    | ERROR_RESOURCE_WRITE    |
| Cannot find the resource       | -9    | ERROR_RESOURCE_NOT_FND  |
| Cannot load the configuration  | -10   | ERROR_CONFIG_LOAD       |
| Cannot save the configuration  | -11   | ERROR_CONFIG_SAVE       |
| Configuration data is invalid  | -12   | ERROR_CONFIG_INVALID    |
| Configuration data is corrupt  | -13   | ERROR_CONFIG_CORRUPT    |
| System overload                | -14   | ERROR_SYSTEM_OVERLOAD   |
| Port overload                  | -15   | ERROR_PORT_OVERLOAD     |
| Startup overload               | -16   | ERROR_STARTUP_OVERLOAD  |


### 4.10.3. Information Codes

A positive code indicates useful information.

**Table 23. Information Codes**

| Information                  | Value | Symbol                 |
|------------------------------|-------|------------------------|
| Restored to factory defaults | 1     | INFO_DEFAULTS_RESTORED |
| System reset                 | 2     | INFO_SYSTEM_RESET      |
| Configuration saved          | 3     | INFO_CONFIG_SAVED      |

## 5. Pin Descriptions



**Table 24. Si3482 Pin Descriptions**

| Pin # | Name  | Type     | Description   |
|-------|-------|----------|---|
| 1     | MISO  | Output   | SPI output.   |
| 2     | SCK   | Input    | SPI clock.  |
| 3     | GND   | Power    | Ground.   |
| 4     | VDD   | Power    | VDD.  |
| 5     | RST   | Input    | Reset (a low will reset the Si3480).                      |
| 6     | RSVD  | Input    | Reserved—tie low.   |
| 7     | RSVD  | Reserved | Do not connect.   |
| 8     | RSVD  | Reserved | Do not connect.   |
| 9     | RSVD  | Reserved | Do not connect.   |
| 10    | PS3   | Input    | Logic high indicates the power supply is available.       |
| 11    | PS2   | Input    | Logic high indicates the power supply is available.       |
| 12    | PS1   | Input    | Logic high indicates the power supply is available.       |
| 13    | PSLCT | Input    | Tie high or low to select between SPI and UART interface. |
| 14    | BAUD2 | Input    | Tie high or low to select UART baud rate.                 |
| 15    | BAUD1 | Input    | Tie high or low to select UART baud rate.                 |


**Table 24. Si3482 Pin Descriptions (Continued)**

| Pin # | Name  | Type           | Description                                 |
|-------|-------|----------------|---|
| 16    | BAUD0 | Input          | Tie high or low to select UART baud rate.   |
| 17    | SCL   | Open Collector | Connect to Si3452 SCL and pull up resistor. |
| 18    | SDA   | Open Collector | Connect to Si3452 SDA and pull up resistor. |
| 19    | INT   | Input          | Connect to Si3452 INT and pull up resistor. |
| 20    | RSVD  | Reserved       | Do not connect.                             |
| 21    | RX    | Input          | UART receive.                               |
| 22    | TX    | Output         | UART transmit.                              |
| 23    | NSS   | Input          | SPI select.                                 |
| 24    | MOSI  | Input          | SPI input.                                  |



## 6. Package Outline: 24-Pin QFN


The Si3482 is packaged in an industry-standard, RoHS-compliant 6 x 6 mm<sup>2</sup>, 24-pin QFN package.



**Figure 14. 24-Pin QFN Mechanical Diagram**  
**Table 6.1. QFN-24 Package Dimensions**


|    | MM   |      |      |
|----|------|------|------|
|    | Min  | Typ  | Max  |
| A  | 0.70 | 0.75 | 0.80 |
| A1 | 0.00 | 0.02 | 0.05 |
| A2 | —    | 0.50 | —    |
| A3 | —    | 0.25 | —    |
| b  | 0.18 | 0.25 | 0.30 |
| D  | —    | 4.00 | —    |
| D2 | 2.50 | 2.60 | 2.70 |
| E  | —    | 4.00 | —    |
| E2 | 2.50 | 2.60 | 2.70 |
| e  | —    | 0.50 | —    |
| L  | 0.35 | 0.40 | 0.45 |
| N  | —    | 24   | —    |
| ND | —    | 6    | —    |
| NE | —    | 6    | —    |
| R  | 0.09 | —    | —    |

## 7. PCB Land Pattern




**Figure 15. Typical QFN-24 PCB Land Pattern**

## 8. Solder/Paste Recommendation



**Figure 16. QFN-24 Solder Paste Recommendation**

## 9. Top Marking Diagram



**Figure 17. Top Marking Diagram**

**Table 25. Top Marking Explanation**

|                 |                      |   |
|-----------------|----------------------|---|
| Line 1 Marking: | Pin 1 Identifier     | Circle, 0.25 mm diameter  |
|                 | Product ID           | 3482A   |
| Line 2 Marking: | Firmware revision    | 01 = Firmware revision 01   |
| Line 3 Marking: | TTTTTT = Trace Code  | Manufacturing code characters from the Markings section of the Assembly Purchase Order form |
| Line 4 Marking: | YYWW+ = Date Code    | YY = Last two digits of current year<br>WW = Current Work Week                              |
|                 | Lead Free Designator | +   |

## 10. Ordering Guide

**Table 26. Si3482 Ordering Guide**

| Ordering Part Number  | Description  | Package Information                 |
|---|--|-------------------------------------|
| Si3482-A01-GM   | Power management controller  | 24-pin 4x4 mm QFN<br>RoHS compliant |
| SMARTPSE24-KIT  | An evaluation kit with the Si3482, six Si3452 controllers, and the Si3500 for generating the 3.3 V supply from the PoE supply. | Evaluation Board                    |
| <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>1. Add "R" to the part number to denote tape and reel option (Si3482-A01-GMR).</li> <li>2. The ordering part number is not the same as the device mark. See "6. Package Outline: 24-Pin QFN" on page 33 for device marking information</li> </ol> |  |                                     |

## CONTACT INFORMATION

### Silicon Laboratories Inc.

400 West Cesar Chavez  
Austin, TX 78701  
Tel: 1+(512) 416-8500  
Fax: 1+(512) 416-9669  
Toll Free: 1+(877) 444-3032

Please visit the Silicon Labs Technical Support web page:  
<https://www.silabs.com/support/pages/contacttechnicalsupport.aspx>  
and register to submit a technical support request.

The information in this document is believed to be accurate in all respects at the time of publication but is subject to change without notice. Silicon Laboratories assumes no responsibility for errors and omissions, and disclaims responsibility for any consequences resulting from the use of information included herein. Additionally, Silicon Laboratories assumes no responsibility for the functioning of undescribed features or parameters. Silicon Laboratories reserves the right to make changes without further notice. Silicon Laboratories makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Silicon Laboratories assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Silicon Laboratories products are not designed, intended, or authorized for use in applications intended to support or sustain life, or for any other application in which the failure of the Silicon Laboratories product could create a situation where personal injury or death may occur. Should Buyer purchase or use Silicon Laboratories products for any such unintended or unauthorized application, Buyer shall indemnify and hold Silicon Laboratories harmless against all claims and damages.

Silicon Laboratories and Silicon Labs are trademarks of Silicon Laboratories Inc.

Other products or brandnames mentioned herein are trademarks or registered trademarks of their respective holders.