

Wristband Circumference - 2.5" - 14"

Jewel® MagSnap Wrist Straps meet or exceed the requirements of ANSI/ESD S20.20 and ANSI/ESD S1.1 including section 5.4 Breakaway Force "With the ground cord connected to the cuff in a normal manner, a force of \Box 45 kg (1 lb) but \Box 2.3 kg (5 lb) applied to the ground cord, in the normal disconnect direction, shall be required to separate the ground cord from the cuff."

Per ANSI/ESD S20.20 Paragraph 6.2.2.1. Personnel Grounding Requirements "All personnel shall be bonded or electrically connected to ground or contrived ground when handling ESD sensitive items. When personnel are seated at ESD protective workstations, they shall be connected to the common point ground via a wrist strap system

"At first glance, the ground cord appears to be a relatively simple assembly. However, the design requirements are considerable, given the wide range of user applications and the durability requirements of constant tugging, flexing, and dragging over the edge of workstation tops and equipment chassis."

(ESD Handbook TR20.20 paragraph 5.3.2.2.2 Wrist Strap Ground Cord)

NOTE: Complete wrist strap kits include an alligator clip. Wrist strap kits include an alligator clip for occasions when a grounded banana jack is not available. However, "Wrist strap ground cords must be connected to a groundable point or an equipotential bonding point. Do not connect to a snap on a dissipative mat unless it is the groundable point for the mat. Do not clip a wirst strap to the edge of a dissipative mat." (ESD Handbook TDP000 excited 5.2.3.2) TR20.20 section 5.3.2.7)

ESD Handbook TR 20.20 paragraph 5.3.2.4.4 Test Frequency "Because wrist straps have a finite life, it is important to develop a test frequency that will guarantee integrity of the system. Typical test programs recommend that wrist straps that are used daily should be tested daily. However, if the products that are being produced are of such value that knowledge of a continuous, reliable ground is needed, and then continuous monitoring should be considered or even required'

Continuous Monitors pay for themselves improving quality, productivity, eliminating wrist strap daily testing and test result logging. Per ESD-S1.1 paragraph 6.1.3 Frequency of Functional Testing "Daily (Wrist Strap) testing may be omitted if constant monitoring is und " used

DESCO

- Patented revolutionary magnetic interconnect technology (U.S. Patent 5,004,425) Creates magnetic connection between wristband and coil cord; meets ANSI/ESD S20.20 and ESD S1.1, including disengagement force test (1-5 lbs). More consistent disengagement force than standard 4 mm designs More reliable design
- MagSnap revolutionary design provides consistent retention and release performance. Durable, lightweight fabric Some users prefer the softness, comfort and flexibility of this material
- Has silver plated polypropylene knitted on inside for superior conductivity Reliably removes generated static charges
- Made with pure silver irreversibly bound to fibers providing both antimicrobial and anti-odor performance
- Adjustable
- Only one item to stock; may be fitted to almost all people
- Locking clasp Protects wearers from electrical hazards; provides many years of product life
 - Medical grade 300 series stainless steel used for all metal parts Eliminates allergic skin reaction for most people
- Non-shedding, non-sloughing band material Safe for microelectronics
 - UL Listed
 - Note: This product is not recommended for use on equipment with operating voltage exceeding 250 V/A(
 - **CAUTION:** The ESD Series is for electrostatic control. It will not reduce or increase your risk of receiving electric shock when using or working on electrical equipment. Follow the same precautions you would use without wrist straps, including:
 - · Make certain that equipment having a grounding type plug is properly grounded. · Make certain that you are not in contact with grounded objects other than through the ESD Series.
- Date coded
 - Providing lot tractability to ensure quality control
 - Superior resistor connection strain relief
 - Superior reliability. Greatly exceeds ESD S1.1 Bending Life Test. Tested at over 1,000,000 cycles vs. the 16,000 requirement
 - Covered by one or more of the following patents: Wristband: 4,662,695 Coil Cord: 5,951,337

DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407

PHONE (781) 821-8370 FAX (781) 575-0172

- Superior warranty See details of 1 year Limited Warranty at <u>http://www.desco.com/Warranty.aspx</u>
- Made in America

ITEM	DESCRIPTION		
<u>09183</u>	Jewel [®] MagSnap Adjustable Elastic Wristband		
<u>09184</u>	Jewel [®] MagSnap Adjustable Elastic Wrist Strap with 6 ft Coil Cord		
<u>09185</u>	Jewel [®] MagSnap Adjustable Elastic Wrist Strap with 12 fl	t Coil Cord	
See Dra	wing <u>09180</u> for details on Jewel [®] MagSnap Coil Cords		
Improve w	Improve wrist strap contact with Reztore™ ESD Hand Lotion.		
Specificat	ions and procedures subject to change without notice.		Made in Americ
Jewel [®] MagSnap Adjustable Elastic Wrist Strap			
	WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: <u>Desco.com</u> (909) 627-8178 FAX (909) 627-7449	DRAWING	DATE
DESCO	FAST: ONE COLGATE WAY, CANTON, MA 02021-1407	NUMBER	Februa

09183

2010

© 2010 DESCO INDUSTRIES INC