

iDRN-ACV AC VOLTAGE INPUT

General Description:

The iDRN Series of DIN rail-mountable signal conditioners are available for Thermocouple, RTD, Strain, Process, AC Voltage, AC Current and Pulse/Totalizer input types.

The factory calibrated signal conditioners are ideal for all process and power monitoring applications, they feature 3-way isolation, high accuracy input, programmable outputs and are excellent front end interfaces for programmable logic controllers or data acquisition systems. For maximum user configurability the signal conditioners allow complete inputoutput scaling via a RS-232 connection to any PC or PLC.

Software Description:


The signal conditioner configuration program is a MS DOS/Windows program (this manual is for the Windows version). It is designed especially for the iDRN Series Signal Conditioner. This program will run on any PC with Windows application and will start automatically.

Free Serial Communication software and ActiveX Controls are on the CD-ROM enclosed with this shipment. To download the latest software release (or request a free CD-ROM) please go to: www.newportUS.com/software

What You need:

 Your choice of the signal conditioner • IBM PC or compatible •Windows software 3.1 or higher, or Windows 95/98 •RI12 connector with telephone cable • Adapter (DB9 or DB25 to RJ12)

Setting up your System



2 INPUT RANGES: 400 mV, 4V, 40 Volt, 400 Volt

FREQUENCY RANGE: 30 Hz to 1 KHz

INPUT IMPEDANCE: 2.1 Meg for all ranges.

ISOLATION:

Dielectric strength per 1 minute test based on EN 61010 for 50 Vdc or Vrms working voltage.

Three way Isolation: Power to Signal Input: 1800V Peak

- Power to Analog Output/Communication: 1800V Peak
 Signal Input to Analog Output/Communication: 1400V
- COMMON MODE REJECTION:

INPUT OVER-VOLTAGE PROTECTION: 10% Above full scale continuously. 100% Above full scale for 10 seconds. ANALOG TO DIGITAL TECHNIQUE: Dual slope

READ RATE: 8 readings/second

ACCURACY AT 25 °C: 400 mV, 4V, 40V and 400V ranges 49 Hz to 500 Hz $\pm 0.2\%$ of FS 30 Hz to 1KHz $\pm 0.2\%$ of FS ± 10 counts

TEMPERATURE STABILITY: 400 mV and 40 Volt range 150 ppm/°C typical 4V and 400 Volt range $\,100\;ppm/\,^{o}C$ typical

STEP RESPONSE FOR RS232 OUTPUT: 2 seconds to 99% of the final value (Filter time constant = 64)

RESPONSE TIME: To verify the response time, check the carriage return <CR>, it will be sent at the end of the response. You can send another command after you receive the <CR>.

i.e. send: *X01

response: X01<DATA><CR>

WARM UP TO RATED ACCURACY:

ANALOG OUTPUT SIGNAL TYPE: Voltage: 0-10 Volt, maximum current 10mA

Current: 0-20 mA or 4-20 mA, maximum compliance voltage 10 Volts (maximum loop resistance 500Ω)




ANALOG OUTPUT LINEARITY: 0.1% of FS ANALOG OUTPUT STEP RESPONSE TIME: 2 seconds to 99% of final value

INPUT POWER: 10 to 32 Volt DC POWER CONSUMPTION: 2.4 watts (100 mA at 24 Vdc)


OPERATING AMBIENT: STORAGE TEMPERATURE:

-40 to +85 °C



Introduction:

The AC voltage input signal conditioners are high performance instruments that measure AC voltages in 4 ranges which are as follows: 400 mV, 4 Volt, 40 Volt and 400 Volt. Key features of the signal conditioners are built in active attenuator, scalable analog output and a simple RS232 interface for scaling analog output and range selection. The RS232 interface may also be used for digital transmission of input signal to a computer or a PLC. Additional features include three way isolation between DC power, signal input and analog output/RS232.



Operation:

Note: When connecting a voltage signal, extra care should be taken to prevent electrical shock. Always turn the signal power off before making connections to the signal conditioner.

 $\underline{\wedge}$ always ensure that the maximum voltage INPUT SIGNAL DOES NOT EXCEED 400 VOLTS AC.

▲ PLEASE OBSERVE THE INPUT SIGNAL CONNECTION SPECIFIED IN THE SECTION BELOW. THIS DEVICE MUST ONLY BE INSTALLED BY A PROFESSIONAL ELECTRICIAN.

Power Input and Analog Output Setup:

To connect the signal input proceed as follows: 1. Connect a DC power supply with an output voltage

between 10 to 32 Volt DC to the signal conditioner (J1). Note: If power supply used has current limiting, it may not be able to power the signal conditioners if the available output voltage is around 10 Volt, since the peak current may reach 1 to 5 amp for a few milliseconds.

2. Determine the maximum voltage to be measured.





3. Determine the appropriate input signal range, i.e. 400 mV, 4 Volt, 40 Volt or 400 Volt. Also ensure that the frequency of AC source is within the specified limits.

4. Ensure that if the selected range is different from the default then change the internal range by using the Setup Software and select the appropriate range.

5. Connect the signal input to screw terminal, and ensure that the screws are tight. Failure to do so may cause electrical shock should the wires become loose and come out of the screw terminal.

6. To verify that the set up is correct, you may connect a DVM to the analog output. Once connected, power the signal conditioner and apply a known voltage from an AC source to input. Measure and compare with expected values. To custom scale the analog output proceed to the next step.

7. To view/change the scaling that relates the analog output to signal input: connect the RS232 output of the signal conditioner to an available serial port of a computer. The cable and the DB9 or DB25 connectors are available as an option.

8. Turn on the computer, start Windows 3.0 or higher and run the Signal Conditioner Configuration Setup Program.

9. Start the configuration program, you need to indicate which serial port is to be used for serial communication by checking the appropriate check box on the opening menu. Note: It is not necessary to know the serial communication

protocol. i.e. baud rate, parity, 7/8 data bit and stop bit; the program will determine this information automatically. However, it is good practice to mark the protocols used on the signal conditioner label if different from default.

10. Once the program starts it will automatically detect the signal conditioner configuration and will display a window of available options. To view the signal input click on the display on/off.

11. To change analog output scaling choose analog output scaling and enter the desired values

12. Once the custom scaling is finished, ensure that Send Configuration is clicked, otherwise the changes will not take effect. 13. The input/output scaling may be fine tuned, while both communication and analog output are active. In fact you may make a change to the analog output in the configuration program, and watch the DVM connected to analog output of the signal conditioner follow the new settings.

14. You may save or print a particular configuration by selecting the file menu. It's always a good practice to both print and save the scaling of each signal conditioner.



15. If the program is not able to establish communication then an error message is displayed. This happens either when the wrong serial port is specified or when the cable is disconnected.

The procedure to disable Continuous Mode and change 16. the iDRN to Command Mode is as follows:

Using HyperTerminal, or any serial communication program, type: Ctrl + S To change the device to Command Mode, type: ^AE To change the Bus Format Register, type: *W0814 To reset the device, type: *Z01 Cycle power to the unit. Modbus Register Definition

| Reg. # | Read Function | Write Function | # of byte |
|--------|-----------------------|--------------------------|-----------|
| 1 | Input Range | Input Range | 1 |
| 2 | Input/Output Config. | Input/Output Conf. | 1 |
| 3 | Decimal Point | Decimal Point | 1 |
| 4 | Filter Time Constant | Filter Time Constant | 1 |
| 5 | Reading/Output Scale | Not supported | 3 |
| 6 | Reading/Output Offset | Not supported | 3 |
| 7 | Comm. Parameters | Comm. Parameters | 1 |
| 8 | Comm. Bus Format | Comm. Bus Format | 1 |
| 9 | Comm. Data Format | Comm. Data Format | 1 |
| А | Comm. Device Addr. | Comm. Device Addr. | 1 |
| В | Comm. Recog. Char. | Comm. Recog. Addr. | 1 |
| С | Unit of measure | Not supported | 3 |
| D | Gate Time | Gate Time | 1 |
| E | Debounce Time | Debounce Time | 1 |
| F | Transmit Time | Transmit Time | 2 |
| 10 | Main Value | Hard Reset | 3 |
| 11 | Peak Value | Reset Peak | 1 |
| 12 | Valley Value | Reset Valley | 1 |
| 13 | Not Supported | L.S. bytes Output Scale | 2 |
| 14 | Not Supported | M.S. byte Output Scale | 1 |
| 15 | Not Supported | M.S. bytes Output Offset | 2 |
| 16 | Not Supported | L.S. byte Output Offset | 1 |

1) Main, Peak, Valley value: 4 bytes will send from the unit

a. Highest byte always 00h.
 b. 2nd Highest byte: (MSB is sign (1=negative, 0=positive), next 3 bits are number of decimal points).

c. Low nibble of second byte, and lowest 2 bytes are the value

d. The decimal point register has to set to: 1, 2, 3, or 4.
2) Bus Format: Bit 5 1/0 = Modbus/Newport

3) Output Scale / Offset Write:

- Due to write single only, two write operation is needed to write scale/offset, and to make it effective it needs to follow with Hard Reset command.
- 4) To configure to Newport protocol, set bit 5 of Bus Format to low and follow with Hard Reset command.

WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.

This device is marked with the international caution symbol. It is important to read the Setup Guide before installing or commissioning this device, as the guide contains important information relating to safety and EMC.

is the policy of NEWPORT to comply with all worldwide safety and EM at apply. NEWPORT is constantly pursuing certification of its products aw Approach Directives. NEWPORT will add the CE mark to every a

a contained in this document is believed to be correct, but NEWPORT accepts no liability for any errors it contains, and reserves the right to alter thout notice

specifications wirrour nouse. PATENT NOTCE: This product is covered by one or more of the following patents: U.S. Pat. No. Des. 336, 885, 5274,577/ Canada 2052599, 2052600/ Italy 1249456, 1250938 France Brevet No. 91 12756/ Spain 2039150, 2048066/ UK Patent No. GB2 249 837, GB2 248 934/ Germany DE 41 34398 C2.

X X NEWPORT NEWPORT (00) newportUS.com and INFINITY are trademarks of

WARRANTY/DISCLAIMER

NEWPORT Electronics, Inc. warrants this unit to be free of defects in materials workmanship for a period of **one** (1) year from the date of purchase. In additi NEWPORT is standard warrantly period, NEWPORT Electronics will extend the war period for **one** (1) additional year if the warranty card enclosed with each instrume terumed to NEWPORT.

relevand to NEWPORT. If the unit antilections, it must be returned to the factory for evaluation. NEWPORTs by the unit antilections, it must be returned to the factory for evaluation. NEWPORTs upon phone or written request Upon sammafor by NEWPORT² of the unit is found to be apply to detects returning from any schematic of the purchases, including but not infined to maintaining, improve and the straining of the straining and any schematic of the straining and pages to detects returned to the survivance and a result of excessive means of the other schematic of the straining and a result of excessive misses or other operating conditions outlied of the straining. Use, and faces we are not oursample, locating but on the locations. Uses, and faces we are not oursample, locating but on the locations to the straining the location and the straining of the location of the interfaces. Uses, and faces we are not oursample, locating but on the locations to the locations that the straining of the locations outlines to contain points. Uses, and faces the location of the location of the locations outlines to contain points.

war are not warranee, including our not intered to contact points, lutes, and table. NEWPORT is pleased to offer suggestions on the use of its various products. However, NEWPORT netther assumes responsibility for any omissions or errors nor assumes liability for any ion appointed to the NEWPORT; either to the lo over without suggestions and the suggestion of the suggestion of the loss of the loss of the loss of the suggestion. NEWPORT warrants only that the parts manufactured by it will be as specified and free of defects.

NEWPORT MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED.

LUMITATION PLABILITY: The remedies of purchaser set forth herein and the total liability of NEWPORT with respect to this order, whe contract, warranty, negligence, indemnification, strict liability or other exceed the purchase price of the component upon which liability is bas shall NEWPORT be liable for consequential, incledental or special damag

shall NEWPORT he liable for consequential, incidental or special damages. CONDITIONS: Experiment and by NEWPORT is no interedued to be used, ori shall is be used. (1) as a "basic Component under 10 CFR 21 (NRC), used in or with any nuclear initialition or activity or (2) in medical applications or used on humans. Should any or humans, or maxwell in any way, NEWPORT assumes not successful as set forth in our basic WARRANT/DISCLAIMER language, and, additionally purchaser with initientemity NEWPORT and hold NEWPORT harmless from any labelity or damage whatsoever artising out of the use of the VISAL (1) in the NEWPORT harmless from any labelity or damage whatsoever artising out of the use of the VISAL (1) in the NEWPORT harmless from any labelity or damage whatsoever artising out of the use of the NEWPORT harmless from any labelity or damage whatsoever artising

| RETORN REQUEST/INQUIRIES |
|--|
| bited all warranty and repair requests/inquiries to the NEWPORT Customer Service learnment. BerCoRE RETLINING ANY PRODUCTIS TO NEWPORT. PURCHASE NUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM NEWPORTS USTOMER SERVICE DEPARTMENT (IN ORDER TO AVIOD PROCESSING ELLAYS) he assigned AR number should then be marked on the outside of the return package and any correspondence. |
| |

NEWPORT's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

NEWPORT is a registered trademark of NEWPORT Electronics, Inc. © Copyright 2004 NEWPORT Electronics, Inc. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of NEWPORT Electronics, Inc.

M2533/N/0304



iDRN-ACV AC Voltage Signal Conditioner

te technical or application a 1-800-6397678° 1-800-NEWPORT

Newport Electronics, Inc. 2229 South Yale Street - Santa Ana, CA - 92704 - U.S.A. TEL: (714) 540-914 - FAX: (203) 988-7311 Toll Free: 1-800-839-7879 - www.newportUS.com -e-mail.info@newportUS.com ISO 9001 Centiled

Newport Technologies, Inc. 976 Bergar - Laval (Quebec) - H7L 5A1 - Canada TEL: (514) 355-3183 - FAX: (514) 856-6886 Toll Free: 1-800-639-7678 - www.newport.ca - e-mail:info@new

Newport Electronics, Ltd. One Omega Drive - River Bend Technology Centre Northbank, Lifam - Manchester M44 SBD - United Kingdom Tei - 44 161 777 6611 - FAX: - 44 161 777 6622 Toll Free: 0800 484 88 - www.newportuk.co.uk - e-mailsaele@gnewpc

Newport Electronics B.V. Postbus 8054 • 1180 LA-Amstelveen - The Netherlan TEL - 312 0 347241 - 16-44 - 312 0 634364 0800 0953344 • www.newport.al - email: info@n Newport Electronics gol # 1.0 Frystatska 154, 733 01 Kanvind - Czech Republic TEL + 402 0 56311890 - FAX-4202 96 331114 TEL + 402 0 56311890 - FAX-4202 96 331141 Old Free: 0800-1-66342 • www.newport.cz • e-mail: info@n

Newport Electronics GmbH Daimienstrasse 26 • 0-75392 Deckenpfronn • Germany TEL: 49 7056 9396-0 • FAX: 49 7056 9398-29 Toll Free: 0800 / 6397678 • www.newport.de • e-mail: sales@new

Newport Electronique S.A.R.L. 11, rue Jacques Cartier • 78280 Guyancourt • France TEL: +33 1 61 37 29 00 • FAX: +33 1 30 57 54 27 e: 0800 466 342 • www.newport.fr • e-mail: sales@ne

Mexico and Latin America FAX: 001 (203) 359-7807 En Español: 001 (203) 359-7803

NEWPORTnet" On-Line Service Internet e-mail www.newportUS.com info@newportUS.com

NEWPORT Electronics, Inc.

The purchaser is responsible for to prevent breakage in transit. FOR <u>WARRANTY</u> RETURNS, REPAIR please consult NEWPORT for current repair BEFORE contacting NEWPORT: available BEFORE contacting FOR NON-WARRANTY have the following informs charges. Have the follow NEWPORT: Purchase Order number to cover the COST of the repair,
 Model and serial number of product, and
 Repair instructions and/or specific problems relative to the product. Purchase Order number under which the product was PURCHASED, Model and serial number of the product under wrench, and Model and serial number of the product under warranty, and Repair instructions and/or specific problems relative to the product.