

speco technologies™

VM-5LCD

OSD Adjustment

1. Press the POWER ON/OFF button on the monitor to turn on the power.
2. Press MENU button on the monitor Keep 3-5secs or remote unit to activate the OSD functions shown on the LCD screen and press again to select the adjustment items as below.

VOLUME
CONTRAST
BRIGHTNESS
COLOR
TINT
U/D NORM/REV(NORMAL/REVERSE)
RESET RST

3. Press UP/DOWN button on the monitor to increase or decrease the value of the adjustment functions for optimum viewing.
4. VIDEO1 / VIDEO2 can use Menu Key to change, when power on.
5. The monitor will auto turn on, when gear happen.

Accessories

Cable
Remote Control Unit
Stand
User's Manual

