


MODERN STEPPER RELAY USING ELECTRONIC SWITCHING CIRCUIT

VS MODULE

VS



· High reliability and efficiency

- Low power requirement
- Short switching times
- Economic and spacesaving
- · Universal application in stepper devices or counters
- · Suitable for most common washing methods except ultrasonic cleaning

Dimensions 18.5 x 3.3 x 6.3 PCB hole dia 0.6

Relay connection - In contrast to connecting between pins 2 and 4 connecting contact K across pins 2 and 3 of the new VS monolithic module (as shown above) ensures reliable switchig even with bouncing signals. On the earlier design of thick film VS module, the contact K had to be connected between pins 2 and 4 in all cases.

Traditional stepper relays maintain their latched position mechanically, but by using the VS switching principle with polarised 2 coil relays this is not required. The already well known operating charac-Switching of the relay using the VS module is achieved as shown in the above diagram. A relay contact is required for the internal circuitry and is thus not available for other switching circuits. This applies to changeover contacts. The VS5-24V Electronic module is suitable for 4V to

30V coil voltage. It withstands temperatures between -55°C to +125°C and can be operated between -20°C and +80°C.

Operation

A logic level of 3.6 V for the logic circuitry is obtained as shown in the block diagram, from the voltage regulator. A relay contact K is connected between pin 2 and the positive terminal 3 of the power supply. On receiving a signal from the output of the schmitt trigger the pulse generator gives a 10 micro second impulse which changes the logical state at input 1 of both AND gates to "high". The logical state of input 2 of gate A is "low" since the relay contact K is open: input 2 of gate B is "high" due to the inverter I depending on the input signals, the output of the AND gate B is driven high and the flip flop F/F is set switching the output \sqrt{Q} high and turning on the transistor Ts.


The relay is then latched by coil L2 and the contact K closes

With contact K now closed and the voltage U applied, the logical state of input 2 goes "high" so that both inputs 2 of the AND gates change state from their previous condition.

(Input 2 of AND gate A goes high and input 2 of AND gate B goes "low"). Simultaneously a 10 microsecond impulse from the pulse generator is fed to the input 1 of both AND gates consequently the output of gate A goes "high" and the output of gate B goes "low". The F/F is reset, the transistor Tr is driven on by output "Q", and the relay coil L1 is energized, opening the contact K.

The maximum output current of the VS module is 100 mA. Thus depending on coil resistance several relays can be controlled by a single VS module.

The more important characteristics of relay types which can be combined with the VS module are described on the rear of this datasheet.



Downloaded from Elcodis.com electronic components distributor

e given contact arrangement can vary; and b contacts can be wired as change- er contacts. pontact configuration: = normaly open = normaly closed = change over "pe mensions: (I x b x h) mm o. of available contacts * ax. make current A ax. continuous current A ax. break voltage V ax. break power W/VA om. power consumption W est voltage: cont./cont./coil V _{rms} ax. switching frequency Hz begiven contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly closed = change over pe mensions: (I x b x h) mm o. of available contacts * ax. make current A ax. switching frequency Hz	$\begin{array}{c c} RG \\ \hline for high frequency application \\ \hline RG2-L2 \\ \hline 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline - \\ \hline 1 \\ \hline 1 \\ \hline 24 \\ 24 \\ \hline 24 \\ \hline 24 \\ \hline 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline \hline 0 \\ \hline$	TQ TF TN TX TQ2-L2 $14 \times 9 \times 5$ 1c 5 2 1 125 $30/62.5$ 0.32 750/1000 100 100 100 000 100 000 100 000 100 000 100 000 100 000 100 000 100 000 100 000 100 000 100 000	DF DF2-L2 16 x 9.9 x 7 1c - 1 1 125 30/30 0.32 500/1000 100 $\frac{+0}{0.00} + \frac{1}{0.00} + \frac{1}{0.0$	DX DX-L2 20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 0.4 500/500 200 ST ST ST ST ST ST 1-/ST2-L2 31 x 14 x 11 1a/1b
rer contacts. Instact configuration: = normaly open = normaly closed = change over pe mensions: (l x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- ter contacts. Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- ter contacts. Dontact configuration: = normaly open = normaly closed = change over rpe mensions: (l x b x h) mm D. of available contacts * ax. make current A ax. break current A ax. break current A ax. break voltage V	$\begin{array}{c c} RG2-L2 \\ 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 1000/2000 \\ \hline \\ 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 0.52 \\ \hline \\ 0.52 \\ \hline 0.52$	TN TQ2-L2 14 x 9 x 5 1c 5 2 1 125 30/62.5 0.32 750/1000 100 100 DSP 125 0.32 0.55 0.32 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55 0.32 0.55	$16 \times 9.9 \times 7$ 1c - 1 1 1 125 30/30 0.32 500/1000 100 100 $t = 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0$	20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 10 0.4 500/500 200 500 500 500 500 500 500
<pre>= normaly open = normaly closed = change over ppe mensions: (1 x b x h) mm o. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V ax. break power W/VA om. power consumption W est voltage: cont./cont./coil V_{rms} ax. switching frequency Hz</pre>	$\begin{array}{c c} RG2-L2 \\ 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 1000/2000 \\ \hline \\ 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 0.52 \\ \hline \\ 0.52 \\ \hline 0.52$	$\begin{array}{c c} TQ2-L2 \\ \hline 14 \times 9 \times 5 \\ \hline 1c \\ 5 \\ 2 \\ \hline 1 \\ 125 \\ 30/62.5 \\ 0.32 \\ \hline 750/1000 \\ \hline 100 \\ \hline \\$	$16 \times 9.9 \times 7$ 1c - 1 1 1 125 30/30 0.32 500/1000 100 100 $t = 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0$	20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 10 0.4 500/500 200 500 500 500 500 500 500
<pre>= normaly closed = change over pe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break current A ax. break voltage V ax. break power W/VA bm. power consumption W ist voltage: cont./cont./coil V_{rms} ax. switching frequency Hz</pre>	$\begin{array}{c c} RG2-L2 \\ 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 1000/2000 \\ \hline \\ 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 0.52 \\ \hline \\ 0.52 \\ \hline 0.52$	$\begin{array}{c c} TQ2-L2 \\ \hline 14 \times 9 \times 5 \\ \hline 1c \\ 5 \\ 2 \\ \hline 1 \\ 125 \\ 30/62.5 \\ 0.32 \\ \hline 750/1000 \\ \hline 100 \\ \hline \\$	$16 \times 9.9 \times 7$ 1c - 1 1 1 125 30/30 0.32 500/1000 100 100 $t = 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0$	20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 10 0.4 500/500 200 500 500 500 500 500 500
= change over pe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break power W/VA pm. power consumption W est voltage: cont./cont./coil Vrms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter contacts. pmeter contacts. pmeter contact configuration: = normaly open = normaly open = normaly closed = change over pe	$\begin{array}{c c} RG2-L2 \\ 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 1000/2000 \\ \hline \\ 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 0.52 \\ \hline \\ 0.52 \\ \hline 0.52$	$\begin{array}{c c} TQ2-L2 \\ \hline 14 \times 9 \times 5 \\ \hline 1c \\ 5 \\ 2 \\ \hline 1 \\ 125 \\ 30/62.5 \\ 0.32 \\ \hline 750/1000 \\ \hline 100 \\ \hline \\$	$16 \times 9.9 \times 7$ 1c - 1 1 1 125 30/30 0.32 500/1000 100 100 $t = 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0$	20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 10 0.4 500/500 200 500 500 500 500 500 500
pe mensions: (I x b x h) mm p. of available contacts * ax. make current A ax. continuous current A ax. break current ax. break current A ax. break current ax. break voltage V ax. break voltage V ax. break voltage V ax. break voltage V ax. break power W/VA pom. power consumption W vst voltage: cont./coil Vms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter contacts. pontact configuration: = = normaly open = = normaly closed = = change over rpe mensions: (I x b x h) mm p. of available contacts * ax. make current ax. continuous current A ax. break current A ax. break voltage V	$\begin{array}{c c} RG2-L2 \\ 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 1000/2000 \\ \hline \\ 50 \\ \hline \\ \hline \\ 0.52 \\ \hline 0.52 \\ \hline \\ 0.52 \\ \hline 0.52$	14 x 9 x 5 1c 5 2 1 125 30/62.5 0.32 750/1000 100 Image: state stat	$16 \times 9.9 \times 7$ 1c - 1 1 1 125 30/30 0.32 500/1000 100 100 $t = 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0$	20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 10 0.4 500/500 200 500 500 500 500 500 500
mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. make current A ax. continuous current A ax. break current A ax. break current A ax. break voltage V v ax. break voltage V ax. break voltage V ax. break voltage V ax. break voltage V w/v ax. break voltage V ax. break power W/VA W/VA w/v pom. power consumption W w w st voltage: cont./coil Vms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter configuration: normaly open = normaly open = normaly open = normaly open pontact configuration: = normaly closed = change over rpe mm p. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V W M	$\begin{array}{c c} 25 \times 23 \times 9.9 \\ \hline 1c \\ \hline - \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ \hline 1000/2000 \\ \hline 50 \\ \hline 0 \\ $	14 x 9 x 5 1c 5 2 1 125 30/62.5 0.32 750/1000 100 Image: state stat	$16 \times 9.9 \times 7$ 1c - 1 1 1 125 30/30 0.32 500/1000 100 100 $t = 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0 + 0$	20 x 12 x 6 1c 3 2 1 220 30/50 0.4 500/500 200 10 0.4 500/500 200 500 500 500 500 500 500
Defending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter contact arrangement can vary; and b contact scan be wired as change-ter contact arrangement can vary; and b contact scan be wired as change-ter contacts. Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter contacts. Dentation: = normaly open = normaly closed = change over type mensions: (I x b x h) m D. of available contacts * ax. continuous current A ax. break current A ax. break voltage V ax. break voltage V	$\begin{array}{c c} 1c \\ - \\ 1 \\ 1 \\ 24 \\ 24 \\ 0.52 \\ 1000/2000 \\ \hline 50 \\ \hline 0 $	1c 5 2 1 125 30/62.5 0.32 750/1000 100 100 100 100 100 100 100 0.32 750/1000 100 0.32 0.32 0.32 0.32 0.32 0.32 0.32 0.32 0.32 0.32 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 0.5 10.5 12 18 26	$ \begin{array}{c} 1c \\ \\ 1 \\ 1 \\ 125 \\ 30/30 \\ 0.32 \\ 500/1000 \\ 100 \\ \hline $	1c 3 2 1 220 30/50 0.4 500/500 200 0.4 500/500 200 500/500 5
ax. make current A ax. continuous current A ax. break current A ax. break voltage V ax. break voltage V ax. break power W/VA pm. power consumption W st voltage: cont./cont./coil Vrms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter contacts. pontact configuration: = normaly open = normaly closed = change over rpe mensions: (I x b x h) mm p. of available contacts * ax. continuous current A ax. break current A ax. break voltage V	$\begin{array}{c c} & - & \\ & 1 \\ & 1 \\ & 24 \\ & 24 \\ & 0.52 \\ \hline 1000/2000 \\ & 50 \\ \hline & & & & \\ \hline & & & & \\ \hline & & & & & \\ \hline & & & &$	5 2 1 125 30/62.5 0.32 750/1000 100 100 0 0 0 0 0 0 0 0 0 0 0 0	$S \\ S \\$	3 2 1 220 30/50 0.4 500/500 200 ••••••• ••••••• •••••••• ••••••••
ax. continuous current A ax. break current A ax. break voltage V ax. break voltage V ax. break power W/VA om. power consumption W st voltage: cont./cont./coil Vrms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- ter contacts. ontact configuration: = normaly open = normaly open = normaly closed = change over rpe .o. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	2 1 125 30/62.5 0.32 750/1000 100 100 0 0 0 0 0 0 0 0 0 0 0 0	1 1 125 30/30 0.32 500/1000 100 $t \to 0^{-}$ $t \to$	2 1 220 30/50 0.4 500/500 200 0.4 500/500 200 500/500 500/500 200 500/5
ax. break current A ax. break voltage V ax. break power W/VA om. power consumption W sst voltage: cont./cont./coil Vrms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change-ter contacts. Depending on the switching configuration, e normaly open = normaly open = normaly closed = change over rpe mensions: (I x b x h) mm o. of available contacts * ax. make current ax. continuous current A ax. break current A ax. break voltage V	$ \begin{array}{c} 1 \\ 24 \\ 24 \\ 0.52 \\ 1000/2000 \\ 50 \\ \hline 0 & 0 & 0 & 0 \\ \hline 0 & 0 & 0 & 0 & 0 \\ \hline $	1 125 30/62.5 0.32 750/1000 100 100 DSP DSP DSP DSP 11 x 10.5 1a 18 26	$S = \frac{52/53/54-L2}{28.4 \times 12.5 \times 10.2}$	1 220 30/50 0.4 500/500 200 + 0 0 - 1 0 0 0 0 0 200 ST 500/500 200 ST 500/500 200 ST 500/500 200
ax. break voltage V ax. break power W/VA om. power consumption W sst voltage: cont./cont./coil Vrms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- ter contacts. contact configuration: = normaly open = normaly closed = change over rpe .o. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break current A ax. break voltage	$\begin{array}{c c} 24 \\ 24 \\ 0.52 \\ 1000/2000 \\ \hline 50 \\ \hline \\ $	125 30/62.5 0.32 750/1000 100 Image: constraint of the second sec	$S = \frac{52/53/54-L2}{28.4 \times 12.5 \times 10.2}$	220 30/50 0.4 500/500 200 0 0 0 0 0 0 0 0 0 0 0 0
ax. break power W/VA pm. power consumption W pm. power consumption W pst voltage: cont./cont./coil V _{rms} ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- rer contacts. pntact configuration: = normaly open = normaly closed = change over ppe mensions: (I x b x h) mm p. of available contacts * ax. make current A ax. noreak current A ax. break current A ax. break voltage V	24 0.52 1000/2000 50 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	30/62.5 0.32 750/1000 100 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	30/30 0.32 500/1000 100 S S S S S S S S S S S S S S S	30/50 0.4 500/500 200 +0 0 - i 0
Depending on the switching configuration, ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontacts can be wired as change- e normaly open = normaly open = normaly closed = change over pe mensions: (I x b x h) of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	0.52 1000/2000 50 + 0 0	0.32 750/1000 100 DSP DSP DSP 12 20.2 x 11 x 10.5 1a 18 26	0.32 500/1000 100	0.4 500/500 200
Instruction Vrms ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- rer contacts. and b contacts can be wired as change- rer contacts. and b contacts can be wired as change- rer contacts. and b contacts can be wired as change- rer contacts. and b contacts can be wired as change- rer contacts. and b contacts can be wired as change- rer contacts. and b contacts can be wired as change- rer contacts. and open and open and open contage over pe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	1000/2000 50 + 0 0 - 1000/2000 50 + 0 0 - 1000/2000 0	750/1000 100 DSP DSP USP1-L2 20.2 x 11 x 10.5 1a 18 26	500/1000 100 100 S S S S S S S S S S S S S	500/500 200 +0 0- 0
ax. switching frequency Hz Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- rer contacts. ontact configuration: = normaly open = normaly closed = change over	50 + 0 0 - 10 0 0 0 5 0 0 0 0 0 7 0 0 0 0 0 0 0 7 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	100 100 100 100 100 100 100 100	100 100 S S S S S S S S S S S S S	200 +0 0- 10 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Depending on the switching configuration, e given contact arrangement can vary; and b contacts can be wired as change- rer contacts. = normaly open = normaly closed = change over pe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS DS DS DS DS DS DS DS	DSP 20.2 x 11 x 10.5 18 26	S S S S S S S S S S S S S S	ST
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS 20/35.2 × 9.9 × 9.3 1c/3c 8 3	DSP DSP DSP DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S S S S S S S S S S S S S S	ST ST ST ST ST ST 1 ST ST ST ST ST ST ST ST ST ST
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP DSP DSP DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S S S S S S S S S S S S S S	ST ST ST ST ST ST 1 ST ST ST ST ST ST ST ST ST ST
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP DSP DSP DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S S S S S S S S S S S S S S	ST ST ST ST ST ST 1 ST ST ST ST ST ST ST ST ST ST
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS DS DS DS DS DS DS DS	DSP DSP DSP DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S S S S S S S S S S S S S S	ST ST ST ST ST1-/ST2-L2 31 x 14 x 11 1a/1b
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	s2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST ST ST ST ST ST ST ST ST ST
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	s2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST ST ST1-/ST2-L2 31 x 14 x 11 1a/1b
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	s2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST ST ST1-/ST2-L2 31 x 14 x 11 1a/1b
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST ST ST1-/ST2-L2 31 x 14 x 11 1a/1b
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS DS DS2-/DS4-L2 20/35.2 x 9.9 x 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST1-/ST2-L2 31 x 14 x 11 1a/1b
e given contact arrangement can vary; and b contacts can be wired as change- er contacts. ontact configuration: = normaly open = normaly closed = change over pe mensions: (I x b x h) mm 0. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS2-/DS4-L2 20/35.2 × 9.9 × 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST1-/ST2-L2 31 x 14 x 11 1a/1b
and b contacts can be wired as change- er contacts. = normaly open = normaly closed = change over 'pe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	DS2-/DS4-L2 20/35.2 × 9.9 × 9.3 1c/3c 8 3	DSP1-L2 20.2 x 11 x 10.5 1a 18 26	S2-/S3-/S4-L2 28.4 x 12.5 x 10.2 2a1b/3a/1a2b	ST1-/ST2-L2 31 x 14 x 11 1a/1b
rer contacts. pntact configuration: = normaly open = normaly closed = change over rpe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	20/35.2 x 9.9 x 9.3 1c/3c 8 3	20.2 x 11 x 10.5 1a 18 26	28.4 x 12.5 x 10.2 2a1b/3a/1a2b	31 x 14 x 11 1a/1b
ontact configuration: = normaly open = normaly closed = change over pe mensions: (l x b x h) mm o. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	20/35.2 x 9.9 x 9.3 1c/3c 8 3	20.2 x 11 x 10.5 1a 18 26	28.4 x 12.5 x 10.2 2a1b/3a/1a2b	31 x 14 x 11 1a/1b
= normaly open = normaly closed = change over pe mensions: (I x b x h) mm o. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	20/35.2 x 9.9 x 9.3 1c/3c 8 3	20.2 x 11 x 10.5 1a 18 26	28.4 x 12.5 x 10.2 2a1b/3a/1a2b	31 x 14 x 11 1a/1b
= normaly closed = change over pe mensions: (I x b x h) mm o. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	20/35.2 x 9.9 x 9.3 1c/3c 8 3	20.2 x 11 x 10.5 1a 18 26	28.4 x 12.5 x 10.2 2a1b/3a/1a2b	31 x 14 x 11 1a/1b
pe mensions: (I x b x h) mm b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	20/35.2 x 9.9 x 9.3 1c/3c 8 3	20.2 x 11 x 10.5 1a 18 26	28.4 x 12.5 x 10.2 2a1b/3a/1a2b	31 x 14 x 11 1a/1b
mensions: (I x b x h) mm b. of available contacts * ax. ax. make current A ax. continuous current A ax. break current A ax. break voltage V	20/35.2 x 9.9 x 9.3 1c/3c 8 3	20.2 x 11 x 10.5 1a 18 26	28.4 x 12.5 x 10.2 2a1b/3a/1a2b	31 x 14 x 11 1a/1b
b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	1c/3c 8 3	1a 18 26	2a1b/3a/1a2b	1a/1b
b. of available contacts * ax. make current A ax. continuous current A ax. break current A ax. break voltage V	8 3	18 26		
ax. make current A ax. continuous current A ax. break current A ax. break voltage V	8 3	18 26		
ax. continuous current A ax. break current A ax. break voltage V	3			50/35
ax. break current A ax. break voltage V			5	8
ax. break voltage V	2	5 5	5	8
	250	380	250	250
ax. break power W/VA	60/125	150/1250	100/1000	150/2000
ax. break power W/VA	0.48	0.42	0.32	0.345
	1000/1500	1000/3000	750/1500	0.345
	1000/1500	50	50	50
ax. switching frequency Hz	100	00	50	
	+ Q Q -		+ 0 0-	+ Q Q -
		+ 0 0-		
		19 9 9 9 95	[199995	100005
	9 16 12 14			
			↓]	
	8 1 3 5			
	DS2-L2 DS4-L2		/	L8
Depending on the switching configuration,	DK	SP		
e given contact arrangement can vary; and b contacts can be wired as change-				
er contacts.	****	North P		
ontact configuration:				
= normaly open				
= normaly closed = change over	Ŧ			
	DV/4-45-LO			
	DK1a1b-L2	SP2-L2 SP4-L2		
mensions: (l x b x h) mm	20 x 12.5 x 9.7	50x25.6x20.5 50x36.8x20.5		
o. of available contacts *	1a	1c 3c		
ax. make current A	-	70 50		
ax. continuous current A	8	16 10		
ax. break current A	8	16 10		
ax. break voltage V	380	250		
ax. break power W/VA	240/2000	300/4000 300/2500		
om. power consumption W	0.32	0.42		
est voltage: cont./coil V _{rms}	1000/4000	1500/3000		
ax. switching frequency Hz	50	10		
······································		+ Q Q -		
	+ ο -			
		19 9 9 9 55		
		1 5 6 7 3		

Downloaded from $\underline{\text{Elcodis.com}}$ electronic components distributor