

5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 

### DESCRIPTION

The LXMG1811-05-6xS is a Single Output 6W CCFL (Cold Cathode extend the life of the display and save Fluorescent Lamp) Inverter Module power (particularly important for battery designed for the driving LCD backlight powered products). lamps for panels in the range of 3.9" to needing full manual control of lamp 15".

capabilities of the Microsemi's highly not offer the light sensor input. integrated LX6512 CCFL backlight controller the inverter allows a wider lamp inverter is externally programmable over output voltage range 280V to 730V a range of 4mA to 7mA in 1mA steps to compared to Microsemi's existing Direct allow the inverter to properly match Drive<sup>™</sup> inverter solutions.

additional input connector which links the higher input voltage requirements the inverter to a light sensor board (the LXMG1813-12-6x or -6xS will work LXMG1800 LS). inverter is capable of automatically adjusting (VEasyLIT<sup>TM</sup>) the brightness of topology include stable fixed-frequency the LCD display to ambient lighting operation, secondary-side strike voltage conditions.

IMPORTANT: For the most current data, consult MICROSEMI's website: http://www.microsemi.com Protected by U.S. Patents: 5,923, 129; 5,930,121; 6,198,234; Patents Pending

Automatic brightness control can For applications brightness (dimming) we recommend the Utilizing the full-bridge drive topology LXMG1811-05-6x (non-S), which does

The maximum output current of the (PanelMatch<sup>TM</sup>) to a wide array of LCD Also this 'S' version includes an panel lamp current specifications. For So connected the from a 9V to 16V input supply.

> Other benefits of the inverter's regulation and both open/shorted lamp protection with fault timeout.

## **KEY FEATURES**


- Automatic Lamp Dimming Using External LXMG1800 LS Light Sensor Board Assembly
- Externally Programmable Maximum Output Current
- Wide Lamp Voltage Range
- Fixed Frequency Operation
- **Output Short-Circuit Protection** and Automatic Strike-Voltage Regulation and Timeout RangeMAX Wide Range
- Dimming (50:1+) Rated From -30°C to 80°C
- UL60950 Pending
- **RoHS** Compliant

#### APPLICATIONS

- Medical Instrument Displays
- Portable Instrumentation
- Desktop Displays
- Industrial Display Controls

#### BENEFITS

- Smooth, Flicker Free Full-Range Brightness Control
- Programmable Output Current Allows Inverter to Mate with a Wide Variety of LCD Panel's Specifications



Copyright © 2008 Rev 1.0, 2008-11-14

#### Microsemi Analog Mixed Signal Group

11861 Western Avenue, Garden Grove, CA. 92841, 800-877-6458, 714-898-8121, Fax: 714-893-2570

XMG1811-05-6xS



5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 

#### ABSOLUTE MAXIMUM RATINGS

Input Signal Voltage (V <sub>IN</sub> )	-0.3V to 6V
Input Power	
Output Voltage, no load	
Output Current	
Output Power	
Input Signal Voltage (SLEEP Input)	-0.3V to V <sub>IN</sub>
Input Signal Voltage (ALS_IN)	-0.3V to 5.5V
Analog Output (ALS VCC external load current)	
Ambient Operating Temperature, zero airflow	
Storage Temperature Range	

Note: Exceeding these ratings could cause damage to the device. All voltages are with respect to Ground. Currents are positive into, negative out of specified terminal.

#### **RECOMMENDED OPERATING CONDITIONS (R.C.)**

This module has been designed to operate over a wide range of input and output conditions. However, best efficiency and performance will be obtained if the module is operated under the condition listed in the 'R.C.' column. Min. and Max. columns indicate values beyond which the inverter, although operational, may not function optimally.

Parameter	Symbol	Recomme	Units		
i arameter	Cymbol	Min	R.C.	Max	Onits
Input Supply Voltage Range (Fully Regulated Lamp Current)	V <sub>IN</sub>	4.75	5.0	5.25	V
Input Supply Voltage Range (Functional)		4.5	5.0	5.5	
Output Power	Po		4.2	6.0	W
Lamp Operating Voltage	VLAMP	280	500	730	V <sub>RMS</sub>
Lamp Current (Full Brightness)	I <sub>O(LAMP)</sub>	4.0		7.0	mA <sub>RMS</sub>
Operating Ambient Temperature Range	T <sub>A</sub>	-30		80	°C

#### ELECTRICAL CHARACTERISTICS

The following specifications apply over the recommended operating condition and ambient temperature of 0°C to 60°C except where otherwise noted;  $ALS_{IN} \ge 2.75V$ ,  $\overline{SLEEP} \ge 2.1V$ ,  $V_{IN} = 5V$ .

Parameter	Symbol	Test Conditions	LXMG1811-05-6xS			Units	
Falalletei	Symbol	bol lest collutions		Тур	Max		
OUTPUT PIN CHARACTERISTICS							
Full Lamp Current	I <sub>L(MAX)</sub>	$SET_1 = Ground, SET_2 = Ground$	3.5	4.0	4.5	mA <sub>RMS</sub>	
Full Lamp Current	I <sub>L(MAX)</sub>	$SET_1 = Ground, SET_2 = Open$	4.5	5.0	5.5	mA <sub>RMS</sub>	
Full Lamp Current	I <sub>L(MAX)</sub>	$SET_1 = Open, SET_2 = Ground$	5.4	6.0	6.6	mA <sub>RMS</sub>	
Full Lamp Current	I <sub>L(MAX)</sub>	SET <sub>1</sub> = Open, SET <sub>2</sub> = Open	6.3	7.0	7.7	mA <sub>RMS</sub>	
Full Lamp Current	I <sub>L(MAX)</sub>	$V_{IN}$ = 4.5 to 5.5V; SET <sub>1</sub> = Open, SET <sub>2</sub> = Ground	5.3	6.0	6.7	mA <sub>RMS</sub>	
Min. Average Lamp Current	I <sub>L(MIN)</sub>	$\label{eq:alsolution} \begin{array}{l} ALS\_IN \leq 0.9V,  SET_1 = SET_2 = Ground,  V_{BRT\_ADJ} \\ floating;  I_{L(MIN)} = I_L^{\star}  \sqrt{(Min  Duty  Ratio)} \end{array}$		1.0		mA <sub>RMS</sub>	
Lamp Start Voltage	V <sub>LS</sub>	-30°C < T <sub>A</sub> < 80°C, V <sub>IN</sub> ≥ 4.5V	1400	1650		V <sub>RMS</sub>	
Operating Frequency	f <sub>o</sub>		47.7	53	58.3	kHz	
Burst Frequency	f <sub>BURST</sub>	Output Burst Frequency	173	206	239	Hz	

Copyright © 2008 Rev 1.0, 2008-11-14

Downloaded from Elcodis.com electronic components distributor

ELECTRICALS



5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 

otherwise noted; $ALS_IN \ge 2.75V$ , $\overline{SLE}$		Test Conditions	LXMG1811-05-6xS			Units
Parameter	Symbol	Test Collditions	Min	Тур	Max	Units
BRITE INPUT						
Potentiometer Max Impedance	BRT <sub>POT</sub>	Full Lamp Current	400	500		kΩ
Potentiometer Min Impedance	DICTPOT	Minimum Lamp Current		0		kΩ
SLEEP BAR INPUT						
RUN Mode	V		2.1		VIN	V
SLEEP Mode	V		0		0.8	V
SET <sub>1,2</sub> INPUT						
SET <sub>1,2</sub> Low Threshold	VL			0		V
Input Current	I <sub>SET</sub>	V <sub>SETx</sub> = 0V		-400		μA
ALS (AMBIENT LIGHT SENSOR)						
ALS_VCC	ALS <sub>VCC</sub>	I <sub>LOAD</sub> = 3mA	4.5		5.5	V
POWER CHARACTERISTICS						
Sleep Current	I <sub>IN(MIN)</sub>	SLEEP ≤ 0.8V		10	20	μA
Run Current	I <sub>RUN</sub>	SET <sub>1</sub> = Open SET <sub>2</sub> = Ground, $V_{LAMP}$ = 500 $V_{RMS}$		750		mA
Strike (Open Lamp)	T <sub>S_DWELL</sub>		1.0	1.4	2.0	Sec
Supply Current under Fault condition	I <sub>FAULT</sub>	Fault condition		5		mA
Typical Efficiency	η	SET <sub>1</sub> = Open SET <sub>2</sub> = Ground, $V_{LAMP}$ = 500V <sub>RMS</sub>	75	80		%

CONN

#### FUNCTIONAL PIN DESCRIPTION

DESCRIPTION

N1 (Molex 8	53261-0871 or e	quivalent) mates with 51021-0800 housing, 50079-8100 pins. Mates with LX9501G input cable assembly			
CN1-1	V <sub>IN</sub>	Main Input Power Supply 4.75V $\leq$ V <sub>IN</sub> $\leq$ 5.25V (Functional 4.5V to 5.5V)			
CN1-2	♥ IN	$\frac{1}{10000000000000000000000000000000000$			
CN1-3	GND	Power Supply Return			
CN1-4	OND				
CN1-5	SLEEP	ON/OFF Control. (0V $\leq \overline{\text{SLEEP}} \leq 0.8$ V = OFF, $\overline{\text{SLEEP}} \geq 2.1$ V = ON			
CN1-6	BRITE	Can be left open or connected to a 500k potentiometer to reduce brightness when the LX1800_LS is connected. It is not recommended as brightness control voltage input.			
CN1-7	SET <sub>1</sub>	SET <sub>1</sub> MSB Connecting this pin to ground decreases the output current (see Table 1)			
CN1-8	SET <sub>2</sub>	SET <sub>2</sub> LSB Connecting this pin to ground decreases the output current (see Table 1)			
N2 (Molex 8	53261-0371 or e	quivalent) mates with 51021-0800 housing, 50079-8100 pins. Mates with LXMG1800_LS ALS Assembly			
CN2-1	ALS_VCC	Nominal 5V Supply for ALS Board Assembly. 3mA maximum output load			
CN2-2	ALS_IN	Brightness Control Voltage input from light sensor board.			
CN2-3 ASL_GND ALS Board Power Supply Return.					

Copyright © 2008 Rev 1.0, 2008-11-14

#### **Microsemi** Analog Mixed Signal Group

Page 3

ELECTRICALS

11861 Western Avenue, Garden Grove, CA. 92841, 800-877-6458, 714-898-8121, Fax: 714-893-2570

ΡιΝ



5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 


	FUNCTIONAL PIN DESCRIPTION						
CONN	CONN PIN DESCRIPTION						
CN3 for LXN	CN3 for LXMG1811-05-61S and -62S (JST SM02(8.0)B-BHS-1-TB(LF)(SN) ; Yeon Ho 20015WR-05A00, SM02B-BHSS-1-TB(LF)(SN) ; Yeon Ho 35001WR-02A00) or equivalent						
CN3-1 V <sub>HI</sub> High voltage connection to high side of lamp. Connect to lamp terminal with shortest lead length. <b>DO NOT</b> connect to Ground.							
CN3-2 V <sub>LO</sub> Connection to low side of lamp. Connect to lamp terminal with longer lead length.   DO NOT connect to Ground Do NOT							

### TABLE 1

SET₁ (Pin 7)	SET <sub>2</sub> (Pin 8)	Nominal Output Current
Open*	Open*	7.0mA
Open*	Ground	6.0mA
Ground	Open*	5.0mA
Ground	Ground	4.0mA

**OUTPUT CURRENT SETTINGS** 

\* If driven by a logic signal it should be open collector or open drain only, not a voltage source.




www.Microsemi.com



5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 


# SIMPLIFIED BLOCK DIAGRAM



#### VeasyLIT™ LXMG1800\_LS APPLICATION

Key LXMG1800\_LS Features

Small Size 9.5 x 31 x 2.5 mm Flush Mount on Sensor Side Board is Powered by Inverter User Customizable Light Gain Human Eye Light Response Flexible Mounting Location




www.Microsemi.com



5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 

#### TYPICAL APPLICATION



- It is recommended to use LXMG1811-05-6xS only with the LXMG1800\_LS external light sensor assembly. A 500k potentiometer may be added to the inverter's BRITE input pin to allow a degree of manual override to the light sensor. Adjustment of the potentiometer will only dim the display further; it cannot increase the maximum brightness level set by the light sensor. If full manual control of dimming is required by the application we recommend the use of the LXMG1811-05-6x (non-S) version.
- If you need to turn the inverter ON/OFF remotely, connect to TTL logic signal to the SLEEP input.
- Connect V<sub>HI</sub> to high voltage wire from the lamp. Connect V<sub>LO</sub> to the low voltage wire (wire with thinner insulation). Never connect V<sub>LO</sub> to circuit ground as this will defeat lamp current regulation. If both lamp wires have heavy high voltage insulation, connect the longest wire to V<sub>LO</sub>. This wire is typically white.
- Use the SET<sub>1</sub> and SET<sub>2</sub> (see Figure 2) inputs to select the desired maximum output current. Using these two pins in combination allows the inverter to match a wide variety of panels from different manufacturers. Generally the best lamp lifetime correlates with driving the CCFL at the manufacture's nominal current setting. However the SET<sub>1</sub> and SET<sub>2</sub> inputs allow the user the flexibility to adjust the current to the maximum allowable output current to increase panel brightness at the expense of some reduced lamp life.
- Although the SET pins are designed such that just leaving them open or grounding them is all that is needed to set the output current, they can also be actively set. Using an open collector or open drain logic signal will allow you to reduce the lamp current for situations where greater dim range is required. Since the dim ratio is a factor of both the burst duty cycle and the peak output current, using this technique the effective dim ratio can be increased greater than the burst duty cycle alone. Conversely, the SET inputs could be used to overdrive the lamp temporarily to facilitate faster lamp warm up at initial lamp turn on. Of course any possible degradation on lamp life from such practices is the user's responsibility since not all lamps are designed to be overdriven.
- The inverter has a built-in fault timeout function. If the output is open (lamp disconnected or broken) or shorted the inverter will attempt to strike the lamp up to about two seconds, after which (without success) the inverter will shutdown. In this mode the inverter will draw about 5mA from VIN. In order to restart the inverter it is necessary to toggle the sleep input or cycle the V<sub>IN</sub> input supply.

APPLICATION



5V 6W CCFL Programmable Inverter Module

**PRODUCTION DATASHEET** 

#### NOTES

www.Microsemi.com

PRODUCTION DATA – Information contained in this document is proprietary to Microsemi and is current as of publication date. This document may not be modified in any way without the express written consent of Microsemi. Product processing does not necessarily include testing of all parameters. Microsemi reserves the right to change the configuration and performance of the product and to discontinue product at any time