



USA OFFICE Suite 202 364 Pennsylvania Avenue, Glen Ellyn Illinois 60137 USA Tel +1 (630) 469 2981

UK OFFICE 14 Bentinck Court Bentinck Road West Drayton UB7 7RQ ENGLAND Tel +44 (1895) 431421

www.keymat.com

email: sales@keymat.com

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 1 of 16



Section 1. Table of Contents

Section

<u>Page</u>

| Section 1. Overview of Product Range | 3 |
|---|---|
| Section 2. Options | 4 |
| Section 3. Ratings and Performance , ADA Compliance | 5 |
| Section 4. Connectors and Connections | 7 |
| Matrix Keypad | |
| PS2 / USB Encoded Keypad | |
| PS2 / USB Cable Pinout | |

Section 5. Configuration / Installation

| | Final Assembly of Encryption Ready Keypad | 9 |
|------------|---|----|
| | Installation | 10 |
| | Part Numbering Scheme | 11 |
| | Ordering Details | 12 |
| Appendix 1 | Layouts | |
| Appendix 2 | Panel Cutouts and Mounting Details | |
| Appendix 3 | Code Tables | |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 2 of 16



Section 2. Product Overview

Key Features / Specifications

- Rugged, reliable and responsive data entry
- Vandal Resistant (20J BS EN 60068-2-75: 1997)
- Weather Resistant (IP65)
- Large buttons for clarity and ease of use
- Permanent, high contrast, laser engraved keytop graphics
- Raised tactile symbols on coloured function keys
- Raised "home pip" on the "5" key
- 4 Row x 4 Column matrix circuit format
- Optional USB or PS2 encoded interface circuit (enclosed in water resistant pod)
- Optional PS2 or USB connection cable (supplied separately)
- Optional RS232 plug in module (supplied separately)
- Suitable for use by those with mobility or sensory impairment
- Overall dimensions: 124.0 mm x 118.5 mm x 17.5 mm (excluding interface pod on back face)
- UL approved

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.



Section 2. Options

| | Matrix Output | PS2 / USB Output | "Encryption Ready" |
|---|--------------------|---------------------------|--------------------|
| <u>Build Style</u> Vandal Resistant (stainless steel top plate) | | | |
| <u>Keytops</u> Black Keytops laser marked white Coloured Function Keys laser marked with black text | | √ √ | √ √ |
| Keypad Circuit Matrix Output | V | _ | |
| PS2 / USB Selectable En- coder Non-Encoded Keypad su- plied with empty circuit pod (pod lid not fitted) | | | |
| <u>Layout</u> UK Layout | | \checkmark | |
| USA Layout | \checkmark | \checkmark | |
| Customer Specified | | | |
| <u>Accessories</u> Cable with PS2 terminator Cable with USB terminator | : | | |
| Underpanel Mounting Clips | | | |
| Key : Available as standa | ard 🗹 Available as | an option 🗌 Not Available | • |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 4 of 16



Section 3. Ratings and Performance

The 6000 Series keypad range is designed to meet the following requirements. Validation is by in-house test and additional third party assessment by an accredited test house, where appropriate. Storm 6000 Series keypads are a UL Recognized Component.

| | Matrix Keypad | PS2/USB Keypad | REFERENCE | RELATED BASIC STANDARD OR TEST METHOD |
|---------------------------------|--|--|---|--|
| Electrical | | | | |
| EMC Emissions | N/A | | EN55022 : 1998 Class B Limit | * |
| | | | FCC CFR 47 Part 15 Class B | * |
| EMC Immunity to ESD | N/A | | EN55024 : 1998 | EN 61000-4-2 :1995 * ± 8kV Air ± 4kV Contact |
| EMC Immunity to Radiated Fields | N/A | | EN55024 : 1998 | EN61000-4-3 :1996 * |
| Electrical Safety | | | EN60950, UL60950 UL Recognized Component E230121 | |
| Communication | | Industry Stan- dard PS2 or USB Interface | | |
| Supply requirements – Voltage | | + 5V nominal (5.5 V to 4.75 V) | | |
| Supply requirements – Current | | 20mA | | |
| Key Switch Rating | +24V dc MAX | | | |
| Anti Tamper Circuit Rating | 50mA MAX +24V dc MAX 10mA MAX <500 Ohms (NORMALLY CLOSED) | | | |
| Environmental | OLOGED) | | | |
| Sealing – Water / Particulates | | | EN60529 (sealing to IP65) | |
| Temperature | | | -20 °C to + 60 °C operating (dry) | |
| Mechanical | | | | |
| Impact resistance | | | 20 Joules via 50mm dia steel striker | |
| Key pitch | | | 20 mm General | |
| Size | | | 15 mm square | |
| Travel | | | 1.5mm nominal | |
| Actuation force | | | 130g nominal | |

| Keytops UL94 HB |
|-------------------|
| Moulding UL94 V-0 |
| PCB UL94 V-0 |
| Actuators UL94 HB |
| |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, revision ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 5 of 16



The 6000 Series keypad range is designed to meet the requirements of existing and forthcoming Disability Access Requirements.

As international standards requirements are many and varied (although with some common themes for ATM Keypads), we have chosen the ADAAG requirements to illustrate compliance in the table below

| | ADAAG Pt 707.4 | 6000 Series Keypad USA Layout |
|-----------------------------------|--|---|
| | Requirements for ATM Keypads | |
| Key Characteristics | Key surfaces shall be raised above the surrounding surface by 1/25 inch (1 mm) mini- mum. | Key surfaces are raised above the surrounding surface by 3mm |
| | The outer edge of key surfaces shall have a radius of 1/50 inch (0.5 mm) maximum. | Corner radii are 0.5mm |
| Keypad Layout General | 707.4.4.1 Arrangement. Numeric keys shall be arranged in a 12-key telephone keypad layout with the number one key in the upper left hand corner. | Telephone Layout is used |
| | 707.4.4.2 Marking. The number five key shall have a single raised dot. | Number 5 key has a single raised feature. |
| Key Separation | Any key surface shall be separated from other key surfaces by 1/8 inch (3.2 mm) mini- mum. | Minimum separation is 5mm |
| Separation from Function Keys | Function keys shall be separated from numeric keys by a distance that is not less than three times greater the distance between the numeric keys. | Separation to function keys is 15mm |
| Function Keys General | 707.4.5.1 Arrangement. Function keys shall be arranged in the order of enter, clear, can- cel, add value and decrease value horizontally from left to right or vertically from top to bottom. Where provided, add value and decrease value function keys shall be grouped with other function keys. | Order of function keys is Enter Clear Cancel |
| Function Keys Tactile Markings | 707.4.5.2 Marking. Function keys shall be marked with tactile characters as follows: Enter or proceed key: raised circle; Clear or correct key: raised vertical line or bar; Cancel key: raised x; Add value key: raised plus sign; Decrease value key: raised minus sign. | Markings are Compliant (NB Add Value / Decrease Value not part of this layout) |
| Function Keys Colours | 707.4.5.3 Colour Coding. Where function keys are colour coded, they shall be coloured as follows Cancel key: red;: Clear or correct key: black; | All these colours are available. This layout has:- Cancel : Red Clear : Yellow |
| | Enter or proceed key: green; Add value key: blue; Decrease value key: yellow. | Enter : Green (NB Canadian / European stds re- quire Yellow for the Clear key, how- ever layouts including Black key with raised Vertical bar is available to special order) |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is ubject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd.


6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 6 of 16



Section 4. Connectors and Connections - Matrix Output

The 6000 Series matrix keypad is supplied without a cable so that the user can select the correct cable length. Switches provide a momentary contact between designated connector pins. Pins are to suit Molex KK Type 0.1" Pitch Headers. The Connector Details below shows the orientation and position of the connector.


If RS232 output is required then the Storm 420 Series Encoder may be purchased separately - this plugs in directly to the rear of the keypad.



REAR VIEW with Storm 420 Series Encoder fitted

| Installation Checklist - Keypad plus RS232 |
|---|
| ✓Keypad ✓Encoder, configuration switch set ✓Panel Fixing prepared ✓+5V regulated supply ✓RS 232 cable with 6 way Molex KK socket ✓13 way ribbon cable keypad to encoder if encoder is to be remote from keypad ✓Polarising pins fitted to encoder |





| ANTI-TAMPER CIRCUIT CONTACT OPERATING VOLTAGE 24V dc (max) OPERATING CURRENT 10mA (max) CIRCUIT RESISTANCE <500 Ohms (normally closed) |
|---|
|---|

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 7 of 16



Section 4. Connectors and Connections - PS2/USB Output


The 6000 Series encoded keypad is supplied without a cable so that the user can select the correct cable length and connector type to suit their application. Cables are offered as separately purchased options, or alternatively the user can source their own cable to suit the application. The pinout details for the connectors are shown on the following page.

Option 1 PS2 Minidin connector, straight cable, 2.5 metres long Option 2 USB connector, straight cable, 2.5 metres long

Fitting Cables

WARNING : THE FOLLOWING MUST BE DONE IN AN ESSD SAFE HANDLING AREA

In order to fit the cable, the pod cover on the back of the keypad must be removed. Plug the molex connector into the connector designated JP1 on the encoder pcb. Connect the earth tag to the securing nut and tighten. Set the positions of the USB / PS2 selector switches (see table below). Note that SW2 toggles the function key output codes between USA layout and UK layout. Ensure the grommet is correctly located into the slot in the pod; this provides strain relief and sealing. Close the pod cover.




| SWITCH SETTINGS | SW1 | SW2 | SW3 |
|-----------------|------|-------------------|------|
| ON | USB | FUNCTION KEYS UK | USB |
| OFF | PS/2 | FUNCTION KEYS USA | PS/2 |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 8 of 16



Section 4. Connectors and Connections -PS2/USB Cable



This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.


6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 9 of 16



Section 5. Fitting Encryption Device (PCB) to "Encyption Ready" Keypad

"Encryption Ready" Keypads are supplied with a separate kit comprising a pod housing (base and lid), fixings, and the elastomeric connector. The customer supplies the encryption device(pcb) and cable. Assembly stages are as follows :-

- 1. Fit pod base assembly over the studs and secure with 2-off M3 nyloc nuts -Torque setting 70Ncm then fit 4-off M3 x 10mm plastite screws Torque setting: 70 Ncm.
- 2. Place Zebra Strip into pod base.



- 3. Fit (customer supplied) encoder assembly to pod base using the Jig to snap it into place. Take care not to bend the pcb retaining clips.
- 4. Fit (customer supplied) cable and test.
- 5. If specified, fit 4 off anti-tamper boot to the pod lid.
- 6. Clip pod lid onto the base.

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.


6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 10 of 16



Section 5. Installation


The 6000 Series keypad is designed to be secured with 6 panel mount clips and locknuts. The gasket is to be positioned between keypad and fixing panel prior to installation. Ensure that a suitable panel material is used to support the keypad. This must provide sufficient rigidity where sealing is required. (e.g. 1.6mm to 2.0mm steel). To optimise sealing the under side of the panel should be flat, clean & free of debris.

1)) Prepare a panel with 2mm weld studs and the appropriate cutout (see below)



2) Fit the sealing gasket over the weld studs.

3) Offer up the keypad to the rear of the panel, and fit a mounting clip over each stud. Secure in place with locknuts. The torque applied to the locknuts should not exceed 25cN.m



This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 11 of 16



Part Numbering Scheme

| DENsite Kots Encler / Foul Cable Mot Used Larver (100 plate - - 0 None 0 None 0 None (100 - customerrites 0 None 0 None 0 None | DIGIT 123 | DIGIT 4 | | DIGIT 5 | DIGIT 6 | DIGIT 7 | DIGIT 8 | DIGIT 9 | DIGIT 10 |
|---|---------------------------------------|--|------------|---------------------|--|--------------|--------------|---------------|-------------|
| 2 Black 0 None 0 None 0 None 1 Som 1 2 Black 1 Matrix output to 0:1* 1 2.5m 2 Nac 2 2 Nac 2 Nac 2 Nac 2 Nac 2 Nac 2 Nac 2 2 Nac 2 2 Nac 2 2 Nac 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 3 0.05 0.05 3 0.05 3 0.05 3 0.05 | Range | <u>Moulding/Top Plate</u> | | | Encoder / Pod | Cable | Not Used | <u>Layout</u> | Distributor |
| 2 Black 1 Matrix output to 0.1" 1.25m 2 ADA Com- 2 bilantie 2 Encoder fitted with USB 2 Stand Dear 3 Custom 3 bilantie 3 PS2 and Clear 3 1 m PS2 0 bilantie 3 PS2 and Clear 3 1 m PS2 0 bilantie 5 Zebra strip connecting own encoder 4 2.5m 3 custom 3 6 MCL ANTITITIAMPER CIRCUIT 7 m PS2 1 m PS2 6 MCL ANTITITIAMPER CIRCUIT 7 m PS2 1 m PS2 6 MCL ANTITITIAMPER CIRCUIT 7 m PS2 1 m PS2 6 MCL ANTITITIAMPER CIRCUIT 7 m PS2 1 m PS2 7 M S 1 m PS2 1 m PS2 7 MAPER CIRCUIT 7 m PS2 1 m PS2 1 m PS2 7 MAPER CIRCUIT 7 m PS2 1 m PS2 1 m PS2 7 MAPER CIRCUIT 7 m PS2 1 m PS2 1 m PS2 7 MAPER CIRCUIT 7 m PS2 1 m PS2 1 m PS2 7 MAPER CIRCUIT 7 m PS2 1 m PS2 1 m PS2 7 MAPER MEAPU MEAPU MEAPU MEAPU MEAPU MEAPU MEAPU MEAPU MEANTIN MCL ENCODER POD MOLEND 1 m PS2 | 600 | | | | 0 Zebra strip connec- tion - customer fits own encoder | | 0 | | 1 KT |
| 2 Encoder filted with user selectable PS2 USB 3 Custom 3 3 PS2 and Clear 3 1 m PS2 3 Lustom 1 Lustom 3 Lustom Lustom 3 Lustom Lustom 3 Lustom 3 Lustom | | | 2 Bla | ick | | | | | 2 RS |
| 3 7000 February 3 1m PS2 Cover 3 1m PS2 Cover 4 RS232 Encoder 4 5 Zebra strip connection 4 25m 6 Tanner CLANTIT Tanner CLANTIT 7m PS2 6 Customer Specific products are non-recorder file soun N S 6 Constandard) in dgits 5 and 6. N S 6 Constandard) in dgits 5 and 6. N S 6 Constandard) in dgits 5 and 6. N S 6 Constandard) in dgits 5 and 6. N S 6 Constandard N S S | | | | | | | | | 3 USA |
| 4 RS232 Encoder 4 2.5m 5 Zena strip connec 5 Zena strip connec Mote - Customer Specific products are designated NS (non-standard) in digits 5 and 6. N S Note - Customer Specific products are designated NS (non-standard) in digits 5 and 6. Note - Customer Specific products are designated NS (non-standard) in digits 5 and 6. N S Note - Customer Specific products are designated NS (non-standard) in digits 5 and 6. Note - Customer Specific products are designated NS (non-standard) in digits 5 and 6. N S Note - Customer Specific products are designated NS (non-standard) in digits 5 and 6. N S | | | | | | 3 1 m PS2 | | | |
| 5 Zabra strip connec- tion - INCL ANTI Tamer ER CINCUIT austomer Fis CINCUIT austomer Fis CINCUIT austomer Fis CINCUIT austomer Specific products are austomer fits own encoder N >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>> | | | | | | | | | |
| More - Customer Specific products are designated NS (non-standard) in digits 5 and 6. N S Herric All Standard in digits 5 and 6. N S Edit Composition of the standard in digits 5 and 6. N S Edit Composition of the standard in digits 5 and 6. N S Edit Composition of the standard in digits 5 and 6. N S Edit Composition of the standard in digits 5 and 6. N N Edit Composition of the standard in digits 5 and 6. N N Edit Composition of the standard in digits 5 and 6. N N Edit Composition of the standard in the | | | | | | K3237 | | | |
| EXAMPLES EXAMPLES 6000-210011 6000 SERIES 16 WAY MATRIX KEYPAD, UK LAYOUT 6000-220011 6000 SERIES 16 WAY PS2/USB KEYPAD, UK LAYOUT 6000-22011 6000 SERIES 16 WAY EADY KEYPAD, INF389 LAYOUT 6000-25NS01-0389 6000 SERIES 16 WAY EADY KEYPAD, INP389 LAYOUT | Note - Customer , designated NS (, | Specific products are non-standard) in digits 5 a | and 6. | | 2 | S | | | |
| 6000 6000 | | | | | | | | | |
| 6000 6000 | EXAMPLES | | | | | | | | |
| 6000 6000 | 6000-210011 | 6000 SERIES | 16 WAY MA | TRIX KEYPAD, (| JK LA YOUT | | | | |
| 6000 | 6000-220011 | 6000 SERIES | 16 WAY PS2 | VUSB KEYPAD, | VO CABLE, UK LAYOUT | | | | |
| | 6000-25NS01-03 | 6000 | 16 WAY ENC | SRYPTION REA | DY KEYPAD, INP389 LAY | OUT, INCL EI | VCODER POD H | OUSING KIT | |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision, reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 12 of 16



| Stock No | <u>Item</u> |
|--|--|
| KEYPADS | |
| 6000-21001[x] 6000-21002[x] 6000-22001[x] 6000-22002[x] | Keypad 6000 Series 16 way Matrix Output UK Layout Keypad 6000 Series 16 way Matrix Output USA Layout Keypad 6000 Series 16 way PS2 / USB, UK Layout Keypad 6000 Series 16 way PS2 / USB, USA Layout |
| ACCESSORIES | |
| 6000-MK00[x] | Mounting Clips Underpanel for 6000 Series |
| 1200-00100[x] 1200-00200[x] | Cable, 2.5m, PS/2 to 5 way Molex Cable, 2.5m, USB to 5 way Molex |
| RELATED PRODUCTS | 5 |
| 4200-00[x] | Encoder 420 Series, RS232, No Cable, Plug-in (See Storm Application / Engineering Guide: 420 Series Encoder , for fixing and connection details) |
| | |

6000 Series Application/Engineering Manual - free download from www.keymat.com

[x] denotes packaging variant

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is ubject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 13 of 16




| CTION KEY COLOURS |
|-------------------|
| RED |
| YELLOW |
| BLUE |
| GREEN |
| |

UK Layout



USA Layout




6000 Series keypad for public environments Application / Engineering Manual


Other layouts are possible -see below.

Contact your Storm distributor for availability.

Alternative Layout - 13 Key



Alternative Layout - 15 Key





This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 14 of 16



Appendix 2. Dimensions and Mounting Details





ASSEMBLY SHOWING BASIC SIZES. CUT OUT SIZE FOR UNDER PANEL MOUNT :-VERTICAL 109.5±0.2 x HORIZONTAL 115.0±0.2 x RADIUS 5.0mm

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is subject to periodic revision, reissue or withdrawal. Whilst every effort is made to ensure the information, data and illustrations are correct at the time of publication, Keymat Technology Ltd. are not responsible for any errors or omissions contained within this document.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 15 of 16



Appendix 3. Code Tables.

(NB : ASCII CODES ACHIEVED WITH 420 SERIES RS232 ENCODER FITTED)

| Row / Column | UK Layout | | | | | USA Layout | | | | |
|------------------------------------|-----------|--|---------------|----------------------------|-------------|------------|--|---------------|----------------------------|-------------|
| | Marking | Base Key | ASCII Code | PC/AT Code (Code Set 2) | USB Code | Marking | Base Key | ASCII Code | PC/AT Code (Code Set 2) | USB Code |
| R1C1 | 1 | Black | 31 | 69 | 59 | 1 QZ | Black | 31 | 69 | 59 |
| R1C2 | 2 ABC | Black | 32 | 72 | 5A | 2 ABC | Black | 32 | 72 | 5A |
| R1C3 | 3 DEF | Black | 33 | 7A | 5B | 3 DEF | Black | 33 | 7A | 5B |
| R1C4 | CANCEL | Red with raised Cross | 0D | 76 | 29 | ENTER | Green with raised circle | 1B | 5A | 28 |
| R2C1 | 4 GHI | Black | 34 | 6B | 5C | 4 GHI | Black | 34 | 6B | 5C |
| R2C2 | 5 JKL | Black with Homepip | 35 | 73 | 5D | 5 JKL | Black with Homepip | 35 | 73 | 5D |
| R2C3 | 6 MNO | Black | 36 | 74 | 5E | 6 MNO | Black | 36 | 74 | 5E |
| R2C4 | CLEAR | Yellow with raised vertical line | 7F | 66 | 2A | CLEAR | Yellow with raised vertical line | 7F | 66 | 2A |
| R3C1 | 7 PQRS | Black | 37 | 6C | 5F | 7 PRS | Black | 37 | 6C | 5F |
| R3C2 | 8 TUV | Black | 38 | 75 | 60 | 8 TUV | Black | 38 | 75 | 60 |
| R3C3 | 9 WXYZ | Black | 39 | 7D | 61 | 9 WXY | Black | 39 | 7D | 61 |
| R3C4 | ? | Blue | 05 | 05 | ЗА | ? | Blue | 05 | 05 | ЗA |
| R4C1 | * | Black | 2A | 7C | 55 | * | Black | 2A | 7C | 55 |
| R4C2 | 0 | Black | 30 | 70 | 62 | 0 | Black | 30 | 70 | 62 |
| R4C3 | # | Black | 23 | 5D | 31 | # | Black | 23 | 12,26 | E1,20 |
| R4C4 | ENTER | Green with raised circle | 1B | 5A | 28 | CANCEL | Red with raised Cross | 0D | 76 | 29 |
| ANTI- TAMPER OPEN CIRCUIT | | | 07* | NOT USED | | | 07 [*] NOT USED | | ISED | |

This document is provided for use and guidance of engineering personnel engaged in the installation or application of STORM data entry products manufactured by Keymat Technology Ltd. Please be advised that all information, data, and illustrations contained within this document remain the exclusive property of Keymat Technology Ltd. and are provided for the express and exclusive use as described above. This document is not supported by Keymat Technology's engineering change note, revision or reissue system. Data contained within this document is ubject to periodic revision, reissue or withdrawal. While very effort is made to ensure the information, data and illustrations are correct at the time of publication. Keymat Technology Ltd.

6000 Series Application/Engineering Manual Version 1.01 Feb 2004 Page 16 of 16