### T-1 (3mm) SOLID STATE LAMP

Part Number: WP132XND

Pure Orange


#### Features

- Low power consumption.
- Popular T-1 diameter package.
- General purpose leads.
- Reliable and rugged.
- Long life-solid state reliability.
- Available on tape and reel.
- RoHS compliant.

#### Description

The Pure Orange source color devices are made with Gallium Arsenide Phosphide on Gallium Phosphide Pure Orange Light Emitting Diode.

#### Package Dimensions



Downloaded from Elcodis.com electronic components distributor

APPROVED: WYNEC

CHECKED: Allen Liu DRAWN: J.Yu

ERP: 1101001111

Selection Guide					
Part No.	Dice	Lens Type	lv (mcd) [2] @ 10mA		Viewing Angle [1]
			Min.	Тур.	201/2
WP132XND	Pure Orange (GaAsP/GaP)	Orange Diffused	15	30	60°

Notes:

01/2 is the angle from optical centerline where the luminous intensity is 1/2 of the optical peak value.
Luminous intensity/ luminous Flux: +/-15%.

### Electrical / Optical Characteristics at TA=25°C

Symbol	Parameter	Device	Тур.	Max.	Units	Test Conditions
λpeak	Peak Wavelength	Pure Orange	607		nm	I⊧=20mA
λD [1]	Dominant Wavelength	Pure Orange	610		nm	I⊧=20mA
Δλ1/2	Spectral Line Half-width	Pure Orange	35		nm	I⊧=20mA
С	Capacitance	Pure Orange	15		pF	VF=0V;f=1MHz
VF [2]	Forward Voltage	Pure Orange	2.05	2.5	V	I⊧=20mA
lr	Reverse Current	Pure Orange		10	uA	VR = 5V

Notes:

1.Wavelength: +/-1nm. 2. Forward Voltage: +/-0.1V.

### Absolute Maximum Ratings at TA=25°C


Pure Orange	
62.5	
C Forward Current 25	
145	mA
5	V
rating/Storage Temperature -40°C To +85°C	
d Solder Temperature [2] 260°C For 3 Seconds	
260°C For 5 Seconds	
	62.5 25 145 5 -40°C To +85°C 260°C For 3 Seconds


2. 2mm below package base.
3. 5mm below package base.

SPEC NO: DSAF2132 APPROVED: WYNEC

**REV NO: V.4** CHECKED: Allen Liu DATE: FEB/28/2011 DRAWN: J.Yu


PAGE: 2 OF 6 ERP: 1101001111





### PRECAUTIONS


1. The lead pitch of the LED must match the pitch of the mounting holes on the PCB during component placement. Lead-forming may be required to insure the lead pitch matches the hole pitch. Refer to the figure below for proper lead forming procedures. (Fig. 1)



"〇

Correct mounting method "imes" Incorrect mounting method

- When soldering wire to the LED, use individual heat-shrink tubing to insulate the exposed leads to prevent accidental contact short-circuit. (Fig.2)
- 3.Use stand-offs (Fig.3) or spacers (Fig.4) to securely position the LED above the PCB.



- 4. Maintain a minimum of 2mm clearance between the base of the LED lens and the first lead bend. (Fig. 5 and 6)
- 5. During lead forming, use tools or jigs to hold the leads securely so that the bending force will not be transmitted to the LED lens and its internal structures. Do not perform lead forming once the component has been mounted onto the PCB. (Fig. 7)

SPEC NO: DSAF2132 APPROVED: WYNEC REV NO: V.4 CHECKED: Allen Liu DATE: FEB/28/2011 DRAWN: J.Yu

