

-

JB26 Jumper Bars

Terminal Blocks Accessories

Features and Benefits

Screw jumper bars



Main Technical Da	Mounting Instructions		Screw			
	IEC	cULus - CSA	Ex e	Tool	\bigcirc	Allen Key Ø 4 mm
Rated current	232 A	230 A				Ø 0.157 in
Rated voltage Standard	use 1000 V	600 V	630 V	Torque	Č.	2 Nm ± 0.4
Alternated	poles		Not authorized		\bigcirc	17.7 lb.in ± 3.54
Impulse withstand voltage	e 8000 V					
Protection	IP	NEMA				
Material Specifications	Flammabili	Insulating material Flammability				
	NF F 16 10		-55 +110 °C			
Ambient temperature min				-67 +230 F		
	Storage		-55 +110 °C	-67 +230 F		
	Installing					

Ordering Details

Description		Туре	Order Code	Pack(ing) Weight	
				pieces	g (1 pce)
26 mm 1.02 in spacing	2 poles	JB26-2	1SNK 926 302 R0000	5	41.20
	3 poles	JB26-3	1SNK 926 303 R0000	5	65.70
	5 poles	JB26-5	1SNK 926 305 R0000	5	115.70
	10 poles	JB26-10	1SNK 926 310 R0000	5	241.50

JB26 Mounting Instructions



 With flat pliers, cut out the partitions on the terminal block insulating body.
Be careful to not cut out the jumpered terminal blocks at both ends of the assembly,

- Mount the jumper bar with the recommended tool and torque.



All terminal blocks are certified with its compatible accessories. See complete information in "Technical Data Sheet"