



System Power Supply for TV Series

Built-in 1ch FET Light Load Type DC/DC converters





BD8622EFV

Description

BD8622EFV has realized the high performance and reliability required as a power supply for thin-screen TV.

Due to the high-speed load response, it is most suitable for TV-purpose processors with increasingly high performance, and due to the wide phase margin it leaves a good margin for board pattern & constant setting and so facilitates its application design.

As a high-reliability design, it has various built-in protection circuits (overcurrent protection, output voltage abnormal protection, thermal protection, and off-latch function at the time of abnormality etc.), therefore as an advantage it does not easily damage in every possible abnormal condition such as all-pin short circuit test etc. and hence most suitable for thin-screen TV which requires the high reliability.

Features

- 1) High efficiency in all load area
- 2) 3.0A output current
- 3) PWM mode/PFM mode switch(automatic operation)
- 4) Low current mode/RorrippImord switch with terminal MODE
- 5) Low RDS(ON) internal switches : $75m\Omega(typ.)$
- 6) ±1% reference voltage accuracy
- 7) Programmable frequency: 250kHz-1MHz

(Can the adjustment by an external synchronization and the terminal RT resistance.)

- 8) Terminal RT OPEN/SHORT detecting function
- 9) Over current protection function
- 10) Output over voltage/low voltage protection function (over : FB > VREF +60mV , low : FB < VREF -60mV)
- 11) Timer off latch function in abnormal circumstances
- 12) Thermal shutdown function
- 13) Under voltage protection
- 14) Soft start/start delay circuit
- 15) Soft start time out function
- 16) Protecting BUS function with terminal PDET
- 17) HTSSOP-B20 package

Jul. 2008

• Electrical characteristic

(Unless otherwise noted Ta=25°C, VIN=3.3V, GND=0V)

Parameter	Symbol		Specification value		UNIT	Condition
Faranteter	Syrribor	MIN	TYP	MAX	UNIT	Condition
VIN supply current (operating)	I _{Q_active}	-	210	350	μA	$V_{FB} = 0.83V, V_{FC} = 1V$
VIN supply current (standby)	I_{Q_stby}	•	0	1	μA	V _{EN} = 0V
Reference voltage (VREF)	V_{REF}	0.792	0.8	0.808	V	
Output rise detection voltage	V_{OVP}	30	60	90	mV	Monitoring FB terminal
Output decrease detection voltage	V_{LVP}	-90	-60	-30	mV	Monitoring FB terminal
Terminal PDET output current	I _{PDET}	0.4	-	-	mA	V _{PDET} < 0.3V
Oscillation frequency	f _{OSC}	500	550	600	kHz	R_{RT} = 220k Ω
Pch FET ON resistance	R _{PFET}	-	75	110	mΩ	I _{SW} = 1A
UVLO voltage	V_{UVLO}	2.35	2.50	2.65	V	
SW leak current	I_{LSW}	1	0	1	μΑ	V_{EN} = 0V, V_{IN} = 5.5V
EN terminal H threshold voltage	V_{ENH}	1.1	-	-	V	
EN terminal L threshold voltage	V_{ENL}	-	-	0.4	V	
FC sink current	I _{FCSI}	10	20	-	μA	
FC source current	I _{FCSO}	-	-20	-10	μA	
SS/DELAY terminal source current	I _{SSSO}	2	4	6	μA	
Terminal PDET pull-up resistor	R _{PDET}	100	170	250	kΩ	

 V_{FB} :FB terminal voltage, V_{EN} :EN terminal voltage, V_{FC} :FC terminal voltage, V_{PDET} : PDET terminal voltage Current capability should not exceed Pd.

• Block Diagram




Fig1 Block diagram

• Pin Description

No.	Symbol	Description	Explanation		
1	SGND	Signal GND terminal	Small signal system GND		
2	FB	Feed back terminal	Output voltage detection		
3	PDET	Abnormal state notification and external IC abnormality detection terminal	Protecting BUS communication terminal		
4	NC				
5	SW				
6	SW	Cuitabing output tarminal			
7	SW	Switching output terminal			
8	SW				
9	NC				
10	PGND	Power GND terminal	GND for power MOSFET		
11	VIN				
12	VIN	Dower overheimet terminel	Power supply input. The decoupling is done to PGND		
13	VIN	Power supply input terminal	Fower supply input. The decoupling is done to FGND		
14	VIN				
15	NC				
16	EN	Enable input	ON/OFF control for device operation		
17	MODE	MODE palastics towards at	The operation mode is switched according to the input voltage		
		MODE selection terminal	at a light load.		
18	SS/DELAY	Soft start adjustment capacity connection terminal	The soft start time is adjusted with the connected capacitor		
19	FC	Error amplifier output	Error amplifier phase compensation point		
20	RT	Frequency adjustment resistance connection terminal	The switching frequency is set by the connected resistance		

• Pin equivalence circuit diagram

No.	Symbol	cuit diagram Explanation	Terminal equivalent circuit diagram
1	SGND	GND (connected 0V)	
2	FB	Output voltage detection terminal	VIN →
3	PDET	Protecting BUS I/O terminal	VIN
5,6,7,8	SW	Output terminal	VIN (5) (6) (7) (8) (7) (9) (9) (9) (10) (10) (10) (10) (10) (10) (10) (10
10	PGND	Power GND (Same voltage as SGND)	
11,12,13	PVIN	Power supply input terminal	
14	SVIN	Power supply input terminal	

No.	Symbol	Explanation	Terminal equivalent circuit diagram
16	EN	Enable terminal	VIN VIN
17	MODE	Operation mode switch terminal at light load	VIN VIN O

No.	Symbol	Explanation	Terminal equivalent circuit diagram
18	SS /DELAY	Soft start time adjustment terminal	VIN OF THE STATE O
19	FC	Error amplifier compensation terminal	VIN O W SGND SGND SGND SGND SGND SGND SGND SGND
20	RT	Oscillator frequency adjustment terminal	

• Operation description

Enable control

The device can be controlled ON/OFF by EN terminal (16 pin) voltage.

An internal circuit starts when VEN reaches 1.1V.

When standing up of VIN is too steep (1msec or less), a defective start might be caused according to the state of Pascon between GND substrate pattern and power supply—when the terminal EN is short—circuited to the terminal VIN and it is used.




Fig.2 ON/OFF transition wave form in EN controlling

Soft start time set function

As for BD8622EFV, output can do soft start without overshoot by charging soft start capacity (CSS) connected between SS and SGND terminal.

Also, soft start time (tss) can be set by setting soft start capacity (CSS) arbitrarily.

OSC oscillation frequency setting function

The output oscillation frequency can be set by connecting resistance between terminal RT (20 pins) and SGND (range = 250kHz - 1MHz)

The relation between RT terminal resistance and the oscillation frequency follows Fig.4.




Fig.4 RT resistance-oscillation frequency

Light load mode operation

· Low current mode

When the terminal MODE (17 pins) is made "H", low current mode operation becomes effective. The characteristic of the efficiency valuing is obtained in low current mode operation at a light load.




Fig.5 Low current mode operation

· Low ripple mode

When the terminal MODE is made "L", the Low ripple mode operation becomes effective. It becomes operation of valuing a low ripple in the Low ripple mode operation at a light load.




Fig.6 Low ripplemord operation




Fig7 Light load mode efficiency comparison

Protection function

<u>Protection circuit is effective for destruction prevention due to accident so that avoid using under continuous protection operation.</u>

Low voltage protection function (LVP)

The voltage of the terminal FB (2 pins) is compared with internal reference voltage VREF.

If FB terminal voltage falls below V_{LVP} (= VREF -60mV) and the state continues for 500us, output changes to low voltage and the state is fixed. In that case, PDET (3pin) output changes to L.

Table 4-1	output low	voltage	protection	function
	Output IOW	VOILLAGE	pi otootioi i	iui iouoi i

EN terminal	SS terminal	FB terminal	Low voltage protection function	Low voltage protection operation
>V _{ENH}	\1 4\//±\	<v<sub>LVP</v<sub>	C#ootiv o	ON
	>1.4V(typ)	>V _{LVP}	Effective	OFF
	<1.4V(typ)	-	Invalidity	OFF
<v<sub>ENL</v<sub>	_	_	Invalidity	OFF

^{*} Low voltage protection function is available when SS terminal voltage becomes more than 1.4V (typ) in the transition to ON control (during soft start).

Over voltage protection function(OVP)

The voltage of the terminal FB is compared with internal reference voltage VREF.

If FB terminal voltage is over Vovp (=VREF +60mV) and the state is continues for 500usec, output changes to low voltage and the state is fixed.

Table 4-2 output overvoltage protection function

		•		
EN terminal	SS terminal	FB terminal	Over voltage protection function	Over voltage protection operation
>V _{ENH}	\1 4\/(±, m)	>V _{OVP}	Effective	ON
	>1.4V(typ)	<v<sub>OVP</v<sub>	Ellective	OFF
	<1.4V(typ)	-	Invalidity	OFF
<v<sub>ENL</v<sub>	_	-	Invalidity	OFF

^{*} Over voltage protection function is available when SS terminal voltage becomes more than 1.4V (typ) in the transition to ON control (during soft start).




Fig.8 Output voltage error detection range

Under voltage lock out protection (UVLO)

As for BD8622EFV, the power-supply voltage decrease detection protection circuit is built in.

It the input voltage decrease below the UVLO voltage (2.5V typ), the device state changes to the standby mode (Moreover, to prevent the chattering of the output) hysteresis width of 100mV(typ) has been installed in the UVLO cancel voltage.

RT terminal open/short protection function (RTO/RTS)

RT terminal opening/short protection function prevent the clock from abnormal oscillation.

If RT terminal open/short protection function is detected, output voltage changes to low level and is fixed.

Terminal RT opening/short protection function is available if the state continue for 500usec, abnormal detection operates when the state continues about 500µsec(typ).

Soft start time-out function

If VSS doesn't exceed VSSTH within 64msec (typ) since a soft start began, BD8622EFV controls an off latch. Vo is fixed in a low level.




Fig.9 Soft start time-out

Thermal shut down function

Thermal shut down circuit (TSD circuit) is built into BD8622EFV. When the temperature of the chip exceeds Tjmax=175, the DC/DC converter is fixed in a low voltage.

TSD function is aimed to shut down IC from thermal reckless driving under an abnormal state to exceed Tjmax=175. It aims at neither protection nor the guarantee of the set. Therefore, please do not use this function to protect the set.

Over current protection function

The over current protection function has been achieved by limiting the current that flows on high side MOSFET.

The current is controlled in every one cycle of the switching frequency. When an abnormal state continues for about 500µsec(typ), the output is fixed in a low level.

Protecting BUS function with terminal PDET

The terminal PDET (3 pins) monitors whether IC is normal or not. When IC becomes abnormal, the PDET output is reduced at "L" level with the output voltage fixed "L" level at the same time. Moreover, it is possible to make the output fix in a low level by compulsorily reducing the terminal PDET at "L" level from the outside.

When two or more BD8622EFV is used in the application, this function prevents the IC from destroying, because one IC error transmits all other ICs by PDET line in the condition that PDET terminals are connected each other.




Fig.6 Protecting BUS communication

XPlease give the terminal PDET as OPEN when you do not use protecting BUS function.

Error detection (off latch) release method

BD8622EFV enters the state of an off latch when the protection function operates.

To release the off latch state, EN terminal voltage should be changed to low level once time.

• Each characteristic reference data




Fig.11 Output load response




Fig.13 Efficiency




Fig.15 Regulation




Fig.12 Output ripple




Fig.14 Soft start




Fig.16 Reference voltage - Temperature characteristic




Fig.18 Switching frequency-power-supply voltage characteristic




Fig.20 PMOS on resistance-power-supply voltage




Fig.22 Terminal EN H voltage-temperature characteristic




Fig.17 SS Charging current - Temperature characteristic




Fig.19 Switching frequency-temperature characteristic




Fig.21 PMOS on resistance-temperature characteristic






Fig.23 Circuit current-power-supply voltage characteristic

HTSSOP-B20





- The contents described herein are correct as of July, 2008
- The contents described herein are subject to change without notice. For updates of the latest information, please contact and confirm with ROHM CO.,LTD.
 Any part of this application note must not be duplicated or copied without our permission.
- Application circuit diagrams and circuit constants contained herein are shown as examples of standard use and operation. Please pay careful attention to the peripheral conditions when designing circuits and deciding upon circuit constants in the set.
- Any data, including, but not limited to application circuit diagrams and information, described herein are intended only as illustrations of such devices and not as the specifications for such devices. ROHM CO.,LTD. disclaims any warranty that any use of such devices shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes no liability of whatsoever nature in the event of any such infringement, or arising from or connected with or related to the use of such devices.
- Upon the sale of any such devices, other than for buyer's right to use such devices itself, resell or otherwise dispose of the same, implied right or license to practice or commercially exploit any intellectual property rights or other proprietary rights owned or controlled by ROHM CO., LTD. is granted to any such buyer.

 The products described herein utilize silicon as the main material.

● The products described herein are not designed to be X ray proof.

The products listed in this catalog are designed to be used with ordinary electronic equipment or devices (such as audio visual equipment, office-automation equipment, communications devices, electrical appliances and electronic toys).

Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of which would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers, fuel controllers and other safety devices), please be sure to consult with our sales representative in advance.

Excellence in Electronics



ROHM CO., LTD.

21 Saiin Mizosaki-cho, Ukyo-ku, Kyoto 615-8585, Japan TEL: +81-75-311-2121 FAX: +81-75-315-0172 URL http://www.rohm.com

Published by KTC LSI Development Headquarters LSI Business Pomotion Group

Contact us for further information about the products. San Diego Atlanta Boston Chicago Dallas Denver Düsseldorf Munich Stuttgart France United Kingdom Denmark Espoo Oulu Barcelona Hungary Poland Russia Masan

Beijing

TEL: +1-858-625-3630 TEL: +1-770-754-5972 TEL: +1-978-371-0382 TEL: +1-847-368-1006 TEL: +1-469-287-5366 TEL: +1-303-708-0908 TEL: +1-303-708-0908 TEL: +1-248-348-9920 TEL: +1-615-620-6700 TEL: +52-33-3123-2001 TEL: +49-2154-9210 TEL: +49-899-216168 TEL: +49-899-216168
TEL: +49-711-72723710
TEL: +33-1-5697-3060
TEL: +44-1-908-306700
TEL: +45-3694-4739
TEL: +358-9725-54491 TEL: +358-2-7332234 TEL: +358-8-5372930 TEL: +358-8-5372930 TEL: +34-9375-24320 TEL: +36-1-4719338 TEL: +48-22-5757213 TEL: +7-95-980-6755 TEL: +82-2-8182-700 TEL: +82-55-240-6234 TEL: +86-411-8230-8549 FAX: +86-411-8230-8537 TEL: +86-10-8525-2483 FAX: +86-10-8525-2489

FAX: +1-858-625-3670 FAX: +1-770-754-0691 FAX: +1-928-438-7164 FAX: +1-847-368-1008 FAX: +1-469-362-7973 FAX: +1-469-362-7973
FAX: +1-303-708-0858
FAX: +1-248-348-9942
FAX: +1-615-620-6702
FAX: +52-33-3123-2002
FAX: +49-2154-921400 FAX: +49-899-216176 FAX: +49-711-72723720 FAX: +49-711-72723720 FAX: +33-1-5697-3080 FAX: +44-1-908-235788 FAX: +45-3694-4789 FAX: +358-9-7255-4499 FAX: +358-2-7332237 FAX: +358-8-5372931 FAX: +358-8-5372931 FAX: +34-9375-24410 FAX: +36-1-4719339 FAX: +48-22-5757001 FAX: +7-95-937-8290 FAX: +82-2-8182-715 FAX: +82-55-240-6236

Tianjin Shanghai Hangzhou Nanjing Ningbo Qingdao Suzhou Wuxi Shenzhen Dongguan Fuzhou Guangzhou Huizhou Xiamen Zhuhai Hong Kong Taipei Kaohsiung Singapore Philippines Thailand Kuala Lumpur Penang Kvoto Yokohama

TEL: +86-22-23029181 FAX: +86-22-23029183
TEL: +86-21-6279-2727 FAX: +86-21-6247-2066
TEL: +86-571-87658072 FAX: +86-571-87658071
TEL: +86-25-8689-0015 FAX: +86-25-8689-0393 TEL: +86-574-87654201 FAX: +86-574-87654208 TEL: +86-5/4-8/694201 FAX: +86-5/4-8/694208 TEL: +86-5/2-5/79-615 FAX: +86-5/2-5/79-653 TEL: +86-51-2-6807-1300 FAX: +86-51-2-6807-2300 TEL: +86-510-82702992 TEL: +86-755-8307-3008 FAX: +86-755-8307-3003 TEL: +86-769-8399-4140 TEL: +86-591-8801-8698 FAX: +86-591-8801-8690 TEL: +86-591-8801-8698 TEL: +86-20-3878-8100 TEL: +86-752-205-1054 TEL: +86-592-238-5705 TEL: +86-756-3232-480 TEL: +852-2-740-6262 FAX: +86-591-8801-869 FAX: +86-20-3825-5965 FAX: +86-752-205-1059 FAX: +86-592-239-8380 FAX: +86-756-3232-460 FAX: +852-2-375-8971 TEL: +886-2-2500-6956 FAX: +886-2-2503-2869 TEL: +886-7-237-0881 FAX: +886-7-238-7332 TEL: +886-7-237-0881 TEL: +65-6332-2322 TEL: +63-2-807-6872 TEL: +66-2-254-4890 TEL: +60-3-7958-8355 TEL: +60-4-2286453 TEL: +81-75-365-1218 FAX: +886-7-238-7332 FAX: +65-6332-5662 FAX: +63-2-809-1422 FAX: +66-2-256-6334 FAX: +60-3-7958-8377 FAX: +60-4-2286452 FAX: +81-75-365-1228 TEL: +81-45-476-2290 FAX: +81-45-476-2295

Notes

- No technical content pages of this document may be reproduced in any form or transmitted by any
 means without prior permission of ROHM CO.,LTD.
- The contents described herein are subject to change without notice. The specifications for the
 product described in this document are for reference only. Upon actual use, therefore, please request
 that specifications to be separately delivered.
- Application circuit diagrams and circuit constants contained herein are shown as examples of standard
 use and operation. Please pay careful attention to the peripheral conditions when designing circuits
 and deciding upon circuit constants in the set.
- Any data, including, but not limited to application circuit diagrams information, described herein are intended only as illustrations of such devices and not as the specifications for such devices. ROHM CO.,LTD. disclaims any warranty that any use of such devices shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes no liability of whatsoever nature in the event of any such infringement, or arising from or connected with or related to the use of such devices.
- Upon the sale of any such devices, other than for buyer's right to use such devices itself, resell or
 otherwise dispose of the same, no express or implied right or license to practice or commercially
 exploit any intellectual property rights or other proprietary rights owned or controlled by
- ROHM CO., LTD. is granted to any such buyer.
- Products listed in this document are no antiradiation design.

The products listed in this document are designed to be used with ordinary electronic equipment or devices (such as audio visual equipment, office-automation equipment, communications devices, electrical appliances and electronic toys).

Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of which would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers, fuel controllers and other safety devices), please be sure to consult with our sales representative in advance.

It is our top priority to supply products with the utmost quality and reliability. However, there is always a chance of failure due to unexpected factors. Therefore, please take into account the derating characteristics and allow for sufficient safety features, such as extra margin, anti-flammability, and fail-safe measures when designing in order to prevent possible accidents that may result in bodily harm or fire caused by component failure. ROHM cannot be held responsible for any damages arising from the use of the products under conditions out of the range of the specifications or due to non-compliance with the NOTES specified in this catalog.

Thank you for your accessing to ROHM product informations.

More detail product informations and catalogs are available, please contact your nearest sales office.

ROHM Customer Support System

THE AMERICAS / EUROPE / ASIA / JAPAN

www.rohm.com

Contact us : webmaster@rohm.co.jp

Copyright © 2008 ROHM CO.,LTD.

ROHM CO., LTD. 21 Saiin Mizosaki-cho, Ukyo-ku, Kyoto 615-8585, Japan

an TEL:+81-75-311-2121 FAX:+81-75-315-0172

