

# **RR Series Power Relays**

## SPDT through 4PDT, 10A contacts Midget power type relays

- Available in pin and blade terminal styles.
- Options include an indicator, check button for test operations and side flange.
- DIN rail, surface and panel mount sockets are available for a wide a variety of mounting applications.











## **Part Number Selection**

	Part Number			
Contact	Model	Pin Terminal	Blade Terminal*	Coil Voltage Code (Standard Stock Items in Bold)
SPDT	Basic		RR1BA-U	
A THE	With Indicator		RR1BA-UL	
	With Check Button	_	RR1BA-UC	
	With Indicator and Check Button		RR1BA-ULC	
	Side Flange Model		RR1BA-US	
DPDT	Basic	RR2P-U	RR2BA-U	
	With Indicator	RR2P-UL	RR2BA-UL	AC6V, AC12V, AC24V, AC110V, <b>AC120V</b> ,
	With Check Button	RR2P-UC	RR2BA-UC	AC220V, AC240V, AC110V, AC120V, AC220V, AC240V,
THE WAY	With Indicator and Check Button	RR2P-ULC	RR2BA-ULC	DC6V, DC12V, <b>DC24V</b> , DC48V, DC110V
	Side Flange Model	_	RR2BA-US	
3PDT	Basic	RR3PA-U	RR3B-U	
TO MAN	With Indicator	RR3PA-UL	RR3B-UL	
	With Check Button	RR3PA-UC	RR3B-UC	
	With Indicator and Check Button	RR3PA-ULC	RR3B-ULC	
a different all to	Side Flange Model	_	RR3B-US	



\*Blade type not TUV tested or CE marked.

## **Ordering Information**

When ordering, specify the Part No. and coil voltage code:

(example) RR3B-U Part No.

AC120V

Coil Voltage Code

#### Sockets

Relays	Standard DIN Rail Mount	Finger-safe DIN Rail Mount	Through Panel Mount
RR2P	SR2P-05 SR2P-06	SR2P-05C	SR2P-51
RR3PA	SR3P-05 SR3P-06	SR3P-05C	SR3P-51
RR1BA RR2BA RR3B	SR3B-05	_	SR3B-51









All DIN rail mount sockets shown above can be mounted using DIN rail BNDN1000.

IDEC

# **Hold Down Springs & Clips**

Appearance	Description	Relay	For DIN Mount Socket	For Through Panel & PCB Mount Socket	Min Order Qty	
		RR2P	SR2B-02F1	SR3P-01F1		
	Pullover Wire Spring	RR3PA	SR3B-02F1	SN3F-01F1	10 pcs	
		RR1BA, RR2BA, RR3B	SR3B-02F1	SR3B-02F1	10 poo	
A COLOR	Leaf Spring (side latch)	RR2P, RR3PA	SFA-203	-	20 pcs	

## **Accessories**

Description	Appearance	Use with	Part No.	Remarks
Aluminum DIN Rail (1 meter length)		All DIN rail sockets	BNDN1000	IDEC offers a low-profile DIN rail (BNDN1000). The BNDN1000 is designed to accommodate DIN mount sockets. Made of durable extruded aluminum, the BNDN1000 measures 0.413 (10.5mm) in height and 1.37 (35mm) in width (DIN standard). Standard length is 39" (1,000mm).
DIN Rail End Stop	A STATE OF THE PARTY OF THE PAR	DIN rail	BNL5	9.1 mm wide.
Replacement		Horseshoe clip for sockets SR3B-05, SR2P-06, SR3P-06	Y778-011	For use on DIN rail mount socket when using pullover wire hold down
Hold-Down Spring Anchor	A.	Chair clip for sockets SR2P-05(C), SR3P-05(C)	Y703-102	spring. 2 pieces included with each socket.

## **Specifications**

opcomounds.					
Contact Mater	ial	Silver			
Contact Resistance <sup>1</sup>		30 mΩ maximum			
Minimum Applicable Load		1V DC, 10 mA			
Operate Time <sup>2</sup>		25 ms maximum			
Release Time	2	25 ms maximum			
Power Consun	nption (approx.)	AC: 3 VA (50 Hz), 2.5 V DC: 1.5W	A (60 Hz)		
Insulation Res	istance	100 MΩ minimum (500	V DC megger)		
		Between live and dead	d parts:	1500V AC, 1 minute	
	Die Terrieral	Between contact and o	coil:	1500V AC, 1 minute	
	Pin Terminal	Between contacts of d	ifferent poles:	1500V AC, 1 minute	
Dielectric Strength		Between contacts of the same pole:		1000V AC, 1 minute	
	Blade Terminal	Between live and dead parts:		2000V AC, 1 minute	
		Between contact and coil:		2000V AC, 1 minute	
		Between contacts of different poles:		2000V AC, 1 minute	
		Between contacts of the same pole:		1000V AC, 1 minute	
Operating Freq		Electrical:	1800 operations/h maximum		
Operating Fred	luency	Mechanical:	18,000 operation	s/h maximum	
Vibration Resi	otomo o	Damage limits:	10 to 55 Hz, amp	litude 0.5 mm	
VIDIALIUII NESI	stance	Operating extremes:	10 to 55 Hz, amp	litude 0.5 mm	
Chaol: Docioto	noo	Damage limits:	1000 m/s <sup>2</sup> (100g)		
Shock Resistance		Operating extremes:	100 m/s <sup>2</sup> (10G)		
Mechanical Life		10,000,000 operations			
Electrical Life		200,000 operations (220V AC, 5A)			
Operating Temperature <sup>3</sup>		-25 to +40°C (no freezing)			
Operating Humidity		5 to 85% RH (no condensation)			
Weight (approx.) (Basic type)		RR2P: 90g, RR3PA: 96g, RR1BA/RR2BA/RR3B: 82g			



- Measured using 5V DC, 1A voltage drop method
   Measured at the rated voltage (at 20°C), excluding
- For use under different temperature conditions, refer to Continuous Load Current vs. Operating Temperature Curve

Canada: 888-317-IDEC

# **Coil Ratings**

Rated Voltage (V)		Rated Current (mA) ±15% (at 20°C)		Coil Resistance (Ω)	Operating Characteristics (values at 20°C)		
		50 Hz	60 Hz	±10% (at 20°C)	Maximum Continuous Applied Voltage	Pickup Voltage	Dropout Voltage
	6	490	420	4.9			
	12	245	210	18		80% maximum	30% minimum
AC	24	121	105	79	110%		
(50/60 Hz)	(50/60 Hz) 110 120	27	23	1,680	110%		
		24	20.5	2,100			
	240	12.1	10.5	8,330			
	6	24	40	25			
	12	12	20	100			
DC 24	24	6	60		110%	80% maximum	10% minimum
	48	3	0	1,600			
	110	1	3	8,460			

# **Contact Ratings**

Maximum Contact Capacity							
Continuous Current	Allowable Contact Power Rated Load						
	Resistive Load	Inductive Load	Voltage (V)	Res. Load	Ind. Load		
10A		1100VA AC 150W DC	110 AC	10A	7.5A		
			220 AC	7.5A	5A		
			30 DC	10A	5A		

A

Note: Inductive load for the rated load —  $\cos \varnothing = 0.3$ , L/R = 7 ms

# **TÜV Ratings**

Voltage	
240V AC	10A
30V DC	10A



AC:  $\cos \emptyset = 1.0$ , DC: L/R = 0 ms

# **UL Ratings**

Voltage	Resistive	General use	Horse Power Rating
240V AC	10A	7A	1/3 HP
120V AC	10A	7.5A	1/4 HP
30V DC	10A	7A	_

## **CSA** Ratings

Voltage	Resistive	General use
240V AC	10A	7A
120V AC	10A	7.5A
100V DC	_	0.5A
30V DC	10A	7.5A

## **Socket Specifications**


	Relays	Terminal	Electrical Rating	Wire Size	Torque
	SR2P-05	M3 screw with captive wire clamp	300V, 10A	2-12 AWG	9 - 11.5in∙lbs
	SR2P-05C	M3 screw with captive wire clamp, fingersafe	300V, 10A	2-12 AWG	9 - 11.5in∙lbs
	SR2P-06	M3 screw with captive wire clamp	300V, 10A	2-12 AWG	9 - 11.5in•lbs
DIN Rail Sockets	SR3P-05	M3 screw with captive wire clamp	300V, 10A	2-12 AWG	9 - 11.5in•lbs
00011010	SR3P-05C	M3 screw with captive wire clamp, fingersafe	300V, 10A	2-12 AWG	9 - 11.5in•lbs
	SR3P-06	M3 screw with captive wire clamp	300V, 10A	2-12 AWG	9 - 11.5in•lbs
	SR3B-05	M3 screw with captive wire clamp	300V, 15A (10A)* (*CSA rating)	2-12 AWG	9 - 11.5in•lbs
Through	SR2P-51	Solder	300V, 10A	_	_
Panel Mount	SR3P-51	Solder	300V, 10A	_	_
Sockets	SR3B-51	Solder	300V, 10A	_	_

IDEC


## **Characteristics (Reference Data)**

#### **Electrical Life Curves**


#### **AC Load**




## **Maximum Switching Capacity**




#### **DC** Load




# Continuous Load Current vs. Operating Temperature Curve (Basic Type, With Check Button, and Side Flange Type)



# Internal Connection (View from Bottom) Basic Type



## With Indicator (-UL type)




SR3P-05


# IDEC

## **Dimensions (mm)**


## RR2P-U/RR2P-UL




## RR3PA-U/RR3PA-UL




## RR1BA-U/RR2BA-UL/RR2BA-U RR2BA-UL/RR3B-U/RR3B-UL




## RR1BA-US/RR2BA-US/RR3B-US




## **Standard DIN Rail Mount Sockets**




## **SR2P-06**












IDEC




## SR3B-05




## **Finger-safe DIN Rail Mount Sockets**

## SR2P-05C




#### SR3P-05C




## **Through Panel Mount Socket**


## SR2P-51



## SR3P-51



## SR3B-51







## **Driving Circuit for Relays**

#### 1. To ensure correct relay operation, apply rated voltage to the relay coil.

## 2. Input voltage for the DC coil:

A complete DC voltage is best for the coil power to make sure of stable relay operation. When using a power supply containing a ripple voltage, suppress the ripple factor within 5%. When power is supplied through a rectification circuit, the relay operating characteristics, such as pickup voltage and dropout voltage, depend on the ripple factor. Connect a smoothing capacitor for better operating characteristics as shown below.







Emax = Maximum of pulsating current Emin = Minimum of pulsating current Emean = DC mean value

#### 3. Leakage current while relay is off:


When driving an element at the same time as the relay operation, special consideration is needed for the circuit design. As shown in the incorrect circuit below, leakage current (lo) flows through the relay coil while the relay is off. Leakage current causes coil release failure or adversely affects the vibration resistance and shock resistance. Design a circuit as shown in the correct example.





4. Surge suppression for transistor driving circuits:

When the relay coil is turned off, a high-voltage pulse is generated, causing a transistor to deteriorate and sometimes to break. Be sure to connect a diode to suppress the back electromotive force. Then, the coil release time becomes slightly longer. To shorten the coil release time, connect a Zener diode between the collector and emitter of the transistor. Select a Zener diode with a Zener voltage slightly higher than the power voltage.




## **Protection for Relay Contacts**


- The contact ratings show maximum values. Make sure that these values are not exceeded. When an inrush current flows through the load, the contact may become welded. If this is the case, connect a contact protection circuit, such as a current limiting resistor.
- 2. Contact protection circuit:

**Operating Instructions** 

When switching an inductive load, arcing causes carbides to form on the contacts, resulting in increased contact resistance. In consideration of contact reliability, contact life, and noise suppression, use of a surge absorbing circuit is recommended. Note that the release time of the load becomes slightly longer. Check the operation using the actual load. Incorrect use of a contact protection circuit will adversely affect switching characteristics. Four typical examples of contact protection circuits are shown in the following table:



3. Do not use a contact protection circuit as shown below:



Generally, switching a DC inductive load is more difficult than switching a DC resistive load. Using an appropriate arc suppressor, however, will improve the switching characteristics of a DC inductive load.

#### **Soldering**

- 1. When soldering the relay terminals, use a soldering iron of 30 to 60W, and quickly complete soldering (within approximately 3 seconds).
- 2. Use a non-corrosive rosin flux.

## **Operating Instructions con't**

## **Other Precautions**

1. General notice:

To maintain the initial characteristics, do not drop or shock the relay.

The relay cover cannot be removed from the base during normal operation. To maintain the initial characteristics, do not remove the relay cover.

Use the relay in environments free from condensation, dust, sulfur dioxide (SO<sub>2</sub>), and hydrogen sulfide (H<sub>2</sub>S).

Make sure that the coil voltage does not exceed applicable coil voltage range.

- 2. UL and CSA ratings may differ from product rated values determined by IDEC.
- 3. Do not use relays in the vicinity of strong magnetic field, as this may affect relay operation.

## **Safety Precautions**

- Turn off the power to the relay before starting installation, removal, wiring, maintenance, and inspection of the relays. Failure to turn power off may cause electrical shock or fire hazard.
- Observe specifications and rated values, otherwise electrical shock or fire hazard may be caused.
- Use wires of the proper size to meet voltage and current requirements. Tighten the terminal screws on the relay socket to the proper tightening torque.
- Surge absorbing elements on AC relays with RC or DC relays with diode are
  provided to absorb the back electromotive force generated by the coil. When
  the relay is subject to an excessive external surge voltage, the surge absorbing element may be damaged. Add another surge absorbing provision to the
  relay to prevent damage.

## **Precautions for the RU Relays**

- Before operating the latching lever of the RU relay, turn off the power to the RU relay. After checking the circuit, return the latching lever to the original position.
- Do not use the latching lever as a switch. The durability of the latching lever is a minimum of 100 operations.
- When using DC loads on 4PDT relays, apply a positive voltage to terminals of neighboring poles and a negative voltage to the other terminals of neighboring poles to prevent the possibility of short circuits.
- DC relays with a diode have a polarity in the coil terminals. Apply the DC voltage to the correct terminals.

Canada: 888-317-IDEC