IMO

Accessories

Auxiliary Contacts		Description	Product
For use with MC10 to MC74			
Twin bifurcated for low level switching		1 make	**MCA10**
Rating	AC1 @ 690V 10A	1 break	**MCA01**
	AC15 @ 400V 2A – @ 230V 3A	Early make	**MCA10U**
Maximum of 4 per contactor		Late break	**MCA01U**
For use with K3–150 – K3–175 max 1 piece		1M 1B INSIDE	**HKS11**
For use with K3–150 – K3–175 max 2 pieces		1M 1B OUTSIDE	**HKS11A**
For use with K3–200 – K3-315 max 3 pieces		1M 1B	**HKD11**
For use with K3–450 – K3-700 max 1 piece		2M 2B	**HKF22**
Rating	AC1 @ 690V 10A		
	AC15 @ 400V 2A – @230V 3A		

Electronic Timer	Description	Product
For use with MC10 to MC74	Delay-on	
Delay timer with LED indicator	1-30 secs	**MCT-A30**
Repeat accuracy 1% – Recovery time 50mS	10-180 secs	**MCT-A180**
Rating AC15 0.75A @ 60V-0.15A @ 250V	30-600 secs	**MCT-A600**
	Delay-off	
Max. inrush 25A – min. switching 5mA	1-30 secs	**MCT-B30**
Delay-on supply 24–60V AC or DC – 100–250V AC or DC	10-180 secs	**MCT-B180**
Delay-off supply 24–60V AC, 100–120V AC or 200-250V AC	30-600 secs	**MCT-B600**

Indicator	Description	Product
For use with MC10 to MC74		
Current indicator	Green (LED)	**MC-ING**
24–660V AC or DC (voltage drop 2V)	Red (LED)	**MC-INR**
Voltage indicator		
220 – 415V AC or DC	White (Lamp)	**MC-UN**
24 – 120V AC or DC	Red (LED)	**MC-UNR**

Auxiliary Contacts	Description	Product
Interface Relay		
For use with MC10 to MC74		
Relay to interface with electronic circuits		**MC-IM 24V**
1 make contact rated 0.75A max 250V AC 30V DC		

Mechanical Interlock		
For use with MC10 to MC40		**MCI-W**
MC24 to MC74		**MCI-X**
K85A22 to K110A22		**LG8511**
K3–150A11 to K3–175A11		**LG10397H**
K3–200A11		**LG10398H**
K3–315A11 to K3–550A22		**LG10400H**
K3–700A22		**LG10402H**

Coil Suppressor			
For use with	MC10 to MC22	12–24V AC/DC	**MC-E24**
		24–48V AC/DC	**MC-E48**
		110–230V AC/DC	**MC-E220**
		250–415V AC/DC	**MC-E380**
	MC24 to MC74	12–24V AC/DC	**VG-MC/24**
		24–48V AC/DC	**VG-MC/48**
		110–230V AC/DC	**VG-MC/250**
		250–415V AC/DC	**VG-MC/415**

Overload Mounting			
For separate mounting of overloads			
For use with	U1216	With terminal	**U12SM**